

JVC

SERVICE MANUAL

DIGITAL *Hi-Fi* STEREO VIDEO CASSETTE RECORDER VHS

HR-D530E/EG

DIGITAL

HQ
High Quality



SPECIFICATIONS

Format	: VHS PAL standard with Hi-Fi audio	Output level	: AUDIO/VIDEO socket (21-pin Peri connector): -3.8 dBs (CENELEC standard), high impedance load AUDIO AUSG. connector (RCA x 2): -6 dBs, high impedance load
Video recording system	: Rotary two-head helical scan system with slant double-azimuth combination video heads	Output impedance	: Less than 1 k-ohm, unbalanced
Hi-Fi audio recording system	: Deep-layer recording system conforming to stereo Hi-Fi VHS standard	Signal-to-noise ratio	: More than 40 dB
No. of audio channels	: 2 Hi-Fi audio channels 1 normal audio channel	Frequency range	: 70 Hz to 10,000 Hz
Video signal system	: PAL colour and CCIR monochrome signals, 625 lines	Hi-Fi audio	
Tape width	: 12.65 mm	Frequency response	: 20 Hz - 20,000 Hz
Tape speed (SP)	: 23.39 mm/sec	Dynamic range	: More than 90 dB
(LP)	: 11.70 mm/sec	Wow and flutter	: Less than 0.005 % WRMS
Maximum recording time (SP)	: 240 min. with E-240 video cassette	TV tuner/RF section	
(LP)	: 480 min. with E-240 video cassette	Channel storage capacity	: 48 channels
Temperature		Aerial input	: VHF 47 - 89 MHz 104 - 300 MHz 302 - 470 MHz UHF 470 - 862 MHz
Operating	: 5°C to 40°C	Aerial output	: UHF channels 32 - 40 (Adjustable)
Storage	: -20°C to 60°C	Digital clock/timer	
Power requirement	: 220 V~, 50/60 Hz	Clock display	: 24-hour fluorescent digital display with day and date indication
Power consumption	: 41 W	Reference frequency	: Quartz controlled
Video		Start time setting	: Within one year
Input	: 0.5 to 2.0 Vp-p, 75 ohms, unbalanced	Programming capacity	: 8 programmes
Output	: 1.0 Vp-p, 75-ohms, unbalanced	Dimensions	: 435 mm(W) x 95 mm(H) x 339 mm(D)
Signal-to-noise ratio	: 43 dB (Rohde & Schwarz noise meter) with BILDSCHÄRFE control at centre position	Weight	: 8.3 kg
Horizontal resolution	: 250 lines with BILDSCHÄRFE control at centre position	Provided accessories	: Aerial cable, Infrared remote control, "R6"-size battery x 2, Audio cable (RCA-RCA)
Audio			
Input	: Mic: -67 dBs, high impedance, unbalanced AUDIO EING. connector (RCA x 2): -8 dBs, 50 k-ohms, unbalanced AUDIO/VIDEO socket (21-pin Peri connector): -3.8 dBs (CENELEC standard), 10 k-ohms, unbalanced		

*Specifications shown are for SP mode unless otherwise specified.
Design and specifications subject to change without notice.*

NOTE: For a technical description, please refer to Technical Guide VTG82013 HR-D530 PAL.

TABLE OF CONTENTS

Section	title	Page	Section	Page	Page
	Important Safety Precautions		3.36	TERMINAL SCHEMATIC DIAGRAM	3-40
	INSTRUCTIONS		3.37	TERMINAL CIRCUIT BOARD	3-41
1. MECHANISM ADJUSTMENT			3.38	POWER SUPPLY SCHEMATIC DIAGRAM	3-42
1.1	GENERAL	1-1	3.39	POWER TRANSFORMER, REGULATOR, FUSE AND POWER TRANSISTOR CIRCUIT BOARDS	3-43
1.2	MAIN ASSEMBLY REPLACEMENT	1-4	3.40	DIGITAL SCHEMATIC DIAGRAM	3-44
1.3	ASSEMBLY PROCEDURE OF MECHANISM	1-6	3.41	DIGITAL COLOR PROCESS SCHEMATIC DIAGRAM	3-45
1.4	CONFIRMATION AND ADJUSTMENT	1-8	3.42	DIGITAL AND DIGITAL COLOR PROCESS CIRCUIT BOARDS	3-45
1.5	TAPE TRANSPORT CHECKS AND ADJUSTMENT PREPARATIONS	1-9	3.43	APC SCHEMATIC DIAGRAM AND CIRCUIT BOARD	3-46
1.6	INTERCHANGEABILITY CHECKS AND ADJUSTMENTS	1-10	3.44	VPS (VIDEO PROGRAM SYSTEM) SCHEMATIC DIAGRAM AND CIRCUIT BOARD (EG ONLY)	3-47
			3.45	RF CONVERTER AND MIX BOOSTER SCHEMATIC DIAGRAM	3-48
2. ELECTRICAL ADJUSTMENTS			3.46	REMOTE CONTROL SCHEMATIC DIAGRAM ..	3-48
2.1	PREPARATION	2-1	4. EXPLODED VIEWS AND PARTS LIST		
2.2	REGULATOR CIRCUIT	2-3	4.1	STANDARD PART NUMBER CODING	4-1
2.3	SERVO CIRCUIT	2-3	4.2	CABINET ASSEMBLY <M2>	4-2
2.4	VIDEO CIRCUIT	2-4	4.3	CHASSIS ASSEMBLY <M3>	4-3
2.5	AUDIO CIRCUIT	2-8	4.4	MECHANISM ASSEMBLY (1) <M4>	4-4
2.6	FMA CIRCUIT	2-8		MECHANISM ASSEMBLY (2) <M4>	4-4
2.7	TIMER CIRCUIT	2-9	4.5	REMOTE CONTROL ASSEMBLY <M5>	4-6
2.8	TUNER/IF CIRCUIT	2-10	4.6	PACKING ASSEMBLY <M1>	4-7
2.9	VPS CIRCUIT (EG only)	2-11			
2.10	DEMODULATOR CIRCUIT	2-12	5. ELECTRICAL PARTS LIST		
3. CHARTS AND DIAGRAMS			5.1	STANDARD PART NUMBER CODING	5-2
3.1	CIRCUIT BOARD LOCATIONS	3-1		POWER SUPPLY BOARD ASSEMBLY <01><02>	5-6
3.2	GENERAL INFORMATIONS	3-2		MAIN BOARD ASSEMBLY <03><04>	5-6
3.3	ABBREVIATIONS USED IN THE SCHEMATIC DIAGRAM	3-3		MOTHER BOARD ASSEMBLY <05>	5-12
3.4	MAIN TYPES OF ACTIVE AND PACKAGE CIRCUITS	3-5		TERMINAL BOARD ASSEMBLY <06>	5-12
3.5	BOARD INTERCONNECTIONS	3-6		TUNER/IF BOARD ASSEMBLY <07>	5-13
3.6	POWER SYSTEM BLOCK DIAGRAM	3-7		SERVO BOARD ASSEMBLY <08>	5-15
3.7	SERVO BLOCK DIAGRAM	3-8		AUDIO BOARD ASSEMBLY <09>	5-16
3.8	FM AUDIO BLOCK DIAGRAM	3-9		AUDIO/CTL HEAD BOARD <12>	5-17
3.9	VIDEO BLOCK DIAGRAM	3-10		FMA BOARD ASSEMBLY <13>	5-17
3.10	MECHANISM CONTROL SCHEMATIC DIAGRAM	3-12		DEMODULATOR BOARD ASSEMBLY <14>	5-20
3.11	DECK TERMINAL SCHEMATIC DIAGRAMS	3-13		TIMER BOARD ASSEMBLY <15>	5-21
3.12	MECHANISM CONTROL AND SERVO CIRCUIT BOARDS	3-14		JUNCTION BOARD ASSEMBLY <16>	5-22
3.13	VIDEO SCHEMATIC DIAGRAM	3-16		VPS BOARD ASSEMBLY (EG ONLY) <18>	5-22
3.14	SERVO SCHEMATIC DIAGRAM	3-18		POWER TRANSISTOR BOARD ASSEMBLY <19>	5-23
3.15	VIDEO, VIDEO SUB (3) AND VIDEO SUB (1) CIRCUIT BOARDS	3-19		DIGITAL BOARD ASSEMBLY <20>	5-23
3.16	PRE/REC SCHEMATIC DIAGRAM	3-20		OPERATION BOARD ASSEMBLY <22>	5-24
3.17	PRE/REC AND UPPER DRUM CIRCUIT BOARDS	3-21		DISPLAY BOARD ASSEMBLY <27>	5-25
3.18	AUDIO SCHEMATIC DIAGRAM	3-22		SUB JUNCTION BOARD ASSEMBLY <38>	5-25
3.19	AUDIO AND A/CTL HEAD CIRCUIT BOARDS	3-23		CONTROL BOARD ASSEMBLY <39>	5-25
3.20	FM AUDIO (FMA) SCHEMATIC DIAGRAM	3-24		UPPER DRUM BOARD <41>	5-26
3.21	FM AUDIO CIRCUIT BOARD	3-25		PRE/REC AMP BOARD ASSEMBLY <43>	5-26
3.22	TUNER/IF SCHEMATIC DIAGRAM	3-26		DECK TERMINAL BOARD ASSEMBLY <51> , <53>	5-24
3.23	TUNER/IF CIRCUIT BOARD	3-27		RELAY BOARD ASSEMBLY <52>	5-27
3.24	DEMODULATOR SCHEMATIC DIAGRAM	3-28		RELAY BOARD ASSEMBLY <52>	5-27
3.25	DEMODULATOR CIRCUIT BOARD	3-29		END SENSOR BOARD ASSEMBLY <54>	5-27
3.26	DISPLAY SCHEMATIC DIAGRAM	3-30		CASSETTE HOUSING BOARD <56>	5-27
3.27	DISPLAY CIRCUIT BOARD	3-31		APC BOARD ASSEMBLY <61>	5-27
3.28	TIMER SCHEMATIC DIAGRAM	3-32		DIG. COL. PROCESS BOARD ASSEMBLY <62> ..	5-27
3.29	TIMER CIRCUIT BOARD	3-33		FUSE BOARD ASSEMBLY <65>	5-28
3.30	MOTHER SCHEMATIC DIAGRAM	3-34		REMOTE CONTROL BOARD ASSEMBLY <RM> ..	5-28
3.31	MOTHER CIRCUIT BOARD	3-35			
3.32	JUNCTION AND OPERATION SCHEMATIC DIAGRAMS	3-36			
3.33	JUNCTION AND OPERATION CIRCUIT BOARDS	3-37			
3.34	CONTROL AND SUB JUNCTION SCHEMATIC DIAGRAMS	3-38			
3.35	CONTROL AND SUB JUNCTION CIRCUIT BOARDS	3-39			

Important Safety Precautions

Prior to shipment from the factory, JVC products are strictly inspected to conform with the recognized product safety and electrical codes of the countries in which they are to be sold. However, in order to maintain such compliance, it is equally important to implement the following precautions when a set is being serviced.

● Precautions during Servicing

1. Locations requiring special caution are denoted by labels and inscriptions on the cabinet, chassis and certain parts of the product. When performing service, be sure to read and comply with these and other cautionary notices appearing in the operation and service manuals.

2. Parts identified by the \triangle symbol and shaded (▨) parts are critical for safety.

Replace only with specified part numbers.

Note: Parts in this category also include those specified to comply with X-ray emission standards for products using cathode ray tubes and those specified for compliance with various regulations regarding spurious radiation emission.

3. Fuse replacement caution notice.

Caution for continued protection against fire hazard.

Replace only with same type and rated fuse(s) as specified.

4. Use specified internal wiring. Note especially:

- 1) Wires covered with PVC tubing
- 2) Double insulated wires
- 3) High voltage leads

5. Use specified insulating materials for hazardous live parts. Note especially:

- | | | |
|--------------------|--------------------------------------|------------|
| 1) Insulation Tape | 3) Spacers | 5) Barrier |
| 2) PVC tubing | 4) Insulation sheets for transistors | |

6. When replacing AC primary side components (transformers, power cords, noise blocking capacitors, etc.) wrap ends of wires securely about the terminals before soldering.




Fig. 1

7. Observe that wires do not contact heat producing parts (heat-sinks, oxide metal film resistors, fusible resistors, etc.)

8. Check that replaced wires do not contact sharp edged or pointed parts.

9. When a power cord has been replaced, check that 10–15 kg of force in any direction will not loosen it.




Fig. 2

10. Also check areas surrounding repaired locations.

11. Products using cathode ray tubes (CRTs)

In regard to such products, the cathode ray tubes themselves, the high voltage circuits, and related circuits are specified for compliance with recognized codes pertaining to X-ray emission. Consequently, when servicing these products, replace the cathode ray tubes and other parts with only the specified parts. Under no circumstances attempt to modify these circuits. Unauthorized modification can increase the high voltage value and cause X-ray emission from the cathode ray tube.

12. Crimp type wire connector

In such cases as when replacing the power transformer in sets where the connections between the power cord and power transformer primary lead wires are performed using crimp type connectors, if replacing the connectors is unavoidable, in order to prevent safety hazards, perform carefully and precisely according to the following steps.

1) **Connector part number** : E03830-001

2) **Required tool** : Connector crimping tool of the proper type which will not damage insulated parts.

3) **Replacement procedure**

(1) Remove the old connector by cutting the wires at a point close to the connector.

Important : Do not reuse a connector (discard it).




Fig. 3

(2) Strip about 15 mm of the insulation from the ends of the wires. If the wires are stranded, twist the strands to avoid frayed conductors.




Fig. 4

(3) Align the lengths of the wires to be connected. Insert the wires fully into the connector.




Fig. 5

(4) As shown in Fig. 6, use the crimping tool to crimp the metal sleeve at the center position. Be sure to crimp fully to the complete closure of the tool.




Fig. 6

(5) Check the four points noted in Fig. 7.

Not easily pulled free Crimped at approx. center of metal sleeve




Fig. 7

● Safety Check after Servicing

Examine the area surrounding the repaired location for damage or deterioration. Observe that screws, parts and wires have been returned to original positions. Afterwards, perform the following tests and confirm the specified values in order to verify compliance with safety standards.

1. Insulation resistance test


Confirm the specified insulation resistance or greater between power cord plug prongs and externally exposed parts of the set (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.). See table 1 below.

2. Dielectric strength test

Confirm specified dielectric strength or greater between power cord plug prongs and exposed accessible parts of the set (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.). See table 1 below.

3. Clearance distance

When replacing primary circuit components, confirm specified clearance distance (d), (d') between soldered terminals, and between terminals and surrounding metallic parts. See table 1 below.




4. Leakage current test

Confirm specified or lower leakage current between earth ground/power cord plug prongs and externally exposed accessible parts (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.).

Measuring Method: (Power ON)

Insert load Z between earth ground/power cord plug prongs and externally exposed accessible parts. Use an AC voltmeter to measure across both terminals of load Z. See figure 9 and following table 2.




5. Grounding (Class I model only)

Confirm specified or lower grounding impedance between earth pin in AC inlet and externally exposed accessible parts (Video in, Video out, Audio in, Audio out or Fixing screw etc.).

Measuring Method:

Connect milli ohm meter between earth pin in AC inlet and exposed accessible parts. See figure 10 and grounding specifications.



Grounding Specifications

Region	Grounding Impedance (Z)
USA & Canada	$Z \leq 0.1 \text{ ohm}$
Europe & Australia	$Z \leq 0.5 \text{ ohm}$

AC Line Voltage	Region	Insulation Resistance (R)	Dielectric Strength	Clearance Distance (d), (d')
100 V	Japan	$R \geq 1 \text{ M}\Omega / 500 \text{ V DC}$	AC 1 kV 1 minute	$d, d' \geq 3 \text{ mm}$
100 to 240 V			AC 1.5 kV 1 minute	$d, d' \geq 4 \text{ mm}$
110 to 130 V	USA & Canada	—	AC 900 V 1 minute	$d, d' \geq 3.2 \text{ mm}$
110 to 130 V	Europe & Australia	$R \geq 10 \text{ M}\Omega / 500 \text{ V DC}$	AC 3 kV 1 minute (Class II)	$d \geq 4 \text{ mm}$
200 to 240 V			AC 1.5 kV 1 minute (Class I)	$d' \geq 8 \text{ mm}$ (Power cord) $d' \geq 6 \text{ mm}$ (Primary wire)

Table 1 Specifications for each region

AC Line Voltage	Region	Load Z	Leakage Current (i)	a, b, c
100 V	Japan		$i \leq 1 \text{ mA rms}$	Exposed accessible parts
110 to 130 V	USA & Canada		$i \leq 0.5 \text{ mA rms}$	Exposed accessible parts
110 to 130 V 220 to 240 V	Europe & Australia		$i \leq 0.7 \text{ mA peak}$ $i \leq 2 \text{ mA dc}$	Antenna earth terminals
			$i \leq 0.7 \text{ mA peak}$ $i \leq 2 \text{ mA dc}$	Other terminals

Table 2 Leakage current specifications for each region

Note: These tables are unofficial and for reference only. Be sure to confirm the precise values for your particular country and locality.

SECTION 1 MECHANISM ADJUSTMENT

1.1 GENERAL

1.1.1 Precautions

IMPORTANT:

1. Disconnect unit from power before removing or soldering components.
2. When removing a fastener (screw, washer, etc.), be careful not to drop it into the mechanism. If a fastener should be dropped, be sure to retrieve it.
3. The tape transport mechanism has been precisely adjusted at the factory and ordinarily does not require readjustment.
4. When removing a part, be very careful not to damage or displace other parts. (Be especially careful with the tape guides and rotary video head drum.)
5. For service procedures that call for operation of the set when the cassette housing is separated from the main-deck, perform as below.
 - 1) Remove the cassette housing from the main-deck.
 - 2) Disable the photo transistor sensor (END SENSOR) on the main-deck by applying an opaque cover.
 - 3) The desired modes can be obtained by using the operation switches.

1.1.2 Required test equipment, fixtures and tools

For proper mechanical adjustment, the following test equipment, fixtures and tools are strongly recommended. Without them, a long trial-and-error period would be necessary, resulting in possible damage. In addition, general-purpose tools are required.

1. Test equipment required:
 - Color television or monitor
 - Oscilloscope: Wide-band, dual trace, triggered, delayed sweep
 - Recording tape
 - Alignment tapes





<p>Alignment tape MH-2, MH-2L, MH-F2</p> 	<p>Torque gauge assembly PUJ48075-2</p> 	<p>Back tension cassette gauge PUJ48076-2</p> 
<p>A/CTL head position tool PUJ47351-2</p> 		

Table 1-1-1 Fixtures and tools

1.1.3 Disassembly

1. Top cover

- 1) Take out five screws from the right, left and rear sides of the set.
- 2) Shift the top cover a little to the rear direction, then remove it upwards.

2. Front panel

- 1) Remove the top cover.
- 2) Bend three portions (A) of the front panel upwards to disengage them from the chassis.
- 3) Then pull the front panel outwards.
- 4) Disengage three portions (B) of the front panel from the chassis, then remove the front panel.

3. Bottom cover

- 1) Remove the top cover.
- 2) Loosen the screws of the two feet, then pull out the feet from the chassis.
- 3) Take out four screws, then remove the bottom cover.

4. Cassette housing door

- 1) Pull the center of the cassette housing door to bend it out, then remove the cassette housing door. Use care regarding the torsion spring on the left.




Fig. 1-1-1 Removal of external covers

1.1.4 Layout of main parts




Fig. 1-1-2 Top view of main-deck




Fig. 1-1-3 Bottom view of main-deck




Fig. 1-1-4 Cassette housing

- | | | |
|-------------------------|-----------------------|----------------------|
| 1. Supply guide roller | 9. Take-up guide pole | 17. Impedance roller |
| 2. Supply slant pole | 10. Guide arm | 18. Full erase head |
| 3. Tension pole | 11. Capstan | 19. Cassette motor |
| 4. Upper drum | 12. Take-up reel disk | 20. Capstan motor |
| 5. Take-up slant pole | 13. Reel idler | 21. Reel motor |
| 6. Take-up guide roller | 14. Tension band | 22. Mode motor |
| 7. A/C head | 15. Supply reel disk | 23. Mode belt |
| 8. Pinch roller | 16. Lower drum | 24. Cassette belt |

1.2 MAIN ASSEMBLY REPLACEMENT




No.	Item	Adjustment parts	Operating mode	Description
1	Upper drum assembly -- Drum removal -- 			<p>Note: When installing the new upper drum, use care not to touch the video heads. If heads are soiled, clean with a soft, finely woven cotton cloth or chamois that has been moistened in alcohol.</p> <p>Hold lightly against the heads and turn the drum clockwise. By no means clean with a vertical stroke.</p> <ol style="list-style-type: none"> 1) Refer to Fig. 1-2-1. Take out screw (1) and remove the brush assembly. 2) Use a desoldering tool or desoldering braid to unsolder the upper drum board. 3) Take out two screws (2) and raise the upper drum to remove it together with the upper drum board. (If this drum is to be re-installed, use care not to touch or damage the heads.)
	-- Installation --			<ol style="list-style-type: none"> 1) Refer to Fig. 1-2-1. Align the black relay pin of the new upper drum with the white marking of the lower drum. 2) Reinsert screws (2) and tighten them in a balanced manner. 3) Reinstall and solder the upper drum board. 4) Clean the drum assemblies (see above note). 5) Reinstall the brush assembly and secure with screw (1).
	-- Checks and adjustments --			<p>After installing the upper drum, perform the following checks and adjustments (refer to appropriate Sections of this Manual).</p> <ol style="list-style-type: none"> 1) FM waveform 2) Servo circuit 3) Video circuit 4) FM audio circuit

Fig. 1-2-1 Upper drum assembly

No.	Item	Adjustment parts	Operating mode	Description
2	<p>A/C head (Audio/Control head)</p> <p>– A/C head removal –</p>			<ol style="list-style-type: none"> 1) Disengage connectors attached to the A/C head board. 2) Take out two screws (1) and remove the A/C head together with the head base. 3) Remove the A/C head board from the A/C head. 4) Take out screw (2) and remove the shield cap from the A/C head. 5) Take out three screws (3) and remove the A/C head from the head base. Use care regarding the three springs.
	<p>– Replacement –</p>			<ol style="list-style-type: none"> 1) Install the A/C head by reversing the steps of 1.2.2. 2) Temporarily set the A/C head height above the head base for 6.6 mm (see Fig. 1-2-3).
	<p>– Checks and adjustments –</p>			<ol style="list-style-type: none"> 1) Use a spare tape (not Alignment tape) and confirm proper operation of the tape transport (see Section 1.5). 2) Perform interchangeability adjustment (see Section 1.6).




No.	Item	Adjustment parts	Operating mode	Description
3	Tension band assembly			<p>1) Take out screw (1) and disengage the tension band assembly from the tension arm assembly (see Fig. 1-2-4).</p> <p>2) Remove and replace the tension band assembly.</p> <p>3) Perform tension pole position adjustment (see Section 1.4).</p>

Fig. 1-2-4 Tension band assembly

1.3 ASSEMBLY PROCEDURE OF MECHANISM

No.	Item	Adjustment parts	Operating mode	Description
1	<p>Loading arm assemblies</p> <p>Take-up loading arm assembly</p>  <p>Supply loading arm assembly</p> <p>Fig. 1-3-1 Loading arm assembly (1)</p> <p>Holes confront each other.</p>  <p>(Black)</p> <p>(White)</p> <p>(To take-up pole base)</p> <p>(To supply pole base)</p> <p>Take-up loading arm assembly</p> <p>Supply loading arm assembly</p> <p>Fig. 1-3-2 Loading arm assembly (2)</p>			<p>A close relationship exists between the mode select switch and the mechacon circuit. Therefore, the mode select switch and control arm engagement determines the overall mechanical operations of the levers, gears, rollers, etc. If these parts are not properly positioned, the video deck becomes stalled in the unloading or Stop mode.</p> <p>These assemblies are comprised of loading gears, torsion springs and loading arms.</p> <p>1) Refer to Fig. 1-3-1 and install the loading arm assemblies correctly.</p> <p>2) The take-up and supply loading arm positions with respect to the loading gear holes are indicated in Fig. 1-3-2. This configuration is important to allow shifting to the next operation.</p>

No.	Item	Adjustment parts	Operating mode	Description
2	Control cam			<p>1) Set the arm gear assembly on the cam bracket assembly so that the hole of the arm gear assembly overlaps the hole of the cam bracket assembly.</p> <p>2) Install the control cam on the cam bracket assembly so that the hole of the control cam overlaps the hole which is indicated in the step 1), as shown in Fig. 1-3-3. Do not turn the control cam from this position for the next step.</p>
3	Cam bracket assembly			<p>1) Push and hold the plate assembly so that the hole of the plate assembly overlaps the hole of the main-deck, as shown in Fig. 1-3-4.</p> <p>2) Then mount the cam bracket assembly.</p>
4	Mode switch position			<p>1) Engage the plate assembly and mode switch as shown in Fig. 1-3-5. Partially tighten screw (1) to where the switch can still be shifted for adjusting the position.</p> <p>2) Press the plate assembly toward the right to where the holes are overlapped as in Fig. 1-3-4. Insert a jeweler's screwdriver into the holes to keep them aligned.</p> <p>3) Shift the mode switch to align the V-notch as indicated in Fig. 1-3-5. Then tighten screw (1) to secure.</p> <p>4) Remove the jeweler's screwdriver, then reinstall and solder the circuit board.</p>




Fig. 1-3-3 Control cam




Fig. 1-3-4 Cam bracket assembly








Fig. 1-3-5 Mode switch

1.4 CONFIRMATION AND ADJUSTMENT



No.	Item	Adjustment parts	Operating mode	Description
1	Tension pole position	 <p data-bbox="227 922 588 952">Fig. 1-4-1 Tension pole position</p>		<ol style="list-style-type: none"> 1) Without a cassette tape, set for the Play mode (see Section 1.1). 2) Refer to Fig. 1-4-1. Slightly loosen screw (1). Adjust the tension band holder position for 0 mm (gentle contact) separation between the tension arm and cutout position. 3) Tighten screw (1) to secure the tension band holder. 4) Use the back tension cassette gauge and set for the Play mode. 5) Check for a scale reading between 25 and 75. 6) If outside this range, clean the tension band contacting portions of the supply reel disk with alcohol, or if necessary, replace the tension band assembly.
2	Take-up torque			<ol style="list-style-type: none"> 1) Without a cassette tape, set for the Play mode (see Section 1.1). 2) Set the torque gauge on the take-up reel disk. 3) Grasp the torque gauge lightly so that it rotates and read the value when the scale matches the indicator needle. Confirm a value between 45 and 155. 4) If outside this range, clean the rubber portion of the idler arm with alcohol, or if necessary, replace the idler arm assembly.

1.5 TAPE TRANSPORT CHECKS AND ADJUSTMENT PREPARATIONS

No.	Item	Adjustment parts	Operating mode	Description
<p>The tape transport system has been precision-adjusted at the factory and ordinarily does not require readjustment. However, adjustment may become necessary after long term usage or after replacing parts that affect the tape transport. The following steps mainly cover preparations for the interchangeability adjustments of Section 1.6.</p>				
1	Guide roller	<p>Turn with screw-driver.</p>  <p>Fig. 1-5-1 Guide roller</p>		<p>1) During interchangeability adjustments, the guide roller is turned with a flat-blade screwdriver to adjust its height and correct FM waveform linearity. Use a metric hex key (1.25 mm) to slightly loosen the setscrew at the base of the guide roller (see Fig. 1-5-1). Loosen the setscrew just sufficiently to allow the guide roller to be turned. If too loose, tape transport will be too unstable to permit correct adjustment.</p>
2	Impedance roller	<p>Turn with nut-driver.</p>  <p>Fig. 1-5-2 Impedance roller</p>		<p>1) This compensates for tape running stability between the cassette and head drum. After adjusting the supply guide roller, the impedance roller height is adjusted for smooth tape transport at the lower flange.</p> <p>2) Use a metric nutdriver (5.5 mm) to adjust by turning the upper nut (see Fig. 1-5-2). However, note that excess turning can disturb the FM waveform stability.</p>
3	A/C head (audio/control head)	<p>Turn this screw to obtain smooth tape travel.</p>  <p>Fig. 1-5-3 A/C head</p>		<p>1) After adjusting the take-up guide roller, adjust the A/C head inclination for smooth tape travel at the lower flange of the take-up guide pole. Refer to Fig. 1-5-3.</p>

1.6 INTERCHANGEABILITY CHECKS AND ADJUSTMENTS

No.	Item	Adjustment parts	Operating mode	Description
Before using costly Alignment tape, use a spare tape and confirm correct operation of the tape transport.				
1	FM waveform			
$\frac{b}{a} \cong 0.7, \frac{c}{a} \cong 0.5 \text{ and } \frac{d}{a} \cong 0.5$				
<p>Oscilloscope display</p> <p>Trigger point</p> <p>Ideal FM envelope</p>				
Fig. 1-6-1 FM envelope				
<p>Drum entrance</p> <p>Simulation</p> <p>(Incorrect) (Correct)</p>				
Fig. 1-6-2 Drum entrance				
<p>Drum exit</p> <p>Simulation</p> <p>(Incorrect) (Correct)</p>				
Fig. 1-6-3 Drum exit				
				<ol style="list-style-type: none"> 1) Connect oscilloscope to the FM OUT testpoint of the video playback circuit. Trigger the oscilloscope externally with the signal from the drum flipflop (D-FF or FF) testpoint. Set the trigger slope to minus (-). 2) Play the MH-2 Alignment tape and adjust the tracking for maximum FM waveform output. Refer to Fig. 1-6-1. Confirm the relationships indicated in the figure for maximum output (a), minimum center output (b), minimum output at the drum intake (c) and minimum output at the drum output (d). 3) Adjustment is required if the above specifications are not fulfilled. Even when these are fulfilled, check that the FM waveform varies linearly overall. If not, slight deviation in tracking will cause a large proportional level drop to result in noise appearing in the picture. Therefore, in this condition, proceed to the following checks and perform adjustments where necessary. 4) Operate the tracking adjustment between minimum and maximum outputs of the FM waveform. Observe the portion of the waveform corresponding to the drum intake (see Fig. 1-6-2). As the tracking is adjusted, although the gain may increase or decrease, the geometric shape of this part of the waveform should remain consistent. If the shape varies, as shown by the incorrect examples in the figure, carefully perform adjustment of the supply guide roller height. 5) Next observe the portion of the waveform corresponding to the drum output (see Fig. 1-6-3), while operating the tracking adjustment. This should also vary only in gain, but not in shape. If the shape varies, as shown by the incorrect examples in the figure, carefully perform adjustment of the take-up guide roller height. 6) Check the overall FM waveform. Fine-adjust both guide rollers so that variation is as minimum and linear as possible. 7) Observe the tape travel at the guide rollers and guide poles. Confirm absence of tape creasing or curling. Confirm that the tape properly rides at the lower flange of the supply guide pole. Carefully adjust the guide pole height if necessary. This adjustment is important and affects FM waveform response. If creasing or curling is observed at the take-up guide pole, carefully adjust the audio/control head inclination so that the tape rides properly at the lower flange of the guide pole. Finally, again check the FM waveform.

No.	Item	Adjustment parts	Operating mode	Description
2	A/C head adjustments	 <p>Fig. 1-6-4 A/C head</p>		<p>Proper adjustment of the A/C head position is important for ensuring adequate audio output and S/N. Severe misalignment can prevent control signal pick-up and cause servo instability. Precise adjustment is particularly important for models that include tape indexing and addressing features, since these rely on control signal coding for operation. To observe the audio signal, connect an oscilloscope to the test point (AUDIO OUT) of the audio circuit, or directly to the audio output terminal. In some cases, monitoring the sound with headphones may be helpful.</p> <ol style="list-style-type: none"> 1) Play the stairstep (audio 6 kHz) portion of the MH-2 Alignment tape. 2) Adjust screw (3) (Fig. 1-6-4), which is the azimuth adjustment, for maximum output. 3) Turn screws (1), (2) and (3) by small and equal increments (about 45° at a time) to adjust the A/C head height for maximum audio output. Slightly raise and lower the height to confirm the maximum output position. 4) Observe the FM waveform and tighten the guide roller set-screws. Use care not to disturb the height adjustments. Then again confirm the FM waveform.
3	Control head phase (X value)	 <p>Fig. 1-6-5 Control head phase</p>		<p>This determines the distance between the sound and picture information on the tape. Correct adjustment is important for providing synchronization of picture and sound in the program. Incorrect adjustment is particularly noticeable in the slow speed (LP) mode. Observe the FM waveform by connecting an oscilloscope to the video play-back circuit test point (FM OUT). Trigger the oscilloscope externally with the drum flipflop signal. Use plus (+) trigger to view the CH-2 waveform. Set the tracking adjustment to the neutral (AUTO) position.</p> <ol style="list-style-type: none"> 1) Play the stairstep portion of the MH-2 Alignment tape. 2) See Fig. 1-6-5. Slightly loosen screws (4) and (5). Set the A/C head positioning tool over screw (4) with the pin of the tool inserted into the indicated hole. 3) Turn the tool counterclockwise to shift the A/C head fully toward the capstan direction. 4) While observing the CH-2 FM waveform, gradually turn the tool clockwise. Stop at the peak output position and tighten screw (5). Remove the tool and tighten screw (4). 5) Replace alignment tape MH-2L with MH-2, play back the stairstep segment of the alignment tape MH-2L. 6) Operate the tracking adjustment and confirm that the maximum FM waveform is obtained at the neutral setting. 7) If the FM output peak is not obtained at tracking neutral position, shift the A/C head at the FM output peak nearest to this position.

No.	Item	Adjustment parts	Operating mode	Description
4	Final checks			<ol style="list-style-type: none"> 1) Supply a video or TV signal (monochrome is preferable). Use a spare tape and record and play back. Confirm that the play-back FM signal conforms to the parameters indicated in Fig. 1-6-1. Check for both SP and LP modes. 2) Connect the oscilloscope to the test point (FM OUT) of the FM audio play-back circuit. Play the stairstep portion (which includes the FM audio carrier) of the MH-F2 Alignment tape. Confirm absence of severe drop in FM waveform level. 3) Perform the checks and, if necessary adjustments, of the Electrical Adjustments Section for the servo, video and audio (and FM audio) circuits.

SECTION 2 ELECTRICAL ADJUSTMENTS


2.1 PREPARATION

Electrical adjustments are required after replacing circuit components and certain mechanical parts. It is important to perform these adjustments only after all repairs and replacements have been completed. Also, do not attempt these adjustments unless the proper equipment is available.

2.1.1 Required test equipment

1. Color television or monitor
2. Oscilloscope: wide-band, dual-trace, triggered delayed sweep
3. Frequency counter
4. Audio oscillator
5. Audio voltmeter
6. Digital voltmeter
7. Signal generator: RF/IF sweep/marker
8. Signal generator: PAL color bar
9. Recording tape
10. Alignment tapes: (MH-2, MH-F2)

11. Board extender (PTU93002D)



- TIMER, DEMODULATOR, DIGITAL, FMA, SERVO, MECHACON, REGULATOR BOARDS
- EXTRACTOR for boards




Fig. 2-1-1 Color bar signal of pattern generator




Fig. 2-1-2 Color bar signal waveform

White	Yellow	Cyan	Green	Magenta	Red	Blue
V	U	White 100%		Black		

Fig. 2-1-3 Color bar pattern

2.1.2 Check and adjustment steps

The check and adjustment steps are provided in the following in the form of charts. For clarity, the nomenclature used in the charts is outlined below.

No.	Checks and adjustments are numbered in the recommended sequence in which they are to be performed.
Item	Name assigned to the particular check and adjustment step.
Check Point	Location to which measuring instrument (oscilloscope unless otherwise noted) is to be connected.
Adjustment Parts	Variable component (resistor, capacitor, etc.) to be adjusted in this step. Dash (—) indicates check only.
Signal & Mode	<ul style="list-style-type: none"> • Input signal required to perform adjustment. Dash (—) indicates that special signal is not required. • Equipment operating mode at time of check or adjustment.
Color bar	Color bar signal as video input.
Stairstep	Stairstep signal as video input.
1 kHz	Supply a 1 kHz sinewave as audio input signal.
MH-2 Color bar	Play color bar segment of MH-2 alignment tape.
MH-2 Stairstep	Play stairstep segment of MH-2 alignment tape.
MH-2 1 kHz	Play 1 kHz audio signal segment of MH-2 alignment tape.
MH-2 RF sweep	Play RF sweep segment of MH-2 alignment tape.
Stop	Power on and machine in Stop mode.
REC	Recording mode
PB	Playback mode
REC ↓ (another mode)	Use blank tape, record, then play back in the mode specified.
Search	Search (FWDS and REVS) playback mode.
Slow	Slow motion playback mode.
Still	Playback then Pause.
A DUB	Audio dubbing mode.
Description	This column provides an explanation of the step, notes, adjustment values, and reference to waveforms where applicable.


2.2 REGULATOR CIRCUIT

Note: Unless otherwise specified, all test points and adjustments are located on the REGULATOR board.

No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description
1	5 V DC Output Voltage	TP1	R17	• REC	<ol style="list-style-type: none"> 1. Connect the digital voltmeter to TP1 and TP GND. 2. Adjust R17 for 5.33 ± 0.1 V at TP1.



2.3 SERVO CIRCUIT



Note: Unless otherwise specified, all test points and adjustments are located on the SERVO board.





No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description
1	PB Switching Point	VIDEO OUT or CN111-1	R24 (SP PB SW POINT)	<ul style="list-style-type: none"> • PB • MH-2 Stairstep • Trigger slope (←) • SP mode 	<ol style="list-style-type: none"> 1. Connect an oscilloscope to VIDEO OUT (or CN111-1 of the MAIN board). 2. Play back the stairstep segment of MH-2 alignment tape. 3. Trigger the oscilloscope externally (← slope) with the signal from TP11 SERVO board (DRUM FF). 4. Adjust R24 to position the trigger point 6.5 ± 0.5 H from V. sync.
 <p>Fig. 2-3-1</p>					
2	Slow Tracking Preset	Monitor	R72	<ul style="list-style-type: none"> • Slow PB • SP mode 	<ol style="list-style-type: none"> 1. Set the slow tracking control of the Front panel to the center detent position. 2. Record a color bar signal in the SP mode, then play back in the slow mode. 3. Adjust R72 to minimize noise bars in the monitor-TV display and confirm that the noise bar is not visible in the picture.
			R69	<ul style="list-style-type: none"> • Slow PB • LP mode 	<ol style="list-style-type: none"> 4. Repeat the above steps (1 to 2) for the LP mode. 5. Adjust R69 to minimize noise bars in the monitor-TV display and confirm that the noise bar becomes in the lower 1/3 of the picture.
3	X2 Tracking Preset	Monitor	R18	<ul style="list-style-type: none"> • PB X2 • SP mode 	<ol style="list-style-type: none"> 1. Set the tracking control of the Front panel to the center detent position. 2. Record a color bar signal in the SP mode, then play back in the PB X2 mode. 3. Adjust R18 to minimize noise bar in the monitor-TV display and confirm that the noise bar is not visible in the picture.
			R20	<ul style="list-style-type: none"> • PB X2 • LP mode 	<ol style="list-style-type: none"> 4. Repeat the above steps (1 to 2) for the LP mode. 5. Adjust R20 to minimize noise bar in the monitor-TV display and confirm that the noise bar is not visible in the picture.

2.4 VIDEO CIRCUIT

Note: Unless otherwise specified, all test points and adjustments are located on the MAIN board.

No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description	
1	Video Head Resonance & Q (Quality Factor)	TP5 PRE REC board	C5, R1 CH2 PRE REC board	<ul style="list-style-type: none"> • RF sweeper • PB • SP mode 	<p>Notes: 1. This adjustment is required only after replacing the upper drum (video heads). 2. Connect ground of probe (oscilloscope) to shield case of the PRE REC board.</p> <ol style="list-style-type: none"> 1. Set for the playback mode without a cassette tape. (Refer to mechanical adjustment 2.3.1.) 2. Connect an oscilloscope to TP5 of the PRE REC board. Supply a sweep generator output to TP1 of the PRE REC board, then adjust the sweep generator again so that the waveform does not distort at TP5. 3. Adjust C5 (Resonance) for 5 MHz peaking, and R1 (Quality Factor) so that the ratio between 1 MHz and 5 MHz level becomes 1 : 2 as shown in Fig. 2-4-1. 	
						 <p style="text-align: center;">a : b = 1 : 2</p> <p style="text-align: center;">Fig. 2-4-1</p>
		TP5 PRE REC board	C13, R3 CH1	<ul style="list-style-type: none"> • RF sweeper • PB • LP mode 	<ol style="list-style-type: none"> 6. Repeat the above steps (1 to 3) for the LP mode. Connect the sweep generator output to TP3 of the PRE REC board. 7. Adjust resonance with C13 and Q with R3 for CH1. 	
			C15, R4 CH2		<ol style="list-style-type: none"> 8. Similarly, perform adjustment in the same manner as CH1. Change the sweep generator output from TP3 to TP4 of the PRE REC board. 9. Adjust resonance with C15 and Q with R4. 	
		TP5 PRE REC board	C5, R1 CH2 ----- C7, R2 CH1 PRE REC board	<ul style="list-style-type: none"> • MH-2 (RF sweep) • SP mode • PB 	<ul style="list-style-type: none"> • Alternate method <ol style="list-style-type: none"> 1. Play back RF sweep segment of MH-2 alignment tape. Connect the oscilloscope to TP5 of the PRE REC board and trigger the oscilloscope externally with the signal from TP11 of the servo board. 2. Use (-) trigger for CH1 and (+) trigger for CH2. Adjust tracking control of the Front panel to the center detent position. 3. Turn R1 fully clockwise and R2 fully counterclockwise so as not to damp as viewed from the component side of the PRE REC board. 4. Adjust C5 and C7 to set the CH2 and CH1 resonance point to 5.0 MHz. Use the control of the oscilloscope to position the 4 MHz region at graduation 3 (0 dB) of the oscilloscope scale. 5. Adjust R1 to position the 5 MHz portion at 2.4 (1 dB) of the oscilloscope graduations as shown in Fig. 2-4-2. 6. In the same manner, adjust R2 for CH2. 7. If the CH1 and CH2 levels differ, adjust the higher level channel to match the lower with R1 and R2. 	
					 <p style="text-align: center;">A : B = 3 : 2.4</p> <p style="text-align: center;">Fig. 2-4-2</p>	

No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description
		TP5 PRE REC board	C13, R3 CH1 ----- C15, R4 CH2 PRE REC board	•MH-2 (RF sweep) •LP mode •PB	8. Short TP4 of the servo board to ground for LP mode. Similarly, perform adjustment in the same as SP mode. 9. Adjust resonance with C13 and Q with R3 for CH1. 10. Adjust resonance with C15 and Q with R4 for CH2. 11. If the CH1 and CH2 levels differ, adjust the higher level channel to match the lower with R3 and R4.
2	REC FM Level	TP3 PRE REC board	R119	•Color bar •REC •LP mode	1. Connect an oscilloscope to TP3 of the PRE REC board. Supply a color bar signal to VIDEO IN and set for the REC mode. 2. Adjust R119 for 1.05 Vp-p between centers of the waveform portions indicated in Fig. 2-4-3.
					
Fig. 2-4-3					
3	VXO	TP306	R328	•PB •MH-2 Color bar •SP mode	1. Connect a frequency counter to TP306. 2. Play back the color bar segment of MH-2 alignment tape. 3. Adjust R328 for 4.433619 MHz \pm 50 Hz.
4	REC Color Level	TP304	R322	•PB •MH-2 (Color bar) •SP mode ----- •REC then PB •Color bar •SP mode	1. Connect an oscilloscope to TP304. Play back a color bar segment of the MH-2 and observe color signal level. 2. Adjust the Tracking control of the Front panel for maximum level of the color waveform and make a note of the higher color level. 3. Set the Tracking control to the center detent position. 4. Record and play back a color bar signal. If necessary, before recording, adjust R322 so that the higher level channel becomes 75 to 85 % of the noted level during playback. At this time, confirm that the channel difference is within 3 dB.
					
Fig. 2-4-4					
		TP304	R438	•PB mode •MH-2 (Color bar) •LP mode ----- •REC then PB •Color bar •LP mode	Note: Perform the LP mode adjustment after completing the SP mode. 5. Short TP4 of the servo board to ground and repeat the above steps (1 to 3) for the LP mode. 6. Record and play back a color bar signal. If necessary, before recording, adjust R438 so that the higher level channel becomes 75 to 85 % of the noted level during playback. At this time, confirm that the channel difference is within 3 dB.

No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description
5	1 H Delayed Color Level	TP405	R401	<ul style="list-style-type: none"> • PB mode • MH-2 (Color bar) • SP mode 	<ol style="list-style-type: none"> 1. Connect an oscilloscope to TP405. Play back the color bar segment of MH-2 alignment tape and make a note of the color level. 2. Short TP434, TP435 to ground. Adjust R401 so that the color level becomes equal of the noted color level.
 <p data-bbox="467 645 577 678">Fig. 2-4-5</p>					
6	0.5 H Delayed Color Level	VIDEO OUT or CN111-1	R223	<ul style="list-style-type: none"> • REC then PB • Color bar • LP mode 	<ol style="list-style-type: none"> 1. Connect an oscilloscope to VIDEO OUT or CN111-1 and set the time base of the oscilloscope to 2 ms/div. Trigger the oscilloscope externally (– slope) with the signal from TP11 (DRUM FF). 2. During Search, adjust R223 so that the Y level difference is uniform at VIDEO OUT as shown in Fig. 2-4-6.
 <p data-bbox="467 1176 577 1209">Fig. 2-4-6</p>					
7	APC Error Phase	TP405	L401	<ul style="list-style-type: none"> • PB mode • MH-2 Color bar • SP mode 	<ol style="list-style-type: none"> 1. Connect a jump wire between TP436 and GND. 2. Connect one channel of a dual trace oscilloscope to TP405 and the other channel to TP433 and observe the waveforms. 3. Adjust L401 to position the zero-cross 30 μsec ± 3 μsec from the center of the burst signal as shown in Fig. 2-4-7.
 <p data-bbox="467 1657 577 1691">Fig. 2-4-7</p>					
8	0.5 H Delayed Jump Det.	TP432	R418	<ul style="list-style-type: none"> • EE mode • No signal 	<ol style="list-style-type: none"> 1. Use Jig circuit as shown in Fig. 2-4-8 and connect the Jig circuit to TP SW5, GND and TP431 (Vcc/2 V). 2. Connect a frequency counter to TP432. Adjust R418 for 30 ± 0.2 kHz at TP432.
 <p data-bbox="467 2004 577 2038">Fig. 2-4-8</p>					

No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description
9	SP PB Frequency & CH Balance	VIDEO OUT or CN111-1	R110	<ul style="list-style-type: none"> • REC then PB • Video sweep • SP mode 	<ol style="list-style-type: none"> 1. Terminate VIDEO OUT at 75 Ω and set the sharpness control of the Front panel to the center detent position. Connect a video sweep generator to VIDEO IN. 2. Record and play back a video sweep signal in the SP mode. Use the control of the oscilloscope to position the 100 kHz region at graduation 3 (0 dB) of the oscilloscope scale. 3. Adjust R110 to position the 2 MHz of CH1 portion at 2.4 ~ 3.0 (-1 ± 1 dB) of the oscilloscope graduations as shown in Fig. 2-4-9. 4. Confirm that the channel difference is within 2 dB.
				<p style="text-align: center;">Fig. 2-4-9</p>	<ul style="list-style-type: none"> • REC then PB • TV broadcast • SP mode
10	LP PB Frequency & CH Balance	VIDEO OUT or CN111-1	R202	<ul style="list-style-type: none"> • REC then PB • Video sweep • LP mode 	<ol style="list-style-type: none"> 1. Repeat the above steps for LP mode. Adjust R202 for -5 ± 1 dB (1.5 ~ 1.7 scale).
			PRE REC board	<ul style="list-style-type: none"> • REC then PB • TV broadcast • LP mode 	<ul style="list-style-type: none"> • Alternate method 1. Repeat the above steps for LP mode. Adjust R202 for distinct facial features on the monitor. <p>Note: R202 nearly at the center position.</p>
11	SECAM DET.	TP310	L351 R355	<ul style="list-style-type: none"> • SECAM • Color bar • E-E • SP mode • REC then PB 	<ol style="list-style-type: none"> 1. Connect an oscilloscope to TP310. Record and play back a SECAM color bar and adjust R355 (SECAM DET) to obtain 6 ± 0.5 Vp-p. 2. Adjust L351 (1/2 Fh TUNING) so that the transition step becomes at the center of "A" and "B" as shown in Fig. 2-4-10.
<p style="text-align: center;">Set this point to center position between points "A" and "B".</p> <p style="text-align: center;">V = more than 4 Vp-p in REC V = 6.0 ± 0.5 Vp-p in PB</p> <p style="text-align: center;">Fig. 2-4-10</p>					

2.5 AUDIO CIRCUIT

Note: Unless otherwise noted, all test points and adjustments are located on the AUDIO board.

No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description
1	Bias Level	TP31 TP32	R20	<ul style="list-style-type: none"> • REC • SP mode • TV PR button: AUX • AUDIO OUT: NORM 	<ol style="list-style-type: none"> 1. Connect a millivoltmeter between TP32 and TP31. Set for REC mode without signal (VIDEO and AUDIO). Adjust R20 for 3.0 ± 0.2 mVrms.
2	PB Level	AUDIO OUT	R5	<ul style="list-style-type: none"> • SP or LP mode • REC then PB 1 kHz, -8 dBs • TV PR button: AUX • AUDIO OUT: NORM 	<ol style="list-style-type: none"> 1. Supply an audio signal (-8 dBs/1 kHz at A/V connector to both channels of AUDIO IN and record and play back an audio signal together with a video signal. 2. Adjust R5 so that the audio output level during playback becomes -6 ± 2 dBs.

2.6 FMA CIRCUIT

Note: 1. Unless otherwise specified, all test points and adjustments are located on the FMA board.
2. Set the AUDIO LIMITER SW to ON position to obtain -6 dBs ± 0.5 dBs at AUDIO OUT.

No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description
1	E-E Level 1	AUDIO OUT	R5 (CH1/L) ----- R6 (CH2/R)	<ul style="list-style-type: none"> • TV PR button: AUX • Limiter SW to ON • AUDIO OUT to Hi-Fi • E-E 	<ol style="list-style-type: none"> 1. Set the TV PROGRAM button switch to the AUX position. Supply a 1 kHz, -8 dBs audio signal via A/V CONN. (both channels). 2. Set the AUDIO LIMITER SW to ON position. In the STOP (E-E) mode, adjust R5 to obtain -6 ± 0.5 dBs at AUDIO OUT. 3. In the same manner, adjust R6 for the R (CH2) channel.
2	E-E Level 2	AUDIO OUT	R33 (CH1/L) ----- R34 (CH2/R)	<ul style="list-style-type: none"> • TV PR button: AUX • Limiter SW to OFF • E-E (STOP) • AUDIO OUT monitor to Hi-Fi 	<ol style="list-style-type: none"> 1. Set the TV PROGRAM button switch to the AUX position. Supply a 1 kHz, -8 dBs audio signal via A/V CONN. (both channels). 2. Set the AUDIO LIMITER switch to OFF. Set the Hi-Fi recording level control to the center position. In the STOP (E-E) mode, adjust R33 to obtain -6 ± 0.5 dBs at AUDIO OUT. 3. In the same manner, adjust R34 for the R (CH2) channel.
3	REC FM Level	TP201	R218	<ul style="list-style-type: none"> • TV PR button: AUX • Without Audio signal • SP REC mode • AUDIO OUT: Hi-Fi 	<p>Note: Perform the FMA REC FM Level adjustment after completing the VIDEO REC FM Level adjustment (Section 2.4, No. 2).</p> <ol style="list-style-type: none"> 1. Without supplying input signal, set the TV PROGRAM button switch to the AUX position. 2. In the SP REC mode, adjust R218 for 400 ± 20 mVp-p FM waveform envelope at TP201.

No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description
4	PB Level	AUDIO OUT	R259 (CH1/L) ----- R250 (CH2/R)	<ul style="list-style-type: none"> •PB •MH-F2 •1 kHz \pm 50 kHz deviation •AUDIO OUT to Hi-Fi 	<ol style="list-style-type: none"> 1. Play back the 1 kHz \pm 50 kHz deviation segment of the MH-F2 alignment tape. 2. Adjust R259 to obtain -9 ± 0.5 dBs during playback at AUDIO OUT. ----- 3. In the same manner, adjust R250 for the R(CH2) channel.
5	Level Indicator	FDP (Level Ind.)	R29 (Indicator CH1/L) ----- R30 (Indicator CH2/R)	<ul style="list-style-type: none"> •AUX •AUDIO OUT to Hi-Fi •Limiter SW to OFF 	<p>Note: Perform the level indicator adjustment after completing the E-E level adjustment (section 2.6, No. 1, 2).</p> <ol style="list-style-type: none"> 1. Set the TV PROGRAM button switch to the AUX position. Supply a 1 kHz, -8 dBs audio signal via A/V CONN. (both channels). 2. Set Hi-Fi REC controls to obtain -6 ± 0.5 dBs at AUDIO OUT. In the E-E (STOP) mode, adjust R29 to where the FDP level indicators show 0 dB (all white LEDs light). ----- 3. In the same manner, adjust R30 for the R(CH2) channel.

2.7 TIMER CIRCUIT

Note: Unless otherwise specified, all test points and adjustments are located on the TIMER board.

No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description
1	Timer Clock	TP2	C101	•E-E	<ol style="list-style-type: none"> 1. Connect the frequency counter to TP2 (OSC OUT) and TP3 (GND). 2. Short GND and TP1 (TEST). Then short the leads of electrolytic capacitor C7 once in order to reset IC101. 3. Adjust C101 for 488.2813 ± 0.005 μsec (or, 2048.000 Hz \pm 0.002 Hz). <p>Note: Resetting IC1 while TP1 and GND are shorted provides the TEST mode.</p>

2.8 DIGITAL COLOR PROCESS CIRCUIT

Note: Unless otherwise specified, all test points and adjustments are located on the DIGITAL COLOR PROCESS board.


No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description
1	Digital Color Level	TP1 (Digital Color process board)	R14	<ul style="list-style-type: none"> •E-E •TV channel button (0) : AUX 	<ol style="list-style-type: none"> 1. Set the TV channel button switch (0) to the AUX position. Supply a color bar signal to VIDEO IN via A/V CONN. and set for the DIGITAL MEMORY mode by remote controller. 2. Connect an oscilloscope to TP1 and TP GND of the digital color process board. Adjust R14 for the same and stable color level between frames.

2.8 TUNER/IF CIRCUIT

Note: Unless otherwise specified, all test points and adjustments are located on the TUNER/IF board.

No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description
<p>Equipment required:</p> <ol style="list-style-type: none"> Oscilloscope IF sweep signal generator with suitable markers (PIF, SIF, etc.) Sweeper probe (sweep signal supply cable) as shown below. 					
				<p style="text-align: center;">Fig. 2-8-1</p>	
1	VCO	IC1 - 28	T2 (VCO)	<ul style="list-style-type: none"> Sweep generator out: 70 dBμ (38.9 MHz) Tuner mode without antenna IN 	<ol style="list-style-type: none"> Use a sweeper probe as shown in Fig. 2-8-1 and connect the sweep generator output to pin 1 of SAW 1. Adjust the sweep gain so that the waveform does not distort as observed with the oscilloscope. Connect the oscilloscope to pin 28 of IC1 (VIDEO DET OUT) and adjust T2 to align the waveform with the frequency marker as shown in Fig. 2-8-2.
		<p style="text-align: center;">Fig. 2-8-2</p>			
2	IF Adj.	IC1 - 28	IF Core in Front end	<ul style="list-style-type: none"> Sweep generator out: 70 dBμ (38.15 MHz) Tuner mode without antenna IN 	<ol style="list-style-type: none"> Use a sweeper probe as shown in Fig. 2-8-1 and connect the sweep generator output to TP of the Front end (TUNER). Connect the oscilloscope to pin 28 of IC1. Adjust IF core of the Front end so that the 38.15 MHz marker becomes maximum level.
3	FTZ Trap	IC1 - 28	T1	<ul style="list-style-type: none"> Sweep generator out: 70 dBμ (32.4 MHz) Tuner mode without antenna IN 	<ol style="list-style-type: none"> Use a sweeper probe as shown in Fig. 2-8-1. 32.4 MHz signal that is modulated (Amplitude Modulation) at 400 Hz is supplied to Front TP of U/V Tuner (Front end). Connect the oscilloscope to pin 28 of IC1. Adjust T1 for minimum level.
<p>• Before the following adjustments:</p> <ol style="list-style-type: none"> Connect a cable to ANT IN and terminate TV OUT at 75 Ω. Set a TV channel signal generator as follows. <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 5px auto;"> <p>Video : 65 dBμ/75 Ω, color bar 87.5% modulation Audio : 55 dBμ/75 Ω, 1 kHz \pm 50 kHz deviation</p> </div>					
4	RF AGC	IF terminal of Front end	R11	<ul style="list-style-type: none"> TV signal Tuner mode 	<ol style="list-style-type: none"> Connect the oscilloscope to IF terminal of U/V Tuner (Front end). Adjust R11 for maximum level, then again adjust R11 for -5 dB again.
5	VPS Y Level	CN3 - 1 (E) CN4 - 1 (EG)	R16	<ul style="list-style-type: none"> TV signal TV mode 	<ol style="list-style-type: none"> Connect the oscilloscope to pin 1 of CN3. Adjust R16 to obtain a Y level (including SYNC) of 2.0 Vp-p at CN3 - 1 (or CN4 - 1).

No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description
6	Color Level	CN2 - 3 (VIDEO OUT)	R42	TV signal Tuner mode Color bar	1. Receiving a color bar signal. Set the Y level for 100% reference signal and then adjust R42 for a magenta level of 48% at pin 3 of CN2.



B: magenta A:B = 1:0.48

Fig. 2-8-3

2.9 VPS CIRCUIT (EG only)

Note: Unless otherwise specified, all test points and adjustments are located on the VPS board.

No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description
1	Oscillator or adjustment	TP6	T1	Tuner mode	1. Observe the TP6 waveform on the oscilloscope. 2. Adjust the inner core of coil T1 so that maximum (peak) appears as shown by ① in the figure.




Fig. 2-9-1

2	Duty check (TP2 and TP3 waveforms)	TP2 TP3	—	Tuner mode	1. Connect the oscilloscope to TP2 and TP3. 2. Refer to the figure and check that a : b = 200 ± 10 (nsec) : 200 ± 10 (nsec) A : B = 400 ± 20 (nsec) : 400 ± 20 (nsec) The start pulse is positioned ahead of the data and is 600 nsec only at this point.
---	------------------------------------	------------	---	------------	---




Fig. 2-9-2

3	Timing adjust	TP2	T1	Tuner mode	1. On the same situation as above. 2. Adjust T1 so that time between data rise and clock rise (② in figure 2-9-2) is 80 ± 5 nsec.
---	---------------	-----	----	------------	--

2.10 DEMODULATOR CIRCUIT


Note: Unless otherwise specified, all test points and adjustments are located on the DEMODULATOR board.

Audio Multiplex TV Signal Generator

Recommended Specifications

1. Signal Format	Based on CCIR-B	9. Sound Modulation Modes	S ₁	S ₂
2. Frequency		Mono	Mono 1	Mono 2
Video Carrier F _v	38.9 MHz	Stereo	(L + R)/2	R
1st Sound Carrier f _{s1}	33.4 MHz	Dual	Mono 1	Mono 2
2nd Sound Carrier f _{s2}	33.1578125 MHz	10. Functions	S ₁	S ₂
3. Modulator		Mono (M)	100%	100%
Video	Crosshatch (black on white) V: 50 Hz, H: 15.625 kHz	Stereo (L, R)	(L + R)/2	R
Audio	Sinewave 1 kHz; CH1 and CH-2 outputs switchable	(L)	L/2	—
4. Output	97 dB/μV (open) ± 2 dB fixed, BNC-R 75 Ω	(R)	R/2	R
5. P-S Ratio	S ₁ P - 13 dB ± 2 fixed S ₂ P - 20 dB ± 2 fixed	(OFF)	—	—
6. Modulation		Mult (S ₁ , S ₂)	100%	100%
Video	87.5% ± 3%	(S ₁)	100%	0
Audio	±30 kHz ± 2 kHz	(S ₂)	0	100%
7. Stereo Separation	Less than -40 dB	(OFF)	0	0
8. Pilot Signal		V. MOD (ON/OFF)		
Carrier Frequency	54.6875 kHz ± 5 Hz synchro- nized type	11. Frequency Accuracy	Within ±5 × 10 ⁻⁵	
Stereo	117.5 Hz AM 50%	12. Spurious	Less than -50 dB	
Dual	274.1 Hz AM 50%	13. Saw Filter	Self-contained	


No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description
<p>Equipment required:</p> <ol style="list-style-type: none"> Oscilloscope IF sweep signal generator with suitable markers (PIF, SIF, etc.) Sweeper probe (sweep signal supply) as shown below. 					
<p style="text-align: center;">Fig. 2-10-1</p>					
1	VCO	IC1 - 28	T4	<ul style="list-style-type: none"> Sweep generator out: 70 dBμ (38.9 MHz) Tuner mode 	<ol style="list-style-type: none"> Use sweeper probe as shown in Fig. 2-10-1 and connect the sweep generator output to pin 1 of SAW 1. Adjust the sweep gain so that the waveform does not distort as observed with the oscilloscope. Connect the oscilloscope to pin 28 of IC1 (VIDEO DET OUT) and adjust T4 to align the waveform with the 38.9 MHz marker as shown in Fig. 2-10-2.
<p style="text-align: center;">Fig. 2-10-2</p>					

No.	Item	Check Point	Adjustment Parts	Signal & Mode	Description
<p>• Before the following adjustments:</p> <ol style="list-style-type: none"> 1. Connect a cable to ANT IN and terminate TV OUT at 75 Ω. 2. Set a TV channel signal generator as follows. <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>Video : 70 dBμ/75 Ω, color bar 87.5% modulation Audio : S1 (L); 57 dBμ/75 Ω, S2 (R); 50 dBμ/75 Ω, 1 kHz \pm 30 kHz deviation</p> </div>					
2	Sound Det.	IC2 - 3	T3 (SOUND 1 DET)	• Tuner mode	1. Set the signal generator mode to dual (L) 1 kHz 100% and (R) unmodulated, connect a distortion meter to IC2 pin 3. Adjust T3 for minimum distortion.
		IC2 - 2	T5 (SOUND 2 DET)	• Tuner mode	2. Set the signal generator mode to dual (R) 1 kHz 100% and (L) unmodulated, connect a distortion meter to IC2 pin 2. Adjust T5 for minimum distortion.
3	Stereo Separation	IC2 - 5	R31	• Tuner mode	1. Set the signal generator mode to stereo (R) 1 kHz 100%, connect an oscilloscope to IC2 pin 5. Adjust R31 for minimum level.
4	Buzz Adj.	CN2 - 4	T4	• Tuner mode	<p>Note: Perform items 1 (VCO) and 4 (BUZZ) mutually.</p> <p>1. Set the signal generator mode to (L), (R) unmodulated, connect the oscilloscope to CN2 pin 4. Carefully adjust T4 to minimize pulse-type noise as shown in Fig. 2-10-3.</p>
 <p>Fig. 2-10-3</p>					
5	Stereo Output Level	CN2 - 4 (L)	R57 (L)	• Tuner mode	1. Set the signal generator mode to stereo (L) 1 kHz 100% and (R) unmodulated, connect a level meter to CN2 - 4. Adjust R57 for -17 ± 0.5 dBs.
		CN2 - 2 (R)	R62 (R)	• Tuner mode	2. Similarly, with the L channel unmodulated, provide 1 kHz 100% modulation on the R channel. Adjust R62 for -17 ± 0.5 dBs.

SECTION 3 CHARTS AND DIAGRAMS

3.1 CIRCUIT BOARD LOCATIONS

No.	PWB NAME
01	POWER TRANSFORMER
02	REGULATOR
03	MAIN (VIDEO)
04	MAIN (MECHACON)
05	MOTHER
06	TERMINAL
07	TUNER/IF
08	SERVO
09	AUDIO
12	A/CTL HEAD
13	FM AUDIO
14	DEMODULATOR
15	TIMER
16	JUNCTION
18	VPS (EG ONLY)
19	POWER TRANSISTOR
20	DIGITAL
22	OPERATION
27	DISPLAY
38	SUB JUNCTION
39	CONTROL
41	UPPER DRUM
42	CONNECT
43	PRE/REC AMP
51	DECK TERMINAL
52	RELAY
53	REC SAFETY
54	END SENSOR
56	CASSETTE HOUSING
58	DRUM MOTOR
61	APC
62	DIGITAL COLOUR PROCESS
65	FUSE



3.2 GENERAL INFORMATIONS

3.2.1 Connections

Note:
Unless otherwise specified, only signal input flow is indicated.
Connection arrows indicate only signal outputs.



: Connector



: Direct connection



: Board in connector



: Connected pattern in the board.
Abbreviations



V : Video M : Mechacon




S : Servo A : Audio



VS : Signal flow from video to servo.

3.2.2 Indications

AUX : Active only at high.
 $\overline{\text{AUX}}$: Active only at low.
 $\overline{\text{AUX}}$: Active only at middle.
 $\overline{\text{AUX}}$: Active only at open.



3.2.3 Digital transistor




DTA114T
T mark only

Note:
The digital transistor includes built in resistors.
It features small size and high reliability.
Both PNP and NPN types are available.

Uses:
Inverter, Interface, driver circuits.

3.2.4 Signal flow in the schematic



3.2.5 Schematic diagram values

Unless otherwise specified.

- All resistance values are in ohms, 1/6 W, 1/8 W, (refer to parts list).
- All capacitance values are in μF , (P; PF).
- All inductance values are in μH , (m; mH).
- All diodes are 1SS133 or MA165, (refer to parts list).
- Voltages are DC-measured (reference to ground) with a digital voltmeter during recording (SP mode) and playback (SP mode) with alignment tape. Where voltages differ between recording and playback, the voltage during playback is shown in parentheses.
- Waveforms (VIDEO System) are measured (reference to ground) with a color bar during recording (SP mode) and playback (SP mode) with alignment tape.
- Waveforms (AUDIO System) are measured (reference to ground) with 1 kHz (-3.8 dBs at A/V connector) during recording and playback with alignment tape (1 kHz).
- Shaded (■) parts are critical for safety.
Replace only with specified parts numbers.

3.3 ABBREVIATIONS USED IN THE SCHEMATIC DIAGRAM

A	AC	: Alternating Current
	ACC	: Automatic Color Control
	ACCEL	: Acceleration
	A/CTL	: Audio/Control
	ADC	: Analog to Digital Converter
	ADD	: Adder
	ADRS	: Address
	ADJ	: Adjustment
	A DUB	: Audio Dubbing
	AE	: Audio Erase
	AEF	: Automatic Editing Function
	AFC	: Automatic Frequency Control
	AFT	: Automatic Fine Tuning
	AGC	: Automatic Gain Control
	AH	: Audio Head
	AL	: After Loading
	ALC	: Automatic Light Compensation Automatic Level Control
	AM	: Amplitude Modulation
	AMP	: Amplifier
	ANT	: Antenna
	APC	: Automatic Pedestal Control Automatic Phase Control
	APL	: Average Picture Level
	A/S/M	: Audio/Servo/Mechacon
	ASS'Y	: Assembly
	ATT	: Attenuator
	AUD	: Audio
	AUTO	: Automatic
	AUX	: Auxiliary

B	B	: Base
	BAL	: Balance
	BATT	: Battery
	BFP	: Burst Flag Pulse
	BIT	: Binary Digit
	BLK	: Black, Blanking
	BLU	: Blue
	BILING	: Bilingual
	BPF	: Bandpass Filter
	BRK	: Brake
	BRN	: Brown
	BT	: Band Tuning
	BUFF	: Buffer
	BW or B/W	: Black and White

C	C	: Capacitance, Collector, Color
	CAP	: Capstan, Capacitor
	CAR	: Carrier
	CARR	: Carrier
	CASS	: Cassette
	CCD	: Charge Coupled Device
	CCT	: Circuit
	CD	: Count Down
	CE	: Chip Enable
	CF	: Ceramic Filter
	CH	: Channel
	CHG	: Charge
	CHROMA	: Chrominance
	CLK	: Clock
	CLR	: Clear
	CMD	: Command
	CNT	: Count, Counter
	COL	: Color
	COM	: Common
	COMB	: Combination Comb Filter
	COMP	: Comparator Composite Compensation
	CONN	: Connector
	CONV	: Converter
	CP	: Circuit Protector Clamp Pulse
	CPC	: Capstan Phase Control
	CTL	: Control

D	D	: Drum, Digital, Diode, Drain
	DAC	: Digital to Analog Converter
	dB	: Decibel
	DC	: Direct Current
	DEC	: Decoder
	DEMODO	: Demodulator
	DEMUX	: Demultiplexer
	DET	: Detector
	DEV	: Deviation
	DIF	: Differential
	DISCR	: Discriminator
	DL	: Delay Line
	DOC	: Dropout Compensator
	DOD	: Drop Out Detector
	DPC	: Drum Phase Control

E	E	: Edit, Emitter
	E-E	: Electric to Electric
	EF	: Emitter-Follower
	EMP	: Emphasis
	EN	: Enable
	ENC	: Encoder
	ENV	: Envelope
	EP	: Extended Play
	EQ	: Equalizer
	ES	: Electronic Switch
	ESNS	: End Sensor
	EXP	: Expander
	EXT	: External

F	F	: Farad, Fuse
	F ADV	: Frame Advance
	FDP	: Fluorescent Display Panel
	FE	: Full Erase
	FET	: Field Effect Transistor
	FF	: Fast Forward Flipflop
	FG	: Frequency Generator
	FM	: Frequency Modulation
	FMA	: FM Audio
	FR	: Full Recording, Frame, Fusible Resistor
	FREQ	: Frequency
	F-V CONV	: Frequency to Voltage Converter
	FWD	: Forward
	FWD S	: Forward Search

G	G	: Green, Gate, Grid
	GEN	: Generator
	GND	: Ground
	GRN	: Green
	GRY	: Gray

H	H	: High, Henry, Hour
	HG	: Hall Generator
	HPF	: Highpass Filter
	Hz	: Herz

I	IC	: Integrated Circuit
	ID	: Identification (Pulse)
	IF	: Intermediate Frequency
	IFR	: Infrared
	IFT	: Intermediate Frequency Transformer
	IND	: Indicator
	INH	: Inhibit
	INS	: Insert
	INT	: Internal, Interrupt
	INV	: Inverter
	I/O	: Input/Output
	IR	: Infrared

L	L	: Low, Left
	LIM	: Limiter
	LIN	: Linearity
	LOAD	: Loading (Cassette)
	LP	: Long Play
	LPF	: Lowpass Filter

M M : Motor, Mega
 MAX : Maximum
 MDA : Motor Drive Amplifier
 MECHACON : Mechanism Control
 MIC : Microphone
 MIN : Minimum
 MIX : Mixer, Mixing
 MMV : Monostable Multivibrator
 MOD : Modulation, Modulator
 MODEM : Modulator-Demodulator
 MON : Monitor
 MPX : Multiplexer, Multiplex
 MS : Mode Select

N NAND : Not-And
 NC : Not Connected, Normally Closed
 NFB : Negative Feedback
 NLN : Non-Linear
 NO : Normally Open
 NOR : Normal, Not-Or
 NR : Noise Reduction

O OP : Operation
 OPAMP : Operational Amplifier
 ORN : Orange
 OSC : Oscillator

P PB : Playback
 PC : Photocoupler, Pulse Counter
 PCM : Pulse Code Modulation
 PG : Pulse Generator
 PGM : Program
 PI : Photo Interrupter
 PIF : Picture Intermediate Frequency
 PLA : Programmable Logic Array
 PLL : Phase Locked Loop
 POS : Position
 p-p : Peak-to-Peak
 PREAMP : Preamplifier
 P/S : Pause/Still
 PSC : Pulse Swallowing Control
 PU : Pickup
 PUT : Programmable Unijunction Transistor
 PWM : Pulse Width Modulation
 PWR : Power

Q Q : Quality Factor

R R : Red, Right
 RA : Resistor Array
 RAE : Random Access Enable
 RAM : Random Access Memory
 REC : Recording
 REF : Reference
 REG : Regulated, Regulator
 REM : Remote
 REMOCON : Remote Control (Unit)
 REV : Reverse
 REV S : Reverse Search
 REW : Rewind
 R/P : Record/Playback
 RPT : Repeat
 RST : Reset
 RT : Rotary Transformer
 RUN : Running
 RY : Relay

S SAW : Sawtooth, Surface Acoustic Wave
 SC : Subcarrier, Simulcast
 SCH : Search
 SEL : Select, Selector
 SENS : Sensor
 SEP : Separator
 SF : Source Follower
 SFF : Short Fast Forward
 SIF : Sound Intermediate Frequency

SHARP : Sharpness
 SN : Signal to Noise Ratio
 SOL : Solenoid
 SP : Standard Play
 SREV : Search Reverse
 SREW : Short Rewind
 S/S : Slow/Still
 SSG : Sync Signal Generator
 SSNS : Start Sensor
 STD : Strobe Data, Standard
 SUP : Supply
 SW : Switch
 SWD : Switched
 SYNC : Synchronization

T TF : Thermal Fuse
 TIM : Timing
 TK : Tracking
 TNR : Tuner
 TP : Test Point
 TPZD : Trapezoid
 TR : Transistor, Trimmer
 TRANS : Transformer
 TU : Take-up

U UL : Unloading
 UNCOR : Uncorrelated
 UNREG : Unregulated
 UNSW : Unswitched

V V : Vertical, Volt
 VCO : Voltage Controlled Oscillator
 VD : Vertical Drive
 VIF : Video Intermediate Frequency
 VLT : Violet
 VR : Variable Resistor
 VS : Video and Sync
 V/T : Video/Television
 V/U : VHF/UHF
 VXO : Variable Crystal Oscillator

W W : Watt
 W & D : White and Dark
 WHT : White

X XTAL : Crystal

Y Y : Luminance
 YEL : Yellow

Digital features

- **Digital Freeze** to freeze the action during playback or while watching a regular TV broadcast, with the soundtrack unaffected.
- **Digital Strobe** for a "time-lapse" effect during playback or while watching a regular TV broadcast, with the soundtrack unaffected.
- **Digital Solarization** for a variety of fascinating colour changes during playback or while watching television, with the soundtrack unaffected.
- **Digital Still and Slow-motion** at 1/5, 1/12, 1/18, 1/24 or 1/30 normal speed during playback.
- **Digital double-speed playback.**

High-quality pictures

- **HQ (High-Quality) System** technologies with a Detail Enhancer and 20 % higher white clip level.
- **Double-Azimuth 4-head (DA-4) system** for quality recording and playback in both SP (Standard Play) and LP (Long Play) modes.

High-quality sound

- **Conforms to the Hi-Fi VHS standard** for superlative stereo sound with a dynamic range of more than 90 dB.
- **New switching noise reduction system** for cleaner-than-ever high-fidelity sound reproduction.
- **Hi-Fi recording level control** with ALC switch.
- **Peak-hold audio level indicators/Hi-Fi tracking meter.**

Tuner features

- **PLL frequency synthesized wide-band cable tuner** with 48-channel storage capacity.
- **Pretuned to European television broadcast frequencies:** VHF, UHF and cable channels including those of hyper band.*
- **Sound Multiplex capability** for recording stereo and bilingual broadcasts.
- **10-Key random-access channel selection** and up/down scan tuning.
- **Compatible with VPS (Video Programme System)** with built-in VPS decoder.

Remote control features

- **Independent timer programming** with LCD and built-in 4-programme memory.
- **10-Key random-access channel selection** and up/down scanning.
- **TV control** for power on/off, volume and channel selection (designated JVC TV models only).

Advanced tape access feature

- **VHS Index Search System** facilitates location of the beginning of each recording by automatically marking an index code on the control track of the tape; index codes can be specified with the 10-digit keypad, and detected in the Shuttle Search mode to locate up to 9 selections in either direction. This system is based on the newly standardised CTL coding system for VHS.
- **Counter go-to function** permits direct access to any point on a tape specified by keying in a counter number with the 10-digit keypad.

- **Counter memory** for returning to a point on a tape corresponding to the counter reading of "0000".

Convenient automatic functions

- **Auto play function:** insert a cassette (with safety tab removed), and playback will start automatically.
- **Next-function memory** allows a command to be entered immediately after pressing RÜCKLAUF (or VORLAUF), with the second command "remembered" and performed automatically after the tape rewinds to its beginning or fast-forwards to the counter reading of "0000".
 - Memory play; for automatic start of playback.
 - Memory eject; to eject the cassette after rewind, without waiting for completion of rewind to press the eject button.
 - Memory timer standby; to engage the timer recording standby mode after rewind.
 - Memory power-off; to turn the power off after rewind.
- **Automatic backspace editing.**
- **Auto-power-on convenience.**
- **Power-off ejection.**
- **Automatic rewind** at the end of tape.

Other value features


- **1-Year/8-event remote-programmable timer** with SP/LP programming.
- **60-Minute memory backup** for clock and timer settings.
- **On-screen record-pause mode display** with elapsed time indicated by shrinking white bar.
- **FM simulcast recording;** also allows independent TV and audio programming on the same cassette.
- **Instant recording function** with auto shut-off.
- **Audio dubbing** to replace the linear soundtrack with new material.
- **Electronic tracking controls.**
- **Shuttle Search with latch function:** with the Shuttle Search button locked or held depressed, offers high-speed playback at 9 times normal speed in SP and LP modes.
- **Switchable AC outlet** to timer-control a connected source component.
- **Frame advance.**
- **Comprehensive fluorescent display** with symbolic mode indicators.
- **Picture sharpness control.**
- **Remaining tape time indicator.**

Handling and storage

- **Avoid using the recorder under the following conditions:**
 - extremely hot, cold or humid places,
 - dusty places,
 - near appliances generating strong magnetic fields,
 - places subject to vibrations, and
 - poorly ventilated places.
- **Be careful of moisture condensation.** Avoid using the recorder immediately after moving from a cold place to a warm place or soon after heating a room which was cold. The water vapour in warm air will condense on the still-cold video head drum and tape guides and may cause damage to the tape and the recorder.
- **Handle the recorder carefully.**
 - Do not block the ventilation openings.
 - Do not place anything heavy on the recorder.
 - Do not place anything which might spill and cause trouble on the top cover of the recorder.
 - Use in horizontal (flat) position only.
- **In case of transportation,**
 - Avoid violent shocks to the recorder during packing and transportation.
 - Before packing, be sure to remove the cassette from the recorder.

Video cassettes

- This recorder employs VHS-type cassettes only. E-240 for 4 hours/8 hours, E-180 for 3 hours/6 hours, E-120 for 2 hours/4 hours, E-90 for 1 hour and 30 minutes/3 hours, E-60 for 1 hour/2 hours and E-30 for 30 minutes/1 hour of recording.
- Video cassettes are equipped with a safety tab to prevent accidental erasure. When the tab is removed, recording cannot be performed. If you wish to record on a cassette whose tab has already been removed, use adhesive tape to block the hole.



Safety tab

- Avoid exposing the cassettes to direct sunlight. Keep them away from heaters.
- Avoid extreme humidity, violent vibrations or shocks, strong magnetic fields (near a motor, transformer or magnet) and dusty places.
- Place the cassettes in cassette cases and position vertically.

Moisture condensation

- If you pour a cold liquid into a glass, water vapour in the air will condense on the surface of the glass. This is called moisture condensation.
- Moisture condensation on the head drum, one of the most crucial parts of the video recorder, will cause damage to the tape.
- Moisture in the air will condense on the recorder when you move it from a cold place to a warm place, after heating a cold room or under extremely humid conditions.
- In conditions where moisture condensation may occur, keep the power cord plugged in an AC outlet and the OPERATE switch set to ON; this would help prevent condensation from occurring. When condensation has occurred, it will not evaporate quickly once the power is switched on. Wait a few hours for the recorder to become dry.

Operation

- When a cassette is loaded, the power is switched on automatically.
- The cassette can be unloaded even when the power is off. Pressing the CASSETTE button turns the power on and, after ejection of the cassette, shuts it off automatically in this case.
- As long as the SCHALTUHR button is engaged with the TIMER indicator lit, the BETRIEB and CASSETTE buttons have no effect and unloading of a cassette is not possible. If a cassette has not yet been inserted, simply insert a cassette; the power will be switched on to load the cassette properly and, after completion of automatic loading, the Timer Recording Standby mode will be engaged with power off.

Remote control unit

- Avoid violent shocks, especially take care not to drop the unit.
- Take care not to allow liquid to spill into the unit.
- Do not place heavy objects on the unit.
- Avoid leaving the unit in places subject to direct sunlight or extremely high temperatures.

WARNING


1. This recorder can also receive colour television signals in East Germany (DDR) for recording and playback.
2. Recordings made of DDR television signals produce monochrome pictures if played back on another video recorder of PAL or SECAM standard.
3. SECAM prerecorded cassettes or recordings made with a SECAM video recorder produce monochrome pictures when played back with this recorder.
4. This recorder cannot be used in France. Use a SECAM recorder to record French SECAM signals.

(*Applicable only in certain areas.)

CONTROLS, INDICATORS AND CONNECTORS Refer to the diagrams on the front foldout page.

Front Panel

- **Operate button (BETRIEB)** with green indicator
Press to apply operating power to the recorder. The indicator will light. Loading a cassette also turns the power on.
- **Cassette eject button (KASSETTE)**
- **Infrared beam receiving window (FERNB. SENSOR)**
- **Cassette loading slot**
Insert a VHS cassette. The door will close and the "cassette loaded" indicator will appear on the FDP (fluorescent display panel).
- **LED indicators**
 - STEREO : Lights when a stereo programme is being received.
 - 2-KANAL : Lights when a bilingual programme is being received.
 - DIGITAL : Lights when the Digital Memory is in operation.
 - SIMULTAN : Lights when the AUFNAHMEWAHL switch is set to SIMUL.
- **Fluorescent display panel**
Fully explained in relevant sections.



- **Headphone level control (KOPFHÖRERPEGEL)**
Adjusts the level of audio output from the headphone jack.
- **Headphone jack (KOPFHÖRER)**
- **Mic jack (MIKROFON)**
- **Play/x2 button (WIEDERGABE/x2)**
Press once to play back the tape; press again for double-speed playback. Also press this button to cancel the Pause/Still, Slow and Search modes.
- **Record button (AUFNAHME)**
Press together with the WIEDERGABE/x2 button for recording.
- **Audio dubbing button (VERTONUNG)**
Press together with the PAUSE/STANDB. button, then the WIEDERGABE/x2 button for audio dubbing.
- **STOP button**
PREPARE TO STOP THE TAPE.
- **Pause/Still button (PAUSE/STANDB.)**
Press to stop the tape temporarily to avoid recording of unwanted material or to view a still picture. The still picture can be advanced step by step or continuously.

- **Audio monitor indicators**
Show the selected audio channel (Hi-Fi STEREO, L, R and NORMAL).
- **Rewind and Fast-Forward (Shuttle Search) buttons (RÜCKLAUF and VORLAUF) (BILDSUCHLAUF)**
Press while in the Stop mode to rewind or fast-forward the tape; press while in the Play mode to view the speeded-up picture for programme search. See pages 41 and 45.
- **AUDIO MONITOR button**
Each time the button is pressed, the audio channel to be output changes and is indicated by the audio monitor indicators. See page 38.
- **Slow (-, +) buttons (ZEITLUPE)**
Press in the Play or Still mode to engage the Slow-Motion mode. To increase the speed, press "+" button; to decrease the speed, press "-" button. See page 41.
- **Search button (AUTO-SUCHLAUF)**
Press to initiate automatic scan tuning in the Real-channel mode. (See pages 25 and 36.)
- **Clock adjust button (UHREINSTELLUNG)**
Press to adjust the clock.
- **Cancel/Skip button (ÜBERSPRINGEN/LÖSCHEN)**
A dual-purpose switch. Use to clear the programmed data in the Timer Set mode or skip unnecessary channels in the Channel Set mode. (See page 36 or 48.)
- **Fine (-, +) button (FEIN)**
To fine-tune in to a certain station by shifting the frequency in both directions. (See page 36.)
- **Store button (SPEICHERN)**
Press to store necessary channels. (See page 36.)
- **VPS/Channel button (VPS/KANAL)**
Allows for VPS programming when pressed in the Timer Set mode. In all other modes, this button functions to engage the tuner in the Real-channel mode. (See pages 35, 36 and 49.)
- **Hi-Fi Audio recording level controls (AUDIO HI-FI AUFNAHMEAUSSTEUERUNG)**
Use to adjust the hi-fi audio recording level, referring to the audio level indicators on the FDP. See page 38.
- **Source select switch (AUFNAHMEWAHL)**
TUNER : To record signals coming from the built-in tuner.
SIMUL : To record the video signal and normal audio signal from the built-in tuner and the hi-fi audio signal from the rear panel AUDIO EING. connectors. When recording FM simulcast TV programmes, use this position.
- **AC online switch (NETZAUSGANG)**
AUS position : Power is available from the rear panel AC outlet regardless of whether the recorder is on or off.
EIN position : Power is available from the rear panel AC outlet only when the recorder is on. When used in combination with the built-in timer, this enables timer-controlled power supply for the connected equipment.
- **Level indicator switch (PEGELANZEIGE)**
Selects the function of the audio level indicators. See page 38.
- **Counter memory switch (ZÄHLWERKSPEICHER)**
When this switch is set to EIN, the tape will stop automatically at the counter reading of about "0000" in the Rewind or Fast Forward mode.
- **Automatic level control switch (AUDIOBEGRENZER)**
Set to AUS when adjusting the hi-fi audio recording level manually.

- **DISPLAY button**
Press to change the display from the Timer Set mode to the Clock mode. Usually use this button to switch the middle 4-digit display to tape counter (ZÄHLW.), remaining tape time (RESTZT.) and date (DATUM).
- **SP/LP button**
Press to select the recording mode (SP or LP).
- **Counter reset button (ZÄHLWERK-RÜCKST.)**
Press to reset the tape counter reading to "0000".
- **Go-to button (ZIELLAUF)**
Press to engage the counter Go-To mode. See page 45.
- **Multi-purpose numeric keys**
 - Channel selection: See page 35.
 - Clock setting: See page 34.
 - Timer programming: See page 47 and 48.
 - Counter Go-To: See page 45.
 - Index Search: See page 45.
 - External source recording: See page 50.
- **Programme button (AUFZ. NR.)**
Press to programme the timer.
- **Timer button (SCHALTUHR)**
Press to engage the timer recording standby mode.
- **TV PR. (-, +) buttons**
Press either button to scan a desired channel. These buttons can also be used as cursor keys for 10-key programming.
- **Instant record button (SOFORTAUFNAHME)**
Use this button to start recording instantly and stop automatically after a specific time. (See page 43.)
- **Tracking (-, +) controls (SPURLAGE)**
If noise bars are seen during playback (normal or slow), use these buttons to reduce them. The tracking is reset to

- standard when both buttons are pressed together, the cassette ejected, or the power turned off.
- **Picture sharpness control (BILDSCHÄRFE)**
Turn this knob clockwise to make the picture sharper. Turn counterclockwise to give the picture a softer tone. Effective only for playback pictures. (No effect for recording.)
- **Vertical lock control (V-BILDFANG)**
Turn this control to eliminate vertical jitters in the Still mode.
- **Hi-Fi/NORM MIX switch**
Set to EIN to listen to both the hi-fi and normal soundtracks simultaneously.
- **Tuner sound select switch (2-KANAL-TON)**
HAUPT : To record the main soundtrack (local language).
NEBEN : To record the sub soundtrack (foreign language). See page 37.

Remote Control Unit

- **TV operate button (TV-BETRIEB)**
Press to turn the TV power on or off. (Designated TV models only.)
- **Timer button (SCHALTUHR)**
Press to engage the timer recording standby mode.
- **Video operate button (VIDEO-BETRIEB)**
Press to turn the recorder power on or off.
- **TV volume buttons (TV-LAUTSTÄRKE)**
Press "-" or "+" to decrease or increase the TV's sound volume.
- **TV channel button (TV-KANAL)**
Press to select a desired channel on the TV receiver.

Remote Control Unit

A/B mode switching

A switch on the back of the remote control labelled A/B is accessible when the battery compartment cover is removed.

- This switch is preset to the "A" position. Do not touch it unless you use two JVC video decks side by side.

- When you place two JVC video decks near each other, use this remote control in the "B" mode to prevent both decks from responding simultaneously to this remote control's signals. For this purpose, carefully follow the instructions below:

- (1) Unplug the power cord of the HR-D530EG from the AC outlet.
 - (2) Set the remote control unit's A/B mode switch to "B".
 - (3) Plug the power cord of the HR-D530EG into the AC outlet.
 - (4) Turn on the power of the HR-D530EG using the remote control's VIDEO-BETRIEB button.
- The HR-D530EG "memories" this B code and then will respond only to the signals of this remote control unit. The other deck will respond only to its remote control.

Note:

Do not operate other remote controls after you have plugged the HR-D530EG into the AC outlet


and before you press the VIDEO-BETRIEB button of this remote control.

Operating distance for remote control unit

6 The maximum operating distance is about 8 m.


Installing the batteries

- Insert two "R6"-size batteries (provided) into the battery compartment on the rear of the remote control unit, observing correct polarity.



LCD (Liquid Crystal Display) panel

Refer to this panel when programming the remote control's built-in timer memory.




- **Memory programme button (SPEICHER AUFZ. NR.)**
Press to programme the remote control's timer memory.
- **Memory cancel button (SPEICHER LÖSCHEN)**
Press to cancel the programmed data in the remote control's timer memory.
- **Programme transfer button (ÜBERTRAG)**
Press to transfer the data held in the memory to the recorder.
- **Multi-purpose numeric keys**
- **VPS/Channel button (VPS/KANAL)**
- **Programme button**
Press to programme the recorder's timer memory directly from the remote control.
- **Cancel button (LÖSCHEN)**
Press to cancel the programmed data held in the recorder's timer memory.
- **CURSOR/TV PR. buttons**
- **SP/LP button**
- **Go-to button (ZIELLAUF)**
- **Display button (ANZEIGE)**
- **Counter reset button (ZÄHLWERK-RÜCKST.)**
- **DIGITAL MEMORY button**
Press once to engage the Digital Freeze mode; press again for strobing. For more details, see page 42.
- **Digital off button (DIGITAL AUS)**
Press to cancel the digital effects (Freeze, Strobe, Solarization). See page 42.
- **AUDIO MONITOR button**
- **Solarization button (SOLARISATION)**
Press to engage the Solarization mode; press to select between the three solarization effects in sequence. See page 42.
- **Slow (-, +) button (ZEITLUPE)**
- **Rewind and Fast-Forward (Shuttle search) buttons (RÜCK. and VOR.)**
- **Record button (AUFNAHME)**
- **Play/x2 button (WIEDERGABE/x2)**
- **Pause/Still button (PAUSE/STANDB.)**
- **STOP button**

Rear Panel

- **AC outlet**
Connect the power cord of other audio or video equipment (such as an FM tuner) requiring less than 2 A of current. This outlet is controlled by the NETZAUSGANG switch.
- **AUDIO/VIDEO socket**
A 21-pin standardised audio/video input/output socket for the connection to a TV or a 2nd video recorder equipped with the same type of socket. The input from this socket can be recorded in the AUX mode engaged by obtaining "AU" in the channel display.
- **Audio output connectors (AUDIO AUSG.)**
Both hi-fi and normal audio signals can be obtained from these connectors. The output can be selected with the AUDIO MONITOR button (●, ●) and the Hi-Fi/NORM MIX switch (●).
- **Audio input connectors (AUDIO EING.)**
Connect an audio tape recorder or other audio sources for recording sound onto the hi-fi audio track.
- **RF converter frequency adjustment screw**
- **RF output connector (HF-AUSGANG)**
Connect to the aerial terminal of a TV receiver through the aerial cable (provided).
- **Aerial input connector (ANTENNEN-EINGANG)**
Connect an aerial to this connector.
- **Attenuator switch (ANT. SIGN.)**
Set to SCHWACH to receive broadcasts from distant stations. Set to STARK to receive broadcasts of high field strength.
- **TEST signal switch**
Set to EIN when tuning your TV receiver for the video channel. A test signal in the form of two vertical white bars will be available.
- **Remote pause control terminal (PAUSE FERNBEDIENUNG)**
When using a JVC video camera, connect the remote control cable of the camera adapter to this terminal for the purpose of controlling the starting and stopping of the tape with the camera's start/stop switch.
- **Power cord**

CONNECTIONS

System Example 1




Procedure

1. Remove the serial cable from the TV receiver and reconnect to the HR-D530EG.
2. Connect the HR-D530EG to the TV receiver using the aerial cable (provided).
3. Connect the AUDIO EING. L and R ● connectors of the HR-D530EG to the recording output terminals of the amplifier. (Exactly as one hooks up an audio cassette deck.)
4. Connect the AUDIO AUSG. L and R ● connectors of the HR-D530EG to the AUX IN or TAPE MONITOR terminals of the amplifier.

Notes:

- Observe L and R when connecting the audio input and output connectors of the HR-D530EG to a stereo amplifier.
- If stereo or bilingual TV broadcasts are receivable in your area, this recorder can record them independently of the TV set and play them back through the connected audio system.
- When listening to sound from the connected stereo system, turn down completely the sound volume of the TV receiver.
- Listening to stereophonic sound is also possible using stereo headphones connected to the front panel KOPFHÖRER jack (●).
- With this setup, you can enjoy prerecorded Hi-Fi VHS video tapes in hi-fi stereo while viewing them on a regular TV receiver, and also you can record FM simulcast television programmes with hi-fi audio accompaniment. See page 44.
- If you want to timer-control the recording of FM simulcast programmes, connect the tuner's power cord to the HR-D530EG's AC outlet. Set the NETZAUSGANG switch (●) to EIN, and both the tuner and the HR-D530EG will be switched on at a time preprogrammed by the HR-D530EG. Timer-controlled recording of FM simulcast programmes is not possible with the type of tuners which reset the channel each time the power is switched off.

System Example 2



For customers who own a stereo TV equipped with a standardised audio/video socket

By connecting the 21-pin AUDIO/VIDEO socket (●) of the HR-D530EG to your TV's audio/video socket, it is possible to play stereo tapes through the TV's speakers. In this case, use the A/V mode specified on your TV, instead of UHF channel 36.

CAUTION

- The HR-D530EG has a dynamic range of more than 90 dB with regards to its hi-fi audio capability. It is recommended that you check the maximum level if you are going to listen to the hi-fi audio signals through a stereo amplifier. A sudden surge in speaker input may cause speaker damage.
- Some speakers and televisions are specially shielded to prevent television interference. If both are of the non-shielded type, do not place the speakers adjacent to the TV set, otherwise the video playback picture will not be normal because of mutual interference.

VIDEO CHANNEL SETTING

- 1 Press the **BETRIEB** button ● to turn the power on. Turn on the TV receiver.
- 2 Set the **TEST** switch ● to **EIN**.
- 3 Adjust your TV receiver in the vicinity of UHF channel 36 until you bring in the two white signal bars on the screen as illustrated. This is your **VIDEO CHANNEL**.
- 4 Reset the **TEST** switch to **AUS**.




Notes:

- If some interference noise is seen on the screen because of broadcasts on neighbouring channels or if your preset broadcasts should be affected in picture quality, it is necessary to shift the RF converter output frequency from that of channel 36. Consult your JVC dealer for making this adjustment.
- Video channel setting is also possible using a prerecorded VHS video cassette. Play back the tape and tune the TV receiver to obtain clear pictures and sound while monitoring the playback picture on the TV screen.
- If your TV receiver is not provided with an AFC circuit, perform fine tuning of the TV receiver when you are actually viewing video cassettes.



CLOCK SETTING

Plug the HR-D530EG into an AC outlet. The display shows a blinking 0:00 with SO and UHR illuminated.



Power failure indicator

The initial condition of the display is also a power failure indicator, showing that there has been a power failure exceeding 60 minutes. Re-adjusting the time restores the normal condition of the clock display.



Notes:

- If you press a wrong numeric key, you can return to the previous position using the **ZURÜCK** "-" key ●.
- Once all necessary data have been entered, you can reach any position for correction using the **ZURÜCK** and **VOR** "-" and "+" keys.
- Clock setting is not possible during playback, or if the **SCHALTUHR** button ● is engaged with the **TIMER** indicator lit. First check to see that the **TIMER** indicator is off.

1 Press UHREINSTELLUNG ●.

The display will change to the Clock Set mode with "SO" and "UHR" blinking.

- 2 Press one of the numeric keys "1 (SO)" to "7 (SA)" that corresponds to the day of setting. The hour digits will start blinking.

3 Set the hour and minute in that order.

- The blinking position is ready for entry.
- To set a one-digit number, first press "0", then press the numeric key for 1 to 9.
- Zero will not be displayed in the tens place of the hour indication unless the cursor is moved back to the hour digits.
- For a two-digit number, simply press the corresponding numeric keys in the right order.
- In hour setting, numbers larger than 23 will be rejected.
- In minute setting, numbers larger than 59 will be rejected.

4 Set the day and month in that order.


- The setting method is the same as for time setting.
- In day setting, invalid numbers such as 32 of January or 30 of February will be rejected.
- 29 of February will be accepted only during leap years.
- In month setting, numbers larger than 12 will be rejected.

5 Set the year in the channel display section.

- Key in only the two last digits of the year.
- 6 Press **UHREINSTELLUNG**.
- Press it at the exact instant of the time signal, and the clock will be set accurately to the present time.

OPERATING THE BUILT-IN TUNER

The HR-D530EG incorporates an advanced frequency synthesized tuner which is pretuned to 112 channels to cover VHF, UHF and CATV broadcasts. Channel indication is given in two different ways: real channel numbers and channel position numbers. Real channel number indication is available by pressing the **VPS/KANAL** button ●, while channel position number indication is always available in the channel display.



Real channel number display

Channel position number display

Correspondence between 112 pretuned TV stations and the HR-D530EG's real channel indications

DISPLAY	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20
Ch	-	E2	E3	E4	E5	E6	E7	E8	E9	E10	E11	E12	A	B	C	D	E	F	G	H
CC	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	S13	S14	S15	S16	S17	S18	S19	S20
	M1	M2	M3	M4	M5	M6	M7	M8	M9	M10	U1	U2	U3	U4	U5	U6	U7	U8	U9	U10
	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99
DISPLAY	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
Ch	E21	E22	E23	E24	E25	E26	E27	E28	E29	E30	E31	E32	E33	E34	E35	E36	E37	E38	E39	E40
CC	S21	S22	S23	S24	S25	S26	S27	S28	S29	S30	S31	S32	S33	S34	S35	S36	S37	S38	S39	S40
DISPLAY	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
Ch	E41	E42	E43	E44	E45	E46	E47	E48	E49	E50	E51	E52	E53	E54	E55	E56	E57	E58	E59	E60
CC	S41	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
DISPLAY	61	62	63	64	65	66	67	68	69			76	76	77						
Ch	E61	E62	E63	E64	E65	E66	E67	E68	E69											
CC	-	-	-	-	-	-	-	-	-			X	Y	Z						

Stored channels

A total of 112 channels are receivable. Of them, up to 48 can be stored for easy channel selection. Prior to shipment, some channels are stored.

It is possible to store more channels or skip some channels if there are no broadcasts on those channels in your area. It is possible to change the stored channels to correspond to your preferred channel allocation. Skipped channels can be restored whenever necessary.

- Channel memories are permanent; the programmed channel allocation will not be erased even if the recorder is unplugged from the AC outlet.

Channel selection

To select a channel for recording, normally use the TV **PR.** +/- buttons ● (TV **PR.** +/- button ● on remote control) or 10 numeric keys ● | ● on remote control). You can choose any channel from among the stored ones by calling up the corresponding channel position number.

- Use the TV **PR.** "-" button to scan to a channel in the direction of decreasing numbers; the TV **PR.** "+" button, in the direction of increasing numbers.

- When using the 10 numeric keys, pay attention to the following: When 1, 2, 3 or 4 is entered, it blinks for about 2 seconds: To set channel 1, 2, 3 or 4, leave it blinking until it remains lit. To key in a two-digit number, enter the 2nd number while 1, 2, 3 or 4 is blinking. The number entered first will be shifted to the tens place and channels 10 to 48 can be set. If you enter an invalid number (larger than 48), the channel display will return to the previous figure after 2 seconds.

If you want to select a channel other than those stored, engage the **Real Channel** mode and call up a channel, while referring to the **Real Channel** number display.

With recorder's controls:

- Press the **VPS/KANAL** button ● to engage the **Real Channel** mode and call up a channel by either pressing the **AUTO-SUCHLAUF** button ● or using the 10 numeric keys.


With remote control:

- Press the **VPS/KANAL** button ● to engage the **Real Channel** mode and call up a channel by using the 10 numeric keys.


Changing the stored channels



Turn the TV receiver to ON and adjust it to your video channel.




Upper or lower "-" sign indicates the operating tuning frequency is above or below the standard broadcast frequency. Center "-" sign will appear when it corresponds to the standard.




Then press either the FEIN "-" or "+" button, depending on the direction of fine adjustment, so that the picture clears up. Each time the button is pressed, the picture condition changes in a single increment. Continuous changing is also possible by keeping the button pressed. If the tuning frequency falls on the next station, the channel number advances as well. If no command is given for 2 seconds after either FEIN button has been pressed, the Fine Tuning mode will be automatically cancelled. To cancel the Fine Tuning mode instantly, press the VPS/KANAL button.

- Press the VPS/KANAL button ●. The middle 4-digit display will change to the Real Channel mode and show the band and real channel number of a station stored for that position.




VHF channel 2 is stored for channel position 5.



Cable channel 75 is stored for channel position 6.

- Call up the channel position number for which you wish to change the stored TV station.
 - For this purpose, press either the TV PR. "-" or "+" button ●. Channel positions from 1 to 48 appear successively. "AU" indicates that the unit is in the external input mode usually referred to as AUX.
- Select a TV station which you wish to store into the position.
 - Pressing the VPS/KANAL button changes the band and alternates the band indication between "Ch" (for VHF and UHF) and "CC" (for Cable). Select the appropriate indication.
 - You can scan to the real channel number corresponding to the desired station by pressing the AUTO-SUCHLAUF button ●. Pressing the AUTO-SUCHLAUF button initiates automatic scanning from real channel number Ch 02 to 69, CC 01 to 41, 75, 76, 77, then back to Ch 02. When a broadcast is detected, scanning stops automatically. To advance to the next station, press the AUTO-SUCHLAUF button.



"Colon" will appear to indicate that this real channel is not stored for the indicated channel position.

- You can key in that real channel number using 10 numeric keys ●. 70, 71, 72, 73, 74 and numbers larger than 77 are invalid numbers. If an invalid number is keyed in, the previously selected channel will be received.

- If the picture quality is unsatisfactory due to ghosts or other noise, perform fine tuning.
 - For this purpose, press either the FEIN "-" or "+" button ●. The Fine Tuning mode will be engaged.

- If the picture is not clear after all procedures, perform fine tuning on your television.
- Distorted pictures or sound will be recorded if fine tuning has not been properly performed. Exercise care with this adjustment since the recorded picture and sound cannot be adjusted later.
- After confirming both the real channel number and channel position number, press the SPEICHERN button ●. "Colon" will disappear.
- The selected station will be stored in memory.
- Press the DISPLAY button ● to disengage the Real Channel mode.

Skipping the stored channels

- Call up the channel position number that you wish to skip by using the TV PR. buttons or 10 numeric keys.
- Press the VPS/KANAL button.
- Press the ÜBERSPRINGEN button ●. "Colon" will appear to indicate that the displayed real channel is not stored.
- Press the DISPLAY button to disengage the Real Channel mode.
 - The skipped channel number will not appear on the channel display during up/down scan tuning.

Restoring the skipped channels

- Press the VPS/KANAL button to engage the Real Channel mode.
 - In this mode, all channel position number 1 through 48 are available in the channel display.
- Select the channel position number that you wish to restore by using the TV PR. "-" or "+" button.
- Select a real channel that you wish to restore in that channel position by using the AUTO-SUCHLAUF button or 10 numeric keys.
- After confirming both the real channel number and channel position number, press the SPEICHERN button.
- Press the DISPLAY button to disengage the Real Channel mode.

INFORMATION ON THE HR-D530EG'S AUDIO SYSTEM

Hi-Fi and normal audio


To provide true hi-fi audio accompaniment to video entertainment and, at the same time, compatibility with regular VHS tapes, the HR-D530EG employs a unique audio recording system. Hi-fi audio signals (2-channel) are recorded deep into the tape's magnetic coating, and the video signal is recorded on top of the audio signals in a shallower layer. At the same time, another audio head records normal audio signals (monaural) onto the usual longitudinal audio track. Since this longitudinal

audio track is exactly the same as on regular VHS tapes, tapes recorded on the HR-D530EG can be played back on other VHS machines, and vice versa. Also, this longitudinal track can be replaced later with new recordings through audio dubbing.

CAUTION:

The hi-fi soundtrack recorded with the HR-D530EG cannot be reproduced with video equipment other than Hi-Fi VHS.

Tape pattern recorded with the HR-D530EG



Hi-fi audio recording and reproduction are available only from the hi-fi audio track while the longitudinal audio track provides normal audio.

The hi-fi and normal soundtracks are recorded simultaneously, and audio dubbing is applicable only to the normal audio.

Recording options according to the selected input mode

Track	Video track	Normal audio track (mono)	Hi-fi audio track (2-channel)
TUNER MICROPHONE	TV picture (from built-in tuner)	TV sound (from built-in tuner)	TV sound (from built-in tuner)
SIMUL. MICROPHONE	TV picture (from built-in tuner)	TV sound (from built-in tuner)	Audio signal from AUDIO EING. (Mixing with microphone input is possible.)
AUX Channel display section	Video signal from AUDIO/VIDEO	Audio signal from AUDIO/VIDEO (Mixing with microphone input is possible.)	

Notes:

- To engage the AUX mode, press the "0" key of the 10-digit keypad.
- Microphone input will always be mixed with the audio signals on the hi-fi audio track. Therefore, do not leave a microphone connected to the MIKROFON jack unless needed.
- You can record audio only (without recording any video signal) on the hi-fi audio track. This means you can record a continuous 8-hour FM programme onto a single cassette (E-240). For this purpose, set the AUFNAHMEWAHL switch to SIMUL and connect an audio source, such as an FM tuner, to the AUDIO EING. connectors ●. And tune the built-in tuner to a vacant channel.

Recording options according to the type of broadcasts and the setting of the 2-KANAL-TON switch

Type of broadcast	2-KANAL-TON switch position	Audio Track	Normal audio track (mono)	Hi-fi audio track (2-channel)	
				L	R
Regular (monaural audio)	Either position	Mono	Mono	Mono	
Stereo broadcast	Either position	L + R mixed	Stereo		
Bilingual broadcast	HAUPT	Main soundtrack (local language)	Main soundtrack (local language)	Sub soundtrack (foreign language)	
	NEBEN	Sub soundtrack (foreign language)			

Hi-Fi audio recording level adjustment

While recording onto the normal audio track is controlled by the built-in Automatic Level Control circuit, hi-fi audio recording has two control options: manual and automatic.

Audio level indicators

For manual control of the recording level, first set the relevant switches as follows:

AUDIOBEGRENZER ● → AUS

PEGELANZEIGE ● → EIN

AUDIO MONITOR ● → Hi-Fi STEREO

Then slide the Hi-Fi recording level controls referring to these indicators. When indicators up to or near 0 dB light for the loudest signal being applied, the recording level is optimum. (The level at which only one red indicator lights from time to time may be most appropriate.)

During playback, these indicators show the level of audio signals recorded on the tape.


These indicators do not light when the PEGELANZEIGE switch is in the AUS position.

Notes:

- With the AUDIO MONITOR button set to L, R or NORMAL, the recording level of hi-fi audio signals cannot be correctly indicated. Select the Hi-Fi STEREO setting when adjusting the recording level.
- The normal audio signal level is also displayed by these indicators, but cannot be adjusted.

AUDIOBEGRENZER switch

Setting this switch to EIN activates the built-in audio limiter circuit for both channels so that the recording level is automatically controlled. For manual adjustment, set this switch to AUS. (The recording level for normal audio is always controlled automatically regardless of the setting of this switch.)



AUDIO Hi-Fi AUFNAHMEAUSSTEU-UNG controls

Slide these controls, the upper for left channel and the lower for right channel, for manual adjustment of the hi-fi audio recording level.

PEGELANZEIGE switch and SPURLAGE buttons

The right-channel audio level indicator also functions as a tracking meter during playback. If noise or breaks are sensed in the reproduced sound from the hi-fi audio track or noise bars are visible on the screen, attempt to correct using the SPURLAGE buttons while referring to the meter. For this purpose, set this switch to Hi-Fi SPURLAGE and press the buttons so that the greatest number of elements of the right-channel indicator light. When this switch is set to AUS, the indicators do not light, regardless of whether during recording or playback.

Notes:


When playing back a tape with no recording on the hi-fi audio track, the level indicator does not light when the PEGELANZEIGE switch is set to Hi-Fi SPURLAGE.

Note:

When a microphone is connected to the MIKROFON jack, set the AUDIO-BEGRENZER switch to the EIN position to protect against over-level input signals from the microphone.

Dual-audio playback flexibility

Two different types of audio tracks (hi-fi and normal) allow a variety of playback options depending on the connection and the settings of relevant controls and switches.



HF-AUSGANG connector

Delivers audio (both hi-fi and normal) and video signals to a TV receiver. When the recorder is not used, the aerial signal is supplied from this connector to the TV receiver to allow regular TV viewing; when a video tape is played back through the HF-AUSGANG connector, the audio is reproduced always as monaural; with hi-fi stereo tapes, both channels are mixed or the one selected by the AUDIO MONITOR button is reproduced. Therefore, for stereo playback, connect a stereo system to the AUDIO AUSG. connectors or a stereo television to the AUDIO/VIDEO socket. Refer to page 33.

AUDIO/VIDEO socket

Delivers audio (both hi-fi and normal) and video signals. (Also accepts audio and video signals for recording from other video equipment.)

AUDIO AUSG. connectors


Delivers the audio signals from both hi-fi and normal audio tracks.

KOPFHÖRER jack and KOPFHÖRERPEGEL control

Delivers the audio signals from both hi-fi and normal audio tracks. The headphone output level is adjustable with the KOPFHÖRERPEGEL control.

Audio select indicators

(Hi-Fi STEREO, L, R, NORMAL)



AUDIO MONITOR button

Selects the hi-fi audio channel (left, right or both) or the normal soundtrack for listening. Use this button together with the Hi-Fi/NORM MIX switch referring to the four indicators (Hi-Fi STEREO, L, R and NORMAL).

- Set to Hi-Fi STEREO to listen to a stereo soundtrack.
- Set to L to listen to the hi-fi left channel sound.
- Set to R to listen to the hi-fi right channel sound.
- Set to NORMAL to listen to the normal sound.

Note:

This button functions during recording as well, although it has no effect on the recorded signal.

Hi-Fi/NORM MIX switch

Operates in conjunction with the AUDIO MONITOR button to select soundtracks for listening.

- Set to EIN to listen to a mixture of Hi-Fi and normal soundtracks by selecting the combination with the AUDIO MONITOR button.


Notes:

- This switch functions during recording as well, although it has no effect on the recorded signal.
- When playing back a tape containing the same soundtrack on both hi-fi and normal audio tracks, a slight time lag is sensed between the two soundtracks, probably with some distortion, in the EIN position. Therefore, in such a case, use the AUS position.
- Set to AUS to listen to each soundtrack independently by selecting it with the AUDIO MONITOR button.

LOADING AND UNLOADING A CASSETTE

Loading

Insert a cassette as illustrated. Be sure to insert it firmly into the slot; otherwise, it will be automatically ejected.



- The automatic loading mechanism will operate only when the cassette is inserted correctly.
- With a cassette inserted, the "cassette loaded" indicator will appear on the FDP.

Unloading

Press the KASSETTE button ●.

CAUTION

- If unloading of the cassette is not possible, check to see whether the TIMER indicator is lit. If so, press the SCHALTUHR button so the TIMER indicator extinguishes.
- Do not attempt to pull out the cassette once automatic loading has started.
- Do not insert fingers or any foreign object beyond the door of the cassette loading slot, as this could lead to injury or damage to the mechanism. Show special caution with children.


AUTO POWER-ON AND AUTO PLAY SYSTEM

- The cassette can be loaded even when the power has not been turned on. Inserting a cassette into the loading slot turns the power on automatically.
- Inserting a cassette, with its safety tab removed, turns the recorder on and playback of the cassette begins automatically.

POWER-OFF EJECT SYSTEM

- The cassette can be unloaded even after the power has been turned off. Pressing the KASSETTE button turns the power on automatically and, after ejection of the cassette, shuts it off automatically.

BASIC OPERATION FOR PLAYING BACK A VIDEO CASSETTE



- Turn the TV receiver on and adjust it to your video channel.
- Load a pre-recorded cassette.
 - Power will be switched on automatically.
 - When the cassette loaded has no safety tab, playback will start automatically.
- Press WIEDERGABE/X2 ●.
 - The SP/LP button may be in either position. The SP or LP mode recording is automatically detected and played back at a correct speed respectively with the corresponding indicator lit on the FDP.
- Press STOP ● at the end of the programme.
 - The tape will be rewound automatically when its end is reached and the recorder will enter the Stop mode.

Picture Sharpness Adjustment

Images on the screen can be adjusted to a preferred softer or sharper definition by turning the BILD-SCHÄRFE control ● in the corresponding direction.

Tracking Adjustment

Noise bars may appear on the screen if you play back a tape which was recorded using another recorder. For correction, press either SPURLAGE button ●. Tracking will be reset to the preset standard each time the cassette is ejected.

CAUTION:

When a tape recorded from SECAM B/G broadcasts in the LP mode is played back, colours disappear if special-effects (still and shuttle search) are applied.

SPECIAL-EFFECTS PLAYBACK


When one of the following modes (except Shuttle Search) is engaged, the digital circuitry is automatically activated to help compensate for picture quality deterioration. Therefore, stills, slow-motion and double-speed pictures are all cleaner than before.

DOUBLE-SPEED PLAYBACK

- Press WIEDERGABE/X2 ● while in the Play mode; double-speed playback will be engaged.
- To resume normal playback, press the same button again.
- The "DIGITAL" indicator will remain lit while in the Double-speed mode.

Mode indicator

SLOW:	STILL:
REW SHUTTLE SEARCH:	FF SHUTTLE SEARCH:
REW:	FF:



SHUTTLE SEARCH

Shuttle Search allows high-speed playback at 9 times normal speed in either direction.


- Press either RÜCKLAUF or VORLAUF BILD-SUCHLAUF ● during playback.
- To cancel the Search mode, press WIEDERGABE/x2.
 - For briefer scanning, keep the BILD-SUCHLAUF button pressed for more than 2 seconds, when you release the button, the Search mode will be cancelled.

STILL PICTURE

- Press PAUSE/STANDB. ● during playback.
 - To advance the still picture, press PAUSE/STANDB. a number of times.
 - The "DIGITAL" indicator will remain lit while in the Still mode.
 - To cancel the Still mode, press WIEDERGABE/x2.
- Notes:**
- When the Still mode continues for longer than about 5 minutes, the Stop mode will be entered automatically.
 - With some televisions, the still picture may be unstable. This is not due to any defect of the unit.

SLOW-MOTION PLAYBACK

- Press the "-" button while in the Play mode, slow-motion playback at 1/30 normal speed will start.
- Press the "+" button while in the Play mode; slow-motion playback at 1/6 normal speed will start.
- Each time the "-" button is pressed, the tape speed becomes slower.
- Each time the "+" button is pressed, the tape speed becomes faster.
- To return to the normal Play mode, press the WIEDERGABE/x2 button.



- The "DIGITAL" indicator will remain lit while in the slow-motion mode.



DIGITAL-EFFECTS PLAYBACK

The HR-D530EG incorporates digital memory circuits (six DRAMs) to provide a variety of special effects while watching a recorded tape or a regular television broadcast.

Freeze-frame: A still picture stored digitally in the memory is frozen on the TV screen while the tape or regular broadcast continues.

Strobe effect: A still picture selected at regular intervals from a tape or TV broadcast and stored digitally in the memory, is continuously played back on the screen while the tape or regular broadcast continues. In this mode, the regular changes in the stored picture result in a strobe-light or time-lapse effect.

Solarization: 3 different solarization effects can be added to pictures during playback or viewing of a regular TV broadcast.



FREEZE-FRAME/STROBE-EFFECT PLAYBACK

- Press **DIGITAL MEMORY** while in the Play mode; the image will be frozen on the screen while normal sound continues.
- Press again; the still picture will be switched at regular intervals, giving a strobe effect.
- Press again; the still picture will be switched at shorter intervals, giving a quicker strobe effect.
- Pressing the button again engages the Freeze-frame mode.
- The "DIGITAL" indicator will remain lit while the DIGITAL MEMORY button is being used.
- To restore normal recording or playback, press the DIGITAL AUS button.

PLAYBACK WITH SOLARIZATION EFFECTS

- Press **SOLARISATION** while in the Play mode; the picture will be solarized.
- Press again; a different solarization effect will occur.
- Press again; the solarization effect will change once again.
- Pressing the button again restores the initial Solarization mode.
- The "DIGITAL" indicator will remain lit while the solarization effect is in use.
- To restore normal pictures, press the DIGITAL AUS button.

SPECIAL-EFFECTS TELEVISION VIEWING


To use the HR-D530EG as a special-effects generator while watching television:

- Turn the HR-D530EG's power on.
- Set the TV receiver to your video channel.
- Select the channel you wish to view with the HR-D530EG's channel selector.
- While using freeze-frame and strobe-effect modes, the regular broadcast continues unseen and the audio portion of the broadcast can be heard as usual.

Notes:

- If off-air signals are distorted or weak, or the tuned-in channel is switched when the digital memory is being used, the memory is automatically reset and the screen will change to normal pictures.
- With some tapes, the playback picture may be unstable in digital mode. This is not due to any defect of the unit.

BASIC OPERATION FOR RECORDING TV PROGRAMMES



- Turn the TV receiver on and adjust it to your video channel.
- Load a cassette (with safety tab in place).
 - Power will be switched on automatically.
- Set **AUFNAHMEWAHL** to TUNER.
- Press either **TV PR** or the numeric keys to select the channel you wish to record.
- Select the recording speed (SP or LP).
 - SP: 4 hours with an E-240 cassette.
 - LP: 8 hours with an E-240 cassette.
- Press **AUFNAHME** and **WIEDERGABE/X2** simultaneously.
 - If there is part of the programme you don't want to record, press **PAUSE/STANDBY**. A white horizontal bar will appear on the screen, which reduces in size in 4 steps as time elapses. When the last quarter starts blinking and disappears, the Stop mode will be entered automatically. The pause duration is possible for about 5 minutes.

INSTANT RECORDING

If you need to start recording instantly from other modes or wish for recording to stop automatically after a certain period of time, use this Instant Recording mode.

1. Press **SOFORTAUFNAHME**.
 - The FDP shows "AUTO STOP ---:--".
2. Press **SOFORTAUFNAHME** once again within 10 seconds.
 - Recording will begin and the FDP shows "AUTO STOP 0:30", indicating that recording will automatically stop and power will switch off after 30 minutes.
3. Adjust the switch-off time, if necessary.
 - Press **SOFORTAUFNAHME** to increase the time in 30-minute increments (possible up to 4-hours).
 - Use the numeric keys to set to a more precise time when required (possible up to 9 hours 59 minutes). Always key in a full number including hours and minutes. For "0:35", key in zero first. After setting the time, press **SOFORTAUFNAHME** immediately.

Notes:

- Instant recording has priority over all other modes.

Pause mode indicator



- To continue recording from the Pause mode, press **WIEDERGABE/X2** while the white bar is on-screen.
- Press **STOP** at the end of the programme.
- When the end of the tape is reached during recording, the tape is automatically rewound and stops.

Notes:

- When recording is restarted from the Pause mode, a few frames recorded before are erased due to overlap of the new recording. This is not due to any defect of the unit.
- The selected channel cannot be altered during recording. If you wish to change the channel, first engage the Pause mode and then select a different channel.

RECORDING A TV PROGRAMME WHILE WATCHING ANOTHER

A programme not being viewed can be recorded while you enjoy another programme. This permits the recorded programme to be played back later at your convenience.

The recording procedure is exactly the same as described on the previous page. The points to be remembered are:

- Select the channel you wish to record with the recorder's channel select buttons.
- Select the channel you wish to view with the TV receiver's channel selector.

RECORDING STEREO TV PROGRAMMES

(Applicable only to the West German Sound-Multiplex TV system)

If stereo TV programmes are broadcast in your area, the HR-D530EG automatically receives them in stereo. When a stereo programme is being received, the STEREO indicator lights and recording is made in stereo on the hi-fi audio track and in mono (mixed L + R) on the normal audio track. To listen to the stereo soundtrack during recording, set the AUDIO MONITOR button ● for HI-FI STEREO. If this button is left either in the L or R position, you will hear only one channel while recording, though the recording is being made in stereo.

RECORDING BILINGUAL TV PROGRAMMES

(Applicable only to the West German Sound-Multiplex TV system)

When a bilingual TV programme is being received, the 2-KANAL indicator lights. There is a switch to select the soundtrack to be recorded on the normal audio track, however, because both soundtracks are recorded always on the hi-fi track for selective listening, you can ignore the switch labelled 2-KANAL-TON in most cases unless you need a specific soundtrack on the normal audio track.

- Set 2-KANAL-TON switch ● to HAUPT to record the main soundtrack (local language); to NEBEN to record the sub soundtrack (foreign language).
- To listen to the selected soundtrack from the hi-fi audio track while recording, set the AUDIO MONITOR button for either L or R.
- To listen to the soundtrack being recorded on the normal audio track, set the AUDIO MONITOR button for NORMAL.

RECORDING FM SIMULCAST TV PROGRAMMES

FM simulcast TV programmes can be recorded using an FM stereo tuner. Connect necessary components. (Connect the FM tuner to the rear panel AUDIO EING. connectors.) Select the TV channel broadcasting the simulcast programme with the recorder's channel select buttons and tune the FM stereo tuner to the station broadcasting the soundtrack for this TV programme.

The only difference from the basic recording procedure is in step ■ on page 43.

- Set AUFNAHMEWAHL ● to SIMUL. Then the SIMULTAN indicator will light. With this setting, the video and audio signals from the built-in tuner will be recorded on the video and normal audio track and the audio signal from the FM stereo tuner will be recorded on the hi-fi audio track.

Notes:

- After finishing recording, be sure to set the AUFNAHMEWAHL switch back to TUNER.
- While recording simulcast programmes, it might happen that the hi-fi sound distorts momentarily at switching points between different programmes. This is not due to any defect of the unit.

RECORDING A TV PROGRAMME WHILE RECORDING AN INDEPENDENT AUDIO SOURCE

Using the "simulcast" recording function, you can record independent audio and video programmes, because the TV soundtrack is not lost, but recorded on the normal audio track. While recording a TV programme, record any audio source independently.

- Connect an audio component (such as an FM tuner) to the AUDIO EING. connectors.

- Set the AUFNAHMEWAHL switch to SIMUL.

Notes:

- If you stop recording to avoid unwanted material of the TV programme using the PAUSE/STANDB. button, the audio programme from an external source is also cut.
- If television broadcasting comes to an end during recording, the hi-fi sound being recorded from an external source may distort. It is recommended that you check the timetable of TV broadcasts in advance.
- After finishing recording, be sure to set the AUFNAHMEWAHL switch back to TUNER, otherwise recording on the hi-fi audio track from the built-in tuner will not be possible.

USING THE HR-D530EG AS AN AUDIO TAPE DECK

You can record audio only (without recording any video signal) on the hi-fi audio track. This means you can record a continuous 8-hour FM programme onto a single cassette (E-240).

- Connect an audio source (such as an FM tuner) to the AUDIO EING. connectors.
- Tune the built-in tuner to a vacant channel.
- Set the AUFNAHMEWAHL switch to SIMUL.

VHS Index Search System


When you start recording from the Stop or Timer Standby mode, an index code is marked on the tape. These index codes can be detected in the Shuttle Search mode for automatic start of normal playback.

1. Press WIEDERGABE/x2 ● to start playback.
2. Specify the number of codes by which you wish to skip, by keying in that number with the numeric keys ● .
 - The SUCH indicator and the specified number will appear in the FDP.
3. Press either VORLAUF or RÜCKLAUF ● within 2 seconds.
 - The tape will move fast and the index number will count down to "zero", where normal playback will start.

Notes:


- To cancel the Index Search mode before completion, press the WIEDERGABE/x2 or STOP button.
- If the end of the tape is reached while still in the Index Search mode, the mode is cancelled and the tape is rewound.

Tips for specifying the index number



- "1" + VORLAUF moves playback to the beginning of segment D.
- "1" + RÜCKLAUF moves playback to the beginning of segment C.
- "2" + RÜCKLAUF moves playback to the beginning of segment B.
- If no number is entered, a value of "1" is assumed.

COUNTER GO-TO AND COUNTER SEARCH



Counter Search

The counter reading of "0000" can be located automatically.

- 1 Press DISPLAY ● to obtain the Counter mode.
- 2 Press ZAHLWERK-RÜCKST. ● during playback or recording at a point which you wish to locate later.
- 3 Set RÜCKLAUF or VORLAUF ● to EIN.
- 4 Press RÜCKLAUF or VORLAUF ● when you need to return to the designated point.

- The tape will stop automatically at about "0000".
- When used in conjunction with the Memory Play function, this offers more convenience. See next page.

Counter Go-To

Specify the desired counter number, and the tape will be fast-forwarded or rewound to that point for automatic playback.

- Press ZIELLAUF ● in the Stop mode.
 - The counter will display the current position of the tape as calculated from the leader at the beginning of the tape.
- Specify the counter number of the point you wish to locate, using the numeric keys ● .
- Press WIEDERGABE/x2 ● .
 - The tape will be fast-forwarded or rewound depending on the relative position of the specified point, at which playback will start automatically.

Notes:

- If the recorder has not detected the leader tape since the tape was loaded, no number will be displayed when the ZIELLAUF button is pressed, but after pressing the WIEDERGABE/x2 button, the tape will be rewound to the beginning (to enable counting from the leader) before fast-forward to the desired location.
- If the specified number exceeds the length of the tape, as calculated from the leader, the tape will fast-forward to the end, rewind to the beginning and then enter the Play mode.

REMAINING TAPE TIME INDICATOR

The tape counter is switchable to the remaining tape time indicator.

1. Press DISPLAY ● to obtain the Remain mode.
2. The remaining tape length will be shown in hours and minutes.

Notes:

- During recording, the remaining tape length is calculated in reference to the recording mode selected by the SP/LP button; during playback, it is calculated in reference to the recording mode of the tape being played (SP/LP).
- The indicated remaining time is approximate. The time required to calculate the remaining tape length and the accuracy of that calculation may vary according to the type of cassette tape. (The remaining time indication is not available if this mode is engaged from Fast Forward or Rewind.)

NEXT-FUNCTION MEMORY


Memory Play function

- If you want to watch the tape from its beginning after rewinding, press RÜCKLAUF and then WIEDERGABEx2 within 2 seconds. Playback will start automatically at the beginning of the tape. (The ZÄHLWERKSPEICHER switch ● must be in the AUS position.)
- If you want to watch the tape from the counter reading of "0000", set ZÄHLWERKSPEICHER to EIN, then RÜCKLAUF (or VORLAUF) and then WIEDERGABEx2 within 2 seconds.
- While the tape is being rewound, the PLAY indicator is blinking. To cancel the Memory Play mode and go to another mode, press the corresponding button (STOP, WIEDERGABEx2, VORLAUF, RÜCKLAUF).

Memory Eject/Power-Off/Timer Standby

If you are going to eject the cassette, turn the power off or engage the Timer Standby mode after rewinding the tape, you do not have to wait for completion of rewind to press the corresponding button.

- To eject the cassette after rewind, press RÜCKLAUF and then KASSETTE within 2 seconds. (To cancel the Memory Eject mode, press STOP.)
- To turn the power off after rewind, press RÜCKLAUF and then BETRIEB within 2 seconds. (To cancel the Memory Power-off mode, press BETRIEB.)
- To engage the Timer Standby mode after rewind, press RÜCKLAUF and then SCHALTUHR within 2 seconds. (To cancel the Memory Timer Standby mode, press SCHALTUHR.)




AUTOMATIC TIMER RECORDING



First of all, load a cassette (with safety tab in place); power will be switched on automatically.


Three ways to perform timer programming

- Local programming:** Programme the timer using the recorder's controls while referring to the recorder's FDP.
- Direct remote programming:** Programme the timer using the remote control's keys while referring to the recorder's FDP.
- Independent remote programming:** Programme the remote control's memory using the remote control's keys while referring to its own LCD and then transfer the data to the recorder.




A. Local Programming

- Press AUFZ. NR. ● .
- The display will change to the Timer Set mode for programme number "1". To advance to programme numbers 2 - 8, press AUFZ. NR.



- Enter the date using numeric keys ● .
- Invalid numbers will be rejected.
- To record a daily serial starting on the day of setting, press VOR "+" ● without entering any date figure.
- To record a daily serial starting on a certain day, press TAGL. (8) and enter the date.
- To record a weekly serial, press WÖCH. (9) and enter the date.
- Both "daily" and "weekly" commands can be entered or cancelled by pressing the corresponding button any time in the date and time setting stages.
- When the display changes to the next stage, key in the start time, stop time and channel in succession using numeric keys.
- To key in a one-digit number of hours or minutes, first press "0". Then press the relevant numeric key.
- For keying in channel numbers, refer to page 35.




- Press SP/LP ● to obtain the desired recording mode indication on the display.
- The SP or LP entry can be made anytime while in the Timer Set mode.
- After making sure that the cassette is loaded, press SCHALTUHR ● .
- The Timer Recording Standby mode will be engaged with the TIMER indicator and the press programme number(s) illuminated and the power turned off.
- With no cassette loaded, the TIMER and "cassette loaded" indicators will continue blinking.
- A cassette whose safety tab has been removed will be rejected automatically.
- If a preset programme contains errors, that programme number will not be illuminated. Recheck the programmed data.

B. Direct Remote Programming

Following the procedures above, use the remote control's buttons instead of the recorder's with the remote control directed toward the recorder's FERNB. SENSOR window ● .


C. Independent Remote Programming

- The remote control incorporates 4 programme memories (A, B, C and D).
- The programmed data is held in memory even after it has been transferred to the recorder.




1 Press SPEICHER AUFZ. NR.

- The LCD will be activated for programme memory "A".
- To advance to programmes B to D, press again.




2 Enter the date using numeric keys

- Setting for a daily or weekly serial is the same as described in "A. Local Programming".




For daily serial setting



For weekly serial setting

3 When the display changes to the next stage, enter the start time, stop time and channel in succession.

- After the channel has been entered, the transfer-ready mark will appear and blink.



Transfer-ready mark

4 Press SP/LP

- To obtain the desired recording mode indication on the display.
- The SP or LP entry can be made anytime while in the Timer Set mode.

5 Direct the remote control to the recorder's FERNB. SENSOR window

- and press ÜBERTRAG.
- The programmed data will be loaded in one of the recorder's memories (1-8), the vacant one of the smallest programme number.

6 If all programme memories are full, the recorder's clock will blink and transmission will not take place.

- Press SCHALTUHR.
- Check to see that the TIMER indicator and other items on the recorder's FDP respond correctly. See page 47.

Setting the date, start and stop times, and channel

- It is not possible to set the date, start and stop times unless the date and clock have previously been set.
- Enter the data while the digits are blinking.
- Unless the start time has been properly set, stop time setting is not possible.
- The stop time can be set within 24 hours from the start time.
- Non-applicable numbers (such as January 32, February 30 for dates, 24 or larger for hours, 60 or larger for minutes and 49 or larger for channels) will be rejected when keyed in.

Canceling the preset data

- The preset programmes can be cancelled. First engage the Timer Set mode for the programme number you wish to cancel and then press the LÖSCHEN button or .

Checking the programmed data


- Checking and re-programming can be performed anytime, even when the SCHALTUHR button has already been engaged.
- While recording is actually taking place according to one preset programme, all other preset programmes can be checked or re-programmed.
- To disengage the Timer Set mode, press the DISPLAY button or .

Timer recording operation

- When the preset start time is reached, recording starts.
- After timer recording, the power is switched off. If the tape end is reached during timer recording, the cassette is automatically ejected and the power is switched off.


How to use the cursor keys

- If you press a wrong key and the flashing position has advanced, press "-" to return to the previous position for correction.
- Once all data have been programmed, you can reach any position for correction using "-" or "+". The flashing position is ready for re-entry.
- The cursor (flashing position) advances or returns in the following order.



(Pressing AUFZ. NR. engages the check mode in which no position flashes and data correction is not possible. To correct the data, press either cursor key. "+" to move to "Date" or "-" to move to "Channel".)

In the VPS (Video Programme System) system, TV stations transmit different VPS codes for different TV programmes, which control the starting and stopping of the video recorder and have precedence over times preset in the timer for accurate recording of a particular programme from start to finish.




Notes:

- When programming the remote control's memory, the VPS indicator will appear on the LCD when VPS command is entered.
- If no VPS code is detected from that station or a system status code which cancels VPS recording is detected, ordinary timer recording will be engaged.
- Operation at the end of VPS recording is the same as with ordinary timer recording.

- Press AUFZ. NR.
- Set the date, start time, stop time and channel in the same way as for timer programming.
- Select SP or LP.
- Press VPS/KANAL.
- All timer data will be converted to VPS codes and stored in memory.

- Press SCHALTUHR.
- The recorder will enter the VPS standby mode at 20:00 on the day previous to the preset day and remain engaged until 3:59 on the following day, if the intended programme has not yet been broadcast.
- When a VPS code corresponding to the intended TV programme is detected during the VPS standby mode, recording will start. When the VPS code changes to another, recording will stop.
- When an interruption code is detected during VPS recording, the VPS standby mode is engaged and recording restarts when the regular VPS code is restored.



AUDIO DUBBING

- Switch on the TV receiver.
 - Adjust the TV receiver's channel to your video channel.
- Load a pre-recorded cassette. Power will be switched on automatically.
- Connect a microphone or an audio source to the MIKROFON jack 9 or the AUDIO/VIDEO socket respectively.
 - With both microphone and audio source connected, mixed sound is recorded.
- Press "0" of the numeric keys.
 - If you record sound only from the microphone, the source equipment connected to the AUDIO/VIDEO socket should be off.
- Press WIEDERGABE to start playback and then press RÜCKLAUF or VORLAUF to search for the point from which you wish to start audio dubbing.

- Press PAUSE/STANDB. at the start point of audio dubbing.
- Press PAUSE/STANDB. while holding VERTONUNG depressed.
- Press WIEDERGABE.
 - Audio dubbing will start.

Audio dubbing means recording a new soundtrack on a pre-recorded tape. In other words, the previously recorded sound is erased and replaced with a new soundtrack. Audio dubbing is applicable only to the longitudinal audio track (normal audio). Therefore, a dubbed narration can be heard together with the original hi-fi sound.

Notes:

- It is recommended that you use a lower-impedance microphone.
- If whistling or howling is heard during audio dubbing, reduce the TV volume or move the microphone farther away from the TV. Recording is being performed even if sound is not heard from the TV receiver. If you want to monitor the sound being recorded, connect headphones to the KOPFHÖRER jack.

CAUTION: Audio dubbing is not possible with an audio source connected to the rear panel AUDIO EING. connectors.

RECORDING FROM AN EXTERNAL SOURCE

By connecting an external video source (such as a VideoMovie camera-recorder, 2nd video recorder, video camera, etc.) to the AUDIO/VIDEO socket, recording and/or editing are possible.

- For connection of these units, an appropriate cable is necessary.
- For connection of a video camera, a camera adapter is also necessary. Connect the camera adapter's PAUSE terminal to the recorder's PAUSE FERNBEDIENUNG connector. Then you can control taping start/stop with the camera's start/stop switch. For proper connection of a camera, consult a JVC dealer.

1. Turn the power on for all connected equipment.
2. Adjust the TV receiver to your video channel.
3. Load a cassette.
4. Press either TV PR. button ● or the numeric key 0/AUX ● to obtain "AU" in the channel display.
5. Press SP/LP ● for required mode.
6. Operate the source equipment properly.
7. Press AUFNAHME ● and WIEDERGABE/x2 ● simultaneously.
 - When recording with a camera, press AUFNAHME and PAUSE/STANDB. ● to enter the Recording Standby mode, then control taping start/stop will the camera's start/stop switch.
8. To stop recording temporarily, press PAUSE/STANDB.
9. To end recording, press STOP ●.

Note:

- For the operation of the source equipment, refer to the instruction manual of the relevant machine.

IN CASE OF DIFFICULTY

What may initially appear to be trouble is not always a real problem. Make sure first

POWER AND TAPE TRANSPORT PROBLEMS

Symptoms	Check points
No power is applied to the recorder.	<ul style="list-style-type: none"> • Is the power cord disconnected? – Connect it.
Clock is functioning properly, but the recorder cannot be powered.	<ul style="list-style-type: none"> • Is the TIMER indicator lit on the FDP? – Press SCHALTUHR to disengage the Timer Recording Standby mode.
Tape does not run during recording.	<ul style="list-style-type: none"> • Is the PAUSE/STANDB. button engaged? – Press the WIEDERGABE/x2 button.
Tape stops in the Rewind or Fast Forward mode.	<ul style="list-style-type: none"> • Is the ZÄHLWERKSPEICHER switch set to EIN? – Set it to AUS.
Tape will not rewind or fast forward.	<ul style="list-style-type: none"> • Is the tape already fully rewound or fast forwarded? – Check the cassette.

RECORDING PROBLEMS

Symptoms	Check points
Recording cannot be started.	<ul style="list-style-type: none"> • Is a cassette loaded? • Is the safety tab on the cassette removed? – Reseal the slot with cellophane tape.
Camera recording is not possible.	<ul style="list-style-type: none"> • Are the camera and the camera adapter correctly connected? • Is the power switch of the camera adapter set to ON? • Does the channel display indicate "AU"? – Press "0/AUX".
Simulcast recording is not possible.	<ul style="list-style-type: none"> • Is the AUFNAHMEWAHL switch set to TUNER? – Set it to SIMUL. • Is an audio source correctly connected to the AUDIO EING. connectors? – Check connections.
Timer recording is not possible.	<ul style="list-style-type: none"> • Have you set the clock correctly and programmed the timer correctly? – Check once again. • Is the TIMER indicator lit on the FDP? – Press SCHALTUHR.

PLAYBACK PROBLEMS

Symptoms	Check points
Playback picture does not appear while the tape is running.	<ul style="list-style-type: none"> • Is the TV receiver's channel selector set to the correct video channel? – Set it to the RF converter channel. (See page 34.)
Noise appear during playback.	<ul style="list-style-type: none"> • Press SPURLAGE buttons.
Playback picture is blurred or interrupted while TV broadcasts are clear.	<ul style="list-style-type: none"> • Video heads may be dirty. – Head cleaning is necessary. Consult your nearest JVC dealer.

HI-FI AUDIO PROBLEMS

Symptoms	Check points
TV sound cannot be recorded on hi-fi audio track.	<ul style="list-style-type: none"> • Is the AUFNAHMEWAHL switch set to SIMUL? – Set it to TUNER.
Breaks are noticeable in hi-fi audio reproduction.	<ul style="list-style-type: none"> • Press the SPURLAGE buttons. (See page 38.) • Have you adjusted the recording level correctly? – Over-level recordings could be a cause. Adjust the level correctly next time. See page 38.
Soundtrack on the hi-fi audio track cannot be reproduced.	<ul style="list-style-type: none"> • Does the NORMAL indicator light? – Press the AUDIO MONITOR button to Hi-Fi STEREO (or L or R as required).
Audio level indicators do not function.	<ul style="list-style-type: none"> • Is the PEGELANZEIGE switch set to a position other than EIN? – Set it to EIN.

OTHERS

Symptoms	Check points
Whistling or howling is heard from TV.	<ul style="list-style-type: none"> • Move camera or microphone away from TV or reduce TV sound volume.
Some channels are skipped over when selecting a channel.	<ul style="list-style-type: none"> • Those channels are preset to be skipped over. If you need them, restore them. (See page 36.)
Channel cannot be switched.	<ul style="list-style-type: none"> • Is recording in progress? – Press the PAUSE/STANDB., select a desired channel and press the WIEDERGABE/x2.

This recorder contains microcomputers. External electronic noise or interference could cause malfunctioning. In such cases, switch the power off and unplug the power cord. Then plug it in again and switch on. Take out the cassette. After checking the cassette, operate the unit as usual.

HEAD CLEANING

- Picture playback may become blurred or interrupted while the TV programme received is clear. This does not mean that the recorded programme has been erased.
- Dirt accumulated on the video heads after long periods of use causes such problems. In this case, head cleaning requiring highly technical care is necessary.


For head cleaning, consult the nearest JVC dealer.

3.4 MAIN TYPES OF ACTIVE AND PACKAGE CIRCUITS

	Integrated Circuit		Transistor		Diode
	A	B	C	D	E
1					
2					
3					
4					
5					
6					
7					
8					
9					

	NAME	L	NAME	L	NAME	L
A	AN3926K AN6299NK AN6308 AN6392 AN3994NK AN3592K	1A 1A 3A 4B 1A 1A	U UPD82C43CY UPD41221C-70 UPD74HC02C UPD74HC02G	1A 2A	2SK 2SK301 2SK381 2SK656	4D 2C 5C
B	BA7001 BA7021 BA3707 BA7751ALS BU2767S BA6222 BU4030B BU4030BF BX6325 BA6259N BA618	4B 4B 1B 5B 1B 4B 1B 1B 6B 1B	V VC2022C VC2030 VC2031DP VC2034 VC2050 VC2052	1A 1A 1B 6B 1B 1B	P PN268R-NC	4C
			7 7VT12	6B	U UN4119	5C
			D DTA114EF DTA114ES DTA124EF DTA124EK DTA124ES DTA143ES DTA144EF DTA144ES DTA144WF DTC114ES DTC124ES DTC144EF DTC144EK DTC144ES DTC144WS DTC144WK	5C 5C 1D 3D 5C 5C 1D 5C 5C 3D 5C 5C	D DA204K DA203 DA210S DAN201 DAN202K DAN209S DAP202K DS5B10	7E 9E 5E 2E 8E 6E
G	GPIU501				E E-452-2	3E
H	HA11752 HA118019NT H8DN1916A H8DN1917A HD49712ANT HD49703NT	1A 1B 4B 4B 1A 1A			H HZ4A2 HZ6C2 HZ12C1 HZ30-2 HZS5.1EB2 HZS5.6EB1 HZS6.8EB2 HZS7.5EB2 HZS4.3EB2	3E 3E 3E 3E 3E 3E 3E 3E
I	IC-PST523H-2	5A			L LTZ-MR15	4E
	M50253P M5218P M5278L05 M50440-397SP M50731-621SP M51365SP M58655P M51458P M51647SP M51722P M50965-633SP M54647L M5M21C67P-55 MB40176 MN3106 MN3801 MN4081BS MSC1124BRS MSM6989RS M5201L M5278L10	3A 5A 1B 1A 1A 1A 1A 1A 1A 2A 1A 4B 1A 1A 3A 1A 2B 1B 1B 4B 5A	2SA 2SA854 2SA933 2SA937 2SA1020 2SA1037 2SA1309	5C 5C 1D 1C 3D 5C	M MA27T(A) MA27W(B) MA29W(A) MA150 MA165 MTZ4.7B MTZ5.1B MTZ13A MTZ10B MTZJ5.1B	2E 2E 3E 3E 3E 3E
			2SB 2SB641 2SB643 2SB644 2SB810 2SB851 2SB1015 2SB808	1D 1D 1D 5C 2D 5C	R RD3.0ESB2 RD5.1ES-T1B2 RD5.6ES-T1B3 RD8.2EB1 RD10ESB3 RD11ES-T1B3 RD24ESB2 RD9.1ESB2	3E 3E 3E 3E 3E 3E 3E
			2SC 2SC1317 2SC1740 2SC1741 2SC2021 2SC2412 2SC2636 2SC2655 2SC2878 2SC3070 2SC3243 2SC3311 2SC3354 2SC3313 2SC3327	3C 5C 5C 1D 3D 1D 1C 5C 1C 5C 1D 5C 1C	S SLH-34MC3F SLH-34VC3F SLH-34YC3F SLV-34MC3F S5688G	1E 1E 1E 2E
			2SD 2SD636 2SD637 2SD638 2SD1266 2SD1383 2SD1423 2SD1450 2SD1469 2SD1740-01 2SD1761 2SD1449 2SD1468 2SD1292 2SD1785	1D 1D 1D 2D 3D 5C 5C 5C 2D 2D 2D	O OA90	2E
					1 10E2 11E2 1SR35-200A 1SS99 1SS132 1SS133 11ES2	2E 2E 2E 2E 2E 2E 2E

3.7 SERVO BLOCK DIAGRAM



A

B

C

3-8

3-8


E

F


G



H

3.8 FM AUDIO BLOCK DIAGRAM




3.9 VIDEO BLOCK DIAGRAM





3.10 MECHANISM CONTROL SCHEMATIC DIAGRAM



From/To MOTHER CN4

From/To	Pin	Signal
DRUM ON/OFF	12	4.7
DATA 0	7	0.1
VP CTL	13	0.1
DATA 1	6	2.1
SLOW PULSE	12	2.1
DATA 2	5	5.2
3/7S MODE	11	5.2
DATA 3	4	3.8
CAP REV	10	3.8
STROBE	3	0.1
CAP FWD	9	0.1
NC	2	0
CNT PULSE	8	0
CAP DRIVE	1	0.4

IC602 TRUTH TABLE

MOTOR	MODE	IN	OUT
FWD	L	H	L
REV	L	H	H
FWD	H	L	L
REV	H	L	H
STOP	L	L	L
STOP	H	L	L
STOP	L	H	L
STOP	H	L	L

IC603 TRUTH TABLE

MOTOR	MODE	IN	OUT
STOP	L	L	L
FWD	L	L	H
REV	L	L	L
STOP	H	L	L
FWD	H	L	H
REV	H	L	L

IC604 TRUTH TABLE

MOTOR	MODE	IN	OUT
STOP	L	L	L
FWD	L	L	H
REV	L	L	L
STOP	H	L	L
FWD	H	L	H
REV	H	L	L

From/To MOTHER CN6

From/To	Pin	Signal
INDEX	1	11.7
REC MUTE	8	10.8
MON SEL	2	5.4
DRUM FF	9	5.4
CH SEL	3	12.0(10.4)
FB	10	0
NC	4	0
SP	11	0.1
MIX	5	10.8
REC START	12	0.1(2.8)
REMOTE PAUSE	6	0
REC	13	0.3(11.9)
MOTOR 12V	7	2.3
HIF MUTE	14	8.8

From/To DECK TERMINAL CN1

From/To	Pin	Signal
REEL MOTOR(+)	19	2.1
REEL MOTOR(-)	18	0.1
CAP MOTOR(+)	17	1.6
MODE MOTOR(-)	16	0
CAP MOTOR(-)	15	0
MODE MOTOR(+)	14	2.2
SWD 5V	13	4.8
END SENS	12	0
TU FG	11	0
MODE SENS 1	10	0
CAP FG(+)	9	4.9
MODE SENS 2	8	0
CAP FG(-)	7	0
REC SAFE	6	0
GND	5	0
SUP FG	4	0
NC	3	0

From/To MOTHER CN3

From/To	Pin	Signal
REC START	1	3.2
POWER ON/OFF	2	3.2
REMOTE	3	3.2
UNSW 12V	4	3.2
OP 1	5	3.2
NC	6	3.2
OP 2	7	3.2
POWER LED	8	3.2
P SHARPNESS CTL	9	3.2
SHARPNESS MAX	10	3.2

From/To MOTHER CN2

From/To	Pin	Signal
CAP FG	1	0.1(7.2)
A DUB	2	0
CAP FG(+)	3	0
S CLOCK	4	0
CAP FG(-)	5	0
S DATA	6	0
CTL PULSE	7	0
D SERIAL DATA	8	0
SYNC	9	0
SWD 5V	10	0
V PULSE	11	0
GND	12	0
D SERIAL CLOCK	13	0

From/To VIDEO, J2

From/To	Pin	Signal
LF SEARCH	1	0
LF SPECIAL	2	0
SP	3	0
VP CTL	4	0
REC	5	0
REC START	6	0
DRUM FF	7	0
NC	8	0
SWD 12V	9	0
GND	10	0
VIDEO	11	0


From/To MOTHER CN7

From/To	Pin	Signal
NC	1	12.0
PB 12V	2	12.0
GND	3	12.0
VIDEO	4	12.0
SWD 12V	5	12.0
NC	6	12.0

From/To MOTHER CN5

From/To	Pin	Signal
NC	1	15.3
UNREG 17V	2	15.3
GND	3	15.3
SWD 5V	4	15.3
NC	5	15.3
GND/100	6	15.3
NC	7	15.3
NC	8	15.3
MOTOR 12V	9	15.3

3.11 DECK TERMINAL SCHEMATIC DIAGRAMS



6

5

4

3

2

1

A


B

C

D

3.12 MECHANISM CONTROL AND SERVO CIRCUIT BOARDS


— CASSETTE HOUSING —




— REC SAFETY —




— END SENSOR —




— RELAY —




— MECHANISM CONTROL —



— DECK TERMINAL —




— SERVO —




6
5
4
3
2
1

A B C 3-15 3-15 E F G H

3.13 VIDEO SCHEMATIC DIAGRAM






From/To 21
MECHACON
J2

To 22
DIGITAL COLOUR
PROCESS, CN2

From/To 23
MECHACON
J1

To 20
DIGITAL, CN3
From 22
DIGITAL COLOUR
PROCESS, CN1
From/To 20
DIGITAL, CN3

3.14 SERVO SCHEMATIC DIAGRAM




6
5
4
3
2
1


A B C 3-18 3-18 E F G H

3.15 VIDEO, VIDEO SUB (3) AND VIDEO SUB (1) CIRCUIT BOARDS


- VIDEO -




- VIDEO SUB (3) -



- VIDEO SUB (1) -



3.16 PRE/REC SCHEMATIC DIAGRAM




6
5
4
3
2
1


A B C 3-20 3-20 E F G H

3.17 PRE/REC AND UPPER DRUM CIRCUIT BOARDS

— PRE/REC —



— UPPER DRUM —



A

B

C

3-21

3-21

E


F

G

H

3.18 AUDIO SCHEMATIC DIAGRAM


6
5
4
3
2
1



A B C 3-22 3-22 E F G H


3.19 AUDIO AND A/CTL HEAD CIRCUIT BOARDS

- AUDIO -




R5 PB LEVEL
 R20 BIAS LEVEL

- A/CTL HEAD -




3.20 FM AUDIO(FMA) SCHEMATIC DIAGRAM



A B C 3-24 3-24 E F G H


3.22 TUNER/IF SCHEMATIC DIAGRAM

NOTE:
Voltages are DC-measured with a digital voltmeter during stop mode.



3.23 TUNER/IF CIRCUIT BOARD


6
5
4
3
2
1




A B C 3-27 3-27 E F G H

3.24 DEMODULATOR SCHEMATIC DIAGRAM

NOTE:
Voltages are DC-measured with a digital voltmeter during stop mode.



3.25 DEMODULATOR CIRCUIT BOARD



R57
L LEVEL

R62
R LEVEL

T3
SOUND 1 DET

T4
VCO

T5
SOUND 2 DET

R31
SEPARATION

PU22376D

DEM00 PWB ASS'Y

6

5

4

3

2

1

A

B

C

3-29

3-29

E



F

G

H


3.26 DISPLAY SCHEMATIC DIAGRAM

NOTE:
Voltages are DC-measured with a digital voltmeter during stop mode.



6
5
4
3
2
1
A B C 3-30 3-30 E F G H

3.27 DISPLAY CIRCUIT BOARD




PB20041A(E) PB20041C(EG)
 DISPLAY PWB ASS'Y

6
5
4
3
2
1

A B C 3-31 3-31 E F G H

3.28 TIMER SCHEMATIC DIAGRAM


6
5
4
3
2
1



NOTE:
Voltages are DC-measured with a digital voltmeter during stop mode.

A B C 3-32 3-32 E F G F

3.29 TIMER CIRCUIT BOARD




C101
TIMER CLOCK


6
5
4
3
2
1

A B C 3-33 3-33 E F G H

3.30 MOTHER SCHEMATIC DIAGRAM




3.31 MOTHER CIRCUIT BOARD




3.32 JUNCTION AND OPERATION SCHEMATIC DIAGRAMS

6
5
4
3
2
1




3.33 JUNCTION AND OPERATION CIRCUIT BOARDS


— JUNCTION —



— OPERATION —




3.34 CONTROL AND SUB JUNCTION SCHEMATIC DIAGRAMS




3.36 TERMINAL SCHEMATIC DIAGRAM

6
5
4
3
2
1



A B C 3-40 3-40 E F G


3.37 TERMINAL CIRCUIT BOARD



6
5
4
3
2
1

A B C 3-41 3-41 E F G H


3.38 POWER SUPPLY SCHEMATIC DIAGRAM




NOTE:
Voltages are DC-measured with a digital voltmeter during stop mode.

3.39 POWER TRANSFORMER, REGULATOR, FUSE AND POWER TRANSISTOR CIRCUIT BOARDS


- POWER TRANSFORMER -




- POWER TRANSISTOR -



- REGULATOR -




- FUSE -




6
5
4
3
2
1
A B C 3-43 3-43 E F G H

3.40 DIGITAL SCHEMATIC DIAGRAM




3.41 DIGITAL COLOR PROCESS SCHEMATIC DIAGRAM




3.42 DIGITAL AND DIGITAL COLOR PROCESS CIRCUIT BOARDS

- DIGITAL -





- DIGITAL COLOR PROCESS -




R14
DIG COL LEVEL

3.43 APC SCHEMATIC DIAGRAM AND CIRCUIT BOARD




3.45 RF CONVERTER AND MIX BOOSTER SCHEMATIC DIAGRAM



NOTES:
 1. All parts shown in this schematic are critical for safety.
 2. This schematic is only for reference.
 Avoid replacing individual parts.
 Replace the entire unit only.

3.46 REMOTE CONTROL SCHEMATIC DIAGRAM



NOTE:
 All parts shown in this schematic are critical for safety.
 Replace only with specified part numbers.

SECTION 4 EXPLODED VIEWS AND PARTS LIST

SAFETY PRECAUTION

Parts identified by the \triangle symbol are critical for safety. Replace only with specified part numbers.



NOTE:

[M] indicates mechanical symbol number.


4.1 STANDARD PART NUMBER CODING

4.1.1 Screw coding

Standard screw part numbers are as follows.

<p>Type of screw (in capital letters)</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">1</div> <div style="text-align: center;">2</div> <div style="text-align: center;">3</div> <div style="text-align: center;">4</div> </div> <p>Shape of screw head (in capital letters)</p>	<p>Shape of thread (in capital letters)</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">5</div> <div style="text-align: center;">6</div> <div style="text-align: center;">7</div> <div style="text-align: center;">8</div> </div> <p>Nominal diameter (in figures)</p>	<p>Length (in figures)</p> <div style="text-align: center;">9</div> <p>Surface treatment (in capital letters)</p>																																											
<p>Type of screw (first digit)</p> <ul style="list-style-type: none"> S Normal screws D Assembled machine screws (with plain and spring washers) L " (with spring washer) N " (with plain washer) F Feather screws G Washer head tapping screws M Wood screws 	<p>Shape of screw head (second digit)</p> <ul style="list-style-type: none"> B Brazier head D Binding head H Oval countersunk head P Pan head R Round head S Flat head T Truss head W Washer head (machinescrews) X Toothed head 																																												
<p>-Type of screw (first digit) -</p> 		<p>- Shape of screw head (second digit) -</p> 																																											
<p>Material (third digit)</p> <table border="0" style="width: 100%;"> <tr> <td>S Steel</td> <td>N Nickel silver</td> </tr> <tr> <td>E Stainless steel</td> <td>Y Cast brass</td> </tr> <tr> <td>C Cast iron</td> <td>A Aluminum</td> </tr> <tr> <td>U Copper</td> <td>Z Zinc alloy</td> </tr> <tr> <td>B Brass</td> <td>K Polycarbonate</td> </tr> <tr> <td>P Phosphor bronze</td> <td></td> </tr> </table>	S Steel	N Nickel silver	E Stainless steel	Y Cast brass	C Cast iron	A Aluminum	U Copper	Z Zinc alloy	B Brass	K Polycarbonate	P Phosphor bronze		<p>Shape of thread (fourth digit)</p> <ul style="list-style-type: none"> P Cross recessed head screws (-) Slotted head machine screws X Slotted-cross recessed head machine screws K Cross recessed head machine screws for precision equipment (type 1) H " (type 3) A Cross recessed head tapping screws (type 1) B " (type 2) C " (type 3) E Cross recessed head special tapping screws (brand : evertight) F " (brand : P-tight) T " (brand : taptight) G " (brand : taptight) 																																
S Steel	N Nickel silver																																												
E Stainless steel	Y Cast brass																																												
C Cast iron	A Aluminum																																												
U Copper	Z Zinc alloy																																												
B Brass	K Polycarbonate																																												
P Phosphor bronze																																													
<p>- Shape of thread (fourth digit) -</p> <table border="0" style="width: 100%;"> <tr> <td style="text-align: center;">Cross recessed head</td> <td style="text-align: center;">Slotted head</td> <td style="text-align: center;">Slotted-cross recessed head</td> <td style="text-align: center;">P, (-), X, K, H</td> <td style="text-align: center;">A</td> <td style="text-align: center;">B</td> <td style="text-align: center;">C</td> </tr> <tr> <td style="text-align: center;"></td> <td style="text-align: center;"></td> <td style="text-align: center;"></td> <td style="text-align: center;"></td> <td style="text-align: center;"></td> <td style="text-align: center;"></td> <td style="text-align: center;"></td> </tr> <tr> <td style="text-align: center;">E</td> <td style="text-align: center;">F</td> <td style="text-align: center;">G</td> <td colspan="4"></td> </tr> <tr> <td style="text-align: center;"></td> <td style="text-align: center;"></td> <td style="text-align: center;"></td> <td colspan="4"></td> </tr> <tr> <td colspan="4"></td> <td style="text-align: center;">T</td> <td colspan="2"></td> </tr> <tr> <td colspan="4"></td> <td style="text-align: center;"></td> <td colspan="2"></td> </tr> </table>				Cross recessed head	Slotted head	Slotted-cross recessed head	P, (-), X, K, H	A	B	C								E	F	G																T									
Cross recessed head	Slotted head	Slotted-cross recessed head	P, (-), X, K, H	A	B	C																																							
E	F	G																																											
				T																																									
<p>Nominal diameter (fifth and sixth digits)</p> <p>The fifth and sixth digits indicate a nominal diameter or dimension. If the dimension exceeds 10 mm, three digits are used. The number indicates a nominal diameter or dimension, given in millimeters, multiplied by ten.</p>	<p>Surface treatment (ninth digit)</p> <ul style="list-style-type: none"> Z Dichromate treatment after galvanizing (MFZn II-C) N Nickel plating (MFNi II, MFNi I) R Chromium plating (MBCr II, MBCr I) G Silver plating (SP4) B Black coating after plating F Blackening of iron (FB) M Blackening after galvanizing K Pickling of brass (PF2) P Phosphate treatment W Uni-chrome plating L Coated with transparent paint A Colored red after galvanizing (MFZn II-C) C Colored blue after galvanizing (MFZn II-C) T Colored green after galvanizing (MFZn II-C) V Colored purple after galvanizing (MFZn II-C) 																																												
<p>Length (seventh and eighth digits)</p> <p>The seventh and eighth digits indicate length in millimeters. The preceding figure is zero when the dimension is smaller than 10 mm. For machine screws used in precision equipment whose length is given in units of 0.1 mm, the number indicates ten times the size of their length.</p>																																													

4.2 CABINET ASSEMBLY <M2>



REF NO. PART NO. PART NAME, DESCRIPTION

2. CABINET ASSEMBLY <M2>


1	PQ10496F-15	FRONT PANEL ASSY,INCL.41-56,EG
2	PQ10496C-15	FRONT PANEL ASSY,INCL41-56,E
3	PQ10330-1-6	BOTTOM COVER
4	PQ10328-2-9	TOP COVER
5	SDSA4014M	TAPPING SCREW, TOP, X4
6	SDSF3010M	TAPPING SCREW, TOP
7	SDSF3010Z	TAPPING SCREW, BOTTOM, X3
8	PQ31819-7-4	C.H.DOOR
9	PQ42410-1-1	TORSION SPRING
10	PQ31967	PROTECTOR
11	PQ31335	FDP FILTER, PINK SHEET
12	SDSF2005M	TAPPING SCREW, CONT PANEL, X5
13	SDSF2605Z	TAPPING SCREW, X2
14	SDSF2608Z	TAPPING SCREW, X6
16	SDSF2608Z	TAPPING SCREW, X2
17	SDSF2608Z	TAPPING SCREW, X2
18	SDSF2006Z	TAPPING SCREW, X3
21	PQ205350-2	COTROL PANEL ASSY, INCL22-26, EG
22	PQ20535A-2	COTROL PANEL ASSY, INCL22-26, E
23	PQ31773-2	BUTTON(INSTANT REC)
24	PQ20459-2	BUTTON(TEN KEY)
25	PQ20459-1-2	BUTTON(TEN KEY)
26	PQ43059	BASE
27	PQ20538A-2	COVER ASS'Y, INCL28-30, E
28	PQ20538D-2	COVER ASS'Y, INCL.28-30, EG
29	PQ31777-1-3	DOOR, X2
30	PQ43060-1-2	EARTH PLATE
31	PQ43189-1-1	SPRING
32	PQ43063-1-2	KNOB, X6
33	PQ43064-1-2	KNOB
34	PQ43065-1-3	KNOB, X2
35	PQ43066	KNOB, X2
36	PQ43221	KNOB(PHONE VOL)
37	PQ43157	EARTH PLATE
38	PQ31979	WIRE CLAMP
39	PU57662-1-1	FOOT, X2
40	SDSF2608Z	TAPPING SCREW
41	PQ43153	BUTTON
42	PQ43057B	BUTTON ASS'Y, POWER, E
43	PQ43057C	BUTTON ASS'Y, EG
44	PQ31763-4	BUTTON(T/V, EJT), EG
45	PQ31763-2	BUTTON(T/V, EJT), E
46	PQ32094-3-3	BUTTON 1(OPE), EG
47	PQ32094-1-3	BUTTON 1(OPE), E
48	PQ32095-3-4	BUTTON 2(OPE), EG
49	PQ32095-1-4	BUTTON 2(OPE), E
50	PQ31768-3	DOOR, EG
51	PQ31768	DOOR, E
52	PQ31769	ARM(L)
53	PQ31770	ARM(R)
54	PQ31821	STOPPER, DOOR
55	SDSF2005Z	TAPPING SCREW, X2
56	PQ43061-1-1	EARTH PLATE
57	PQ31949	EARTH PLATE
58	SDSF2606Z	TAPPING SCREW
59	PU60047-1-5	DAMP. UNIT ASS'Y
60	SSS82606Z	TAPPING SCREW
61	SDSF2606Z	TAPPING SCREW
62	PQ43058-3	IR WINDOW, EG
63	PQ43058	IR WINDOW, E

REF NO. PART NO. PART NAME, DESCRIPTION


3. CHASSIS ASSEMBLY <M3>

2	PDV2089A	DRUM ASSY, INCL.31-35
3	PQ31171-2-7	DRUM SHIELD
4	SDST2605Z	TAPPING SCREW, X2 D.SHILD
5	SOSP2608Z	SCREW, X3 DRUM
6	PQ31242	EARTH SPRING
7	PUS28277H	CASS.HOUSING ASSY, INCL.41-46
8	SDSA4014Z	TAPPING SCREW, X2 M.DECK
9	PQ41396	SPECIAL SCREW, M.DECK
10	SDSF3010Z	TAPPING SCREW, X7 MOT.B.OARD
11	SDSF3010Z	TAPPING SCREW, X3 TNR/IF BOARD
12	SDSF3010Z	TAPPING SCREW, X2 HEAT SINK
13	GPST2608Z	SCREW, X2 VIDEO BOARD
14	PQ31613	AC COVER
15	PQ42850-1-1	PWB HOLDER, X2
16	SDST3006Z	SCREW, X5 P.S BOARD
17	SDST3006Z	SCREW, FUSE BOARD
18	SDST2605Z	TAPPING SCREW, X2 C.HOUSING
19	SDST3006C	TAPPING SCREW, EARTH
20	SDSA4014Z	TAPPING SCREW, X3 TRANS
21	SDST2605Z	TAPPING SCREW, X2 BOARD BRACKET
22	SPST2606Z	SCREW
23	QMP3980-200	POWER CORD
24	PQ20370-2-2	TRANS BRACKET
25	QHS3771-108	STRAIN RELIEF
26	QMC9021-001	AC OUTLET
27	PU5908Z	PRE SHIELD (3)
31	PDM2001C-8	UPPER DRUM ASSY
32	PDM4001A	DRUM SCREW ASSY, X2
33	PDM2053L-11	LOWER DRUM MOTOR ASSY
34	PDM4015B	BRUSH ASSY
35	LPSP2606Z	SCREW
41	PQ42385A	CASSETTE MOTOR ASSY
42	OR PQ42385B	CASSETTE MOTOR ASSY
43	SPSP2603Z	SCREW, X2
44	PQM30003-19	BELT
45	SPSP2604Z	SCREW
46	SPST2605Z	TAPPING SCREW, X2
47	DV710SR223M16	VARIATOR
56	PQ43184	BRACKET(VPS), EG
57	SDSF3010Z	TAPPING SCREW, VPS, EG
58	PU60379	POWER TRANSFORMER
62	PQ42596A	BRAKE ASS'Y
63	PQM30001-212	TENSION SPRING
64	PU59401-3	SOLENOID
65	OR PU60475-3	SOLENOID
66	PQ31380-1-4	BRAKE BASE
67	PQM30002-187	COMP. SPRING
68	SPSP2005Z	SCREW, X2
69	SDST2608Z	SCREW


4.3 CHASSIS ASSEMBLY <M3>



4.4 MECHANISM ASSEMBLY (1) <M4>



MECHANISM ASSEMBLY (2) <M4>




#	REF NO.	PART NO.	PART NAME, DESCRIPTION

* 4. MECHANISM ASSEMBLY <M4> *			

1		PQ41944A-7	TENSION ARM ASSY, INCL.2
2		PQ41952-3	SPRING
3		PQ41948A	TENSION BAND ASSY
4		SDST2606Z	TAPPING SCREW
5		PU57641-2	FULL ERASE HEAD
6		PQ31036	FULL ERASE HEAD BASE
7		SPSG2606Z	SCREW
8		PQ41954-1-1	TORSION SPRING
9		PQ41955	IMPEDANCE ROLLER
10		PQ41956	COLLAR
11		PQ41957	LOWER FLANGE
	OR	PQ42958	LOWER FLANGE
12		PQM30018-39	SPACER
	OR	PQM30018-50	SPACER
13		PQM30002-124	COMPRESSION SPRING
14		PQ40353	NYLON NUT
15		PU59253	AUDIO/CONTROL HEAD
16		PU55535	SHIELD CAP
17		HPSP2015N	SCREW
18		PQ42984-2	HEAD BASE
19		SPSP2608Z	SCREW,X3
20		PU30080-49	SPRING,X3
21		SDSP2606Z	SCREW,X2
22		PQ41963A-2	POLE BASE ASSY (TU)
23		PQ41969A-2	POLE BASE ASSY (SUP)
24		PQM30017-5	SLIT WASHER,X2
25		PU53629-2	TAPE GUIDE
26		PQ40268-2	GUIDE FLANGE,X2
27		PQ42999-2-1	G.POLE CAP
28		SDSP2006Z	SCREW
Δ 29		PU60201V	CAPSTAN MOTOR
30		SPSP2605N	SCREW,X3
31		PQ41974A-3	REEL MOTOR BRACKET ASSY
32		PU58645-1-4	IDLER ARM
33		Q03093-834	WASHER
34		PQ41976A-1	SPRING ARM ASSY, INCL.35
35		PQ42212-1-4	SPRING
36		PQM30017-22	SLIT WASHER
37		PQ41978	HOLDER
38		SPST2606Z	TAPPING SCREW
Δ 39		PU58636W	REEL MOTOR
Δ 40	OR	PU58636M	REEL MOTOR
		LPSP2604Z	SCREW,X2
41		SPST2606Z	TAPPING SCREW,X2
42		PU59250-1-2	REEL DISK(SUP)
43		PU58638-1-2	REEL DISK(TU)
44		PQM30017-5	SLIT WASHER,X2
45		Q03093-828	WASHER, X2
46		PQ41979A-4	LOADING ARM ASSY(SUP)
47		PQ41985B	LOADING ARM ASSY(TU)
48		PQ41992A-2	CAM BRACKET SUB ASSY
49		PQ41994A-3	ARM GEAR SUB ASSY
50		PQ20250-1-1	CONTRQL CAM
51		PQ41996A	MODE MOTOR ASSY
52		PQ41998A	WORM ASSY
53		LPSP2604Z	SCREW,X2
54		PQ42001	WINDMILL
55		PQ42002	CLUTCH SPRING
56		PQ42003	WORM SHAFT
57		PQM30017-5	SLIT WASHER,X2
58		PQM30003-20	BELT
59		PQM30018-22	SPACER
60		SPST2606Z	SCREW,X2

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
61		SPST2606Z	SCREW,X2
62		SPSP2603Z	SCREW
63		PQ42038A-3	PLATE ASS'Y, INCL 64-66
64		PQ31044-1-2	LOCK LEVER
65		PQM30001-191	TENSION SPRING
66		PQM30001-211	TENSION SPRING
67		PQM30017-28	SLIT WASHER,X2
68		PQ42006B	PINCH ROLLER ARM ASSY
69		PQM30017-28	SLIT WASHER
70		Q03093-833	WASHER
71		PQM30001-229	TENSION SPRING
72		PQ42013B-4	GUIDE ARM ASSY, INCL.73
73		PQ42029	SPRING
74		PQM30017-6	SLIT WASHER
75		PQ42019A-6	MAIN BRAKE ASSY(SUP)
76		PQ42020B	MAIN BRAKE ASSY(TU)
77		PQM30001-216	TENSION SPRING
78		PQ42021A-3	SUB BRAKE ASSY(SUP), INCL.79
79		PQ42023-1-2	TENSION SPRING
80		PQ42037A-2	SUB BRAKE ASSY(TU)
81		PQM30017-6	SLIT WASHER
82		PU59452	LED HOLDER, INCL.LE DIODE
	OR	PU58640	LED HOLDER, INCL.LE DIODE
83		SPST2606Z	TAPPING SCREW
84		SPST2606Z	TAPPING SCREW
85		PU58642	SLIDE ENCODER
86		SDSP2610Z	SCREW
87		SDSP2606Z	SCREW,X3
88		SDST2606Z	TAPPING SCREW
96		PU59251-1-2	R. SENSOR(SUP)
97		SPSP2603Z	SCREW

4.5 REMOTE CONTROL ASSEMBLY < M5 >




REF NO.	PART NO.	PART NAME, DESCRIPTION

* 5. REMOTE CONTROLLER < M5 > *		

1	PQ10543U	REMOTE CONTROLLER, INCL. 2-23, EG
2	PQ10543T	REMOTE CONTROLLER, INCL. 2-23, E
3	PQ31909	UPPER CASE
4	PQ31910	LOWER CASE
5	PQ31449	BATTERY CAP
6	PQ31911-3	LCD WINDOW, E
	PQ31911-2	L.C.D. WINDOW, EG
	PQ31912-18	TOP PANEL, E
	PQ31912-19	TOP PANEL, EG

REF NO.	PART NO.	PART NAME, DESCRIPTION
8	PQ10543-003	WINDOW
9	PQ10543-004	RUBBER SHEET(L)
10	PQ10543-005	RUBBER SHEET(S)
11	-	REMOCON BOARD ASSY, REF. <RM>
12	PQ10355-009	BATTERY TERMINAL
13	S0SF2005M	TAPPING SCREW, X5
14	S5SG2010M	TAPPING SCREW
15	PQ10543-006	BUTTON, X20
16	PQ10543-007	BUTTON, GRAY (L)
17	PQ10543-008	BUTTON, BLACK(S), X5
18	PQ10543-009	BUTTON, RED & WHITE
19	PQ10543-010	BUTTON, WHITE (L), X2
20	PQ10543-011	BUTTON, BLUE, X2
21	PQ10543-012	BUTTON, GRAY(S), X10
22	PQ10543-013	LCD, E
	PQ10543-014	LCD, EG
23	PQ10543-015	CONNECTOR, X2

4.6 PACKING ASSEMBLY < M1 >



REF NO.	PART NO.	PART NAME, DESCRIPTION	REF NO.	PART NO.	PART NAME, DESCRIPTION

* 1. PACKING ASSEMBLY <M1> *					

1	PQ31705-82	PACKING CASE, E	5	PU56142-3	PIN CORD ASSY
	PQ31705-84	PACKING CASE, EG	△ 6	PU59168-3	RF CABLE
2	PQ31860A-1	CUSHION ASSY	△	OR PU59167-3	RF CABLE
3	PQ41026-10	PROTECT SHEET	7	UM-3DJ2P	BATTERY
4	PQM30021-59-11	POLY BAG	8	QPG4020-02003	POLY BAG
			△ 9	PU30425-947	INSTRUCTIONS, E
			△	PU30425-946	INSTRUCTIONS, EG
			10	QPG4025-03505	POLY BAG
			11	BT-20069A	WARRANTY CARD, EG
			12	TCN-3379	TAPE CATALOG
			13	PU60504	INST SHEET (DIG), EG

SECTION 5 ELECTRICAL PARTS LIST

SAFETY PRECAUTION

Parts identified by the \triangle symbol are critical for safety. Replace only with specified part numbers.

ABBREVIATIONS IN THIS LIST ARE AS FOLLOWS:

RESISTORS— All resistance values are in ohms (Ω), unless otherwise indicated.

k	: 1,000 (Kilo)
M	: 1,000,000 (Mega)
Chip R	: Chip Resistor
Chip VR	: Chip Variable Resistor
Comp. R	: Composition Resistor
CR	: Carbon Film Resistor
FR	: Fusible Resistor
MFR	: Metal Film Resistor
MPR	: Metal Plate Resistor
OMR	: Oxide Metal Film Resistor
PMR	: Precision Metal Film Resistor
UFR	: Unflammable Resistor
VR	: Variable Resistor (Potentiometer)
WR	: Wire Wound Resistor

CAPACITORS— All capacitance values are in μF , unless otherwise indicated.

pF	: $\mu\mu\text{F}$ (Pico farad)
C Cap	: Ceramic Capacitor
Chip Cap	: Chip Capacitor
Chip T Cap	: Chip Tantalum Capacitor
E Cap	: Electrolytic Capacitor
FM Cap	: Film Mica Capacitor
LL Cap	: Low Leak Current Electrolytic Capacitor
MM Cap	: Metalized Mylar Capacitor
MP Cap	: Metalized Paper Capacitor
MY Cap	: Mylar Capacitor
NP Cap	: Non-polar Capacitor
PC Cap	: Polycarbonate Capacitor
PP Cap	: Polypropylene Capacitor
PS Cap	: Polystyrol Capacitor
T Cap	: Tantalum Capacitor
TF Cap	: Thin Film Capacitor
TR Cap	: Trimmer Capacitor


NOTES:

- [2 digits] indicates circuit board symbol number.
- "X " indicates quantity per set.

5.1 STANDARD PART NUMBER CODING

5.1.1 Fixed resistor coding

Fixed resistor part numbers are as follows.



Type of resistor (third digit)	Rated wattage (fourth and fifth digits)	Tolerance (seventh digit)	Assistant code (twelfth digit)
C Composition resistors	A0 1/10 W	F $\pm 1\%$	A Small type
D Carbon film resistors	18 1/8 W	G $\pm 2\%$	B Small type
F Unflammable resistors	16 1/6 W	J $\pm 5\%$	S Small type
G Oxide metal film resistors	14 1/4 W	K $\pm 10\%$	Y Lead taping
H Fusible resistors	12 1/2 W	M $\pm 20\%$	Z Lead taping
M Metal plate resistors	01 1 W		
S Metal glazed resistors	02 2 W		
V Precision metal film resistors	03 3 W		
W Wire wound resistors	04 4 W		
X Metal film resistors	05 5 W		
Z Special resistors	06 6 W		
	07 7 W		
	75 7.5 W		
	08 8 W		
	10 10 W		
	15 15 W		
	A6 16 W		
	20 20 W		
	30 30 W		

Values (eighth – tenth or eleventh digits)	examples:
R47	0.47 Ω
4R7	4.7 Ω
470	47×10^0 47 Ω
471	47×10^1 470 Ω
472	47×10^2 4.7 k Ω
473	47×10^3 47 k Ω
474	47×10^4 470 k Ω
475	47×10^5 4.7 M Ω

QRV resistance shown by four digits:		
4640	464×10^0	464 Ω
4641	464×10^1	4.64 k Ω
4642	464×10^2	46.4 k Ω


Shape of resistor (sixth digit)

Note: indicates flame retardant resistor.

Type of resistor / Shape of resistor	C	D	F	G	H	M	S	V	W	X
1										
2										
3										
4										
5									(L) type	
6										
7			Lug (B) type							
8			Lug (A) type					Chip		
9			Lug (C) type							

5.1.2 Fixed capacitor coding

Fixed capacitor part numbers are as follows.



Ceramic capacitors

Type of capacitor (first – third digits)		Shape of capacitor (fourth digit)				
Symbol	Characteristics	Mono-direction	Kink lead	Axial lead	Axial forming lead	Chip
QCC	Ceramic	1		4	5	
QCD	High capacitance					A
QCF	High capacitance	1,4	3			8,A
QCS	Temperature compensation	1	3	4	5	8,A
QCT	Temperature compensation	Special coding				8,A
QCV	Ceramic			1	3	
QCX	Ceramic			1	3	
QCY	High capacitance	1,4	3	6	7	8,A
QCZ	Special type	Special coding				
QCB	Ceramic			B	C	

Electrolytic capacitors

Type of capacitor (first-third digits)		Shape of capacitor (fourth digit)				
Symbol	Characteristics	Tubular	Mono-direction	Anti-stress	Forming	Snap-in
QEB	Low leakage		4	5	6	
QEC	Low leakage		4,8,A	9,B	6,C	
QEE	Tantalum (normal)		4	5	6	
	Tantalum (small)		8			
QEF	Chip tantalum	8 (chip type)				
QEG	Low impedance		4			
QEK	Miniature type		4	5	6	
QEL	Small type		4	5	6	7
QEM	Small type		4,A	5	6	
QEN	Non-polar	2	4	5	6	
QEP	Non-polar (small)		4,A	5,B	6,C	
QER	Miniature type		4	5	6	
QET	Small type	2	4,A	5,B	6,C	7
QEU	Small type		4	5	6	
QEV	Small type		4		6	7
QEW	Normal	2	4	5	6	7

Paper film capacitors

Type of capacitor (first – third digits)		Shape of capacitor (fourth digit)					
		Tubular	Normal		Flame retardant		
Symbol	Characteristics			Mono-direction	Kink lead	Mono-direction	Kink lead
QFA	Metalized polypropylene					7	
QFE	Metalized mylar					5	
QFF	Film mica		4				
QFG	Polypropylene film		4	8			
QFH	Metalized mylar	2	4	3	5,7	6	
QFJ	Mylar (special)		4				
QFK	Metalized mylar (small)					5	
QFM	Mylar	2	4	3,7	5	6	
QFN	Mylar (small)		4	3			
QFP	Polypropylene		4	3,8			
QFS	Polystyrole	2	4	3			
QFV	Thin film		4	8			
QFZ	Special type	Special coding					

Rated voltage (fifth and sixth digits)

Fifth digit \ Sixth digit	Sixth digit												
	A	B	C	D	E	F	G	H	J	K	V	W	X
0						3.15	4.0		6.3				
1	10		16	20	25		40	50	63	80	35		
2	100	125	160	200	250	315	400	500	630		350	450	600
3	1000	1250		2000				5000					

Tolerance (seventh digit)

A	+100 %	M	±20 %
	-10 %		
F	±1 %	N	±30 %
G	±2 %	P	+100 %
			-0 %
H	+50 %	R	+30 %
	-10 %		-10 %
J	±5 %	X	+40 %
			-20 %
K	±10 %	Z	+80 %
			-20 %

Values (eighth – tenth digits)

Example : Values are in picofarads


101 10×10^1 pF	100 pF
102 10×10^2 pF	1,000 pF (0.001 μ F)
103 10×10^3 pF	10,000 pF (0.01 μ F)
104 10×10^4 pF	100,000 pF (0.1 μ F)
105 10×10^5 pF	1 μ F
5R0	5.0 pF

Assistant code (eleventh digit)

- G Small size
- Z Lead taping
- Y Lead taping

5.1.3 Fuse coding

Standard fuse part numbers are as follows.



Shape of fuse (fourth and fifth digits)

51	φ5.2 × 20 mm
60	φ6.4 × 30 mm
61	φ6.35 × 31.8 mm
63	φ6.4 × 30 mm with lead wires
66	φ6.35 × 31.8 mm with lead wires
00	Special type

Rated voltage (seventh digit)

1	AC125 V
2	AC250 V
3	0.1 – 1 A : AC250 V 1.25 – 6.3 A : AC125 V

Values (eighth-tenth or eleventh digits) example:

R63	0.63 A
1R0	1.0 A
2R5	2.5 A
100	10 A
R315	0.315 A
1R25	1.25 A

Characteristics (sixth digit)

Symbol	Fusing Current	Fusing Time	Remarks
A	210 %	Within 2 min.	Anti-rush type (for Europe)
	275 %	0.6 – 10 sec.	
	400 %	0.15 – 3 sec.	
	1000 %	0.02 – 0.3 sec.	
B	210 %	Within 30 min.	Regular fusible type (for SEMKO, Europe)
	275 %	0.05 – 2 sec.	
	400 %	0.01 – 0.3 sec.	
C	135 %	Within 1 hr.	Regular fusible type (for UL, Japan)
	200 %	Within 2 min.	
E	210 %	Within 2 min.	Anti-rush type (for Europe)
	275 %	0.6 – 10 sec.	
	400 %	0.15 – 3 sec.	
	1000 %	0.02 – 0.3 sec.	
J	135 %	Within 1 hr.	Anti-rush type
	200 %	Within 2 min.	
M	135 %	Within 1 hr.	Regular fusible type (for UL)
	200 %	Within 2 min.	
R	160 %	Within 1 hr.	Regular fusible type
	200 %	Within 2 min.	
S	160 %	Within 1 hr.	Anti-rush type
	200 %	Within 2 min.	
	700 % – 2000 %	Within 0.01 sec.	
U	135 %	Within 1 hr.	Anti-rush type (for UL)
	200 %	Within 2 min.	
	800 % – 2000 %	Within 0.01 sec.	

#	REF NO.	PART NO.	PART NAME, DESCRIPTION

* 6. POWER SUPPLY BOARD ASSEY <01><02> *			

	PWBA	PB20117B-03	POWER SUPPLY BOARD ASSY
	WR1	PW30101-50AAZZ9 OR PW30115-50AAZZ9	PARALLEL WIRE PARALLEL WIRE
-POWER TRANSFORMER BOARD ASSY < 01 >-			
	PWBA	PB20117B1-03	POWER TRANS BOARD ASSY
	D1	10E2	DIODE
	D2	10E2	DIODE
	D3	11E2	DIODE
	D4	OR 1SR35-200A 11E2 OR 1SR35-200A	DIODE DIODE DIODE
	DS1	D5SB10	DIODE ARRAY
		OR RBV-601	BRIDGE DIODE
	DS2	D5SB10 OR RBV-601	DIODE ARRAY BRIDGE DIODE
Δ	R1	QRZ0077-100X	FUSIBLE RESISTOR
Δ	C1	QFK52AK-473	M CAPACITOR
	C2	QETB1EM-228	E CAPACITOR
	C3	QETB1EM-478	E CAPACITOR
	C4	QETB1CM-338	E CAPACITOR
	C5	QEH81JM-476	E CAPACITOR
	C6	QEH81JM-107	E CAPACITOR
Δ	C101	QCZ9016-472P	CAPACITOR
Δ	HD1	PU57505	FUSE CLIP,X4
Δ	HS1	PU59816	HEAT SINK
Δ	HS2	PU60151-1-1	HEAT SINK
Δ	LF1	PU59779	LINE FILTER
Δ	LF2	PU59586	LINE FILTER
	SCW1	DPSP3008Z	SCREW,X4
Δ	TAB1	A74316	TAB,X2
	SPC1	Q03095-208	WASHER,X2
	CN7	PU43351-104	CAP HOUSING
Δ	F1	QMF51E2-R80	FUSE, NOT INCL. P. TRANS. BOARD ASSY
Δ	F4	QMF51E2-2R0	FUSE, NOT INCL. P. TRANS. BOARD ASSY
-REGULATOR BOARD ASSEMBLY < 02 >-			
	PWBA	PB20117B2-03	REGULATOR BOARD ASSY
	Q1	2SB1015D,Y OR 2SB1185VQ(DE)	TRANSISTOR TRANSISTOR
	Q2	2SB644R,S	TRANSISTOR
	Q3	2SB644R,S	TRANSISTOR
	Q4	2SC3311A	TRANSISTOR
	Q5	2SB1068(KU)	TRANSISTOR
	Q6	2SC3311A	TRANSISTOR
	Q11	2SA1020(Y)	TRANSISTOR
	Q12	2SC3311A	TRANSISTOR
	Q13	2SD1449	TRANSISTOR
	D5	HZ12C1	ZENER DIODE
	D6	HZ30-2	ZENER DIODE

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
	D7	HZ4A2	ZENER DIODE
	D8	HZ6C2	ZENER DIODE
	D9	MA150	DIODE
	D10	MA150	DIODE
	D11	1SS133	DIODE
	R2	QRD181J-102	RESISTOR
	R3	QRD181J-822	RESISTOR
	R4	QRD181J-4R7	RESISTOR
	R5	QRD181J-272	RESISTOR
	R6	QRD181J-272	RESISTOR
	R7	QRD181J-682	RESISTOR
	R8	QRD181J-122	RESISTOR
	R9	QRD181J-272	RESISTOR
	R10	QRD181J-332	RESISTOR
	R11	QRD181J-682	RESISTOR
	R12	QRD181J-103	RESISTOR
	R13	QRD181J-272	RESISTOR
	R14	QRD181J-331	RESISTOR
	R15	QRD181J-471	RESISTOR
	R16	QRD181J-271	RESISTOR
	R17	QVZ3521-331	V RESISTOR, DC 5V
	R18	QRD181J-222	RESISTOR
	R19	QRD181J-103	RESISTOR
	R20	QRD181J-222	RESISTOR
	R21	QRD181J-561	RESISTOR
	R24	QRD181J-331	RESISTOR
	R25	QRD181J-331	RESISTOR
	R26	QRD181J-681	RESISTOR
	R27	QRD181J-102	RESISTOR
	C7	QETC1HM-106	E CAPACITOR
	C8	QETC1HM-226	E CAPACITOR
	C9	QETC1HM-107	E CAPACITOR
	C10	QETC1CM-476	E CAPACITOR
	C11	QCF31HP-103	CAPACITOR
	C12	QETC1CM-107	E CAPACITOR
	C13	QETC1CM-476	E CAPACITOR
	C14	QETC1CM-107	E CAPACITOR
	C15	QETC1VM-226	E CAPACITOR
	C17	QETC1CM-336	E CAPACITOR
	C20	QCF31HP-103	CAPACITOR
	C21	QCF31HP-103	CAPACITOR
	C22	QCF32HP-102	CAPACITOR
Δ	RY1	PU59457	RELAY
Δ	CP1	ICP-F25	CIRCUIT PROTECTOR
	TP	PU55774	TEST PIN, X3
	CN1	PU58931-16	HOUSING
	CN2	PU58844-109	CAP HOUSING
	CN6	PU58844-102	CAP HOUSING

* 7. MAIN BOARD ASSEMBLY <03><04> *			

	PWBA	PB10074B-03	MAIN BOARD ASSY
-VIDEO BOARD ASSEMBLY < 03 >-			

#△ REF NO.	PART NO.	PART NAME, DESCRIPTION
	PWBA PB10074B1	VIDEO BOARD ASSY
	IC101 PU22282B	Y.MODULE
	IC102 7VT12	IC
	IC201 TA7374P	IC
△	IC202 MSM6989RS	IC
△	IC301 PU22046A	C.MODULE
	IC351 BA7007	IC
	IC401 AN3592K	IC
	Q101 2SC1740S(QRS)	TRANSISTOR
	Q102 2SC1740S(QRS)	TRANSISTOR
	Q103 DTC124ES	TRANSISTOR
	Q104 2SC1740S(QRS)	TRANSISTOR
	Q105 2SC1740S(QRS)	TRANSISTOR
	Q106 2SC1740S(QRS)	TRANSISTOR
	Q111 2SC1740S(QRS)	TRANSISTOR
	Q112 2SA933S(RS)	TRANSISTOR
	Q113 2SA933S(RS)	TRANSISTOR
	Q201 DTC124ES	TRANSISTOR
	Q202 DTC124ES	TRANSISTOR
	Q203 DTC124ES	TRANSISTOR
	Q204 DTC124ES	TRANSISTOR
	Q208 2SC1740S(QRS)	TRANSISTOR
	Q209 2SC1740S(QRS)	TRANSISTOR
	Q210 2SC1740S(QRS)	TRANSISTOR
	Q211 2SA1309R,S	TRANSISTOR
	Q212 2SC1740S(QRS)	TRANSISTOR
	Q213 2SC1740S(QRS)	TRANSISTOR
	Q215 2SC1740S(QRS)	TRANSISTOR
	Q216 DTC124ES	TRANSISTOR
	Q217 DTC144WS	TRANSISTOR
	Q222 2SA933S(RS)	TRANSISTOR
	Q301 2SC1740S(QRS)	TRANSISTOR
	Q302 2SC1740S(QRS)	TRANSISTOR
	Q311 DTC124ES	TRANSISTOR
	Q312 DTC144WS	TRANSISTOR
	Q313 DTC144ES	TRANSISTOR
	Q314 DTC144ES	TRANSISTOR
	Q315 DTC144WS	TRANSISTOR
	Q316 DTC144ES	TRANSISTOR
	Q317 2SC1740S(QRS)	TRANSISTOR
	Q318 2SC1740S(QRS)	TRANSISTOR
	Q319 2SC1740S(QRS)	TRANSISTOR
	Q320 DTC144ES	TRANSISTOR
	Q321 DTC144ES	TRANSISTOR
	Q351 2SC1740S(QRS)	TRANSISTOR
	Q352 2SC1740S(QRS)	TRANSISTOR
	Q401 2SC1740S(QRS)	TRANSISTOR
	Q402 2SC1740S(QRS)	TRANSISTOR
	Q403 DTA144ES	TRANSISTOR
	Q404 2SC1740S(QRS)	TRANSISTOR
	Q405 2SC1740S(QRS)	TRANSISTOR
	Q406 2SC1740S(QRS)	TRANSISTOR
	Q407 2SC1740S(QRS)	TRANSISTOR
	Q411 2SC1740S(QRS)	TRANSISTOR
	Q412 DTC124ES	TRANSISTOR
	Q414 2SC1740S(QRS)	TRANSISTOR

#△ REF NO.	PART NO.	PART NAME, DESCRIPTION
	Q415 DTC124ES	TRANSISTOR
	Q416 DTC124ES	TRANSISTOR
	Q417 DTC124ES	TRANSISTOR
	Q418 DTC144ES	TRANSISTOR
	Q419 DTC143ES	TRANSISTOR
	Q420 DTC124ES	TRANSISTOR
	Q421 DTC124ES	TRANSISTOR
	Q422 DTC124ES	TRANSISTOR
	Q501 2SA933(S)	TRANSISTOR
	OR 2SA933S(S)	TRANSISTOR
	Q502 2SB643R,S	TRANSISTOR
	Q503 DTC144WS	TRANSISTOR
	Q504 2SB643R,S	TRANSISTOR
	Q505 2SB643R,S	TRANSISTOR
	Q506 DTC124ES	TRANSISTOR
	Q507 DTC124ES	TRANSISTOR
	D101 MA165	DIODE
	OR 1SS133	DIODE
	D102 MA165	DIODE
	OR 1SS133	DIODE
	D103 0A90	DIODE
	D104 0A90	DIODE
	D105 MA165	DIODE
	OR 1SS133	DIODE
	D106 MA165	DIODE
	OR 1SS133	DIODE
	D203 RD9.1ESB2	ZENER DIODE
	D207 MA165	DIODE
	OR 1SS133	DIODE
	D208 MA165	DIODE
	OR 1SS133	DIODE
	D209 MA165	DIODE
	OR 1SS133	DIODE
	D211 MA165	DIODE
	OR 1SS133	DIODE
	D212 1SS133	DIODE
	D231 MA165	DIODE
	OR 1SS133	DIODE
	D301 MA165	DIODE
	OR 1SS133	DIODE
	D302 MA165	DIODE
	OR 1SS133	DIODE
	D303 MA165	DIODE
	OR 1SS133	DIODE
	D305 MA165	DIODE
	OR 1SS133	DIODE
	D306 MA165	DIODE
	OR 1SS133	DIODE
	D307 MA165	DIODE
	OR 1SS133	DIODE
	D308 MA165	DIODE
	OR 1SS133	DIODE
	D351 MA165	DIODE
	OR 1SS133	DIODE
	D352 MA165	DIODE
	OR 1SS133	DIODE
	D353 MA165	DIODE
	OR 1SS133	DIODE
	D354 MA165	DIODE
	OR 1SS133	DIODE
	D355 MA165	DIODE
	OR 1SS133	DIODE
	D356 MA165	DIODE
	OR 1SS133	DIODE
	D357 MA165	DIODE
	OR 1SS133	DIODE

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
	D358	MA165 OR 1SS133	DIODE DIODE
	D403	MA165 OR 1SS133	DIODE DIODE
	D405	MA165 OR 1SS133	DIODE DIODE
	D407	MA165 OR 1SS133	DIODE DIODE
	D408	MA165 OR 1SS133	DIODE DIODE
	D409	MA165 OR 1SS133	DIODE DIODE
	D501	MA165 OR 1SS133	DIODE DIODE
	D502	MA165 OR 1SS133	DIODE DIODE
	D503	MA165 OR 1SS133	DIODE DIODE
	D504	MA165 OR 1SS133	DIODE DIODE
	D505	MA165 OR 1SS133	DIODE DIODE
	D507	MA165 OR 1SS133	DIODE DIODE
	D615	MA165 OR 1SS133	DIODE DIODE
	R101	QRD161J-332	RESISTOR
	R102	QRD161J-152	RESISTOR
	R103	QRD161J-102	RESISTOR
	R104	QRD161J-122	RESISTOR
	R105	QRD161J-821	RESISTOR
	R106	QRD161J-471	RESISTOR
	R107	QRD161J-102	RESISTOR
	R108	QRD161J-152	RESISTOR
	R109	QRD161J-101	RESISTOR
	R110	QVZ3518-222	V RESISTOR, SP PB FREQ & CH BAL
	R112	QRD161J-561	RESISTOR
	R113	QRD161J-222	RESISTOR
	R114	QRD161J-222	RESISTOR
	R115	QRD161J-391	RESISTOR
	R116	QRD161J-333	RESISTOR
	R117	QRD161J-333	RESISTOR
	R119	QVZ3518-102	V RESISTOR, REC FM LEVEL
	R120	QRD161J-221	RESISTOR
	R121	QRD161J-472	RESISTOR
	R122	QRD161J-333	RESISTOR
	R123	QRD161J-562	RESISTOR
	R124	QRD161J-225	RESISTOR
	R125	QRD161J-475	RESISTOR
	R126	QRD161J-335	RESISTOR
	R127	QRD161J-102	RESISTOR
	R128	QRD161J-152	RESISTOR
	R130	QRD161J-684	RESISTOR
	R131	QRD162J-824	RESISTOR
	R132	QRD161J-562	RESISTOR
	R133	QRD161J-152	RESISTOR
	R136	QRD161J-102	RESISTOR
	R138	QRD161J-681	RESISTOR
	R141	QRD161J-102	RESISTOR
	R142	QRD161J-272	RESISTOR
	R143	QRD161J-181	RESISTOR
	R144	QRD161J-821	RESISTOR
	R145	QRD161J-181	RESISTOR
	R146	QRD121J-391	RESISTOR
	R147	QRD161J-223	RESISTOR
	R148	QRD161J-472	RESISTOR

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
	R149	QRD161J-682	RESISTOR
	R150	QRD162J-475	RESISTOR
	R202	QVZ3518-102	V RESISTOR, LP PB FREQ & CH BAL
	R203	QRD161J-471	RESISTOR
	R204	QRD162J-101	RESISTOR
	R211	QRD162J-562	RESISTOR
	R214	QRD161J-391	RESISTOR
	R215	QRD161J-122	RESISTOR
	R216	QRD161J-681	RESISTOR
	R217	QRD121J-181	CARBON RESISTOR
	R218	QRD161J-103	RESISTOR
	R219	QRD161J-222	RESISTOR
	R220	QRD161J-393	RESISTOR
	R221	QRD161J-473	RESISTOR
	R222	QRD161J-332	RESISTOR
	R223	QVZ3518-682	V RESISTOR, 0.5H DELAY
	R224	QRD161J-102	RESISTOR
	R225	QRD161J-122	RESISTOR
	R226	QRD161J-153	RESISTOR
	R227	QRD161J-223	RESISTOR
	R228	QRD161J-561	RESISTOR
	R229	QRD161J-681	RESISTOR
	R230	QRD161J-681	RESISTOR
	R231	QRD161J-681	RESISTOR
	R232	QRD161J-471	RESISTOR
	R233	QRD161J-222	RESISTOR
	R234	QRD161J-102	RESISTOR
	R235	QRD161J-222	RESISTOR
	R236	QRD161J-103	RESISTOR
	R238	QRD161J-822	RESISTOR
	R239	QRD161J-122	RESISTOR
	R240	QRD162J-563	RESISTOR
	R241	QRD162J-822	RESISTOR
	R242	QRD161J-223	RESISTOR
	R243	QRD161J-103	RESISTOR
	R244	QRD161J-103	RESISTOR
	R245	QRD161J-103	RESISTOR
	R246	QRD161J-333	RESISTOR
	R267	QRD161J-391	RESISTOR
	R301	QRD161J-102	RESISTOR
	R302	QRD161J-102	RESISTOR
	R303	QRD161J-473	RESISTOR
	R304	QRD161J-272	RESISTOR
	R305	QRD161J-681	RESISTOR
	R306	QRD161J-102	RESISTOR
	R307	QRD161J-102	RESISTOR
	R311	QRD161J-562	RESISTOR
	R312	QRD161J-221	RESISTOR
	R313	QRD161J-102	RESISTOR
	R316	QRD161J-221	RESISTOR
	R317	QRD161J-391	RESISTOR
	R318	QRD161J-122	RESISTOR
	R319	QRD161J-393	RESISTOR
	R320	QRD161J-103	RESISTOR
	R321	QRD161J-103	RESISTOR
	R322	QVZ3518-331	V RESISTOR, SP REC COLOR LEV
	R323	QRD162J-821	RESISTOR
	R325	QRD161J-102	RESISTOR
	R326	QRD161J-472	RESISTOR
	R327	QRD161J-274	RESISTOR
	R328	QVZ3518-223	V RESISTOR, VXO
	R329	QRD161J-103	RESISTOR
	R330	QRD161J-122	RESISTOR
	R331	QRD161J-222	RESISTOR

#△	REF NO.	PART NO.	PART NAME, DESCRIPTION
R332	QRD161J-103	RESISTOR	
R333	QRD161J-103	RESISTOR	
R334	QRD161J-102	RESISTOR	
R335	QRD161J-122	RESISTOR	
R336	QRD161J-471	RESISTOR	
R337	QRD161J-152	RESISTOR	
R338	QRD161J-223	RESISTOR	
R339	QRD161J-682	RESISTOR	
R340	QRD161J-102	RESISTOR	
R341	QRD161J-181	RESISTOR	
R342	QRD161J-391	RESISTOR	
R343	QRD161J-331	RESISTOR	
R344	QRD161J-562	RESISTOR	
R346	QRD161J-222	RESISTOR	
R347	QRD161J-153	RESISTOR	
R348	QRD161J-103	RESISTOR	
R351	QRD161J-332	RESISTOR	
R352	QRD161J-154	RESISTOR	
R353	QRD161J-563	RESISTOR	
R354	QRD161J-182	RESISTOR	
R355	QVZ3518-472	V RESISTOR, SECAM DET	
R356	QRD161J-103	RESISTOR	
R357	QRD161J-562	RESISTOR	
R358	QRD161J-333	RESISTOR	
R359	QRD161J-393	RESISTOR	
R360	QRD161J-102	RESISTOR	
R361	QRD161J-393	RESISTOR	
R362	QRD161J-393	RESISTOR	
R363	QRD161J-822	RESISTOR	
R364	QRD161J-223	RESISTOR	
R365	QRD161J-333	RESISTOR	
R401	QVZ3518-222	V RESISTOR, 1H DELAY COLOR LEV	
R402	QRD161J-222	RESISTOR	
R403	QRD161J-272	RESISTOR	
R404	QRD161J-821	RESISTOR	
R405	QRD161J-222	RESISTOR	
R407	QRD161J-104	RESISTOR	
R408	QRD161J-391	RESISTOR	
R409	QRD161J-123	RESISTOR	
R410	QRD161J-332	RESISTOR	
R413	QRD161J-223	RESISTOR	
R414	QRD161J-103	RESISTOR	
R415	QRD161J-154	RESISTOR	
R416	QRD161J-221	RESISTOR	
R417	QRD161J-393	RESISTOR	
R418	QVZ3518-473	V RESISTOR, 0.5H DELAY JUMP DET	
R420	QRD161J-122	RESISTOR	
R421	QRD161J-101	RESISTOR	
R423	QRD161J-222	RESISTOR	
R424	QRD161J-561	RESISTOR	
R425	QRD161J-561	RESISTOR	
R426	QRD161J-393	RESISTOR	
R427	QRD161J-223	RESISTOR	
R428	QRD161J-391	RESISTOR	
R429	QRD161J-223	RESISTOR	
R431	QRD161J-682	RESISTOR	
R432	QRD161J-104	RESISTOR	
R433	QRD161J-473	RESISTOR	
R434	QRD161J-472	RESISTOR	
R435	QRD161J-682	RESISTOR	
R436	QRD161J-103	RESISTOR	
R437	QRD161J-153	RESISTOR	
R438	QVZ3518-331	V RESISTOR, LP REC COLOR LEVEL	
R439	QRD161J-822	RESISTOR	
R440	QRD161J-102	RESISTOR	
R441	QRD161J-272	RESISTOR	

#△	REF NO.	PART NO.	PART NAME, DESCRIPTION
R442	QRD162J-683	RESISTOR	
R443	QRD161J-183	RESISTOR	
R444	QRD161J-333	RESISTOR	
R446	QRD161J-562	RESISTOR	
R448	QRD161J-562	RESISTOR	
R501	QRD161J-393	RESISTOR	
R502	QRD161J-682	RESISTOR	
R503	QRD161J-393	RESISTOR	
R504	QRD161J-103	RESISTOR	
R505	QRD161J-103	RESISTOR	
R506	QRD161J-393	RESISTOR	
R507	QRD161J-103	RESISTOR	
R508	QRD161J-393	RESISTOR	
R509	QRD161J-103	RESISTOR	
R510	QRD161J-103	RESISTOR	
R511	QRD161J-103	RESISTOR	
R512	QRD161J-332	RESISTOR	
C101	QCVB1CN-103	CAPACITOR	
C102	QCSB1HJ-680	CAPACITOR	
C103	QCSB1HJ-330	CAPACITOR	
C104	QET60JM-476	E CAPACITOR	
C105	QCVB1CN-103	CAPACITOR	
C106	QCSB1HJ-470	CAPACITOR	
C107	QCVB1CN-103	CAPACITOR	
C108	QCVB1CN-103	CAPACITOR	
C110	QCVB1CN-103	CAPACITOR	
C112	QCVB1CN-103	CAPACITOR	
C113	QCVB1CN-103	CAPACITOR	
C114	QCB01HJ-121	CAPACITOR	
C115	QCB01HJ-121	CAPACITOR	
C116	QCSB1HJ-360	CAPACITOR	
C117	QET60JM-476	E CAPACITOR	
C118	QCVB1CN-103	CAPACITOR	
C121	QCB01HJ-151	CAPACITOR	
C122	QCSB1HJ-330	CAPACITOR	
C123	QET61HM-105	E CAPACITOR	
C124	QETB1HM-105	E CAPACITOR	
C125	QCB01HJ-151	CAPACITOR	
C126	QCB01HJ-151	CAPACITOR	
C127	QET61HM-225	E CAPACITOR	
C128	QER60JM-107	E CAPACITOR	
C129	QER60JM-107	E CAPACITOR	
C130	QET61EM-335	E CAPACITOR	
C131	QER41HM-105	E CAPACITOR	
C132	QER41HM-225	E CAPACITOR	
C133	QER40JM-476	E CAPACITOR	
C134	QER41HM-225	E CAPACITOR	
C135	QER41CM-106	E CAPACITOR	
C136	QEN41EM-335	NP E CAPACITOR	
C137	QEM51AK-107	E CAPACITOR	
C138	QCVB1CN-103	CAPACITOR	
C139	QCB01HJ-181	CAPACITOR	
C140	QCB01HJ-121	CAPACITOR	
C141	QCSB1HJ-560	CAPACITOR	
C142	QCSB1HJ-220	CAPACITOR	
C144	QCB01HJ-121	CAPACITOR	
C145	QCB01HJ-151	CAPACITOR	
C146	QET61EM-475	E CAPACITOR	
C147	QET61CM-476	E CAPACITOR	
C148	QCVB1CN-103	CAPACITOR	
C149	QCSB1HJ-220	CAPACITOR	
C151	QCVB1CN-103	CAPACITOR	
C152	QCVB1CN-103	CAPACITOR	
C153	QCVB1CN-103	CAPACITOR	
C154	QCSB1HJ-390	CAPACITOR	

*△ REF NO.	PART NO.	PART NAME, DESCRIPTION
C201	QCSB1HJ-160	CAPACITOR
C202	QFN31HJ-223	M CAPACITOR
C211	QCVB1CN-103	CAPACITOR
C212	QCSB1HJ-100	CAPACITOR
C213	QCVB1CN-103	CAPACITOR
C214	QEK60JM-476	E CAPACITOR
C217	QFN31HJ-102	M CAPACITOR
C218	QEK61EM-475	E CAPACITOR
C219	QCB81HJ-102	CAPACITOR
C220	QFN31HJ-473	M CAPACITOR
C221	QEK61AM-107	E CAPACITOR
C222	QCVB1CN-103	CAPACITOR
C224	QEK61HM-104	E CAPACITOR
C225	QEK61EM-475	E CAPACITOR
C226	QCVB1CN-103	CAPACITOR
C227	QCVB1CN-103	CAPACITOR
C229	QEK60JM-476	E CAPACITOR
C230	QCVB1CN-103	CAPACITOR
C233	QER41CM-106	E CAPACITOR
C234	QER41CM-476	E CAPACITOR
C235	QCVB1CN-103	CAPACITOR
C236	QCSB1HJ-330	CAPACITOR
C237	QCSB1HJ-270	CAPACITOR
C238	QER41AM-476	E CAPACITOR
C239	QCSB1HJ-200	CAPACITOR
C241	QCVB1CN-103	CAPACITOR
C242	QCSB1HJ-330	CAPACITOR
C243	QCB81HJ-221	CAPACITOR
C244	QER40JM-107	E CAPACITOR
C245	QCVB1CN-103	CAPACITOR
C246	QEK61HM-104	E CAPACITOR
C247	QEK61HM-105	E CAPACITOR
C248	QETA1AM-476	E CAPACITOR
C249	QER41HM-335	E CAPACITOR
C250	QEK41HM-225	E CAPACITOR
C251	QCS31HJ-561	CAPACITOR
C252	QCC11EK-223ZR	CAPACITOR
C302	QCB81HJ-820	CAPACITOR
C303	QCB81HJ-102	CAPACITOR
C304	QCVB1CN-103	CAPACITOR
C305	QFN31HJ-473	M CAPACITOR
C306	QCSB1HJ-470	CAPACITOR
C311	QET61CM-106	E CAPACITOR
C312	QET61HM-474	E CAPACITOR
C313	QFN31HJ-563	M CAPACITOR
C314	QET61CM-106	E CAPACITOR
C315	QET61HM-225	E CAPACITOR
C316	QET61EM-335	E CAPACITOR
C317	QFN31HJ-473	M CAPACITOR
C318	QCVB1CN-103	CAPACITOR
C319	QET61EM-475	E CAPACITOR
C320	QEM51AK-107	E CAPACITOR
C321	QCVB1CN-103	CAPACITOR
C322	QET61HM-105	E CAPACITOR
C323	QET61HM-475	E CAPACITOR
C324	QET61HM-475	E CAPACITOR
C325	QCVB1CN-103	CAPACITOR
C326	QCVB1CN-103	CAPACITOR
C327	QET61HM-105	E CAPACITOR
C328	QFN31HJ-223	M CAPACITOR
C329	QCT25CH-220	CAPACITOR
C330	QCVB1CN-103	CAPACITOR
C331	QET61CM-106	E CAPACITOR
C332	QCB81HJ-101	CAPACITOR
C333	QCVB1CN-103	CAPACITOR

*△ REF NO.	PART NO.	PART NAME, DESCRIPTION
C334	QCB81HJ-102	CAPACITOR
C335	QET61AM-476	E CAPACITOR
C336	QCVB1CN-103	CAPACITOR
C337	QCSB1HJ-100	CAPACITOR
C338	QCB81HJ-681	CAPACITOR
C339	QCC11EJ-104	CAPACITOR
C340	QCC11EK-273	CAPACITOR
	OR QCC11EK-273ZR	CAPACITOR
C351	QET61CM-476	E CAPACITOR
C352	QCVB1CN-103	CAPACITOR
C353	QET61AM-336	E CAPACITOR
C354	QFN31HJ-182	M CAPACITOR
C355	QFN31HJ-272	M CAPACITOR
C356	QFN31HJ-223	M CAPACITOR
C357	QETB1CM-106	E CAPACITOR
C358	QCVB1CN-103	CAPACITOR
C359	QCB81HJ-102	CAPACITOR
C401	QCVB1CN-103	CAPACITOR
C402	QCSB1HJ-220	CAPACITOR
C403	QCSB1HJ-220	CAPACITOR
C404	QCVB1CN-103	CAPACITOR
C406	QET61HM-105	E CAPACITOR
C407	QET61HM-105	E CAPACITOR
C408	QET61EM-475	E CAPACITOR
C409	QET61HM-105	E CAPACITOR
C410	QFN31HJ-152	M CAPACITOR
C411	QFN31HJ-332	M CAPACITOR
C412	QCVB1CN-103	CAPACITOR
C413	QCVB1CN-103	CAPACITOR
C414	QET60JM-107	E CAPACITOR
C415	QCVB1CN-103	CAPACITOR
C416	QFN31HJ-222	M CAPACITOR
C417	QFN31HJ-103	M CAPACITOR
C418	QFN31HJ-273	M CAPACITOR
C419	QFN31HJ-222	M CAPACITOR
C420	QET61HM-105	E CAPACITOR
C421	QCVB1CN-103	CAPACITOR
C422	QCVB1CN-103	CAPACITOR
C423	QCSB1HJ-680	CAPACITOR
C424	QCVB1CN-103	CAPACITOR
C426	QCVB1CN-103	CAPACITOR
C427	QCVB1CN-103	CAPACITOR
C432	QFN31HJ-103	M CAPACITOR
C433	QFN31HJ-104	M CAPACITOR
C436	QET51AM-226	E CAPACITOR
C437	QCB81HJ-181	CAPACITOR
L101	PU48530-101K	PEAKING COIL
L102	PU59152-560J	PEAKING COIL
L103	PU59152-270J	PEAKING COIL
L104	PU59152-180J	PEAKING COIL
L106	PU59152-221J	PEAKING COIL
L107	PU59152-470J	PEAKING COIL
L108	PU59152-270J	PEAKING COIL
L109	PU48530-101K	PEAKING COIL
L111	PU59152-121J	PEAKING COIL
L112	PU59152-180J	PEAKING COIL
L113	PU59152-180J	PEAKING COIL
L114	PU48530-471J	PEAKING COIL
L115	PU59152-121J	PEAKING COIL
L116	PU48530-101K	PEAKING COIL
L117	PU59152-560J	PEAKING COIL
L118	PU59152-680J	PEAKING COIL
L119	PU48530-681J	PEAKING COIL
L121	PU48530-101K	PEAKING COIL
L122	PU48530-331J	PEAKING COIL

#△	REF NO.	PART NO.	PART NAME, DESCRIPTION
L201		PU48530-101K	PEAKING COIL
L202		PU48530-101K	PEAKING COIL
L203		PU48530-101K	PEAKING COIL
L204		PU59152-560J	PEAKING COIL
L205		PU59152-390J	PEAKING COIL
L206		PU48530-101K	PEAKING COIL
L207		PU48530-101K	PEAKING COIL
L302		PU48530-222J	PEAKING COIL
L303		PU54223-271J	PEAKING COIL
L311		PU47051-822	COIL
L312		PU48530-101K	PEAKING COIL
L313		PU59153-101K	INDUCTOR
L314		PU59152-150J	PEAKING COIL
L315		PU59152-680J	PEAKING COIL
L316		PU48530-101K	PEAKING COIL
L351		PU49057	LC BLOCK, 1/2 FH TUNING
L352		PU53223-101J	PEAKING COIL
L353		PU47051-562	COIL
L401		PU49057	LC BLOCK, APC ERROR PHASE
L402		PU57139	LC BLOCK
L403		PU59152-330J	PEAKING COIL
L404		PU48530-101K	PEAKING COIL
L405		PU59152-100J	PEAKING COIL
EQ201		PU58315	EQUALIZER
EQ301		PU53501-7	EQUALIZER
LPF101		PU58021-2	LOW PASS FILTER
		OR PU58021-3	LOW PASS FILTER
LPF301		PU58022	LOW PASS FILTER
LPF302		PU54988	LOW PASS FILTER
		OR PU54988-2	LOW PASS FILTER
BPF301		PU54410-2	BAND PASS FILTER
BPF302		PU57072	BAND PASS FILTER
CF351		PU56983	CERAMIC FILTER
DL101		PU59173	1H DELAY LINE
DL301		PU60340	COMB FILTER
		OR PU58971-3	2H DELAY LINE
		OR PU60222	2H DELAY LINE
XB301		PU58023	CRYSTAL BLOCK
△ X301		PU60307	CRYSTAL RESONATOR
		OR PU59335	CRYSTAL RESONATOR
		OR PU31449-4K	CRYSTAL RESONATOR
TH101		ERT-D2FGL101S	THERMISTOR
SLD1		PU59170	CCD SHIELD 1
SLD2		PU59171	CCD SHIELD 2
SLD3		PU59172-1-1	CCD SHIELD 3
TP		PU57545	TEST PIN, X18
TP 401		PU56347	TEST POINT
TP		PU59391	STYLE PIN
			-VIDEO SUB BOARD ASSEMBLY (1)-
PWBA		PB40007A	VIDEO SUB BOARD ASSY (1)
IC203		BA7021	IC
Q221		DTA144EF	TRANSISTOR
D221		1SS133	DIODE
R251		QRD162J-333	RESISTOR

#△	REF NO.	PART NO.	PART NAME, DESCRIPTION
R252		QRD162J-332	RESISTOR
C261		QEK51HM-104	E CAPACITOR
C262		QCSC1HJ-330	CAPACITOR
TML1		PU59935-10	TERMINAL
			-VIDEO SUB BOARD ASSEMBLY (3)-
PWBA		PB40021A-01	VIDEO SUB BOARD ASSY (3)
IC211		BA7001	IC
Q231		2SC1740S(QRS)	TRANSISTOR
R261		QRD121J-271	RESISTOR
R262		QRD162J-223	RESISTOR
R263		QRD162J-103	RESISTOR
R264		QRD162J-103	RESISTOR
R265		QRD162J-103	RESISTOR
R266		QRD162J-103	RESISTOR
C271		QER40JM-336	E CAPACITOR
C272		QER41CM-476	E CAPACITOR
C273		QCV81CN-103	CAPACITOR
C274		QCSB1HJ-100	CAPACITOR
L211		PU48530-101K	PEAKING COIL
SPC		PU57215-2	SPACER, X2
CN102		PU58844-2	CAP HOUSING
CN111		PU58844-7	CAP HOUSING
			-MECHACON BOARD ASSEMBLY < 04 >-
PWBA		PB10074B2	MECHACON BOARD ASSEMBLY
IC601		M50965-644SP	IC
		OR M50965E-322SP	IC
IC602		BA6259N	IC
IC603		M54647L	IC
IC604		BA6222	IC
△ Q601		2SC1317(RS)	TRANSISTOR
Q603		DTC114ES	TRANSISTOR
Q604		2SB641R,S	TRANSISTOR
Q605		DTC114ES	TRANSISTOR
D601		1SS133	DIODE
		OR MA165	DIODE
D602		1SS133	DIODE
		OR MA165	DIODE
D603		HZ54.3EB2	ZENER DIODE
△ D604		HZ57.5EB2	ZENER DIODE
D607		1SS133	DIODE
		OR MA165	DIODE
D608		1SS133	DIODE
		OR MA165	DIODE
D609		1SS133	DIODE
		OR MA165	DIODE
R601		QRD161J-152	RESISTOR
R602		QRD161J-103	RESISTOR
R603		QRD161J-103	RESISTOR
R604		QRD161J-122	RESISTOR
R605		QRD161J-823	RESISTOR
R606		QRD161J-102	RESISTOR

#△ REF NO.	PART NO.	PART NAME, DESCRIPTION
R607	QRD161J-102	RESISTOR
R608	QRD161J-102	RESISTOR
R609	QRD161J-472	RESISTOR
R610	QRD161J-103	RESISTOR
R611	QRD161J-105	RESISTOR
R614	QRD161J-472	RESISTOR
R615	QRD161J-472	RESISTOR
R616	QRD161J-472	RESISTOR
R617	QRD161J-472	RESISTOR
R618	QRD161J-472	RESISTOR
R619	QRD161J-472	RESISTOR
R620	QRD161J-472	RESISTOR
R621	QRD161J-472	RESISTOR
R622	QRD161J-472	RESISTOR
R623	QRD161J-472	RESISTOR
R624	QRD161J-472	RESISTOR
R625	QRD161J-472	RESISTOR
R626	QRD161J-472	RESISTOR
R627	QRD161J-472	RESISTOR
R628	QRD161J-124	RESISTOR
R629	QRD161J-124	RESISTOR
R630	QRD161J-333	RESISTOR
R632	QRD161J-332	RESISTOR
R633	QRD161J-103	RESISTOR
R634	QRD161J-822	RESISTOR
R635	QRD161J-331	RESISTOR
R640	QRD161J-333	RESISTOR
R641	QRD161J-333	RESISTOR
R643	QRD161J-124	RESISTOR
R645	QRD161J-103	RESISTOR
R646	QRD161J-393	RESISTOR
R648	QRD161J-103	RESISTOR
R649	QRD161J-272	RESISTOR
RA602	QRB049J-103	RESISTOR ARRAY
RA603	QRB049J-472	RESISTOR ARRAY
C601	QCFB1EZ-223	CAPACITOR
C602	QCFB1EZ-223	CAPACITOR
C603	QCC11EK-473	CAPACITOR
C604	QETC1EM-335	E CAPACITOR
C605	QETC1EM-475	E CAPACITOR
C608	QETC1HM-105	E CAPACITOR
C611	QETC1EM-106	E CAPACITOR
C612	QETC1EM-106	E CAPACITOR
C615	QCFB1EZ-223	CAPACITOR
L601	PUS9152-100J	PEAKING COIL
△ CF601	PU60030	RESONATOR
△ OR	PU60125	RESONATOR
ICP601	ICP-N10	CIRCUIT PROTECT
HD1	PUS7951	TUNER BOARD HINGE, X2
△ HS1	PU60346	HEAT SINK
RV1	PUS2105	P RIVET
SCW1	SBSE3006Z	TAPPING SCREW,X2
SCW2	SBSE3008Z	TAPPING SCREW
SPC1	PQ41028-2	SPACER
SPC2	PQM30029-100	SPACER
WR1	PW30109-50AAZ26	PARALLEL WIRE
WR2	PW30109-50AAZ2C	PARALLEL WIRE
WR3	PUS8665-3	FLAT WIRE
CN601	PUS8931-14	HOUSING
CN602	PUS8931-10	HOUSING

#△ REF NO.	PART NO.	PART NAME, DESCRIPTION
CN603	PUS8931-14	HOUSING
CN604	PUS8931-8	HOUSING
CN605	PUS8931-14	HOUSING
CN606	PUS8931-6	HOUSING
CN607	PUS8798-17	CONNECTOR
CN608	PUS8844-6	CAP HOUSING

* 8. MOTHER BOARD ASSEMBLY <05> *		

PWBA	PB10026B-02	MOTHER BOARD ASSY
R1	QRD182J-183	RESISTOR
L1	PUS9152-101J	PEAKING COIL
CN1	PUS8930-16	CAP HOUSING
CN2	PUS8930-14	CAP HOUSING
CN3	PUS8930-10	CAP HOUSING
CN4	PUS8930-14	CAP HOUSING
CN5	PUS8930-8	CAP HOUSING
CN6	PUS8930-14	CAP HOUSING
CN7	PUS8930-6	CAP HOUSING
CN8	PUS8930-14	CAP HOUSING
CN9	PUS8930-16	CAP HOUSING
CN10	PUS8928-14	CAP HOUSING
CN11	PUS8844-7	CAP HOUSING
CN12	PUS8844-10	CAP HOUSING
CN13	PUS8928-6	CAP HOUSING
CN14	PUS8928-9	CAP HOUSING
CN15	PUS8928-5	CAP HOUSING
CN16	PUS8928-8	CAP HOUSING
CN17	PUS8930-22	CAP HOUSING
CN18	PUS8928-13	CAP HOUSING
CN19	PUS8928-18	CAP HOUSING
CN20	PUS8928-20	CAP HOUSING
CN22	PUS8844-8	CAP HOUSING
CN24	PUS8844-2R	CAP HOUSING
CN25	PUS8928-3	CAP HOUSING
CN26	PUS8928-8	CAP HOUSING
CN30	PUS8928-4	CAP HOUSING
CN31	PUS8930-8	CAP HOUSING

* 9. TERMINAL BOARD ASSEMBLY <06> *		

PWBA	PU22307BB-03	TERMINAL BOARD ASSY, EG
	PU22307BE-03	TERMINAL BOARD ASSY, E
IC1	BX6325	IC
OR	10VT27	IC
Q1	2SC1740S(QRS)	TRANSISTOR
Q13	2SA1309Q,R,S	TRANSISTOR

*Δ REF NO.	PART NO.	PART NAME, DESCRIPTION	*Δ REF NO.	PART NO.	PART NAME, DESCRIPTION
D1	MA165	DIODE			
	OR 1SS133	DIODE	Q 4	2SC3311A(RS)	TRANSISTOR
D5	MA165	DIODE		2SC1740S(RS)	TRANSISTOR
	OR 1SS133	DIODE		OR 2SC3311A(RS)	TRANSISTOR
D11	MA165	DIODE	Q 5	2SA933S(RS)	TRANSISTOR
	OR 1SS133	DIODE		OR 2SA1309R,S	TRANSISTOR
R2	QRD161J-102	RESISTOR	Q 6	2SC1740S(RS)	TRANSISTOR
R3	QRD161J-102	RESISTOR		OR 2SC3311A(RS)	TRANSISTOR
R4	QRD161J-102	RESISTOR	Q 7	2SC1740S(RS)	TRANSISTOR
R5	QRD161J-221	RESISTOR		OR 2SC3311A(RS)	TRANSISTOR
R6	QRD161J-750	RESISTOR	Q 9	2SB808SPA(FG)	TRANSISTOR
R7	QRD161J-750	RESISTOR	Q10	2SB808SPA(FG)	TRANSISTOR
R25	QRD181J-102	RESISTOR	Q11	2SB808SPA(FG)	TRANSISTOR
R27	QRD181J-102	RESISTOR	Q12	2SB808SPA(FG)	TRANSISTOR
R30	QRD161J-123	RESISTOR	Q13	2SK381(C)	FE TRANSISTOR
R33	QRD161J-123	RESISTOR	Q14	2SC1740S(RS)	TRANSISTOR
R45	QRD161J-102	RESISTOR		OR 2SC3311A(RS)	TRANSISTOR
R47	QRD161J-102	RESISTOR	Q15	2SD1468S(RSE)	TRANSISTOR
R51	QRD161J-393	RESISTOR		OR 2SD1450S,T	TRANSISTOR
R52	QRD161J-152	RESISTOR	Q16	2SD1863(QR)	TRANSISTOR
C1	QEK61CM-476	E CAPACITOR		OR 2SC3243D,E	TRANSISTOR
C2	QEK61CM-476	E CAPACITOR	Q17	2SB1010(QR)	TRANSISTOR
C3	QETC0JM-477	E CAPACITOR	Q18	DTA124ES	TRANSISTOR
C4	QETC1CM-476	E CAPACITOR	Q21	2SC1740S(RS)	TRANSISTOR
C5	QETC1CM-476	E CAPACITOR		OR 2SC3311A(RS)	TRANSISTOR
C6	QEK61CM-476	E CAPACITOR	Q22	2SA933S(RS)	TRANSISTOR
L1	PU48530-101K	PEAKING COIL		OR 2SA1309R,S	TRANSISTOR
EQ1	PUS4838	EQUALIZER	Q23	2SC1740S(RS)	TRANSISTOR
LC1	PUS9885-102	N FILTER		OR 2SC3311A(RS)	TRANSISTOR
LC2	PUS9885-102	N FILTER	Q24	2SC3354	TRANSISTOR
LC3	PUS9885-102	N FILTER	Q26	DTC144ES	TRANSISTOR
LC4	PUS9885-102	N FILTER	D 1	1SS133	DIODE
RY1	PUS5260	RELAY	D 2	1SS133	DIODE
Δ TML	PUS9260-62	TERMINAL BOARD,E	D 3	1SS133	DIODE
Δ	PUS9260-55	TERMINAL BOARD,E	D 4	1SS133	DIODE
CN1	PUS8929-14	HOUSING	D 5	1SS133	DIODE
CN3	PUS8962-6	CAP HOUSING	D 6	H230-2	ZENER DIODE

* 10. TUNER/IF BOARD ASSEMBLY <07> *					

PWBA	PB20093D	TUNER/IF BOARD ASSY,E	D 7	MTZ108	ZENER DIODE
	PB20093J	TUNER/IF BOARD ASSEMBLY, EG		OR RD10ES-T182	ZENER DIODE
Δ RF	PUS9241M-2	RF CONV.& MIXER	D 8	1SS133	DIODE
Δ TNR	PU36155-1-4	U/V TUNER,EG	D 9	MTZ7.5B	ZENER DIODE
Δ	PU36155-1-3	U/V TUNER,E		OR RD7.5ES-T182	ZENER DIODE
Δ	OR PU36155-1-4	U/V TUNER,E	D10	E-452-2	DIODE
IC 1	M51365SP	IC	D11	RD5.6ES-T183	ZENER DIODE
IC 2	M50440-397SP	IC		OR MTZ5.6C	ZENER DIODE
IC 3	M58655P	IC	D12	1SS133	DIODE
Q 1	2SC2636S,T	TRANSISTOR	R 1	QRD161J-151	RESISTOR
Q 3	2SC1740S(RS)	TRANSISTOR	R 2	QRD161J-822	RESISTOR
			R 3	QRD161J-392	RESISTOR
			R 4	QRD161J-470	RESISTOR
			R 6	QRD161J-681	RESISTOR
			R 7	QRD161J-271	RESISTOR
			R 8	QRD161J-120	RESISTOR
			R10	QRD161J-824	RESISTOR
			R11	QVZ3518-472	V RESISTOR,RF AGC
			R12	QRD161J-222	RESISTOR
			R13	QRD161J-562	RESISTOR
			R14	QRD161J-332	RESISTOR
			R15	QRD161J-152	RESISTOR
			R16	QVZ3518-103	V RESISTOR, Y LEVEL
			R17	QRD161J-331	RESISTOR
			R18	QRD161J-561	RESISTOR
			R19	QRD161J-470	RESISTOR
			R20	QRD161J-561	RESISTOR
			R23	QRD161J-473	RESISTOR
			R40	QRD161J-182	RESISTOR

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
R41	QRD161J-272	RESISTOR	
R42	QVZ3518-103	V RESISTOR, COLOR LEVEL	
R43	QRD161J-123	RESISTOR	
R44	QRD161J-123	RESISTOR	
R45	QRD161J-331	RESISTOR	
R46	QRD161J-222	RESISTOR	
R49	QRD161J-331	RESISTOR	
R50	QRD161J-680	RESISTOR	
R51	QRD161J-222	RESISTOR	
R52	QRD161J-471	RESISTOR	
R53	QRD161J-103	RESISTOR	
R54	QRD161J-332	RESISTOR	
R55	QRD161J-680	RESISTOR	
R56	QRD161J-223	RESISTOR	
R57	QRD161J-471	RESISTOR	
R58	QRD161J-102	RESISTOR	
R59	QRD161J-223	RESISTOR	
R60	QRD161J-103	RESISTOR	
R61	QRD161J-334	RESISTOR	
R62	QRD161J-103	RESISTOR	
R63	QRD161J-331	RESISTOR	
R75	QRD161J-472	RESISTOR	
R76	QRD161J-103	RESISTOR	
R77	QRD161J-153	RESISTOR	
R78	QRD161J-472	RESISTOR	
R79	QRD161J-103	RESISTOR	
R80	QRD161J-153	RESISTOR	
R81	QRD161J-472	RESISTOR	
R82	QRD161J-103	RESISTOR	
R83	QRD161J-153	RESISTOR	
R84	QRD161J-472	RESISTOR	
R85	QRD161J-103	RESISTOR	
R86	QRD161J-153	RESISTOR	
R87	QRD161J-224	RESISTOR	
R88	QRD161J-153	RESISTOR	
R91	QRD161J-472	RESISTOR	
R92	QRD161J-562	RESISTOR	
R93	QRD161J-152	RESISTOR	
R94	QRD161J-472	RESISTOR	
R95	QRD161J-121	RESISTOR	
R96	QRD161J-103	RESISTOR	
R97	QRD161J-103	RESISTOR	
R98	QRD161J-153	RESISTOR	
R100	QRD161J-101	RESISTOR	
R101	QRD161J-222	RESISTOR	
R102	QRD161J-222	RESISTOR	
R103	QRD161J-222	RESISTOR	
R104	QRD161J-222	RESISTOR	
R105	QRD161J-222	RESISTOR	
R106	QRD161J-102	RESISTOR	
R107	QRD161J-222	RESISTOR	
R108	QRD161J-103	RESISTOR	
R110	QRD161J-104	RESISTOR	
R112	QRD161J-222	RESISTOR	
R122	QRD161J-103	RESISTOR	
R123	QRD161J-103	RESISTOR	
R124	QRD161J-103	RESISTOR	
R125	QRD161J-103	RESISTOR	
R126	QRD161J-103	RESISTOR	
R127	QRD161J-473	RESISTOR	
R128	QRD161J-473	RESISTOR	
R130	QRD161J-471	RESISTOR	
R131	QRD161J-102	RESISTOR	
R133	QRD161J-103	RESISTOR	
R134	QRD161J-102	RESISTOR	

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
R140	QRD161J-122	RESISTOR	
R141	QRD161J-472	RESISTOR	
R142	QRD161J-331	RESISTOR	
RA 1	QRB047J-104	RESISTOR ARRAY	
C 1	QCSB1HJ-100	CAPACITOR	
C 2	QCB81HK-102	CAPACITOR	
C 3	QCXB1CK-222	CAPACITOR	
C 4	QCB81HK-102	CAPACITOR	
C 5	QCB81HK-102	CAPACITOR	
C 7	PU57601-474ME	E CAPACITOR	
C 8	QET61CM-336	E CAPACITOR	
C 9	QCXB1CK-222	CAPACITOR	
C10	QCSB1HJ-470	CAPACITOR	
C11	QET61HM-474	E CAPACITOR	
C12	QCT25PH-270	CAPACITOR	
C13	QCXB1CK-222	CAPACITOR	
C14	QET61CM-336	E CAPACITOR	
C23	QET61HM-105	E CAPACITOR	
C30	QEN61CM-336	NP E CAPACITOR	
C31	QCSB1HJ-470	CAPACITOR	
C34	QET61CM-336	E CAPACITOR	
C35	QET61CM-106	E CAPACITOR	
C36	QCC11EK-223	CAPACITOR	
C37	QET61HM-474	E CAPACITOR	
C39	QCC31EK-104	CAPACITOR	
C40	QET61CM-106	E CAPACITOR	
C41	QET61CM-106	E CAPACITOR	
C42	QET61CM-106	E CAPACITOR	
C43	QET61CM-106	E CAPACITOR	
C44	QET61HM-225	E CAPACITOR	
C46	QFV81HJ-474	M CAPACITOR	
OR	QF29011-474	MM CAPACITOR	
C47	QFN31HJ-223	M CAPACITOR	
C48	QCB81HK-102	CAPACITOR	
C49	QCB81HK-102	CAPACITOR	
C51	QCT25CH-220	CAPACITOR	
C52	QCT25CH-270	CAPACITOR	
C53	QCVB1CM-103	CAPACITOR	
C54	QCVB1CM-103	CAPACITOR	
C55	QET61CM-106	E CAPACITOR	
C56	QET61CM-336	E CAPACITOR	
C57	QET61CM-107	E CAPACITOR	
C58	QCB81HK-102	CAPACITOR	
C59	QET61AM-336	E CAPACITOR	
C60	QET61AM-107	E CAPACITOR	
C61	QET61CM-106	E CAPACITOR	
C63	QET61HM-106	E CAPACITOR	
C65	QET61CM-336	E CAPACITOR	
C66	PU57601-335MC	E CAPACITOR	
C70	QCB81HK-102	CAPACITOR	
C71	QCB81HK-102	CAPACITOR	
L 1	PU59152-R22K	PEAKING COIL	
L 2	PU57717-1R0J	PEAKING COIL	
L 3	PU57717-1R5J	PEAKING COIL	
L 4	PU59152-6R8K	PEAKING COIL	
L 5	PU59152-120J	PEAKING COIL	
L 6	PU59152-6R8K	PEAKING COIL	
L 8	PU59152-220J	PEAKING COIL	
L10	PU59152-100J	PEAKING COIL	
L11	PU59152-R22K	PEAKING COIL	
OR	PU53223-R22K	PEAKING COIL	
L13	PU53223-101J	PEAKING COIL	

*△ REF NO.	PART NO.	PART NAME, DESCRIPTION	*△ REF NO.	PART NO.	PART NAME, DESCRIPTION
CF 3	PU32990-2	CERAMIC FILTER	D7	1SS133	DIODE
SAW 1	PU35557-4	SAW FILTER	OR MA165	DIODE	
X1	PU58554-2	CRYSTAL RESONATOR, 4.0M	D8	1SS133	DIODE
T 1	PU59402	TRAP COIL, FTZ TRAP	OR MA165	DIODE	
T 2	PU59308	COIL, VCO	D9	1SS133	DIODE
T 5	PU55184	IF.TRANSFORMER, SYNC DET	OR MA165	DIODE	
SLD1	PU36322	SHIELD CASE	D10	1SS133	DIODE
SLD2	PQ31328-1-1	SHIELD COVER	OR MA165	DIODE	
SLD3	PQ42506	SHIELD PLATE	D11	1SS133	DIODE
TP	PU59391	STYLE PIN, EG	OR MA165	DIODE	
WR1	PW30401-AE11S	COAXIAL CORD, PLL	D12	1SS133	DIODE
WR2	PW30401-AE11S	COAXIAL CORD, PSC	OR MA165	DIODE	
WR3	PW30401-AB11S	COAXIAL CORD, RF CONV	D13	1SS133	DIODE
OR PW30401-AB11T	COAXIAL CORD		OR MA165	DIODE	
WR4	PW30401-AC36S	COAXIAL CORD	D15	1SS133	DIODE
OR PW30401-AC36T	COAXIAL CORD		OR MA165	DIODE	
CN3	PU58844-3	CAP HOUSING, E	D61	11E2	DIODE
CN4	PU58928-3	CAP HOUSING, EG	D65	1SS133	DIODE
CN6	PU59374	JACK	OR MA165	DIODE	
*****			D68	1SS133	DIODE
*****			OR MA165	DIODE	
*****			D70	1SS133	DIODE
*****			OR MA165	DIODE	
*****			R1	QRD161J-102	RESISTOR
*****			R2	QRD161J-222	RESISTOR
*****			R3	QRD161J-221	RESISTOR
*****			R4	QRD161J-563	RESISTOR
*****			R5	QRD161J-153	RESISTOR
*****			R6	QRD161J-682	RESISTOR
*****			R7	QRD161J-331	RESISTOR
*****			R8	QRD161J-105	RESISTOR
*****			R9	QRD161J-103	RESISTOR
*****			R10	QRD161J-152	RESISTOR
*****			R11	QRD161J-684	RESISTOR
*****			R12	QRD161J-333	RESISTOR
*****			R13	QRD161J-223	RESISTOR
*****			R14	QRD161J-332	RESISTOR
*****			R15	QRD161J-102	RESISTOR
*****			R16	QRD161J-102	RESISTOR
*****			R17	QRD161J-102	RESISTOR
*****			R18	QV23521-474	V RESISTOR, SP X2 TK PRESET
*****			R19	QRD161J-393	RESISTOR
*****			R20	QV23521-474	V RESISTOR, LP X2 TK PRESET
*****			R21	QRD161J-334	RESISTOR
*****			R22	QRD161J-223	RESISTOR
*****			R24	QV23521-684	V RESISTOR, PB SW POINT
*****			R25	QRD161J-104	RESISTOR
*****			R26	QRD161J-102	RESISTOR
*****			R27	QRD161J-273	RESISTOR
*****			R28	QRD161J-105	RESISTOR
*****			R29	QRD161J-104	RESISTOR
*****			R30	QRD161J-105	RESISTOR
*****			R31	QRD161J-105	RESISTOR
*****			R32	QRD161J-273	RESISTOR
*****			R33	QRD161J-334	RESISTOR
*****			R34	QRD161J-103	RESISTOR
*****			R35	QRD161J-102	RESISTOR
*****			R36	QRD161J-103	RESISTOR
*****			R37	QRD161J-105	RESISTOR
*****			R38	QRD161J-273	RESISTOR
*****			R39	QRD161J-182	RESISTOR
*****			R40	QRD161J-472	RESISTOR
*****			R41	QRD161J-103	RESISTOR
*****			R42	QRD161J-475	RESISTOR
*****			R43	QRD161J-473	RESISTOR
*****			R44	QRD161J-222	RESISTOR
*****			R45	QRD161J-273	RESISTOR

PWBA	PB20104A-02	SERVO BOARD ASSEMBLY			
IC1	HD49712ANT	IC			
IC61	BU2767S	IC			
Q1	2SC3311A	TRANSISTOR			
Q2	DTA124ES	TRANSISTOR			
OR UN4112	TRANSISTOR				
Q3	DTA124ES	TRANSISTOR			
OR UN4112	TRANSISTOR				
Q4	DTA124ES	TRANSISTOR			
OR UN4112	TRANSISTOR				
Q5	DTA124ES	TRANSISTOR			
OR UN4112	TRANSISTOR				
Q6	DTC124XS	TRANSISTOR			
Q7	DTA144ES	TRANSISTOR			
Q61	DTA124ES	TRANSISTOR			
OR UN4112	TRANSISTOR				
Q63	2SD1468S(SE)	TRANSISTOR			
Q64	2SD1468S(SE)	TRANSISTOR			
Q65	DTC144ES	TRANSISTOR			
OR UN4213	TRANSISTOR				
Q66	DTC144ES	TRANSISTOR			
OR UN4213	TRANSISTOR				
D1	1SS133	DIODE			
OR MA165	DIODE				
D2	1SS133	DIODE			
OR MA165	DIODE				
D3	1SS133	DIODE			
OR MA165	DIODE				
D4	1SS133	DIODE			
OR MA165	DIODE				
D5	1SS133	DIODE			
OR MA165	DIODE				
D6	1SS133	DIODE			
OR MA165	DIODE				

*Δ REF NO.	PART NO.	PART NAME, DESCRIPTION
R46	QRD161J-103	RESISTOR
R47	QRD161J-222	RESISTOR
R49	QRD161J-223	RESISTOR
R50	QRD161J-103	RESISTOR
R61	QRD161J-103	RESISTOR
R67	QRD161J-684	RESISTOR
R68	QRD161J-104	RESISTOR
R69	QVZ3521-105	V RESISTOR, LP PRESET (SLOW)
R70	QRD161J-274	RESISTOR
R71	QRD161J-154	RESISTOR
R72	QVZ3521-105	V RESISTOR, SP PRESET (SLOW)
R73	QRD161J-684	RESISTOR
R74	QRD161J-334	RESISTOR
R75	QRD161J-103	RESISTOR
R85	QRD161J-123	RESISTOR
R86	QRD161J-822	RESISTOR
R87	QRD161J-222	RESISTOR
R88	QRD161J-473	RESISTOR
Δ R89	QRG019J-331S	DMF RESISTOR
R90	QRD161J-562	RESISTOR
R91	QRD161J-473	RESISTOR
R92	QRD161J-105	RESISTOR
R93	QRD161J-103	RESISTOR
C1	QETC1CM-106	E CAPACITOR
C2	QCBB1HJ-102	CAPACITOR
C3	QETC1HM-474	E CAPACITOR
C4	QCBB1HJ-102	CAPACITOR
C5	QCBB1HJ-102	CAPACITOR
C6	QETC1AM-226	E CAPACITOR
C7	QETC1AM-226	E CAPACITOR
C8	QCSB1HJ-150	CAPACITOR
C9	QETC1HM-105	E CAPACITOR
C10	QCXB1CN-472	CAPACITOR
C11	QCXB1CN-222	CAPACITOR
C12	QCBB1HJ-102	CAPACITOR
C13	QETC1HM-224	E CAPACITOR
C14	QCBB1HJ-102	CAPACITOR
C15	QETC1HM-105	E CAPACITOR
C16	QETC1AM-226	E CAPACITOR
C19	QFV71HJ-124	M CAPACITOR
C21	QFL31HJ-682	M CAPACITOR
C22	QCBB1HJ-471	CAPACITOR
C23	QFV71HJ-104	M CAPACITOR
C24	QEN61HM-105	NP E CAPACITOR
C25	QETC1CM-106	E CAPACITOR
C26	QETC1CM-106	E CAPACITOR
C27	QETC1EM-475	E CAPACITOR
C28	QETC1EM-475	E CAPACITOR
C29	QCC31CK-122	CAPACITOR
OR C30	QFN31HJ-122	M CAPACITOR
C30	QFV71HJ-334	M CAPACITOR
C31	QCBB1HJ-102	CAPACITOR
C32	QCVB1CN-103	CAPACITOR
C33	QCBB1HJ-101	CAPACITOR
C36	QEN50JM-336	NP E CAPACITOR
C37	QCBB1HJ-471	CAPACITOR
C38	QCBB1HJ-471	CAPACITOR
C61	QET61AM-226	E CAPACITOR
C62	QFN31HJ-393	M CAPACITOR
C63	QFN31HJ-393	M CAPACITOR
C64	QFN31HJ-104	M CAPACITOR
C65	QFN31HJ-124	M CAPACITOR
C66	QFN31HJ-393	M CAPACITOR
C67	QCBB1HJ-681	CAPACITOR
C68	QCBB1HJ-471	CAPACITOR

*Δ REF NO.	PART NO.	PART NAME, DESCRIPTION
C71	QCC31CK-102	CAPACITOR
Δ CF61	PU60215	RESONATOR
TP GND	PU55774	TEST PIN
TP 1	PU55774	TEST PIN
TP 11	PU55774	TEST PIN
TP 4	PU55774	TEST PIN
TP	PU59391	STYLE PIN
CN1	PU58844-2	CAP HOUSING
CN2	PU58844-2	CAP HOUSING
CN3	PU58844-5	CAP HOUSING
CN4	PU58931-14	HOUSING
CN5	PU58931-16	HOUSING
CN6	PU58844-6	CAP HOUSING
*** *****		

* 12. AUDIO BOARD ASSEMBLY <09> *		

PWBA	PU36223B-04	AUDIO BOARD ASSEMBLY
IC1	AN3994NK	IC
Q1	2SC1740S(RS)	TRANSISTOR
Q2	2SC1740S(RS)	TRANSISTOR
Q3	2SC1740S(RS)	TRANSISTOR
Q4	2SA1309R,S	TRANSISTOR
Q6	DTC124ES	TRANSISTOR
Q7	2SA1309R,S	TRANSISTOR
Q8	2SA1309R,S	TRANSISTOR
Q9	DTC144ES	TRANSISTOR
D1	MA165	DIODE
OR 1S5133		DIODE
D2	MA165	DIODE
OR 1S5133		DIODE
D3	MA165	DIODE
OR 1S5133		DIODE
D4	MA165	DIODE
OR 1S5133		DIODE
D5	MA165	DIODE
OR 1S5133		DIODE
D6	MA165	DIODE
OR 1S5133		DIODE
D7	MA165	DIODE
OR 1S5133		DIODE
D10	1S5133	DIODE
OR MA165		DIODE
D12	1S5133	DIODE
OR MA165		DIODE
R1	QRD161J-103	RESISTOR
R2	QRD161J-124	RESISTOR
R3	QRD161J-223	RESISTOR
R4	QRD161J-331	RESISTOR
R5	QVZ3518-102	V RESISTOR, PB LEVEL
R6	QRD161J-100	RESISTOR
R7	QRD161J-471	RESISTOR
R8	QRD161J-303	RESISTOR
R9	QRD161J-470	RESISTOR
R10	QRD161J-473	RESISTOR
R11	QRD161J-563	RESISTOR
R12	QRD161J-271	RESISTOR

*△ REF NO.	PART NO.	PART NAME, DESCRIPTION
R13	QRD161J-153	RESISTOR
R14	QRD161J-153	RESISTOR
R15	QRD161J-103	RESISTOR
R16	QRD161J-103	RESISTOR
R17	QRD161J-103	RESISTOR
R18	QRD161J-331	RESISTOR
R19	QRD161J-103	RESISTOR
R20	QVZ3518-473	V RESISTOR, BIAS LEVEL
R21	QRD161J-8R2	RESISTOR
R22	QRD161J-104	RESISTOR
R23	QRD161J-100	RESISTOR
R24	QRD161J-223	RESISTOR
△ R31	PU52108-4R7	POSISTOR
R32	QRD161J-100	RESISTOR
R33	QRD161J-473	RESISTOR
R36	QRD161J-223	RESISTOR
R37	QRD161J-563	RESISTOR
C1	QEK61EM-475G	E CAPACITOR
OR	QEK61EM-475	E CAPACITOR
C2	QER61HM-474G	E CAPACITOR
C3	QFV71HJ-224	M CAPACITOR
C4	QFN31HJ-123	M CAPACITOR
C5	QEL61EM-475	E CAPACITOR
C6	QCB81HJ-102	CAPACITOR
C7	QFN31HJ-152	M CAPACITOR
C8	QER61CM-226	E CAPACITOR
C9	QER61CM-106	E CAPACITOR
C10	QER61CM-476	E CAPACITOR
C11	QER61CM-106G	E CAPACITOR
C12	QCB81HJ-331	CAPACITOR
C13	QFN31HJ-683	M CAPACITOR
C14	QFN31HJ-683	M CAPACITOR
C15	QER61HM-225G	E CAPACITOR
C16	QCB81HJ-102	CAPACITOR
C17	QER60JM-476	E CAPACITOR
C18	QER61AM-476	E CAPACITOR
C19	QCB81HJ-331	CAPACITOR
C20	QFN31HJ-333	M CAPACITOR
C21	QER61CM-476	E CAPACITOR
C22	QCB81HJ-102	CAPACITOR
C23	QCB81HJ-102	CAPACITOR
C26	QER61CM-106	E CAPACITOR
C27	QCV81CN-103	CAPACITOR
C40	QEN61CM-106	NP E CAPACITOR
C41	QFN31HJ-563	M CAPACITOR
C42	QCB81HJ-102	CAPACITOR
C43	QCB81HJ-102	CAPACITOR
L1	PU58308-272J	COIL
T1	PU59520	OSC TRANS
T2	PU59521	OSC TRANS
TP31	PU55774	TEST PIN
TP32	PU55774	TEST PIN
CN1	PU58844-7	CAP HOUSING
CN2	PU58844-4	CAP HOUSING
CN3	PU58844-8	CAP HOUSING

*△ REF NO.	PART NO.	PART NAME, DESCRIPTION

* 13. AUDIO/CTL HEAD BOARD <12> *		

PWB1	PU58016	A/CTL HEAD BOARD
BKT1	PQ43014	BRACKET
SCW1	SPSH1740	MINI SCREW
CN1	PU54537-5	CAP HOUSING
CN2	PU54537-2B	CAP HOUSING

* 14. FMA BOARD ASSEMBLY <13> *		

PWBA	PU22346W	FMA BOARD ASSEMBLY
IC1	AN6299NK	IC
IC2	AN3926K	IC
IC3	BA3707	IC
IC4	M5218P	IC
IC201	HA11752	IC
IC202	PU22280B-02	FMA MODULE
△ IC203	M5278L10	IC
△ Q5	2SC1740S(QR)	TRANSISTOR
Q6	DTA143ES	TRANSISTOR
Q7	DTC124ES	TRANSISTOR
Q201	2SC1740S(QRS)	TRANSISTOR
Q202	2SC1740S(QRS)	TRANSISTOR
Q203	2SC1740S(QRS)	TRANSISTOR
Q204	2SB643Q	TRANSISTOR
Q205	2SD638Q	TRANSISTOR
Q206	2SB641Q	TRANSISTOR
Q207	2SC1740S(QRS)	TRANSISTOR
Q208	2SC1740S(QRS)	TRANSISTOR
Q209	2SC1740S(QRS)	TRANSISTOR
Q212	DTA143ES	TRANSISTOR
△ Q213	UN4119	TRANSISTOR
Q214	DTC144ES	TRANSISTOR
Q215	DTC144ES	TRANSISTOR
△ Q216	UN4119	TRANSISTOR
D201	1SS133	DIODE
D203	DA210S	DIODE
D204	DAN209S	DIODE
D206	1SS133	DIODE
R1	QRSA08J-473YN	RESISTOR
R2	QRSA08J-473YN	RESISTOR
R3	QRSA08J-273YN	RESISTOR
R4	QRSA08J-273YN	RESISTOR
R5	QVZ3244-472	V RESISTOR, E-E LEVEL-1 (L)
R6	QVZ3244-472	V RESISTOR, E-E LEVEL-1 (R)
R7	QRSA08J-682YN	RESISTOR
R8	QRSA08J-682YN	RESISTOR
R9	QRSA08J-821YN	RESISTOR
R10	QRSA08J-821YN	RESISTOR
R11	QRSA08J-392YN	RESISTOR
R12	QRSA08J-392YN	RESISTOR
R13	QRSA08J-123YN	RESISTOR

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
R14		QRSA08J-123YN	RESISTOR
R15		QRSA08J-123YN	RESISTOR
R16		QRSA08J-123YN	RESISTOR
R17		QRSA08J-153YN	RESISTOR
R18		QRSA08J-153YN	RESISTOR
R19		QRSA08J-513YN	RESISTOR
R20		QRSA08J-513YN	RESISTOR
R21		QRSA08J-102YN	RESISTOR
R22		QRSA08J-102YN	RESISTOR
R23		QRSA08J-102YN	RESISTOR
R24		QRSA08J-102YN	RESISTOR
R25		QRSA08J-151YN	RESISTOR
R26		QRSA08J-151YN	RESISTOR
R27		QRSA08J-225YN	RESISTOR
R28		QRSA08J-225YN	RESISTOR
R29		QVZ3244-472	V RESISTOR, IND LEVEL (L)
R30		QVZ3244-472	V RESISTOR, IND LEVEL (R)
R31		QRSA08J-222YN	RESISTOR
R32		QRSA08J-222YN	RESISTOR
R33		QVZ3244-472	V RESISTOR, E-E LEVEL-2 (L)
R34		QVZ3244-472	V RESISTOR, E-E LEVEL-2 (R)
R35		QRSA08J-682YN	RESISTOR
R36		QRSA08J-682YN	RESISTOR
R37		QRSA08J-124YN	RESISTOR
R38		QRSA08J-334YN	RESISTOR
R39		QRSA08J-222YN	RESISTOR
R40		QRSA08J-333YN	RESISTOR
R41		QRSA08J-102YN	RESISTOR
R42		QRSA08J-102YN	RESISTOR
R43		QRSA08J-122YN	RESISTOR
R44		QRSA08J-472YN	RESISTOR
R45		QRSA08J-272YN	RESISTOR
R46		QRSA08J-122YN	RESISTOR
R47		QRSA08J-103YN	RESISTOR
R48		QRSA08J-104YN	RESISTOR
R49		QRSA08J-224YN	RESISTOR
R50		QRSA08J-822YN	RESISTOR
R51		QRSA08J-102YN	RESISTOR
R52		QRSA08J-104YN	RESISTOR
R53		QRSA08J-154YN	RESISTOR
R54		QRSA08J-333YN	RESISTOR
R55		QRSA08J-392YN	RESISTOR
R56		QRSA08J-223YN	RESISTOR
R57		QRSA08J-223YN	RESISTOR
R58		QRSA08J-392YN	RESISTOR
R59		QRSA08J-392YN	RESISTOR
R65		QRSA08J-102YN	RESISTOR
R66		QRSA08J-561YN	RESISTOR
R68		QRSA08J-122YN	RESISTOR
R69		QRSA08J-103YN	RESISTOR
R72		QRSA08J-333YN	RESISTOR
R74		QRSA08J-561YN	RESISTOR
R75		QRSA08J-472YN	RESISTOR
R76		QRSA08J-472YN	RESISTOR
R78		QRSA08J-103YN	RESISTOR
R201		QRSA08J-681YN	RESISTOR
R202		QRSA08J-102YN	RESISTOR
R203		QRSA08J-100YN	RESISTOR
R204		QRSA08J-100YN	RESISTOR
R205		QRSA08J-392YN	RESISTOR
R206		QRSA08J-392YN	RESISTOR
R207		QRSA08J-152YN	RESISTOR
R208		QRSA08J-152YN	RESISTOR
R209		QRSA08J-472YN	RESISTOR
R210		QRSA08J-562YN	RESISTOR
R211		QRSA08J-562YN	RESISTOR

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
R212		QRSA08J-152YN	RESISTOR
R213		QRSA08J-100YN	RESISTOR
R214		QRSA08J-100YN	RESISTOR
R215		QRSA08J-102YN	RESISTOR
R216		QRSA08J-104YN	RESISTOR
R217		QRSA08J-104YN	RESISTOR
R218		QVZ3244-223	V RESISTOR, REC FM LEVEL
R219		QRSA08J-221YN	RESISTOR
R220		QRSA08J-221YN	RESISTOR
R221		QRSA08J-223YN	RESISTOR
R222		QRSA08J-223YN	RESISTOR
R223		QRSA08J-102YN	RESISTOR
R226		QRSA08J-224YN	RESISTOR
R227		QRSA08J-392YN	RESISTOR
R228		QRSA08J-221YN	RESISTOR
R229		QRSA08J-821YN	RESISTOR
R230		QRSA08J-223YN	RESISTOR
R231		QRSA08J-103YN	RESISTOR
R232		QRSA08J-273YN	RESISTOR
R233		QRSA08J-273YN	RESISTOR
R234		QRSA08J-123YN	RESISTOR
R235		QRSA08J-333YN	RESISTOR
R236		QRD161J-0R0	RESISTOR
R237		QRD161J-0R0	RESISTOR
R240		QRSA08J-561YN	RESISTOR
R241		QRSA08J-472YN	RESISTOR
R242		QRSA08J-472YN	RESISTOR
R243		QRSA08J-561YN	RESISTOR
R244		QRSA08J-561YN	RESISTOR
R245		QRSA08J-302YN	RESISTOR
R246		QRSA08J-102YN	RESISTOR
R247		QRSA08J-102YN	RESISTOR
R248		QRSA08J-102YN	RESISTOR
R249		QRSA08J-102YN	RESISTOR
R250		QVZ3244-223	V RESISTOR, PB LEVEL (R)
R251		QRSA08J-182YN	RESISTOR
R252		QRSA08J-332YN	RESISTOR
R253		QRSA08J-202YN	RESISTOR
R254		QRSA08J-334YN	RESISTOR
R255		QRSA08J-122YN	RESISTOR
R256		QRSA08J-182YN	RESISTOR
R257		QRSA08J-332YN	RESISTOR
R258		QRSA08J-202YN	RESISTOR
R259		QVZ3244-223	V RESISTOR, PB LEVEL (L)
R260		QRSA08J-102YN	RESISTOR
R267		QRSA08J-122YN	RESISTOR
R268		QRSA08J-683YN	RESISTOR
R269		QRSA08J-103YN	RESISTOR
R270		QRSA08J-102YN	RESISTOR
R271		QRSA08J-183YN	RESISTOR
C1		QER41HM-225	E CAPACITOR
C2		QER41HM-225	E CAPACITOR
C3		QER41HM-225	E CAPACITOR
C4		QER41HM-225	E CAPACITOR
C5		QER41HM-225	E CAPACITOR
C6		QER41HM-225	E CAPACITOR
C7		QER41CM-106	E CAPACITOR
C8		QER41CM-106	E CAPACITOR
C9		QER41CM-106	E CAPACITOR
C10		QER41CM-106	E CAPACITOR
C11		QER41CM-226	E CAPACITOR
C12		QER41CM-226	E CAPACITOR
C13		QER41CM-106	E CAPACITOR
C14		QER41CM-106	E CAPACITOR
C15		QCSA1HJ-151	CAPACITOR
C16		QCSA1HJ-151	CAPACITOR

#△	REF NO.	PART NO.	PART NAME, DESCRIPTION	#△	REF NO.	PART NO.	PART NAME, DESCRIPTION
C17	QER41AM-336	E	CAPACITOR	C218	QCS31HJ-221	CAPACITOR	
C18	QER61AM-336	E	CAPACITOR	C219	QCYA1HK-102	CAPACITOR	
C19	QER41AM-336	E	CAPACITOR	C220	QCYA1HK-102	CAPACITOR	
C20	QER41AM-336	E	CAPACITOR				
C21	QFN31HJ-333	M	CAPACITOR	C221	QCS31HJ-221	CAPACITOR	
C22	QFN31HJ-333	M	CAPACITOR	C222	QCSA1HJ-331	CAPACITOR	
C23	QER41HM-225	E	CAPACITOR	C223	QCYA1HK-102	CAPACITOR	
C24	QER41HM-225	E	CAPACITOR	C224	QCF31HP-103	CAPACITOR	
C25	QFN31HJ-153	M	CAPACITOR	C226	QER41HM-224	E CAPACITOR	
C26	QFN31HJ-153	M	CAPACITOR	C227	QCYA1HK-103	CAPACITOR	
C27	QER41AM-336	E	CAPACITOR	C228	QER40JM-476	E CAPACITOR	
C28	QER41AM-336	E	CAPACITOR	C229	QCF31HP-103	CAPACITOR	
C29	QER41AM-336	E	CAPACITOR	C230	QER40JM-476	E CAPACITOR	
C30	QER41AM-336	E	CAPACITOR				
C31	QFN31HJ-332	M	CAPACITOR	C232	QCF31HP-103	CAPACITOR	
C32	QFN31HJ-332	M	CAPACITOR	C235	QCF31HP-103	CAPACITOR	
C33	QER41AM-336	E	CAPACITOR	C237	QCYA1HK-102	CAPACITOR	
C34	QER41AM-336	E	CAPACITOR	C238	QCYA1HK-103	CAPACITOR	
C35	QER41CM-106	E	CAPACITOR				
C36	QER41CM-106	E	CAPACITOR	C241	QFN31HJ-182	M CAPACITOR	
C37	QER41CM-106	E	CAPACITOR	C242	QER41CM-106	E CAPACITOR	
C38	QER41CM-106	E	CAPACITOR	C243	QFN31HJ-122	M CAPACITOR	
C39	QER41CM-106	E	CAPACITOR	C244	QFN31HJ-103	M CAPACITOR	
C40	QER41CM-106	E	CAPACITOR	C245	QER41AM-336	E CAPACITOR	
C41	QER41HM-105	E	CAPACITOR	C246	QER41CM-106	E CAPACITOR	
C42	QER41HM-105	E	CAPACITOR	C247	QER41CM-106	E CAPACITOR	
C43	QER40JM-107	E	CAPACITOR	C248	QER40JM-107	E CAPACITOR	
C44	QER41CM-476	E	CAPACITOR	C249	QER41AM-336	E CAPACITOR	
C45	QER41HM-335	E	CAPACITOR	C250	QCF11HP-102	CAPACITOR	
C46	QER41HM-335	E	CAPACITOR				
C47	QER41CM-106	E	CAPACITOR	C251	QER41CM-106	E CAPACITOR	
C48	QFN31HJ-103	M	CAPACITOR	C252	QFN31HJ-182	M CAPACITOR	
C49	QER41CM-106	E	CAPACITOR	C253	QER41AM-336	E CAPACITOR	
C50	QER41CM-476	E	CAPACITOR	C254	QER41CM-106	E CAPACITOR	
C51	QER41CM-106	E	CAPACITOR	C255	QER41CM-476	E CAPACITOR	
C52	QER41CM-476	E	CAPACITOR	C256	QER41CM-106	E CAPACITOR	
C53	QER41CM-476	E	CAPACITOR				
C54	QER41HM-474	E	CAPACITOR	C264	QER41HM-105	E CAPACITOR	
C55	QER41HM-474	E	CAPACITOR	C265	QER41CM-476	E CAPACITOR	
C56	QER41CM-106	E	CAPACITOR	C267	QER41AM-336	E CAPACITOR	
C57	QER41HM-474	E	CAPACITOR	C269	QFN31HJ-122	M CAPACITOR	
C58	QER41CM-226	E	CAPACITOR	C270	QFN31HJ-103	M CAPACITOR	
C59	QER41HM-225	E	CAPACITOR				
C60	QER41HM-105	E	CAPACITOR	C271	QER41HM-104	E CAPACITOR	
C61	QER41HM-105	E	CAPACITOR	C272	QCSA1HJ-470	CAPACITOR	
C62	QER41HM-105	E	CAPACITOR	C273	QCSA1HJ-470	CAPACITOR	
C64	QCYA1HK-221	CAPACITOR		C274	QEK41EM-475	E CAPACITOR	
C66	QER41HM-105	E	CAPACITOR				
C68	QFJ41HJ-563	E	CAPACITOR	L1	PU58308-152J	COIL	
C69	QER41HM-105	E	CAPACITOR	L2	PU58308-152J	COIL	
C70	QER41CM-476	E	CAPACITOR				
C71	QER40JM-476	E	CAPACITOR	L201	PU53223-101J	PEAKING COIL	
C201	QCF31HP-103	CAPACITOR		L202	PU53223-221J	PEAKING COIL	
C202	QER41CM-476	E CAPACITOR		L203	PU53223-101J	PEAKING COIL	
C203	QCYA1HK-103	CAPACITOR		L204	PU53223-101J	PEAKING COIL	
C205	QCYA1HK-102	CAPACITOR		L205	PU48530-101K	PEAKING COIL	
C206	QCYA1HK-103	CAPACITOR		L206	PU58308-222J	COIL	
C207	QCF31HP-103	CAPACITOR		L207	PU53223-101J	PEAKING COIL	
C208	QCF31HP-103	CAPACITOR		L209	PU58308-222J	COIL	
C209	QCF31HP-103	CAPACITOR					
C210	QCF31HP-103	CAPACITOR		BPF1	PU58494	BAND PASS FILTER	
C211	QCYA1HK-102	CAPACITOR		BPF2	PU58494-2	BAND PASS FILTER	
C212	QER40JM-476	E CAPACITOR					
C213	QCF31HP-103	CAPACITOR		SLD1	PQ42581	PRE AMP SHIELD1, MIDDLE	
C216	QCF31HP-103	CAPACITOR		SLD2	PQ42582	PRE AMP SHIELD2, CAP	
C217	QCF31HP-103	CAPACITOR		SLD3	PQ42583	PRE AMP SHIELD3, BOTTOM	
				TP201	PU51721	TEST PIN, REC FM	
				TP203	PU51721	TEST PIN, PB FM	
				TP204	PU51721	TEST PIN, PB FM	
				TP205	PU51721	TEST PIN, CH1 FM	
				TP206	PU51721	TEST PIN, CH2 FM	
				CN1	PU58844-4	CAP HOUSING, TO DRUM	

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
CN2		PU58844-104	CAP HOUSING, AUX IN
CN3		PU58844-107	CAP HOUSING, REC VR
CN4		PU58844-102	CAP HOUSING, TO NORM
CN5		PU58844-104	CAP HOUSING, HEADPHONE
CN6		PU58844-103	CAP HOUSING, MIC(2-4)
CN11		PU58929-6	HOUSING, FROM TUNER
CN12		PU58929-8	CAP HOUSING, MECHACON
CN14		PU58929-5	HOUSING, INDICATE
CN15		PU58929-9	HOUSING, I/O CTL

* 15. DEMODULATOR BOARD ASSEMBLY <14> *			

PWBA		PU22376D	DEMOMULATOR BOARD ASSEMBLY
IC1		M51365SP	IC
IC2		TDA3800GS	IC
Q 1		2SD1450S,T	TRANSISTOR
	OR	2SD1292(QR)	TRANSISTOR
Q 2		DTC114ES	TRANSISTOR
	OR	UN4211	TRANSISTOR
	OR	2SC3402	TRANSISTOR
Q 3		2SC3354	TRANSISTOR
	OR	2SC2926S(PQ)	TRANSISTOR
Q 4		2SC3354	TRANSISTOR
	OR	2SC2926S(PQ)	TRANSISTOR
Q11		DTC114ES	TRANSISTOR
	OR	2SC3402	TRANSISTOR
	OR	UN4211	TRANSISTOR
Q12		DTC114ES	TRANSISTOR
	OR	2SC3402	TRANSISTOR
	OR	UN4211	TRANSISTOR
Q13		DTC114ES	TRANSISTOR
	OR	2SC3402	TRANSISTOR
	OR	UN4211	TRANSISTOR
Q14		DTC114ES	TRANSISTOR
	OR	2SC3402	TRANSISTOR
Q15		2SD1450S,T	TRANSISTOR
	OR	2SD1468S(RSE)	TRANSISTOR
Q16		2SD1450S,T	TRANSISTOR
	OR	2SD1468S(RSE)	TRANSISTOR
Q17		2SC3311A(S)	TRANSISTOR
	OR	2SC1740S(S)	TRANSISTOR
Q18		2SC3311A(S)	TRANSISTOR
	OR	2SC1740S(S)	TRANSISTOR
Q19		DTC144ES	TRANSISTOR
	OR	UN4213	TRANSISTOR
	OR	2SC3399	TRANSISTOR
Q20		DTC114ES	TRANSISTOR
D 2		1SS133	DIODE
D 5		1SS133	DIODE
D 6		1SS133	DIODE
D 7		1SS133	DIODE
D 8		1SS133	DIODE
D 9		1SS133	DIODE
R 1		QRD161J-561	RESISTOR
R 9		QRD161J-331	RESISTOR
R11		QRD161J-561	RESISTOR
R12		QRD161J-101	RESISTOR
R13		QRD161J-330	RESISTOR
R14		QRD161J-101	RESISTOR
R15		QRD161J-471	RESISTOR
R16		QRD161J-821	RESISTOR

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
R18		QRD161J-824	RESISTOR
R21		QRD161J-822	RESISTOR
R22		QRD161J-222	RESISTOR
R23		QRD161J-272	RESISTOR
R24		QRD161J-223	RESISTOR
R26		QRD161J-470	RESISTOR
R27		QRD161J-561	RESISTOR
R31		QVZ3518-103	V RESISTOR, SEPARATION
R32		QRD161J-331	RESISTOR
R33		QRD161J-331	RESISTOR
R36		QRD161J-471	RESISTOR
R42		QRD161J-103	RESISTOR
R43		QRD161J-103	RESISTOR
R44		QRD161J-123	RESISTOR
R45		QRD161J-821	RESISTOR
R46		QRD161J-102	RESISTOR
R48		QRD161J-273	RESISTOR
R51		QRD161J-103	RESISTOR
R52		QRD161J-103	RESISTOR
R53		QRD161J-681	RESISTOR
R54		QRD161J-103	RESISTOR
R55		QRD161J-103	RESISTOR
R56		QRD161J-681	RESISTOR
R57		QVZ3518-332	V RESISTOR, L LEVEL
R58		QRD161J-222	RESISTOR
R59		QRD161J-103	RESISTOR
R62		QVZ3518-332	V RESISTOR, R LEVEL
R63		QRD161J-222	RESISTOR
R64		QRD161J-103	RESISTOR
R66		QRD161J-821	RESISTOR
R67		QRD161J-821	RESISTOR
R71		QRD161J-104	RESISTOR
R72		QRD161J-154	RESISTOR
R73		QRD161J-104	RESISTOR
R74		QRD161J-154	RESISTOR
R75		QRD161J-272	RESISTOR
R76		QRD161J-224	RESISTOR
R77		QRD161J-103	RESISTOR
R78		QRD161J-820	RESISTOR
R79		QRD161J-473	RESISTOR
R84		QRD161J-103	RESISTOR
R86		QRD161J-101	RESISTOR
C 1		QCBB1HK-102	CAPACITOR
C 2		QETC1CM-476	E CAPACITOR
C12		QCXB1CM-222	CAPACITOR
C13		QCBB1HK-102	CAPACITOR
C14		QCXB1CM-222	CAPACITOR
C15		QCC11EK-473	CAPACITOR
C16		QETC1CM-336	E CAPACITOR
C17		QCXB1CM-222	CAPACITOR
C19		QETC1HM-474	E CAPACITOR
C21		QCXB1CM-222	CAPACITOR
C22		QETC1CM-336	E CAPACITOR
C23		QCVB1CM-103	CAPACITOR
C24		QCBB1HJ-101	CAPACITOR
C26		QETC1CM-106	E CAPACITOR
C27		QETC1HM-105	E CAPACITOR
C28		QCXB1CM-222	CAPACITOR
C29		QETC1CM-476	E CAPACITOR
C30		QETC1CM-106	E CAPACITOR
C31		QCT25PH-270	CAPACITOR
C32		QETC1HM-474	E CAPACITOR
C37		QFN31HK-392	M CAPACITOR

*Δ REF NO.	PART NO.	PART NAME, DESCRIPTION
C38	QFN31HK-392	M CAPACITOR
C39	QFN31HK-392	M CAPACITOR
C41	QETC1CM-106	E CAPACITOR
C42	QETC1CM-106	E CAPACITOR
C43	QETC1CM-476	E CAPACITOR
C44	QCF31HP-223	CAPACITOR
C45	QCC11EK-473	CAPACITOR
C46	QFP31HJ-102	M CAPACITOR
C47	QETA1CM-477	E CAPACITOR
C49	QEU51CM-108	E CAPACITOR
C50	QCXB1CM-222	CAPACITOR
C51	QCC11EK-473	CAPACITOR
C52	QETC1CM-106	E CAPACITOR
C53	QETC1CM-106	E CAPACITOR
C54	QETC1HM-105	E CAPACITOR
C63	QETC1CM-336	E CAPACITOR
C64	QETC1CM-476	E CAPACITOR
C65	QFN31HJ-123	M CAPACITOR
C66	QFN31HJ-123	M CAPACITOR
L 1	PU57717-1R0	PEAKING COIL
L 2	PU57717-1R5	PEAKING COIL
L 3	PU59152-6R8J	PEAKING COIL
L 4	PU59152-6R8J	PEAKING COIL
L 6	PU59152-6R8J	PEAKING COIL
L 9	PU59152-221J	PEAKING COIL
BPF1	PU58226	BAND PASS FILTER
CF1	PU49295	CERAMIC FILTER, 5.5MHZ
CF2	PU49295-2	N FILTER, 5.5MHZ
CF4	PU52775	CERAMIC FILTER, 5.74MHZ
CF5	PU52775-2	CERAMIC FILTER, 5.74M DET
SAW1	PU32987-7	SAW FILTER
T 3	PU59488	COIL, 5.6M SOUND 1 DET
T 4	PU59308	COIL, VCO
T 5	PU59489	COIL, 5.74M SOUND 2 DET
T 6	PU59490	COIL, 54.7K DET
T 7	PU59243	F.HTRAP
T 8	PU59243	F.HTRAP
CN 1	PU58929-3	CAP HOUSING
CN 2	PU58929-8	CAP HOUSING
CN 3	PU59374	JACK

* 16. TIMER BOARD ASSEMBLY <15> *		

PWBA	PB20002Q-01	TIMER BOARD ASSY
IC2	S-8053ALB	IC
IC101	UPD75216ACW-037	IC
IC102	UPD82C43CY	IC
Q1	2SC1317(RS)	TRANSISTOR
Q2	2SC3311A(RS)	TRANSISTOR
Q3	2SC3311A(RS)	TRANSISTOR
Q6	DTC124ES	TRANSISTOR
Q7	DTC124ES	TRANSISTOR
Q101	DTC124ES	TRANSISTOR
Q102	DTC124ES	TRANSISTOR
Q104	2SC3311A(RS)	TRANSISTOR

*Δ REF NO.	PART NO.	PART NAME, DESCRIPTION
D1	MTZJ5.1B	ZENER DIODE
OR	RD5.1ES-T1B2	ZENER DIODE
D2	1SS133	DIODE
D3	1SS133	DIODE
D5	RO9.1ES-T1B2	ZENER DIODE
OR	HZS9.1EB2	ZENER DIODE
D6	DA210S	DIODE
D7	MTZ8.2A	ZENER DIODE
OR	MTZ8.2B	ZENER DIODE
D8	MTZ8.2A	ZENER DIODE
OR	MTZ8.2B	ZENER DIODE
D103	1SS133	DIODE
OR	MA165	DIODE
D106	1SS133	DIODE
OR	MA165	DIODE
D107	1SS133	DIODE
OR	MA165	DIODE
D108	1SS133	DIODE
OR	MA165	DIODE
D111	1SS133	DIODE
OR	MA165	DIODE
R1	QRD161J-222	RESISTOR
R2	QRD161J-121	RESISTOR
R3	QRD161J-682	RESISTOR
R4	QRD161J-103	RESISTOR
R5	QRD161J-104	RESISTOR
R6	QRD161J-471	RESISTOR
R7	QRD161J-151	RESISTOR
R8	QRD161J-102	RESISTOR
R9	QRD161J-472	RESISTOR
R10	QRD161J-474	RESISTOR
R11	QRD161J-104	RESISTOR
R12	QRD161J-684	RESISTOR
R13	QRD161J-332	RESISTOR
R14	QRD161J-332	RESISTOR
R15	QRD161J-152	RESISTOR
R101	QRD161J-102	RESISTOR
R102	QRD161J-102	RESISTOR
R103	QRD161J-102	RESISTOR
R104	QRD161J-472	RESISTOR
R105	QRD161J-102	RESISTOR
R106	QRD161J-103	RESISTOR
R107	QRD161J-103	RESISTOR
R108	QRD161J-103	RESISTOR
R109	QRD161J-102	RESISTOR
R110	QRD161J-102	RESISTOR
R111	QRD161J-102	RESISTOR
R113	QRD161J-472	RESISTOR
R114	QRD161J-472	RESISTOR
R115	QRD161J-472	RESISTOR
R116	QRD161J-472	RESISTOR
R117	QRD161J-472	RESISTOR
R118	QRD161J-102	RESISTOR
R119	QRD161J-472	RESISTOR
R120	QRD161J-472	RESISTOR
R121	QRD161J-472	RESISTOR
R122	QRD161J-472	RESISTOR
R125	QRD161J-102	RESISTOR
R131	QRD161J-472	RESISTOR
R132	QRD161J-472	RESISTOR
R133	QRD161J-472	RESISTOR
R134	QRD161J-472	RESISTOR
R135	QRD161J-472	RESISTOR
R136	QRD161J-472	RESISTOR
R137	QRD161J-472	RESISTOR

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
R138		QRD161J-472	RESISTOR
R139		QRD161J-102	RESISTOR
R140		QRD161J-472	RESISTOR
R141		QRD161J-472	RESISTOR
R142		QRD161J-472	RESISTOR
R143		QRD161J-472	RESISTOR
R144		QRD161J-472	RESISTOR
R145		QRD161J-472	RESISTOR
R146		QRD161J-472	RESISTOR
R147		QRD161J-472	RESISTOR
R148		QRD161J-472	RESISTOR
R149		QRD161J-102	RESISTOR
R150		QRD161J-102	RESISTOR
R152		QRD161J-272	RESISTOR
R153		QRD161J-102	RESISTOR
R154		QRD161J-472	RESISTOR
R155		QRD161J-334	RESISTOR
R156		QRD161J-222	RESISTOR
R158		QRD161J-333	RESISTOR
R159		QRD161J-222	RESISTOR
R160		QRD161J-472	RESISTOR
R165		QRD161J-103	RESISTOR
R166		QRD161J-104	RESISTOR
R168		QRD161J-683	RESISTOR
RA101		QRB047J-472	RESISTOR ARRAY
	OR	QRB049J-472	RESISTOR ARRAY
	OR	QRB049J-472C	RESISTOR NETWORK
RA103		QRB047J-333	RESISTOR ARRAY
	OR	QRB049J-333	ARRAY
	OR	QRB049J-333C	RESISTOR NETWORK
RA104		QRB087J-224	RESISTOR ARRAY
	OR	QRB089J-224	RESISTOR ARRAY
	OR	QRB089J-224C	RESISTOR NETWORK
RA105		QRB067J-104	RESISTOR ARRAY
	OR	QRB069J-104	RESISTOR NETWORK
	OR	QRB069J-104C	RESISTOR NETWORK
RA106		QRB047J-224	RESISTOR NETWORK
	OR	QRB049J-224	RESISTOR NETWORK
	OR	QRB049J-224C	RESISTOR NETWORK
C1		QETC1CM-336	E CAPACITOR
C2		QETA1HM-335	E CAPACITOR
C3		QETA1AM-336	E CAPACITOR
C4		QETA0JM-336	E CAPACITOR
C5		QCBBIHJ-102	CAPACITOR
C6		QCVB1CM-103	CAPACITOR
C7		QETA1CM-106	E CAPACITOR
C8		PU59421-104	E CAPACITOR
C9		QETA1CM-106	E CAPACITOR
C101		PU57672-200	TRIMMER CAPACITOR, TIMER CLOCK
C102		QCT30CH-120	CAPACITOR
C103		QCSB1HJ-390	CAPACITOR
C104		QCSB1HJ-150	CAPACITOR
C105		QCC31CK-104	CAPACITOR
	OR	QCC31CJ-104	CAPACITOR
C107		QCC31CK-473	CAPACITOR
L1		PU48530-101K	PEAKING COIL
△ X101		PU58394	CRYSTAL RESONATOR
△ X102		PU60226	CRYSTAL RESONATOR
CL1		PU59154	WIRE CLAMP
TP1		PU56008	TEST PIN
TP2		PU56008	TEST PIN
TP3		PU56008	TEST PIN
CN1		PU58931-22	CAP HOUSING

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
CN2		PU58929-13	HOUSING
CN3		PU58844-107	CAP HOUSING
CN4		PU58844-104	CAP HOUSING

* 17. JUNCTION BOARD ASSEMBLY <16> *			

PWBA		P820072B	JUNCTION BOARD ASSY
CN1		PU58929-18	HOUSING
CN2		PU58929-20	HOUSING
CN4		PU59555-106	CAP HOUSING
CN5		PU58844-104	CAP HOUSING
CN6		PU58844-108	CAP HOUSING
CN7		PU59555-112	CAP HOUSING
CN8		PU58798-122	CAP HOUSING

* 18. VPS BOARD ASSEMBLY, (EG ONLY) <18> *			

PWBA		PU36127C	VPS BOARD ASSEMBLY
IC1		HD49703NT	IC
IC2		M5278L05	IC
Q1		2SB641R,S	TRANSISTOR
Q2		2SC3327A	TRANSISTOR
	OR	2SC2878A	TRANSISTOR
Q3		2SD637R,S	TRANSISTOR
D1-D5		1SS133	DIODE,X5
R1		QRD161J-103	RESISTOR
R2		QRD161J-103	RESISTOR
R3		QRD161J-102	RESISTOR
R4		QRD161J-102	RESISTOR
R5		QRD161J-102	RESISTOR
R6		QRD161J-473	RESISTOR
R7		QRD161J-103	RESISTOR
R8		QRD161J-391	RESISTOR
R9		QRD161J-562	RESISTOR
R10		QRD161J-102	RESISTOR
R11		QRD161J-473	RESISTOR
R12		QRD161J-562	RESISTOR
R13		QRD161J-105	RESISTOR
R14		QRD161J-472	RESISTOR
R15		QRD161J-472	RESISTOR
R16		QRD161J-472	RESISTOR
R17		QRD161J-472	RESISTOR
R18		QRD161J-562	RESISTOR
R19		QRD161J-563	RESISTOR
R20		QRD161J-222	RESISTOR
R21		QRD161J-222	RESISTOR
R22		QRD161J-222	RESISTOR
R23		QRD161J-222	RESISTOR
R24		QRD161J-472	RESISTOR
R25		QRD161J-682	RESISTOR
R26		QRD161J-472	RESISTOR
R27		QRD161J-102	RESISTOR
R28		QRD161J-103	RESISTOR
R29		QRD161J-103	RESISTOR
R30		QRD161J-184	RESISTOR

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
R31		QRD161J-103	RESISTOR
R32		QRD161J-332	RESISTOR
R33		QRD161J-561	RESISTOR
R34		QRD161J-474	RESISTOR
R35		QRD161J-474	RESISTOR
R36		QRD161J-332	RESISTOR
R37		QRD161J-103	RESISTOR
RA1		QRB049J-224C	RESISTOR ARRAY
C1		QETC1CM-336	E CAPACITOR
C2		QCS31HJ-681	CAPACITOR
C3		QETC1CM-106	E CAPACITOR
C4		QCS31HJ-391	CAPACITOR
C5		QCT25CH-390	CAPACITOR
C6		QFN31HJ-103	M CAPACITOR
C7		QFN31HJ-102	M CAPACITOR
C8		QFN31HJ-102	M CAPACITOR
C9		QETC1CM-336	E CAPACITOR
C10		QETC1CM-336	E CAPACITOR
C11		QCF31HP-473	CAPACITOR
C12		QETC1CM-336	E CAPACITOR
C13		QETC1CM-336	E CAPACITOR
C14		QETC1CM-336	E CAPACITOR
C15		QCS31HJ-391	CAPACITOR
C16		QETC1HM-335	E CAPACITOR
C17		QETC1HM-105	E CAPACITOR
C18		QETC1HM-106	E CAPACITOR
C19		QCT25CH-390	CAPACITOR
C20		QCT25CH-150	CERAMIC CAP
C21		QETC1CM-336	E CAPACITOR
C22		QCT25CH-100	CAPACITOR
T1		PU58484	COIL
TP1-TP6		PU56008	TEST-PIN,X6
CN1		PU58929-3	CAP HOUSING
CN2		PU58844-4	CAP HOUSING

* 19. POWER TRANSISTOR BOARD ASSEMBLY <19> *			

PWBA		PB400028	POWER TRANSISTOR BOARD ASSY
Q7		2SD1785	TRANSISTOR
Q8		2SD1761(DE)	TRANSISTOR
Q9		2SD1785	TRANSISTOR
Q10		2SD1785	TRANSISTOR
R22		QRD142J-R47S	RESISTOR
R23		QRD142J-R47S	RESISTOR
△ HS1		PQ31808	HEAT SINK
SCW1		DPSP3010Z	SCREW,X4 FOR Q7-Q10

* 20. DIGITAL BOARD ASSEMBLY <20> *			

PWBA		PB20216A-01	DIGITAL BOARD ASSEMBLY

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
IC1		VC2058	IC
IC2		MB40176	IC
IC3		UPD41221C-70	IC
	OR	UPD41221C-90	IC
IC4		UPD41221C-70	IC
	OR	UPD41221C-90	IC
IC5		UPD41221C-70	IC
	OR	UPD41221C-90	IC
IC6		UPD41221C-70	IC
	OR	UPD41221C-90	IC
IC7		UPD41221C-70	IC
	OR	UPD41221C-90	IC
IC8		UPD41221C-70	IC
	OR	UPD41221C-90	IC
Q1		2SC1740S(RS)	TRANSISTOR
	OR	2SC3311(RS)	TRANSISTOR
Q2		2SA933S(RS)	TRANSISTOR
	OR	2SA1309R,S	TRANSISTOR
Q3		2SC1740S(RS)	TRANSISTOR
	OR	2SC3311(RS)	TRANSISTOR
Q4		2SC3354	TRANSISTOR
Q5		2SC3354	TRANSISTOR
Q6		2SC3354	TRANSISTOR
Q7		2SC3354	TRANSISTOR
Q8		2SC1740S(RS)	TRANSISTOR
	OR	2SC3311(RS)	TRANSISTOR
Q9		2SC1740S(RS)	TRANSISTOR
	OR	2SC3311(RS)	TRANSISTOR
Q10		DTC114ES	TRANSISTOR
D2		11ES2	DIODE
R1		QRD161J-102	RESISTOR
R2		QRD161J-102	RESISTOR
R3		QRD161J-102	RESISTOR
R4		QRD161J-221	RESISTOR
R5		QRD161J-332	RESISTOR
R6		QRD161J-102	RESISTOR
R7		QRD161J-151	RESISTOR
R8		QRD161J-221	RESISTOR
R9		QRD161J-102	RESISTOR
R10		QRD161J-102	RESISTOR
R11		QRD161J-102	RESISTOR
R12		QRD161J-223	RESISTOR
R14		QRD161J-104	RESISTOR
R15		QRD161J-153	RESISTOR
R16		QRD161J-472	RESISTOR
R17		QRD161J-561	RESISTOR
R18		QRD161J-152	RESISTOR
R19		QRD161J-332	RESISTOR
R20		QRD161J-223	RESISTOR
R21		QRD161J-681	RESISTOR
R22		QRD161J-104	RESISTOR
R23		QRD161J-473	RESISTOR
R24		QRD161J-221	RESISTOR
R25		QRD161J-822	RESISTOR
R26		QRD161J-153	RESISTOR
R27		QRD161J-102	RESISTOR
R28		QRD161J-104	RESISTOR
R29		QRD161J-363	RESISTOR
R30		QRD161J-102	RESISTOR
R31		QRD161J-472	RESISTOR
R32		QRD161J-472	RESISTOR
R33		QRD161J-472	RESISTOR
R34		QRD161J-103	RESISTOR
R35		QRD161J-103	RESISTOR
R36		QRD161J-472	RESISTOR
R37		QRD161J-472	RESISTOR
R38		QRD161J-472	RESISTOR

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
R39	QRD161J-103		RESISTOR
R40	QRD161J-103		RESISTOR
C1	QCB81HJ-820		CAPACITOR
C2	QCVB1CM-103		CAPACITOR
C3	QEK61CM-476		E CAPACITOR
C4	QCVB1CM-103		CAPACITOR
C5	QCVB1CM-103		CAPACITOR
C6	QCVB1CM-103		CAPACITOR
C7	QCVB1CM-103		CAPACITOR
C8	QCVB1CM-103		CAPACITOR
C9	QCVB1CM-103		CAPACITOR
C10	QCVB1CM-103		CAPACITOR
C11	QCVB1CM-103		CAPACITOR
C12	QEK61CM-476		E CAPACITOR
C13	QEJ41AM-106		TANTAL CAP
C14	QEK61HM-105		E CAPACITOR
C15	QEK61HM-105		E CAPACITOR
C16	QEK61HM-105		E CAPACITOR
C17	QEJ41AM-106		TANTAL CAP
C18	QEJ41AM-106		TANTAL CAP
C19	PU59971-104		CAPACITOR
C20	PU59971-104		CAPACITOR
C21	PU59971-104		CAPACITOR
C22	PU59971-104		CAPACITOR
C23	QEJ41AM-106		TANTAL CAP
C24	QCB81HJ-102		CAPACITOR
C25	QEN61CM-336		NP E CAPACITOR
C27	QCSB1HJ-220		CAPACITOR
C28	QCSB1HJ-200		CAPACITOR
C32	QCB81HJ-151		CAPACITOR
L1	PU59152-150J		PEAKING COIL
L2	PU59152-270J		PEAKING COIL
L3	PU59152-330J		PEAKING COIL
LPF1	PU59542		LOW PASS FILTER
LC1	PU59736-331		N FILTER
LC2	PU59736-331		RESISTOR
LC3	PU59736-331		N FILTER
LC4	PU59736-331		N FILTER
LC5	QRD161J-103		RESISTOR
LC6	PU59736-331		N FILTER
LC7	PU59736-223		N FILTER
LC8	PU59736-223		N FILTER
LC9	PU59736-223		N FILTER
LC10	PU59736-223		N FILTER
LC11	PU59736-331		N FILTER
LC12	PU59736-331		N FILTER
LC13	PU59736-331		N FILTER
LC14	PU59736-331		N FILTER
LC15	PU59736-331		N FILTER
LC16	PU59736-331		N FILTER
LC17	PU59736-331		N FILTER
LC18	PU59736-223		N FILTER
LC19	PU59736-223		N FILTER
LC20	PU59736-223		N FILTER
LC21	PU59736-223		N FILTER
LC22	PU59736-223		N FILTER
T1	PU60388		LC FILTER
T2	PU60388		LC FILTER
SLD1	PU60389-1-1		SHIELD CASE 1
SLD2	PU59552		SHIELD CASE 2
SLD3	PU36444-1-1		SHIELD CASE 3
CN1	PU58931-8		HOUSING

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
CN2	PU58929-4		CAP HOUSING
CN3	PU58844-104		CAP HOUSING
CN4	PU58844-102		CAP HOUSING
CN5	PU58844-104		CAP HOUSING
CN6	PU58844-2		CAP HOUSING

* 21. OPERATION BOARD ASSEMBLY <22> *			

PWBA	PB20092B		OPERATION BOARD ASSY
IC201	GP1U501		INFRATED RAYS UNIT
D200	MTZ5.1B		ZENER DIODE
D201	SLV-31MC3F		LE DIODE
D202	SLV-31MC3F		LE DIODE
D208	SLH-34VC3F		LE DIODE
D209	SLH-34VC3F		LE DIODE
D210	SLH-34VC3F		LE DIODE
D211	SLH-34VC3F		LE DIODE
R201	QRD161J-471		RESISTOR
R208	QRD161J-222		RESISTOR
R209	QRD161J-222		RESISTOR
R210	QRD161J-332		RESISTOR
R213	QRD161J-821		RESISTOR
R215	QRD161J-222		RESISTOR
R216	QRD161J-222		RESISTOR
R217	QRD161J-332		RESISTOR
R218	QRD161J-472		RESISTOR
R219	QRD161J-103		RESISTOR
R220	QRD161J-223		RESISTOR
R404	PU57928		V RESISTOR, PHONES LEVEL
C301	QCB81HJ-102		CAPACITOR
LC201	PU59326-223SL		N FILTER
LC202	PU59326-223SL		N FILTER
S201	PU57551		SWITCH(TACT), POWER
S202	PU57551		SWITCH(TACT), EJECT
S204	PU57551		SWITCH(TACT), STOP
S205	PU57551		SWITCH(TACT), PAUSE
S206	PU57551		SWITCH(TACT), PLAY
S207	PU57551		SWITCH(TACT), REW
S208	PU57551		SWITCH(TACT), FF
S209	PU57551		SWITCH(TACT), REC
S214	PU57551		SWITCH(TACT), A DUB
CL1	PU59311-2		WIRE CLAMP
HD1	PQ31764		SHADE (LED)
HD2	PQM30038-2-2		LED HOLDER,X4
J401	PU58356-2		JACK(HEADPHONE)
J402	PU58355-2		MIC JACK
CN1	PU59513-4		CAP HOUSING
CN3	PU58844-104		CAP HOUSING
CN4	PU59513-3		CAP HOUSING
CN5	PU59513-4		CAP HOUSING

#	REF NO.	PART NO.	PART NAME, DESCRIPTION

* 22. DISPLAY BOARD ASSEMBLY <27> *			

PWBA	PB20041A		DISPLAY BOARD ASSY,E
	PB20041C		DISPLAY BOARD ASSY,EG
IC1	UPD7538ACU-214	IC	
	OR UPD7538ACU-216	IC	
IC2	BA618	IC	
IC101	MSC1124BRS	IC	
Q1	DTC124EF	TRANSISTOR	
Q2	DTA114EF	TRANSISTOR	
D1	RD8.2E-T1B2	ZENER DIODE	
D2	1SS132	DIODE	
D3	1SS132	DIODE	
D4	1SS132	DIODE	
D5	1SS132	DIODE	
D6	1SS132	DIODE	
D7	RD3.0ES-T1B2	ZENER DIODE	
O101	RD24E-T1B2	ZENER DIODE	
O212	SLH-34VC3F	LE DIODE	
O213	SLH-34VC3F	LE DIODE	
O214	SLH-34VC3F	LE DIODE	
O215	SLH-34VC3F	LE DIODE	
R1	QRD161J-102	RESISTOR	
R2	QRD161J-103	RESISTOR	
R3	QRD161J-103	RESISTOR	
R4	QRD161J-102	RESISTOR	
R5	QRD161J-102	RESISTOR	
R6	QRD161J-103	RESISTOR	
R7	QRD161J-472	RESISTOR	
R8	QRD161J-273	RESISTOR	
R9	QRD161J-104	RESISTOR	
R10	QRD161J-104	RESISTOR	
R11	QRD161J-102	RESISTOR	
R12	QRD161J-102	RESISTOR	
R13	QRD161J-102	RESISTOR	
R14	QRD161J-102	RESISTOR	
R15	QRD161J-102	RESISTOR	
R16	QRD161J-102	RESISTOR	
R17	QRD161J-102	RESISTOR	
R19	QRD161J-102	RESISTOR	
R20	QRD161J-102	RESISTOR	
R21	QRD161J-102	RESISTOR	
R102	QRD161J-104	RESISTOR	
R103	QRD161J-103	RESISTOR	
R104	QRD161J-151	RESISTOR	
R105	QRD161J-103	RESISTOR	
R106	QRD161J-104	RESISTOR	
R107	QRD161J-151	RESISTOR	
R108	QRD161J-103	RESISTOR	
R109	QRD161J-103	RESISTOR	
R110	QRD161J-103	RESISTOR	
C1	QCBB1HJ-101	CAPACITOR	
C2	QCBB1HJ-101	CAPACITOR	
C3	QER40JM-476	E CAPACITOR	
C5	QER41VM-226	E CAPACITOR	
C6	QCF11HP-103	CAPACITOR	
C7	QCBB1HJ-102	CAPACITOR	

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
C8	QCVB1CM-103		CAPACITOR
C9	QCVB1CM-103		CAPACITOR
C102	QER41HM-475		E CAPACITOR
C103	QER41HM-105		E CAPACITOR
C104	QER41HM-105		E CAPACITOR
C105	QER41CM-106		E CAPACITOR
C106	QER41CM-106		E CAPACITOR
C107	QFJ41HJ-223		M CAPACITOR
C108	QER41HM-225		E CAPACITOR
△ CF1	PU59109		RESONATOR
FDP1	PU59952-2		FLUORESCENT DISPLAY PANEL,E
	PU59952-3		FLUORESCENT DISPLAY PANEL,EG
HD1	PQ31309		FDP HOLDER (L)
HD2	PQ31310		FDP HOLDER (R)
HD3	PQ43223		LED HOLDER

* 23. SUB JUNCTION BOARD ASSEMBLY <38> *			

PWBA	PB30017A		SUB JUNCTION BOARD ASSY
CN1	PU58798-120		FFC CONNECTOR

* 24. CONTROL BOARD ASSEMBLY <39> *			

PWBA	PB10044B-01		CONTROL BOARD ASSY
D401	1SS133		DIODE
D402	1SS133		DIODE
R211	QRD162J-472		RESISTOR
R212	QRD162J-103		RESISTOR
R221	QRD162J-563		RESISTOR
R222	QRD162J-223		RESISTOR
R305	QRD162J-102		RESISTOR
R306	QRD162J-223		RESISTOR
R307	QRD162J-223		RESISTOR
R401	PU59092-12		V RESISTOR, SHARPNESS (10K)
R402	PU59092-13		V RESISTOR, V LOCK ADJ (500K)
R405	PU59092-1		SLIDE CTL, HIFI REC LEV(2K)
S1	PU59092-14		SWITCH(TACT), 1/SUN
S2	PU59092-14		SWITCH(TACT), 2/MON
S3	PU59092-14		SWITCH(TACT), 3/TUE
S4	PU59092-14		SWITCH(TACT), 4/WED
S5	PU59092-14		SWITCH(TACT), 5/THU
S6	PU59092-14		SWITCH(TACT), 6/FRI
S7	PU59092-14		SWITCH(TACT), 7/SAT
S8	PU59092-14		SWITCH(TACT), 8/1ND/2ND
S9	PU59092-14		SWITCH(TACT), 9/DAI
S10	PU59092-14		SWITCH(TACT), 0/AUX
S11	PU59092-14		SWITCH(TACT), GO-T0
S13	PU59092-14		SWITCH(TACT), C RESET
S14	PU59092-14		SWITCH(TACT), DISPLAY
S15	PU59092-14		SWITCH(TACT), INST REC

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
*	S16	PU59092-14	SWITCH(TACT), TIMER
	S17	PU59092-14	SWITCH(TACT), CH+/NEXT
	S18	PU59092-14	SWITCH(TACT), CH-/BACK
	S19	PU59092-14	SWITCH(TACT), SEARCH
	S20	PU59092-14	SWITCH(TACT), CH
	S21	PU59092-14	SWITCH(TACT), CANCEL/SKIP
	S22	PU59092-14	SWITCH(TACT), STORE
	S23	PU59092-14	SWITCH(TACT), FINE (+)
	S24	PU59092-14	SWITCH(TACT), FINE (-)
	S25	PU59092-14	SWITCH(TACT), C ADJ
	S26	PU59092-14	SWITCH(TACT), PROGRAM
	S27	PU59092-14	SWITCH(TACT), SP/LP
	S210	PU59092-14	SWITCH(TACT), A MONI
	S215	PU59092-14	SWITCH(TACT), TRACK (+)
	S216	PU59092-14	SWITCH(TACT), SLOW (+)
	S217	PU59092-14	SWITCH(TACT), TRACK (-)
	S218	PU59092-14	SWITCH(TACT), SLOW (-)
	S401	PU54440	SWITCH, INPUT SEL
	S402	PU54440	SWITCH, C MEMORY
	S407	PU59092-6	SWITCH, LEVEL IND
	S409	PU54440	SWITCH, ALC
	S410	PU54440	SWITCH, AC ONLINE
	S415	PU54440	SWITCH, MIX
	S417	PU54440	SWITCH, TNR S SEL
	J1	PU36448	FPC
	SPC1	PQM30029-102	SPACER
	WR1	PU60341	FPC
	CN1	PU60329-120	FPC CONNECTOR

	*	25. UPPER DRUM BOARD <41>	*

	PWB1	PDM3017	UPPER DRUM BOARD

	*	26. PRE/REC AMP BOARD ASSEMBLY <43>	*

	PWBA	PU36147F-01	PRE/REC AMP BOARD ASSEMBLY
	IC1	HA118019NT	IC
	Q1	DTC144WS	TRANSISTOR
	Q2	DTC144WS	TRANSISTOR
	Q3	2SA1309R,S	TRANSISTOR
	Q4	2SC1740S(QRS)	TRANSISTOR
	D1	MA165	DIODE
	OR	1SS133	DIODE
	D2	MA165	DIODE
	OR	1SS133	DIODE
	D3	MA165	DIODE
	OR	1SS133	DIODE
	R1	QVZ3518-221	V RESISTOR, SP CH-2,Q
	R2	PU57457-221	V RESISTOR, SP CH-1,Q
	R3	QVZ3518-221	V RESISTOR, LP CH-1,Q

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
	R4	PU57457-221	V RESISTOR, LP CH-2,Q
	R5	QRD161J-184	RESISTOR
	R6	QRD161J-223	RESISTOR
	R7	QRD161J-223	RESISTOR
	R8	QRD161J-393	RESISTOR
	R9	QRD161J-103	RESISTOR
	R10	QRD161J-153	RESISTOR
	R11	QRD161J-103	RESISTOR
	R12	QRD161J-103	RESISTOR
	R13	QRD161J-103	RESISTOR
	R14	QRD161J-223	RESISTOR
	R15	QRD161J-103	RESISTOR
	R17	QRD161J-152	RESISTOR
	R18	QRD161J-332	RESISTOR
	R19	QRD161J-391	RESISTOR
	R20	QRD161J-561	RESISTOR
	R21	QRD161J-561	RESISTOR
	R22	QRD161J-474	RESISTOR
	R24	QRD161J-223	RESISTOR
	R25	QRD161J-272	RESISTOR
	C1	QCVB1CN-103	CAPACITOR
	C2	QFZ0096-224	MM CAPACITOR
	C3	QFZ0096-224	MM CAPACITOR
	C4	QCSB1HJ-220	CAPACITOR
	C5	PU57672-500	TANTAL CAPACITOR, SP CH-2,F0
	C6	QCSB1HJ-390	CAPACITOR
	C7	PU57672-500	TANTAL CAPACITOR, SP CH-1,F0
	C8	QCVB1CN-103	CAPACITOR
	C9	QCVB1CN-103	CAPACITOR
	C10	QFZ0096-224	MM CAPACITOR
	C11	QFZ0096-224	MM CAPACITOR
	C12	QCSB1HJ-330	CAPACITOR
	C13	PU57672-500	TANTAL CAPACITOR, LP CH-1,F0
	C14	QCSB1HJ-390	CAPACITOR
	C15	PU57672-500	TANTAL CAPACITOR, LP CH-2,F0
	C16	QCVB1CN-103	CAPACITOR
	C17	QER60JM-476	E CAPACITOR
	C18	QCF31HP-223	CAPACITOR
	C20	QCSB1HJ-681	CAPACITOR
	C21	QCVB1CN-103	CAPACITOR
	C22	QCVB1CN-103	CAPACITOR
	C23	QEK61HM-104	E CAPACITOR
	C24	QCVB1CN-103	CAPACITOR
	C25	QCSB1HJ-820	CAPACITOR
	C26	QCF31HP-223	CAPACITOR
	C27	QER60JM-476	E CAPACITOR
	C29	QCVB1CN-103	CAPACITOR
	C31	QCSB1HJ-300	CAPACITOR
	C32	QCVB1CN-103	CAPACITOR
	C33	QCF31HP-223	CAPACITOR
	C34	QET60JM-476	E CAPACITOR
	L1	PU54223-101K	PEAKING COIL
	L4	PU54223-560J	PEAKING COIL
	L5	PU54223-101K	PEAKING COIL
	L6	PU54223-101K	PEAKING COIL
	SPC	WBS2600Z	WASHER
	BKT1	PQ42558	PWB BRACKET
	ETH1	PQ40433-2	EARTH LUG
	SCW1	DPSP2606Z	SCREW
	SCW2	DPSP2606Z	SCREW,X2
	SLD1	PU59080	PRE AMP SHIELD (1)
	SLD2	PU59081-1-3	PRE AMP SHIELD (2)

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
	SPC1	WBS2600Z	WASHER
	TP	PU57545	TEST PIN, X5
	CN1	PU58844-12	CAP HOUSING
	CN2	PU56258-10	CAP HOUSING
	CN3	PU58844-6	CAP HOUSING

* 27. DECK TERMINAL BOARD ASSEMBLY <51><53> *			

	PWBA	PU22329F-02	D.TERM BOARD ASS,Y - DECK TERMINAL BOARD ASS'Y <51>-
	PWBA1	PU22329B1	DECK TERMINAL BOARD ASSY
	R1	QRD181J-151	RESISTOR
	R3	QRD181J-331	RESISTOR
	PS1	PU60271	PHOTO INTERRUPTER
	CN1	PU58798-17	CAP CONNECTOR - REC SAFETY BOARD ASS'Y <53> -
	PWBA3	PU22329A3	REC SAFETY BOARD ASSY
	S1	PU58644-1-3	REC SAFETY SWITCH

* 28. RELAY BOARD ASSEMBLY <52> *			

	PWBA2	PU22329D2	RELAY BOARD ASSY
	LC	PU59809-222T	N FILTER, X2

* 29. END SENSOR BOARD ASSEMBLY <54> *			

	PWBA4	PU22329A4	END SENSOR BOARD ASSY
	Q1	PN268R-NC	PHOTO TRANSISTOR
	HD1	PQ31047	END SENSOR HOLDER
	WR1	PW30110-26DD885	PARALLEL WIRE
	CN1	PU49215-102	CAP HOUSING

* 30. CASSETTE HOUSING BOARD <56> *			

	PWB1	PB30043	CASSETTE HOUSING BOARD
	Q1	PN268R-NC	PHOTO TRANSISTOR
	R1	QRD161J-471	RESISTOR
	PS1	PU58879	PHOTO INTERRUPTER
	CN1	PU58844-106	CAP HOUSING

#	REF NO.	PART NO.	PART NAME, DESCRIPTION

* 31. APC BOARD ASSEMBLY <61> *			

	PWBA	PU36276B-01	APC BOARD ASSEMBLY
	IC1	HA11247	IC
	Q1	2SC1740S(RS)	TRANSISTOR
	Q3	2SC1740S(RS)	TRANSISTOR
	R1	QRD161J-471	RESISTOR
	R2	QRD161J-561	RESISTOR
	R3	QRD161J-102	RESISTOR
	R4	QRD161J-152	RESISTOR
	R6	QRD181J-103	RESISTOR
	R9	QRD161J-102	RESISTOR
	R10	QRD161J-102	RESISTOR
	R13	QRD182J-332	RESISTOR
	C1	QETC1EM-475	E CAPACITOR
	OR	QET61EM-475	E CAPACITOR
	C2	QCC31CJ-223	CAPACITOR
	OR	QCC31EJ-223	CAPACITOR
	C3	QCSB1HJ-220	CAPACITOR
	C4	QCSB1HJ-620	CAPACITOR
	C5	QCSB1HJ-220	CAPACITOR
	C8	QETA1CM-107	E CAPACITOR
	C9	QCVB1CM-103	CAPACITOR
	C10	QCVB1CM-103	CAPACITOR
	C11	QETC1CM-336	E CAPACITOR
	OR	QET61CM-336	E CAPACITOR
	C12	QCSB1HJ-330	CAPACITOR
	C13	QCVB1CM-103	CAPACITOR
	C14	QETC1EM-475	E CAPACITOR
	OR	QET61EM-475	E CAPACITOR
	L1	PU48530-390J	PEAKING COIL
	L2	PU48530-101K	PEAKING COIL
	△ X1	PU31449-4K	CRYSTAL RESONATOR
	BKT1	PQ43625	BRACKET (APC)
	SCW1	DPSP2606Z	SCREW
	CN1	PU58844-6	CAP HOUSING

* 32. DIG. COL. PROCESS BOARD ASSEMBLY <62> *			

	PWBA	PB20217A	DIG. COL. PROCESS BOARD ASSY
	IC1	AN6308	IC
	IC2	AN6308	IC
	Q1	2SC1740S(QRS)	TRANSISTOR
	Q2	2SC1740S(QRS)	TRANSISTOR
	Q4	2SC1740S(QRS)	TRANSISTOR
	Q5	2SC1740S(QRS)	TRANSISTOR
	Q6	2SC1740S(QRS)	TRANSISTOR
	Q7	2SC1740S(QRS)	TRANSISTOR
	R1	QRD161J-223	RESISTOR
	R2	QRD161J-333	RESISTOR
	R3	QRD161J-102	RESISTOR
	R4	QRD161J-102	RESISTOR
	R5	QRD161J-102	RESISTOR
	R6	QRD161J-182	RESISTOR
	R7	QRD161J-391	RESISTOR
	R8	QRD161J-182	RESISTOR
	R9	QRD161J-102	RESISTOR
	R10	QRD161J-102	RESISTOR

#	REF NO.	PART NO.	PART NAME, DESCRIPTION
R11		QRD161J-182	RESISTOR
R12		QRD161J-391	RESISTOR
R13		QRD161J-472	RESISTOR
R14		QVZ3521-221	V RESISTOR, DIG. COL LEVEL
R15		QRD161J-181	RESISTOR
R16		QRD161J-471	RESISTOR
R17		QRD161J-473	RESISTOR
R18		QRD161J-223	RESISTOR
R19		QRD161J-102	RESISTOR
R20		QRD161J-102	RESISTOR
R21		QRD161J-820	RESISTOR
R22		QRD161J-222	RESISTOR
R23		QRD161J-472	RESISTOR
R24		QRD161J-472	RESISTOR
R25		QRD161J-333	RESISTOR
R26		QRD161J-123	RESISTOR
R27		QRD161J-122	RESISTOR
R28		QRD161J-471	RESISTOR
R29		QRD161J-102	RESISTOR
R30		QRD161J-222	RESISTOR
C2		QETC0JM-476	E CAPACITOR
C3		QCVB1CN-103	CAPACITOR
C4		QETCIAM-226	E CAPACITOR
C5		QETCIAM-226	E CAPACITOR
C6		QCVB1CN-103	CAPACITOR
C7		QETC0JM-227	E CAPACITOR
C8		QCVB1CN-103	CAPACITOR
C9		QCVB1CN-103	CAPACITOR
C10		QCVB1CN-103	CAPACITOR
C11		QETC0JM-476	E CAPACITOR
C12		QCVB1CN-103	CAPACITOR
C13		QCVB1CN-103	CAPACITOR
C14		QCVB1CN-103	CAPACITOR
C15		QCVB1CN-103	CAPACITOR
C16		QETC0JM-476	E CAPACITOR
C17		QETC0JM-476	E CAPACITOR
L1		PU48530-101K	PEAKING COIL
L2		PU59152-8R2J	PEAKING COIL
L3		PU59152-8R2J	PEAKING COIL
L4		PU48530-101K	PEAKING COIL
LPF1		PU58021-2	LOW PASS FILTER
LPF2	OR	PU58021-3	LOW PASS FILTER
LPF2		PU60547	LOW PASS FILTER
BPF1		PU57072	BAND PASS FILTER
DL1		PU60551	1H DELAY LINE
TP		PU55774	TEST PIN, X2
CN1		PU58844-2	CAP HOUSING
CN2		PU58844-2	CAP HOUSING

#	REF NO.	PART NO.	PART NAME, DESCRIPTION

* 33. FUSE BOARD ASSEMBLY <65> *			

	PWBA	PU59814B	FUSE BOARD ASSEMBLY
	BKT1	PQ31633	BRACKET
	△ HD1	PUS7505	FUSE CLIP, X4
	SCW1	SDST3006Z	SCREW
	△ F2	QMF51E2-2R5	FUSE, NOT INCL. FUSE BOARD ASSY
	△ F3	QMF51E2-1R6	FUSE, NOT INCL. FUSE BOARD ASSY

* 34. REMOTE CONTROL BOARD ASSEMBLY [RM] *			

	PWBA	PQ10543-027	REMOCON BOARD ASSY
	IC1	M50565-016FP	IC
	Q1	2SD601(RS)	TRANSISTOR
	Q2	2SB822(RS)	TRANSISTOR
	LED1	SE303AY	LE DIODE
	LED2	SE303AY	LE DIODE
	D1	MA151WA	DIODE
	D2	MA151A	DIODE
	D3	MA151WK	DIODE
	D4	MA151WK	DIODE
	D5	MA151WK	DIODE
	D6	MA151WK	DIODE
	D7	MA151WK	DIODE
	D8	MA151WK	DIODE
	D9	MA151WK	DIODE
	D10	MA151WK	DIODE
	D11	MA151WK	DIODE
	D12	MA151WK	DIODE
	D13	MA151WK	DIODE
	D14	MA151WK	DIODE
	D15	MA151WK	DIODE
	D16	MA151WK	DIODE
	D17	MA151WK	DIODE
	D18	MA151WK	DIODE
	D19	MA151WA	DIODE
	X1	CSB400PB1T	CERAMIC RESONATOR
	S129	PQ10355-021	SLIDE SWITCH
	TML1	PQ10355-018	BATTERY TERMINAL, (-)
	TML2	PQ10355-017	BATTERY TERMINAL, (+)