



STEREO DOUBLE CASSETTE DECK
KX-W4080/W6080
 SERVICE MANUAL

KENWOOD

15年保管

Illustration is KX-W6080.



* Refer to parts list on page 21.

PRECAUTIONS FOR REPAIR

Refer to KX-W4070/W6070 service manual(B51-5031-00), if you want to know more information of **CIRCUIT DESCRIPTION**.

KX-W4080/W6080


CONTENTS / ACCESSORIES / CAUTIONS

Contents


CONTENTS / ACCESSORIES / CAUTIONS	2	EXPLODED VIEW	19
CONTROLS	3	PARTS LIST	21
ADJUSTMENT	5	PARTS DESCRIPTIONS	25
PC BOARD	9	SPECIFICATIONS	BACK COVER
SCHEMATIC DIAGRAM	11		

Accessories

Audio cord 2
(E30-0505-05)



System control cord 1
(E30-2816-05)



Except for U.S.A., Mexico, Canada,
U.K., Europe and Australia

AC plug adaptor 1
(E03-0115-05)



KX-W4080/W6080

CONTROLS

This Illustration shows the KX-W6080 model.


Operation Indicators (Deck A)

- ◀, ▶ Transport direction
- Recording indicator (KX-W6080 only)
- Pause indicator

Peak level indicators

(Dolby NR reference level)

CCRS indicators



Deck A counter

RELAY indicator

DUBBING indicators
NORMAL
HIGH

DOLBY NR indicators
B C

AUTO BIAS indicator

CCTS indicators

MPX indicator

BAL.BIAS LEVEL indicators

(KX-W4080:
BAL.,LEVEL only)

Operation Indicators (Deck B)

- ◀, ▶ Transport direction
- Recording indicator
- Pause indicator


MPX indicator

BAL.BIAS LEVEL indicators
(KX-W4080:
BAL.,LEVEL only)

Peak level indicators

(Dolby NR reference level)

CCRS indicators



Deck B counter

AUTO BIAS indicator

DOLBY NR indicators
B C

AUTO BIAS indicator

Display

Operation key section

Eject button ▲


Deck B:
Playback and
Recording

Deck A:
Playback and Recording
(KX-W4080: Playback only)

KENWOOD

AUTO REVERSE

TAPE A



II PAUSE key

● REC/ARM key

Fast reverse key ◀

Fast forward key ▶


● REC/ARM key
II PAUSE key
Fast forward key ▶
Fast reverse key ◀

POWER switch

PHONES jack

TIMER switch

MODE key



HIGH DUBBING key

NORMAL DUBBING key

Cautions

Beware of condensation

When water vapor comes into contact with the surface of cold material, water drops are produced. If condensation occurs, correct operation may not be possible, or the unit may not function correctly. This is not a malfunction, however, and the unit should be dried. (To do this, turn the POWER switch ON and leave the unit for several hours.)


Be especially careful in the following conditions:

- When the unit is brought from a cold place to a warm place, and there is a large temperature difference.
- When a heater starts operating.
- When the unit is brought from an air-conditioned place to a place of high temperature with high humidity.
- When there is a large difference between the internal temperature of the unit and the ambient temperature, or in conditions where condensation occurs easily.


KX-W4080/W6080

CONTROLS

■ Operation key section (KX-W6080)



■ Operation key section (KX-W4080)



KX-W4080/W6080


ADJUSTMENT

No.	ITEM	INPUT SETTING	OUTPUT SETTING	DECK SETTING	ALIGNMENT POINTS	ALIGN FOR	FIG.
Unless otherwise specified, set the respective switches as follows : TAPE : NORMAL, DOLBY : OFF 0dBs = 0.775V							
I. Cassette mechanism section(Adjustment of the REC/PLAY HEAD)							
(1)	DEMAGNETIZATION and CLEANING	—	—	POWER OFF Demagnetization Cleaning PLAY	REC/PLAY head Erase head Capstan Pinch roller	Demagnetize the REC/PLAY head with a head eraser. Clean the REC/PLAY head erase head, capstan and pinch roller using a cotton swab slightly damped with alcohol.	
(2)	AZIMUTH of the REC/PLAY HEAD	SCC-1727 TCC-153 MTT-114 10kHz, -10dB	—	PLAY	RVS FWD	Adjust the output to maximum and adjust the azimuth adjustment screw for the Lissajous waveform pattern of the oscilloscope to become close to a 45° straight line.	(a)
II. PC BOARD adjustment Note : Carry out the high-speed adjustment in the first place.							
[1]	TAPE SPEED (HI SPEED)	SCC-1727 TCC-110 MTT-111 3kHz	—	*TEST MODE	VR1 (A) VR2 (B)	Adjust the tape speed so that 6kHz is obtained at the center of the tape.	
[2]	TAPE SPEED (NORMAL)	—	—		VR3 (A) VR4 (B)	Adjust the tape speed so that 3kHz is obtained at the center of the tape.	

*Short circuit TP5, TP6 by diode (TP5 → TP6) and turn the POWER ON. FF key : High-speed, PLAY key : Normal-speed.

System connections

(a) Azimuth adjustment screw



*Please refer to Automatic Adjustment for Playing, Recording, BIAS level adjustment.

AJUSTES

Orden	ítem	Ajuste de entrada	Ajuste de salida	Ajuste de la platina	Puntos de ajuste	Método de ajuste	Fig.
A menos que se indique lo contrario, ajustar los interruptores respectivos de la manera siguiente : TAPE : NORMAL, DOLBY : OFF							0dBs = 0.775V
I. sección del mecanismo de la cassette (ajuste de la cabeza de GRABACION/ REPRODUCCION)							
(1)	DEMAGNETIZACION y LIMPIEZA	—	—	ALIMENTACION: apagado, desmagnetización, REPRODUCCION	Cabezas de GRABACION/ REPRODUCCION, cabezas de borrado, ejes de arrastre, rodillos presores	Demagnetizar las cabezas de grabación/reproducción con un borrador de cabezas. Limpiar las cabezas de grabación/reproducción, cabezas de borrado, ejes de arrastre y rodillos presores con un bastoncillo de algodón humedecido en alcohol.	
(2)	ACIMUT de la cabeza de GRABACION/ REPRODUCCION	SCC-1727 TCC-153 MTT-114 10kHz, -10dB	—	REPRODUCCION (PLAY)		Ajustar la salida al nivel máximo y regular el tornillo de ajuste del acimut para la forma de onda de Lissajous del osciloscopio de manera que sea lo más cercano posible a una línea recta de 45°.	(a)
II. Ajuste de la tarjeta circuito impreso							
Nota : Efectuar primero el ajuste de la alta velocidad.							
[1]	VELOCIDAD DE LA CINTA (ALTA VELOCIDAD)	SCC-1727 TCC-110 MTT-111 3kHz	—	*MODE DE PRUEBA	PLATINA A:VR1 PLATINA B:VR2	Ajustar de manera que la hasta obtener un nivel de 6kHz en el centro de la cinta.	
[2]	VELOCIDAD DE LA CINTA (NORMAL)				PLATINA A:VR3 PLATINA B:VR4	Ajustar de manera que la hasta obtener un nivel de 3kHz en el centro de la cinta.	

*Cortocircuitar (en el diodo) TP5 y TP6 y alimentar energía. Teca FF: alta velocidad ; teca de reproducción: velocidad normal.

(TP5 → TP6)

ADJUSTMENT

Playback Level & REC Level Adjustment

1. Automatic adjustment

• Playback level adjustment

- Turn the POWER OFF (AC OFF).
- Insert the TCC-130 into respective deck A or B.
- Short TP4-TP6 and turn the AC plug receptacle ON.
- When "END P" is displayed in FL, adjustment is complete.
If an error occurs, it will display the location causing the "CAL E", "PL E", etc.
Turn the POWER OFF (AC OFF) or the REC PAUSE key twice (one press is for the test mode) to return to normal operation.

• Recording level and bias adjustment

- Turn the POWER OFF (AC OFF).
- Insert the TCC-106A into deck B.
- Short TP4-TP6 and turn the AC plug receptacle ON.
- When "END" is displayed in FL, adjustment is complete.
If an error occurs, it will display the location causing the "RL E", "BL E", etc.
Turn the POWER OFF (AC OFF) or the PAUSE key twice (one press is for the test mode) to return to normal operation.

• Indication items of FL tube

- END P Normal completion state of playback level adjustment mode.
- END Normal completion state of all (playback/REC level) adjustment mode.
- CAL E Lch ERR state of sensitivity correction.
- CAR E Rch ERR state of sensitivity correction.

Counter A

- PLE Lch ERR state of A PB adjustment.
- PR E Rch ERR state of A PB adjustment.

Counter B

- PLE Lch ERR state of B PB adjustment.
- PR E Rch ERR state of B PB adjustment.

Counter B

- RL E Lch ERR state of B REC EQ adjustment.
- RR E Rch ERR state of B REC EQ adjustment.

Counter B

- BL E Lch ERR state of B BIAS adjustment.
- BR E Rch ERR state of B BIAS adjustment.

NOTE :

- The playback level can be adjusted independently for A or B. The procedure in this case as well is as in the above procedure.
- Turn off the display to suppress power fluctuations and other such problems during automatic adjustment.

- The playback level adjustment is done with the DOLBY level as the standard value, so be sure to use a 200nWb/m (315Hz or 400Hz) tape.

2. Manual adjustment

• Playback level adjustment

- Turn the POWER OFF (AC OFF).
- Turn the AC plug receptacle ON while shorting the TP7-TP6. Then open TP7-TP6.
- Insert the TCC-130 into deck A and play.
- Deck A Lch level adjustment
The initial FL display is "PL 00". The "00" displays the step number. Since the initial value is set at 30, adjust it at this setting by turning the REC LEVEL () key.
Adjustment level : TCC-130 (200nWb/m) → -1dBs (690mV). When using 160nWb/m or 250nWb/m tapes set to 4dBs and 0dBs respectively.
- Press the DUBB NOR key.
- When the DISPLAY key is pressed, the display switches to the "PR 00".
- Deck A Rch level adjustment : Same as Lch
- Press the DUBB NOR key.
- Press the DISPLAY key.
- Insert the TCC-106A into deck B and play.
- Deck B Lch level adjustment
- Press the DUBB NOR key.
- Press the DISPLAY key.
- Deck B Rch level adjustment
- Press the DUBB NOR key.
- Press the DISPLAY key.

• Recording level and bias adjustment

- Insert the recording tape into deck B (A BEX TCC-108A or TDK AC-225) and set the AG to 400Hz.
- Press the REC key to start recording and adjust the AG so that the output becomes -20dBs.
(If you press the PAUSE key at this time, manual adjustment will be cancelled, so be careful.)
Playback the recorded tape and turn the level volume so that the output becomes -20dBs.
(It changes about 0.2dB with each step.)
Lch REC level adjustment.
- Press the DUBB NOR key.
- Press the DISPLAY key.
- Rch REC level adjustment : Same as Lch
- Press the DUBB NOR key.
- Press the DISPLAY key.
- Set the AG to 125kHz, then press the REC key to begin recording. Adjust the AG so that the output becomes -20dBs. Playback the recorded tape and adjust the level volume so that the output becomes -20dBs.

KX-W4080/W6080

ADJUSTMENT

(It changes about 0.4dB~0.5dB with each step.)

Lch REC bias adjustment.

9. Press the DUBB NOR key.

10. Press the DISPLAY key.


11. Deck B Rch bias adjustment


12. Press the DUBB NOR key.


NOTE :

- The PAUSE key cancels the Adjustment mode, so do press it during adjustment.
- When adjusting manually, the DUBB NOR key and DUBB HIGH key respectively become the MODE WRITE and ALL WRITE keys, so you need not press the DUBB NOR key for each adjustment mode and can just press the DUBB HIGH key when all the adjustments have been completed.
- When manual adjustment is turned on, all the adjustment data is initialized, so whether or not you make an adjustment, at the end, after writing data, you should cancel using the DUBB HIGH key or another key.

PC BOARD(Component side view)








KX-W4080

KENWOOD

Y26-4100-10

KX-W4080 / 4080 (K) (1/2)



AF

AG

AH

AI

AJ

AK

AL

AM

AN



AO

X28 - 278x - xx

MODEL NAME	DESTINATION		UNIT NO.	S10, 12, 14, 15 17, 19, 21 D46, 50, 51 53, 66 W215	S11, 13 16, 20 D52 W216	D78	C166 WH8
	COUNTRY	ABB.		YES	NO		
KX-W6080	USA	K, P	0-10				
	EUROPE	X, T, E	2-71				
	GENERAL MARKET	Y, M	0-21				
KX-W4080	USA	K, P	0-11				
	EUROPE	X, T, E	2-72				
	GENERAL MARKET	Y, M	0-22				

ED1 : FIP6AMW6
 D39~66, 80, 81 : 1SS133 or HSS104
 *D78
 D79 : 1SS199

A DECK
 X28 - (D/8)




GND LINE
 +B LINE
 -B LINE

KX-W6080/4080 (K) (2/2)




2SA1534A
 2SA992
 2SC1845
 2SC2003
 2SC3246




UN4212
 2SA1309A
 2SC3311A



NJM4558D



TA8125S




UPC1297CA

DTA124ES
 DTC124ES
 UN4112
 2SA1048
 2SC2458

UN4212
 2SA1309A
 2SC3311A



BA10393
 XL24C01AP



HA12167FB

CAUTION: For continued safety, replace components only with manufacturer's recommended parts (refer to parts list). Δ indicates safety critical component. For continued protection against risk of electric shock, leakage-current or resistance shall be carried out (exposed parts are to be disconnected from the supply circuit) before the application by the customer.


The DC voltage is an actual reading measured across the component terminals. Impedance type voltmeter with a capacitance probe is used. The measurement depends on the measuring instrument and the product. Bias circuit DC voltage is measured in record mode.

DOLBY and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation. Noise reduction circuitry is made under license from Dolby Laboratories Licensing Corporation.


Y26-4100-10

KX-W4080/V
KENWOOD

EXPLODED VIEW (MECHANISM)



EXPLODED VIEW (UNIT)



Parts with the exploded numbers larger than 700 are not supplied.

* New Parts
Parts without Parts No. are not supplied.
Les articles non mentionnés dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

1 KX-W4080/W6080

Ref. No.	Add.- ress	Parts No.	Description	Desti- nation	Re- marks
601	1D	* A01-3275-11	METALLIC CABINET	KP YM/XTE	
605	2D	* A53-1905-02	CASSETTE LID	KP YM/XTE	
605	2D	* A53-1915-02	CASSETTE LID	KP YM/XTE	
606	2D	* A53-1919-02	CASSETTE LID	KP YM/XTE	
608	2D	A53-1848-13	CASSETTE HOLDER ASSY (A)	KPY MXTE	
608	2E	A53-0812-11	CASSETTE HOLDER ASSY (B)	KPY MXTE	
610	2E	* A60-0812-11	PANEL PANEL	KPY MXTE	
611	2E	* A60-0842-11	PANEL	KPY MXTE	
611	2E	* A60-0843-11	PANEL	KPY MXTE	
615	2D	* B10-2174-03	FRONT GLASS	KY XT	
615	2D	* B10-2175-03	FRONT GLASS	KY XT	
616	2E	* B11-0297-04	COLOR FILTER	KY XT	
618	2E	* B07-2292-13	ESCUCHION	KY XT	
-	-	* B46-0092-43	WARRANTY CARD	KY XT	
-	-	* B46-0096-53	WARRANTY CARD	KY XT	
-	-	* B46-0121-53	WARRANTY CARD	KY XT	
-	-	* B46-0197-00	QUESTIONNAIRE CARD	KY XT	
-	-	* B46-0310-03	WARRANTY CARD	KY XT	
-	-	* B46-0326-03	WARRANTY CARD	KY XT	
-	-	* B58-0515-04	CAUTION CARD (PRESET220-240)	KY XT	
-	-	* B58-0945-03	CAUTION CARD (UL)	KY XT	
-	-	* B58-0961-13	CAUTION CARD (PL)	KY XT	
-	-	* B58-0965-13	CAUTION CARD (PL)	KY XT	
-	-	* B58-0966-13	CAUTION CARD (PL)	KY XT	
-	-	* B58-0967-03	CAUTION CARD (PL)	KY XT	
-	-	* B59-1104-00	SERVICE DIRECTORY	KY XT	
-	-	* B60-2389-00	INSTRUCTION MANUAL(ENGLISH)	KY XT	
-	-	* B60-2389-00	INSTRUCTION MANUAL(CHINESE)	KY XT	
-	-	* B60-2400-00	INSTRUCTION MANUAL(SPANISH)	KY XT	
-	-	* B60-2401-00	INSTRUCTION MANUAL(DUTCH)	KY XT	
-	-	B60-2402-00	INSTRUCTION MANUAL(GERMAN)	KY XT	
-	-	D39-0314-06	INSTRUCTION MANUAL(CHINESE)	KY XT	
-	-	E03-0115-05	AC PLUG ADAPTER	KY XT	
-	-	E34-0505-05	AC POWER CORD	KY XT	
-	-	E32-2787-05	AC POWER CORD	KY XT	
-	-	E30-2788-05	AC POWER CORD	KY XT	
-	-	E30-2788-05	AC POWER CORD	KY XT	
-	-	E30-2790-05	AC POWER CORD	KY XT	
-	-	E30-2791-05	AC POWER CORD	KY XT	
-	-	E30-2816-05	AC POWER CORD	KY XT	
-	-	E33-2855-05	AC POWER CORD	KY XT	
-	-	E33-381-05	FLAT CABLE	KY XT	
-	-	G01-3838-04	TORSION COIL SPRING	KY XT	
-	-	G01-3839-04	TORSION COIL SPRING	KY XT	
-	-	G02-1057-14	FLAT SPRING	KY XT	
-	-	*	POLYSTYRENE FOAMED FIXTURE	KPY/NX/E	
-	-	*	H10-7105-02	KPY/NX/E	
-	-	*	H10-7107-02	KPY/NX/E	
-	-	*	H10-7108-12	KPY/NX/E	
-	-	*	H10-0211-14	KPY/NX/E	
-	-	*	H20-0568-04	KPY/NX/E	
-	-	*	H2-0232-04	KPY/NX/E	
-	-	*	H2-0391-04	KPY/NX/E	
-	-	*	H2-0651-04	KPY/NX/E	
-	-	*	H50-1682-04	KPY/NX/E	
-	-	*	H50-1684-04	KPY/NX/E	
-	-	*	H50-1685-04	KPY/NX/E	
-	-	*	H50-1686-04	KPY/NX/E	
-	-	*	H50-1687-04	KPY/NX/E	
-	-	*	H50-1688-04	KPY/NX/E	
-	-	*	J02-1148-13	KPY/NX/E	
-	-	*	J19-732-04	KPY/NX/E	
-	-	*	J42-0083-05	KPY/NX/E	
-	-	*	J61-0098-05	KPY/NX/E	
-	-	*	K27-2175-04	KPY/NX/E	
-	-	*	K29-5828-04	KPY/NX/E	
-	-	*	K29-6253-03	KPY/NX/E	
-	-	*	K29-6255-03	KPY/NX/E	
-	-	*	K29-6260-03	KPY/NX/E	
-	-	*	K29-6262-03	KPY/NX/E	
-	-	*	K29-6265-04	KPY/NX/E	
-	-	*	K29-6266-03	KPY/NX/E	
-	-	*	K29-6267-04	KPY/NX/E	
-	-	*	K29-6268-04	KPY/NX/E	
-	-	*	K29-6269-03	KPY/NX/E	
-	-	*	K29-6270-04	KPY/NX/E	
-	-	*	K29-6271-04	KPY/NX/E	
-	-	*	K29-6272-04	KPY/NX/E	
-	-	*	K29-6273-04	KPY/NX/E	
-	-	*	K29-6274-04	KPY/NX/E	
-	-	*	K29-6275-04	KPY/NX/E	
-	-	*	K29-6276-04	KPY/NX/E	
-	-	*	K29-6277-04	KPY/NX/E	
-	-	*	K29-6278-04	KPY/NX/E	
-	-	*	K29-6279-04	KPY/NX/E	
-	-	*	K29-6280-04	KPY/NX/E	
-	-	*	K29-6281-05	KPY/NX/E	
-	-	*	K29-6282-05	KPY/NX/E	
-	-	*	K29-6283-05	KPY/NX/E	
-	-	*	K29-6284-05	KPY/NX/E	
-	-	*	K29-6285-05	KPY/NX/E	
-	-	*	K29-6286-05	KPY/NX/E	
-	-	*	K29-6287-05	KPY/NX/E	
-	-	*	K29-6288-05	KPY/NX/E	
-	-	*	K29-6289-05	KPY/NX/E	
-	-	*	K29-6290-05	KPY/NX/E	
-	-	*	K29-6291-05	KPY/NX/E	
-	-	*	K29-6292-05	KPY/NX/E	
-	-	*	K29-6293-05	KPY/NX/E	
-	-	*	K29-6294-05	KPY/NX/E	
-	-	*	K29-6295-05	KPY/NX/E	
-	-	*	K29-6296-05	KPY/NX/E	
-	-	*	K29-6297-05	KPY/NX/E	
-	-	*	K29-6298-05	KPY/NX/E	
-	-	*	K29-6299-05	KPY/NX/E	
-	-	*	K29-6300-05	KPY/NX/E	
-	-	*	K29-6301-05	KPY/NX/E	
-	-	*	K29-6302-05		

PARTS LIST

* New Parts
Parts without Parts No. are not supplied.
Parts non mentionnés dans le Parts No. ne sont pas fournis.

* New Parts
Parts without Parts No. are not supplied.
Parts non mentionnés dans le Parts No. ne sont pas fournis.

Ref. No	Add- ress	New Parts	Parts No.	Description	Desti- nation	Re- marks
Q58			2SC2458(Y GR)	TRANSISTOR		
Q58			2SC3311(A,Q,R)	TRANSISTOR		
Q59	60		2SC3246	TRANSISTOR		
Q61	62		2SA1048(Y GR)	TRANSISTOR		
Q61	62		2SA1309(A,Q,R)	TRANSISTOR		
Q63	64		2SC3246	DIGITAL TRANSISTOR		
Q65	68		DTC124ES	TRANSISTOR		
Q65	68		UN4212	TRANSISTOR		

MECHANISM ASSY

(D40-1451-05 : W4080 , 0-05 : W6080 : A , D40-1473-05 : B)

Ref. No	Add- ress	New Parts	Parts No.	Description	Desti- nation	Re- marks
401	2A	A10-3178-08	HEAD CHASSIS			
403	1C,2C	B30-2409-08	LED SEL2415E			
405	2C	D01-0175-08	FLYWHEEL (R) ASSY			
406	1B	D01-0175-08	FLYWHEEL (L) ASSY			
409	1C	*	D10-3470-08	SHIFT LEVER		
410	2C	*	D10-3471-18	HEAD CHANGE ARM		
411	1C	*	D13-1622-18	CAM GEAR		
412	1A	D10-3506-08	EJECT LEVER (L) (B MECHA)			
413	2C	D10-3501-08	EJECT LEVER (R) (A MECHA)			
414	2A	D10-3478-08	SELECT LEVER			
415	1B	D10-3479-08	CHASSIS ASSY			
416	2A	D10-3480-08	CIR LEVER			
417	1A	D10-3502-08	ARM (LEFT) INTER LOCK			
418	2B	D10-3503-08	ARM (RIGHT) INTER LOCK			
420	2A	D13-0981-08	ROTATION GEAR			
421	1A	D13-1616-08	REEL GEAR			
422	1A,2B	D13-1617-08	REEL GEAR			
423	1B	D13-1618-08	IDLER GEAR			
424	2A	D13-1621-08	RETURN GEAR			
425	1C	D10-3470-08	TRIGGER ARM			
426	2B	D14-0367-08	PINCH ARM (R) ASSY			
427	2A	D14-0368-08	PINCH ARM (L) ASSY			
430	1B	D15-0365-08	IDLER PULLEY			
431	2C	D16-0375-08	DRIVE BELT			
432	1A,2A	D16-0376-08	CLUTCH BELT			
433	1A,2A	*	D19-0287-18	REFL CAP (A)		
434	1B	*	D19-0287-18	CLUTCH ARM ASSY		
439	1C	E35-0934-08	1SP FLAT RIBBON WIRE (A MECHA)			
440	1C	E35-0056-08	1SP HEAD WIRE ASSY			
441	2A	E35-006-08	1SP HEAD WIRE ASSY			
441	2A	*	E35-1189-08	BP HEAD WIRE ASSY		
442	1C	E35-0986-08	MOTOR WIRE			
443	1A	*	G01-3705-08	SPRING (L) (B MECHA)		
444	2B	G01-3707-18	BT SPRING (R) (A MECHA)			
445	1A,2B	G01-3708-08	SHIFT LEVER SP			
446	1C	G01-3710-08	TRIGGER ARM SP			
447	1C	G01-3711-08	HEAD CHANGE ARM SP			
448	2C	G01-3712-08	EJECT SP			
450	1A,2C	G01-3714-08	CIR LEVER SP			
451	2A	G01-3715-08	SELECT SP			
452	2A	G01-3716-08	SHIFT SP			

L : Scandinavia K : USA P : Canada
Y : PX(Far East, Hawaii) T : Europe E : Europe
Y : AA/FES(Europe) X : Australia M : Other Areas

4 : W4080 5 : W6080 6 : W6080
Δ indicates safety/critical components.

3 = Temp. coefficient

4 = Voltage rating

5 = Value

6 = Tolerance

7 = Dimension

8 = Type

9 = Shape

10 = Rating wattage

11 = Dimension

12 = Value

13 = Tolerance

14 = Temp. coefficient

15 = Rating wattage

16 = Dimension

17 = Value

18 = Tolerance

19 = Type

20 = Shape

21 = Rating wattage

22 = Dimension

23 = Value

24 = Tolerance

25 = Type

26 = Shape

27 = Rating wattage

28 = Dimension

29 = Value

30 = Tolerance

31 = Type

32 = Shape

33 = Rating wattage

34 = Dimension

35 = Value

36 = Tolerance

37 = Type

38 = Shape

39 = Rating wattage

40 = Dimension

41 = Value

42 = Tolerance

43 = Type

44 = Shape

45 = Rating wattage

46 = Dimension

47 = Value

48 = Tolerance

49 = Type

50 = Shape

51 = Rating wattage

52 = Dimension

53 = Value

54 = Tolerance

55 = Type

56 = Shape

57 = Rating wattage

58 = Dimension

59 = Value

60 = Tolerance

61 = Type

62 = Shape

63 = Rating wattage

64 = Dimension

65 = Value

66 = Tolerance

67 = Type

68 = Shape

69 = Rating wattage

70 = Dimension

71 = Value

72 = Tolerance

73 = Type

74 = Shape

75 = Rating wattage

76 = Dimension

77 = Value

78 = Tolerance

79 = Type

80 = Shape

81 = Rating wattage

82 = Dimension

83 = Value

84 = Tolerance

85 = Type

86 = Shape

87 = Rating wattage

88 = Dimension

89 = Value

90 = Tolerance

91 = Type

92 = Shape

93 = Rating wattage

94 = Dimension

95 = Value

96 = Tolerance

97 = Type

98 = Shape

99 = Rating wattage

100 = Dimension

101 = Value

102 = Tolerance

103 = Type

KX-W4080/W6080

SPECIFICATIONS

[MODEL: KX-W6080]

Track System	4 track, 2 channel stereo
Recording System	AC bias (Frequency: 105 kHz)
Heads	A DECK
	Playback/recording heads ..1
	Erasing head1
B DECK	
	Playback/recording heads ..1
	Erasing head1
Motors.....	A DECKDC motor x 1
	B DECKDC motor x 1
Wow and Flutter	±0.17 % (IEC) ±0.28 % (DIN) 0.1 % (W.R.M.S)
Fast Winding Time	Approx. 110 seconds (C-60 tape)
Frequency Response	
TYPE I tape	30 Hz to 18,000 Hz, ±3 dB
TYPE II tape	30 Hz to 19,000 Hz, ±3 dB
Signal to Noise Ratio	
Dolby NR OFF	56 dB (IEC, 250 nWb/m, TYPE II tape)
Dolby NR OFF.....	59 dB
Dolby B NR ON	68 dB
Dolby C NR ON	75 dB (3rd, H.D., 3 %, TYPE II tape)
Harmonic Distortion.....	Less than 1.2 % (at 315 Hz, 3rd H.D., 250 nWb/m, TYPE II tape)
Input sensitivity/Impedance	
LINE IN	122.8 mV/47 kΩ
Output Level/Impedance	
LINE OUT	775 mV/1.0 kΩ
Headphones	0.5 mW/32 Ω

[General]

Power Consumption	30W
Dimensions.....	W : 440 mm (17-5/16") H : 134 mm (5-1/4") D : 367 mm (14-7/16")
Weight (Net)	4.6 kg (10.1 lb)

KENWOOD follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.

KENWOOD CORPORATION

14-6,Dogenzaka 1-chome, Shibuya-ku, Tokyo, 150 Japan

KENWOOD SERVICE CORPORATION

P.O BOX 22745, 2201 East Dominguez St., Long Beach, CA 90801-5745, U.S.A.

KENWOOD ELECTRONICS CANADA INC.

6070 Kestrel Road, Mississauga, Ontario, Canada L5T 1S8

KENWOOD ELECTRONICS LATIN AMERICA S.A.

P.O BOX 55-2791, Piso 6 plaza Chase, Cl. 47 y Aquino de la Guardia Panama, Republic de Panama

TRIO-KENWOOD U.K. LIMITED

KENWOOD House, Dwight Road, Watford, Herts., WD1 8EB., United Kingdom

KENWOOD ELECTRONICS BENELUX N.V.

Meachelsteenweg 418, B-1930 Zaventem, Belgium

KENWOOD ELECTRONICS DEUTSCHLAND GMBH

Rembrucker Str. 15, 63150 Heusenstamm, Germany

[MODEL: KX-W4080]

Track System	4 track, 2 channel stereo
Recording System	AC bias (Frequency: 105 kHz)
Heads	A DECK
	Playback head
B DECK	
	Playback/recording heads ..1
	Erasing head1
Motors	A DECKDC motor x 1
	B DECKDC motor x 1
Wow and Flutter	±0.17 % (IEC) ±0.28 % (DIN) 0.1 % (W.R.M.S)
Fast Winding Time	Approx. 110 seconds (C-60 tape)
Frequency Response	
TYPE I tape	30 Hz to 18,000 Hz, ±3 dB
TYPE II tape	30 Hz to 19,000 Hz, ±3 dB
Signal to Noise Ratio	
Dolby NR OFF	56 dB (IEC, 250 nWb/m, TYPE II tape)
Dolby NR OFF	59 dB
Dolby B NR ON	68 dB
Dolby C NR ON	75 dB (3rd, H.D., 3 %, TYPE II tape)
Harmonic Distortion	Less than 1.2 % (at 315 Hz, 3rd H.D., 250 nWb/m, TYPE II tape)
Input sensitivity/Impedance	
LINE IN	122.8 mV/47 kΩ
Output Level/Impedance	
LINE OUT	775 mV/1.0 kΩ
Headphones	0.5 mW/32 Ω

[General]

Power Consumption	30 W
Dimensions.....	W : 440 mm (17-5/16") H : 134 mm (5-1/4") D : 367 mm (14-7/16")
Weight (Net)	4.6 kg (10.1 lb)

Note:

Component and circuitry are subject to modification to insure best operation under differing local conditions. This manual is based on the U.S.A.(K) standard, and provides information on regional circuit modification through use of alternate schematic diagrams, and information on regional component variations through use of parts list.

TRIO-KENWOOD FRANCE S.A.

13 Boulevard Ney, 75018 Paris, France

KENWOOD ELECTRONICS ITALIA S.p.A.

Via G. Sirtori, 79 20129, Milano, Italy

KENWOOD IBÉRICA S.A.

Bolivia, 239-08020 Barcelona, Spain

KENWOOD ELECTRONICS AUSTRALIA PTY. LTD. (A.C.N. 001499 074)

P.O Box 504, 8 Figtree Drive, Australia Centre, Homebush, N.S.W. 2140, Australia

KENWOOD & LEE ELECTRONICS, LTD.

Unit 3712-3724, Level 37, Tower 1, Metropiazza, 223 Hing Fong Road, Kwai Fong N.T., Hong Kong

KENWOOD ELECTRONICS SINGAPORE PTE LTD.

No. 1 Genting Lane # 07-00, KENWOOD Building, Singapore, 349544

KENWOOD ELECTRONICS (MALAYSIA) SDN BHD

10th Floor, Block B, Wisma Semantan, No. 12 Janjan Gelenggang, Bukit Damansara, 50490
Kuala Lumpur, Malaysia