

DENON


Hi-Fi Personal Component System

For Europe Model

SERVICE MANUAL

MODEL UDRA-F07

AM-FM STEREO RECEIVER









— CONTENTS —

OPERATING INSTRUCTIONS	2-9
DISASSEMBLY	10
ADJUSTMENT	11, 12
SEMICONDUCTORS	12-19
PRINTED WIRING BOARD	20-23
NOTE FOR PARTS LIST	24
PRINTED WIRING BOARD PARTS LIST	24, 25
EXPLODED VIEW OF CHASSIS	26
PARTS LIST OF EXPLODED VIEW	27
BLOCK AND LEVEL DIAGRAM	28
BLOCK DIAGRAM	29, 30
WIRING DIAGRAM	31, 32
SCHEMATIC DIAGRAM	33, 34

• Some illustrations using in this service manual are slightly different from the actual set.

NIPPON COLUMBIA CO., LTD.

NOTE ON USE / HINWEISE ZUM GEBRAUCH / OBSERVATIONS RELATIVES A L'UTILISATION
NOTE SULL'USO

 <ul style="list-style-type: none"> ● Avoid high temperatures. Allow for sufficient heat dispersion when installed on a rack. ● Vermeiden Sie hohe Temperaturen. Beachten Sie, daß eine ausreichende Luftzirkulation gewährleistet wird, wenn das Gerät auf ein Regal gestellt wird. ● Éviter des températures élevées. Tenir compte d'une dispersion de chaleur suffisante lors de l'installation sur une étagère. ● Evitare di esporre l'unità a temperature alte. Assicurarsi che ci sia un'adeguata dispersione del calore quando installate l'unità in un mobile per componenti audio. 	 <ul style="list-style-type: none"> ● Keep the set free from moisture, water and dust. ● Halten Sie das Gerät von Feuchtigkeit, Wasser und Staub fern. ● Protéger l'appareil contre l'humidité, l'eau et la poussière. ● Tenere l'unità lontana dall'umidità, dall'acqua e dalla polvere. 	 <ul style="list-style-type: none"> ● Do not let foreign objects in the set. ● Keine fremden Gegenstände in das Gerät kommen lassen. ● Ne pas laisser des objets étrangers dans l'appareil. ● È importante che nessun oggetto è inserito all'interno dell'unità.
 <ul style="list-style-type: none"> ● Handle the power cord carefully. Hold the plug when unplugging the cord. ● Gehen Sie vorsichtig mit dem Netzstecker um. Halten Sie das Kabel am Stecker, wenn Sie den Stecker herausziehen. ● Manipuler le cordon d'alimentation avec précaution. Tenir la prise lors du débranchement du cordon. ● Manipolare il filo di alimentazione con cura. Agitare per la spina quando scollegate il cavo dalla presa. 	 <ul style="list-style-type: none"> ● Unplug the power cord when not using the set for long periods of time. ● Wenn das Gerät eine längere Zeit nicht verwendet werden soll, trennen Sie das Netzstecker vom Netzstecker. ● Débrancher le cordon d'alimentation lorsque l'appareil n'est pas utilisé pendant de longues périodes. ● Disinnestare il filo di alimentazione quando avete l'intenzione di non usare il filo di alimentazione per un lungo periodo di tempo. 	 <ul style="list-style-type: none"> ● Do not let insecticides, benzene, and thinner come in contact with the set. ● Lassen Sie das Gerät nicht mit Insektiziden, Benzin oder Verdünnungsmitteln in Berührung kommen. ● Ne pas mettre en contact des insecticides, du benzène et un diluant avec l'appareil. ● Assicurarsi che l'unità non venga in contatto con insetticidi, benzolo o solventi.

CAUTION / VORSICHT / ATTENTION / AVVISIO

- If the system should smoke or produce strange smells, immediately set the power switch to the STANDBY position, unplug the power cord, and contact your store of purchase.
- Sollte das Gerät Rauch produzieren oder eigenartig riechen, stellen Sie den Netzschalter sofort auf die Position STANDBY (Bereitschaft), ziehen Sie den Netzstecker heraus und kontaktieren Sie Ihren Händler.
- Si de la fumée sort de la chaîne ou des odeurs bizarres, placer l'interrupteur d'alimentation immédiatement sur la position de veille (STANDBY), débrancher le cordon d'alimentation et contacter le distributeur.
- Qualora il sistema dovesse produrre del fumo o degli odori strani, scollegare immediatamente l'interruttore di accensione nella posizione STANDBY, disinnestare il filo di alimentazione e rivolgetevi al negozio dell'acquisto.

"SERIAL NO. _____
PLEASE RECORD UNIT SERIAL NUMBER ATTACHED TO THE REAR OF THE CABINET FOR FUTURE REFERENCE"

SAFETY IMPORTANT

WARNING:
TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

● **DECLARATION OF CONFORMITY**
We declare under our sole responsibility that this product, to which this declaration relates, is in conformity with the following standards:
EN60065, EN55013, EN55020, EN60555-2 and EN60555-3.
Following the provisions of 73/23/EEC, 89/336/EEC and 93/88/EEC Directive.

● **ÜBEREINSTIMMUNGSEKTLÄRUNG**
Wir erklären unter unserer Verantwortung, daß dieses Produkt, auf das sich diese Erklärung bezieht, den folgenden Standards entspricht:
EN60065, EN55013, EN55020, EN60555-2 und EN60555-3.
Entspricht den Verordnungen der Direktive 73/23/EEC, 89/336/EEC und 93/88/EEC.

● **DECLARATION DE CONFORMITE**
Nous déclarons sous notre seule responsabilité que l'appareil, auquel se réfère cette déclaration, est conforme aux standards suivants:
EN60065, EN55013, EN55020, EN60555-2 et EN60555-3.
D'après les dispositions de la Directive 73/23/EEC, 89/336/EEC et 93/88/EEC.

● **DICHIARAZIONE DI CONFORMITÀ**
Dichiaro con piena responsabilità che questo prodotto, al quale la nostra dichiarazione si riferisce, è conforme alle seguenti normative:
EN60065, EN55013, EN55020, EN60555-2 e EN60555-3.
In conformità con le condizioni delle direttive 73/23/EEC, 89/336/EEC e 93/88/EEC.
QUESTO PRODOTTO È CONFORME
AL D.M. 28/08/95 N. 548

CLASS 1 LASER PRODUCT

LUOKAN 1 LASERLAITE

KLASS 1 LASERAPPARAT

ADVARSEL

VAROITUS!

VARNING-

USVNLIG LASERSTRÅLING VED ÅBNING, NÅR SIKKERHEDSFRYDERE ER UDE AF FUNKTION. UNDGÅ UDSEJTELSE FOR STRÅLING.
LÄTTEN KÄVTTÄMINEN MUKILLA KUUN TÄSSÄ KÄYTTÖOHJEESSA MAINITULLA TAVALLA SAATTAA ALSTETA KÄYTTÄJÄN TUUVALLISUUSLUOKAN 1 YLITTÄVÄLLE NÄKYMÄTÖMÄLLE LASERSTRÄLLELLE.
OM APPARATEN ANVÄRDS PÅ ANNET SÄTT ÄR DENNA RIKRSANSVÄRIGT SPECIFIKERAT. VÄN ANVÄNDAREN UTSÄTTS FÖR OSVNLIG LASERSTRÅLING SOM ÖVERSKRIDER GRÄNSEN FÖR LASERKLASS 1.


"CLASS 1 LASER PRODUCT"



FRONT PANEL / FRONTPLATTE / PANNEAU AVANT / PANNELLO ANTERIORE

AM-FM STEREO RECEIVER
AM-FM STEREO-RECEIVER
AMPLI-TUNER AM-FM
RICEVITORE STEREO AM-FM

See ENGLISH Page 6
Sehen Sie DEUTSCH Seite 30
Voir FRANÇAIS Page 54
Fate riferimento alla sezione ITALIANO alla pagina 78





CD PLAYER
CD-SPIELER
LECTEUR CD
DISPLAY DELLA PIASTRA A CASSETTE

See ENGLISH Page 7
Sehen Sie DEUTSCH Seite 31
Voir FRANÇAIS Page 55
Fate riferimento alla sezione ITALIANO alla pagina 79

CASSETTE DECK
CASSETTENDECK
PLATINE CASSETTE
PIASTRA A CASSETTE

See ENGLISH Page 8
Sehen Sie DEUTSCH Seite 32
Voir FRANÇAIS Page 56
Fate riferimento alla sezione ITALIANO alla pagina 80



- As an aid to better understanding the operation method, the illustrations used in this manual may differ from the actual system.
- Als Hilfestellung zum besseren Verständnis der Betriebsmethode, erlauben wir uns den Hinweis, daß sich die Abbildungen in dieser Bedienungsanleitung leicht von dem aktuellen System unterscheiden.
- Pour faciliter la compréhension de la méthode de fonctionnement, les illustrations utilisées dans ce manuel peuvent être différentes de celles de la chaîne réelle.
- Per rendere la spiegazione del metodo operativo più facile, le illustrazioni usate in questo libretto delle istruzioni possono differire dal sistema stesso.

CONTENTS

1 Main Features	4	10 Playing Cassette Tapes	19
2 Before Using	4	11 Recording Cassette Tapes	20
3 Connecting the Included Antennas	4	12 Playing CDs	21 ~ 25
4 Connections	5	• About Compact Discs	21
5 Part Names, Functions and Displays	6 ~ 8	• Normal Playback	21, 22
• Receiver	6	• Various Playback Functions	22 ~ 24
• CD Player	7	• Edited Recording on Sides A and B of a Tape	25
• Cassette Deck	8	13 Auto On Function	26
6 Remote Control Unit	8, 9	14 Other Information	26
7 Listening to Radio Programs	10 ~ 12	15 Specifications	26
8 Using the Timer	13 ~ 16	16 Troubleshooting	27
9 Before Recording and Playing Tapes	17, 18	19 DENON Service Network	196, 199

Check that the following parts are included in the package aside from the main unit:

- UDRA-F07 (AM-FM stereo receiver)
 - Remote control unit (RC-S1B)..... 1
 - R67/AA batteries..... 2
 - Operating instructions..... 1
 - FM antenna..... 1
 - AM loop antenna..... 1
- UCD-F07 (compact disc player)
 - System connector cable..... 1
 - RCA pin-plug cord..... 1
- UDR-F07 (cassette tape deck)
 - System connector cable..... 1
 - RCA pin-plug cord..... 2

1 MAIN FEATURES

- RDS compatible
Compatible with various RDS services, including program service name (PS), program type identification (PTY), traffic program identification (TP), clock time (CT), radio text message (RT) and enhanced other network (EON).
- Quality power for high quality sound
40W + 40W (4 Ω/ohms, DIN) high quality amplifier and terminals for large speakers.
- High sound quality, multi-function CD player
Edit function for automatically dividing the tracks on a CD for recording onto sides A and B of a tape.

- Cassette deck with Dolby B, C and HX-Pro circuits
For playback and recording of high quality sound.
- Two timer settings.
Two timer settings can be made — everyday and sleep.
- Easy-to-use remote control unit
Auto on function
The power turns on automatically and playback begins when the play button on the CD player or the cassette deck or the tuner preset up/down buttons on the remote control unit are pressed.

2 BEFORE USING


Read the following before using the system.

- Before turning on the power
Check again that all connections are correct and that there are no problems with the connection cords. Be sure to unplug the power cord before connecting or disconnecting the connection cords.
- Humming may be produced if this system is set near a TV or other audio equipment. If this happens, try changing the position of the equipment or the connection cords.
- Moving the system
Be sure to remove CDs before moving the system. If a CD is left in the CD player, it may be scratched. To prevent short-circuits or damage to the connection cords, always unplug the power cord and disconnect all connection cords to other audio equipment.

- Condensation (dew)
Condensation (water droplets) may be produced on internal optical lenses or discs in the following cases:
 - Directly after a heater is turned on.
 - When the system is in a steamy or humid room.
 - When the system is moved abruptly from a cold place (room) to a warm room.
- Should condensation occur:
The signals on the disc cannot be read and the system will not function properly. Remove the disc then let the system set with the power on. The condensation will evaporate in one hour or less, at which time the system will function normally.
- Note that some of the illustrations used for explanations in this manual may differ from the actual system.

4 CONNECTIONS

NOTE:
This system includes digital circuitry which may cause interference such as color blotching or changes in the color on TV. If this happens, move the system and the TV as far apart as possible.




System operations
Such system operations as the timer and the auto on functions, as well as remote control operations cannot be performed unless all the RCA pin-plug cords and system connector cords are connected between the units, so be sure to make all the connections properly as shown in the diagram. Also, disconnecting system connectors while the system is operating may result in malfunction. Be sure to unplug the power cord before changing connections.

3 CONNECTING THE INCLUDED ANTENNAS

Installing the FM indoor antenna

Tune in an FM station (see Page 10), set the antenna in a position in which distortion and noise is minimum, then fasten the tip of the antenna in this position using tape or a pin.




Installing the AM loop antenna

Tune in an AM station (see Page 10) and set the antenna in a position as far from the system as possible in which distortion and noise is minimum. In some cases it is best to invert the polarities. AM broadcasts cannot be received well if the loop antenna is not connected or if it is set close to metal objects.

Assembling the AM loop antenna


Assemble the included AM loop antenna as shown in the diagram.
1 Remove the clamp.
2 Insert the AM loop antenna into the antenna stand.



Connecting the AM loop antenna

Connect the included AM loop antenna to the antenna terminals as shown in the diagram.

- 1 Loosen the terminal knob
- 2 Insert the antenna wire
- 3 Tighten the terminal knob



Connecting an FM outdoor antenna


If good reception cannot be achieved with the included FM antenna, use an FM outdoor antenna. Connect an F-shaped connector to the coaxial cable and connect the antenna to the FM COAX (75 Ω) terminal.

Selecting a place for the FM outdoor antenna

- Set the antenna so that it is pointing towards the broadcast station's transmitting antenna. Behind buildings or mountains, set the antenna in the position at which reception is best, and also try changing the direction of the antenna.
- Do not install the antenna under power lines.
Doing so is extremely dangerous, as the power-line could touch the antenna.
- Install the antenna away from roads or train tracks to avoid noise from cars or trains.
- Do not install the antenna too high, as it may be hit by lightning.

Installing an AM outdoor antenna

Connect the signal wire from the AM outdoor antenna to the antenna terminal. Be sure to ground the antenna and connect the ground wire to the GND terminal. Also be sure to connect the included AM loop antenna.




Connecting the speaker systems

Connect the speaker system for the left channel (the left side as seen from the front) to the "L" terminals, the speaker system for the right channel to the "R" terminals. Be sure to use speaker systems with an impedance of 4 Ω/ohms or greater.

CAUTION:
Whenever the power switch is in the STANDBY position, the unit is still connected on AC line voltage. Please be sure to unplug the cord when you leave home for, say, a vacation.

PRECAUTIONS FOR INSTALLATION
For heat dispersal, leave at least 10 cm of space between the top, back and sides of this unit and the wall or other components.



- NOTES:**
- Do not plug the power cord into the power outlet until all connections are completed. Be sure to interconnect the channels (L to L, white and R to R) properly, as shown on the diagram.
 - Insert the plugs securely. Incomplete connections may result in noise.
 - Be sure to connect the speaker cords between the speaker terminals and the speaker systems with the same polarities (+ to +, - to -). If the polarities are switched, the sound at the center will be weak, the position of the different instruments will be unclear, and the stereo effect will be lost.
 - After unplugging the power cord, wait about 5 seconds before plugging it back in.
 - Note that setting the connection cords (pin-plug cords) next to the power cords may result in humming or other noise.


5 PART NAMES, FUNCTIONS AND DISPLAYS

RECEIVER

- 1 **REMOTE SENSOR**
When operating the remote control unit, point it at this sensor.
- 2 **RT Indicator**
This lights in green when a radio station offering an RT service is tuned in. The indicator lights in red when the RT mode is selected. When the RT message is displayed, the indicator flashes in green.
- 3 **EON TA Indicator**
This lights in green when an EON station with traffic announcements is being received. When the EON TA mode is selected, the indicator lights in red. The indicator flashes in green when another broadcast station in the same network is automatically tuned in and a traffic announcement is being received.
- 4 **EON PTY indicator**
This lights in green when an EON station with PTY information is being received. When the EON PTY mode is selected, the indicator lights in red. The indicator flashes in green when another broadcast station in the same network is automatically tuned in and a broadcast of the desired program type is being received.
- 5 **TUNING UP and DOWN buttons**
These buttons are used to select AM and FM stations and to set the clock and timer.
- 6 **BAND (AM / FM) selector button**
The band switches between AM and FM each time this button is pressed.
- 7 **MONO / STEREO selector button**
AUTO mode:
Use this mode to receive programs in stereo. The sound and the indicators on the display automatically switch between monaural ("MONO") and stereo ("STEREO") according to whether the program is being broadcast in monaural or stereo.
MONO mode:
Use this mode to receive programs in monaural, regardless of whether they are being broadcast in monaural or stereo. Set this mode if there is much noise or if the signals are weak when receiving stereo programs (when "AUTO" is lit).

- 8 **VOLUME control**
Use this to adjust the overall volume. The volume increases when the control is turned clockwise (↻) and decreases when it is turned counter-clockwise (↺).
- 9 **SYSTEM POWER switch**
This turns the power for the entire system on and off. Press this once to turn the power on, then press again to set the power to the standby mode.
- 10 **PHONES (headphones jack)**
Plug the headphones into this jack. No sound is produced from the speakers when headphones are plugged in.
- 11 **Display**
- 12 **TIMER / TIMER STANDBY button**
Press this when setting the timer and to turn the timer on so that it operates at the set times. When the button is pressed after the timer has been set, the timer standby mark ("⏸") appears on the display. The timer will not operate when the "⏸" mark is off.
- 13 **CLOCK / DISPLAY selector button**
This button is used to switch the display between the reception frequency (function) and the clock.
- 14 **MEMO ENT / NEXT button**
This button is used to preset AM and FM stations and when setting the timer.
- 15 **FUNCTION (input) selector button**
Use this to select the input function. The input changes in the following order each time this button is pressed: CD, TAPE, TUNER, PHONO, MD and AUX. (The function changes automatically when the system's CD player or cassette deck is played or when a preset channel is recalled on the tuner.)
- 16 **BALANCE control**
Use this to adjust the balance of the volume between the left and right channels. When set at the center position, the volume is the same for the left and right channels.
- 17 **BASS control**
Use this to adjust the volume of the low frequencies.
- 18 **TREBLE control**
Use this to adjust the volume of the high frequencies.

RECEIVER DISPLAY



6

6 REMOTE CONTROL UNIT

The UDRA-F07 comes with a system remote control unit (RC-818).


Inserting the batteries

- NOTES:**
- Use R6P (AA) batteries in this remote control unit.
 - Replace the batteries with new ones approximately once each year, though this depends on how frequently the remote control unit is used.
 - Replace the batteries with new ones earlier if the remote control unit does not operate even from a short distance.
 - Insert the batteries in the proper + and - direction, following the marks in the battery compartment.
 - Remove the batteries when not using the remote control unit for extended periods of time.
 - To avoid damage and leakage:
 - Do not use a new battery with an old one.
 - Do not use two different types of batteries.
 - Do not short-circuit, take apart, heat or dispose of batteries in flames.
 - If the batteries should leak, carefully wipe the fluid out of the battery compartment, then insert new batteries.

- 1 Open the battery compartment cover on the back of the remote control unit. Press the knob and open the cover in the direction of the arrow.
- 2 Insert the two R6P (AA) batteries, following the + and - marks in the battery compartment.
- 3 Close the cover of the battery compartment.

Using the Remote Control Unit

- Cautions on Use**
- The remote control unit may not operate if the remote sensor is exposed to direct sunlight or the strong light from a lighting fixture, or if there is an obstacle between the remote control unit and the remote sensor.
 - Do not press buttons on the remote control unit and on the set at the same time. Doing so could result in malfunction.
 - If the remote control unit is pointed away from the remote sensor during continuous operations (such as when turning the volume up or down), the operation will stop. If this happens, point the remote control unit at the remote sensor and press the button again.



8

Remote Control Unit Part Names and Functions

Cassette deck operation buttons

- STOP button**: Press this button to stop the tape.
- ▶ (forward play) button**: Press this to start playback or recording in the forward direction.
- ◀ (reverse play) button**: Press this to start playback or recording in the reverse direction.

POWER switch

Use this switch to turn on the power of the entire system or set the power to the standby mode.

Number buttons

Press these buttons after pressing the TUNER button to recall preset stations. When playing a CD, press these buttons after pressing the DIRECT or PROGRAM button to specify the desired track.

PRESET buttons

Use these buttons to recall preset stations on the tuner.

BAND (AM / FM) selector button

TUNING buttons

MEMO button

SLEEP button

Press this button to set the sleep timer.

CD operation buttons

- STOP button**: Press this button to stop playback.
- ▶ (play) button**: Press this button to start playback.
- ◀ and ▶ (automatic search) buttons**: Use these buttons to search for the beginning of the desired track.

FUNCTION selector button

Press this button to switch the input (function). The input changes in the following order each time this button is pressed: CD, TAPE, TUNER, PHONO, MD/AUX.

TUNER button

Press this button to recall preset stations from the remote control unit using the number buttons.

VOLUME buttons

Use these to adjust the volume. The volume increases when the ▲ button is pressed and decreases when the ▼ button is pressed.

Cassette deck operation buttons

- REC / REC MUTE button**: To start recording from the stop mode, press this button, then press ▶.

When this button is pressed during the recording, a blank section of approximately 5 seconds is created, after which the recording standby mode is set.

- ◀ (rewind) button**: Press this button to rewind the tape. Press this button during playback to set the music search mode (to find the beginning of selections).
- ▶▶ (fast-forward) button**: Press this button to fast-forward the tape. Press this button during playback to set the music search mode (to find the beginning of selections).

RESET button

Press this button to reset the tape counter to "0000".

CD player operation buttons

- DIRECT button**: Press this button for direct search on the CD player.
- ◀ and ▶ (manual search) buttons**: Press these buttons during playback to move quickly forward or backward.
- REPEAT button**: Press this button for repeat playback.
- RANDOM button**: Press this button to play the tracks in random order.
- PROGRAM button**: Press this button for programmed playback on the CD player.
- CANCEL button**: Press this button to clear the last track from the program.
- EDIT button**: Press this button for edited recording on a tape, dividing the tracks onto sides A and B according to the length of the tape.
- TIME / SIDE A/B button**: Press this button during the play or pause mode to switch the time display. Normally the elapsed time for the track currently playing is displayed. When this button is pressed, the display switches to the remaining time for that track, the total remaining time on the disc, then back to the elapsed time per track. During programmed playback, the total remaining time display indicates the total remaining time of the programmed tracks.
- SIDE A/B**: Press this button during the editing operation to switch the display between sides A and B of the tape. The TIME / SIDE A/B button functions as the SIDE A/B button when it is pressed after the EDIT button is pressed and the tracks have been divided between sides A and B and before the play or pause button is pressed before the recording mode is set. The TIME / SIDE A/B button functions as the TIME button when it is pressed during the play, pause, or edited recording modes.

RDS button

Use this button to automatically tune to stations using the radio data system.

PTY button

Press this button after selecting "PTY" with the RDS button to select one of the 15 program types.

CT button

Use this to correct the time of the clock on the UDRA-F07. Press this button when the time service of an RDS station is being properly received.

CT and TIME

"CT" and "TIME" are displayed for 2 seconds and the UDRA-F07's clock is corrected. "NO CT" is displayed if the RDS station does not offer a time service and when the broadcast is not being received properly.

PANEL button

This button is used to select the panel mode. Press this button when receiving RDS stations to select the frequency, PS, PTY or RT display. The display mode changes as follows each time the button pressed.

EON button

Press this button to turn EON mode on and off. The mode changes as follows each time the button pressed.

Flowcharts:

- RDS: OFF → RDS → PTY → TP
- Panel: PS → PTY → Frequency → RT
- EON: OFF → EON TA → EON PTY → EON TA

Note that this button will not function if the reception is poor.

7 LISTENING TO RADIO PROGRAMS

(Check the connections on Pages 4 and 5.)

TUNING

Receiver (UDRA-F07)

Example: Tuning in FM 87.50 MHz
(AM stations are tuned in using the same procedure.)

1	Set the VOLUME control on the receiver to the minimum position, then press the SYSTEM POWER switch to turn on the power.	SYSTEM POWER		
2	Press the BAND button on the receiver to select the FM band.	BAND		
3	Use the TUNING UP and DOWN buttons to tune the frequency to 87.50. Once the frequency is tuned in, adjust the volume to the desired level using the VOLUME control.	DOWN TUNING UP		

Auto Tuning

- When one of the TUNING buttons is pressed, the frequency changes in steps of 50kHz in the FM band, 9kHz in the AM band.
- If one of the TUNING buttons is held in for over 1 second, the frequency continues to change when the button is released (auto tuning) and stops when a station is tuned in. Tuning will not stop at stations whose reception is poor.
- To stop the auto tuning function, press the UP or DOWN button once.

Auto Preset Memory Function

(FM ONLY)

This function automatically stores the FM stations which can be received in the area in which the set is being used in the preset memory. Use this function so that the RDS functions can be used more effectively. Also note that the channel memories can be changed at will even after the preset stations have been stored with this function.

1	Connect the FM antenna and set it so that FM stations can be received.	Refer to page 4
2	Press the POWER button to turn on the power while holding in the MEMO ENT/NEXT button.	
3	Searching begins automatically, and stations are stored in the preset memory in order, beginning from channel 1 (the operation automatically stops once 40 stations have been set in the memory).	

NOTES:

- In addition to the reception frequency, the reception mode (monaural or auto) is also preset, so check the display when presetting stations.
- If a station is preset at a number where a station is already preset, the previous station is replaced with the new station.
- The preset memory is not cleared immediately when the power cord is unplugged, but is cleared if the cord is left unplugged for an extended period of time. If this happens, preset the stations again.

Listening to Preset Stations

The preset stations can be recalled using the number buttons on the remote control unit. Also, if the following operation is performed when the system power is off, the power automatically turns on and the radio is played. (Auto on function)

Example: Listening to the station preset at number 3
(This operation is only possible from the remote control unit.)

1	Press the TUNER button on the remote control unit.	
2	Press button "3" on the remote control unit.	

Presetting AM and FM Stations

Example: Presetting FM 87.50 (currently tuned in) at preset number 3

4	Press the MEMO ENT/NEXT button. The MEMO indicator flashes for 10 seconds.	MEMO ENT/NEXT		
5	Use the UP and DOWN buttons to call out the number at which you want to preset the station (3), or simply press the corresponding number button "3" on the remote control unit.	DOWN TUNING UP		
6	Press the MEMO ENT/NEXT button while the MEMO indicator is flashing.	MEMO ENT/NEXT		

Up to 30 AM or FM stations can be preset using this procedure.

Using the RDS functions

Receiving RDS broadcasts (FM only)

1	Press the BAND button and set the FM band.		FM 87.50
2	Press the RDS button once.		(-RDS-) Flashes "RDS" blinks
3	Press the AUTO TUNING UP (▲) or DOWN (▼) button.		FM 87.50 Flashes "RDS" displayed
4	The station is tuned in.		"RDS" lights after 5 seconds of flashing. Once the station is tuned in, "RDS" flashes for 5 seconds and the program service name is displayed.

NOTE: If no RDS station is found, "NO PROG" is displayed.

PTY Search

1	Press the RDS button twice.		(-PTY-) Flashes ("PTY" and "RDS" flash, and "-PTY-" is displayed.)
2	Press the PTY button to select the type of program. (One of the 15 types listed below can be selected.)		NEWS Flashes
3	Press the AUTO TUNING UP (▲) or DOWN (▼) button.		FM 87.50 Flashes
4	The station is tuned in.		"PTY" and "RDS" light after 5 seconds of flashing. Once the station is tuned in, "RDS" and "PTY" flash for 5 seconds and the program service name is displayed.

NOTE: If no program of the specified type is found, "NO PROG" is displayed.

Programs

NEWS (News)	VARIED (Varied)
AFFAIRS (Current Affairs)	POP M (Pop Music)
INFO (Information)	ROCK M (Rock Music)
SPORT (Sport)	MOR M (M.O.R. Music)
EDUCATE (Education)	LIGHT M (Light Classics)
DRAMA (Drama)	CLASSICS (Serious Classics)
CULTURE (Culture)	OTHER M (Other Music)
SCIENCE (Science)	

TP Search

1	Press the RDS button 3 times.		(-TP-) Flashes
2	Press the AUTO TUNING UP (▲) or DOWN (▼) button.		FM 87.50 Flashes
3	Broadcast reception.		"TP" and "RDS" light Once the station is tuned in, "TP" and "RDS" light and the program service name is displayed.

NOTE: "NO PROG" is displayed when there is no traffic information broadcast station.

Receiving FM programs in stereo

- Press the MONO/STEREO selector button to turn on the "AUTO" indicator. When a program being broadcast in stereo is received, the "STEREO" indicator lights and the program is received in stereo.
- If reception is poor and there is much noise in the stereo signals, press the MONO/STEREO selector button to set the monoaural mode.

NOTE:

A humming sound may be heard when using a TV nearby while receiving AM programs. If this happens, move the system as far from the TV as possible.

Radio Text (RDS stations only)

1	When a radio station offering an RT service is tuned in, the RT indicator lights to indicate that the RT service can be received.		FM 87.50 RT (Green)
2	To turn the RT mode on, press the PANEL button on the remote control unit until the RT indicator is lit in red. (Refer to page 9.)		WDR 3 RT (Red)
3	When the station currently tuned in is offering a radio text message service the message scrolls on the display.		RADIO RT (Green) The RT indicator blinks in green.

- When the RT mode is turned on while an RDS radio station not offering an RT service is tuned in, "NO TEXT" flashes on the display, then the mode automatically switches to the PS mode.
- In the same way, the mode automatically switches to the PS mode when the RT service is finished. In this case, the mode automatically switches from the PS mode back to the RT mode when an RT broadcast is resumed.
- The RT mode cannot be set in the AM band or for FM stations not offering RDS broadcasts.
- To turn the RT mode off, press the PANEL button and switch to the desired display mode.

EON TA (RDS stations only)

When an RDS station is broadcasting RDS information on other stations within the same network and a traffic announcement begins on another station in the same network based on this information (EON = Enhanced Other Network), that network station is automatically tuned in. The previous station is tuned back in once the traffic announcement is over.

1	When EON TA function is not on while receiving EON TA information the EON TA indicator lights in green.		WDR 3 EON TA (Green) (STATION A)
2	Press the EON button once, then the TA indicator turns on in red. (Refer to page 9.)		WDR 3 EON TA (Red) (STATION A)
3	When a traffic announcement starts, that station is automatically tuned in. The EON TA indicator blinks in green.		WDR 2 EON TA (Green) (STATION B)
4	When a traffic announcement is over, the previous station is tuned in. The EON TA indicator stops blinking and remains lit in green. The EON TA function turns off.		WDR 3 EON TA (Green) (STATION A)

- The EON TA function cannot be turned on if the station currently tuned in is not an RDS station. If you attempt to do so, "NO RDS" flashes on the display.
- If the RDS station currently tuned in does not provide an EON service, the EON TA function does turn on, but "NO EON" flashes on the display.
- To turn the EON TA mode off, press the EON button until the EON TA indicator turns off or lights in green, following the instructions on page 9. If the EON TA mode is turned off under the conditions in 3 on the table above, Station B continues to be tuned in.
- If the tuning button, preset button, band button, system power button or function button is pressed when this mode is set, the mode is turned off.
- "NO TP" appears on the display if no traffic announcement is being broadcast on the network of the station which is currently tuned in.

EON PTY (RDS stations only)

When an RDS station is broadcasting RDS information on other stations within the same network and a programme of the specified programme type (PTY) begins on a station in the same network, that network station is automatically tuned in. Use this function to tune in broadcasts of the desired programme type with priority.

1	When EON PTY function is not on while receiving EON PTY information, the EON PTY indicator lights in green.		WDR 3 EON PTY (Green) (STATION A)
2	Press the EON button twice, then the EON PTY indicator turns on in red. (Refer to page 9.)		PTM EON PTY (Red) (STATION A)
3	The programme type flashes for approximately 5 seconds. During this time, press the PTY button to select the type of program. (Refer to page 11.)		NEWS EON PTY (Red) (STATION A)
4	Once the desired programme type is selected, set it with the MEMO button.		POP M EON PTY (Red) (STATION A) (The set programme type lights, and its display turns back on after several seconds. The programme type is set automatically if the MEMO button is not pressed within 5 seconds.)
5	When a programme of the specified programme type begins on a station in the same network, that station is tuned in. The EON PTY indicator blinks in green.		WDR 2 EON PTY (Green) (STATION B)
6	The previous station is tuned back in once a programme of a different programme type begins. The EON PTY indicator stops blinking, remaining lit in green. The EON PTY function also turns off.		WDR 3 EON PTY (Green) (STATION A)

- The EON PTY function cannot be turned on if the station currently tuned in is not an RDS station. If you attempt to do so, "NO RDS" flashes on the display.
- If the RDS station currently tuned in does not provide an EON service, the EON PTY function does turn on, but "NO EON" flashes on the display.
- To turn the EON PTY mode off, press the EON button until the EON PTY indicator turns off or lights in green, following the instructions on page 9. If the EON PTY mode is turned off under the conditions in 5 on the table above, Station B continues to be tuned in.
- If the tuning button, preset button, band button, system power button or function button is pressed when this mode is set, the mode is turned off.
- When using the EON TA function together with the EON PTY function, press the EON button once after making the settings on the table above. (Refer to page 9.)
- To reset the PTY after setting it, repeat the procedure from step 2.

NOTE:

- Be sure to turn the EON TA and EON PTY modes off when recording programmes.
- In the EON TA and EON PTY modes, if the station is switched from the current station to another station in the network but the signals of that network station are weak and it cannot be tuned in properly, "WEAK" is displayed and the original station is immediately tuned back in.
- In the EON TA mode, the station does not switch to another station in the network if the current station is broadcasting a traffic announcement.
- In the EON PTY mode, the station does not switch to another station in the network if the current station is broadcasting a programme of the same programme type.
- Since the RDS services offered differ from station to station, some RDS functions may not operate for some stations, but this is not a malfunction.

8 USING THE TIMER

The time and timer functions are incorporated in the receiver.

Timer Settings

Types of timer operations

- TIMER** Use this to turn the power on and off at the same times every day.
- SLEEP TIMER** Use this to set the power to turn off after 10 to 60 minutes (operated from the remote control unit).

Notes on timer settings

- Be sure to set the current time beforehand.
- To listen to or record a radio program ("air check") using the timer, be sure to preset the station beforehand. (Refer to "Presetting AM and FM Stations" on Page 10.)

Power Failures

Should there be a power failure or should the power cord be unplugged, the time display will flash at "00:00". If this happens, reset the current time. Also check the timer and tuner presettings, and reset them if they have been cleared.

Checking the Settings

To check the timer settings, press the **TIMER/TIMER STANDBY** button for at least 3 seconds. (This can also be done when the tuner's power is off.) Next, press the **ENTER/NEXT** button repeatedly to display the timer start mode, the reception band and preset channel number when in the tuner mode, the on time and the off time. Press the **ENTER/NEXT** button once more to return to the current mode display.

Changing the Settings

Repeat the timer setting operation to erase the previous settings and set the new settings.

Clearing the Settings

Press the **TIMER/TIMER STANDBY** button for at least 3 seconds, then press it for at least 3 seconds again while "FUNC" is displayed to clear the timer settings.

Note on Setting the Timer


If the time set with the timer is reached while the system power is on, the operation switches to the operation set by the timer.

Turning the Timer Off

Press the **TIMER/TIMER STANDBY** button to turn the mark off.

Setting the Current Time

The time is displayed in the 24-hour mode.




Example: Setting to 19:30 (7:30 p.m.)

1	Press the CLOCK/ON/OFF button for at least 3 seconds.			The hours place flashes. (If the hours have already been set, that number flashes.)
2	Use the UP and DOWN buttons to set the hours.			The hours place flashes.
3	Press the MEMO ENT/NEXT button.			The minutes place flashes. (If the minutes have already been set, that number flashes.)
4	Use the UP and DOWN buttons to set the minutes.			The minutes place flashes.
5	Press the MEMO ENT/NEXT button at the sound of a time service's chime. The time display stops flashing and the clock starts running.			The display stops flashing and the clock starts running from 00 seconds.

- The current time can be set even when the power is off.
- If an RDS station offers a time service, the time can be set by pressing the **CT** button on the remote control unit while that station is tuned in.

Setting the Timer

The power can be set to turn on and off every day at the same time in any of five modes: tuner, CD, cassette deck, MD player (optional) and air check (recording from the radio). (Preset the AM or FM station beforehand.)



Example: Setting the timer to turn on at 12:35, off at 12:56 (with FM 87.50 MHz preset at channel "3")

1	Press the SYSTEM POWER switch on the receiver to turn on the system's power.			Say that FM 90.00 MHz is tuned in at preset channel number "1".
2	Press the TIMER/TIMER STANDBY button for at least 3 seconds to set the timer setting mode.			
3	Use the UP and DOWN buttons to set the "TUNER" mode.			
4	Press the MEMO ENT/NEXT button.			
5	Use the UP and DOWN buttons to set the preset channel number.			
6	Press the MEMO ENT/NEXT button.			Flashes (If the timer has already been set, that number flashes.)
7	Use the UP and DOWN buttons to set the hours for the timer on time.			Flashes


8	Press the MEMO ENT/NEXT button.			Flashes (If the timer has already been set, that number flashes.)
9	Use the UP and DOWN buttons to set the minutes for the timer on time.			Flashes
10	Press the MEMO ENT/NEXT button.			Flashes
11	Use the UP and DOWN buttons to set the hours for the timer off time.			Flashes (If the timer has already been set, that number flashes.)
12	Press the MEMO ENT/NEXT button.			Flashes (If the timer has already been set, that number flashes.)
13	Use the UP and DOWN buttons to set the minutes for the timer off time.			Flashes (If the timer has already been set, that number flashes.)
14	Press the MEMO ENT/NEXT button.			The display returns to as it was before the timer setting mode was set.
15	Press the TIMER/TIMER STANDBY button.			Lights
16	Press the SYSTEM POWER switch on the receiver to turn off the system's power.			

If the mark is displayed after the **TIMER/TIMER STANDBY** button is pressed, the timer will operate at the same times every day. To turn the timer off, press the **TIMER/TIMER STANDBY** button again to turn the mark off.

NOTE:


- The standby mark () will not light if the current time is not set. If this is the case, set the current time, then press the **TIMER/TIMER STANDBY** button.

Various Timer Operations



Example 1: Playing a compact disc with the timer


1	Press the SYSTEM POWER switch on the receiver to turn on the system's power.		
2	Press the CD player's OPEN/CLOSE button to open the disc tray.		
3	Load the disc in the disc tray. Refer to Page 21.		
4	Press the CD player's OPEN/CLOSE button again to close the disc tray.		
5	Press the receiver's TIMER/TIMER STANDBY button for at least 3 seconds.		
6	Use the receiver's UP and DOWN buttons to set the "CD" mode.		
7	Now follow steps 6 to 16 under "Setting the Timer" on Page 14.		



Example 2: Playing a cassette tape with the timer

1	Press the SYSTEM POWER switch on the receiver to turn on the system's power.		
2	Press the cassette deck's OPEN/CLOSE button to open the cassette tray.		
3	Load the cassette tape in the cassette tray. Refer to Page 17.		
4	Press the cassette deck's OPEN/CLOSE button again to close the cassette tray.		
5	Press the receiver's TIMER/TIMER STANDBY button for at least 3 seconds.		
6	Use the receiver's UP and DOWN buttons to set the "TAPE" mode.		
7	Now follow steps 6 to 16 under "Setting the Timer" on Page 14.		

• Check that the direction of tape travel, reverse mode and Doby NR mode are set as desired.



Example 3: Unattended recording of radio programs ("air check")

1	Press the SYSTEM POWER switch on the receiver to turn on the system's power.		
2	Press the cassette deck's OPEN/CLOSE button to open the cassette tray.		
3	Load the cassette tape in the cassette tray. Refer to Page 17.		
4	Press the cassette deck's OPEN/CLOSE button again to close the cassette tray.		• For instructions on setting the reverse mode and Doby NR mode, refer to 2 and 3 on Page 20.
5	Press the receiver's TIMER/TIMER STANDBY button for at least 3 seconds.		
6	Use the receiver's UP and DOWN buttons to set the "AIRCH" mode.		
7	Now follow steps 6 to 16 under "Setting the Timer" on Page 14.		

- Check that the direction of tape travel and reverse mode are set as desired.
- Timer recording starts in the direction indicated on the display.
- Recording is not possible on the leader tape at the beginning of the cassette tape, so to avoid missing any of the program, we recommend setting the timer to approximately 1 minute before the program is scheduled to start.

Setting the Sleep Timer

With this function, the power can be set to turn off after 10 to 60 minutes, in steps of 10 minutes, using the remote control unit.

Example: Setting the power to turn off in 50 minutes (This operation is only possible from the remote control unit.)

1	Tuner currently set to FM 87.50 MHz.	
2	Press the SLEEP button.	
3	Press the SLEEP button again while the "SLEEP" indicator is flashing.	
4	The previous display reappears after 5 seconds. The "SLEEP" indicator remains lit, indicating that the sleep timer is functioning.	

• The time is reset to "60" (60 minutes) if the SLEEP button is pressed again while the sleep timer is functioning.

Cancelling the Sleep Timer


Press the SLEEP button repeatedly until the "SLEEP" indicator turns off. The sleep timer is also cancelled if the receiver's SYSTEM POWER switch or the POWER switch on the remote control unit is pressed, turning the system power off.

NOTE:

• If the times set with the sleep and everyday timers overlap, the sleep timer has priority.

Order of priority of the sleep and everyday timers

The sleep timer has priority for the off time. (The system operates as indicated by the bold lines.)



Even when the power was turned on with the timer, the power turns off if the remaining time of the sleep timer reaches "00" before the off time set with the everyday timer is reached. If the everyday timer's time is reached while the sleep timer is functioning, the everyday timer does not function.

16 TROUBLESHOOTING

Check the following once more before assuming there is a problem with the system.
 8. Are connections proper?
 7. Is the system being operated as explained in the operating instructions?
 If the system does not seem to be operating properly, check as shown on the table below. If none of these checks apply to the problem, the system may be malfunctioning. Disconnect the power cord immediately and contact your store of purchase.

Symptom	Cause	Countermeasure	Page
General	Power does not turn on when power switch is pressed.	• Power cord is not plugged into a power outlet.	5
	No sound is produced from the speakers.	• VOLUME control is turned down. • Headphones are connected. • Speaker cords are not securely connected.	6 6 5
	No trouble sound is produced, or the position of the instrument is unclear.	• Speaker potentiometers (B and G) are inverted.	5
Cassette deck	A source other than the cassette is heard.	• Function is not properly set.	6
	Recording does not start when REC/REC MUTE buttons is pressed.	• No cassette tape is loaded. • Accidental ensure protection tabs are broken off.	17 17
	Sound is broken or no sound is produced during recording and playback.	• Heads are dirty. • Cassette tape is defective.	28 -
Receiver	Humming sound is heard while playing cassette tapes.	• Noise from a TV (Noise may be produced by some types of TVs.)	4 -
	Wow (shaky sound) is heard during recording or playback.	• Capstans or pinch rollers are dirty.	28
	Hissing sound is heard in FM programs.	• Antenna direction is poor. • Signals from the broadcast station are weak.	4 4
CD player	Hissing sound is heard in AM programs.	• Noise from a TV or interference from a broadcast station.	- 4
	Humming sound is heard in AM programs.	• Signals on the power cord are being modulated by the power source frequency.	- 4
	Total number of tracks not displayed when disc is loaded.	• Disc is loaded upside-down. • Disc is dirty. • Disc is not of the specified type.	21 20 -
CD player	Nothing happens when operating buttons are pressed.	• Disc is loaded upside-down. • Foreign object on disc tray.	21 21
	Disc stops in the middle of a track and will not play properly.	• Disc is dirty. • Disc is scratched.	20 -
	Sound is broken.	• Disc, fingerprints, spots, etc. on disc. • Disc is scratched. • Player is in an unstable place and vibrates strongly.	20 - -
CD player	Humming sound is heard when disc is played.	• Signals on the power cord are being modulated by the power source frequency.	-

• Protector circuit
 The UDRA-F07 is equipped with a high speed protector circuit. This circuit protects internal parts from being damaged by strong currents generated in the set should the set be operated when the speaker terminals are incompletely connected or short-circuited. If this protector circuit is activated, a relay sound is produced, the output to the speakers is interrupted, and the function and power LEDs flash to indicate that there is a problem. If this should happen, unplug the power cord, check the speaker connections, then plug in the power cord and turn the power back on. After several seconds, a relay sound is heard and the set starts operating properly.

• The set may not operate properly due to such external influences as lightning or static electricity. If this happens, either turn off the power with the receiver's SYSTEM POWER switch or unplug the power cord, wait approximately 5 seconds, then plug the power cord back in.

SPECIFICATIONS

■ Receiver (UDRA-F07)

Practical maximum output:
Low frequency adjustment range:
High frequency adjustment range:
Reception frequency band:

40 W + 40 W (4 Ω / ohms, DIN)
 100 Hz ± 8 dB
 10 kHz ± 8 dB
 FM: 87.50 MHz ~ 108.00 MHz
 AM: 522 kHz ~ 1611 kHz
 FM: 1.5 μ / 75 Ω / ohms
 AM: 20 μ V

Reception sensitivity:

FM stereo separation:
Audio input / output jacks:

35 dB (1 kHz)
 CD input jacks, tape input/output jacks,
 MD input/output jacks, Aux input jacks.
 6.3 mm headphones jack and phono input jacks

Power supply:
Power consumption:
Maximum external dimensions:

AC 230 V, 50 Hz
 110 W
 270 (W) × 112 (H) × 327 (D) mm
 (10-5/8" × 4-13/32" × 12-7/8")
 (including feet, controls and terminals)
 5.1 kg (11 lbs. 4 oz)

Weight:

■ Remote control unit (RC-818)

Remote control system:
Number of buttons:
Power supply:
Maximum external dimensions:

Infrared pulse
 48
 Two DC 1.5V R6P/AA batteries
 64 (W) × 176 (H) × 18 (D) mm
 (2-1/2" × 6-15/16" × 23/32")
 130 g (including batteries) (Approx. 4.6 oz)


Weight:

* Maximum dimensions include controls, jacks, and covers.

(W) = width, (H) = height, (D) = depth

• For improvement purposes, specifications and functions are subject to change without advanced notice.

■ Dolby noise reduction and HX Pro headroom extension manufactured under license from Dolby Laboratories Licensing Corporation. HX Pro originated by Bang & Olufsen.


■ "DOLBY", the double-D symbol  and "HX PRO" are trademarks of Dolby Laboratories Licensing Corporation.

DISASSEMBLY


(To reassemble reverse disassembly)

1. Top Cover


- 1) Remove 6 screws ① on the left, right and rear side.
- 2) Detach the Top Cover in arrow direction.

**2. Front Panel**

- 1) Remove 4 screws ③ on the left, right and bottom side.
- 2) Unfasten 2 hooks and detach the Front Panel with the Inner Panel in arrow direction ④.

**3. Volume P.W.B. Unit**

- 1) Pull out 4 knobs and remove 4 nuts ⑤.
- 2) Detach the Volume P.W.B. Unit in arrow direction.

**4. Headphone P.W.B. Unit**


- Remove 2 screws ⑥ securing the Headphone.

5. Front P.W.B. Unit


- 1) Remove 3 screws ⑦.
- 2) Unfasten 6 hooks ⑧, and pull out the Front P.W.B. Unit in arrow direction.

6. Rear Panel

- 1) Disconnect the connector ⑨ connecting with the Power Transformer.
- 2) Remove 10 screws ⑩ and detach the Rear Panel in arrow direction ⑪.

**7. Amplifier P.W.B. Unit**


- 1) Remove a screw ⑫ fixing the Power Radiator on the bottom.
- 2) Remove 2 screws ⑬ securing Power Radiator.

**8. Tuner and Function P.W.B. Unit**

- Pull out the Tuner P.W.B. Unit ⑭ and the Function P.W.B. Unit ⑮ as shown in the figure.

9. Main P.W.B. Unit

- Remove 4 screws ⑯ and detach the Main P.W.B. unit.




ADJUSTMENT


● TUNER SECTION

CONNECTION DIAGRAM OF MEASURING INSTRUMENTS

● FM



FRONT END



FM adjustment (BAND button: FM, MONO / AUTO button: AUTO, RF ATT button: OFF)


Step	Adjustment item	Tuning point (channel setting)	Input					Output		Adjustment location	Setting value	Notes
			Measuring instrument	Frequency	Input level	Modulation	Connection location	Measuring instrument	Connection location			
1	FM DC balance	98.0 MHz	FM S.G.	98.0 MHz	60 dB μ	1 kHz 75 kHz DEV	FM antenna terminal	Digital volt meter	TP1 TP2	T702	0 \pm 50 mV	Perform with monaural modulation signal
2	Distortion	98.0 MHz	FM S.G.	98.0 MHz	60 dB μ	1 kHz 75 kHz DEV	FM antenna terminal	Distortion factor meter	Output jack	T703	Minimum distortion	Perform with monaural modulation signal
3	Repeat steps 1 and 2.											
4	Muting level	98.0 MHz	FM S.G.	98.0 MHz	19 dB μ	1 kHz 75 kHz DEV	FM antenna terminal	Check for the lighting of TUNED	Output jack	VR702	Input level 22 dB μ \pm 4 dB	(Level at which TUNED lights up)
5	Stereo separation	98.0 MHz	FM stereo modulator FM S.G.	98.0 MHz	60 dB μ	1 kHz L or R: 67.5 kHz DEV Pilot: 7.5 kHz DEV	FM antenna terminal	VTVM. Oscilloscope	Output jack	VR703	Minimum R ch Output	Perform with L ch. Input of FM stereo modulator

● AM

AM adjustment (BAND button: AM)

Note: The AM IFT and MW ANT.-OSC. coil are adjusted individually and normally do not require adjustment.

1	IF	Clear frequency (without a broadcast)	AM IF sweep	455 kHz	Level at which AGC is not applied	—	AM antenna terminal	Oscilloscope	⊕IC701 Output terminal Pin ⑭ ⊖Q716 (Base)	T704	Waveform maximum and symmetry	
2	Band edge	522 kHz 1611 kHz	—	—	—	—	—	Digital voltmeter	⊕Q714 (collector) ⊖GND	T701 Black —	1.2V \pm 0.2V Approx. 7.5V	No place to adjust
3	Tracking	603 kHz	AM S.G.	603 kHz	Level at which AGC is not applied	400Hz 30%	Loop antenna	VTVM	Output terminal	T701 Red	maximum output	



External Terminals

1. ANT
2. GND
3. GND
4. GND
5. Vt
6. +B
7. IF OUT
8. OSC OUT

● AUDIO SECTION

Measuring Instruments Required for the adjustments


- DC Voltmeter

Arrangement

- (1) Avoid direct blow from an air conditioner or an electric fan, and adjust the unit at normal room temperature 15°C~30°C. (59°F~86°F).
- (2) Presetting
 - POWER (Power source switch) → ON
 - SPEAKER terminals → No load (Do not connect speaker, dummy resistor, etc.)
 - INPUT, Terminal → No input


Adjustment

- (1) Remove the top cover and connect the DC Voltmeter to the test points (R319, R320).
- (2) Connect power cord to AC Line, and turn the Power Switch "ON".
- (3) After 10 minute, read the Test Points voltage whether it is from 2 mV to 40 mV DC.
- (4) When the value read from the voltmeter is 2 mV or less, cut R317 and R318 (2 kohm) on the AMP P.W.B. unit.



SEMICONDUCTORS

- IC's
- HD6433726A76H (IC901)





HD6433726A76H Terminal Function

Pin No.	Symbol	Port Name	I/O	INI	ACT	Function
1	AM Stereo	P60/AN6	I	-	L	AM stereo signal detection.
2	Tuned in	P07/AN7	I	L	H	- FM/AM tuning signal input.
3	GND	AVss	-	-	-	Analog ground.
4	GND	Test	-	-	-	
5	Sub Xtal	X2	O	-	-	Sub Xtal drive.
6	Sub Xtal	X1	I	-	-	Sub Xtal input.
7	Vss	Vss	-	-	-	Ground.
8	OSC1	OSC1	O	-	-	8.38 MHz Xtal out.
9	OSC2	OSC2	I	-	-	8.38 MHz Xtal in.
10	Reset	Res	I	-	L	Reset input.
11	Remocon	P10/IRQ0	I	-	L	Remote control signal in.
12	50/60	P11/IRQ1	I	-	L	50/60 Hz AC input.
13	Protect	P12/IRQ2	I	-	L	Overcurrent detection signal input.
14	RDS Start	P13/IRQ3	I	-	L	RDS signal start detection.
15	RXD	P14/IRQ4	I	-	L	Denon Bus data input.
16	Mute	P15/IRQ5	O	H	L	Speaker relay off.
17	GND	P16/EVNT	I	-	-	Not used.
18	N.C.	P33	O	L	L	No connection.
19	RT Gr LED	P32	O	L	H	RT green LED.
20	TA Gr LED	P31	O	L	H	TA green LED.
21	PTY Gr LED	P30	O	L	H	PTY green LED.
22	RT Rd LED	P47	O	L	H	RT red LED.
23	TA Rd LED	P46	O	L	H	TA red LED.
24	RTY Rd LED	P45	O	L	H	PTY red LED.
25	Diode 1	P44	I	-	H	Setting return input 1.
26	Diode 2	P43	I	-	H	Setting return input 2.
27	Seg 1	P42/FS18	O	L	H	Segment 1 output.

Pin No.	Symbol	Port Name	I/O	INI	ACT	Function
28	Seg 2	P41/FS17	O	L	H	Segment 2 output.
29	Seg 3	P40/FS16	O	L	H	Segment 3 output.
30	Seg 4	P50/FS15	O	L	H	Segment 4 output.
31	Seg 5	P51/FS14	O	L	H	Segment 5 output.
32	Seg 6	P52/FS13	O	L	H	Segment 6 output.
33	Seg 7	P53/FS12	O	L	H	Segment 7 output.
34	Seg 8	P54/FS11	O	L	H	Segment 8 output.
35	Seg 9	P55/FS10	O	L	H	Segment 9 output.
36	Seg 10	P56/FS9	O	L	H	Segment 10 output.
37	Seg 11	P57/FS8	O	L	H	Segment 11 output.
38	Vdisp	P17/Vdsp	-	-	-	High B voltage.
39	Seg 12	P60/FS7	O	L	H	Segment 12 output.
40	Seg 13	P61/FS6	O	L	H	Segment 13 output.
41	Seg 14	P62/FS5	O	L	H	Segment 14 output.
42	Seg 15	P63/FS4	O	L	H	Segment 15 output.
43	Seg 16	P64/FS3	O	L	H	Segment 16 output.
44	Dig 11	P65/FD5	O	L	H	Digit 11 output.
45	Dig 10	P66/FD6	O	L	H	Digit 10 output.
46	Dig 9	P67/FD7	O	L	H	Digit 9 output.
47	Dig 8	P70/FD8	O	L	H	Digit 8 output.
48	Dig 7	P71/FD9	O	L	H	Digit 7 output.
49	Dig 6	P72/FD10	O	L	H	Digit 6 output.
50	Dig 5	P73/FD11	O	L	H	Digit 5 output.
51	Dig 4	P74/FD12	O	L	H	Digit 4 output.
52	Dig 3	P75/FD13	O	L	H	Digit 3 output.
53	Dig 2	P76/FD14	O	L	H	Digit 2 output.
54	Dig 1	P77/FD15	O	L	H	Digit 1 output.
55	Vcc	Vcc	-	-	-	5V.
56	Volume Dwn	P80	O	H	H	Master volume down.
57	Volume Up	P81	O	H	H	Master volume up.
58	Power	P82	O	L	L	Amplifier circuit power on.
59	TU Mute	P83	O	H	L	Tuner audio mute.
60	Auto/Mono	P84	O	H	-	FM Auto/Mono setting.
61	Ant Sns	P85	O	L	H	Antenna sensitivity reduction.
62	SDB	P86	O	L	H	Super Dynamic Bass.
63	Sel EEROM	P87	O	L	H	Select SCI to EEROM.
64	PLL CE	P90	O	L	H	PLL serial data selection output.
65	Bus Clock	P91/SCK1	O	H	-	Denon Bus clock.
66	Bus Data In	P92/SI1	I	-	-	Denon Bus data input.
67	Bus Data Out	P93/SO1	O	H	-	Denon Bus data output.
68	RDS Clock	P97/SCK2	O	H	-	RDS data fetch clock input, PLL control clock output, LC7821 clock output.
69	RDS Data	P95/SI2	I	H	-	RDS serial data input.
70	PLL Data	P96/SO2	O	H	-	PLL serial data output, LC7821 serial data output.
71	RDS Res	P97	O	H	L	LC7070 reset output.
72	PLL STRQ	PA0	O	L	H	IF count operation request output.
73	LC7821CE	PA1	O	L	H	LC7821 chip enable.
74	AVcc	AVcc	-	-	-	Analog 5 V power supply.
75	Key AD0	P00/AN0	I	-	-	Analog key input 0.
76	Key AD1	P01/AN1	I	-	-	Analog key input 1.
77	PWB Test	P02/AN2	I	-	-	Board check at 5 V.
78	Stereo In	P03/AN3	I	-	L	FM stereo demodulation detection.
79	Signal In	P04/AN4	I	-	L	RF signal detection signal input.
80	Stop In	P05/AN5	I	-	L	IF count tuning detection.




LC7074M (IC705)



LC7074M Terminal Function

Pin No.	Symbol	I/O	INI	Function
1	OSC1	I	-	• 4 MHz ceramic oscillator connection.
2	GND	-	-	• Ground
3	GND	-	-	• Ground
4	RES	I	-	• System reset input. • Reset and restart is accomplished by inputting the low level for 4 or more cycles.
5	CLOCK IN	I	H	• RDS LA2230 series demodulation clock input.
6	DATA IN	I	H	• RDS LA2230 serial demodulation data input.
7	CORR. SEL	I	H	• Error correction on/off selection input. • Sets the IC to correct errors in the RDS demodulation data or to output the data without correction. When input is 0 : No corrections are made When input is 1 : Corrections are executed
8	CL. ED. SEL	I	H	• Serial data clock polarity selection input. When input is 0 : Serial data output is enabled at the rise of output clock. (Serial data output changes at the fall of the output clock.) When input is 1 : Serial data output is enabled at the fall of the output clock. (Serial data output changes at the rise of the output clock.) Note: Set at the time of RES input.
9	+5V	-	H	• Power supply
10	RECEIVE (NC)	O	H	• Output during RDS data reception. • After the completion of sync detection, there is a low-level output while the serial data is being output. There is a high-level output at other times. • Open drain output.
11	D.S. CONTROL	I	H	• Block data start signal control input. When input is 0 : Data start signal is output for all blocks. When input is 1 : Data start signal is output for only the second block.
12	CORRECTION (NC)	O	H	• Output without error correction. • There is a low level output when the output data of the serial data output have been corrected when correction is not possible. There is a high-level output when correction have not been applied. • Open drain output.
13	ERROR (NC)	O	H	• Presence error output. • There is a low-level output when the output data of the serial data output has an error and correction is not possible. There is a high-level output when there is no error or when the error has been corrected. • Open drain output.
14	DATA START	O	H	• Block data start signal of the serial data output. Output with pull-up resistor.
15	DATA OUT	O	H	• Data output of the serial data output. Output with pull-up resistor.
16	CLOCK OUT	O	H	• Clock output of the serial data output. Output with pull-up resistor.
17	GND	-	-	• Ground
18	OSC2	O	-	• 4 MHz ceramic oscillator connection.




LM7000 (IC703)



Pin Description

- SYC : Clock (400kHz) for the controller
- XIN, XOUT : X'tal oscillator (7.2MHz) with built-in feedback resistor
- FM IN, AM IN : Local oscillator signal input
- CE, CL, DATA : Data input
- B01, B02, B03 : Band data output, B01 can be set as the time base output (8Hz)
- STRQ : IF counter request input
- STOUT : Auto research stop signal output
- VDD1, VDD2, VSS : Power supply (VDD2 is back-up power supply)
- AMIF, FMIF : IF signal input
- PD1, PD2 : Charge pump output




SAA6579T (IC704)





SAA6579T Terminal Function

Pin No.	Symbol	Function
1	QUAL	Quality indication output.
2	RDDA	RDS data output.
3	Vref	Reference voltage output (0.5 VDD A).
4	MUX	Multiplex signal input.
5	VDD A	+5V power supply for analog part.
6	VSS A	Ground for analog part (0V).
7	CIN	Subcarrier input to comparator.
8	SCOUT	Subcarrier output of reconstruction filter.
9	TSTLD	Test control.
10	TEST	Test enable.
11	VSS D	Ground for digital part (0V).
12	VDD D	+5V power supply for digital part.
13	OSCI	Oscillator input.
14	OSCO	Oscillator output.
15	T57	57kHz clock signal output.
16	RDCL	RDS clock output.



LC7821 (IC202)





LA1267S (IC701)



LA3410 (IC702)






μPC1225H (IC301, 302)





μPC1225H Terminal Function

Pin No.	Function
1	+V _{CCD} (drive stage power supply)
2	+V _{CCP} (pre-drive stage power supply)
3	MUTING
4	INPUT (non-inverting)
5	INPUT (inverting)
6	PHASE COMP
7	BIAS
8	BIAS
9	-V _{CCP} (pre-drive stage power supply)
10	-V _{CCD} (drive stage power supply)
11	LOWER OUTPUT
12	UPPER OUTPUT

M5230L (IC4)





XL904F (IC902)





XL904F Terminal Function

Pin No.	Pin Name	I/O	Function
1	R/B	O	READY, BUSY status signal output
2	Vcc	-	Connected to the power supply
3	CS	I	Chip select input
4	SK	I	Serial data clock input
5	DI	I	Operation code, address, and serial data input
6	DO	O	Serial data output
7	GND	-	Reference voltage of all inputs and outputs; 0 V
8	WC	I	Write control input



**NJM4565MD (IC101, 201, 203)
NJM2068MD (IC302, 303)**



LB1639 (IC102)




PST529C (IC903)





● IC PROTECTOR

ICP-N15/ICP-F15 (IC1, 2, 3)



● INFRARED REMOTE CONTROL SENSOR


SBX8035F (RM901)




- Equivalent Circuit and Measurement Circuit
 IC1 : CX20106A Chip
 D1 : PIN Photo Diode Chip
 C1,C2,C4 : Aluminum Electrolytic Capacitor
 C3 : SL Characteristic $\pm 5\%$
 R1 : Resistor for Gain Adjustment
 R2 : Use $\pm 1\%$ Resistor for fo Adjustment
 R (except for above) : $\pm 5\%$

● TRANSISTORS


2SA933S (S)
 2SC1740S (E)
 KTA1266 (Y)
 KTC3198 (Y)




2SB1185 (E/F)
 2SD1762 (E/F)



2SA1694 (O.P.Y)
 2SC4467 (O.P.Y)




2SA1037K (S/R)
 2SC2412K (S), (LN)




1: Emitter
 2: Base
 3: Collector


DTA114EK
 DTC343TK



1: Emitter
 2: Base
 3: Collector




	R1	R2
DTA114EK	10 kohm	10 kohm




	R1
DTC343TK	2.2 kohm

DTA144ES
 DTC114ES
 DTC144ES




	R1	R2
DTC114ES	10 kohm	10 kohm
DTC144ES	47 kohm	47 kohm




	R1	R2
DTA144ES	47 kohm	47 kohm

● DIODES


ISS131
IN4002




SPR-39MVW3
(LED901, 902, 903)



MTZJ5.6B
MTZJ6.2B
MTZJ13B
MTZJ27B






DBF40C/D3SB20



● FL DISPLAY

11BT127GK (FL901)



Pin Connections

Pin No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Connection	F1	F1	NP	NP	1G	2G	3G	4G	5G	6G	7G	8G	9G	10G	11G	NC	NC	NC	NC	NC	NC	NC	NC	NC

Pin No.	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
Connection	NC	NC	NC	P16	P15	P14	P13	P12	P11	P10	P9	P8	P7	P6	P5	P4	P3	P2	P1	NP	NP	F2	F2

NOTE: 1) F1 and F2: Filaments
 2) NP: No pin
 3) NC: No connection
 4) 1G through 11G: Grid

ANODE CONNECTION

	11G	10G	9G	8G	7G	6G	5G	4G	3G	2G	1G
P1		a	a	a	a	a	a	a	a	1a	1a
P2	DATE	b	b	b	b	b	b	b	b	1b	1b
P3	⊙	c	c	c	c	c	c	c	c	1c	1c
P4	TIME	d	d	d	d	d	d	d	d	1d	1d
P5	TIMER	e	e	e	e	e	e	e	e	1e	1e
P6	TUNED	f	f	f	f	f	f	f	f	1f	1f
P7	—	g	g	g	g	g	g	g	g	1g	1g
P8	—	h	h	h	h	h	h	h	h	ADJ	1h, 1k
P9	—	j	j	j	j	j	j	j	j	MEMO	2a
P10	—	k	k	k	k	k	k	k	k	SLEEP	2b
P11	—	m	m	m	m	m	m	m	m	OFF	2c
P12	—	n	n	n	n	n	n	n	n	—	2d
P13	—	p	p	p	p	p	p	p	p	—	2e
P14	—	r	r	r	r	r	r	r	r	—	2f
P15	—	ON	OFF	AUTO	RDS	PS	Co	TP	kHz	—	2g
P16	—	STEREO	MONO	—	—	—	Dp	PTY	MHz	—	CH

1

2

3

4

5

6

7

8

Main P.W.B Unit (Component side)


A

B

C


D

E




1 2 3 4 5 6 7 8

Main P.W.B Unit (Pattern side)



A
B
C
D
E

NOTE FOR PARTS LIST

- Part indicated with the mark "⊙" are not always in stock and possibly to take a long period of time for supplying, or in some case supplying of part may be refused.
 - When ordering of part, clearly indicate "1" and "1" (i) to avoid mis-supplying.
 - Ordering part without stating its part number can not be supplied.
 - Part indicated with the mark "★" is not illustrated in the exploded view.
 - Not including Carbon Film ±5%, 1/4W Type in the P.W.Board parts list. (Refer to the Schematic Diagram for those parts.)
- WARNING:**
Parts marked with this symbol  have critical characteristics.
Use ONLY replacement parts recommended by the manufacturer.

Resistors

Ex.: RN 14K 2E 182 G FR

Type Shape Power Resist- Allowable FR
and per- ance error Others
formance

RD : Carbon	2B : 1/8W	F : ±1%	P : Pulse-resistant type
RC : Composition	2E : 1/4W	G : ±2%	NL : Low noise type
RS : Metal oxide film	2H : 1/2W	J : ±5%	NB : Non-burning type
RW : Winding	3A : 1W	K : ±10%	FR : Fuse-resistor
RN : Metal film	3D : 2W	M : ±20%	F : Lead wire forming
RK : Metal mixture	3F : 3W		
	3H : 5W		

*** Resistance**

1 8 2 ⇒ 1800 ohm = 1.8 kohm
Indicates number of zeros after effective number.
2-digit effective number.

• Units: ohm

1 R 2 ⇒ 1.2 ohm
1-digit effective number.
2-digit effective number, decimal point indicated by R.

• Units: ohm

Capacitors

Ex.: CE 04W 1H 2R2 M BP

Type Shape Dielectric Capacity Allowable Others
and per- strength error

CE : Aluminum foil electrolytic	0J : 6.3V	F : ±1%	HS : High stability type
CA : Aluminum solid electrolytic	1A : 10V	G : ±2%	BP : Non-polar type
CS : Tantalum electrolytic	1C : 16V	J : ±5%	HR : Ripple-resistant type
CQ : Film	1E : 25V	K : ±10%	DL : For change and discharge
CK : Ceramic	1V : 35V	M : ±20%	HF : For assuring high frequency
CC : Ceramic	1H : 50V	Z : +80%	U : UL part
CP : Oil	2A : 100V	-20%	C : CSA part
CM : Mica	2B : 125V	P : +100%	W : UL-CSA type
CF : Metallized	2C : 160V	-0%	F : Lead wire forming
CH : Metallized	2D : 200V	C : ±0.25pF	
	2E : 250V	D : ±0.5pF	
	2H : 500V	= : Others	
	2J : 630V		

*** Capacity (electrolyte only)**

2 2 2 ⇒ 2200µF
Indicates number of zeros after effective number.
2-digit effective number.

• Units: µF.

2 R 2 ⇒ 2.2µF
1-digit effective number.
2-digit effective number, decimal point indicated by R.

• Units: µF.

*** Capacity (except electrolyte)**

2 2 2 ⇒ 2200pF=0.0022µF
(More than 2) — Indicates number of zeros after effective number.
2-digit effective number.

• Units: pF.

2 2 1 ⇒ 220pF
(0 or 1) — Indicates number of zeros after effective number.
2-digit effective number.

• Units: pF.

• When the dielectric strength is indicated in AC, "AC" is included after the dielectric strength value.

**PARTS LIST OF P.W.B. UNIT ASS'Y
MAIN UNIT**


Ref. No.	Part No.	Part Name	Remarks	Ref. No.	Part No.	Part Name	Remarks
SEMICONDUCTORS GROUP							
IC001-003	268 0073 905	IC protector ICP-N15		R071,072	960 9001 731	Metal oxide 560ohm 1W	RS14B3A561JFR
IC004	263 0646 007	IC M5230L		R319,320	243 2026 032	Cement 0.22ohm x 2, 3W	RW===3FR22R22K
IC101	928 0035 809	IC NJM4565MD		VR101	960 0049 909	Variable resistor 100kohm-B	VOLUME
IC102	263 0476 002	IC LB1639		VR401,402	960 0049 802	Variable resistor 100kohm-A	TREBLE,BASS
IC301,302	363 0206 007	IC µPC1225H		VR403	960 0049 705	Variable resistor 200kohm	BLANCE
Q001	271 0238 908	Transistor 2SA1037K		CAPACITORS GROUP (Not included ceramic chip type capacitor)			
Q002,003	273 0384 900	Transistor 2SC2412K		C014	253 1174 018	Ceramic 0.01 µF/16V	CK14Y1C103M
Q004	960 0049 404	Transistor 2SD2576F		C015	254 4254 912	Electrolytic 22 µF/16V	CE04W1C220M
Q005	9LC F013 21	Transistor 2SB1655E		C016	254 4260 061	Electrolytic 3.3 µF/50V	CE04W1H3R3M
Q006	960 0049 404	Transistor 2SD2576F		C017	254 4260 045	Electrolytic 1 µF/50V	CE04W1H010M
Q007	269 0040 009	Transistor DTC144ES		C018	255 1251 940	Film 0.0047 µF/50V	CQ92M1H472J
Q008	960 0005 202	Transistor KTC3198Y		C019,020	254 4256 046	Electrolytic 100 µF/25V	CE04W1E101M
Q009	271 0192 002	Transistor 2SA933S		C021	254 4260 087	Electrolytic 10 µF/50V	CE04W1H100M
Q010	269 0093 904	Transistor DTA144ES		C022	253 1174 018	Ceramic 0.01 µF/16V	CK14Y1C103M
Q011	269 0040 009	Transistor DTC144ES		C023,024	254 4260 087	Electrolytic 10 µF/50V	CE04W1H100M
Q012	269 0020 906	Transistor DTC114ES		C025,026	960 9002 219	Electrolytic 4700 µF/50V	
Q013	960 0005 105	Transistor KTA1266Y		C027,028	960 9001 100	Ceramic 0.01 µF/500V	CK45F2H103Z
Q014-016	960 0005 202	Transistor KTC3198Y		C029	253 1010 004	Ceramic 0.01 µF/50V	CK45B1H103K
Q017	960 0005 105	Transistor KTA1266Y		C030	254 4260 087	Electrolytic 10 µF/50V	CE04W1H100M
Q018	960 0049 404	Transistor 2SD2576F		C031	254 4261 028	Electrolytic 100 µF/50V	CE04W1H101M
Q301,302	273 0388 906	Transistor 2SC1740SE		C032-034	253 1010 004	Ceramic 0.01 µF/50V	CK45B1H103K
Q303,304	960 0000 304	Transistor 2SC4467P		C035-038	255 4224 903	Film 0.047 µF/50V	CQ92M1H473J
Q305,306	960 0000 207	Transistor 2SA1694P		C039,040	255 1251 940	Film 0.0047 µF/50V	CQ92M1H472J
Q307,308	273 0207 003	Transistor KSC1845F		C041,042	253 1179 084	Ceramic 0.0047 µF/50V	CK45B1H472K
D001-009	960 0031 409	Diode 1SS131		C043	253 1174 018	Ceramic 0.01 µF/16V	CK14Y1C103M
D010	960 0039 508	Diode D3SB20 or DBF40C		C044	254 4260 087	Electrolytic 10 µF/50V	CE04W1H100M
D011-015	916 0053 008	Diode 1N4002A		C045	254 4250 042	Electrolytic 330 µF/6.3V	CE04W0J331M
D016	960 0031 409	Diode 1SS131		C046	254 4260 087	Electrolytic 10 µF/50V	CE04W1H100M
D301-306	960 0031 409	Diode 1SS131		C047	254 4260 045	Electrolytic 1 µF/50V	CE04W1H010M
				C048	960 9001 100	Ceramic 0.01 µF/500V	CK45F2H103Z
ZD001,002	LA2 100U 125	Zener diode MTZJ6.2B		C101,102	254 4260 045	Electrolytic 1 µF/50V	CE04W1H010M
ZD003,004	LA2 60C0 058	Zener diode MTZJ5.6B		C107,108	254 4260 087	Electrolytic 10 µF/50V	CE04W1H100M
ZD005	9H3 0000 231	Zener diode MTZJ27B		C113	254 4260 087	Electrolytic 10 µF/50V	CE04W1H100M
ZD006	960 0037 209	Zener diode MTZJ13B		C114	255 4199 973	Film 0.01 µF/50V	CQ92M1H103J
RESISTORS GROUP (Not included carbon film ±5% 1/4W and chip type resistor)							
R035	960 9001 634	Fuse resistor 4.7kohm 1/4W	RD14B2E472JFR	C301,302	253 1193 976	Ceramic 220pF/50V	CK14B1H221K
R037,038	960 9001 621	Fuse resistor 220ohm 1/4W	RD14B2E221JFR	C303,304	HMA 1000 159	Ceramic 100pF/50V	CK14B1H101K
R047,048	960 9001 728	Metal oxide 390ohm 1W	RS14B3A391JFR	C305,306	960 9002 235	Ceramic 4.7pF/50V	CK14CH1H4R7K
R056	960 9001 618	Fuse resistor 1.5kohm 1/4W	RD14B2E152JFR	C307,308	254 4252 037	Electrolytic 100 µF/10V	CE04W1A101M
R061,062	960 9001 702	Metal oxide 10ohm 1W	RS14B3A100JFR	C309,310	253 1195 929	Ceramic 0.0022 µF/16V	CK14X1C222M
R063	960 9001 728	Metal oxide 390ohm 1W	RS14B3A391JFR	C311,312	253 3617 017	Ceramic 39pF/50V	CC45SL1H390J
R070	960 9002 206	Fuse resistor 1.2kohm 1/4W	RD14B2E122JFR	C313,314	254 4261 015	Electrolytic 47 µF/50V	CE04W1H470M
				C315,316	253 4297 002	Ceramic 150pF/500V	CC45SL2H151J
				C317,318	255 4223 988	Film 0.033 µF/50V	CQ92M1H333J
				C319,320	253 1175 907	Ceramic 0.022 µF/25V	CK14F1E223Z
				C325-328	254 4260 045	Electrolytic 1 µF/50V	CE04W1H010M

FRONT UNIT

Ref. No.	Part No.	Part Name	Remarks
C401,402	255 1251 982	Film 0.0056 μ F/50V	CQ92M1H562J
C403-406	255 4212 067	Film 0.033 μ F/50V	CQ92M1H333K(MRZ)
C407,408	960 9002 222	Film 0.18 μ F/50V	CQ92M1H184J
C601,602	HMA 1000 160	Ceramic 220pF/50V	CK14B1H221K
OTHER PARTS GROUP			
Δ F501	960 0037 005	Fuse 250V/T1.25A	
Δ F503	960 0049 606	Fuse 250V/T1A	
	960 0005 804	Fuse holder	(F501,503)
Δ A501,502	960 0049 501	AC outlet	
GND1	960 0036 909	Earth terminal	
JACK1	960 0005 406	6P RCA terminal	CD/TAPE
JACK2	960 0004 504	4P RCA terminal	MD
JACK3,4	960 0004 407	Jack D3.5	System connector
JACK5	960 0004 601	4P speaker terminal	Speaker
JACK601	960 0002 904	Jack D6.5	Headphone
K001	214 0128 002	Relay	
L001,002	960 0005 008	Coil 0.15 μ H	
B	DCD 2150 903	3x8 special screw	Heat sink Power PWB
SEMICONDUCTORS GROUP			
IC201	928 0035 809	IC NJM4565MD	
IC202	262 1227 008	IC LC7821	
IC203	928 0035 809	IC NJM4565MD	
IC701	263 0421 002	IC LA1267	
IC702	263 0584 004	IC LA3410	
IC703	262 0703 002	IC LM7000	
IC704	262 1827 000	IC SAA6579T	
IC705	9LC K044 71	IC LC7074M	
IC901	262 2177 007	IC HD6433726A76H	
IC902	960 0050 503	IC XL9040F	
IC903	LA2 50C0 028	IC PST529C	
Q701	960 0050 901	Transistor KTC3880O	
Q703-706	273 0384 900	Transistor 2SC2412K	
Q707-710	269 0104 903	Transistor DTC343TK	
Q711,712	269 0083 901	Transistor DTA114EK	
Q713	960 0050 901	Transistor KTC3880O	
Q714	273 0303 907	Transistor 2SC1740SR	
Q715	273 0207 003	Transistor KSC1845F	
Q716	269 0083 901	Transistor DTA114EK	
D201-204	960 0031 409	Diode 1SS131	
D701-711	960 0031 409	Diode 1SS131	
D901	960 0031 409	Diode 1SS131	
D903	960 0031 409	Diode 1SS131	
LED901-903	960 0050 202	LED SPR39MVW3	
RM901	960 0050 105	Remocon sensor	
RESISTORS GROUP (Not included carbon film \pm 5% 1/4W and chip type resistor)			
R701	241 2313 066	Fuse resistor 47ohm 1/4W	RD14B2E470JFR
R775	241 2313 901	Fuse resistor 100ohm 1/4W	RD14B2E101JFR
R840	241 2313 901	Fuse resistor 100ohm 1/4W	RD14B2E101JFR
R848	241 2315 912	Fuse resistor 10ohm 1/4W	RD14B2E100JFR
VR702	960 0043 303	Semi fixed 47kohm-B	
VR703	960 0043 206	Semi fixed 220kohm-B	

Ref. No.	Part No.	Part Name	Remarks
CAPACITORS GROUP (Not included ceramic chip type capacitor)			
C203,204	254 4260 980	Electrolytic 10 μ F/50V	CE04W1H100M
C207,208	254 4252 037	Electrolytic 100 μ F/10V	CE04W1A101M
C211,212	255 4223 933	Film 0.012 μ F/50V	CQ92M1H123J
C213,214	255 4222 963	Film 0.0033 μ F/50V	CQ92M1H332J
C215,216	254 4260 951	Electrolytic 2.2 μ F/50V	CE04W1H2R2M
C219	253 1174 018	Ceramic 0.01 μ F/16V	CK14Y1C103M
C223	253 1194 959	Ceramic 0.001 μ F/50V	CK14B1H102K
C224,225	HMA 1000 159	Ceramic 100pF/50V	CK14B1H101K
C226,227	253 1174 018	Ceramic 0.01 μ F/16V	CK14Y1C103M
C228	253 1175 907	Ceramic 0.022 μ F/25V	CK14F1E223Z
C229,230	254 4260 045	Electrolytic 1 μ F/50V	CE04W1H010M
C235,236	254 4260 045	Electrolytic 1 μ F/50V	CE04W1H010M
C701	254 4254 938	Electrolytic 47 μ F/16V	CE04W1C470M
C704	254 4260 045	Electrolytic 1 μ F/50V	CE04W1H010M
C706	253 1174 018	Ceramic 0.01 μ F/16V	CK14Y1C103M
C707	254 4260 087	Electrolytic 10 μ F/50V	CE04W1H100M
C709	254 4260 045	Electrolytic 1 μ F/50V	CE04W1H010M
C713	254 4260 061	Electrolytic 3.3 μ F/50V	CE04W1H3R3M
C718	HMA 1000 156	Ceramic 22pF/50V	CC14SL1H220J
C719	254 4260 074	Electrolytic 4.7 μ F/50V	CE04W1H4R7M
C720	254 4260 061	Electrolytic 3.3 μ F/50V	CE04W1H3R3M
C721	255 4223 945	Film 0.015 μ F/50V	CQ92M1H153J
C722	254 4260 087	Electrolytic 10 μ F/50V	CE04W1H100M
C723	253 1174 018	Ceramic 0.01 μ F/16V	CK14Y1C103M
C725	253 4535 968	Ceramic 6pF/50V	CC45SL1H060D
C726	253 1026 001	Ceramic 0.047 μ F/50V	CK45F1H473Z
C727	253 1190 940	Ceramic 15pF/50V	CK14SL1H150J
C729	254 4260 087	Electrolytic 10 μ F/50V	CE04W1H100M
C770	254 4260 045	Electrolytic 1 μ F/50V	CE04W1H010M
C771	254 4260 061	Electrolytic 3.3 μ F/50V	CE04W1H3R3M
C772	254 3056 001	Electrolytic 0.47 μ F/50V	CE04W1HR47M
C773	254 4260 087	Electrolytic 10 μ F/50V	CE04W1H100M
C774	255 4212 054	Film 0.047 μ F/50V	CQ92M1H473J
C776	254 4260 087	Electrolytic 10 μ F/50V	CE04W1H100M
C778	254 4254 938	Electrolytic 47 μ F/16V	CE04W1C470M
C780	254 4250 929	Electrolytic 100 μ F/16V	CE04W1C101M
C781	254 4260 087	Electrolytic 10 μ F/50V	CE04W1H100M
C785	254 4254 938	Electrolytic 47 μ F/16V	CE04W1C470M
C786,787	255 4212 012	Film 0.0047 μ F/50V	CQ92M1H472J
C788,789	254 4260 951	Electrolytic 2.2 μ F/50V	CE04W1H2R2M
C840	254 4254 938	Electrolytic 47 μ F/16V	CE04W1C470M
C843	255 4223 975	Film 0.027 μ F/50V	CQ92M1H273J
C844	254 4260 045	Electrolytic 1 μ F/50V	CE04W1H010M
C845	253 1174 018	Ceramic 0.01 μ F/16V	CK14Y1C103M
C847	254 4254 938	Electrolytic 47 μ F/16V	CE04W1C470M
C849	HMA 1000 159	Ceramic 100pF/50V	CK14B1H101K
C852	254 4260 951	Electrolytic 2.2 μ F/50V	CE04W1H2R2M
C853	254 4254 938	Electrolytic 47 μ F/16V	CE04W1C470M
C855,856	254 4254 938	Electrolytic 47 μ F/16V	CE04W1C470M
C901	253 1174 018	Ceramic 0.01 μ F/16V	CK14Y1C103M
C903	254 4299 919	Electrolytic 22 μ F/16V	CE04W1C220M(SRE)
C904,905	253 1174 018	Ceramic 0.01 μ F/16V	CK14Y1C103M
C906	254 4299 964	Electrolytic 47 μ F/16V	CE04W1C470M(SRE)
C907	254 4299 919	Electrolytic 22 μ F/16V	CE04W1C220M(SRE)
OTHER PARTS GROUP			
CF701,702	261 0120 006	FM filter SFE10.7MS3GK-A	
CF703	940 0425 202	AM filter BFU450C4N	
CF704	261 0079 005	Resonator CSB456F11	
FL901	393 8012 002	FL display	
JACK201	960 0004 504	4P RCA terminal	PHONO/AUX
LACK701	960 0008 209	ANT terminal	
L701	960 0007 307	Filter coil 1 μ H	
L702	960 0051 007	Filter coil 10 μ H	
S901-909	LA2 60C0 008	Tact switch	
T701	960 0007 336	MW IF coil	
T702	960 0007 349	FM IF coil	
T703	960 0007 352	FM IF coil	
T704	960 0007 323	MW IF coil	
T705	960 0037 607	LC filter	
T706,707	960 0050 600	LC MPX filter	
TU701	960 0050 707	FM tuner FE418-G02	
X701	960 0008 005	Crystal 7.2MHz	
X702	399 0178 007	Crystal 4.332MHz	
X703	399 9018 003	Resonator CST4.00MGW	
X901	399 0243 903	Resonator CST8.38MTW	
	960 0050 406	LED holder	
	960 0050 309	FLD supporter	
	960 0050 804	Earth plate	


EXPLODED VIEW



PARTS LIST OF EXPLODED VIEW

Ref. No.	Part No.	Part Name	Remarks	Q'ty	Ref. No.	Part No.	Part Name	Remarks	Q'ty
1	960 0050 105	Remocon sensor		1	A	DCD 2150 904	3x8 special screw		28
2	960 0050 008	Front P.W.B. Ass'y		1	B	DCD 2150 903	3x8 special screw		20
3		LED holder		1	C	DCD 2150 905	3x8 special screw		2
4	960 0001 303	Power button		1	D	960 9000 101	3x8 tapp screw		1
5	960 0048 201	Function lens		1	E	960 9000 185	3x14 s/washer screw		4
6	960 0048 104	Inner panel		1	F	960 9000 169	4x8 special screw		4
7	960 0001 400	Remocon window		1	G	DCD 2150 907	3x17 Special screw		2
8	960 0048 007	Front panel		1	H	DCD 2150 908	3x8 washer screw		2
9	960 0007 608	Display window		1	★	960 9000 172	4x8 S/washer screw		2
10	960 0003 806	Volume knob		1					
11	960 0048 706	Control knob		3					
12	960 0051 201	Button guide		1					
13	960 0048 308	Function button		1					
14	—	TONE volume P.W.B. Ass'y		(1)					
15	—	VOLUME P.W.B. Ass'y		(1)					
16	960 0003 505	Foot cushion		4					
17	960 0003 408	Foot front		2					
18	960 0003 301	PWB supporter		2					
19	960 0003 204	Foot rear		2					
20	960 0048 609	Main chassis		1					
21	960 0048 502	Rear panel		1					
A	22	960 0003 602	AC conl stopper	1					
	23	—	Heat sink	1					
A	24	960 0032 301	AC cord	1					
	25	—	Heat sink bracket R	1					
	26	—	Tuner P.W.B. Ass'y	(1)					
	27	—	Function P.W.B. Ass'y	(1)					
	28	—	Heat sink sub Ass'y	2					
	29	—	AMP P.W.B. Ass'y	(1)					
	30	—	PWB bracket	1					
	31	—	Heat sink brscket L	1					
	32	—	Power P.W.B. Ass'y	(1)					
	33	960 0049 307	Main P.W.B. Ass'y	1					
A	34	960 0051 104	Power trans	1					
	35	—	Heat sink sub Ass'y	1					
	36	—	Heat sink sub Ass'y	2					
	37	—	Headphone P.W.B. Ass'y	(1)					
	38	960 0000 702	Top cover	1					
	41	363 0206 007	IC μ PC1225H	IC301,302	2				
A	42	960 0049 501	AC outlet	A501,502	2				
	43	960 0004 407	Jack D3.5	Jack3,4	2				
	44	960 0004 601	4P speaker terminal	Jack5	1				
	45	960 0004 504	4P RCA terminal	Jack201	1				
	46	960 0008 209	ANT terminal	Jack701	1				
	47	960 0050 707	FM tuner FE418-G02	TU701	1				
	48	960 9002 219	Electrolytic capacitor 4700 μ F/50V	C25,26	2				
	49	960 0002 904	Jack D6.5	Headphone	1				
	50	960 0049 909	Variable resistor 100kohm-B	Volume	1				
	51	393 8012 002	FL display		1				
	52	960 0049 705	Variable resistor 200kohm	Balance	1				
	53	960 0049 802	Variable resistor 100kohm-A	Bass, Treble	2				
ACCESSORIES AND PACKING									
		960 0004 106	AM loop antenna		1				
		960 0004 203	FM antenna wire		1				
		960 0048 803	Inst. manual		1				
		960 0048 900	Remote controler	RC-818	1				
		960 0049 006	Carton case		1				
		960 0049 103	Cushion		1				
		505 8092 023	Poly bag 470x550		1				


BLOCK AND LEVEL DIAGRAM




BLOCK DIAGRAM

1 2 3 4 5 6 7 8

Tuner Section




A
B
C
D
E



WIRING DIAGRAM

1 2 3 4 5 6 7 8



A
B
C
D
E

NOTE

SCHEMATIC DIAGRAM

1


2




3

4


5

6






NOTES
 ALL RESISTANCE VALUES IN OHM. k=1,000 OHM, M=1,000,000 OHM
 ALL CAPACITANCE VALUES IN MICRO FARAD. P=MICRO-MICRO FARAD
 EACH VOLTAGE AND CURRENT ARE MEASURED AT NO SIGNAL INPUT CONDITION.
 CIRCUIT AND PARTS ARE SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

WARNING:
 Parts marked with this symbol  have critical characteristics. Use ONLY replacement parts recommended by the manufacturer.

CAUTION:
 Before returning the unit to the customer, make sure you make either (1) a leakage current check or (2) a line to chassis resistance check. If the leakage current exceeds 0.5 millamps, or if the resistance from chassis to either side of the power cord is less than 240 kohms, the unit is defective.

WARNING:
 DO NOT return the unit to the customer until the problem is located and corrected.




A
 B
 C
 D
 E
 F
 G
 H

SCHEMATIC DIAGRAM

1 2 3 4 5 6

A
B
C
D
E
F
G
H





NOTES
 ALL RESISTANCE VALUES IN OHM. k=1,000 OHM, M=1,000,000 OHM
 ALL CAPACITANCE VALUES IN MICRO FARAD. P=MICRO-MICRO FARAD
 EACH VOLTAGE AND CURRENT ARE MEASURED AT NO SIGNAL INPUT CONDITION.
 CIRCUIT AND PARTS ARE SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

WARNING:
 Parts marked with this symbol have critical characteristics. Use ONLY replacement parts recommended by the manufacturer.

CAUTION:
 Before returning the unit to the customer, make sure you make either (1) a leakage current check or (2) a line to chassis resistance check. If the leakage current exceeds 0.5 milliamps, or if the resistance from chassis to either side of the power cord is less than 240 kohms, the unit is defective.

WARNING:
 DO NOT return the unit to the customer until the problem is located and corrected.



— +B LINE
 - - - -B LINE
 ■■■■■ SIGNAL LINE