




Service Manual

VIDEO CASSETTE RECORDER



MODEL
HS-HD2000U

Only cassettes marked D-VHS or S-VHS or VHS can be used with this video cassette recorder.

SPECIFICATIONS

Tape Format	: S-VHS/VHS NTSC standard with Hi-Fi audio and D-VHS standard	Video Input	: 0.5 to 2.0 V(p-p), 75 Ω unbalanced RCA pin Jack
Power Source	: 120 V AC ; 60 Hz	Audio Input	: -346 mV(rms), 47 k Ω unbalanced RCA pin Jack
Power Consumption	: Approx. 28 W (standby 6.0 W)	Video Output	: 1.0 V(p-p), 75 Ω unbalanced RCA pin Jack
Video Signal System	: EIA standard ; NTSC color	Audio Output	: -346 mV(rms), 1 k Ω unbalanced RCA pin Jack
Video Recording System	: S-VHS standard/D-VHS standard	Digital Interface	: based on IEEE 1394 digital interface, 4 pin, corresponds to S400
Luminance	: Frequency modulation recording	Input/Output	
Color Signal	: Low frequency conversion sub-carrier phase shift recording	Tuner	VHF : 54 to 88 MHz, 174 to 216 MHz
Hi-Fi Audio	: S-VHS standard	UHF : 470 to 806 MHz	CATV : 54 to 88 MHz, 90 to 804 MHz
Recording System	: Azimuth helical scanning system	Operating Temperature	: 41 $^{\circ}$ F to 104 $^{\circ}$ F
Linear Audio Track	: 1 track	Relative Humidity	: 30 % to 80 %
Maximum Recording Time		RF Channel Output	: Channel 3 or 4 switchable
D-VHS	: 150 min. with DF-300 video cassette (HS) 300 min. with DF-300 video cassette (STD)	Weight	: Approx. 9.9 lbs (4.5 kg)
S-VHS/VHS	: 120 min. with T-120 video cassette (SP) 360 min. with T-120 video cassette (EP)	Dimensions	: 16.7"(W) \times 3.7"(H) \times 12.0"(D)
Record/Playback System		Timer Program Capacity	: 1 month programmable / 8 programs
Video	: 4 heads	Memory Backup Time	: Approx. 30 minutes
Audio	: 2 Hi-Fi channels and 1 monoral audio control	Deck	: α Deck
Digital	: HS 4 heads STD 2 heads		
Rewind Time	: Approx. 43 seconds for T-120 cassette		

- Weight and dimensions shown are approximate.
- Design and specifications are subject to change without notice.

MITSUBISHI DIGITAL ELECTRONICS AMERICA, INC.

9351 Jeronimo Ave. Irvine, California 92618 U.S.A.

Copyright © 2001 Mitsubishi Digital Electronics America, Inc. All Rights Reserved.

CONTENTS

– FILE “COVERPGE” –

SPECIFICATIONS1
CONTENTS.....2
GLOSSARY OF ABBREVIATIONS4

– FILE “DISASSY” –

SAFETY PRECAUTIONS1
CONNECTION3
WARNING.....3
DISASSEMBLY4
HOW TO EXECUTE CIRCUIT BOARD SERVICE7
CHIP PARTS REPLACEMENT11

– FILE “ELCTADJ” –

HOW TO INITIALIZE THE E²PROM1
WHEN REPLACING IC5A0.....1
ELECTRICAL ADJUSTMENTS.....1
 Servo circuit Adjustment.....3
 D-VHS signal circuit Adjustment4

– FILE “MECHAADJ” –

**MECHANICAL ADJUSTMENT
 AND REPLACEMENT**1

1. DECK Cleaning.....1
 - 1-1 VIDEO HEAD1
 - 1-2 Tape Running System.....1
 - 1-3 REEL DISK Drive System1
2. Replacement of Major Parts2
 - 2-1 CLEANING ARM, FELT RING2
 - 2-2 STAY PLATE2
 - 2-3 BOTTOM ASSY.....3
 - 2-4 INSERT GUIDE (TU).....4
 - 2-5 INSERT GUIDE (SP).....4
 - 2-6 REC HOLDER, REC LEVER,
REC SPRING5
 - 2-7 F/L ARM ASSY, F/L BEARING5
 - 2-8 A/C HEAD UNIT6
 - 2-9 F/E HEAD6
 - 2-10 SENSOR COVER (TU)7
 - 2-11 SENSOR COVER (SP)7
 - 2-12 REVERSE ASSY (TU),
REVERSE ASSY (SP).....8
 - 2-13 MODE POSITION UNIT8
 - 2-14 REEL BELT, PULLEY BUSH,
THRUST WASHER,
BELT PULLEY, SHIFT SLIDER,

PULLEY GEAR ASSY, SLIP GEAR,
SLIP SPRING, SLIP WASHER,
THRUST WASHER, SLIP ADJUSTER,
IDLER UNIT9

- 2-15 CAPSTAN BRAKE SPRING,
CAPSTAN BRAKE ASSY11
- 2-16 FC HOLDER, MOTOR HOLDER,
LOADING WORM,
LOADING MOTOR ASSY,
WORM WHEEL.....12
- 2-17 PINCH ARM CAP, PINCH ASSY13
- 2-18 F/L PLATE, DOOR ARM.....13
- 2-19 BRAKE CAM PLATE.....14
- 2-20 GUIDE LAMP15
- 2-21 MAIN CAM, GUIDE ARM (TU),
BRAKE LEVER, LB PIN16
- 2-22 L/D LOCK LEVER17
- 2-23 BRAKE BELT (SP), BELT HOLDER.....17
- 2-24 BELT LEVER, BELT ADJUSTER18
- 2-25 TENSION ARM, TENSION LEVER,
TENSION SPRING, TENS AXIS HOLDER,
REEL DISK (SP side).....18
- 2-26 BRAKE BELT (TU).....19
- 2-27 BRAKE (TU), REEL DISK (TU side)19
- 2-28 SHIFT LEVER20
- 2-29 CHARGE SPRING, SWING LEVER,
CHARGE ASSY21
- 2-30 LOADING ARM ASSY (SP),
LOADING ARM ASSY (TU)21
- 2-31 A/L LEVER22
- 2-32 TAPE GUIDE ASSY (SP),
TAPE GUIDE ASSY (TU).....24
- 2-33 GUIDE ARM (SP).....24
- 2-34 DRUM CLAMPER, DRUM ASSY25
- 2-35 DRUM MOTOR STATOR, BRUSH SPRING,
SPACER, ROTOR CASE, END RING,
BRUSH, UPPER DRUM ASSY.....26
- 2-36 CAPSTAN MOTOR27
- 2-37 IMPEDANCE UNIT (SP),
FLYWHEEL (SP).....29
- 2-38 SSW HOLDER, SSW SLIDER.....29

3. Interchangeability Adjustment
of the Mechanism.....30
 - 3-1 Adjustment of BACK TENSION and

CONTENTS

TENSION POLE's Position	30
3-2 Check and Adjustment of FM Envelope	31
3-2-1 GUIDE ROLLER Adjustment Check	31
3-2-2 Height Adjustment of GUIDE ROLLER (SP)	31
3-2-3 Height Adjustment of GUIDE ROLLER (TU)	31
3-2-4 Coarse Adjustment of Phase	32
3-2-5 Flatness Check of FM Waveform	32
3-2-6 Tape Running Condition at the GUIDE ROLLERS (Check1)	33
3-2-7 Tape Running Condition at the GUIDE ROLLERS (Check 2)	33
3-3 A/C HEAD Adjustment	34
3-3-1 Slant Adjustment of A/C HEAD	34
3-3-2 Azimuth and Height Adjustment of A/C HEAD	34
3-4 Phase Adjustment	35
3-5 Tape wrinkle check	35
4. Servicing for Tape Jam during the Loading Process	36
SERVICE CAN BE EXECUTED WITH THE EE PICTURE DISPLAYED	37
DECK OPERATION CHECK	37
– FILE “PARTSLST” –	
PARTS LIST	1
1. CABINET ASSEMBLY	1
2. PACKING PARTS	3
3. ELECTRICAL PARTS	5
– FILE “DECKASSY” –	
DECK ASSEMBLY-1	1
DECK ASSEMBLY-1 P/L	2
DECK ASSEMBLY-2	4
DECK ASSEMBLY-2 P/L	5
– FILE “SCHEMATC” –	
BLOCK DIAGRAMS	
SCHEMATIC DIAGRAMS	
PRINTED CIRCUIT BOARD PARTS LAYOUT	

GLOSSARY OF ABBREVIATIONS

A/C	: Audio/Control	JSTCLK	: Just Clock
A-PB	: Audio Play Back	LIN-IN	: Linear Audio In
A-REC	: Audio Recording	LIN-OUT	: Linear Audio Out
AE	: Audio Erase	LMUTE	: Linear Mute
AENV	: Audio Envelope	LP	: Long Play
AFC	: Automatic Frequency Control	MOD	: Modulator
AFF	: Audio Flip Flop	MOTORV	: Motor Voltage
AFTV	: Auto Fine Tuning Voltage	NL	: Non Linear
ALC	: Automatic Level Control	OSC	: Oscillator
AMODE	: Audio Mode	PB	: Play Back
AMPC	: Amplifier Alternating Current Ground	PC	: Position Control
APC	: Automatic Phase Control	PCB	: Printed Circuit Board
ATFN	: Auto Fine	PG	: Pulse Generator
ATT	: Attenuator	PLL	: Phase Locked Loop
BLMUTE	: Blue Back Mute	PRT	: Protect
C/N	: Carrier/Noise Ratio	PSAVE	: Power Save
CCD	: Charge Coupled Device	PSLED	: Power Save Light Emitting Diode
CG-CS	: Character Generator-Chip Slect	PSYNC	: Pretened Vartical Synchronizing Signal
CHSW	: Channel Switch	PWSV	: Power Save
CLKSEL	: Clock Select	PWV	: ON/OFF Command to supply B + Power
CNTR	: Counter	QH	: Cue Horizontal Signal
COM	: Comparator	QV	: Cue Vertical Signal
CONV SW	: Converter Switch	REC	: Recording
CP-FG	: Capstan-Frequency Generator	REC2	: Record Command for the PB/REC Control Circuit
CP-REV	: Capstan-Reverse	RECPBC	: Record/Play Back Chroma Signal
CPMOTORV	: Capstan Motor Voltage	RES	: Reset
CROT	: Chroma Rotation	RESPCM	: Reset Pulse Code Modulation
CSYNC	: Composite Synchronizing Signal	REW	: Rewind
CTL	: Control	RIS	: Record Inhibit Switch
D.E.	: Detail Enhancer	RMSDET	: Root Mean Square Detector
D-FF	: Drum Flip Flop	RXD	: Read X Data
DEMOD	: Demodulator	SAPIND	: SAP carrier detect Indicator
DET	: Detector	SCLK	: Serial Clock
DLY	: Delay	SCR	: Scramble
DOC	: Drop Out Compensator	SI	: Serial control data Input
DOCSTOP	: Drop Out Control Stop	SLD	: Side Lock Detector
DR-FG	: Drum-Frequency Generator	SP	: Standard Play
DR-OUT	: Drum Control Out	SS	: Start Sensor
DR-PG	: Drum-Phase Generator	SSVSYNC	: Speed Search Vertical Synchronizing Signal
EE	: Electronic-Electronic	STRB	: Strobe
EMPH	: Emphasis	SU-SENS	: Supply Reel Sensor
EP	: Extended Play	TSREC	: Tape Simulate Recording
EQ	: Equalizer	TSSW	: Tape Simulator Switch
ES	: End Sensor	TU-SENS	: Take Up Reel Sensor
FBC	: Feed Back Clamp	V-REF	: Voltage Reference
FE	: Full Erase	VBUSY	: VSET Busy
FF	: Fast Forward	VCA	: Voltage Control Amplifier
FG	: Frequency Generator	VCO	: Voltage Controlled Oscillator
FLDCS	: Fluorescent Tube Driver Chip Slect	VENV	: Video Envelope
FM	: Frequency Modulation	VSETCLK	: VSET Clock
FSC	: Frequency of Color Subcarrier	VSETCS	: VSET Chip Select
G	: Ground	YNR	: Y(Luminance) Signal Noise Reduction
HASW	: Head Amplifier Switch		
HFR400	: Hi-Fast Forward/Rewind 400		
HFRSS	: Hi-Fast Forward/Reverse Speed Search		
HSYNC	: Horizontal Synchronizing Signal		
I-LIMIT	: I(Current)-Limiter		

SAFETY PRECAUTIONS

INTRODUCTION

This manual provides service information for the adjustments of mechanical and electrical operations.

Due to design modifications, the servicing procedures and data given in this manual are subject to possible change without prior notice.

WARNING : Many of the programs broadcast by television stations are protected by copyright and Federal law imposes strict penalties for copyright infringement. Some motion picture companies have taken the position that home recording for noncommercial purposes is an infringement of their copyrights. Until the courts have ruled on the proper interpretation of the law as applied to home video recording, this equipment, if used to record copyrighted material, should be operated at the user's own risk.

WARNING :
TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.
This video cassette recorder should be used with AC 120V, 60Hz only.

SAFETY NOTICE

Before returning VCR to the customer a safety check of the entire VCR should be made. The service technician must be sure that no protective device built into the instrument by the manufacturer has become defective or inadvertently damaged during servicing. Observe all caution and safety related notes located on or inside the VCR cabinet.

WARNING : Alterations of the design or circuitry of this VCR should not be made. Any design alterations or additions, such as circuit modifications, auxiliary speaker jacks, switches, grounding, active or passive circuitry, etc., or use of unauthorized camera, cables, accessories, etc. may alter the safety characteristics of this VCR and potentially create a hazardous situation for the user. Any design alterations or unauthorized additions will invalidate the manufacturer's warranty and will further relieve the manufacturer of responsibility for personal injury or property damage resulting from them. Do not lubricate any motors. When reassembling the VCR, always be certain that all the protective devices are put back in place, such as non-metallic control knobs, shield plates, etc. When service is required, observe the original lead dress. Components that show evidence of overheating or other electrical or mechanical damage should be replaced.



WARNING : Replace with same type 1.6A, 125V FUSE.

LEAKAGE CURRENT CHECK

Before returning the VCR to the customer, it is recommended the leakage current be measured by the following methods.

1. Cold Check


With the AC plug removed from the 120V AC source, place a jumper across the two AC plug prongs. Turn the AC switch on. Using an ohmmeter, connect one lead to the jumpered AC plug and touch the other lead to each exposed metal part (metal cabinet, screwheads, metal overlays, control shafts, etc.), particularly any exposed metal part having a return path to the chassis. Exposed metal parts having a return path to the chassis should have a minimum resistance reading of 1 M Ω . Any resistance below this value indicates an abnormality which requires corrective action. Exposed metal parts not having a return path to the chassis will indicate an open circuit.

2. Hot Check

The test sequence, with reference to the measuring circuit in the figure is as follows:

(1) With switch S1 open, connect the VCR to the measuring circuit. Immediately after connection, measure the leakage current using both positions of switch S2 and with the switching devices in the VCR in all of their operating positions.

(2) Close switch S1, energizing the VCR, and immediately after closing the switch, measure leakage current using both positions of switch S2, and with the switching devices in the VCR in all of their operating positions. Repeat the current measurements of items (1) and (2) after the VCR has reached thermal stabilization. The leakage current should not be more than 0.5 mA.



AC Leakage Test

Avoid shock hazards. Do not connect this VCR to a TV antenna, cable or accessory that exhibits excessive leakage currents. If available, the television instrument or cable to which this VCR is connected should have the antenna cold check and leakage current hot check performed.

PRECAUTIONS

Handling and storage

- Avoid using the VCR in the following places:
 - extremely hot, cold or humid places,
 - dusty places,
 - near appliances generating strong magnetic fields,
 - places subject to vibration,
 - poorly ventilated areas.
- Be careful of moisture condensation.
- If you pour a cold liquid into a glass, water vapor in the air will condense on the surface of the glass. This is called moisture condensation.
- Moisture condensation on the head drum, one of the most critical parts of the VCR, will cause damage to the tape.
- The VCR is equipped with a moisture condensation prevention circuit. This circuit operates only when the unit is attached to an AC outlet.
- Handle the VCR carefully.
- Do not block the ventilation openings.
- Do not place anything heavy on the recorder.
- Do not place liquids on the top cover of the recorder.
- Use the Recorder in horizontal (flat) position only.
- Avoid violent shocks to the recorder during packing and transportation.
- Before packing, be sure to remove the cassette from the recorder.

CONNECTION

Connecting separate antennas (UHF/VHF)

Connecting the Television


To connect separate UHF/VHF antennas to the VCR:

1. Disconnect the antennas from the back of your TV.
2. Connect the antenna leads to the combiner.
3. Screw or push the combiner onto the ANTENNA terminal on the VCR labeled ANTENNA IN.
4. When you are finished, refer to "Connecting the Television" to complete your connections.

Now that you've completed the antenna connections to your VCR, you're ready to connect the VCR to the TV.

Because every television is different (especially older model TVs), your VCR may need to be connected in a variety of ways. See the Owner's Manual for Instruction Information ON:

- Determining if you need a splitter,
- Connecting TVs with audio and video inputs.



Connecting a regular TV to the VCR

Before connecting the VCR to the TV, complete the cable or antenna connections to the VCR. (If you have not already done so.)

To connect a regular TV to the VCR:

1. Take the black cable that is supplied with your VCR (called a coaxial cable) and connect it to the ANTENNA terminal on the VCR labeled ANTENNA OUT.
2. Connect the other end of this cable to the terminal on your TV labeled ANTENNA IN. (This terminal may also be labeled VHF IN.) If you have an older TV without this kind of terminal, you will have to use a splitter and then connect the splitter to the television.

WARNING

Use the specified batteries.

Batteries of wrong type can lead to explosion.

Be sure to replace with batteries of the same type or equivalent batteries. Use the parts specified in the circuit diagram or parts list.

Confirm that the batteries are placed with their positive (+) and negative (-) in the correct position.


DISASSEMBLY

1. Removal of Top Cover

1. Remove the two Top Cover fastening screws (a) shown in Fig. 1 and remove the Top Cover in the direction shown by arrow.



2. Removal of Front Panel

1. Remove the Top Cover.
(Refer to Para. 1 of the DISASSEMBLY.)
2. Remove the Jog Dial and the Shuttle Ring.
3. Unfasten the seven catches (b) shown in Fig. 1 and remove the Front Panel in the direction shown by arrows.
4. Disconnect the Connector OG in Fig.1.



3. Removal of Bottom Panel

1. Remove the Top Cover.
(Refer to Para. 1 of the DISASSEMBLY.)
2. Remove the two fastening screws (a) shown in Fig. 2.
3. Turn the set upside down as shown in Fig. 3.
4. Push the one hook (b) toward inside. Slide the Bottom Panel backward to remove it, with taking care of the six catches (c).



4. Removal of DECK ASSY

1. Remove the Top Cover.
(Refer to Para. 1 of the DISASSEMBLY.)
2. Remove the Front Panel.
(Refer to Para. 2 of the DISASSEMBLY.)
3. Short-circuit J483 and the GND of the DECK ASSY using the jig shown below.

Note: The CAPSTAN MOTOR may be damaged without above short circuit.

4. Remove the one screw (a) and remove PCB HA Holder.
5. Disconnect the Connectors HH and HK on PCB-HEAD AMP.
6. Remove the two screws (b) shown in Fig. 4 and raise the PCB-HEAD AMP to remove it.
7. Remove the four screws (c) shown in Fig. 5.
8. Disconnect the Connectors MA, MD and ML on PCB-MAIN.
9. Release the two catches (d) shown in Fig.5 and raise the DECK ASSY to remove it.

Note1: Remove the DECK ASSY paying attention to the Connectors MC and MF under it.

Note2: Short-circuit the J483 and the Shield Case using the jig shown below before attaching the DECK ASSY.




Fig. 4

Jig (Part No. : 859C548010)





Fig. 5

HOW TO EXECUTE CIRCUIT BOARD SERVICE

CAUTION: BEFORE ATTEMPTING TO REMOVE OR REPAIR ANY PCB, UNPLUG THE POWER CORD FROM THE A.C. SOURCE.

LOCATION OF PRINT CIRCUIT BOARDS

Note :

- Take caution when removing flat cables to prevent any contact problem.
- Connect and disconnect the flat cables at right angles to the connector and make sure that it is completely secured.
- After servicing the PCB, restore the flat cable and leads to their former state.




Fig. 6

1. PCB-OPE L

1. Remove the Top Cover.
(Refer to Para. 1 of the DISASSEMBLY.)
2. Remove the Front Panel.
(Refer to Para. 2 of the DISASSEMBLY.)
3. Remove the Connector OS.
4. Unfasten the two catches (a) shown in Fig. 7 and rotate the PCB-OPE L in the direction shown by arrow (b) and remove it in the direction shown by arrow (c).




Fig. 7

2. PCB-OPE R

1. Remove the Top Cover.
(Refer to Para. 1 of the DISASSEMBLY.)
2. Remove the Front Panel.
(Refer to Para. 2 of the DISASSEMBLY.)
3. Remove the Connector OJ.
4. Unfasten the two catches (a) shown in Fig. 8 and rotate the PCB-OPE R in the direction shown by arrow (b) and remove it in the direction shown by arrow (c).




Fig. 8

3. PCB-JOG

1. Remove the Top Cover.
(Refer to Para. 1 of the DISASSEMBLY.)
2. Remove the Front Panel.
(Refer to Para. 2 of the DISASSEMBLY.)
3. Unfasten the three screws (a) shown in Fig. 9 and remove the PCB-JOG.




Fig. 9

4. PCB-SIGNAL

1. Remove the Top Cover.
(Refer to Para. 1 of the DISASSEMBLY.)
2. Lift and remove the Cover D VHS as shown in Fig.10.
3. Remove the one screw (a) and remove the PCB HOLDER shown in fig. 10.
4. Disconnect the Connector FX on PCB-D-IF.
5. Disconnect the Connector HK on PCB-HEAD AMP.
6. Lift and remove the PCB-SIGNAL as shown in Fig. 10.





Fig. 10

5. PCB-D-IF

1. Remove the Top Cover.
(Refer to Para. 1 of the DISASSEMBLY.)
2. Lift and remove the Cover D VHS as shown in Fig.10.
3. Remove the one screw (a) and remove the PCB HOLDER shown in fig. 10.
4. Remove the Connector FX.
5. Lift and remove the PCB-D-IF as shown in Fig. 10.


6. PCB-1394

1. Remove the Top Cover.
(Refer to Para. 1 of the DISASSEMBLY.)
2. Lift and remove the Cover D VHS as shown in Fig.10.
3. Remove the PCB HOLDER shown in fig. 10.
4. Disconnect the connectors EE and EX on the PCB-1394 .
5. Pull out the Part A,lift and remove the Spring Earth EMC as shown in Fig. 11.
6. Unfasten the one screws (ⓐ) shown in Fig. 11 and remove the PCB-1394 ASSY.
7. Disconnect the connector PG3821 on the PCB-D-VHS .
8. Separate the bottom of the Shield Cover from the ASSY PCB-1394 first. Remove the Shield Cover moving the bottom in the direction shown by the arrow (Ⓐ) as shown in Fig. 11.
9. Remove the connectors EL and EH on the PCB-1394.
10. Disconnect six soldering connections and remove the PCB-1394 as shown in Fig. 12.






7. PCB-DVHS

1. Remove the Top Cover.
(Refer to Para. 1 of the DISASSEMBLY.)
2. Lift and remove the Cover D VHS as shown in Fig.10.
3. Remove the PCB HOLDER shown in fig. 10.
4. Disconnect the connectors EE and EX on the PCB-1394 .
5. Pull out the Part A,lift and remove the Spring Earth EMC as shown in Fig. 11.
6. Unfasten the one screws (ⓐ) shown in Fig. 11 and remove the PCB-1394 ASSY.
7. Disconnect the connector PG3821 on the PCB-D-VHS .
8. Separate the bottom of the Shield Cover from the ASSY PCB-1394 first. Remove the Shield Cover moving the bottom in the direction shown by the arrow (Ⓐ) as shown in Fig. 11.
9. Remove the connectors PG3823 and PG5153 on the PCB-DVHS.
10. Disconnect seven soldering connections and remove the PCB-DVHS as shown in Fig. 12.



8. PCB-MAIN

1. Carry out steps 1 and 2 of "3. Removal of Bottom Panel" of "DISASSEMBLY"
2. Remove the Front Panel.
(Refer to Para. 2 of the DISASSEMBLY.)
3. Remove the DECK ASSY.
(Refer to Para. 4 of the DISASSEMBLY.)
4. Remove the PCB-SIGNAL.
(Refer to Para. 4 of the HOW TO EXECUT CIRCUIT BOARD SERVICE.)
5. Remove the PCB-D-IF.
6. Disconnect the connectors EE and EX on the PCB-1394 .
7. Pull out the Part A, lift and remove the Spring Earth EMC as shown in Fig. 11.
(Refer to Para. 4 of the HOW TO EXECUT CIRCUIT BOARD SERVICE.)
8. Remove the three screws (a) shown in Fig. 13.
9. Remove the Holder for the AC Power Cord from the Base Chassis shown in Fig. 14.
10. Disconnect the connectors ME, MJ and MS on the PCB-MAIN .
11. Release the two fastening catches (b) shown in Fig. 13. Raise the PCB-MAIN to remove it.
12. Release the two fastening catches (c) and remove the Antenna Cover (R) shown in Fig. 15.
13. Unfasten the fastening five screws (d) shown in Fig. 15 and remove the Antenna Cover (L).
14. Lift and remove the PCB-JACK as shown in Fig. 15.



CHIP PARTS REPLACEMENT

CHIP PARTS REPLACEMENT


Some resistors, shorting jumpers (0Ω resistor), ceramic capacitors, transistors and diodes are chip parts. When replacing these parts, note the following cautions.

Cautions :

- Use fine tipped, well insulated soldering pencil (iron), about 30 watts, and tweezers.
- Melt the solder and remove the Chip Parts carefully not to tear off the copper foil of the printed circuit board.
- Discard removed chips ; do not reuse them.
- Do not apply heat for more than 3 seconds to new Chip Parts.
- Avoid using a rubbing stroke when soldering.
- Take care not to scratch, or damage the Chip Parts when soldering.
- Supplementary cementing is not required.


1. Removal of Chip Parts (Resistors, capacitors, etc.)

- Grasp the part with tweezers. Melt the solder at both sides alternately, remove one side of the part with a twisting motion.
- Melt the solder at the other side and remove the part.




2. Removal of Chip Parts (Transistors)

- Melt the solder of one lead. Lift the side of that lead upward.
- Simultaneously melt the solder of the two remaining leads and lift the part from the PCB.



3. Replacement

- Presolder the contact points of the circuit pattern.
- Press the part downward with tweezers and apply the soldering pencil as shown in Fig. 3.



MECHANICAL ADJUSTMENT AND REPLACEMENT

1. DECK Cleaning

The following Parts require cleaning whenever serviced in order to maintain satisfactory performance.


1-1. VIDEO HEAD

1. Clean the VIDEO HEAD according to the following method. Dust and other foreign objects on the VIDEO HEAD disturb the normal PLAYBACK picture. To clean the VIDEO HEAD, hold a VIDEO HEAD cleaning cloth dampened with alcohol against the DRUM and slowly turn the DRUM counter-clockwise.

Note : Do not directly touch the HEADS installed to the UPPER DRUM ASSY. The HEADS are very hard but brittle to shock (especially to shock in the vertical direction) and easily breakable.

Never apply force to it in the vertical direction.

2. Allow the residual alcohol to dry thoroughly before running a tape. The residual alcohol on the HEADS may damage the tape if not dried completely.




1-2. Tape Running System

Clean the following Parts of the Tape Running System.

1. TENSION PIN
 2. F/E HEAD
 3. SLANT POLE (SP)
 4. SLANT POLE (TU)
 5. A/C HEAD
 6. GUIDE POLE (TU)
 7. PINCH ROLLER
 8. GUIDE PIN (TU)
 9. GUIDE ROLLER (SP)
 10. UPPER / LOWER DRUM ASSY
 11. GUIDE ROLLER (TU)
 12. CAPSTAN SHAFT
 13. IMPEDANCE UNIT (SP)
1. Clean the Tape Running System, using a piece of gauze dampened with alcohol, except for the GUIDE ROLLER (SP), GUIDE ROLLER (TU), and PINCH ROLLER which require to be cleaned with a piece of dry gauze.
 2. Allow the residual alcohol to dry thoroughly before running the tape. The residual alcohol on the SYSTEM may damage the tape if not dried completely.

1-3. REEL DISK Drive System

1. Clean the BRAKE side and REEL BELT of the REEL DISK Drive System.
2. Clean the REEL DISK Drive System, using a piece of gauze dampened with alcohol, except for the REEL BELT which requires cleaning with a piece of dry gauze.
3. Allow the residual alcohol to dry thoroughly before operation.



2. Replacement of Major Parts

2-1. CLEANING ARM, FELT RING


SET POSITION : Normal

(Removal)

1. Release the two catches (a) of the CLEANING ARM shown in the Fig. 2-1 to remove the CLEANING ARM.
2. Release the two catches (b) of the CLEANING ARM shown in the Fig. 2-1 to remove the FELT RING.

(Installation)

1. Install the FELT RING shown in the Fig. 2-1 to the CLEANING ARM.
2. Install the CLEANING ARM shown in the Fig. 2-1.



2-2. STAY PLATE


SET POSITION : Normal

(Removal)

1. Remove the two screws (a) fastening the STAY PLATE shown in the Fig. 2-2 to remove the STAY PLATE.

(Installation)

1. Install the STAY PLATE shown in the Fig. 2-2.



2-3. BOTTOM ASSY

SET POSITION : Normal

Remove the following part before replacing the BOTTOM ASSY. Refer to the corresponding item to install it.

- STAY PLATE (Item 2-2)

(Removal)

1. Move the WORM WHEEL in the Fig. 2-3-1 in the direction shown by the arrow (A). And match the Boss (a) of the BOTTOM ASSY with the Hole in the MAIN PLATE ASSY.
2. Lift the BOTTOM ASSY in the Fig. 2-3-1 in the direction shown by the arrow (B) and pull it out in the direction shown by the arrow (C).

(Installation)

1. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the Grooves of the MAIN PLATE ASSY shown in the Fig. 2-3-2.
2. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the Bosses of the BOTTOM ASSY shown in the Fig. 2-3-2.
3. Rotate the WORM WHEEL shown in the Fig. 2-3-1 so that the ARM (SP) stands vertically.
4. Insert the Boss (b) of the BOTTOM ASSY shown in the Fig. 2-3-2 in the Upper Groove of the MAIN PLATE and the Boss (c) in the Lower Groove.
5. Insert the Boss (d) of the BOTTOM ASSY to the Upper Groove through the Hole in the MAIN PLATE ASSY shown in the Fig. 2-3-1 and the Boss (e) to the Lower Groove through the slot in the ARM (SP).




Fig. 2-3-1




Fig. 2-3-2

2-4. INSERT GUIDE (TU)

SET POSITION : Normal

Remove the following parts before replacing the INSERT GUIDE (TU). Refer to the corresponding items to install them.


- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)

(Removal)

1. Remove the screw (a) fastening the INSERT GUIDE (TU) shown in the Fig. 2-4 to remove the INSERT GUIDE (TU).

(Installation)

1. Install the INSERT GUIDE (TU) shown in the Fig. 2-4.



2-5. INSERT GUIDE (SP)

SET POSITION : Normal

Remove the following parts before replacing the INSERT GUIDE (SP). Refer to the corresponding items to install them.


- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)

(Removal)

1. Remove the screw (a) fastening the INSERT GUIDE (SP) shown in the Fig. 2-5 to remove the INSERT GUIDE (SP).

(Installation)

1. Install the INSERT GUIDE (SP) shown in the Fig. 2-5.



2-6. REC HOLDER, REC LEVER, REC SPRING

SET POSITION : Upside down

(Removal)

1. Remove the screw (a) fastening the REC HOLDER shown in the Fig. 2-6 to remove the REC HOLDER.
2. Release the REC SPRING shown in the Fig. 2-6 from the catch (b) of the REC HOLDER to remove the REC LEVER.
3. Release the two catches (c) of the REC LEVER shown in the Fig. 2-6 to remove the REC SPRING.

(Installation)

1. Install the REC SPRING shown in the Fig. 2-6 to the REC LEVER and hook the REC SPRING to the catches (c).
2. Install the REC LEVER shown in the Fig. 2-6 to the REC HOLDER.
3. Hook the REC SPRING shown in the Fig. 2-6 to the catch (b).
4. Install the REC HOLDER shown in the Fig. 2-6.




Fig. 2-6

2-7. F/L ARM ASSY, F/L BEARING

SET POSITION : Normal

Remove the following parts before replacing the F/L ARM ASSY, F/L BEARING. Refer to the corresponding items to install them.

- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)
- INSERT GUIDE (TU) (Item 2-4)
- INSERT GUIDE (SP) (Item 2-5)
- REC HOLDER (Item 2-5)

(Removal)

1. Release the catch (a) of the F/L BEARING shown in the Fig. 2-7 and pull out the F/L ARM ASSY in the direction shown by the arrow (A).

Note : Do not pull the F/L ARM by force because it may break the catch (a) of the F/L BEARING.

2. Release the catch (b) of the F/L BEARING shown in the Fig. 2-7 and rotate the F/L BEARING by 90 degrees to remove it.

(Installation)

1. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the Groove of the MAIN PLATE ASSY shown in the Fig. 2-7.
2. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the Boss of the ARM (SP) shown in the Fig. 2-7.
3. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the Bosses of the ARM (TU) shown in the Fig. 2-7.
4. Install the F/L BEARING shown in the Fig. 2-7.
5. Insert the Boss (c) of the F/L ARM ASSY shown in the Fig. 2-7 into the Groove (d) of the MAIN PLATE ASSY to install the F/L ARM ASSY.




Fig. 2-7

2-8. A/C HEAD UNIT

SET POSITION : Normal

(Removal)

1. Remove the LEAD CONNECTOR of the A/C HEAD UNIT shown in the Fig. 2-8.
2. Remove the two screws (a) fastening the A/C HEAD UNIT shown in the Fig. 2-8 to remove the A/C HEAD UNIT.

(Installation)

1. Install the A/C HEAD UNIT shown in the Fig. 2-8.

Note : Never touch the Head of the A/C HEAD UNIT shown in the Fig. 2-8. Clean the dirt on the Head with alcohol if necessary.

2. Install the LEAD CONNECTOR of the A/C HEAD UNIT shown in the Fig. 2-8.
3. Perform the Item 3-3. "A/C HEAD Adjustment" and Item 3-4. "Phase Adjustment" of the "Interchangeability Adjustment of the Mechanism".




Fig. 2-8

2-9. F/E HEAD

SET POSITION : Normal

(Removal)

1. Lift the F/E HEAD shown in the Fig. 2-9-1 in the direction by the arrow (A) to remove it.

Note : Be sure to replace the removed F/E HEAD with a new one.

(Installation)

1. Install the F/E HEAD shown in the Fig. 2-9-1.

Note : Never touch the Head shown in the Fig. 2-9-2. Clean it with alcohol if necessary.




Fig. 2-9-1




Fig. 2-9-2

2-10. SENSOR COVER (TU)

SET POSITION : Normal

(Removal)

1. Release the catch (a) of the SENSOR COVER (TU) shown in the Fig. 2-10 to remove the SENSOR COVER (TU).

(Installation)

1. Install the SENSOR COVER (TU) shown in the Fig. 2-10.




Fig. 2-10

2-11. SENSOR COVER (SP)

SET POSITION : Normal

(Removal)

1. Remove the catch (a) of the SENSOR COVER (SP) shown in the Fig. 2-11 to remove the SENSOR COVER (SP).

(Installation)

1. Install the SENSOR COVER (SP) shown in the Fig. 2-11.




Fig. 2-11

2-12. REVERSE ASSY (TU), REVERSE ASSY (SP)

SET POSITION : Upside down

(Removal)

1. Release the two catches (a) of the REVERSE ASSY (TU) shown in the Fig. 2-12 to remove the REVERSE ASSY (TU).
2. Release the two catches (b) of the REVERSE ASSY (SP) shown in the Fig. 2-12 to remove the REVERSE ASSY (SP).

(Installation)

1. Clean the dirt on the transparent part of the REVERSE ASSY (TU) with a VIDEO HEAD cleaning cloth.

Note : Never use solvent such as alcohol to clean the REVERSE ASSY (TU).

2. Install the REVERSE ASSY (TU) shown in the Fig. 2-12.

3. Clean the dirt on the transparent part of the REVERSE ASSY (SP) with a VIDEO HEAD cleaning cloth.

Note : Never use solvent such as alcohol to clean the REVERSE HEAD (SP).

4. Install the REVERSE ASSY (SP) shown in the Fig. 2-12.




Fig. 2-12

2-13. MODE POSITION UNIT

SET POSITION: Upside down

(Removal)

1. Release the two catches (a, b) of the MODE POSITION UNIT shown in the Fig. 2-13 to remove the MODE POSITION UNIT.

(Installation)

1. Install the catch (b) of the MODE POSITION UNIT shown in the Fig. 2-13.
2. Install the catch (a) of the MODE POSITION UNIT shown in the Fig. 2-13.




Fig. 2-13

2-14. REEL BELT, PULLEY BUSH, THRUST WASHER, BELT PULLEY, SHIFT SLIDER, PULLEY GEAR ASSY, SLIP GEAR, SLIP SPRING, SLIP WASHER, THRUST WASHER, SLIP ADJUSTER, IDLER UNIT

SET POSITION : Upside down

(Removal)

1. Remove the REEL BELT shown in the Fig. 2-14-1.
2. Move the SHIFT SLIDER in the Fig. 2-14-1 in the direction shown of the arrow (A) to remove the SHIFT SLIDER from the SHIFT LEVER.
3. Release the two catches (a) of the PULLEY BUSH shown in the Fig. 2-14-1 to remove the PULLEY BUSH.

Note : Be sure to replace the removed PULLEY BUSH with a new one.

4. Remove the units from the THRUST WASHER to IDLER UNIT shown in the Fig. 2-14-1.

(Installation)

Note : Be careful so that GREASE and OIL does not adhere on the Felt Side of the PULLEY GEAR ASSY or the Grooved Side of the SLIP GEAR shown in the Fig. 2-14-4.

1. Apply OIL (FLOIL 948P) [859D154O20] to the SHAFT for the IDLER UNIT shown in the Fig. 2-14-1.
2. Apply GREASE (PG-641) [859D055O30] to the parts on the IDLER UNIT specified in the Fig. 2-14-1.
3. Apply GREASE (MULTEMP AC-DM) [859D055O90] to the parts on the MAIN PLATE ASSY specified in the Fig. 2-14-1.
4. Apply GREASE (PG-641) [859D055O30] to the parts on the new SHIFT SLIDER specified in the Fig. 2-14-2.
5. Apply GREASE (PG-641) [859D055O30] to the parts on the new SLIP ADJUSTER specified in the Fig. 2-14-2.
6. Apply GREASE (PG-641) [859D055O30] to the parts on the new BELT PULLEY specified in the Fig. 2-14-3.
7. Install the IDLER UNIT shown in the Fig. 2-14-1.
8. Install the SLIP ADJUSTER shown in the Fig. 2-14-3, matching the Lug of the SLIP ADJUSTER with the Center Notch of the IDLER UNIT.




Fig. 2-14-1




Fig. 2-14-2

9. Install the units from the SLIP WASHER to REEL BELT shown in the Fig. 2-14-1.




Note1 : Be sure to replace the removed PULLEY BUSH with a new one.

Note2 : Attach the SLIP SPRING with its straight end facing the SLIP GEAR side.

Note3 : Attach the SLIP WASHER with its position set as shown in the Fig. 2-14-5.

Note4 : Apply GREASE (PG-641) [859D055O30] to the part on the SLIP WASHER specified in the Fig. 2-14-5.

10. Install the SHIFT SLIDER to the SHIFT LEVER shown in the Fig. 2-14-1.



2-15. CAPSTAN BRAKE SPRING, CAPSTAN BRAKE ASSY

SET POSITION : Upside down

(Removal)

1. Remove the CAPSTAN BRAKE SPRING shown in the Fig. 2-15.
2. Remove the catch (a) of the CAPSTAN BRAKE ASSY shown in the Fig. 2-15 to remove the CAPSTAN BRAKE ASSY.

(Installation)

1. Install the CAPSTAN BRAKE ASSY shown in the Fig. 2-15.
2. Install the CAPSTAN BRAKE SPRING shown in the Fig. 2-15.




Fig. 2-15

2-16.FC HOLDER, MOTOR HOLDER, LOADING WORM, LOADING MOTOR ASSY, WORM WHEEL

SET POSITION : Normal

(Removal)

1. Release the two catches (a) of the FC HOLDER shown in the Fig. 2-16-1 to remove the FC HOLDER.
2. Remove the two screws (b) fastening the MOTOR HOLDER shown in the Fig. 2-16-1 to remove the MOTOR HOLDER.
3. Remove the two screws (c) fastening the LOADING MOTOR ASSY shown in the Fig. 2-16-1 to remove the LOADING MOTOR ASSY and LOADING WORM.
4. Remove the WORM WHEEL.

(Installation)

1. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the LOADING WORM shown in the Fig. 2-16-2.
2. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the WORM WHEEL shown in the Fig. 2-16-2.
3. Install the WORM WHEEL.
4. Install the LOADING WORM, LOADING MOTOR ASSY to the MOTOR HOLDER.

Note : Tighten the screw (c) shown in the Fig. 2-16-1 after putting the LUG TERMINAL on the screw.

5. Install the MOTOR HOLDER.
6. Install the FC HOLDER.





Fig. 2-16-1



Apply GREASE (MULTEMP AC-DM) to the parts ● .

Fig. 2-16-2

2-17. PINCH ARM CAP, PINCH ASSY

SET POSITION : Normal

(Removal)

1. Release the two catches (a) of the PINCH ARM CAP shown in the Fig. 2-17 to remove the PINCH ARM CAP.
2. Remove the PINCH ASSY shown in the Fig. 2-17.

(Installation)

1. Insert Part (A) of the PINCH ASSY shown in the Fig. 2-17 in the most external groove of the MAIN CAM.
2. Install the PINCH ARM CAP matching the Part (B) of the PINCH ARM CAP with the Rib of the MAIN PLATE ASSY.




Fig. 2-17

2-18. F/L PLATE, DOOR ARM

SET POSITION : Normal

Remove the following parts before replacing the F/L PLATE, DOOR ARM. Refer to the corresponding items to install them.

- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)
- SENSOR COVER (TU) (Item 2-10)
- MOTOR HOLDER (Item 2-16)
- PINCH ARM CAP (Item 2-17)
- PINCH ASSY (Item 2-17)

(Removal)

1. Slightly lift the back of the F/L PLATE (MAIN CAM side) shown in the Fig. 2-18-1 to remove the F/L PLATE.
2. Remove the DOOR ARM.




Fig. 2-18-1

(Installation)

1. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the points on the new F/L PLATE specified in the Fig. 2-18-1.
2. Apply GREASE (MOLYKOTE G PASTE) [859D055O50] to the points on the new F/L PLATE specified in the Fig. 2-18-1.
3. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the points on the MAIN PLATE ASSY specified in the Fig. 2-18-1.
4. Install the DOOR ARM.
5. Match the Hole in the MAIN CAM with the Hole in the MAIN PLATE ASSY shown in the Fig. 2-18-2.
6. Install the F/L PLATE shown in the Fig. 2-18-1 from the front side (ARM (TU) side).
7. Insert the Boss of the F/L PLATE shown in the Fig. 2-18-2 into the Groove of the MAIN CAM.




Fig. 2-18-2

2-19. BRAKE CAM PLATE

SET POSITION : Normal

Remove the following parts before replacing the BRAKE CAM PLATE. Refer to the corresponding items to install them.

- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)
- MOTOR HOLDER (Item 2-16)
- PINCH ARM CAP (Item 2-17)
- PINCH ASSY (Item 2-17)

(Removal)

1. Rotate the MAIN CAM in the Fig. 2-19-1 in the direction shown by the arrow (A). And move the BRAKE CAM PLATE so that the three catches (a) of the MAIN PLATE ASSY can be released.
2. Remove the BRAKE CAM PLATE.




Fig. 2-19-1

(Installation)

1. Apply GREASE (MOLYKOTE G PASTE) [859D055O50] to the points on the BRAKE CAM PLATE specified in the Fig. 2-19-2.
2. Hook the BRAKE SPRING shown in the Fig. 2-19-3 to the catch of the BRAKE (TU).
3. Install the BRAKE CAM PLATE, inserting the six Guide Pins (b) shown in the Fig. 2-19-1 into the slits of the BRAKE CAM PLATE.
4. Move the BRAKE SPRING in the Fig. 2-19-3 in the direction of the arrow (C) to release the Catch of the BRAKE (TU) and insert the BRAKE SPRING under the Catch.
5. Rotate the MAIN CAM shown in the Fig. 2-19-1 in the direction shown of the arrow (B). And move the BRAKE CAM PLATE to hook it to the three catches (a) of the MAIN PLATE ASSY.




Fig. 2-19-2

2-20. GUIDE LAMP

SET POSITION : Normal

Remove the following parts before replacing the GUIDE LAMP. Refer to the corresponding items to install them.

- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)
- MOTOR HOLDER (Item 2-16)
- PINCH ARM CAP (Item 2-17)
- PINCH ASSY (Item 2-17)
- BRAKE CAM PLATE (Item 2-19)



(Removal)

1. Release the catch (Ⓐ) of the GUIDE LAMP shown in the Fig. 2-20.
2. Rotate the GUIDE LAMP in the direction shown by the arrow Ⓐ (counterclockwise, when viewed from the bottom) to match the longest slit (Ⓒ) of the MAIN PLATE ASSY with the longest arm (Ⓑ) of the GUIDE LAMP shown in the Fig. 2-20. Pull it out downward to remove it.

(Installation)

1. Clean the dirt on the GUIDE LAMP with a VIDEO HEAD cleaning cloth.
- Note:** Never use solvent such as alcohol to clean the GUIDE LAMP.
2. Insert the GUIDE LAMP in the Fig. 2-20, matching the longest arm (Ⓑ) of the GUIDE LAMP with the longest slit (Ⓒ) of the MAIN PLATE ASSY.
 3. Rotate the GUIDE LAMP in the direction shown by the arrow Ⓑ (clockwise, when viewed from the bottom) to match the arm (Ⓐ) of the GUIDE LAMP shown in the Fig. 2-20 with the longest slit (Ⓒ) of the MAIN PLATE ASSY.

Note : Clean the dirt on the GUIDE LAMP with a VIDEO HEAD cleaning cloth if necessary.



2-21.MAIN CAM, GUIDE ARM (TU), BRAKE LEVER, LB PIN

SET POSITION : Normal

Remove the following parts before replacing the MAIN CAM, GUIDE ARM (TU), BRAKE LEVER. Refer to the corresponding items to install them.

- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)
- SENSOR COVER (TU) (Item 2-10)
- MOTOR HOLDER (Item 2-16)
- WORM WHEEL (Item 2-16)
- PINCH ARM CAP (Item 2-17)
- PINCH ASSY (Item 2-17)
- F/L PLATE (Item 2-18)

(Removal)

1. Remove the MAIN CAM shown in the Fig. 2-21-1.
2. Remove the GUIDE ARM (TU) shown in the Fig. 2-21-1.
3. Move the BRAKE LEVER in the Fig. 2-21-1 in the direction shown by the arrow (A) and release the catch (a) to remove the BRAKE LEVER.
4. Remove the LB PIN shown in the Fig. 2-21-1.

(Installation)

1. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the points on the new GUIDE ARM (TU) specified in the Fig. 2-21-1.
2. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the points on the MAIN PLATE ASSY specified in the Fig. 2-21-1.
3. Install the GUIDE ARM (TU), matching the Hole in the GUIDE ARM (TU) shown in the Fig. 2-21-2 with the Hole in the MAIN PLATE ASSY.

Note : Install the GUIDE ARM (TU) so that the Part specified with the Oblique Lines of the GUIDE ARM (TU) will be under the SHAFT FLANGE of the PINCH ASSY.

4. Install the BRAKE LEVER shown in the Fig. 2-21-2 so that the Hole in the BRAKE LEVER overlaps the Hole in the MAIN PLATE ASSY.
5. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the points on the new MAIN CAM specified in the Fig. 2-21-3.
6. Install the MAIN CAM so that the Hole in the MAIN CAM shown in the Fig. 2-21-2 overlaps with the Hole in the MAIN PLATE ASSY.

Note : Install the MAIN CAM inserting the Pins of the CAPSTAN BRAKE ASSY, GUIDE ARM (TU), BRAKE LEVER into the Grooves on the back of the MAIN CAM for sure.
Be careful that GREASE does not adhere on the Wall when applying GREASE to the most external circle on the back of the MAIN CAM (4 parts) shown in the Fig. 2-21-3.




Fig. 2-21-1




Fig. 2-21-2




Fig. 2-21-3

2-22. L/D LOCK LEVER

SET POSITION : Normal

Remove the following parts before replacing the L/D LOCK LEVER. Refer to the corresponding items to install them.


- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)
- MOTOR HOLDER (Item 2-16)
- PINCH ARM CAP (Item 2-17)
- PINCH ASSY (Item 2-17)
- BRAKE CAM PLATE (Item 2-19)

(Removal)

1. Remove the L/D LOCK LEVER shown in the Fig. 2-22.

(Installation)

1. Install the L/D LOCK LEVER shown in Fig. 2-22.



2-23. BRAKE BELT (SP), BELT HOLDER

SET POSITION : Normal

Remove the following parts before replacing the BRAKE BELT (SP), BELT HOLDER. Refer to the corresponding items to install them.

- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)


(Removal)

1. Lift the BRAKE BELT (SP) shown in the Fig. 2-23 to remove it from the REEL DISK (SP side).
2. Release the BRAKE BELT (SP) from the catch (a) of the BELT LEVER shown in the Fig. 2-23.
3. Release the two catches (b) of the BELT HOLDER shown in the Fig. 2-23 and separate the BELT HOLDER from the BRAKE BELT (SP).
4. Release the catch (c) of the BELT HOLDER shown in the Fig. 2-23 to remove the BRAKE BELT (SP).

(Installation)

Note : Install the BRAKE BELT (SP) so that its Felt Side touches the REEL DISK (SP side). GREASE applied to the BRAKE CAM PLATE and MAIN PLATE ASSY should not adhere on the Felt Side of the BRAKE BELT (SP).

1. Install the BRAKE BELT (SP) shown in the Fig. 2-23 to the catch (c) of the BELT HOLDER.
2. Install the BELT HOLDER shown in the Fig. 2-23.
3. Install the BRAKE BELT (SP) shown in the Fig. 2-23 to the catch (a) of the BELT LEVER.
4. Hook the BRAKE BELT (SP) shown in the Fig. 2-23 to the REEL DISK (SP side).



2-24. BELT LEVER, BELT ADJUSTER

SET POSITION : Normal

Remove the following parts before replacing the BELT LEVER, BELT ADJUSTER. Refer to the corresponding items to install them.

- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)
- MOTOR HOLDER (Item 2-16)
- PINCH ARM CAP (Item 2-17)
- PINCH ASSY (Item 2-17)
- BRAKE CAM PLATE (Item 2-19)
- BRAKE BELT (SP) (Item 2-23)
- BELT HOLDER (Item 2-23)

(Removal)

1. Release the catch (a) of the BELT LEVER shown in the Fig. 2-24 to remove the BELT LEVER.
2. Remove the BELT ADJUSTER shown in the Fig. 2-24.

(Installation)

1. Install the BELT ADJUSTER shown in the Fig. 2-24.
2. Install the BELT LEVER shown in the Fig. 2-24.




Fig. 2-24

2-25 TENSION ARM, TENSION LEVER, TENSION SPRING, TENS AXIS HOLDER, REEL DISK (SP side)

SET POSITION : Normal

Remove the following parts before performing this item. Refer to the corresponding items to install them.

- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)
- MOTOR HOLDER (Item 2-16)
- PINCH ARM CAP (Item 2-17)
- PINCH ASSY (Item 2-17)
- BRAKE CAM PLATE (Item 2-19)
- BRAKE BELT (SP) (Item 2-23)
- BELT HOLDER (Item 2-23)
- BELT LEVER (Item 2-24)

(Removal)

1. Remove the TENSION SPRING shown in the Fig. 2-25.
2. Release the catch (a) of the TENS AXIS HOLDER shown in the Fig. 2-25 to remove the TENSION ARM.
3. Remove the TENSION LEVER shown in the Fig. 2-25.
4. Release the catch (b) of the TENS AXIS HOLDER shown in the Fig. 2-25. Move the TENS AXIS HOLDER in the direction shown by the arrow A to remove it.
5. Remove the REEL DISK (SP side).




Fig. 2-25

(Installation)

1. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the parts on the MAIN PLATE ASSY specified in the Fig. 2-25.
2. Install the REEL DISK (SP side).
3. Install the TENS AXIS HOLDER.

Note : Install the TENS AXIS HOLDER so that the catch (a) for the TENSION ARM will be positioned on the front (F/L ARM ASSY side).

4. Install the TENSION LEVER.
5. Install the TENSION ARM.
6. Install the TENSION SPRING.

Note : Install the longer hook of the TENSION SPRING to the TENSION ARM.

2-26. BRAKE BELT (TU)

SET POSITION : Normal

Remove the following parts before replacing the BRAKE BELT. Refer to the corresponding items to install them.

- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)


(Removal)

1. Lift the BRAKE BELT (TU) shown in the Fig. 2-26 to remove it from the REEL DISK (TU side).
2. Release the two catches (a) of the BRAKE (TU) shown in the Fig. 2-26 to remove the BRAKE BELT (TU).

(Installation)

1. Install the BRAKE BELT (TU) shown in the Fig. 2-26 to the BRAKE (TU).
2. Hook the BRAKE BELT (TU) shown in the Fig. 2-26 to the REEL DISK (TU side).

Note : Install the BRAKE BELT (TU) so that its Felt Side touches the REEL DISK (TU side).



2-27. BRAKE (TU), REEL DISK (TU side)


SET POSITION : Normal

Remove the following parts before replacing the BRAKE (TU), REEL DISK (TU side). Refer to the corresponding items to install them.

- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)
- MOTOR HOLDER (Item 2-16)
- PINCH ARM CAP (Item 2-17)
- PINCH ASSY (Item 2-17)
- BRAKE CAM PLATE (Item 2-19)

(Removal)

1. Move the BRAKE (TU) in the Fig. 2-27 in the direction shown by the arrow (A) to remove it.
2. Remove the BRAKE BELT (TU) from the BRAKE (TU).
3. Remove the REEL DISK (TU).



(Installation)

(Installation)

Note : Install the BRAKE BELT (TU) so that its Felt Side touches the REEL DISK (TU side).

The GREASE applied to the BRAKE CAM PLATE and the MAIN PLATE ASSY should not adhere on the Felt Side of the BRAKE BELT (SP).

1. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the parts on the MAIN PLATE ASSY specified in the Fig. 2-27.
2. Install the REEL DISK (TU side).
3. Install the BRAKE BELT (TU) to the BRAKE (TU).
4. Install the BRAKE (TU).
5. Hook the BRAKE BELT (TU) to the REEL DISK (TU side).

2-28. SHIFT LEVER

SET POSITION : Normal

Remove the following parts before replacing the SHIFT LEVER. Refer to the corresponding items to install them.


- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)
- MOTOR HOLDER (Item 2-16)
- PINCH ARM CAP (Item 2-17)
- PINCH ASSY (Item 2-17)
- BRAKE CAM PLATE (Item 2-19)
- BRAKE (TU) (Item 2-27)
- REEL DISK (TU side) (Item 2-27)

(Removal)

1. Move the SHIFT SLIDER in the Fig. 2-28 in the direction shown by the arrow (A) to release it from the SHIFT LEVER.
2. Move the SHIFT LEVER in the Fig. 2-28 in the direction shown by the arrow (B) to remove it.

(Installation)

1. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the parts on the new SHIFT LEVER specified in the Fig. 2-28.
2. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the parts on the MAIN PLATE ASSY specified in the Fig. 2-28.
3. Install the SHIFT LEVER so that its Part (a) shown in the Fig. 2-28 will be positioned under the MAIN PLATE ASSY.
4. Install the SHIFT SLIDER to the SHIFT LEVER.



2-29.CHARGE SPRING, SWING LEVER, CHARGE ASSY

SET POSITION : Normal

Remove the following parts before replacing the CHARGE SPRING, SWING LEVER, CHARGE ASSY. Refer to the corresponding items to install them.

- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)
- MOTOR HOLDER (Item 2-16)
- PINCH ARM CAP (Item 2-17)
- PINCH ASSY (Item 2-17)
- BRAKE CAM PLATE (Item 2-19)

(Removal)

1. Remove the CHARGE SPRING shown in the Fig. 2-29 from the SWING LEVER.
2. Remove the SWING LEVER shown in the Fig. 2-29.
3. Release the Part ① of the CHARGE ASSY shown in the Fig. 2-29 from the Part ② of the MAIN PLATE ASSY to remove the CHARGE ASSY.

(Installation)

1. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the parts on the MAIN PLATE ASSY specified in the Fig. 2-29.
2. Install the CHARGE ASSY.
3. Install the SWING LEVER inserting the Part ③ of the SWING LEVER in the Fig. 2-29 into the groove in the MAIN PLATE ASSY.
4. Install the CHARGE SPRING to the SWING LEVER.




Fig. 2-29

2-30.LOADING ARM ASSY (SP), LOADING ARM ASSY (TU)

SET POSITION : Upside down

(Removal)

1. Release the catch (①) of the LOADING ARM ASSY (SP) shown in the Fig. 2-30-1 to remove the LOADING ARM ASSY (SP).

Note : Be sure to replace the removed LOADING ARM ASSY (SP) with a new one.

2. Remove the screw (②) fastening the SPACER PLATE shown in the Fig. 2-30-1 to remove the SPACER PLATE.
3. Remove the LOADING ARM ASSY (TU) shown in the Fig. 2-30-1.






Fig. 2-30-1

(Installation)

1. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the parts on the MAIN PLATE ASSY specified in the Fig. 2-30-1.
2. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the parts on the LOADING ARM ASSY (TU) specified in the Fig. 2-30-2.
3. Install the LOADING ARM ASSY (SP) and LOADING ARM ASSY (TU) so that the Marks on the both UNITS face each other, as shown in the Fig. 2-30-3.

Note : Be sure to replace the removed LOADING ARM ASSY (SP) with a new one.



2-31. A/L LEVER


SET POSITION: Upside down

Remove the following parts before replacing the A/L LEVER. Refer to the corresponding items to install them.

- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)
- MOTOR HOLDER (Item 2-16)
- PINCH ARM CAP (Item 2-17)
- PINCH ASSY (Item 2-17)
- BRAKE CAM PLATE (Item 2-19)
- LOADING ARM ASSY (SP) (Item 2-30)
- LOADING ARM ASSY (TU) (Item 2-30)

(Removal)

1. Remove the CUT WASHER and WASHER shown in the Fig. 2-31-1. Then, remove the A/L LEVER.



(Installation)




Note : Install the LOADING ARM ASSY (TU) and LOADING ARM ASSY (SP), according to the following procedure, after installing the A/L LEVER.

1. Apply GREASE (MOLYKOTE G PASTE) [859D055O50] to the parts on the MAIN PLATE ASSY specified in the Fig. 2-31-1.
2. Apply GREASE (MOLYKOTE G PASTE) [859D055O50] to the parts on the A/L LEVER specified in the Fig. 2-31-2.
3. Install the A/L LEVER so that the Mark on the A/L LEVER faces to the FLANGE of the LOADING ARM ASSY (SP), as shown in the Fig. 2-31-3.

Note : The Part specified with Oblique Lines on the A/L LEVER should be under the FLANGE of the LOADING ARM ASSY (SP).

4. Install the LOADING ARM ASSY (TU) so that the Marks on the LOADING ARM ASSY (TU) and on the A/L LEVER will face each other, as shown in the Fig. 2-31-4.
5. Install the LOADING ARM ASSY (SP) so that the ▲ mark on the LOADING ARM ASSY (SP) and the Reinforcement Rib of the LOADING ARM ASSY (TU) will face each other, as shown in the Fig. 2-31-4.

Note : Be sure to replace the removed LOADING ARM ASSY (SP) with a new one.



2-32. TAPE GUIDE ASSY (SP), TAPE GUIDE ASSY (TU)

SET POSITION : Normal

Remove the following parts before replacing the TAPE GUIDE ASSY (SP), (TU). Refer to the corresponding items to install them.

- STAY PLATE (Item 2-2)
- BOTTOM ASSY (Item 2-3)
- MOTOR HOLDER (Item 2-16)
- PINCH ARM CAP (Item 2-17)
- PINCH ASSY (Item 2-17)
- BRAKE CAM PLATE (Item 2-19)
- BRAKE BELT (SP) (Item 2-23)
- BELT HOLDER (Item 2-23)
- BELT LEVER (Item 2-24)
- TENSION ARM (Item 2-25)

(Removal)

1. Loosen the TAPE GUIDE ASSY (SP) shown in the Fig. 2-32-1 (turn it fully in the Unloading direction) to remove it.
2. Loosen the TAPE GUIDE ASSY (TU) shown in the Fig. 2-32-1 (turn it fully in the Unloading direction) to remove it.

(Installation)

1. Apply GREASE (MULTEMP AC-DM)[859D055O90] to the parts on the MAIN PLATE ASSY specified in the Fig. 2-32-2.
2. Install the TAPE GUIDE ASSY (SP) shown in the Fig. 2-32-1.
3. Install the TAPE GUIDE ASSY (TU) shown in the Fig. 2-32-1.
4. Perform the Item 3-2-1. "GUIDE ROLLER Check" to the Item 3-2-5. "Flatness Check of FM Waveform" of the "Interchangeability Adjustment of the Mechanism".




Fig. 2-32-1




Fig. 2-32-2

2-33. GUIDE ARM (SP)

SET POSITION : Normal

(Removal)

1. Release the catch (a) of the GUIDE ARM (SP) shown in the Fig. 2-33 to remove the GUIDE ARM (SP).

(Installation)

1. Install the GUIDE ARM (SP) shown in the Fig. 2-33.




Fig. 2-33

2-34. DRUM CLAMPER, DRUM ASSY

SET POSITION : Normal

(Removal)

1. Disconnect the LEAD CONNECTOR of the DRUM ASSY shown in the Fig. 2-34-1.
2. Remove the two screws (a, b) fastening the DRUM CLAMPER shown in the Fig. 2-34-1 to remove the DRUM ASSY with the DRUM CLAMPER.
3. Rotate the DRUM CLAMPER in the Fig. 2-34-2 in the direction shown by the arrow (A) to remove it from the DRUM ASSY.

(Installation)



1. Install the DRUM CLAMPER in the Fig. 2-34-2 to the DRUM ASSY by rotating it in the direction shown of the arrow (B).
2. Hook the Catch of the DRUM CLAMPER shown in the Fig. 2-34-3 to the Reference Pin.
3. Fasten the screw (b) while pushing the Part (A) in the direction shown by the arrow (C) (clockwise when viewed from the top) as shown in the Fig. 2-34-3.

Note : Confirm at this time that the Catch of the DRUM CLAMPER touches the side of the Reference Pin.

4. Fasten the screw (a) shown in the Fig. 2-34-3.

Note : Confirm at this time that the Catch of the DRUM CLAMPER touches the side of the Reference Pin.

5. Connect the LEAD CONNECTOR of the DRUM ASSY with the DRUM CLAMPER shown in the Fig. 2-34-1.
6. Connect the LEAD CONNECTOR of the DRUM ASSY shown in the Fig. 2-34-1.
7. Perform the Item "PLAYBACK Switching Point" of the "Circuit Adjustment" in this service manual.
8. Perform the Item "Interchangeability Adjustment of the Mechanism".
9. Clean the DRUM ASSY shown in the Fig. 2-34-1 with alcohol.



2-35.DRUM MOTOR STATOR, BRUSH SPRING, SPACER, ROTOR CASE, END RING, BRUSH, UPPER DRUM ASSY



SET POSITION : Normal

(Removal)

1. Disconnect the LEAD CONNECTOR of the DRUM ASSY shown in the Fig. 2-35-1.
2. Remove the two screws (a) fastening the DRUM MOTOR STATOR shown in the Fig. 2-35-1 to remove the DRUM MOTOR STATOR.
3. Remove the two screws (b) fastening the ROTOR CASE shown in the Fig. 2-35-1 to remove the ROTOR CASE.

Note : Mark on the END RING and UPPER DRUM ASSY shown in the Fig. 2-35-1 using a pen, etc. for convenience in installing them.

4. Loosen the hexagon screw (c) fastening the END RING shown in the Fig. 2-35-1 to remove the END RING.
5. Remove the BRUSH SPRING shown in the Fig. 2-35-1.
6. Remove the BRUSH shown in the Fig. 2-35-1.
7. Remove the UPPER DRUM ASSY shown in the Fig. 2-35-1.
8. Remove the SPACER shown in the Fig. 2-35-1.



(Installation)

1. Install the SPACER shown in the Fig. 2-35-1.

Note : Be sure to use the new SPACER packed with the new UPPER DRUM ASSY.

2. Install the UPPER DRUM ASSY shown in the Fig. 2-35-1.
3. Install the END RING so that the reference hole (A) of the END RING shown in the Fig. 2-35-2 will be placed in parallel with the Rear Line of the MAIN PLATE ASSY. (The reference hole (A) should be on the right when viewed from the bottom.)
4. Apply the screw-sealing agent to the hexagon screw (C) fastening the END RING shown in the Fig. 2-35-1.
5. Install the ROTOR CASE shown in the Fig. 2-35-3, matching its Holes with the three reference holes (B) of the UPPER DRUM ASSY.
6. Install the BRUSH shown in the Fig. 2-35-1.
7. Install the BRUSH SPRING shown in the Fig. 2-35-1.
8. Install the DRUM MOTOR STATOR shown in the Fig. 2-35-1.
9. Connect the LEAD CONNECTOR of the DRUM ASSY shown in the Fig. 2-35-1.
10. Perform the Item "PLAYBACK Switching Point" adjustment.
11. Perform the Item "Interchangeability Adjustment of the Mechanism".
12. Clean the DRUM ASSY with alcohol.




Fig. 2-35-2




Fig. 2-35-3

2-36. CAPSTAN MOTOR

SET POSITION : Normal

Remove the following part before replacing the CAPSTAN MOTOR. Refer to the corresponding item to install it.

- REEL BELT (Item 2-14.)

(Removal)

1. Rotate the WORM WHEEL in the Fig. 2-36-1 in the direction shown by the arrow (A) to release the Hooks of the BOTTOM ASSY from the Locks of the STAY PLATE.
2. Rotate the WORM WHEEL in the Fig. 2-36-2 in the direction shown by the arrow (A) so that the GUIDE ARM (TU) moves in the direction of arrow (B) and expose the three screws (a) fastening the CAPSTAN MOTOR.
3. Remove the three screws (a) fastening the CAPSTAN MOTOR shown in the Fig. 2-36-2 to remove the CAPSTAN MOTOR.




Fig. 2-36-1

(Installation)

1. Apply SILICON COMPOUND (SC102) [859D164O10] to the parts on the MAIN PLATE ASSY specified in the Fig. 2-36-3.
2. Install the CAPSTAN MOTOR.




Fig. 2-36-2




Fig. 2-36-3

2-37.IMPEDANCE UNIT (SP), FLYWHEEL (SP)


SET POSITION : Normal

(Removal)

1. Unfasten the two catches (a) on the IMPEDANCE UNIT (SP) shown in Fig. 2-37, and remove the FLYWHEEL (SP).
2. Remove the one screw (b) on the IMPEDANCE UNIT (SP) shown in Fig. 2-37, and remove the IMPEDANCE UNIT (SP).

(Installation)

1. Install the IMPEDANCE UNIT (SP) shown in Fig. 2-37.
2. Install the FLYWHEEL (SP) shown in Fig. 2-37.



2-38.SSW HOLDER, SSW SLIDER

SET POSITION : Upside down

To access the SSW UNIT, remove the following parts :


- STAY PLATE (Para. 2-2)
- BOTTOM ASSY (Para. 2-3)

(Removal)

1. Remove the SSW SLIDER shown in the Fig. 2-38 .
2. Unfasten the two catches (a) shown in Fig. 2-38, and remove the SSW HOLDER.

(Installation)

1. Install the SSW HOLDER shown in Fig. 2-38.
2. Install the SSW SLIDER shown in Fig. 2-38.



3. Interchangeability Adjustment of the Mechanism

Note 1 : Tracking may need to be preset during interchangeability adjustment of the mechanism. Digital tracking is preset by short circuiting TP5A and TP5B on the PCB-MAIN.

Note 2 : The adjustments are performed in the PLAYBACK mode, using the staircase signal of an alignment tape, unless otherwise specified. Connect an oscilloscope to TP2A (FM Waveform) and externally trigger from TP2H.

3-1. Adjustment of BACK TENSION and TENSION POLE's Position

Run a Blank Tape for several minutes to break in the REEL DISKS and the Tape Running System before the adjustment.

1. Play back a dummy Tape.
2. Confirm that "A", the distance between the Holes in the TENSION ARM and the MAIN PLATE ASSY shown in the Fig. 3-1-1, is $0.6 \pm 0.5\text{mm}$.
3. If "A" is not $0.6 \pm 0.5\text{mm}$, move the Hole in the BELT ADJUSTER in the Fig. 3-1-2 within the range shown by the arrow (A) to set "A" at $0.6 \pm 0.5\text{mm}$.
4. Set the BACK TENSION measuring jig (Code: 859C345O80) and play-back the tape.
5. Confirm that "A" shown in the Fig. 3-1-1 is $0.0 \pm 0.5\text{mm}$.
6. If "A" is not $0.0 \pm 0.5\text{mm}$ at step 5, repeat the adjustment from step 1.
7. Confirm that the indicated value of the BACK TENSION measuring jig is within $5.4 \pm 0.59\text{mNm}$.

Note 1 : Check the indicated value of the BACK TENSION measuring jig when the tape running condition becomes steady.

Note 2 : Replace the TENSION SPRING if the indicated value exceeds the specified value.

8. While the tape is running steadily, check visually that the vibration range of the TENSION POLE is 1mm or less. If the vibration range exceeds 1mm, replace the REEL DISK.




Fig. 3-1-1




Fig. 3-1-2

3-2. Check and Adjustment of the FM Envelope

3-2-1. GUIDE ROLLER Adjustment check



1. Play back an alignment tape (NM6KE2 : 859C339O90).
2. Preset the tracking.
3. Confirm that the FM Waveform is flat such as in (A).
4. Perform the Item 3-2-2. "Height Adjustment of GUIDE ROLLER (SP)" if the leading edge (the DRUM entry side) of the FM Waveform is not flat (Waveform (B) or (C)). Perform the Item 3-2-3. "Height Adjustment of GUIDE ROLLER (TU)" if the trailing edge (the DRUM exit side) is not flat (Waveform (D) or (E)).

3-2-2. Height Adjustment of GUIDE ROLLER (SP)

1. Loosen the height adjustment screw at the top of the GUIDE ROLLER (SP) so that the GUIDE ROLLER (SP) will rotate smoothly.
2. Observe the leading edge (DRUM entry side) of the FM Waveform. If it looks like (B), the GUIDE ROLLER may be set too low. If it looks like (C), the GUIDE ROLLER may be set too high. To adjust it, turn the height adjustment screw at the top of the GUIDE ROLLER (SP) so that the FM Waveform becomes flat such as in (A).
 - Turn the screw counter-clockwise if the position of the GUIDE ROLLER is lower than specified.
 - Turn the screw clockwise if the position of the GUIDE ROLLER is higher than specified.
3. Perform the Item 3-2-4. "Coarse Adjustment of Phase".

3-2-3. Height Adjustment of GUIDE ROLLER (TU)

1. Loosen the height adjustment screw at the top of the GUIDE ROLLER (TU) so that the GUIDE ROLLER (TU) will rotate smoothly.
2. Observe the trailing edge (DRUM exit side) of the FM Waveform. If it looks like (D), the GUIDE ROLLER may be set too low. If it looks like (E), the GUIDE ROLLER may be set too high. To adjust it, turn the height adjustment screw at the top of the GUIDE ROLLER (TU) so that the FM Waveform becomes flat as in (A).
 - Turn the screw counter-clockwise if the position of the GUIDE ROLLER is too low.
 - Turn the screw clockwise if the position of the GUIDE ROLLER is too high.
3. Perform the Item 3-2-4. "Coarse Adjustment of Phase".



3-2-4. Coarse Adjustment of Phase

1. Play back an alignment tape (NM6KE2 : 859C339O90).
2. Preset the tracking.
3. Observe the FM Waveform after performing Item 3-2-1. "GUIDE ROLLER Check".
4. If the amplitude level of the FM Waveform is low as in (F) in Fig. 3-2-4, set it at the maximum level as in (G), according to the following procedure. Loosen the Screws D and E and insert a screw driver (+) into the Hole in the MAIN PLATE ASSY (Part A). Then, move the A/C PLATE to the right and left to set the amplitude level to maximum.
5. Tighten the Screws D and E.




Fig. 3-2-3

3-2-5. Flatness Check of FM Waveform

1. Play back an alignment tape (NM6KE2 : 859C339O90).
2. Adjust the tracking and confirm that the amplitude of the FM signal remains flat.

Note : Adjust the tracking manually, according to the following procedure.

- Turn the Shuttle Ring of the product during PLAYBACK for manual tracking adjustment.
- Press the 3DSP button to switch the tracking adjustment from "Manual" to "Auto".

3. Adjust the tracking so that the amplitude level of the FM Waveform will be at the maximum. Set the oscilloscope so that the amplitude level of the FM Waveform is 5 divisions on the oscilloscope.
4. Adjust the tracking so that the peak of the FM Output Waveform is 4 divisions. Confirm that the FM Waveforms (B), (C), (D) and (E) are within the range of the specified values in the Fig. 3-2-5.
5. If the Waveforms are out of the specified values in step 4, repeat the Item 3-2. "Check and Adjustment of FM Envelope" from the beginning.




Fig. 3-2-4





Fig. 3-2-5

3-2-6. Tape Running Condition at the GUIDE ROLLERS (Check 1)

1. Play back an Alignment Tape.
[NM6KE2: 859C339O90]
2. Confirm visually that there is a space between the Tape and the Lower FLANGE of the GUIDE ROLLER (SP) and the GUIDE ROLLER (TU).
3. If there is no space in step 2, replace the TAPE GUIDE ASSY (SP) and TAPE GUIDE ASSY (TU), according to the Item 2-32. "TAPE GUIDE ASSY (SP), TAPE GUIDE ASSY (TU)".
4. Alternately load and unload the tape several times and confirm that the FM Waveform remains flat.
5. If the flatness is affected, check the position of the A/C HEAD. If it is installed incorrectly, correct it according to the Item 2-8. "A/C HEAD UNIT" and repeat Item 3-2-4. "Coarse Adjustment of Phase".



3-2-7. Tape Running Condition at the GUIDE ROLLERS (Check 2)

1. Play back an alignment tape (NM6KE2 : 859C339O90).
2. Check that the FM Waveform is quickly restored to the previous level, after lightly pressing and releasing the tops of the GUIDE ROLLER (SP) and GUIDE ROLLER (TU).
3. If the FM Waveform is not restored immediately, replace the TAPE GUIDE ASSY (SP) and TAPE GUIDE ASSY (TU) according to the Item 2-32. "TAPE GUIDE ASSY (SP), TAPE GUIDE ASSY (TU)".

3-3. A/C HEAD Adjustment

3-3-1. Slant Adjustment of A/C HEAD

1. Play back a blank tape.
2. Slowly turn the slant adjustment Screw C shown in the Fig. 3-3-1 counter-clockwise to slightly crease the bottom of the tape at the Lower FLANGE of the GUIDE POLE (TU).
3. Slowly return the slant adjustment Screw C to remove the crease.
4. Slowly turn the slant adjustment Screw C counter-clockwise again and stop just before the tape is creased.

3-3-2. Azimuth and Height Adjustment of A/C HEAD

1. If the height of the CONTROL HEAD is shifted from the specified value in the Fig. 3-3-2, adjust it with the Height Adjustment Screws A, B and C shown in the Fig. 3-3-1.
2. After adjustment with the Screws A, B or C, repeat the Item 3-3-1. "Slant Adjustment of A/C HEAD".
3. Connect the oscilloscope to the audio output terminal.
4. Play back an alignment tape (NM6KE2 : 859C339O90).
5. Turn the Azimuth Adjustment Screw B in the Fig. 3-3-1 to set the audio output level in the Fig. 3-3-1 at the maximum. After the adjustment, remove the screw driver and confirm that the audio output level is 4.6 divisions or more when the maximum audio output level is set to 5. If the audio output level is less than 4.6, repeat steps 1 ~ 5.
6. Push the A/C HEAD to the right and left (in the direction of A-A' in the Fig. 3-3-1) and release it. And confirm that the audio output level does not change. (Do not push the A/C HEAD until the audio output level is reduced to 3/4 or less of its maximum level.)
7. Confirm that changes in the audio output level are 2dB or less in the PLAYBACK mode.
8. If the change in the audio output level exceeds 2dB, repeat the Item 3-3-1. "Slant Adjustment of A/C HEAD".
9. If the above procedure steps 1 ~ 8 proves to be unsatisfactory, replace the TAPE GUIDE ASSY (SP) and the TAPE GUIDE ASSY (TU), according to the Item 2-32. "TAPE GUIDE ASSY (SP), TAPE GUIDE ASSY (TU)".




Fig. 3-3-1




Fig. 3-3-2




Fig. 3-3-3

3-4. Phase Adjustment

1. Play back an alignment tape (NM3KE6 : 859C339O50).
2. Preset the tracking.
3. Loosen the Screws D and E shown in the Fig. 3-4-1. Insert a screw driver (+) into the Hole in the MAIN PLATE ASSY (Part A) and move the A/C PLATE to the right and left to set the amplitude level of the FM Waveform to maximum.
4. Tighten the Screws D and E.
5. Play back an alignment tape [NMX : 859C568O60].
6. Confirm the Missing Portions of the FM Waveform and Audio Waveform are as shown in the Fig. 3-4-2.
7. If the Missing Portions differ from the Fig. 3-4-2, repeat the procedure 3.
8. Adjust the tracking so that the amplitude level of the FM Waveform will be at the maximum. And set the oscilloscope so that the Waveform will be 5 divisions of the oscilloscope.
9. Preset the tracking.
10. Confirm that the FM Waveform on the oscilloscope is 4.8 divisions or more.
11. If the FM Waveform is below 4.8 divisions, preset the tracking and repeat steps 3~10.
12. Push the A/C HEAD to the right and left (in the direction of A-A' in the Fig. 3-4-1) and release it. Confirm that the amplitude of the FM Waveform does not change, compared to before the A/C HEAD was shifted.
13. If the amplitude level of the FM Waveform changes, check the set position of the A/C HEAD. If the A/C HEAD is installed incorrectly, correct the position according to the Item 2-8. "A/C HEAD UNIT" and 3-3. "A/C HEAD Adjustment", and then repeat this item from the beginning.
14. Alternately load and unload the tape several times. Confirm that the amplitude of the FM Waveform does not change.

3-5. Tape wrinkle check

1. Confirm that there is no wrinkle at the lower edge of GUIDE POLE(TU) in PB/FS mode with T-160 tape beginning and ending.
2. Confirm that there is no wrinkle at the upper edge of GUIDE POLE(TU) in RS mode with T-160 tape beginning and ending.




Fig. 3-4-1




Fig. 3-4-2





Fig. 3-5

4. Servicing for Tape Jam during the Loading Process

1. Remove the tape if the mechanism part is locked due tangled tape.
2. Rotate the WORM WHEEL of the LOADING MOTOR ASSY shown in the Fig. 4 in the direction of the arrow **(A)** to eject the cassette tape.



SERVICE CAN BE EXECUTED WITH THE EE PICTURE DISPLAYED

1. Short-circuit the J483 and the GND of the DECK ASSY using the jig shown in Fig. 2.
2. Remove the DECK ASSY.
3. Connect TP5X and TP5Y with a jumper

Note1: Short-circuit the test points before turning on the power.

Note2: Short-circuit the Shield Case and the J483 using the jig shown in Fig. 2 before attaching the DECK ASSY.




Fig. 1

Jig (Part No. : 859C548010)




Fig. 2

DECK OPERATION CHECK

Check the DECK position and the operation of the Tape Running System, according to the following procedure.

1. Short-circuit TP5T and TP5Y shown in the Fig. 1.
2. Initialize the E²PROM.
3. Check the operation of the Tape Running System by pressing the FF button, REW button on the PCB-MAIN.
FF button : For forward rotation of the CAPSTAN MOTOR
REW button : For reverse rotation of the CAPSTAN MOTOR
4. Check the DECK position by pressing the CH-UP button, CH-DOWN button on the PCB-MAIN.
CH-UP button : DECK operation in the Loading direction
CH-DOWN button : DECK operation in the Unloading direction

HOW TO INITIALIZE THE E²PROM

A replacement E²PROM is not initialized before shipping, so the E²PROM must be initialized when replaced.

Initialize the E²PROM by following the steps below.

1. Press and hold the POWER button on the set for 8 seconds.
2. E²PROM initial setting is completed.

WHEN REPLACING IC5A0

When replacing IC5A0, be sure to press the RESET button after turning on the power.

ELECTRICAL ADJUSTMENTS

Perform only the alignments required. If proper equipment is not available, do not attempt an alignment.

PRE-ADJUSTMENT SETTINGS

- Set the PerfectTape™ to "MANUAL" mode.

TEST EQUIPMENT

- Miscellaneous electrical tools
- Oscilloscope (10:1 probe unless 1:1 specified.)


ALIGNMENT TAPES

- | | |
|---|---|
| • NS1.....Part No.859C339O00
Stair step, Color Bars, RF, 1kHz audio (SP) | • NM3KE6.....Part No.859C339O50
Monoscope, 3kHz audio (EP) |
| • NM6KE2.....Part No.859C339O90
Monoscope, 6kHz audio (SP) | • NMX.....Part No.859C568O60
Monoscope, 3kHz audio (SP) |
| • NC1KS.....Part No.859C339O80
Color Bars, 1kHz audio (SP) | • D-VHS (HS/STD).....Part No.859C340O00 |


LOCATIONS

PCB-MAIN (Component side)


REAR



PCB-D-IF (Component side)



PCB-HEAD AMP (Component side)




[Servo circuit] 1. Playback Switching Point	Adjustment purpose Video switch over timing during playback.
	Symptom when incorrectly adjusted Switching noise or jitter in the playback picture.

Measuring instrument and condition		VCR set up condition	
	---	Input signal	---
Test point	---	Using tape	Alignment Tape (NS1, stair step)
EXT trigger	---	VCR condition	Playback
Measurement range	----	Using Jig	----

1. Play back an Alignment Tape. (NS1, stair step)
2. Short-circuit TP5A to TP5B.
3. Push the SP / EP buttons at the same time.
(The adjustment will finish in about six seconds.)
4. The automatic adjustment will finish in about 6 seconds. A value between 55 and 75 will be displayed on the fluorescent display.
5. Open-circuit TP5A to TP5B.

PCB-MAIN (Component side)




[D-VHS signal circuit] 2. D-VHS switching point	Adjustment purpose	To adjust the timing for switching the video head during playback.
	Symptom when incorrectly adjusted	Images may not be displayed or block noise may appear.


Measuring instrument and condition		VCR set up condition	
Oscilloscope		Input signal	---
Test point	TPHSL,TPHSR	Using tape	Alignment Tape
EXT trigger	TP2H,TP3Y	VCR condition	Playback
Measurement range	DIV 10 mV TIM 50 μs	Using Jig	---

1. Playback an alignment tape (D-VHS [HS/STD] : STD part).
2. Connect TP5A and TP5B for short circuit.
3. Press the SP/EP button.
4. Connect the CH1 of the oscilloscope with TPHSL, and connect the CH2 with TP2H.
5. Trigger at the rising edge of the waveform of TP2H. Set the period from the trigger point of TPHSL to the specified value as shown in the figure below by pressing the JOG +/- button or the CH UP/DOWN button on the remote hand unit.
6. Disconnect TP5A and TP5B.
7. Playback an alignment tape (D-VHS [HS/STD] : HS part).
8. Carry out step 2 and 3.
9. Press the PLAY button to switch to display "AM" on the fluorescent display.
10. Carry out step 4 and 5.
11. Press the PLAY button to switch to display "PM" on the fluorescent display.
12. Connect the CH1 of the oscilloscope with TPHSR, and connect the CH2 with TP3Y.
13. Trigger at the rising edge of the waveform of TP3Y. Set the period from the trigger point of TPHSR to the specified value as shown in the figure below by pressing the JOG +/- button or the CH UP/DOWN button on the remote hand unit.
14. Disconnect TP5A and TP5B.


PCB-MAIN (Component side)



PCB-D-IF (Component side)




PCB-HEAD AMP (Component side)




PARTS LIST

1. CABINET ASSEMBLY




ITEM NO.	PARTS NO.	PARTS NAME	DESCRIPTION
CABINET ASSEMBLY			
1	968C050O04	TOP COVER ASSY	
2	669D221O40	SCREW	4 × 12 46LA005
3	572D385O10	F/L SPRING	
4	752C672O60	CASSETTE DOOR ASSY	
5	701B416O30	FRONT UNIT	
6	752C671O40	TIMER PANEL	
7	701C081O40	JOG SHUTTLE ASSY	
8	246C324O10	AC POWER CORD	
9	761B366O50	TERMINAL COVER	
10	761B645O20	ANTENNA COVER	
11	752C665O80	DOOR PANEL ASSY	
12	669D531O10	SCREW	2.6 × 8
13	669D229O90	SCREW	M3.0 × 4 46LA005
14	669D500O30	SCREW	3 × 10
15	669D501O10	SCREW	3 × 10

2. PACKING PARTS




A ACCESSORY

B



ITEM NO.	PARTS NO.	PARTS NAME	DESCRIPTION
PACKING PARTS			
1	831D190O30	PACKING SHEET	800X800
2	803A574O10	CUSHION	
3	802B797O10	PACKING CASE	
4	-----	D VIDEO CASSETTE	
ACCESSORY			
11	872C244O90	INSTRUCTION BOOK	
12	-----	REGISTRATION CARD	
13	831D337O10	PACKING BAG	(FOR ACCESSORY A)
14	-----	ACCESSORY BOARD	
15	939P850O10	REMOTE HAND UNIT	
16	242C938O60	CABLE	
17	243C273O40	CABLE	
18	243C274O30	Y/C CABLE	
19	-----	PACKING BAG	(FOR CABLE)
20	242P021O10	CABLE	IEEE1394
21	939P724O10	IR BLASTER	
22	-----	BATTERY	

DECK ASSEMBLY
DECK ASSEMBLY-1



DECK ASSEMBLY-1

* Settled Service Parts


ITEM	PARTS NO.	*	ADDRESS	PARTS NAME	DESCRIPTION	Qt.
A-019	669D224O90	○	G-3	SCREW	2.6 × 5	1
A-021	597D568O10		G-2	FLYWHEEL (SP)		1
A-022	948B419O01		G-1	DRUM ASSY		1
A-023	592B552O10		F-2	DRUM CLAMPER		1
A-024	594C306O10		F-3	IMPEDANCE UNIT (SP)		1
A-025	927D027O01		H-2	CLEANING ASSY		1
A-026	669D556O10	○	F-2	SCREW	2.6 × 4	1
A-027	669D556O10	○	F-2	SCREW	2.6 × 4	1
B-010	925B139O21	○	G-1	UPPER DRUM ASSY		1
B-015	925B140O01	○	G-1	LOWER DRUM ASSY		1
B-025	288P158O30	○	G-1	DRUM MOTOR		1
C-010	641B903O10	○	G-2	CLEANING ARM		1
C-011	554D104O20	○	H-2	FELT RING		1
G-012	928D472O11	○	K-2	LOADING MOTOR ASSY		1
G-015	948D088O03		D-8	F/L ARM ASSY		1
G-016	948B406O03	○	B-8	F/L BOTTOM ASSY		1
G-022	948D095O01		F-1	TENSION BELT ASSY		1
G-023	948D096O01		F-8	BRAKE ASSY (TU)		1
G-024	948D097O02	○	A-5	CHARGE ASSY		1
G-032	594C260O40	○	K-4	PINCH ASSY		1
G-033	460C007O10	○	E-7	A/C HEAD UNIT		1
G-045	621C769O20	○	I-4	MAIN CAM		1
G-047	621C783O10	○	E-4	SENSOR COVER (SP)	SUPPLY	1
G-048	621C784O10	○	G-6	SENSOR COVER (TU)	TAKE UP	1
G-049	621C794O10	○	J-3	WROM WHEEL		1
G-054	640C181O20	○	D-4	D-7 REEL DISK		2
G-062	621C789O10	○	C-6	INSERT GUIDE (SP)	SUPPLY	1
G-063	621C790O10	○	D-7	INSERT GUIDE (TU)	TAKE UP	1
G-064	641B902O10	○	K-3	PINCH ARM CAP		1
G-065	641B908O10	○	H-6	DOOR ARM		1
G-067	621C804O10		J-1	FC HOLDER		1
G-068	621C805O10		D-3	GUIDE ARM (SP)		1
G-071	592B549O10	○	B-3	STAY PLATE		1
G-072	640D852O20		B-1	B-2 SPACER		2
G-074	594C217O10	○	E-2	TENSION LEVER		1
G-075	594C218O10	○	D-1	TENSION ARM		1
G-077	594C222O10	○	I-3	BRAKE LEVER		1
G-078	594C223O10	○	I-6	F/L PLATE		1
G-079	594C224O20	○	H-2	GUIDE ARM (TU)		1
G-080	594C225O30	○	D-4	BRAKE CAM PLATE		1
G-082	594C229O10	○	E-7	SHIFT LEVER		1
G-083	594C230O10	○	C-5	SWING LEVER		1
G-084	597D866O10	○	G-7	L/D LOCK LEVER		1
G-089	622D829O10	○	I-4	LB PIN		1
G-091	572D974O10	○	D-2	TENSION SPRING		1
G-104	460D018O10	○	C-4	F/E HEAD		1
G-201	669D224O90	○	A-1	C-2 SCREW	2.6×5	6
			D-7	I-1		
			J-2			
G-203	669D476O30	○	E-7	SCREW	2.6×6	2
G-212	552C017O30	○	C-5	E-8 THRUST WASHER	2.5×6×0.13	4
H-011	621C758O10	○	J-2	LOADING WORM		1
H-012	622D788O10		J-2	COUPLING WORM		1
H-021	594C216O10		J-2	MOTOR HOLDER		1
H-031	288P090O10		J-2	LOADING MOTOR		1

* Settled Service Parts

ITEM	PARTS NO.	*	ADDRESS	PARTS NAME	DESCRIPTION	Qt.
H-051	669D173O80	○	H-2	SCREW	M3×0.5-4	2
I-011	641B913O10	○	B-7	ARM (SP)		1
I-012	641B911O20	○	C-8	ARM (TU)		1
I-021	631D823O10	○	C-7	F/L SHAFT		1
I-031	573D004O10		B-7 D-8	ARM SPRING		2
M-011	948B403O01		G-5	MAIN PLATE ASSY		1
M-012	948D084O01	○	A-3	TAPE GUIDE ASSY (SP)	SUPPLY	1
M-013	948D086O01	○	B-3	TAPE GUIDE ASSY (TU)	TAKE UP	1
M-021	594C258O01		F-3	GUIDE CATCHER (SP)	SUPPLY	1
M-022	594C259O01		H-3	GUIDE CATCHER (TU)	TAKE UP	1
M-023	622D799O10	○	B-7	F/L BEARING		1
M-025	622D820O10	○	G-3	GUIDE PIN COVER		1
M-026	621C944O10	○	G-3	GUIDE PIN COVER 2		1
M-032	622D791O10	○	D-6	BELT ADJUSTER		1
M-033	669D224O90	○	F-3 H-2	SCREW	M2.6×5	2
M-037	622D792O10	○	C-2	TENS AXIS HOLDER		1
S-011	522B061O10	○	A-3	GUIDE ROLLER (SP)	SUPPLY	1
T-011	522B061O10	○	B-3	GUIDE ROLLER (TU)	TAKE UP	1
N-011	621C759O10	○	E-1	BELT LEVER		1
N-012	622D790O10	○	D-1	BELT HOLDER		1
N-013	554D103O10	○	E-1	BRAKE BELT (SP)		1
O-011	621C760O10	○	F-8	BRAKE (TU)		1
O-021	572D975O10	○	F-8	BRAKE SPRING		1
O-031	554D103O10	○	F-8	BRAKE BELT (TU)		1
P-011	640C187O10		B-5	CHARGE BASE		1
P-012	640C188O20		B-5	CHARGE TIP		1
P-021	572D983O20		B-5	CHARGE SPRING		1

A B C D E F G H I

DECK ASSEMBLY
DECK ASSEMBLY-2



DECK ASSEMBLY-2

* Settled Service Parts

ITEM	PARTS NO.	*	ADDRESS	PARTS NAME	DESCRIPTION	Qt.
A-028	621C810O10		A-5	SSW HOLDER		2
A-029	622D837O10		A-4	SSW SLIDER		2
G-017	948D089O01	○	H-4	LOADING ARM ASSY (SP)	SUPPLY	1
G-018	948D090O01	○	G-3	LOADING ARM ASSY (TU)	TAKE UP	1
G-019	622D916O10	○	B-5	IDLER UNIT		1
G-025	948D098O03	○	B-4	PULLEY GEAR ASSY		1
G-031	622D800O10	○	E-3	MODE POSITION UNIT		1
G-034	622D801O10	○	F-5	REVERSE UNIT (SP)	SUPPLY	1
G-035	622D802O10	○	C-4	REVERSE UNIT (TU)	TAKE UP	1
G-042	621C807O10		I-6	REC HOLDER		1
G-043	621C765O10	○	C-3	LAMP GUIDE		1
G-044	621C766O20	○	H-5	REC LEVER		1
G-056	640C185O30	○	B-3	BELT PULLEY		1
G-057	640C186O10	○	B-3	SHIFT SLIDER		1
G-060	640D948O10	○	B-2	PULLEY BUSH		1
G-061	640D949O10	○	B-4	SLIP GEAR		1
G-066	640C189O20	○	B-5	SLIP ADJUSTER		1
G-081	594C228O10	○	G-4	A/L LEVER		1
G-088	594C304O10	○	G-2	SPACER PLATE		1
G-093	572D976O10	○	E-2	CAPSTAN BRAKE SPRING		1
G-094	572D977O10	○	I-6	REC SPRING		1
G-096	573D073O10	○	B-4	SLIP SPRING 2		1
G-101	521D102O10	○	B-1	REEL BELT		1
G-201	669D224O90	○	G-2	I-6 SCREW	2.6×5	2
G-211	597D997O10	○	B-4	SLIP WASHER		1
G-212	552C017O30	○	B-3	THRUST WASHER	2.5×6×0.13	1
G-214	552C022O10		F-3	CUT WASHER	4.0×8.0×0.5	1
G-215	680P140O10		F-3	WASHER		1
G-216	552C012O50		B-5	THRUST WASHER	5.6×9.5×0.2	1
M-014	948D094O01	○	F-2	CAPSTAN BRAKE ASSY		1
M-031	288P213O20	○	E-2	CAPSTAN MOTOR	F2QSB34	1
M-034	669D285O10		D-8	SCREW	M2.6×6	3

3. ELECTRICAL PARTS

SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION	SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION
INTEGRATED CIRCUITS				Q2003	260P818O30	CHIP TRANSISTOR	2SC2412K-S
IC120	275P344O30	MOS IC	M35053-051FP	Q2004	261P818O10	CHIP TRANSISTOR	2SC3932
IC150	272P583O20	IC	NJM2533M	Q2005	261P818O10	CHIP TRANSISTOR	2SC3932
IC151	272P325O40	IC	NJM2535M	Q2006	261P066O10	CHIP TRANSISTOR	2SA1037AK
IC180	263P094O50	MOS IC	BU4094BCF	Q2007	260P818O30	CHIP TRANSISTOR	2SC2412K-S
IC2A0	270P827O10	IC	JCP8017-NSA	Q2008	260P818O30	CHIP TRANSISTOR	2SC2412K-S
IC2A1	270P787O10	IC	NJM2534M	Q2009	260P818O30	CHIP TRANSISTOR	2SC2412K-S
IC2001	270P671O10	IC	AN3360SB	Q2010	261P818O10	CHIP TRANSISTOR	2SC3932
IC2002	270P671O10	IC	AN3360SB	Q2011	260P818O30	CHIP TRANSISTOR	2SC2412K-S
IC3A0	275P410O10	IC	AN3662FBP	Q2012	260P818O30	CHIP TRANSISTOR	2SC2412K-S
IC5A0	275P629O20	MOS IC	M37777MAHYYYGP	Q2013	261P066O10	CHIP TRANSISTOR	2SA1037AK
IC5A1	274P670O60	IC	CAT24WC16J-TE13	Q2014	260P818O30	CHIP TRANSISTOR	2SC2412K-S
IC5A4	272P235O10	IC	TA7291S	Q2015	261P819O10	CHIP TRANSISTOR	2SA1532-C
IC5A6	263P653O10	MOS IC	TC4053BF	Q2016	261P819O10	CHIP TRANSISTOR	2SA1532-C
IC5A7	274P760O10	MOS IC	TC4W53F	Q2017	260P844O10	CHIP TRANSISTOR	FMW1
IC5D01	275P705O10	MOS IC	M37777MFH100GP	Q2018	261P819O10	CHIP TRANSISTOR	2SA1532-C
IC5D02	275P700O20	MOS IC	SN74ACT244NSR	Q2019	261P819O10	CHIP TRANSISTOR	2SA1532-C
IC5D03	275P649O20	MOS IC	SN74LVTH541NSR	Q2020	260P844O10	CHIP TRANSISTOR	FMW1
IC6001	270P838O10	IC	NJM2520M	Q2023	261P065O30	CHIP TRANSISTOR	DTA124EKA
IC6002	270P838O10	IC	NJM2520M	Q2024	261P066O10	CHIP TRANSISTOR	2SA1037AK
IC6003	270P828O10	IC	MM1506XNRE	Q2025	260P818O30	CHIP TRANSISTOR	2SC2412K-S
IC6004	270P829O10	IC	MM1508XNRE	Q2026	260P818O30	CHIP TRANSISTOR	2SC2412K-S
IC6005	272P583O20	IC	NJM2533M	Q2027	261P818O10	CHIP TRANSISTOR	2SC3932
IC6301	275P360O10	MOS IC	M38503M4-082FP	Q2028	261P818O10	CHIP TRANSISTOR	2SC3932
IC8A0	275P345O20	IC	PT6312LQ/μPD16312GB	Q2029	261P818O10	CHIP TRANSISTOR	2SC3932
IC901	272P500O20	IC	HA17431PA	Q2031	260P818O30	CHIP TRANSISTOR	2SC2412K-S
IC902	270P771O10	IC	MA8620	Q2032	261P065O30	CHIP TRANSISTOR	DTA124EKA
TRANSISTORS				Q2034	260P818O30	CHIP TRANSISTOR	2SC2412K-S
Q100	260P818O30	CHIP TRANSISTOR	2SC2412K-S	Q2035	261P066O10	CHIP TRANSISTOR	2SA1037AK
Q102	261P066O10	CHIP TRANSISTOR	2SA1037AK	Q2036	260P818O30	CHIP TRANSISTOR	2SC2412K-S
Q122	261P066O10	CHIP TRANSISTOR	2SA1037AK	Q2037	261P067O30	CHIP TRANSISTOR	DTC124EKA
Q123	260P818O30	CHIP TRANSISTOR	2SC2412K-S	Q2038	261P065O30	CHIP TRANSISTOR	DTA124EKA
Q124	261P067O30	CHIP TRANSISTOR	DTC124EKA	Q2039	261P819O10	CHIP TRANSISTOR	2SA1532-C
Q150	260P818O30	CHIP TRANSISTOR	2SC2412K-S	Q2040	261P819O10	CHIP TRANSISTOR	2SA1532-C
Q153	261P067O30	CHIP TRANSISTOR	DTC124EKA	Q2042	260P844O10	CHIP TRANSISTOR	FMW1
Q154	261P067O30	CHIP TRANSISTOR	DTC124EKA	Q2043	261P065O30	CHIP TRANSISTOR	DTA124EKA
Q155	261P067O30	CHIP TRANSISTOR	DTC124EKA	Q2044	260P844O10	CHIP TRANSISTOR	FMW1
Q156	261P065O30	CHIP TRANSISTOR	DTA124EKA	Q2045	260P844O10	CHIP TRANSISTOR	FMW1
Q157	261P067O30	CHIP TRANSISTOR	DTC124EKA	Q2046	260P844O10	CHIP TRANSISTOR	FMW1
Q2A0	261P067O30	CHIP TRANSISTOR	DTC124EKA	Q2047	261P065O30	CHIP TRANSISTOR	DTA124EKA
Q2A2	261P067O30	CHIP TRANSISTOR	DTC124EKA	Q2048	260P562O40	TRANSISTOR	2SA952-K
Q2A3	261P067O30	CHIP TRANSISTOR	DTC124EKA	Q2049	260P562O40	TRANSISTOR	2SA952-K
Q2A5	261P066O10	CHIP TRANSISTOR	2SA1037AK	Q2050	261P067O30	CHIP TRANSISTOR	DTC124EKA
Q2A6	260P818O30	CHIP TRANSISTOR	2SC2412K-S	Q2051	261P067O30	CHIP TRANSISTOR	DTC124EKA
Q2B0	261P066O10	CHIP TRANSISTOR	2SA1037AK	Q2053	260P818O30	CHIP TRANSISTOR	2SC2412K-S
Q2B1	261P066O10	CHIP TRANSISTOR	2SA1037AK	Q2054	260P818O30	CHIP TRANSISTOR	2SC2412K-S
Q2B2	260P818O30	CHIP TRANSISTOR	2SC2412K-S	Q2055	260P818O30	CHIP TRANSISTOR	2SC2412K-S
Q2B3	261P066O10	CHIP TRANSISTOR	2SA1037AK	Q2056	260P818O30	CHIP TRANSISTOR	2SC2412K-S
Q2B9	261P067O30	CHIP TRANSISTOR	DTC124EKA	Q2057	260P818O30	CHIP TRANSISTOR	2SC2412K-S
Q2C0	260P818O30	CHIP TRANSISTOR	2SC2412K-S	Q2060	261P065O30	CHIP TRANSISTOR	DTA124EKA
Q2D0	261P065O30	CHIP TRANSISTOR	DTA124EKA	Q2061	261P065O30	CHIP TRANSISTOR	DTA124EKA
Q2E5	261P067O30	CHIP TRANSISTOR	DTC124EKA	Q351	261P056O10	TRANSISTOR	2SD734F
Q2001	261P066O10	CHIP TRANSISTOR	2SA1037AK	Q352	260P629O60	TRANSISTOR	2SC3331-T
Q2002	260P818O30	CHIP TRANSISTOR	2SC2412K-S	Q353	260P629O60	TRANSISTOR	2SC3331-T
				Q354	261P065O30	CHIP TRANSISTOR	DTA124EKA
				Q355	260P562O40	TRANSISTOR	2SA952-K
				Q356	261P067O30	CHIP TRANSISTOR	DTC124EKA

SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION	SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION
Q3L0	261P067030	CHIP TRANSISTOR	DTC124EKA	D809	264P621020	LIGHT EMITTING DIODE	SEL2410E TP2
Q5A3	260P802020	CHIP TRANSISTOR	2SA1235-F	D810	264P621020	LIGHT EMITTING DIODE	SEL2410E TP2
Q5A4	261P066010	CHIP TRANSISTOR	2SA1037AK	D811	264P568030	DIODE	1SS254
Q5A5	260P818030	CHIP TRANSISTOR	2SC2412K-S	D812	264P568030	DIODE	1SS254
Q5B1	261P066010	CHIP TRANSISTOR	2SA1037AK	D813	264P568030	DIODE	1SS254
Q5B4	260P804030	CHIP TRANSISTOR	2SC3052-G	D814	264P568030	DIODE	1SS254
Q5L0	260P818030	CHIP TRANSISTOR	2SC2412K-S	D821	264P568030	DIODE	1SS254
Q5D01	261P067030	CHIP TRANSISTOR	DTC124EKA	D822	264P568030	DIODE	1SS254
Q5D05	260P818030	CHIP TRANSISTOR	2SC2412K-S	D823	264P568030	DIODE	1SS254
Q5D80	260P818030	CHIP TRANSISTOR	2SC2412K-S	D824	264P568030	DIODE	1SS254
Q6002	261P066010	CHIP TRANSISTOR	2SA1037AK	D8A8	264P568030	DIODE	1SS254
Q6003	261P066010	CHIP TRANSISTOR	2SA1037AK	D8A9	264P568030	DIODE	1SS254
Q6004	261P066010	CHIP TRANSISTOR	2SA1037AK	D8G5	264P568030	DIODE	1SS254
Q6005	261P067030	CHIP TRANSISTOR	DTC124EKA	D901	264P508070	DIODE	S1WB(A)60F4072
Q6009	261P065030	CHIP TRANSISTOR	DTA124EKA	D905	264P695010	DIODE	RK34/D2S4M
Q6010	260P818030	CHIP TRANSISTOR	2SC2412K-S	D907	264P670010	DIODE	D5S4M
Q6011	260P818030	CHIP TRANSISTOR	2SC2412K-S	D908	264P672010	DIODE	D5S6M
Q6301	260P562040	TRANSISTOR	2SA952-K	D909	264P663010	DIODE	D1NL20U
Q905	260P559040	TRANSISTOR	2SC1740S-R,S	D910	264P663010	DIODE	D1NL20U
Q906	260P559040	TRANSISTOR	2SC1740S-R,S	D911	264P527030	DIODE	D1NS4/AK04
Q907	260P559040	TRANSISTOR	2SC1740S-R,S	D912	264P771080	DIODE	MTZJ2.4A
Q908	260C628010	TRANSISTOR	2SA1619A-Q	D913	264P783060	DIODE	MTZJ30D
Q910	260C560010	TRANSISTOR	2SA933S-R,S	D914	264P783010	DIODE	MTZJ27D
Q918	260P559040	TRANSISTOR	2SC1740S-R,S	D917	264P452030	DIODE	HZ5C3
Q919	261P067030	CHIP TRANSISTOR	DTC124EKA	D918	264P568030	DIODE	1SS254
Q922	260P586020	TRANSISTOR	2SB892-T	D920	264P500020	DIODE	EM01Z
Q927	260P586020	TRANSISTOR	2SB892-T	D926	264P488090	DIODE	RD16FB
Q928	260P559040	TRANSISTOR	2SC1740S-R,S	D927	264P695070	DIODE	RK39
Q929	261P036010	TRANSISTOR	2SB1548	D931	264P568030	DIODE	1SS254
Q930	260P559040	TRANSISTOR	2SC1740S-R,S	D937	264P663010	DIODE	D1NL20U
Q985	260P585030	TRANSISTOR	2SD1682-T,U	D938	264P663010	DIODE	D1NL20U
Q990	260P559040	TRANSISTOR	2SC1740S-R,S	D943	264P568030	DIODE	1SS254
Q991	260P586020	TRANSISTOR	2SB892-T	D951	264P695010	DIODE	RK34/D2S4M
Q992	260P559050	TRANSISTOR	2SC1740S-E	D970	264P568030	DIODE	1SS254
Q993	261P036010	TRANSISTOR	2SB1548	D971	264P568030	DIODE	1SS254
DIODES				D972	264P568030	DIODE	1SS254
D120	264P568030	DIODE	1SS254	D974	264P568030	DIODE	1SS254
D2A0	264P568030	DIODE	1SS254	D985	264P783060	DIODE	MTZJ30D
D2001	264P807010	CHIP DIODE	DAP202K	D990	264P670010	DIODE	D5S4M
D2002	264P807010	CHIP DIODE	DAP202K	D991	264P568030	DIODE	1SS254
D3A2	264P568030	DIODE	1SS254	D992	264P568030	DIODE	1SS254
D5A0	264P568030	DIODE	1SS254	FILTERS			
D5A9	264P795020	LIGHT EMITTING DIODE	SID1050CMMTP5	L901	351P172010	LINE FILTER	SS11V-10062
D5B4	264P795020	LIGHT EMITTING DIODE	SID1050CMMTP5	COILS			
D5B5	264P795020	LIGHT EMITTING DIODE	SID1050CMMTP5	L02	325C472020	PEAKING COIL	56μH-J
D5C0	264P795020	LIGHT EMITTING DIODE	SID1050CMMTP5	L03	325C122050	PEAKING COIL	100μH-K
D5D0	264P773060	DIODE	MTZJ3.9B	L04	325C472050	PEAKING COIL	100μH-J
D5D2	264P500020	DIODE	EM01Z	L100	325C473070	PEAKING COIL	1000μH-J
D5D3	264P500020	DIODE	EM01Z	L120	325C472050	PEAKING COIL	100μH-J
D5D01	264P773060	DIODE	MTZJ3.9B	L121	325C472050	PEAKING COIL	100μH-J
D6002	264P568030	DIODE	1SS254	L122	325C472010	PEAKING COIL	47μH-J
D801	264P568030	DIODE	1SS254	L150	325C472050	PEAKING COIL	100μH-J
D802	264P568030	DIODE	1SS254	L2A1	325C472030	PEAKING COIL	68μH-J
D803	264P568030	DIODE	1SS254	L2A3	325C472050	PEAKING COIL	100μH-J
D805	264P568030	DIODE	1SS254				
D807	264P568030	DIODE	1SS254				

SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION	SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION
L2A4	325C472050	PEAKING COIL	100μH-J	R131	103P402010	CHIP RESISTOR	1/10W 470Ω-J
L2A6	325C472020	PEAKING COIL	56μH-J	R134	103P474070	CHIP RESISTOR	1/10W 8.2kΩ-F
L2A7	325C166040	PEAKING COIL	12μH-J	R135	103P475030	CHIP RESISTOR	1/10W 15kΩ-F
L2A9	325C471030	PEAKING COIL	10μH-J	R136	103P475010	CHIP RESISTOR	1/10W 12kΩ-F
L2B0	325C472050	PEAKING COIL	100μH-J	R139	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
L2B1	325C472050	PEAKING COIL	100μH-J	R150	103P402050	CHIP RESISTOR	1/10W 1kΩ-J
L2B3	325C473050	PEAKING COIL	680μH-J	R151	103P472050	CHIP RESISTOR	1/10W 1kΩ-F
L2001	325C472050	PEAKING COIL	100μH-J	R2A2	103P474040	CHIP RESISTOR	1/10W 6.2kΩ-F
L2002	325C472050	PEAKING COIL	100μH-J	R2A3	103P472090	CHIP RESISTOR	1/10W 1.5kΩ-F
L2003	325C472050	PEAKING COIL	100μH-J	R2A4	103P475030	CHIP RESISTOR	1/10W 15kΩ-F
L2004	325C472050	PEAKING COIL	100μH-J	R2A5	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
L300	325C472050	PEAKING COIL	100μH-J	R2A9	103P403010	CHIP RESISTOR	1/10W 3.3kΩ-J
L350	325C472050	PEAKING COIL	100μH-J	R2B0	103P476030	CHIP RESISTOR	1/10W 39kΩ-F
L3A0	325C471030	PEAKING COIL	10μH-J	R2B2	103P473090	CHIP RESISTOR	1/10W 3.9kΩ-F
L3A1	325C121030	PEAKING COIL	10μH-K	R2B3	103P473070	CHIP RESISTOR	1/10W 3.3kΩ-F
L3A2	325C472050	PEAKING COIL	100μH-J	R2B8	103P401070	CHIP RESISTOR	1/10W 220Ω-J
L3A3	325C471030	PEAKING COIL	10μH-J	R2C0	103P406020	CHIP METAL RESISTOR	1/10W 1.2MΩ-J
L5D01	325C471090	PEAKING COIL	33μH-J	R2C1	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
L6008	325C472050	PEAKING COIL	100μH-J	R2C4	103P402060	CHIP RESISTOR	1/10W 1.2kΩ-J
L6009	325C472050	PEAKING COIL	100μH-J	R2C7	103P403030	CHIP RESISTOR	1/10W 4.7kΩ-J
L6150	325C472050	PEAKING COIL	100μH-J	R2D2	103P402050	CHIP RESISTOR	1/10W 1kΩ-J
L6300	325C472050	PEAKING COIL	100μH-J	R2D4	103P402070	CHIP RESISTOR	1/10W 1.5kΩ-J
L8A0	325C472050	PEAKING COIL	100μH-J	R2D6	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J
L902	321C141090	RF COIL	33μH-K	R2D7	103P472070	CHIP RESISTOR	1/10W 1.2kΩ-F
L903	321C141030	RF COIL	10μH-K	R2D8	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
L904	321C141090	RF COIL	33μH-K	R2D9	103P473030	CHIP RESISTOR	1/10W 2.2kΩ-F
L906	321C141090	RF COIL	33μH-K	R2E0	103P472050	CHIP RESISTOR	1/10W 1kΩ-F
L907	321C141030	RF COIL	10μH-K	R2E1	103P472050	CHIP RESISTOR	1/10W 1kΩ-F
L990	321C141090	RF COIL	33μH-K	R2E5	103P404080	CHIP RESISTOR	1/10W 82kΩ-J
T350	409P880030	BIAS OSCILLATOR COIL		R2E6	103P405030	CHIP RESISTOR	1/10W 220kΩ-J
TRANSFORMERS				R2E7	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
T901	350P717090	POWER TRANSFORMER		R2F0	103P405080	CHIP RESISTOR	1/10W 560kΩ-J
VARIABLE RESISTORS				R2F1	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R901	109C010050	SOLID RESISTOR	1/2W 2.2MΩ-K (UL)	R2F8	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R930	109C010010	SOLID RESISTOR	1/2W 1MΩ-K	R2G0	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
RESISTORS				R2G1	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J
R100	103P401030	CHIP RESISTOR	1/10W 100Ω-J	R2Z1	103P402060	CHIP RESISTOR	1/10W 1.2kΩ-J
R101	103P402060	CHIP RESISTOR	1/10W 1.2kΩ-J	R2001	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R102	103P403090	CHIP RESISTOR	1/10W 15kΩ-J	R2002	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R103	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	R2003	103P401050	CHIP RESISTOR	1/10W 150Ω-J
R104	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)	R2004	103P402050	CHIP RESISTOR	1/10W 1kΩ-J
R105	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	R2005	103P402010	CHIP RESISTOR	1/10W 470Ω-J
R106	103P402050	CHIP RESISTOR	1/10W 1kΩ-J	R2006	103P400090	CHIP RESISTOR	1/10W 47Ω-J
R107	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	R2007	103P401030	CHIP RESISTOR	1/10W 100Ω-J
R108	103P401030	CHIP RESISTOR	1/10W 100Ω-J	R2008	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R120	103P472090	CHIP RESISTOR	1/10W 1.5kΩ-	R2009	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R121	103P472000	CHIP RESISTOR	1/10W 620Ω-F	R2010	103P401030	CHIP RESISTOR	1/10W 100Ω-J
R122	103P402050	CHIP RESISTOR	1/10W 1kΩ-J	R2011	103P401030	CHIP RESISTOR	1/10W 100Ω-J
R125	103P401070	CHIP RESISTOR	1/10W 220Ω-J	R2012	103P402020	CHIP RESISTOR	1/10W 560Ω-J
R127	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	R2013	103P400050	CHIP RESISTOR	1/10W 22Ω-J
R128	103P472060	CHIP RESISTOR	1/10W 1.1kΩ-F	R2014	103P402070	CHIP RESISTOR	1/10W 1.5kΩ-J
R129	103P473040	CHIP RESISTOR	1/10W 2.4kΩ-F	R2015	103P400050	CHIP RESISTOR	1/10W 22Ω-J
R130	103P402050	CHIP RESISTOR	1/10W 1kΩ-J	R2016	103P402010	CHIP RESISTOR	1/10W 470Ω-J
				R2017	103P402070	CHIP RESISTOR	1/10W 1.5kΩ-J
				R2020	103P402050	CHIP RESISTOR	1/10W 1kΩ-J
				R2021	103P402050	CHIP RESISTOR	1/10W 1kΩ-J
				R2022	103P409090	CHIP RESISTOR	1/10W 75Ω-J

SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION	SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION
R2023	103P409090	CHIP RESISTOR	1/10W 75Ω-J	R2082	103P401080	CHIP RESISTOR	1/10W 270Ω-J
R2024	103P401050	CHIP RESISTOR	1/10W 150Ω-J	R2083	103P402080	CHIP RESISTOR	1/10W 1.8kΩ-J
R2025	103P401030	CHIP RESISTOR	1/10W 100Ω-J	R2084	103P402080	CHIP RESISTOR	1/10W 1.8kΩ-J
R2026	103P400030	CHIP METAL RESISTOR	1/10W 15Ω-J	R2085	103P401080	CHIP RESISTOR	1/10W 270Ω-J
R2027	103P401060	CHIP RESISTOR	1/10W 180Ω-J	R2086	103P400010	CHIP RESISTOR	1/10W 10Ω-J
R2028	103P402020	CHIP RESISTOR	1/10W 560Ω-J	R2087	103P402010	CHIP RESISTOR	1/10W 470Ω-J
R2029	103P401050	CHIP RESISTOR	1/10W 150Ω-J	R2088	103P402010	CHIP RESISTOR	1/10W 470Ω-J
R2030	103P401030	CHIP RESISTOR	1/10W 100Ω-J	R2089	103P400010	CHIP RESISTOR	1/10W 10Ω-J
R2031	103P402070	CHIP RESISTOR	1/10W 1.5kΩ-J	R2090	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J
R2032	103P404020	CHIP RESISTOR	1/10W 27kΩ-J	R2091	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J
R2033	103P404050	CHIP RESISTOR	1/10W 47kΩ-J	R2092	103P403030	CHIP RESISTOR	1/10W 4.7kΩ-J
R2034	103P404020	CHIP RESISTOR	1/10W 27kΩ-J	R2093	103P403030	CHIP RESISTOR	1/10W 4.7kΩ-J
R2035	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J	R2094	103P403030	CHIP RESISTOR	1/10W 4.7kΩ-J
R2036	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J	R2095	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J
R2037	103P401080	CHIP RESISTOR	1/10W 270Ω-J	R2096	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J
R2038	103P402080	CHIP RESISTOR	1/10W 1.8kΩ-J	R2097	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J
R2039	103P402080	CHIP RESISTOR	1/10W 1.8kΩ-J	R2098	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J
R2040	103P401080	CHIP RESISTOR	1/10W 270Ω-J	R2099	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J
R2041	103P401080	CHIP RESISTOR	1/10W 270Ω-J	R2100	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J
R2042	103P402080	CHIP RESISTOR	1/10W 1.8kΩ-J	R2101	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R2043	103P402080	CHIP RESISTOR	1/10W 1.8kΩ-J	R2102	103P401050	CHIP RESISTOR	1/10W 150Ω-J
R2044	103P401080	CHIP RESISTOR	1/10W 270Ω-J	R2103	103P400030	CHIP METAL RESISTOR	1/10W 15Ω-J
R2045	103P400010	CHIP RESISTOR	1/10W 10Ω-J	R2104	103P401060	CHIP RESISTOR	1/10W 180Ω-J
R2046	103P402010	CHIP RESISTOR	1/10W 470Ω-J	R2105	103P401050	CHIP RESISTOR	1/10W 150Ω-J
R2047	103P402010	CHIP RESISTOR	1/10W 470Ω-J	R2106	103P401030	CHIP RESISTOR	1/10W 100Ω-J
R2048	103P400010	CHIP RESISTOR	1/10W 10Ω-J	R2107	103P402070	CHIP RESISTOR	1/10W 1.5kΩ-J
R2049	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J	R2108	103P402020	CHIP RESISTOR	1/10W 560Ω-J
R2050	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J	R2110	103P401050	CHIP RESISTOR	1/10W 150Ω-J
R2051	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)	R2111	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R2052	103P400010	CHIP RESISTOR	1/10W 10Ω-J	R2113	103P401030	CHIP RESISTOR	1/10W 100Ω-J
R2053	103P402010	CHIP RESISTOR	1/10W 470Ω-J	R2114	103P404050	CHIP RESISTOR	1/10W 47kΩ-J
R2054	103P402010	CHIP RESISTOR	1/10W 470Ω-J	R2115	103P404020	CHIP RESISTOR	1/10W 27kΩ-J
R2055	103P400010	CHIP RESISTOR	1/10W 10Ω-J	R2116	103P401030	CHIP RESISTOR	1/10W 100Ω-J
R2056	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J	R2117	103P401030	CHIP RESISTOR	1/10W 100Ω-J
R2057	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J	R2120	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R2058	103P403030	CHIP RESISTOR	1/10W 4.7kΩ-J	R2121	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R2059	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	R2122	103P401050	CHIP RESISTOR	1/10W 150Ω-J
R2060	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	R2123	103P402050	CHIP RESISTOR	1/10W 1kΩ-J
R2061	103P400090	CHIP RESISTOR	1/10W 47Ω-J	R2124	103P402010	CHIP RESISTOR	1/10W 470Ω-J
R2062	103P402050	CHIP RESISTOR	1/10W 1kΩ-J	R2125	103P400090	CHIP RESISTOR	1/10W 47Ω-J
R2063	103P402010	CHIP RESISTOR	1/10W 470Ω-J	R2126	103P401030	CHIP RESISTOR	1/10W 100Ω-J
R2064	103P401030	CHIP RESISTOR	1/10W 100Ω-J	R2127	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R2065	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	R2128	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R2066	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	R2129	103P401030	CHIP RESISTOR	1/10W 100Ω-J
R2067	103P401030	CHIP RESISTOR	1/10W 100Ω-J	R2130	103P401030	CHIP RESISTOR	1/10W 100Ω-J
R2068	103P401030	CHIP RESISTOR	1/10W 100Ω-J	R2131	103P402020	CHIP RESISTOR	1/10W 560Ω-J
R2069	103P402020	CHIP RESISTOR	1/10W 560Ω-J	R2132	103P400050	CHIP RESISTOR	1/10W 22Ω-J
R2070	103P400050	CHIP RESISTOR	1/10W 22Ω-J	R2133	103P400050	CHIP RESISTOR	1/10W 22Ω-J
R2071	103P400050	CHIP RESISTOR	1/10W 22Ω-J	R2134	103P402010	CHIP RESISTOR	1/10W 470Ω-J
R2072	103P402010	CHIP RESISTOR	1/10W 470Ω-J	R2135	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R2075	103P402050	CHIP RESISTOR	1/10W 1kΩ-J	R2136	103P402050	CHIP RESISTOR	1/10W 1kΩ-J
R2077	103P403030	CHIP RESISTOR	1/10W 4.7kΩ-J	R2137	103P402050	CHIP RESISTOR	1/10W 1kΩ-J
R2078	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	R2138	103P402050	CHIP RESISTOR	1/10W 1kΩ-J
R2079	103P403030	CHIP RESISTOR	1/10W 4.7kΩ-J	R2139	103P404020	CHIP RESISTOR	1/10W 27kΩ-J
R2080	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	R2140	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R2081	103P402090	CHIP RESISTOR	1/10W 2.2kΩ-J	R2141	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
				R2142	103P471010	CHIP RESISTOR	1/10W 270Ω-F


SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION	SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION
R2143	103P472010	CHIP RESISTOR	1/10W 680Ω-F	R5E4	103P406090	CHIP METAL RESISTOR	1/10W 4.7MΩ-K
R2144	103P471010	CHIP RESISTOR	1/10W 270Ω-F	R5E5	103P402040	CHIP RESISTOR	1/10W 820Ω-J
R2145	103P472010	CHIP RESISTOR	1/10W 680Ω-F	R5E6	103P406010	CHIP RESISTOR	1/10W 1MΩ-J
R2146	103P471010	CHIP RESISTOR	1/10W 270Ω-F	R5E7	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R2147	103P472010	CHIP RESISTOR	1/10W 680Ω-F	R5F7	103P403000	CHIP RESISTOR	1/10W 2.7kΩ-J
R2150	103P402010	CHIP RESISTOR	1/10W 470Ω-J	R5F8	103P403000	CHIP RESISTOR	1/10W 2.7kΩ-J
R2151	103P402010	CHIP RESISTOR	1/10W 470Ω-J	R5G5	103P402050	CHIP RESISTOR	1/10W 1kΩ-J
R301	103P405050	CHIP RESISTOR	1/10W 330kΩ-J	R5J6	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R302	103P403080	CHIP RESISTOR	1/10W 12kΩ-J	R5K7	103P404030	CHIP RESISTOR	1/10W 33kΩ-J
R303	103P470080	CHIP RESISTOR	1/10W 200Ω-F	R5K8	103P404030	CHIP RESISTOR	1/10W 33kΩ-J
R304	103P404010	CHIP RESISTOR	1/10W 22kΩ-J	R5L0	103P404090	CHIP RESISTOR	1/10W 100kΩ-J
R351	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	R5R2	103P402060	CHIP RESISTOR	1/10W 1.2kΩ-J
R352	103P403030	CHIP RESISTOR	1/10W 4.7kΩ-J	R5R3	103P403090	CHIP RESISTOR	1/10W 15kΩ-J
R357	103P403020	CHIP RESISTOR	1/10W 3.9kΩ-J	R5S0	103P404030	CHIP RESISTOR	1/10W 33kΩ-J
R358	103P403020	CHIP RESISTOR	1/10W 3.9kΩ-J	R5S3	103P403090	CHIP RESISTOR	1/10W 15kΩ-J
R365	103P400090	CHIP RESISTOR	1/10W 47Ω-J	R5S4	103P404040	CHIP RESISTOR	1/10W 39kΩ-J
R366	103P403030	CHIP RESISTOR	1/10W 4.7kΩ-J	R5S8	103P473070	CHIP RESISTOR	1/10W 3.3kΩ-F
R367	103P408040	CHIP RESISTOR	1/10W 2.2Ω-J	R5S9	103P405050	CHIP RESISTOR	1/10W 330kΩ-J
R368	103P403020	CHIP RESISTOR	1/10W 3.9kΩ-J	R5T3	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R3A0	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)	R5T4	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R3A3	103P402030	CHIP RESISTOR	1/10W 680Ω-J	R5T5	103P404030	CHIP RESISTOR	1/10W 33kΩ-J
R3A8	103P405060	CHIP RESISTOR	1/10W 390kΩ-J	R5T6	103P404030	CHIP RESISTOR	1/10W 33kΩ-J
R3A9	103P474040	CHIP RESISTOR	1/10W 6.2kΩ-F	R5V2	103P404090	CHIP RESISTOR	1/10W 100kΩ-J
R3B1	103P474040	CHIP RESISTOR	1/10W 6.2kΩ-F	R5W0	103P402050	CHIP RESISTOR	1/10W 1kΩ-J
R3B2	103P476050	CHIP RESISTOR	1/10W 47kΩ-F	R5W1	103P404030	CHIP RESISTOR	1/10W 33kΩ-J
R3B3	103P474070	CHIP RESISTOR	1/10W 8.2kΩ-F	R5X2	103P402050	CHIP RESISTOR	1/10W 1kΩ-J
R3B4	103P476010	CHIP RESISTOR	1/10W 33kΩ-F	R5D03	103P403010	CHIP RESISTOR	1/10W 3.3kΩ-J
R3B5	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)	R5D04	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R3B9	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)	R5D05	103P402050	CHIP RESISTOR	1/10W 1kΩ-J
R3C3	103P474040	CHIP RESISTOR	1/10W 6.2kΩ-F	R5D06	103P401080	CHIP RESISTOR	1/10W 270Ω-J
R3C5	103P474040	CHIP RESISTOR	1/10W 6.2kΩ-F	R5D07	103P406010	CHIP RESISTOR	1/10W 1MΩ-J
R3F6	103P476010	CHIP RESISTOR	1/10W 33kΩ-F	R5D08	103P402040	CHIP RESISTOR	1/10W 820Ω-J
R3G1	103P403010	CHIP RESISTOR	1/10W 3.3kΩ-J	R5D10	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R3L0	103P473050	CHIP RESISTOR	1/10W 2.7kΩ-F	R5D13	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R5A1	103P404000	CHIP RESISTOR	1/10W 18kΩ-J	R5D14	103P400090	CHIP RESISTOR	1/10W 47Ω-J
R5A3	103P404000	CHIP RESISTOR	1/10W 18kΩ-J	R5D15	103P400090	CHIP RESISTOR	1/10W 47Ω-J
R5A7	103P403090	CHIP RESISTOR	1/10W 15kΩ-J	R5D16	103P400090	CHIP RESISTOR	1/10W 47Ω-J
R5A8	103P401080	CHIP RESISTOR	1/10W 270Ω-J	R5D17	103P400090	CHIP RESISTOR	1/10W 47Ω-J
R5A9	103P402050	CHIP RESISTOR	1/10W 1kΩ-J	R5D18	103P400090	CHIP RESISTOR	1/10W 47Ω-J
R5B0	103P402080	CHIP RESISTOR	1/10W 1.8kΩ-J	R5D19	103P400090	CHIP RESISTOR	1/10W 47Ω-J
R5B2	103P402020	CHIP RESISTOR	1/10W 560Ω-J	R5D21	103P400090	CHIP RESISTOR	1/10W 47Ω-J
R5B3	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	R5D22	103P403010	CHIP RESISTOR	1/10W 3.3kΩ-J
R5B5	103P405030	CHIP RESISTOR	1/10W 220kΩ-J	R5D23	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R5B6	103P405030	CHIP RESISTOR	1/10W 220kΩ-J	R5D24	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R5B8	103P405000	CHIP RESISTOR	1/10W 120kΩ-J	R5D25	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R5B9	103P405000	CHIP RESISTOR	1/10W 120kΩ-J	R5D26	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R5C0	103P405000	CHIP RESISTOR	1/10W 120kΩ-J	R5D27	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R5C6	103P401070	CHIP RESISTOR	1/10W 220Ω-J	R5D80	103P405010	CHIP RESISTOR	1/10W 150kΩ-J
R5D4	103P405030	CHIP RESISTOR	1/10W 220kΩ-J	R5D81	103P404090	CHIP RESISTOR	1/10W 100kΩ-J
R5D5	103P406010	CHIP RESISTOR	1/10W 1MΩ-J	R5D86	103P404090	CHIP RESISTOR	1/10W 100kΩ-J
R5D6	103P405070	CHIP RESISTOR	1/10W 470kΩ-J	R6001	103P409090	CHIP RESISTOR	1/10W 75Ω-J
R5D7	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	R6002	103P409090	CHIP RESISTOR	1/10W 75Ω-J
R5D9	103P403040	CHIP RESISTOR	1/10W 5.6kΩ-J	R6003	103P409090	CHIP RESISTOR	1/10W 75Ω-J
R5E0	103P403020	CHIP RESISTOR	1/10W 3.9kΩ-J	R6004	103P402040	CHIP RESISTOR	1/10W 820Ω-J
R5E1	103P403060	CHIP RESISTOR	1/10W 8.2kΩ-J	R6006	103P402040	CHIP RESISTOR	1/10W 820Ω-J
R5E2	103P404090	CHIP RESISTOR	1/10W 100kΩ-J	R6010	103P403010	CHIP RESISTOR	1/10W 3.3kΩ-J
R5E3	103P406090	CHIP METAL RESISTOR	1/10W 4.7MΩ-K				

SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION	SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION
R6011	103P403010	CHIP RESISTOR	1/10W 3.3kΩ-J	R973	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R6012	103P402030	CHIP RESISTOR	1/10W 680Ω-J	R975	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R6013	103P402030	CHIP RESISTOR	1/10W 680Ω-J	R985	103P402050	CHIP RESISTOR	1/10W 1kΩ-J
R6025	103P401090	CHIP RESISTOR	1/10W 330Ω-J	R990	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R6026	103P401090	CHIP RESISTOR	1/10W 330Ω-J	R991	103P403090	CHIP RESISTOR	1/10W 15kΩ-J
R6027	103P401090	CHIP RESISTOR	1/10W 330Ω-J	R992	103P404030	CHIP RESISTOR	1/10W 33kΩ-J
R6028	103P401090	CHIP RESISTOR	1/10W 330Ω-J	R993	103P402050	CHIP RESISTOR	1/10W 1kΩ-J
R6029	103P409090	CHIP RESISTOR	1/10W 75Ω-J	R994	103P403070	CHIP RESISTOR	1/10W 10kΩ-J
R6031	103P409090	CHIP RESISTOR	1/10W 75Ω-J	R996	103P404030	CHIP RESISTOR	1/10W 33kΩ-J
R6032	103P409090	CHIP RESISTOR	1/10W 75Ω-J	R997	103P401090	CHIP RESISTOR	1/10W 330Ω-J
R6033	103P409090	CHIP RESISTOR	1/10W 75Ω-J	RJ01	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6034	103P409090	CHIP RESISTOR	1/10W 75Ω-J	RJ02	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6039	103P402050	CHIP RESISTOR	1/10W 1kΩ-J	RJ03	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6040	103P402050	CHIP RESISTOR	1/10W 1kΩ-J	RJ04	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6041	103P402040	CHIP RESISTOR	1/10W 820Ω-J	RJ05	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6042	103P401030	CHIP RESISTOR	1/10W 100Ω-J	RJ06	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6056	103P400080	CHIP METAL RESISTOR	1/10W 39Ω-J	RJ07	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6066	103P409090	CHIP RESISTOR	1/10W 75Ω-J	RJ08	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6086	103P404020	CHIP RESISTOR	1/10W 27kΩ-J	RJ09	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6087	103P404020	CHIP RESISTOR	1/10W 27kΩ-J	RJ10	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6110	103P400080	CHIP METAL RESISTOR	1/10W 39Ω-J	RJ11	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6111	103P400080	CHIP METAL RESISTOR	1/10W 39Ω-J	RJ12	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6112	103P401030	CHIP RESISTOR	1/10W 100Ω-J	RJ13	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6115	103P404050	CHIP RESISTOR	1/10W 47kΩ-J	RJ14	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6118	103P404050	CHIP RESISTOR	1/10W 47kΩ-J	RJ15	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6122	103P404010	CHIP RESISTOR	1/10W 22kΩ-J	RJ16	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6126	103P403020	CHIP RESISTOR	1/10W 3.9kΩ-J	RJ17	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6301	103P404090	CHIP RESISTOR	1/10W 100kΩ-J	RJ18	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6303	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	RJ19	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6304	103P402000	CHIP RESISTOR	1/10W 390Ω-J	RJ20	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R6314	103P403010	CHIP RESISTOR	1/10W 3.3kΩ-J	RJ21	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R8A0	103P404030	CHIP RESISTOR	1/10W 33kΩ-J	RJ22	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R8A1	103P404030	CHIP RESISTOR	1/10W 33kΩ-J	RJ23	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R8A2	103P404030	CHIP RESISTOR	1/10W 33kΩ-J	RJ24	103P409050	CHIP RESISTOR	0.1W 0Ω(2125)
R8A3	103P404030	CHIP RESISTOR	1/10W 33kΩ-J				
R8A4	103P403010	CHIP RESISTOR	1/10W 3.3kΩ-J	CAPACITORS AND TRIMMERS			
R8A5	103P404050	CHIP RESISTOR	1/10W 47kΩ-J	C100	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
R8A9	103P401070	CHIP RESISTOR	1/10W 220Ω-J	C101	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
R902	102P108050	WIRE RESISTOR	2W 2.7Ω-J	C103	141P137040	CHIP CAPACITOR	B25V 0.022μF-K
R905	103P403010	CHIP RESISTOR	1/10W 3.3kΩ-J	C120	154P325020	CHIP CAPACITOR	SL50V 470pF-J
R911	103P472070	CHIP RESISTOR	1/10W 1.2kΩ-F	C121	141P139070	CHIP CAPACITOR	B16V 0.22μF-K
R912	103P472070	CHIP RESISTOR	1/10W 1.2kΩ-F	C123	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
R916	103P471090	CHIP RESISTOR	1/10W 560Ω-F	C124	181P350060	ELECTROLYTIC CAPACITOR	CE04W 6.3V 1000μF-M
R917	103P472010	CHIP RESISTOR	1/10W 680Ω-F	C126	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
R918	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	C127	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
R919	103P404080	CHIP RESISTOR	1/10W 82kΩ-J	C128	154P332070	CHIP CAPACITOR	CH50V 47pF-J
R920	103P403020	CHIP RESISTOR	1/10W 3.9kΩ-J	C130	141P130030	CHIP CAPACITOR	B50V 330pF-K
R921	103P751030	FUSE RESISTOR	1/4W 100Ω-J	C132	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
R922	103P402050	CHIP RESISTOR	1/10W 1kΩ-J	C133	154P332050	CHIP CAPACITOR	CH50V 39pF-J
R925	103P758000	FUSE RESISTOR	1/4W 1Ω-J	C150	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
R926	103P470010	CHIP RESISTOR	1/10W 100Ω-F	C151	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
R927	103P403040	CHIP RESISTOR	1/10W 5.6kΩ-J	C152	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
R955	103P402050	CHIP RESISTOR	1/10W 1kΩ-J	C156	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
R956	103P473000	CHIP RESISTOR	1/10W 1.6kΩ-F	C163	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
R963	103P403070	CHIP RESISTOR	1/10W 10kΩ-J	C180	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
R964	103P478020	CHIP RESISTOR	1/10W 240kΩ-F	C2A0	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
R971	103P403070	CHIP RESISTOR	1/10W 10kΩ-J				

SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION	SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION
C2A1	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2010	141P135O70	CHIP CAPACITOR	F16V 1μF-Z
C2A2	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2011	141P135O80	CHIP CAPACITOR	F25V 0.1μF-Z
C2A3	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2012	141P135O70	CHIP CAPACITOR	F16V 1μF-Z
C2A4	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K				
C2A5	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2013	141P131O70	CHIP CAPACITOR	B50V 4700pF-K
				C2014	141P139O30	CHIP CAPACITOR	B25V 0.1μF-K
C2A6	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2015	141P130O90	CHIP CAPACITOR	B50V 1000pF-K
C2A7	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2016	141P130O90	CHIP CAPACITOR	B50V 1000pF-K
C2A8	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2017	154P333O10	CHIP CAPACITOR	CH50V 68pF-J
C2B4	141P135O80	CHIP CAPACITOR	F25V 0.1μF-Z				
C2C0	154P330O60	CHIP CAPACITOR	CH50V 5pF-C	C2018	141P135O80	CHIP CAPACITOR	F25V 0.1μF-Z
				C2019	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
C2C1	154P333O90	CHIP CAPACITOR	CH50V 150pF-J	C2020	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
C2C2	154P331O90	CHIP CAPACITOR	CH50V 22pF-J	C2021	154P333O10	CHIP CAPACITOR	CH50V 68pF-J
C2C3	141P135O80	CHIP CAPACITOR	F25V 0.1μF-Z	C2022	141P135O80	CHIP CAPACITOR	F25V 0.1μF-Z
C2C5	141P139O30	CHIP CAPACITOR	B25V 0.1μF-K				
C2C7	154P331O30	CHIP CAPACITOR	CH50V 12pF-J	C2023	141P135O80	CHIP CAPACITOR	F25V 0.1μF-Z
				C2024	154P333O10	CHIP CAPACITOR	CH50V 68pF-J
C2C8	154P331O90	CHIP CAPACITOR	CH50V 22pF-J	C2025	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
C2C9	141P139O30	CHIP CAPACITOR	B25V 0.1μF-K	C2026	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
C2D0	141P139O30	CHIP CAPACITOR	B25V 0.1μF-K	C2027	154P333O10	CHIP CAPACITOR	CH50V 68pF-J
C2D3	141P139O30	CHIP CAPACITOR	B25V 0.1μF-K				
C2D4	141P139O30	CHIP CAPACITOR	B25V 0.1μF-K	C2028	141P135O80	CHIP CAPACITOR	F25V 0.1μF-Z
				C2029	141P135O70	CHIP CAPACITOR	F16V 1μF-Z
C2D5	141P139O30	CHIP CAPACITOR	B25V 0.1μF-K	C2030	141P135O70	CHIP CAPACITOR	F16V 1μF-Z
C2D9	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2031	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
C2E2	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2032	141P135O70	CHIP CAPACITOR	F16V 1μF-Z
C2E3	141P130O30	CHIP CAPACITOR	B50V 330pF-K				
C2E5	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2033	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
				C2034	141P135O70	CHIP CAPACITOR	F16V 1μF-Z
C2E6	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2035	141P135O70	CHIP CAPACITOR	F16V 1μF-Z
C2E7	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2036	141P135O70	CHIP CAPACITOR	F16V 1μF-Z
C2E8	141P139O30	CHIP CAPACITOR	B25V 0.1μF-K	C2037	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
C2E9	141P139O30	CHIP CAPACITOR	B25V 0.1μF-K				
C2F1	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2038	141P135O80	CHIP CAPACITOR	F25V 0.1μF-Z
				C2039	141P135O70	CHIP CAPACITOR	F16V 1μF-Z
C2F2	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2040	141P135O70	CHIP CAPACITOR	F16V 1μF-Z
C2F5	154P330O50	CHIP CAPACITOR	CH50V 4pF-C	C2041	141P131O70	CHIP CAPACITOR	B50V 4700pF-K
C2F6	141P135O80	CHIP CAPACITOR	F25V 0.1μF-Z	C2042	141P139O30	CHIP CAPACITOR	B25V 0.1μF-K
C2F7	141P139O10	CHIP CAPACITOR	B25V 0.068μF-K				
C2G0	141P137O40	CHIP CAPACITOR	B25V 0.022μF-K	C2043	141P130O90	CHIP CAPACITOR	B50V 1000pF-K
				C2044	154P333O10	CHIP CAPACITOR	CH50V 68pF-J
C2G1	141P131O70	CHIP CAPACITOR	B50V 4700pF-K	C2045	141P135O80	CHIP CAPACITOR	F25V 0.1μF-Z
C2G7	141P139O30	CHIP CAPACITOR	B25V 0.1μF-K	C2046	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
C2G9	141P139O30	CHIP CAPACITOR	B25V 0.1μF-K	C2047	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
C2H0	154P330O80	CHIP CAPACITOR	CH50V 7pF-C				
C2H1	154P332O70	CHIP CAPACITOR	CH50V 47pF-J	C2048	141P135O80	CHIP CAPACITOR	F25V 0.1μF-Z
				C2049	154P333O10	CHIP CAPACITOR	CH50V 68pF-J
C2H3	141P135O80	CHIP CAPACITOR	F25V 0.1μF-Z	C2050	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
C2H5	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2051	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
C2H6	141P139O30	CHIP CAPACITOR	B25V 0.1μF-K	C2052	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
C2H7	141P137O60	CHIP CAPACITOR	B50V 0.033μF-K				
C2H9	154P331O50	CHIP CAPACITOR	CH50V 15pF-J	C2054	141P135O70	CHIP CAPACITOR	F16V 1μF-Z
				C2055	141P135O80	CHIP CAPACITOR	F25V 0.1μF-Z
C2J0	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2056	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
C2J2	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2057	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
C2J4	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K	C2059	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
C2J5	154P333O90	CHIP CAPACITOR	CH50V 150pF-J				
C2K0	141P139O30	CHIP CAPACITOR	B25V 0.1μF-K	C2060	141P135O70	CHIP CAPACITOR	F16V 1μF-Z
				C2061	141P135O70	CHIP CAPACITOR	F16V 1μF-Z
C2001	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z	C2062	141P135O70	CHIP CAPACITOR	F16V 1μF-Z
C2003	141P135O70	CHIP CAPACITOR	F16V 1μF-Z	C2063	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z
C2004	141P135O70	CHIP CAPACITOR	F16V 1μF-Z	C300	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K
C2005	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z				
C2007	141P135O70	CHIP CAPACITOR	F16V 1μF-Z	C301	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K
				C302	141P130O60	CHIP CAPACITOR	B50V 560pF-K
C2008	141P133O80	CHIP CAPACITOR	F50V 0.01μF-Z	C303	141P131O60	CHIP CAPACITOR	B50V 3900pF-K
C2009	141P135O80	CHIP CAPACITOR	F25V 0.1μF-Z	C304	141P132O10	CHIP CAPACITOR	B50V 0.01μF-K

SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION	SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION
C305	141P139030	CHIP CAPACITOR	B25V 0.1μF-K	C5W2	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
C350	141P130010	CHIP CAPACITOR	B50V 220pF-K	C5X1	141P133080	CHIP CAPACITOR	F50V 0.01μF-Z
C357	141P137040	CHIP CAPACITOR	B25V 0.022μF-K	C5D01	141P135080	CHIP CAPACITOR	F25V 0.1μF-Z
C358	141P131070	CHIP CAPACITOR	B50V 4700pF-K	C5D02	141P135080	CHIP CAPACITOR	F25V 0.1μF-Z
C379	181P212060	ELECTROLYTIC CAPACITOR	04W 16V 47μF-M	C5D04	141P133090	CHIP CAPACITOR	F50V 0.022μF-Z
C3A7	141P139030	CHIP CAPACITOR	B25V 0.1μF-K	C5D07	141P139030	CHIP CAPACITOR	B25V 0.1μF-K
C3A9	141P139070	CHIP CAPACITOR	B16V 0.22μF-K	C5D15	154P331070	CHIP CAPACITOR	CH50V 18pF-J
C3B9	141P139030	CHIP CAPACITOR	B25V 0.1μF-K	C5D16	154P331070	CHIP CAPACITOR	CH50V 18pF-J
C3C0	141P139030	CHIP CAPACITOR	B25V 0.1μF-K	C6005	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
C3C1	141P139030	CHIP CAPACITOR	B25V 0.1μF-K	C6028	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
C3C8	141P139030	CHIP CAPACITOR	B25V 0.1μF-K	C6030	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
C3E4	141P133080	CHIP CAPACITOR	F50V 0.01μF-Z	C6032	181P219090	ELECTROLYTIC CAPACITOR	04W 50V 3.3μF-M
C3E8	141P139030	CHIP CAPACITOR	B25V 0.1μF-K	C6033	181P219090	ELECTROLYTIC CAPACITOR	04W 50V 3.3μF-M
C3F2	141P139090	CHIP CAPACITOR	B16V 0.47μF-K	C6034	181P219090	ELECTROLYTIC CAPACITOR	04W 50V 3.3μF-M
C3F4	141P139030	CHIP CAPACITOR	B25V 0.1μF-K	C6035	181P219090	ELECTROLYTIC CAPACITOR	04W 50V 3.3μF-M
C3F5	141P132010	CHIP CAPACITOR	B50V 0.01μF-K	C6036	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
C3G1	141P132010	CHIP CAPACITOR	B50V 0.01μF-K	C6037	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
C3G3	141P132010	CHIP CAPACITOR	B50V 0.01μF-K	C6040	181P219090	ELECTROLYTIC CAPACITOR	04W 50V 3.3μF-M
C3G5	141P139070	CHIP CAPACITOR	B16V 0.22μF-K	C6041	181P219090	ELECTROLYTIC CAPACITOR	04W 50V 3.3μF-M
C3G9	141P137040	CHIP CAPACITOR	B25V 0.022μF-K	C6072	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
C3J0	141P139030	CHIP CAPACITOR	B25V 0.1μF-K	C6116	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
C3J1	141P139030	CHIP CAPACITOR	B25V 0.1μF-K	C6117	181P350060	ELECTROLYTIC CAPACITOR	CE04W 6.3V 1000μF-M
C3J2	141P139030	CHIP CAPACITOR	B25V 0.1μF-K	C6151	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
C3J3	141P132010	CHIP CAPACITOR	B50V 0.01μF-K	C6303	154P331090	CHIP CAPACITOR	CH50V 22pF-J
C3J4	141P132010	CHIP CAPACITOR	B50V 0.01μF-K	C8A1	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
C3J5	181P210030	ELECTROLYTIC CAPACITOR	04W 6.3V 47μF-M	C901	189P193030	C-M-P-AC	AC125V 0.068μF-M
C3L0	141P137080	CHIP CAPACITOR	B25V 0.047μF-K	C902	189P193030	C-M-P-AC	AC125V 0.068μF-M
C5A0	189P197020	ELE DOUBLE LAYER CAPACITOR	FM0H473Z	C908	189P215090	AC CERAMIC CAPACITOR	AC250V E2200pF-M
C5A3	141P133090	CHIP CAPACITOR	F50V 0.022μF-Z	C911	141P132010	CHIP CAPACITOR	B50V 0.01μF-K
C5A4	141P132010	CHIP CAPACITOR	B50V 0.01μF-K	C912	181P732010	ELECTROLYTIC CAPACITOR	04W10V 1000μF-M
C5A6	141P132010	CHIP CAPACITOR	B50V 0.01μF-K	C913	181P732010	ELECTROLYTIC CAPACITOR	04W10V 1000μF-M
C5A7	141P132010	CHIP CAPACITOR	B50V 0.01μF-K	C914	141P139090	CHIP CAPACITOR	B16V 0.47μF-K
C5B1	141P131090	CHIP CAPACITOR	B50V 6800pF-K	C915	181P355010	ELECTROLYTIC CAPACITOR	04W 50V 1μF-M
C5B2	141P131090	CHIP CAPACITOR	B50V 6800pF-K	C916	181P734030	ELECTROLYTIC CAPACITOR	04W16V 680μF-M
C5B3	141P131090	CHIP CAPACITOR	B50V 6800pF-K	C917	181P737050	ELECTROLYTIC CAPACITOR	04W50V 22μF-M
C5B5	141P139030	CHIP CAPACITOR	B25V 0.1μF-K	C918	181P737050	ELECTROLYTIC CAPACITOR	04W50V 22μF-M
C5B6	154P331090	CHIP CAPACITOR	CH50V 22pF-J	C920	181P731070	ELECTROLYTIC CAPACITOR	04W10V 220μF-M
C5B7	154P331070	CHIP CAPACITOR	CH50V 18pF-J	C921	181P351050	ELECTROLYTIC CAPACITOR	10V 220μF-M
C5B8	154P331070	CHIP CAPACITOR	CH50V 18pF-J	C926	181P352050	ELECTROLYTIC CAPACITOR	04W 16V 220μF-M
C5B9	154P331070	CHIP CAPACITOR	CH50V 18pF-J	C927	141P130060	CHIP CAPACITOR	B50V 560pF-K
C5C0	141P132010	CHIP CAPACITOR	B50V 0.01μF-K	C929	181P352060	ELECTROLYTIC CAPACITOR	16V 330μF-M
C5C6	141P130050	CHIP CAPACITOR	B50V 470pF-K	C930	181P736070	ELECTROLYTIC CAPACITOR	04W35V 330μF-M
C5C9	141P132010	CHIP CAPACITOR	B50V 0.01μF-K	C933	181P352050	ELECTROLYTIC CAPACITOR	04W 16V 220μF-M
C5J9	141P133090	CHIP CAPACITOR	F50V 0.022μF-Z	C936	181P351050	ELECTROLYTIC CAPACITOR	10V 220μF-M
C5L0	141P139030	CHIP CAPACITOR	B25V 0.1μF-K	C937	181P351050	ELECTROLYTIC CAPACITOR	10V 220μF-M
C5R1	141P130080	CHIP CAPACITOR	B50V 820pF-K	C944	181P352040	ELECTROLYTIC CAPACITOR	04W 16V 100μF-M
C5S0	141P131070	CHIP CAPACITOR	B50V 4700pF-K	C945	181P351040	ELECTROLYTIC CAPACITOR	CE04W 10V 100μF-M
C5S1	141P132020	CHIP CAPACITOR	B50V 0.012μF-K	C946	181P351040	ELECTROLYTIC CAPACITOR	CE04W 10V 100μF-M
C5S3	141P139000	CHIP CAPACITOR	B25V 0.056μF-K	C990	181P732010	ELECTROLYTIC CAPACITOR	04W10V 1000μF-M
C5S4	141P139000	CHIP CAPACITOR	B25V 0.056μF-K	C991	181P351050	ELECTROLYTIC CAPACITOR	10V 220μF-M
C5S5	141P130090	CHIP CAPACITOR	B50V 1000pF-K	C992	181P351050	ELECTROLYTIC CAPACITOR	10V 220μF-M
C5S6	141P131030	CHIP CAPACITOR	B50V 2200pF-K	C993	181P351050	ELECTROLYTIC CAPACITOR	10V 220μF-M
C5T5	141P130090	CHIP CAPACITOR	B50V 1000pF-K	C9Y1	189P215090	AC CERAMIC CAPACITOR	AC250V E2200pF-M
C5T6	141P130090	CHIP CAPACITOR	B50V 1000pF-K	C9Y2	189P215090	AC CERAMIC CAPACITOR	AC250V E2200pF-M
C5T9	141P134050	CHIP CAPACITOR	B50V 0.047μF-K	SWITCHES			
C5V2	154P334030	CHIP CAPACITOR	CH50V 220pF-J	S5B1	432P166010	KEY BOARD SWITCH	RESET


SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION	SYMBOL No.	PARTS No.	PARTS NAME	DESCRIPTION
S5S0	439P045010	SWITCH	S-SW MPU10184MLBO		925B126002	MAIN PCB ASSY	
S5S1	439P045010	SWITCH	D-SW MPU10184MLBO		928D478003	OPE L PCB ASSY	
S801	432P203030	KEY BOARD SWITCH	3D-TBC				
S802	432P203030	KEY BOARD SWITCH	REC		928D479003	OPE R PCB ASSY	
S803	432P203030	KEY BOARD SWITCH	PAUSE		928D571002	SIGNAL PCB ASSY	
S805	432P203030	KEY BOARD SWITCH	PLAY		928D560001	D-IF PCB ASSY	
S807	432P203030	KEY BOARD SWITCH	STOP		928P009020	DVHS PCB ASSY	
S811	432P203030	KEY BOARD SWITCH	POWER				
S812	432P203030	KEY BOARD SWITCH	EJECT				
S813	432P203030	KEY BOARD SWITCH	DVHS				
S814	432P203030	KEY BOARD SWITCH	SP/EP/VP				
S820	439P041010	JOG SWITCH	JOG/SHUTTLE				
MISCELLANEOUS							
	621C525010	LED HOLDER	(D5B4)				
	243C160050	CARD LEAD WIRE	(EX FX) 19P L160(MA-OA)				
	243C155010	CARD LEAD WIRE	(JG OG) 9PIN L=85				
	243C193050	CARD LEAD WIRE	(MA DA) 7PIN L=160				
	243C193030	CARD LEAD WIRE	(MD DD) 7PIN L=120				
	243C157020	CARD LEAD WIRE	(MJ OJ) 13P L=100				
	243C160020	CARD LEAD WIRE	(MS OS) 19P L=100				
	621C564010	LED HOLDER R	(Q5A0)				
	621C564010	LED HOLDER R	(Q5A1)				
	621C527010	PHOTO HOLDER	(Q5A2)				
CF6301	299P116010	CERAMIC RESONATOR	KBR-4.0KES				
F901	283D130030	FUSE	S1.6A 125V				
J6003	449C100010	DIN SOCKET(4P)					
J6004	451C207030	RCA PIN JACK					
J6005	449C100010	DIN SOCKET(4P)					
J6006	451C207010	RCA PIN JACK	3P				
J6007	449C100010	DIN SOCKET(4P)					
J6008	451C207010	RCA PIN JACK	3P				
J6012	451C117010	HEADPHONE JACK	BLACK				
J801	451C207030	RCA PIN JACK					
J802	449C100010	DIN SOCKET(4P)					
PC901	268P058010	PHOTO COUPLER	ON3131-R				
Q5A0	268P076020	PHOTO TRANSISTOR	SPS-1119C-BC-T				
Q5A1	268P076020	PHOTO TRANSISTOR	SPS-1119C-BC-T				
Q5A2	268P076020	PHOTO TRANSISTOR	SPS-1119C-BC-T				
Q5A6	268P092010	PHOTO TRANSISTOR	PT492FK1				
Q5A7	268P092010	PHOTO TRANSISTOR	PT492FK1				
Q5A8	268P076020	PHOTO TRANSISTOR	SPS-1119C-BC-T				
Q5A9	268P076020	PHOTO TRANSISTOR	SPS-1119C-BC-T				
Q5B0	268P076020	PHOTO TRANSISTOR	SPS-1119C-BC-T				
RV901	265P100020	VARIATOR	ERZV10D271CS				
TU01	295P515010	TUNER	VD025AW				
V8A0	253P157010	FLUOR DISPLAY TUBE					
X2A0	285P147060	CRYSTAL RESONATOR	3.579545MH				
X5A0	285P054040	CRYSTAL RESONATOR	32.768kHz				
X5A1	285P368040	CRYSTAL RESONATOR	12.000MHz				
X5D01	285P368040	CRYSTAL RESONATOR	12.000MHz				
Z5A0	939P662020	PREAMP UNIT	GP1U293Q				
PRINTED CIRCUIT BOARD ASSY'S							
	927C324002	1394 PCB ASSY					
	928D572001	HEAD AMP PCB ASSY					
	928D559001	JACK PCB ASSY					



HS-HD2000U BLOCK DIAGRAM (Digital Signal)


(HD2000U01081)

Deck



Luminance Record, Chroma Record HS-HD2000U (Analog Signal)


(HD2000U01082)



Luminance Playback, Chroma Playback HS-HD2000U (Analog Signal)


PCB-JACK
(HD2000U01083)

IC3A0 Hi-Fi Sound and Linear Selector





**Hi-Fi and Linear Sound
HS-HD2000U (Analog Signal)**


Power, Timer, Mechanical Control HS-HD2000U (Analog Signal)




(HIFI) PCB-MAIN






Note: Unless otherwise specified.
 All PNP transistors are 2SA1037AK-R.S.
 All NPN transistors are 2SC2412K-R.S/2SD601AI-R.S.
 All diodes are 1SS254/1SS133.
 All resistors are 1/10W.
 All PNP digital transistors are DTA124EKA/RT1P241C.
 All NPN digital transistors are DTC124EKA/RT1N241C.





Note: All R-M-CHIP are 1/10W unless otherwise specified.
 PNP transistors are 2SA1037AK/R-S.
 NPN transistors are 2SC2412K-R, S/2SD601AI-R, S.
 All diodes are 1SS254/1SS133.
 PNP digital transistors are DTA124EKA/RT1N241C.
 NPN digital transistors are DTC124EKA/RT1N241C.



TRUE TABLE

CLOCK	OUTPUT ENABLE	STROBE	DATA	PARALLEL OUTPUTS		SERIAL OUTPUTS	
				Q1	Q2	Q3	Q4
0	X	X	3S	3S	Q7	NO CHG.	Q7
0	X	X	3S	3S	NO CHG.	Q7	NO CHG.
1	0	X	NO CHG.	NO CHG.	Q7	NO CHG.	Q7
1	1	0	0	QN-1	Q7	NO CHG.	Q7
1	1	1	1	QN-1	Q7	NO CHG.	Q7
1	1	1	1	NO CHG.	NO CHG.	NO CHG.	Q7

3S = Three-Stroke
 X = Don't Care
 At the positive clock edge, information in the 7th shift register stage is transferred to Q8 and Q5.

A

(SIGNAL) PCB-SIGNAL

B


C

D

E

F


G




Note : Unless otherwise specified.
 All resistors are 1/10W.
 All PNP transistors are 2SA1037AK-R.5.
 All NPN transistors are 2SC2412K-R.5/2SD601AI-R.5.
 All PNP digital transistors are DTA124EKA/RT1P241C.
 All NPN digital transistors are DTC124EKA/RT1N241C.
 All diodes are DAN202K/M1MA151WKT1.
 All C-CERAMIC-CHIP K-.1 are 25V.

(YT) PCB-SIGNAL


A
B
C
D
E
F
G



Note : Unless otherwise specified,
 All PNP transistors are 2SA1037AK-R.S.
 All NPN transistors are 2SC2412K-R.S/2SD601AI-R.S.
 All PNP digital transistors are DTA124EKA/RT1P241C.
 All NPN digital transistors are DTC124EKA/RT1N241C.
 All diodes are DAN202K.
 All R-M-CHIP are 1/10W.
 All C-CERAMIC-CHIP K-.1 are 25V.




(VSET) PCB-SIGNAL





Note:
 Unless otherwise specified.
 PNP transistors are 2SC2412K-R.S./2SD601AI-R.S.
 NPN transistors are 2SA1037AK-R.S.

(Y/C/A) PCB-MAIN





- Recording of Luminance Signal
- - - Playback of Luminance Signal
- Recording of Color Signal
- - - Playback of Color Signal





NOTE:
 UNLESS OTHERWISE SPECIFIED,
 ALL RESISTORS ARE 1/10W.
 ALL DIODES ARE 1SS254/1SS133.
 ALL PNP TRANSISTORS ARE 2SA1037AK-R-S.
 ALL NPN TRANSISTORS ARE 2SC2412K-R-S/2SD0601A1-R-S.
 PNP DIGITAL TRANSISTORS ARE DTA124EKA/RT1P241C.
 NPN DIGITAL TRANSISTORS ARE DTC124EKA/RT1N241C.

(CONTROL) PCB-MAIN




NOTE:
 All registers are 1/6 or 1/4W unless otherwise specified.
 All diodes are 1SS24/1SS133 unless otherwise specified.
 All NPN transistors are 2SC2412K-R-S/2SD5014I-R-S unless otherwise specified.
 All PNP transistors are 2SA1037K-R-S unless otherwise specified.




INPUT	OUTPUT	MODE
0 0	0	STOP
1 0	H	L CW/CWV
0 1	L	H CW/CWV
1 1	L	L BRAKE

REMOTE HAND UNIT



KEY No.	FUNCTION	KEY No.	FUNCTION	SUTILE PLACE	SUTILE CODE
K1	LCD PROGRAM	K18	3	FVD7	JHFS
K2	J-FS	K19	J-FS	FVD8	J-FS
K3	J-2PB	K20	0	FVD9	J-2PB
K4	DISPLAY	K21	0	FVD4	J-SPB
K5	TV AUDIO	K22	VOLUME V	FVD2	J-SLOW3
K6	VCR-AB	K23	VOLUME A	FVD1	J-SLOW1
K7	VCR-AB	K24	STOP	REV1	J-STILL
K8	REC	K25	INDEX > RIGHT	REV2	J-RSLOW3
K9	VCR POWER	K26	QUICK PROGRAM TRANSFER	REV3	J-RSLOW3
K10	OTR2-START TIME	K27	9	REV4	J-RPB
K11	VIDEO	K28	8	REV5	J-X3RPB
K12	10	K29	MUTE	REV6	J-RS
K13	CHANNEL A	K30	ENTER	REV7	JHRS
K14	CHANNEL V	K31	MENU		
K15	PLAY	K32	INPUT/DAILY WEEKLY		
K16	INDEX << LEFT	K33	FF		
K17	VCR Plus+				

KEY No.	FUNCTION	KEY No.	FUNCTION
K18	3	K27	9
K19	J-FS	K28	8
K20	0	K29	MUTE
K21	0	K30	ENTER
K22	VOLUME V	K31	MENU
K23	VOLUME A	K32	INPUT/DAILY WEEKLY
K24	STOP	K33	FF
K25	INDEX > RIGHT		
K26	QUICK PROGRAM TRANSFER		



(TIMER) PCB-MAIN

A

B

C


D

E

F

G


PCB-OPE L



TO POWER

TO HI-FI


TO TUNER/CG




TO CONTROL

All resistors are 1/6 or 1/4W unless otherwise specified.
 All diodes are 1SS254/1SS133 unless otherwise specified.


PCB-JOG





PCB-OPE R



IC8A0 μPD16312GB-3BS



PCB-JACK




Note:
 Unless otherwise specified.
 PNP transistors are 2SA1037AK-R, S.
 NPN transistors are 2SC2412K-R, S/2SD601AI-R, S.
 All diodes are 1SS254.
 PNP digital transistors are DTA124EKA/RT1P241C.
 NPN digital transistors are DTC124EKA/RT1N241C.
 All resistors are 1/10W.

PCB-MAIN [MH]
(TUNER/CG)

PCB-MAIN [MG]
(CONTROL)

PCB-D-IF

A
B
C
D
E
F



Note: Unless otherwise specified.
 All PNP transistors are 2SA1037AK-R.S.
 All NPN transistors are 2SC2412K-R.S/2SD601AI-R.S.
 All diodes are 1SS254/1SS133.
 All resistors are 1/10W.
 All PNP digital transistors are DTA124EKA/RT1P241C.
 All NPN digital transistors are DTC124EKA/RT1N241C.

IC5D02 SN74ACT244NSR

INPUT		OUTPUT	
OE	A	Y	
L	H	L	H
L	L	L	L
H	X	X	Z
H	H	X	Z

H: HIGH LEVEL
 L: LOW LEVEL
 X: IMMATERIAL
 Z: HIGH IMPEDANCE

IC5D03 SN74LVTH541NSR


INPUT		OUTPUT	
OE1	OE2	A	Y
L	L	L	L
L	L	L	L
L	X	X	X
L	H	X	X
H	X	X	X
H	H	X	X

H: HIGH LEVEL
 L: LOW LEVEL
 X: IMMATERIAL
 Z: HIGH IMPEDANCE




PCB-1394 [EX]
(1/2)

(FPC-S)

G




NOTE:
All registers are 1/16w 1608
unless otherwise specified.
All IC-CHIP are 1608
unless otherwise specified.



FUNCTION TABLE (each flip-flop)

INPUTS		OUTPUT	
OE	CLK D	Q	Qn
L	↑	H	L
L	H or L	L	L
L	X	X	X

H: HIGH LEVEL
L: LOW LEVEL
X: IMMATERIAL
Z: HIGH IMPEDANCE
Qn: PREVIOUS STATUS IS OUTPUT



PCB-1394 (2/2)

