


Service Manual



* The above illustration shows CT-W704RS.

ORDER NO.
RRV1231

STEREO DOUBLE CASSETTE DECK

CT-W604RS

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model	Power Requirement	Remarks
	CT-W604RS		
KUXJ	○	AC120V	
KCXJ	○	AC120V	

CONTENTS

1. SAFETY INFORMATION	2
2. BLOCK DIAGRAM	3
3. EXPLODED VIEWS, PACKING AND PARTS LIST ..	4
4. TEST MODE	10
5. ADJUSTMENTS	12
6. FL INFORMATION	16
7. SCHEMATIC AND PCB CONNECTION DIAGRAMS	17
8. PCB PARTS LIST	31
9. IC INFORMATION	36
10. PANEL FACILITIES	40
11. SPECIFICATIONS	41

1. SAFETY INFORMATION



This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual. Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.

WARNING

Lead in solder used in this product is listed by the California Health and Welfare agency as a known reproductive toxicant which may cause birth defects or other reproductive harm (California Health & Safety Code, Section 25249.5). When servicing or handling circuit boards and other components which contain lead in solder, avoid unprotected skin contact with the solder. Also, when soldering do not inhale any smoke or fumes produced.



NOTICE

(FOR CANADIAN MODEL ONLY)

Fuse symbols  (fast operating fuse) and/or  (slow operating fuse) on PCB indicate that replacement parts must be of identical designation.

REMARQUE

(POUR MODÈLE CANADIEN SEULEMENT)

Les symboles de fusible  (fusible de type rapide) et/ou  (fusible de type lent) sur CCI indiquent que les pièces de remplacement doivent avoir la même désignation.


(FOR USA MODEL ONLY)

1. SAFETY PRECAUTIONS

The following check should be performed for the continued protection of the customer and service technician.

LEAKAGE CURRENT CHECK

Measure leakage current to a known earth ground (water pipe, conduit, etc.) by connecting a leakage current tester such as Simpson Model 229-2 or equivalent between the earth ground and all exposed metal parts of the appliance (input/output terminals, screwheads, metal overlays, control shaft, etc.). Plug the AC line cord of the appliance directly into a 120V AC 60Hz outlet and turn the AC power switch on. Any current measured must not exceed 0.5mA.



AC Leakage Test

ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE APPLIANCE TO THE CUSTOMER.

2. PRODUCT SAFETY NOTICE


Many electrical and mechanical parts in the appliance have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a Δ on the schematics and on the parts list in this Service Manual.

The use of a substitute replacement component which does not have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire, or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.

2. BLOCK DIAGRAM




3. EXPLODED VIEWS, PACKING AND PARTS LIST

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the parts. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "⊙" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

1. EXTERIOR AND PACKING


Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
	1	Main Unit	RWZ3545		46	Sheet	ZZ3-007
	2	Sub Unit	RWZ3546		47	LED Lens	PNW2019
	3	Dolby S Unit	RWX1101		48	Screw	BBZ30P060FMC
NSP	4	Transformer 2 Unit	RWZ3547		49	Screw	BBZ30P080FZK
Δ	5	Strain Relief	CM-22C		50	Screw	IBZ30P150FCU
Δ	6	Fuse (1.5A)	REK1059		51	65 Label (CT-W604RS/KUXJ only)	ORW1069
Δ	7	AC Power Cord	PDG1015		52	Screw	BCZ26P050FMC
	8	Lead Card 30P	RDD1334		53	Slide Knob	REA1078
Δ	9	Power Transformer	RTT1223		54	Screw	BSZ26P120FMC
	10	1 Mechanism Unit	RYM1237		55	Bonnet	REA1077
	11	2 Mechanism Unit	RYM1238		56	Spacer	REB1267
	12	Rubber Sheet	AEB1111	NSP	57	Spacer	REB1171
	13	Foot Assy	AEC1531		58	
	14	Eject Spring L	RBH1379		59	
	15	Door Spring L	RBH1304	NSP	60	Eject Collar	RLA1283
	16	Door Spring R	RBH1305		61	Arm Collar	RLA1290
	17	Half Pressure Spring	RBK1004	NSP	62	Earth Lead Unit	XDF-504
	18	Eject Spring R	RBH1380	NSP	63	Fuse Caution Label	RRW-111
	19	Damper Assy	REC1005	NSP	64	Transformer 1 PCB	RNZ2861
	20	Knob Spacer	REC1195	NSP	65	Warranty Card (CT-W604RS/KUXJ)	ARY1051
	21	Eject Arm L	RNE1763		66	Warranty Card (CT-W604RS/KCXJ)	ARY1039
	22	Eject Arm R	RNE1764	NSP	67	
	23	Eject Lever L	RNK2045		68	PCB Spacer	PNY-404
	24	Cord Clamper	RNH-184	NSP	69	Chassis	RNB1091
	25	Balance Knob	RAC1705		70	Connector Assy 3P	RKP1675
	26	Eject Knob L	RAC1881		71	Connector Assy 5P	RKP1677
	27	Eject Knob R	RAC1882	NSP	72	Binder	Z09-057
	28	Power Knob	RAC1883		73	Eject Lever R	RNK2046
	29	Control Knob	RAC1987				
	30	REC Knob B	RAC1788				
	31	FL Lens	RAH2376				
	32	Front Panel	RAH2507				
	33	Door Pocket L	RAH2518				
	34	Door Pocket R	RAH2517				
	35	Door Lens	RAH2435				
	36	Name Plate	RAM1007				
	37	Remain Display Paper	REE-113				
	38	Rear Panel (CT-W604RS/KUXJ)	RNA1903				
	38	Rear Panel (CT-W604RS/KCXJ)	RNA1904				
	39	Connection Cord with Mini Plug	PDE-319				
	40	Connection Cord Assy	RDE1036				
	41	Control Cord	RDE1030				
	42	Operating Instructions (English)	RRB1154				
	42	Operating Instructions (French) (CT-W604RS/KCXJ)	RRD1154				
	43	Pad	RHA1115				
	44	Pad R	RHA1116				
	45	Packing Case	RHG1631				




Exterior

CT-W604RS

NOTE: Screws adjacent to ▼ mark on the product are used for disassembly



2. 1 MECHANISM UNIT AND 2 MECHANISM UNIT



A

B

C

D

CT-W604RS

Parts List

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
	1	Plunger	RLA1288	51	Stop Ring	YE15FUC	
	2	PCB Control BLK (1 Mechanism Unit)	RXA1623	52	Spring Interlock L (2 Mechanism Unit only)	RBH1385	
	3	Push Switch	RSG1018	53	Arm Interlock L (2 Mechanism Unit only)	RNE1780	
	4	SPLF	RSN1023	54	PCB Control BLK (2 Mechanism Unit)	RXA1624	
	5	Photo-Transistor	SPI33534FG	55	Plate HD BLK (2 Mechanism Unit)	RXA1683	
	6	MTR Main BLK	RXM1081				
	7	Solenoid BLK	RXP1021				
	8	Spring Interlock R	RBH1386				
	9	Arm Interlock R	RNE1781				
	10	Chassis Base BLK	RXA1626				
	11	Spring Brake	RBH1387				
	12	Main Belt	REB1157				
	13	F/R Belt	REB1254				
	14	Lever Brake	RNK2071				
	15	F/W Assy	RXA1428				
	16	Pinch Roller BLK R	RXA1628				
	17	Pinch Roller BLK L	RXA1629				
	18	Clutch BLK Assy	RXA1631				
	19	Screw	RBA1113				
	20	Washer 2.1 × 0.25T	RBF1038				
	21	Spring Reel (L)	RBH1388				
	22	Spring Reel (R)	RBH1389				
	23	Cam Spring	RBH1393				
	24	Spacer	RLA1286				
	25	Lever F/R	RNE1782				
	26	Reel Feather	RNK2072				
	27	Reel Base	RNK2073				
	28	Play Gear (A)	RNK2074				
	29	FF Gear (A)	RNK2075				
	30	F/R Pulley	RNK2076				
	31	Clutch BLK Assy	RXA1632				
	32	Washer	WA17D040D025				
	33	Washer	WA23F068M040				
	34	Screw	PCZ20P040FMC				
	35	Screw	RBA1077				
	36	Spring HB	RBH1390				
	37	Head Base	RNE1783				
	38	Plate HD BLK (1 Mechanism Unit)	RXA1682				
	39	HD PCB 5P	RXA1635				
	40	Screw	RBA1113				
	41	Washer 2.0 × 0.3	RBE1009				
	42	Spring Arm Play	RBH1392				
	43	Spacer	RLA1286				
	44	Plate Slide	RNE1785				
	45	Cam Gear	RNK2078				
	46	Arm Play	RNK2079				
	47	Spring Cassette	RNE1786				
	48	Screw	BMZ26P040FZK				
	49	Washer	WA26D045D025				
	50	Washer	WA26D047D050				

4. TEST MODE

1. Entering the Test Mode

- To enter the test mode, set both DECK I and DECK II into the STOP mode and press the TIME/COUNT key of DECK I. RESET key of DECK I and PAUSE key of DECK II all together. (Refer to Fig. 4-1)


Exiting the Test Mode

To exit the test mode, press the RESET key of DECK I or turn off the power.

2. Tape Speed Adjustment, Auto Stop Check Mode

- The following adjustments and check are possible in the test mode.

MODE No. (Deck II Display)	Adjustment and Check (The mechanism will operate even in the "no-half" state only for this mode.)
10	<ul style="list-style-type: none"> Tape speed adjustment mode During play (except during the assist), the speed can be doubled by pressing the FAST key (FF or REW key of DECK I or II). During double speed play, the play can be returned to normal speed by pressing the FWD or REV key.
10	<ul style="list-style-type: none"> Auto stop check The RELAY mode will be turned on forcibly. But the REC is not relayed from DECK II to DECK I. Auto stop is carried out at tape end for one second only in this mode. (Usually four seconds.) Reverse is carried out as normally, but if the reverse is carried out in double speed, the tape will be played at constant speed.



3. CD SYNCHRO, SW Check Modes

- Test mode setting.

MODE No. (Deck II Display)	Key Input	LINE MUTE	REC MUTE	BIAS	Adjustment and check
20	CD SYNC	ON	ON	OFF	<ul style="list-style-type: none"> CD SYNCHRO Check Short-circuit one of the CD SYNCHRO cord's plugs. Connect the other plug to the CD SYNCHRO jack of the cassette deck. Press the CD SYNC key. If "CD SYNC" is displayed, the CD SYNCHRO mode is normal.
1 (When there is no half on the deck II side, "HALF" will be displayed.)	TIME/COUNT for Deck I	ON	ON	OFF	<ul style="list-style-type: none"> SW Check When there is no-half, the corresponding counter will display "HALF". Mistaken Erasure Detection Check When FWD recording is possible: "▶" lights up When REW recording is possible: "◀" lights up Reverse SW Check ⊞ : "I" lights up ⊞ : "II" lights up Tape Detection Check Deck II Check NORMAL : Lch -3dB lights up CR02 : Lch 0dB lights up METAL : Lch +3dB lights up Deck I Check NORMAL : Lch -20dB lights up CR02 : Lch -10dB lights up METAL : Lch -6dB lights up

BLE Adjustment Mode

Entering the BLE Adjustment Mode

Press the STOP KEY when the DECK II display is other than 10.

To set the BLE adjustment mode, press the BLE KEY of DECK II. When the key is pressed continuously, the BLE adjustment mode will change in order.

Exiting the BLE Adjustment Mode

To exit the BLE adjustment mode, press the STOP KEY. The deck will set into the mechanism operation check mode.

Deck I Display	Deck II Display	Key Input	LINE OUT	REC MUTE	BIAS	Adjustment and Check
	30	2-BLE	OFF	ON	OFF	_____
400	31XX	2-BLE	OFF	ON	OFF	<ul style="list-style-type: none"> For AUTO BLE 400 Hz OSC output level adjustment mode □ □ □ ■ □ □ ■ ■ ■ □ ■ ■ Adjust so that the meter becomes as shown in the above diagram. (LINE OUT output = -23 dBV)
10k	32XX	2-BLE	OFF	ON	OFF	<ul style="list-style-type: none"> For AUTO BLE 10 kHz OSC output level adjustment mode □ □ □ ■ □ □ ■ ■ ■ □ ■ ■ Adjust so that the meter becomes as shown in the above diagram. (LINE OUT output = -23 dBV)
12k	33XX	2-BLE	OFF	ON	OFF	<ul style="list-style-type: none"> For AUTO BLE 12 kHz OSC output level adjustment mode □ □ □-□-□-□ ■ ■ ■ □ ■ ■ Make sure that the meter becomes as shown in the above diagram (LINE OUT output = -10 dBV)
8k	34XX	2-BLE	OFF	ON	OFF	<ul style="list-style-type: none"> For AUTO BLE 8 kHz OSC output level adjustment mode □ □ □ ■ □ □ ■ ■ ■ □ ■ ■ Adjust so that the meter becomes as shown in the above diagram. (LINE OUT output = -10 dBV)
3k	35XX	2-BLE	OFF	ON	OFF	<ul style="list-style-type: none"> For AUTO BLE 3 kHz OSC output level adjustment mode □ □ □-□-□-□ ■ ■ ■ □ ■ ■ Make sure that the meter becomes as shown in the above diagram. (LINE OUT output = -23 dBV)
HPFL	36XX	2-BLE	OFF	ON	OFF	<ul style="list-style-type: none"> For BLE XD HIGH PASS FILTER Lch adjustment Input the 12.5 kHz, -10 dBV signal to LINE IN. □ □ □-□-□-□ ■ ■ ■ □ ■ ■ Adjust so that the meter becomes as shown in the above diagram.
HPFr	37XX	2-BLE	OFF	ON	OFF	<ul style="list-style-type: none"> For BLE XD HIGH PASS FILTER Rch adjustment Input the 12.5 kHz, -10 dBV signal to LINE IN. □ □ □-□-□-□ ■ ■ ■ □ ■ ■ Adjust so that the meter becomes as shown in the above diagram.

※ ■ : Indicates lit □ : Indicates OFF □-□ : Indicates lit or blinking

5. ADJUSTMENTS

1. MECHANICAL ADJUSTMENT

1.1 Door Damping Check and Adjustment

Set the door spring of the DECK I side to position (A) as shown in Fig. 5-1. Then, erect the front panel assembly vertically.

Open the doors of DECK I and DECK II at the same time. At this point, confirm that the difference between the door completely opened and the other door is within 15mm. If this standard is not satisfied install the door spring of DECK I at another position and adjust as follows:

- When the door of DECK I opens later than that of DECK II :
Change the door spring of DECK II form A to B.
- When the door of DECK I opens faster than that of DECK II :
Change the door spring of DECK I form A to B.




Fig. 5-1

1.2 Tape Speed

- Perform this adjustment in the test mode.
- TEST mode setting.

1. Press the TIME/COUNT and RESET keys of DECK I together with the PAUSE key of DECK II.
2. The speed becomes normal when the PLAY key is pressed, and double when the FF key is pressed.
3. To cancel the TEST mode, press the RESET key of DECK I.

1. Tape Speed Adjustment and Check						
No.	Deck	Mode	Test tape	Adjusting points	Specifications/Ratings (playback frequency)	Remarks
1	I	Double speed PLAY	STD-301	check	6000 Hz = 600 Hz	
2	II			VR801	Within ± 10 Hz against the measurement value of the step 1 (deck I)	
3	I	NORMAL speed PLAY	(3 KHz)	VR851	2980 Hz = 5 Hz	
4	II			VR802	Within ± 5 Hz against the measurement value of the step 3 (deck I)	




Fig. 5-2 Adjusting points

2. ELECTRICAL ADJUSTMENTS

Adjustment Conditions

1. The mechanical adjustments must be completed first.
2. The head must be cleaned and demagnetized.
3. Turn power on allow the deck to warm up for at least a few minutes before commencing any electrical adjustments.
4. The reference signal is 0 dBV = 1 Vrms.
5. Connect a 10 kΩ load resistance to the OUTPUT terminals.
6. Unless otherwise specified, the switches listed below are left in the positions indicated.
DOLBY NR : OFF
TAPE SELECTOR : NORM

Test Tapes

- STD-331E : Playback adjustments (See Fig. 5-3)
- STD-631 or STD-632 : NORMAL blank tape
- STD-621 : CrO₂ blank tape
- STD-610 : METAL blank tape

- As the reference recording level is 250 nwb/m for STD-331E, the recording level will be higher by 4 dB for STD-331B (160 nwb/m). When adjusting, pay careful attention to the type of tape used.

List of Adjustments

Playback sections

1. Head azimuth adjustment.
2. Playback level adjustment.

Recording sections

1. Bias oscillator adjustment.
2. Recording bias adjustment.
3. Recording level adjustment.
4. Level meter check.
5. AUTO BLE adjustment.

NOTE: This unit has an automatic tape selection feature.

Dolby noise reduction and HX Pro headroom extension manufactured under license from Dolby Laboratories Licensing Corporation. HX Pro originated by Bang & Olufsen. "DOLBY", the double-D symbol, and "HX PRO" are trademarks of Dolby Laboratories Licensing Corporation.




Fig. 5-3 Constants of the test tape STD-331E





Fig. 5-4 Head azimuth adjustment

PLAY BACK



RECORDING




Fig. 5-5 Frequency response zone

PLAYBACK SECTION

1. Head Azimuth Adjustment

• Turn VR101, 102 (Deck I) or VR103, 104 (Deck II) to mechanical center positions

No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment value	Remarks	
1.	PLAY	Play the 10 kHz/±20 dB section of STD-331E test tape.	Head azimuth adjustment screw. (See Fig. 5-4)	LINE OUT	Maximum playback signal level.		
2.	STOP	Lock the screw with silicon bond after completing adjustment.					

2. Playback Level Adjustment

• This adjustment determines the DOLBY NR level, and must be performed with great care.

No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment value	Remarks	
1	PLAY	Play the 315 Hz/0 dB section of the STD-331E test tape.	Deck II	VR 103 (Lch) VR 104 (Rch)	TP. 1 (Lch) TP. 2 (Rch)	-7.2 dBV	
			Deck I	VR 101 (Lch) VR 102 (Rch)			

RECORDING SECTION

1. Bias Oscillator Adjustment

No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment value	Remarks	
1.	REC	Load the STD-610 test tape with no input signal.	Deck II	L402	TP. 11 - 2	105 kHz ± 0.3 kHz	If the values on the left cannot be attained by adjusting, the value should be below 105 ± 2 kHz.

2. Recording Bias Adjustment

• After the adjustment, caution should be exercised so as not to become under bias by checking the distortion rate.

No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1.	REC	Record the 315 Hz and 10kHz signals at -26 dBV input level and playback. (STD-631 or STD-632)	Deck II	VR 453 (Lch) VR 454 (Rch)	LINE OUT	Repeatedly record, playback and adjust so that the playback level of 10 kHz signal becomes 0 dB ± 0.5 dB when compared with the 315 Hz signal.

3. Recording Level Adjustment

No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1.	REC PAUSE	Apply a 315 Hz/0 dBV signal to the line input terminals, load the STD-631 or STD-632 test tape.	REC level control volume	TP. 1 (Lch) TP. 2 (Rch)	-11.2 dBV	
2.	REC/ PLAY	Record the above signal onto the STD-631 or STD-632 test tape, and playback.	Deck II	VR 303 (Lch) VR 304 (Rch)	TP. 1 (Lch) TP. 2 (Rch)	Repeatedly record, playback and adjust so that the playback signal level becomes -11.2 dBV.
3.	REC/ PLAY	Record the above signal onto the STD-621 test tape, and playback.	Check	TP. 1 (Lch) TP. 2 (Rch)	-11.2 dBV ± 1.0 dB	
4.	REC/ PLAY	Record the above signal onto the STD-610 test tape, and playback.	Check	TP. 1 (Lch) TP. 2 (Rch)	-11.2 dBV ± 1.0 dB	

4. Level Meter Check

No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment Value	Remarks
1.	REC PAUSE	Apply a 315 Hz/±6 dBV (500 mV) signal to the Line input terminals.	REC level control volume	T.P. 1 (Lch) T.P. 2 (Rch)	Check that the level meters "0dB" light up within -7.2 dBV ± 1 dB of the signal output level.	

5. AUTO BLE Adjustment (Deck II only)

- BLE adjustment should be performed after all other adjustments are completed.
- This adjustment should be performed in the test mode.
- Entering the test mode.


For details of how to enter the test mode, refer to the "Mechanical Adjustment" section (Page 12)
• Refer to Page 11 "BLE Adjustment Mode".

No.	Mode	Input signal & test tape	Adjustment location	Measuring location	Adjustment Value	Remarks
1.		Set to test mode.	---	---	---	
2.		Press the 2 BLE XD key on the front panel.	VR552	Level meter (R channel)	Adjust so that -3 dB on the level meter turn on.	400 Hz adjustment
3.		Press the 2 BLE XD key on the front panel.	VR551			10 kHz adjustment
4.		Press the 2 BLE XD key on the front panel.	VR553			5 kHz adjustment
5.	REC PAUSE	Apply a 12kHz/0 dBV signal to the line input terminals. Load the STD631 or STD632 test tape.	LINE OUT	REC level control volume	-10 dBV	
6.		Press the 2 BLE XD key on the front panel.	VR591	Level meter (R Channel)	Adjust so that -3 dB on the level meter turn on.	12 kHz adjustment
7.		Press the 2 BLE XD key on the front panel.	VR592	Level meter (R Channel)	Adjust so that -3 dB other level meter turn on.	12 kHz adjustment

Reference: The output of LINE OUT after completing the adjustments for 400 Hz, 10kHz, 5 kHz becomes -23dBV ± 1dB. (Refer to page 11.)

6. FL INFORMATION

■ RAW1146 (V1501)




Pin Connection

PIN NO.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	
CONNECTION	F	F	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N
	1	1	P	C	G	G	G	G	C	G	G	C	G	G	C	G	G	C	C	2	1	0	9	8	C	7	6	5	4	3	2	1	C	P	2	2

- NOTE 1) F1, F2 --- Filament 4) 1G~10G --- Grid
2) NP --- No pin
3) NC --- No connection

Grid Assignment




Anode Connection

	10G	9G	8G	7G	6G	5G	4G	3G	2G	1G
P1	a	a	a	a	B1	B1	a	a	a	a
P2	b	b	b	b	B2	B2	b	b	b	b
P3	f	f	f	f	B3	B3	f	f	f	f
P4	g	g	g	g	B4	B4	g	g	g	g
P5	c	c	c	c	B5	B5	c	c	c	c
P6	e	e	e	e	B6	B6	e	e	e	e
P7	d	d	d	d	BLE	CDSYNC	d	d	d	d
P8	h, j	h, j	h, j	h, j	XD	0	h, j	h, j	h, j	h, j
P9	-	col	k	-	1	FLEX	00-	col	k	-
P12	◀	PLAY	▶	-	1	0	COPY	◀	PLAY	▶
P11	-	REC	-	-	S1	0	-	-	REC	-
P12	-	-	-	-	S2	S2	-	-	-	-

SCH-1

A



B

C

D

MAIN UNIT (CN1702)
 (→ SCH-2)


TO MAIN UNIT (CN1701)
 (← SCH-2)

DOLBY S UNIT

SCH-1


- This diagram is viewed from the gray colored foil side.
- This PCB is double sided.

DOLBY S UNIT



A-11581-A


TRANSFORMER S UNIT



TO POWER TO TRANSFORMER

- This diagram is viewed from the foil side.

SUB UNIT




- This diagram is viewed from the pink colored foil side.
- This PCB is double sided.

NOTE FOR PCB DIAGRAMS:


1. Part numbers in PCB diagrams match those in the schematic diagrams.
2. A comparison between the main parts of PCB and schematic diagrams is shown below.

Symbol in PCB Diagrams	Symbol in Schematic Diagrams	Part Name
		Transistor
		Transistor with resistor
		Field effect transistor
		Resistor array
		3-terminal regulator

DOLBY S UNIT




TRANSFORMER 2 UNIT



TO POWER TRANSFORMER

- This diagram is viewed from the mounted parts side.

SUB UNIT



EMER 2 UNIT

IC601	Q652	Q651	VR552
Q752	Q751		VR553
Q171			
Q901	IC551	Q556	VR551
Q553		Q202	VR101
Q174	Q552	Q173	VR102
Q452	Q551	Q172	VR103
IC1003	Q451	Q555	VR104
IC1005		Q554	
Q451			VR453
Q453	Q403		VR454
Q454	Q101		
			VR304
IC1004	Q102	Q304	
Q401		Q303	
			VR303
Q402	Q106	IC101	
Q105	Q331	Q302	
Q146	Q143		
Q145	Q201	Q203	
Q141	Q144	Q332	
	Q142		VR591
Q1001			
IC1001	IC601		
Q1002	IC601	Q803	VR801
		Q801	VR592
IC1002		Q805	VR802
Q1003	Q1004	Q806	
Q804	Q807	Q802	
Q855		Q857	
Q854	Q853	Q844	
Q856			VR851
Q851			
Q852			
Q772			
Q771			

MAIN UNIT


TO 1 MECHANISM
UNIT 1/2
PB HEAD

TO 2 MECHANISM
UNIT 1/2
PB HEAD

TO 1 MECHANISM
UNIT 2/2


TO 2 MECHANISM
UNIT 1/2
PB HEAD

TO 2 MECHANISM
UNIT 2/2




SUB UNIT
(RWZ3546)

NOTE: If the parts are not identified in the diagram the followings are used.




TO MAIN
UNIT (1/2)
SCH-2


MECHANISM 1 CONTROL




MECHANISM 2 CONTROL



IC501: SYSTEM CONTROL



TO MAIN
UNIT (1/2)
SCH-2
A




AC POWER CORD
 PDG1015
 AC120V/60HZ
 NEUTRAL
 LIVE

TRANSFORMER 1 PCB
 (RNZ2861)


CAUTION - FOR CONTINUED PROTECTION AGAINST RISK OF FIRE, REPLACE ONLY WITH SAME TYPE AND RATINGS ONLY.

NOTE FOR FUSE REPLACEMENT



2 MECHANISM UNIT (3/3)
(RYM1238)


MECHANISM 2 CONTROL




● NOTE FOR FUSE REPLACEMENT


CAUTION - FOR CONTINUED PROTECTION AGAINST RISK OF FIRE, REPLACE ONLY WITH SAME TYPE AND RATINGS ONLY.

TRANSFORMER 1 PCB
(RNZ2861)



TRANSFORMER 2 UNIT
(RWZ3547)





SUB UNIT (RWZ3546)


NOTE: If the parts are not identified in the diagram the followings are used.

- 1SS254
- 2SA1309A-R/S
- 2SC3311A-R/S
- DTA114TS
- DTC114TS
- XDA114ES
- XDC124ES

2. MAIN UNIT (1/2)


1 MECHANISM UNIT (1/2) (RYM1237)

2 MECHANISM UNIT (1/3) (RYM1238)



TO MAIN UNIT (2/2) (SCH-3)

MAIN UNIT(1/2)
(RWZ3545)



SIGNAL ROUTE
 ⇨ : PLAY BACK SIGNAL
 ⇩ : RECORDING SIGNAL

NOTE: If the parts are not identified in the diagram the followings are used.

- | | |
|--------------|----------|
| 1SS254 | DTC114TS |
| 2SA1309A-R/S | XDA114ES |
| 2SC3311A-R/S | XDC124ES |
| DTA114TS | |

SCH-2

TO MAIN UNIT (2/2)
(SCH-3)

8. PCB PARTS LIST

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "⊙" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47K ohm (tolerance is shown by J=5%, and K=10%).

560 Ω \rightarrow 56 \times 10¹ \rightarrow 561 RD1/8PM $\begin{matrix} \text{5} & \text{6} & \text{1} \\ \text{J} \end{matrix}$
 47k Ω \rightarrow 47 \times 10³ \rightarrow 473 RD1/4PS $\begin{matrix} \text{4} & \text{7} & \text{3} \\ \text{J} \end{matrix}$
 0.5 Ω \rightarrow OR5 RN2H $\begin{matrix} \text{0} & \text{5} \\ \text{K} \end{matrix}$
 1 Ω \rightarrow 010 RS1P $\begin{matrix} \text{0} & \text{1} & \text{0} \\ \text{K} \end{matrix}$

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62k Ω \rightarrow 562 \times 10¹ \rightarrow 5621 RN1/4PC $\begin{matrix} \text{5} & \text{6} & \text{2} & \text{1} \\ \text{F} \end{matrix}$

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
------	-----	-------------	----------	------	-----	-------------	----------

LIST OF ASSEMBLIES

NSP	MOTHER UNIT	RWM1816
	└ MAIN UNIT	RWZ3545
	└└ DOLBY S UNIT	RWX1101
	└ SUB UNIT	RWZ3546
	└ TRANSFORMER 2 UNIT	RWZ3547

DOLBY S UNIT

SEMICONDUCTORS

IC1001, IC1002	DOLBY S-TYPE IC	CXA1417Q
----------------	-----------------	----------

CAPACITORS

C1001, C1002	ELECT. CAPACITOR	CEJAR22M50-TS
C1003, C1004	ELECT. CAPACITOR	CEJA010M50-TS
C1005, C1006	CHIP CAPACITOR	CKSQYB393K50
C1007, C1008	CERAMIC CAPACITOR	CKSQYB104K25
C1009, C1010	CHIP CAPACITOR	CKSQYB223K50

C1011, C1012	CERAMIC CAPACITOR	CKSQYB681K50
C1013, C1014	CHIP CAPACITOR	CKSQYB102K50
C1015, C1016	ELECT. CAPACITOR	CEJA010M50-TS
C1017, C1018	CERAMIC CAPACITOR	CKSQYB822K50
C1019, C1020	AUDIO FILM CAPACITOR	CFTYA224J50

C1021, C1022	CERAMIC CAPACITOR	CKSQYB823K25
C1023, C1024	CERAMIC CAPACITOR	CKSQYB153K50
C1025, C1026	CERAMIC CAPACITOR	CKSQYB104K25
C1027, C1028	ELECT. CAPACITOR	CEJAR47M50-TS
C1029, C1030	ELECTR. CAPACITOR	RCH1095

C1031, C1032	ELECT. CAPACITOR	CEJAR22M50-TS
C1033, C1034	ELECT. CAPACITOR	CEJA10M50-TS
C1035, C1036	ELECTR. CAPACITOR	RCH1095
C1037, C1038	AUDIO FILM CAPACITOR	CFTYA334J50
C1039, C1040	CERAMIC CAPACITOR	CKSQYB823K25

C1041, C1042	ELECT. CAPACITOR	CEJAR47M50-TS
C1043, C1044	CERAMIC CAPACITOR	CKSQYB104K25
C1045, C1046	ELECT. CAPACITOR	CEJAR22M50-TS
C1047, C1048	CERAMIC CAPACITOR	CKSQYB473K50
C1049, C1050	CERAMIC CAPACITOR	CKSQYB153K50

C1051, C1052	ELECT. CAPACITOR	CEJA010M50-TS
C1053, C1054	CERAMIC CAPACITOR	CKSQYB822K50
C1055, C1056	CHIP CAPACITOR	CKSQYB102K50
C1059, C1060	CHIP CAPACITOR	CKSQYB222K50
C1061, C1062	CHIP CAPACITOR	CKSQYB393K50
C1063, C1064	CERAMIC CAPACITOR	CKSQYB471K50
C1065, C1066	CERAMIC CAPACITOR	CKSQYB182K50
C1067, C1068	CERAMIC CAPACITOR	CKSQYB104K25
C1069, C1072	CERAMIC CAPACITOR	CKSQYB182K50
C1073, C1074	CHIP CAPACITOR	CKSQYB223K50

C1075, C1076	ELECT. CAPACITOR	CEJAR47M50-TS
C1077, C1078	CERAMIC CAPACITOR	CKSQYB104K25
C1079, C1080	CERAMIC CAPACITOR	CKSQYB183K50
C1081, C1082	CERAMIC CAPACITOR	CKSQYB104K25
C1083, C1084	CERAMIC CAPACITOR	CKSQYB182K50

C1085, C1086	ELECT. CAPACITOR	CEJA220M25-TS
C1087, C1088	CERAMIC CAPACITOR	CKSQYB104K25
C1089, C1090	ELECT. CAPACITOR	CEJA100M25-TS
C1091, C1092	ELECT. CAPACITOR	CEJAR22M50-TS
C1093, C1094	CERAMIC CAPACITOR	CKSQYB333K50

RESISTORS

R1001, R1002	CHIP RESISTOR	RS1/10S330J
R1003, R1006	CHIP RESISTOR	RS1/10S393J
R1007, R1008	CHIP RESISTOR	RS1/10S183J
R1009, R1010	CHIP RESISTOR	RS1/10S103J
R1011, R1012	CHIP RESISTOR	RS1/10S824J

R1013, R1014	CHIP RESISTOR	RS1/10S162J
R1015, R1016	CHIP RESISTOR	RS1/10S273J
R1017, R1018	CHIP RESISTOR	RS1/10S622J
R1019, R1020	CHIP RESISTOR	RS1/10S182J
R1021, R1022	CHIP RESISTOR	RS1/10S472J

R1023, R1024	CHIP RESISTOR	RS1/10S242J
R1025, R1026	CHIP RESISTOR	RS1/10S132J
R1027, R1028	CHIP RESISTOR	RS1/10S330J
R1029, R1030	CHIP RESISTOR	RS1/10S470J
R1031, R1032	CHIP RESISTOR	RS1/10S122J

R1033, R1034	CHIP RESISTOR	RS1/10S472J
--------------	---------------	-------------

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.	Mark	No.	Description	Part No.	
R1035, R1036	CHIP RESISTOR	RS1/105242J	Q145	DIGITAL TRANSISTOR	XDA114ES	COILS AND FILTERS						
R1037, R1038	CHIP RESISTOR	RS1/105330J	Q146	DIGITAL TRANSISTOR	DTC114TS	P201, P202	FILTER	RTF1062	C323, C324	ELECT. CAPACITOR	CEAS100M50	
R1039, R1040	CHIP RESISTOR	RS1/105622J	Q171, Q172	TRANSISTOR	XDC124ES	L101, L102	COIL	RTF1099	C325	ELECT. CAPACITOR	CEAS470M16	
R1041, R1042	CHIP RESISTOR	RS1/105273J	Q173	DIGITAL TRANSISTOR	DTC114TS	L331, L332	COIL	RTF1102	C326	CERAMIC CAPACITOR	CKCYF103250	
R1043, R1044	CHIP RESISTOR	RS1/105162J	Q174	TRANSISTOR	2SA1309A	L401	RADIAL INDUCTOR	LFA121K	C327	ELECT. CAPACITOR	CEAS470M16	
R1047, R1048	CHIP RESISTOR	RS1/105153J	Q201, Q202	DIGITAL TRANSISTOR	DTC114TS	L402		RTD1048	C328, C329	ELECT. CAPACITOR	CEAS100M50	
R1049, R1050	CHIP RESISTOR	RS1/105822J	Q303	TRANSISTOR	XDC124ES	L451, L452	COIL	RTD1030	C331, C332	ELECT. CAPACITOR	CEAS47R7M50	
R1051, R1052	CHIP RESISTOR	RS1/105103J	Q303, Q304	DIGITAL TRANSISTOR	DTC114TS	CAPACITORS						
R1053, R1054	CHIP RESISTOR	RS1/105133J	Q331, Q332	TRANSISTOR	2SD2144S	C1001-C1003	CERAMIC CAPACITOR	CKCYF473Z50	C333, C334	CERAMIC CAPACITOR	CKSQYB221K50	
R1055, R1056	CHIP RESISTOR	RS1/105683J	Q341	TRANSISTOR	2SC3311A	C1004	CERAMIC CAPACITOR	CKSQYF473Z50	C337	CERAMIC CAPACITOR	CKCYF103250	
R1057, R1058	CHIP RESISTOR	RS1/105824J	Q401, Q402	TRANSISTOR	2SC1815	C1005	ELECTROLYTIC CAPACIT	RCH1116	C338	ELECT. CAPACITOR	CEAS470M16	
R1059, R1060	CHIP RESISTOR	RS1/105512J	Q403	TRANSISTOR	2SD2144S	C1006, C1007	ELECT. CAPACITOR	CEAS331M16	C401	POLYPROPYLEN	CQPA682J100	
R1061, R1062	CHIP RESISTOR	RS1/105273J	Q451	DIGITAL TRANSISTOR	XDA114ES	C1008	ELECT. CAPACITOR	CEAS100M50	C402	AUDIO FILM CAPACITOR	CFTXA223J50	
R1063, R1064	CHIP RESISTOR	RS1/105163J	Q452	TRANSISTOR	XDC124ES	C1009	ELECT. CAPACITOR	CEAS220M16	C404, C405	CERAMIC CAPACITOR	CGCYX333K25	
R1065, R1066	CHIP RESISTOR	RS1/105512J	Q453, Q454	DIGITAL TRANSISTOR	XDA114ES	C1010	CERAMIC CAPACITOR	CKSQYB471K50	C406-C408	ELECT. CAPACITOR	CEAS470M16	
R1067, R1068	CHIP RESISTOR	RS1/105242J	Q551, Q552	DIGITAL TRANSISTOR	DTC114TS	C1011	ELECT. CAPACITOR	CEAS221M50	C451, C452	CERAMIC CAPACITOR	CGCYX103K25	
R1069, R1070	CHIP RESISTOR	RS1/105203J	Q553	N-FET	2SK246	C1012	ELECT. CAPACITOR	CEAS330M35	C453, C454	CERAMIC CAPACITOR	CKSQYB821K50	
R1071, R1072	CHIP RESISTOR	RS1/105243J	Q554-Q556	DIGITAL TRANSISTOR	XDC114ES	C1013	ELECT. CAPACITOR	CEAS470M16	C455, C456	CERAMIC CAPACITOR	CGCYX223K25	
R1073-R1076	CHIP RESISTOR	RS1/105303J	Q651, Q652	TRANSISTOR	XDC124ES	C1014	ELECTROLYTIC CAPACIT	PCH1116	C457, C458	CERAMIC CAPACITOR	CKSQYF473Z50	
R1077, R1078	CHIP RESISTOR	RS1/105113J	Q751, Q752	TRANSISTOR	2SD2144S	C1015	ELECT. CAPACITOR	CEAS331M16	C459, C460	CERAMIC CAPACITOR	CCCL271K500	
R1079, R1080	CHIP RESISTOR	RS1/105512J	Q771, Q772	DIGITAL TRANSISTOR	DTA114TS	C1016	ELECT. CAPACITOR	CEAS102M6R3	C461, C462	CERAMIC CAPACITOR	RCG1005	
R1081, R1082	CHIP RESISTOR	RS1/105363J	Q801	TRANSISTOR	2SA1309A	C1017	CERAMIC CAPACITOR	CKCYF473Z50	C463	CHIP CAPACITOR	CCSQSL101J50	
R1083, R1084	CHIP RESISTOR	RS1/105303J	Q802	TRANSISTOR	XDC124ES	C102	CERAMIC CAPACITOR	CKSQYB471K50	C464	ELECT. CAPACITOR	CEASR10M50	
R1085, R1086	CHIP RESISTOR	RS1/105163J	Q803	TRANSISTOR	2SB1425	C103, C104	CERAMIC CAPACITOR	CKSQYB331K50	C465	ELECT. CAPACITOR	CEAS100M50	
R1087, R1088	CHIP RESISTOR	RS1/105822J	Q804	TRANSISTOR	XDC124ES	C105, C106	CERAMIC CAPACITOR	CKSQYB821K50	C467, C468	CHIP CAPACITOR	CKSQYB222K250	
R1089, R1090	CHIP RESISTOR	RS1/105113J	Q805	TRANSISTOR	2SB1238X	C107, C108	ELECT. CAPACITOR	CEANL101M16	C503, C504	CERAMIC CAPACITOR	CKCYF103Z50	
R1091, R1092	CHIP RESISTOR	RS1/105470J	Q806	TRANSISTOR	XDC124ES	C109, C110	AUDIO FILM CAPACITOR	CFTXA822J50	C505	CERAMIC CAPACITOR	CKCYF103Z50	
R1093, R1094	CHIP RESISTOR	RS1/105183J	Q807	TRANSISTOR	2SC3311A	C111, C112	ELECT. CAPACITOR	CEAS47R7M50	C551	ELECT. CAPACITOR	CEASR47M50	
R1095, R1096	CHIP RESISTOR	RS1/105113J	Q851	TRANSISTOR	2SA1309A	C113-C116	CHIP CAPACITOR	CCSQSL101J50	C552	CERAMIC CAPACITOR	CKCYB682K50	
OTHERS				Q852	TRANSISTOR	XDC124ES	C119, C120	ELECT. CAPACITOR	CEAS470M16	C553	CERAMIC CAPACITOR	CKCYB272K50
CN1001	CONNECTOR	6033B-082029	Q853	TRANSISTOR	2SB1425	C123, C124	CERAMIC CAPACITOR	CKSQYB391K50	C557	CERAMIC CAPACITOR	CKCYB221K50	
CN1002	CONNECTOR	6033B-072029	Q854	TRANSISTOR	XDC124ES	C127-C129	CERAMIC CAPACITOR	CKSQYF473Z50	C559	CERAMIC CAPACITOR	CGCYX333K25	
MAIN UNIT				Q855	TRANSISTOR	2SB1238X	C133-C136	ELECT. CAPACITOR	CEAS010M50	C560	CERAMIC CAPACITOR	CKCYB472K50
SEMICONDUCTORS				Q856	TRANSISTOR	XDC124ES	C141, C142	CHIP CAPACITOR	CCSQCH100D50	C561	CERAMIC CAPACITOR	CGCYX104K25
△ IC1001, IC1002	REGULATOR IC	NJM7812FA	Q857	TRANSISTOR	2SC3311A	C148, C149	CHIP CAPACITOR	CCSQCH100D50	C581, C582	ELECT. CAPACITOR	CEASR10M50	
△ IC1003	REGULATOR IC	NJM79L06A	Q901	TRANSISTOR	XDC124ES	C171, C172	ELECT. CAPACITOR	CEAS100M50	C583, C584	AUDIO FILM CAPACITOR	CFTXA102J50	
△ IC1004	REGULATOR IC	NJM78L06A	D1001	DIODE	S2VB20	C175, C176	AUDIO FILM CAPACITOR	CFTXA103J50	C591, C592	AUDIO FILM CAPACITOR	CFTXA102J50	
△ IC1005	REGULATOR IC	NJM78M05FA	D1002, D1003	DIODE	1SS254	C177, C178	AUDIO FILM CAPACITOR	CFTXA222J50	C601, C602	ELECT. CAPACITOR	CEASR22M50	
△ IC101	PB-EQ AMP IC	CXA1115BP	D1004	DIODE	1SS254	C179-C182	ELECT. CAPACITOR	CEAS47R7M50	C603, C604	ELECT. CAPACITOR	CEAS101M16	
IC171	FLEX IC	PA0059AM	D1011	DIODE	1SR35-100AVL	C183	ELECT. CAPACITOR	CEAS470M16	C605	ELECT. CAPACITOR	CEAS331M16	
IC301	DOLBY REC IC	CXA1797Q	D1012	ZENER DIODE	MTZ13.3B	C184	ELECT. CAPACITOR	CEAS101M10	C606	CERAMIC CAPACITOR	CKCYF473Z50	
IC451	DOLBY HX PRO IC	UPC1297CA	D1013	DIODE	1SR35-100AVL	C185	ELECT. CAPACITOR	CEAS47R7M50	C701, C702	ELECT. CAPACITOR	CEAS010M50	
IC501	U-COM IC	PD5308A	D141-D146	DIODE	1SS254	C186	ELECT. CAPACITOR	CEAS010M50	C703	CERAMIC CAPACITOR	CKCYF473Z50	
IC551	OP-AMP IC	XRA15218	D171-D174	DIODE	1SS254	C187-C189	ELECT. CAPACITOR	CEAS101M10	C711	CERAMIC CAPACITOR	CKSQYF473Z50	
IC581	OP-AMP IC	BA14741	D453, D454	DIODE	1SS254	C191, C198	ELECT. CAPACITOR	CEAS47R7M50	C751, C752	CHIP CAPACITOR	CCSQSL101J50	
IC601	OP-AMP IC	XRA15218N	D501, D502	DIODE	1SS254	C199	ELECT. CAPACITOR	CEAS47R7M50	C771	CERAMIC CAPACITOR	CKSQYF473Z50	
Q1001	TRANSISTOR	2SA1309A	D513, D514	DIODE	1SS254	C201, C202	AUDIO FILM CAPACITOR	CFTXA472J50	C801, C851	CHIP CAPACITOR	CKSQYB102K50	
Q1002, Q1003	TRANSISTOR	2SC3311A	D517-D524	DIODE	1SS254	C203, C204	ELECT. CAPACITOR	CEAS100M50	C901	CERAMIC CAPACITOR	CKCYF103Z50	
Q1004	DIGITAL TRANSISTOR	XDA114ES	D581, D582	DIODE	1SS254	C205	ELECT. CAPACITOR	CEAS010M50	C902	CERAMIC CAPACITOR	CKCYF473Z50	
Q101, Q102	TRANSISTOR	XDC124ES	D771	ZENER DIODE	MTZ13.9B	C301, C302	ELECT. CAPACITOR	CEASR68M50	C903	CERAMIC CAPACITOR	CKCYF103Z50	
Q105, Q106	DIGITAL TRANSISTOR	DTC114TS	D801, D851	DIODE	S5688G	C311, C312	ELECT. CAPACITOR	CEASR10M50				
Q141, Q142	N-FET	2SK373	D901-D903	DIODE	1SS254	C313, C314	AUDIO FILM CAPACITOR	CFTXA683J50				
Q143, Q144	DIGITAL TRANSISTOR	DTC114TS	D905-D907	DIODE	1SS254	C315, C316	ELECT. CAPACITOR	CEAS100M50				
RESISTORS												
		R1001	CARBON FILM RESISTOR	RD106PM362J								
		R1002	CHIP RESISTOR	RS1/105332J								
		R1003	CHIP RESISTOR	RS1/105222J								

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.	Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
R1004		CHIP RESISTOR	RS1/10S223J	R320		CHIP RESISTOR	RS1/10S223J	R559		CHIP RESISTOR	RS1/10S560J	R858, R859		CARBON FILM RESISTOR	RD1/6PM152J
R1005		CHIP RESISTOR	RS1/10S103J	R321		CHIP RESISTOR	RS1/10S203J	R560		CARBON FILM RESISTOR	RD1/6PM431J	R860		CHIP RESISTOR	RS1/10S683J
R1006		CHIP RESISTOR	RS1/10S332J	R322		CHIP RESISTOR	RS1/10S822J	R561		CHIP RESISTOR	RS1/10S242J	R861, R862		CHIP RESISTOR	RS1/10S223J
R1007, R1008		CHIP RESISTOR	RS1/10S223J	R331, R332		CARBON FILM RESISTOR	RD1/6PM491J	R563		CARBON FILM RESISTOR	RD1/6PM683J	R863		CHIP RESISTOR	RS1/10S102J
R1009		CHIP RESISTOR	RS1/10S123J	R333, R334		CHIP RESISTOR	RS1/10S912J	R564		CARBON FILM RESISTOR	RD1/6PM473J	R901		CHIP RESISTOR	RS1/10S274J
R101		CHIP RESISTOR	RS1/10S334J	R335, R336		CHIP RESISTOR	RS1/10S682J	R565		CHIP RESISTOR	RS1/10S621J	R902		CHIP RESISTOR	RS1/10S223J
R1010		CHIP RESISTOR	RS1/10S103J	R341		CARBON FILM RESISTOR	RD1/6PM222J	R566, R567		CHIP RESISTOR	RS1/10S223J	VR101-VR104		VR (22K)	RCP1046
Δ R1011		FUSIBLE RESISTOR	RFA1/4L470J	R401		CARBON FILM RESISTOR	RD1/2LMF010J	R568		CHIP RESISTOR	RS1/10S104J	VR303, VR304		VR (47K)	RCP1047
R1012, R1013		CARBON FILM RESISTOR	RD1/6PM123J	R402, R403		CHIP RESISTOR	RS1/10S123J	R570		CHIP RESISTOR	RS1/10S202J	VR453, R454		VR (22K)	RCP1046
R1014		METAL OXIDE RESISTOR	RS2LMF271J	R404		CARBON FILM RESISTOR	RD1/2LMF5R6J	R571-R574		CHIP RESISTOR	RS1/10S162J	VR551		VR (10K)	RCP1045
R102		CHIP RESISTOR	RS1/10S334J	R405		CARBON FILM RESISTOR	RD1/6PM113J	R575		CARBON FILM RESISTOR	RD1/6PM562J	VR552		VR (22K)	RCP1046
R103-R106		CHIP RESISTOR	RS1/10S653J	R406		CHIP RESISTOR	RS1/10S102J	R576-R578		CHIP RESISTOR	RS1/10S821J	VR553		VR (47K)	RCP1047
R107, R108		CHIP RESISTOR	RS1/10S151J	R407		CHIP RESISTOR	RS1/10S473J	R579, R580		CHIP RESISTOR	RS1/10S162J	VR591, VR592		VR (22K)	RCP1046
R109, R110		CHIP RESISTOR	RS1/10S273J	R408		CHIP RESISTOR	RS1/10S222J	R581, R582		CHIP RESISTOR	RS1/10S243J	VR701		VARIABLE RESISTOR	RCV1107
R111		CHIP RESISTOR	RS1/10S153J	R409		CARBON FILM RESISTOR	RD1/6PM113J	R583, R584		CARBON FILM RESISTOR	RD1/6PM101J	VR801		VR (22K)	RCP1019
R112		CARBON FILM RESISTOR	RD1/6PM153J	R410		CARBON FILM RESISTOR	RD1/2LMF330J					VR802, VR851		VR (1K)	RCP1044
R119		CARBON FILM RESISTOR	RD1/6PM104J	R451, R452		CARBON FILM RESISTOR	RD1/6PM105J	R585, R586		CHIP RESISTOR	RS1/10S133J				
R120		CARBON FILM RESISTOR	RD1/6PM222J	R453, R454		CHIP RESISTOR	RS1/10S223J	R587, R588		CHIP RESISTOR	RS1/10S103J				
R123, R124		CHIP RESISTOR	RS1/10S472J	R455, R456		CHIP RESISTOR	RS1/10S224J	R589, R590		CHIP RESISTOR	RS1/10S162J				
R125		CHIP RESISTOR	RS1/10S334J	R459, R460		CARBON FILM RESISTOR	RD1/6PM153J	R591, R592		CHIP RESISTOR	RS1/10S822J				
R126		CHIP RESISTOR	RS1/10S222J	R461, R462		CHIP RESISTOR	RS1/10S273J	R593, R594		CHIP RESISTOR	RS1/10S124J				
R141, R142		CHIP RESISTOR	RS1/10S103J	R463, R464		CHIP RESISTOR	RS1/10S563J	R595, R596		CARBON FILM RESISTOR	RD1/6PM682J				
R145		CHIP RESISTOR	RS1/10S473J	R465, R466		CHIP RESISTOR	RS1/10S114J	R597, R598		CHIP RESISTOR	RS1/10S682J				
R171, R172		CHIP RESISTOR	RS1/10S562J	R467, R468		CHIP RESISTOR	RS1/10S224J	R599		CHIP RESISTOR	RS1/10S104J				
R173, R174		CHIP RESISTOR	RS1/10S512J	R469, R470		CHIP RESISTOR	RS1/10S153J	R600		CHIP RESISTOR	RS1/10S162J				
R175		CHIP RESISTOR	RS1/10S122J	R471, R472		CHIP RESISTOR	RS1/10S433J	R601-R604		CHIP RESISTOR	RS1/10S823J				
R176		CARBON FILM RESISTOR	RD1/6PM122J	R473, R474		CHIP RESISTOR	RS1/10S223J	R605, R606		CARBON FILM RESISTOR	RD1/6PM470J				
R177, R178		CHIP RESISTOR	RS1/10S472J	R501		CHIP RESISTOR	RS1/10S223J	R607, R608		CHIP RESISTOR	RS1/10S561J				
R179		CHIP RESISTOR	RS1/10S563J	R502		CHIP RESISTOR	RS1/10S683J	R609		METAL OXIDE RESISTOR	RS2LMF750J				
R180		CHIP RESISTOR	RS1/10S102J	R503		CARBON FILM RESISTOR	RD1/6PM104J	R651		CARBON FILM RESISTOR	RD1/6PM223J				
R181		CARBON FILM RESISTOR	RD1/6PM223J	R504		CARBON FILM RESISTOR	RD1/6PM203J	R652		CHIP RESISTOR	RS1/10S223J				
R182		CARBON FILM RESISTOR	RD1/6PM122J	R505		CARBON FILM RESISTOR	RD1/6PM683J	R701, R702		CHIP RESISTOR	RS1/10S184J				
R183		CHIP RESISTOR	RS1/10S681J	R506		CHIP RESISTOR	RS1/10S274J	R703, R704		CHIP RESISTOR	RS1/10S273J				
R185, R186		CHIP RESISTOR	RS1/10S822J	R508		CHIP RESISTOR	RS1/10S683J	R707		CARBON FILM RESISTOR	RD1/6PM221J				
R187		CHIP RESISTOR	RS1/10S103J	R510, R511		CHIP RESISTOR	RS1/10S222J	R713		CARBON FILM RESISTOR	RD1/6PM222J				
R201, R202		CHIP RESISTOR	RS1/10S362J	R512		CHIP RESISTOR	RS1/10S223J	R751, R752		CHIP RESISTOR	RS1/10S152J				
R203, R204		CARBON FILM RESISTOR	RD1/6PM242J	R513-R515		CARBON FILM RESISTOR	RD1/6PM223J	R753, R754		CHIP RESISTOR	RS1/10S104J				
R205		CHIP RESISTOR	RS1/10S272J	R519, R520		CARBON FILM RESISTOR	RD1/6PM302J	R755, R756		CHIP RESISTOR	RS1/10S471J				
R206		CARBON FILM RESISTOR	RD1/6PM272J	R521, R526		CARBON FILM RESISTOR	RD1/6PM182J	R771, R772		CHIP RESISTOR	RS1/10S681J				
R207		CARBON FILM RESISTOR	RD1/6PM474J	R527		CARBON FILM RESISTOR	RD1/6PM182J	R773		CARBON FILM RESISTOR	RD1/6PM681J				
R208		CHIP RESISTOR	RS1/10S474J	R528, R529		CARBON FILM RESISTOR	RD1/6PM302J	R774, R775		CARBON FILM RESISTOR	RD1/6PM104J				
R209		CARBON FILM RESISTOR	RD1/6PM302J	R530		CARBON FILM RESISTOR	RD1/6PM182J	R801		CHIP RESISTOR	RS1/10S222J				
R210		CARBON FILM RESISTOR	RD1/6PM123J	R531		CARBON FILM RESISTOR	RD1/6PM302J	R802		CHIP RESISTOR	RS1/10S561J				
R303, R304		CARBON FILM RESISTOR	RD1/6PM392J	R532-R536		CARBON FILM RESISTOR	RD1/6PM182J	R805		CHIP RESISTOR	RS1/10S124J				
R305, R306		CARBON FILM RESISTOR	RD1/6PM472J	R537		CARBON FILM RESISTOR	RD1/6PM473J	R804, R805		CHIP RESISTOR	RS1/10S223J				
R307		CARBON FILM RESISTOR	RD1/6PM513J	R546		CHIP RESISTOR	RS1/10S223J	R806		CARBON FILM RESISTOR	RD1/6PM222J				
R311		CARBON FILM RESISTOR	RD1/6PM432J	R547		CHIP RESISTOR	RS1/10S162J	R807		CHIP RESISTOR	RS1/10S203J				
R313		CARBON FILM RESISTOR	RD1/6PM362J	R548-R550		CHIP RESISTOR	RS1/10S821J	R808, R809		CARBON FILM RESISTOR	RD1/6PM152J				
R314		CARBON FILM RESISTOR	RD1/6PM122J	R552		CHIP RESISTOR	RS1/10S153J	R810		CHIP RESISTOR	RS1/10S683J				
R315		CHIP RESISTOR	RS1/10S152J	R553		CHIP RESISTOR	RS1/10S392J	R811, R812		CHIP RESISTOR	RS1/10S223J				
R316		CARBON FILM RESISTOR	RD1/6PM682J	R554		CHIP RESISTOR	RS1/10S242J	R851		CHIP RESISTOR	RS1/10S242J				
R317		CARBON FILM RESISTOR	RD1/6PM332J	R555		CHIP RESISTOR	RS1/10S393J	R852		CHIP RESISTOR	RS1/10S661J				
R318		CARBON FILM RESISTOR	RD1/6PM392J	R556		CHIP RESISTOR	RS1/10S104J	R853		CARBON FILM RESISTOR	RD1/6PM124J				
				R557, R558		CHIP RESISTOR	RS1/10S103J	R854, R855		CHIP RESISTOR	RS1/10S223J				
								R856		CARBON FILM RESISTOR	RD1/6PM222J				
								R857		CHIP RESISTOR	RS1/10S203J				

OTHERS

SUB UNIT

SEMICONDUCTORS

SWITCHES AND RELAYS

RESISTORS

OTHERS

TRANSFORMER 2 UNIT

OTHERS


9. IC INFORMATION

The information shown in the list is basic information and may not correspond exactly to that shown in the schematic diagrams.


■ CXA1797Q (MAIN UNIT, IC301)

DOLBY B/C NR, REC EQ

● Pin Arrangement (Top view)




● Block Diagram



■ PD5308A (MAIN UNIT, IC501)

System Control IC

● Pin Arrangement (Top view)



● Pin Function


Pin No.	NAME	I/O	FUNCTION		
1	SWIN	I	Mechanism switch input pin (Shared with key scan)		
2	MEQ	O	BLE MID-EQ control pin		
3	BIASL3	O	BLE-XD L-CH BIAS control pin		
4	BIASL2	O			
5	BIASL1	O			
6	BIASL0	O	BLE-XD R-CH BIAS control pin		
7	BIASR3	O			
8	BIASR2	O			
9	BIASR1	O	BLE EQ control pin		
10	BIASR0	O			
11	EQ3	O			
12	EQ2	O	BLE LEVEL control pin		
13	EQ1	O			
14	EQ0	O			
15	LEVEL3	O	BLE BIAS control pin		
16	LEVEL2	O			
17	LEVEL1	O			
18	LEVEL0	O	Recording head selection pin ("L" in 1 mechanism recording)		
19	BIAS1	O			
20	BIAS0	O			
21	_2RSEL	O	Recording head selection pin ("L" in 1 mechanism recording)		
22	INMUTE	O	LINE input MUTE pin		
23	FSEL1	O	BLE oscillator frequency selection pin		
			Selection Frequency	FSEL 1	FSEL 0
			400Hz	H	H
24	FSEL0	O	3kHz, 8kHz	H	L
			10kHz, 12kHz	L	H

Pin No.	NAME	I/O	FUNCTION
25	1RSEL	O	Recording head selection pin ("H" in 1 mechanism recording)
26	RECHI	O	"L" when the normal tape position is selected at the recording side mechanism (Only output is executed when not used.)
27	BLEOSC	O	BLE square wave output pin
28	OSCGAIN	O	BLE oscillator gain switching pin ("L":HIGH GAIN)
29	SOL1	O	1 mechanism solenoid control pin
30	CPM1	O	1 mechanism motor control pin
31	2X1	O	2 mechanism tape speed selection pin
32	1X1	O	1 mechanism tape speed selection pin
33	REMOTE	I	Remote control signal input pin
34	POFF	I	Power OFF signal input pin ("H" when the power is OFF.)
35	XRESET	I	Reset signal input pin ("L" in reset.)
36	XCIN	I	XCIN is connected to GND.
37	XCOU	O	
38	XIN	I	Main clock connection pin (6.3 MHz)
39	XOUT	O	
40	Vss	I	Connected to GND.
41	ICDATA	O	CX1797Q serial communication pins DATA CLOCK LATCH RESET
42	ICCLK	O	
43	ICLTH	O	
44	ICRST	O	
45	KEY3	I	Key scan input pin
46	KEY2	I	
47	KEY1	I	
48	KEY0	I	
49	BIAS	O	Bias control pin ("H" in bias ON)
50	PB1	O	Playback head selection pin ("H" in 1 mechanism playback)
51	SENS2	I	2 mechanism sensing pulse input pin
52	PB2	O	PLayback head selection pin ("H" in 2 mechanism playback)
53	SOL2	O	2 mechanism solenoid control pin
54	CPM2	O	2 mechanism motor control pin
55	RMUTE	O	REC MUTE control pin ("H" when MUTE is OFF)
56	LMUTE	O	LINE MUTE control pin ("H" when MUTE is OFF)
57	TOCD	O	CD SYNC output pin
58	STANBY	O	Standby LED lighting pin
59	G0	O	FL grid scan output pin (Built-in pull-down resistor)
60	G1	O	
61	G2	O	
62	G3	O	
63	G4	O	
64	G5	O	
65	G6	O	
66	G7	O	
67	G8	O	
68	G9	O	

Pin No.	NAME	I/O	FUNCTION
69	S0	O	FL segment scan output pin (Built-in pull down resistor)
70	S1	O	
71	S2	O	
72	S3	O	
73	S4	O	
74	S5	O	
75	S6	O	
76	S7	O	
77	S8	O	
78	S9	O	
79	S10	O	
80	S11	O	
81	BLEON	O	BLE oscillator ON/OFF pin ("H" when BLE oscillator is ON)
82	MPXOFF	O	MPX FILTER ON/OFF pin ("L" when MPX FILTER is ON)
83	SENS1	I	1 mechanism sensing pulse input pin
84	NC	I	Connected to pull down resistor
85	DOLOFF	O	Dolby control pin ("H" when dolby is OFF)
86	FLEXOFF	O	FLEX IC ON/OFF control pin ("H" when FLEX is OFF)
87	MRCV	O	Meter circuit recovery control pin ("H" when recovery is FAST)
88	MGAIN	O	Meter circuit gain switching pin ("H" when high gain)
89	VEE	I	Built-in pull down resistor power supply pin
90	FROMCD	I	CD SYNC input pin
91	Vcc	I	Power supply pin (+5V)
92	SYNCJ	I	CD SYNC JACK detection pin
93	AVSS	I	A/D conversion GND
94	VREF	I	A/D conversion power supply pin (+5V)
95	NC	I	Connected to pull down resistor
96	METL	I	L-CH level meter input pin
97	METR	I	R-CH level meter input pin
98	PBNOR	O	"H" when the normal tape position is selected at the recording side mechanism (Only when not used and in output.)
99	HIDETL	I	L-CH BLE-XD high-pass filter output level input pin
100	HIDETR	I	R-CH BLE-XD high-pass filter output level input pin

10. PANEL FACILITIES

The illustration shows model CT-W704RS.



① POWER STANDBY/ON switch/indicator

The POWER switch activates the secondary transformer only. Even when the switch is in the STANDBY position, there will be a power flow to the deck's circuits as long as the power cord is connected to a power outlet. The indicator lights when the unit functions enter STANDBY, and it goes off when the power is turned on.

② FLEX button

③ DECK I counter reset button (RESET)

④ DECK I counter mode button (TIME/COUNT)

⑤ DECK I BLE XD button (Except for CT-W604RS)

⑥ DOLBY NR ON/OFF switch

⑦ (CT-W604RS only) Synchro copy button (COPY I ▶ II)

Normal: Normal speed copy

⑧ DOLBY* NR switch (B/C/S)

- *Dolby noise reduction and HX Pro headroom extension manufactured under license from Dolby Laboratories Licensing Corporation. HX Pro originated by Bang & Olufsen.*

- "DOLBY", the double-D symbol and "HX PRO" are trademarks of Dolby Laboratories Licensing Corporation.

⑨ Function display

⑩ (CT-W704RS) Synchro copy buttons (COPY I ▶ II)

NORMAL: Normal speed copy

HIGH: Double speed copy

(CT-W604RS only) Synchro copy button (COPY I ▶ II)

HIGH: Double speed copy

DECK II BLE XD button

⑪ Reverse mode switch (REV MODE RELAY/SKIP)

⑫ DECK II BLE XD button (CT-W704RS)

⑬ DECK II counter mode button (TIME/COUNT)

⑭ DECK II counter reset button (RESET)

⑮ CD-DECK SYNCHRO recording button (CD SYNC)

⑯ DECK I eject button (▲)

- If the tape is moving (recording, playback, tape winding, etc.), press the stop (■) button before pressing this button.

NOTE:

If the power is turned off while the tape is moving, the cassette door may remain locked. In this case, turn the power on before pressing the eject (▲) button.

⑰ DECK I operation buttons

- ◀ : Reverse playback
- ▶ : Forward playback
- ◀◀/MS : Fast reverse/music search
- : Stop
- ▶▶/MS : Fast forward/music search

(CT-W704RS only):

- : Recording mute

- ⏸ : Pause

- : Recording

⑰ Microphone jack (MIC) (CT-W704RS only)

⑱ MIC LEVEL control (CT-W704RS only)

⑲ Headphones jack (PHONES)

⑳ Recording level control (REC LEVEL)

㉑ DECK II operation buttons

- ◀ : Reverse playback
- ▶ : Forward playback
- ◀◀/MS : Fast reverse/music search
- : Stop
- ▶▶/MS : Fast forward/music search
- : Recording mute
- ⏸ : Pause
- : Recording

㉒ DECK II eject button (▲)

- If the tape is moving (recording, playback, tape winding, etc.), press the stop (■) button before pressing this button.

NOTE:

If the power is turned off while the tape is moving, the cassette door may remain locked. In this case, turn the power on before pressing the eject (▲) button.

11. SPECIFICATIONS

System	4-track, 2-channel stereo
Heads	
CT-W704RS	"Hard Permalloy" recording/playback head X 2 "Ferrite" erasing head X 2
CT-W604RS	"Hard Permalloy" recording/playback head X 1 "Ferrite" erasing head X 1
Motor	DC servo motor X 2
Wow and Flutter	0.09% (WRMS)
Fast Winding Time	Approximately 100 seconds (C-60 tape)

Frequency Response

-20 dB recording:	
TYPE IV (Metal) tape	20 to 20,000 Hz
TYPE II (High/CrO ₂) tape	20 to 19,000 Hz
TYPE I (Normal) tape	20 to 18,000 Hz
Signal-to-Noise Ratio	
Dolby NR OFF	More than 57 dB
Noise Reduction Effect	
Dolby B-type NR ON	More than 10 dB (at 5 kHz)
Dolby C-type NR ON	More than 19 dB (at 5 kHz)
Dolby S-type NR ON	More than 22 dB (at 5 kHz)
Harmonic Distortion	No more than 0.8% (at -4 dB; 160 nwb/m)

Input (Sensitivity)

LINE (INPUT)	100 mV (Input impedance 68 kΩ)
MIC (INPUT)	0.63 mV

(CT-W704RS: U.S. and Canadian models only)

Output (Reference level)

LINE (OUTPUT)	0.5 V (Output impedance 1.9 kΩ)
---------------	---------------------------------

Headphones	1.33 mW (Load impedance 32Ω)
------------	------------------------------

Subfunctions

- Super AUTO BLE XD tuning system
- Automatic reverse
- Double recording/playback reverse (CT-W704RS only)
- DOLBY HX PRO recording function
- DOLBY B/C/S type NR
- Relay recording (CT-W704RS only)
- Music search over ±15 selections
- Synchronized copy start
- High-speed and normal-speed copy (DECK I → DECK II)
- Relay playback/blank skip
- CD-DECK SYNCHRO recording capability
- Peak level meter with peak-hold function
- MPX FILTER (Interlocks with DOLBY NR switch) (CT-W704RS only)
- Automatic space recording mute
- Automatic tape selector
- System remote control available
- 2-mode electronic 4-digit twin tape counter
- Microphone jack (CT-W704RS: U.S. and Canadian models only)
- Headphone jack
- FLEX system

Miscellaneous

Power Requirements

U.S. and Canadian models	AC 120 V, 60 Hz
U.K. model	AC 230-240 Volts, 50/60 Hz

Power Consumption

CT-W704RS/CT-W604RS	19 W
---------------------	------

Dimensions

CT-W704RS/CT-W604RS	420(W) X 125(H) X 250(D) mm
---------------------	-----------------------------

	16-1/2(W) X 4-7/8(H) X 9-13/16(D) in.
--	---------------------------------------

Weight (without package)

CT-W704RS/CT-W604RS	4.0 kg (8 lb 13 oz)
---------------------	---------------------

Accessories

Operating instructions	
Connection cord with pin plugs	
Remote control cord	
CD-DECK SYNCHRO control cord	

NOTE:

Specifications and design subject to possible modifications without notice, due to improvements.

Service Manual



ORDER NO.
RRV1611

STEREO DOUBLE CASSETTE DECK

CT-W604RS

● Refer to the service manual RRV1231 for CT-W604RS/KUXJ.

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model	Power Requirement	The voltage can be converted by the following method.
	CT-W604RS		
SDXJ	○	AC110V/120-127V/220V/230-240V	With the voltage selector

CONTRAST OF MISCELLANEOUS PARTS

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the parts. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "⊙" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

■ CONTRAST OF SDXJ AND KUXJ TYPES


SDXJ and KUXJ types have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		KUXJ type	SDXJ type	
NSP	Mother unit	RWM1816	RWM1767	
	Main unit	RWZ3545	RWZ3548	
	Sub unit	RWZ3546	RWZ3549	
NSP	Transformer 2 unit	RWZ3547	RWZ3380	
NSP	Transformer 1 unit	Not Used	RWZ4030	*1
Δ	AC power cord	PDG1015	ADG1157	
Δ	Fuse (1.5A)	REK1059	Not Used	
Δ	Fuse (T1.6A)	Not Used	REK1024	
Δ	Strain relief	CM-22C	CM-22B	
Δ	Power transformer (AC120V)	RTT1223	Not Used	
Δ	Power transformer (AC110V/120-127V/220V/240V)	Not Used	RTT1272	
Δ	Voltage selector	Not Used	RSB1022	*2 No. 1
	Rear panel	RNA1903	RNA2087	
	Repellent Panel	Not Used	DEC1158	*2 No. 2
	Fuse Caution label	RRW111	Not Used	
	65 Label	ORW1069	Not Used	
	Packing case	RHG1631	RHG1757	
NSP	Warranty card	ARY1051	Not Used	
	Caution 220V label	Not Used	ARR1003	*2 No. 3
	Connection cord assy	RDE1002	RDE1026	
NSP	Earth lead	XDF-504	DE015VFO	
	Operating instructions (English)	RRB1154	Not Used	
	Operating instructions (English/Spanish/Chinese)	Not Used	BRE1141	

*1 : Refer to "SCHEMATIC AND PCB DIAGRAMS".

*2 : The numbers in the remarks column correspond to the numbers on the exploded diagram.
Refer to "EXPLODED VIEWS".

• EXPLODED VIEWS



■ CONTRAST OF PCB ASSEMBLIES

MAIN UNIT

RWZ3548 and RWZ3545 types have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		RWZ3545	RWZ3548	
	C1005	RCH1116 (4700 μ F/25V)	RCH1120 (4700 μ F/35V)	

SUB UNIT

Although RWZ3549 and RWZ3546 are different in part number, they consist of the same components.

TRANSFORMER 2 UNIT

Although RWZ3380 and RWZ3547 are different in part number, they consist of the same components.

TRANSFORMER 1 UNIT

Transformer 1 unit has no service part.

■ SCHEMATIC AND PCB DIAGRAMS

The differences of adjacencies to power supply are as follows.

For SDXJ type

