


# Operating Instructions

STEREO DOUBLE CASSETTE TAPE DECK

# CT-W500



Thank you for buying this Pioneer product.

Please read through these operating instructions so you will know how to operate your model properly. After you have finished reading the instructions, put them away in a safe place for future reference.

In some countries or regions, the shape of the power plug and power outlet may sometimes differ from that shown in the explanatory drawings. However, the method of connecting and operating the unit is the same.

**WARNING:** TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

## IMPORTANT NOTICE [For U.S. and Canadian models]

The serial number for this equipment is located on the rear panel. Please write this serial number on your enclosed warranty card and keep in a secure area. This is for your security.


## LINE VOLTAGE SELECTOR SWITCH

Only multi-voltage models are provided with this switch. U.S., Canadian, European, U.K., and Australian models are not provided with this switch.

Main voltages in Saudi Arabia are 127V and 220V only. Never use this model with 110V setting in Saudi Arabia.

The line voltage selector switch is on the rear panel. Before your model is shipped from the factory, this switch is set to the power requirements of the destination. Check that it is set properly before plugging the power cord into the AC outlet. If the voltage is not properly set or if you move to an area where the voltage requirements differ, adjust the selector switch as follows.

1. Disconnect the power cord.
2. Use a medium-size screwdriver.
3. Insert the screwdriver into the groove on the voltage selector, and adjust so that the tip of the arrow points to the voltage value of your area.



"This product is manufactured to comply with the radio interference requirements of EEC Directive 76/889/EEC and 82/499/EEC."

## IMPORTANT 1



The lightning flash with arrowhead, within an equilateral triangle, is intended to alert the user of the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

**CAUTION**  
RISK OF ELECTRIC SHOCK  
DO NOT OPEN

**CAUTION:**  
TO PREVENT THE RISK OF ELECTRIC SHOCK,  
DO NOT REMOVE COVER (OR BACK). NO  
USER-SERVICEABLE PARTS INSIDE. REFER  
SERVICING TO QUALIFIED SERVICE  
PERSONNEL.



The exclamation point within an equilateral triangle is intended to alert the user of the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

## IMPORTANT 2

If the apparatus is fitted with AC mains power outlet(s), see REAR PANEL FACILITIES for convenient connection of additional Hi-Fi component(s). Make all connections to the AC outlet(s) and the signal terminals first. Connect the plug to the wall socket last, make sure that the power switch is off.

## FOR USE IN THE UNITED KINGDOM

The wires in this mains lead are coloured in accordance with the following code:

Blue: Neutral  
Brown: Live

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured marking identifying the terminals in your plug proceed as follows:

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

Equipment sold in the U.K. is not supplied with a power plug.

# SAFETY INSTRUCTIONS

**READ INSTRUCTIONS** — All the safety and operating instructions should be read before the appliance is operated.

**RETAIN INSTRUCTIONS** — The operating instructions should be retained for future reference.

**HEED WARNING** — All warnings on the appliance and in the operating instructions should be adhered to.

**FOLLOW INSTRUCTIONS** — All operating and use instructions should be followed.

**WATER AND MOISTURE** — The appliance should not be used near water — for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, etc.

**LOCATION** — The appliance should be installed in a stable location.

**WALL OR CEILING MOUNTING** — The appliance should not be mounted to a wall or ceiling.

**VENTILATION** — The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; or, placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.

**HEAT** — The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.

**POWER SOURCES** — The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.

**POWER-CORD PROTECTION** — Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

**POLARIZATION** — If your purchased product is provided with a polarized power plug, please read the following instructions. This product is equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

**CLEANING** — The appliance should be cleaned only with a polishing cloth or a soft dry cloth. Never clean with furniture wax, benzine, insecticides or other volatile liquids since they may corrode the cabinet.

**POWER LINES** — An outdoor antenna should be

located away from power lines.

**NONUSE PERIODS** — The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.

**OBJECT AND LIQUID ENTRY** — Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.

**DAMAGE REQUIRING SERVICE** — The appliance should be serviced by a Pioneer authorized service center or qualified service personnel when:

- The power-supply cord or the plug has been damaged; or
- Objects have fallen, or liquid has been spilled into the appliance; or
- The appliance has been exposed to rain; or
- The appliance does not appear to operate normally or exhibits a marked change in performance; or
- The appliance has been dropped; or the enclosure damaged.

**SERVICING** — The user should not attempt to service the appliance beyond that described in the operating instructions. For all other servicing, contact the nearest Pioneer authorized service center.

**OUTDOOR ANTENNA GROUNDING** — If an outside antenna is connected to the antenna terminal, be sure the antenna system is grounded so as to provide some protection against voltage surges and built up static charges.

In the U.S.A. section 810 of the National Electrical Code, ANSI/NFPA No. 70-1984, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See Fig. A.

- a) Use No. 10 AWG (5.3 mm<sup>2</sup>) copper, No. 8 AWG (8.4 mm<sup>2</sup>) aluminum, No. 17 AWG (1.0 mm<sup>2</sup>) copperclad steel, bronze wire, or larger as ground wire.
- b) Secure antenna lead-in and ground wires to house with stand-off insulators spaced from 4 feet (1.22 meters) to 6 feet (1.83 meters) apart.
- c) Mount antenna discharge unit as closely as possible to where lead-in enters house.
- d) Use jumper wire not smaller than No. 6 AWG (13.3 mm<sup>2</sup>) copper, or the equivalent, when a separate antenna-grounding electrode is used. See NEC Section 810-21 (j).




FIG. A


## CONTENTS

Installation .....	3	Playback .....	10
Connections .....	4	Timer Recording/Playback .....	12
Front Panel Facilities .....	5	Tape Copying .....	12
How to Handle Cassette Tapes .....	8	Maintenance .....	13
Recording .....	9	Troubleshooting .....	14
		Specifications .....	16

## INSTALLATION

When installing the deck, avoid locations with high temperature or humidity, and be sure that the location is well ventilated.


Do not install the deck in locations subject to direct sunlight, or next to a space heater or other heating device, since the finish or internal parts may be affected adversely. Malfunctions may also result if the unit is installed in a humid or dusty location. Also avoid installations next to kitchen counters or other places subject to oily smoke or heat.



- If you place the unit directly on top of an amplifier, it may pick up humming or other noise. Also, if the amplifier generates a large amount of heat, the unit may break down.
- If you place the unit near a television set, it may pick up noise which may be recorded as a whistling tone on the tape. In such a case, either install the unit away from the television set or switch OFF the television set.

### DEW CONDENSATION

When the unit is moved from a cold to a warm room, or the temperature changes quickly, condensation will form on the mechanical parts and this will affect the performance of the tape. In such cases, leave the unit in a warmer atmosphere for about one hour or change the room temperature gradually.



#### NOTE:

When installing the tape deck, do not place a cloth over the top or block the ventilation openings in any other way.

### INFORMATION TO USER [FOR U.S. MODEL]

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- reorient the receiving antenna
- relocate this equipment with respect to the receiver
- move this equipment away from the receiver
- plug this equipment into a different outlet so that equipment and receiver are on different branch circuits.

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user may find the following booklet prepared by the Federal Communications Commission helpful:

"How to Identify and Resolve Radio-TV Interference Problems".

This booklet is available from the US Government Printing Office, Washington, D.C., 20402, Stock No. 004-000-00345-4.


The above instructions apply only to units which will be operated in the United States.

# CONNECTIONS

- Read through the operating instructions of the stereo components which you intend to connect to this unit.
- Turn on the power only after all the connections are completed.
- Make sure that the plugs are inserted securely. Improper connection may generate noise.

(Not provided with the European model.)

## CONTROL IN jack


Connect this jack to the CONTROL OUT jack of a component equipped with the Pioneer System Remote Control (bearing the  mark) using the supplied mini-plug cord, and you will be able to operate this component using the system remote control.

## CONTROL OUT jack

Intermediary output of remote control signals from the above input jack. Connect it to the CONTROL IN jack of another component compatible with the Pioneer System Remote Control.

## PIONEER System remote control



(Not provided in the European model.)

Connect the CONTROL IN jack to a component equipped with the PIONEER System remote control (bearing the  mark), and you will be able to operate this component from the hand-held remote controller that comes with the component connected. (Only deck II can be operated when the remote control unit is not equipped with independent keys for deck I and deck II or when there is no selection key for deck I and deck II.)


Refer to page 10 for the procedure for operating deck I with PIONEER Remote control units not designed for double decks.

## Connecting the input/output cords

Connect the plugs properly.



# FRONT PANEL FACILITIES



## 1 POWER switch

## 2 PHONES jack

## 3 REC LEVEL control

## 4 DECK II tape COUNTER/RESET button

Resets the tape counter reading to "000"  
(The TAPE COUNTER works for deck II only.)

## 5 REC BALANCE control

Balancing the recording level between left (L) and right (R) channels. (see page 9)

## 6 Record muting (MUTE) button ( O )

Press this button during recording to create a blank portion of approx. 4 seconds on the tape. The unit will then enter the recording pause mode.

## 7 PAUSE button ( ■ )

To stop tape transport momentarily during recording or playback. Press the button again to resume operation (this can also be done by pressing the ► button). This button does not work during fast-forward and rewind.

## 8 Recording (REC) button ( ● )

To start recording. The unit will not enter the recording mode if a cassette with the erasure prevention tabs removed is loaded.

Only deck II is equipped with a recording function.

## 9 EJECT button ( ▲ )

Press to open the cassette door after you have pressed the stop ( ■ ) button and the tape has stopped.

### NOTE:

If the power is turned off while the tape is moving, the cassette door may remain locked. In this case, turn the power on before pressing the EJECT button.

## 10 TIMER switch

### OFF:

Normally, be sure to leave the switch in this position.

### REC:

For timer recording (see page 12)

### PLAY:

For timer playback (see page 12)

- Recording or playback may suddenly start when turning power on with this switch in the REC or PLAY position.


## FRONT PANEL FACILITIES

### 11 DOLBY NR\* switch

Set this switch to B or C for recording with the built-in Dolby Noise Reduction system and for playback of tapes which have been recorded using the Dolby Noise Reduction system. For other tapes, set the DOLBY NR switch to OFF.

#### \*NOTE:

*When playing back Dolby-encoded tapes, always set this switch to the same position (B or C) used for recording.*

- *Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.*
- *"DOLBY" and the double-D symbol  are trademarks of Dolby Laboratories Licensing Corporation.*

### 12 RELAY/SKIP button

Press this button (turning the corresponding indicator on) to perform relay playback from deck I to deck II or from deck II to deck I.

It also activates the blank skip function, which fast forwards the tape to the beginning of the next selection, resuming playback from there, when mute playback continues for more than 15 seconds.

### 13 REPEAT button

When the REPEAT button is pressed, the tape will be rewound upon reaching its end during playback, and then will be played again. By using the REPEAT button together with the RELAY/SKIP button, continuous playback is possible as described in "Combined use of REPEAT and RELAY/SKIP functions".

### 14 SYNCHRO COPY buttons

#### NORMAL SPEED:

Starts tape copy at normal speed from deck I to deck II.

#### HIGH SPEED:

Starts tape copy at double speed (half time, from deck I to deck II.

### 15 REWIND button (◀◀)

To rewind the tape in the direction of the arrows. When pressed during playback, the unit will skip one selection each time the button is pressed, then start playback from the beginning of the next selection. (see page 11)

### 16 STOP button (■)

To stop all operations, including tape copy.


### 17 PLAY mode button (▶)

To playback the front side of the tape; that is the side whose label is visible.

### 18 FAST FORWARD button (▶▶)

To fast-forward the tape in the direction of the arrows. When pressed during playback, the unit will skip one selection each time the button is pressed, then start playback from the beginning of the next selection. (see page 11)

# OPERATING DISPLAY



## ① Deck I tape transport mode indicators

### ② DOLBY NR B/C indicator

Indicates the selected Dolby Noise Reduction system, B or C.

- When Dolby is off



- Version B on



- Version C on




## ③ SYNCHRO COPY indicator

Lights up during the tape copy operation.

- Normal-speed copy



- High-speed copy




## ④ RELAY PLAY indicator

Lights up when the RELAY/SKIP button is pressed to start relay playback.

## ⑤ REPEAT indicator

Light up when the REPEAT button is pressed to ON.

## ⑥ LEVEL meter

The  beside the +3 dB mark indicates the Dolby NR system standard level.

## ⑦ Deck II tape transport mode indicators



# HOW TO HANDLE CASSETTE TAPES

## CHECK CASSETTE BEFORE USE

Bear in mind the following points before loading cassette tapes.

### Is the tape loose, or is some of the tape outside the cassette?

If some of the tape is projecting outside the cassette shell or if it is loose, it may not enter between the capstan and pinch roller. This will prevent the tape from being supplied or damage the tape itself. In cases like these, insert a pencil into the reel hole and take up the slack (Fig. A).

Some cassette tapes come with a plastic or thick paper stopper which prevents tape slack. Remove this stopper when loading the tape and replace it after having used the cassette.

### What are the accidental erasure prevention tabs for?

A cassette is provided with these tabs so that important or otherwise valuable recordings will not be erased accidentally.

When the tab (Fig. B) on the cassette shell is broken off with the tip of a screwdriver, it will not be possible to activate the recording function even by pressing the recording (REC) button, so valuable recordings will not be erased in error. To re-record a cassette on which tabs have been broken off, simply stick a piece of doubled adhesive tape over the tab areas, as shown in Fig. C.

In case of metal tape or chrome tape, take sufficient care that the detection hole (Fig. D, Fig. E) is not blocked.

When this hole is blocked, the automatic tape selector mechanism does not operate correctly.

#### NOTE:

- The accidental erasure prevention tabs are located at the top left on both sides A and B (1 or 2), so that material on each side can be prevented from being erased in error.
- When breaking off the tab on the cassette shell is broken off, do not use magnetized screwdriver.

Turn pencil to  
remove tape slack



Fig. A

For erasure prevention  
remove ...




Fig. B




Fig. C

## AUTOMATIC TAPE SELECTOR FUNCTION

This unit (Deck I and Deck II) is equipped with an automatic tape selector function which utilizes the sensor holes on the tape cassette to determine the type of tape being used, in order to set the deck to match the tape recording bias and equalization.


## REGARDING THE TAPE CASSETTE SENSOR HOLES

- Do not use FeCr tapes with this unit.
- When using metal tapes, be sure the tape cassettes have sensor holes.



Metal tape

Fig. D



CrO2 tape

Fig. E

## TIPS ON USING CASSETTE TAPES

- Leader tape (which does not allow sound to be recorded on it) is provided at the beginning of a cassette tape. Start recording after allowing the tape to run for about 5 seconds so that the leader tape clears the recording head.
- Do not leave a cassette tape exposed to the environment. Store the cassette in its case so that dust and dirt do not adhere to the tape after use, and so that the tape is prevented from becoming slack. Choose a location which is not exposed to the effects of magnetism, dust, dirt and oil for storing the tapes.
- Because C-120 tapes are so thin, they easily jam in the pinch roller and capstan, and they are susceptible to other trouble such as irregular winding. Try not to use them with this unit.



# RECORDING

## RECORDING

(using deck II)

1. Insert a blank tape.
2. Set the DOLBY NR switch 11.
3. Press the PAUSE ( ■ ) button 7.
4. Press the recording (REC ● ) button 8.
5. Select the recording source at the stereo amplifier.
6. Adjust the recording level.  
Adjust the REC LEVEL control 3 so that the 0 dB mark in the level meter lights up. The +6 dB mark may light up momentarily.
7. Press the playback (▶) button 17.

### To Momentarily Stop Recording

- Press the PAUSE ( ■ ) button.
- To resume recording, press the PAUSE ( ■ ) button again.

### When Recording is Finished

Press the stop ( ■ ) button 16.

## SETTING THE RECORDING LEVEL

Recording level adjustment is the most important factor in achieving good recording results. A high recording level helps to improve signal-to-noise ratio and dynamic range, but if excessively high it results in distortion. On the other hand, if the level is set too low out of fear of distorting the sound, irritating tape hiss will become noticeable in the recording. Although tape characteristics differ depending on the maker and kind of tape, even for tapes of the same position, you can get the most of any tape and obtain good recordings if you adjust the recording level to a value close to the characteristics of the tape.

## Balancing the recording level between left (L) and right (R) channels

Due to the source to be recorded or the equipment used for playback, the sound volume balance between left and right may be shifted to one side. In this case perform fine adjustment using the REC BALANCE control.

Turning the control clockwise will lower the left channel level, and turning it counterclockwise will lower the level of the right channel.

### NOTES:

- When a cassette without erasure prevention tabs is loaded, the unit will not enter the recording mode when the recording button ( ● ) is pressed.
- Normally leave the REC BALANCE control in the center click position. Adjust it if you want to change the relative recording levels of the right and left channels.

## RECORD MUTING

(creating blanks on the tape)

Use this function to create the 4 seconds blanks required for the music search operation.

- Press the record muting MUTE ( ○ ) button during recording, and the unit will stop recording sound on the tape for about 4 seconds, then enter the recording pause mode.
- To create a blank more than 4 seconds long, hold the button down for the desired time. The unit will enter the recording pause mode when you release the button.
- To resume recording, press the PAUSE ( ■ ) button.

## DOLBY NR SYSTEM

The Dolby NR system is designed to reduce high-frequency noise (tape hiss) during playback. The level of low-volume, high-frequency sounds is increased during recording, and decreased by the same amount during playback to restore the original level. At the same time, high-frequency noise (most easily perceived by the human ear) is attenuated as well.

Dolby NR type B reduces high-frequency tape noise, widening the dynamic range. Type C is even more powerful, applying the noise reduction effect to a wider spectrum of frequencies from the middle range.

For playback always use the same Dolby NR setting that was used for recording.

### NOTE:

*Avoid playing back tapes recorded using the Dolby NR system with the DOLBY NR switch in the OFF position, or tapes recorded without Dolby NR system with the DOLBY NR switch in the ON position (B or C), since this does not allow faithful reproduction of the original sound.*

# PLAYBACK

## SINGLE PLAYBACK

(using only one deck, either deck I or deck II)

1. Insert a recorded tape.
2. Set the DOLBY NR switch ⑪.
3. Set the stereo amplifier for tape playback.
4. Press the playback (▶) button ⑰.
  - Playback can be performed on either deck I or deck II, only one at a time.
  - Always set the DOLBY NR switch ⑪ to the same position used for recording.

### When Playback is Finished

Press the stop (■) button.

## OPERATION OF DECK I USING A REMOTE CONTROL UNIT NOT DESIGNED FOR DOUBLE DECKS

### [Operation of deck I]

Perform the following operation when turning on the power of this unit.

Turn on the power while pressing the stop (■) button for deck I. Hold the stop (■) button down for approximately 5 seconds. Operation of deck I will now be possible.

### [Switching operation from deck I to deck II]

With deck II stopped, press the deck II stop (■) button. Operation of deck II will now be possible.

Operation can be switched back to deck I from deck II by pressing the stop (■) button of deck I again while deck I is stopped.

### NOTE:

*When a power failure or another sudden change in power supply (caused by lightning, etc.) occurs during operation of the unit, it will be reset to OFF state. To restart operation, please repeat the steps described above.*

## BLANK SKIP

(skipping unrecorded portions during playback)

Press the RELAY/SKIP button ⑫, turning the corresponding indicator on. Then blank skip function will work. In this condition, when an unrecorded portion continues for more than 15 seconds, the unit will fast-forward the tape to the beginning of the next selection, then resume playback from there.

## RELAY PLAYBACK

(using both decks for continuous playback)

1. Insert recorded tapes in both decks.
2. Set the DOLBY NR switch ⑪.
3. Set the stereo amplifier for tape playback.
4. Press the RELAY/SKIP button ⑫.  
The indicator will light up.
5. Press the playback (▶) button of the deck where playback is to start.

### When Playback is Finished




Press the stop (■) button.

- Continuous playback can be performed either from deck I to deck II or from deck II to deck I.
- For relay playback, always use tapes recorded with the same Dolby NR version, and set the DOLBY NR switch ⑪ to the same position used for recording.
- When playback finishes in one deck, and operation stops automatically at the tape end, the other deck will search for the beginning of the first selection and start playback.
- For continuous playback of different tapes, you can replace tapes already listened to during playback on the other deck. This is a convenient feature for party background music, etc.
- If mute playback continues for more than 15 seconds with the RELAY indicator lit, the blank skip function will automatically search for the beginning of the next selection and resume playback from there.  
To cancel relay playback, press the RELAY/SKIP button ⑫ once again (turning the RELAY indicator off).

## REPEAT PLAYBACK

1. Insert pre-recorded tapes into DECK I and DECK II.
2. Set the DOLBY NR switch (11).
3. Set the stereo amplifier to tape playback.
4. Press the REPEAT button (13).
5. Press the playback (▶) button (17) of the deck where playback is to start.

### Combined use of REPEAT and RELAY/SKIP functions

REPEAT	RELAY/SKIP	OPERATION
ON	ON	<p>During playback with Deck I, the tape in Deck II is rewound automatically. However, if the tape in Deck II has been rewound already, Deck II does not operate and will remain in standby mode.</p>  <p>During playback with Deck II, the tape in Deck I is rewound automatically.</p>
OFF	ON	 <p>Playback stops.</p>
ON	OFF	 <p>Tape is rewound.</p>

- One side of the tape is played repeatedly up to 12 times or until the stop (■) button is pressed. If the PAUSE button is pressed during REPEAT playback the function is reset, and when resuming playback the side of the tape will be played repeatedly for up to 12 times again.
- In the relay mode (RELAY/SKIP indicator is lit) the unit will perform repeated playback with both decks 12 times, after which the unit stops automatically.

**MS (MUSIC SEARCH)** (To return to the beginning of the present selection or advance to the next selection.)

**MUSIC SEARCH** (skipping forward or backward to playback a desired selection)

The music search function detects blanks (longer than 4 seconds) between selections, advances the tape quickly in the forward or reverse direction to find the beginning of the desired selection and automatically starts playback.

It can find a selection located up to 15 selections before or after the present position.

### During Playback

When you wish to locate the next song or beyond, press the ►► button as many times as the number of songs to be skipped.

When you wish to listen to the song being currently played from the beginning, press the ◀◀ button once. To return to the previous song or more, press the ◀◀ button as many times as the number of songs to be skipped plus one.

### From the Stop Mode

Press the playback (▶) button to set the playback mode, then press the ◀◀ or ►► button to perform music search as mentioned above.


### NOTE:

In the following cases, the music search function may be unable to properly detect blanks between selections, thus operating incorrectly. This is not, however, a sign of unit malfunction.

- When using a tape with blanks between selections less than 4 seconds long.
- When listening to tapes with long low-level parts, like classical music, or with sound breaks several seconds long within selections.
- When listening to recorded conferences or talk shows, where sound is interrupted.
- When using tapes with noise in the blanks between selections.

### How Selections are Counted

When starting music search operation from the middle of a selection by pressing the ◀◀ button, playback will return to the beginning of the present selection. To return to selections further back, press the ◀◀ button repeatedly.



# TIMER RECORDING/PLAYBACK

**TIMER RECORDING** (unattended recording from a tuner, etc.)

1. Insert a blank tape into Deck II.
2. Set the DOLBY NR switch ⑪.
3. Press the PAUSE ( ■ ) button.
4. Press the recording (REC, ● ) button.

5. Prepare the program source.

Set the amplifier input selector to tuner, and tune in the desired broadcasting station.

6. Adjust the recording level.  
(see page 9)

7. Press the stop ( ■ ) button.

8. Set the audio timer.

Power of all components will go off.

9. Set the TIMER switch to REC.

- At the preset time, power will be turned on and recording will start automatically.
- Timer recording will not work if a cassette with its erasure prevention tabs removed is loaded.
- Operation of audio timers differs depending on the model, so consult the instruction manual of your unit.

**TIMER PLAYBACK** (wake-up playback)

1. Insert the recorded tape.

- Playback will be performed on the deck having a cassette loaded.
- If tapes are loaded in both decks, relay playback will be carried out.

2. Set the DOLBY NR switch ⑪.

3. Set the stereo amplifier for tape playback  
Adjust the volume level for wake-up playback.  
(Check it by actually playing back the tape.)

4. Set the audio timer

Power of all components will go off.

5. Set the TIMER switch ⑩ to PLAY.

- At the preset time, power will be turned on and playback will start automatically.
- Playback will be performed on the deck having a tape loaded.
- If cassettes are loaded in both decks, playback will start from deck I, and continue on deck II at the tape end (relay playback).
- Always set the DOLBY NR switch ⑪ to the same position used for recording.
- Operation of audio timers differs depending on the model, so consult the instruction manual of your unit.

When not performing timer operation, always set the TIMER switch ⑩ to the OFF position. Otherwise, recording or playback might automatically start when turning power on.

## TAPE COPYING

### From Deck I to Deck II

1. Insert the recorded tape into deck I.
2. Insert a blank tape into deck II.
3. Press the desired SYNCHRO COPY button ⑭.

#### HIGH SPEED:

To copy the whole tape in a short time

#### NORMAL SPEED:

To copy the tape while listening to the sound

- When listening to the tape during operation, set the DOLBY NR switch ⑪ accordingly.

#### To Stop Copying

Press one of the stop ( ■ ) button. Both decks will stop simultaneously.

- This function copies the sound from deck I to deck II.
- You can either copy the whole tape at normal speed while listening to the sound, or at double speed to reduce recording time to one half.

- No recording level adjustment is required when copying tapes.
- The deck II tape will be an identical copy of the deck I tape, regardless of the DOLBY NR switch ⑪ position. For example, when copying a Dolby C encoded tape, the deck II tape is also recorded with Dolby C. During double speed copy, all controls become inoperative except for the stop ( ■ ) button.  
During normal speed copy, the deck II record muting (MUTE ○ ) and PAUSE ( ■ ) buttons also work.
- The tape copy mode is canceled when the end of one of the tapes is reached, so it is advisable to use tapes of the same length.
- When copying the same material several times, always record it from the original tape. Sound quality would deteriorate if recorded from a copy.

#### Note on High-Speed Copy

When performing high speed copy, an interference beep might be recorded if there is a TV nearby. In this case, use normal speed copy or turn the TV power off.

# MAINTENANCE

## CLEANING THE HEADS, PINCH ROLLERS AND CAPSTANS


The heads, pinch rollers and capstans are parts which are liable to get dirty quite easily. In particular, if the heads are dirty, the high-frequency components are not reproduced and the stereo balance is impaired, resulting in a deterioration of the playback sound. It is therefore recommended that the head section be cleaned regularly.

1. Depress the EJECT button ⑨ and open the cassette door.
2. Dip the cleaning swab into the cleaning fluid and use it to wipe the heads, capstans and pinch rollers.

### To clean the pinch rollers while they are rotating:

Press up the detector lever in the cassette door. Next, press the playback (▶) button ⑰.

- After rotating and cleaning the pinch rollers, press the stop (■) button. The cassette door will not close unless the stop mode has been set.
- The position of the detector lever is shown in the diagram.



### NOTE:

Do not load a tape after cleaning the head section until the cleaning fluid has completely dried (this takes two or three minutes).

## DEMAGNETIZING THE HEADS

After using the cassette deck over a period of time, the heads will become magnetized. The same effect is also caused by bringing a screwdriver, magnet or other magnetized object too close to the heads. This causes loss of high-frequency sound during recording and playback, and is also a cause of interference noise. The heads should be regularly demagnetized with a head demagnetizer (eraser) which can be purchased at dealer shops.

When demagnetizing the heads, be sure the cassette deck POWER switch ① is OFF. For detailed instructions, consult the operating manual for your head demagnetizer (eraser).

## CLEANING THE FRONT PANEL SECTION

Wipe the front panel and the cassette door when dusty or greasy with a soft cloth containing a small amount of ordinary liquid soap. Then, wipe dry with a cloth. Never use volatile spirits like thinners, benzine or alcohol because they will damage the panel finish.

# TROUBLESHOOTING

Incorrect operations are often mistaken for trouble and malfunctions. If you think that there is something wrong with this component, check the points below. Sometimes the trouble may lie in another component. Investigate the other components and electrical appliances being used.

If the trouble cannot be rectified even after exercising the checks listed below, ask your nearest PIONEER authorized service center or your dealer to carry out repair work.

Symptom	Probable Cause	Remedy
<b>POWER</b>		
Cannot turn power on.	<ul style="list-style-type: none"> <li>The power plug is removed.</li> <li>The component (stereo amplifier, audio timer, etc.) to which the power cord is connected is off.</li> </ul>	<ul style="list-style-type: none"> <li>Insert the power plug correctly.</li> <li>Turn the stereo amplifier or audio timer on.</li> </ul>
<b>CASSETTE DOOR</b>		
The door does not open.	<ul style="list-style-type: none"> <li>The deck is not in stop mode (tape is moving).</li> <li>Power was turned off with the tape moving.</li> </ul>	<ul style="list-style-type: none"> <li>Press the stop ( ■ ) button.</li> <li>Turn power on.</li> </ul>
The door does not close.	The cassette is not properly loaded.	Reinsert the cassette.
<b>PLAYBACK</b>		
Immediately stops.	The tape is completely wound.	Rewind the tape.
The level meter does not work.	<ul style="list-style-type: none"> <li>The tape is not recorded.</li> <li>The tape head is dirty.</li> </ul>	<ul style="list-style-type: none"> <li>Replace the tape with a recorded one.</li> <li>Clean the head (see page 13).</li> </ul>
No sound	<ul style="list-style-type: none"> <li>The amplifier input selector is not correctly set.</li> <li>The amplifier volume level setting is too low.</li> <li>Connection problems (wrong connection, cord removed, poor contact, broken wire).</li> </ul>	<ul style="list-style-type: none"> <li>Set the amplifier input selector correctly.</li> <li>Turn the amplifier volume control up.</li> <li>Connect securely.</li> </ul>
<b>RECORDING</b>		
The recording indicator does not light up.	The cassette erasure prevention tabs are broken.	<ul style="list-style-type: none"> <li>Replace the cassette with one whose tabs are intact.</li> <li>Cover the hole under the tab (see page 8).</li> </ul>
The level meter does not work.	<ul style="list-style-type: none"> <li>The REC LEVEL control is set too low.</li> <li>The amplifier is not delivering a recording signal (from the tuner, CD player, etc.).</li> <li>Wrong connection, connection cord removed, poor contact, broken wire.</li> </ul>	<ul style="list-style-type: none"> <li>Turn the REC LEVEL control up.</li> <li>Set the amplifier recording output selector correctly.</li> <li>Check connections.</li> </ul>
Immediately stops.	The tape is completely wound up.	Rewind the tape.
Cannot record	The head is dirty.	Clean the head (see page 13).



## TROUBLESHOOTING

Symptom	Probable Cause	Remedy
<b>POOR SOUND QUALITY</b>		
Unstable or interrupted sound	<ul style="list-style-type: none"> <li>• The head, pinch rollers and capstans are dirty.</li> <li>• The tape is not uniformly wound.</li> </ul>	<ul style="list-style-type: none"> <li>• Clean (see page 13).</li> <li>• Completely fast-forward or rewind the tape.</li> </ul>
No high frequencies	<ul style="list-style-type: none"> <li>• A tape recorded without Dolby NR is being played back with the DOLBY NR switch in the B or C position.</li> <li>• The head is dirty.</li> </ul>	<ul style="list-style-type: none"> <li>• Set the DOLBY NR switch to OFF.</li> <li>• Clean the head (see page 13).</li> </ul>
High frequencies are emphasized.	A Dolby-encoded tape is being played back with the DOLBY NR switch in the OFF position.	Set the DOLBY NR switch to the same position used for recording.
Sound from previous recordings remains when re-recording a tape.	The head is dirty.	Clean the head (see page 13).
The sound is distorted.	<ul style="list-style-type: none"> <li>• Recording level is too high.</li> <li>• The recorded signal itself is distorted.</li> <li>• The head is dirty.</li> </ul>	<ul style="list-style-type: none"> <li>• Turn the REC LEVEL control down when recording (see page 9).</li> <li>• Replace the cassette.</li> <li>• Clean the head (see page 13).</li> </ul>
Too much noise	<ul style="list-style-type: none"> <li>• A noisy tape is being used.</li> <li>• Incomplete insertion of a connection cord, poor contact.</li> <li>• Recording level is too low.</li> <li>• The head is dirty.</li> <li>• The head is magnetized.</li> </ul>	<ul style="list-style-type: none"> <li>• Replace the cassette.</li> <li>• Check connections.</li> <li>• Turn the REC LEVEL control up when recording (see page 9).</li> <li>• Clean the head (see page 13).</li> <li>• Demagnetize with a head demagnetizer.</li> </ul>
<b>OTHERS</b>		
The music search function does not work.	Blanks between selections are less than 4 seconds long.	Use a tape with blanks more than 4 seconds long.
Recording or playback starts suddenly when turning power on.	The TIMER switch is set to the PLAY or REC position.	Set the TIMER switch to OFF.
Cannot use the remote control system	The control cord is not connected.	Connect the control cord.

System .....	4 track, 2-channel stereo
Heads .....	
	“Hard Permalloy” playback head × 1
	“Hard Permalloy” recording/playback head × 1
	“Ferrite” erasing head × 1
Motor .....	DC servo capstan motor × 2
Wow and Flutter .....	No more than 0.06% (WRMS)
	No more than ±0.17% (DIN)
Fast winding Time .....	Approximately 100 seconds
	(C-60 tape)
Frequency Response	
– 20 dB recording:	
Normal tape .....	25 to 15,000 Hz
Chrome tape .....	25 to 16,000 Hz
Metal tape .....	25 to 16,000 Hz
Signal-to-Noise Ratio	
Dolby NR OFF .....	More than 56 dB
Noise Reduction Effect	
Dolby NR B type ON ...	More than 10 dB (at 5 kHz)
Dolby NR C type ON ...	More than 19 dB (at 5 kHz)
Harmonic Distortion .....	No more than 0.7% (0 dB)
Input (Sensitivity)	
LINE (INPUT) .....	63 mV (Input impedance 68 kΩ)
Output (Reference level)	
LINE (OUTPUT) .....	
	316 mV (Output impedance 5.2 kΩ)
Headphone .....	
	45 mV (Load impedance 8Ω)

- DOLBY B/C NR
- Music search over  $\pm 15$  selections (DECK I & DECK II)
- High-speed and normal-speed copy (DECK I  $\rightarrow$  DECK II)
- Relay playback/blank skip
- Repeat playback (I  $\leftrightarrow$  II)
- Synchronized copy start
- One-touch recording
- 3-digit mechanical tape counter (DECK II)
- 6 segments/channel LED level meter
- Automatic space record muting
- Automatic tape selector
- Headphones jack
- System remote control compatible (not provided in the European model.)
- TIMER Recording/Playback (Automatic relay on)

*Specifications and design subject to possible modifications without notice due to improvements.*

**PIONEER ELECTRONIC CORPORATION** 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan

**PIONEER ELECTRONICS [USA] INC.** 2265 East 220th Street Long Beach, California 90810 U.S.A.

P.O. BOX 1720 Long Beach, California 90801-1720 U.S.A.

**PIONEER ELECTRONICS OF CANADA, INC.** 505 Cochrane Drive, Markham, Ontario L3R 8E3 Canada

**PIONEER ELECTRONIC (EUROPE) N.V.** Keetberglaan 1, 2740 Beveren, Belgium TEL: 03/775-28-08

**PIONEER ELECTRONICS AUSTRALIA PTY. LTD.** 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL: [03] 580-9911