

JVC

SERVICE MANUAL

MODEL

3090EN

B/W PORTABLE TV WITH
STEREOPHONIC RADIO
AND CASSETTER



No. 3304
March 1979

Index

Specifications	2
Servicing in the Field	3
How to Fit the Dial Cords	3
Disassembly Instruction	3
Alignment Instructions for TV	6
Alignment Instructions for Radio	7
Parts Arrangement for Radio Alignment	9
Adjustment Instructions for Amplifier	9
Cassette Mechanism Adjustment	10
Servicing Guide	11
Mechanical Parts Diagram	13
Exploded View of Cassette Mechanism	23
Cassette Mechanism Parts List	24
Electronic Parts List for TV	25
Electronic Parts List for Radio	26
Electronic Parts List for Amp.	27
Electronic Parts List for Power Supply	28
Electronic Parts List for UHF Tuner	28
Electronic Parts List for Control Panel	29

Specifications

TV standard:	Inter-carrier system CCIR TV standard (625 lines)	● PHONO IN jack x 2 Minimum input level 3mV, input impedance 50KΩ or more
TV channels:	CCIR VHF channels 2-12 and UHF channels 21-69	● External speaker jack x 2 6 - 8Ω
Radio frequency ranges:	FM 88 - 108MHz SW 6 - 18MHz MW 510 - 1600MHz LW 150 - 350 KHz	● Headphone jack x 2 8Ω ● LINE OUT jack x 2 Output level 300mV, output impedance 10KΩ or less
Antenna:	Built-in rod antennas for TV & FM, SW radio Built-in ferrite core antenna for MW & LW radio	● Input impedance 1.5KΩ input level 0.5V Output impedance 10KΩ or less, output level 0.5V
TV tuner:	Contactless electronic tuner	6.0W (3.0W + 3.0W) EIAJ/DC AC110/220V, 50Hz, DC 13.5V
Picture tube:	4.5-inch, picture measured diagonally, 55 degree deflec- tion	(9 "R20" cells) or DC 12V with car battery cord (AP-23E)
Semi-conductors:	8 ICs, 60 Transistors, 63 Diodes	22W on AC
Speakers:	12 cm round type 6Ω 2 pcs, 5 cm round type 6Ω 2 pcs.	Approx. 6 hours on super type batteries
Built-in microphones:	condenser microphone 2 pcs.	Approx. 11 hours on ultra- super type batteries
Tape:	Philips type cassette	Approx. 21 hours on Alka- line type batteries
Track system:	4 track, 2 channel/stereo- phonic	(in the either case, the time is on continuous TV opera- tion)
Monitor system:	Variable sound monitor	Dimensions:
Rewind/Fast forward time:	Within 100 sec. (with C-60 cassette)	29.4 cm(H) without handle height x 49.7 cm (W) x 20.5 cm (D)
Wow & flutter:	less than 0.09% (WRMS)	Weight:
Recording system:	AC bias system	8.5kg (without cells) 9.4kg (with cells)
Erasing system:	AC erasing system	
S/N ratio:	50 dB	
Stop system:	full-Auto-stop system	
Frequency characteristics:	45-12,000Hz (with normal tape) 40-13,000Hz (with chrome tape)	
Input jacks:	<ul style="list-style-type: none"> ● Microphone jack x 2 Minimum input level 0.8mV, matching load impedance 50KΩ or more. ● LINE IN jack x 2 Minimum input level 110mV, input impedance 50KΩ or more 	<p>Note: Design and specifications subject to change without notice.</p> <p>Accessories</p> <p>power cord 1 head cleaning stick 2 blank cassette tape 1</p>

Servicing in the Field

Cleaning the Cabinet

Clean the external appearance of Cabinet body when necessary, with a clean soft cloth with mild soap. Don't use any solution which contains benzine or petroleum.

Raster Centering

The centering device is 2 magnetic rings located on yoke rear cover. By alternately rotating those 2 magnetic rings, the picture can be properly centered on the screen.

Deflection Yoke Adjustments

If the lines of the raster are not horizontal or corner shadows appear, loose the yoke clamp screw and rotate deflection yoke, push yoke snug up against bell of picture tube.

Vertical Height and Vertical Linearity Adjustments

When the upper or lower part of picture extends or shrinks, adjust the vertical height and vertical linearity controls alternately to fill the screen $\frac{1}{2}$ inch beyond the mask until the picture on test pattern is symmetrical from top to bottom. The height control extends (or shrinks) mainly a lower part of raster, and the linearity control an upper part.

AGC Adjustment

Adjust the AGC control when picture is a very slight bend as it's top, or excessive snow.

AGC may be adjusted by tuning the control fully counterclockwise when there is a very slight bend, and clockwise when snow.

How to Fit the Dial Cords

1. TV dial cord fitting




Fig. 1

1. Insert the drum in the shaft of variable resistor and turn it to left fully.
2. Fit the dial cord in order of above numbers.

2. Radio dial cord fitting




Fig. 2

Disassembly Instructions

1. Rear Cover Removal

1. Unfasten 12 screws fastening the rear cover indicated in Fig. 3.
2. Remove the rear cover.





Fig. 3

2. Power Supply Block Removal

1. Remove the rear cover.
2. Unfasten 3 screws fastening the power supply block indicated in Fig. 4.
3. Pull the power supply block to this side.



Power Supply Block

Fig. 4

Radio P.C. Board





Fig. 6

TV Signal P.C. Board



UHF Tuner

Wire clamp

TV Band Switch




Fig. 8

Fig. 7

3. The Printed Circuit Boards for TV and radio Removal

1. Pull out the TV tuning, Radio tuning, TV Band and Radio Band Knobs.
2. Remove the rear cover.
3. Unlock two clamps located on the low side of the antenna terminal board and pull out the antenna terminal board to this side.
4. Unfasten a screw indicated in Fig. 5 and pull out the printed circuit boards for TV and radio.




Fig. 5

4. Separating the printed circuit boards for TV and radio

1. Remove the printed circuit boards for TV and radio from the set as described in abovementioned.
2. Unfasten 2 screws from the face of the radio board. A screw fastened with a wire clamp from the back of the TV board and a screw fastened the shaft of TV Band switch.
3. Pull out the TV printed circuit board to the opposite direction against the dial scales.

5. The printed circuit board for TV Deflection Removal

1. To remove the antenna terminal board, unlock two clamps located on the low side of the board and pull out the board to this side.
2. Unfasten a screw indicated in Fig. 9 and pull out the printed circuit board for TV deflection to this side.




Fig. 9

6. The printed circuit board for Amplifier Removal

1. Pull out the REC LEVEL control knobs (L & R) and remove the antenna terminal boards from the set.
2. Unfasten 4 screws fastened the amplifier board.
3. Pull out the amplifier board and stop to pull out it on the way.
4. Unplug 3 connectors from the face of the amplifier board, pull out it again and then the amplifier board will be removed from the set.




Fig. 10




Fig. 11

7. The Cassette Mechanism Removal

1. Remove the power supply block and the printed circuit board for amplifier from the set.
2. Open the cassette door and remove a fastener joined the cassette door and lever with a (-) type screwdriver.
3. Unfasten 5 screws fastened the cassette mecha.




Fig. 12

8. The Meter Holder Removal

1. Pull out the Vol, Balance, Treble and Bass Control Knobs.
2. Remove the printed circuit board for TV deflection from the set.
3. Unfasten 3 screws fastened the meter holder.




Fig. 13




Fig. 14

9. The Picture Tube Removal

1. Remove the printed circuit boards for TV, radio and amplifier from the set.
2. Unfasten 2 screws fastened the CRT holder and then the picture tube will be removed from the set.




Fig. 15

10. The Protector Glass for Picture Tube Removal

1. Remove the picture tube from the set.
2. Push out 6 fasteners of the protector ring to the outside with a pliers and then the protector glass will be removed together with the plotector ring from the set.




Fig. 16

Alignment Instructions For TV.

B Voltage Adjustment

1. Apply the rated AC power supply.
2. Set the TV BAND switch to VHF, push in the TV of the SELECTOR switchs and turn the volume control to left fully.
3. Connect a DC voltmeter (15V range) between TP-91 and earth.
4. Adjust R512 until +5.9 volts are obtained.

PIX IF Alignment

Test Equipments

Sweep generator with markers

Sweep frequency range: 30~45 MHz

Marker generator

frequencies: 38.9, 36.8, 34.7, 33.4 MHz

Oscilloscope

Power Source

DC10.5V and 0.7V for AGC

Preparations before Alignment

1. Set the TV BAND switch to VHF and push in the TV of the SELECTOR switch.
2. Connect the capacitor and resistor (2200PF & 560Ω) in series between TP-7 and output of the sweep generator.
3. Connect the resistor (10KΩ) between TP-12 and input of the oscilloscope.
4. Supply DC +0.7V for AGC to TP-14 and DC +10.5V to TP-91.
5. Connect the base of X401 transistor to earth to stop the working of the horizontal oscillator circuit.
6. Connect a DC voltmeter between TP-4 and earth and adjust the TV tuning control until VT (tuning voltage) +8.0 volts are obtained.

Alignment procedures

1. Align the wave center to 36.8 MHz and also for maximum gain with L102.
 2. Align T102 and T103 to obtain equal height of 38.9 MHz and 34.7 MHz markers.
- T102 adjustment is marker position and T103 adjustment is slant on top of the response curve.




Fig. 17

Over-all Adjustment

Change the connection of the sweep generator only to TP-3 on PIX IF alignment above-mentioned.

Alignment Procedures

Align T4, T101, L101 to obtain the response curve illustrated in Fig. 18.




Fig. 18

If there is slant on top of the response curve, T102 may be aligned.

Sound IF Alignment

Test Equipments

Sweep generator with marker

Sweep frequency range: 5.5 MHz ± 500 KHz.

Marker generator frequency: 5.5 MHz.

Oscilloscope

Preparations before Alignment

1. Connect the resistor (10KΩ) between TP-21 and input of the oscilloscope.
2. Connect the capacitor and resistor (10000 PF & 1 KΩ) in series between TP-12 and Output of the sweep generator.
3. Connect the electrolytic capacitor (3.3 μF) between TP-22 and earth.

Alignment procedures

1. Set the TV TUNING control to any non-signal position.
2. Make strongly output of the sweep generator without suppressing the limitter.
3. Align the wave center to 5.5 MHz with L202.
4. Make weakly output of the sweep generator.
5. Align the wave center to 5.5 MHz and also for maximum gain with T201.




Fig. 19

VHF Tuner Alignment

Test Equipments

Sweep generator

Sweep frequency range: 40 MHz~250MHz

Oscilloscope

Power Source

DC10.5V and 0.7V for AGC

V.T.V.M

Preparations before Alignment

1. Connect the vertical and horizontal terminals of the oscilloscope to the correspondings of the sweep generator.
2. Align the vertical gain of oscilloscope to easy reading of 0.9 V_{p-p} on the screen of the oscilloscope.
3. Supply DC + 0.7 volts for AGC to TP-14 and DC + 10.5 volts to TP-91.
4. Set the antenna switch S1 to Ext ANT position and the TV BAND switch to VHF position.
5. Connect the V.T.V.M. to the center PIN of the TV TUNING control R37 to observe the tuning voltage (V_T).
6. Turn the RF AGC control R136 to right fully.

Alignment procedures

1) IF Trap Alignment

1. Set the TV TUNING control to low channel.
2. Connect IF signal (38.9MHz) of the sweep generator to TP-2.
3. Align L1 to obtain minimum gain for 38.9 MHz and also equal height for double humps on the top of the response curve.




Fig. 20

2) Low Channel Alignment

1. Connect RF output of the sweep generator to TP-2.
2. Set the TV TUNING control R37 to low channel and adjust it to obtain DC + 5.6 volts (V_T). At this time confirm that the collector voltage of X5 transistor is approx. DC-10V.
3. Set RF output of the sweep generator to 3CH.
4. Align the wave center to 55.2 MHz with L11 and also for maximum gain with L3 and L9.

3) High Channel Alignment

1. Set the TV TUNING control R37 to high channel and adjust it to obtain DC + 8.10 volts (V_T). At this time confirm that the collector voltage of X5 transistor is approx. DC + 5.7 V.
2. Set RF output of the sweep generator to 9CH.
3. Align the wave center to 203.25 MHz with L12 and also for maximum gain with L5 and L8.

Start Point Alignment for RF AGC

After Turning AGC control (R136) to left fully, turn it slowly to right until noises on screen of picture tube is disappeared.

The Position Adjustment for TV Channel Indicating Pointer

1. Connect a tester on resistance mode between a and b pin of J6 connector.
2. Adjust the TV TUNING control R37 to obtain the position that the tester reading is changed to maximum from 0Ω or to 0Ω from maximum.
3. Under the intactness of the TV TUNING control, set the TV channel indicating pointer to the center position of 4ch and 5ch on the TV channel indicating plate and supply a rock binding to it.

TV Channel Indicator Position Adjustments

1. Set the TV channel indicating pointer to 2 CH with the TV TUNING control.
2. Receive 2 CH broadcasting program by adjusting the resistor R30.
3. Set the pointer to 12 CH and receive 12 CH broadcasting by adjusting the resistor R32.
4. Set the pointer to 5 CH and receive 5 CH broadcasting by adjusting the resistor R29.
5. Set the pointer to 69 CH and receive 69 CH broadcasting by adjusting the resistor R31.
6. Set the pointer to 21 CH and receive 21 CH broadcasting by adjusting the resistor R34.

Alignment Instructions For Radio

MW IF Alignment

Test Equipments

Sweep generator with marker

Marker generator frequency 445, 455, 465kHz

Oscilloscope

Power supply DC 10.5V

Preparations before Alignment

1. Set "Selector" switch to Radio position, "Radio Band" switch to MW position and MW SENS/AFC switch to LOCAL/OFF position.
2. Set the variable capacitor to near the minimum capacity where no signal comes in.
3. Connect output of the sweep generator between TP-802 and earth of the variable capacitor.
4. Connect input of the oscilloscope to TP-804.
5. Supply DC +10.5V to J11.

Alignment procedure

Align the wave center to 455kHz and for symmetrize "A" and "B" shown in below and also for maximum gain with T805 and T806.




Fig. 21

FM IF Alignment

Test Equipments

Sweep generator with marker
Marker generator frequency 10.55, 10.625, 10.7,
10.775, 10.85MHz
Oscilloscope
Power supply DC-10.5V

Preparations before Alignment

- Set "Selector" switch to Radio position, "Radio Band" switch to FM position and MW SENS/AFC switch to Local/OFF position.
- Set the variable capacitor to near the minimum capacity where no signal comes in.
- Connect the capacitor and resistor (33pF & 33kΩ) in series between TP-801 and RF output of sweep generator.
- Connect input of the oscilloscope to TP-805.
- Supply DC +10.5V to J11.

Alignment procedures

- Keep the output of sweep generator to 34dB (50μV)
- Adjust the wave center to 10.7MHz with T801 (Fig. 22).
- Change input of the oscilloscope from TP-805 to TP-808.
- Adjust L804 to obtain maximum gain and also for symmetrize to left and right on S curve characteristics. (Fig. 23)




Fig. 22

Fig. 23

MW/SW/LW RF Alignment

Preparations before Alignment

- Set "Selector" switch to radio position and "Radio Band" switch to MW, SW or LW position according with chart below.
- Set MW SENS/AFC switch to DX/ON position.
- Connect output of the standard signal generator (AM modulation 400Hz, 30%) to test loop antenna. Keep the distance between the test loop antenna and built-in ferrite bar antenna to 60cm.
- Connect V.T.V.M. to speaker terminals.

Alignment Procedure

Align according to the chart below.

Step	Band	Frequency of marker	Variable capacitor Setting	Adjust	V.T.V.M. Reading	
1	MW	500kHz	Maximum	T802	Maximum	
2		1650kHz	Minimum	C842		
3		Repeat the steps 1~2.				
4		620kHz	tune to 620kHz	T803 (MW)		
5		1400kHz	tune to 1400kHz	C832		
6		Repeat the steps 4~5.				
7	SW	5.8MHz	Maximum	T809	Maximum	
8		18.6MHz	Minimum	C8118		
9		Repeat the steps 7~8.				
10		6MHz	tune to 6MHz	T811 (SW)		
11		18MHz	tune to 18MHz	C8126		
12		Repeat the steps 10~11.				
13	LW	145kHz	Maximum	T808	Maximum	
14		360kHz	Minimum	C8111		
15		Repeat the steps 13~14.				
16		160kHz	tune to 160kHz	T810 (LW)		
17		350kHz	tune to 350kHz	C8124		
18		Repeat the steps 16~17.				

Chart 1

FM RF Alignment

Preparations before Alignment

- Set "Selector" switch to radio position, "Radio Band" switch to FM position and MW SENS/AFC switch to "LOCAL/OFF" position.
- Connect a capacitor (1000pF) between output of the standard signal generator (FM modulation 400Hz, 30%) and P9.
- Connect V.T.V.M. to speaker terminals.

Alignment Procedures

Adjust according to the chart below.

Step	Frequency of marker	Variable capacitor Setting	Adjust	V.T.V.M. Reading
1	87.5MHz	Maximum	L803	Maximum
2	109MHz	Minimum	C822	Maximum
3	Repeat the steps 1. 2			
4	90MHz	tune to 90MHz	L801	Maximum
5	106MHz	tune to 106MHz	C806	Maximum
6	Repeat the steps 4. 5			

Chart 2

Parts Arrangement For Radio Alignment




Fig. 24

Adjustment Instructions For Amplifier

Before making the amplifier alignments, be sure to set the controls to the following position in the absence of any indication.

VOLUME control	→ Minimum
LOUDNESS switch	→ OFF
BASS control	→ Center position
TREBLE control	→ Center position
REC MODE switch	→ MANUAL
MODE switch	→ STEREO
METER switch	→ LEVEL
REC LEVEL control	→ MAX.
TAPE SELECT switch	→ NORMAL

1. Azimuth Adjustment

After replacing the heads, be sure to make the head azimuth adjustment.

1. Connect a V.T.V.M. to the speaker terminals.
2. Make playing with the cassette tape for the azimuth adjustment (Model VTT-658, 10 KHz) or the equivalent good.
3. Adjust the azimuth adjusting screw so that the V.T.V.M. reading is Max.
4. After adjusting, supply a lock paint to the screw.

2. Tape Speed Adjustment

1. Connect a frequency counter to the LINE OUT jack.
2. Make Playing with the cassette tape for tape speed adjustment (Model VTT-656, 3 KHz) or the equivalent good.
3. Adjust the resistor located into the motor to tune to 2985 Hz ~ 3030 Hz through the opening on the motor top.

3. Tape recording level adjustment

1. Connect the resistor (22KΩ) between the LINE OUT jacks of each channel (R.L) and earth.
2. Make playing with the cassette tape for tape recording level adjustment (Model VTT-664, 1 KHz) or the equivalent good.
3. Adjust the resistors (R612 for L CH and R712 for R CH) so that the voltages on the LINE OUT jacks of each channel are -8.2 dBs (300mV)

4. Phono Input Level Adjustment

1. Connect the resistor (22KΩ) between the LINE OUT jacks of each channel (R.L) and earth.
2. Push in the PHONO switch of the selector.
3. Add the signal (-45 dBs / 4.36mV, 1KHz) to the PHONO IN jacks of each channel.
4. Adjust the resistors (R607 for L ch and R707 for Rch) so that the voltage on the LINE OUT jacks of each channel are -8.2dBs (300mV).

5. Recording Current Adjustment

1. Push in the LINE IN switch of the selector.
2. Add the signal (-20dBs/77.5 mV, 1KHz) to the LINE IN jacks of each channel.
3. Disconnect the connection of TP-901.
4. Connect the high sensitive V.T.V.M. between TP-601 and TP-602 for L channel and, TP-701 and TP-702 for R channel.
5. Adjust the resistor (R637 for L ch and R737 for Rch) so that the V.T.V.M. readings are 0.32 mV ($32\mu A \times 10\Omega$).

6. Meter Balance Adjustment

Make the following adjustments under intact connections of the item 5. "Recording Current Adjustment".

1. Adjust the resistors (R629, 729) so that the L channel level meter pointer of this unit is indicated -3 dB.
2. Adjust the resistor (R738) so that R channel level meter pointer of this unit is indicated -3dB.

7. Bias OSC frequency and Bias Current Adjustment

Make the following adjustments under intact connections of the item 5 "Recording Current Adjustment".

1. Connect the disconnection of TP-901.
2. Connect the frequency counter between TP-601 and TP-602 for L channel and, TP-701 and TP-702 for R channel.
3. Set the BEAT CUT switch to "2" position.
4. Adjust the OSC. transformer (T901) to tune to 71.5 KHz.
5. Adjust the resistors (R625 for Lch and R725 for Rch) so that the V.T.V.M. readings are 5.0mV (500μA × 10Ω).

Cassette Mechanism Adjustment

1. Flywheel Thrust Adjustment

Loosen and adjust the adjusting screw to keep the clearance between the flywheel and the flywheel bracket within 0.2~0.4mm.

After the adjustment, apply lock paint to the adjusting screw. (Fig. 25)




Fig. 25

2. Pause Operation & The Timing Check

1) Pause Operation & the Timing Check

In the playback mode, check that the running of the cassette tape is temporarily stopped when depressing the PAUSE button and then when pressing the PAUSE button again the button is unlocked, the playback mode is restored and the running of the cassette tape is restarted.

Note: Be sure to use a C-30 type cassette tape in this checking.

2) Pause Operation & the Timing Adjustment

- a. Adjust the pinch arm lever to keep the clearance between the pinch roller and the capstan more than 0.5mm while depressing the PAUSE button. Bend the portion (C) of the pinch arm lever to the direction A in shorter clearance and the direction B in longer (Fig. 26).
- b. Adjust the pinch arm lever by bending the portion (C) to the direction A, if the rotation of reel disc is stopped or the cassette tape is pulled out from the cassette by the pinch roller rotation while depressing the PAUSE button in the playing mode (Fig. 26).




Fig. 26

3. Cue, Review Operations Check & Adjustment

1) Cue, review operation check

- a. Check that the rotation of the pinch roller is stopped and then the rotation of rewind reel base is stopped, when depressing slowly the CUE button in the play mode.

Nextly check that the rotation of the rewind reel base is started and then the pinch roller is rotated, when unlocking the depressing of the cue button.

- b. Check that the rotation of the pinch roller is stopped and then the rotation of the rewind reel base is stopped, when depressing slowly the Rewind button in the playback mode.

Nextly check that the rotation of the rewind reel base is started and then the pinch roller is rotated when unlocking the depressing of the REVIEW button.

Note: If these operations are made in the contrary order, the cassette tape will be drawn out from cassette and tangled to the pinch roller.

2) Review timing Adjustment

- a. Bend the portion (C) of the pinch arm lever to direction A if cassette tape is drawn out from the cassette on starting of the review operation. (Fig. 27)
- b. Bend the portion (C) of the pinch arm lever to the direction B, if the mechanism is made in fast forward mode on starting of the review operation. (Fig. 26)

3) Cue timing Adjustment

- a. Bend the portion (C) of the pinch arm lever to the direction A, if the cassette tape is drawn out from the cassette on starting of the review operation.

- b. Bend the portion (C) of the pinch arm lever to the direction-B, if the mechanism is made in fast forward mode on starting of the cue operation.

* After making the Review and Cue timing adjustments, be sure to make "pause operation & the timing check" of the section 2.

* Check that the clearance between the pinch roller arm and the pinch arm lever is more than 0.2mm, when depressing the REVIEW button in the recording mode (Fig. 27).




Fig. 27




Fig. 28

- * Bend the portion A of the pinch roller arm to keep the clearance between the RQ boss and the pinch roller arm plate within 0.7~1mm. (Fig. 28)

4. Head Position Adjustment

Loosen 4 adjusting screws and then adjust the position of the REC/PB and erasing heads as shown in Fig. 29.




Fig. 29

5. Clearance adjustment between Recording slide lever and Recording safety lever

Bend the portion A of the recording slide lever to keep the clearance between the recording slide lever and the recording safety lever within 0.5~0.8mm. (Fig. 30)
If the clearance is more than 0.8mm, the recorded cassette tape may be erased by operating of recording slide switch, when depressing the record button in the playback mode.




Fig. 30

6. Recording torque Adjustment

Adjust the playing torque within 40~70g-cm with the crutch plate. After cleaning the dirt on the rubber parts and the rotating portions, change the crutch spring plate to "3" position of the crutch pulley in lighter torque, and to "1" position in heavier. (Fig. 31)




Fig. 31

7. FF & REWIND Torque Adjustment

1) FF Torque Adjustment

Depress the Cue button and then suspend the torque gauge on reel disc from "take up" side.
Check that the reading is more than 60g-cm, when pulling out the gauge. If lighter, bend the portion C of the FF button lever located on reverse side of the chassis base to the direction A shown in Fig. 31.

2) REW Torque Adjustment

Depress the Review button and then suspend the torque gauge on reel disc from "supply" side. Check that the reading is more than 60g-cm, when pulling out the gauge. If lighter, bend the portion D of the REW button lever located on reverse side of the chassis base to the direction B shown in Fig. 32.




Fig. 32

Note: The Cue & Review mechanisms may be made inferior, if the levers are excessively bent in the adjustments above.

Servicing Guide

A. Deteriorating sound in playing

1. Check the REC/PB head if it is attached to dirt or dust.
2. Check the REC/PB head if it is weared off.
If so, the response will be bad in high frequency range.
3. Check that the wirings are cut or all transistors are correctly operating.

B. Crash Sound in Recording

When you make playing the recorded Demo cassette tape, the tone quality is clear.

But when you make playing the cassette tape which recorded with normal blank tape, the tone quality is bad.

In this case check as following.

1. Make monitoring the recording sound with an earphone.
2. If bad on step 1, make the checking of the broken wirings and all the transistors.
3. If OK on step 2, make the checking of the recording bias oscillator circuit.

C. WOW-FLUTTER

Check as following in increased wow and flutter.

Causes	Symptoms	Servicing
Capstan or Flywheel	<ul style="list-style-type: none"> The capstan shaft deflection Heavy rotation of the flywheel 	<ul style="list-style-type: none"> Replace the flywheel Adjust the flywheel thrust Oiling to or cleaning the flywheel
Pinch-roller	<ul style="list-style-type: none"> Rough rotation Inaccuracy angle for the capstan Non-sticking pressure to the tape 	<ul style="list-style-type: none"> Replace the pinch-roller Clean the pinch-roller Make the pinch roller in parallel with the capstan Replace or adjust the spring
Belt	<ul style="list-style-type: none"> Dirty belt Slipping belt 	<ul style="list-style-type: none"> Replace or clean the belt
Back-Tension	<ul style="list-style-type: none"> Rough back-tension 	<ul style="list-style-type: none"> Replace or oil to the back-tension spring.
Motor	<ul style="list-style-type: none"> The motor shaft deflection The motor pully dirt The pully swing 	<ul style="list-style-type: none"> Replace or clean the motor shaft Replace the take-up idler ass'y

Chart 3

D. Rewinding Faults

Causes	Symptoms	Servicing
In the playback Mode	<ul style="list-style-type: none"> Slipping between the take-up idler and the reel base The take-up idler Slipping between the take-up idler and the capstan belt 	<ul style="list-style-type: none"> Replace or adjust the take-up idler spring Clean rubber portion of the reel base Replace or clean the capstan belt
In the Cue Mode	<ul style="list-style-type: none"> The FF idler slipping The FF idler The capstan belt slipping 	<ul style="list-style-type: none"> Clean rubber portion of the idler Replace or adjust the spring Replace the idler Replace or clean the capstan belt
In the review Mode	<ul style="list-style-type: none"> The REW idler or the FF idler slipping The FF idler Capstan belt slipping 	<ul style="list-style-type: none"> Clean rubber portion of the idler Replace or adjust the spring Replace the idler Replace or clean the capstan belt

Chart 4

E. Noises

Causes	Symptoms	Servicing
Noises in the playback Mode	<ul style="list-style-type: none"> Noises from the take-up idler Noises from the rotating portions 	<ul style="list-style-type: none"> Replace the take-up idler Lubricate to the rotating parts
Noises in the Cue or REW Mode	<ul style="list-style-type: none"> Noises from the FF idler Noise from the REW idler 	<ul style="list-style-type: none"> Lubricate or replace the idler
Motor Noises	<ul style="list-style-type: none"> Noises from the motor 	<ul style="list-style-type: none"> Replace the motor

Chart 5

F. Cleaning

Be sure to clean the heads, capstan, pinch roller and other parts which come into contact with the tape with cotton tick in a little alcohol.

The dirty heads will deteriorate the sound quality and cannot erase.

G. Oiling

Make oiling 1~2 drops to the reel disc, pinch roller and rewind idler bearings 1~3 times in a year.
If oiling to too much, it will scatter the oil to the parts near and cause the rough rotating.

Mechanical Parts Diagram




Fig. 33

No.	Parts Name	Parts No.	Q'ty
1	Meter Ring	A60007-001	1
2	Protector Ring	A32100-001	1
3	Protector Glass	A60010-001	1
4	Indicator Ring	A60008-001	2
5	Indicator Glass (TV)	A60009-002	1
6	Indicator Glass (RA)	A60009-003	1
7	Speaker Ring (Right & Left Rotated)	A60004-001	2
8	Speaker Net (Right & Left Rotated)	A60005-001	2
9	Mic Cap (Right & Left Rotated)	A60002-001	2
10-1	Guard Bar (Right & Left Rotated)	A45998-001	2
-2	Cap	A45999-001	4
-3	Nut	NFZ4000ZS	4
11	Speaker Net (Right & Left Rotated)	A32099-001	2
12	Speaker Ring (Right & Left Rotated)	A32098-001	2
13-1	Guard Bar	A45997-001	1
-2	Cap	A60001-001	2
-3	Door Stopper	A60019-001	2
-4	Nut	NNZ3000ZS	2
14	Reflection Label	A45551-003	1
15	Cap	A60018-001	1
16	Cassette Door Ass'y	A20935-00B	1
17	Front Panel	A10384-00B	1
18	Counter Glass	A60012-001	1




Fig. 34

No.	Parts Name	Parts No.	Q'ty
1-1	VR. Knob	A32114-001	2
-2	VR. Knob	A32113-001	2
2	Push Knob	A60048-001	8
3-1	Lever Knob	A32112-001	4
-2	SW. Washer	A60052-001	4
4	Push Knob	A60049-001	2
5	Counter Knob	A60051-001	1
6	Select Knob	AXKP0015-30111	2
7	Tuning Knob	AXKP020-30121	2
8	Cassette Knob	A32109-003	1
9	Push Knob	A60050-001	2
10	Cassette Knob	A32109-001	4
11	Cassette Knob	A32109-002	1
12	Knob	AXKP012-30131	5




Fig. 35

No.	Parts Name	Parts No.	Q'ty
1	Rod Antenna	QZR2110-001	2
2-1	Handle Holder	A60014-001	1
-2	Handle Bushing	A60015-001	1
-3	Washer	A60092-001	1
-4	Washer	Q03091-110	1
-5	Ass'y Screw	LPSP4012ZS	1
3	Handle Ass'y	A32117-00A	1
4	Rear Cover	A10386-001	1
5-1	Handle Holder	A60014-001	1
-2	Handle Bushing	A60015-001	1
-3	Washer	Q03091-110	1
-4	Ass'y Screw	LPSP4012ZS	1
6	Screw	SDSP3012RS	2
7	Tap. Screw	SDSA4016R	10
8-1	Battery Cover	A20923-001	1
-2	Cushion (attached to reverse side)	A41455-042	1
9	Label	A31694-127	1
10	Label	A31694-126	1
11	Antenna Terminal Ass'y	A20939-00A	1




Fig. 36

No.	Parts Name	Parts No.	Q'ty
1	Relay Plate	A60045-001	2
2-1	Spring	A45507-001	2
-2	Ant. Holder	A60046-001	2
-3	Tap. Screw	SDSA3012Z	4
3	Rear Cover	A10386-001	1




Fig. 37

No.	Parts Name	Parts No.	Q'ty
1	Contact Spring	A45377-001	1
2	Contact Spring	A60047-001	2
3	Label	A31694-109	
4	Label	A31694-109	1
5	Ribbon	A4555-002	1
6	Stick Sheet	A41545-088	1
7	Battery Plate	A45375-001	1




Fig. 38

No.	Parts Name	Parts No.	Q'ty
1	Cushion	A60017-001	4




Fig. 39

No.	Parts Name	Parts No.	Q'ty
1	MIC Stand Holder	A32103-001	2
2-1	Washer	Q03091-105	1
-2	Tap. Screw	SDSA3012Z	1
3	Eject Hook	A32104-001	1
4-1	Stopper	A60026-001	1
-2	Tap. Screw	SDSA3012Z	1
5	Meter Holder	A20927-001	1
6	MIC Stand Frame	A60016-001	2
7	Speaker Spring	A60006-001	2
8	MIC Holder	A60003-001	2
9	Door Spring	A60024-001	1
10-1	Door Stopper	A60019-001	2
-2	Nut	NNZ3000ZS	2




Fig. 40

No.	Parts Name	Parts No.	Q'ty
1	Tap. Screw	SHSA3012M	2
2	Rear Cover	A10386-001	1
3	Body	A10385-00A	1
4	Front Panel	A10384-00B	1




Fig. 41

No.	Parts Name	Parts No.	Q'ty
1	Earth Spring	A45929-001	1
2	CRT Holder	A32101-001	1
3	CRT	120ANB4	1




Fig. 42




Fig. 43




Fig. 44

No.	Parts Name	Parts No.	Q'ty
1	Cassette Door Arm	A60028-001	1
2	Screw	A60031-001	1
3	Damper Bracket	A32105-001	1
4-1	Washer	Q03091-105	1
-2	Tap. Screw	SDSA3012Z	1
5-1	Washer	Q03091-105	1
-2	Tap. Screw	SBSB3005Z	1
6	Brake Shaft	V44808-001	1
7	Brake Pipe Ass'y	V44830-00A	1
8	Damper Holder	A60029-001	1
9-1	Shaft	A60030-001	1
-2	E. Ring	REE2000	1
1	Cassette Door Arm	A60028-001	(1)
10	"O" Ring	TER267508-02	1




Fig. 45

No.	Parts Name	Parts No.	Q'ty
1	Plastics Rivet	A60020-00A	1




Fig. 46




Fig. 47

No.	Parts Name	Parts No.	Q'ty
1	Ass'y Screw	LPSP3010ZS	2
2	Meter	A03092-001	1
3-1	Meter	A03092-002	1
-2	Meter Cushion	A60025-001	1
4	Meter Holder	A20927-001	1
5	Earth Plate	A60032-001	1




Fig. 48

No.	Parts Name	Parts No.	Q'ty
1-1	Record Holder	A60043-001	1
-2	Record Spring	A60042-001	1
-3	Ass'y Screw	LPSP3008ZS	2
2	Chassis Base	A10387-001	1




Fig. 49




Fig. 50

No.	Parts Name	Parts No.	Q'ty
1	Heat Sink	A20932-001	1
2-1	Transistor (X503)	2SB566(C)	1
-2	Spacer	IS-313	1
-3	Ass'y Screw	LPSP3010ZS	1
-4	Washer	WNS3000Z	1
-5	Nut	NNZ3000ZS	1
3-1	Transistor (X501)	2SD727 (P, Q)	1
-2	Spacer	N018P	1
-3	Ass'y Screw	LPSP3010ZS	1
-4	Washer	WNS3000Z	1
-5	Nut	NNZ3000ZS	1
4	Heat Sink (D501)	A45751-00A	1
5	Fuse Clip	A44594-001	2
6	Cap. Ass'y	V44399-00D	1
7	Fuse Cover	A32127-001	1
8	Binder	PU43192-1	1
9-1	Ass'y Screw	LPSP4010ZS	2
-2	Washer	WNS4000Z	2
-3	Nut	NNZ4000ZS	2
10	AC Cover	A32126-001	1
11	Ass'y Screw	LPSP3010ZS	2
12	Power Plate	A32110-002	1
13	Power Board	A20933-001	1
14	Tap. Screw	SBSB3010Z	3




Fig. 51




Fig. 52




Fig. 53

No.	Parts Name	Parts No.	Q'ty
1	Needle	A60036-001	1
2-1	Dial Plate	A20929-004	1
-2	Plate	A60039-002	1
3	Needle	A60036-001	1
4-1	Dial Plate	A20929-003	1
-2	Plate	A60039-001	1
5	Tuning Holder	A20928-002	1
6-1	Tuning Shaft	A60034-001	2
-2	E. Ring	REE4000	2
7-1	Roller	V40409-3	11
-2	S. Washer	V42562-1	11
8	Roller Holder	A60035-001	1
9-1	Tuning Drum	A32084-001	1
-2	Spring	53498-3	1
-3	Dial Cord (76cm)	A45773-001	1
10	P.W.B. Holder	A32107-001	1
11	Pulley Ass'y	A60037-00A	2
12	Dial Cord (89cm)	A45773-001	1
13-1	Tuning Drum	A32069-001	1
-2	Spring	53498-3	1
14-1	Screw	SPSP2608Z	1
-2	T. Lock Washer	WBS2600W	1

Exploded View of Cassette Mechanism




Fig. 54

Cassette Mechanism Parts List

Symbol No.	Parts No.	Parts Name	Symbol No.	Parts No.	Parts Name
1	1312 0181	Chassis Ass'y	56	REE1500	E Ring (ϕ 1.5)
2	268 0503	Record Safety Lever	57	REE1900	E Ring (ϕ 1.9)
3			58	REE2000	E Ring (ϕ 2)
4	713 0482	Head Panel Ass'y	59	REE2500	E Ring (ϕ 2.5)
5	48 0408	Head Spring	60	REE3200	E Ring (ϕ 3.2)
6			61	REE4000	E Ring (ϕ 4)
7	408 0413	Panel Spring	62		
8	18 0606	Panel Spring	63		Vinyle Tube (ϕ 3.5 x 24)
9	408 0405	Review/Cue Spring	64		
10	408 0411	Head Panel Collar	65	706 1501	Washer
11			66		
12	829 0481	Pinch Roller Ass'y	67	878 0920	Washer (M2)
13	668 0501	Pinch Roller Spring	68	03 1503	Oil Washer
14	1238 0791	Clutch Sub Ass'y	69		FL Washer
15	408 0792B	Clutch Arm Ass'y	70	EG-510AD-TZ	Motor
16	408 0704	Clutch Plate	71	MP-390356	Counter
17	973 0701	Clutch Pulley	72	THC00487-0B	R/P Head
18	542 0705	Clutch Shaft	73	V03078-044	Erasing Head
19	408 0706	Clutch Spring Holder	74	1312 1202	Shield Plate
20	408 0712	Clutch Spring Stopper	75	1247 1211	Tube
21			76	1019 0102	Pack Holder Spring
22	238 0406	Arm Spring	77	1312 0291	Push Button Ass'y
23	58 0503	Clutch Felt	78	1279 0301	Slide Lever
24	03 0601	Take-Up Idler	79	1105 0202	Slide Lever Collar
25	970 0701	Washer	80	132 0303	Safety Spring
26	668 0891	FF Idler Arm Ass'y	81	1312 0301	Slide Lever
27	58 1316	Center Spring	82	238 1305	Slide Spring
28	408 0804	FF Plate	83		
29	408 0810	FF Spring	84		
30	408 0815	Rewind Actuator	85	542 0408	Slide Lever
31	408 0810	Rewind Spring	86	09 0302	Slide Lever Collar
32			87	572 0695	Reel Disk Ass'y
33	408 0901	Brake Arm	88	04 0508	Tension Spring
34	408 0902	Arm Spring	89	408 0720	Clutch Spring
35	408 0903	Arm Actuator	90	369 0701	FL Block
36			91	446 0701	Earth Plate
37	970 1081	Rewind Arm Ass'y	92		
38	211 0902	Rewind Idler	93	10501201	Motor Bracket
39	02 0905B	Idler Spring	94	1045 1202	Main Belt
40	878 0902	LE Spring	95	58 1009	Motor Collar
41	1191 1105	FL Capstan	96	58 1006	Motor Rubber
42	408 1195	FL Holder Ass'y	97		
43	06 0405	Thrust Spring	98	973 1202M	Motor Pulley
44	408 1405	Auto Lever	99	58 1011	Rubber
45	542 1401	Auto Lever Collar	100	1312 1303	Lock Lever
46			101	1312 1304	Lock Collar
47			102	96 0805	Lock Spring
48	LPSP2005Z	Screw (M2 x 5)	103		
49	SPSX2006Z	Screw (M2 x 6)	104	1312 1301	Eject Bracket
50			105	1312 1302	Slide Lever
51	LPSP2604Z	Screw (M2.6 x 4)	106	408 0411	Eject Collar
52	SDSP2604Z	Screw (M2.6 x 4)	107	96 0806	Slide Spring
53	SPSP2610Z	Screw (M2.6 x 10)	108	408 1407	Lever Spring
54		Tapping Screw (M3 x 5)	109		
55	REE1200	E Ring (ϕ 1.2)	110	408 1581	Slide Lever Ass'y

Symbol No.	Parts No.	Parts Name	Symbol No.	Parts No.	Parts Name
111	408 1515	Lever Spring	136	SPST2604Z	T. Screw (M2.6 x 4)
112	408 1503	Arm Lever	137		FH. Screw (M3 x 5)
113	238 1304	Lever Collar	138	LPSP2608Z	Screw (M2.6 x 8)
114	1312 1601	Counter Bracket	139	SPST2606Z	T. Screw (2.6 x 6)
115	1239 1408	Counter Belt	140	SPSP2003Z	Screw (M2 x 3)
116	MSW-0086	Leaf Switch	141		
117			142	SPST3006Z	G. Tapping (3 x 6)
118	542 1881	Pause Lever Ass'y	143	11 0505	Nylon Washer
119	542 1803	Lever Spring	144	048 0713	Nylon Washer
120	542 1801	Pause Lever	145	03 1501	Washer (ϕ 2.6 x ϕ 7.5 x 0.5t)
121	408 0807	RQ. Lever	146		
122	408 0806	RQ. Plate	147	03 1307	Cord Clamp
123	408 0305	Stopper B	148	446 0901	Cord Clamp
124	89 0401	R/P Head Collar	149	268 0515	Stopper
125	463 0402	E.H. Stud	150		
126	408 0811	Lever Spring	151	668 1408	RP. Bracket
127	1312 1401	Switch Bracket	152	668 1485	Solenoid Coil Ass'y
128	1312 1402	Insulator	153	668 1481	Solenoid Lever Ass'y
129	SPST26005Z	Tapping (2.6 x 5)	154	973 1401	Pause Switch
130	SDSP2606Z	Screw (M2.6 x 6)	155	408 0715	Nylon Washer
131	SPSP2011Z	Screw (M2 x 11)	156	408 0716	Nylon Washer
132	SPSP2012Z	Screw (M2 x 12)			
133	LPSP2605Z	Screw (M2.6 x 5)			
134					
135	SPSP2606Z	Screw (M2.6 x 6)			

Electronic Parts List For TV.

Symbol No.	Parts No.	Description	Symbol No.	Parts No.	Description
Transistor					
X1	2SC1779-A	RF. Amp.	L101	A45742-00B	S. Trap Coil Ass'y
X2	2SC1215	Mixer	L102	A45412-00B	2nd. Pix. IF Coil
X3	2SC1730	VHF OSC.	L103	A04725-15	Peaking Coil
X4	2SD468(C)	Vol. Reg.	L104	A04872-82	Peaking Coil
X5	2SA844(C)	VHF (Low-High) SW	L105	A04376-151A	Peaking Coil
X101	2SC1674(L,M)	1st. Pix. IF Amp.	L106	A04376-181A	Peaking Coil
X102	2SC1674(L,M)	2nd. Pix. IF Amp.	L107	A04376-271A	Peaking Coil
X103	2SC1906	3rd. Pix. IF Amp.	L201	A04376-470A	Peaking Coil
X104	2SC454(C)	Video Amp.	L202	A60090-00B	Sound Det. Coil Ass'y
X105	2SD637(Q,R)	AGC Amp.	L401	A44897-00C	Hor. OSC. Coil Ass'y
X106	2SD637(Q,R)	AGC Amp.	L402,404	A04359-500	Choke Coil
X107	2SD637(Q,R)	RF. AGC Amp.	L403	A04368-001	Linearity Coil
X108	2SC1890(E)	Video Out.	L301,302,	A32124-00A	Def. Yoke Ass'y
X201	2SD637(Q,R)	Muting Drive	T4	A45379-00C	Conv. Trans. Ass'y
X202	2SD637(Q,R)	Muting Drive	T101	A45380-00B	1st. Pix. IF Trans. Ass'y
X203	2SD787(C,D)	Muting SW	T102	A45314-00A	3rd. Pix. IF Trans. Ass'y
X301	2SB642(R)	Sync. Sep.	T103	A45315-00A	4th. Pix. IF Trans. Ass'y
X302	2SC458(C)	Vert. OSC.	T201	A44586-A	Sound IF Trans. Ass'y
X303	2SD637(S)	Vert. Drive	T401	A32123-00A	HV Trans. Ass'y
X304	2SD787(E)01	Vert. Out.	Variable Resistors		
X305	2SB738(C)	Vert. Out.	R29,30	QVP2A0B-024	Sub-Tuning
X306	2SD637(Q,R)	CRT Protector	R31	QVP2A0B-014	20kΩB
X401	2SC458(C)	Hor. OSC.	R32,34	QVP2A0B-025	Sub-Tuning
X402	2SC945L(P,Q)	Hor. Drive	R136	QVP2A0B-053	200kΩB
X403	2SC2556A	Hor. Out.	R153	QVG0A3B-025Z	AGC
ICs			R155	QVG0A3C-013Z	5kΩB
IC1	MPC574J	Vol. Reg.	R208	QVP5A0B-054	Bright
IC8	HA11229	S. IF Amp. & Det.	R313	QVF4A2B-025	200kΩB
Diodes			R321	QVP2A0B-054	Contrast
D1,2,4,5,7, 8,10,17,18 19,20	1S2222	Band Switch Diode	R326	QVP2A0B-053	50kΩB
D6,9,11	MA320G2V	Variable Capacitance Diode	R435	QVZ3504-017	V. Hold
D12	1S188AM	Diode			200kΩB
D13	HZ7A2L	Zener Diode			50kΩB
D14,15,203, 204	1S2076V	Diode			V. Height
D16	1S2076	Diode			V. Lin
D101	1N60TF1	Diode			5kΩB
D102,103,21	HV23GBLV	Diode			Focus
D301,304, 401~405	1N34ATF1	Diode			10MΩB
D302	HV23G-13	Diode	Resistors		
D303	HV70-02	Diode	R315	A04383-001	P. Thermistor
D406,408	10E2(V)	Silicon Power Diode	R328	A04292-107	N. Thermistor
D407	RH1ALF	Silicon Power Diode	R412	A04292-102	N. Thermistor
CRT			Electrolytic Capacitors		
V1	120ANB4	Picture Tube	C48	QET61AR-476	47μF
Coils & Transformers			C125	QET61AR-107	100μF
L1	A44900-13-5	RF Coil	C132,135,209	QET61HR-475	10WV
L2	A44900-11-1	RF Coil	C134,411	QET61CR-227	50WV
L3,7,9,13	A44900-49-5	RF Coil	C139	QET61AR-227	16WV
L5	A44899-5-5	RF Coil	C211,318	QET61CR-336	10WV
L6	A44899-3-1	RF Coil	C213,303,313	QET61HR-105	50WV
L8	A44899-7-2	RF Coil	C215,405,407	QET61HR-335	16WV
L10	A44900-9-2	RF Coil	C301,316,414	QET61CR-477	3.3μF
L11	A44900-25-5	RF Coil	C309,311	QEE51AK-106	470μF
L12	A44900-5-1	RF Coil	C312,413,418	QET61HR-106	10μF
Capacitors			C314	QET61CR-107	100μF
			C404	QET62AR-105	1μF
			C419	QET61HR-476	47μF
			C423	QET61JR-335	3.3μF
			C425,428	QET61CR-108	63WV
					1000μF
C.R. Blocks			Capacitors		
			C416	QFP32XK-332	Polypropylene Capacitor
			C417	QFP32XK-822	Polypropylene Capacitor
			CR1	A03008-017	C18, R8
			CR2	A03008-013	C27, R19
			CR101	A03008-013	C106, R104

Symbol No.	Parts No.	Description	Symbol No.	Parts No.	Description
CR102	A03008-013	C111, R108	P7	QMV5002-005 A31989-00D	Connector CRT Socket Ass'y
Speakers					
	EAS-16P51SC	6Ω Woofer 16 cm	S1	QSS2201-031	Slide Switch
	EAS-5PH50SU	6Ω Tweeter 5 cm	S2	QSR6082-202	Rotary Switch
Sockets & Plug (Connector)					
J5	A03085-00C	5P Connector Ass'y	CF101	A04306-B	Ceramic Filter
J7	A03085-00F	5P Connector Ass'y	CF201	A04355-00B	Ceramic Filter
J9	A03083-00H	3P Connector Ass'y	SEP1	A45743-00A	U-V Separator
J10	A03085-00G	5P Connector Ass'y		QMP3950-183	Power Cord with Plug
P4	A41267-B	Plug Ass'y		QZR2110-001	Rod Antenna
P6	QMV5003-008	Connector			
Miscellaneous					

Electronic Parts List For Radio

Symbol No.	Parts No.	Description	Symbol No.	Parts No.	Description
Transistor					
X801	2SC461(B)	FM RF Amp.	L803	A60097-00A	RF Coil
X802	2SC1675(L)	FM OSC.	L804	A45986-00A	FM Det. Coil
X803	2SC1674(L)	FM Mixer	L805	A04376-180A	Peaking Coil
X804	2SC929(D)	FM IF Amp.	T801	A45958-00A	IF. Trans.
X805	2SC929(D)	LW/MW/SW Mixer	T802	VQM1T03-201	OSC. Trans.
X806	2SC929(D)	MW OSC.	T803,810	A32047-00C	Bar Ant. Ass'y
X807	2SD637(R)	MW Meter Drive	T804	V03067-25	Det. Trans.
X808	2SD637(R)	Muting Drive/Stereo SW.	T808	A45823-00A	OSC. Trans.
X809	2SA844(C)	AF Amp. & Muting SW.	T809	V03101-025	OSC. Trans.
X810	2SA844(C)	AF Amp. & Muting SW.	T811	A60108-00A	Ant. Trans.
X811	2SD637(R)	Muting SW.	R868	QVP5A0B-014	14kHz Adj.
X812	2SD637(R)	Muting SW.	R872	QVP5A0B-052	Separation
X813	2SD637(R)	Muting Drive	R874	QVP5A0B-054	Muting Level
X814	2SD468(C)	Vol. Reg.	R37	A04392-001	Tuning
X815	2SC929(D)	LW OSC.	Variable Resistors		
X816	2SC929(D)	SW OSC.	C816,881,882	QET61HR-475	4.7μF
ICs			C853,858,869	QET61AR-476	50WV
IC2	HA11227	FM MPX Demodulator	871,893		47μF
IC3	HA11251	FM/MW IF Amp. FM Det.	C854,864,873	QET61HR-105	10WV
Diodes			879,885,886		
D801	SD113V	Variable Capacitance Diode	C862,863	QET61HR-335	1μF
D802,804,805, 808	1S2076V	Diode	C867	QEE51VK-104	3.3μF
D803	1N60TF1	Diode	C872,887,888	QET61HR-474	0.1μF
D806	GL-3PR1	L.E.D.	C876	QEE51EK-105	0.47μF
D807	HZ7B2L	Zener Diode	C877	QEE51VK-334	1μF
Coils & Transformers			C878,880	QEE51CK-225	25WV
L801	A45973-00B	RF Coil	C889	QET61CR-477	0.33μF
L802,806	A04376-R68A	Peaking Coil	C890	QET61CR-107	2.2μF
Electrolytic Capacitors			C894	QET61AR-227	16WV
			C895,896	QET61HR-106	470μF
			C897	QEE51EK-105	100μF
					16WV
					220μF
					10WV
					50WV
					1μF
					25WV

Symbol No.	Parts No.	Description	Symbol No.	Parts No.	Description
Capacitors					
C805,806,821, 822,831,832, 841,842	QAP1224-504	Variable Capacitor	S4 S5,6	QSR60A4-20A QSP0210-015	Rotary Switch Push Switch
C875	QFS41HJ-471	Polystyrol Capacitor	J6	A03088-00A	8P Connector Ass'y
C8119	QFS41HJ-332	Polystyrol Capacitor	J11	A03088-00B	8P Connector Ass'y
C8111,8124	QAT2002-001	Trimmer Capacitor	J13	A03086-00C	6P Connector Ass'y
C8118,8126	QAT2002-001	Trimmer Capacitor	J16	A03084-00E	4P Connector Ass'y
C.R. Block					
CR801	03126-15	C865, 866, R858	P9	QMV5002-003	Connector
Filters					
CF801,802	A04384-001	Ceramic Filter	PL1,2	QLP3101-319	Pilot Lamp
CF803	V03067-026	Ceramic Filter		A04382-001	E.C. MIC (Pair)
BPF801	A45961-00B	Band Pass Filter		V04041-1	Test Point
LPF801,802	A04385-00A	Low Pass Filter			
Switch					
Socket & Jacks					
Miscellaneous					

Electronic Parts List For Amplifier

Symbol No.	Parts No.	Description	Symbol No.	Parts No.	Description
Transistors					
X601,701	2SD661(R,S)	Pri. Amp.	R629,729	QLV8A3B-054	Rec. Level 50kΩB
X602,702	2SD637(Q,R)	Vol. Drive	R637,737	QVP5A0B-024	Rec. Level 20kΩB
X603,703	2SD637(Q,R)	Meter Drive	R738	QVP5A0B-053	Meter Balance 5kΩB
X604,704	2SD637(Q,R)	Rec. Amp.	R913	QRX029J-IRO	Resistor Metal Film Resistor
X605,705	2SD637(Q,R)	Rec. Out.			
X901,902	2SC536(F) AUD	Bias OSC.			
ICs					
IC4,5	TA7137P-ST	Equalizer Amp. (Pair)	C601,701,603,	QET61HR-475	Electrolytic Capacitors 4.7μF 50WV
IC6	AN7145M	Audio Out.	703,619,719, 627,727,630, 730,631,731, 638,738,639, 739		
Diodes					
D601,701	1S2076V	Diode	C604,704,608,	QET61AR-107	4.7μF 50WV
D602,702	1N34ATF1	Diode	708,905		
D603,703	1N34ATF1	Diode	C605,705,635,	QET61CR-336	33μF 16WV
D604,704	DS430	Diode	735,643,743, 912		
Coils & Transformers					
L601,701	03226-19	Inductor	C609,709,611, 711	QET61HR-106	10μF 50WV
L602,702	A04391-103	Inductor	C616,716,622,	QET61HR-474	0.47μF 50WV
L603,703	03226-17	Inductor	722,623,723,		
L604,704	A04359-100	Choke Coil	642,742,651,		
L901	03226-17	Inductor	751		
L902	A04359-100	Choke Coil	C621,721,914	QET61CR-477	470μF 16WV
T901	V03083-019	Bias OSC. Coil	C646,746	QET61AR-108	1000μF 10WV
Variable Resistors					
R607,707	QVP5A0B-015	Phono Level	C647,747	QET61AR-476	47μF 10WV
R612,712	QVP5A0B-054	Tape PB Level	C652,752	QEZ0046-335	33μF 50WV
R625,725	QVP2A0B-054	Bias Adj.	C911	QET61CR-227	220μF 16WV
			C913	QET61CR-228	2200μF 16WV

Symbol No.	Parts No.	Description	Symbol No.	Parts No.	Description
Capacitors					
C633,733	QFS41HJ-501	Polystyrol Capacitor	J17,18,19,32	A20931-00B	Jack Board Ass'y
Switch					
S7,8,9,10,11	QSP0251-003	Push Switch	J20	QMC9014-006	DIN Socket
S12,13,15	QL4210-202	Lever Switch	J21L,21R	QMC0289-003	DIN Socket
S14	QL4310-012	Lever Switch	J22	QMS6312-002	Jack Ass'y
S16	QSSC201-107	Slide Switch	J24	A03084-00G	4P Connector Ass'y
S17	QSP4210-061	Push Switch	P10	QMV5003-005	Connector
Sockets & Jacks					
J15L	QMS6303-006	Jack Ass'y (L. Ext. MIC)	P11	QMV5003-008	Connector
J15R	QMS6303-006	Jack Ass'y (R. Ext. MIC)	P12	QMV5003-012	Connector
			P13	QMV5002-006	Connector
			P14	QMV5003-003	Connector
			P16,31	QMV5002-004	Connector
			P23	QMV5003-004	Connector

Electronic Parts List For Power Supply


Symbol No.	Parts No.	Description	Symbol No.	Parts No.	Description	
Transistors						
X501	2SD727(P,Q)	Vol. Reg.	C507	QET61HR-106	10μF 50WV	
X502	2SC1213(C)	Vol. Drive	C508,510	QET61CR-476	47μF 16WV	
X503	2SB566(C)	Vol. Reg.	C509,511	QET61HR-475	4.7μF 50WV	
X504	2SC458(C)	Error Amp.			C.R. Blocks	
X505	2SA844(C,D)	Active Filter	CR501,502	A03008-006	C.R. Block	
X506	2SC458(C)	Active Filter			Miscellaneous	
Diodes						
D501	S4VB20(V)	Si. Diode Stack	S26	QSP2210-057	Push Switch	
D502	HZ151L	Zener Diode	S27	QSP1210-123	Push Switch	
D503	RD6.8EV	Zener Diode	S28	QSP3110-003	Push Switch	
D504	GL-4PR2	L.E.D.	S29,P27	QMA1221-003	Ext. Batt. Jack Ass'y	
D505	1SS55(V)	Diode	S30, P28	QMC0263-001	AC Socket Ass'y	
Variable Resistor						
R512	QVP2A0B-013	B. Voltage Adj. 1kΩB	S31	QSS0037-004	Slide Switch	
Electrolytic Capacitors						
C505	QEWA81EA-478	4700μF 25WV	P24	QMV5002-004	Connector	
C506	QET61ER-227	220μF 25WV	P26	QMV5002-003	Connector	
			J25	A03084-00H	4P Connector Ass'y	
			Fuse 1	QMF51A2-R63	Fuse T630mA	
			Fuse 2	QMF51A2-1R6	Fuse 1.6A	
			T501	A03205-00B	Power Trans. Ass'y	

Electronic Parts List For UHF Tuner

Symbol No.	Parts No.	Description	Symbol No.	Parts No.	Description	
Transistors						
X001	2SC1070(B)V	RF Amp.	L004,008	A44900-7-5	RF Coil	
X002	2SC1070(B)V	Mixer	L010	A04378-1R0	Choke Coil	
X003	2SC288A(5B)	UHF OSC.	L015	A44899-23-5	RF Coil	
Diodes						
D001,002,003	1S2208	Variable Capacitance Diode			Electrolytic Capacitors	
Coils						
L001,002,016	A44899-15-1	RF Coil	C023,026	A04364-001	1000μF 10WV	
			C024	QET61AR-476	47μF 10WV	
Miscellaneous						
			J4	QMC0131-002	Jack Ass'y	
			P5	QMV5002-005	Plug Ass'y	

TELEVISION SCHEMATIC

(Power Supply & A



JVC

VICTOR COMPANY OF JAPAN, LIMITED
B/W TELEVISION DIVISION

B : CE
DE
MY : MY
NP : NO
PS : PO
ELECT
LE
4.
CA

TELEVISION SCHEMATIC DIAGRAM MODEL 3090EN

(Power Supply & Audio Amplifier Sections Diagram)






DIAGRAM MODEL 3090EN


(Amplifier Sections Diagram)



Reverse Patterns of Printed




Printed Bo




Printed Board for Radio



Reverse Patterns of Printed Board for Model 3090EN



Printed Board for TV




Printed Board for UHF Tuner




Printed Board


ard for Model 3090EN



TV



Board for UHF Tuner



Printed Board for Antenna

TELEVISION SCHEMATIC DIAGRAM MODEL 3090EN

(TV & Radio Sections Diagram)

NOTE

- I. VOLTAGE VALUES SHOW READINGS BY CIRCUIT TESTER ($20\text{ k}\Omega/\text{V}$) ON NORMAL RECEPTION.
- TV IS ON UHF RECEPTION, EXCEPT FOR THOSE AT X3 AND X5 ON VHF (HIGH CH) (FOR THOSE AT DIODES IN TUNER, SEE NOTE .)
- RADIO SECTION
 - SHOWS READINGS ON FM POSITION WITH NO SIGNAL.
 - SHOWS READINGS ON LW,MW,SW POSITION WITH NO SIGNAL.
 - SHOWS READINGS ON FM STEREO RECEPTION.

2. ALIGNMENT ————— OPERATION FOR USER
————— OPERATION FOR SERVICE

3. RESISTANCE VALUES ARE IN OHMS.
(K : $1,000\Omega$ M : $1,000,000\Omega$)

UNSPECIFIED : CARBON RESISTOR $\pm 5\%$ 1/4 W
COMP : COMPOSITION RESISTOR $\pm 10\%$
MFR : METAL FILM RESISTOR $\pm 5\%$
UFR : UNFLAMMABLE RESISTOR $\pm 10\%$
TH-N : NEGATIVE THERMISTOR
CR : CHIP RESISTOR $\pm 5\%$

4. CAPACITANCE VALUES LESS THAN
1 ARE IN μF , THOSE 1 AND ABOVE
IN PF EXCEPT THAT ELECTROLYTICS ARE IN μF .

RATING VOLTAGE IS 50WV UNLESS
OTHERWISE INDICATED.

TOLERANCE FOR CAPACITOR

J $\pm 5\%$, K $\pm 10\%$, M $\pm 20\%$, Z $\pm 80\%$
UNSPECIFIED :

CERAMIC CAPACITOR

1000PF AND ABOVE $\pm 80\%$
LESS THAN 1000PF $\pm 5\%$

CH : TEMPERATURE COEFFICIENT IS
 $0 \pm 60\text{PPM}/^\circ\text{C}$

RH : TEMPERATURE COEFFICIENT IS
 $220 \pm 60\text{PPM}/^\circ\text{C}$

(B) : THERMAL DEVIATION IS $\pm 10\%$
UJ : TEMPERATURE COEFFICIENT IS
 $-750 \pm 60\text{PPM}/^\circ\text{C}$

FTC : FEED THROUGH TYPE CAPACITOR
ND : NUDE CERAMIC CAPACITOR $\pm 5\%$
CC : CHIP CERAMIC CAPACITOR $\pm 5\%$
PP : POLYPROPYLENE CAPACITOR $\pm 10\%$

MY : MYLAR CAPACITOR $\pm 10\%$
TA : TANTAL ELECT. CAPACITOR $\pm 10\%$
NP : NON POLARIZED ELECT.

CAPACITOR

PS : POLYSTYROL CAPACITOR $\pm 5\%$
ELECT. CAPACITOR $\pm 70\%$
LESS THAN $4.7\mu\text{F} \pm 70\%$

CAPACITANCE/WORKING VOLTAGE

5. SELECTOR SW POSITION

SI ANT SW (ROD)

S2(a~h) TV BAND SW (VHF)

S4(a~f) RADIO BAND SW (FM)

S5(a,b) FM AFC (ON) MW SENS(DX)


S6(a,b) FM MUTING SW (OFF)





S24 TV-VHF BAND SW(HIGH CH)


6. VOLTAGES AT DIODES IN TUNER AND ANTENNA

	VHF LOW	VHF HIGH	UHF	RA FM	RA LW MW SW	(OV AT CATHODE)
D001	-0.5	-2	-1	—	—	
D002	-14	-16	-25	—	—	
D004	0.7	0.7	0	-1.95	0	
D1	-1.25	-1.25	0	0.7	0.03	
D2	-5.7	0.7	0	—	—	
D4, D5	-1.25	-1.25	0.7	—	—	
D6, D10, D11	-0.5	-2	-16	0.7	—	
D7	-1.25	-1.25	0.7	—	—	
D9	-1.25	-1.25	0.5	—	—	
D17	0.7	0.7	0	-0.48	0	
D18	-0.4	-0.4	0	0.72	0	
D19	0.7	0.7	0	0.72	0	

ANT TERMINAL









JVC
VICTOR COMPANY OF JAPAN, LIMITED
B/W TELEVISION DIVISION


MODEL 3090EN




Printed Board for Power Supply




Printed Board for Controls




Printed Board for Amplifier



Reverse Patterns of Printed Board for Model 3090EN




Printed Board for Power Supply





Printed Board for Controls

Transistor & IC Basing



Reverse Patterns of Printed Board for Model 3090EN



Electronic Parts List For TV. Control Panel

Symbol No.	Parts No.	Description	Symbol No.	Parts No.	Description	
	Transistors			Electrolytic Capacitors		
X903	2SD637(Q,R)	Pulse Amp.	C920	QET61CR-336	33μF 16WV	
X904	2SD637(Q,R)	Plunger Drive	C921	QET61AR-107	100μF 10WV	
X905	2SD468(C)	Plunger Drive	C922	QET61CR-477	470μF 16WV	
	IC			Miscellaneous		
IC7	DN6835	Tape Running Det.	S18	QSR4523-302	Rotary Switch	
	Diodes			S19	Push Switch	
D901	GL-3PR1	L.E.D	S23	QSP0210-014	Push Switch	
D902	HZ5B3	Zener Diode	J12	QSP2210-058		
D903	1N34ATF1	Diode	J14	A03091-00A	12P Connector Ass'y	
D904	10E2(V)	Silicon Power Diode	J31	A03083-00J	3P Connector Ass'y	
	Variable Resistors			P25	4P Connector Ass'y	
R677,777	QVD8A3A-115	Bass	PL3	QMV5002-004	Connector	
R681,781	QVD8A3A-115	Treble	PL4	QLP3104-215	Pilot Lamp	
R684,784	QVZ1710-001	Vol. Balance		QLP3104-214	Pilot Lamp	
	Resistors			A03092-001	Meter (L CH)	
R922	QRX129J-2R2	Metal Film Resistor		A03092-002	Meter (R CH)	
R924	QRX129J-1R0	Metal Film Resistor				