

# GV-A500/A500E

## SERVICE MANUAL

**Self Diagnostics**  
Supported model

**video Hi8**

**VIDEO**  
**WALKMAN**

**B MECHANISM**



Photo : GV-A500E

**GV-A500 (NTSC)  
GV-A500E (PAL)**

**US Model  
Canadian Model  
GV-A500  
AEP Model  
UK Model  
E Model  
Hong Kong Model  
GV-A500E**

### SPECIFICATIONS

#### VCR

##### **System**

**Video recording system**

Four rotary heads, Helical scanning  
FM system

**Audio recording system**

Rotary heads, FM system

**Video signal**

NTSC color, EIA standards (GV-A500)  
PAL color, EIA standards (GV-A500E)

**Usable cassette**

8 mm video format cassette (Hi8 or  
standard 8 mm)

**Recording/playback time**

GV-A500:  
SP mode: 2 hours (E6/P6-120)

LP mode: 4 hours (E6/P6-120)

GV-A500E:

SP mode: 1 hour 30 minutes  
(E5/P5-90)

LP mode: 3 hours (E5/P5-90)

**Fastforward/rewind time**

GV-A500:

Approx. 6 min. (E6/P6-120)

GV-A500E

Approx. 5 min. (E5/P5-90)

#### LCD screen

**Picture**

4 inches measured diagonally  
 $3\frac{1}{4} \times 2\frac{3}{8}$  in. (80.7 × 58.9 mm)

**On-screen display**

TN LCD/TFT active matrix method

**Total dot number**

112,086 (479 × 234)

#### **Input and output connectors**

**S video input/output**

4-pin mini DIN

Luminance signal: 1 Vp-p, 75 ohms,  
unbalanced, sync negative

Chrominance signal: 0.286 Vp-p  
(GV-A500), 0.3 Vp-p (GV-A500E),  
75 ohms, unbalanced

**Video input/output**

Phono jack, 1 Vp-p, 75 ohm,  
unbalanced, sync negative

**Audio input/output**

327 mV, (at output impedance  
less than 1 kohm)

**RFU DC OUT**

Special minijack, DC 5 V

**Headphones jack**

Stereo minijack (ø 3.5 mm)

**CLANC jack**

Stereo mini-minijack (ø 2.5 mm)

**LASER LINK**

**Video/Audio**

IR special transmission system

**Audio carrier**

Lch: 4.3 MHz

Rch: 4.8 MHz

#### **General**

**Power requirements**

7.2 V (battery pack)

8.4 V (AC power adaptor)

**Average power consumption**

5.3 W

**Operating temperature**

32°F to 104°F (0°C to 40°C)

**Storage temperature**

-4°F to +140°F (-20°C to +60°C)

**Dimensions**

Approx.  $5\frac{7}{8} \times 2\frac{1}{2} \times 5\frac{3}{8}$  in.  
(w/h/d) (148 × 62 × 135 mm)

**Mass**

Approx. 1 lb 15 oz (900 g) excluding  
the battery pack, lithium battery,  
cassette, and shoulder strap

Approx. 2 lb 2 oz (970 g) including  
cassette E6/P6-120, and shoulder  
strap

**Speaker**

Dynamic-speaker

**Supplied accessories**

See page 1-1.

#### **AC power adaptor**

**Power requirements**

100 to 240 V AC, 50/60 Hz

**Power consumption**

25 W

**Output voltage**

DC OUT: 8.4 V, 1.8 A in operating  
mode

Battery charge terminal: 8.4 V, 1.4 A  
in charge mode

**Application**

Sony battery pack NP-F530, NP-  
F730, NP-F930 lithium ion type

**Operating temperature**

32°F to 104°F (0°C to 40°C)

**Storage temperature**

-4°F to +140°F (-20°C to +60°C)

**Dimensions**

Approx.  $2\frac{3}{16} \times 1\frac{3}{4} \times 4\frac{3}{16}$  in.  
(56 × 44 × 107 mm) (w/h/d)

**Mass**

Approx. 6.7 oz (190 g)

Design and specifications are  
subject to change without notice.

## Hi8 VIDEO CASSETTE RECORDER



**MICROFILM**

# SONY®

#### **SAFETY-RELATED COMPONENT WARNING!!**

COMPONENTS IDENTIFIED BY MARK  OR DOTTED LINE WITH MARK  ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

#### **ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!**

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE  SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈSES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPÉMENTS PUBLIÉS PAR SONY.

## **SAFETY CHECK-OUT**

After correcting the original service problem, perform the following safety checks before releasing the set to the customer.

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, through functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
5. Check the B+ voltage to see it is at the values specified.
6. Flexible Circuit Board Repairing
  - Keep the temperature of the soldering iron around 270°C during repairing.
  - Do not touch the soldering iron on the same conductor of the circuit board (within 3 times).
  - Be careful not to apply force on the conductor when soldering or unsoldering.

## TABLE OF CONTENTS

### **SELF-DIAGNOSIS FUNCTION**

1. Self-diagnosis Function .....	5
2. Self-diagnosis display .....	5
3. Service Mode Display .....	5
3-1. Display Method .....	5
3-2. Switching of Backup No. ....	5
3-3. End of Display .....	5
4. Self-diagnosis Code Table .....	6

### **1. GENERAL**

Before you begin

Using this manual .....	1-1
Checking supplied accessories .....	1-1
Basic operations	
Installing the AC power adaptor .....	1-1
Inserting a cassette .....	1-1
Playing back a tape .....	1-2
Advanced operations	
Watching on a TV screen .....	1-3
Editing onto another tape .....	1-4
Recording from a VCR or TV .....	1-4
Changing the mode settings .....	1-5
Using alternative power sources .....	1-6
Additional information	
Charging the vanadiumlithium battery in the VCR .....	1-7
Usable cassettes and playback modes .....	1-7
Notes on "InfoLITHIUM" battery pack .....	1-7
Maintenance information and precautions .....	1-8
Using your VCR abroad .....	1-9
Trouble check .....	1-9
Self-diagnosis display .....	1-10
Identifying the parts .....	1-10
Warning indicators .....	1-11

### **2. DISASSEMBLY**

2-1. CASSETTE LID ASSEMBLY .....	2-1
2-2. LCD CABINET .....	2-1
2-3. CRYSTAL INDICATION MODULE, FLUORESCENT COLD CATHODE TUBE, PD-88 BOARD .....	2-2
2-4. CABINET (BOTTOM) ASSEMBLY .....	2-3
2-5. MD BLOCK ASSEMBLY .....	2-3
2-6. CONTROL (FK-71) SWITCH BLOCK, DD-100 BOARD .....	2-3
2-7. VC-197 BOARD .....	2-4
2-8. B MECHANISM DECK .....	2-4
2-9. CABINET (R) BLOCK ASSEMBLY, FP-571 BOARD .....	2-4
2-10. EX-34 BOARD .....	2-4
2-11. IO-62, IR-29, FP-572, FP-573, FP-574, FP-575 BOARDS SPEAKER .....	2-5
2-12. CABINET (UPPER) ASSEMBLY .....	2-5
2-13. CIRCUIT BOARDS LOCATION .....	2-6

### **3. BLOCK DIAGRAMS**

3-1. OVERALL BLOCK DIAGRAM .....	3-1
3-2. VIDEO BLOCK DIAGRAM 1 .....	3-4
3-3. VIDEO BLOCK DIAGRAM 2 .....	3-7
3-4. SERVO BLOCK DIAGRAM .....	3-10
3-5. SYSTEM CONTROL BLOCK DIAGRAM .....	3-13
3-6. AUDIO BLOCK DIAGRAM .....	3-15
3-7. MODE CONTROL BLOCK DIAGRAM .....	3-17
3-8. LCD BLOCK DIAGRAM .....	3-20
3-9. POWER SUPPLY BLOCK DIAGRAM .....	3-23

### **4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS**

4-1. FRAME SCHEMATIC DIAGRAM .....	4-1
4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS .....	4-4
• VC-197 (MAIN) PRINTED WIRING BOARD .....	4-5
• VC-197 (REC/PB HEAD AMP) SCHEMATIC DIAGRAM .....	4-11
• VC-197 (EVR) SCHEMATIC DIAGRAM .....	4-16
• VC-197 (VIDEO PROCESS) SCHEMATIC DIAGRAM .....	4-19
• VC-197 (Y/C PROCESS) SCHEMATIC DIAGRAM .....	4-23
• VC-197 (TBC/CNR) SCHEMATIC DIAGRAM .....	4-27
• VC-197 (VIDEO IN/OUT) SCHEMATIC DIAGRAM .....	4-30
• VC-197 (RGB DECODER) SCHEMATIC DIAGRAM .....	4-33
• VC-197 (IR DRIVER), IR-29 (TRANSMITTER) SCHEMATIC DIAGRAM .....	4-37
• IR-29 (TRANSMITTER) PRINTED WIRING BOARD .....	4-40
• VC-197 (SERVO/SYSTEM CONTROL) SCHEMATIC DIAGRAM .....	4-41
• VC-197 (SERVO) SCHEMATIC DIAGRAM .....	4-44
• VC-197 (MODE CONTROL) SCHEMATIC DIAGRAM .....	4-47
• VC-197 (AUDIO) SCHEMATIC DIAGRAM .....	4-51
• IO-62 (AV IN/OUT) SCHEMATIC DIAGRAM .....	4-55
• EX-34 (MULTI CONNECTOR) SCHEMATIC DIAGRAM .....	4-59
• EX-34 (MULTI CONNECTOR) PRINTED WIRING BOARD .....	4-63
• IO-62 (AV IN/OUT) PRINTED WIRING BOARD .....	4-65
• PD-88 (LCD DRIVER) SCHEMATIC DIAGRAM .....	4-68
• PD-88 (LCD DRIVER) PRINTED WIRING BOARD .....	4-71
• DD-100 (POWER SUPPLY) PRINTED WIRING BOARD .....	4-73
• DD-100 (POWER SUPPLY) SCHEMATIC DIAGRAM .....	4-75

### **5. ADJUSTMENT**

5-1. PREPARATIONS .....	5-1
1-1. PREPARATIONS BEFORE ADJUSTMENT .....	5-1
1-1-1. List of Service Tools .....	5-1
1-1-2. Adjusting Remote Commander .....	5-2
1. Using the adjusting remote commander .....	5-2
2. Precautions upon using the adjusting remote commander .....	5-2
1-1-3. Page D Address .....	5-3
1-1-4. Page F Address .....	5-4
1-1-5. Page E Address .....	5-7
1-2. INITIALIZATION OF D, E, F PAGE DATA .....	5-8
1. Initialization of D, E, F Page Data .....	5-8
2. Modification of D Page Data .....	5-8
3. Modification of F Page Data .....	5-9
4. Modification of E Page Data .....	5-10
1-3. Data Processing .....	5-10
5-2. MECHANICAL SECTION ADJUSTMENT .....	5-11
2-1. OPERATING WITHOUT A CASSETTE .....	5-11
2-2. TAPE PATH ADJUSTMENT .....	5-11
1. Preparations for adjustments .....	5-11

5-3. VIDEO SECTION ADJUSTMENTS .....	5-12
3-1. PREPARATIONS BEFORE ADJUSTMENT .....	5-12
3-1-1. Equipments to be Used .....	5-12
3-1-2. Precautions in Adjustment .....	5-13
3-1-3. Connector for Adjustments .....	5-13
3-1-4. Connecting the Equipments .....	5-14
3-1-5. Checking the Input Signals .....	5-15
1. S VIDEO input .....	5-15
2. VIDEO input .....	5-15
3-1-6. Alignment Tape .....	5-16
3-1-7. Input/Output Level and Impedance .....	5-18
3-1-8. Recording Mode (Standard 8/Hi8) switching .....	5-18
3-1-9. Service Mode .....	5-18
1. Test mode setting .....	5-18
2. Emergency Memory Address .....	5-19
2-1. EMG CODE (Emergency Code) .....	5-19
2-2. MSW Codes .....	5-20
3. Bit value discrimination .....	5-21
4. Input/output selection check .....	5-21
5. Condensation, head clogging check .....	5-22
6. VTR state check (1) .....	5-22
7. VTR state check (2) .....	5-22
8. VTR state check (3) .....	5-23
9. Record of Use Check .....	5-23
3-2. SYSTEM CONTROL SYSTEM ADJUSTMENTS .....	5-24
1. Initialization of D, E, F Page Data .....	5-24
2. Battery End Adjustment (VC-197 board) .....	5-24
3. Battery down voltage check .....	5-24
3-3. SERVO SYSTEM ADJUSTMENTS .....	5-25
1. CAP FG Offset Adjustment (VC-197 board) .....	5-25
2. Switching Position Adjustment (VC-197 board) .....	5-25
3. NTSC LP mode Switching Position Adjustment (VC-197 board) .....	5-26
3-4. VIDEO SYSTEM ADJUSTMENTS .....	5-26
1. 28 MHz Origin Oscillation Adjustment (VC-197 board) .....	5-26
2. Filter f0 Adjustment (VC-197 board) .....	5-27
3. Y OUT Level Adjustment (VC-197 board) .....	5-27
4. C OUT Level Adjustment (VC-197 board) .....	5-28
5. RP Filter f0 Adjustment (VC-197 board) .....	5-28
6. AFC f0 Adjustment (VC-197 board) .....	5-29
7. NTSC Hi8 REC Y Current Adjustment (VC-197 board) .....	5-30
8. PAL Hi8 REC Y Current Adjustment (VC-197 board) .....	5-30
9. NTSC Hi8 REC C Current Adjustment (VC-197 board) .....	5-31
10. PAL Hi8 REC C Current Adjustment (VC-197 board) .....	5-32
11. REC C Current Adjustment (VC-197 board) .....	5-33
3-5. IR Transmitter Adjustments .....	5-34
1. IR Video Carrier Frequency Adjustment (MI-27/28 board) .....	5-34
2. IR Video Deviation Adjustment (MI-27/28 board) .....	5-34
3. IR Audio Deviation Adjustment (MI-27/28 board) .....	5-35
3-6. AUDIO SYSTEM ADJUSTMENT .....	5-36
1. 1.5 MHz Deviation Adjustment (VC-197 board) .....	5-37
2. 1.7 MHz Deviation Adjustment (VC-197 board) .....	5-37
3. BPF f0 Adjustment (VC-197 board) .....	5-38
3-7. LCD SYSTEM ADJUSTMENT .....	5-39
1. LCD Initial Data Input .....	5-39
2. VCO Adjustment (PD-88 baord) .....	5-40
3. H POS Adjustment (VC-197 baord) .....	5-40
4. Bright Adjustment (VC-197 baord) .....	5-41
5. Contrast Adjustment (VC-197 baord) .....	5-41
6. Color Adjustment for NTSC model (VC-197 baord) .....	5-42
7. Hue Adjustment for NTSC model (VC-197 baord) .....	5-42
8. Burst Cleaning Adjustment for PAL model (VC-197 baord) .....	5-43
9. Color Adjustment for PAL model (VC-197 baord) .....	5-43
10. V-COM Adjustment (PD-88 baord) .....	5-44
11. White Balance Adjustment (VC-197 baord) .....	5-44

## 6. REPAIR PARTS LIST

6-1. EXPLODED VIEWS .....	6-1
6-1-1. OUTER CABINET ASSEMBLY .....	6-1
6-1-2. LCD BLOCK, UPPER CABINET BLOCK ASSEMBLY .....	6-2
6-1-3. MD BLOCK ASSEMBLY .....	6-3
6-1-4. CASSETTE COMPARTMENT BLOCK SECTION .....	6-4
6-1-5. LS CHASSIS BLOCK SECTION .....	6-5
6-1-6. MECHANISM CHASSIS BLOCK SECTION .....	6-6
6-2. ELECTRICAL PARTS LIST .....	6-7

# SELF-DIAGNOSIS FUNCTION


## 1. Self-diagnosis Function

When problems occur while the unit is operating, the self-diagnosis function starts working, and displays on the LCD window what to do. This function consists of two display; self-diagnosis display and service mode display.

Details of the self-diagnosis functions are provided in the Instruction manual.

## 2. Self-diagnosis display

When problems occur while the unit is operating, the counter of the LCD window shows a 4-digit display consisting of an alphabet and numbers, which blinks at 3.2 Hz. This 5-character display indicates the “repaired by:”, “block” in which the problem occurred, and “detailed code” of the problem.




## 3. Service Mode Display

The service mode display shows up to six self-diagnosis codes shown in the past.

### 3-1. Display Method

While pressing the “STOP” key, set the power switch from OFF to “ON”, and continue pressing the “STOP” key for 5 seconds continuously. The service mode will be displayed, and the counter will show the backup No. and the 5-character self-diagnosis codes.



### 3-2. Switching of Backup No.

By rotating the SEL/PUSH EXEC dial, past self-diagnosis codes will be shown in order. The backup No. in the [] indicates the order in which the problem occurred. (If the number of problems which occurred is less than 6, only the number of problems which occurred will be shown.)

- [1] : Occurred first time [4] : Occurred fourth time
- [2] : Occurred second time [5] : Occurred fifth time
- [3] : Occurred third time [6] : Occurred the last time

### 3-3. End of Display

Turning OFF the power supply will end the service mode display.

**Note:** The self-diagnosis display data will be backed up by the coin-type lithium battery. When this coin-type lithium battery is disconnected, the self-diagnosis data will be lost by initialization.

#### 4. Self-diagnosis Code Table

Self-diagnosis Code			Symptom/State	Correction
Repaired by:	Block Function	Detailed Code		
C	2 1	0 0	Condensation.	Remove the cassette, and insert it again after one hour.
C	2 2	0 0	Video head is dirty.	Clean with the optional cleaning cassette.
C	2 3	0 0	Non-standard battery is used.	Use the InfoLITHIUM battery.
C	2 3	1 0	LOAD direction. Loading does not complete within specified time	Load the tape again, and perform operations from the beginning.
C	3 1	1 1	UNLOAD direction. Loading does not complete within specified time	Load the tape again, and perform operations from the beginning.
C	3 1	2 0	T reel side tape slackening when unloading.	Load the tape again, and perform operations from the beginning.
C	3 1	2 1	S reel side tape slackening when unloading.	Load the tape again, and perform operations from the beginning.
C	3 1	2 2	T reel fault	Load the tape again, and perform operations from the beginning.
C	3 1	2 3	S reel fault	Load the tape again, and perform operations from the beginning.
C	3 1	3 0	FG fault when starting capstan	Load the tape again, and perform operations from the beginning.
C	3 1	3 1	FG fault during normal capstan operations	Load the tape again, and perform operations from the beginning.
C	3 1	4 0	FG fault when starting drum	Load the tape again, and perform operations from the beginning.
C	3 1	4 1	PG fault when starting drum	Load the tape again, and perform operations from the beginning.
C	3 1	4 2	FG fault during normal drum operations	Load the tape again, and perform operations from the beginning.
C	3 1	4 3	PG fault during normal drum operations	Load the tape again, and perform operations from the beginning.
C	3 1	4 4	Phase fault during normal drum operations	Load the tape again, and perform operations from the beginning.
C	3 2	1 0	LOAD direction loading motor time-out	Remove the battery or power cable, connect, and perform operations from the beginning.
C	3 2	1 1	UNLOAD direction loading motor time-out	Remove the battery or power cable, connect, and perform operations from the beginning.
C	3 2	2 0	T reel side tape slackening when unloading.	Remove the battery or power cable, connect, and perform operations from the beginning.
C	3 2	2 1	S reel side tape slackening when unloading.	Remove the battery or power cable, connect, and perform operations from the beginning.
C	3 2	2 2	T reel fault	Remove the battery or power cable, connect, and perform operations from the beginning.
C	3 2	2 3	S reel fault	Remove the battery or power cable, connect, and perform operations from the beginning.
C	3 2	3 0	FG fault when starting capstan	Remove the battery or power cable, connect, and perform operations from the beginning.
C	3 2	3 1	FG fault during normal capstan operations	Remove the battery or power cable, connect, and perform operations from the beginning.
C	3 2	4 0	FG fault when starting drum	Remove the battery or power cable, connect, and perform operations from the beginning.
C	3 2	4 1	PG fault when starting drum	Remove the battery or power cable, connect, and perform operations from the beginning.
C	3 2	4 2	FG fault during normal drum operations	Remove the battery or power cable, connect, and perform operations from the beginning.
C	3 2	4 3	PG fault during normal drum operations	Remove the battery or power cable, connect, and perform operations from the beginning.
C	3 2	4 4	Phase fault during normal drum operations	Remove the battery or power cable, connect, and perform operations from the beginning.

# SECTION 1

## GENERAL

This section is extracted from instruction manual. (GV-A500 model)

### Before you begin Using this manual

#### Welcome !

Congratulations on your purchase of this Sony "Video Walkman" VCR.

As you read through this manual, buttons and settings on the VCR are shown in capital letters. e.g., Set the POWER switch to ON. As indicated with in the illustrations, you can hear the beep sound to confirm your operation.

#### Note on TV color systems

TV color systems differ from country to country. To view the playback picture on a TV, you need an NTSC system-based TV.

#### Precaution on copyright

Television programs, films, video tapes, and other materials may be copyrighted.

Unauthorized recording of such materials may be contrary to the provision of the copyright laws.

#### Precautions on VCR care


- The LCD screen is made with high-precision technology. However, black points or bright points of light (red, blue or green) may appear constantly on the LCD screen. These points are not recorded on the tape. This is not a malfunction. (Effective dots: more than 99.99%)
- Do not let the VCR get wet. Keep the VCR away from rain and sea water. Letting the VCR get wet may cause the unit to malfunction, and sometimes the malfunction cannot be repaired [a].
- Never leave the VCR exposed to temperatures above 140°F (60°C), such as in a car parked in the sun or under direct sunlight [b].



### Basic operations Installing the AC power adaptor

Use the supplied AC power adaptor.

- (1) While pressing the connecting plate of the connecting cord, slide it to the left so that it attaches to the battery mounting surface firmly.
- (2) Connect the connecting cord to the DC OUT jack on the AC power adaptor.
- (3) Connect the power cord to the AC power adaptor.
- (4) Connect the power cord to a wall outlet. The POWER lamp (green) lights up.



#### To remove the AC power adaptor

While pressing BATT, slide the connecting plate to the right.

#### PRECAUTION

The set is not disconnected from the AC power source (house current) as long as it is connected to the wall outlet, even if the set itself has been turned off.

### Operaciones básicas Instalación del adaptador de alimentación de CA

Emplee el adaptador de alimentación de CA suministrado.

- (1) Mientras presiona la placa de conexión del cable de conexión, deslícela a la izquierda de forma que quede firmemente fijada a la superficie de montaje de la batería.
- (2) Conecte el cable de conexión a la toma DC OUT del adaptador de alimentación de CA.
- (3) Conecte el cable de alimentación al adaptador.
- (4) Conecte el cable de alimentación a una toma mural. El indicador POWER (verde) se ilumina.

#### Para extraer el adaptador de alimentación de CA


Deslice la placa de conexión a la derecha mientras pulsa BATT.

#### PRECAUCIÓN

La unidad no estará desconectada de la fuente de alimentación de CA (corriente doméstica) mientras esté conectada a la toma mural, aunque la haya apagado.

### Checking supplied accessories

Check that the following accessories are supplied with your VCR.



[1] AC-V615 AC power adaptor (1) (p. 6, 25)  
The shape of the plug varies from region to region.

[2] DK-415 connecting cord (1) (p. 6)

[3] A/V connecting cable (1) (p. 14, 17, 19)

[4] S video cable (1) (p. 14, 17, 19)

[5] Shoulder strap (1) (p. 49)

### Comprobación de los accesorios suministrados

Compruebe que ha recibido los siguientes accesorios junto con la videocámara:

Contents of the recording cannot be compensated if recording or playback is not made due to a malfunction of the VCR, video tape, etc.

El contenido de la grabación no puede compensarse si ésta o la reproducción no se realiza debido a algún fallo de funcionamiento de la videocámara, cinta de video, etc.

Before you begin / Antes de comenzar

5

### Inserting a cassette

Make sure that the power source is installed.


When you want to record in the Hi8 system, use Hi8 video cassette .

(1) While pressing PUSH OPEN, open the LCD panel.

(2) While pressing the small blue button, slide EJECT to the right. The cassette compartment automatically lifts up and opens.

(3) Insert a cassette with the window facing up.

(4) Close the cassette compartment by pressing the on the cassette compartment.



#### To eject the cassette

While pressing the small blue button, slide EJECT to the right.

#### To prevent accidental erasure

Slide the tab on the cassette to expose the red mark. If you insert the cassette with the red mark exposed and close the cassette compartment, the beeps sound for a while. If you try to record with the red mark exposed, the and indicators flash on the LCD screen, and you cannot record. To re-record on this tape, slide the tab back out covering the red mark.

### Inserción de videocassettes


Compruebe que la fuente de alimentación está instalada. Si desea grabar en el sistema Hi8, emplee videocassettes .

(1) Abra el panel LCD mientras pulsa PUSH OPEN.

(2) Mientras pulsa el botón azul pequeño, deslice EJECT a la derecha. El compartimiento de videocassettes se eleva y se abre automáticamente.

(3) Inserte un videocassete con la ventana hacia arriba.

(4) Cierre el compartimiento de videocassettes presionando la marca del mismo.



#### Para expulsar el videocassete

Deslice EJECT a la derecha mientras pulsa el botón azul pequeño.


#### Para evitar borrados accidentales

Deslice la lengüeta del videocassete para que la marca roja sea visible. Si inserta el videocassete con la marca roja visible y cierra el compartimiento de videocassettes, la unidad emitirá pitidos durante unos instantes. Si intenta grabar con dicha marca visible, los indicadores y parpadearán en la pantalla LCD y no será posible grabar. Para volver a grabar en esta cinta, deslice la lengüeta a su posición anterior para cubrir la marca roja.

Basic operations / Operaciones básicas

## Playing back a tape

- (1) While pressing the small green button on the POWER switch, set it to ON. The POWER lamp (green) on the front lights up.
- (2) Press  $\triangleleft\triangleright$  to rewind the tape.
- (3) Press  $\triangleright\triangleright$  to start playback.
- (4) Adjust the volume using VOLUME. You can also monitor the picture on a TV screen, after connecting the VCR to a TV or another VCR.




To stop playback, press  $\square$ .  
To rewind the tape, press  $\triangleleft\triangleright$ .  
To fast-forward the tape rapidly, press  $\triangleright\triangleright$ .  
To adjust the brightness of the LCD screen, press LCD BRIGHT.

**Note on DISPLAY button**  
Press DISPLAY to display the screen indicators on the LCD screen. To erase the indicators, press again.

**Using headphones**  
Connect headphones (not supplied) to the  $\circlearrowright$  jack (p. 48). You can adjust the volume of the headphones using VOLUME.

## Reproducción de cintas

- (1) Ajuste el interruptor POWER en ON mientras pulsa el botón verde pequeño del mismo. El indicador POWER (verde) de la parte frontal se ilumina.
- (2) Pulse  $\triangleleft\triangleright$  para rebobinar la cinta.
- (3) Pulse  $\triangleright\triangleright$  para iniciar la reproducción.
- (4) Ajuste el volumen con VOLUME. También es posible ver la imagen en la pantalla de un TV, después de conectar la videocámara a un TV o a otra videocámara.



Para detener la reproducción, pulse  $\square$ .  
Para rebobinar la cinta, pulse  $\triangleleft\triangleright$ .  
Para avanzar la cinta rápidamente, pulse  $\triangleright\triangleright$ .  
Para ajustar el brillo de la pantalla LCD, pulse LCD BRIGHT.

**Nota sobre el botón DISPLAY**  
Pulse DISPLAY para mostrar los indicadores en la pantalla LCD. Para borrarlos, vuelva a pulsarlo.

**Usos de auriculares**  
Conecte auriculares (no suministrados) a la toma  $\circlearrowright$  (p. 48). Es posible ajustar el volumen de los auriculares con VOLUME.

## Playing back a tape

### Various playback modes

You can enjoy noiseless pictures on the LCD screen during still, slow and picture search. (Crystal-clear still/slow/picture search)

### To view a still picture (playback pause)

Press  $\blacksquare$  during playback. The PAUSE lamp (orange) lights up. To resume playback, press  $\blacksquare$  or  $\triangleright\triangleright$ .

### To locate a scene (picture search)

Keep pressing  $\triangleleft\triangleright$  or  $\triangleright\triangleright$  during playback. To resume normal playback, release the button.

### To monitor the high-speed picture while advancing the tape or rewinding (skip scan)

Keep pressing  $\triangleleft\triangleright$  while rewinding or  $\triangleright\triangleright$  while advancing the tape. To resume normal rewinding or fast-forward, release the button.

### To view the picture at 1/5 speed (slow playback)

Press  $\triangleright\triangleright$  during playback. To resume normal playback, press  $\triangleright\triangleright$ . If slow playback lasts for about 1 minute, it shifts to normal speed automatically.

### Notes on playback

- Streaks appear and the sound is muted in the various playback modes.
- When playback pause mode lasts for 5 minutes, the VCR automatically enters stop mode.
- Horizontal noise appears at the centre of the screen when you play back a tape in reverse if the RC time code or the Data Code is displayed on the screen. This is normal.

## Reproducción de cintas

### Distintos modos de reproducción

Es posible obtener imágenes sin ruido en la pantalla LCD durante los modos de imagen fija, reproducción a cámara lenta y búsqueda de imágenes (búsqueda de imágenes)/reproducción a cámara lenta/imagen fija con nítidez.

### Para ver imágenes fijas (pausa de reproducción)

Pulse  $\blacksquare$  durante la reproducción. El indicador PAUSE (naranja) se ilumina. Para reanudar la reproducción, pulse  $\blacksquare$  o  $\triangleright\triangleright$ .

### Para localizar escenas (búsqueda de imágenes)

Mantenga pulsado  $\triangleleft\triangleright$  o  $\triangleright\triangleright$  durante la reproducción. Para reanudar la reproducción, pulse el botón.

### Para controlar la imagen a alta velocidad mientras la cinta avanza rápidamente o se rebobina (exploración con omisión)

Mantenga pulsado  $\triangleleft\triangleright$  durante el rebobinado o  $\triangleright\triangleright$  durante el avance rápido de la cinta. Para reanudar el rebobinado o avance rápido normal, suelte el botón.

### Para ver la imagen a una velocidad de 1/5 (reproducción a cámara lenta)

Pulse  $\triangleright\triangleright$  durante la reproducción. Para reanudar la reproducción normal, pulse  $\triangleright\triangleright$ . Si la reproducción a cámara lenta dura aproximadamente 1 minuto, la unidad volverá automáticamente a la velocidad normal.

### Notas sobre la reproducción

- Aparecen rayas y el sonido se cancela en los distintos modos de reproducción.
- Si el modo de pausa de reproducción dura 5 minutos, la videocámara introduce automáticamente el modo de parada.
- Aparecerá ruido horizontal en el centro de la pantalla al reproducir una cinta en sentido inverso si el código de tiempos RC o el de datos se muestra en la pantalla. Esto es normal.

## Playing back a tape

### Using a Remote Commander

You can operate this VCR using a Remote Commander supplied with a Sony 8mm camcorder. Point the Remote Commander at the remote sensor of this VCR.

### Notes on recording mode

- This VCR plays back and records in SP (standard play) mode and in LP (long play) mode. The VCR automatically plays back the tape in the recorded mode. The playback quality in LP mode, however, will not be as good as that in SP mode. When recording, select SP or LP in the menu system.
- When a tape recorded on this VCR in LP mode is played back on other types of 8 mm VCRs or camcorders, the playback quality may not be as good as that on this VCR.

### Notes on the tape counter

- The tape counter indicates the playback or recording time. Use it as a guide. There will be a time lag of several seconds from the actual time. To set the counter to zero, press COUNTER RESET.
- If the tape is recorded in SP and LP modes mixed, the tape counter shows incorrect recording time. When you intend to edit the tape using the tape counter as a guide, record in same (SP or LP) mode.

### Note on the beep sound

As indicated with  $\Delta$  in the illustrations, a beep sounds when you turn the power on. Several beeps also sound as a warning of any unusual condition of the VCR.

Note that the beep sound is not recorded on the tape. If you do not want to hear the beep sound, select "OFF" in the menu system.

### Cautions on the LCD panel

- Do not push nor touch the LCD when moving the LCD panel.
- Do not pick up the VCR by the LCD panel.
- Do not place the VCR so as to point the LCD screen toward the sun. The LCD panel may be damaged. Be careful when placing the VCR under sunlight or by a window.

Note that the beep sound is not recorded on the tape. If you do not want to hear the beep sound, select "OFF" in the menu system.

### Precautions sobre el panel LCD

- No presione ni toque la pantalla LCD al mover el panel LCD.
- No agarre la videocámara por el panel LCD.
- Coloque la videocámara de forma que la pantalla LCD no quede orientada hacia el sol, ya que el panel LCD podría dañarse. Tenga cuidado al colocar la videocámara bajo la luz solar o en una ventana.

## Reproducción de cintas

### Uso de un mando a distancia

Es posible controlar esta videocámara con un mando a distancia suministrado con una videocámara Sony de 8mm. Oriente dicho mando al sensor de control remoto de esta videocámara.

### Notas sobre el modo de grabación

- Esta videocámara reproduce y graba en los modos SP (reproducción estándar) y LP (reproducción de larga duración). La videocámara reproduce la cinta automáticamente en el modo grabado. No obstante, la calidad de reproducción en el modo LP no será tan buena como en el modo SP. Al grabar, seleccione SP o LP en el sistema de menús.
- Si una cinta grabada en esta videocámara en el modo LP se reproduce en otros tipos de videocámaras o videocámaras de 8 mm, es posible que la calidad de reproducción sea tan buena como la obtenida en esta videocámara.

### Notas sobre el contador de cinta

- El contador de cinta indica el tiempo de reproducción o grabación. Empléelo como referencia. Habrá una diferencia de tiempo de varios segundos con respecto al tiempo real. Para ajustar el contador a cero, pulse COUNTER RESET.
- Si la cinta se graba mezclando los modos SP y LP, el contador de cinta mostrará un tiempo de grabación incorrecto. Si piensa editar la cinta utilizando el contador de cinta como referencia, grabe en el mismo modo (SP o LP).

### Notas sobre los pitidos

Como se indica con  $\Delta$  en las ilustraciones, la unidad emite un pitido al activar la alimentación. También emite varios pitidos como aviso de alguna condición inusual de la videocámara. Observe que los pitidos no se graban en la cinta. Si no desea oír los pitidos, seleccione "OFF" en el sistema de menús.

### Precauciones sobre el panel LCD

- No presione ni toque la pantalla LCD al mover el panel LCD.
- No agarre la videocámara por el panel LCD.
- Coloque la videocámara de forma que la pantalla LCD no quede orientada hacia el sol, ya que el panel LCD podría dañarse. Tenga cuidado al colocar la videocámara bajo la luz solar o en una ventana.

## Playing back a tape

### Different playback modes

You can enjoy noiseless pictures on the LCD screen during still, slow and picture search. (Crystal-clear still/slow/picture search)

### To view a still picture (playback pause)

Press  $\blacksquare$  during playback. The PAUSE lamp (orange) lights up. To resume playback, press  $\blacksquare$  or  $\triangleright\triangleright$ .

### To locate a scene (picture search)

Keep pressing  $\triangleleft\triangleright$  or  $\triangleright\triangleright$  during playback. To resume normal playback, release the button.

### To monitor the high-speed picture while advancing the tape or rewinding (skip scan)

Keep pressing  $\triangleleft\triangleright$  while rewinding or  $\triangleright\triangleright$  while advancing the tape. To resume normal rewinding or fast-forward, release the button.

### To view the picture at 1/5 speed (slow playback)

Press  $\triangleright\triangleright$  during playback. To resume normal playback, press  $\triangleright\triangleright$ . If slow playback lasts for about 1 minute, it shifts to normal speed automatically.

### Notes on playback

- Streaks appear and the sound is muted in the various playback modes.
- When playback pause mode lasts for 5 minutes, the VCR automatically enters stop mode.
- Horizontal noise appears at the centre of the screen when you play back a tape in reverse if the RC time code or the Data Code is displayed on the screen. This is normal.

## Reproducción de cintas

### Different modes of reproduction

Es posible obtener imágenes sin ruido en la pantalla LCD durante los modos de imagen fija, reproducción a cámara lenta y búsqueda de imágenes (búsqueda de imágenes)/reproducción a cámara lenta/imagen fija con nítidez.

### Para ver imágenes fijas (pausa de reproducción)

Pulse  $\blacksquare$  durante la reproducción. El indicador PAUSE (naranja) se ilumina. Para reanudar la reproducción, pulse  $\blacksquare$  o  $\triangleright\triangleright$ .

### Para localizar escenas (búsqueda de imágenes)

Mantenga pulsado  $\triangleleft\triangleright$  o  $\triangleright\triangleright$  durante la reproducción. Para reanudar la reproducción, pulse el botón.

### Para controlar la imagen a alta velocidad mientras la cinta avanza rápidamente o se rebobina (exploración con omisión)

Mantenga pulsado  $\triangleleft\triangleright$  durante el rebobinado o  $\triangleright\triangleright$  durante el avance rápido de la cinta. Para reanudar el rebobinado o avance rápido normal, suelte el botón.

### Para ver la imagen a una velocidad de 1/5 (reproducción a cámara lenta)

Pulse  $\triangleright\triangleright$  durante la reproducción. Para reanudar la reproducción normal, pulse  $\triangleright\triangleright$ . Si la reproducción a cámara lenta dura aproximadamente 1 minuto, la unidad volverá automáticamente a la velocidad normal.

### Notas sobre la reproducción

- Aparecen rayas y el sonido se cancela en los distintos modos de reproducción.
- Si el modo de pausa de reproducción dura 5 minutos, la videocámara introduce automáticamente el modo de parada.
- Aparecerá ruido horizontal en el centro de la pantalla al reproducir una cinta en sentido inverso si el código de tiempos RC o el de datos se muestra en la pantalla. Esto es normal.

## Playing back a tape

### Playing back a dual soundtrack tape

When you play back a dual soundtrack tape, select the desired sound in the menu.

- (1) Press MENU to display the menu.
- (2) Turn the control dial to select HiFi SOUND, then press the control dial.
- (3) Turn the control dial to select 1 or 2 to playback desired sound, then press the control dial.
- Normally select STEREO.

(4) Press MENU to erase the menu display.


## Reproducción de cintas

### Reproducción de cinta de pista de sonido dual

Al reproducir una cinta de pista de sonido dual, seleccione el sonido que deseé en el menú.

- (1) Pulse MENU para mostrar el menú.
- (2) Gire el dial de control para seleccionar HiFi SOUND y, a continuación, pulselo.
- (3) Gire el dial de control para seleccionar 1 o 2 con el fin de reproducir el sonido que deseé y, a continuación, pulse dicho dial.
- Normalmente, seleccione STEREO.

(4) Pulse MENU para que el menú desaparezca.





## Playing back a tape

## Reproducción de cintas

## Viewing the picture recorded in 16:9 mode

- When you play back a picture recorded in 16:9 wide mode of the camcorder, set the LCD 16:9PB mode in the menu.
- Press MENU to display the menu.
- Turn the control dial to select LCD 16:9PB, then press the control dial.
- Turn the control dial to select ON, then press the control dial.
- Press MENU to erase the menu display.



\*2


## Advanced operations

## Watching on a TV screen

Connect this VCR to another VCR or TV to watch the playback picture on the TV screen.

## Connecting directly to a VCR/TV\*

- Open the jack cover. Connect this VCR to the LINE IN inputs on the TV or VCR connected to the TV, using the supplied A/V connecting cable. Set the TV/VCR selector on the TV to VCR.
- When connecting to the VCR, set the input selector on the VCR to LINE.
- your VCR or TV has an S video jack, connect using the supplied S video cable [a] to obtain a high quality picture. If you are going to connect the VCR using the S video cable [a], you do not need to connect the yellow (video) plug of the A/V connecting cable [b].
- Procedure to play back is the same as when playing back on the LCD screen. Turn down the volume of this VCR.



## When connecting the A/V connecting cable

- Connect the plugs to the jacks in the same colors as the VCR and the TV or the other VCR.
- If the VCR or TV is a monaural type

Connect only the white plug for audio on both VCRs or the TV. With this connection, the sound is monaural even in stereo mode.

## Operaciones avanzadas

## Visualización de imágenes en la pantalla de un TV

Conecte esta videocámara a otra videocámara o a un TV para ver la imagen de reproducción en la pantalla del TV.

## Conexión directamente a una videocámara/TV

Abra la cubierta de la toma. Conecte esta videocámara a las entradas LINE IN del TV o videocámara conectada al TV mediante el cable de conexión de A/V suministrado. Ajuste el selector TV/VCR del TV en VCR. Si realiza la conexión a la videocámara, ajuste el selector de entrada de ésta en LINE. Si la videocámara o el TV dispone de una toma de video S, realice la conexión mediante el cable de video S suministrado [a] para obtener imágenes de alta calidad. Si va a conectar la videocámara mediante el cable de video S [a], no es preciso conectar el enchufe amarillo (video) del cable de conexión de A/V [b]. El procedimiento de reproducción es el mismo que para reproducir en la pantalla LCD. Disminuya el volumen de esta videocámara.

**Si conecta el cable de conexión de A/V**  
Conecte los enchufes a las tomas del mismo color en esta videocámara y en el TV o en la otra videocámara.

## Si la videocámara o el TV es de tipo monofónico

Conecte sólo el enchufe blanco de audio en ambas videocámaras o en el TV. Con esta conexión, el sonido será monofónico incluso en el modo estéreo.

## Playing back a tape

## Reproducción de cintas

## Notes on playing back the picture recorded in 16:9 wide mode

- If LCD 16:9PB is set to OFF, the picture appears horizontally compressed.
- The picture output from the VIDEO/AUDIO jacks appears horizontally compressed regardless of the LCD 16:9PB setting.

## Note on LCD 16:9PB setting

If you set LCD 16:9PB to ON when playing back a picture which was not recorded in 16:9 wide mode, the picture will appear widened.

## Notas sobre la reproducción de imágenes grabadas en el modo panorámico de 16:9

- Si LCD 16:9PB está ajustado en OFF, la imagen aparecerá comprimida horizontalmente.
- La imagen enviada desde las tomas VIDEO/AUDIO aparece comprimida horizontalmente independientemente del ajuste de LCD 16:9PB.

## Nota sobre el ajuste de LCD 16:9PB

Si ajusta LCD 16:9PB en ON para reproducir imágenes que no se han grabado en el modo panorámico de 16:9, la imagen aparecerá ensanchada.

13

## Watching on a TV screen

## Visualización de imágenes en la pantalla de un TV

To connect to a VCR or TV without video/audio input jacks  
Use the RFU-95UC RFU adaptor (not supplied).

## To display indicators on the TV

Set DISPLAY to V-OUT/LCD in the menu and press DISPLAY. To turn off, press DISPLAY again.

## Using the AV cordless IR receiver - LASER LINK

Once you connect the AV cordless IR receiver (not supplied) having the LASER LINK mark to your TV or VCR, you can easily view the picture on your TV. For details, refer to the instruction manual of the AV cordless IR receiver.

LASER LINK is a system which transmits and receives a picture and sound between video equipment having the mark by using infrared rays.

LASER LINK is a trademark of Sony Corporation.

## To play back on a TV

- After connecting your TV and AV cordless IR receiver, set the POWER switch on the AV cordless IR receiver to ON.
- Set the POWER switch on this VCR to ON.
- Turn the TV on and set the TV/VCR selector on the TV to VCR.
- Press LASER LINK. The lamp of the LASER LINK button lights up.
- Press PLAY on this VCR to start playback.
- Point the LASER LINK emitter at the AV cordless IR receiver.

Para realizar la conexión a una videocámara o TV sin tomas de entrada de video/audio

Emplee el adaptador RFU-95UC (no suministrado).

## Para mostrar indicadores en el TV

Ajuste DISPLAY en V-OUT/LCD en el menú y pulse DISPLAY. Para desactivarlos, vuelva a pulsar DISPLAY.

## Usando el receptor IR de AV inalámbrico - LASER LINK

Si conecta el receptor IR de AV inalámbrico (no suministrado) que presente la marca LASER LINK al TV o videocámara, podrá ver fácilmente las imágenes en el TV. Para más información, consulte el manual de instrucciones de dicho receptor.

LASER LINK es un sistema que transmite y recibe mediante rayos infrarrojos imágenes y sonido entre equipos de video que presenten la marca .

LASER LINK es una marca comercial de Sony Corporation.

## Para realizar la reproducción en un TV

- Después de conectar el TV y el receptor IR, ajuste el interruptor POWER de éste en ON.
- Ajuste el interruptor POWER de esta videocámara en ON.
- Encienda el TV y ajuste el selector TV/VCR del TV en VCR.
- Pulse LASER LINK. El indicador del botón LASER LINK se ilumina.
- Pulse PLAY en esta videocámara para iniciar la reproducción.
- Oriente el emisor LASER LINK hacia el receptor IR.

## Watching on a TV screen

### If you use a Sony TV

- You can turn on the TV automatically when you press the LASER LINK or ▶ PLAY button. To do so, set the AUTO TV ON to ON in the menu system and turn the TV's main switch on, then do either of the following:
  - Point the LASER LINK emitter towards the TV's remote sensor and press LASER LINK.
  - Turn on the LASER LINK button and press ▶ PLAY.
- You can switch the video input of the TV automatically to the one which the AV cordless IR receiver is connected. To do so, set the AUTO TV ON to ON and the TV INPUT to the same video input (1, 2, 3) in the menu system. With some models, however, the picture and sound may be disconnected momentarily when the video input is switched.
- The above features may not work with some TV models.

### Note

When LASER LINK is activated (the LASER LINK button is lit), the VCR consumes power. Press and turn off the LASER LINK button when it is not needed.

## Visualización de imágenes en la pantalla de un TV

### Si utiliza un TV Sony

- Es posible encenderlo automáticamente al pulsar el botón LASER LINK o ▶ PLAY. Para ello ajuste AUTO TV ON en ON en el sistema de menús y active el interruptor principal del TV; a continuación, realice alguna de las siguientes operaciones:
  - Oriente el emisor LASER LINK hacia el sensor de control remoto del TV y pulse LASER LINK.
  - Active el botón LASER LINK y pulse ▶ PLAY.
- Es posible cambiar automáticamente la entrada de video del TV a la que esté conectada el receptor IR. Para ello, ajuste AUTO TV ON en ON y TV INPUT en la misma entrada de video (1, 2, 3) en el sistema de menús. No obstante, con determinados modelos es posible que la imagen y el sonido se desconecten momentáneamente al cambiar la entrada de video.
- Las características anteriores pueden no funcionar con ciertos modelos de TV.

### Nota

Si LASER LINK está activado (el botón LASER LINK está iluminado), la videocámara consumirá energía. Pulse y desactive el botón LASER LINK si no es necesario.

## Editing onto another tape


## Edición en otra cinta

You can create your own video program by editing with any other 8 mm, Hi8, S-VHS, VHS, S-VHS, VHSC, S-VHSC, Betamax, or ED Betamax VCR that has audio/video inputs.

### Before editing

Connect this (playback) VCR to another (recording) VCR using the supplied A/V connecting cable. Set the input selector on the VCR to LINE, if available.

- While pressing the small green button on the POWER switch, set it to ON.
- Set EDIT to ON in the menu system.



→ : Signal flow / Flujo de señales

If the (recording) VCR is a monaural type  
Connect only the white plug for audio on both VCRs. With this connection, the sound is monaural even in stereo mode.

Puede crear su propio programa de video editando con otra videocámara 8 mm, Hi8, S-VHS, VHS, S-VHS, VHSC, S-VHSC, Betamax, o ED Betamax VCR que disponga de entradas de audio/vídeo.

### Antes de editar

Conecte esta videocámara (reproductora) a otra videocámara (grabadora) mediante el cable de conexión de A/V suministrado. Ajuste el selector TV/VCR del TV en VCR. Si se encuentra disponible, ajuste el selector de entrada de la videocámara en LINE.

- Ajuste el interruptor POWER en ON mientras pulsa el botón verde pequeño del mismo.
- Ajuste EDIT en ON en el sistema de menús.

Advanced operations / Operaciones avanzadas

Si la videocámara (grabadora) es del tipo monofónico  
Conecte sólo el enchufe blanco de audio en ambas videocámaras. Con esta conexión, el sonido será monofónico incluso en el modo estéreo.

## Recording from a VCR or TV

## Grabación desde una videocámara o TV

You can record a tape from another VCR or a TV program from a TV that has video/audio outputs. Connect this (recording) VCR to the (playback) VCR or TV. Turn down the volume of this VCR while editing. Otherwise, picture distortion may occur.

- While pressing the small green button on the POWER switch, set it to ON.
- Press the two REC buttons at the same time, then press II to set the VCR to recording pause mode. The REC (red) and PAUSE (orange) lamps light up.

- Start playing back a tape on the (playback) VCR or turn in the TV program you want to record. The pictures on the VCR or TV appear on the LCD screen of this VCR.
- Press II at the point where you want to start recording. The REC lamp remains on and the PAUSE lamp goes off.

S VIDEO and VIDEO/AUDIO jacks automatically work as input jacks.  
If the (playback) VCR or TV has an S video jack, connect using the S video cable [a] to obtain high quality picture.

Es posible grabar cintas desde otra videocámara o programas de TV desde un TV que disponga de salidas de video/audio. Conecte esta videocámara a la reproductora o al TV. Disminuya el volumen de esta videocámara durante la edición, ya que en caso contrario la imagen puede distorsionarse.

- Ajuste el interruptor POWER en ON mientras pulsa el botón verde pequeño del mismo.


(2) Pulse simultáneamente los dos botones REC y, a continuación, II para ajustar la videocámara en el modo de pausa de grabación. Los indicadores REC (rojo) y PAUSE (naranja) se iluminan.

- Inicie la reproducción de la cinta de la videocámara (reproductora) o sintonice el programa de TV que desea grabar. Las imágenes de la videocámara o del TV aparecen en la pantalla LCD de esta videocámara.

(4) Pulse II en el punto donde desea iniciar la grabación. El indicador REC permanece encendido, mientras que el PAUSE se apaga.

Las tomas S VIDEO y VIDEO/AUDIO funcionan automáticamente como tomas de entrada. Si la videocámara (reproductora) o el TV dispone de toma de video S, realice la conexión con el cable de video S [a] para obtener imágenes de alta calidad.

Apéndice suscriptores / Suscripción para lectores



If the (playback) VCR or TV is a monaural type, connect only the white plug for audio on the VCR or TV. Do not connect the red plug. With this connection, the recorded sound is monaural. If you are going to connect the VCR using the S video cable [a], you do not need to connect the yellow (video) plug of the A/V connecting cable [b].

## Recording from a VCR or TV

### Note on the S video jack

If the S video jack is not provided on the TV or VCR, do not connect the S video cable to this VCR. Pictures will not appear.

### To stop recording

Press □.

### Notes on recording

- When you record from the beginning of the tape, run the tape for about 15 seconds before you start recording. Otherwise, the first scenes may not be played back on other players.
- You cannot record a picture that has a copyright control signal for copyright protection of software. "COPY INHIBIT" appears if you try to record such a picture.

### To record TV programs

The TGV-100 TV tuner unit (not supplied) enables you to record the TV program easily without connecting the VCR to the TV. See the operating instructions of the TV tuner unit for details.

## Grabación desde una videocámaras o TV

### Nota sobre la toma de video S

Si el TV o la videocámaras no dispone de toma de video S, no conecte el cable de video S a esta videocámaras. Las imágenes no aparecerán.

### Para detener la grabación

Pulse □.

### Notas sobre la grabación

- Si graba desde el principio de la cinta, ponga ésta en funcionamiento aproximadamente 15 segundos antes de iniciar la grabación. En caso contrario, es posible que las primeras escenas no se reproduzcan en otros reproductores.
- No es posible grabar imágenes que presenten señales de control de protección del copyright de software. Si intenta reproducir dicho tipo de imágenes, aparecerá "COPY INHIBIT".

### Para grabar programas de TV

La unidad de sintonización de TV TGV-100 (no suministrada) permite grabar programas de TV con facilidad sin conectar la videocámaras al TV. Consulte el manual de instrucciones de dicha unidad para más información.

## Changing the mode settings


## Cambio de los ajustes de modo

You can change the mode settings in the menu system to further enjoy the features and functions of the VCR.

- Press MENU to display the menu.
- Turn the control dial to select the desired item, then press the control dial. Only the selected item is displayed.
- Turn the control dial to select the desired mode, then press the control dial. If you want to change the other modes, repeat steps 2 and 3.
- Press MENU to erase the menu display.

Es posible cambiar los ajustes de modo en el sistema de menús para disfrutar en mayor medida de las características y funciones de la videocámaras.

- Pulse MENU para mostrar el menú.
- Gire el dial de control para seleccionar el elemento que deseas y, a continuación, pulselo. Solo aparecerá el elemento seleccionado.
- Gire el dial de control para seleccionar el modo que deseas y, a continuación, pulselo. Si deseas cambiar otros modos, repita los pasos 2 y 3.
- Pulse MENU para que el menú desaparezca.



## Changing the mode settings

## Cambio de los ajustes de modo

### Selecting the mode setting of each item

#### COMMANDER <ON/OFF>

- Select ON when using a Remote Commander (not supplied).
- Select OFF when not using a Remote Commander.

#### EDIT <ON/OFF>

- Select ON to minimize picture deterioration when editing.
- Normally select OFF.

#### HIFI SOUND <STEREO/1/2>

- Normally select STEREO.
- Select 1 or 2 to play back a dual soundtrack tape.

#### COUNTER\* <NORMAL/TIME CODE>

- Normally select NORMAL.
- Select TIME CODE to display the RC time code in order to edit more precisely.

#### REC MODE\* <SP/LP>

- Select SP when recording in SP (standard play) mode.
- Select LP when recording in LP (long play) mode.

#### TBC\* <ON/OFF>

- Normally select ON, to correct for jitter.
- Select OFF to not correct for jitter. The picture may not be steady when played back.

#### Note on TBC setting

Set TBC to OFF when playing back:

- A tape recorded when the VCR was shaking.
- A tape on which you recorded a low quality TV signal.
- A tape you have dubbed over.
- A tape on which you recorded the signal of a TV game or similar machine.

### Selección del ajuste de modo de cada elemento

#### COMMANDER <ON/OFF>

- Seleccione ON si utiliza un mando a distancia (no suministrado).
- Seleccione OFF si no utiliza un mando a distancia.

#### EDIT <ON/OFF>

- Seleccione ON para reducir el deterioro de imagen al editar.
- Normalmente, seleccione OFF.

#### HIFI SOUND <STEREO/1/2>

- Normalmente, seleccione STEREO.
- Seleccione 1 o 2 para reproducir cintas de pista de sonido dual.

#### COUNTER\* <NORMAL/TIME CODE>

- Normalmente, seleccione NORMAL.
- Seleccione TIME CODE para mostrar el código de tiempos RC con el fin de editar con mayor precisión.

#### REC MODE\* <SP/LP>

- Seleccione SP al grabar en el modo SP (reproducción estándar).
- Seleccione LP al grabar en el modo LP (reproducción de larga duración).

#### TBC\* <ON/OFF>

- Normalmente, seleccione ON para corregir vibraciones.
- Seleccione OFF si no desea corregir vibraciones. Es posible que la imagen no aparezca estable al reproducirse.

#### Nota sobre el ajuste TBC

Ajuste TBC en OFF para reproducir:

- Cintas grabadas mientras la videocámaras sufría sacudidas.
- Cintas en las que se grabaron señales de TV de baja calidad.
- Cintas copiadas.
- Cintas en las que se grabaron señales de un juego de TV o dispositivo similar.

## Changing the mode settings

## Cambio de los ajustes de modo

#### DNR\* <ON/OFF>

- Normalmente select ON para reducir el ruido de imagen.
- Select OFF if the picture has a lot of movement, causing a conspicuous afterimage.

#### LCD COLOR\* <OFF/ON>

- Normalmente select OFF.
- Select ON to view the picture recorded in 16:9 wide mode.

#### LCD COLOR\*

- Select this item and change the level of the indicator by turning the control dial to adjust the color intensity of the picture.

#### LCD HUE\*

- Select this item and change the level of the indicator by turning the control dial to adjust the hue of the picture.

#### BEEP\* <ON/OFF>

- Select ON so that beeps sound when you turn the power on, etc.
- Select OFF when you do not want to hear the beep sound.

#### DISPLAY\* <LCD or V-OUT/LCD>

- Normalmente select LCD.
- Select V-OUT/LCD to display indicator both on the LCD screen and the TV screen.

#### Note on DISPLAY setting

If you press the DISPLAY button with DISPLAY set to V-OUT/LCD, you cannot input an external signal.

#### AUTO TV ON\* <OFF/ON>

- You can use this feature only with Sony TVs.
- Select ON to turn on the TV automatically when using the LASER LINK function.
- Select OFF not to turn on the TV.

#### TV INPUT\* <VIDEO1/VIDEO2/VIDEO3/OFF>

- Select 1 or 2 or 3 of the video input on the TV which the IR receiver (not supplied) is connected to when using the LASER LINK function.

\* These settings are retained even when the battery is removed, as long as the vanadium-lithium battery is charged. As far as the items without an asterisk are concerned, their settings return to the default 5 minutes or more after the battery is removed.

#### AUTO TV ON\* <OFF/ON>

Sólo es posible utilizar esta función con televisores Sony.

- Seleccione ON para encender el TV automáticamente al emplear la función LASER LINK.
- Seleccione OFF si no desea encender el TV.

#### TV INPUT\* <VIDEO1/VIDEO2/VIDEO3/OFF>

Seleccione 1 o 2 o 3 de la entrada de video del TV que la que esté conectado el receptor IR (no suministrado) al emplear la función LASER LINK.

- Estos ajustes se conservan aunque retire la batería, siempre que la pila de vanadio-litio esté cargada. En cuanto a los elementos sin asterisco, sus ajustes recuperan el valor por omisión 5 minutos o más después de extraer la batería.

## Using alternative power sources

You can choose any of the following power sources for your VCR: battery pack, house current, and 12/24 V car battery. Choose the appropriate power source depending on where you want to use your VCR.

Place	Power source	Accessory to be used
Indoors	House current	Supplied AC power adaptor
Outdoors	Battery pack	Battery pack NP-F530, NP-F730, NP-F930
In the car	12 V or 24 V car battery	Sony car battery charger DC-V515A

### Note on power sources

Disconnecting the power source or removing the battery pack during recording or playback may damage the inserted tape. If this happens, restore the power supply again immediately.

## Uso de fuentes de alimentación alternativas

Es posible elegir cualquiera de las siguientes fuentes de alimentación para la videocámara: paquete de batería, corriente doméstica y batería de automóvil de 12/24 V. Elija la fuente adecuada en función del lugar donde deseé emplear la videocámara.

Lugar	Fuente de alimentación	Accesorio necesario
Interior	Corriente doméstica	Adaptador de alimentación de CA suministrado
Exterior	Paquete de batería	Paquete de batería NP-F530, NP-F730, NP-F930
En el coche	Batería de automóvil de 12V o de 24V	Cargador Sony de batería de automóvil DC-V515A

**Nota sobre las fuentes de alimentación**  
Si desconecta la fuente de alimentación o extrae el paquete de batería durante la grabación o la reproducción, puede dañar la cinta insertada. Si esto ocurre, vuelve a restaurar el suministro de alimentación inmediatamente.

## Using alternative power sources

This VCR operates with the "InfoLITHIUM" battery pack (not supplied). If you use any other battery pack to operate your VCR, the VCR may not operate or the battery life may be shortened.

"InfoLITHIUM" is a trademark of Sony Corporation.

### Charging the battery pack

- (1) Connect the power cord to the AC power adaptor.
- (2) Align the surface of the battery pack indicated by the ▶ mark with the edge of the terminal shutter of the AC power adaptor. Then fit and slide the battery pack in the direction of the arrow.
- (3) Connect the power cord to a wall outlet. The CHARGE lamp (orange) lights up. Charging begins. When the CHARGE lamp goes out, normal charge is completed (Normal charge). For a full charge, which allows you to use the battery longer than usual, leave the battery pack in place for approximately one hour (Full charge). Unplug the AC power cord from the wall outlet, then remove the battery pack and install it into the VCR. You can also use the battery pack before it is completely charged.
- (4) When it is charged, remove the battery pack.

## Uso de fuentes de alimentación alternativas


### Uso del paquete de batería

Esta videocámara funciona con el paquete de batería "InfoLITHIUM" (no suministrado). Si emplea otro tipo de paquete para emplear la videocámara, es posible que ésta no funcione o que la duración de la batería se reduzca.

"InfoLITHIUM" es una marca comercial de Sony Corporation.

### Carga del paquete de batería

- (1) Conecte el cable de alimentación al adaptador de CA.
- (2) Alinee la superficie del paquete, indicada con la marca ▶, con el borde del obturador del terminal del adaptador de alimentación de CA. A continuación, encaje y deslice el paquete en la dirección de la flecha.
- (3) Conecte el cable de alimentación de CA a una toma mural. El indicador CHARGE (naranja) se ilumina y la carga comienza. Cuando el indicador CHARGE se apague, significa que la carga normal ha finalizado (carga normal). Para obtener una carga completa, que permite emplear la batería durante más tiempo del habitual, deje el paquete de batería cargándose durante aproximadamente una hora (carga completa). Desenchufe el cable de alimentación de CA de la toma mural, extraiga el paquete de batería e instálelo en la videocámara. También puede emplear dicho paquete antes de que esté completamente cargado.
- (4) Una vez cargado, extraiga el paquete de batería.



## Using alternative power sources

## Uso de fuentes de alimentación alternativas

### Charging time

Battery pack	Charging time *
NP-F530	170 (110)
NP-F730	250 (190)
NP-F930	330 (270)

Numbers in parentheses indicate the time for a normal charge. (Normal charge)

\* Approximate number of minutes to charge an empty battery pack fully using the supplied AC power adaptor. (Full charge) (Lower temperatures require a longer charging time.)

### Battery life

Battery pack	Playback time
NP-F530	90 (80)
NP-F730	205 (185)
NP-F930	315 (285)

Numbers in parentheses indicate the time when you use a normal charged battery pack.

**Note on remaining battery time indication**  
Remaining battery time is displayed on the LCD screen. It may not be displayed properly, however, depending on the conditions and circumstances of use.

### Notes on charging the battery pack

- The CHARGE lamp will remain lit for a while even if the battery pack is removed and the power cord is unplugged after charging the battery pack. This is normal.
- If the CHARGE lamp does not light, disconnect the power cord. After about one minute, reconnect the power cord again.
- You cannot charge the battery pack while operating the VCR using the AC power adaptor.
- When a fully charged battery pack is installed, the CHARGE lamp will light once, then go out.

### Tiempo de carga

Paquete de batería	Tiempo de carga *
NP-F530	170 (110)
NP-F730	250 (190)
NP-F930	330 (270)

Los números entre paréntesis indican el tiempo de una carga normal.

\* Número aproximado de minutos para cargar completamente un paquete de batería descargado mediante el adaptador de alimentación de CA suministrado (carga completa). (Las temperaturas bajas requieren un tiempo de carga mayor.)

### Duración de la batería

Paquete de batería	Tiempo de reproducción
NP-F530	90 (80)
NP-F730	205 (185)
NP-F930	315 (285)

Los números entre paréntesis indican el tiempo al emplear un paquete de batería con carga normal.

### Nota sobre la indicación de tiempo de batería restante

El tiempo de batería restante aparece en la pantalla LCD. No obstante, es posible que no aparezca correctamente en función de las condiciones y circunstancias de uso.

### Notas sobre la carga del paquete de batería


- El indicador CHARGE permanecerá iluminado durante unos instantes aunque haya retirado el paquete de batería y haya desenchufado el cable de alimentación después de cargar dicho paquete. Esto es normal.
- Si el indicador CHARGE no se ilumina, desconecte el cable de alimentación. Transcurrido un minuto aproximadamente, vuelva a conectarlo.
- No es posible cargar el paquete de batería mientras emplea la videocámara con el adaptador de alimentación de CA.
- Al instalar un paquete de batería completamente cargado, el indicador CHARGE se iluminará una vez y, a continuación, se apagará.

## Using alternative power sources

## Uso de fuentes de alimentación alternativas

### Install the battery pack on the VCR

While pressing the battery pack, slide it to the left so that it attaches to the battery mounting surface firmly.



**Note on the battery pack**  
Do not carry the VCR by grasping the battery pack.

**To remove the battery pack**  
While pressing BATT., slide the battery pack to the right.

### Using a car battery

Use a car battery charger such as Sony DC-V515A (not supplied). Connect the car battery cord to the cigarette lighter socket of a car (12 V or 24 V). Connect the car battery charger and the VCR using the supplied DK-415 connecting cord.

### Instale el paquete de batería en la videocámara

Mientras presiona el paquete, deslizelo a la izquierda de forma que quede firmemente fijado en la superficie de montaje de la batería.

**Nota sobre el paquete de batería**  
No transporte la videocámara agarrando el paquete de batería.

**Para extraer el paquete de batería**  
Deslice el paquete de batería a la derecha mientras pulsa BATT.

### Usa de una batería de automóvil

Emplea un cargador de batería de automóvil, como el DC-V515A de Sony (no suministrado). Conecte el cable de batería de automóvil a la clavija del encendedor del automóvil (12 V o 24 V). Conecte el cargador de batería de automóvil y la videocámara con el cable de conexión DK-415 suministrado.



This mark indicates that this product is a genuine accessory for Sony video product.  
When purchasing Sony video products, Sony recommends that you purchase accessories with this "GENUINE VIDEO ACCESSORIES" mark.



Esta marca indica que este producto es un accesorio genuino para productos de video Sony.  
Al adquirir productos de video Sony, Sony recomienda accesorios que presenten la marca "GENUINE VIDEO ACCESSORIES".

#### Additional information

### Charging the vanadium-lithium battery in the VCR

Your VCR is supplied with a vanadium-lithium battery installed so as to retain the menu settings, regardless of the setting of the POWER switch. The vanadium-lithium battery is always charged as long as you are using the VCR. The battery, however, will get discharged gradually if you do not use the VCR. It will be completely discharged in about 1 year if you do not use the VCR at all. Even if the vanadium-lithium battery is not charged, it will not affect the VCR operation. To retain the menu settings, charge the battery if the battery is discharged. The following are charging methods:

- Connect the VCR to a wall outlet using the supplied AC power adaptor, and leave the VCR with the POWER switch turned off for more than 24 hours.
- Install the fully charged battery pack on the VCR, and leave the VCR with the POWER switch turned off for more than 24 hours.

#### Información complementaria

### Carga de la pila de vanadio-litio de la videocámara

La videocámara se suministra con una pila de vanadio-litio instalada para conservar los ajustes de menú, independientemente del ajuste del interruptor POWER. Dicha pila siempre está cargada en tanto se utilice la videocámara. No obstante, se descargará gradualmente si no se utiliza la videocámara. Se descargará por completo en 1 año aproximadamente si no se utiliza la videocámara en absoluto. Aunque la pila de vanadio-litio no esté cargada, no afectará al funcionamiento de la videocámara. Para conservar los ajustes de menú, cargue la pila si está descargada. A continuación se describen métodos de carga:

- Conecte la videocámara a una toma mural mediante el adaptador de alimentación de CA suministrado, y déjela con el interruptor POWER desactivado durante más de 24 horas.
- Instale el paquete de batería completamente cargado en la videocámara, y déjela con el interruptor POWER desactivado durante más de 24 horas.

### Usable cassettes and playback modes

#### Selecting cassette types

This Hi8 system is an extension of the standard 8 mm systems, and was developed for higher-quality pictures. You can use Hi8 video and standard 8 mm cassettes. When you want to record in the Hi8 system, use only Hi8 video cassettes. You cannot record on standard 8 mm cassettes in the Hi8 system.

#### When you play back

The playback mode (SP/LP mode or Hi8/standard 8 mm) is selected automatically according to the format in which the tape has been recorded. The quality of the recorded picture in LP mode, however, will not be as good as that in SP mode.

#### Note on AFM Hi-Fi stereo

When you play back a tape, the sound will be in monaural if:

- you record the tape using this VCR, then play it back on an AFM Hi-Fi monaural video recorder/player.
- you record the tape on an AFM Hi-Fi monaural video recorder, then play it back on this VCR.

#### Recording mode

When you play back a tape, the SP/LP indicator on the LCD screen shows the recording mode SP/LP.

#### Foreign 8 mm Video

You may not play back tapes recorded on a different TV color system. Because the TV color systems differ from country to country, you may not be able to play back foreign pre-recorded tapes. Refer to the list of "Using your VCR abroad" to check the TV color system of foreign countries.

### Videocassettes utilizables y modos de reproducción

#### Selección del tipo de videocassette

Este sistema Hi8 es una extensión de los sistemas estándares de 8 mm, y se ha desarrollado para proporcionar imágenes de mayor calidad. Es posible utilizar videocasettes Hi8 y estándar de 8 mm. Si desea grabar en el sistema Hi8, emplee sólo videocasettes Hi8. No es posible grabar en videocasettes estándar de 8 mm en el sistema Hi8.

#### Al realizar la reproducción

El modo de reproducción (SP/LP o Hi8/estándar de 8 mm) se selecciona automáticamente según el formato en el que se ha grabado la cinta. No obstante, la calidad de las imágenes grabadas en el modo LP no será tan buena como la del modo SP.

#### Nota sobre el sonido estéreo AFM Hi-Fi

Al reproducir una cinta, el sonido será monofónico si:

- graba la cinta con esta videocámara y la reproduce en una videocámara/reproductor AFM Hi-Fi monofónico.
- graba la cinta en una videocámara monofónica AFM Hi-Fi y la reproduce en esta videocámara.

#### Modo de grabación

Al reproducir una cinta, el indicador SP/LP de la pantalla LCD muestra el modo de grabación SP/LP.

#### Vídeos de 8 mm extranjeros

Es posible que no pueda reproducir cintas grabadas en un sistema de color de TV diferente. Puesto que los sistemas de color de TV varían en función del país, es posible que no pueda reproducir cintas extranjeras previamente grabadas. Consulte la lista que aparece en "Uso de la videocámara en el extranjero" para obtener información sobre el sistema de color de TV de países extranjeros.

### Notes on "InfoLITHIUM" battery pack

#### "InfoLITHIUM" battery pack

The "InfoLITHIUM" battery pack is a lithium battery pack which can exchange data with compatible video equipment about its battery consumption.

Sony recommends that you use the "InfoLITHIUM" battery pack with video equipment having the  mark. When you use this battery pack with video equipment having the  mark, the video equipment will indicate the remaining battery time in minutes.\* However, if you use it with video equipment not having this mark, the remaining battery capacity will not be indicated in minutes.

\* The indication may not be accurate depending on the condition and environment in which the equipment is used under.

#### How the battery consumption is displayed

The power consumption of the VCR changes depending on its use.

While checking the condition of the VCR, the "InfoLITHIUM" battery pack measures the battery consumption and calculates the remaining battery power. If the condition changes drastically, the remaining battery indication may suddenly decrease or increase by more than 2 minutes. Even if 5 to 10 minutes is indicated as the battery remaining time on the LCD screen, the  indicator may also flash under some conditions.

### Notas sobre el paquete de batería "InfoLITHIUM"

#### Paquete de batería "InfoLITHIUM"

"InfoLITHIUM" es un paquete de batería de litio que puede intercambiar datos con equipos de video compatibles sobre su consumo de energía. Sony recomienda el empleo del paquete de batería "InfoLITHIUM" con equipos de video que presenten la marca .

Si utiliza este paquete de batería con un equipo de video que presente la marca , dicho equipo indicará el tiempo de batería restante en minutos\*. No obstante, si lo utiliza con un equipo que no presente dicha marca, la capacidad de batería restante no se indicará en minutos.

\* La indicación puede no ser precisa en función de la condición y entorno en los que se emplee el equipo.

#### Cómo se muestra el consumo de batería

El consumo de energía de la videocámara cambia dependiendo de su uso.

Mientras comprueba la condición de la videocámara, el paquete de batería "InfoLITHIUM" mide el consumo de energía y calcula la energía restante de la batería. Si la condición cambia drásticamente, es posible que la indicación de batería restante disminuya o aumente repentinamente en más de 2 minutos. Aunque se indiquen de 5 a 10 minutos como el tiempo de batería restante en la pantalla LCD, es posible que el indicador  también parpadee en ciertas condiciones.

### Notes on "InfoLITHIUM" battery pack

#### To obtain more accurate remaining battery indication

If the indication seems incorrect, use up the battery pack and then recharge it fully (Full charge<sup>1)</sup>). Note that if you have used the battery in a hot or cold environment for long time, or you have repeated charging many times, the battery pack may not be able to show the correct time even after being fully charged.

After you have used the "InfoLITHIUM" battery pack with an equipment not having the  mark, make sure that you use up the battery pack on the equipment having the  mark and then recharge fully.

#### Why the remaining battery indication does not match the battery life in the operation manual

The battery life is affected by the environmental temperature and conditions. The battery life becomes very short in a cold environment. The battery life in the operation manual is measured under the condition of using a fully charged (or normal charged<sup>2)</sup>) battery pack in 77°F (25°C). As the environmental temperature and condition are different when you actually use the VCR, the remaining battery time is not same as the battery life in the operation manual.

<sup>1)</sup> Full charge: Charging for about 1 hour after the CHARGE lamp of the AC power adaptor goes off.

<sup>2)</sup> Normal charge: Charging just until the CHARGE lamp of the AC power adaptor goes off.

### Notas sobre el paquete de batería "InfoLITHIUM"

#### Para obtener una indicación de batería restante más precisa

Si la indicación parece incorrecta, agote el paquete de batería y, a continuación, recárguelo por completo (carga completa<sup>1)</sup>). Tenga en cuenta que si ha empleado la batería en un entorno cálido o frío durante mucho tiempo, o si ha repetido la carga muchas veces, es posible que el paquete de batería no pueda mostrar el tiempo correcto incluso después de cargarse por completo.

Después de haber empleado el paquete de batería "InfoLITHIUM" con un equipo que no presente la marca , asegúrese de agotar dicho paquete en el equipo que presente la marca  y, a continuación, recárguelo por completo.

#### Porqué la indicación de batería restante no coincide con la duración que aparece en el manual de instrucciones

La duración de la batería se ve afectada por las condiciones y temperatura ambiental. Dicha duración se reduce notablemente en entornos fríos. La duración de la batería del manual de instrucciones se ha medido utilizando un paquete completamente cargado (o con carga normal<sup>2)</sup>) a 77°F (25°C). Puesto que la condición y temperatura ambiental son diferentes cuando la videocámara se utiliza en la realidad, el tiempo de batería restante no es el mismo que la duración de dicha batería que aparece en el manual de instrucciones.

<sup>1)</sup> Carga completa: Carga realizada durante aproximadamente 1 hora después de apagarse el indicador CHARGE del adaptador de alimentación de CA.

<sup>2)</sup> Carga normal: Carga realizada justo hasta apagarse el indicador CHARGE del adaptador de alimentación de CA.

## Maintenance information and precautions

### Moisture condensation

If the VCR is brought directly from a cold place to a warm place, moisture may condense inside the VCR, on the surface of the tape, or on the head drum. In this condition, the tape may stick to the head drum and be damaged or the VCR may not operate correctly. To prevent possible damage under these circumstances, the VCR is furnished with moisture sensors. Take the following precautions.

### Inside the VCR

If there is moisture inside the VCR, the beep sounds and the **[■]** indicator flashes on the LCD screen. If this happens, none of the function except cassette ejection will work. Open the cassette compartment, turn off the VCR, and leave it about 1 hour. When **[■]** indicator flashes at the same time, the cassette is inserted in the VCR. Eject the cassette, turn off the VCR, and leave also the cassette about 1 hour.

### How to prevent moisture condensation

When bringing the VCR from a cold place to a warm place, put the VCR in a plastic bag and allow it to adapt to room conditions over a period of time.

(1) Be sure to tightly seal the plastic bag containing the VCR.

(2) Remove the bag when the air temperature inside it has reached the temperature surrounding it (after about 1 hour).

## Información y precauciones sobre mantenimiento

### Condensación de humedad

Si traslada la videocámara directamente de un lugar frío a otro cálido, es posible que se condense humedad en el interior de la misma, en la superficie de la cinta o en el tambor del cabezal. En estas condiciones, la cinta puede adherirse en el tambor del cabezal y dañarse o la videocámara puede no funcionar correctamente. Para evitar posibles daños en estas circunstancias, la videocámara está equipada con sensores de humedad. Tome las siguientes precauciones.

### Interior de la videocámara

Si hay humedad en el interior de la videocámara, se oír un pitido y el indicador **[■]** parpadeará en la pantalla LCD. Si esto ocurre, no se activará ninguna función, excepto la de expulsión de videocassettes. Abra el compartimento de videocassettes, apague la videocámara y no la utilice durante 1 hora aproximadamente. Si el indicador **[■]** parpadea simultáneamente, significa que el videocassette está insertado en la videocámara. Expúlselo, apague la videocámara y tómelo y utilice el videocassete durante 1 hora aproximadamente.

### Cómo evitar la condensación de humedad

Cuando traslade la videocámara de un lugar frío a otro cálido, introduzcala en una bolsa de plástico y déjela que se adapte a las condiciones de la sala durante un espacio de tiempo.

(1) Asegúrese de cerrar herméticamente la bolsa de plástico en la que se encuentra la videocámara.

(2) Retire la bolsa cuando la temperatura de su interior alcance la del lugar en la que se encuentra (después de 1 hora aproximadamente).

## Maintenance information and precautions

### Video head cleaning

To ensure normal recording and clear pictures, clean the video heads. When the **[●]** indicator and **[■]** CLEANING CASSETTE message appear one after another on the LCD screen or playback pictures are "noisy" or hardly visible, the video heads may be dirty.



[a]



[b]

[a] Slightly dirty

[b] Very dirty

If this happens, clean the video heads with the Sony V8-25CLH cleaning cassette (not supplied). After checking the picture, if it is still "noisy," repeat the cleaning. (Do not repeat cleaning more than 5 times in one session.)

### Caution

Do not use a commercially available wet-type cleaning cassette. It may damage the video heads.

### Note

If the V8-25CLH cleaning cassette is not available in your area, consult your nearest Sony dealer.

## Información y precauciones sobre mantenimiento

### Limpieza de los cabezales de video

Para garantizar grabaciones normales e imágenes nítidas, limpie los cabezales de video. Si el indicador **[●]** y el mensaje "**[■]** CLEANING CASSETTE" aparecen uno tras otro en la pantalla LCD o si las imágenes de reproducción aparecen con "ruído" o apenas se ven, es posible que los cabezales de video estén sucios.

Additional Information / Información complementaria

32

33

## Maintenance information and precautions

### Precautions

#### VCR operation

- Operate the VCR on 8.4 V (AC power adaptor) or 7.2 V (battery pack).
- Should any solid object or liquid get inside the casing, unplug the VCR and have it checked by Sony dealer before operating it any further.
- Avoid rough handling or mechanical shock.
- Keep the POWER switch set to OFF when not using the VCR.
- Do not wrap up the VCR and operate it since heat may build up internally.
- Keep the VCR away from strong magnetic fields or mechanical vibration.
- Do not push the LCD screen.
- If the VCR is used in a cold place, a residual image may appear on the LCD screen. This is not a malfunction.
- While using the VCR, the back of the LCD screen may heat up. This is not a malfunction.

#### On handling tapes

Do not insert anything in the small holes on the rear of the cassette. These holes are used to sense the type of tape, thickness of tape and if the recording tab is in or out.

#### VCR care

- When the VCR is not to be used for a long time, disconnect the power source and remove the tape. Periodically turn on the power, play back a tape for about 3 minutes.
- If fingerprints or dust are on the LCD screen, we recommend you remove them using the LCD cleaning kit (not supplied).
- Clean the VCR body with a dry soft cloth, or a soft cloth lightly moistened with a mild detergent solution. Do not use any type of solvent which may damage the finish.
- Do not let sand get into the VCR. When you use the VCR on a sandy beach or in a dusty place, protect it from the sand or dust. Sand or dust may cause the unit to malfunction, and sometimes this malfunction cannot be repaired.

## Información y precauciones sobre mantenimiento

### Precauciones

#### Empleo de la videocámara

- Emplee la videocámara con 8.4 V (adaptador de alimentación de CA) o con 7.2 V (paquete de batería).
- Si se introduce algún objeto sólido o líquido en la videocámara, desenchufela y haga que sea revisada por un proveedor Sony antes de volver a utilizarla.
- Evite manejara bruscamente y los golpes mecánicos.
- Mantenga el interruptor POWER ajustado en OFF cuando no utilice la videocámara.
- No cubra la videocámara mientras la emplea, ya que puede producirse recalentamiento interno.
- Mantenga la videocámara alejada de campos magnéticos intensos y de vibraciones mecánicas.
- No presione la pantalla LCD.
- Si utiliza la videocámara en un lugar frío, es posible que aparezca una imagen residual en la pantalla LCD. Esto no es un fallo de funcionamiento.
- Mientras emplea la videocámara, es posible que la parte trasera de la pantalla LCD se caliente. Esto no es un fallo de funcionamiento.

#### Manejo de cintas

No inserte nada en los orificios pequeños de la parte posterior del videocassete. Estos orificios se utilizan para detectar el tipo de cinta, el grosor de ésta y si la lengüeta de grabación se encuentra dentro o fuera.

#### Cuidados de la videocámara

- Si no va a utilizar la videocámara durante mucho tiempo, desconecte la fuente de alimentación y extraiga la cinta.
- Periodicamente, active la alimentación y reproduzca una cinta durante unos 3 minutos.
- Si hay huellas dactilares o polvo en la pantalla LCD, recomienda eliminarlos con un kit de limpieza LCD (no suministrado).
- Limpie el exterior de la videocámara con un paño seco y suave, o con un paño suave ligeramente humedecido con una solución detergente poco concentrada. No utilice ningún tipo de disolvente, ya que puede dañar el acabado.

## Maintenance information and precautions

### On AC power adaptor

#### Charging

- Use only a lithium ion type battery pack.
- Place the battery pack on a flat surface without vibration during charging.
- The battery pack will get hot during charging. This is normal.

#### Others

- Unplug the unit from the wall outlet when not in use for a long time. To disconnect the power cord, pull it out by the plug. Never pull the cord itself.
- Do not operate the unit with a damaged cord or if the unit has been dropped or damaged.
- Do not bend the AC power cord forcibly, or put a heavy object on it. This will damage the cord and may cause a fire or an electrical shock.
- Be sure that nothing metallic comes into contact with the metal parts of the connecting plate. If this happens, a short may occur and the unit may be damaged.
- Always keep the metal contacts clean.
- Do not disassemble the unit.
- Do not apply mechanical shock or drop the unit.
- While the unit is in use, particularly during charging, keep it away from AM receivers and video equipment because it will disturb AM reception and video operation.
- The unit becomes warm while in use. This is normal.
- Do not place the unit in locations that are:

  - Extremely hot or cold
  - Dusty or dirty
  - Very humid
  - Vibrating

If any difficulty should arise, unplug the unit and contact your nearest Sony dealer.

## Información y precauciones sobre mantenimiento

### Adaptador de alimentación de CA

#### Carga

- Utilice sólo paquetes de batería de tipo ion de arena.
- Coloque el paquete de batería sobre una superficie plana sin vibraciones durante la carga.
- El paquete de batería se calienta durante la carga. Esto es normal.

#### Otros

- Desenchufe la unidad de la toma mural cuando no la utilice durante mucho tiempo. Para desconectar el cable de alimentación, tire del enchufe, nunca del propio cable.
- No utilice la unidad con un cable dañado o si dicha unidad se ha caído o dañado.
- No doble a la fuerza el cable de alimentación de CA, ni ponga objetos pesados sobre él. Si lo hace, el cable se dañará y puede causar un incendio o descargas eléctricas.
- Asegúrese de que ningún objeto metálico entre en contacto con los componentes metálicos de la placa de conexión. Si esto ocurre, puede producirse un cortocircuito y dañarse la unidad.
- Mantenga los contactos metálicos siempre limpios.
- No desmonte la unidad.
- No aplique golpes mecánicos sobre la unidad ni la deje caer.
- Mientras la unidad se encuentre en uso, particularmente durante la carga, manténgala alejada de receptores de AM y de equipos de video, ya que dificultará la recepción de AM y el funcionamiento del video.
- La unidad se calienta durante el uso. Esto es normal.
- No coloque la unidad en lugares:

  - Extremadamente cálidos o fríos
  - Polvorientos o sucios
  - Muy húmedos
  - Con vibraciones

Si surgen dificultades, desenchufe la unidad y póngase en contacto con el proveedor Sony más próximo.


Additional Information / Información complementaria

## Using your VCR abroad

Each country or area has its own electric and TV color systems. Before using your VCR abroad, check the following points.

### Power sources

You can use your VCR in any country or area with the supplied AC power adaptor within 100 V to 240 V AC, 50/60 Hz. Use a commercially available AC plug adaptor [a], if necessary, depending on the wall outlet [b].



### Difference in color systems

This VCR is an NTSC system-based VCR. If you want to view the playback picture on a TV, it must be an NTSC system-based TV. Check the following list.

#### NTSC system

Bahamas Islands, Bolivia, Canada, Central America, Chile, Colombia, Ecuador, Jamaica, Japan, Korea, Mexico, Peru, Surinam, Taiwan, the Philippines, the U.S.A., Venezuela, etc.

#### PAL system

Australia, Austria, Belgium, China, Czech Republic, Denmark, Finland, Germany, Great Britain, Holland, Hong Kong, Italy, Kuwait, Malaysia, New Zealand, Norway, Portugal, Singapore, Slovak Republic, Spain, Sweden, Switzerland, Thailand, etc.

#### PAL-M system

Brazil

#### PAL-N system

Argentina, Paraguay, Uruguay

#### SECAM system

Bulgaria, France, Guiana, Hungary, Iran, Iraq, Monaco, Poland, Russia, Ukraine, etc.

## Uso de la videocámara en el extranjero

Cada país o zona tiene su propio sistema eléctrico y de color de TV. Antes de utilizar la videocámara en el extranjero, consulte los siguientes puntos.

### Fuentes de alimentación

Puede emplear la videocámara en cualquier país o zona con el adaptador de alimentación de CA suministrado con una corriente de 100 V a 240 V CA, 50/60 Hz. Si es necesario y dependiendo de la toma mural [b], utilice un adaptador de enchufe de CA [a] disponible en las tiendas del ramo.

## English Trouble check

If you run into any problem using the VCR, use the following table to troubleshoot the problem. Should the difficulty persist, disconnect the power source and contact your Sony dealer or local authorized Sony service facility.

### VCR

#### Power

Symptom	Cause and/or corrective actions
The power is not on.	<ul style="list-style-type: none"> <li>The AC power adaptor is not connected to a wall outlet. → Connect the AC power adaptor to a wall outlet. (p. 6)</li> <li>The battery pack is not installed. → Install the battery pack. (p. 27)</li> <li>The battery is dead. → Use a charged battery pack. (p. 25)</li> </ul>
The battery pack is quickly discharged.	<ul style="list-style-type: none"> <li>The ambient temperature is too low. → The battery pack has not been charged fully.</li> <li>Charge the battery pack again. (p. 25)</li> <li>The battery pack is completely dead, and cannot be recharged. → Use another battery pack. (p. 24)</li> <li>The VCR does not operate when using a battery that is not an "InfoLITHIUM" battery pack. → Use an "InfoLITHIUM" battery pack. (p. 25)</li> </ul>

#### Operation

Symptom	Cause and/or corrective actions
The tape does not move when a tape transport button is pressed.	<ul style="list-style-type: none"> <li>The POWER switch is set to OFF. → Set it to ON. (p. 8)</li> <li>The tape has run out. → Rewind the tape or use a new one. (p. 8)</li> </ul>
Recording does not start.	<ul style="list-style-type: none"> <li>The tape is stuck to the drum. → Eject the tape. (p. 7)</li> <li>The tape has run out. → Rewind the tape or use a new one. (p. 8)</li> <li>The tab on the cassette is out (red). → Use a new tape or slide the tab. (p. 7)</li> </ul>
The cassette cannot be removed from the holder.	<ul style="list-style-type: none"> <li>The AC power cord is disconnected. → Connect the cord properly.</li> <li>The battery is dead. → Use a charged battery pack or the AC power adaptor. (p. 6, 25)</li> </ul>
① and ② indicators flash and no function except for cassette ejection works.	<ul style="list-style-type: none"> <li>Moisture condensation has occurred. → Remove the cassette and leave the VCR for at least 1 hour. (p. 32)</li> </ul>
No sound or only a low sound is heard when playing back a tape.	<ul style="list-style-type: none"> <li>The stereo tape is played back with HiFi SOUND set to 2 in the menu system. → Set it to STEREO. (p. 11)</li> <li>The volume is turned to the minimum. → Turn the volume up. (p. 8)</li> </ul>

## Trouble check

### Picture

Symptom	Cause and/or corrective actions
The playback picture is not clear.	<ul style="list-style-type: none"> <li>EDIT is set to ON in the menu system. → Set it to OFF. (p. 21)</li> </ul>
The picture is "noisy".	<ul style="list-style-type: none"> <li>The video heads may be dirty. → Clean the heads using the Sony V8-25CLH cleaning cassette. (p. 33)</li> </ul>
The picture is too dark.	<ul style="list-style-type: none"> <li>The LCD BRIGHT button is set to the minimum. → Press + to obtain the brightness you want. (p. 8)</li> </ul>
The picture does not appear on the LCD screen.	<ul style="list-style-type: none"> <li>Incorporated fluorescent tube is worn out. → Please contact your nearest Sony dealer.</li> </ul>
The picture jitters.	<ul style="list-style-type: none"> <li>A tape where video game pictures are recorded is played back with TBC set to ON in the menu system. → Set TBC to OFF. (p. 21)</li> <li>A tape in a poor condition, such as a tape recorded repeatedly, is played back with TBC set to ON in the menu system. → Set TBC to OFF. (p. 21)</li> </ul>

### Others

Symptom	Cause and/or corrective actions
No function works though the power is on.	<ul style="list-style-type: none"> <li>Disconnect the connecting plug on the AC power adaptor or the battery pack, then reconnect it in about 1 minute. Turn the power on. If the functions still do not work, press the RESET button at the bottom of the VCR using a sharp-pointed object. (If you press the RESET button, all the settings return to the default.) (p. 47)</li> </ul>


### AC power adaptor

Symptom	Corrective actions
The VTR/CAMERA or CHARGE lamp does not light.	<ul style="list-style-type: none"> <li>Disconnect the power cord. After about 1 minute, reconnect the power cord. (p. 26)</li> </ul>
The CHARGE lamp flashes.	<ul style="list-style-type: none"> <li>See the chart on the next page.</li> </ul>

## Trouble check

### When the CHARGE lamp flashes


Check through the following chart.



\* If you use a battery pack which you have just bought or which has been left unused for a long time, the CHARGE lamp may flash at the first charging. This does not indicate a problem. Repeat again to charge with same battery pack.

## Self-diagnosis display

The VCR has a self-diagnosis display. This function displays the VCR's condition with five digits (a combination of a letter and figures) on the LCD screen. If this occurs, check the following code chart. The five-digit display informs you of the VCR's current condition. The last two digits (indicated by **□□**) will differ depending on the state of the VCR.



### Self-diagnosis display



- C:□□□□
- You can service the VCR yourself.
- E:□□□□
- Contact your Sony dealer or local authorized Sony facility.

Five-digit display	Cause and/or corrective actions
C:21:□□	<ul style="list-style-type: none"> <li>• Moisture condensation has occurred. → Remove the cassette and leave the VCR for at least 1 hour. (p. 32)</li> </ul>
C:22:□□	<ul style="list-style-type: none"> <li>• The video heads are dirty. → Clean the heads using the Sony V8-25CLH cleaning cassette (not supplied). (p. 33)</li> </ul>
C:23:□□	<ul style="list-style-type: none"> <li>• You are using a battery pack that is not an "InfoLITHIUM" battery pack. → Use an "InfoLITHIUM" battery pack. (p. 25)</li> </ul>
C:31:□□	<ul style="list-style-type: none"> <li>• A servicable situation not malfunctioned above has occurred. → Remove the cassette and insert it again, then operate the VCR. (p. 7)</li> </ul>
C:32:□□	<ul style="list-style-type: none"> <li>• Disconnect the power cord of the AC power adaptor or remove the battery pack. After reconnecting the power source, operate the VCR.</li> </ul>
E:61:□□	<ul style="list-style-type: none"> <li>• A VCR malfunction which you cannot service has occurred. → Contact your Sony dealer or local authorized Sony service facility and inform them of the five digits. (example: E:61:10)</li> </ul>
E:62:□□	

If you are unable to resolve the problem, contact your Sony dealer or local authorized Sony service facility.

## Identifying the parts

### Identificación de los componentes




- 16 ● REC (recording) buttons and lamp (p. 19)
- 17 DISPLAY button (p. 8)
- 18 COUNTER RESET button (p. 9)
- 19 ▶ SLOW (slow) button (p. 10)
- 20 □ PAUSE (pause) button and lamp (p. 10)
- 21 ▶ PLAY (playback) button (p. 8)
- 22 ▶▶ FF (fastforward) button (p. 8)
- 23 □ STOP (stop) button (p. 8)
- 24 ▲REW (rewind) button (p. 8)
- 25 (headphones) jack (p. 8)
- 26 S VIDEO input/output jack (p. 14, 17, 19)
- 27 VIDEO/AUDIO input/output jacks (p. 14, 17, 19)
- 28 RFU DC OUT jack (p. 15)

- 16 Botones e indicador ● REC (grabación) (p. 19)
- 17 Botón DISPLAY (p. 8)
- 18 Botón COUNTER RESET (p. 9)
- 19 Botón ▶ SLOW (cámara lenta) (p. 10)
- 20 Botón e indicador □ PAUSE (pausa) (p. 10)
- 21 Botón ▶ PLAY (reproducción) (p. 8)
- 22 Botón ▶▶ FF (avance rápido) (p. 8)
- 23 Botón □ STOP (parada) (p. 8)
- 24 Botón ▲REW (rebobinado) (p. 8)
- 25 Toma (auriculares) (p. 8)
- 26 Toma de entrada/salida S VIDEO (p. 14, 17, 19)
- 27 Toma de entrada/salida VIDEO/AUDIO (p. 14, 17, 19)
- 28 Toma RFU DC OUT (p. 15)

## Identifying the parts

### Identificación de los componentes



- 29 PUSH OPEN button (p. 7)
- 30 LCD panel
- 31 Hooks for shoulder strap
- 32 LASER LINK emitter (p. 15)
- 33 Battery mounting surface (p. 6)
- 34 RELEASE knob  
Slide up to release the terminal cover when attaching the TV tuner unit or Video/Computer Interface unit (not supplied).
- 35 BATT release lever (p. 6)

### Botón PUSH OPEN (p. 7)

### Panel LCD

### Ganchos para el asa de hombro

### Emisor LASER LINK (p. 15)

### Superficie de montaje de la batería (p. 6)

### Mando RELEASE

Deslícelo hacia arriba para liberar la cubierta del terminal al fijar la unidad de sintonización de TV o la interfaz de video/ordenador (no suministradas).


### Palanca de liberación BATT (p. 6)


## Attaching the shoulder strap

Attach the supplied shoulder strap to the hooks for the shoulder strap.

## Fijación del asa de hombro

Fije el asa suministrado a los ganchos para el mismo.



**Identifying the parts****Identificación de los componentes****Operation indicators****Indicadores de funcionamiento**

**①** Lights up when playing back or recording in Hi8 format.

**②** Warning indicators (p. 51)

**③** BRIGHT indicator (p. 8)/ VOLUME indicator (p. 8)

**④** Recording mode indicator (p. 29)

**⑤** Tape transport mode indicator

**⑥** Tape counter/RC time code/Self-diagnosis display (p. 40)

**⑦** Remaining tape indicator

Remaining tape in minutes appears during recording only.

**⑧** Remaining battery indicator

Remaining time in minutes also appears.

**①** Se ilumina al reproducir o grabar en el formato Hi8.

**②** Indicadores de aviso (p. 51)

**③** Indicador BRIGHT (p. 8)/ Indicador VOLUME (p. 8)

**④** Indicador de modo de grabación (p. 29)

**⑤** Indicador de modo de transporte de la cinta

**⑥** Contador de cinta/código de tiempos RC/ Indicación de autodiagnóstico (p. 40)

**⑦** Indicador de cinta restante

La cinta restante en minutos aparece sólo durante la grabación.

**⑧** Indicador de batería restante

También aparece el tiempo restante en minutos.


**Warning indicators****Indicadores de aviso**

If indicators flash on the LCD screen, check the following:

♪ you can hear the beep sound when BEEP is set to ON in the menu system.

Si parpadean indicadores en la pantalla LCD, compruebe lo siguiente:

♪ es posible escuchar el pitido si BEEP está ajustado en ON en el sistema de menús.



**①** The battery is weak or dead.

Slow flashing: The battery is weak.

Fast flashing: The battery is dead.

**②** The tape is near the end.

The flashing is slow.

**③** The tape has run out.

The flashing becomes rapid.

**④** No tape has been inserted.

Appears only when REC was pressed.

**⑤** The tab on the tape is out (red).

Appears only when REC was pressed.

**⑥** Moisture condensation has occurred. (p. 32)

**⑦** The video heads may be contaminated. (p. 33)

**⑧** Some other trouble has occurred.

Disconnect the power source and contact your Sony dealer or local authorized facility.

**⑨** Self-diagnosis function was activated. (p. 40)

**⑩** The tape has recorded a copyright control signal. (p. 20)

**①** La batería está débil o agotada.

Parpadeo lento: La batería está débil.

Parpadeo rápido: La batería está agotada.

**②** La cinta está cerca del final.

El parpadeo es lento.

**③** La cinta ha llegado al final.

El parpadeo pasa a ser rápido.

**④** No ha insertado ninguna cinta.

Aparece sólo si se pulsa REC.

**⑤** La lengüeta de la cinta está fuera (roja).

Aparece sólo si se pulsa REC.

**⑥** Se ha condensado humedad (p. 32).

**⑦** Es posible que los cabezales de video estén sucios. (p. 33)

**⑧** Se ha producido cualquier otro problema.

Desconecte la fuente de alimentación y póngase en contacto con un proveedor Sony o con un centro de servicio técnico local autorizado.


**⑨** Se ha activado la función de autodiagnóstico (p. 40).

**⑩** La cinta presenta señales de control de copyright. (p. 20)


## SECTION 2 DISASSEMBLY

NOTE : Follow the disassembly procedure in the numerical order given.


### 2-1. CASSETTE LID ASSEMBLY




### 2-2. LCD CABINET




## 2-3. CRYSTAL INDICATION MODULE, FLUORESCENT COLD CATHODE TUBE, PD-88 BOARD




## 2-4. CABINET (BOTTOM) ASSEMBLY




## 2-5. MD BLOCK ASSEMBLY




## 2-6. CONTROL (FK-71) SWITCH BLOCK, DD-100 BOARD




## 2-7. VC-197 BOARD




## 2-8. B MECHANISM DECK




## 2-9. CABINET (R) BLOCK ASSEMBLY, FP-571 BOARD




## 2-10. EX-34 BOARD




## 2-11.IO-62, IR-29, FP-572, FP-573, FP-574, FP-575 BOARDS SPEAKER



## 2-12.CABINET (UPPER) ASSEMBLY




## 2-13.CIRCUIT BOARDS LOCATION




### SECTION 3 BLOCK DIAGRAMS



#### 3-1. OVERALL BLOCK DIAGRAM




## 3-2. VIDEO BLOCK DIAGRAM 1




### **3-3. VIDEO BLOCK DIAGRAM 2**




### **3-4. SERVO BLOCK DIAGRAM**




## 3-5. SYSTEM CONTROL BLOCK DIAGRAM




## 3-6. AUDIO BLOCK DIAGRAM




### **3-7. MODE CONTROL BLOCK DIAGRAM**




### **3-8. LCD BLOCK DIAGRAM**



**PD-88 BOARD** (SEE PAGE 4-68)




## 3-9. POWER SUPPLY BLOCK DIAGRAM



## **SECTION 4**

### **PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS**

#### **4-1. FRAME SCHEMATIC DIAGRAM**




## 4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

**THIS NOTE IS COMMON FOR WIRING BOARDS AND SCHEMATIC DIAGRAMS**  
**(In addition to this, the necessary note is printed in each block)**

**(For printed wiring boards)**

- : Pattern from the side which enables seeing.  
 (The other layers' patterns are not indicated.)
- Through hole is omitted.
- Circled numbers refer to waveforms.
- There are few cases that the part printed on diagram isn't mounted in this model.
- Chip parts.




**(Measuring conditions voltage and waveform)**

- Voltages and waveforms are measured between the measurement points and ground when the color bar is fed. They are reference values \* and reference waveforms.  
 (VOM of DC 10 MΩ input impedance is used.).
- Voltage values change depending upon input impedance of VOM used.)

When indicating parts by reference number, please include the board name.

**(For schematic diagrams)**

- All capacitors are in  $\mu\text{F}$  unless otherwise noted.  $\text{pF} : \mu\text{F}$ . 50V or less are not indicated except for electrolytics and tantalums.
- Chip resistors are 1/10W unless otherwise noted.  
 $\text{k}\Omega=1000\Omega$ ,  $\text{M}\Omega=1000\text{k}\Omega$ .
- Caution when replacing chip parts.  
 New parts must be attached after removal of chip.  
 Be careful not to heat the minus side of tantalum capacitor, Because it is damaged by the heat.
- Some chip part will be indicated as follows.



- Constants of resistors, capacitors, ICs and etc with XX indicate that they are not used.  
 In such cases, the unused circuits may be indicated.
- Parts with ★ differ according to the model/destination.  
 Refer to the mount table for each function.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- Signal name  
 $\text{XEDIT} \rightarrow \text{EDIT}$        $\text{PB/XREC} \rightarrow \text{PB/REC}$
- : non flammable resistor
- : fusible resistor
- : panel designation
- : B+ Line \*
- : B- Line \*
- : IN/OUT direction of (+,-) B LINE. \*
- : adjustment for repair. \*
- Circled numbers refer to waveforms. \*

\* Indicated by the color red.

**Note :** Les composants identifiés par une marque  $\Delta$  sont critiques pour la sécurité.  
 Ne les remplacer que par une pièce portant le numéro spécifié.


**Note :** The components identified by mark  $\Delta$  or dotted line with mark  $\Delta$  are critical for safety.  
 Replace only with part number specified.

## **VC-197 (MAIN) PRINTED WIRING BOARD**


There are few cases that the part printed on this diagram isn't mounted in this model.

— Ref. No. VC-197 board; 10,000 series

## **VC-197 BOARD (SIDE A)**



## 7 BOARD (SIDE B)



MAIN  
VC-197

## VC-197 BOARD

C002	B-4	C842	C-9	C1160	G-14	C1357	A-18	C1781	D-13	D114	D-20	L1018	E-5
C003	B-4	C845	B-9	C1161	G-14	C1358	C-2	C1851	H-6	D116	A-1	L1019	E-17
C004	B-3	C849	C-12	C1162	H-14	C1359	A-18	C1852	H-7	D801	C-11	L1020	E-5
C005	B-3	C850	C-11	C1163	H-15	C1360	C-18	C1853	G-7	D1201	D-16	L1151	G-16
C010	A-3	C852	B-12	C1164	H-15	C1361	B-18	C1854	G-16	D1202	E-16	L1154	G-14
C013	A-5	C902	D-9	C1165	G-14	C1362	A-17	C1855	G-7	D1305	C-18	L1201	D-5
C014	B-4	C908	D-9	C1166	H-15	C1363	A-18	C1856	G-15	D1306	D-19	L1202	E-5
C015	B-5	C909	D-9	C1167	H-15	C1364	A-19	C1857	G-16	D1602	B-16	L1203	D-17
C016	A-5	C1001	G-17	C1168	H-15	C1366	B-20	C1858	G-7	D1851	E-9	L1204	D-16
C017	A-5	C1002	G-17	C1173	F-14	C1370	E-4	C1859	G-7	D1951	F-20	L1206	G-13
C018	A-5	C1005	H-4	C1201	D-16	C1403	F-19	C1860	G-16	D1952	G-20	L1207	F-7
C020	B-5	C1007	H-5	C1202	D-16	C1404	F-19	C1861	G-16	D1953	H-20	L1209	D-5
C021	B-5	C1009	H-5	C1203	E-16	C1405	E-2	C1862	G-6	D1954	H-20	L1220	D-16
C102	A-2	C1011	H-3	C1204	E-16	C1406	F-19	C1863	G-6	D1955	H-20	L1301	E-5
C361	A-15	C1012	G-16	C1205	D-16	C1407	F-19	C1864	G-16	D1956	G-3	L1303	D-4
C362	B-15	C1013	G-16	C1206	D-16	C1409	F-18	C1865	G-6	D1957	G-20	L1305	C-19
C363	A-16	C1014	G-14	C1207	D-16	C1410	E-19	C1866	G-6	D1959	G-20	L1306	D-18
C365	A-6	C1015	G-17	C1208	E-16	C1411	E-19	C1867	G-6			L1307	D-18
C366	A-16	C1016	F-16	C1209	D-16	C1412	F-3	C1868	H-13	FB1151	E-16	L1308	C-19
C367	A-16	C1017	G-5	C1210	D-14	C1414	E-19	C1869	G-13	FB1305	B-17	L1309	C-19
C368	A-16	C1018	G-4	C1212	D-16	C1415	E-2	C1870	H-8	FB1601	B-16	L1310	D-4
C369	A-6	C1019	G-17	C1213	D-16	C1416	D-19	C1871	H-7	FB1602	B-16	L1311	A-18
C370	A-5	C1020	G-17	C1215	E-16	C1422	E-2	C1872	H-14	FB1603	B-17	L1312	B-17
C371	A-5	C1021	H-17	C1216	E-16	C1423	D-2	C1873	H-14	FB1701	D-9	L1313	C-17
C372	A-5	C1022	H-17	C1217	E-17	C1424	D-19	C1874	H-8			L1603	B-6
C373	A-6	C1023	H-17	C1218	D-16	C1425	D-19	C1875	H-13	IC001	A-4	L1604	C-4
C374	A-5	C1024	H-18	C1220	D-16	C1426	D-19	C1876	H-8	IC101	G-4	L1751	B-6
C375	B-16	C1025	G-16	C1222	G-13	C1430	D-20	C1877	H-8	IC102	F-15	L1752	B-14
C376	A-6	C1026	F-16	C1223	E-7	C1431	D-20	C1878	H-8	IC103	G-15	L1753	B-13
C377	A-15	C1027	H-4	C1224	E-7	C1432	C-20	C1879	H-8	IC104	F-13	L1754	D-13
C378	A-6	C1028	H-4	C1227	D-5	C1433	D-20	C1880	H-13	IC105	D-15	L1755	E-13
C379	A-15	C1029	G-17	C1228	D-5	C1435	E-20	C1881	F-9	IC106	D-6	L1951	G-20
C380	A-15	C1030	G-4	C1229	D-5	C1437	E-20	C1882	H-8	IC108	D-17		
C381	A-15	C1031	G-4	C1230	E-5	C1439	E-20	C1884	H-9	IC109	E-19	Q001	A-4
C382	A-6	C1032	H-5	C1231	E-5	C1441	E-20	C1886	F-6	IC111	B-18	Q002	A-3
C383	A-6	C1033	H-4	C1232	D-5	C1444	D-20	C1887	G-12	IC112	A-19	Q003	A-2
C385	A-16	C1034	F-4	C1233	E-5	C1450	E-1	C1888	H-7	IC113	A-2	Q004	A-3
C386	B-15	C1035	F-4	C1234	D-5	C1451	E-1	C1890	E-9	IC114	E-8	Q007	B-3
C387	A-15	C1036	G-5	C1236	D-5	C1452	D-20	C1891	F-9	IC116	B-14	Q008	B-2
C388	A-6	C1037	G-4	C1237	D-5	C1453	E-19	C1893	G-7	IC117	C-7	Q009	B-2
C389	A-6	C1039	G-5	C1240	E-5	C1463	D-19	C1951	F-20	IC119	D-14	Q010	B-3
C390	A-6	C1040	G-5	C1280	D-16	C1465	E-19	C1952	F-20	IC120	C-13	Q351	A-6
C391	A-6	C1041	G-3	C1282	E-6	C1466	E-19	C1953	G-20	IC121	G-6	Q352	A-15
C392	A-6	C1042	G-5	C1283	D-17	C1468	F-19	C1954	H-3	IC122	H-8	Q353	A-15
C393	A-15	C1044	G-3	C1285	D-7	C1477	C-20	C1955	G-20	IC129	D-3	Q701	F-13
C394	A-15	C1045	G-5	C1301	E-5	C1481	F-20	C1957	F-2	IC130	E-7	Q702	F-9
C395	A-14	C1046	G-3	C1302	E-4	C1488	E-2	C1958	H-1	IC131	B-2	Q703	F-8
C701	F-9	C1047	G-18	C1306	D-18	C1489	E-2	C1959	F-2	IC203	C-5	Q704	F-9
C702	F-9	C1048	G-5	C1307	D-18	C1490	F-20	C1960	H-3	IC204	C-17	Q705	G-9
C703	F-13	C1049	G-18	C1308	C-3	C1492	E-18	C1962	H-20	IC205	B-17	Q801	C-9
C704	F-13	C1050	F-5	C1309	C-3	C1616	B-16	C1965	H-3	IC206	B-16	Q802	C-9
C705	F-9	C1051	G-5	C1310	C-3	C1618	C-5	C1968	H-2	IC361	A-16	Q803	D-12
C706	F-8	C1052	F-5	C1311	C-4	C1619	C-5	C1971	H-19	IC701	G-8	Q804	B-11
C707	F-8	C1053	G-3	C1312	C-3	C1620	C-5	C1974	H-2	IC801	B-10	Q805	A-11
C708	F-8	C1054	F-5	C1313	C-4	C1621	C-16	C1976	F-1	IC802	A-8	Q806	B-10
C709	F-8	C1058	F-17	C1314	C-18	C1622	C-5	C1978	G-1	IC803	A-7	Q808	C-10
C710	G-7	C1060	F-4	C1315	D-18	C1624	C-5	C1980	G-1	IC804	B-7	Q811	D-12
C711	G-7	C1063	F-4	C1316	C-1	C1625	B-5	C1981	G-1	IC805	A-10	Q813	D-12
C712	F-8	C1065	G-17	C1317	C-4	C1635	D-5	C1982	G-1	IC1951	G-20	Q814	A-9
C713	F-8	C1068	F-4	C1318	C-3	C1637	D-5	C1986	G-19	IC1952	G-2	Q1001	H-16
C714	F-9	C1070	F-17	C1319	C-18	C1638	D-5	C1987	G-19	IC1995	G-19	Q1002	G-16
C715	G-8	C1071	G-18	C1320	D-2	C1639	D-5	C1989	G-19			Q1003	F-16
C719	G-8	C1073	F-18	C1321	D-4	C1640	D-5	C1990	H-20	L362	B-15	Q1004	H-17
C720	G-7	C1074	F-17	C1322	D-18	C1641	C-5	C1991	H-3	L363	A-6	Q1005	H-17
C801	C-9	C1076	F-17	C1323	D-18	C1642	D-5	C1992	B-13	L364	A-6	Q1006	H-18
C802	C-9	C1077	F-18	C1324	D-4	C1645	C-5			L365	A-15	Q1007	H-17
C805	A-9	C1078	F-18	C1326	E-4	C1646	C-5	CN101	H-4	L701	F-9	Q1008	F-16
C806	C-9	C1080	F-16	C1327	E-4	C1647	C-6	CN102	H-13	L702	E-13	Q1009	H-17
C807	C-12	C1081	F-18	C1328	E-4	C1648	B-17	CN103	H-14	L703	G-7	Q1010	H-17
C808	A-13	C1083	F-4	C1329		C1702		CN104	H-6	L704	G-7	Q1011	H-17
C809	A-12	C1084	F-18	C1330	E-18	C1752	B-13	CN105	H-19	L705	F-9	Q1012	H-18
C810	C-10	C1085	F-17	C1331	E-3	C1753	D-14	CN106	F-12	L801	C-9	Q1014	F-17
C811	C-10	C1086	F-4	C1332	E-3	C1754	D-7	CN107	B-1	L802	C-9	Q1015	F-17
C812	C-11	C1087	F-4	C1333	F-3	C1755	D-8	CN108	G-9	L803	A-14	Q1016	G-17
C813	D-9	C1089	E-17	C1334	E-3	C1756	D-8	CN109	D-1	L804	B-11	Q1018	F-5
C815	B-9	C1090	F-5	C1335	D-19	C1757	D-8	CN110	H-1	L805	A-12	Q1025	E-16
C817	C-12	C1091	F-17	C1336	D-18	C1758	D-8	CN111	A-1	L901	F-9	Q1026	G-18
C818	C-10	C1092	F-17	C1337	D-19	C1759	D-13	CN112	D-10	L902	D-9	Q1028	F-4
C820	B-8	C1093	F-17	C1338	D-19	C1760	B-14	CN207	G-1	L903	D-9	Q1029	E-18
C821	B-11	C1094	E-5	C1339	D-2	C1761	B-9	CN802	A-8	L904	C-9	Q1030	E-4
C823	B-11	C1095	E-5	C1340	D-2	C1762	B-9			L1002	H-3	Q1033	E-4
C824	B-8	C1096	F-16	C1341	A-18	C1763	B-13	D001	B-3	L1003	G-16	Q1034	F-18
C825	B-11	C1097	F-5	C1342	D-4	C1764	B-14	D101	C-1	L1004	F-16	Q1036	F-17
C826	B-10	C1140	F-18	C1343	C-18	C1765	B-13	D102	D-20	L1005	G-4	Q1037	F-17
C828	B-11	C1141	F-18	C1344	D-18	C1768	C-12	D103	D-20	L1006	F-4	Q1038	F-4
C829	B-11	C1144	F-4	C1345	A-18	C1769	C-12	D104	D-20	L1007	F-17	Q1040	F-5
C830	B-11	C1147	F-17	C1346	A-19	C1770	C-12	D105	E-20	L1008	F-17	Q1041	E-5
C832	A-10	C1149	G-18	C1347	A-18	C1771	D-13	D106	D-1	L1009	F-18	Q1043	E-5
C833	A-12	C1150	E-4	C1350	F-6	C1772	D-13	D107	D-1	L1010	F-18	Q1044	F-16
C834	A-10	C1152	G-16	C1351	C-19	C1773	C-13	D108	D-1	L1011	F-18	Q1045	F-5
C835	B-12	C1153	F-16	C1352	F-6	C1774	C-13	D109	E-1	L1012	E-4	Q1100	F-4
C836	A-12	C1154	F-										


# GV-A500/A500E

Q1140	F-4	R372	A-16	R869	D-11	R1122	F-17	R1320	A-18	R1758	D-14	R1960	H-20
Q1141	G-18	R373	A-15	R871	E-11	R1123	F-17	R1321	D-18	R1759	D-14	R1961	F-20
Q1150	F-4	R375	A-15	R872	A-8	R1124	E-17	R1322	D-18	R1760	D-14	R1962	G-20
Q1151	H-15	R376	A-15	R874	C-12	R1125	F-5	R1323	D-18	R1761	D-13	R1963	F-1
Q1201	D-17	R377	A-15	R875	B-12	R1128	F-5	R1324	D-18	R1762	B-6	R1964	H-19
Q1202	E-16	R378	A-6	R876	A-10	R1129	E-16	R1325	A-19	R1763	B-7	R1965	G-19
Q1203	D-16	R379	A-6	R877	A-10	R1131	F-5	R1326	C-1	R1772	D-14	R1966	G-19
Q1220	D-17	R380	A-6	R878	A-10	R1134	F-5	R1328	C-3	R1773	D-14	R1967	G-19
Q1221	F-7	R382	A-5	R880	E-9	R1135	E-5	R1329	A-19	R1774	B-7	R1968	G-19
Q1305	C-18	R386	A-5	R882	C-11	R1136	E-16	R1330	C-18	R1775	D-7	R1969	F-19
Q1306	A-18	R387	A-5	R888	C-11	R1137	F-5	R1331	D-18	R1776	B-7	R1970	F-19
Q1307	A-18	R390	A-16	R890	B-9	R1138	F-5	R1332	D-18	R1778	D-14	R1971	F-20
Q1309	C-18	R392	A-15	R891	C-12	R1141	E-17	R1333	A-19	R1779	B-7	R1972	G-19
Q1350	D-19	R393	A-15	R900	D-12	R1142	E-4	R1334	A-18	R1780	B-7	R1973	G-3
Q1351	F-6	R394	R902	D-12	R1143	R1335	A-18	R1781	D-7	R1974			
Q1352	C-2	R397	A-16	R904	D-12	R1144	F-4	R1336	A-18	R1782	B-7	R1975	H-1
Q1353	F-6	R399	A-15	R1001	H-16	R1146	F-4	R1337	A-18	R1783	D-7	R1976	H-2
Q1354	D-2	R701	F-13	R1002	G-16	R1147	E-4	R1338	C-2	R1784	D-8	R1977	H-2
Q1355	C-2	R702	F-13	R1003	G-16	R1148	R1339	B-20	R1785	D-8	R1978	H-20	
Q1356	E-6	R703	F-13	R1004	G-16	R1149	G-18	R1349	A-18	R1787	C-7	R1979	F-20
Q1357	F-6	R704	E-13	R1005	G-16	R1150	G-18	R1350	F-6	R1790	C-9	R1980	F-19
Q1358	C-18	R705	B-7	R1006	G-16	R1151	F-16	R1351	F-6	R1792	B-9	R1982	H-2
Q1359	C-19	R706	B-7	R1007	G-16	R1152	F-16	R1352	C-2	R1793	C-8	R1983	H-2
Q1360	A-18	R707	E-9	R1008	G-17	R1153	F-16	R1353	F-6	R1794	C-8	R1984	H-2
Q1361	A-19	R708	E-9	R1009	F-16	R1154	F-16	R1354	F-6	R1795	C-8	R1985	H-2
Q1362	A-18	R709	F-8	R1010	G-16	R1155	F-16	R1355	C-2	R1796	C-8	R1986	H-2
Q1363	B-20	R710	F-8	R1011	H-17	R1156	F-16	R1356	F-6	R1798	R1991	G-19	
Q1486	E-1	R711	F-8	R1012	H-17	R1157	G-15	R1357	C-2	R1803	B-13	R1992	H-5
Q1487	E-1	R712	F-8	R1013	H-18	R1159	G-15	R1358	F-6	R1804	C-13	R1993	H-20
Q1488	F-2	R713	F-8	R1014	F-16	R1160	H-15	R1360	E-6	R1805	C-12	R1994	H-20
Q1489	E-2	R714	F-8	R1015	F-16	R1162	H-15	R1361	F-6	R1808	B-13	R1995	H-20
Q1490	E-2	R715	F-8	R1016	H-17	R1163	H-16	R1362	D-2	R1809	C-13	R1996	H-20
Q1491	E-2	R716	F-9	R1017	H-17	R1164	F-14	R1363	D-2	R1810	C-13	R2001	F-2
Q1492	E-2	R717	F-9	R1018	H-17	R1165	E-15	R1364	F-6	R1811	C-13	R2011	F-2
Q1493	D-2	R718	F-13	R1019	H-18	R1180	H-15	R1365	F-6	R1812	C-14	R2012	H-19
Q1494	D-2	R719	G-9	R1020	G-18	R1181	H-15	R1366	D-2	R1813	C-14	R2015	F-1
Q1605	D-5	R720	G-9	R1021	G-18	R1213	D-17	R1367	D-2	R1814	C-14	R2017	G-1
Q1751	D-13	R721	G-9	R1022	G-18	R1215	D-17	R1368	D-2	R1815	B-13	R2020	G-1
Q1752	D-13	R722	G-8	R1023	G-4	R1216	D-16	R1369	D-2	R1821	B-7	R2021	G-1
Q1753	D-13	R723	G-8	R1024	G-4	R1217	D-16	R1371	R1822	B-14	R2022	G-1	
Q1851	H-13	R724	G-8	R1025	G-17	R1218	D-16	R1373	A-19	R1827	B-7	R2023	G-1
Q1852	G-13	R725	G-9	R1026	G-17	R1219	D-16	R1374	G-14	R1836	C-9	R2024	G-1
Q1854	H-13	R726	G-8	R1027	G-17	R1220	D-15	R1375	B-18	R1840	E-9	R2026	G-1
Q1855	E-9	R727	G-8	R1028	G-17	R1221	D-16	R1376	B-18	R1841	E-9	R2029	G-1
Q1856	F-9	R801	A-7	R1030	G-17	R1222	E-16	R1377	F-14	R1842	F-9	R2031	G-1
Q1857	E-9	R802	A-8	R1031	G-17	R1223	E-16	R1384	C-19	R1843	F-9	R2036	H-19
Q1858	F-9	R803	D-9	R1033	G-17	R1225	D-16	R1385	C-18	R1844	E-9	R2037	H-19
Q1862	E-9	R804	C-9	R1034	G-5	R1227	D-16	R1386	C-19	R1848	E-10	R2038	H-19
Q1863	F-9	R805	C-9	R1035	G-4	R1228	E-16	R1387	C-18	R1851	G-6	R2044	G-20
Q1951	G-1	R806	D-9	R1037	G-17	R1230	D-16	R1388	A-18	R1852	G-6	R2046	G-19
Q1952	F-20	R807	C-9	R1038	G-17	R1231	D-16	R1389	A-18	R1853	G-6	R2047	G-19
Q1953	F-20	R808	C-9	R1039	G-17	R1232	E-16	R1403	F-2	R1855	H-16	R2048	G-19
Q1954	G-20	R809	C-12	R1040	G-5	R1233	E-16	R1404	E-19	R1856	H-15	R2049	G-19
Q1955	G-1	R811	B-7	R1041	G-5	R1234	E-16	R1405	E-1	R1857	H-15	R2050	H-20
Q1956	G-20	R812	B-7	R1042	G-5	R1236	F-14	R1406	E-18	R1858	E-9	R2051	H-19
Q1957	G-20	R815	A-11	R1045	F-5	R1237	G-14	R1408	E-19	R1859	G-6	R2052	H-2
Q1959	H-20	R817	C-9	R1046	G-5	R1238	F-14	R1409	E-18	R1860	G-6	R2151	G-20
Q1960	F-1	R818	C-12	R1048	G-18	R1239	F-13	R1410	D-20	R1861	B-6	R2152	G-20
Q1961	G-19	R819	C-11	R1051	F-5	R1240	G-13	R1411	E-1	R1862	C-6	R2154	F-3
Q1963	H-20	R820	C-10	R1052	G-3	R1241	G-13	R1412	E-20	R1863	C-6	R2162	F-19
R005	B-3	R822	C-12	R1054	F-5	R1246	D-6	R1414	D-20	R1865	H-14	R2164	H-2
R006	B-3	R823	B-14	R1057	F-5	R1247	C-6	R1415	D-20	R1866	F-9	R2165	H-19
R007	B-3	R824	C-11	R1061	F-17	R1248	D-5	R1416	D-20	R1867	H-16	R2166	G-19
R010	B-3	R826	C-12	R1062	G-17	R1249	E-5	R1418	E-2	R1868	H-14		
R011	B-3	R827	C-12	R1076	F-4	R1250	D-5	R1419	D-20	R1869	H-13	S1951	H-3
R012	B-3	R829	R1081	F-17	R1251	D-5	R1421	D-20	R1870	F-9	S1952	B-12	
R015	B-3	R830	D-11	R1082	F-18	R1252	D-5	R1422	D-20	R1872	H-7		
R016	B-3	R831	C-10	R1083	G-18	R1253	E-5	R1423	D-20	R1873	H-14	TH1751	F-18
R017	B-3	R832	C-10	R1084	F-16	R1254	E-5	R1424	D-20	R1874	H-8		
R018	B-3	R833	C-10	R1085	E-16	R1255	E-5	R1425	D-20	R1875	H-8	X801	A-10
R027	B-5	R834	R1086	F-17	R1256	D-5	R1426	D-20	R1876	H-8	X1305	D-4	
R031	A-5	R835	B-10	R1087	F-18	R1280	D-16	R1430	E-1	R1877	G-13	X1601	C-16
R032	A-5	R836	C-12	R1088	F-18	R1281	D-16	R1431	E-1	R1878	G-13	X1751	D-8
R034	A-5	R837	B-9	R1089	F-17	R1283	E-7	R1461	D-19	R1880	G-14	X1752	B-8
R046	B-3	R838	C-12	R1090	F-18	R1284	E-7	R1462	F-19	R1881	H-8	X1951	F-1
R047	B-3	R839	C-12	R1097	F-18	R1285	E-7	R1476	E-2	R1882	G-14	X1952	F-2
R049	B-5	R840	B-10	R1098	E-18	R1289	D-16	R1488	E-2	R1883	H-8		
R050	B-5	R841	B-11	R1100	F-18	R1290	E-17	R1489	E-2	R1884	G-13		
R051	A-3	R842	B-9	R1101	F-4	R1292	E-17	R1490	E-2	R1887	H-13		
R052	A-3	R843	B-12	R1103	F-4	R1293	G-13	R1491	E-2	R1888	G-13		
R055	A-3	R844	B-11	R1104	E-4	R1295	E-16	R1492	E-2	R1889	H-13		
R066	B-3	R845	B-11	R1105	F-4	R1297	D-5	R1616	B-16	R1890	H-13		
R067	A-3	R846	B-12	R1106	E-18	R1298	D-16	R1618	C-16	R1891	H-13		
R068	A-3	R847	C-12	R1107	E-17	R1307	C-18	R1633	D-5	R1892	H-13		
R101	A-1	R848	B-10	R1110	F-17	R1308	D-18	R1638	D-5	R1893	H-7		
R102	H-1	R849	B-10	R1111	E-17	R1309	C-18	R1639	D-4	R1894	H-13		
R361	A-16	R850	B-11	R1112	E-4	R1310	D-4	R1640	C-5	R1896	G-13		
R362	A-15	R851	B-12	R1113	E-17	R1311	A-18	R1642	B-16	R1897	G-16		
R363	A-16	R852	B-12	R1114	F-17	R1312	D-18	R1643	B-16	R1898	H-13		
R364	A-16	R853	B-12	R1115	E-5	R1313	D-18	R1644	C-17	R1953	F-20		
R365	A-16	R854	B-10	R1116	E-5	R1314	E-3	R1751	D-7	R1954	G-1		
R366	A-16	R855	A-10	R1117	E-5	R1315	E-19	R1752	C-7	R1955	G-20		
R367	A-5	R856	A-10	R1118	F								


## VC-197 (REC/PB HEAD AMP) SCHEMATIC DIAGRAM

Ref. No. VC-197 board; 10,000 series

• See page 4-5 for VC-197 BOARD printed wiring board.



## VC-197 BOARD




**Mount table for each function:**

Pin	Function	Value
R1001	XX	0
R1002	XX	0
R1003	XX	0
R1004	XX	0
R1005	XX	0
R1006	XX	0
R1007	XX	0
R1008	XX	0
R1009	XX	0
R1010	XX	0
R1011	XX	0
R1012	XX	0
R1013	XX	0
R1014	XX	0
R1015	XX	0
R1016	XX	0
R1017	XX	0
R1018	XX	0
R1019	XX	0
R1020	XX	0
R1021	XX	0
R1022	XX	0
R1023	XX	0
R1024	XX	0
R1025	XX	0
R1026	XX	0
R1027	XX	0
R1028	XX	0
R1029	XX	0
R1030	XX	0
R1031	XX	0
R1032	XX	0
R1033	XX	0
R1034	XX	0
R1035	XX	0
R1036	XX	0
R1037	XX	0
R1038	XX	0
R1039	XX	0
R1040	XX	0
R1041	XX	0
R1042	XX	0
R1043	XX	0
R1044	XX	0
R1045	XX	0
R1046	XX	0
R1047	XX	0
R1048	XX	0
R1049	XX	0
R1050	XX	0
R1051	XX	0
R1052	XX	0
R1053	XX	0
R1054	XX	0
R1055	XX	0
R1056	XX	0
R1057	XX	0
R1058	XX	0
R1059	XX	0
R1060	XX	0
R1061	XX	0
R1062	XX	0
R1063	XX	0
R1064	XX	0
R1065	XX	0
R1066	XX	0
R1067	XX	0
R1068	XX	0
R1069	XX	0
R1070	XX	0
R1071	XX	0
R1072	XX	0
R1073	XX	0
R1074	XX	0
R1075	XX	0
R1076	XX	0
R1077	XX	0
R1078	XX	0
R1079	XX	0
R1080	XX	0
R1081	XX	0
R1082	XX	0
R1083	XX	0
R1084	XX	0
R1085	XX	0
R1086	XX	0
R1087	XX	0
R1088	XX	0
R1089	XX	0
R1090	XX	0
R1091	XX	0
R1092	XX	0
R1093	XX	0
R1094	XX	0
R1095	XX	0
R1096	XX	0
R1097	XX	0
R1098	XX	0
R1099	XX	0
R1100	XX	0
R1101	XX	0
R1102	XX	0
R1103	XX	0
R1104	XX	0
R1105	XX	0
R1106	XX	0
R1107	XX	0
R1108	XX	0
R1109	XX	0
R1110	XX	0
R1111	XX	0
R1112	XX	0
R1113	XX	0
R1114	XX	0
R1115	XX	0
R1116	XX	0
R11		

VC-197 (EVR) SCHEMATIC DIAGRAM

- See page 4-5 for VC-197 BOARD printed wiring board.


— Ref No. VC-197 board; 10,000 series —




## VC-197 (VIDEO PROCESS) SCHEMATIC DIAGRAM

• See page 4-5 for VC-197 BOARD printed wiring board.

— Ref. No. VC-197 board; 10,000 series —





## VC-197 BOARD



## **VC-197 (Y/C PROCESS) SCHEMATIC DIAGRAM**

— Ref. No. VC-197 board; 10,000 series —

See page 4-5 for VC-197 BOARD printed wiring board.




## VC-197 (TBC/CNR) SCHEMATIC DIAGRAM


— Ref. No. VC-197 board; 10,000 series —

• See page 4-5 for VC-197 BOARD printed wiring board.

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18

VC-197 BOARD (5/12)  
(CH/ME)


VC-197 BOARD



## VC-197 (VIDEO IN/OUT) SCHEMATIC DIAGRAM


— Ref. No. VC-197 board; 10,000 series —

- See page 4-5 for VC-197 BOARD printed wiring board.
- See page 4-36 for waveforms.






## VC-197 BOARD




VC-197 (IR DRIVER), IR-29 (TRANSMITTER) SCHEMATIC DIAGRAM  
— Ref No. VC-197 board; 10,000 series, IR-29 board; 3,000 series —

• See page 4-5 for VC-197 BOARD printed wiring board.



## VC-197 BOARD



Note:  
The components identified by mark **⚠** or dotted line with mark **⚠** are critical for safety. Replace only with part number specified.


Note:  
Les composants identifiés par une marque **⚠** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

## **IR-29 (TRANSMITTER) PRINTED WIRING BOARD**



— Ref. No. IR-29 board; 3,000 series —

There are few cases that the part printed on this diagram isn't mounted in this model.

IR-29 BOARD  
○ (SIDE A)



**IR-29 BOARD  
(SIDE B)**




IR-29 BOARD

C382	A-2
C392	C-1
C393	A-3
CN361	B-3
D362	C-2
D363	C-1
F361	B-2
L363	B-2
Q365	C-2
R388	C-1
R389	C-1
R390	A-1
R392	B-2
S361	A-1


## VC-197 (SERVO/SYSTEM CONTROL) SCHEMATIC DIAGRAM

—Ref. No. VC-197 board; 10.000 series—

• See page 4-5 for VC-197 BOARD printed wiring board.




**VC-197 BOARD**



VC-197 BOARD  
(10/12)

1





See page 4-50 for the inner circuit of B-mechanism

**B-MECHA  
CHASSIS**

## VC-197 (MODE CONTROL) SCHEMATIC DIAGRAM

— Ref. No. VC-197 board; 10,000 series —

• See page 4-5 for VC-197 printed wiring board.





**VC-197 (AUDIO) SCHEMATIC DIAGRAM**  
P-1-N, UC-1971, 1-10,000

Ref. No. VC-197 board; 10,000 series —

Ref. No. VC-197 board; 10,000 series —

See page 4-5 for VC-197BOARD printed wiring board.




mount table  
tion.

	AUDIO SIGNAL
Y/CHROMA	

## IO-62 (AV IN/OUT) SCHEMATIC DIAGRAM


—Ref. No. IO-62 board, 3,000 series—

• See page 4-65 for IO-62 BOARD printed wiring board.




## EX-34 (MULTI CONNECTOR) SCHEMATIC DIAGRAM

— Ref. No. EX-34 board; 3,000 series —




There are few cases that the part printed on this diagram isn't mounted in this model.

## EX-34 BOARD(SIDE A)




## EX-34 BOARD(SIDE B)



### EX-34 BOARD

CN203	D-5
CN204	A-7
D204	E-6
D205	E-5




## IO-62 (AV IN/OUT) PRINTED WIRING BOARD


— Ref. No. IO-62 board; 3,000 series —

There are few cases that the part printed on this diagram isn't mounted in this model.

## IO-62 BOARD (SIDE A)



## IO-62 BOARD (SIDE B)





## IO-62 BOARD

C101	B-7	D118	B-2
C102	B-6	J 02	C-6
C103	B-6	J 03	B-3
C104	B-6	L101	A-5
C107	B-6	L102	B-7
C110	A-5	L103	B-6
C116	A-6	C118	B-2
C117	B-1	C119	B-1
C118	B-2	C120	B-1
C119	B-1	C121	B-2
C120	B-1	C122	B-2
C121	B-2	C123	B-1
C122	B-2	C124	B-1
C123	B-1	F101	A-6
C124	B-1	F102	B-6
CN103	C-2	F105	B-6
CN104	B-1	F110	B-2
CN105	F-7	F111	B-3
CN106	A-3	F112	B-3
D101	A-6	F121	B-3
D102	A-3	F124	A-3
D103	F-6	F128	A-2
D104	A-5	F129	A-2
D105	B-2	F130	A-2
D106	B-3	F131	A-2
D107	B-3	F132	A-6
D108	B-2	F133	A-7
D109	F-6	F134	A-7
D110	B-3	S101	A-6
D111	A-7	S102	A-5
D112	A-7	S103	A-3
D113	B-2	S104	A-2
D114	B-2	S105	A-2
D115	B-1	S106	A-1
D116	B-1	S107	A-4

## PD-88 (LCD DRIVER) SCHEMATIC DIAGRAM

— Ref. No. PD-88 board; 3,000 series —



**PD-88 (LCD DRIVER) PRINTED WIRING BOARD**

— Ref. No. PD-88 board; 3,000 series —

There are few cases that the part printed on this diagram isn't mounted in this model.

**PD-88 BOARD (SIDE A)**

A

B

C

D






E

F


G

H

I

**PD-88 BOARD (SIDE B)****PD-88 BOARD**

C801	G-9	D803	C-2	R817	D-4
C802	H-9	D804	C-4	R818	F-4
C803	F-9	D805	G-10	R819	B-10
C804	D-4	D808	H-9	R820	B-10
C805	A-9	IC801	B-9	R822	G-3
C806	H-9	IC802	C-3	R826	C-2
C807	B-9	IC803	C-4	R829	C-2
C808	B-9	IC804	H-10	R830	G-3
C809	B-9			R833	C-4
C810	C-5			R836	C-2
C811	B-9	L801	B-10	R837	H-9
C812	C-4	L802	D-1	R838	C-2
C813	D-2	L803	D-5	R839	C-4
C814	G-3	L804	D-2	R840	C-3
C816	G-4	L805	C-9	R841	C-4
C817	C-2	L806	D-9	R842	C-3
C818	C-2	L807	C-4	R844	G-2
C820	C-4	L808	D-5	R845	C-4
C821	F-10			R846	C-4
C822	C-4	Q801	A-9	R848	C-4
C823	F-10	Q803	A-9	R849	G-9
C824	C-4	Q806	B-9	R850	C-3
C825	C-3	Q807	H-9	R851	H-9
C826	C-4	Q808	B-10	R852	H-10
C827	H-10	Q812	G-9	R853	F-9
C828	F-9	Q816	F-9	R855	F-10
C830	D-6	Q817	H-9	R856	D-3
C831	D-2	Q818	H-9	R857	D-3
C832	D-4	R804	D-4	R860	F-4
C833	D-3	R805	F-4	R861	G-9
C834	D-3	R806	D-4	R862	F-4
C835	D-3	R807	B-10	R863	H-9
C836	D-1	R808	A-9	R864	D-3
C838	F-4	R809	A-9	R865	F-3
C839	D-1	R810	B-9	R866	D-3
CN801	F-2	R811	B-9	R868	F-3
CN802	A-10	R812	B-9	R869	G-3
CN803	C-6	R813	B-9	R870	G-3
CN804	D-3	R814	H-10	T801	D-8
D802	G-4	R815	B-9		
		R816	B-9		




**DD-100 (POWER SUPPLY) PRINTED WIRING BOARD**  
— Ref. No. DD-100 board; 3,000 series —

There are few cases that the part printed on this diagram isn't mounted in this model.



**DD-100 BOARD**

C501	E-1	C544	F-3	L508	B-5	R508	D-1
C502	E-1	C545	A-6	L509	B-5	R509	D-1
C503	E-1	C546	C-6	L510	B-5	R510	F-1
C504	E-1	C547	A-6	L511	C-5	R511	F-1
C505	E-1	C548	C-6	L512	A-3	R512	F-1
C506	D-1	C549	B-6	L513	B-6	R513	F-2
C507	D-1	C550	B-4	L514	B-6	R514	D-2
C508	D-1	C551	A-4	L515	B-6	R515	D-2
C509	D-2	C552	E-3	L516	B-6	R516	E-2
C510	D-2	C553	B-5	L517	B-5	R517	E-2
C511	F-1	C554	C-5	L518	B-5	R518	F-2
C512	F-1			L519	B-6	R519	F-2
C513	F-1	CN501	B-1			R520	D-5
C514	F-1	CN502	A-5			R521	D-5
C515	F-2					R523	B-4
C516	E-2	D501	E-3			R525	E-4
C517	E-2	D502	E-3			R526	D-6
C518	E-2	D503	E-3			R527	C-5
C525	B-2	D504	F-3	Q501	E-3	R528	E-3
C526	C-2	D505	C-4	Q502	D-3	R529	C-5
C527	C-1	D506	F-3	Q503	E-3	R532	E-6
C529	A-2	D507	A-1	Q504	F-3	R533	C-5
C530	D-2	D508	A-1	Q505	F-3	R535	D-5
C531	D-3	D509	B-4	Q506	E-3	R536	F-2
C532	E-4	D510	B-4	Q507	F-3	R537	F-5
C533	E-2			Q508	D-4	R538	F-4
C534	E-3	IC501	E-1	Q520	F-5	R540	F-1
C535	F-3	IC502	B-5	Q521	A-4	R541	A-1
C536	A-6					R542	F-1
C537	A-5	L501	A-2	R501	E-1	R548	F-6
C538	A-5	L502	B-2	R502	E-1	R549	F-6
C539	B-5	L503	C-2	R503	E-1	R550	F-6
C540	B-5	L504	C-3	R504	D-1	T501	B-4
C541	C-6	L505	C-4	R505	D-1		
C542	B-5	L506	B-3	R506	E-1		
C543	F-2	L507	A-4	R507	D-1		

**DD-100 BOARD (SIDE A)**



**DD-100 BOARD (SIDE B)**




## DD-100 (POWER SUPPLY) SCHEMATIC DIAGRAM


— Ref. No. DD-100 board; 3,000 series —

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21

## DD-100 BOARD



## DD-100 BOARD



TO  
VC-197  
BOARD (10/12)  
CN106  
(SEE PAGE 4-46)

## SECTION 5 ADJUSTMENTS

### 5-1. PREPARATIONS

When performing adjustments, refer to the layout diagrams for adjustment related parts beginning from page 5-46.

NTSC model : GV-A500  
 PAL model : GV-A500E

#### 1-1. PREPARATIONS BEFORE ADJUSTMENT

##### 1-1-1. List of Service Tools

- Oscilloscope
- Color monitor
- Adjusting driver
- Regulated power supply
- Vectorscope
- Digital voltmeter

Ref. No.	Name	Parts Code	Usage
J-1	Adjusting remote commander (RM-95-remodeled partly)Note 1	J-6082-053-B	_____
J-2	Multi CPC jig	J-6082-311-A	For adjusting LCD block
J-3	CPC-7 jig	J-6082-382-A	For adjusting the video section
J-4	Power code	J-6082-223-A	For connecting the battery terminal and DC power supply
J-5	AFM DEV jig	J-6082-312-A	For adjusting the deviation
J-6	IR receiver jig	J-6082-383-A	For adjusting the IR transmitter

**Note :** If the micro processor IC in the adjusting remote commander is not the new micro processor (UPD7503G-C56-12), the pages cannot be switched. In this case, replace with the new micro processor (8-759-148-35).




Fig. 5-1-1.

### 1-1-2. Adjusting Remote Commander

The adjusting remote commander is used for changing the calculation coefficient in signal processing, EVR data, etc. The adjusting remote commander performs bidirectional communication with the unit using the remote commander signal line (LANC). The resultant data of this bidirectional communication is written in the non-volatile memory.

#### 1. Using the adjusting remote commander

- 1) Connect the adjusting remote commander to the LANC terminal.
- 2) Adjust the HOLD switch of the adjusting remote commander to "HOLD" (SERVICE position).  
If it has been properly connected, the LCD on the adjusting remote commander will display as shown in Fig. 5-1-7.




Fig. 5-1-2.

- 3) Operate the adjusting remote commander as follows.

- Changing the page

The page increases when the EDIT SEARCH+ button is pressed, and decreases when the EDIT SEARCH- button is pressed. There are altogether 16 pages, from 0 to F.

Hexadecimal notation	0 1 2 3 4 5 6 7 8 9 A B C D E F
LCD Display	0 1 2 3 4 5 6 7 8 9 A B C D E F
Decimal notation conversion value	0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15

- Changing the address

The address increases when the FF (►►) button is pressed, and decreases when the REW (◀◀) button is pressed. There are altogether 256 addresses, from 00 to FF.

- Changing the data (Data setting)

The data increases when the PLAY (►) button is pressed, and decreases when the STOP (■) button is pressed. There are altogether 256 data, from 00 to FF.

- Writing the adjustment data

The PAUSE button must be pressed to write the adjustment data (D, E, F page) in the nonvolatile memory.

(The new adjustment data will not be recorded in the nonvolatile memory if this step is not performed.)

- 4) Select page: 0, address: 01, and set the data to 01, and enables Page D and E, F to be adjusted.
- 5) After completing all adjustments, set page: 0, address: 01, data: 00 and turn off the main power supply (7.2V) once.

#### 2. Precautions upon using the adjusting remote commander

Mishandling of the adjusting remote commander may erase the correct adjustment data at times. To prevent this, it is recommended that all adjustment data be noted down before beginning adjustments and new adjustment data after each adjustment.

### 1-1-3. Page D Address

**Note 1 :** The initial adjustment data value is the value after “Page D, Page E, Page F Data Initialization” and “Page D Data Modification” have been executed. It is different from the value after all adjustments have been executed.

**Note 2 :** The ← mark shown in the adjustment data memo column indicates that the address data is fixed and same as the initial value.

Address	Adjustment Data			
	Initial Value			
	GV-A500	GV-A500E		Memo Column
		AEP,UK	E,HK	
00 to 0F				
10	00	00	00	←
11	02	07	07	←
12	7E	FE	FE	←
13	30	30	30	←
14	D6	56	D6	←
15	F0	F0	F0	←
16	80	80	80	←
17	0E	0E	0E	←
18	00	00	00	←
19	12	12	12	←
1A	40	40	40	←
1B	00	00	00	←
1C	00	00	00	←
1D	34	34	34	←
1E	00	00	00	←
1F	00	00	00	←
20	2D	2D	2D	←
21	10	10	10	←
22	1E	1E	1E	←
23	19	19	19	←
24	12	12	12	←
25	64	50	50	←
26	02	02	02	←
27	F9	F9	F9	←
28	88	88	88	
29	8D	8D	8D	
2A	A8	A8	A8	
2B	BD	BD	BD	
2C	C8	C8	C8	
2D	05	05	05	←
2E	03	03	03	←
2F	01	01	01	←
30	01	01	01	←
31	7C	7C	7C	←
32	36	36	36	←
33	4B	4B	4B	←
34	07	07	07	←
35	88	88	88	
36	C9	C9	C9	←
37	02	02	02	←
38	0A	0A	0A	←
39	04	04	04	←
3A	0A	0A	0A	←
3B	32	32	32	←
3C	04	04	04	←
3D	04	04	04	←
3E	04	04	04	←
3F	03	03	03	←

Address	Adjustment Data			
	Initial Value			
	GV-A500	GV-A500E		Memo Column
		AEP,UK	E,HK	
40				←
41				←
42				←
43				←
44				←
45				←
46				←
47				←
48				
49				
4A				
4B				
4C				←
4D				←
4E				←
4F				
50				
51				
52	76	84	84	
53	6D	9B	9B	
54	5D	67	67	
55	65	7D	7D	
56	5B	76	76	
57	94	9B	9B	
58	7C	80	80	
59	41	90	90	
5A	67	7E	7E	
5B	40	7C	7C	
5C	80	80	80	←
5D	76	84	84	
5E	00	67	67	
5F	80	80	80	←
60	00	F0	F0	←
61	00	60	60	←
62	A1	A1	A1	←
63	DA	DA	DA	←
64 to FF				

Table 5-1-1 .

#### 1-1-4. Page F Address

**Note 1 :** The initial adjustment data value is the value after “Page D, Page E, Page F Data Initialization” and “Page F Data Modification” have been executed. It is different from the value after all adjustments have been executed.

**Note 2 :** The ← mark shown in the adjustment data memo column indicates that the address data is fixed and same as the initial value.

Address	Adjustment Data			
	Initial Value			
	GV-A500	GV-A500E		Memo Column
		AEP,UK	E,HK	
00				
01				
02				
03				
04				
05	B4	BA	BA	←
06	B8	B8	B8	←
07	5E	5E	5E	←
08	45	47	47	←
09	54	58	58	←
0A	69	6B	6B	←
0B	8A	8E	8E	←
0C				
0D				
0E				
0F				
10	00	00	00	
11	00	00	00	
12	00	00	00	
13	00	00	00	
14	00	00	00	
15	00	00	00	
16	00	00	00	
17	00	00	00	
18	00	00	00	
19	00	00	00	
1A	00	00	00	
1B	00	00	00	
1C	50	51	51	←
1D	00	10	10	←
1E	23	23	23	←
1F	52	52	52	
20	00	02	02	←
21	02	02	02	←
22	3B	3B	3B	
23	00	00	00	←
24	7C	7C	7C	←
25	80	80	80	←
26	1F	1F	1F	←
27	00	00	00	←
28	46	46	46	←
29	00	00	00	←
2A	FF	FF	FF	
2B	3B	3B	3B	
2C	7D	7D	7D	
2D	56	56	56	
2E	00	00	00	←
2F	00	00	00	←

Address	Adjustment Data			
	Initial Value			
	GV-A500	GV-A500E		Memo Column
		AEP,UK	E,HK	
30	A6	A6	A6	
31	1A	1A	1A	
32	15	15	15	
33	24	24	24	
34	8C	8C	8C	
35	11	11	11	
36	00	00	00	
37	0A	0A	0A	
38	00	00	00	
39	0A	0A	0A	
3A	3C	3C	3C	
3B	A0	A0	A0	
3C	80	80	80	
3D	80	80	80	
3E	30	30	30	
3F	49	49	49	←
40	1B	1B	1B	
41	1B	1B	1B	
42	AE	AE	AE	
43	42	42	42	
44	44	44	44	
45	34	34	34	
46	2A	2A	2A	
47	89	89	89	
48	59	59	59	
49	38	38	38	
4A	41	41	41	
4B	25	25	25	
4C	00	00	00	
4D	19	19	19	
4E	00	00	00	
4F	16	16	16	
50	52	52	52	
51	52	52	52	
52	7A	7A	7A	
53	8D	8D	8D	
54	7A	7A	7A	
55	55	55	55	←
56	A8	A8	A8	
57	00	00	00	
58	9A	9A	9A	
59	50	50	50	←
5A	7B	7B	7B	
5B	B3	B3	B3	
5C	99	AA	AA	←
5D	70	70	70	←
5E	A8	A2	A2	←
5F	70	70	70	←

Table 5-1-2 (1).

Address	Adjustment Data			
	Initial Value			
	GV-A500	GV-A500E		Memo Column
		AEP,UK	E,HK	
60	D5	D5	D5	
61	D5	D5	D5	
62	EA	EA	EA	
63	EA	EA	EA	
64	8B	93	93	←
65	80	8C	8C	←
66	89	93	93	←
67	80	8C	8C	←
68	B8	B8	B8	
69	B8	B8	B8	
6A	B1	B1	B1	
6B	B1	B1	B1	
6C	80	80	80	
6D	80	80	80	
6E	80	80	80	
6F	80	80	80	
70	7D	80	80	←
71	7D	80	80	←
72	80	80	80	
73	80	00	00	
74	00	00	00	←
75	80	00	00	
76	80	00	00	
77	00	00	00	←
78	7C	92	92	←
79	AA	00	00	←
7A	A0	00	00	←
7B	C3	00	00	←
7C	0C	0C	0C	←
7D	18	00	00	←
7E	77	77	77	←
7F	40	40	40	←
80	75	75	75	←
81	73	73	73	←
82	12	12	12	←
83	8A	8A	8A	←
84	A5	A5	A5	←
85	68	68	68	←
86	4A	4A	4A	←
87	F0	F0	F0	←
88	00	00	00	←
89	01	01	01	←
8A	6C	6C	6C	←
8B	40	40	40	←
8C	68	28	28	←
8D	A0	60	60	←
8E	70	40	40	←
8F	40	29	29	←
90	68	28	28	←
91	70	70	70	←
92	40	40	40	←
93	25	25	25	←
94	58	58	58	←

Address	Adjustment Data			
	Initial Value			
	GV-A500	GV-A500E		Memo Column
		AEP,UK	E,HK	
95	F0	60	60	←
96	40	40	40	←
97	3D	10	10	←
98	58	28	28	←
99	FF	80	80	←
9A	40	40	40	←
9B	30	10	10	←
9C	78	28	28	←
9D	70	70	70	←
9E	4C	30	30	←
9F	06	00	00	←
A0	28	28	28	←
A1	FF	E0	E0	←
A2	30	30	30	←
A3	10	00	00	←
A4	62	60	60	←
A5	91	91	91	←
A6	62	70	70	←
A7	B2	92	92	←
A8	62	70	70	←
A9	91	A2	A2	←
AA	62	70	70	←
AB	A2	A3	A3	←
AC	04	04	04	←
AD	E5	D5	D5	←
AE	04	04	04	←
AF	F7	D6	D6	←
B0	40	40	40	←
B1	00	00	00	←
B2	B3	B3	B3	←
B3	B3	B3	B3	←
B4	21	10	10	←
B5	05	01	01	←
B6	11	10	10	←
B7	06	03	03	←
B8	71	40	40	←
B9	35	32	32	←
BA	20	00	00	←
BB	00	00	00	←
BC	22	22	22	←
BD	80	80	80	←
BE	30	20	20	←
BF	40	40	40	←
C0	20	30	30	←
C1	50	50	50	←
C2	1B	2B	2B	←
C3	4B	4B	4B	←
C4	00	00	00	←
C5	00	00	00	←
C6	00	00	00	←
C7	DF	BF	BF	←
C8	FD	CE	CE	←
C9	DD	DF	DF	←

Table 5-1-2 (2).

Address	Adjustment Data			
	Initial Value			
	GV-A500	GV-A500E		Memo Column
		AEP,UK	E,HK	
CA	00	00	00	←
CB	DF	BF	BF	←
CC	FD	CE	CE	←
CD	DD	DF	DF	←
CE	00	00	00	←
CF	27	27	27	←
D0	CA	CA	CA	←
D1	00	00	00	←
D2	40	40	40	←
D3	1B	1B	1B	←
D4	E0	EC	EC	←
D5	A0	A0	A0	←
D6	30	28	28	←
D7	20	1A	1A	←
D8	C0	C0	C0	←
D9	6A	6A	6A	←
DA	60	60	60	←
DB	55	55	55	←
DC	55	55	55	←
DD	66	66	66	←
DE	25	25	25	←
DF	34	34	34	←
E0	3F	3F	3F	←
E1	A0	A0	A0	←
E2	00	00	00	←
E3	80	80	80	←
E4	70	70	70	←

Address	Adjustment Data			
	Initial Value			
	GV-A500	GV-A500E		Memo Column
		AEP,UK	E,HK	
E5	41	41	41	←
E6	1F	1F	1F	←
E7	C0	C0	C0	←
E8	14	14	14	←
E9	03	03	03	←
EA	00	00	00	←
EB	FE	FD	FD	
EC	F5	F4	F4	
ED	1A	21	21	←
EE	33	46	46	←
EF	FE	FE	FE	←
F0	3C	3C	3C	←
F1	24	24	24	←
F2	83	83	83	←
F3	A0	A0	A0	←
F4	67	67	67	←
F5	4D	4D	4D	←
F6	33	33	33	←
F7	5C	5C	5C	←
F8	5C	5C	5C	←
F9	5C	5C	5C	←
FA	3C	3C	3C	←
FB	0F	0F	0F	←
FC	10	10	10	←
FD	2C	2C	2C	←
FE	0A	0A	0A	←
FF	36	36	36	←

Table 5-1-2 (3).

### 1-1-5. Page E Address

**Note 1 :** The initial adjustment data value is the value after “Page D, Page E, Page F Data Initialization” and “Page E Data Modification” have been executed. It is different from the value after all adjustments have been executed.

**Note 2 :** The ← mark shown in the adjustment data memo column indicates that the address data is fixed and same as the initial value.

Address	Adjustment Data			
	Initial Value			
	GV-A500	GV-A500E		Memo Column
		AEP,UK	E,HK	
00	42	72	72	←
01	06	06	06	←
02	E0	E0	E0	←
03	50	50	50	←
04	3B	3B	3B	←
05	14	14	14	←
06	E8	E8	E8	←
07	90	90	90	←
08	00	00	00	←
09	02	02	02	←
0A	F3	F3	F3	←
0B	A0	A0	A0	←
0C	69	69	69	←
0D	89	89	89	←
0E	15	15	15	←
0F	50	50	50	←
10	5F	5F	5F	←
11	69	69	69	←
12	93	93	93	←
13	AA	AA	AA	←
14	65	65	65	←
15	44	44	44	←
16	A2	A2	A2	←
17	63	63	63	←
18	90	90	90	←
19	33	33	33	←
1A	15	15	15	←
1B	82	82	82	←
1C	00	00	00	←
1D	F3	F3	F3	←
1E	EE	EE	EE	←
1F	AD	AD	AD	←
20	D9	D9	D9	←
21	20	20	20	←
22	2A	2A	2A	←
23	EB	EB	EB	←
24	1F	1F	1F	←
25	0F	0F	0F	←
26	31	31	31	←
27	20	20	20	←
28	53	53	53	←
29	41	41	41	←
2A	F8	F8	F8	←
2B	10	10	10	←
2C	40	40	40	←
2D	60	60	60	←
2E	00	00	00	←
2F	00	00	00	←
30	00	00	00	←
31	10	10	10	←
32	20	20	20	←

Table 5-1-3.

Address	Adjustment Data			
	Initial Value			
	GV-A500	GV-A500E		Memo Column
		AEP,UK	E,HK	
33	12	12	12	←
34	3D	3D	3D	←
35	00	00	00	←
36	00	00	00	←
37	00	00	00	←
38	00	00	00	←
39	00	00	00	←
3A	00	00	00	←
3B	20	20	20	←
3C	26	21	21	←
3D	27	24	24	←
3E	08	09	09	←
3F	09	08	08	←
40	CC	20	20	←
41	40	40	40	←
42	1E	1E	1E	←
43	00	00	00	←
44	F8	00	00	←
45	30	22	22	←
46	10	10	10	←
47	04	00	00	←
48	10	04	04	←
49	F8	F8	F8	←
4A	F8	F8	F8	←
4B	60	60	60	←
4C	50	50	50	←
4D	1C	20	20	←
4E	00	F8	F8	←
4F	48	60	60	←
50	40	50	50	←
51	1E	20	20	←
52	00	F8	F8	←
53	80	80	80	←
54	FF	FF	FF	←
55	DD	DD	DD	←
56	B4	B4	B4	←
57	94	94	94	←
58	74	74	74	←
59	62	62	62	←
5A	49	49	49	←
5B	19	19	19	←
5C	1B	1B	1B	←
5D	1B	1B	1B	←
5E	00	00	00	←
5F	00	00	00	←
60	F3	F5	F5	←
61	EB	EB	EB	←
62	00	00	00	←
63	00	00	00	←
64	00	00	00	←
65	00	00	00	←
66 to FF				

## 1-2. INITIALIZATION OF D, E, F PAGE DATA

### 1. Initialization of D, E, F Page Data

**Note 1 :** If the D, E, F page data has been initialized, all adjustments need to be performed again.

**Note 2 :** < >: NTSC model: GV-A500

[ ]: PAL model: GV-A500E

Adjustment page	D
Adjustment address	00 to 63
Adjustment page	F
Adjustment address	00 to FF
Adjustment page	E
Adjustment address	00 to 65

#### Initializing method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Set page: 2, address: 00, data: <55> [51].
- 3) Set page: 2, address: 01, data: <55> [51] and press the PAUSE button of the adjusting remote commander.
- 4) Check that the data of page: 2, address: 02 is 01.
- 5) Set page: 3, address: 00, data: 29.
- 6) Set page: 3, address: 01, data: 29 and press the PAUSE button of the adjusting remote commander.
- 7) Set page: 0, address: 01, data: 00.
- 8) Perform “Modification of D, E and F Page Data”.

### 2. Modification of D Page Data

If the D, E and F page data has been initialized, change the data as shown in the following table by manual input.

**Note 1 :** Before changing the data, set page: 0, address: 01, data: 01.

**Note 2 :** To write in the non-volatile memory (EEPROM), press the PAUSE button of the adjusting remote commander each time to set the new data.

**Note 3 :** After changing the data, set page: 0, address: 01, data: 00. Also perform “Modification of F Page Data”.

Address	Adjustment Data			
	Initial Value			
	GV-A500	GV-A500E		E,HK
		AEP,UK		
11	02			
13	30	30	30	
14	D6	56	D6	
15	F0	F0	F0	
16	80	80	80	
17	0E	0E	0E	
18	00	00	00	
19	12	12	12	
1A	40	40	40	
1B	00	00	00	
1C	00	00	00	
1D	34	34	34	
1E	00	00	00	
1F	00	00	00	
20	2D	2D	2D	
21	10	10	10	
22	1E	1E	1E	
23	19	19	19	
26	02	02	02	
30	01	01	01	
31	7C	7C	7C	
32	36	36	36	
33	4B	4B	4B	

Address	Adjustment Data			
	Initial Value			
	GV-A500	GV-A500E		E,HK
		AEP,UK		
38	0A	0A	0A	
3C	04	04	04	
3D	04	04	04	
3E	04	04	04	
3F	03	04	03	
52	76	84	84	
53	6D	9B	9B	
54	5D	67	67	
55	66	7D	7D	
56	5B	76	76	
57	94	9B	9B	
58	7C	80	80	
59	41	90	90	
5A	67	7E	7E	
5B	40	7C	7C	
5C	80	80	80	
5D	76	84	84	
5E	00	67	67	
5F	80	80	80	
60	00	F0	F0	
61	00	60	60	
62	A1	A1	A1	
63	DA	DA	DA	

Table 5-1-4.

### 3. Modification of F Page Data

If the D, E and F page data has been initialized, change the data as shown in the following table by manual input.

**Note 1 :** Before changing the data, set page: 0, address: 01, data: 80.

**Note 2 :** To write in the non-volatile memory (EEPROM), press the PAUSE button of the adjusting remote commander each time to set the new data.

**Note 3 :** After changing the data, set page: 0, address: 01, data: 00. Also perform “Modification of E Page Data”.

Address	Adjustment Data			
	Initial Value			
	GV-A500	GV-A500E		E,HK
		AEP,UK		
05	B4	BA	BA	
06	B8	B8	B8	
07	5E	5E	5E	
08	45	47	47	
09	54	58	58	
0A	69	6B	6B	
0B	8A	8E	8E	
10	00	00	00	
11	00	00	00	
12	00	00	00	
13	00	00	00	
14	00	00	00	
15	00	00	00	
16	00	00	00	
17	00	00	00	
18	00	00	00	
19	00	00	00	
1A	00	00	00	
1B	00	00	00	
1C	50	51	51	
1D	00	10	10	
21	02	02	02	
27				
28	46	46	46	
5D	70	70	70	
5F	70			
64	8B	93	93	
65		8C	8C	
66	89	93	93	
67		8C	8C	
70	7D	80	80	
71	7D	80	80	

Address	Adjustment Data			
	Initial Value			
	GV-A500	GV-A500E		E,HK
		AEP,UK		
73	80			
75	80			
76	80			
8D	A0			
8F	40			
91		70	70	
93	25			
95	F0	60	60	
97	3D	10	10	
99	FF	80	80	
9A	40			
9B	30			
A1	FF			
A2	30			
A3	10			
A7	B2			
B9	35			
BE	30			
C2	1B	2B	2B	
C3	4B	4B	4B	
C7	DF	BF	BF	
C8	FD	CE	CE	
C9	DD	DF	DF	
CB	DF	BF	BF	
CC	FD	CE	CE	
CD	DD	DF	DF	
D4	E0	EC	EC	
EB	FE	FD	FD	
EC	F5	F4	F4	
ED	1A	21	21	
EE		46	46	

Table 5-1-5.

#### 4. Modification of E Page Data

If the D, E and F page data has been initialized, change the data as shown in the following table by manual input.

**Note 1 :** Before changing the data, set page: 0, address: 01, data: 01.

**Note 2 :** To write in the non-volatile memory (EEPROM), press the PAUSE button of the adjusting remote commander each time to set the new data.

**Note 3 :** After changing the data, set page: 0, address: 01, data: 00. Also perform all adjustments of this unit.

Address	Adjustment Data			
	Initial Value			
	GV-A500		GV-A500E	
	AEP,UK		E,HK	
00		72		72
3D		24		24
40	CC	20		20
44		00		00
47		00		00
48	10			
4B	60			

Address	Adjustment Data			
	Initial Value			
	GV-A500		GV-A500E	
	AEP,UK		E,HK	
4C	50		50	50
4D	1C			
4F	48			
50	40		50	50
51	1E			
5C	1B		1B	1B
5D	1B		1B	1B

Table 5-1-6.

#### 1-3. Data Processing

The calculation of the DDS display and the adjusting remote commander display data (hexadecimal notation) are required for obtaining the adjustment data of some adjustment items. In this case, after converting the hexadecimal notation to decimal notation, calculate and convert the result to hexadecimal notation, and use it as the adjustment data. Table 5-1-7. indicates the hexadecimal notation-decimal notation calculation table.

Hexadecimal notation-decimal notation calculation table																②	
①	Lower digit of hexadecimal	0	1	2	3	4	5	6	7	8	9	A (R)	B (b)	C (c)	D (d)	E (E)	F (F)
	Upper digit of hexadecimal	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
	0	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
	1	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
	2	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
	3	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63
	4	64	65	66	67	68	69	70	71	72	73	74	77	76	77	78	79
	5	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95
	6	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111
	7	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127
	8	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143
	9	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159
	A (R)	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175
	B (b)	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	191
	C (c)	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207
	D (d)	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223
	E (E)	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239
	F (F)	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255

Note : The characters shown in the parenthesis ( ) shown the display on the adjustment remote commander.  
(Example) If the DDS display or the adjustment remote commander shows BD (b d);  
Because the upper digit of the adjustment number is B (b), and the lower digit is D (d), the meeting point "189" of ① and ② in the above table is the corresponding decimal number.

Table 5-1-7.

## 5-2. MECHANICAL SECTION ADJUSTMENT

### Mechanism Parts Adjustments

For details on the adjustments and checks of mechanical section and replacements of mechanism parts, refer to the separate volume “8 mm Video Mechanism Adjustment Manual VII [B Mechanism]”.

### 2-1. OPERATING WITHOUT A CASSETTE

- 1) Refer to “Section 2 DISASSEMBLY” and supply the power with the cabinet removed. (So that the mechanical deck can be operated.)
- 2) Connect the adjusting remote commander to the LANC terminal.
- 3) Turn on the HOLD switch of the adjusting remote commander.
- 4) Close the cassette compartment without loading a cassette and complete loading.
- 5) Set page: 0, address: 01, data: 01.
- 6) Set page: F, address: 29, data: 01 and press the PAUSE button of the adjusting remote commander.
- 7) Set page: D, address: 10, data: 04 and press the PAUSE button of the adjusting remote commander.
- 8) Disconnect the power supply of the unit.

By carrying out the above procedure, the unit can be operated without loading a cassette.

Be sure to carry out “Processing after Operations” after checking the operations.

Set the data of page: D, address: 10 to the following if the sensor ineffective mode, forced PLAYER (VTR) power supply ON mode or forced camera power supply ON mode are to be used together.

Forced VTR power supply ON mode ..... 06

#### [Processing after Operations]

- 1) Set page: 0, address: 01, data: 01.
- 2) Set page: F, address: 29, data: 00 and press the PAUSE button of the adjusting remote commander.
- 3) Set page: D, address: 10, data: 00 and press the PAUSE button of the adjusting remote commander.
- 4) Set page: 0, address: 01, data: 00 .
- 5) Disconnect the power supply of the unit.

### 2-2. TAPE PATH ADJUSTMENT

#### 1. Preparations for adjustments

- 1) Clean the tape path face (tape guide, drum, capstan shaft, pinch roller).
- 2) Connect the adjusting remote commander to the LANC terminal.
- 3) Turn on the HOLD switch of the adjusting remote commander.
- 4) Select page: 0, address: 01, and set data: 01.
- 5) Select page: F, address: 29, and set data: 04 and press the PAUSE button of the adjusting remote commander.  
Be sure to perform “Processing after operations” after completing adjustments.
- 6) Connect the oscilloscope.  
Channel 1: Pin ⑥ of CN207 of VC-197 board  
External trigger: Pin ③ of CN207 of VC-197 board  
Connect the oscilloscope via the CPC-7 jig  
(J-6082-382-A)
- 7) Playback the alignment tape for tracking.  
WR5-1NP: For NTSC model (GV-A500)  
WR5-1CP: For PAL model (GV-A500E)
- 8) Check that the RF waveform of the oscilloscope is flat at both the entrance and the exit.  
If not flat, perform necessary adjustment according to the separate “8 mm Video Mechanical Adjustment Manual VII (B Mechanism)”.
- 9) Perform “Processing after operations”, after completing adjustments.

#### CN207 of VC-197 board

Pin No.	Signal Name	Pin No.	Signal Name
1	PB PCM RF	9	EZ I/O
2	REC RF	10	
3	RF SWP	11	VGL-19V
4	CAP FG	12	
5	REG GND	13	
6	PB RF	14	BPF MON
7	RF AGC IN	15	RF AGC OUT
8	REC AFM	16	AFC FO

#### [Processing after operations]

- 1) Connect the adjusting remote commander, and turn on the HOLD switch.
- 2) Select page: 0, address: 01, and set data: 01.
- 3) Select page: F, address: 29, and set data: 00.
- 4) Press the PAUSE button of the adjusting remote commander.
- 5) Select page: 0, address: 01, and set data: 00.
- 6) Remove the power supply from the unit.




Fig. 5-2-1.

## 5-3. VIDEO SECTION ADJUSTMENTS

When performing adjustments, refer to the layout diagrams for adjustment related parts beginning from page 5-46.

### 3-1. PREPARATIONS BEFORE ADJUSTMENT

The following adjusting instruments are used for adjusting the video section.

#### 3-1-1. Equipments to be Used

- 1) TV monitor
- 2) Oscilloscope: 2 phenomena, band 30 MHz or wider, with delay mode. (Use a 10:1 probe unless specified otherwise.)
- 3) Frequency counter
- 4) Pattern generator with video output terminal
- 5) Digital voltmeter
- 6) Audio generator
- 7) Audio level meter
- 8) Audio distortion meter
- 9) Audio attenuator
- 10) Regulated power supply
- 11) Alignment tape

##### [For NTSC model]

- For tracking adjustment (WR5-1NP)  
Part Code: 8-967-995-02
- For video frequency characteristics adjustment (WR5-7NE)  
Part Code: 8-967-995-13
- For checking Standard 8 mode operations  
For LP (WR5-4NL)  
Part Code: 8-967-995-51
- For SP (WR5-5NSP)  
Part Code: 8-967-995-42

**Note :** The following alignment tapes can also be used.

1) WR5-4NSP (8-967-995-41)

- For checking Hi8 mode operations  
For SP (WR5-8NSE)  
Part Code: 8-967-995-43

For LP (WR5-8NLE)  
Part Code: 8-967-995-52

- For checking AFM stereo operations (WR5-9NS)  
Part Code: 8-967-995-23

For checking BPF adjustment (WR5-11NS)  
Part Code: 8-967-995-71

12) Remote commander for adjustment (J-6082-053-B)

13) CPC-7 jig Part Code: J-6082-382-A

14) Power code Part Code: J-6082-223-A

15) AFM DEV jig (J-6082-312-A)

16) IR Receiving jig (J-6082-383-A)

##### [For PAL model]

- For tracking adjustment (WR5-1CP)  
Part Code: 8-967-995-07
- For video frequency characteristics adjustment (WR5-7CE)  
Part Code: 8-967-995-18
- For checking Standard 8 mode operations  
For LP (WR5-4CL)  
Part Code: 8-967-995-56

For SP (WR5-5CSP)  
Part Code: 8-967-995-47

**Note :** The following alignment tapes can also be used.

1) WR5-3CL (8-967-995-36)

2) WR5-4CSP (8-967-995-46)

- For checking Hi8 mode operations  
For SP (WR5-8CSE)  
Part Code: 8-967-995-48

For LP (WR5-8CLE)  
Part Code: 8-967-995-57

- For checking AFM stereo operations (WR5-9CS)  
Part Code: 8-967-995-28

For checking BPF adjustment (WR5-11CS)  
Part Code: 8-967-995-76

### **3-1-2. Precautions in Adjustment**

- 1) The adjustments of this unit are performed in the VTR mode (S VIDEO terminal input or VIDEO terminal input mode). To set to the VTR mode, set the power switch to "ON" or set to the "forced VTR power supply ON mode" (Note 1) using the adjusting remote commander. After completing adjustments, be sure to exit the "forced VTR power supply ON mode". (Note 3)

**Note 1 :** Setting the "forced VTR power supply ON mode"

- 1) Set page: 0, address: 01, data: 01.
  - 2) Set page: D, address: 10, data: 02 and press the PAUSE button of the adjusting remote commander. Hereafter, VTR operations can be performed even if the cabinet has been removed.
- After completing adjustments, be sure to exit the "forced VTR power supply ON mode".

**Note 2 :** Exiting the "forced power supply ON mode"

- 1) Set page: 0, address: 01, data: 01.
- 2) Set page: D, address: 10, data: 00 and press the PAUSE button of the adjusting remote commander.
- 3) Set page: 0, address: 01, data: 00.

### **3-1-3. Connector for Adjustments**

Some video section adjustment points are concentrated on the VC-197 board CN207. Connect the measuring instruments via a CPC-7 jig (J-6082-382-A).

Pin No.	Signal Name	Pin No.	Signal Name
1	PB PCM RF	9	EZ I/O
2	REC RF	10	
3	RF SWP	11	VGL-19V
4	CAP FG	12	
5	REG GND	13	
6	PB RF	14	BPF MON
7	RF AGC IN	15	RF AGC OUT
8	REC AFM	16	AFC FO

*Table 5-3-1.*

### 3-1-4. Connecting the Equipments


Connect the measuring instruments as shown in Fig. 5-3-1 according to the input terminal specifications (VIDEO input or S VIDEO input), and perform the adjustments.

The input terminal is specified in the ( ) in the signal column. Either input terminal can be used when there are no specifications.


**Note 1 :** If the VIDEO input is used for adjustments which specify for the S VIDEO input to be used, the product specifications of the unit may not be satisfied in some cases. Be sure to perform according to the specifications.

**Note 2 :** When adjustments are performed with the S video output terminal VTR as the signal source, the efficiencies of the unit may be affected by the VTR. It is recommended that a pattern generator with a Y/C separation output terminal be used as much as possible.

#### Connecting the TV Monitor and Regulated Power Supply




#### Connecting the Pattern Generator [VIDEO Input]



**Note 1:** The TV monitor cannot be connected.  
Monitor on the LCD.

#### [S VIDEO Input]

- When the pattern generator has a Y/C separation output terminal



- When the pattern generator has no Y/C separation output terminal




Fig. 5-3-1.

### 3-1-5. Checking the Input Signals

Because the video signal obtained from the pattern generator is used as the adjustment signal for adjusting the VTR section, the video output signal must satisfy the given specifications.

#### 1. S VIDEO input

Connect the oscilloscope to the Y signal terminal of the S VIDEO terminal, and check that the sync signal of the Y signal is approximately <0.286>[0.30]V and that the amplitude of the video section is approximately <0.714>[0.70]V. (When a VTR with the S VIDEO output terminal is used, also check that the chroma signal and burst signal have not remained.) Connect the oscilloscope to

the chroma signal terminal of the S VIDEO terminal, and check that the burst signal amplitude of the chroma signal is approximately <0.286>[0.30]V and flat, and that the amplitude ratio of the burst signal to the chroma signal is 0.30:0.66. The Y and chroma signals used in the adjustment are shown in Fig. 5-3-2.

< > : NTSC model

[ ] : PAL model




Fig. 5-3-2. Color bar signal of pattern generator

#### 2. VIDEO input

Connect the oscilloscope to the VIDEO terminal, and check that the sync signal amplitude of the video signal is approximately <0.286>[0.30]V, the amplitude of the video section is approximately <0.714>[0.70]V, the amplitude of the burst signal is approximately <0.286>[0.30]V and flat, and that the level ratio of the burst signal

to the “red” signal is 0.30 : 0.66.

The video signal (color bar) used for adjusting the VTR section is shown in Fig. 5-3-3.

< > : NTSC model

[ ] : PAL model




Fig. 5-3-3. Color Bar Signal of Pattern Generator

### 3-1-6. Alignment Tape

The following table lists alignment tapes which are available.  
 Use the tape specified in the signal column for each adjustment.  
 If the type of tape to be used for checking operations is not specified,  
 use whichever type.

Name	Record -ing mode	Tape type	Tape speed	Usage
Tracking WR5-1NP (NTSC) WR5-1CP (PAL)	Standard 8 mm	MP	SP	Tape path adjustment Switching position adjustment
Video frequency characteristics WR5-7NE (NTSC) WR5-7CE (PAL)	Hi8	ME	SP (NTSC) LP (PAL)	Frequency characteristics adjustment
Operation check (SP mode) WR5-5NSP (NTSC) WR5-5CSP (PAL)	Standard 8 mm	MP	SP	
Operation check (SP mode) WR5-8NSE (NTSC) WR5-8CSE (PAL)	Hi8	ME	SP	
Operation check (LP mode) WR5-4NL (NTSC) WR5-4CL (PAL)	Standard 8 mm	MP	LP	Checking operations
Operation check (LP mode) WR5-8NLE (NTSC) WR5-8CLE (PAL)	Hi8	ME	LP	
AFM stereo Operation check WR5-9NS (NTSC) WR5-9CS (PAL)	Standard 8 mm	MP	SP	AFM stereo Checking operations
BPF adjustment WR5-11NS (NTSC) WR5-11CS (PAL)	Hi8	MP	SP	BPF adjustment

Fig. 5-3-4. Shows the color bar signals recorded on the alignment tape.

**Note :** Measure using the VIDEO terminal (Terminated at  $75 \Omega$ ).




Fig. 5-3-4. Color Bar Signals of the Alignment Tape

### 3-1-7. Input/Output Level and Impedance

Video input/output

Phono jack, 1 Vp-p, 75Ω,  
unbalanced, sync negative

S video input/output (Hi8 model)

4-pin mini DIN

Luminance signal:  
1Vp-p, 75Ω, unbalanced, sync negative

Chrominance signal:

0.3Vp-p 75Ω, unbalanced

Audio input/output

Phono jack,

Input: -7.5 dBs, input impedance more  
than 47 kΩ

Output: -7.5 dBs, (at load impedance 47 kΩ), impedance  
less than 2.2 kΩ

### 3-1-8. Recording Mode (Standard 8/Hi8) switching

The record mode (Standard 8/Hi8) of this unit switches as shown in the following table. The playback mode (Standard 8/Hi8) switches automatically according to the recording mode of the tape played back.

Tape Used	Recording Mode
ME	
Hi8 MP	Hi8
MP	Standard 8

### 3-1-9. Service Mode

Additional note on adjustment

**Note :** After the completion of the all adjustments, cancel the service mode by either of the following ways.

- 1) Unplug the main power supply and remove the lithium battery.  
(In this case, date and time and menu setting have been set by users are canceled. Perform resetting.)
- 2) After data on page: D and F is restored, return data of the address: 01 on page: 0 to 00. And when data on page: 2 or page: 3 is changed, return the data to the original condition.

#### 1. Test mode setting

Set/release each test mode. Set page: 0, address: 01, data: 01 before setting the data of page D and F.

Page F	Address 29
--------	------------

Data	Function
00	Normal
01	Test mode Various emergency prohibitions and releases Drum emergency, capstan emergency, loading motor emergency, reel emergency, tape top and end, DEW detection

Page D	Address 10
--------	------------

Data	Function
00	Normal
01	
02	VTR power ON
03	

- \* For page D and F, the data set will be recorded in the nonvolatile memory by pressing the PAUSE button on the adjusting remote commander. Take note that, in this case, the test mode will not be released even if the main power has been turned off (7.2 Vdc).
- \* Be sure to return this address data to 00 after completing adjustments/repairs and press the PAUSE button of the adjusting remote commander. And set page: 0, address: 01, data: 00.

## 2. Emergency Memory Address

When there are no emergency, data 00 will be written in the above addresses (10 to 1B). When the first emergency occurs, the data corresponding to the emergency will be written in the address (10 to 13) for this first emergency. In the same way, when the second emergency occurs, the data corresponding to the emergency will be written in the address (14 to 17) for this second emergency.

The data corresponding to the emergency occurring the last will be written in the address (18 to 1B) for this last emergency.

Therefore the data of addresses 18 to 1B are renewed each time an emergency occurs.

Page F	Address 10 to 1B
--------	------------------

Address	Contents
10	1st EMG code
12	Upper: MSW code when the mechanism starts shifting the 1st time Lower: MSW code when the 1st emergency occurs
13	Lower: Target MSW code of the 1st emergency occurs
14	2nd EMG code
16	Upper: MSW code when the mechanism starts shifting the 2nd time Lower: MSW code when the 2nd emergency occurs
17	Lower: Target MSW code of the 2nd emergency occurs
18	Last EMG code
1A	Upper: MSW code when the mechanism starts shifting the last time Lower: MSW code when the last emergency occurs
1B	Lower: Target MSW code of the last emergency occurs

### 2-1. EMG CODE (Emergency Code)

The codes shown in the following table which correspond to errors that occur are recorded in addresses 10, 14, and 18.


Code	Type of Emergency
00	No error
10	Loading motor time-out during load
11	Loading motor time-out during unload
20	T reel emergency (reel slack) during unloading
21	S reel emergency (reel slack) during unloading
22	T reel emergency
23	S reel emergency
30	FG emergency at the start up of the capstan
31	FG emergency during the normal rotation of the capstan
40	FG emergency at the start up of the drum
41	PG emergency at the start up of the drum
42	FG emergency during the normal rotation of the drum
43	PG emergency during the normal rotation of the drum
44	Phase emergency during the normal rotation of the drum

**Note 1 :** Be sure to rewrite the data of addresses 10 to 1B to 00 after repairs/adjustments.

**Note 2 :** When rewriting the data, be sure to press the PAUSE button of the remote commander after setting the data.

## 2-2. MSW Codes


- The lower parts of the data of addresses 12, 16 and 1A represent the MSW codes (mode switch, mechanism position) when errors occurs.
- The upper parts of the data of addresses 12, 16 and 1A represent, when the mechanism position is to be moved, the MSW codes at the start of movement (when moving the loading motor).
- The lower parts of the data of addresses 13, 17 and 1B represent the MSW codes of the desired movement when the mechanism position is to be moved.



Mechanism Position	MSWCode	Contents
EJECT	1	Position at which the cassette compartment lock is released. The mechanism will not move any further in the unloading direction.
BL	7	BLANC code. Between two codes. The mechanism will not be stopped by this code while it is operating.
USE	3	EJECT completion position. When the cassette is ejected, the mechanism will stop at this position.
LOAD	2	Code during loading/unloading. Code that is used while the LS chassis is moving.
STOP	6	Normal stop position. The pinch roller separates, the tension regulator returns, and the brakes of both reels turn on.
TURN	4	Position at which is used when the pendulum gear swings from S to T or from T to S.
RECP/PB	0	PB, REC, CUE, REV, PAUSE, FF positions. The pinch roller is pressed and tension regulator is on.
REW	5	REW position. REW are carried at this position. The mechanism will not move any further in the loading direction.

### 3. Bit value discrimination

Bit values must be discriminated using the display data of the adjustment remote commander for the following items. Use the table below to discriminate if the bit value is “1” or “0”.



(Example) If the remote commander display is “8E”, bit value from bit 7 to bit 4 can be discriminated from the column Ⓐ, and those from bit 3 to bit 0 from column Ⓡ.

Display on the adjustment remote commander	Bit values			
	bit3 or bit7	bit2 or bit6	bit1 or bit5	bit0 or bit4
0	0	0	0	0
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1
4	0	1	0	0
5	0	1	0	1
6	0	1	1	0
7	0	1	1	1
8	1	0	0	0
9	1	0	0	1
A (Ⓐ)	1	0	1	0
B (Ⓑ)	1	0	1	1
C (Ⓒ)	1	1	0	0
D (Ⓓ)	1	1	0	1
E (Ⓔ)	1	1	1	0
F (Ⓕ)	1	1	1	1

### 4. Input/output selection check

Page 3	Address 16
--------	------------

Bit	Function	When bit value = 1	When bit value = 0
0	Not S video terminal input		S video terminal input
1	Not video terminal input		Video terminal input
2	Audio terminal monaural	Monaural	
3			
4			
5			
6			
7			

#### Using method:

- 1) Select page: 3, address: 16.
- 2) By discriminating the bit value of the display data, the state of the input/output selection can be discriminated.

## 5. Condensation, head clogging check

Page 3	Address 17
--------	------------

Bit	Function	When bit value = 1	When bit value = 0
0	Condensation state (1 hour preservation)	Condensation	
1	Head clogging	Head clogging	
2			
3			
4			
5			
6			
7			

**Using method:**

- 1) Select page: 3, address: 17.
- 2) By discriminating the bit value of the display data, the state of the VTR can be discriminated.

## 6. VTR state check (1)

Page 3	Address 18
--------	------------

Bit	Function	When bit value = 1	When bit value = 0
0	Video/audio circuit PB mode	PB mode	REC/E-E mode
1			
2			
3			
4	Head clog detection when REC	Head clog	
5			
6	Recorded tape playback	Playback	
7	Capstan rotation	Rotation	

**Using method:**

- 1) Select page: 3, address: 18.
- 2) By discriminating the bit value of the display data, the state of the VTR can be discriminated.

## 7. VTR state check (2)

Page 3	Address 19
--------	------------

Bit	Function	When bit value = 1	When bit value = 0
0	Eject state	Eject state	REC/E-E mode
1	Cassette insertion state	Cassette in	
2	Cassette accidental erasure prevention	Accidental erasure prevention state	
3	Tape type	ME	MP
4	Tape type	Hi8 MP	MORMAL MP, ME
5	Crystal variable speed playback	Variable speed playback	
6	Variable speed playback mode	Variable speed playback mode	
7	DRUM	DRUM rotation	STOP

**Using method:**

- 1) Select page: 3, address: 19.
- 2) By discriminating the bit value of the display data, the state of the VTR can be discriminated.

## 8. VTR state check (3)

Page 3 | Address 1A

Bit	Function	When bit value = 1	When bit value = 0
0	Playback tape recording mode	Hi8	Standard 8
1			
2	Audio mode	Monaural	Stereo
3			
4			
5			
6			
7			

### Using method:

- 1) Select page: 3, address: 1A.
- 2) By discriminating the bit value of the display data, the state of the VTR can be discriminated.

## 9. Record of Use Check

Page 3 | Address E0 to E9

Bit	Function	Remarks	
E0	Service status	For checking reset. Normal = "FF". Reset: "00"	
E1	Drum rotation	Hour (H)	1000th place digit and 100th place digit of counted time (decimal digit)
E2	counted time	Hour (L)	10th place digit and 1st place digit of counted time (decimal digital)
E3	(BCD code)	Minute	
E4	User initial power	Year	After setting the clock, set the date of power on next
E5	on date	Month	
E6	(BCD code)	Day	
E7	Final condensation	Year	
E8	occurrence date	Month	
E9	(BCD code)	Day	

### Using method:

- 1) The record of use data is displayed at page 3, addresses: E0 to E9.

**Note :** This data will be erased when the coin lithium battery is removed (reset).

## 3-2. SYSTEM CONTROL SYSTEM ADJUSTMENTS

### 1. Initialization of D, E, F Page Data

If the D, E, F page data is erased due to some reason, perform “1-2. INITIALIZATION OF D, E, F PAGE DATA” (See page 5-8).

### 2. Battery End Adjustment (VC-197 board)

Set the battery end voltage.

If the voltage is incorrect, the life of the battery will shorten.

The image at the battery end will also be rough.

Mode	Camera record
Signal	Arbitrary
Measurement Point	LCD display of the adjusting remote control unit
Measuring Instrument	
Adjustment Page	D
Specified Value	28 to 2C, 35

#### Connection:

- 1) Connect the regulated power supply and the digital voltmeter to the battery terminal as shown in Fig. 5-3-5.

#### Adjusting method:

- 1) Adjust the output voltage of the regulated power supply so that the digital voltmeter display is  $6.1 \pm 0.1$  Vdc.
- 2) Turn off the regulated power supply.
- 3) Turn on the HOLD switch of the adjusting remote commander.
- 4) Turn on the regulated power supply.
- 5) Load a cassette, and set to the VTR PB mode.
- 6) Set page: 0, address: 01, data: 01.
- 7) Decrease the output voltage of the regulated power supply so that the digital voltmeter display is  $5.30 \pm 0.01$  Vdc.
- 8) Select page: 3, address: 15, read the adjusting remote commander display data, and this data is named Dref.
- 9) Set data Dref to page: D, address: 28, and press the PAUSE button of the adjusting remote commander.
- 10) Set the Dref to page: D, address: 35, and press the PAUSE button of the adjusting remote commander.
- 11) Convert Dref to decimal notation, and obtain Dref'. (Refer to Table 5-1-7. “Hexadecimal notation-decimal notation calculation table”)

- 12) Calculate  $D_{29}'$ ,  $D_{2A}'$ ,  $D_{2B}'$  and  $D_{2C}'$  using following equations (decimal notation calculation).

$$D_{29}' = Dref' + 8$$

$$D_{2A}' = Dref' + 32$$

$$D_{2B}' = Dref' + 53$$

$$D_{2C}' = Dref' + 64$$

- 13) Convert  $D_{29}'$ ,  $D_{2A}'$ ,  $D_{2B}'$  and  $D_{2C}'$  to hexadecimal notation, and obtain  $D_{29}$ ,  $D_{2A}$ ,  $D_{2B}$  and  $D_{2C}$ .
- 14) Set page: D, address: 29, data:  $D_{29}$  and press the PAUSE button of the adjusting remote commander.
- 15) Set page: D, address: 2A, data:  $D_{2A}$  and press the PAUSE button.
- 16) Set page: D, address: 2B, data:  $D_{2B}$  and press the PAUSE button.
- 17) Set page: D, address: 2C, data:  $D_{2C}$  and press the PAUSE button.
- 18) Set page: 0, address: 01, data: 00.

### 3. Battery down voltage check

#### Connection:

Same connection as item “1. Battery down voltage adjustment”.

#### Adjustment method:

- 1) Adjust the output voltage of the regulated power supply so that the digital voltmeter indicates  $6.10 \pm 0.01$  Vdc.
- 2) Insert a cassette and enter the VTR PB mode.
- 3) Adjust the output voltage of the regulated power supply so that the digital voltmeter indicates  $5.53 \pm 0.01$  Vdc.
- 4) Confirm that the battery down indication  on the POWER LED and EVF flashes at the rate of 0.8Hz.
- 5) Adjust the output voltage of the regulated power supply so that the digital voltmeter indicates  $5.27 \pm 0.01$  Vdc.
- 6) Confirm that the battery down indication  on the POWER LED and EVF flashes at the rate of 3.2Hz.




Fig. 5-3-5.

### 3-3. SERVO SYSTEM ADJUSTMENTS

#### 1. CAP FG Offset Adjustment (VC-197 board)

Improve the capstan servo characteristic. If it is not correct, jitters will increase.

Mode	Playback (SP mode)
Signal	Alignment tape : For operation check (WR5-5NSP(NTSC)) (WR5-5CSP(PAL))
Measurement Point	Pin ④ of CN207 (CAP FG)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	3A
Specified Value	Duty = $50 \pm 1.5\%$

#### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Change the page: F, address: 3A, data by pressing the PLAY and STOP buttons of the remote commander until the duty satisfies the specification.
- 3) Press the PAUSE button of the adjusting remote commander.
- 4) Set page: 0, address: 01, data: 00.




Fig. 5-3-6.

#### 2. Switching Position Adjustment (VC-197 board)

If deviated in this case causes switching noise or jitter on the played back screen.

Mode	Playback
Signal	Alignment tape: For tracking adjustment (WR5-1NP (NTSC)) (WR5-1CP (PAL))
Measurement Point	CH1: Pin ③ of CN207 (RF SWP) CH2: Pin ⑥ of CN207 (PB RF)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	36, 37
Specified Value	$t1 = 0 \pm 10 \mu\text{sec}$

**Note :** NTSC model : GV-A500  
PAL model : GV-A500E

#### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Change the data of page: F, address: 37 and minimize "t1", and press the PAUSE button of the adjusting remote commander. (Coarse adjustment)
- 3) Change the data of page: F, address: 36, and adjust so that the switching position (t1) becomes the specified value. (Fine adjustment)
- 4) Press the PAUSE button of the adjusting remote commander.
- 5) Set page: 0, address: 01, data: 00.




Fig. 5-3-7.

### 3. NTSC LP mode Switching Position Adjustment (VC-197 board)

If deviated in this case causes switching noise or jitter on the LP mode played back screen.

Mode	Playback
Signal	Alignment tape: For tracking adjustment (WR5-1NP)
Measurement Point	CH1: Pin ③ of CN207 (RF SWP) CH2: Pin ⑥ of CN207 (PB RF)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	38, 39
Specified Value	$t1 = 0 \pm 10 \mu\text{sec}$

#### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Set page: F, address: 29, data: 40 and press the PAUSE button of the adjusting remote commander.
- 3) Change the data of page: F, address: 39 and minimize “t1”, and press the PAUSE button of the adjusting remote commander. (Coarse adjustment)
- 4) Change the data of page: F, address: 38, and adjust so that the switching position (t1) becomes the specified value. (Fine adjustment)
- 5) Press the PAUSE button of the adjusting remote commander.
- 6) Set page: F, address: 29, data: 00 and press the PAUSE button of the adjusting remote commander.
- 7) Set page: 0, address: 01, data: 00.




Fig. 5-3-8.

### 3-4. VIDEO SYSTEM ADJUSTMENTS

Video system adjustments must be performed in the following order.

#### [Adjusting Order]

1. 28 MHz origin oscillation adjustment
2. Filter f0 adjustment
3. Y OUT level adjustment
4. C OUT level adjustment
5. RP filter f0 adjustment
6. AFC f0 adjustment
7. NTSC Hi8 REC Y current adjustment
8. PAL Hi8 REC Y current adjustment
9. NTSC Hi8 REC C current adjustment
10. PAL Hi8 REC C current adjustment
11. REC C current adjustment

#### 1. 28 MHz Origin Oscillation Adjustment (VC-197 board)

Set the frequency of the clock for synchronization.

If deviated, the synchronization will be disrupted and the color will become inconsistent.

**Note 1 :** If the x2 frequency is displayed, insert a  $1 \text{ k}\Omega$  resistor between the measuring point and probe.

**Note 2 :** NTSC model : GV-A500  
PAL model : GV-A500E

Mode	VTR stop
Subject	Arbitrary
Measurement Point	Pin ⑥ of IC206
Measuring Instrument	Frequency counter
Adjustment Page	F
Adjustment Address	3B
Specified Value	$f = 14318181 \pm 71 \text{ Hz}$ (NTSC) $f = 14187500 \pm 70 \text{ Hz}$ (PAL)

#### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Set page: 3, address: 01, data: 41 and press the PAUSE button of the adjusting remote commander.
- 3) Change the data of page: F, address: 3B, and set the oscillation frequency (f) to the specified value.
- 4) Press the PAUSE button of the adjusting remote commander.
- 5) Set page: 3, address: 01, data: 00 and press the PAUSE button of the adjusting remote commander.
- 6) Set page: 0, address: 01, data: 00.

## 2. Filter f0 Adjustment (VC-197 board)

Minimize the chroma signal residual components during composite video signal input.

**Note :** Do not insert a plug into the S video terminal.

Mode	VTR stop
Signal	Color bar (Video input)
Measurement Point	Pin ⑨ of CN207 (EZ I/O)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	5A
Specified Value	Minimum residual chroma signal components

## 3. Y OUT Level Adjustment (VC-197 board)

Set the Y signal output level.

**Note :** Insert the plug into the S video terminal.

Mode	VTR stop
Subject	Arbitrary
Measurement Point	Y signal terminal of S VIDEO terminal (75Ω terminated)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	56
Specified Value	$A = 286 \pm 5 \text{ mV}$ (NTSC) $A = 300 \pm 5 \text{ mV}$ (PAL)

### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Set page: 3, address: 01, data: 33 and press the PAUSE button of the adjusting remote commander.
- 3) Change the data of page: F, address: 5A, and minimize the residual chroma signal components (A).
- 4) Press the PAUSE button of the adjusting remote commander.
- 5) Set page: 3, address: 01, data: 00 and press the PAUSE button of the adjusting remote commander.
- 6) Set page: 0, address: 01, data: 00.




Fig. 5-3-9.

### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Set page: 3, address: 01, data: 41 and press the PAUSE button of the adjusting remote commander.
- 3) Change the data of page: F, address: 56, and set the SYNC level (A) to the specified value.
- 4) Press the PAUSE button of the adjusting remote commander.
- 5) Set page: 3, address: 01, data: 00 and press the PAUSE button of the adjusting remote commander.
- 6) Set page: 0, address: 01, data: 00.




Fig. 5-3-10.

#### 4. C OUT Level Adjustment (VC-197 board)

Set the chroma signal output level.

**Note :** Insert the plug into the S video terminal.

Mode	VTR stop
Subject	Arbitrary
Measurement Point	Chroma signal terminal of S VIDEO terminal ( $75\Omega$ terminated)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	58
Specified Value	$A = 286 \pm 5 \text{ mV}$ (NTSC) $A = 300 \pm 5 \text{ mV}$ (PAL)

#### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Set page: 3, address: 01, data: 41 and press the PAUSE button of the adjusting remote commander.
- 3) Change the data of page: F, address: 58, and set the burst level (A) to the specified value.
- 4) Press the PAUSE button of the adjusting remote commander.
- 5) Set page: 3, address: 01, data: 00 and press the PAUSE button of the adjusting remote commander.
- 6) Set page: 0, address: 01, data: 00.




Fig. 5-3-11.


#### 5. RP Filter f0 Adjustment (VC-197 board)

Adjust the LPF of the playback RF amplifier.

Mode	VTR stop
Subject	Arbitrary
Measurement Point	Pin ⑯ of CN207 (RF AGC OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	5B
Specified Value	$A = \text{Below } 10 \text{ mVp-p}$

#### Connection:

- 1) Input a 14.2 MHz, 400 mVp-p CW signal to Pin ⑦ of CN207 (RF AGC IN).



Transistor : General NPN transistor (2SC403, etc)

47 resistor : 1-249-401-11

1k resistor : 1-249-417-11

15k resistor : 1-249-431-11

0.01μF capacitor : 1-101-004-00

Fig. 5-3-12.

#### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Set page: 3, address: 01, data: 35 and press the PAUSE button of the adjusting remote commander.
- 3) Change the data of page: F, address: 5B, and minimize the 14.2 MHz signal level (A).
- 4) Press the PAUSE button of the adjusting remote commander.
- 5) Set page: 3, address: 01, data: 00 and press the PAUSE button of the adjusting remote commander.
- 6) Set page: 0, address: 01, data: 00.




Fig. 5-3-13.

## 6. AFC f0 Adjustment (VC-197 board)

Adjust the pull-in range of the A/D converted clock generator during playback.

**Note :** Do not insert the plug in the S video terminal.

Mode	VTR stop
Signal	Color bar (Video input)
Measurement Point	Pin ⑯ of CN207 (AFC f0)
Measuring Instrument	Digital voltmeter
Adjustment Page	F
Adjustment Address	57
Specified Value	$A = 2.2 \pm 0.05 \text{ Vdc}$

### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Set page: 3, address: 01, data: 31 and press the PAUSE button of the adjusting remote commander.
- 3) Change the data of page: F, address: 57, and set the DC voltage (A) to the specified value.
- 4) Press the PAUSE button of the adjusting remote commander.
- 5) Set page: 3, address: 01, data: 00 and press the PAUSE button of the adjusting remote commander.
- 6) Set page: 0, address: 01, data: 00.

## 7. NTSC Hi8 REC Y Current Adjustment (VC-197 board)

Adjust the Y FM signal recording current.

Mode	VTR recording
Signal	No signal
Measurement point	Pin ② of CN207 (REC RF)
Measuring instrument	Oscilloscope (20 MHz BW LIMIT: OFF)
Adjustment page	F
Adjustment address	60, 61, 62, 63, 64, 65, 66, 67
Specified value	A = $140 \pm 5$ mVp-p (ME, E, SP mode) A = $120 \pm 5$ mVp-p (MP, E, SP mode) A = $140 \pm 5$ mVp-p (MP, L, SP mode) A = $120 \pm 5$ mVp-p (ME, E, LP mode) A = $100 \pm 5$ mVp-p (MP, E, LP mode) A = $120 \pm 5$ mVp-p (MP, L, LP mode)

### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Note down the data of page: F, address: 69, set data: FF, and press the PAUSE button of the adjusting remote commander.
- 3) Set page: F, address: 29, data: 01 and press the PAUSE button of the adjusting remote commander.
- 4) Note down the data of page: D, address: 10, set data: 06, and press the PAUSE button of the adjusting remote commander.
- 5) Set to recording mode.
- 6) Set page: 3, address: 01, data: 41 and press the PAUSE button of the adjusting remote commander. (ME, E, SP mode)
- 7) Change the data of page: F, address: 61, and set the REC Y signal level (A) to the specified value.
- 8) Press the PAUSE button of the adjusting remote commander.
- 9) Read the data ( $D_{61}$ ) of page: F, address: 61.
- 10) Convert  $D_{61}$  to a decimal number, to obtain  $D'_{61}$ .  
(Refer to Table 5-1-7. Hexadecimal notation-decimal notation calculation table.)
- 11) Calculate the adjustment data (decimal) from the following equations (decimal calculation), convert it to a hexadecimal number, and input each adjustment address.  
Address: 60     $D_{60}' = D'_{61}$   
Address: 62     $D_{62}' = D'_{61} + 13$   
Address: 63     $D_{63}' = D'_{61} + 13$

**Note :** After setting each data, be sure to press the PAUSE button of the adjusting remote commander.

- 12) After setting data noted down at step 3) for page: F, address: 69, press the PAUSE button of the adjusting remote commander.
- 13) After setting data noted down at step 16) for page: F, address: 6B, press the PAUSE button of the adjusting remote commander.
- 14) After setting data noted down at step 5) for page: D, address: 10, press the PAUSE button of the adjusting remote commander.
- 15) Set page: F, address: 29, data: 00 and press the PAUSE button of the adjusting remote commander.
- 16) Set page: 3, address: 01, data: 00 and press the PAUSE button of the adjusting remote commander.
- 17) Set page: 0, address: 01, data: 00.




Fig. 5-3-14.

## 8. PAL Hi8 REC Y Current Adjustment (VC-197 board)

Adjust the Y FM signal recording current.

Mode	VTR recording (SP mode)
Signal	No signal
Measurement point	Pin ② of CN207 (REC RF)
Measuring instrument	Oscilloscope (20 MHz BW LIMIT: OFF)
Adjustment page	F
Adjustment address	60, 61, 62, 63, 64, 65
Specified value	A = $185 \pm 5$ mVp-p (ME, E, SP mode) A = $150 \pm 5$ mVp-p (MP, E, SP mode) A = $160 \pm 5$ mVp-p (MP, L, SP mode)

### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Note down the data of page: F, address: 69, set data: FF, and press the PAUSE button of the adjusting remote commander.
- 3) Set page: F, address: 29, data: 01 and press the PAUSE button of the adjusting remote commander.
- 4) Note down the data of page: D, address: 10, set data: 06, and press the PAUSE button of the adjusting remote commander.
- 5) Set to recording mode.
- 6) Set page: 3, address: 01, data: 41 and press the PAUSE button of the adjusting remote commander. (ME, E, SP mode)
- 7) Change the data of page: F, address: 61, and set the REC Y signal level (A) to the specified value.
- 8) Press the PAUSE button of the adjusting remote commander.
- 9) Read the page: F, address: 61, data ( $D_{61}$ ).
- 10) Set page: F, address: 60, 62 and 63, data:  $D_{61}$ .

**Note :** After setting each data, be sure to press the PAUSE button of the adjusting remote commander.

- 11) After setting data noted down at step 3) for page: F, address: 69, press the PAUSE button of the adjusting remote commander.
- 12) After setting data noted down at step 5) for page: D, address: 10, press the PAUSE button of the adjusting remote commander.
- 13) Set page: F, address: 29, data: 00 and press the PAUSE button of the adjusting remote commander.
- 14) Set page: 3, address: 01, data: 00 and press the PAUSE button of the adjusting remote commander.
- 15) Set page: 0, address: 01, data: 00.




Fig. 5-3-15.

## 9. NTSC Hi8 REC C Current Adjustment (VC-197 board)

Set the recording levels of the REC AFM signal and REC ATF signal. If the level is too low, the audio S/N will deteriorate, tracking will not be stable, or SP/LP will not be discriminated properly. If too high, color beets will be produced on the self-recording /playback image.

Adjust the REC chroma signal recording current.

Mode	VTR recording
Signal	No signal
Measurement point	Pin ② of CN207 (REC RF)
Measuring instrument	Oscilloscope (20 MHz BW LIMIT: OFF)
Adjustment page	F
Adjustment address	60 to 71
Specified value	$A = 30.3 \pm 1 \text{ mVp-p}$ (ME, E, SP mode)

### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Insert a tape, and set to recording mode.
- 3) Note down the data of page: F, address: 29, set data: 01, and press the PAUSE button of the adjusting remote commander.
- 4) Note down the data of page: D, address: 10, set data: 06, and press the PAUSE button of the adjusting remote commander.
- 5) Set page: 2, address: 61, data: 30 and press the PAUSE button of the adjusting remote commander.
- 6) Set page: 3, address: 01, data: 41 and press the PAUSE button of the adjusting remote commander. (ME, E, SP mode)
- 7) Change the data of page: F, address: 69, and set the REC L signal level (A) to the specified value.
- 8) Press the PAUSE button of the adjusting remote commander.
- 9) Read the page: F, address: 69, data ( $D_{69}'$ ).
- 10) Convert  $D_{69}'$  to a decimal number, to obtain  $D_{69}'$ .  
(Refer to Table 5-1-7. Hexadecimal notation-decimal notation calculation table.)
- 11) Calculate the adjustment data (decimal) from the following equations (decimal calculation), convert it to a hexadecimal number, and input each adjustment address.
 

Address: 68	$D_{68}' = D_{69}'$
Address: 6A	$D_{6A}' = D_{69}' - 11$
Address: 6B	$D_{6B}' = D_{69}' - 11$
Address: 6C	$D_{6C}' = D_{69}' + 16$
Address: 6D	$D_{6D}' = D_{69}' + 16$
Address: 6E	$D_{6E}' = D_{69}' + 16$
Address: 6F	$D_{6F}' = D_{69}' + 16$
- Note :** After setting each data, be sure to press the PAUSE button of the adjusting remote commander.
- 12) After setting data noted down at step 3) for page: F, address: 29, press the PAUSE button of the adjusting remote commander.
- 13) After setting data noted down at step 4) for page: D, address: 10, press the PAUSE button of the adjusting remote commander.
- 14) Set page: 3, address: 01, data 00 and press the PAUSE button of adjusting remote commander.
- 15) Set page: 2, address: 61, data: 10 and press the PAUSE button of the adjusting remote commander.
- 16) Set page: 0, address: 01, data: 00.

**Note :** Do not insert a plug into the AUDIO (R) terminal.

### Connection:

- 1) Remove C1060 (0.01μF, near Pin ⑤ of IC101).  
**Note :** After completing “REC L Level Adjustment” and “RECC Current Adjustment”, replace C1060 with new parts (1-162-970-11 CERAMIC CHIP 0.01μF 10% 25V).
- 2) Connect Pin ⑥ of IC101 and GND with a 0.01μF capacitor.  
0.01μF capacitor: 1-101-004-00




Fig. 5-3-16.

## 10. PAL Hi8 REC C Current Adjustment

### (VC-197 board)

Set the recording levels of the REC AFM signal and REC ATF signal. If the level is too low, the audio S/N will deteriorate, tracking will not be stable, or SP/LP will not be discriminated properly. If too high, color beets will be produced on the self-recording /playback image.

Adjust the REC chroma signal recording current.

Mode	VTR recording
Signal	No signal
Measurement point	Pin ② of CN207 (REC RF)
Measuring instrument	Oscilloscope (20 MHz BW LIMIT: OFF)
Adjustment page	F
Adjustment address	68 to 71
Specified value	A = $35.7 \pm 1.3$ mVp-p (ME, E, SP mode)

### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Insert a tape, and set to recording mode.
- 3) Note down the data of page: F, address: 29, set data: 01, and press the PAUSE button of the adjusting remote commander.
- 4) Note down the data of page: D, address: 10, set data: 06, and press the PAUSE button of the adjusting remote commander.
- 5) Set page: 2, address: 61, data: 30 and press the PAUSE button of the adjusting remote commander.
- 6) Set page: 3, address: 01, data: 41 and press the PAUSE button of the adjusting remote commander. (ME, E, SP mode)
- 7) Change the data of page: F, address: 69, and set the REC C signal level (A) to the specified value.
- 8) Press the PAUSE button of the adjusting remote commander.
- 9) Read the page: F, address: 69, data ( $D_{69}'$ ).
- 10) Convert  $D_{69}$  to a decimal number, to obtain  $D_{69}'$ .  
(Refer to Table 5-1-7. Hexadecimal notation-decimal notation calculation table.)
- 11) Calculate the adjustment data (decimal) from the following equations (decimal calculation), convert it to a hexadecimal number, and input each adjustment address.
 

Address: 68	$D_{68}' = D_{69}'$
Address: 6A	$D_{6A}' = D_{69}'$
Address: 6B	$D_{6B}' = D_{69}'$
Address: 6C	$D_{6C}' = D_{69}' + 14$
Address: 6D	$D_{6D}' = D_{69}' + 14$
Address: 6E	$D_{6E}' = D_{69}' + 14$
Address: 6F	$D_{6F}' = D_{69}' + 14$
- Note :** After setting each data, be sure to press the PAUSE button of the adjusting remote commander.
- 12) After setting data noted down at step 3) for page: F, address: 29, press the PAUSE button of the adjusting remote commander.
- 13) After setting data noted down at step 4) for page: D, address: 10, press the PAUSE button of the adjusting remote commander.
- 14) Set page: 3, address: 01, data: 00 and press the PAUSE button of the adjusting remote commander.
- 15) Set page: 3, address: 01, data: 00 page: 3, address: 01, and press the PAUSE button of the adjusting remote commander.
- 16) Set page: 0, address: 01, data: 00.

**Note :** Do not insert a plug into the AUDIO (R) terminal.

### Connection:

- 1) Remove C1060 (0.01μF, near Pin ⑤ of IC101).  
**Note :** After completing “REC L Level Adjustment” and “REC C Current Adjustment”, replace C1060 with new parts (1-162-970-11 CERAMIC CHIP 0.01μF 10% 25V).
- 2) Connect Pin ⑥ of IC101 and GND with a 0.01μF capacitor. 0.01μF capacitor: 1-101-004-00




Fig. 5-3-17.

## 11. REC C Current Adjustment (VC-197 board)

Set the recording current level of REC chroma signal. If it is lower than its normal level, chroma signal noise in played back picture will increase and white modulation noises will be produced.

Mode	VTR recording (SP mode)
Signal	No signal
Measurement point	Pin ② of CN207 (REC RF)
Measuring instrument	Oscilloscope (20 MHz BW LIMIT: OFF)
Adjustment page	F
Adjustment address	72
Specified value	$A = 116 \pm 6.4 \text{ mVp-p}$ (NTSC) $A = 129 \pm 7 \text{ mVp-p}$ (PAL)

### Connection:

- 1) Remove C1060 (0.01μF, near Pin ⑤ of IC101).  
**Note :** After completing “REC L Level Adjustment” and “REC C Current Adjustment”, replace C1060 with new parts (1-162-970-11 CERAMIC CHIP 0.01μF 10% 25V).
- 2) Connect Pin ① of IC101 and GND with a 0.01μF capacitor.  
0.01μF capacitor: 1-101-004-00
- 3) Connect Pin ⑥ of IC101 and GND with a 0.01μF capacitor.  
0.01μF capacitor: 1-101-004-00

### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Set to recording mode.
- 3) Note down the data of page: F, address: 29, set data: 01, and press the PAUSE button of the adjusting remote commander.
- 4) Note down the data of page: D, address: 10, set data: 06, and press the PAUSE button of the adjusting remote commander.
- 5) Set page: 2, address: 61, data: 30 and press the PAUSE button of the adjusting remote commander.
- 6) Set page: 3, address: 01, data: 41 and press the PAUSE button of the adjusting remote commander. (MP, SP mode)
- 7) Change the data of page: F, address: 72, and set the REC C signal level (A) to the specified value.
- 8) Press the PAUSE button of the adjusting remote commander.
- 9) After setting data noted down at step 3) for page: F, address: 29, press the PAUSE button of the adjusting remote commander.
- 10) After setting data noted down at step 4) for page: D, address: 10, press the PAUSE button of the adjusting remote commander.
- 11) Set page: 2, address: 61, data: 10 and press the PAUSE button of the adjusting remote commander.
- 12) Set page: 3, address: 01, data: 00 and press the PAUSE button of the adjusting remote commander.
- 13) Set page: 0, address: 01, data: 00.




Fig. 5-3-18.

### 3-5. IR Transmitter Adjustments

Adjust using a IR receiver jig.

#### Switch setting:

LASER LINK ..... ON (Red LED is lit)

#### 1. IR Video Carrier Frequency Adjustment (MI-27/28 board)

Mode	VTR stop
Subject	Arbitrary
Measuring point	TP607 of IR receiver jig (or Pin ⑯ of IC361 of MI-27/28 board)
Measuring instrument	Frequency counter
Adjusting page	F
Adjusting address	76
Specified value	$f = 11.85 \pm 0.05 \text{ MHz}$

#### Connection of Equipment:

Connect the measuring devices as shown in the following figure, and adjust.




Fig. 5-3-19.

#### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Set page: 3, address: 09, data: 01 and press the PAUSE button of the adjusting remote commander.
- 3) Set page: 3, address: 01, data: 37 and press the PAUSE button of the adjusting remote commander.
- 4) Change the data of page: F, address: 76, and set the video carrier frequency (f) to the specified value.
- 5) Press the PAUSE button of the adjusting remote commander.
- 6) Set page: 3, address: 01, data: 00 and press the PAUSE button of the adjusting remote commander.
- 7) Set page: 3, address: 09, data: 00 and press the PAUSE button of the adjusting remote commander.
- 8) Set page: 0, address: 01, data: 00.

#### 2. IR Video Deviation Adjustment (MI-27/28 board)

Mode	VTR stop
Subject	Arbitrary
Measuring point	VIDEO OUT terminal of IR receiver jig (Terminated at $75\Omega$ )
Measuring instrument	Oscilloscope
Adjusting page	F
Adjusting address	73
Specified value	$A = 0.87^{+0.04}_{-0.10} \text{ V}$

#### Connection of Equipment:

Connect the measuring devices as shown in the following figure, and adjust.




Fig. 5-3-20.

#### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Set page: 3, address: 09, data: 01 and press the PAUSE button of the adjusting remote commander.
- 3) Set page: 3, address: 01, data: 39 and press the PAUSE button of the adjusting remote commander.
- 4) Change the data of page: F, address: 73, and set the video signal amplitude (A) to the specified value.
- 5) Press the PAUSE button of the adjusting remote commander.
- 6) Set page: 3, address: 01, data: 00 and press the PAUSE button of the adjusting remote commander.
- 7) Set page: 3, address: 09, data: 00 and press the PAUSE button of the adjusting remote commander.
- 8) Set page: 0, address: 01, data: 00.




Fig. 5-3-21.

### 3. IR Audio Deviation Adjustment (MI-27/28 board)

Mode	VTR recording
Signal	Audio signal: 400 Hz, -7.5 dBs: Left or right of audio input/output terminal Video signal: Color bar signal: Video input/ output terminal
Measuring point	AUDIO OUT L terminal and AUDIO OUT R terminal of IR receiver jig (Terminated at 47 kΩ)
Measuring instrument	Audio level meter
Adjusting page	F
Adjusting address	75
Specified value	-7.5 ± 0.5 dBs

#### Connection of Equipment:

Connect the measuring devices as shown in the following figure, and adjust.




Fig. 5-3-22.

#### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Connect the audio level meter to the AUDIO OUT L terminal of the IR receiver jig.
- 3) Set page: 3, address: 09, data: 01 and press the PAUSE button of the adjusting remote commander.
- 4) Change the data of page: F, address: 75, and set the audio signal level to the specified value.
- 5) Press the PAUSE button of the adjusting remote commander.
- 6) Connect the audio level meter to the AUDIO OUT R terminal of the IR receiver jig.
- 7) Check that the audio level is within the specified value. If outside, repeat from step 2.
- 8) Set page: 3, address: 09, data: 00 and press the PAUSE button of the adjusting remote commander.
- 9) Set page: 0, address: 01, data: 00.

### 3-6. AUDIO SYSTEM ADJUSTMENT

- Perform the adjustment using the color bar signal as a video signal input for VIDEO terminal.
- The items to be adjusted for the R channel will be indicated within the [ ], in regard to the adjusting items to be adjusted for both L and R channels.
- Set the Hi-Fi sound switch in the menu display to “STEREO” position unless specified otherwise.

#### Note :

- 1) When inputting the audio signal, input the same signal to both the L and R channels, unless specified otherwise.
- 2) Be sure to insert the plug (Shorting plug or dummy plug, etc) into the AUDIO terminal (Right). If the plug is not inserted, the monaural mode will be set, and correct adjustments can not be carried out.  
[Monaural mode]  
During recording ..... REC AFM RF 1.7MHz carrier will not be output.  
During playback ..... The L+R signal will be output from the AUDIO terminal (Left).

#### [Connecting the measuring instruments for the audio]

Connect the audio system measuring instruments in addition to the video system measuring instruments as shown in Fig. 5-3-25, and perform adjustments at the power switch [VTR] or [PLAYER] position.

#### [Adjustment Procedure]

- 1) 1.5 MHz deviation adjustment
- 2) 1.7 MHz deviation adjustment
- 3) BPF adjustment




Fig. 5-3-24.

### 1.1.5 MHz Deviation Adjustment (VC-197 board)

Sets the spectrum of the L-ch (L+R/2 signal) level modulated during recording. If deviated, the crosstalk of the audio signal will occur and the audio level will drop during both playback and recording.

Mode	VTR recording
Signal	Input the AFM DEV jig output signal to the right and left audio input terminals (Note 1)
Measuring point	CH1: AFM DEV jig TP31 CH2: AFM DEV jig TP3
Measuring device	Oscilloscope ADD mode CH2 INV mode
Adjustment page	F
Adjustment address	52
Specified value	The difference between CH1 signal and CH2 signal should be minimum.

#### Connection:

- 1) Connect CN2 of the AFM DEV jig to CN207 of the VC-197 board.
- 2) Connect the audio output terminal (J1 and J2) of the AFM DEV jig to AUDIO terminal of the unit.
- 3) Connect TP28 (DC), TP27 (GND) of the AFM DEV jig to the DC power supply (+7 Vdc to +9 Vdc).
- 4) Set the AFM DEV jig switches to the following positions.  
 S1 ..... BIL position  
 S2 ..... NT position (NTSC)  
 PAL position (PAL)  
 S3 ..... SIN position

**Note :** NTSC model : GV-A500  
PAL model : GV-A500E

#### Adjustment method:

- 1) Match the vertical ranges of CH1 and CH2 of the oscilloscope to each other.
- 2) Set the oscilloscope to the ADD mode and CH2 to the INV (inverse) mode.
- 3) Set page: 0, address: 01, data: 01.
- 4) Change the data of page: F, address: 52 and minimize the audio signal level difference (A).
- 5) Press the PAUSE button of the adjusting remote commander.
- 6) Set page: 0, address: 01, data: 00.




Fig. 5-3-25.

### 2.1.7 MHz Deviation Adjustment (VC-197 board)

Sets the spectrum of the R-ch (L-R/2 signal) level modulated during recording. If deviated, the crosstalk of the audio signal will occur and the audio level will drop during both playback and recording.

Mode	VTR recording
Signal	Input the AFM DEV jig output signal to the right and left audio input terminals
Measuring point	CH1: AFM DEV jig TP32 CH2: AFM DEV jig TP2
Measuring device	Oscilloscope ADD mode CH2 INV mode
Adjustment page	F
Adjustment address	53
Specified value	The difference between CH1 signal and CH2 signal should be minimum.

#### Connection:

- 1) Connect CN2 of the AFM DEV jig to CN207 of the VC-197 board.
- 2) Connect the audio output terminal (J1 and J2) of the AFM DEV jig to AUDIO terminal of the unit.
- 3) Connect TP28 (DC), TP27 (GND) of the AFM DEV jig to the DC power supply (+7 to +9 Vdc).
- 4) Set the AFM DEV jig switches to the following positions.  
 S1 ..... BIL position  
 S2 ..... NT position (NTSC)  
 PAL position (PAL)  
 S3 ..... SIN position

**Note :** NTSC model : GV-A500  
PAL model : GV-A500E

#### Adjustment method:

- 1) Match the vertical ranges of CH1 and CH2 of the oscilloscope to each other.
- 2) Set the oscilloscope to the ADD mode and CH2 to the INV (inverse) mode.
- 3) Set page: 0, address: 01, data: 01.
- 4) Change the data of page: F, address: 53 and minimize the audio signal level difference (A).
- 5) Press the PAUSE button of the adjusting remote commander.
- 6) Set page: 0, address: 01, data: 00.




Fig. 5-3-26.

### **3. BPF f0 Adjustment (VC-197 board)**

Sets the BPF passing frequency so that the AFM signal can separate from the playback RF signal properly. If deviated the mono/stereo mode will be differentiated incorrectly, and noises and distortions will increase during high volume playback.

Mode	Playback
Signal	Alignment tape: For BPF adjustment (WR5-11NS (NTSC)) (WR5-11CS (PAL))
Measuring point	Right or left audio output terminal
Measuring device	Distortion meter
Adjustment page	F
Adjustment address	54
Specified value	The Main and Sub channel distortion rates should be almost the same (within ± 1%) and minimum

**Note :** NTSC model : GV-A500

PAL model : GV-A500E

#### **Adjustment method:**

- 1) Set page: 0, address: 01, data: 01.
- 2) Set the Hi-Fi sound switch (menu display) to “**[2]**”.
- 3) Change the data of page: F, address: 54 and minimize the distortion rate.
- 4) Press the PAUSE button of the adjusting remote commander.
- 5) Set the Hi-Fi sound switch to “**[1]**”.
- 6) Change the data of page: F, address: 54 and minimize the distortion rate.
- 7) Press the PAUSE button of the adjusting remote commander.
- 8) Repeat steps 2) to 7) and set the data of address: 54 so that the distortion rates when the Hi-Fi sound switch is set to “**[2]**” and set to “**[1]**” respectively are almost the same and minimum.
- 9) Press the PAUSE button of the adjusting remote commander.
- 10) Set page: 0, address: 01, data: 00.
- 11) Set the Hi-Fi sound switch to “STEREO”.

### 3-7. LCD SYSTEM ADJUSTMENT

**Note 1 :** The back light (fluorescent tube) is driven by a high voltage AC power supply. Therefore, do not touch the back light holder to avoid electrical shock.

**Note 2 :** When replacing the LCD unit, be careful to prevent damages caused by static electricity.

**Note 3 :** Set the brightness to the center using the LCD BRIGHT button.

#### [Adjusting connector]

Most of the measuring points for adjusting the LCD display are concentrated in the following connector.

CN802 of the VC-197 board. Connect the measuring instruments via the multi CPC jig (J-6082-311-A).

The following table shows the Pin No. and signal name of the connector.

Pin No.	Signal Name	Pin No.	Signal Name
1	VR	2	VG
3	VB	4	V-COM
5	GND	6	SYNC
7	HDB	8	SAT
9	FRP		

#### [Power Supply Voltage]

Adjust the power supply voltage so that the battery terminal voltage becomes  $7.2 \pm 0.1$  Vdc .

#### [Video input signal for adjustment]

If stated as "10-step stair-step" in the signal column, input the 10-step stair-step signal in the video input terminal as the video input signal for the adjusting. Check that the input signal level is 1.00 Vp-p before adjusting.




Fig. 5-3-27.

### 1. LCD Initial Data Input

Mode	VTR stop
Signal	Arbitrary
Adjustment Page	D
Adjustment Address	3C to 3F, 52 to 62

#### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Select page: D, and input the data in the following table.  
**Note :** To write in the non-volatile memory (EEPROM), press the PAUSE button of the adjusting remote commander each time to set the data.
- 3) Set page: 0, address: 01, data: 00.

Address	Data		Remark
	NTSC 4" LCD	PAL 4" LCD	
3C	08	08	
3D	07	08	
3E	03	03	Fixed value
3F	05	05	Fixed value
52	88	86	
53	79	66	
54	72	60	
55	76	79	
56	68	73	
57	97	9A	
58	85	56	
59	97	9A	
5A	7D	7C	Fixed value
5B	7E	7D	Fixed value
5C	69	60	Fixed value
5D	88	86	
5E	00	60	(Fixed value)
5F	69	60	Fixed value
60	00	B0	Fixed value
61	00	67	Fixed value
62	A1	A1	Fixed value

( ): NTSC model only (GV-A500)

## 2. VCO Adjustment (PD-88 board)

Set the VCO freerun frequency. If deviated, the LCD screen will be blurred.

Mode	VTR stop
Signal	No signal
Measurement point	Pin ⑦ of CN802 (HDB) of VC-197 board
Measuring instrument	Frequency counter
Adjustment page	D
Adjustment address	58
Specified value	$f = 15734 \pm 30\text{Hz}$ (NTSC) $f = 15625 \pm 30\text{Hz}$ (PAL)

**Note :** Press the DISPLAY button and erase the screen indicators on the LCD screen.

### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Set page: 3, address: 01, data: 37 and press the PAUSE button of the adjusting remote commander.
- 3) Change the data of page: D, address: 58, and set the HDB signal frequency (f) to the specified value.
- 4) Press the PAUSE button of the adjusting remote commander.
- 5) Set page: 3, address: 01, data: 00 and press the PAUSE button of the adjusting remote commander.
- 6) Set page: 0, address: 01, data: 00.

## 3. H POS Adjustment (VC-197 board)

Adjusts the horizontal position of picture on LCD display.

Mode	VTR stop
Signal	Color bar signal
Measurement point	CH1: VC-197 board CN802 pin ⑥ (SYNC) CH2: VC-197 board CN802 pin ⑧ (SRT)
Measuring equipment	Oscilloscope
Adjustment page	D
Adjustment address	5C, 55
Specification	$T=6.9 \pm 0.1\mu\text{sec}$ (NTSC) $T=8.40 \pm 0.1\mu\text{sec}$ (PAL)

**Note :** Set the LCD so that it is directed toward the lens. (The waveform is different depending upon direction.)

### Adjusting method:

- 1) Set page :0, address: 01, data: 01
- 2) Change the data of page: D, address: 5C and set the signal level (T) to the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.
- 4) Read the page: D, address: 5C, data ( $D_{SC}$ ).
- 5) Set page: D, address: 5F, data:  $D_{SC}$  and press the PAUSE button of the adjusting remote commander.
- 6) Set page: 0, address: 01, data: 01.




Fig. 5-3-28.

#### 4. Bright Adjustment (VC-197 board)

Set the D range of the RGB decoder used to drive the LCD to the specified value. If deviated, the LCD screen will become blackish or saturated (whitish).

Mode	VTR stop
Signal	10-step stair-step signal or color bar signal whose chroma and burst signals are turned off
Measurement point	Pin ② of CN802 (VG) of VC-197 board
Measuring instrument	Oscilloscope
Adjustment page	D
Adjustment address	52, 5D
Specified value	$A = 2.60 \pm 0.05V$

**Note :** Perform “3. Bright Adjustment” and “4. Contrast Adjustment” alternately until each specified value is satisfied.

#### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Change the data of page: D, address: 52, and set the voltage (A) between the reversed waveform pedestal and non-reversed waveform pedestal to the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.
- 4) Set the same data as page: D, address: 52 to page: D, address: 5D, and press the PAUSE button of the adjusting remote commander.
- 5) Set page: 0, address: 01, data: 00.
- 6) Check that the specified value of “Contrast Adjustment” is satisfied, if not, perform “Contrast Adjustment”.




Fig. 5-3-29.

#### 5. Contrast Adjustment (VC-197 board)

Set the level of the VIDEO signal for driving the LCD to the specified value. If deviated, the screen image will be blackish or saturated (whitish).

Mode	VTR stop
Signal	10-step stair-step signal
Measurement point	Pin ② of CN802 (VG) of VC-197 board
Measuring instrument	Oscilloscope
Adjustment page	D
Adjustment address	57
Specified value	$A = 3.30 \pm 0.05V$

**Note :** Perform “3. Bright Adjustment” and “4. Contrast Adjustment” alternately until each specified value is satisfied.

#### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Change the data of page: D, address: 57, and set the voltage (A) between the reversed waveform pedestal and non-reversed waveform pedestal to the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.
- 4) Set page: 0, address: 01, data: 00 .
- 5) Check that the specified value of “Bright Adjustment” is satisfied, if not, perform “Bright Adjustment”.




Fig. 5-3-30.

## 6. Color Adjustment for NTSC model (VC-197 baord)

Set the color saturation to the standard value. If deviated, the color will be to dark or light.

Mode	VTR stop
Signal	Color bar
Measurement point	Pin ② of CN802 (VG)
Measuring instrument	Oscilloscope
Adjustment page	D
Adjustment address	53
Specified value	$A = 0.27 \pm 0.05V$

### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Change the data of page: D, address: 53 and set the green level (A) to White (75%) to the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.
- 4) Set page: 0, address: 01, data: 00.




Fig. 5-3-31

## 7. Hue Adjustment for NTSC model (VC-197 baord)

Set the hue to the standard value. If deviated, the color will be to unnatural.

Mode	VTR stop
Signal	Color bar
Measurement point	Pin ② of CN802 (VG)
Measuring instrument	Oscilloscope
Adjustment page	D
Adjustment address	54
Specified value	$A = 0.27 \pm 0.05V$

### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Change the data of page: D, address: 54, and set the cyan level (A) to yellow to the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.
- 4) Set page: 0, address: 01, data: 00.




Fig. 5-3-32.

## 8. Burst Cleaning Adjustment for PAL model (VC-197 board)

Adjust to the optimum PAL chroma signal demodulation phase. If the phase is not correct, moire distortion noises will stand out.

Mode	VTR stop
Signal	Color bar
Measurement point	Pin ② of CN802 (VG) of VC-197 board
Measuring instrument	Oscilloscope
Adjustment page	D
Adjustment address	54, 5E
Specified value	$A = 0 \pm 50 \text{ mV}$

**Note :** Perform “7. Burst Cleaning Adjustment for PAL model” and “8. Color Adjustment for PAL model” alternately until each specified value is satisfied.

### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Change the data of page: D, address: 54, and adjust so that the flicker amplitude (A) of the cyan section becomes minimum.
- 3) Press the PAUSE button of the adjusting remote commander.
- 4) Set the same data as page: D, address: 54 to page: D, address: 5E, and press the PAUSE button of the adjusting remote commander.
- 5) Set page: 0, address: 01, data: 00.
- 6) Check that the specified value of “Color Adjustment for PAL model” is satisfied, if not, perform “Color Adjustment for PAL model”.




Fig. 5-3-32.

## 9. Color Adjustment for PAL model (VC-197 board)

Set the color saturation to the standard value. If deviated, the color will be too dark or light.

Mode	VTR stop
Signal	Color bar
Measurement point	Pin ② of CN802 (VG) of VC-197 board
Measuring instrument	Oscilloscope
Adjustment page	D
Adjustment address	53
Specified value	$A = 0.37 \pm 0.05 \text{ V}$

**Note :** Perform “7. Burst Cleaning Adjustment for PAL model” and “8. Color Adjustment for PAL model” alternately until each specified value is satisfied.

### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Change the data of page: D, address: 53, and set the green level (A) to yellow to the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.
- 4) Set page: 0, address: 01, data: 00.
- 5) Check that the specified value of “Burst Cleaning Adjustment for PAL model” is satisfied, if not, perform “Burst Cleaning Adjustment for PAL model”.




Fig. 5-3-33.

## 10. V-COM Adjustment (PD-88 board)

Set the DC bias of the common electrode drive signal of LCD display to the specified value.

If deviated, the LCD display will move, producing flicker and conspicuous vertical lines.

Mode	Playback pause
Signal	Alignment tape: LP mode operation check (WR5-8NLE (NTSC)) (WR5-8CLE or WR5-4CL (PAL)) Color bar portion
Measurement point	Check on LCD display
Measuring instrument	
Adjustment page	D
Adjustment address	59

### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Playback the alignment tape and set to the playback pause mode.
- 3) Change the data of page: D, address: 59. When the data is increased from the initial value, vertical lines with intervals of 3 dots between them will be seen. Take the data at this times as  $D_A$ . When decreased from the initial value, the same vertical lines will be seen. Take the data at this times as  $D_B$ .
- 4) Convert  $D_A$  and  $D_B$  to decimal numbers to obtain  $D_A'$  and  $D_B'$ . (Refer to Table 5-1-5. "Hexadecimal notation-decimal notation calculation table".)
- 5) Calculate  $D_c'$  using the following equation (decimal calculation).  

$$D_c' = (D_A' + D_B') \div 2$$
- 6) Convert  $D_c'$  to hexadecimal number to obtain  $D_c$ .
- 7) Set page: D, address: 59, data:  $D_c$  and press the PAUSE button of the adjusting remote commander.
- 8) Set page: 0, address: 01, data: 00.




Fig. 5-3-35.

## 11. White Balance Adjustment (VC-197 board)

Correct the white balance.

If deviated, the LCD screen color cannot be reproduced.

Mode	VTR stop
Signal	10-step stair-step signal or color bar signal whose chroma and burst signals are turned off
Measurement point	Check on LCD screen
Measuring instrument	
Adjustment page	D
Adjustment address	55, 56
Specified value	The LCD screen should not be colored.

**Note :** Check the white balance only when replacing the following parts. If necessary, adjust them.

1. LCD panel
2. Light induction plate
3. IC801

### Adjusting method:

- 1) Set page: 0, address: 01, data: 01.
- 2) Check that the LCD screen is not colored. If colored, change the data of page: D, address: 55 and 56 so that the LCD screen is not colored.
- 3) Set page: 0, address: 01, data: 00.

**Note :** To write in the non-volatile memory (EEPROM), press the PAUSE button of the adjusting remote commander each time to set the data.

- 3) Set page: 0, address: 01, data: 00.

## SECTION 6

### REPAIR PARTS LIST

#### 6-1. EXPLODED VIEWS


**Note:**

- -XX, -X mean standardized parts, so they may have some differences from the original one.
- Items marked “\*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (#mark) list is given in the last of this parts list.


The components identified by mark $\triangle$ or dotted line with mark $\triangle$ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque $\triangle$ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.
--	--

#### 6-1-1. OUTER CABINET ASSEMBLY




Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
1	X-3947-749-1	CABINET (BOTTOM) ASSY		5	X-3947-753-1	PANEL ASSY, BATTERY	
2	X-3947-872-1	LID ASSY, CASSETTE		6	1-694-076-11	TERMINAL BOARD, BATTERY	
3	X-3947-873-1	CABINET (LID) ASSY		7	3-978-675-11	LID, JACK	
4	3-948-339-61	TAPPING		8	3-968-729-01	SCREW (M2), LOCK ACE, P2	

## 6-1-2. LCD BLOCK, UPPER CABINET BLOCK ASSEMBLY




Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
51	X-3947-874-1	CABINET ASSY, LCD WINDOW		67	X-3947-754-1	CABINET (R) ASSY	
52	1-801-664-21	MODULE, CRYSTAL INDICATION		68	1-667-402-11	FP-573 FLEXIBLE BOARD	
$\triangle$ 53	1-517-656-21	TUBE, FLUORESCENT LOLD CATHODE		69	1-667-403-11	FP-574 FLEXIBLE BOARD	
54	1-667-405-11	FP-576 FLEXIBLE BOARD		70	3-965-367-01	SPACER, SP	
* 55	X-3948-044-1	PLATE ASSY, FIXED		71	1-504-753-21	SPEAKER (2.8CM)	
56	3-978-718-01	COVER (L), SHAFT		72	1-667-399-11	FP-570 FLEXIBLE BOARD	
57	3-978-717-11	CABINET, LCD (A500)		73	A-7073-364-A	EX-34 BOARD, COMPLETE	
57	3-978-717-21	CABINET, LCD (A500E)		74	3-948-339-61	TAPPING	
58	3-968-729-01	SCREW (M2), LOCK ACE, P2		75	X-3947-871-1	CABINET (UPPER) ASSY	
59	3-978-709-01	HINGE UNIT		76	3-978-710-01	LID, LITHIUM	
60	3-978-719-01	COVER (R), SHAFT		77	7-685-203-19	SCREW +KTP 2X5 TYPE2 NON-SLIT	
62	3-968-729-51	SCREW (M2), LOCK ACE, P2		78	1-667-400-11	FP-571 FLEXIBLE BOARD	
63	1-667-404-11	FP-575 FLEXIBLE BOARD		79	A-7073-363-A	PD-88 BOARD, COMPLETE	
64	1-667-401-11	FP-572 FLEXIBLE BOARD		* 80	3-978-678-01	SHEET METAL (L), STRAP	
65	A-7073-329-A	IR-29 BOARD, COMPLETE		* 81	3-978-677-01	SHEET METAL (R), STRAP	
66	A-7073-328-A	IO-62 BOARD, COMPLETE (A500)		* 82	X-3947-865-1	FRAME ASSY, JACK	
66	A-7073-365-A	IO-62 BOARD, COMPLETE (A500E)					

### 6-1-3. MD BLOCK ASSEMBLY




Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
101	3-968-729-51	SCREW (M2), LOCK ACE, P2		110	3-978-713-01	SPRING (R), FRAME RETURN	
102	1-667-402-11	FP-573 FLEXIBLE BOARD		111	3-703-816-33	SCREW (M1.4X1.6), SPECIAL HEAD	
103	A-7085-076-A	VC-197 BOARD, COMPLETE (A500)		112	1-475-383-31	SWITCH BLOCK, CONTROL (FK-71)	
103	A-7085-077-A	VC-197 BOARD, COMPLETE (A500E)		113	3-978-711-01	LID, LOADING	
104	1-667-400-11	FP-571 FLEXIBLE BOARD		114	3-968-729-01	SCREW (M2), LOCK ACE, P2	
105	1-667-399-11	FP-570 FLEXIBLE BOARD		115	A-7073-362-A	DD-100 BOARD, COMPLETE	
* 106	X-3947-997-1	FRAME ASSY, MAIN		116	1-500-227-11	BEAD, FERRITE	
* 107	X-3947-755-1	FRAME ASSY, LID		117	1-667-401-11	FP-572 FLEXIBLE BOARD	
108	3-978-702-01	SPRING (L), FRAME RETURN		118	1-667-405-11	FP-576 FLEXIBLE BOARD	
109	3-965-303-01	DAMPER		119	not supplied		

#### 6-1-4. CASSETTE COMPARTMENT BLOCK SECTION




Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
701	A-7040-421-A	DAMPER ASSY		707	X-3945-399-1	GEAR ASSY, GOOSENECK	
702	7-624-102-04	STOP RING 1.5, TYPE -E		708	3-947-503-01	SCREW (M1.4X2.5)	
703	X-3945-400-1	CASSETTE COMPARTMENT ASSY		709	3-727-176-01	WASHER	
704	3-965-587-03	SPRING, TENSION		710	3-971-076-01	FASTENER, D	
705	3-965-584-08	RETAINER, GOOSENECK		711	3-976-055-01	SCREW (M1.4X1)	
706	3-973-268-01	SPRING, TENSION					

## **6-1-5. LS CHASSIS BLOCK SECTION**



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
751	A-7040-419-A	BASE (S) BLOCK ASSY, GUIDE		773	3-965-648-01	SPRING (PINCH), TENSION	
752	A-7040-418-B	BASE (T) BLOCK ASSY, GUIDE		774	3-965-579-01	ROLLER, PINCH PRESS	
753	3-965-559-01	STOPPER (T)		775	3-965-563-01	GEAR, T SOFT	
754	3-965-557-01	STOPPER (T), GB		776	3-965-565-01	CLAW, T SOFT	
755	3-965-558-01	STOPPER (S)		777	X-3945-397-1	DECK ASSY, REEL, S	
756	3-965-556-01	STOPPER (S), GB		778	X-3945-396-1	BAND ASSY, TENSION REGULATOR	
757	3-965-553-01	RAIL, GUIDE		779	3-945-756-01	SCREW (M1.4X3)	
758	3-947-503-01	SCREW (M1.4X2.5)		780	3-965-583-01	ARM, RVS	
759	3-965-573-01	RETAINER, TG4		781	3-965-580-01	SPRING, TENSION	
760	1-658-213-11	FP-355 FLEXIBLE PRINT BOARD		782	3-966-384-01	SPRING, T SOFT	
761	3-965-552-01	HOLDER (T), SENSOR		783	3-965-578-01	SPRING, TENSION	
762	1-657-786-13	FP-221 FLEXIBLE BOARD		784	3-965-560-01	RATCHET, S	
763	3-965-551-01	HOLDER (S), SENSOR		785	3-965-561-01	PLATE, RELEASE, S RATCHET	
764	1-658-214-11	FP-356 FLEXIBLE PRINT BOARD		786	X-3945-395-1	ARM ASSY, TG1	
765	A-7040-417-A	ARM BLOCK ASSY, TG4		787	3-965-576-01	SPRING (TG1), TENSION	
766	3-965-574-01	SPRING, TORSION		788	3-965-567-01	LID OPEN	
767	3-965-575-01	SPRING (PINCH), TORSION		789	3-965-566-01	COVER, LS GUIDE	
768	3-965-568-01	GUIDE, LOCK		* 790	3-965-577-01	PLATE, CAM, LS	
769	3-965-562-01	SPRING (RATCHET), TENSION		791	3-965-569-01	ARM, EJ	
770	3-965-581-03	RATCHET, T		792	A-7040-427-A	CHASSIS (S1) ASSY, LS	
771	X-3945-394-1	ARM ASSY, PINCH		D001	8-719-988-42	DIODE GL453	
772	X-3945-398-1	DECK ASSY, REEL, T		S002	1-572-688-11	SWITCH, PUSH (1 KEY)(C.C.LOCK)	

## 6-1-6. MECHANISM CHASSIS BLOCK SECTION



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
801	X-3947-343-1	GROUND (IM) ASSY, SHAFT		822	3-965-535-01	SPRING, TENSION	
802	3-965-550-02	SCREW (M1.7X1.6)		823	3-965-542-01	SHIELD, MOTOR	
803	1-657-785-11	FP-248 FLEXIBLE BOARD		824	3-965-539-01	GEAR (A)	
804	3-965-545-01	SPACER, CAPSTAN		825	3-965-538-01	SLEEVE, MOTOR HOLDER	
805	3-965-549-01	SCREW (M1.4 X 6.5)		826	3-965-540-01	HOLDER, MOTOR	
806	3-966-349-01	HOLDER, FLEXIBLE		827	3-965-541-01	SHAFT, WORM	
807	3-971-644-01	SLIDER (2), M		828	3-321-393-01	WASHER, STOPPER	
808	3-965-588-11	SCREW (M1.4)		829	3-965-724-01	SPRING, TORSION	
809	3-947-503-01	SCREW (M1.4X2.5)		830	A-7040-423-A	ROLLER BLOCK ASSY, HC	
810	A-7040-416-A	BASE BLOCK ASSY, DRUM		831	X-3945-407-1	ARM ASSY, HC ROLLER	
811	3-965-527-01	GEAR, CHANGE		832	3-965-531-01	ARM, GL	
812	3-965-544-01	GEAR, RELAY		833	3-965-530-01	PLATE (2), REGULATOR, TENSION	
813	3-331-007-21	WASHER		834	X-3947-915-2	CHASSIS ASSY, MECHANICAL	
814	3-965-546-01	BELT, TIMING		835	3-965-526-02	ROLLER, LS GUIDE	
815	3-965-533-01	ROLLER, LS		836	3-965-547-01	ARM, HC DRIVING	
816	3-965-528-01	GEAR, CAM		837	3-965-534-01	PLATE, PRESS, PINCH	
817	1-657-784-11	FP-220 FLEXIBLE BOARD		M901	A-7048-849-A	DRUM BLOCK ASSY (DGH-0D4A-R)(NTSC)	
818	3-965-529-01	PLATE, REGULATOR, TENSION		M901	A-7048-859-A	DRUM BLOCK ASSY (DGH-0E0A-R)(PAL)	
819	3-965-536-01	SPRING, TENSION		M902	8-835-531-32	MOTOR, DC SCE-0601A/C-NP (CAPSTAN)	
820	X-3945-388-1	SLIDER ASSY, GL		M903	X-3945-401-1	MOTOR ASSY, DC (LOADING)	
821	3-965-532-01	ARM, LS		S901	1-762-436-15	SWITCH, ROTARY (ENCODER)	

## 6-2. ELECTRICAL PARTS LIST

### Note:

When indicating parts by reference number, please include the board name.

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.

• Items marked “\*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

• CAPACITORS:

uF:  $\mu$ F

• RESISTORS

All resistors are in ohms.

METAL: metal-film resistor

METAL OXIDE: Metal Oxide-film resistor

F: nonflammable

• COILS

uH:  $\mu$ H

• SEMICONDUCTORS

In each case, u:  $\mu$ , for example:

uA...:  $\mu$ A..., uPA...,  $\mu$ PA...,

uPB...:  $\mu$ PB...,  $\mu$ PC...,  $\mu$ PC...,

uPD...,  $\mu$ PD...

Ref. No.	Part No.	Description					Remarks	Ref. No.	Part No.	Description					Remarks
A-7073-362-A	DD-100 BOARD, COMPLETE	*****						C548	1-104-913-11	TANTAL. CHIP	10uF	20%	16V		
		(Ref.No.: 3,000 Series)						C549	1-104-913-11	TANTAL. CHIP	10uF	20%	16V		
		< CAPACITOR >						C550	1-164-506-11	CERAMIC CHIP	4.7uF		16V		
C501	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V		C551	1-164-489-11	CERAMIC CHIP	0.22uF	10%	16V			
C502	1-162-960-11	CERAMIC CHIP	220PF	10%	50V		C552	1-164-506-11	CERAMIC CHIP	4.7uF		16V			
C503	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V		C553	1-113-985-11	TANTAL. CHIP	10uF	20%	20V			
C504	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V		C554	1-104-913-11	TANTAL. CHIP	10uF	20%	16V			
C505	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V		< CONNECTOR >								
C506	1-162-967-11	CERAMIC CHIP	0.0033uF	10%	50V		CN501	1-569-775-21	PIN, CONNECTOR 5P						
C507	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V		CN502	1-691-520-11	CONNECTOR, BOARD TO BOARD 48P						
C508	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V		< DIODE >								
C509	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V		D501	8-719-057-68	DIODE	SBS001C-TB					
C510	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V		D502	8-719-057-68	DIODE	SBS001C-TB					
C511	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V		D503	8-719-057-68	DIODE	SBS001C-TB					
C512	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V		D504	8-719-057-68	DIODE	SBS001C-TB					
C513	1-162-967-11	CERAMIC CHIP	0.0033uF	10%	50V		D505	8-719-801-48	DIODE	1SS193					
C514	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V		D506	8-719-057-68	DIODE	SBS001C-TB					
C515	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V		D507	8-719-420-14	DIODE	MA8082-E					
C516	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V		D508	8-719-420-14	DIODE	MA8082-E					
C517	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V		D509	8-719-801-48	DIODE	1SS193					
C518	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V		D510	8-719-801-48	DIODE	1SS193					
C525	1-104-919-11	TANTAL. CHIP	10uF	20%	25V		< IC >								
C526	1-104-919-11	TANTAL. CHIP	10uF	20%	25V		IC501	8-759-350-29	IC	SN104213PM-T6					
C527	1-104-823-11	TANTAL. CHIP	47uF	20%	16V		IC502	8-759-281-13	IC	S-81250SG-QD-S					
C529	1-104-919-11	TANTAL. CHIP	10uF	20%	25V		< COIL >								
C530	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V		L501	1-424-653-11	COIL, CHOKE	10uH					
C531	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V		L502	1-424-653-11	COIL, CHOKE	10uH					
C532	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V		L503	1-424-653-11	COIL, CHOKE	10uH					
C533	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V		L504	1-424-674-11	COIL, CHOKE	22uH					
C534	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V		L505	1-424-675-11	COIL, CHOKE	33uH					
C535	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V		L506	1-424-674-11	COIL, CHOKE	22uH					
C536	1-104-913-11	TANTAL. CHIP	10uF	20%	16V		L507	1-424-674-11	COIL, CHOKE	22uH					
C537	1-104-913-11	TANTAL. CHIP	10uF	20%	16V		L508	1-414-396-21	INDUCTOR	4.7uH					
C538	1-104-913-11	TANTAL. CHIP	10uF	20%	16V		L509	1-414-396-21	INDUCTOR	4.7uH					
C539	1-164-506-11	CERAMIC CHIP	4.7uF		16V		L510	1-414-396-21	INDUCTOR	4.7uH					
C540	1-164-506-11	CERAMIC CHIP	4.7uF		16V		L511	1-414-406-11	INDUCTOR	220uH					
C541	1-113-992-11	TANTAL. CHIP	3.3uF	20%	35V		L512	1-424-674-11	COIL, CHOKE	22uH					
C542	1-104-919-11	TANTAL. CHIP	10uF	20%	25V		L513	1-414-400-11	INDUCTOR	22uH					
C543	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V		L514	1-414-396-21	INDUCTOR	4.7uH					
C544	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V		L515	1-414-396-21	INDUCTOR	4.7uH					
C545	1-104-913-11	TANTAL. CHIP	10uF	20%	16V										
C546	1-104-913-11	TANTAL. CHIP	10uF	20%	16V										
C547	1-104-913-11	TANTAL. CHIP	10uF	20%	16V										

DD-100

EX-34

FP-249

FP-355

FP-571

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
L516	1-414-396-21	INDUCTOR 4.7uH		R542	1-216-821-11	METAL CHIP 1K	5% 1/16W
L517	1-414-404-11	INDUCTOR 100uH		R548	1-216-295-11	CONDUCTOR, CHIP (2012)	
L518	1-414-404-11	INDUCTOR 100uH		R549	1-216-295-11	CONDUCTOR, CHIP (2012)	
L519	1-412-054-21	INDUCTOR CHIP 2.2uH		R550	1-216-295-11	CONDUCTOR, CHIP (2012)	
< IC LINK >				< TRANSFORMER >			
△PS501	1-533-760-21	FUSE (SMD) 1.4A		△T501	1-431-548-21	TRANSFORMER, DC-DC CONVERTER	
△PS502	1-533-760-21	FUSE (SMD) 1.4A		A-7073-364-A	EX-34 BOARD, COMPLETE		
△PS503	1-533-760-21	FUSE (SMD) 1.4A					*****
△PS504	1-533-760-21	FUSE (SMD) 1.4A					(Ref.No.: 3,000 Series)
< TRANSISTOR >				< CONNECTOR >			
Q501	8-729-039-86	TRANSISTOR FMMT717TA		CN203	1-770-542-21	CONNECTOR, FFC/FPC 40P	
Q502	8-729-039-86	TRANSISTOR FMMT717TA		CN204	1-537-439-11	TARMINAL BOARD, CONNECTOR	
Q503	8-729-039-86	TRANSISTOR FMMT717TA		< DIODE >			
Q504	8-729-039-86	TRANSISTOR FMMT717TA		D204	8-719-062-16	DIODE 01ZA8.2(TPL3)	
Q505	8-729-041-24	TRANSISTOR NDS355AN		D205	8-719-062-16	DIODE 01ZA8.2(TPL3)	
Q506	8-729-804-41	TRANSISTOR 2SB1122-S		FP-249 BOARD, COMPLETE			
Q507	8-729-039-86	TRANSISTOR FMMT717TA					*****
Q508	8-729-037-74	TRANSISTOR UN9213J-(TX).SO					(Ref.No.: 3,000 Series)
Q520	8-729-037-74	TRANSISTOR UN9213J-(TX).SO					
Q521	8-729-041-69	TRANSISTOR MMSF5P02HDR2		< RESISTOR >			
R501	1-216-841-11	METAL CHIP 47K	5% 1/16W	R502	1-216-837-11	METAL CHIP 22K	5% 1/16W
R503	1-216-839-11	METAL CHIP 33K	5% 1/16W	R504	1-216-833-11	METAL CHIP 10K	5% 1/16W
R505	1-218-907-11	METAL GLAZE 330K	0.50% 1/16W				1-658-214-11 FP-356 FLEXIBLE BOARD
R506	1-216-833-11	METAL CHIP 10K	5% 1/16W	R507	1-216-823-11	METAL CHIP 1.5K	5% 1/16W
R508	1-216-845-11	METAL CHIP 100K	5% 1/16W	R509	1-216-821-11	METAL CHIP 1K	5% 1/16W
R510	1-216-837-11	METAL CHIP 22K	5% 1/16W				3-965-551-01 HOLDER (S), SENSOR
R511	1-216-839-11	METAL CHIP 33K	5% 1/16W	R512	1-216-861-11	METAL CHIP 2.2M	5% 1/16W
R513	1-216-864-11	METAL CHIP 0	5% 1/16W	R514	1-216-837-11	METAL CHIP 22K	5% 1/16W
R515	1-216-837-11	METAL CHIP 22K	5% 1/16W				3-965-552-01 HOLDER (T), SENSOR
R516	1-216-839-11	METAL CHIP 33K	5% 1/16W	R517	1-216-834-11	METAL CHIP 12K	5% 1/16W
R518	1-216-837-11	METAL CHIP 22K	5% 1/16W	R519	1-216-839-11	METAL CHIP 33K	5% 1/16W
R520	1-216-845-11	METAL CHIP 100K	5% 1/16W				< HOLE ELEMENT >
R521	1-216-840-11	METAL CHIP 39K	5% 1/16W	R523	1-216-864-11	METAL CHIP 0	5% 1/16W
R525	1-216-864-11	METAL CHIP 0	5% 1/16W	R526	1-218-863-11	METAL GLAZE 4.7K	0.50% 1/16W
R527	1-218-883-11	METAL GLAZE 33K	0.50% 1/16W				< TRANSISTOR >
R528	1-216-841-11	METAL CHIP 47K	5% 1/16W	R529	1-218-869-11	METAL GLAZE 8.2K	0.50% 1/16W
R529	1-218-869-11	METAL GLAZE 8.2K	0.50% 1/16W	R532	1-216-864-11	METAL CHIP 0	5% 1/16W
R532	1-216-864-11	METAL CHIP 0	5% 1/16W	R533	1-216-864-11	METAL CHIP 0	5% 1/16W
R533	1-216-864-11	METAL CHIP 0	5% 1/16W	R535	1-216-864-11	METAL CHIP 0	5% 1/16W
R536	1-216-864-11	METAL CHIP 0	5% 1/16W				< SWITCH >
R537	1-216-845-11	METAL CHIP 100K	5% 1/16W	R538	1-216-857-11	METAL CHIP 1M	5% 1/16W
R538	1-216-857-11	METAL CHIP 1M	5% 1/16W	R540	1-216-797-11	METAL CHIP 10	5% 1/16W
R540	1-216-797-11	METAL CHIP 10	5% 1/16W	R541	1-216-864-11	METAL CHIP 0	5% 1/16W
R541	1-216-864-11	METAL CHIP 0	5% 1/16W				< BATTERY >
				BT001	1-528-724-21	BATTERY, V/L RICHARGEABL	

The components identified by mark △ or dotted line with mark △ are critical for safety.  
Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité.  
Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remarks			Ref. No.	Part No.	Description	Remarks		
	1-667-403-11	FP-574 FLEXIBLE BOARD ***** (Ref.No.: 3,000 Series)				D116	8-719-062-16	DIODE 01ZA8.2(TPL3)			
						D117	8-719-062-16	DIODE 01ZA8.2(TPL3)			
						D118	8-719-062-16	DIODE 01ZA8.2(TPL3)			
		< JACK >						< JACK >			
J001	1-695-514-21	JACK (SMALL TYPE) 1P (PHONES)				J102	1-537-747-31	TERMINAL BOARD (AUDIO/VIDEO LINE IN/OUT)			
	A-7073-328-A	IO-62 BOARD, COMPLETE (A500) *****				J103	1-566-850-31	CONNECTOR, (S) TERMINAL 4P (S VIDEO IN/OUT)			
	A-7073-365-A	IO-62 BOARD, COMPLETE (A500E) *****						< COIL >			
			(Ref.No.: 3,000 Series)			L101	1-414-072-11	INDUCTOR 1uH			
C101	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V (A500E)				L102	1-412-963-11	INDUCTOR 100uH (A500E)			
C102	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V (A500E)				L103	1-412-963-11	INDUCTOR 100uH (A500E)			
C103	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V (A500E)				L104	1-412-963-11	INDUCTOR 100uH (A500E)			
C104	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V (A500E)				L105	1-412-963-11	INDUCTOR 100uH			
C107	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V (A500E)				L106	1-412-963-11	INDUCTOR 100uH			
C110	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V (A500E)				L107	1-412-963-11	INDUCTOR 100uH			
C116	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V				L108	1-412-963-11	INDUCTOR 100uH			
C117	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V						< RESISTOR >			
C118	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V				R101	1-216-864-11	METAL CHIP 0 5% 1/16W (A500E)			
C119	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V				R102	1-216-864-11	METAL CHIP 0 5% 1/16W			
C120	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V				R105	1-216-864-11	METAL CHIP 0 5% 1/16W (A500E)			
C121	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V				R110	1-216-864-11	METAL CHIP 0 5% 1/16W			
C122	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V				R111	1-216-864-11	METAL CHIP 0 5% 1/16W			
C123	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V				R112	1-216-864-11	METAL CHIP 0 5% 1/16W			
C124	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V				R120	1-216-821-11	METAL CHIP 1K 5% 1/16W			
		< CONNECTOR >				R121	1-216-821-11	METAL CHIP 1K 5% 1/16W			
CN103	1-750-332-41	CONNECTOR, BOARD TO BOARD 48P				R124	1-216-824-11	METAL CHIP 1.8K 5% 1/16W			
CN104	1-573-371-21	CONNECTOR, BOARD TO BOARD 14P				R128	1-216-824-11	METAL CHIP 1.8K 5% 1/16W			
CN105	1-774-631-21	CONNECTOR, FFC/FPC 6P				R129	1-216-826-11	METAL CHIP 2.7K 5% 1/16W			
* CN106	1-695-320-21	PIN, CONNECTOR (1.5MM)(SMD) 2P				R130	1-216-829-11	METAL CHIP 4.7K 5% 1/16W			
		< DIODE >				R131	1-216-833-11	METAL CHIP 10K 5% 1/16W			
D101	8-719-062-16	DIODE 01ZA8.2(TPL3)				R132	1-216-817-11	METAL CHIP 470 5% 1/16W			
D102	8-719-062-16	DIODE 01ZA8.2(TPL3)				R133	1-216-864-11	METAL CHIP 0 5% 1/16W			
D103	8-719-420-14	DIODE MA8082-M				R134	1-216-864-11	METAL CHIP 0 5% 1/16W			
D104	8-719-062-16	DIODE 01ZA8.2(TPL3)						< SWITCH >			
D105	8-719-062-16	DIODE 01ZA8.2(TPL3)				S101	1-692-088-41	SWITCH, TACTILE (IR ON)			
D106	8-719-062-16	DIODE 01ZA8.2(TPL3)				S102	1-692-088-41	SWITCH, TACTILE (MENU)			
D107	8-719-062-16	DIODE 01ZA8.2(TPL3)				S103	1-692-088-41	SWITCH, TACTILE (BRIGHT +)			
D108	8-719-420-14	DIODE MA8082-TX				S104	1-692-088-41	SWITCH, TACTILE (BRIGHT -)			
D109	8-719-061-82	DIODE TLSU1002(TPX1,SONY)				S105	1-692-088-41	SWITCH, TACTILE (VOL +)			
D110	8-719-062-16	DIODE 01ZA8.2(TPL3)				S106	1-692-088-41	SWITCH, TACTILE (VOL -)			
D111	8-719-420-14	DIODE MA8082-M				S107	1-771-025-21	SWITCH, ROTARY (ENCODER)			
D112	8-719-420-14	DIODE MA8082-M									
D113	8-719-404-49	DIODE MA111									
D114	8-719-062-16	DIODE 01ZA8.2(TPL3)									
D115	8-719-062-16	DIODE 01ZA8.2(TPL3)									
		< CAPACITOR >									
						C382	1-135-181-21	TANTALUM CHIP 4.7uF 20% 6.3V			
						C392	1-107-826-11	CERAMIC CHIP 0.1uF 10% 16V			
						C393	1-109-982-11	CERAMIC CHIP 1uF 10% 10V			
	</										

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
< CONNECTOR >							
CN361	1-766-866-21	CONNECTOR, FFC/FPC 6P		C828	1-164-664-11	CERAMIC CHIP	0.033uF 10% 50V
< DIODE >							
D362	8-749-060-65	DIODE DCC3810		△C830	1-113-521-11	CERAMIC CHIP	12PF 10% 3KV
D363	8-719-061-86	DIODE DCR2810		C831	1-165-319-11	CERAMIC CHIP	0.1uF 50V
< FUSE >				C832	1-104-913-11	TANTAL. CHIP	10uF 20% 16V
△F361	1-533-874-11	FUSE, MICRO	200mA	C833	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V
< COIL >							
L363	1-414-078-11	INDUCTOR	10uH	C834	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V
< TRANSISTOR >				C835	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V
Q365	8-729-140-75	TRANSISTOR	2SD999-CLK	C836	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
< RESISTOR >				C838	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
R388	1-216-302-00	METAL CHIP	2.7	R389	1-216-311-00	METAL CHIP	6.8 5% 1/10W
R390	1-216-864-11	METAL CHIP	0	R392	1-216-801-11	METAL CHIP	22 5% 1/16W
< SWITCH >							
S361	1-572-467-21	SWITCH, PUSH (1 KEY) (P CLOSE)		D802	8-719-404-49	DIODE	MA111
< IC >				D803	8-713-102-80	DIODE	1T369-01-T8A
< COIL >				D804	8-713-102-80	DIODE	1T369-01-T8A
< IC >				D805	8-719-404-49	DIODE	MA111
< IC >				D808	8-719-404-49	DIODE	MA111
< COIL >							
A-7073-363-A PD-88 BOARD, COMPLETE							
*****							
(Ref. No.: 3,000 Series)							
< CAPACITOR >							
C801	1-104-914-11	TANTAL. CHIP	22uF	C802	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V
C803	1-162-970-11	CERAMIC CHIP	0.01uF	C804	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
C805	1-135-149-21	TANTALUM CHIP	2.2uF	C806	1-164-505-11	CERAMIC CHIP	2.2uF 16V
C807	1-162-918-11	CERAMIC CHIP	18PF	C808	1-164-227-11	CERAMIC CHIP	0.022uF 10% 25V
C809	1-162-970-11	CERAMIC CHIP	0.01uF	C810	1-135-214-21	TANTAL. CHIP	4.7uF 20%
C811	1-162-920-11	CERAMIC CHIP	27PF	C812	1-104-913-11	TANTAL. CHIP	10uF 20% 16V
C813	1-162-970-11	CERAMIC CHIP	0.01uF	C814	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V
C816	1-107-686-11	TANTAL. CHIP	4.7uF	C817	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V
C818	1-162-970-11	CERAMIC CHIP	0.01uF	C819	1-164-739-11	CERAMIC CHIP	560PF 5% 50V
C820	1-104-911-11	TANTAL. CHIP	33uF	C821	1-104-911-11	TANTAL. CHIP	33uF 20% 10V
C822	1-107-826-11	CERAMIC CHIP	0.1uF	C823	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
C824	1-162-964-11	CERAMIC CHIP	0.001uF	C825	1-162-926-11	CERAMIC CHIP	82PF 5% 50V
C826	1-107-826-11	CERAMIC CHIP	0.1uF	C827	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V
< RESISTOR >							
R804	1-216-843-11	METAL CHIP	68K	R805	1-216-837-11	METAL CHIP	22K 5% 1/16W
R806	1-216-841-11	METAL CHIP	47K	R807	1-216-864-11	METAL CHIP	0 5% 1/16W
R808	1-218-867-11	METAL GLAZE	6.8K 0.50%	R809	1-218-881-11	METAL GLAZE	27K 0.50% 1/16W
R810	1-216-818-11	METAL CHIP	560	R811	1-216-837-11	METAL CHIP	22K 5% 1/16W
R812	1-218-897-11	METAL GLAZE	120K 0.50%	R813	1-216-818-11	METAL CHIP	560 5% 1/16W

The components identified by mark △ or dotted line with mark △ are critical for safety.  
Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité.  
Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			Remarks
R814	1-216-833-11	METAL CHIP	10K	5%	1/16W	C013	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
R815	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	C014	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
R816	1-218-873-11	METAL GLAZE	12K	0.50%	1/16W	C015	1-164-346-11	CERAMIC CHIP	1uF	16V	
R817	1-218-891-11	METAL GLAZE	68K	0.50%	1/16W	C016	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
R818	1-218-883-11	METAL GLAZE	33K	0.50%	1/16W	C017	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
R819	1-218-857-11	METAL GLAZE	2.7K	0.50%	1/16W	C018	1-104-847-11	TANTAL. CHIP	22uF	20%	4V
R820	1-218-849-11	METAL GLAZE	1.2K	0.50%	1/16W	C020	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
R822	1-216-840-11	METAL CHIP	39K	5%	1/16W	C021	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
R826	1-216-864-11	METAL CHIP	0	5%	1/16W	C102	1-164-156-11	CERAMIC CHIP	0.1uF	25V	
R829	1-216-857-11	METAL CHIP	1M	5%	1/16W	C361	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R830	1-216-864-11	METAL CHIP	0	5%	1/16W	C362	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
R833	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	C363	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
R836	1-218-889-11	METAL GLAZE	56K	0.50%	1/16W	C365	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
R837	1-216-833-11	METAL CHIP	10K	5%	1/16W	C366	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R838	1-216-821-11	METAL CHIP	1K	5%	1/16W	C367	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V
R839	1-216-843-11	METAL CHIP	68K	5%	1/16W	C368	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V
R840	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	C369	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R841	1-216-843-11	METAL CHIP	68K	5%	1/16W	C370	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
R842	1-216-841-11	METAL CHIP	47K	5%	1/16W	C371	1-135-091-00	TANTALUM CHIP	1uF	20%	16V
R844	1-216-864-11	METAL CHIP	0	5%	1/16W	C372	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R845	1-216-857-11	METAL CHIP	1M	5%	1/16W	C373	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V
R846	1-216-837-11	METAL CHIP	22K	5%	1/16W	C374	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R848	1-216-833-11	METAL CHIP	10K	5%	1/16W	C375	1-164-668-11	CERAMIC CHIP	510PF	5%	50V
R849	1-216-055-00	METAL CHIP	1.8K	5%	1/10W	C376	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
R850	1-216-857-11	METAL CHIP	1M	5%	1/16W	C377	1-162-909-11	CERAMIC CHIP	4PF	0.25PF	50V
R851	1-216-845-11	METAL CHIP	100K	5%	1/16W	C378	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
R852	1-216-833-11	METAL CHIP	10K	5%	1/16W	C379	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
R853	1-216-055-00	METAL CHIP	1.8K	5%	1/10W	C380	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R855	1-216-837-11	METAL CHIP	22K	5%	1/16W	C381	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R856	1-216-864-11	METAL CHIP	0	5%	1/16W	C382	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R857	1-216-864-11	METAL CHIP	0	5%	1/16W	C383	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
R860	1-216-850-11	METAL CHIP	270K	5%	1/16W	C385	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R861	1-216-817-11	METAL CHIP	470	5%	1/16W	C386	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
R862	1-216-853-11	METAL CHIP	470K	5%	1/16W	C387	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
R863	1-216-810-11	METAL CHIP	120	5%	1/16W	C388	1-135-202-21	TANTAL. CHIP	22uF	20%	4V
R864	1-216-864-11	METAL CHIP	0	5%	1/16W	C389	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V
R865	1-216-841-11	METAL CHIP	47K	5%	1/16W	C390	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V
R866	1-216-864-11	METAL CHIP	0	5%	1/16W	C391	1-162-921-11	CERAMIC CHIP	33PF	5%	50V
R868	1-216-864-11	METAL CHIP	0	5%	1/16W	C392	1-162-922-11	CERAMIC CHIP	39PF	5%	50V
R869	1-216-864-11	METAL CHIP	0	5%	1/16W	C393	1-104-760-11	CERAMIC CHIP	0.047uF	10%	50V
R870	1-216-864-11	METAL CHIP	0	5%	1/16W	C394	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V
< TRANSFORMER >						C395	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
△T801	1-429-507-31	TRANSFORMER, INVERTER				C701	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
< CAPACITOR >						C702	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C002	1-104-908-11	TANTAL. CHIP	47uF	20%	4V	C703	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C003	1-104-908-11	TANTAL. CHIP	47uF	20%	4V	C704	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
C004	1-104-908-11	TANTAL. CHIP	47uF	20%	4V	C704	1-162-924-11	CERAMIC CHIP	56PF	5%	(A500E)
C005	1-104-908-11	TANTAL. CHIP	47uF	20%	4V	C705	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C010	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C706	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
						C707	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V
						C708	1-162-925-11	CERAMIC CHIP	68PF	5%	50V
						C709	1-164-156-11	CERAMIC CHIP	0.1uF	25V	
						C710	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
						C711	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
						C712	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V

The components identified by mark △ or dotted line with mark ▲ are critical for safety.  
Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité.  
Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			Remarks
C713	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V	C1012	1-164-217-11	CERAMIC CHIP	150PF	5%	50V
C714	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C1013	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C715	1-164-156-11	CERAMIC CHIP	0.1uF		25V	C1014	1-162-926-11	CERAMIC CHIP	82PF	5%	50V
C719	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1015	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C720	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	C1016	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C801	1-162-924-11	CERAMIC CHIP	56PF	5%	50V	C1017	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C802	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V	C1018	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C805	1-164-489-11	CERAMIC CHIP	0.22uF	10%	16V (A500E)	C1019	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (A500)
C806	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C1020	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C807	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	C1021	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (A500)
C808	1-113-682-11	TANTAL. CHIP	33uF	20%	10V	C1022	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (A500)
C809	1-113-682-11	TANTAL. CHIP	33uF	20%	10V	C1023	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (A500)
C810	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1024	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (A500)
C811	1-162-969-11	CERAMIC CHIP	0.0068uF	10%	25V	C1025	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C812	1-104-912-11	TANTAL. CHIP	3.3uF	20%	6.3V	C1026	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C813	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1027	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C815	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1028	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C817	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	C1029	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (A500)
C818	1-162-963-11	CERAMIC CHIP	680PF	10%	50V (A500E)	C1030	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C820	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1031	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C821	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (A500E)	C1032	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C823	1-163-809-11	CERAMIC CHIP	0.047uF	10%	25V	C1033	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C824	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	C1034	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
C825	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (A500E)	C1035	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C826	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V	C1036	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C828	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (A500E)	C1037	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C829	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (A500E)	C1039	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C830	1-162-922-11	CERAMIC CHIP	39PF	5%	50V (A500E)	C1040	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
C832	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1041	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C833	1-135-155-21	TANTALUM CHIP	4.7uF	10%	16V	C1042	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C834	1-107-682-11	CERAMIC CHIP	1uF	10%	16V	C1044	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (A500)
C835	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1045	1-162-961-11	CERAMIC CHIP	330PF	10%	50V
C836	1-107-682-11	CERAMIC CHIP	1uF	10%	16V	C1046	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (A500)
C837	1-107-682-11	CERAMIC CHIP	1uF	10%	16V	C1047	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C838	1-107-682-11	CERAMIC CHIP	1uF	10%	16V	C1048	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C841	1-107-725-11	CERAMIC CHIP	0.1uF	10%	16V	C1049	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C842	1-162-918-11	CERAMIC CHIP	18PF	5%	50V	C1050	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C845	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V (A500E)	C1051	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
C849	1-135-091-00	TANTALUM CHIP	1uF	20%	16V	C1052	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C850	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1053	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C852	1-216-864-11	METAL CHIP	0	5%	1/16W	C1054	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C902	1-135-214-21	TANTAL. CHIP	4.7uF	20%	20V	C1058	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C908	1-113-992-11	TANTAL. CHIP	3.3uF	20%	35V	C1060	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C909	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1063	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1001	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V (A500E)	C1065	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V
C1002	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V (A500E)	C1068	1-164-217-11	CERAMIC CHIP	150PF	5%	50V
C1005	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1070	1-162-925-11	CERAMIC CHIP	68PF	5%	50V
C1007	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1071	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1009	1-104-752-11	TANTAL. CHIP	33uF	20%	6.3V	C1073	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V
C1011	1-104-752-11	TANTAL. CHIP	33uF	20%	6.3V	C1074	1-162-926-11	CERAMIC CHIP	82PF	5%	50V

Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			Remarks
C1076	1-162-967-11	CERAMIC CHIP	0.0033uF	10%	50V	C1213	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
C1077	1-162-958-11	CERAMIC CHIP	270PF	5%	50V	C1215	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
C1078	1-162-908-11	CERAMIC CHIP	3PF	0.25PF	50V	C1216	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1080	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1217	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
C1081	1-162-921-11	CERAMIC CHIP	33PF	5%	50V	C1218	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1083	1-162-958-11	CERAMIC CHIP	270PF	5%	50V	C1220	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V
C1084	1-162-959-11	CERAMIC CHIP	330PF	5%	50V	C1222	1-115-156-11	CERAMIC CHIP	1uF	10%	10V
C1085	1-162-921-11	CERAMIC CHIP	33PF	5%	50V	C1223	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1086	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V	C1224	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
C1087	1-162-921-11	CERAMIC CHIP	33PF	5%	50V	C1227	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
					(A500)	C1228	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C1087	1-162-922-11	CERAMIC CHIP	39PF	5%	50V	C1229	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
					(A500E)	C1230	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C1089	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	C1231	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V
C1090	1-162-922-11	CERAMIC CHIP	39PF	5%	50V	C1232	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V
C1090	1-162-925-11	CERAMIC CHIP	68PF	5%	50V	C1233	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
					(A500E)	C1234	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1091	1-162-920-11	CERAMIC CHIP	27PF	5%	50V	C1236	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1092	1-162-918-11	CERAMIC CHIP	18PF	5%	50V	C1237	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
C1093	1-162-907-11	CERAMIC CHIP	2PF	0.25PF	50V	C1240	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1094	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V	C1280	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V
C1095	1-162-921-11	CERAMIC CHIP	33PF	5%	50V	C1282	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
					(A500E)	C1283	1-162-922-11	CERAMIC CHIP	39PF	5%	50V
C1095	1-162-922-11	CERAMIC CHIP	39PF	5%	50V	C1285	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
					(A500)	C1301	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1096	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1302	1-104-852-11	TANTAL. CHIP	22uF	20%	6.3V
C1097	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1306	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1140	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1307	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C1141	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C1308	1-135-180-21	TANTALUM CHIP	3.3uF	20%	6.3V
C1144	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1309	1-135-180-21	TANTALUM CHIP	3.3uF	20%	6.3V
C1147	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V	C1310	1-164-677-11	CERAMIC CHIP	0.033uF	10%	16V
C1149	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1311	1-164-489-11	CERAMIC CHIP	0.22uF	10%	16V
C1150	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C1312	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1152	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	C1313	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1153	1-164-217-11	CERAMIC CHIP	150PF	5%	50V	C1314	1-135-180-21	TANTALUM CHIP	3.3uF	20%	6.3V
C1154	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	C1315	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1155	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1316	1-135-180-21	TANTALUM CHIP	3.3uF	20%	6.3V
C1156	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1317	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
C1158	1-115-156-11	CERAMIC CHIP	1uF		10V	C1318	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C1160	1-115-156-11	CERAMIC CHIP	1uF		10V	C1319	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1161	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1320	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1162	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1321	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1163	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1322	1-110-501-11	CERAMIC CHIP	0.33uF	10%	16V
C1164	1-164-156-11	CERAMIC CHIP	0.1uF		25V	C1323	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C1165	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C1324	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C1166	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1326	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C1167	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1327	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1168	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1328	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
C1173	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C1329	1-135-180-21	TANTALUM CHIP	3.3uF	20%	6.3V
					(A500)	C1330	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1201	1-162-965-11	CERAMIC CHIP	0.0015uF	10%	50V	C1331	1-135-149-21	TANTALUM CHIP	2.2uF	20%	10V
C1202	1-162-908-11	CERAMIC CHIP	3PF	0.25PF	50V	C1332	1-113-996-11	TANTAL. CHIP	220uF	20%	4V
C1203	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V	C1333	1-113-996-11	TANTAL. CHIP	220uF	20%	4V
C1204	1-164-392-11	CERAMIC CHIP	390PF	5%	50V	C1334	1-135-149-21	TANTALUM CHIP	2.2uF	20%	10V
C1205	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1335	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
C1206	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	C1336	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1207	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1337	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
C1208	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1338	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1209	1-164-156-11	CERAMIC CHIP	0.1uF		25V	C1339	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
C1210	1-115-156-11	CERAMIC CHIP	1uF		10V	C1340	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1212	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V						

Ref. No.	Part No.	Description		Remarks	Ref. No.	Part No.	Description		Remarks		
C1341	1-162-920-11	CERAMIC CHIP	27PF	5%	50V	C1453	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V
C1342	1-162-928-11	CERAMIC CHIP	120PF	5%	50V (A500E)	C1463	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
C1342	1-164-217-11	CERAMIC CHIP	150PF	5%	50V (A500)	C1465	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V
C1343	1-162-920-11	CERAMIC CHIP	27PF	5%	50V (A500E)	C1466	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V
C1343	1-162-922-11	CERAMIC CHIP	39PF	5%	50V (A500)	C1468	1-163-009-11	CERAMIC CHIP	0.001uF	10%	50V
C1344	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V (A500)	C1477	1-104-913-11	TANTAL. CHIP	10uF	20%	16V
C1345	1-162-917-11	CERAMIC CHIP	15PF	5%	50V	C1481	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C1346	1-164-360-11	CERAMIC CHIP	0.1uF		16V	C1488	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
C1347	1-162-957-11	CERAMIC CHIP	220PF	5%	50V	C1489	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
C1350	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V (A500)	C1490	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1351	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1492	1-162-925-11	CERAMIC CHIP	68PF	5%	50V
C1352	1-115-156-11	CERAMIC CHIP	1uF		10V (A500)	C1616	1-162-911-11	CERAMIC CHIP	6PF	0.5PF	50V
C1353	1-164-156-11	CERAMIC CHIP	0.1uF		25V (A500)	C1618	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C1354	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V	C1619	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C1355	1-164-360-11	CERAMIC CHIP	0.1uF		16V	C1620	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V
C1356	1-104-851-11	TANTAL. CHIP	10uF	20%	10V	C1621	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C1357	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	C1622	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C1358	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V	C1624	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C1359	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	C1625	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
C1360	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1635	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1361	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C1637	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C1362	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1638	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C1363	1-104-852-11	TANTAL. CHIP	22uF	20%	6.3V	C1639	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C1364	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1640	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C1366	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V	C1641	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C1370	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	C1642	1-135-091-00	TANTALUM CHIP	1uF	20%	16V
C1403	1-135-151-21	TANTALUM CHIP	4.7uF	20%	4V	C1645	1-162-917-11	CERAMIC CHIP	15PF	5%	50V
C1404	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V	C1646	1-162-917-11	CERAMIC CHIP	15PF	5%	50V
C1405	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C1647	1-164-156-11	CERAMIC CHIP	0.1uF	25%	
C1406	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	C1648	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
C1407	1-104-847-11	TANTAL. CHIP	22uF	20%	4V	C1702	1-115-156-11	CERAMIC CHIP	1uF		10V
C1409	1-135-145-11	TANTALUM CHIP	0.47uF	10%	35V	C1752	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C1410	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1753	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C1411	1-162-963-11	CERAMIC CHIP	680PF	10%	50V	C1754	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1412	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C1755	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V
C1414	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C1756	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V
C1415	1-164-182-11	CERAMIC CHIP	0.0033uF	10%	50V	C1757	1-162-969-11	CERAMIC CHIP	0.0068uF	10%	25V
C1416	1-135-145-11	TANTALUM CHIP	0.47uF	10%	35V	C1758	1-162-969-11	CERAMIC CHIP	0.0068uF	10%	25V
C1422	1-104-847-11	TANTAL. CHIP	22uF	20%	4V	C1759	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1423	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	C1760	1-164-156-11	CERAMIC CHIP	0.1uF		(A500E)
C1424	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C1761	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V
C1425	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V	C1762	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V
C1426	1-104-913-11	TANTAL. CHIP	10uF	20%	16V	C1763	1-162-911-11	CERAMIC CHIP	6PF	0.5PF	50V
C1430	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C1764	1-104-847-11	TANTAL. CHIP	22uF	20%	4V
C1431	1-135-151-21	TANTALUM CHIP	4.7uF	20%	4V	C1765	1-104-847-11	TANTAL. CHIP	22uF	20%	4V
C1432	1-104-908-11	TANTAL. CHIP	47uF	20%	4V	C1768	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1433	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C1769	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1435	1-104-752-11	TANTAL. CHIP	33uF	20%	6.3V	C1770	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C1437	1-104-847-11	TANTAL. CHIP	22uF	20%	4V	C1771	1-162-957-11	CERAMIC CHIP	220PF	5%	50V
C1439	1-104-852-11	TANTAL. CHIP	22uF	20%	6.3V	C1772	1-162-957-11	CERAMIC CHIP	220PF	5%	50V
C1441	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C1773	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1444	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C1774	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1450	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	C1775	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1451	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	C1776	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V
C1452	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	C1777	1-164-156-11	CERAMIC CHIP	0.1uF		25V
					C1779	1-164-156-11	CERAMIC CHIP	0.1uF		25V	
					C1781	1-164-489-11	CERAMIC CHIP	0.22uF	10%	16V	
					C1851	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	
					C1852	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	
					C1853	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	

Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description		Remarks	
C1854	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V	C1992	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C1855	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V			< CONNECTOR >			
C1856	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V	CN101	1-691-354-21	CONNECTOR, FFC/FPC (ZIF) 16P			
C1857	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V	CN102	1-774-639-21	CONNECTOR, FFC/FPC 15P			
C1858	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	CN103	1-766-673-21	CONNECTOR, FFC/FPC 12P			
C1859	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	CN104	1-691-348-11	CONNECTOR, FFC/FPC (ZIF) 10P			
C1860	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	CN105	1-766-619-11	CONNECTOR, FFC/FPC 8P			
C1861	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	CN106	1-691-542-21	CONNECTOR, BOARD TO BOARD 48P			
C1862	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V	CN107	1-778-597-21	CONNECTOR, BOARD TO BOARD 50P			
C1863	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V	CN108	1-691-374-11	CONNECTOR, FFC/FPC 10P			
C1864	1-107-682-11	CERAMIC CHIP	1uF	10%	16V	CN109	1-770-543-21	CONNECTOR, FFC/FPC 40P			
C1865	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	CN110	1-766-340-21	CONNECTOR, FFC/FPC 10P			
C1866	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V	CN111	1-766-759-11	CONNECTOR, FFC/FPC 4P			
C1867	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V	CN112	1-774-932-21	CONNECTOR, FFC/FPC (ZIF) 32P			
C1868	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	CN207	1-766-677-21	CONNECTOR, FFC/FPC 16P			
C1869	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V	CN802	1-764-708-21	CONNECTOR, FFC/FPC (LIF) 9P			
C1870	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V			< DIODE >			
C1871	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	D001	8-719-062-16	DIODE 01ZA8.2(TPL3)			
C1872	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	D101	8-719-062-16	DIODE 01ZA8.2(TPL3)			
C1873	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V	D102	8-719-062-16	DIODE 01ZA8.2(TPL3)			
C1874	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V	D103	8-719-062-16	DIODE 01ZA8.2(TPL3)			
C1875	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V	D104	8-719-062-16	DIODE 01ZA8.2(TPL3)			
C1876	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V	D105	8-719-062-16	DIODE 01ZA8.2(TPL3)			
C1877	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V	D106	8-719-062-16	DIODE 01ZA8.2(TPL3)			
C1878	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V	D107	8-719-062-16	DIODE 01ZA8.2(TPL3)			
C1879	1-164-156-11	CERAMIC CHIP	0.1uF		25V	D108	8-719-062-16	DIODE 01ZA8.2(TPL3)			
C1880	1-164-156-11	CERAMIC CHIP	0.1uF		25V	D109	8-719-062-16	DIODE 01ZA8.2(TPL3)			
C1881	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	D110	8-719-041-31	DIODE 015Z12-TPH3			
C1882	1-164-156-11	CERAMIC CHIP	0.1uF		25V	D111	8-719-062-16	DIODE 01ZA8.2(TPL3)			
C1884	1-164-156-11	CERAMIC CHIP	0.1uF		25V	D112	8-719-062-16	DIODE 01ZA8.2(TPL3)			
C1886	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	D113	8-719-041-31	DIODE 015Z12-TPH3			
C1887	1-162-957-11	CERAMIC CHIP	220PF	5%	50V	D114	8-719-062-16	DIODE 01ZA8.2(TPL3)			
C1888	1-164-156-11	CERAMIC CHIP	0.1uF		25V	D116	8-719-421-27	DIODE MA728			
C1890	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V	D801	8-713-102-80	DIODE 1T369-01-T8A (A500E)			
C1891	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V	D1201	8-719-055-86	DIODE KV1470TL1-3			
C1893	1-164-362-11	CERAMIC CHIP	470PF	5%	50V	D1202	8-719-055-86	DIODE KV1470TL1-3			
C1951	1-135-091-00	TANTALUM CHIP	1uF	20%	16V	D1305	8-719-404-49	DIODE MA111 (A500)			
C1952	1-164-156-11	CERAMIC CHIP	0.1uF		25V	D1306	8-719-404-49	DIODE MA111(A500)			
C1953	1-164-156-11	CERAMIC CHIP	0.1uF		25V	D1602	8-713-102-28	DIODE 1T379-04-T8A			
C1954	1-115-156-11	CERAMIC CHIP	1uF		10V	D1851	8-719-404-49	DIODE MA111			
C1955	1-164-156-11	CERAMIC CHIP	0.1uF		25V	D1951	8-719-404-49	DIODE MA111			
C1957	1-104-847-11	TANTAL. CHIP	22uF	20%	4V	D1952	8-719-404-49	DIODE MA111			
C1958	1-164-156-11	CERAMIC CHIP	0.1uF		25V	D1953	8-719-404-49	DIODE MA111			
C1959	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V	D1954	8-719-420-51	DIODE MA729			
C1960	1-115-156-11	CERAMIC CHIP	1uF		10V	D1955	8-719-420-51	DIODE MA729			
C1962	1-164-156-11	CERAMIC CHIP	0.1uF		25V	D1956	8-719-421-27	DIODE MA728			
C1965	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	D1957	8-719-404-49	DIODE MA111			
C1968	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	D1959	8-719-420-14	DIODE MA8082-M			
C1971	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V			< FERRITE BEAD >			
C1974	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V						
C1976	1-162-917-11	CERAMIC CHIP	15PF	5%	50V	FB1151	1-500-284-21	INDUCTOR, FERRITE BEAD			
C1978	1-164-156-11	CERAMIC CHIP	0.1uF		25V	FB1305	1-543-955-11	BEAD, FERRITE (CHIP)			
C1980	1-164-156-11	CERAMIC CHIP	0.1uF		25V	FB1601	1-500-284-21	INDUCTOR, FERRITE BEAD			
C1981	1-164-156-11	CERAMIC CHIP	0.1uF		25V	FB1602	1-500-284-21	INDUCTOR, FERRITE BEAD			
C1982	1-162-919-11	CERAMIC CHIP	22PF	5%	50V	FB1603	1-414-228-11	INDUCTOR, FERRITE BEAD			
C1986	1-164-156-11	CERAMIC CHIP	0.1uF		25V	FB1701	1-414-228-11	INDUCTOR, FERRITE BEAD			
C1987	1-104-851-11	TANTAL. CHIP	10uF	20%	10V						
C1989	1-164-156-11	CERAMIC CHIP	0.1uF		25V						
C1990	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V						
C1991	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V						

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks				
< IC >											
IC001	8-759-456-30	IC BA7787FS-E2		L1004	1-414-406-11	INDUCTOR 220uH					
IC101	8-752-070-64	IC CXA1702AR		L1005	1-414-398-11	INDUCTOR 10uH					
IC102	8-759-447-79	IC MB87B121PFV-G-BND-E		L1006	1-412-948-11	INDUCTOR 5.6uH					
IC103	8-752-356-45	IC CXD2301Q		L1007	1-410-656-11	INDUCTOR CHIP 150uH					
IC104	8-759-454-36	IC uPD6466GS-622-GLG-E2		L1008	1-412-963-11	INDUCTOR 100uH					
IC105	8-759-457-06	IC M65510FP-600D		L1009	1-412-282-41	INDUCTOR 470uH					
IC106	8-759-435-29	IC HG51CS296TE TL		L1010	1-412-957-11	INDUCTOR 33uH					
IC108	8-759-169-02	IC MB88344BPV-G-BND-ER		L1011	1-412-280-31	INDUCTOR 330uH					
IC109	8-752-069-26	IC CXA1737R		L1012	1-410-657-21	INDUCTOR CHIP 180uH					
IC111	8-759-349-01	IC MC68HC68VBIFB		L1013	1-410-656-11	INDUCTOR CHIP 150uH					
IC112	8-759-327-60	IC TC7W125FU-TE12R		L1014	1-412-956-21	INDUCTOR 27uH					
IC113	8-759-398-90	IC S-81236PG-P7-T1		L1015	1-412-280-31	INDUCTOR 330uH					
IC114	8-752-384-82	IC CXD3119R		L1017	1-412-949-21	INDUCTOR 6.8uH					
IC116	8-759-445-94	IC AK6480AM-E2		L1018	1-412-951-11	INDUCTOR 10uH					
IC117	8-752-889-21	IC CXP913040-005R		L1019	1-412-944-11	INDUCTOR 2.7uH					
IC119	8-759-058-62	IC TC7S08FU(TE85R)		L1020	1-414-754-11	INDUCTOR 10uH					
IC120	8-752-078-49	IC CXA1814AQ		L1151	1-414-754-11	INDUCTOR 10uH					
IC121	8-759-327-67	IC LB1950V-TLM		L1154	1-414-754-11	INDUCTOR 10uH					
IC122	8-759-327-61	IC LB8112V-TLM		L1201	1-414-754-11	INDUCTOR 10uH					
IC129	8-759-357-63	IC AN2220FH-EB		L1202	1-414-754-11	INDUCTOR 10uH					
IC130	8-759-058-58	IC TC7S04FU(TE85R)		L1203	1-414-754-11	INDUCTOR 10uH					
IC131	8-759-822-99	IC L88MS05T-FA		L1204	1-412-945-11	INDUCTOR 3.3uH					
IC203	8-759-462-43	IC AD9800JCSTRL		L1206	1-414-754-11	INDUCTOR 10uH					
IC204	8-759-243-19	IC TC7SU04F		L1207	1-414-078-11	INDUCTOR 10uH					
IC205	8-759-447-77	IC TC7WH74FU(TR12R)		L1209	1-414-754-11	INDUCTOR 10uH					
IC206	8-759-327-60	IC TC7W125FU-TE12R		L1220	1-412-955-11	INDUCTOR 22uH					
IC361	8-759-474-38	IC LA9510W-B-TBM		L1301	1-414-078-11	INDUCTOR 10uH					
IC701	8-759-421-52	IC MB87B110CPV-G-BND-E		L1303	1-412-937-11	INDUCTOR 0.68uH (A500E)					
IC801	8-752-070-03	IC CXA1785AR-T4		L1303	1-412-939-11	INDUCTOR 1uH (A500)					
IC802	8-759-427-85	IC MB88146APV-G-BND-E		L1305	1-414-754-11	INDUCTOR 10uH					
IC803	8-759-079-52	IC TC74VHC08FS(EL)		L1306	1-414-754-11	INDUCTOR 10uH					
IC804	8-759-196-97	IC TC7SH32FU-TE85R		L1307	1-414-754-11	INDUCTOR 10uH					
IC805	8-759-082-60	IC TC7S66FU(A500E)		L1308	1-412-959-11	INDUCTOR 47uH					
IC1951	8-759-298-10	IC S-8423NFS-T2		L1309	1-414-072-11	INDUCTOR 1uH					
IC1952	8-759-483-53	IC S579GDX4000PZ-TEB		L1310	1-414-754-11	INDUCTOR 10uH					
IC1995	8-759-059-05	IC TL1596CPW		L1311	1-412-959-11	INDUCTOR 47uH					
< COIL >											
L362	1-412-948-11	INDUCTOR 5.6uH		L1312	1-414-754-11	INDUCTOR 10uH					
L363	1-412-957-11	INDUCTOR 33uH		L1313	1-414-754-11	INDUCTOR 10uH					
L364	1-412-957-11	INDUCTOR 33uH		L1603	1-414-398-11	INDUCTOR 10uH					
L365	1-412-951-11	INDUCTOR 10uH		L1604	1-412-955-11	INDUCTOR 22uH					
L701	1-414-754-11	INDUCTOR 10uH		L1751	1-414-754-11	INDUCTOR 10uH					
L702	1-412-950-11	INDUCTOR 8.2uH		L1752	1-414-754-11	INDUCTOR 10uH					
L703	1-414-754-11	INDUCTOR 10uH		L1753	1-414-754-11	INDUCTOR 10uH					
L704	1-414-754-11	INDUCTOR 10uH		L1754	1-412-961-11	INDUCTOR 68uH					
L705	1-410-658-31	INDUCTOR CHIP 220uH		L1755	1-414-757-11	INDUCTOR 100uH (A500E)					
L801	1-412-963-11	INDUCTOR 100uH		L1951	1-414-754-11	INDUCTOR 10uH					
L802	1-412-962-11	INDUCTOR 82uH		< TRANSISTOR >							
L803	1-414-755-11	INDUCTOR 22uH		Q001	8-729-037-78	TRANSISTOR UN9217J-(TX).SO					
L804	1-412-956-21	INDUCTOR 27uH (A500E)		Q002	8-729-037-74	TRANSISTOR UN9213J-(TX).SO					
L805	1-414-754-11	INDUCTOR 10uH		Q003	8-729-037-74	TRANSISTOR UN9213J-(TX).SO					
L901	1-216-295-11	CONDUCTOR, CHIP (2012)		Q004	8-729-037-74	TRANSISTOR UN9213J-(TX).SO					
L902	1-216-295-11	CONDUCTOR, CHIP (2012)		Q007	8-729-037-52	TRANSISTOR 2SD2216J-QR(TX).SO					
L903	1-414-754-11	INDUCTOR 10uH		Q008	8-729-013-60	TRANSISTOR RN1110-TE85L					
L904	1-216-295-11	CONDUCTOR, CHIP (2012)		Q009	8-729-013-60	TRANSISTOR RN1110-TE85L					
L1002	1-414-406-11	INDUCTOR 220uH		Q010	8-729-037-52	TRANSISTOR 2SD2216J-QR(TX).SO					
L1003	1-412-952-11	INDUCTOR 12uH		Q351	8-729-037-74	TRANSISTOR UN9213J-(TX).SO					
				Q352	8-729-122-63	TRANSISTOR 2SA1226					

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks		
Q353	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO	Q1221	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO		
Q701	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	Q1305	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO		
Q702	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	Q1306	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO		
Q703	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	Q1307	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO		
Q704	8-729-037-59	TRANSISTOR	UN9111J-(TX).SO	Q1309	8-729-425-64	TRANSISTOR	2SC4738-YGR-TE85L		
Q705	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	Q1350	8-729-037-61	TRANSISTOR	UN9113J-(TX).SO		
Q801	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	Q1351	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO (A500)		
Q802	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO	Q1352	8-729-040-77	TRANSISTOR	2SC5376-B(TE85L)		
Q803	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO	Q1353	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO (A500)		
Q804	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO	Q1354	8-729-040-77	TRANSISTOR	2SC5376-B(TE85L)		
Q805	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO (A500E)	Q1355	8-729-040-77	TRANSISTOR	2SC5376-B(TE85L)		
Q806	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO (A500E)	Q1356	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO (A500)		
Q808	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO	Q1357	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO (A500)		
Q811	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO	Q1358	8-729-425-64	TRANSISTOR	2SC4738-YGR-TE85L		
Q813	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO	Q1359	8-729-101-07	TRANSISTOR	2SB798-DL		
Q814	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO (A500E)	Q1360	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO		
Q1001	8-729-031-69	TRANSISTOR	2SA1965-TL	Q1361	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO		
Q1002	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO	Q1362	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO		
Q1003	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO	Q1363	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO		
Q1004	8-729-031-69	TRANSISTOR	2SA1965-TL (A500)	Q1486	8-729-013-60	TRANSISTOR	RN1110-TE85L		
Q1005	8-729-031-69	TRANSISTOR	2SA1965-TL (A500)	Q1487	8-729-013-60	TRANSISTOR	RN1110-TE85L		
Q1006	8-729-031-69	TRANSISTOR	2SA1965-TL (A500)	Q1488	8-729-037-63	TRANSISTOR	UN9115J-(TX).SO		
Q1007	8-729-031-69	TRANSISTOR	2SA1965-TL (A500)	Q1489	8-729-013-60	TRANSISTOR	RN1110-TE85L		
Q1008	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	Q1490	8-729-013-60	TRANSISTOR	RN1110-TE85L		
Q1009	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO (A500)	Q1491	8-729-037-76	TRANSISTOR	UN9215J-(TX).SO		
Q1010	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO (A500)	Q1492	8-729-037-76	TRANSISTOR	UN9215J-(TX).SO		
Q1011	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO (A500)	Q1493	8-729-037-61	TRANSISTOR	UN9113J-(TX).SO		
Q1012	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO (A500)	Q1494	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO		
Q1014	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO	Q1605	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO		
Q1015	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO	Q1751	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO (A500)		
Q1016	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	Q1752	8-729-037-89	TRANSISTOR	2SC4627J-C(TX).SO (A500E)		
Q1018	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO (A500E)	Q1753	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO (A500E)		
Q1025	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	Q1851	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO		
Q1026	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	Q1852	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO		
Q1028	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	Q1854	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO		
Q1029	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	Q1855	8-729-039-87	TRANSISTOR	NDS356P		
Q1030	8-729-037-89	TRANSISTOR	2SC4627J-C(TX).SO	Q1856	8-729-039-87	TRANSISTOR	NDS356P		
Q1033	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO	Q1857	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO		
Q1034	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO	Q1858	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO		
Q1036	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO	Q1862	8-729-037-59	TRANSISTOR	UN9111J-(TX).SO		
Q1037	8-729-037-89	TRANSISTOR	2SC4627J-C(TX).SO	Q1863	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO		
Q1038	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO	Q1951	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO		
Q1040	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO	Q1952	8-729-040-77	TRANSISTOR	2SC5376-B(TE85L)		
Q1041	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	Q1953	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO		
Q1043	8-729-807-86	TRANSISTOR	2SB1295-UL5	Q1954	8-729-032-00	TRANSISTOR	2SJ381-TD		
Q1044	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO	Q1955	8-729-037-72	TRANSISTOR	UN9213J-(TX).SO		
Q1045	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO	Q1956	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO		
Q1100	8-729-031-69	TRANSISTOR	2SA1965-TL (A500)	Q1957	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO		
Q1135	8-729-037-89	TRANSISTOR	2SC4627J-C(TX).SO	Q1959	8-729-032-62	TRANSISTOR	2SJ347-TE85L		
Q1136	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO	Q1960	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO		
Q1138	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO	Q1961	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO		
Q1139	8-729-031-69	TRANSISTOR	2SA1965-TL	Q1963	8-729-024-48	TRANSISTOR	2SK1830-TE85L		
Q1140	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO	< RESISTOR >					
Q1141	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	R005	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
Q1150	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	R006	1-216-832-11	METAL CHIP	8.2K	5%	1/16W
Q1151	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	R007	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
Q1201	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO	R010	1-202-924-11	METAL GLAZE	240	5%	1/16W
Q1202	8-729-037-53	TRANSISTOR	2SB1462J-QR(TX).SO	R011	1-216-832-11	METAL CHIP	8.2K	5%	1/16W
Q1203	8-729-037-52	TRANSISTOR	2SD2216J-QR(TX).SO						
Q1220	8-729-037-74	TRANSISTOR	UN9213J-(TX).SO						

Ref. No.	Part No.	Description		Remarks	Ref. No.	Part No.	Description		Remarks		
R012	1-202-924-11	METAL GLAZE	240	5%	1/16W	R706	1-216-845-11	METAL CHIP	100K	5%	1/16W
R015	1-216-809-11	METAL CHIP	100	5%	1/16W	R707	1-216-824-11	METAL CHIP	1.8K	5%	(A500)
R016	1-216-809-11	METAL CHIP	100	5%	1/16W	R708	1-216-816-11	METAL CHIP	390	5%	1/16W
R017	1-216-821-11	METAL CHIP	1K	5%	1/16W	R709	1-216-821-11	METAL CHIP	1K	5%	1/16W
R018	1-216-821-11	METAL CHIP	1K	5%	1/16W	R710	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
R027	1-216-864-11	METAL CHIP	0	5%	1/16W	R711	1-216-820-11	METAL CHIP	820	5%	1/16W
R031	1-216-864-11	METAL CHIP	0	5%	1/16W	R712	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
R032	1-216-826-11	METAL CHIP	2.7K	5%	1/16W	R713	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R034	1-216-849-11	METAL CHIP	220K	5%	1/16W	R714	1-216-833-11	METAL CHIP	10K	5%	1/16W
R046	1-216-834-11	METAL CHIP	12K	5%	1/16W	R715	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R047	1-216-834-11	METAL CHIP	12K	5%	1/16W	R716	1-216-819-11	METAL CHIP	680	5%	1/16W
R049	1-216-837-11	METAL CHIP	22K	5%	1/16W	R717	1-216-821-11	METAL CHIP	1K	5%	1/16W
R050	1-216-837-11	METAL CHIP	22K	5%	1/16W	R718	1-216-812-11	METAL CHIP	180	5%	1/16W
R051	1-216-845-11	METAL CHIP	100K	5%	1/16W	R719	1-216-821-11	METAL CHIP	1K	5%	1/16W
R052	1-216-845-11	METAL CHIP	100K	5%	1/16W	R720	1-216-816-11	METAL CHIP	390	5%	1/16W
R055	1-216-845-11	METAL CHIP	100K	5%	1/16W	R721	1-216-817-11	METAL CHIP	470	5%	1/16W
R066	1-216-836-11	METAL CHIP	18K	5%	1/16W	R722	1-216-821-11	METAL CHIP	1K	5%	1/16W
R067	1-216-834-11	METAL CHIP	12K	5%	1/16W	R723	1-216-821-11	METAL CHIP	1K	5%	1/16W
R068	1-216-852-11	METAL CHIP	390K	5%	1/16W	R724	1-216-821-11	METAL CHIP	1K	5%	1/16W
R101	1-216-804-11	METAL CHIP	39	5%	1/16W	R725	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R102	1-216-864-11	METAL CHIP	0	5%	1/16W	R726	1-216-821-11	METAL CHIP	1K	5%	1/16W
				(A500)	R727	1-216-821-11	METAL CHIP	1K	5%	1/16W	
R361	1-216-841-11	METAL CHIP	47K	5%	1/16W	R801	1-216-839-11	METAL CHIP	33K	5%	1/16W
R362	1-216-817-11	METAL CHIP	470	5%	1/16W	R802	1-216-837-11	METAL CHIP	22K	5%	1/16W
R363	1-216-841-11	METAL CHIP	47K	5%	1/16W	R803	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R364	1-216-821-11	METAL CHIP	1K	5%	1/16W	R804	1-216-817-11	METAL CHIP	470	5%	1/16W
R365	1-216-833-11	METAL CHIP	10K	5%	1/16W	R805	1-216-821-11	METAL CHIP	1K	5%	1/16W
R366	1-216-833-11	METAL CHIP	10K	5%	1/16W	R806	1-216-817-11	METAL CHIP	470	5%	1/16W
R367	1-216-857-11	METAL CHIP	1M	5%	1/16W	R807	1-216-842-11	METAL CHIP	56K	5%	1/16W
R369	1-218-879-11	METAL GLAZE	22K	0.50%	1/16W	R808	1-216-843-11	METAL CHIP	68K	5%	1/16W
R370	1-216-815-11	METAL CHIP	330	5%	1/16W	R809	1-218-885-11	METAL GLAZE	39K	0.50%	1/16W
R371	1-216-821-11	METAL CHIP	1K	5%	1/16W	R811	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R372	1-216-864-11	METAL CHIP	0	5%	1/16W	R812	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
				(A500E)	R815	1-216-864-11	METAL CHIP	0	5%	1/16W	
R373	1-216-817-11	METAL CHIP	470	5%	1/16W	R817	1-216-825-11	METAL CHIP	2.2K	5%	(A500E)
R375	1-216-818-11	METAL CHIP	560	5%	1/16W	R818	1-216-821-11	METAL CHIP	1K	5%	1/16W
R376	1-216-831-11	METAL CHIP	6.8K	5%	1/16W	R819	1-218-893-11	METAL GLAZE	82K	0.50%	1/16W
R377	1-216-817-11	METAL CHIP	470	5%	1/16W	R820	1-218-877-11	METAL GLAZE	18K	0.50%	1/16W
R378	1-216-821-11	METAL CHIP	1K	5%	1/16W	R821	1-216-851-11	METAL CHIP	330K	5%	1/16W
R379	1-216-840-11	METAL CHIP	39K	5%	1/16W	R822	1-218-883-11	METAL GLAZE	33K	0.50%	1/16W
R380	1-216-821-11	METAL CHIP	1K	5%	1/16W	R823	1-216-837-11	METAL CHIP	22K	5%	1/16W
R382	1-216-835-11	METAL CHIP	15K	5%	1/16W	R824	1-218-887-11	METAL GLAZE	47K	0.50%	1/16W
R386	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	R826	1-216-843-11	METAL CHIP	68K	5%	1/16W
R387	1-216-837-11	METAL CHIP	22K	5%	1/16W	R827	1-216-840-11	METAL CHIP	39K	5%	1/16W
R390	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	R829	1-216-841-11	METAL CHIP	47K	5%	1/16W
R392	1-216-847-11	METAL CHIP	150K	5%	1/16W	R830	1-216-841-11	METAL CHIP	47K	5%	1/16W
R393	1-216-847-11	METAL CHIP	150K	5%	1/16W	R831	1-219-570-11	METAL GLAZE	10M	5%	(A500E)
R394	1-216-817-11	METAL CHIP	470	5%	1/16W	R832	1-216-838-11	METAL CHIP	27K	5%	1/16W
R397	1-216-864-11	METAL CHIP	0	5%	1/16W						(A500)
R399	1-216-823-11	METAL CHIP	1.5K	5%	1/16W	R832	1-216-839-11	METAL CHIP	33K	5%	1/16W
R701	1-216-839-11	METAL CHIP	33K	5%	1/16W	R833	1-216-835-11	METAL CHIP	5K	5%	1/16W
R702	1-216-838-11	METAL CHIP	27K	5%	1/16W						(A500)
R703	1-216-821-11	METAL CHIP	1K	5%	1/16W						(A500E)
R704	1-216-819-11	METAL CHIP	680	5%	1/16W						(A500)
R705	1-216-837-11	METAL CHIP	22K	5%	1/16W						(A500)
R706	1-216-843-11	METAL CHIP	68K	5%	1/16W						(A500E)

Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			Remarks
R833	1-216-843-11	METAL CHIP	68K	5%	1/16W (A500E)	R902	1-216-864-11	METAL CHIP	0	5%	1/16W
R834	1-216-864-11	METAL CHIP	0	5%	1/16W	R904	1-216-864-11	METAL CHIP	0	5%	1/16W
R835	1-216-838-11	METAL CHIP	27K	5%	1/16W (A500E)	R1001	1-216-818-11	METAL CHIP	560	5%	1/16W
R835	1-216-843-11	METAL CHIP	68K	5%	1/16W (A500)	R1002	1-216-806-11	METAL GLAZE	56	5%	1/16W
R836	1-218-887-11	METAL GLAZE	47K	0.50%	1/16W	R1003	1-216-809-11	METAL CHIP	100	5%	1/16W
R837	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1004	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R838	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1005	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R839	1-218-877-11	METAL GLAZE	18K	0.50%	1/16W	R1006	1-216-813-11	METAL CHIP	220	5%	1/16W
R840	1-216-857-11	METAL CHIP	1M	5%	1/16W	R1007	1-216-814-11	METAL CHIP	270	5%	1/16W
R841	1-216-837-11	METAL CHIP	22K	5%	1/16W (A500E)	R1008	1-216-828-11	METAL CHIP	3.9K	5%	1/16W (A500)
R842	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1009	1-216-839-11	METAL CHIP	33K	5%	1/16W
R843	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1010	1-216-837-11	METAL CHIP	22K	5%	1/16W
R844	1-216-857-11	METAL CHIP	1M	5%	1/16W	R1011	1-216-828-11	METAL CHIP	3.9K	5%	1/16W
R845	1-216-841-11	METAL CHIP	47K	5%	1/16W (A500E)	R1012	1-216-828-11	METAL CHIP	3.9K	5%	1/16W (A500)
R846	1-216-837-11	METAL CHIP	22K	5%	1/16W	R1013	1-216-828-11	METAL CHIP	3.9K	5%	1/16W (A500)
R847	1-216-837-11	METAL CHIP	22K	5%	1/16W	R1014	1-216-837-11	METAL CHIP	22K	5%	1/16W
R848	1-216-817-11	METAL CHIP	470	5%	1/16W (A500E)	R1015	1-216-837-11	METAL CHIP	22K	5%	1/16W
R848	1-216-821-11	METAL CHIP	1K	5%	1/16W (A500)	R1016	1-216-829-11	METAL CHIP	4.7K	5%	1/16W (A500)
R849	1-216-830-11	METAL CHIP	5.6K	5%	1/16W (A500E)	R1017	1-216-829-11	METAL CHIP	4.7K	5%	1/16W (A500)
R850	1-216-829-11	METAL CHIP	4.7K	5%	1/16W (A500E)	R1018	1-216-829-11	METAL CHIP	4.7K	5%	1/16W (A500)
R851	1-216-805-11	METAL CHIP	47	5%	1/16W	R1019	1-216-829-11	METAL CHIP	4.7K	5%	1/16W (A500)
R852	1-216-805-11	METAL CHIP	47	5%	1/16W	R1020	1-216-838-11	METAL CHIP	27K	5%	1/16W
R853	1-216-805-11	METAL CHIP	47	5%	1/16W	R1021	1-216-864-11	METAL CHIP	0	5%	1/16W (A500E)
R854	1-216-837-11	METAL CHIP	22K	5%	1/16W	R1022	1-216-828-11	METAL CHIP	3.9K	5%	1/16W
R855	1-216-832-11	METAL CHIP	8.2K	5%	1/16W (A500)	R1023	1-216-817-11	METAL CHIP	470	5%	1/16W
R855	1-216-836-11	METAL CHIP	18K	5%	1/16W (A500E)	R1024	1-216-817-11	METAL CHIP	470	5%	1/16W
R856	1-216-838-11	METAL CHIP	27K	5%	1/16W	R1025	1-216-838-11	METAL CHIP	27K	5%	1/16W
R857	1-216-843-11	METAL CHIP	68K	5%	1/16W	R1026	1-216-864-11	METAL CHIP	0	5%	1/16W (A500E)
R858	1-216-830-11	METAL CHIP	5.6K	5%	1/16W (A500)	R1027	1-216-828-11	METAL CHIP	3.9K	5%	1/16W
R858	1-216-836-11	METAL CHIP	18K	5%	1/16W (A500E)	R1028	1-216-838-11	METAL CHIP	27K	5%	1/16W
R863	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1030	1-216-828-11	METAL CHIP	3.9K	5%	1/16W (A500)
R869	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1030	1-216-830-11	METAL CHIP	5.6K	5%	1/16W (A500E)
R871	1-216-864-11	METAL CHIP	0	5%	1/16W	R1031	1-216-838-11	METAL CHIP	27K	5%	1/16W
R872	1-216-864-11	METAL CHIP	0	5%	1/16W	R1033	1-216-828-11	METAL CHIP	3.9K	5%	1/16W (A500)
R874	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1033	1-216-830-11	METAL CHIP	5.6K	5%	1/16W (A500E)
R875	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1034	1-216-817-11	METAL CHIP	470	5%	1/16W
R876	1-218-885-11	METAL GLAZE	39K	0.50%	1/16W (A500E)	R1035	1-216-817-11	METAL CHIP	470	5%	1/16W
R877	1-218-885-11	METAL GLAZE	39K	0.50%	1/16W (A500E)	R1037	1-216-833-11	METAL CHIP	10K	5%	1/16W
R878	1-216-841-11	METAL CHIP	47K	5%	1/16W (A500E)	R1038	1-216-821-11	METAL CHIP	1K	5%	1/16W
R880	1-216-864-11	METAL CHIP	0	5%	1/16W	R1039	1-216-797-11	METAL CHIP	10	5%	1/16W
R882	1-216-864-11	METAL CHIP	0	5%	1/16W	R1040	1-218-875-11	METAL GLAZE	15K	0.50%	1/16W
R888	1-216-864-11	METAL CHIP	0	5%	1/16W	R1041	1-216-836-11	METAL CHIP	18K	5%	1/16W
R890	1-218-879-11	METAL GLAZE	22K	0.50%	1/16W (A500E)	R1042	1-216-864-11	METAL CHIP	0	5%	1/16W
R891	1-218-879-11	METAL GLAZE	22K	0.50%	1/16W (A500E)	R1045	1-216-828-11	METAL CHIP	3.9K	5%	1/16W
R900	1-216-864-11	METAL CHIP	0	5%	1/16W	R1046	1-216-864-11	METAL CHIP	0	5%	1/16W

Ref. No.	Part No.	Description		Remarks	Ref. No.	Part No.	Description		Remarks		
R1048	1-216-832-11	METAL CHIP	8.2K	5%	1/16W (A500E)	R1119	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1051	1-216-835-11	METAL CHIP	15K	5%	1/16W (A500E)	R1120	1-216-817-11	METAL CHIP	470	5%	1/16W
R1051	1-216-837-11	METAL CHIP	22K	5%	1/16W (A500)	R1121	1-216-817-11	METAL CHIP	470	5%	1/16W
R1052	1-216-864-11	METAL CHIP	0	5%	1/16W (A500)	R1122	1-216-839-11	METAL CHIP	33K	5%	1/16W
R1053	1-216-864-11	METAL CHIP	0	5%	1/16W (A500E)	R1123	1-216-837-11	METAL CHIP	22K	5%	1/16W
R1054	1-216-833-11	METAL CHIP	10K	5%	1/16W	R1124	1-216-837-11	METAL CHIP	22K	5%	1/16W
R1057	1-216-829-11	METAL CHIP	4.7K	5%	1/16W (A500)	R1125	1-216-815-11	METAL CHIP	330	5%	1/16W
R1057	1-216-830-11	METAL CHIP	5.6K	5%	1/16W (A500E)	R1128	1-216-815-11	METAL CHIP	330	5%	1/16W (A500E)
R1061	1-216-855-11	METAL CHIP	680K	5%	1/16W	R1129	1-216-809-11	METAL CHIP	100	5%	1/16W
R1062	1-216-853-11	METAL CHIP	470K	5%	1/16W	R1131	1-216-828-11	METAL CHIP	3.9K	5%	1/16W
R1076	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1134	1-216-823-11	METAL CHIP	1.5K	5%	1/16W (A500)
R1081	1-216-825-11	METAL CHIP	2.2K	5%	1/16W	R1134	1-216-825-11	METAL CHIP	2.2K	5%	1/16W (A500E)
R1082	1-216-837-11	METAL CHIP	22K	5%	1/16W	R1135	1-216-814-11	METAL CHIP	270	5%	1/16W (A500)
R1083	1-216-833-11	METAL CHIP	10K	5%	1/16W	R1135	1-216-864-11	METAL CHIP	0	5%	1/16W (A500E)
R1084	1-216-837-11	METAL CHIP	22K	5%	1/16W	R1136	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1085	1-216-837-11	METAL CHIP	22K	5%	1/16W	R1137	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R1086	1-216-818-11	METAL CHIP	560	5%	1/16W	R1138	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R1087	1-216-823-11	METAL CHIP	1.5K	5%	1/16W (A500E)	R1141	1-216-295-11	CONDUCTOR, CHIP (2012)			
R1087	1-216-825-11	METAL CHIP	2.2K	5%	1/16W (A500)	R1142	1-216-820-11	METAL CHIP	820	5%	1/16W (A500E)
R1088	1-216-817-11	METAL CHIP	470	5%	1/16W	R1142	1-216-821-11	METAL CHIP	1K	5%	1/16W (A500)
R1089	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	R1143	1-216-833-11	METAL CHIP	10K	5%	1/16W (A500)
R1090	1-216-864-11	METAL CHIP	0	5%	1/16W	R1144	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1097	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1146	1-216-818-11	METAL CHIP	560	5%	1/16W
R1098	1-216-864-11	METAL CHIP	0	5%	1/16W	R1147	1-216-820-11	METAL CHIP	820	5%	1/16W (A500)
R1100	1-216-816-11	METAL CHIP	390	5%	1/16W	R1147	1-216-864-11	METAL CHIP	0	5%	1/16W (A500E)
R1101	1-216-820-11	METAL CHIP	820	5%	1/16W	R1148	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1103	1-216-815-11	METAL CHIP	330	5%	1/16W (A500)	R1149	1-216-837-11	METAL CHIP	22K	5%	1/16W
R1103	1-216-817-11	METAL CHIP	470	5%	1/16W (A500E)	R1150	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R1104	1-216-815-11	METAL CHIP	330	5%	1/16W (A500)	R1151	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R1104	1-216-817-11	METAL CHIP	470	5%	1/16W (A500E)	R1152	1-216-822-11	METAL CHIP	1.2K	5%	1/16W
R1105	1-216-837-11	METAL CHIP	22K	5%	1/16W	R1153	1-216-816-11	METAL CHIP	390	5%	1/16W
R1106	1-216-816-11	METAL CHIP	390	5%	1/16W	R1154	1-216-834-11	METAL CHIP	12K	5%	1/16W
R1107	1-216-817-11	METAL CHIP	470	5%	1/16W	R1155	1-216-832-11	METAL CHIP	8.2K	5%	1/16W
R1110	1-216-805-11	METAL CHIP	47	5%	1/16W	R1156	1-216-822-11	METAL CHIP	1.2K	5%	1/16W
R1111	1-216-826-11	METAL CHIP	2.7K	5%	1/16W	R1157	1-216-808-11	METAL CHIP	82	5%	1/16W
R1112	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1159	1-216-864-11	METAL CHIP	0	5%	1/16W
R1113	1-216-864-11	METAL CHIP	0	5%	1/16W	R1160	1-216-819-11	METAL CHIP	680	5%	1/16W
R1114	1-216-815-11	METAL CHIP	330	5%	1/16W	R1162	1-216-834-11	METAL CHIP	12K	5%	1/16W
R1115	1-216-817-11	METAL CHIP	470	5%	1/16W (A500E)	R1163	1-216-832-11	METAL CHIP	8.2K	5%	1/16W
R1115	1-216-818-11	METAL CHIP	560	5%	1/16W (A500)	R1164	1-216-821-11	METAL CHIP	1K	5%	1/16W (A500)
R1116	1-216-815-11	METAL CHIP	330	5%	1/16W (A500E)	R1165	1-216-809-11	METAL CHIP	100	5%	1/16W
R1116	1-216-818-11	METAL CHIP	560	5%	1/16W (A500)	R1180	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1117	1-216-815-11	METAL CHIP	330	5%	1/16W (A500)	R1181	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1117	1-216-816-11	METAL CHIP	390	5%	1/16W (A500E)	R1213	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R1118	1-216-833-11	METAL CHIP	10K	5%	1/16W	R1215	1-216-809-11	METAL CHIP	100	5%	1/16W
					R1216	1-216-835-11	METAL CHIP	15K	5%	1/16W	
					R1217	1-216-827-11	METAL CHIP	3.3K	5%	1/16W	
					R1218	1-216-825-11	METAL CHIP	2.2K	5%	1/16W	
					R1219	1-216-831-11	METAL CHIP	6.8K	5%	1/16W	
					R1220	1-216-833-11	METAL CHIP	10K	5%	1/16W	

Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			Remarks
R1221	1-216-818-11	METAL CHIP	560	5%	1/16W	R1320	1-216-815-11	METAL CHIP	330	5%	1/16W
R1222	1-216-820-11	METAL CHIP	820	5%	1/16W	R1321	1-218-876-11	METAL GLAZE	16K	0.50%	1/16W
R1223	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1322	1-218-847-11	METAL GLAZE	1K	0.50%	1/16W
R1225	1-216-819-11	METAL CHIP	680	5%	1/16W	R1323	1-216-832-11	METAL CHIP	8.2K	5%	1/16W
R1227	1-216-833-11	METAL CHIP	10K	5%	1/16W	R1324	1-216-834-11	METAL CHIP	12K	5%	1/16W
R1228	1-216-835-11	METAL CHIP	15K	5%	1/16W	R1325	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R1230	1-216-833-11	METAL CHIP	10K	5%	1/16W	R1326	1-216-864-11	METAL CHIP	0	5%	1/16W
R1231	1-216-857-11	METAL CHIP	1M	5%	1/16W	R1328	1-216-864-11	METAL CHIP	0	5%	1/16W
R1232	1-216-833-11	METAL CHIP	10K	5%	1/16W	R1329	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R1233	1-216-822-11	METAL CHIP	1.2K	5%	1/16W	R1330	1-216-822-11	METAL CHIP	1.2K	5%	1/16W
R1234	1-216-840-11	METAL CHIP	39K	5%	1/16W	R1331	1-216-823-11	METAL CHIP	1.5K	5%	1/16W
R1236	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1332	1-216-864-11	METAL CHIP	0	5%	1/16W
R1237	1-216-827-11	METAL CHIP	3.3K	5%	1/16W	R1333	1-216-821-11	METAL CHIP	1K	5%	1/16W
R1238	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1334	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R1239	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1335	1-216-797-11	METAL CHIP	10	5%	1/16W
R1240	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1336	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
R1241	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1337	1-216-820-11	METAL CHIP	820	5%	1/16W
R1242	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1338	1-216-850-11	METAL CHIP	270K	5%	1/16W
R1246	1-216-833-11	METAL CHIP	10K	5%	1/16W	R1339	1-216-845-11	METAL CHIP	100K	5%	1/16W
R1247	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1349	1-216-845-11	METAL CHIP	100K	5%	1/16W
R1248	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	R1350	1-216-841-11	METAL CHIP	47K	5%	1/16W
R1249	1-216-825-11	METAL CHIP	2.2K	5%	1/16W	R1351	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1250	1-216-864-11	METAL CHIP	0	5%	1/16W	R1352	1-216-822-11	METAL CHIP	1.2K	5%	1/16W
R1251	1-216-818-11	METAL CHIP	560	5%	1/16W	R1353	1-216-837-11	METAL CHIP	22K	5%	1/16W
R1252	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	R1354	1-216-841-11	METAL CHIP	47K	5%	1/16W
R1253	1-216-818-11	METAL CHIP	560	5%	1/16W	R1355	1-216-822-11	METAL CHIP	1.2K	5%	1/16W
R1254	1-216-830-11	METAL CHIP	5.6K	5%	1/16W	R1356	1-216-847-11	METAL CHIP	150K	5%	1/16W
R1255	1-216-817-11	METAL CHIP	470	5%	1/16W	R1357	1-216-822-11	METAL CHIP	1.2K	5%	1/16W
R1256	1-216-816-11	METAL CHIP	390	5%	1/16W	R1358	1-216-845-11	METAL CHIP	100K	5%	1/16W
R1280	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1359	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R1281	1-216-822-11	METAL CHIP	1.2K	5%	1/16W	R1360	1-216-841-11	METAL CHIP	47K	5%	1/16W
R1283	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1361	1-216-825-11	METAL CHIP	150K	5%	1/16W
R1284	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1362	1-216-804-11	METAL CHIP	39	5%	1/16W
R1285	1-216-857-11	METAL CHIP	1M	5%	1/16W	R1363	1-216-803-11	METAL CHIP	33	5%	1/16W
R1289	1-216-864-11	METAL CHIP	0	5%	1/16W	R1364	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1290	1-216-833-11	METAL CHIP	10K	5%	1/16W	R1365	1-216-833-11	METAL CHIP	47K	5%	1/16W
R1292	1-216-845-11	METAL CHIP	100K	5%	1/16W	R1366	1-216-803-11	METAL CHIP	33	5%	1/16W
R1293	1-216-864-11	METAL CHIP	0	5%	1/16W	R1367	1-216-804-11	METAL CHIP	39	5%	1/16W
R1295	1-216-817-11	METAL CHIP	470	5%	1/16W	R1368	1-216-803-11	METAL CHIP	33	5%	1/16W
R1297	1-216-864-11	METAL CHIP	0	5%	1/16W	R1369	1-216-804-11	METAL CHIP	39	5%	1/16W
R1298	1-216-864-11	METAL CHIP	0	5%	1/16W	R1371	1-216-821-11	METAL CHIP	1K	5%	1/16W
R1307	1-216-836-11	METAL CHIP	18K	5%	1/16W	R1372	1-216-821-11	METAL CHIP	47K	5%	1/16W
R1307	1-216-837-11	METAL CHIP	22K	5%	1/16W	R1373	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1308	1-216-837-11	METAL CHIP	22K	5%	1/16W	R1374	1-216-864-11	METAL CHIP	0	5%	1/16W
R1309	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1375	1-216-821-11	METAL CHIP	1K	5%	1/16W
R1310	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1376	1-216-853-11	METAL CHIP	470K	5%	1/16W
R1311	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1377	1-216-864-11	METAL CHIP	0	5%	1/16W
R1312	1-216-834-11	METAL CHIP	12K	5%	1/16W	R1378	1-216-820-11	METAL CHIP	820	5%	1/16W
R1313	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1379	1-216-836-11	METAL CHIP	18K	5%	1/16W
R1314	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1380	1-216-138-00	METAL CHIP	3.3	5%	1/8W
R1315	1-216-815-11	METAL CHIP	330	5%	1/16W	R1381	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R1316	1-216-815-11	METAL CHIP	330	5%	1/16W	R1382	1-216-837-11	METAL CHIP	22K	5%	1/16W
R1317	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1383	1-216-820-11	METAL CHIP	33	5%	1/16W
R1318	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1384	1-216-836-11	METAL CHIP	10K	5%	1/16W
R1319	1-216-864-11	METAL CHIP	0	5%	1/16W	R1385	1-216-830-11	METAL CHIP	470K	5%	1/16W
						R1386	1-216-837-11	METAL CHIP	3.3	5%	1/8W
						R1387	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
						R1388	1-216-837-11	METAL CHIP	22K	5%	1/16W

Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			Remarks
R1389	1-216-833-11	METAL CHIP	10K	5%	1/16W	R1774	1-216-847-11	METAL GLAZE	1K	0.50%	1/16W
R1403	1-216-844-11	METAL CHIP	82K	5%	1/16W	R1775	1-216-841-11	METAL CHIP	47K	5%	1/16W
R1404	1-216-853-11	METAL CHIP	470K	5%	1/16W	R1776	1-216-821-11	METAL CHIP	1K	5%	1/16W
R1405	1-216-817-11	METAL CHIP	470	5%	1/16W	R1778	1-216-864-11	METAL CHIP	0	5%	1/16W
R1406	1-216-844-11	METAL CHIP	82K	5%	1/16W	R1779	1-216-821-11	METAL CHIP	1K	5%	1/16W
R1408	1-216-853-11	METAL CHIP	470K	5%	1/16W	R1780	1-216-821-11	METAL CHIP	1K	5%	1/16W
R1409	1-216-820-11	METAL CHIP	820	5%	1/16W	R1781	1-216-841-11	METAL CHIP	47K	5%	1/16W
R1410	1-216-864-11	METAL CHIP	0	5%	1/16W	R1782	1-216-864-11	METAL CHIP	0	5%	1/16W
R1411	1-216-817-11	METAL CHIP	470	5%	1/16W	R1783	1-216-821-11	METAL CHIP	1K	5%	1/16W
R1412	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1784	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1413	1-216-823-11	METAL CHIP	1.5K	5%	1/16W	R1785	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1414	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1787	1-216-845-11	METAL CHIP	100K	5%	1/16W
R1415	1-216-823-11	METAL CHIP	1.5K	5%	1/16W	R1790	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1416	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1792	1-216-821-11	METAL CHIP	1K	5%	1/16W
R1418	1-216-844-11	METAL CHIP	82K	5%	1/16W	R1793	1-216-845-11	METAL CHIP	100K	5%	1/16W
R1419	1-216-864-11	METAL CHIP	0	5%	1/16W	R1794	1-216-841-11	METAL CHIP	47K	5%	1/16W
R1421	1-216-823-11	METAL CHIP	1.5K	5%	1/16W	R1795	1-216-841-11	METAL CHIP	47K	5%	1/16W
R1422	1-216-854-11	METAL CHIP	560K	5%	1/16W	R1796	1-216-841-11	METAL CHIP	47K	5%	1/16W
R1423	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1798	1-216-821-11	METAL CHIP	1K	5%	1/16W
R1424	1-216-833-11	METAL CHIP	10K	5%	1/16W	R1803	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
											(A500)
R1425	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1803	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1426	1-216-823-11	METAL CHIP	1.5K	5%	1/16W	R1804	1-216-857-11	METAL CHIP	1M	5%	1/16W
R1430	1-216-817-11	METAL CHIP	470	5%	1/16W	R1805	1-216-856-11	METAL CHIP	820K	5%	1/16W
R1431	1-216-817-11	METAL CHIP	470	5%	1/16W						(A500E)
R1461	1-216-864-11	METAL CHIP	0	5%	1/16W	R1805	1-216-857-11	METAL CHIP	1M	5%	1/16W
R1462	1-216-864-11	METAL CHIP	0	5%	1/16W	R1808	1-216-841-11	METAL CHIP	47K	5%	1/16W
R1476	1-216-864-11	METAL CHIP	0	5%	1/16W	R1809	1-216-864-11	METAL CHIP	0	5%	1/16W
R1488	1-216-853-11	METAL CHIP	470K	5%	1/16W	R1810	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R1489	1-216-817-11	METAL CHIP	470	5%	1/16W	R1811	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R1490	1-216-817-11	METAL CHIP	470	5%	1/16W	R1812	1-216-837-11	METAL CHIP	22K	5%	1/16W
R1491	1-216-817-11	METAL CHIP	470	5%	1/16W	R1813	1-216-845-11	METAL CHIP	100K	5%	1/16W
R1492	1-216-817-11	METAL CHIP	470	5%	1/16W	R1814	1-216-864-11	METAL CHIP	0	5%	1/16W
R1616	1-216-853-11	METAL CHIP	470K	5%	1/16W	R1815	1-216-864-11	METAL CHIP	0	5%	1/16W
R1618	1-216-857-11	METAL CHIP	1M	5%	1/16W	R1821	1-216-864-11	METAL CHIP	0	5%	1/16W
R1633	1-216-864-11	METAL CHIP	0	5%	1/16W	R1822	1-216-845-11	METAL CHIP	100K	5%	1/16W
R1638	1-216-825-11	METAL CHIP	2.2K	5%	1/16W	R1827	1-216-839-11	METAL CHIP	33K	5%	1/16W
R1639	1-216-821-11	METAL CHIP	1K	5%	1/16W	R1836	1-216-864-11	METAL CHIP	0	5%	1/16W
R1640	1-216-864-11	METAL CHIP	0	5%	1/16W	R1840	1-216-857-11	METAL CHIP	1M	5%	1/16W
R1642	1-216-809-11	METAL CHIP	100	5%	1/16W	R1841	1-216-845-11	METAL CHIP	100K	5%	1/16W
R1643	1-216-809-11	METAL CHIP	100	5%	1/16W	R1842	1-216-857-11	METAL CHIP	1M	5%	1/16W
R1644	1-216-864-11	METAL CHIP	0	5%	1/16W	R1843	1-216-845-11	METAL CHIP	100K	5%	1/16W
R1751	1-216-845-11	METAL CHIP	100K	5%	1/16W						(A500E)
R1752	1-216-845-11	METAL CHIP	100K	5%	1/16W	R1844	1-216-803-11	METAL CHIP	33	5%	1/16W
R1754	1-216-864-11	METAL CHIP	0	5%	1/16W	R1848	1-216-864-11	METAL CHIP	0	5%	1/16W
R1755	1-216-853-11	METAL CHIP	470K	5%	1/16W	R1851	1-217-671-11	METAL CHIP	1	5%	1/10W
R1756	1-216-839-11	METAL CHIP	33K	5%	1/16W	R1852	1-217-671-11	METAL CHIP	1	5%	1/10W
R1757	1-216-837-11	METAL CHIP	22K	5%	1/16W	R1853	1-217-671-11	METAL CHIP	1	5%	1/10W
R1758	1-216-818-11	METAL CHIP	560	5%	1/16W	R1855	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1759	1-216-816-11	METAL CHIP	390	5%	1/16W	R1856	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1760	1-216-797-11	METAL CHIP	10	5%	1/16W	R1857	1-216-833-11	METAL CHIP	10K	5%	1/16W
R1761	1-216-864-11	METAL CHIP	0	5%	1/16W	R1858	1-216-853-11	METAL CHIP	470K	5%	1/16W
R1762	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	R1859	1-216-864-11	METAL CHIP	0	5%	1/16W
R1763	1-216-864-11	METAL CHIP	0	5%	1/16W	R1860	1-216-864-11	METAL CHIP	0	5%	1/16W
R1764	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1861	1-216-841-11	METAL CHIP	47K	5%	1/16W
R1765	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1862	1-216-841-11	METAL CHIP	47K	5%	1/16W
R1766	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1863	1-216-841-11	METAL CHIP	47K	5%	1/16W
R1773	1-216-841-11	METAL CHIP	47K	5%	1/16W	R1864	1-216-841-11	METAL CHIP	47K	5%	1/16W



Ref. No.	Part No.	Description	Remarks
< VIBRATOR >			
X801	1-579-466-11	VIBRATOR, CRYSTAL 3.579545MHz (A500)	
X801	1-579-661-21	OSCILLATOR, CRYSTAL 4.43619MHz(A500E)	
X1305	1-767-028-21	VIBRATOR, CRYSTAL 14.318182MHz (A500)	
X1305	1-767-029-21	VIBRATOR, CRYSTAL 17.734475MHz (A500E)	
X1601	1-760-320-11	VIBRATOR, CRYSTAL 28.636363MHz (A500)	
X1601	1-760-321-11	VIBRATOR, CRYSTAL 28.375MHz (A500E)	
X1751	1-760-655-41	VIBRATOR, CRYSTAL 20MHz	
X1752	1-767-030-21	VIBRATOR, CRYSTAL 11.895104MHz (A500)	
X1752	1-767-031-21	VIBRATOR, CRYSTAL 11.71875MHz (A500E)	
X1951	1-760-458-21	VIBRATOR, CRYSTAL 32.768kHz	
X1952	1-579-907-21	VIBRATOR, CERAMIC 20MHz	

## MISCELLANEOUS

\*\*\*\*\*

6	1-694-076-11	TERMINAL BOARD, BATTERY
52	1-801-664-21	MODULE, CRYSTAL INDICATION
△53	1-517-656-21	TUBE, FLUORESCENT LOLD CATHODE
71	1-504-753-21	SPEAKER (2.8CM)
112	1-475-383-31	SWITCH BLOCK, CONTROL (FK-71)
116	1-500-227-11	BEAD, FERRITE
M901	A-7048-849-A	DRUM BLOCK ASSY (DGH-0D4A-R)(NTSC)
M901	A-7048-859-A	DRUM BLOCK ASSY (DGH-0E0A-R)(PAL)
M902	8-835-531-32	MOTOR, DC SCE-0601A
M903	X-3945-401-1	MOTOR ASSY, DC
S901	1-762-436-15	SWITCH, ROTARY (ENCODER)

The components identified by mark △ or dotted line with mark △ are critical for safety.  
Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité.  
Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remarks
ACCESSORIES & PACKING MATERIALS			
			*****
△A-7009-474-F		POWER ADAPTER AC-V615 (A500)	
△A-7009-475-A		POWER ADAPTER AC-V615 (A500E)	
△1-569-008-11		ADAPTOR, CONVERSION 2P (A500E: E)	
1-575-334-11		CORD, CONNECTION (AUDIO/VIDEO) 1.5m	
1-575-335-21		CORD, CONNECTION (S VIDEO) 1.5m	
△1-751-676-11		CORD, POWER (A500)	
△1-769-608-11		CORD, POWER (A500E)	
△1-770-019-11		ADAPTOR, CONVERSION PLUG 3P (A500E:UK,Hong Kong)	
1-782-361-11		CODE, CONNECTION (DK-415)	
3-860-731-11		MANUAL, INSTRUCTION (ENGLISH,SPANISH)(A500)	
3-860-731-21		MANUAL, INSTRUCTION (FRENCH)(A500)	
3-860-731-31		MANUAL, INSTRUCTION (CHINESE)(A500)	
3-861-067-11		MANUAL, INSTRUCTION (ENGLISH,RUSSIAN) (A500E: AEP,UK)	
3-861-067-21		MANUAL, INSTRUCTION (GERMAN,ITALIAN) (A500E:AEP)	
3-861-067-31		MANUAL, INSTRUCTION (FRENCH,DUTCH) (A500E:AEP)	
3-861-067-41		MANUAL, INSTRUCTION (SPANISH,PORTUGUESE)(A500E:AEP)	
3-861-067-51		MANUAL, INSTRUCTION (ENGLISH,RUSSIAN) (A500E: E,Hong Kong)	
3-861-067-61		MANUAL, INSTRUCTION (FRENCH,GERMAN) (A500E: E,Hong Kong)	
3-861-067-71		MANUAL, INSTRUCTION (ARABIC,PERSIAN) (A500E: E)	
3-861-067-81		MANUAL, INSTRUCTION (CHINESE) (A500E: E, Hong Kong)	
3-861-067-91		MANUAL, INSTRUCTION (CHINESE) (A500E: Hong Kong)	
*	3-979-155-01	INDIVIDUAL CARTON (A500)	
*	3-979-156-01	CUSHION (UPPER)	
*	3-979-157-01	CUSHION (LOWER)	
*	3-979-196-01	BAG, PROTECTION	
*	3-979-907-01	INDIVIDUAL CARTON (A500E)	
	3-987-015-01	BELT (VW), STRAP	