

Service
Service
Service

190G6FB/00
190G6FB/93
190G6FB/96
190G6FB/97



Service Manual

Horizontal frequencies
30 - 83 kHz

TABLE OF CONTENTS

Description	Page	Description	Page
Important Safety Notice-----	2	Scaler Diagram&C.B.A. -----	37~49
Technical Data-----	3	Inverter Diagram&C.B.A.-----	50~51
Installation&On Screen Display -----	4~9	Audio Diagram&C.B.A. -----	52~56
Aging,Factory mode-----	10	Power Diagram&C.B.A. -----	57~60
Mechanical Instructions -----	11~12	HD Diagram&C.B.A. -----	61~63
Color adjustment -----	13	LED Diagram&C.B.A.-----	64~66
Warning Message -----	14	Control Diagram&C.B.A. -----	67~69
Troubleshooting -----	15	Exploded View -----	70
Electrical instruction -----	16~19	Spare&Recommended parts list-----	71~75
DDC Instructions-----	20~26	General product specification-----	76~94
DDC DATA -----	27~28	Repair tips-----	95~96
Philips Pixel Defect Policy-----	29	Repair Flow chart-----	97~98
Update UAC3556 FW-----	30	Failure mode of panel-----	99
ISP Instructions -----	31~32	Safety Test Requirments -----	100
Wiring&Block Diagram-----	33~36	Different parts list-----	101
		Update for 190G6-----	102

SAFETY NOTICE

ANY PERSON ATTEMPTING TO SERVICE THIS CHASSIS MUST FAMILIARIZE HIMSELF WITH THE CHASSIS AND BE AWARE OF THE NECESSARY SAFETY PRECAUTIONS TO BE USED WHEN SERVICING ELECTRONIC EQUIPMENT CONTAINING HIGH VOLTAGES.

CAUTION: USE A SEPARATE ISOLATION TRANSFORMER FOR THIS UNIT WHEN SERVICING.

REFER TO BACK COVER FOR IMPORTANT SAFETY GUIDELINES

Important Safety Notice

◀◀ Go to cover page

Proper service and repair is important to the safe, reliable operation of all Philips Consumer Electronics Company** Equipment. The service procedures recommended by Philips and described in this service manual are effective methods of performing service operations. Some of these service operations require the use of tools specially designed for the purpose. The special tools should be used when and as recommended.

It is important to note that this manual contains various CAUTIONS and NOTICES which should be carefully read in order to minimize the risk of personal injury to service personnel. The possibility exists that improper service methods may damage the equipment. It is also important to understand that these CAUTIONS and NOTICES ARE NOT EXHAUSTIVE. Philips could not possibly know, evaluate and advise the service trade of all conceivable ways in which service might be done or of the possible hazardous consequences of each way. Consequently, Philips has not undertaken any such broad evaluation. Accordingly, a servicer who uses a service procedure or tool which is not recommended by Philips must first satisfy himself thoroughly that neither his safety nor the safe operation of the equipment will be jeopardized by the service method selected.

* * Hereafter throughout this manual, Philips Consumer Electronics Company will be referred to as Philips.

WARNING

Critical components having special safety characteristics are identified with a ▲ by the Ref. No. in the parts list and enclosed within a broken line* (where several critical components are grouped in one area) along with the safety symbol ▲ on the schematics or exploded views.

Use of substitute replacement parts which do not have the same specified safety characteristics may create shock, fire, or other hazards.

Under no circumstances should the original design be modified or altered without written permission from Philips. Philips assumes no liability, express or implied, arising out of any unauthorized modification of design. Servicer assumes all liability.



* Broken Line

FOR PRODUCTS CONTAINING LASER :

DANGER- Invisible laser radiation when open.
AVOID DIRECT EXPOSURE TO BEAM.

CAUTION- Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION- The use of optical instruments with this product will increase eye hazard.

TO ENSURE THE CONTINUED RELIABILITY OF THIS PRODUCT, USE ONLY ORIGINAL MANUFACTURER'S REPLACEMENT PARTS, WHICH ARE LISTED WITH THEIR PART NUMBERS IN THE PARTS LIST SECTION OF THIS SERVICE MANUAL.

Take care during handling the LCD module with backlight unit

- Must mount the module using mounting holes arranged in four corners.
- Do not press on the panel, edge of the frame strongly or electric shock as this will result in damage to the screen.
- Do not scratch or press on the panel with any sharp objects, such as pencil or pen as this may result in damage to the panel.
- Protect the module from the ESD as it may damage the electronic circuit (C-MOS).
- Make certain that treatment person' s body are grounded through wrist band.

LPL panel

Type NR.	: LM190E03_TLC1
Display area(mm)	: 376.32(H) x 301.056(V) (19.0-inch diagonal)
Number of Pixels	: 1280(H) x 1024(V)
Pitch (mm)	: 0.098(H) x 0.294(V)
Color pixel arrangement	: RGB vertical stripes
Display operating mode	: Transmissive mode, normally white
Color depth	: 16.2M colors (6 bits with FRC)
Brightness (cd/m^2)	: 420(cd/m^2)(Center 1 points Typ.)
Viewing angle(CR>10)	: 88°(R/L), 85°(Up), 85°(Down), Typ
Surface treatment	: Hard coating(2H) & Low reflection glare treatment of front polarizer
Electrical interface	: LVDS (2 port)
Response Time	: 8ms(typ.) (Tr+Tf)
Power Consumption(W)	: 3.05(Max) for LCD, 22.53(Max) for inverter
Contrast ratio	: Typical 700 : 1
Module size (mm)	: 396.0(W) x 324.0(H) x 16.5(D)
Module weight (g)	: 2700(Typ), 2840(Max)
Backlight	: 4 CCFL

Power supply

AC/DC Power adapter	: +16V DC/3.95A (100V~240V)
Power consumption	: 62 W (Max) w/o subwoofer, 100W(Max) with subwoofer
Power cord length and type	: 1.8M, UK type
Power indicator	: LED (On: Green ,Sleeping mode: Amber)

DPMS :
(OFF modes is just for PC mode)


STATUS	H-sync	V-sync	Video	Power	LED
On	On	On	Active	<100 W	Green /With Audio and sub-woofer (Note 1)
On	On	On	Active	<62W	Green / Without subwoofer
Off	Off	On	Blanked	<2W	Amber LCD (Note 2)
Off	On	Off	Blanked	<2W	Amber LCD (Note 2)
Off	Off	Off	Blanked	<2W	Amber LCD (Note 2)
DC Power off			N / A	<1W	LED Off (Note 2)

Note 1: sub-woofer uses individual power.

Note2: Upstream USB cable is disconnected to PC or PC is shut down if upstream USB cable is connected .


Horizontal scan	: 30 - 83KHz
Vertical scan	: 56 - 76 Hz

Pin Assignment



Pin No.	Assignment	Pin No.	Assignment
1	Red video input	9	DDC +5V
2	Green video input	10	GND
3	Blue video input	11	GND
4	GND	12	Serial data line (SDA)
5	Cable detect	13	H-sync
6	Red video GND	14	V-sync
7	Green video GND	15	Data clock line (SCL)
8	Blue video GND		

Input DVI-D connector pin



Pin No.	Description
1	T.M.D.S. data2-
2	T.M.D.S. data2+
3	T.M.D.S. data2 shield
4	No Connect
5	No Connect
6	DDC clock
7	DDC data
8	No Connect
9	T.M.D.S. data1-
10	T.M.D.S. data1+
11	T.M.D.S. data1 shield
12	No Connect
13	No Connect
14	+5V Power
15	Ground (for +5V) - Cable detect
16	Hot plug detect
17	T.M.D.S. data0-
18	T.M.D.S. data0+
19	T.M.D.S. data0 shield
20	No Connect
21	No Connect
22	T.M.D.S. clock shield
23	T.M.D.S. clock+
24	T.M.D.S. clock-

Environmental conditions

Operating

-Temperature C	: 0°C to 35°C
-Humidity	: 20% ~ 80 %
-Altitude	: 0-3658m
-Air pressure	: 600-1100mBAR

Storage

-Temperature C	: -20 to 60°
-Humidity	: 95% max (< 40°C)
-Altitude	: 0-12192m
-Air pressure	: 300-1100mBAR

Note: Recommend at 0 to 35°C, Humidity less than 60 %

Mechanical


Pedestal	: Detachable
Tilt angle	: 0° to 20°
Swivel rotation	: No

Installation

◀◀ Go to cover page

Installing your LCD Monitor/TV

Product Description



- | | |
|--|----------------------|
| 1 To switch display's power On & Off | 20 Antenna |
| 2 Power LED | 21 USB upstream port |
| 3 To access OSD menu | 22 Monitor DC in |
| 4 To adjust the OSD (Up, Down, Left, Right) | 23 Subwoofer out |
| 5 Automatically adjust horizontal position, vertical position, phase and clock setting in D-sub only | 24 Microphone in |
| 6 To adjust the speaker volume | 25 Headphone out |
| 7 To mute the audio | 26 USB hub |
| 8 Preset hotkeys to optimize audio performance | 27 Subwoofer power |
| 9 To adjust the subwoofer bass | 28 Subwoofer in |
| 10 USB Audio LED | 29 SCART |
| 11 DVI-D | |
| 12 D-Sub | |
| 13 PC audio | |
| 14 HD audio jack | |
| 15 YPbPr | |
| 16 S-Video | |
| 17 Kensington lock | |
| 18 CVBS | |
| 19 Audio jack | |

Connecting to Your PC

Accessory Pack
Unpack all the parts

Item

Description



Power Cord (Monitor)



Power Cord (Subwoofer)



D-Sub



DVI-D



USB cable



Component (YPbPr)



Subwoofer Cable



Subwoofer Audio




EDFU pack



Remote Control
(Not available for all model)


Connecting to Your PC

1)




Remove backcover from vertical monitor.

2) Cable management




3)



Note: If you use an Apple Macintosh, you need to connect the special Mac adapter to one end of the monitor signal cable.

4) Connect to PC



- (1) Turn off your computer and unplug its power cable.
- (2) Connect the monitor signal cable to the video connector on the back of your computer.
- (3) Plug the power cord of your computer and your monitor into a nearby outlet.
- (4) USB plug
 - (a) Connect USB upstream port on monitor and the USB port on PC with a USB cable.
 - (b) The USB downstream port is now ready for any USB device to plug in
- (5) Turn on your computer and monitor. If the monitor displays an image, installation is complete.


◀◀ Go to cover page

Note: The USB plug is a pass through connection whether it can support USB 1.1 or USB 2.0 depends on your PC's specification.

5) Connect for AV functionality (Europe Only)

SCART Connections


This connection will supply stereo sound to the display.



- (1) Using a scart cable (not supplied) connect one end of the scart cable to the scart jocket of the scart enabled device. Connect the other end of the scart cable to the scart jack on the bottom of the display.
- (2) Plug the DC adapter into the DC IN 16V jack on the display. Plug the power cable into an outlet and switch the display set on.

S-Video Connections

The S-Video connection on the rear of the display can provide you with better picture detail and clarity for the playback of accessory sources such as DBS (digital broadcast satellite), DVD (digital video discs), video games, and VHS VCR (video cassette recorder) tapes than the normal antenna picture connections.




- (1) Connect an S-Video cable to the S-VIDEO jack of the other equipment (DVD Player, Camcorder, etc.) and to the S-VIDEO jack on the rear of the display.
- (2) Connect RCA-style audio cables (usually red and white) to the AUDIO OUT (left and right) jacks on the other equipment. Connect the other end of the cables to the AUDIO jack on the side of the display.

- (3) Plug the DC Adapter into the DC IN 16V jack on the display. Plug the power cable into an outlet. Turn on the display and other equipment.
- (4) Press the OSD buttons until S-Video appears on the screen.
- (5) Press PLAY on the other equipment to view its material on the display.

Component (HD) Connections

Component Video input provide the highest possible color and picture resolution in the playback of digital signal source material, such as with DVD players. If you are using a HD (High Definition) receiver that can transmit high definition programming, the display can accept those signals through the Component input located on the bottom of the display.




- (1) Connect the component (Y, Pb, Pr) Video OUT jacks from the DVD player (or similar device) to the COMP(onent) VIDEO Input jacks on the bottom of the display.
- (2) Connect the red and white AUDIO CABLES to the Audio (left and right) output jacks on the rear of the accessory device to the AUDIO IN jack. Connect the other end of the cable to the Audio jack on the rear of display.
- (3) Plug the DC Adapter into the DC IN 16 V jack on the display. Plug the power cable into an outlet. Turn on the display and other equipment.
- (4) Press the OSD button until HD appears on the screen.
- (5) Insert a DVD disc into the DVD player and press the PLAY button on the DVD Player.

PC (Monitor) Inputs

This display can be used as a PC monitor. Your computer will have to be equipped with a VGA type video output and interface cable (supplied).


Installation

◀◀ Go to cover page



- (1) Connect the VGA/DVI or DVI end of the interface cable to the computer, while connecting the other end to the D-SUB or DVI INPUT jack on the display.
- (2) Although audio connections are not required, the display can reproduce the computers audio out by an AUDIO ADAPTER to the Audio output jack on the computer (if available) while connecting the other end of the Audio cables to the PC AUDIO Jacks on the bottom of the display.
- (3) Plug the DC Adapter into the DC IN 16V jack on the display. Plug the power cable into an outlet. Turn on the display and PC.
- (4) Press the OSD button until PC MODE appears on the screen.

6) Connect for AV/TV functionality (Asia Pacific Only)
Cable Box (with RF in/outputs)



- (1) Connect the Cable TV signal to the IN jack (or RF IN or CABLE IN) on the Cable Box.
- (2) Connect an RF coaxial cable (not supplied) to the OUT jack (or TO TV or RF OUT) of the Cable Box.
- (3) Connect the other end of the coaxial cable to one end of the supplied L-Adapter as shown, and connect the other end of the adapter to the TV jack on the LCD TV.
- (4) Plug the DC adapter into the DC IN 16V jack on the LCD TV. Plug

the power cable into an outlet and switch TV set on.


- (5) Set the Channel 3/4 (or Output channel) switch of the Cable Box to 3 or 4. Set the TV to the same channel. When watching TV programming, change channels at the Cable Box, not the LCD TV.

Helpful Hint

- 1 Immediately after unpacking and plugging in your new television, run the auto program function to set up the TV for the broadcast or cable channels available in your area. If you do not run the auto program function to set up the channels, your television may not operate properly.
- 2 Please make sure that you have selected the TV mode with AV+ key on your remote control, before installing TV channels.

Cable Box (with Audio/Video outputs)

This connection will supply stereo sound to the LCD TV.




- (1) Connect the Cable TV signal to the IN jack (or RF IN or CABLE IN) on the Cable Box.
- (2) Using an RCA-type video cable (not supplied) connect one end of the video cable to the Video Out jack of the Cable Box. Connect the other end of the cable to the yellow VIDEO jack on the side of the TV. Video cables are usually marked with yellow and are available from Philips or electronics retailers. Video jacks on most equipment are yellow.
- (3) Using RCA-type, stereo audio cables (not supplied), connect one end of the cables to the left and right Audio Out jacks of the Cable Box. Connect the other end of that cable to the Audio jack on the side of the LCD TV. Audio cables are usually marked with red and white and are available from Philips or electronics retailers. The right audio jack is red and the left audio jack is white. Match the cable colors to the jack colors.
- (4) Plug the DC adapter into the DC IN 16V jack on the LCD TV. Plug the power cable into an outlet and switch TV set on.

Note: Use the AV+ button on the remote control to tune to the AV channel for the cable box signal. Once tuned, change channels at the cable box, not the television. When you watch programs using VCR, it is recommended to select Soft Mode via Smart picture.

S-Video Connections

The S-Video connection on the rear of the LCD TV can provide you with better picture detail and clarity for the playback of accessory sources such as DBS (digital broadcast satellite), DVD (digital video discs), video games, and VHS VCR (video cassette recorder) tapes than the normal antenna picture connections.

◀◀ Go to cover page




- (1) Connect an S-Video cable to the S-VIDEO jack of the other equipment (DVD Player, Camcorder, etc.) and to the S-VIDEO jack on the rear of the LCD TV.
- (2) Connect RCA-style audio cables (usually red and white) to the AUDIO OUT (left and right) jacks on the other equipment. Connect the other end of the cables to the AUDIO jack on the side of the LCD TV.
- (3) Plug the DC Adapter into the DC IN 16V jack on the LCD TV. Plug the power cable into an outlet. Turn on the LCD TV and other equipment.
- (4) Press the AV buttons to set the LCD TV to its S-VIDEO mode.
- (5) Press PLAY on the other equipment to view its material on the LCD TV.

Note: The Philips LCD TV remote control can not be used to operate other video/audio equipment.

The Audio jack of AV IN is shared between Video (CVBS) and S-Video signals. If Audio and Video is connected to S-Video input, you can still hear sound if you select Video via AV select, even there appears no image on screen.

Component (HD) Connections

Component Video input provide the highest possible color and picture resolution in the playback of digital signal source material, such as with DVD players. If you are using a HD (High Definition) receiver that can transmit high definition programming, the TV can accept those signals through the Component input located on the bottom of the TV.




- (1) Connect the component (Y, Pb, Pr) Video OUT jacks from the DVD player (or similar device) to the COMP(onent) VIDEO Input jacks on the bottom of the LCD TV.
- (2) Connect the red and white AUDIO CABLES to the Audio (left and right) output jacks on the rear of the accessory device to the AUDIO IN jack. Connect the other end of the cable to the Audio jack on the rear of LCD TV.
- (3) Plug the DC Adapter into the DC IN 16 V jack on the LCD TV. Plug the power cable into an outlet. Turn on the LCD TV and other equipment.
- (4) Press the AV button on the remote control to select HD. HD will appear in the upper left corner on the TV screen.
- (5) Insert a DVD disc into the DVD player and press the PLAY button on the DVD Player.

Note: The Philips LCD TV remote control can not be used to operate other video/audio equipment.

PC (Monitor) inputs

This LCD TV can be used as a PC display monitor. Your computer will have to be equipped with a VGA type video output and interface cable (supplied).



- (1) Connect the VGA or DVI end of the interface cable (supplied) to the computer, while connecting the other end to the DSUB or DVI INPUT jack on the LCD TV.
- (2) Although audio connections are not required, the LCD TV can reproduce the computers audio out by an AUDIO ADAPTER to the Audio output jack on the computer (if available) while connecting the other ends of the Audio cables to the PC AUDIO Jacks on the bottom of the TV.
- (3) Plug the DC Adapter into the DC IN 16V jack on the LCD TV. Plug the power cable into an outlet. Turn on the LCD TV and PC.
- (4) Press the AV button until PC MODE appears on the screen.

Note: USB digital audio applicable in PC mode only.

On Screen Display


◀◀ Go to cover page

On-Screen Display

Description of the On Screen Display

What is the On-Screen Display?

On-Screen Display (OSD) is a feature in all Philips LCD monitors. It allows an end user to adjust screen performance or select functions of the monitors directly through an on-screen instruction window. A user friendly on screen display interface is shown as below :




Basic and simple instruction on the control keys.

In the OSD shown above users can press ▲▼ buttons at the base of the monitor to move the cursor, OK to confirm the choice or change, and ◀▶ to adjust/select the change.


The OSD Tree

Below is an overall view of the structure of the On-Screen Display. You can use this as a reference when you want to work your way around the different adjustments later on.


Asia Pacific (TV/AV/S-VIDEO/HDTV Mode)




Asia Pacific (PC Mode)



Europe (PC Mode)



Europe (EXT/AV/S-VIDEO/HDTV Mode)

Note: sRGB is a standard for ensuring correct exchange of colors between different devices (e.g. digital cameras, monitors, printers, scanners, etc.)

Using a standard unified color space, sRGB will help represent pictures taken by an sRGB compatible device correctly on your sRGB enabled Philips monitors. In that way, the colors are calibrated and you can rely on the correctness of the colors shown on your screen.


Important with the use of sRGB is that the brightness and contrast of your monitor is fixed to a predefined setting as well as the color gamut. Therefore it is important to select the sRGB setting in the monitor's OSD.

To do so, open the OSD by pressing the OK button on the side of your monitor. Move the down button to go to Color and press OK again. Use the right button to go to sRGB. Then move the down button and press OK again to exit the OSD.

After this, please do not change the brightness or contrast setting of your monitor. If you change either of these, the monitor will exit the sRGB mode and go to a color temperature setting of 6500K.

◀◀ Go to cover page

View



Access Aging Mode

Step 1 : Disconnect Interface Cable between Monitor and PC.
 Step 2 : Turn off LCD monitor. Then press power "⏻" button. Then quickly push "OK" and "AUTO", and hold this two buttons until comes out "AGING screen"] => then release all buttons.
 Bring up:



After 50 seconds,
bring up:



After 3 seconds,
bring up:



After 50 seconds,
bring up:



 repeatedly
 Connect Signal cable again=> go back to normal display

Access Factory Mode

- 1). Turn off monitor.
- 2). Press power "⏻" button. Then quickly push "OK" and "AUTO", and hold this two buttons, then the screen comes out "Waiting For Automatic Adjustment", then the screen will be black for one second until comes out "Windows screen"] => then release this two buttons.
- 3). Press "MENU" button, wait until the OSD menu with Characters "Hudson6 190G6 CHINA V0.35 0508LM190E03" (below OSD menu) come on the Screen of the monitor.



Factory Mode indicator

Factory Menu

Cursor can move on gray color area
 Hot key function: by pressing "▲" and "▼" key
 Simultaneously at User Mode (or Factory Mode)
 (PS: The Offset R G B function can be used on reduce or eliminate
 snowy noise on the background when the resolution of video signal
 is 1280*1024 vertical 60Hz. Slightly increase or decrease the value
 until snowy noise completely disappear.



Front view



Back view



Step 1. Remove the back cover and stands.

- a. Remove the PHILIPS cover as Fig.3 .
- b. Remove the back cover .
 1. Unscrew the 4 screws as Fig.4 .
 2. Open 5 clicks on top side as Fig.5 .
 3. Open 4 clicks on bottom side as Fig.6 .
 4. Open 2 clicks on left and right side as Fig.7 and Fig.8 .
 5. Open the back cover .



Fig.3



Fig.4



Fig.5



Fig.6



Fig.7



Fig.8

c. Remove the stands .

1. Unscrew the 6 screws and disconnect the 3 cables as Fig.9 .
2. Remove the stands as Fig.10 .




Fig.1




Fig.9

Fig.10

Step 2. Remove the Control and Audio board.

- a. Unscrew the 12 screws and disconnect the 4 cables as Fig.11 and Fig.12.




Fig.11



Fig.12

Step 3. Remove the Scaler , HD , Inverter and LED board .

- a. Unscrew the 7 screws and remove the shielding-upper-ap as Fig.13 and Fig.14 .



Fig.13




Fig.14

◀◀ Go to cover page

- b. Unscrew the 8 screws and disconnect the 9 cables as Fig. 15 .
- c. Remove the Scaler and HD board as Fig.16 .
- d. Unscrew the 3 screws and remove the shielding-lower-ap as Fig.16 and Fig.17 .
- e. Unscrew the 1 screw and disconnect the 4 cables as Fig.17 .




Fig. 15




Fig. 16




Fig. 17




Fig. 18

Step 4. Remove the LCD panel.

- a. Remove the bezel
 - 1. Open 4 clicks on top and bottom side as Fig.19 and Fig.20 .
 - 2. Open 2 clicks on left and right side as Fig.21 and Fig.22 .
 - 3. Remove the LED board and remove the bezel .
- b. Unscrew the 4 screws and remove the metal frame as Fig.23 .




Fig. 19




Fig. 20




Fig. 21



Fig. 22




Fig. 23

LCD Panel

1050 823827718731 LCD LM190E03-TLC1.



Fig. 24

In warranty, it is not allowed to disassembly the LCD panel, even the
backlight unit defect.

Out of warranty, the replacment of backlight unit is a correct way
when the defect is cused by backlight (CCFL,Lamp).

Go to cover page

Alignment procedure

1. Turn on the LCD monitor.
2. Turn on the Timing/pattern generator. See Fig.1
3. Preset LCD color Analyzer CA-110
 - Remove the lens protective cover of probe CA-A30.
 - Set measuring/viewing selector to measuring position for reset analyzer.(zero calibration) as Fig.2
 - Turn on the color analyzer (CA-110)
 - Press 0-CAL button to starting reset analyzer.




Fig. 1




Fig. 2

4. Access Factory Mode

- 1). Turn off monitor.
- 2). Press power "P" button. Then quickly push "OK" and "AUTO", and hold this two buttons, then the screen comes out "Waiting For Automatic Adjustment", then the screen will be black for one second until comes out "Windows screen" => then release this two buttons.
- 3). Press "MENU" button, wait until the OSD menu with Characters "Hudson6 190G6 CHINA V0.35 0508LM190E03" (below OSD menu) come on the Screen of the monitor.




Factory Mode indicator

Fig. 3

- 4). Press "MENU" button, then select factory mode indicator by "▼" button. Press "MENU" button to bring up submenu windows as below:



Fig. 4



Measurement/Viewing selector

Clear image



Fig.5

5. Display

Press "▲" or "▼" button to select. Change the value by "◀" or "▶" key until the X,Y co-ordinates as below

5.1 Auto color adjustment (B)

Apply a 1024*768/60Hz signal with half black white pattern, set brightness control at 50%, and contrast control at 50%. Adjust the R.G. B. offset, and gain to calibrate the color smoothly and 64-grey level distinguishable.

5.2 Adjustment of WHITE-D (B)

Apply a 1280*1024 / 60Hz signal with white pattern, set brightness control at 50%, and contrast control at 50%. Adjust the R, G, B Sub-Gain, for the screen center, the 1931 CIE chromaticity (X, Y) co-ordinates shall be

	9300°K	6500°K
x (center)	0.283 ± 0.020	0.313 ± 0.020
y (center)	0.297 ± 0.020	0.329 ± 0.020

Use Minolta CA-210 for color coordinates and luminance check.

Luminance is > 200 Nits in the center of the screen when brightness at 50% and contrast set to 50%.

5.3 Adjustment of sRGB (B)

Apply a 1280*1024/ 60Hz signal with white pattern; brightness (0) and contrast (150) will be preloaded in EEPROM. Adjust the R, G, B Sub-Gain for the screen center, the 1931 CIE chromaticity (X, Y) co-ordinates shall be


	sRGB
x (center)	0.313 ± 0.008
y (center)	0.329 ± 0.008
Ynits	180 ± 10

Go to cover page

WARNING: Use of controls, adjustments or procedures other than those specified in this documentation may result in exposure to shock, electrical hazards and/or mechanical hazards.

Read and follow these instructions when connecting and using your computer monitor:

- To protect your display from possible damage, do not put excessive pressure on the LCD panel. When moving your monitor, grasp the frame to lift; do not lift the monitor by placing your hand or fingers on the LCD panel.
- Unplug the monitor if you are not going to use it for an extensive period of time.
- Unplug the monitor if you need to clean it with a slightly damp cloth. The screen may be wiped with a dry cloth when the power is off. However, never use alcohol, solvents or ammonia-based liquids.
- Consult a service technician if the monitor does not operate normally when you have followed the instructions in this manual.
- The casing cover should be opened only by qualified service personnel.
- Keep the monitor out of direct sunlight and away from stoves or any other heat source.
- Remove any object that could fall into the vents or prevent proper cooling of the monitor's electronics.
- Do not block the ventilation holes on the cabinet.
- Keep the monitor dry. To avoid electric shock, do not expose it to rain or excessive moisture.
- When positioning the monitor, make sure the power plug and outlet are easily accessible.
- If turning off the monitor by detaching the power cable or DC power cord, wait for 6 seconds before attaching the power cable or DC power cord for normal operation.
- To avoid the risk of shock or permanent damage to the set, do not expose the monitor to rain or excessive moisture.
- IMPORTANT: Always activate a screen saver program during your application. If a still image in high contrast remains on the screen for an extended period of time, it may leave an 'after-image' or 'ghost image' on front of the screen. This is a well-known phenomenon that is caused by the shortcomings inherent in LCD technology. In most cases, the afterimage will disappear gradually over a period of time after the power has been switched off. Be aware, that the afterimage symptom cannot be repaired and is not covered under warranty.
- Warning for lifting monitor - Do not use the area underneath the logo cover to grip or lift the monitor. Placing weight on the logo cover can cause it to break away from the body and cause the monitor to fall. When lifting the monitor, place one hand under the monitor's frame.



Consult a service technician if the monitor does not operate normally when the operating instructions given in this manual have been followed.

This page deals with problems that can be corrected by the user. If the problem still persists after you have tried these solutions, contact your nearest Philips dealer.

Common Problems	
Having this problem?	Check these items
No Picture (Power LED not lit)	• Make sure the power cord is plugged into the power outlet and into the back of the monitor. • First, ensure that the power button on the front of the monitor is in the OFF position, then press it to the ON position.
No Picture (Power LED is amber or yellow)	• Make sure the computer is turned on. • Make sure the signal cable is properly connected to your computer. • Check to see if the monitor cable has bent pins. • The Energy Saving feature may be activated
Screen says 	• Make sure the monitor cable is properly connected to your computer. (Also refer to the Quick Set-Up Guide). • Check to see if the monitor cable has bent pins. • Make sure the computer is turned on.
AUTO button not working properly	• The Auto Function is designed for use on standard Macintosh or IBM-compatible PCs running Microsoft Windows. • It may not work properly if using nonstandard PC or video card. • The AUTO adjustment does not function when digital input is used for display.
Imaging Problems	
Display position is incorrect	• Press the Auto button. • Adjust the image position using the Horizontal Position and/or Vertical Position in OSD Main Controls.
Image vibrates on the screen	• Check that the signal cable is properly connected to the graphics board or PC.
Vertical flicker appears 	• Press the Auto button. • Eliminate the vertical bars using the Phase/Clock of More Settings in OSD Main Controls.
Horizontal flicker appears 	• Press the Auto button. • Eliminate the vertical bars using the Phase/Clock of More Settings in OSD Main Controls.
The screen is too bright or too dark	• Adjust the contrast and brightness on OSD Main Controls. (The backlight of the LCD monitor has a fixed life span. When the screen becomes dark or begins to flicker, please contact your dealer).
An after-image appears	• If an image remains on the screen for an extended period of time, it may be imprinted in the screen and leave an after-image. This usually disappears after a few hours
An after-image remains after the power has been turned off.	• This is characteristic of liquid crystal and is not caused by a malfunction or deterioration of the liquid crystal. The after-image will disappear after a period of time.
Green, red, blue, dark, and white dots remains	• The remaining dots are normal characteristic of the liquid crystal used in today's technology.
For further assistance, refer to the Consumer Information Centers list and contact your local Philips distributor.	

◀◀ Go to cover page

1. **General points**
 - 1.1 During the test and measuring, supply a distortion free AC mains voltage to the apparatus via an isolated transformer with low internal resistance.
 - 1.2 All measurements mentioned hereafter are carried out at a normal mains voltage (90 - 132 VAC for USA version, 195 - 264 VAC for EUROPEAN version, or 90 - 264 VAC for the model with full range power supply, unless otherwise stated.)
 - 1.3 All voltages are to be measurement or applied with respect to ground, unless otherwise stated.
 - 1.4 The test has to be done on a complete set including LCD panel in a room with temperature of 25 +/- 5 degree C.
 - 1.5 All values mentioned in these test instruction are only applicable of a well aligned apparatus, with correct signal.
 - 1.6 The letters symbols (B) and (S) placed behind the test instruction denotes
 - (B): carried out 100% inspection at assembly line
 - (S): carried out test by sampling
 - 1.7 The white balance (color temperature), has to be tested in subdued lighted room.
 - 1.8 Repetitive power on/off cycle are allowed except it should be avoided within 6 sec.
2. **Input signal**
 - 2.1.1 **PC Signal type**
 - Analog Video : 0.7 Vp-p linear, positive polarity
 - Separate Sync. : TTL level, separate, positive or negative polarity
 - Audio signal : Mini-jack audio input
 - Input level: 500 mVrms ((Speaker output 5Wx2 when Input level > 630mVrms and Volume control at 100%))
 - Signal source: pattern generator format as attachment (table 1 to 11) Reference generator : CHROMA 2200 or 2250
 - 2.1.2 **TV Signal type**
 - RF Signal : Aerial input, NTSC cable and antenna system.
 - Video signal : Cinch input, CVBS with NTSC and PAL system.
 - Level: 1.0Vp-p (0.7V video + 0.3V sync.)
 - S video input: Y/C signal, NTSC and PAL system.
 - Level: Y: 1.0Vp-p (0.7V video + 0.3V sync.)
 - C: +/- 0.3V.
 - Component input: Cinch G/B/R-> YPbPr cinch input.
 - Level: Y: 1.0Vp-p Pb/Pr: +/- 0.35V
 - Audio signal : Side cinch R/L for CVBS and S-video
 - Bottom cinch R/L for component input.
 - Input level: 500 mVrms ((Speaker output 5Wx2 when Input level > 630mVrms and Volume control at 100%))
 - 2.2 **PC Input signal mode**
 - 2.2.1 **PC signal mode:**
 - The maximum resolution display of this monitor is up to 1280x1024, SXGA signal input with full screen display. It shall also automatically up-scale the lower resolution video modes into 1280x1024 full screen display. The display capabilities shall include the following timing modes:
 - (1) Preset modes (30 modes)

#	Resolution	H-freq uency	Pixel rate	V-Freq uency	Comment
1	640X350	31.5K	25.175	70Hz	IBM VGA 10h
2	720X400	31.5K	28.322	70Hz	IBM VGA 3h
3	640X480	31.5K	25.175	60Hz	
4	640X480	35.0K	30.24	67Hz	
5	640X480	37.9K	31.5	72Hz	
6	640X480	37.5K	31.501	75Hz	
7	800X600	35.2K	36	56Hz	
8	800X600	37.9K	40	60Hz	

9	800X600	48.1K	50	72Hz	
10	800X600	46.9K	49.498	75Hz	
11	832X624	49.7K/	57.28	75Hz	MAC
12	960X720	44.76K	57.58	60Hz	
13	960X720	56.4K	72.42	75Hz	
14	1024X768	48.4K	65	60Hz	
15	1024X768	56.5K	75	70Hz	
16	1024X768	60.0K	78.75	75Hz	
17	1024X768	61.1K	83.096	76Hz	IBM XGA-2
18	1152X864	54.0K	79.9	60Hz	Non-VESA
19	1152X864	63.9K	94.5	70Hz	Non-VESA
20	1152X864	67.5K	108	75Hz	
21	1152X870	68.7K	100	75Hz	MAC
22	1152X900	61.8K	92.94	66Hz	SUN Mode IV
23	1152X900	71.8K	108	76Hz	SUN Mode II
24	1280X960	60.0K	108	60Hz	
25	1280X960	75.0K	129.895	75Hz	Non-VESA
26	1280X1024	64.0K	108	60Hz	
27	1280X1024	71.7K	117	67Hz	SUN Mode V
28	1280X1024	76.0K	130.223	72Hz	DOS/V
29	1280X1024	80.0K	135	75Hz	
30	1280X1024	81.1K	135.008	76Hz	SUN Mode I

(2) Factory Preset modes (15 modes)

Monitor in the production line should 100% check following 15 modes and adjust them perfectly.

#	Resolution	H-Freq uency	Pixel rate	V-Freq uency	Comment
1	640X350	31.5KHz	25.175	70Hz	IBM VGA 10h
2	720X400	31.5KHz	28.322	70Hz	IBM VGA 3h
3	640X480	37.5KHz	31.501	75Hz	
4	640X480	35.0KHz	30.24	67Hz	
5	640X480	31.5KHz	25.175	60Hz	
6	800X600	35.2KHz	36	56Hz	
7	800X600	46.9KHz	49.498	75Hz	
8	800X600	37.9KHz	40	60Hz	
9	832X624	49.7KHz	57.28	75Hz	MAC
10	1024X768	60.0KHz	78.75	75Hz	
11	1024X768	48.4KHz	65	60Hz	
12	1152X870	68.7KHz	100	75Hz	MAC
13	1152X900	71.8KHz	108	76Hz	SUN Mode II
14	1280X1024	64.0KHz	108	60Hz	
15	1280X1024	80.0KHz	135	75Hz	

2.3 TV input signal Channel and pattern for AP model (Table1)

Table 1. AP model: AP TV preload Channels

PRG	CH	Frequency Carriers		TV System	Pattern
		Video	Sound		
1	AU37	591.25MHz	597.25MHz	PAL I (UK)	Pure White
2	AU2	64.25MHz	69.75MHz	PAL B (Australia)	Circle Pattern
3	E7	189.25MHz	194.75MHz	PAL B (CCIR)	Circle Pattern
4	G47	679.25MHz	684.75MHz	PAL G (CCIR)	Circle Pattern
5	I23	487.25MHz	493.25MHz	PAL I (UK)	Circle Pattern
6	E12	224.25MHz	229.75MHz	PAL B (CCIR)	Color Bar
7	AU7	182.25MHz	187.75MHz	PAL B (CCIR)	Color Bar
8	G68	847.25MHz	852.75MHz	PAL G (CCIR)	100% White
9	AU9	196.25MHz	201.75MHz	PAL B (Australia) (New Zealand)	Chessboard
10	AU10	209.25MHz	214.75MHz	PAL B (Australia)	Crosshatch
11	AU0	46.25MHz	51.75MHz	PAL B (Australia)	Color Bar
12	AU2	64.25MHz	69.75MHz	PAL B (Australia)	Color Bar
13	AU5	102.25MHz	107.75MHz	PAL B (Australia)	Crosshatch
14	AU5A	138.25MHz	143.75MHz	PAL B (Australia)	Color Bar
15	AU7	182.25MHz	187.75MHz	PAL B (Australia) (New Zealand)	Pure White
16	AU9	196.25MHz	201.75MHz	PAL B (Australia) (New Zealand)	Pure White
17	AU10	209.25MHz	214.75MHz	PAL B (Australia)	Circle Pattern
18	K39	615.25MHz	NICAM 621.10MHZ AM 621.75MHZ	SECAM K1 (France)	Circle Pattern
19	G28	527.25MHz	532.75MHz	PAL G (CCIR)	Circle Pattern
20	AU37	591.25MHz	596.75MHz	PAL G (CCIR)	Circle Pattern
21	I40	623.25MHz	629.25MHz	PAL I (UK)	Color Bar
22	K52	719.25MHz	NICAM 725.10MHZ AM 725.75MHZ	SECAM B/G (France)	Color Bar
23	I60	783.25MHz	789.75MHz	PAL I (UK)	100% White
24	I66	831.25MHz	837.25MHz	PAL I (UK)	Checkerboard
25	K21	471.25MHz	NICAM 477.10MHZ AM 477.74MHZ	SECAM K1 (France)	Crosshatch

Note: It is not necessary to catch good performance in SECAM.

Table 2. Signal Distribution Table (PAL D/K) for China model

PRG	CH	Frequency Carriers		TV System	Pattern
		Video	Sound		
1	C 4	65.75MHz	72.25MHz	PAL D (CCIR)	Full Write
2	E 7	184.25MHz	190.75MHz	PAL D(CCIR)	Circle Pattern
3	E12	224.25MHz	230.75MHz	PAL D(CCIR)	Color Bar
4	K21	471.25MHz	477.75MHz	PAL K (CCIR)	Full Write
5	G34	511.25MHz	517.75MHz	PAL K (CCIR)	Circle Pattern
6	G62	543.25MHz	549.75MHz	PAL K(CCIR)	Color Bar
7	M58	551.25MHz	557.75MHz	PAL K(CCIR)	Crosshatch
8	G47	615.25MHz	621.75MHz	PAL K(CCIR)	Color Bar

3. TV mode display adjustment

3.1 White balance adjustment (B)

General set-up :

Equipment Requirements: Color analyzer.

Input requirements:

Input Signal Type: PAL(B/G)) system frequency=189.25MHz (CH. 3) in AP model, with white pattern of 100 IRE (100%).

PAL(D/K)) system frequency=184.25MHz (CH. 2) in China model, with white pattern of 100 IRE (100%).

Alignment method:

Initial Set-up :

Set TV (7119) Brightness=121; Contrast=66, Saturate=63 in Factory mode (can be fine tuned)

Set Smart picture as "Personal" (Brightness=50, Color=50, Contrast =50)

Apply "100% Full White/100 IRE " pattern by TV pattern generator.

Alignment : Adjust the VIDEO SCALER GAIN R G B in Factory Mode"NORMAL". (See Fig 1.)

[Enter factory menu : press AUTO and OK keys together around six seconds]

The 1931 CIE chromaticity (X, Y) co-ordinates shall be:

Table 3.1: Reading with Minolta CA-110.

Picture Mode	x	y
Normal (Original)	0.289 ± 0.005	0.304 ± 0.005

WARM and COOL will be programmed in software as table 3.2.

Table 3.2: color temp.

	Normal/ the R'G'B' are gain after alignment.	WARM	COOL
R gain	R'	R'	R'-10
G gain	G'	G'-10	G'-10
B gain	B'	B'-10	B'

FACTORY ADJUST MENU

NORMAL

SCALER GAIN R G B ☐ ☒
 AUTO-COLOR (OK)
 ADC OFFSET R G B
 ADC GAIN R G B
 PC OFFSET R G B
 7119 SDTV ☐ SAT ☒ TINT
 TV SHIFT H V
 HD SHIFT H V
☒ SHOW LOCK MESSAGE
 HDTV ADC OFFSET R G B
 HDTV ADC GAIN R G B
 VIDEO SCALER GAIN R G B
 SCALER HUE
 UAC_ISP
 EXIT

Fig-1

◀◀ Go to cover page

4. PC mode display adjustment
- 4.1 Access to factory mode (DDC2B) in auto-alignment system
The communication protocol switches to DDC2B.
- 4.2 Auto color adjustment (B)
Apply a 1024*768/60Hz signal with half black white pattern, set brightness control at 50%, and contrast control at 50%. Adjust the R, G, B, offset, and gain to calibrate the color smoothly and 64-grey level distinguishable.
- 4.3 Adjustment of WHITE-D (B)
Apply a 1280*1024 / 60Hz signal with white pattern, set brightness control at 50%, and contrast control at 50%. Adjust the R, G, B Sub-Gain, for the screen center, the 1931 CIE chromaticity (X, Y) co-ordinates shall be

	9300°K	6500°K
x (center)	0.283 ± 0.020	0.313 ± 0.020
y (center)	0.297 ± 0.020	0.329 ± 0.020

Use Minolta CA-210 for color coordinates and luminance check.
Luminance is > 200 Nits in the center of the screen when brightness at 50% and contrast set to 50%.

- 4.4 Adjustment of sRGB (B)
Apply a 1280*1024/ 60Hz signal with white pattern; brightness (0) and contrast (150) will be preloaded in EEPROM. Adjust the R, G, B Sub-Gain for the screen center, the 1931 CIE chromaticity (X, Y) co-ordinates shall be

	sRGB
x (center)	0.313 ± 0.008
y (center)	0.329 ± 0.008
Ynits	180 ± 10

5. HDTV mode display adjustment
- 5.1 White balance adjustment (B)
General set-up:
Equipment : Quantum Data Pattern Generator 802R.
Apply 1080i, RGBW gray pattern.



(Or FLUKE 54200, apply 576i, DIGITAL SCAN/DIGI_ADC1 pattern.)



Alignment method:

Initial Set-up : Set Smart picture as "Personal", Brightness=50, Color=50, Contrast=50) Set AUTO-COLOR process.
Alignments: Check chromaticity (X, Y) co-ordinates specification:

Picture Mode	x	y
Personal	0.289 ± 0.020	0.304 ± 0.020

If out of specification, fine-tune HDTV ADC Gain in factory mode.
Luminance is 280+/-10% Nits in the center of the screen when brightness at 50% and contrast set to 50%.

6. Preset EEPROM data
- 6.1 EEPROM data has to be preset data according following table.
Factory mode preset.

Function	Preset value		
SCALER GAIN	127	127	127
ADC Offset R/G/B	127	127	127
ADC Gain R/G/B	127	127	127
PC OFFset R/G/B	127	127	127
7119 ☐ brightness	121	(TV,AV,S-video)	
7119 Saturation	63	(TV,AV,S-video)	
7119 ☒ contrast	66	(TV,AV,S-video)	
7119 TINT	24	(TV,AV,S-video)	
		NTSC	PAL
TV shift H	Regul ar	170	186
TV shift V		20	21
HD SHIFT H		See below.	
HD SHIFT V			
HD ADC OFFset R G B		127	127 127
HD ADC GAIN R G B		127	127 127
Video Scaler Gain		127	127 127
Scaler Hue		50	

127 means that it will be programmed after auto-adjusted.
Factory mode:

	480i	480P	576i	576P	720P/ 50Hz	720P/ 60Hz	1080i/ 50Hz	1080i/ 60Hz
HD shift H	92	94	103	103	71	74	38	38
HD shift V	39	40	50	53	39	39	61	59

In user "Picture alignment"

	480i	480P	576i	576P	720P/ 50Hz	720P/ 60Hz	1080i/ 50Hz	1080i/ 60Hz
HD shift H	78	77	75	75	48	47	28	28

6.2 Smart picture & Smart sound:

6.2.1 Final TV mode out box setting.

Smart Picture : MOVIES

Smart Picture

PERSONAL	BRIGHTNESS	50
	COLOR	50
	CONTRAST	50
	SHARPNESS	25
MOVIES	BRIGHTNESS	45
	COLOR	55
	CONTRAST	53
	SHARPNESS	30
SPORTS	BRIGHTNESS	50
	COLOR	65
	CONTRAST	46
	SHARPNESS	36
WEAK SIGNAL	BRIGHTNESS	45
	COLOR	30
	CONTRAST	40
	SHARPNESS	15
MULTIMEDIA	BRIGHTNESS	50
	COLOR	58
	CONTRAST	60
	SHARPNESS	20
NIGHT	BRIGHTNESS	50
	COLOR	55
	CONTRAST	45
	SHARPNESS	20

Smart Sound : Personal

SOUND VOLUME : 50

BASE : 50

TREBLE : 50

Balance : 0

Virtual SURROUND : OFF

AVL : NO

6.2.2 Factory setting (B)

The OSD controls shall have the following factory default values after finishing all the adjustment.

PC MODE :

PICTURE

COLOR TEMP : 6500K

BRIGHTNESS : 50

CONTRAST : 50

AUDIO

SMART SOUND : NEUTRAL

SETTING : TREMBLE (50)

BASS (50)

BALANCE (50)

TV MODE :

PICTURE

SMART PICTURE : MOVIES

AUDIO

SMART SOUND : PERSONAL

SETTING : TREMBLE (50)

BASS (50)

BALANCE (50)

RF CHANNEL: CHANNEL 2

SOURCE : D-SUB

PIP audio source : PC Audio

PIP VIDEO SOURCE : CVBS

PICTURE FORMAT : 4:3

VOLUME : 50

Go to cover page

General

DDC Data Re-programming
In case the DDC data memory IC or main EEPROM which storage all factory settings were replaced due to a defect, the serial numbers have to be re-programmed "Analog DDC IC, Digital DDC IC & EEPROM". It is advised to re-soldered DDC IC and main EEPROM from the old board onto the new board if circuit board have been replaced, in this case the DDC data does not need to be re-programmed.

Additional information
Additional information about DDC (Display Data Channel) may be obtained from Video Electronics Standards Association (VESA). Extended Display Identification Data(EDID) information may be also obtained from VESA.

System and equipment requirements

- 1. An i486 (or above) personal computer or compatible.
- 2. Microsoft operation system Windows 95/98 .
You have to Install the EDID_PORT_Tool under Win2000/XP . As Fig. 1 .

Fig. 1



- A. Copy the "UserPort.sys" to C:\WINNT\system32\drivers(win2000)
C:\WINDOWS\system32\drivers(winXP)

- B. Running " io.exe" everytime, Before you start to programming edid data .

- 3. EDID46.EXE program
- 4. A/D Alignment kits (12NC: 3138 106 10396):
inclusion : a. Alignment box x1 (Fig. 2)




Fig. 2

- b. Printer cable x1
- c. (D-Sub) to (D-Sub) cable x1
- D. (D-Sub) to (DVI) cable x1

Note: The alignment box has already build-in a batteries socket for using batteries (8~12V) as power source. Pull out the socket by remove four screws at the rear of box. Please do not forget that remove batteries after programming. The energy of batteries can only drive circuits for a short period of time.





Fig. 3


Pin assignment

A. 15-pin D-Sub Connector



PIN No.	SIGNAL
1	Red video input
2	Green video input / sync on green
3	Blue video input
4	GND
5	GND - Cable detect
6	Red video GND
7	Green video GND
8	Blue video ND
9	DDC +3.3V or +5V
10	Logic GND
11	GND
12	Serial data line (SDA)
13	H-sync / H+V
14	V-sync
15	Data clock line (SCL)

B. Input DVI -D Connector pin



Pin No.	Description
1	T.M.D.S. data2-
2	T.M.D.S. data2+
3	T.M.D.S. data2 shield
4	No Connect
5	No Connect
6	DDC clock
7	DDC data
8	No Connect
9	T.M.D.S. data1-
10	T.M.D.S. data1+
11	T.M.D.S. data1 shield
12	No Connect
13	No Connect
14	+5V Power
15	Ground (for +5V) - Cable detect
16	Hot plug detect
17	T.M.D.S. data0-
18	T.M.D.S. data0+
19	T.M.D.S. data0 shield
20	No Connect
21	No Connect
22	T.M.D.S clock shield
23	T.M.D.S. clock+
24	T.M.D.S. clock-

Configuration and procedure


There is no Hardware DDC (DDC IC) anymore. Main EEPROM stores all factory settings and DDC data (EDID code) which is also called Software DDC. The following section describes the connection and procedure for Software DDC application. The main EEPROM can be re-programmed by enabling "factory memory data write" function on the DDC program (EDID46.EXE).

Initialize alignment box

In order to avoid that monitor entering power saving mode due to sync will cut off by alignment box, it is necessary to initialize alignment box before running programming software (EDID46.EXE). Following steps show you the procedures and connection.

Step 1: Supply 8-12V DC power source to the Alignment box by plugging a DC power cord .

Step 2: Connecting printer cable and D-Sub cable of monitor as Fig. 4




Step 3: Installation of EDID46.EXE


Method 1: Start on DDC program

Start Microsoft Windows.


1. The Program "EDID46.EXE" in service manual cd-rom be copied to C:\.
2. Click Start, choose Run at start menu of Windows as shown in Fig. 5.




3. At the submenu, type the letter of your computer's hard disk drive followed by :EDID46 (for example, C:\EDID46, as shown in Fig. 6).



4. Click OK button. The main menu appears (as shown in Fig. 7). This is for initialize alignment box.




Note 1: If the connection is improper, you will see the following error message (as shown in Fig. 8) before entering the main menu. Meanwhile, the (read EDID) function will be disabled. At this time, please make sure all cables are connected correctly and fixedly, and the procedure has been performed properly.



Note 2: During the loading, EDID46 will verify the EDID data which just loaded from monitor before proceed any further function, once the data structure of EDID can not be recognized, the following error message will appear on the screen as below. Please confirm following steps to avoid this message.

1. The data structure of EDID was incorrect.
2. DDC IC that you are trying to load data is empty.
3. Wrong communication channel has set at configuration setup windows.
4. Cables loosed or poor contact of connection.



Go to cover page

Re-programming Analog DDC IC

Step 1: After initialize alignment box, connecting all cables and box as shown in Fig. 10.




Fig. 10

Step 2: Read DDC data from monitor

- Click  icon as shown in Fig. 11 from the tool bar to bring up the Channels "Configuration Setup" windows as shown in Fig. 11.




Fig. 11

- Select the DDC2Bi as the communication channel. As shown in Fig. 12.




Fig. 12

- Click OK button to confirm your selection.
- Click  icon (Read EDID function) to read DDC EDID data from monitor. The EDID codes will display on screen as shown in Fig. 13.




Fig. 13

Step 3: Modify DDC data (verify EDID version, week, year)

- Click  (new function) icon from the tool bar, bring up Step 1 of 9 as shown in Fig. 14 . EDID46 DDC application provides the function selection and




Fig. 14

Step 4: Modify DDC data (Monitor Serial No.)

- Click Next , bring up Fig. 15.





Fig. 15

◀ Go to cover page

2. Click Next , bring up Fig.16.



Step 3 of 9 : DPMS and Color Characteristics

Feature Support (DPMS)

DPMS

☐ Stand-by

☐ Suspend

☒ Active Of

Basic display

☐ Monochrome/gray scale disp

☒ RGB color displ

☐ Non-RGB multicolor disp

☐ Undefined

Default

☒ Std. default color space /

☒ Preferred timing m

☐ GTF supported

RGB chromaticity/White point value

Phosphor (0.000 -

Red X 0.639

Y 0.342

Green X 0.297

Y 0.615

Blue X 0.146

Y 0.068


White X 0.313

Y 0.329

< 上一步(B) 下一步(N) > 取消

Fig. 16

5. Click Next , bring up Fig.19.



Step 6 of 9 : Detailed timing and Descriptor descr...

☐ Monitor Descriptor

Pixel Clock (0 - 655.35) 108

H. Active (0 - 4095) 1280

H. Blanking (0 - 4095) 408

V. Active (0 - 4095) 1024

V. Blanking (0 - 4095) 42

H. SyncOffset (0 - 1023) 48

H. SyncWidth (0 - 1023) 112

V. SyncOffset (0 - 63) 1

V. SyncWidth (0 - 63) 3

H. ImageSize (0 - 4095) 338

V. ImageSize (0 - 4095) 270

H. Border (0 - 255) 0

V. Border (0 - 255) 0

Scan Mode

☐ Interlaced / Non-inter

Stereo Mode

☒ No stereo

☐ Field stereo, right im

☐ Field stereo, left ima

☐ 2-way stereo, right im

☐ 2-way stereo, left ima

☐ 4-way interleaved ster

☐ Side-by-Side stereo

Sync. Signal

☐ Analog Composite Sync

☐ Bi-Analog Composite Sy

☐ Digital Composite Sync

☒ Digital Separate Sync


☒ Vsync Positive

☒ Hsync Positive

< 上一步(B) 下一步(N) > 取消

Fig. 19

3. Click Next , bring up Fig.17.



Step 4 of 9 : Established Timings

Established VESA (one-bit flags)

☒ 720x400 @70Hz (IBM, VGA)

☐ 720x400 @88Hz (IBM, XGA2)

☒ 640x480 @60Hz (IBM, VGA)

☒ 640x480 @67Hz (Apple, Mac)

☒ 640x480 @72Hz (VESA)

☒ 640x480 @75Hz (VESA)

☒ 800x600 @56Hz (VESA)

☒ 800x600 @60Hz (VESA)

☒ 800x600 @72Hz (VESA)

☒ 800x600 @75Hz (VESA)

☒ 832x624 @75Hz (Apple, Mac)

☐ 1024x768 @87Hz (Interlaced) C

☒ 1024x768 @60Hz (VESA)

☒ 1024x768 @70Hz (VESA)

☒ 1024x768 @75Hz (VESA)

☒ 1280x1024 @75Hz (VESA)

☒ 1152x870 @75Hz (Apple, Mac)

< 上一步(B) 下一步(N) > 取消

Fig. 17

6. Click Next , bring up Fig. 20.

In this step, please confirm the Descriptor Data Type is Monitor Range Limits, and all the items are same as below.



Step 7 of 9 : Detailed timing and Descriptor descr...

☒ Monitor Descriptor

Descriptor Data Type Monitor Range Limits

Monitor Range

Min. Vertical Rate (0 - 255 Hz) 56

Max. Vertical Rate (0 - 255 Hz) 76

Min. Horizontal (0 - 255 KHz) 30

Max. Horizontal (0 - 255 KHz) 83


Max. Supported Pixel Clock (0 - 140)

☐ Secondary GTF timing formula support

< 上一步(B) 下一步(N) > 取消

Fig. 20

4. Click Next , bring up Fig.18.



Step 5 of 9 : Standard Timing Identification

Standard Timing identification

1280 x 1024 60Hz Aspect ratio = 5:4

Remove

Hx. ActivePixels 0 Add


AspectRatio Replace

Refresh Rate (60 - 123) 0

< 上一步(B) 下一步(N) > 取消

Fig. 18

7. Click Next , bring up Fig. 21.



Step 8 of 9 : Detailed timing and Descriptor descr...

☒ Monitor Descriptor

Descriptor Data Type Monitor Name

Monitor Name : Philips 190G6

< 上一步(B) 下一步(N) > 取消

Fig. 21

Go to cover page

- Click Next , bring up Fig. 22.
 - Click Finish to exit the Step window.
 - Serial number can be filled up at this moment (for example, TY 000814).

NOTE: You must modify the Serial NO. In step 9, otherwise the Serial NO. In OSD Couldn't be modified correctly.




Fig. 22

Step 5: Write DDC data

- Configuration should be as Fig. 23. And press OK.




Fig. 23

2. Access Factory Mode

- Turn off monitor.
- Press power "⏻" button.Then quickly push "OK" and "AUTO",and hold this two buttons , then the screen comes out "Waiting For Automatic Adjustment ",then the screen will be black for one second untill comes out "Windows screen"] => then release this two buttons.
- Press "MENU" button, wait until the OSD menu with Characters "Hudson6 190G6 CHINA V0.35 0508LM190E03" (below OSD menu) come on the Screen of the monitor.



Fig. 24

- Push "Menu" to exit OSD menu.

- Click (Write EDID) icon from the tool bar to write DDC data. Then wait for a few minutes,DDC data will be finished Writing.

Step 6: Save DDC data

Sometimes, you may need to save DDC data as a text file for using in other IC chip. To save DDC data, follow the steps below:

- Click (Save) icon (or click "file"-> "save as") from the tool bar and give a file name as shown in Fig. 25.

The file type is EDID46 file (*.ddc) which can be open in WordPad. By using WordPad, the texts of DDC data & table (128 bytes, hex code) can be modified. If DDC TEXTS & HEX Table ar completely correct, it can be saved as .ddc flie to re-load it into DDC IC for DDC Data application.




Fig. 25

- Click Save.

Step 7: Exit DDC program

Pull down the File menu and select Exit as shown in Fig. 26.




Fig. 26

Step 8: Turn off the monitor, exit the factory mode.

Re-programming Digital DDC IC

Step 1: After initialize alignment box, connecting all cables and box as shown in Fig. 27.




Fig. 27

Step 2: Read DDC data from monitor

1. Click  icon as shown in Fig. 11 from the tool bar to bring up the Channels "Configuration Setup" windows as shown in Fig. 28.




Fig. 28

2. Select the DDC2Bi as the communication channel. As shown in Fig. 29.




Fig. 29




Fig. 30

3. Click OK button to confirm your selection.

4. Click  icon (Read EDID function) to read DDC EDID data from monitor. The EDID codes will display on screen as shown in Fig. 30.

Step 3: Modify DDC data (verify EDID version, week, year)

Click  (new function) icon from the tool bar, bring up Step 1 of 9 as shown in Fig. 31. EDID46 DDC application provides the function selection and text change (select & fill out) from Step 1 to Step 9.



Fig. 31



Fig. 32

Step 4: Modify DDC data (Monitor Serial No.)

1. Click Next, bring up Fig. 32.
2. Click Next, bring up Fig. 33.
3. Click Next, bring up Fig. 34.



Fig. 33



Fig. 34

4. Click Next, bring up Fig. 35.
5. Click Next, bring up Fig. 36.




Fig. 35




Fig. 36

6. Click Next, bring up Fig. 37. In this step, please confirm the Descriptor Data Type is Monitor Range Limits, and all the items are same as below.

7. Click Next, bring up Fig. 38.



Fig. 37



Fig. 38

◀◀ Go to cover page

8. Click Next , bring up Fig. 39.
- Click Finish to exit the Step window.
- Serial number can be filled up at this moment (for example, TY 000814).

NOTE: You must modify the Serial NO. In step 9, otherwise the Serial NO. In OSD Couldn't be modified correctly.




Fig. 39




Fig. 40

Step 5: Write DDC data

1. Configuration should be as Fig. 40. And press OK.
2. Access Factory Mode
 - 1). Turn off monitor.
 - 2). Press power "⏻" button. Then quickly push "OK" and "AUTO", and hold this two buttons , then the screen comes out "Waiting For Automatic Adjustment ", then the screen will be black for one second until comes out "Windows screen" => then release this two buttons.
 - 3). Press "MENU" button, wait until the OSD menu with Characters "Hudson6 190G6 CHINA V0.35 0508LM190E03" (below OSD menu) come on the Screen of the monitor.



Factory Mode indicator

Fig. 41

- 4) Push "Menu" to exit OSD menu.
3. Click  (Write EDID) icon from the tool bar to write DDC data. Then wait for 20-30 seconds ,DDC data will be finished Writing.

Step 6: Save DDC data

Sometimes, you may need to save DDC data as a text file for using in other IC chip. To save DDC data, follow the steps below:

1. Click  (Save) icon (or click "file"-> "save as") from the tool bar and give a file name as shown in Fig. 42.

The file type is EDID46 file (*.ddc) which can be open in WordPad. By using WordPad, the texts of DDC data & table (128 bytes, hex code) can be modified. If DDC TEXTS & HEX Table are completely correct, it can be saved as *.ddc file to re-load it into DDC IC for DDC Data application.




Fig.42

2. Click Save.

Step 7: Exit DDC program

Pull down the File menu and select Exit as shown in Fig. 43.




Fig. 43

Step 8: Turn off the monitor, exit the factory mode.

THE DISPLAY DATA CHANNEL (DDC_2B) CONTENT INCLUDING:
(FOR 190G6 ANALOG FOR LPL PANEL)

EDID log file

Vendor/Product Identification

ID Manufacturer Name : PHL
ID Product Code : C013 (HEX.)
ID Serial Number : 1234 (HEX.)
Week of Manufacture : 27
Year of Manufacture : 2005

EDID Version, Revision

Version : 1
Revision : 3

Basic Display Parameters/Features

Video Input Definition : Analog Video Input
0.700V/0.300V (1.00Vpp)
without Blank-to-Black Setup
Separate Sync
Composite Sync
Without Sync on Green
no Serration required

Maximum H Image Size : 38
Maximum V Image Size : 30

Display Transfer Characteristic : 2.2
(gamma)

Feature Support (DPMS) : no Standby
no Suspend
Active Off

Display Type : RGB color display
Standard Default Color Space : Primary color space
Preferred Timing Mode : Detailed timing block 1

Color Characteristics

Red X coordinate : 0.639
Red Y coordinate : 0.342
Green X coordinate : 0.297
Green Y coordinate : 0.615
Blue X coordinate : 0.146
Blue Y coordinate : 0.068
White X coordinate : 0.313
White Y coordinate : 0.329

Established Timings

Established Timings I : 720 x 400 @ 70Hz (IBM,VGA)
640 x 480 @ 60Hz (IBM,VGA)
640 x 480 @ 67Hz (Apple,Mac II)
640 x 480 @ 72Hz (VESA)
640 x 480 @ 75Hz (VESA)
800 x 600 @ 56Hz (VESA)
800 x 600 @ 60Hz (VESA)

Established Timings II : 800 x 600 @ 72Hz (VESA)
800 x 600 @ 75Hz (VESA)
832 x 624 @ 75Hz (Apple,Mac II)
1024 x 768 @ 60Hz (VESA)
1024 x 768 @ 70Hz (VESA)
1024 x 768 @ 75Hz (VESA)
1280 x 1024 @ 75Hz (VESA)

Manufacturer's timings : 1152 x 870 @ 75Hz (Apple,Mac II)

Standard Timing Identification #1

Horizontal active pixels : 1280
Aspect Ratio : 5:4
Refresh Rate : 60

Detailed Timing #1

Pixel Clock (MHz) : 108

H Active (pixels) : 1280
H Blanking (pixels) : 408
V Active (lines) : 1024
V Blanking (lines) : 42
H Sync Offset (F Porch) (pixels) : 48
H Sync Pulse Width (pixels) : 112
V Sync Offset (F Porch) (lines) : 1
V Sync Pulse Width (lines) : 3
H Image Size (mm) : 338
V Image Size (mm) : 270
H Border (pixels) : 0
V Border (lines) : 0
Flags : Non-interlaced
: Normal Display, No stereo
: Digital Separate sync.
: Positive Vertical Sync.
: Positive Horizontal Sync.

Monitor Descriptor #2

Serial Number : TY 123456

Monitor Descriptor #3

Monitor Name : Philips 190G6

Monitor Descriptor #4

Monitor Range Limits
Min. Vt rate Hz : 56
Max. Vt rate Hz : 76
Min. Horiz. rate kHz : 30
Max. Horiz. rate kHz : 83
Max. Supported Pixel : 140

No secondary GTF timing formula supported.

Extension Flag : 0

Check sum : 0B (HEX.)

EDID data (128 bytes)

0:00 1:ff 2:ff 3:ff 4:ff 5:ff 6:ff 7:00
8:41 9:0c 10:13 11:c0 12:34 13:12 14:00 15:00
16:1b 17:0f 18:01 19:03 20:0c 21:26 22:1e 23:78
24:2e 25:a2 26:a5 27:a3 28:57 29:4c 30:9d 31:25
32:11 33:50 34:54 35:bf 36:ef 37:80 38:81 39:80
40:01 41:01 42:01 43:01 44:01 45:01 46:01 47:01
48:01 49:01 50:01 51:01 52:01 53:01 54:30 55:2a
56:00 57:98 58:51 59:00 60:2a 61:40 62:30 63:70
64:13 65:00 66:52 67:0e 68:11 69:00 70:00 71:1e
72:00 73:00 74:00 75:ff 76:00 77:20 78:54 79:59
80:20 81:20 82:31 83:32 84:33 85:34 86:35 87:36
88:0a 89:20 90:00 91:00 92:00 93:fc 94:00 95:50
96:68 97:69 98:6c 99:69 100:70 101:73 102:20 103:31
104:39 105:30 106:47 107:36 108:00 109:00 110:00 111:fd
112:00 113:38 114:4c 115:1e 116:53 117:0e 118:00 119:0a
120:20 121:20 122:20 123:20 124:20 125:20 126:00 127:0b

◀◀ Go to cover page

THE DISPLAY DATA CHANNEL (DDC_2B) CONTENT INCLUDING:
(FOR 190G6 DIGITAL FOR LPL PANEL)

EDID log file

Vendor/Product Identification

ID Manufacturer Name : PHL
ID Product Code : C013 (HEX.)
ID Serial Number : 1234 (HEX.)
Week of Manufacture : 27
Year of Manufacture : 2005

EDID Version, Revision

Version : 1
Revision : 3

Basic Display Parameters/Features

Video Input Definition : Digital Video Input

Maximum H Image Size : 38
Maximum V Image Size : 30

Display Transfer Characteristic : 2.2
(gamma)

Feature Support (DPMS) : no Standby
no Suspend
Active Off

Display Type : RGB color display
Standard Default Color Space : Primary color space
Preferred Timing Mode : Detailed timing block 1

Color Characteristics

Red X coordinate : 0.639
Red Y coordinate : 0.342
Green X coordinate : 0.297
Green Y coordinate : 0.615
Blue X coordinate : 0.146
Blue Y coordinate : 0.068
White X coordinate : 0.313
White Y coordinate : 0.329

Established Timings

Established Timings I : 720 x 400 @70Hz (IBM,VGA)
640 x 480 @60Hz (IBM,VGA)
640 x 480 @67Hz (Apple,Mac II)
640 x 480 @72Hz (VESA)
640 x 480 @75Hz (VESA)
800 x 600 @56Hz (VESA)
800 x 600 @60Hz (VESA)

Established Timings II : 800 x 600 @72Hz (VESA)
800 x 600 @75Hz (VESA)
832 x 624 @75Hz (Apple,Mac II)
1024 x 768 @60Hz (VESA)
1024 x 768 @70Hz (VESA)
1024 x 768 @75Hz (VESA)
1280 x 1024 @75Hz (VESA)

Manufacturer's timings : 1152 x 870 @75Hz (Apple,Mac II)

Standard Timing Identification #1

Horizontal active pixels : 1280
Aspect Ratio : 5:4
Refresh Rate : 60

Detailed Timing #1

Pixel Clock (MHz) : 108
H Active (pixels) : 1280
H Blanking (pixels) : 408
V Active (lines) : 1024
V Blanking (lines) : 42
H Sync Offset (F Porch) (pixels) : 48
H Sync Pulse Width (pixels) : 112
V Sync Offset (F Porch) (lines) : 1

V Sync Pulse Width (lines) : 3
H Image Size (mm) : 338
V Image Size (mm) : 270
H Border (pixels) : 0
V Border (lines) : 0
Flags : Non-interlaced
: Normal Display, No stereo
: Digital Separate sync.
: Positive Vertical Sync.
: Positive Horizontal Sync.

Monitor Descriptor #2

Serial Number : TY 123456

Monitor Descriptor #3

Monitor Name : Philips 190G6

Monitor Descriptor #4

Monitor Range Limits

Min. Vt rate Hz : 56
Max. Vt rate Hz : 76
Min. Horiz. rate kHz : 30
Max. Horiz. rate kHz : 83
Max. Supported Pixel : 140

No secondary GTF timing formula supported.

Extension Flag : 0


Check sum : 09 (HEX.)

EDID data (128 bytes)

0: 00 1: ff 2: ff 3: ff 4: ff 5: ff 6: ff 7: 00
8: 41 9: 0c 10: 13 11: c0 12: 34 13: 12 14: 00 15: 00
16: 1b 17: 0f 18: 01 19: 03 20: 80 21: 26 22: 1e 23: 78
24: 2e 25: a2 26: a5 27: a3 28: 57 29: 4c 30: 9d 31: 25
32: 11 33: 50 34: 54 35: bf 36: ef 37: 80 38: 81 39: 80
40: 01 41: 01 42: 01 43: 01 44: 01 45: 01 46: 01 47: 01
48: 01 49: 01 50: 01 51: 01 52: 01 53: 01 54: 30 55: 2a
56: 00 57: 98 58: 51 59: 00 60: 2a 61: 40 62: 30 63: 70
64: 13 65: 00 66: 52 67: 0e 68: 11 69: 00 70: 00 71: 1e
72: 00 73: 00 74: 00 75: ff 76: 00 77: 20 78: 54 79: 59
80: 20 81: 20 82: 31 83: 32 84: 33 85: 34 86: 35 87: 36
88: 0a 89: 20 90: 00 91: 00 92: 00 93: fc 94: 00 95: 50
96: 68 97: 69 98: 6c 99: 69 100: 70 101: 73 102: 20 103: 31
104: 39 105: 30 106: 47 107: 36 108: 00 109: 00 110: 00 111: fd
112: 00 113: 38 114: 4c 115: 1e 116: 53 117: 0e 118: 00 119: 0a
120: 20 121: 20 122: 20 123: 20 124: 20 125: 20 126: 00 127: 97

Philips' Flat Panel Monitors Pixel Defect Policy

Philips strives to deliver the highest quality products. We use some of the industry's most advanced manufacturing processes and practice stringent quality control. However, pixel or sub pixel defects on the TFT LCD panels used in flat panel monitors are sometimes unavoidable. No manufacturer can guarantee that all panels will be free from pixel defects, but Philips guarantees that any monitor with an unacceptable number of defects will be repaired or replaced under warranty. This notice explains the different types of pixel defects and defines acceptable defect levels for each type. In order to qualify for repair or replacement under warranty, the number of pixel defects on a TFT LCD panel must exceed these acceptable levels. For example, no more than 0.0004% of the sub pixels on a 15" XGA monitor may be defective. Furthermore, Philips sets even higher quality standards for certain types or combinations of pixel defects that are more noticeable than others. This policy is valid worldwide.

**Pixels and Sub pixels**


A pixel, or picture element, is composed of three sub pixels in the primary colors of red, green and blue. Many pixels together form an image. When all sub pixels of a pixel are lit, the three colored sub pixels together appear as a single white pixel. When all are dark, the three colored sub pixels together appear as a single black pixel. Other combinations of lit and dark sub pixels appear as single pixels of other colors.

Types of Pixel Defects

Pixel and sub pixel defects appear on the screen in different ways. There are two categories of pixel defects and several types of sub pixel defects within each category. Bright dot defects appear as pixels or sub pixels that are always lit or 'on'. These are the types of bright dot defects:



Black Dot Defects Black dot defects appear as pixels or sub pixels that are always dark or 'off'. These are the types of black dot defects:

**Proximity of Pixel Defects**

Because pixel and sub pixels defects of the same type that are near to one another may be more noticeable, Philips also specifies tolerances for the proximity of pixel defects.

Pixel Defect Tolerances

In order to qualify for repair or replacement due to pixel defects during the warranty period, a TFT LCD panel in a Philips flat panel monitor must have pixel or sub pixel defects exceeding the tolerances listed in the following tables.

BRIGHT DOT DEFECTS	ACCEPTABLE LEVEL
MODEL	190G6
1 lit subpixel	3 or fewer
2 adjacent lit subpixels	1 or fewer
3 adjacent lit subpixels (one white pixel)	0
Distance between two bright dot defects*	25 mm or more
Total bright dot defects of all types	3 or fewer

* Bright Dot is defined as dots (sub-pixels) which appeared brightly in the screen when the LCM displayed with whole pattern & Bright Dot's brightness is defined over 50% of the brightness against around. (but, Green bright dot is over 30% of brightness against around)

* Here in Tiny Bright Dot is defined as "for Red and Blue" the bright area should be no longer than 1/2 sub-pixel and for green the bright area should be no longer than 1/3 sub-pixel.

BLACK DOT DEFECTS	ACCEPTABLE LEVEL
MODEL	190G6
1 dark subpixel	5 or fewer
2 adjacent dark subpixels	2 or fewer
3 adjacent dark subpixels	0
Distance between two black dot defects*	15 mm or more
Total black dot defects of all types	5 or fewer

TOTAL DOT DEFECTS	ACCEPTABLE LEVEL
MODEL	190G6
Total bright or black dot defects of all types	5 or fewer

Note:

* 1 or 2 adjacent sub pixel defects = 1 dot defect

All Philips monitors are ISO13406-2 Compliant


Update UAC3556 FW By USB Cable

◀◀ Go to cover page


UAC ISP Tool:

There are two files in the pdf file. Firstly use "Install.exe", then "UAC355x8-SDK.exe".


Before start to updating, Make sure you switch to "D-SUB" mode already.



Step 1. Use Factory key (Menu + Auto) from 190G6's Base. Click until Screen flashed.



Step 2. Click Menu key to enter OSD and then goes to last item to click Right key to enter Factory Menu.



Step 3. Use Up or Down key to "UAC ISP" item. To Click Menu key and then "ON" will be showed after "UAC ISP".




Step 4. Switch-off-on AC Power. Plug USB.

Step 5. Use Factory key (Menu + Auto) from 190G6's Base. Click until Screen flashed, again.


Step 6. To execute "load.vi2c".




Step7. To set Hex file's folder.





Step 8. Click Load



Step9.1. Finished. Switch-off-on AC power.




Step 9.2. Failed. Make sure Switch-off-on AC power from Adapter. If still cannot update, switch off power for a while. And then retry Step1~Step 7.



Step 10. Verify Hex file

Make sure Win XP was update with Service Pack 2.

Switch on the AC power and G6 should stay at D-SUB mode, and then plug USB cable to PC. Check the version number in Device Management window.



Configuration and procedure

"Easywriter " The software is provided by Novatek to upgrade the firmware of CPU.

It is a windows-based program, which cannot be run in MS-DOS.
DDC2BI_ISP TOOL (3138 149 53161) is for the interface between
"Parallel Port of PC" and "15 pin-D-SUB connector of Monitor".

System and equipment requirements

1. An i486 (or above) personal computer or compatible.
2. Microsoft operation system Windows 95/98/2000/XP.
3. ISP Software " Easywrite "
4. DDC2BI_ISP TOOL (3138 106 10396) as shown in Fig. 1




Fig. 1




Fig. 4

Step 5 :Copy the G6_CHINA_V100_20050905 to C:\320WN6 as shown in Fig. 5 .




Fig. 5

5. Connect DDC2BI_ISP TOOL and Mains cord to Monitor as shown in Fig. 2.




Fig.2

6. Install and setup the Easywriter program

Step 1 : Make a folder in your PC as shown in Fig. 3.

For example : C:\190G6

Step 2 : Copy ISP Software Easywriter.zip into your folder as shown in Fig.3.

Step 3 : Unzip Easywriter.zip into your folder as shown in Fig. 3.

Step 4 : Double click the EasywriterV2.09a_user.exe icon to install the Application as Fig. 4.




Fig. 3

Update the firmware

1. Double click the Easywriter.exe icon in desktop then appears window as shown in Fig.7 .



Fig. 6




Fig. 7

2. Press the Load hex then select the hex as shown in Fig. 8.

ISP Instructions

Go to cover page




Fig. 8

3 Press the AUTO to running program ,the firmware be updated as shown in Fig. 9~10.




Fig. 9




Fig. 10

4 Press the file --> exit to end program , as shown in Fig. 11.




Fig. 11

If there is a warring message coming as shown in Fig 12. , you have to check the AC power, Video cable, or Novatek MCU.




Fig. 12

Access Factory Mode

- 1). Turn off monitor.
- 2). Press power " " button. Then quickly push "OK" and "AUTO", and hold this two buttons , then the screen comes out "Waiting For Automatic Adjustment ", then the screen will be black for one second untill comes out "Windows screen"] => then release this two buttons.
- 3). Press "OK" button, wait until the OSD menu come on the Screen of the monitor. You will find, after upgrade, the version have already changed from The former "Hudson6 190G6 CHINA V0.35 0508LM190E03" to the Present "Hudson6 190G6 CHINA V100 050905 LM190E03" as shown in Fig. 13 and Fig. 14.



Fig. 13

Factory Mode indicator




Fig. 14


Factory Mode indicator

4) Turn off the monitor, exit the factory mode.

Notes:


If you want to update the ISP hex code ,you must update the UAC3556 FW first.

Wiring Diagram




Block Diagram

190G6 block function




Architecture of WE boards




Block Diagram

Architecture of AP/China boards




Block Diagram

Block Diagram of Scaler




Block of Audio board




190G6 LCD/TV 37

all rights reserved. reproduction in whole or in parts is prohibited without the written consent of the copyright owner.







1318 C8	3244 C6	1281 A4
1322 A13	3245 B6	1282 B7
1333 B13	3246 B8	1283 F8
1343 B13	3247 F8	1284 B7
1353 B13	3248 B8	1285 F8
1363 B13	3249 F5	1286 F8
1373 B13	3250 F5	1287 B6
1383 B13	3251 C5	1288 F8
1393 B13	3252 C5	1289 B4
1403 B13	4201 D12	1290 B6
1411 B13	4202 D13	1291 F8
1421 B13	5201 F1	1292 B6
1431 B13	5202 G1	1293 F8
1441 G5	6203 H1	1294 B4
1502 A13	5204 D1	1295 B6
1503 A13	5205 E1	1296 F8
1503 F1	5206 H3	1297 E2
1503 G1	5207 H1	1298 B6
1503 H1	5208 H1	1299 B6
1504 G1	5211 D12	1300 B4
1525 G2	7201 A7	1301 F8
1526 H1	7202 A7	1302 G7
1527 H1	7203 A7	1303 F8
1528 H2	7203 B1	1304 F5
1529 F2	7204 C1	1305 F8
1531 E1	7213 B13	1306 C4
1531 F1	7214 C13	1307 F8
1532 E2	7215 C13	1308 B8
1532 E2	7216 C13	1309 D9
1534 E2	7217 C13	1310 F5
1535 E2	7218 C13	1311 D9
1536 E3	7219 C13	1312 D8
1537 E3	7220 C13	1313 D8
1538 E2	7221 C13	1314 D8
1539 E1	7222 C13	1315 I1
1539 E1	7223 C13	1316 F8
1541 E2	7224 D13	1317 F8
1542 E2	7205 D8	1318 E8
1543 E2	7206 D8	1319 E8
1543 E2	7207 D8	1320 E8
1544 E2	7208 D8	1321 E8
1545 E2	7209 D8	1322 E8
1546 E2	7210 D8	1323 E8
1547 E2	7211 A2	1324 E8
1548 E2	7212 C7	1325 E8
1549 E2	7213 C7	1326 H3
1550 E2	7214 C6	1327 E8
1551 E2	7215 C7	1328 F8
1552 E2	7216 C7	1329 I3
1553 E2	7217 C7	
1554 E2	7218 C7	
1555 E2	7219 C7	
1556 E2	7220 C7	
1557 E6	7221 C7	
1558 E6	7222 C7	
1559 E6	7223 C7	
1560 E1	7224 F7	
1561 E1	7225 F7	
1562 E1	7226 F7	
1563 E3	7227 F7	
1564 E3	7228 F7	
1565 F3	7229 F7	
1566 F3	7230 F7	
1567 F3	7231 F7	
1568 F3	7232 F7	
1569 F3	7233 F7	
1570 F3	7234 F7	
1571 F3	7235 F7	
1572 F3	7236 F7	
1573 F3	7237 F7	
1574 F3	7238 F7	
1575 F3	7239 F7	
1576 F3	7240 F7	
1577 F3	7241 F7	
1578 F3	7242 F7	
1579 F3	7243 F7	
1580 F3	7244 F7	
1581 F3	7245 F7	
1582 F3	7246 F7	
1583 F3	7247 F7	
1584 F3	7248 F7	
1585 F3	7249 F7	
1586 F3	7250 F7	
1587 F3	7251 F7	
1588 F3	7252 F7	
1589 F3	7253 F7	
1590 F3	7254 F7	
1591 F3	7255 F7	
1592 F3	7256 F7	
1593 F3	7257 F7	
1594 F3	7258 F7	
1595 F3	7259 F7	
1596 F3	7260 F7	
1597 F3	7261 F7	
1598 F3	7262 F7	
1599 F3	7263 F7	
1600 F3	7264 F7	
1601 F3	7265 F7	
1602 F3	7266 F7	
1603 F3	7267 F7	
1604 F3	7268 F7	
1605 F3	7269 F7	
1606 F3	7270 F7	
1607 F3	7271 F7	
1608 F3	7272 F7	
1609 F3	7273 F7	
1610 F3	7274 F7	
1611 F3	7275 F7	
1612 F3	7276 F7	
1613 F3	7277 F7	
1614 F3	7278 F7	
1615 F3	7279 F7	
1616 F3	7280 F7	

B SCALER BOARD
SB : 61541 x 2
PB : 61551

CHN		CA-		SETNAME		LCD SH66			
CLASS_NO				SCALER		190G6FB/97		1 _____ _____ _____ _____ _____	
_____ _____ _____ _____ _____ _____									
2005-08-12		A							
NAME Sophia Hsia / Joss Hong				SUPERS.		11		10	
TY				CHECK		DATE 2005-08-12		☐ ROYAL PHILIPS ELECTRONICS N.V. 2005	
								130 - 2	
								A2	

Scaler Diagram-3


190G6 LCD/TV

39

Go to cover page

PHILIPS

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.




SCALER BOARD

SB: 61541 x2
PB: 61551


CHN	CA-	SETNAME	LCD SH66
CLASS_NO		DRAM	
		190G6FB/97	
		3138 158 6056	
NAME	Sophia Hsia / Joss Hung	SUPERS.	11
TY	CHECK	DATE	2005-08-12
			10
			130
			A3
			ROYAL PHILIPS ELECTRONICS N.V. 2005

Scaler Diagram-4

Go to cover page




- U4 F4
- U5 C4
- U6 D4
- U7 G4
- U8 F4
- U9 A4
- U10 D4
- U11 E4
- U13 F4
- U14 B4
- U15 A5
- U16 B5
- U46 H4
- U47 A7
- U48 B7
- U52 E7
- U53 A11
- U54 B11
- U55 C11
- U56 D11
- U57 D11
- U58 E11
- 1401-1 F2
- 1401-2 G2
- 1401-3 H2
- 1402-1 E2
- 1402-2 F2
- 1403-1 C2
- 1403-2 D2
- 1403-3 D2
- 1404-1 A9
- 1405 A2
- 1406 F9
- 1407 F7
- 1410 B10
- 1411 B8
- 1412 C0
- 1413 C8
- 1414 C10
- 1415 D8
- 1416 E8
- 1417 E10
- 1418 E8
- 1419 E10
- 1420 B8
- 2401 B4
- 2402 B5
- 2403 B7
- 2404 B10
- 2405 B11
- 2406 B4
- 2407 B5
- 2408 B7
- 2409 C10
- 2410 C11
- 2411 C7
- 2412 C4
- 2413 C11
- 2414 C2
- 2415 D7
- 2416 D4
- 2417 D2
- 2418 E4
- 2419 D7
- 2420 E11
- 2421 E2
- 2422 E2
- 2423 E4
- 2424 E11
- 2425 F2
- 2426 F4
- 2428 G4
- 2429 G2
- 2431 G2
- 2432 G4
- 2433 H2
- 2434 H4
- 3401 A7
- 3402 A4
- 3403 B4
- 3404 B7
- 3405 B11
- 3406 B4
- 3407 B7
- 3408 B4
- 3409 B7
- 3410 C11
- 3411 C7
- 3412 C7
- 3413 C4
- 3414 C11
- 3415 C7
- 3416 D7
- 3417 D4
- 3418 D11
- 3419 D10
- 3420 D7
- 3421 D10
- 3422 E7
- 3423 E4
- 3424 E10
- 3425 E4
- 3426 E11
- 3427 F4
- 3430 F11
- 3431 F4
- 3432 G4
- 3435 G11
- 3436 G4
- 3437 H4
- 3438 E10
- 3439 A10
- 3440 B10
- 3441 C10
- 3443 F7
- 3446 G11
- 4401 E3
- 4402 F3
- 4405 G3
- 4408 H3
- 4409 F2
- 5401 A4
- 5402 B4
- 5403 C7
- 5404 C3
- 5405 C7
- 5406 D3
- 5407 D3
- 5408 D7
- 5409 E7
- 5410 E10
- 5412 F3
- 6401 B3
- 6402 B3
- 6403 C3
- 6404 D3
- 6405 E3
- 6406 G3
- 7401 D11
- F023 A2
- F024 B2
- F025 B3
- F026 F2
- F028 E2
- F031 F2
- FXXX F10
- U224 E10
- U225 F11
- U230 G11
- U232 G2
- U233 H2
- U234 D2
- U235 D2
- U236 C2
- U237 A8
- U238 A10
- U240 B10
- U241 B8
- U242 B9
- U243 C8
- U244 C8
- U245 C9
- U246 D8
- U247 D9
- U274 C9
- U275 B9
- U276 F10
- U277 F10




Scaler Diagram-6

PHILIPS

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.



PHILIPS




Ref Des	Reserved
2711	223886715479 47n
2712	223886715479 47n
2713	223886715479 47n
3707	232270260182 1K5
3708	232270260182 1K5
3709	232270260182 1K5
8701	con-1pin-032
8702	con-1pin-032
8703	con-1pin-032

EXCEPT 8701, 8702, 8703 WERE CHIP COMPONENTS.

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright



U22 B4	U143 D4
U32 B4	U144 C4
U22 C2	U160 C4
U28 D3	U162 C4
U31 B4	U166 C4
U49 C6	U180 C4
U50 B6	U197 C4
U51 B6	U202 C6
U59 C8	U226 D6
U60 C8	U227 D3
U63 C8	U228 C1
U64 C8	U229 C6
U80 D6	U231 C6
U87 C1	
U88 D4	
U89 D4	
U90 B6	
U91 B6	
U92 A5	
1031 C7	
1032 D7	
1033 A4	
2051 A8	
2052 A8	
2053 A3	
2054 A5	
2055 B3	
2056 B3	
2057 C1	
2058 D3	
2059 D2	
3051 A4	
3054 B4	
3056 C8	
3057 C8	
3058 C1	
3059 C3	
3060 C3	
3061 C3	
3064 C1	
3065 C2	
3066 C2	
3067 C3	
3068 D6	
3069 D6	
3070 D3	
3071 D3	
3072 D3	
3073 D8	
3074 D8	
3075 D1	
3076 D1	
3077 D1	
4001 B6	
4002 B6	
5051 A5	
7051 A7	
7052 B5	
7053 B3	
7054 C1	
7055 D2	
F104 D7	
F105 D7	
F106 D7	
F107 D7	
U139 D6	



EXCEPT 1031, 1032, 7055 WERE CHIP COMPONENTS.


Ref Des	Reserved
2056	223858615623 1n0
3072	232270260101 100R

CHN		CA-		SETNAME		LCD SH6G													
CLASS_NO				MCU 190G6FB/97						3138 158 6056						1	-----		
2005-08-12														3					
NAME Sophia Hsia / Joss Hung				SUPERS.				11		10		130 - 8					A3		
TY				CHECK		DATE 2005-08-12				©		ROYAL PHILIPS ELECTRONICS N.V. 2005							

Scaler Diagram-9

PHILIPS

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.







U61 F2	6006 E4
U62 C4	7001 A7
1001 A1	7004 C6
1002 B1	7005 C3
1003 D1	7006 D6
1005 F1	7007 C3
1006 F1	7008 D3
2001 A6	7009 E7
2002 A6	7010 E3
2003 B1	7011 F6
2004 B1	7012 E3
2005 A8	7013 F3
2006 C6	7010 A0
2007 C1	F111 A4
2008 C1	F112 A1
2010 C1	F113 A1
2011 C1	F114 A1
2012 C7	F115 A1
2013 A8	F116 A1
2015 B1	F117 A1
2016 B1	F118 A7
2018 D1	F119 A1
2019 D1	F120 A1
2021 D1	F121 B1
2022 D2	F122 B1
2023 D1	F123 B1
2024 D1	F124 B1
2025 F6	F125 B1
2026 F8	F126 B1
2027 F1	F127 C1
2028 F1	F128 C1
2029 F2	F129 D1
2030 F2	F130 D1
3002 A1	F131 D1
3003 A1	F132 D1
3004 B3	F133 D1
3005 A1	F134 D1
3006 A1	F135 D1
3007 A1	F136 D1
3009 C3	F137 D1
3010 B2	F138 D1
3011 B2	F139 F1
3012 C5	F140 F1
3013 A1	F141 F1
3014 A1	F142 F1
3015 D5	F143 F1
3016 C3	U113 C6
3017 D2	U114 C7
3018 D2	U115 D5
3019 D3	U116 D6
3021 E3	U137 D4
3022 D3	U138 D4
3025 D2	U140 A7
3026 D2	U141 A7
3029 D2	U142 A8
3030 D3	U145 F7
3031 D2	U146 F7
3032 E6	U147 F6
3036 E3	U148 F8
3039 F3	U149 C3
3040 F2	U150 D3
3041 F2	U151 D3
3042 F3	U152 E3
3043 F1	U153 F3
3045 A6	U154 D2
3046 A5	U155 D2
4051 A8	U156 D2
4053 F6	U157 D2
5001 A8	U158 F3
5002 A8	U159 F2
5003 E8	U315 E4
6001 A7	U358 A2
6003 C4	
6004 D4	
6005 D4	

SB : 61541 x 2
PB : 61551

CHN		CA-		SETNAME		LCD SH6G												
CLASS_NO		DC-DC /SWITCH 190G6FB/97						3138 158 6056		1		-----						
<table border="1"><tr><td colspan="2" rowspan="2"></td><td rowspan="2">3</td></tr><tr></tr><tr><td colspan="2">2005-08-12</td></tr></table>												3	2005-08-12					
															3			
2005-08-12																		
NAME		Sophia Hsia / Joss Hung		SUPERS.		11		10		130 - 10		A3						
TY		CHECK		DATE		2005-08-12		© ROYAL PHILIPS ELECTRONICS N.V. 2005										

Scaler Diagram-11

PHILIPS

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.



F

D


G

E


H

I


J



ALL RIGHTS ARE RESERVED. REPRODUCTION IN WHOLE OR IN PART IS PROHIBITED WITHOUT THE WRITTEN CONSENT OF THE COPYRIGHT OWNER.




CN: CA-		190G6																
CLASS NO. 3XX000		Scaler+TV Board LCD 190G6				3138 103 6154						I	2005-08-12					
1 2 3																		
2005-08-12																		
NAME Sophia/Joss		SUPERS		2		10		132 - 1				A3						
TY		CHECK		DATE 2005-08-12		©		ROYAL PHILIPS ELECTRONICS N.V.										


PHILIPSALL RIGHTS ARE RESERVED. REPRODUCTION IN
WHOLE OR IN PART IS PROHIBITED WITHOUT THE
WRITTEN CONSENT OF THE COPYRIGHT OWNER.

190G6 LCD/TV
Scaler+TV Board
LCD 190G6
3138 103 6154
2005-08-12
A3


CN: CA-		190G6			
CLASS NO 3XX000		Scaler+TV Board LCD 190G6		1 2005-08-12	
2005-08-12					
NAME Sophia/Joss		SUPERS		2	10
					132 - 2
TY		CHECK		DATE 2005-08-12	© ROYAL PHILIPS ELECTRONICS N.V.
					A3

Inverter Diagram






NO:LVP-2001 REV:D 2004-09-15 K2AM R3DL102




NO:LVP-2001 REV:D 2004-09-15 K2AM R3DL102



Two right triangles are shown side-by-side, sharing a common horizontal base. The total length of the base is labeled as 7.

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.




A


SB : 61031 x 2
PB : 61041

CHN		CA-		SETNAME		SH66							
CLASS_NO		AUDIO - DC TO DC 190G6FB/97						3138 158 6058		1	-----		
2005-08-12	3												
NAME Sophia Hsia/Sndy Yuan				SUPERS.			3	10		130 - 1			A3
TY			CHECK	DATE 2005-08-12				©	ROYAL PHILIPS ELECTRONICS N.V. 2005				

A	U10 B2	3994 D7
	U18 D1	3995 D7
	U19 A2	3996 D7
	U20 A2	3997 E7
	U21 A2	5971 C2
	U22 B8	5982 D3
	U23 E1	5983 D4
	U24 B8	6982 E3
	U25 C2	7981 D2
	U26 D2	F951 A1
B	U27 D3	F952 A2
	1951 A1	F953 A2
	1952 C2	F954 A2
	1959 A7	F955 A2
	1960 A7	F956 B2
	1961 A7	F957 B2
	1971-1 C1	F961 B7
	1971-2 C1	F962 B7
	1971-3 C1	F963 B7
	1991 D8	F971 C1
C	2951 B2	F972 C1
	2952 B3	F991 D7
	2953 B3	F992 D7
	2954 B3	F993 D7
	2955 B3	F994 D7
	2956 B3	F995 D7
	2957 B2	F996 D7
	2958 B2	F997 E7
	2962 B8	F998 E7
	2963 B8	1981 C3
D	2975 C3	1982 E2
	2976 C3	1983 D4
	2981 E1	
	2983 E3	
	2990 C6	
	2991 E6	
	2992 E6	
	2993 E6	
	2994 E6	
	2995 E6	
E	2996 E6	
	2997 E7	
	3952 A2	
	3953 A2	
	3954 A2	
	3955 A2	
	3956 A2	
	3957 B2	
	3958 B2	
	3961 B7	
	3962 B7	
	3963 B7	
	3981 E1	
	3983 E3	
	3984 C6	
	3985 C6	
	3986 C6	
	3987 C6	
	3988 C6	
	3989 C6	
3990 C7		
3991 D7		
3992 D7		
3993 D7		

EXCEPT 1625, 1631, 1635, 7620 WERE CHIP COMPONENTS.







ALL RIGHTS ARE RESERVED. REPRODUCTION IN WHOLE OR IN PART IS PROHIBITED WITHOUT THE WRITTEN CONSENT OF THE COPYRIGHT OWNER.




CN: CA-		190G6									
CLASS NO. 3XX000		Audio+USB Board		1		2005-08-08					
		LCD 190G6		3138 103 6103							
2005-08-08											
NAME Kurtz ko/Stella		SUPERS		2		10		132 - 2		A3	
TY		CHECK		DATE 2005-08-08		©		ROYAL PHILIPS ELECTRONICS N.V.			

Power Diagram

190G6 LCD/TV


57

Go to cover page




MODEL: LVP-2001_SOP_04


Title LIEN CHANG		
Draw D6	Number LVP-2001	PCB Rev D
Date 02/28/2005	Drawn by Peter Chen	
Filename LVP-2001-D.SCH	Sheet 1	of 1



NO:LVP-2001 REV:D 2004-09-15 X2AM R3D102




NO:LNP-2001 REV:D 2004-09-15 K2AM REDJ02




[Go to cover page](#)

Drill Table			
Hole Dia (mm)	Symbol	Quantity	Plated
1.000	+	68	Yes
1.200	X	26	Yes
3.500	Y	1	Yes



NO:LVP-2001 REV:D 2004-09-15




NO:LVP-2001 REV:D 2004-09-15 SILK SCREEN COMPONENT SIDE

Go to cover page

PHILIPS

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright owner.



U0 E1
U6 B2
U7 C2
U8 D2
U9 A2
U10 A2
U11 E1
U12 E1
U13 E1
U14 E1
U15 E1
U16 E1
1601-1 A1
1601-2 A1
1602-1 B1
1602-2 C1
1602-3 D1
1603 A1
1604 B1
1605 C1
1606 C1
1607 D1
1608 E1
2601 A2
2602 A2
2603 B2
2604 B2
3601 A2
3602 A2
3603 B2
3604 B2
3605 C2
3606 C2
3607 D2
5601 C2
5602 C2
5603 D2

Item number: (X601~620)

CHN CA-

SETNAME SH6G

CLASS_NO

HD BOARD

190G6FB/97

3138 158 6572

NAME Peter Hsieh

SUPERS.

1

10

130

-

A4

TY

CHECK

DATE

2005-08-12

©


ROYAL PHILIPS ELECTRONICS N.V. 2005

Go to cover page

PHILIPS



ALL RIGHTS ARE RESERVED. REPRODUCTION IN WHOLE OR IN PART IS PROHIBITED WITHOUT THE WRITTEN CONSENT OF THE COPYRIGHT OWNER.



CN: ECO-		MMD FL1					
CLASS NO. 3XX000		HD Board		1	2004-12-10		
1		FL1 26MF605W					
2		3138 103 6144					
2004-12-10		3					
NAME Peter Hsieh/IF		SUPERS		2	10	132 - 1	A4
CHECK		DATE 2004-12-10		©		Philips Electronics N.V.	


PHILIPS



ALL RIGHTS ARE RESERVED. REPRODUCTION IN WHOLE OR IN PART IS PROHIBITED WITHOUT THE WRITTEN CONSENT OF THE COPYRIGHT OWNER.




2601 A4 2603 A3 3601 A4 3603 A3 3605 A2 3607 A1 5602 A1
2602 A4 2604 A4 3602 A4 3604 A4 3606 A1 5601 A2 5603 A1



CN: ECO-		MMD FL1	
CLASS NO. 3XX000		HD Board	
2004-12-10		FL1 26MF605W	
NAME Peter Hsieh/IF		SUPERS	
CHECK		DATE 2004-12-10	
1		2	
2		10	
3		132 - 2	
		A4	
© Philips Electronics N.V.			

LED Diagram

All rights reserved. Reproduction in whole or in parts is prohibited without the written consent of the copyright




Ref Des	NI
1930	spark_gap_002
1931	242202518895 63363

ITEM	AP	WE
1931	X	
1932	V	X
2931	V	X
3931	V	X
3932	V	X
6931	V	X

© STANDS FOR CHIP COMPONENTS.

CHN		CA-		SETNAME		SH6G			
CLASS_NO				LED BOARD				1	
				190G6FB/97		3138 158 6035			
2005-08-12		3							
NAME Sophia Hsia / Stella Fann				SUPERS.		1		10	
								130 - 1	
TY				CHECK		DATE 2005-08-12		ROYAL PHILIPS ELECTRONICS N.V. 2005	

ROYAL PHILIPS ELECTRONICS N.V. 2005




PHILIPS



ALL RIGHTS ARE RESERVED. REPRODUCTION IN WHOLE OR IN PART IS PROHIBITED WITHOUT THE WRITTEN CONSENT OF THE COPYRIGHT OWNER.




2931 A2 2933 A1 3932 A2
2932 A1 3931 A2



CN: CA-		190G6	
CLASS NO. 3XX000		LED Board	1 2005-08-08
2005-08-08		LCD 190G6	3138 103 6122
NAME Sophia/Stella		SUPERS	2 10 132 - 2 A4
TY	CHECK	DATE 2005-08-08	© ROYAL PHILIPS ELECTRONICS N.V.


PHILIPS


All rights reserved. Reproduction in whole or in parts
is prohibited without the written consent of the copyright
owner.



Control Board C.B.A.-1


Go to cover page





Exploded View

Go to cover page



Spare Parts List

190G6 LCD/TV

71

Go to cover page

Model: 190G6FB/97(LPL) 12NC: 8639 000 16448			1608	313819874751	CBLE-017 7/50/7-917 AWG28	2021	223891015649	CER2 0805 X7R 25V 100N PM10
Mechanical Parts			1611	243854300085	RES XTL SM 24MHZ 20P SMD-49	2022	223891015649	CER2 0805 X7R 25V 100N PM10
			1625	242202518876	SOC USB H 4P F 2.5 5411	2023	223891015649	CER2 0805 X7R 25V 100N PM10
			1631	242202518875	SOC USB H 4P F 2.0 5401	2024	223891015649	CER2 0805 X7R 25V 100N PM10
			1635	242202518875	SOC USB H 4P F 2.0 5401	2025	223891015649	CER2 0805 X7R 25V 100N PM10
			1641	242202518819	CON V 7P M 2.00 63387	2026	202203100195	ELCAP SM HV 16V 47U PM20
			1651	243854300079	RES XTL SM 12MHZ 32P SMD-49	2027	223891015649	CER2 0805 X7R 25V 100N PM10
			1661	242202605796	SOC PHONE H 1P F 3.5 ST BK	2028	223891015649	CER2 0805 X7R 25V 100N PM10
			1681	242202605797	SOC PHONE H 1P F 3.5 ST PK	2029	223891015649	CER2 0805 X7R 25V 100N PM10
			1701	243854300079	RES XTL SM 12MHZ 32P SMD-49	2030	223886715339	CER1 0603 NP0 50V 33P PM5
			1801	242202518819	CON V 7P M 2.00 63387	2051	223878615649	CER2 0603 X7R 16V 100N PM10
30	313815760671	FRONT BEZEL ASSY	1851	242254301372	RES XTL SM 18M432 16P HC49/S	2052	202203100195	ELCAP SM HV 16V 47U PM20
31	313815413991	BEZEL	1901	313818875501	CON BM H 10P M 2.0 63370	2053	223886715229	CER1 0603 NP0 50V 22P PM5
32	313815414421	LENS-TV	1905	243812800224	SWI PUSH 2P 0.2A 20V SFPC12	2054	222224119876	CER2 1206 Y5V 10V 10U P8020
33	313815414411	LENS-IR	1911	242212803007	SWI TACT 1P 1POS 12V V 5MM	2055	223886715229	CER1 0603 NP0 50V 22P PM5
40	313815760681	BACK COVER ASSY	1912	242212803007	SWI TACT 1P 1POS 12V V 5MM	2057	223824619863	CER2 0603 Y5V 10V 1U P8020
41	313815414031	BACK COVER	1913	242212803007	SWI TACT 1P 1POS 12V V 5MM	2058	223886715109	CER1 0603 NP0 50V 10P PM5
42	313815414041	SPEAKER COVER-A	1914	242212803007	SWI TACT 1P 1POS 12V V 5MM	2059	223878615649	CER2 0603 X7R 16V 100N PM10
43	313815414051	SPEAKER COVER-B	1915	242212803007	SWI TACT 1P 1POS 12V V 5MM	2102	223878615649	CER2 0603 X7R 16V 100N PM10
44	313815417041	INNER COVER-AP	1916	242212803007	SWI TACT 1P 1POS 12V V 5MM	2103	223878615649	CER2 0603 X7R 16V 100N PM10
50	313815760661	BASE ASSY-190G6	1921	313819876011	CBLE-019 9/120/9-529 AWG28	2104	223886715339	CER1 0603 NP0 50V 33P PM5
52	313815414021	HINGE COVER	1922	242212803007	SWI TACT 1P 1POS 12V V 5MM	2105	223886715339	CER1 0603 NP0 50V 33P PM5
60	313815760691	FRONT COVER ASSY	1923	242212803007	SWI TACT 1P 1POS 12V V 5MM	2106	223878615649	CER2 0603 X7R 16V 100N PM10
61	313815414001	FRONT COVER	1924	242212803007	SWI TACT 1P 1POS 12V V 5MM	2107	223878615649	CER2 0603 X7R 16V 100N PM10
62	313815161961	MESH GRILIE	1925	242212803007	SWI TACT 1P 1POS 12V V 5MM	2108	223886715339	CER1 0603 NP0 50V 33P PM5
91	313815137751	SHIELDING-UPPER-AP	1926	242212803007	SWI TACT 1P 1POS 12V V 5MM	2109	223886715339	CER1 0603 NP0 50V 33P PM5
92	313815137781	SHIELDING-LOWER-AP	1927	242212916327	ROT ENCODER 20P DC11G2010*	2110	223886715331	CER1 0603 NP0 50V 330P PM5
95	313815414061	PHILIPS COVER	1951	242202518824	CON V 11P M 2.00 63391	2111	223886715339	CER1 0603 NP0 50V 33P PM5
102	313810440571	HOUSING COVER	1952	242208611053	FUSE SM F 7A 125V UL	2115	223878615649	CER2 0603 X7R 16V 100N PM10
301	313815137731	METAL FRAME	1961	242202605799	SOC PHONE H 1P F 3.5 ST WH	2201	222224119876	CER2 1206 Y5V 10V 10U P8020
303	313815136071	HINGE FRAME-R	1971	242202605309	SOC SUPP H 1P M DC 2.5MM	2202	223878615649	CER2 0603 X7R 16V 100N PM10
304	313815136081	HINGE FRAME-L	1991	242202518949	CON H 9P M 2.00 63369	2203	222224119876	CER2 1206 Y5V 10V 10U P8020
1052	313815865641	BASE ASSY(190G6)	4444	313810610483	CD ROM - SERVICE MANUAL	2204	223878615649	CER2 0603 X7R 16V 100N PM10
1057	313815865651	FRAME+WIRE ASSY	4444	313810610484	SERVICE MANUAL	2205	223878615649	CER2 0603 X7R 16V 100N PM10
Packing Parts			8061	313819876461	CBLE-017 7/310/7-076 AWG24	2206	222224119876	CER2 1206 Y5V 10V 10U P8020
			8062	313819876541	CBLE-020 10/520/10-080 AWG26	2207	223878615649	CER2 0603 X7R 16V 100N PM10
			8063	313819876551	CBLE-021 11/510/11-081 AWG26	2208	223878615649	CER2 0603 X7R 16V 100N PM10
			8064	313819876511	CBLE-012 2/250/2-017 AWG24	2209	223878615649	CER2 0603 X7R 16V 100N PM10
			8065	313819876521	CBLE-013 3/250/3-078 AWG24	2210	222224119876	CER2 1206 Y5V 10V 10U P8020
			8066	313819876531	CBLE-015 5/320/5-015 AWG28	2211	223878615649	CER2 0603 X7R 16V 100N PM10
			8071	313819876471	CBLE-077 7/340/7-017 AWG24	2212	223878615649	CER2 0603 X7R 16V 100N PM10
			8072	313819876481	CBLE-030 10/290/10-020 AWG26	2213	223878615649	CER2 0603 X7R 16V 100N PM10
			8073	313819876491	CBLE-031 11/250/11-021 AWG26	2214	223878615649	CER2 0603 X7R 16V 100N PM10
			8801	242202518814	CON V 2P M 2.00 63382	2215	223878615649	CER2 0603 X7R 16V 100N PM10
Accessory			8802	242202518815	CON V 3P M 2.00 63383	2216	223878615649	CER2 0603 X7R 16V 100N PM10
			LCD Panel			2217	223878615649	CER2 0603 X7R 16V 100N PM10
						2218	223878615649	CER2 0603 X7R 16V 100N PM10
						2219	222224119876	CER2 1206 Y5V 10V 10U P8020
						2220	223878615649	CER2 0603 X7R 16V 100N PM10
						2221	223878615649	CER2 0603 X7R 16V 100N PM10
						2222	223878615649	CER2 0603 X7R 16V 100N PM10
						2223	223878615649	CER2 0603 X7R 16V 100N PM10
						2224	223878615645	CER2 0603 X7R 16V 47N PM10
						2225	223878615645	CER2 0603 X7R 16V 47N PM10
2226	223878615645	CER2 0603 X7R 16V 47N PM10						
miscellanea			2227	223878615649	CER2 0603 X7R 16V 100N PM10			
			2230	223878615645	CER2 0603 X7R 16V 47N PM10			
			2231	223878615645	CER2 0603 X7R 16V 47N PM10			
			2232	223858615623	CER2 0603 X7R 50V 1N PM10			
			2233	223878615645	CER2 0603 X7R 16V 47N PM10			
			2234	223878615645	CER2 0603 X7R 16V 47N PM10			
			2235	223878615645	CER2 0603 X7R 16V 47N PM10			
			2236	223858615623	CER2 0603 X7R 50V 1N PM10			
			2237	223878615645	CER2 0603 X7R 16V 47N PM10			
			2238	223878615649	CER2 0603 X7R 16V 100N PM10			
PCB Assy			2239	223858615636	CER2 0603 X7R 50V 10N PM10			
			2240	223886715229	CER1 0603 NP0 50V 22P PM5			
			2241	223886715229	CER1 0603 NP0 50V 22P PM5			
			2242	223878615649	CER2 0603 X7R 16V 100N PM10			
			2244	222224119876	CER2 1206 Y5V 10V 10U P8020			
			2245	223878615649	CER2 0603 X7R 16V 100N PM10			
			2247	223878615649	CER2 0603 X7R 16V 100N PM10			
			2248	223878615649	CER2 0603 X7R 16V 100N PM10			
			2249	223878615649	CER2 0603 X7R 16V 100N PM10			
			2250	223878615649	CER2 0603 X7R 16V 100N PM10			
PCB Assy			2251	223878615649	CER2 0603 X7R 16V 100N PM10			
			2252	223878615649	CER2 0603 X7R 16V 100N PM10			
			2253	223878615649	CER2 0603 X7R 16V 100N PM10			
			2001	202203100221	ELCAP KM 25V S 470U PM20			
			2002	223891015649	CER2 0805 X7R 25V 100N PM10			
			2003	223886715339	CER1 0603 NP0 50V 33P PM5			
			2004	223886715339	CER1 0603 NP0 50V 33P PM5			
			2005	202203100221	ELCAP KM 25V S 470U PM20			
			2006	223891015649	CER2 0805 X7R 25V 100N PM10			
			2007	223891015649	CER2 0805 X7R 25V 100N PM10			
PCB Assy			2008	203803513313	ELCAP RGA 25V S 100U PM20			
			2010	223891015649	CER2 0805 X7R 25V 100N PM10			
			2011	223891015649	CER2 0805 X7R 25V 100N PM10			
			2012	202203100206	ELCAP SM HV 25V 47U PM10			
			2013	222224119876	CER2 1206 Y5V 10V 10U P8020			
			2015	223886715339	CER1 0603 NP0 50V 33P PM5			
			2016	223886715339	CER1 0603 NP0 50V 33P PM5			
			2018	223891015649	CER2 0805 X7R 25V 100N PM10			
			2019	223891015649	CER2 0805 X7R 25V 100N PM10			
			PCB Assy			2020	223891015649	CER2 0805 X7R 25V 100N PM10
2021	223891015649	CER2 0805 X7R 25V 100N PM10						
2022	223891015649	CER2 0805 X7R 25V 100N PM10						
2023	223891015649	CER2 0805 X7R 25V 100N PM10						
2024	223891015649	CER2 0805 X7R 25V 100N PM10						
2025	223891015649	CER2 0805 X7R 25V 100N PM10						
2026	202203100195	ELCAP SM HV 16V 47U PM20						
2027	223891015649	CER2 0805 X7R 25V 100N PM10						
2028	223891015649	CER2 0805 X7R 25V 100N PM10						
2029	223891015649	CER2 0805 X7R 25V 100N PM10						
PCB Assy			2030	223886715339	CER1 0603 NP0 50V 33P PM5			
			2051	223878615649	CER2 0603 X7R 16V 100N PM10			
			2052	202203100195	ELCAP SM HV 16V 47U PM20			
			2053	223886715229	CER1 0603 NP0 50V 22P PM5			
			2054	222224119876	CER2 1206 Y5V 10V 10U P8020			
			2055	223886715229	CER1 0603 NP0 50V 22P PM5			
			2057	223824619863	CER2 0603 Y5V 10V 1U P8020			
			2058	223886715109	CER1 0603 NP0 50V 10P PM5			
			2059	223878615649	CER2 0603 X7R 16V 100N PM10			
			2102	223878615649	CER2 0603 X7R 16V 100N PM10			
PCB Assy			2103	223878615649	CER2 0603 X7R 16V 100N PM10			
			2104	223886715339	CER1 0603 NP0 50V 33P PM5			
			2105	223886715339	CER1 0603 NP0 50V 33P PM5			
			2106	223878615649	CER2 0603 X7R 16V 100N PM10			
			2107	223878615649	CER2 0603 X7R 16V 100N PM10			
			2108	223886715339	CER1 0603 NP0 50V 33P PM5			
			2109	223886715339	CER1 0603 NP0 50V 33P PM5			
			2110	223886715331	CER1 0603 NP0 50V 330P PM5			
			2111	223886715339	CER1 0603 NP0 50V 33P PM5			
			2115	223878615649	CER2 0603 X7R 16V 100N PM10			
PCB Assy			2201	222224119876	CER2 1206 Y5V 10V 10U P8020			
			2202	223878615649	CER2 0603 X7R 16V 100N PM10			
			2203	222224119876	CER2 1206 Y5V 10V 10U P8020			
			2204	223878615649	CER2 0603 X7R 16V 100N PM10			
			2205	223878615649	CER2 0603 X7R 16V 100N PM10			
			2206	222224119876	CER2 1206 Y5V 10V 10U P8020			
			2207	223878615649	CER2 0603 X7R 16V 100N PM10			
			2208	223878615649	CER2 0603 X7R 16V 100N PM10			
			2209	223878615649	CER2 0603 X7R 16V 100N PM10			
			2210	222224119876	CER2 1206 Y5V 10V 10U P8020			
PCB Assy			2211	223878615649	CER2 0603 X7R 16V 100N PM10			
			2212	223878615649	CER2 0603 X7R 16V 100N PM10			
			2213	223878615649	CER2 0603 X7R 16V 100N PM10			
			2214	223878615649	CER2 0603 X7R 16V 100N PM10			
			2215	223878615649	CER2 0603 X7R 16V 100N PM10			
			2216	223878615649	CER2 0603 X7R 16V 100N PM10			
			2217	223878615649	CER2 0603 X7R 16V 100N PM10			
			2218	223878615649	CER2 0603 X7R 16V 100N PM10			
			2219	222224119876	CER2 1206 Y5V 10V 10U P8020			
			2220	223878615649	CER2 0603 X7R 16V 100N PM10			
PCB Assy			2221	223878615649	CER2 0603 X7R 16V 100N PM10			
			2222	223878615649	CER2 0603 X7R 16V 100N PM10			
			2223	223878615649	CER2 0603 X7R 16V 100N PM10			
			2224	223878615645	CER2 0603 X7R 16V 47N PM10			
			2225	223878615645	CER2 0603 X7R 16V 47N PM10			
			2226	223878615645	CER2 0603 X7R 16V 47N PM10			
			2227	223878615649	CER2 0603 X7R 16V 100N PM10			
			2230	223878615645	CER2 0603 X7R 16V 47N PM10			
			2231	223878615645	CER2 0603 X7R 16V 47N PM10			
			2232	223858615623	CER2 0603 X7R 50V 1N PM10			
PCB Assy			2233	223878615645	CER2 0603 X7R 16V 47N PM10			
			2234	223878615645	CER2 0603 X7R 16V 47N PM10			
			2235	223878615645	CER2 0603 X7R 16V 47N PM10			
			2236	223858615623	CER2 0603 X7R 50V 1N PM10			
			2237	223878615645	CER2 0603 X7R 16V 47N PM10			
			2238	223878615649	CER2 0603 X7R 16V 100N PM10			
			2239	223858615636	CER2 0603 X7R 50V 10N PM10			
			2240	223886715229	CER1 0603 NP0 50V 22P PM5			
			2241	223886715229	CER1 0603 NP0			

Spare Parts List

2254	202203100195	ELCAP SM	HV 16V	47U PM20	2701	223878615649	CER2 0603 X7R 16V	100N PM10	2887	223824619863	CER2 0603 Y5V 10V	1U P8020
2255	202203100195	ELCAP SM	HV 16V	47U PM20	2702	223878615649	CER2 0603 X7R 16V	100N PM10	2890	223878615649	CER2 0603 X7R 16V	100N PM10
2256	202203100195	ELCAP SM	HV 16V	47U PM20	2703	223878615649	CER2 0603 X7R 16V	100N PM10	2891	223824619863	CER2 0603 Y5V 10V	1U P8020
2257	223886715339	CER1 0603 NP0 50V	33P PM5		2704	222224119876	CER2 1206 Y5V 10V	10U P8020	2892	223824619863	CER2 0603 Y5V 10V	1U P8020
2258	223886715339	CER1 0603 NP0 50V	33P PM5		2705	223886715569	CER1 0603 NP0 50V	56P PM5	2893	222291219876	CER2 1210 Y5V 25V	10U P8020
2259	223886715568	CER1 0603 NP0 50V	5P6 PM0P5		2706	223886715569	CER1 0603 NP0 50V	56P PM5				
2260	223878615649	CER2 0603 X7R 16V	100N PM10		2707	223878615649	CER2 0603 X7R 16V	100N PM10	3002	232270260101	RST SM 0603 RC21	100R PM5
2261	223878615649	CER2 0603 X7R 16V	100N PM10		2708	223878615649	CER2 0603 X7R 16V	100N PM10	3003	232270260101	RST SM 0603 RC21	100R PM5
2262	222224119876	CER2 1206 Y5V 10V	10U P8020		2709	223886715101	CER1 0603 NP0 50V	100P PM5	3004	232270260104	RST SM 0603 RC21	100K PM5
2263	223878615649	CER2 0603 X7R 16V	100N PM10		2710	223878615649	CER2 0603 X7R 16V	100N PM10	3005	212211805635	RST SM 0603 RC0603	100R PM5
2264	223878615649	CER2 0603 X7R 16V	100N PM10		2801	223878619854	CER2 0603 Y5V 16V	220N P8020	3006	232270260101	RST SM 0603 RC21	100R PM5
2265	223878615649	CER2 0603 X7R 16V	100N PM10		2802	223878619854	CER2 0603 Y5V 16V	220N P8020	3007	232270260101	RST SM 0603 RC21	100R PM5
2301	223878615649	CER2 0603 X7R 16V	100N PM10		2803	223891119858	CER2 1206 Y5V 25V	470N P8020	3009	232270260104	RST SM 0603 RC21	100K PM5
2302	223878615649	CER2 0603 X7R 16V	100N PM10		2804	223886715101	CER1 0603 NP0 50V	100P PM5	3010	232270260101	RST SM 0603 RC21	100R PM5
2303	222224119876	CER2 1206 Y5V 10V	10U P8020		2805	223886715101	CER1 0603 NP0 50V	100P PM5	3011	232270260101	RST SM 0603 RC21	100R PM5
2304	223878615649	CER2 0603 X7R 16V	100N PM10		2806	202203100173	ELCAP EB	25V S 470U PM20	3012	232270260104	RST SM 0603 RC21	100K PM5
2305	223878615649	CER2 0603 X7R 16V	100N PM10		2807	222291219876	CER2 1210 Y5V 25V	10U P8020	3013	232270260101	RST SM 0603 RC21	100R PM5
2306	223878615649	CER2 0603 X7R 16V	100N PM10		2808	223891015649	CER2 0805 X7R 25V	100N PM10	3014	232270260101	RST SM 0603 RC21	100R PM5
2307	223878615649	CER2 0603 X7R 16V	100N PM10		2809	223891015649	CER2 0805 X7R 25V	100N PM10	3015	212211805669	RST SM 0603 RC0603	10K PM5
2308	222224119876	CER2 1206 Y5V 10V	10U P8020		2810	223858615636	CER2 0603 X7R 50V	10N PM10	3016	232270260512	RST SM 0603 RC21	5K1 PM5
2309	223878615649	CER2 0603 X7R 16V	100N PM10		2811	223858615636	CER2 0603 X7R 50V	10N PM10	3017	232270260101	RST SM 0603 RC21	100R PM5
2310	223878615649	CER2 0603 X7R 16V	100N PM10		2812	202203100235	ELCAP EB	25V S 470U PM20	3018	232270260101	RST SM 0603 RC21	100R PM5
2311	223878615649	CER2 0603 X7R 16V	100N PM10		2813	222291019863	CER2 0805 Y5V 25V	1U P8020	3019	232270260104	RST SM 0603 RC21	100K PM5
2312	223878615649	CER2 0603 X7R 16V	100N PM10		2814	223824619863	CER2 0603 Y5V 10V	1U P8020	3021	232270260104	RST SM 0603 RC21	100K PM5
2313	223878615649	CER2 0603 X7R 16V	100N PM10		2815	223824619863	CER2 0603 Y5V 10V	1U P8020	3022	232270260512	RST SM 0603 RC21	5K1 PM5
2314	223878615649	CER2 0603 X7R 16V	100N PM10		2816	223824619863	CER2 0603 Y5V 10V	1U P8020	3025	212211805645	RST SM 0603 RC0603	150R PM5
2401	223886715101	CER1 0603 NP0 50V	100P PM5		2817	223824619863	CER2 0603 Y5V 10V	1U P8020	3026	212211805645	RST SM 0603 RC0603	150R PM5
2402	223886715229	CER1 0603 NP0 50V	22P PM5		2818	223891015649	CER2 0805 X7R 25V	100N PM10	3029	212211805645	RST SM 0603 RC0603	150R PM5
2406	223886715101	CER1 0603 NP0 50V	100P PM5		2819	222291219876	CER2 1210 Y5V 25V	10U P8020	3030	232270260512	RST SM 0603 RC21	5K1 PM5
2407	223886715229	CER1 0603 NP0 50V	22P PM5		2820	223824619863	CER2 0603 Y5V 10V	1U P8020	3031	212211805645	RST SM 0603 RC0603	150R PM5
2428	223886715229	CER1 0603 NP0 50V	22P PM5		2821	223891015649	CER2 0805 X7R 25V	100N PM10	3032	232270260473	RST SM 0603 RC21	47K PM5
2429	223886715101	CER1 0603 NP0 50V	100P PM5		2822	223886715221	CER1 0603 NP0 50V	220P PM5	3036	232270260512	RST SM 0603 RC21	5K1 PM5
2431	223886715331	CER1 0603 NP0 50V	330P PM5		2823	222291019863	CER2 0805 Y5V 25V	1U P8020	3039	212211805669	RST SM 0603 RC0603	10K PM5
2432	223886715331	CER1 0603 NP0 50V	330P PM5		2824	223891015649	CER2 0805 X7R 25V	100N PM10	3040	212211805645	RST SM 0603 RC0603	150R PM5
2433	223886715331	CER1 0603 NP0 50V	330P PM5		2825	223891015649	CER2 0805 X7R 25V	100N PM10	3041	212211805645	RST SM 0603 RC0603	150R PM5
2434	223886715331	CER1 0603 NP0 50V	330P PM5		2826	223858615636	CER2 0603 X7R 50V	10N PM10	3042	212211805669	RST SM 0603 RC0603	10K PM5
2501	222291219876	CER2 1210 Y5V 25V	10U P8020		2827	223858615636	CER2 0603 X7R 50V	10N PM10	3043	232270260101	RST SM 0603 RC21	100R PM5
2502	223878615649	CER2 0603 X7R 16V	100N PM10		2828	222291219876	CER2 1210 Y5V 25V	10U P8020	3045	232270260223	RST SM 0603 RC21	22K PM5
2504	223886715101	CER1 0603 NP0 50V	100P PM5		2829	202203100173	ELCAP EB	25V S 470U PM20	3046	212211805669	RST SM 0603 RC0603	10K PM5
2505	223886715479	CER1 0603 NP0 50V	47P PM5		2830	223886715101	CER1 0603 NP0 50V	100P PM5	3051	232270260105	RST SM 0603 RC21	1M PM5
2506	223878615649	CER2 0603 X7R 16V	100N PM10		2831	223886715101	CER1 0603 NP0 50V	100P PM5	3054	232270260104	RST SM 0603 RC21	100K PM5
2509	202203100074	ELCAP KM	16V S 1000U PM20		2832	223891119858	CER2 1206 Y5V 25V	470N P8020	3056	232270260101	RST SM 0603 RC21	100R PM5
2551	223878615649	CER2 0603 X7R 16V	100N PM10		2833	223878619854	CER2 0603 Y5V 16V	220N P8020	3057	232270260101	RST SM 0603 RC21	100R PM5
2552	223878615649	CER2 0603 X7R 16V	100N PM10		2834	223878619854	CER2 0603 Y5V 16V	220N P8020	3058	232270260472	RST SM 0603 RC21	4K7 PM5
2553	223878615649	CER2 0603 X7R 16V	100N PM10		2851	222224119876	CER2 1206 Y5V 10V	10U P8020	3059	232270260332	RST SM 0603 RC21	3K3 PM5
2554	223878615649	CER2 0603 X7R 16V	100N PM10		2852	223878615649	CER2 0603 X7R 16V	100N PM10	3060	232270260332	RST SM 0603 RC21	3K3 PM5
2555	223878615649	CER2 0603 X7R 16V	100N PM10		2853	223878615649	CER2 0603 X7R 16V	100N PM10	3061	232270260332	RST SM 0603 RC21	3K3 PM5
2556	223878615649	CER2 0603 X7R 16V	100N PM10		2854	223878615649	CER2 0603 X7R 16V	100N PM10	3064	232270260223	RST SM 0603 RC21	22K PM5
2557	223878615649	CER2 0603 X7R 16V	100N PM10		2855	223878615649	CER2 0603 X7R 16V	100N PM10	3065	232270260222	RST SM 0603 RC21	2K2 PM5
2558	223878615649	CER2 0603 X7R 16V	100N PM10		2856	222224119876	CER2 1206 Y5V 10V	10U P8020	3066	232270260472	RST SM 0603 RC21	4K7 PM5
2559	222224119876	CER2 1206 Y5V 10V	10U P8020		2857	222291019863	CER2 0805 Y5V 25V	1U P8020	3067	232270260332	RST SM 0603 RC21	3K3 PM5
2560	223878615649	CER2 0603 X7R 16V	100N PM10		2858	222291019863	CER2 0805 Y5V 25V	1U P8020	3068	232270260332	RST SM 0603 RC21	3K3 PM5
2561	223878615649	CER2 0603 X7R 16V	100N PM10		2859	223886715159	CER1 0603 NP0 50V	15P PM5	3069	232270260332	RST SM 0603 RC21	3K3 PM5
2562	223878615649	CER2 0603 X7R 16V	100N PM10		2860	223886715159	CER1 0603 NP0 50V	15P PM5	3070	212211805635	RST SM 0603 RC0603	10R PM5
2563	223878615649	CER2 0603 X7R 16V	100N PM10		2861	223886715159	CER1 0603 NP0 50V	15P PM5	3071	232270260332	RST SM 0603 RC21	3K3 PM5
2564	223878615649	CER2 0603 X7R 16V	100N PM10		2862	223886715479	CER1 0603 NP0 50V	47P PM5	3073	232270260101	RST SM 0603 RC21	100R PM5
2565	223878615649	CER2 0603 X7R 16V	100N PM10		2863	223824619863	CER2 0603 Y5V 10V	1U P8020	3074	232270260101	RST SM 0603 RC21	100R PM5
2566	223858615641	CER2 0603 X7R 50V	22N PM10		2864	222224119876	CER2 1206 Y5V 10V	10U P8020	3075	232270260332	RST SM 0603 RC21	3K3 PM5
2567	223858615641	CER2 0603 X7R 50V	22N PM10		2865	223824619863	CER2 0603 Y5V 10V	1U P8020	3076	232270260332	RST SM 0603 RC21	3K3 PM5
2568	223858615641	CER2 0603 X7R 50V	22N PM10		2868	223858615632	CER2 0603 X7R 50V	4N7 PM10	3077	232270260332	RST SM 0603 RC21	3K3 PM5
2569	222224119876	CER2 1206 Y5V 10V	10U P8020		2869	223858615632	CER2 0603 X7R 50V	4N7 PM10	3104	232270260101	RST SM 0603 RC21	100R PM5
2570	223858615641	CER2 0603 X7R 50V	22N PM10		2870	223858615632	CER2 0603 X7R 50V	4N7 PM10	3105	232270260101	RST SM 0603 RC21	100R PM5
2571	223858615641	CER2 0603 X7R 50V	22N PM10		2871	223858615632	CER2 0603 X7R 50V	4N7 PM10	3106	212211805669	RST SM 0603 RC0603	10K PM5
2572	223858615641	CER2 0603 X7R 50V	22N PM10		2872	223824619863	CER2 0603 Y5V 10V	1U P8020	3107	212211805669	RST SM 0603 RC0603	10K PM5
2573	223858615641	CER2 0603 X7R 50V	22N PM10		2873	223824619863	CER2 0603 Y5V 10V	1U P8020	3108	212211805669	RST SM 0603 RC0603	10K PM5
2574	223858615641	CER2 0603 X7R 50V	22N PM10		2874	223824619863	CER2 0603 Y5V 10V	1U P8020	3110	232270260101	RST SM 0603 RC21	100R PM5
2575	223858615641	CER2 0603 X7R 50V	22N PM10		2875	223824619863	CER2 0603 Y5V 10V	1U P8020	3111	232270260101	RST SM 0603 RC21	100R PM5
2576	202203100195	ELCAP SM	HV 16V	47U PM20	2876	223824619863	CER2 0603 Y5V 10V	1U P8020	3114	212211805669	RST SM 0603 RC0603	10K PM5
2577	223858615641	CER2 0603 X7R 50V	22N PM10		2877	223824619863	CER2 0603 Y5V 10V	1U P8020	3115	212211805669	RST SM 0603 RC0603	10K PM5
2578	223858615641	CER2 0603 X7R 50V	22N PM10		2878	223824619863	CER2 0603 Y5V 10V	1U P8020	3116	212211805669	RST SM 0603 RC0603	10K PM5
2579	223858615623	CER2 0603 X7R 50V	1N PM10		2879	223824619863	CER2 0603 Y5V 10V	1U P8020	3118	212211805631	RST SM 0603 JUMP.	MAX 0R05

Spare Parts List

190G6 LCD/TV

73

Go to cover page

3128	212211805669	RST SM 0603 RC0603 10K PM5	3706	232270260243	RST SM 0603 RC21 24K PM5	5851	242253595853	IND FXD SM 0603 0U10 PM10
3129	232270260102	RST SM 0603 RC21 1K PM5	3803	232270260101	RST SM 0603 RC21 100R PM5	5852	242253595853	IND FXD SM 0603 0U10 PM10
3130	232270260689	RST SM 0603 RC21 68R PM5	3804	212211805673	RST SM 0603 RC0603 18K PM5			
3131	232270260689	RST SM 0603 RC21 68R PM5	3805	232270260104	RST SM 0603 RC21 100K PM5	6001	932208282668	DIO REC SM SS34-E3 (VISH)
3132	232270260689	RST SM 0603 RC21 68R PM5	3806	212211805944	RST SM 0603 RC0603 120K PM5	6003	932217950685	DIO REG SM UDZS3.9B (RHM0)
3212	232270462209	RST SM 0603 RC22H 22R PM1	3807	212211805682	RST SM 0603 RC0603 82K PM5	6004	932217950685	DIO REG SM UDZS3.9B (RHM0)
3213	232270462209	RST SM 0603 RC22H 22R PM1	3808	212211805672	RST SM 0603 RC0603 15K PM5	6005	932217950685	DIO REG SM UDZS3.9B (RHM0)
3214	232270462209	RST SM 0603 RC22H 22R PM1	3809	212211805664	RST SM 0603 RC0603 3K9 PM5	6006	932217950685	DIO REG SM UDZS3.9B (RHM0)
3215	232270260101	RST SM 0603 RC21 100R PM5	3810	212211805664	RST SM 0603 RC0603 3K9 PM5	6101	932205976685	DIO SIG SM LS4148 (VISH)
3216	232270260101	RST SM 0603 RC21 100R PM5	3811	212211805667	RST SM 0603 RC0603 6K8 PM5	6102	933742280215	DIO SIG SM BAT54 (PHSE)
3219	212211805651	RST SM 0603 RC0603 390R PM5	3812	212211805667	RST SM 0603 RC0603 6K8 PM5	6103	932205976685	DIO SIG SM LS4148 (VISH)
3220	232270260101	RST SM 0603 RC21 100R PM5	3851	232270260101	RST SM 0603 RC21 100R PM5	6104	933742280215	DIO SIG SM BAT54 (PHSE)
3222	232270260102	RST SM 0603 RC21 1K PM5	3852	232270260101	RST SM 0603 RC21 100R PM5	6401	932209863685	DIO SIG SM BAV99 (VISH)
3230	212211805669	RST SM 0603 RC0603 10K PM5	3853	232270260101	RST SM 0603 RC21 100R PM5	6402	932209863685	DIO SIG SM BAV99 (VISH)
3232	235003510101	RST NETW SM ARV24 4X100R PM5	3854	232270260101	RST SM 0603 RC21 100R PM5	6406	932209863685	DIO SIG SM BAV99 (VISH)
3233	235003510101	RST NETW SM ARV24 4X100R PM5	3855	232270260273	RST SM 0603 RC21 27K PM5	6801	932220675682	DIO REC M100AL-5301-E3 (VISH)
3234	235003510229	RST NETW SM ARV24 4X 22R PM5	3856	232270260101	RST SM 0603 RC21 100R PM5	6851	932205976685	DIO SIG SM LS4148 (VISH)
3235	235003510229	RST NETW SM ARV24 4X 22R PM5	3857	232270260101	RST SM 0603 RC21 100R PM5			
3236	235003510229	RST NETW SM ARV24 4X 22R PM5	3871	212211805631	RST SM 0603 JUMP. MAX 0R05	7001	932215923668	IC SM LM2596SX-5.0 (NSC0)
3244	232270260471	RST SM 0603 RC21 470R PM5	3872	212211805631	RST SM 0603 JUMP. MAX 0R05	7004	932220471668	FET POW SM SI4835BDY-E3(VISH)
3245	232270260471	RST SM 0603 RC21 470R PM5	4001	212211805631	RST SM 0603 JUMP. MAX 0R05	7005	932217439685	TRA SIG SM BC857C (KECO)
3246	212211805635	RST SM 0603 RC0603 10R PM5	4002	212211805631	RST SM 0603 JUMP. MAX 0R05	7006	932209265685	TRA SIG SM MUN2211JG (ONSE)
3247	232270260101	RST SM 0603 RC21 100R PM5	4051	212211805631	RST SM 0603 JUMP. MAX 0R05	7007	932217439685	TRA SIG SM BC857C (KECO)
3248	212211805639	RST SM 0603 RC0603 47R PM5	4053	212211805631	RST SM 0603 JUMP. MAX 0R05	7008	932217439685	TRA SIG SM BC857C (KECO)
3249	232270260105	RST SM 0603 RC21 1M PM5	4103	212211805631	RST SM 0603 JUMP. MAX 0R05	7009	932216638668	FET POW SM SI5441DC-E3 (VISH)
3250	232270260101	RST SM 0603 RC21 100R PM5	4202	212211805631	RST SM 0603 JUMP. MAX 0R05	7010	932217439685	TRA SIG SM BC857C (KECO)
3251	232270260101	RST SM 0603 RC21 100R PM5	4405	212211805631	RST SM 0603 JUMP. MAX 0R05	7011	932217439685	TRA SIG SM MUN2211JG (ONSE)
3252	232270260101	RST SM 0603 RC21 100R PM5	4408	212211805631	RST SM 0603 JUMP. MAX 0R05	7012	932217439685	TRA SIG SM BC857C (KECO)
3301	235003510229	RST NETW SM ARV24 4X 22R PM5	4501	212211805631	RST SM 0603 JUMP. MAX 0R05	7013	932217439685	TRA SIG SM BC857C (KECO)
3302	232270260472	RST SM 0603 RC21 4K7 PM5	4504	212211805631	RST SM 0603 JUMP. MAX 0R05	7051	932222076668	IC SM AME1117CCGTZ (AME0)
3303	232270260472	RST SM 0603 RC21 4K7 PM5	4801	232273091002	RST SM 0805 JUMP. MAX 0R05	7052	313815865671	CPU IC ASSY(AP)
3304	235003510229	RST NETW SM ARV24 4X 22R PM5	4851	212211805631	RST SM 0603 JUMP. MAX 0R05	7052	932222010682	IC SM NT68F632ALG (NOVA)
3305	235003510229	RST NETW SM ARV24 4X 22R PM5	4852	212211805631	RST SM 0603 JUMP. MAX 0R05	7053	932219183685	IC SM LM809M3-2.93 NOPB(NSC0)
3306	235003510229	RST NETW SM ARV24 4X 22R PM5	4853	212211805631	RST SM 0603 JUMP. MAX 0R05	7054	932217438685	TRA SIG SM BC847C (KECO)
3307	235003510229	RST NETW SM ARV24 4X 22R PM5	4856	232273091002	RST SM 0805 JUMP. MAX 0R05	7055	313815865661	EEPROM IC ASSY(AP)
3308	235003510229	RST NETW SM ARV24 4X 22R PM5	4860	212211805631	RST SM 0603 JUMP. MAX 0R05	7055	932210684668	IC SM AT24C32N-10SI-1.8(ATME)
3309	235003510229	RST NETW SM ARV24 4X 22R PM5	4861	212211805631	RST SM 0603 JUMP. MAX 0R05	7101	932220624668	IC SM M24C02-WMN6P (ST00)
3310	235003510229	RST NETW SM ARV24 4X 22R PM5				7102	932220624668	IC SM M24C02-WMN6P (ST00)
3402	232270462709	RST SM 0603 RC22H 27R PM1	5001	313818875691	COI CHOKE 35UH 82M OHM DR10X8	7104	932217126668	IC SM 74LCX14T (ST00)
3403	232270464709	RST SM 0603 RC22H 47R PM1	5002	242253600428	IND FXD TSL0808 S 10U PM10	7201	932222013671	IC SM MST51512L-LF (MSTA)
3406	232270462709	RST SM 0603 RC22H 27R PM1	5003	242254900064	IND FXD 0805 EMI 100MHZ 220R	7202	932222075668	IC SM AME1117BCGTZ (AME0)
3408	232270464709	RST SM 0603 RC22H 47R PM1	5051	242254944197	IND FXD 0805 EMI 100MHZ 220R	7203	932222076668	IC SM AME1117CCGTZ (AME0)
3431	232270462709	RST SM 0603 RC22H 27R PM1	5101	242254945582	IND FXD 0805 EMI 100MHZ 300R	7204	932222076668	IC SM AME1117CCGTZ (AME0)
3432	232270464709	RST SM 0603 RC22H 47R PM1	5102	242254945582	IND FXD 0805 EMI 100MHZ 300R	7301	932216677682	IC SM M12L16161A-7TG (ESMT)
3436	232270260273	RST SM 0603 RC21 27K PM5	5103	242254943769	IND FXD 0603 EMI 100MHZ 30R	7302	932216677682	IC SM M12L16161A-7TG (ESMT)
3437	232270260273	RST SM 0603 RC21 27K PM5	5104	242254943769	IND FXD 0603 EMI 100MHZ 30R	7551	932222077668	IC SM AME1117ECGTZ (AME0)
3442	212211805635	RST SM 0603 RC0603 10R PM5	5105	242254943769	IND FXD 0603 EMI 100MHZ 30R	7552	932222076668	IC SM AME1117CCGTZ (AME0)
3443	212211805635	RST SM 0603 RC0603 10R PM5	5201	242254900064	IND FXD 0805 EMI 100MHZ 220R	7553	935276561518	IC SM SAA7119E/V2/G (PHSE)
3444	212211805635	RST SM 0603 RC0603 10R PM5	5202	242254900064	IND FXD 0805 EMI 100MHZ 220R	7554	932215686685	FET SIG SM 2N7002LG (ONSE)
3445	232270260101	RST SM 0603 RC21 100R PM5	5203	242254900064	IND FXD 0805 EMI 100MHZ 220R	7555	932215686685	FET SIG SM 2N7002LG (ONSE)
3446	232270260101	RST SM 0603 RC21 100R PM5	5204	242254900064	IND FXD 0805 EMI 100MHZ 220R	7701	935274261518	IC SM SAA5360HLM/1/0004(PHSE)
3508	232270260279	RST SM 0603 RC21 27R PM5	5205	242254900064	IND FXD 0805 EMI 100MHZ 220R	7801	932222035668	IC SM TPA3005D2PH (TI00)
3509	212211805639	RST SM 0603 RC0603 47R PM5	5206	242254900064	IND FXD 0805 EMI 100MHZ 220R	7851	932219413671	IC SM MSP3415G-QI-B8V3(MIAS)
3512	212211805631	RST SM 0603 JUMP. MAX 0R05	5207	242254900064	IND FXD 0805 EMI 100MHZ 220R	7852	933714830653	IC SM 74HC4052D (PHSE)
3513	213810500082	RST MOX 1W RSS S 0R82 PM5	5208	242254900064	IND FXD 0805 EMI 100MHZ 220R			
3551	232270260472	RST SM 0603 RC21 4K7 PM5	5211	242254945579	IND FXD 1206 EMI 100MHZ 100R			
3552	212211805642	RST SM 0603 RC0603 75R PM5	5401	242253595853	IND FXD SM 0603 0U10 PM10	PCB Assy		
3553	232270260681	RST SM 0603 RC21 680R PM5	5402	242253595853	IND FXD SM 0603 0U10 PM10	1053	313815860571	CONTROL PCB ASSY
3554	232270260101	RST SM 0603 RC21 100R PM5	5412	242253595853	IND FXD SM 0603 0U10 PM10			
3555	232270260511	RST SM 0603 RC21 510R PM5	5501	242254944197	IND FXD 0805 EMI 100MHZ 220R	3911	212211805668	RST SM 0603 RC0603 8K2 PM5
3556	232270260332	RST SM 0603 RC21 3K3 PM5	5551	242254944527	IND FXD 0603 EMI 100MHZ 600R	3912	232270260122	RST SM 0603 RC21 1K2 PM5
3557	212211805639	RST SM 0603 RC0603 47R PM5	5552	242254944197	IND FXD 0805 EMI 100MHZ 220R	3913	212211805651	RST SM 0603 RC0603 390R PM5
3558	232270260101	RST SM 0603 RC21 100R PM5	5553	242254944527	IND FXD 0603 EMI 100MHZ 600R	3914	232270260303	RST SM 0603 RC21 30K PM5
3560	232270260101	RST SM 0603 RC21 100R PM5	5554	242254944527	IND FXD 0603 EMI 100MHZ 600R	3915	212211805672	RST SM 0603 RC0603 15K PM5
3561	232270260332	RST SM 0603 RC21 3K3 PM5	5555	242254944527	IND FXD 0603 EMI 100MHZ 600R	3916	212211805664	RST SM 0603 RC0603 3K9 PM5
3564	232270260101	RST SM 0603 RC21 100R PM5	5556	242254944527	IND FXD 0603 EMI 100MHZ 600R			
3565	232270260101	RST SM 0603 RC21 100R PM5	5701	242254944527	IND FXD 0603 EMI 100MHZ 600R	6906	932219383682	LED VS L-934MBD (KIEL)
3566	235003510101	RST NETW SM ARV24 4X100R PM5	5702	242254944527	IND FXD 0603 EMI 100MHZ 600R	6907	932219383682	LED VS L-934MBD (KIEL)
3567	235003510101	RST NETW SM ARV24 4X100R PM5	5703	242254944527	IND FXD 0603 EMI 100MHZ 600R	6908	932219383682	LED VS L-934MBD (KIEL)
3570	235003510101	RST SM 0603 RC0603 47R PM5	5801	242254944527	IND FXD 0603 EMI 100MHZ 600R	6909	932219383682	LED VS L-934MBD (KIEL)
3571	212211805639	RST SM 0603 RC0603 47R PM5	5802	242253600782	IND FXD TSL0808 S 33U PM10	6928	932219383682	LED VS L-934MBD (KIEL)
3572	212211805639	RST SM 0603 RC0603 47R PM5	5803	242254900126	IND FXD 0805 EMI 100MHZ 120R			
3573	212211805639	RST SM 0603 RC0603 47R PM5	5804	242254900126	IND FXD 0805 EMI 100MHZ 120R	PCB Assy		
3701	232270260101	RST SM 0603 RC21 100R PM5	5805	242253600782	IND FXD TSL0808 S 33U PM10	1054	313815860351	LED ASSY
3702	232270260101	RST SM 0603 RC21 100R PM5	5806	242254900126	IND FXD 0805 EMI 100MHZ 120R			
3703	212211805645	RST SM 0603 RC0603 150R PM5	5807	242254900126	IND FXD 0805 EMI 100MHZ 120R	2931	223824619863	CER2 0603 Y5V 10V 1U P8020
3704	212211805645	RST SM 0603 RC0603 150R PM5	5808	242253600782	IND FXD TSL0808 S 33U PM10	2932	223878615649	CER2 0603 X7R 16V 100N PM10
3705	212211805645	RST SM 0603 RC0603 150R PM5	5809	242253600782	IND FXD TSL0808 S 33U PM10	2933	223878615649	CER2 0603 X7R 16V 100N PM10
								

Spare Parts List

3931	212211805669	RST SM 0603 RC0603	10K PM5		2962	223878615649	CER2 0603 X7R 16V	100N PM10		3952	212211805631	RST SM 0603 JUMP.	MAX 0R05
3932	232270260101	RST SM 0603 RC21	100R PM5		2963	223886715339	CER1 0603 NP0 50V	33P PM5		3953	212211805631	RST SM 0603 JUMP.	MAX 0R05
					2975	223891619849	CER2 0603 Y5V 25V	100N P8020		3954	212211805631	RST SM 0603 JUMP.	MAX 0R05
6931	932220313667	IR RECEIVER TSOP34136SB1			2976	202203100173	ELCAP EB 25V S	470U PM20		3955	212211805631	RST SM 0603 JUMP.	MAX 0R05
6932	932214603682	LED VS L-3WYGW (KIEL)			2981	223891619849	CER2 0603 Y5V 25V	100N P8020		3956	212211805631	RST SM 0603 JUMP.	MAX 0R05
PCB Assy					2983	202203100173	ELCAP EB 25V S	470U PM20		3961	212211805631	RST SM 0603 JUMP.	MAX 0R05
1065	313815860581	AUDIO+USB ASSY			2990	223878615649	CER2 0603 X7R 16V	100N PM10		3962	212211805631	RST SM 0603 JUMP.	MAX 0R05
					2991	223878615649	CER2 0603 X7R 16V	100N PM10		3963	212211805631	RST SM 0603 JUMP.	MAX 0R05
2605	223858615636	CER2 0603 X7R 50V	10N PM10		2992	223878615649	CER2 0603 X7R 16V	100N PM10		3981	212211805669	RST SM 0603 RC0603	10K PM5
2606	223858615623	CER2 0603 X7R 50V	1N PM10		2993	223878615649	CER2 0603 X7R 16V	100N PM10		3983	212211805631	RST SM 0603 JUMP.	MAX 0R05
2607	223858615636	CER2 0603 X7R 50V	10N PM10		2994	223878615649	CER2 0603 X7R 16V	100N PM10		3984	232270260563	RST SM 0603 RC21	56K PM5
2608	223858615623	CER2 0603 X7R 50V	1N PM10		2995	223878615649	CER2 0603 X7R 16V	100N PM10		3985	232270260563	RST SM 0603 RC21	56K PM5
2609	223858615636	CER2 0603 X7R 50V	10N PM10		2996	223886715391	CER1 0603 NP0 50V	390P PM5		3986	232270260563	RST SM 0603 RC21	56K PM5
2610	223878615649	CER2 0603 X7R 16V	100N PM10		2997	223886715391	CER1 0603 NP0 50V	390P PM5		3987	232270260563	RST SM 0603 RC21	56K PM5
2611	223878615649	CER2 0603 X7R 16V	100N PM10							3988	232270260563	RST SM 0603 RC21	56K PM5
2612	223878615649	CER2 0603 X7R 16V	100N PM10		3611	212211805672	RST SM 0603 RC0603	15K PM5		3989	232270260223	RST SM 0603 RC21	22K PM5
2613	223878615649	CER2 0603 X7R 16V	100N PM10		3612	232270260104	RST SM 0603 RC21	100K PM5		3990	232270260223	RST SM 0603 RC21	22K PM5
2614	223878615649	CER2 0603 X7R 16V	100N PM10		3613	212211805672	RST SM 0603 RC0603	15K PM5		3991	232270260562	RST SM 0603 JUMP.	MAX 0R05
2615	223886715279	CER1 0603 NP0 50V	27P PM5		3614	212211805672	RST SM 0603 RC0603	15K PM5		3992	232270260562	RST SM 0603 RC21	5K6 PM5
2616	223886715279	CER1 0603 NP0 50V	27P PM5		3615	212211805672	RST SM 0603 RC0603	15K PM5		3993	232270260562	RST SM 0603 RC21	5K6 PM5
2617	223878615649	CER2 0603 X7R 16V	100N PM10		3616	212211805672	RST SM 0603 RC0603	15K PM5		3994	232270260562	RST SM 0603 RC21	5K6 PM5
2618	223878615649	CER2 0603 X7R 16V	100N PM10		3617	212211805672	RST SM 0603 RC0603	15K PM5		3995	232270260562	RST SM 0603 RC21	5K6 PM5
2619	223878615649	CER2 0603 X7R 16V	100N PM10		3618	212211805672	RST SM 0603 RC0603	15K PM5		3996	232270260102	RST SM 0603 RC21	1K PM5
2621	223878615649	CER2 0603 X7R 16V	100N PM10		3619	212211805672	RST SM 0603 RC0603	15K PM5		3997	232270260102	RST SM 0603 RC21	1K PM5
2622	222224119876	CER2 1206 Y5V 10V	10U P8020		3620	212211805631	RST SM 0603 JUMP.	MAX 0R05					
2623	223878615649	CER2 0603 X7R 16V	100N PM10		3626	212211805631	RST SM 0603 JUMP.	MAX 0R05		5611	242254943409	IND FXD 1206 EMI 100MHZ	50R
2624	222224119876	CER2 1206 Y5V 10V	10U P8020		3627	212211805631	RST SM 0603 JUMP.	MAX 0R05		5619	242254943409	IND FXD 1206 EMI 100MHZ	50R
2625	223858615623	CER2 0603 X7R 50V	1N PM10		3630	232270260101	RST SM 0603 RC21	100R PM5		5625	242254945579	IND FXD 1206 EMI 100MHZ	100R
2631	202002191778	ELCAP SM RVJ 16V	100U PM20		3631	212266200161	PTC SM 1812 13V2	0R45 PM		5631	242254945579	IND FXD 1206 EMI 100MHZ	100R
2632	223878615649	CER2 0603 X7R 16V	100N PM10		3632	212211805631	RST SM 0603 JUMP.	MAX 0R05		5635	242254945579	IND FXD 1206 EMI 100MHZ	100R
2635	202002191778	ELCAP SM RVJ 16V	100U PM20		3633	212211805631	RST SM 0603 JUMP.	MAX 0R05		5681	242254945579	IND FXD 1206 EMI 100MHZ	100R
2636	223878615649	CER2 0603 X7R 16V	100N PM10		3634	232270260101	RST SM 0603 RC21	100R PM5		5682	242254945579	IND FXD 1206 EMI 100MHZ	100R
2641	223886715229	CER1 0603 NP0 50V	22P PM5		3635	212266200161	PTC SM 1812 13V2	0R45 PM		5971	242254900126	IND FXD 0805 EMI 100MHZ	120R
2642	223886715229	CER1 0603 NP0 50V	22P PM5		3636	212211805631	RST SM 0603 JUMP.	MAX 0R05		5982	313818875691	COI CHOKE 35UH 82M OHM	DR10X8
2643	223878619854	CER2 0603 Y5V 16V	220N P8020		3637	212211805631	RST SM 0603 JUMP.	MAX 0R05		5983	242253600428	IND FXD TSL0808 S 10U	PM10
2644	223824619858	CER2 0603 Y5V 10V	470N P8020		3638	232271161159	RST SM 1206 RC01	15R PM5					
2645	223878619854	CER2 0603 Y5V 16V	220N P8020		3639	232270260104	RST SM 0603 RC21	100K PM5		6612	932205976685	DIO SIG SM LS4148	(VISH)
2646	202203100229	ELCAP SZ 16V S	220U PM20		3640	212211805631	RST SM 0603 JUMP.	MAX 0R05		6641	933400410683	DIO REC 1N4001-E3	A (VISH)
2647	202203100229	ELCAP SZ 16V S	220U PM20		3641	232270260189	RST SM 0603 RC21	18R PM5		6668	932205976685	DIO SIG SM LS4148	(VISH)
2648	223886715331	CER1 0603 NP0 50V	330P PM5		3642	232270260189	RST SM 0603 RC21	18R PM5		6680	932205976685	DIO SIG SM LS4148	(VISH)
2649	223886715331	CER1 0603 NP0 50V	330P PM5		3643	212211805669	RST SM 0603 RC0603	10K PM5		6982	932208282668	DIO REC SM SS34-E3	(VISH)
2651	223886715331	CER1 0603 NP0 50V	330P PM5		3644	212211805669	RST SM 0603 RC0603	10K PM5					
2652	223878615649	CER2 0603 X7R 16V	100N PM10		3645	232270260224	RST SM 0603 RC21	220K PM5		7601	932222076668	IC SM AME1117CCGTZ	(AME0)
2658	223824619858	CER2 0603 Y5V 10V	470N P8020		3646	212211805631	RST SM 0603 JUMP.	MAX 0R05		7611	932222162671	IC SM CY7C65640-LFXC	(CYPR)
2659	223878615649	CER2 0603 X7R 16V	100N PM10		3653	212211805669	RST SM 0603 RC0603	10K PM5		7651	823827718751	AUDIO PROCESSIOR	
2668	222278019767	CER2 0805 Y5V 16V	2U2 PM20		3654	212211805647	RST SM 0603 RC0603	220R PM5		7652	932220471668	FET POW SM SI4835BDY-E3	(VISH)
2670	223858615623	CER2 0603 X7R 50V	1N PM10		3656	232270260102	RST SM 0603 RC21	1K PM5		7653	932217439685	TRA SIG SM BC857C	(KEC0)
2671	223858615614	CER2 0603 X7R 50V	220P PM10		3657	232270462102	RST SM 0603 RC21	1K PM5		7654	932209265685	TRA SIG SM MUN2211JG	(ONSE)
2672	203803513311	ELCAP RGA 25V S	100U PM20		3658	232270462409	RST SM 0603 RC22H	24R PM1		7655	932209265685	TRA SIG SM MUN2211JG	(ONSE)
2673	223858615623	CER2 0603 X7R 50V	1N PM10		3659	232270462409	RST SM 0603 RC22H	24R PM1		7656	932217563685	IC SM L78L05ACU	(ST00)
2674	223858615614	CER2 0603 X7R 50V	220P PM10		3660	212211805631	RST SM 0603 JUMP.	MAX 0R05		7691	935268635118	IC SM PCA9515DP	(PHSE)
2675	223858615627	CER2 0603 X7R 50V	2N2 PM10		3662	212211805631	RST SM 0603 JUMP.	MAX 0R05		7693	823827718761	128K EEPROM	
2676	223824619858	CER2 0603 Y5V 10V	470N P8020		3664	212211805631	RST SM 0603 JUMP.	MAX 0R05		7981	932215923668	IC SM LM2596SX-5.0	(NSC0)
2677	223824619858	CER2 0603 Y5V 10V	470N P8020		3666	232270260101	RST SM 0603 RC21	100R PM5		PCB Assy			
2678	223824619858	CER2 0603 Y5V 10V	470N P8020		3667	212211805669	RST SM 0603 RC0603	10K PM5		1066	313815865721	HD PCB ASSY	
2679	223878619854	CER2 0603 Y5V 16V	220N P8020		3668	232270260224	RST SM 0603 RC21	220K PM5					
2680	223824619858	CER2 0603 Y5V 10V	470N P8020		3670	212211805669	RST SM 0603 RC0603	10K PM5		2601	223886715331	CER1 0603 NP0 50V	330P PM5
2681	223878615649	CER2 0603 X7R 16V	100N PM10		3671	212211805669	RST SM 0603 RC0603	10K PM5		2602	223886715331	CER1 0603 NP0 50V	330P PM5
2682	202203100436	ELCAP KM 160V S	3U3 PM20		3672	212211805669	RST SM 0603 RC0603	10K PM5		2603	223886715331	CER1 0603 NP0 50V	330P PM5
2685	223878615649	CER2 0603 X7R 16V	100N PM10		3673	212211805669	RST SM 0603 RC0603	10K PM5		2604	223886715331	CER1 0603 NP0 50V	330P PM5
2686	202203100179	ELCAP SM HV 25V	10U PM20		3674	212211805669	RST SM 0603 RC0603	10K PM5					
2687	202203100437	ELCAP KM 25V S	22U PM20		3675	212211805669	RST SM 0603 RC0603	10K PM5		3601	232270260102	RST SM 0603 RC21	1K PM5
2688	223878615649	CER2 0603 X7R 16V	100N PM10		3676	212211805647	RST SM 0603 RC0603	220R PM5		3602	232270260273	RST SM 0603 RC21	27K PM5
2689	223878615649	CER2 0603 X7R 16V	100N PM10		3677	212211805631	RST SM 0603 JUMP.	MAX 0R05		3603	232270260102	RST SM 0603 RC21	1K PM5
2690	202203100261	ELCAP LZ 16V S	2200U PM20		3678	232270260102	RST SM 0603 RC21	1K PM5		3604	232270260273	RST SM 0603 RC21	27K PM5
2691	223858615634	CER2 0603 X7R 50V	6N8 PM10		3679	212211805631	RST SM 0603 JUMP.	MAX 0R05		3605	212211805642	RST SM 0603 RC0603	75R PM5
2692	223858615634	CER2 0603 X7R 50V	6N8 PM10		3680	212211805631	RST SM 0603 JUMP.	MAX 0R05		3606	212211805642	RST SM 0603 RC0603	75R PM5
2694	223878615649	CER2 0603 X7R 16V	100N PM10		3684	212211805669	RST SM 0603 RC0603	10K PM5		3607	212211805642	RST SM 0603 RC0603	75R PM5
2951	223891619849	CER2 0603 Y5V 25V	100N P8020		3687	212211805631	RST SM 0603 JUMP.	MAX 0R05					
2952	223886715339	CER1 0603 NP0 50V	33P PM5		3690	212211805669	RST SM 0603 RC0603	10K PM5		5601	242253595853	IND FXD SM 0603	0U10 PM10
2953	223886715339	CER1 0603 NP0 50V	33P PM5		3691	232270260101	RST SM 0603 RC21	100R PM5		5602	242253595853	IND FXD SM 0603	0U10 PM10
2954	223886715339	CER1 0603 NP0 50V	33P PM5		3692	232270260101	RST SM 0603 RC21	100R PM5		5603	242253595853	IND FXD SM 0603	0U10 PM10
2955	223886715339	CER1 0603 NP0 50V	3										

Recommended Parts List

190G6 LCD/TV

75

Go to cover page

Recommended Parts List

TYPE:190G6FB/97

30	313815760671	FRONT BEZEL ASSY	7693	823827718761	128K EEPROM
31	313815413991	BEZEL	7701	935274261518	IC SM SAA5360HL/M1/0004(PHSE)
32	313815414421	LENS-TV	7801	932222035668	IC SM TPA3005D2PHP (TI00)
33	313815414411	LENS-IR	7851	932219413671	IC SM MSP3415G-QI-B8V3(MIAS)
40	313815760681	BACK COVER ASSY	7852	933714830653	IC SM 74HC4052D (PHSE)
41	313815414031	BACK COVER	7981	932215923668	IC SM LM2596SX-5.0 (NSC0)
42	313815414041	SPEAKER COVER-A			
43	313815414051	SPEAKER COVER-B			
44	313815417041	INNER COVER-AP			
50	313815760661	BASE ASSY-190G6			
52	313815414021	HINGE COVER			
60	313815760691	FRONT COVER ASSY			
61	313815414001	FRONT COVER			
62	313815161961	MESH GRILIE			
91	313815137751	SHIELDING-UPPER-AP			
92	313815137781	SHIELDING-LOWER-AP			
95	313815414061	PHILIPS COVER			
102	313810440571	HOUSING COVER			
301	313815137731	METAL FRAME			
303	313815136071	HINGE FRAME-R			
304	313815136081	HINGE FRAME-L			
450	313815641111	CARTON			
451	313815641071	CUSHION-T			
452	313815641081	CUSHION-B			
453	313810645302	P.E. BAG			
490	313815682951	PACKING ASSY-CHINA			
1052	313815865641	BASE ASSY(190G6)			
1057	313815865651	FRAME+WIRE ASSY			
7001	932215923668	IC SM LM2596SX-5.0 (NSC0)			
7004	932220471668	FET POW SM SI4835BDY-E3(VISH)			
7005	932217439685	TRA SIG SM BC857C (KEC0)			
7006	932209265685	TRA SIG SM MUN2211JG (ONSE)			
7009	932216638668	FET POW SM SI5441DC-E3 (VISH)			
7051	932222076668	IC SM AME1117CCGTZ (AME0)			
7052	313815865671	CPU IC ASSY(AP)			
7052	932222010682	IC SM NT68F632ALG (NOVA)			
7053	932219183685	IC SM LM809M3-2.93 NOPB(NSC0)			
7054	932217438685	TRA SIG SM BC847C (KEC0)			
7055	313815865661	EEPROM IC ASSY(AP)			
7055	932210684668	IC SM AT24C32N-10SI-1.8(ATME)			
7101	932220624668	IC SM M24C02-WMN6P (ST00)			
7104	932217126668	IC SM 74LCX14T (ST00)			
7201	932222013671	IC SM MST51512L-LF (MSTA)			
7202	932222075668	IC SM AME1117BCGTZ (AME0)			
7301	932216677682	IC SM M12L16161A-7TG (ESMT)			
7553	935276561518	IC SM SAA7119E/V2/G (PHSE)			
7554	932215686685	FET SIG SM 2N7002LG (ONSE)			
7601	932222076668	IC SM AME1117CCGTZ (AME0)			
7611	932222162671	IC SM CY7C65640-LFXC (CYPR)			
7651	823827718751	AUDIO PROCESSIOR			
7652	932220471668	FET POW SM SI4835BDY-E3(VISH)			
7653	932217439685	TRA SIG SM BC857C (KEC0)			
7654	932209265685	TRA SIG SM MUN2211JG (ONSE)			
7656	932217563685	IC SM L78L05ACU (ST00)			
7691	935268635118	IC SM PCA9515DP (PHSE)			

Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

GENERAL PRODUCT SPECIFICATION													
. 19" Multifunction LCD monitor. . PC 15 pins D-SUB analog and 24 pins DVI _D digital interface. . PC audio line in with mini-Jack . TV Tuner, S-Video, RCA AV input interface with R/L Audio-in, SCART for WE model. . RCA connectors for YPbPr input . NTSC, PAL TV system. . PC graphic auto picture adjustment . 30 user modes . User friendly OSD menu . User friendly remote controller . USB Audio with A type USB connector . USB 2.0 Hub . DDC2B communication capability . Typical Resolution 1280 x 1024 non-interlace at 60 Hz . SXGA 19" color TFT LCD flat panel . Easy tilt base . Low reflection glare treatment of the front polarizer . Power management capability													
CLASS NO.		19 inch TFT SXGA LCD Monitor/TV TYPE : 190G6FB/97 BRAND : PHILIPS				8639 000 16448							
2005-08-22		NAME Sophia Hsia		SUPERS.		19		590 — 1		10		A4	
TY		CHECK		DATE 2005-08-22		Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.							

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

1.0 Foreword

2.0 Product profile

- 2.1 LCD
- 2.2 Scanning frequencies
- 2.3 Video dot rate
- 2.4 Power input
- 2.5 Power consumption
- 2.6 Dimensions
- 2.7 Weight
- 2.8 Satellite speakers
- 2.9 Subwoofer
- 2.10 USB Audio
- 2.11 USB 2.0 Hub
- 2.12 Earphone
- 2.13 Mic-phone
- 2.14 Functions
- 2.15 Ambient temperature
- 2.16 Regulatory compliance

3.0 Electrical characteristics

- 3.1 Interface signals cables
- 3.2 User interface
 - 3.2.1 Keypad definition
 - 3.2.2 Key Function definition
 - 3.2.3 Remote control
- 3.3 PC, TV requirement
 - 3.3.1 PC interface
 - 3.3.1.1 Mode storing capacity
 - 3.3.1.2 Horizontal scanning
 - 3.3.1.3 Vertical scanning
 - 3.3.1.4 Input connectors
 - 3.3.1.5 Available timings
 - 3.3.2 TV interface
 - 3.3.2.1 TV special setting
- 3.4 Power input connection
- 3.5 Power management
- 3.6 Display identification

4.0 Visual characteristics

- 4.1 Test conditions
- 4.2 Resolution
- 4.3 Brightness
- 4.4 Image size
 - 4.4.1 Actual display size
- 4.5 Brightness uniformity
- 4.6 PC white color adjustment
- 4.7 TV white color adjustment
- 4.8 TV picture centering

5.0 Mechanical characteristics

- 5.1 Controls
- 5.2 Unit dimension / weight
- 5.3 Tilt and swivel base
- 5.4 Transportation packages
 - 5.4.1 Shipping dimension / weight
 - 5.4.2 Block unit / palletization

6.0 Environmental characteristics

- 6.1 Susceptibility of display to external environment
- 6.2 Transportation tests
- 6.3 Display disturbances from external environment

CLASS NO.

19 inch TFT SXGA LCD Monitor/TV
 TYPE : 190G6FB/97
 BRAND : PHILIPS

8639 000 16448

2005-08-22

NAME Sophia Hsia

SUPERS.

19

590

—

2

10

A4

TY

CHECK

DATE

2005-08-22

Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

◀◀ Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

- 7.0 Reliability
7.1 Mean time between failures

- 8.0 Quality assurance requirements
8.1 Acceptance test

- 9.0 Serviceability

1.0 FOREWORD

This specification describes a 19" multifunction LCD Monitor, maximum resolution up to 1280x1024/60Hz non-interlaced.

2.0 PRODUCT PROFILE

Philips 19" multifunction LCD Monitor TV can connect to PC's analog D-SUB and DVI connector, and also support TV, AV, S-Video, YPbPr/HD, and AV interface. Europe model

Meet world wide major TV system: NAFTA

2.1 LCD

2.2.1. LCD

LPL panel	
Type NR.	: LM190E03_TLC1
Display area(mm)	: 376.32(H) x 301.056(V) (19.0-inch diagonal)
Number of Pixels	: 1280(H) x 1024(V)
Pitch (mm)	: 0.098(H) x 0.294(V)
Color pixel arrangement	: RGB vertical stripes
Display operating mode	: Transmissive mode, normally white
Color depth	: 16.2M colors (6 bits with FRC)
Brightness (cd/m ²)	: 420(cd/m ²)(Center 1 points Typ.)
Viewing angle(CR>10)	: 80 ° (R/L), 75° (Up) , 85° (Down), Typ
Surface treatment	: Hard coating(2H) & Low reflection glare treatment of front polarizer
Electrical interface	: LVDS (2 port)
Response Time	: 8ms(typ.) (Tr+Tf)
Power Consumption(W)	: 3.05(Max) for LCD, 22.53(Max) for inverter
Contrast ratio	: Typical 700 : 1
Module size (mm)	: 396.0(W) x 324.0(H) x 16.5(D)
Module weight (g)	: 2700(Typ), 2840(Max)
Backlight	: 4 CCFL

2.2 Scanning frequencies : Hor. : 30 - 83KHz Ver.: 56 - 76 Hz

2.3 Video dot rate : <=135 MHz

2.4 Power input : 90 - 264 Vac, 50/60 ± 2 Hz

2.5 Power consumption : max 100 W

2.6 Unit Dimensions : 590mm W x 460mm H x 265mm D (Incl. Pedestal)

2.7 Unit Weight : 10 Kg

2.8 Satellite speaker : 2 x 5 W

2.9 Subwoofer : 20 W

2.10 USB Audio : 1 USB Audio with A type USB connector

2.11 USB 2.0 Hub : 1 USB A type connector and 2 USB B type connectors

2.12 Earphone : Headphones with impedance between 8 - 600 Ω

2.13 Mic-phone : mic-phone is used only in USB audio mode.

CLASS NO.

19 inch TFT SXGA LCD Monitor/TV
TYPE : 190G6FB/97
BRAND : PHILIPS

8639 000 16448

2005-08-22

NAME Sophia Hsia

SUPERS.

19

590 — 3

10

A4

TY

CHECK

DATE 2005-08-22

Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.



2.14 Functions :

PC 15 pins D-sub analog interface and 24 pins DVI _D digital interface with audio mini jack input (PC line in).
 TV AP /China model : Tuner, S-Video, RCA AV with L/R Audio-in and YPbPr with audio.
 WE model : S-Video, RCA AV with L/R Audio-in and YPbPr with Audio, SCART.

2.15 Ambient temperature: 0 - 35 °C

2.16 Regulatory compliance :

Safety	B (Poland), CCC(China), CE(Europe), CE (NZ/Australia), CSA(Canada), Gost(Russia), IEC 950 CB Report, PSB(Singapore), NOM NYCE(Mexico), SEMKO(Nordic), UL(USA), Korea
EMI	C-tick, CE(Europe), FCC(USA), IC(Canada), BSMI, CCC(China), MIC (Korea)
Ergonomics/Power management	E2000, Nutek(Sweden), EPA, ISO13406-2
Compatibility	PC2001, Windows2000, Windows Me, Windows XP, NSTL,

3.0 Electrical characteristics

3.1 Interface signals

3.1.1 PC Signal type

Signal source: pattern generator format as attachment (Table 1 to 30) Reference generator: Quantum Data 802R
 The input signals can be applied in two different modes:

1). VESA Analog

The video input consists of red, green, and blue signals. The video signals are analog levels, where 0V corresponds to black and 700mV is the maximum signal amplitude. Input impedance of video pins is 75-ohm +/- 1%.

2). Intel DVI Digital

Input signal: Single TMDS link (Three channels: RX0-/+, RX1-/+, RX2-/+).

Sync signal input

The capability of sync signal inputs shall include separate sync, composite sync and sync on green. Input impedance: 2k2 ohms The signals are defined as follow:

Separate sync TTL level, Positive/Negative

Composite sync TTL level, Positive/Negative

Signal source: pattern generator format as attachment (Table 1 to 34)

Reference generator: Quantum Data 802R

Audio signal : Mini-jack audio input,

Input Level: 500 mVrms (Speaker output 5W when Input level > 630mVrms and Volume control at 100%)

USB Audio : Digital audio

3.1.2 TV Signal type:

RF Signal : Aerial input / 10mV(80dBuV)

CLASS NO.

19 inch TFT SXGA LCD Monitor/TV

TYPE : 190G6FB/97

BRAND : PHILIPS

8639 000 16448

2005-08-22

NAME Sophia Hsia

SUPERS.

19

590

4

10

A4

TY

CHECK

DATE

2005-08-22

Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

Go to cover page

PHILIPS




Video signal : Cinch CVBS input / 1Vpp (300mV-sync, 700mV-video.)
S video input / 1VppY-signal, 300mVpp C-signal
YPbPr input/ 1Vpp Y signal, 350mVpp Pb, Pr signal
SCART input / CVBS, S, YPbPr are included.(only for WE)
Audio signal : Cinch (1) R/L for AV and S-video.
Input Level: 500 mVrms (Speaker output 5W when Input level > 630mVrms and Volume control at 100%)
Cinch (2) R/L for YPbPr video.
Input Level: 500 mVrms (Speaker output 5W when Input level > 630mVrms and Volume control at 100%)
SCART (3) One R/L input
Input Level: 500 mVrms (Speaker output 5W when Input level > 630mVrms and Volume control at 100%)


3.2 User interface
On screen display user control via keypad and remote control for PC, and TV OSD.

3.2.1 keypad Control on bass 3.2.2 RC on panel down-right

CONTROL BOARD



RC BOARD



KEY	FUNCTION
DC_SW	DC power on/off
UP	Normal up / channel up
DOWN	Normal down / channel down
LEFT	Normal left
RIGHT	Normal right
OK	Normal enter / menu
AUTO	Auto adjusting
CLASSIC	Sound effect
JAZZ	Sound effect
ROCK	Sound effect
NEUTRAL	No extra effect
MUTE	Audio mute

Normal working LED indicator: Green
Power saving LED indicator : Amber.

- 3.2.3. At Monitor mode:
1. Press OK Key to call Monitor Menu
 2. Press UP/DOWN/LEFT/RIGHT Key to select Monitor function
 3. LEFT/RIGHT is Volume Hot Key. Rotary is to control volume.
 4. UP/DOWN key is for switching input signal from D-SUB/DVI/TV/AV/S-Video/HD
 5. Use remoter controller to select D-SUB menu function.

CLASS NO.		19 inch TFT SXGA LCD Monitor/TV					
		TYPE : 190G6FB/97		8639 000 16448			
		BRAND : PHILIPS					
2005-08-22							
NAME	Sophia Hsia	SUPERS.	19	590	5	10	A4
TY	CHECK	DATE	2005-08-22	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.			



3.2.4. At TV mode(CVB, S-video and HD are included):

1. Press OK Key to display TV Menu
2. Press UP/DOWN/LEFT/RIGHT Key to select TV function
3. UP/DOWN Key is Channel Hot Key.
4. LEFT/RIGHT Key is Volume Hot Key.
5. Use remoter controller to select TV menu function.

3.2.5. Recalling from saving mode:

Power saving mode in Dsub or DVI: If sync is off, the monitor TV will enter "Monitor saving mode". And the LED indicator will be changed to amber. The way to wake up from power saving mode are as below:

1. "Source" key on remote control or UP/DOWN key in keypad→ change to other channel
2. Sync exists for Dsub or DVI mode.


Power saving mode in TV mode: When switched off monitor TV by using RC "Standby" key or no TV signal input for 30 minutes, the monitor will enter "TV standby mode". Meanwhile the LED indicator will be changed to amber. The way to wake up from power saving mode are as below:

1. "Source" key on remote control or UP/DOWN key in keypad→ weak up in next source mode.
2. "Standby" key on remote control.

Remark :

Turn off power when the set is entered TV power saving mode. If turn on power, the set still stay in TV saving mode.

3.3 Remote control unit definition



- | | |
|---------------------------------|--|
| 1. Power | : Power On/Standby |
| 2. Source | : Source select for PC, Tuner, CVBS, S-video, HD |
| 3. Sleep Timer | : Sleep timer 15,30,60,120,180,240 OFF |
| 4. TT | : Teletext |
| 5. 2 nd audio | : Sound select in TV |
| 6. Red | : for TT |
| 7. Green | : for TT |
| 8. Yellow | : for TT |
| 9. Cyan | : for TT |
| 10. ? | |
| 11. ? | |
| 12. surround | : virtual surround |
| 13. Menu | : Main menu select and OK key |
| 14. Display Format | : Select display format (4:3, Expand 4:3, Compress 16:9) |
| 15. .OK | : OK |
| 16. UP | :UP in menu |
| 17. LEFT | :LEFT in menu |
| 18. RIGHT | :RIGHT in menu |
| 19. DOWN | :DOWN in menu |
| 20. VOL+ | : Volume Up |
| 21. Mute | : Sound mute function |
| 22. CH+ | : Channel Up |
| 23. Smart Sound | : Select sound effect |
| 24. VOL- | : Volume Down |
| 25. Smart Picture | : Select picture effect (Personal/Movie/Sports/weak signal/multimedia/Night) |
| 26. CH- | : Channel Down |
| 27-35,37. Numerica keys : (0~9) | : Channel setting |
| 36. ? | |
| 38. Prev-CH | : Recall previous CH |

All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority, from the proprietors.

CLASS NO.

19 inch TFT SXGA LCD Monitor/TV

TYPE : 190G6FB/97

BRAND : PHILIPS

8639 000 16448

2005-08-22

NAME Sophia Hsia

SUPERS.

19

590

6

10

A4

TY

CHECK

DATE

2005-08-22

Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

3.3 PC and TV requirement

3.3.1 PC interface

- 3.3.1.1 Mode storing capacity
Pre-load : 15
User modes : 30

3.3.1.2 Horizontal scanning

Sync polarity : Positive or Negative
Scanning frequency : 30 - 83 KHz

3.3.1.3 Vertical scanning


Sync polarity : Positive or Negative
Scanning frequency : 56 - 76 Hz

3.3.1.4 Input connectors

1. VGA signal cable

The input signals are applied to display through D-sub cable.
Length: 1.8 M +/- 50 mm (fixed)
Connector type: D-sub male.
With DDC_2B pin assignments.
Blue connector thumb-operated jackscrews

15-pin D-sub VGA connector of the signal cable:



1	Red video input	9	DDC +3.3V (or 5V)
2	Green video input /SOG	10	Logic ground
3	Blue video input	11	GND
4	GND	12	Serial data line (SDA)
5	GND cable detect	13	H. Sync / H+V
6	Red video ground	14	V. Sync
7	Green video ground	15	Data clock line (SCL)
8	Blue video ground		

2. Digital signal cable

The input signals are applied to display through DVI-D cable.
Length: 1.8 M +/- 50 mm (fixed)
Connector type: DVI-D male
With DDC_2B pin assignments.
White connector thumb-operated jackscrews
Panel Link T.M.D.S input.

24-pin DVI-D digital connect of signal cable.

CLASS NO.

19 inch TFT SXGA LCD Monitor/TV
TYPE : 190G6FB/97
BRAND : PHILIPS

8639 000 16448

2005-08-22

NAME Sophia Hsia

SUPERS.

19

590

7

10

A4

TY

CHECK

DATE 2005-08-22


Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

PHILIPS



Pin1



1	T.M.D.S. Data2-	9	T.M.D.S. Data1-	17	T.M.D.S. Data0-
2	T.M.D.S. Data2+	10	T.M.D.S. Data1+	18	T.M.D.S. Data0+
3	T.M.D.S. Data2/4 Shield	11	T.M.D.S. Data1/3 Shield	19	T.M.D.S. Data0/5 Shield
4	No connect	12	No connect	20	No connect
5	No connect	13	No connect	21	No connect
6	DDC Clock	14	+5V Power	22	T.M.D.S. Clock Shield
7	DDC Data	15	Ground (for +5V)	23	T.M.D.S. Clock+
8	No connect	16	Hot Plug Detect	24	T.M.D.S. Clock-

3. CVBS

The input signals are applied to display through CVBS cable

Pin assignment

PIN NO.	SIGNAL
1	GND
2	CVBS
3	CVBS
4	CVBS

4. S-Video

The input signals are applied to display through S-Video cable

Pin assignment

PIN NO.	SIGNAL
1	GND
2	GND
3	GND
4	GND
5	GND
6	LUMA
8	CHROMA

5. Component Video

The input signals are applied to display through Component Video RCA Jack pin assignment

PIN NO.	SIGNAL
1	GND
2	Red → Pr
3	GND
4	Blue → Pb
5	GND
6	Green → Y

CLASS NO.

19 inch TFT SXGA LCD Monitor/TV

TYPE : 190G6FB/97

BRAND : PHILIPS

8639 000 16448

2005-08-22

NAME Sophia Hsia

SUPERS.

19

590

8

10

A4

TY

CHECK

DATE 2005-08-22

Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

Go to cover page


PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

6. SCART

Scart connector is only used in WE model. The Scart (Syndicat des Constructeurs d'Appareils Radiorecepteurs et Televiseurs) connector is used for combined audio and video connections.



Pin	TV SCART
1	N/C
2	Right audio input
3	N/C
4	Audio ground
5	Blue ground
6	Left audio input
7	Blue output
8	0-2.5 volts (low) when: TV output 4.5-7.5 volts (High-to-6v) when: -inputting picture format setting is '16:9', 9-12 volts (high-to-12v) when: -inputting picture format setting is '4:3' (
9	Green ground
10	N/C
11	Green output
12	N/C
13	Red ground
14	N/C
15	Red output
16	0 volt (low) when:- pin 8 of the TV scart is low or when: - Composite video signal 1-3 volts (high) when: - video input setting is 'RGB',
17	Composite video output ground
18	Composite video input ground
19	N/C
20	Composite video input
21	Ground

CLASS NO.

19 inch TFT SXGA LCD Monitor/TV
TYPE : 190G6FB/97
BRAND : PHILIPS

8639 000 16448

2005-08-22

NAME Sophia Hsia

SUPERS.

19

590

—

9

10

A4

TY

CHECK

DATE 2005-08-22

Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.



3.3.1.5 PC mode timings

The maximum resolution display of this monitor is up to 1280x1024, SXGA signal input with full screen display. It shall also automatically up-scale the lower resolution video modes into 1280x1024 full screen display. The display capabilities shall include the following timing modes:

(1) Preset modes (30 modes)

Table 2.1 Preset modes

#	Resolution	H-Frequency	Pixel rate	V-Frequency	Comment
1	640X350	31.5K	25.175	70Hz	IBM VGA 10h
2	720X400	31.5K	28.322	70Hz	IBM VGA 3h
3	640X480	31.5K	25.175	60Hz	
4	640X480	35.0K	30.24	67Hz	
5	640X480	37.9K	31.5	72Hz	
6	640X480	37.5K	31.501	75Hz	
7	800X600	35.2K	36	56Hz	
8	800X600	37.9K	40	60Hz	
9	800X600	48.1K	50	72Hz	
10	800X600	46.9K	49.498	75Hz	
11	832X624	49.7K/	57.28	75Hz	MAC
12	960X720	44.76K	57.58	60Hz	
13	960X720	56.4K	72.42	75Hz	
14	1024X768	48.4K	65	60Hz	
15	1024X768	56.5K	75	70Hz	
16	1024X768	60.0K	78.75	75Hz	
17	1024X768	61.1K	83.096	76Hz	IBM XGA-2
18	1152X864	54.0K	79.9	60Hz	Non-VESA
19	1152X864	63.9K	94.5	70Hz	Non-VESA
20	1152X864	67.5K	108	75Hz	
21	1152X870	68.7K	100	75Hz	MAC
22	1152X900	61.8K	92.94	66Hz	SUN Mode IV
23	1152X900	71.8K	108	76Hz	SUN Mode II
24	1280X960	60.0K	108	60Hz	
25	1280X960	75.0K	129.895	75Hz	Non-VESA
26	1280X1024	64.0K	108	60Hz	
27	1280X1024	71.7K	117	67Hz	SUN Mode V
28	1280X1024	76.0K	130.223	72Hz	DOS/V
29	1280X1024	80.0K	135	75Hz	
30	1280X1024	81.1K	135.008	76Hz	SUN Mode I

CLASS NO.

19 inch TFT SXGA LCD Monitor/TV

TYPE : 190G6FB/97

BRAND : PHILIPS

8639 000 16448

2005-08-22

NAME Sophia Hsia

SUPERS.

19

590 — 10

10

A4

TY CHECK

DATE 2005-08-22

Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

Go to cover page

PHILIPS




All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

3.3.2 TV interface:

F1-19" TV function include

- 1. Tuner (AP model and China)
- 2. S-video
- 3. CVBS (or AV) (RCA connectors)
- 4. Audio R/L input (RCA connectors)
- 5. YPbPr and audio(RCA connectors)

Location:



Following table is the deviation of main TV system.

Item	AP	China	NAFTA
TV color system	PAL	PAL	NTSC
Tuner	FQ1216ME Intermediate Frequency 38.9MHz	FQ1256 Intermediate Frequency 38MHz	FQ1236 Intermediate Frequency 38MHz
TV system	B/G, I	D/K	M
Sound decoder	MSP3415	MSP3415	MSP3445
CVBS, YC	PAL/NTSC	PAL/NTSC	PAL/NTSC
Closed caption	N	N	Y
V-chip	N	N	Y
Teletext	Y	N	N
Remote controller	WE version	WE version	NAFTA version
Channel number	100	100	US Air 68, cable 125

Note: WE model is without tuner.

CLASS NO.		19 inch TFT SXGA LCD Monitor/TV		8639 000 16448	
		TYPE : 190G6FB/97			
		BRAND : PHILIPS			
2005-08-22					
NAME	Sophia Hsia	SUPERS.	19	590	11
TY	CHECK	DATE	2005-08-22	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatsoever is not permitted without written authority from the proprietors.

Following table is the detail TV System list.

TV system	Position of sound carrier (MHz)	Sound system	Color system	Country
M	4.5/4.724212	FM-Stereo(A2)	NTSC	Korea
	4.5	FM-FM(EIA-J)	NTSC	Japan
	4.5	BTSC-stereo+SAP	NTSC	USA
N	4.5	BTSC-stereo+SAP	PAL	Argentina
B/G	5.5/5.7421875	FM-stereo(A2)	PAL	Germany, Austria, Switzerland, Italy, Netherlands,
	5.5/5.85	FM-Mono/NICAM	PAL	Belgium, Spain, Denmark, Finland, Norway, Sweden.
L	6.5/5.85	AM-Mono/NICAM	SECAM-L	France
I	6.0/6.552	FM-Mono/NICAM	PAL	Great Britain, Hong Kong, Ireland
D/K	6.5/6.2578125	FM-Stereo (A2,D/K1)	SECAM-East	Slovak. Rep.
	6.5/6.7421875	FM-Stereo (A2,D/K2)	PAL	None
	6.5/5.7421875	FM-Stereo (A2,D/K3)	SECAM-East	Poland
	6.5/5.85	FM-Mono/NICAM(D/K,NICAM)	PAL	China, Hungary

3.3.2.1 TV special setting:

Close Caption, V-chip (NAFTA Tuner, CVBS input source only)

- CC-1 .. CC-4 decoding and display
- TXT1..TXT4 Text mode
- No Extended Data Services (EDS)
- support violence rating and checking
- Automatic CC-1 selection at user mute

Teletext (AP model only)

- Level 1.5 teletext
- 0 and 10 pages
- Processing in hardware

3.4 Power input connection

AC/DC adapter : +16V DC/ 3.95A (AC input 100~240V)
 AC Power cord length : 1.8 M
 Power cord type : 3 leads power cord with protective earth plug.

3.5 Power management

OFF modes is just for PC mode.

STATUS	H-sync	V-sync	Video	Power	LED
On	On	On	Active	<100 W	Green /With Audio and sub-woofer (Note 1)
On	On	On	Active	<62W	Green / Without subwoofer
Off	Off	On	Blanked	<2W	Amber LCD (Note 2)
Off	On	Off	Blanked	<2W	Amber LCD (Note 2)
Off	Off	Off	Blanked	<2W	Amber LCD (Note 2)
DC Power off			N / A	<1W	LED Off (Note 2)

Note 1: sub-woofer uses individual power.

Note2: Upstream USB cable is disconnected to PC.

CLASS NO.		19 inch TFT SXGA LCD Monitor/TV		8639 000 16448	
		TYPE : 190G6FB/97			
		BRAND : PHILIPS			
2005-08-22					
NAME	Sophia Hsia	SUPERS.	19	590	12
TY	CHECK	DATE	2005-08-22	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

Go to cover page

PHILIPS



3.6 Display identification

In accordance with DDC requirement - "DDC2B".

4.0 Visual characteristics

4.1 Test conditions

4.1 Test conditions

Unless otherwise specified, this specification is defined under the following conditions.

- (1) Input signal: As defined in 3.3, 1280 x 1024 non-interlaced mode (80K/75Hz), signal sources must have 75 ohm output impedance.
- (2) Luminance setting: controls to be set to 200 nits with full screen 70 % duty cycle white signal
- (3) Warm up: more than 30 minutes after power on with signal supplied.
- (4) Ambient light: 400 -- 600 lux.
- (5) Ambient temperature: 20 ± 5 °C

4.2 Resolution

Factory preset modes (15 modes)

#	Resolution	H-Frequency	Pixel rate	V-Frequency	Comment
1	640X350	31.5KHz	25.175	70Hz	IBM VGA 10h
2	720X400	31.5KHz	28.322	70Hz	IBM VGA 3h
3	640X480	37.5KHz	31.501	75Hz	
4	640X480	35.0KHz	30.24	67Hz	
5	640X480	31.5KHz	25.175	60Hz	
6	800X600	35.2KHz	36	56Hz	
7	800X600	46.9KHz	49.498	75Hz	
8	800X600	37.9KHz	40	60Hz	
9	832X624	49.7KHz	57.28	75Hz	MAC
10	1024X768	60.0KHz	78.75	75Hz	
11	1024X768	48.4KHz	65	60Hz	
12	1152X870	68.7KHz	100	75Hz	MAC
13	1152X900	71.8KHz	108	76Hz	SUN Mode II
14	1280X1024	64.0KHz	108	60Hz	
15	1280X1024	80.0KHz	135	75Hz	

Note: 1.Screen displays perfect picture at 15 factory-preset modes.

2.Screen displays visible picture with OSD warning when input modes are other than 30 preset modes.

4.3 Brightness:

typical 450 nits at maximum contrast and Brightness. (at center of the screen, Fig. 1)

CLASS NO.

19 inch TFT SXGA LCD Monitor/TV
TYPE : 190G6FB/97
BRAND : PHILIPS

8639 000 16448

2005-08-22

NAME Sophia Hsia

SUPERS.

19

590

13

10

A4

TY

CHECK

DATE 2005-08-22

Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.



4.4 Image size

4.4.1 Actual display size 376.32 x 301.056mm

4.5 Brightness uniformity

Set contrast at 100% and turn the brightness to Max. (At original color)

Apply the Fig 1, it should comply with the following formula:

$$\frac{\text{Minimum luminance of five points (brightness)}}{\text{Maximum luminance of five points (brightness)}} > 75\%$$

4.6 PC White color adjustment

There are three factory preset white color 6500K

Apply full white pattern, with brightness in 50 % position and the contrast control at 50% position.

The 1931 CIE Chromaticity (color triangle) diagram (x,y) coordinate for the screen center should be:

6500K CIE coordinates $X = 0.313 \pm 0.020$
 $Y = 0.329 \pm 0.020$

4.7 TV White color adjustment

There is one factory preset white color $x=0.289 \pm 0.020$; $y=0.304 \pm 0.020$ for TV RF signal with the 1931 CIE Chromaticity diagram (x,y) coordinate ,FLUKE54200 color temp pattern, Smart picture is Personal.

4.8 TV picture centering.

Use CVBS (PAL and NTSC) input with cross hatch pattern to check the picture centering and should be

Left(size)-right(size) < +/- 3mm.

Up(size)-down(size) < +/- 3mm.

5.0 Mechanical characteristics

5.1 Controls

Control keys in Base :

- Up key
- Down key
- OK key
- Right key
- Left key
- DC power switch
- Auto key
- Neutral key
- Jazz key
- Rock key
- Classic key
- Mute key

Front in panel - RC sensor

- Rear I/O
- PC D-sub
 - PC DVI
 - Tuner input (for AP/China model)
 - Cinch CVBS input (AV)
 - Cinch Audio input (S-video and CVBS use same audio)
 - S-Video input
 - Mini jack PC audio input
 - YPbPr
 - Audio for YPbPr
 - SCART (for We model)

CLASS NO.

19 inch TFT SXGA LCD Monitor/TV

TYPE : 190G6FB/97

BRAND : PHILIPS

8639 000 16448

2005-08-22

NAME Sophia Hsia

SUPERS.

19

590

14

10

A4

TY

CHECK

DATE

2005-08-22

Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

Go to cover page

PHILIPS



- I/O in bass
- Earphone
 - Mic_phone
 - 2 x USB B type
 - USB A type
 - DC inlet
 - Subwoofer output

5.2 Unit dimension / Weight
Set dimension (incl. pedestal): 590mm W x 460mm H x 265mm D Net weight : 10 Kg

5.3 Tilt base
tilt angle : -5 to 25 degree

5.4 Transportation packages

- 5.4.1 Shipping dimension/Weight
Carton dimension : 677mm W x 564mm H x 526mm D
Gross weight : 14.5 Kg
- 5.4.2 Block unit / Palletization (Sea shipment)
- | layers/block | sets/layer | sets/block unit |
|--------------|------------|-----------------|
| 3 / 4 | 4 | 12/16 |

6.0 Environmental characteristics
The following sections define the interference and susceptibility condition limits that might occur between external environment and the display device.

6.1 Susceptibility of display to external environment

- Operating
- Temperature : 0 to 35 °C
 - Humidity : 80% max
 - Altitude : 0-3658m
 - Air pressure : 600-1100 mBAR
- Storage
- Temperature : -20 to 60 °C
 - Humidity : 95% max (< 40°C)
 - Altitude : 0-12192m
 - Air pressure : 300-1100 mBAR
- ** Note: recommend at 0 to 35°C, Humidity less than 60 %

6.2 Transportation tests

Standard		ISTA-1A
Drop Test	Height	61cm
	Sequence	1C-3E-6F (10 drops)
	Test Result	Electrical function ok Mechanical function ok No serious damage on set appearance (room temp./-10°C, humidity 70 %)
Vibration Test	Sequence	--- PACKAGING 5~500 Hz , 0.73Gms , 30 min. for Each axis(X,Y,Z)
	Test Result	Electrical function ok Mechanical function ok No serious damage on set appearance

6.3 Display disturbances from external environment
According to IEC 801-2 for ESD disturbances

7.0 Reliability

CLASS NO.		19 inch TFT SXGA LCD Monitor/TV		8639 000 16448			
		TYPE : 190G6FB/97					
		BRAND : PHILIPS					
2005-08-22							
NAME	Sophia Hsia	SUPERS.	19	590	15	10	A4
TY	CHECK	DATE	2005-08-22	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.			



8.1 Acceptance test

according to MIL-STD-105D Control II level

AQL : 0.65 (major)
2.5 (minor)
(please also refer to annual quality agreement)

9.0 Serviceability

The serviceability of this monitor should fulfill the requirements which are prescribed in UAW-0346 and must be checked with the check list UAT-0361.




Fig 1: Brightness and Uniformity measure points

Table 1. NAFTA TV Channels

US- Air broadcast channel

Broadcast Channel	Video Carrier (MHz)	Audio Carrier (MHz)	Range (MHz)
2	55.25	59.75	54-60
3	61.25	65.75	60-66
4	67.25	71.75	66-72
5	77.25	81.75	76-82
6	83.25	87.75	82-88
7	175.25	179.75	174-180
8	181.25	185.75	180-186
9	187.25	191.75	186-192
10	193.25	197.75	192-198
11	199.25	203.75	198-204
12	205.25	209.75	204-210
13	211.25	215.75	210-216
14	471.25	475.75	470-476
15	477.25	481.75	476-482
16	483.25	487.75	482-488
17	489.25	493.75	488-494
18	495.25	499.75	494-500
19	501.25	505.75	500-506
20	507.25	511.75	506-512
21	513.25	517.75	512-518
22	519.25	523.75	518-524
23	525.25	529.75	524-530
24	531.25	535.75	530-536

CLASS NO.

19 inch TFT SXGA LCD Monitor/TV

TYPE : 190G6FB/97

BRAND : PHILIPS

8639 000 16448

2005-08-22

NAME Sophia Hsia

SUPERS.

19

590

16

10

A4

TY

CHECK

DATE

2005-08-22

Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

25	537.25	541.75	536-542
26	543.25	547.75	542-548
27	549.25	553.75	548-554
28	555.25	559.75	554-560
29	561.25	565.75	560-566
30	567.25	571.75	566-572
31	573.25	577.75	572-578
32	579.25	583.75	578-584
33	585.25	589.75	584-590
34	591.25	595.75	590-596
35	597.25	601.75	596-602
36	603.25	607.75	602-608
37	609.25	613.75	608-614
38	615.25	619.75	614-620
39	621.25	625.75	620-626
40	627.25	631.75	626-632
41	633.25	637.75	632-638
42	639.25	643.75	638-644
43	645.25	649.75	644-650
44	651.25	655.75	650-656
45	657.25	661.75	656-662
46	663.25	667.75	662-668
47	669.25	673.75	668-674
48	675.25	679.75	674-680
49	681.25	685.75	680-686
50	687.25	691.75	686-692
51	693.25	697.75	692-698
52	699.25	703.75	698-704
53	705.25	709.75	704-710
54	711.25	715.75	710-716
55	717.25	721.75	716-722
56	723.25	727.75	722-728
57	729.25	733.75	728-734
58	735.25	739.75	734-740
59	741.25	745.75	740-746
60	747.25	751.75	746-752
61	753.25	757.75	752-758
62	759.25	763.75	758-764
63	765.25	769.75	764-770
64	771.25	775.75	770-776
65	777.25	781.75	776-782
66	783.25	787.75	782-788
67	789.25	793.75	788-794
68	795.25	799.75	794-800
69	801.25	805.75	800-806

US-Cable channel

Cable Channel	Video carrier MHz	Audio carrier MHz	Range MHz
2	55.25	59.75	54-60
3	61.25	65.75	60-66
4	67.25	71.75	66-72
1	73.25	77.75	72-78
5	79.25	83.75	76-82
6	85.25	89.75	82-88
95	91.25	95.75	90-96
96	97.25	101.75	96-102
97	103.25	107.75	102-108
98	109.25	113.75	108-114

CLASS NO.

19 inch TFT SXGA LCD Monitor/TV
TYPE : 190G6FB/97
BRAND : PHILIPS

8639 000 16448

2005-08-22

NAME Sophia Hsia

SUPERS.

19

590

17

10

A4

TY

CHECK

DATE 2005-08-22

Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

99	115.25	119.75	114-120
14	121.25	125.75	120-126
15	127.25	131.75	126-132
16	133.25	137.75	132-138
17	139.25	143.75	138-144
18	145.25	149.75	144-150
19	151.25	155.75	150-156
20	157.25	161.75	156-162
21	163.25	167.75	162-168
22	169.25	173.75	168-174
7	175.25	179.75	174-180
8	181.25	185.75	180-186
9	187.25	191.75	186-192
10	193.25	197.75	192-198
11	199.25	203.75	198-204
12	205.25	209.75	204-210
13	211.25	215.75	210-216
23	217.25	221.75	216-222
24	223.25	227.75	222-228
25	229.25	233.75	228-234
26	235.25	239.75	234-240
27	241.25	245.75	240-246
28	247.25	251.75	246-252
29	253.25	257.75	252-258
30	259.25	263.75	258-264
31	265.25	269.75	264-270
32	271.25	275.75	270-276
33	277.25	281.75	276-282
34	283.25	287.75	282-288
35	289.25	293.75	288-294
36	295.25	299.75	294-300
37	301.25	305.75	300-306
38	307.25	311.75	306-312
39	313.25	317.75	312-318
40	319.25	323.75	318-324
41	325.25	329.75	324-330
42	331.25	335.75	330-336
43	337.25	341.75	336-342
44	343.25	347.75	342-348
45	349.25	353.75	348-354
46	355.25	359.75	354-360
47	361.25	365.75	360-366
48	367.25	371.75	366-372
49	373.25	377.75	372-378
50	379.25	383.75	378-384
51	385.25	389.75	384-390
52	391.25	395.75	390-396
53	397.25	401.75	396-402
54	403.25	407.75	402-408
55	409.25	413.75	408-414
56	415.25	419.75	414-420
57	421.25	425.75	420-426
58	427.25	431.75	426-432
59	433.25	437.75	432-438
60	439.25	443.75	438-444
61	445.25	449.75	444-450
62	451.25	455.75	450-456
63	457.25	461.75	456-462
64	463.25	467.75	462-468
65	469.25	473.75	468-474
66	475.25	479.25	474-480

CLASS NO.

19 inch TFT SXGA LCD Monitor/TV

TYPE : 190G6FB/97

BRAND : PHILIPS

8639 000 16448

2005-08-22

NAME Sophia Hsia

SUPERS.

19

590 — 18

10

A4

TY

CHECK

DATE

2005-08-22

Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

 Go to cover page




All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

67	481.25	485.75	480-486
68	487.25	491.75	486-492
69	493.25	497.75	492-498
70	499.25	503.75	498-504
71	505.25	509.75	504-510
72	511.25	515.75	510-516
73	517.25	521.75	516-522
74	523.25	527.75	522-528
75	529.25	533.75	528-534
76	535.25	539.75	534-540
77	541.25	545.75	540-546
78	547.25	551.75	546-552
79	553.25	557.75	552-558
80	559.25	563.75	558-564
81	565.25	569.75	564-570
82	571.25	575.75	570-576
83	577.25	581.75	576-582
84	583.25	587.75	582-588
85	589.25	593.75	588-594
86	595.25	599.75	594-600
87	601.25	605.75	600-606
88	607.25	611.75	606-612
89	613.25	617.75	612-618
90	619.25	623.75	618-624
91	625.25	629.75	624-630
92	631.25	635.75	630-636
93	637.25	641.75	636-642
94	643.25	647.75	642-648
100	649.25	653.75	648-654
101	655.25	659.75	654-660
102	661.25	665.75	660-666
103	667.25	671.75	666-672
104	673.25	677.75	672-678
105	679.25	683.75	678-684
106	685.25	689.75	684-690
107	691.25	695.75	690-696
108	697.25	701.75	696-702
109	703.25	707.75	702-708
110	709.25	713.75	708-714
111	715.25	719.75	714-720
112	721.25	725.75	720-726
113	727.25	731.75	726-732
114	733.25	737.75	732-738
115	739.25	743.75	738-744
116	745.25	749.75	744-750
117	751.25	755.75	750-756
118	757.25	761.75	756-762
119	763.25	767.75	762-768
120	769.25	773.75	768-774
121	775.25	779.75	774-780
122	781.25	785.75	780-786
123	787.25	791.75	786-792
124	793.25	797.75	792-798
125	799.25	803.75	798-804

CLASS NO.

19 inch TFT SXGA LCD Monitor/TV
 TYPE : 190G6FB/97
 BRAND : PHILIPS

8639 000 16448

2005-08-22

NAME Sophia Hsia

SUPERS.

19

590 — 19

10

A4

TY

CHECK

DATE 2005-08-22

Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

0. Warning

All ICs and many other semi-conductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically. When repairing, make sure that you are connected with the same potential as the mass of the unit via a wrist wrap with resistance. Keep components and tools also at the same potential !

1. Servicing of SMDs (Surface Mounted Devices)

1.1 General cautions on handling and storage

- Oxidation on the terminals of SMDs results in poor soldering.

Do not handle SMDs with bare hands.

- Avoid using storage places that are sensitive to oxidation such as places with sulphur or chlorine gas, direct sunlight, high temperatures or a high degree of humidity. The capacitance or resistance value of the SMDs may be affected by this.


- Rough handling of circuit boards containing SMDs may cause damage to the components as well as the circuit boards. Circuit boards containing SMDs should never be bent or flexed. Different circuit board materials expand and contract at different rates when heated or cooled and the components and/or solder connections may be damaged due to the stress. Never rub or scrape chip components as this may cause the value of the component to change. Similarly, do not slide the circuit board across any surface.

1.2 Removal of SMDs

- Heat the solder (for 2-3 seconds) at each terminal of the chip. By means of litz wire and a slight horizontal force, small components can be removed with the soldering iron. They can also be removed with a solder sucker (see Fig. 1A).

Fig. 1 DISMOUNTING

1A)



While holding the SMD with a pair of tweezers, take it off gently using the soldering iron's heat applied to each terminal (see Fig. 1 B).

- Remove the excess solder on the solder lands by means of litz wire or a solder sucker (see Fig. 1C).

1.3 Caution on removal

- When handling the soldering iron, use suitable pressure and be careful.
- When removing the chip, do not use undue force with the pair of tweezers.
- The soldering iron to be used (approx. 30 W) should


preferably be equipped with a thermal control (soldering temperature: 225 to 250 C).

- The chip, once removed, must never be reused.

1.4 Attachment of SMDs

- Locate the SMD on the solder lands by means of tweezers and solder the component on one side. Ensure that the component is positioned correctly on the solder lands (see Fig. 2A).
- Next complete the soldering of the terminals of the component (see Fig. 2B).

Fig. 2 MOUNTING



2. Caution when attaching SMDs

- When soldering the SMD terminals, do not touch them directly with the soldering iron. The soldering should be done as quickly as possible, care must be taken to avoid damage to the terminals of the SMDs themselves.
- Keep the SMD's body in contact with the printed board when soldering.
- The soldering iron to be used (approx. 30 W) should preferably be equipped with a thermal control (soldering temperature: 225 to 250 C).
- Soldering should not be done outside the solder land.
- Soldering flux (of rosin) may be used, but should not be acidic.
- After soldering, let the SMD cool down gradually at room temperature.
- The quantity of solder must be proportional to the size of the solder land. If the quantity is too great, the SMD might crack or the solder lands might be torn loose from the printed board (see Fig. 3).




Fig. 3 Examples

◀◀ Go to cover page

3. Lead-free product identification

You can identify lead-free product by Philips-lead-free logo on PCB.



4. Lead-free product repair instruction

4.1 Use only lead-free Solder Alloy 0622 149 00106(1.2mm SAC305) or 0622 14900108(1.0mm SAC305).

Remark: For lead free soldering material, please visit www.alphametals.com website for details. This is recommended by Philips.

4.2 Use only adequate solder tools applicable for lead-free soldering-tin. The solder tool must be able to reach at least a solder-temperature of 400 , to stabilize the adjusted temperature at the solder-tip and to exchange solder-tips for different applications. Small Passives/Actives to be removed with thermal tweezers

Automated system for IC and BGA repair (Microscope, Camera, Beam split optics, Computer, Programmer, Heat controllers, Vacuum system, Laser pointer) Solder Hand-Tool (Adjustable in temperature height, Temperature shall be held constant, Flexible tips)

4.3 Adjust your solder tool so that a temperature around 360 -380 is reached and stabilized at the solder joint.

Heating-time of the solder-joint should not exceed ~ 4 sec. Avoid temperatures above 400 otherwise wear-out of tips will rise drastically and flux-fluid will be destroyed. Corrosion of Tool-Spikes can be avoided when using SAC305 and a temperature of less than 400 .

4.4 Mix of lead-free solder-tin/parts with leaded soldering-tin/parts is possible but not recommended. If not to avoid clean carefully the solder-joint from old tin and re-solder with new tin.

4.5 Use only original spare-parts listed in the Service-Manuals. Standard-material(consumables) can also be purchased at external companies.

4.6 Special information for lead-free BGA-ICs: this ICs will be delivered in so-called dry-packaging to protect the IC against moisture and with lead-free logo on it. This packaging may only be opened shortly before it is used (soldered). Otherwise the body of the IC gets wet inside and during the heating time the structure of the IC will be destroyed due to high (steam-)pressure. If the packaging was opened before usage the IC has to be heated up for some hours (around 90) for drying (Take attention for ESD-protection!)

5. Rework on BGA (Ball Grid Array) ICs

General

Although (LF)BGA assembly yields are very high, there may still be a requirement for component rework. By rework, we mean the process of removing the component from the PWB and replacing it with a new component. If an (LF)BGA is removed from a PWB, the solder balls of the component are deformed drastically so the removed (LF)BGA has to be discarded.

Device Removal

As is the case with any component that, it is essential when removing an (LF)BGA, the board, tracks, solder lands, or surrounding components are not damaged. To remove an (LF)BGA, the board must be uniformly heated to a temperature close to the reflow soldering temperature. A uniform temperature reduces the chance of warping the PWB.

To do this, we recommend that the board is heated until it is certain that all the joints are molten. Then carefully pull the component off the board with a vacuum nozzle. For the appropriate temperature profiles, see the IC data sheet.

Area Preparation

When the component has been removed, the vacant IC area must be cleaned before replacing the (LF)BGA.

Removing an IC often leaves varying amounts of solder on the mounting lands. This excessive solder can be removed with either a solder sucker or solder wick. The remaining flux can be removed with a brush and cleaning agent. After the board is properly cleaned and inspected, apply flux on the solder lands and on the connection balls of the (LF)BGA


Note: Do not apply solder paste, as this has shown to result in problems during re-soldering.

Device Replacement


The last step in the repair process is to solder the new component on the board. Ideally, the (LF)BGA should be aligned under a microscope or magnifying glass. If this is not possible, try to align the (LF)BGA with any board markers. To reflow the solder, apply a temperature profile according to the IC data sheet. So as not to damage neighbouring components, it may be necessary to reduce some temperatures and times.

More Information

For more information on how to handle BGA devices, visit this URL: <http://www.atyourservice.ce.philips.com> (needs subscription). After login, select Magazine , then go to Workshop Information . Here you will find Information on how to deal with BGA-ICs.



Go to cover page




Quick reference for failure mode of LCD panel

this page presents problems that could be made by LCD panel.
It is not necessary to repair circuit board. Simply follow the mechanical instruction on this manual to eliminate failure by replace LCD panel.


Failure description

Phenomenon


Vertical block defect



Vertical dim lines




Vertical lines defect
(Always bright or dark)




Horizontal block defect



Horizontal dim lines




Horizontal lines defect
(Always bright or dark)



Has bright or dark pixel



Polarizer has bubbles



Polarizer has bubbles



Foreign material inside
polarizer. It shows liner or
dot shape.




Concentric circle formed



Bottom back light of LCD is
brighter than normal



Back light un-uniformity



Backlight has foreign material.
Black or white color, liner or
circular type



Go to cover page

All units that are returned for service or repair must pass the original manufactures safety tests. Safety testing requires both Hipot and Ground Continuity testing.

HI-POT TEST INSTRUCTION

1.Application requirements

- 1.1 All mains operated products must pass the Hi-Pot test as described in this instruction.
- 1.2 This test must be performed again after the covers have been refitted following the repair, inspection or modification of the product.

2. Test method

2.1 Connecting conditions

- 2.1.1 The test specified must be applied between the parallel-blade plug of the mainscord and all accessible metal parts of the product.
- 2.1.2 Before carrying out the test, reliable conductive connections must be ensured and thereafter be maintained throughout the test period.
- 2.1.3 The mains switch(es) must be in the "ON" position.

2.2 Test Requirements

All products should be HiPot and Ground Continuity tested as follows:

Condition	HiPot Test for products where the mains input range is Full range(or 220V AC)	HiPot Test for products where the mains input is 110V AC(USA type)	Ground Continuity Test requirement
Test voltage	2820VDC (2000VAC)	1700VDC (1200VAC)	Test current: 25A,AC Test time: 3 seconds(min.) Resistance required: <=0.09+Rohm, R is the resistance of the mains cord.
Test time (min.)	3 seconds	1 second	
Trip current (Tester)	set at 100 uA for Max. limitation; set at 0.1 uA for Min. Limitation	5 mA	
Ramp time (Tester)	set at 2 seconds		

- 2.2.1 The minimum test duration for Quality Control Inspector must be 1 minute.
- 2.2.2 The test voltage must be maintained within the specified voltage + 5%.
- 2.2.3 There must be no breakdown during the test.
- 2.2.4 The grounding blade or pin of mains plug must be conducted with accessible metal parts.


3. Equipments and Connection

3.1. Equipments

- For example :
- ChenHwa 9032 PROGRAMMABLE AUTO SAFETY TESTER
 - ChenHwa 510B Digital Grounding Continuity Tester
 - ChenHwa 901 (AC Hi-pot test), 902 (AC, DC Hi-pot test) Withstanding Tester

3.2. Connection

- * Turn on the power switch of monitor before Hipot and Ground Continuity testing.



(ChenHwa 9032 tester)

Video cable



Grounding screw



Power outlet
(Rear view of monitor)

4. Recording

Hipot and Ground Continuity testing records have to be kept for a period of 10 years.

Different Parts List

190G6 LCD/TV

101

Go to cover page

Diversity of 190G6FB/00 compared with 190G6FB/97

Item	12NC	Description
	863900016443	190G6FB/00
0040	313815760711	BACK COVER ASSY-WE
0044	313815417051	INNER COVER-WE
0091	313815137741	SHIELDING-UPPER-WE
0092	313815137761	SHIELDING-LOWER-WE
0291	313815568611	LABEL-CPU-WE
0295	313815568621	LABEL-EEPROM-WE
0615	313811709061	HEX CODE OF F/W-WE
1051	313815864381	SCALER ASSY(WE)
1054	313815865741	LED ASSY(WE)
1061	313812874931	MAINSCORD
1068	823827718791	SUBWOOFER ASSY 20W(SUB G6/EU)
1402	242202605451	SOC CINCH H 2P F 1L2 WHRD B
1403	242202605453	SOC CINCH H 3P F 1L3 RDBUGR B
1404	313818876611	SOC EURO H 21P F SHE L-GRND Y
2403	223886715331	CER1 0603 NP0 50V 330P PM5 R
2404	223886715331	CER1 0603 NP0 50V 330P PM5 R
2405	223886715331	CER1 0603 NP0 50V 330P PM5 R
2408	223886715331	CER1 0603 NP0 50V 330P PM5 R
2409	223886715331	CER1 0603 NP0 50V 330P PM5 R
2410	223886715331	CER1 0603 NP0 50V 330P PM5 R
2411	223886715229	CER1 0603 NP0 50V 22P PM5 R
2412	223886715121	CER1 0603 NP0 50V 120P PM5 R
2413	223886715331	CER1 0603 NP0 50V 330P PM5 R
2414	223886715689	CER1 0603 NP0 50V 68P PM5 R
2415	223886715229	CER1 0603 NP0 50V 22P PM5 R
2416	223886715121	CER1 0603 NP0 50V 120P PM5 R
2417	223886715689	CER1 0603 NP0 50V 68P PM5 R
2418	223886715121	CER1 0603 NP0 50V 120P PM5 R
2419	223886715229	CER1 0603 NP0 50V 22P PM5 R
2420	223886715229	CER1 0603 NP0 50V 22P PM5 R
2421	223886715689	CER1 0603 NP0 50V 68P PM5 R
2422	223886715331	CER1 0603 NP0 50V 330P PM5 R
2423	223886715331	CER1 0603 NP0 50V 330P PM5 R
2424	223886715229	CER1 0603 NP0 50V 22P PM5 R
2425	223886715331	CER1 0603 NP0 50V 330P PM5 R
2426	223886715331	CER1 0603 NP0 50V 330P PM5 R
3401	212211805645	RST SM 0603 RC0603 150R PM5 R
3404	232270260224	RST SM 0603 RC21 220K PM5 R
3405	232270260273	RST SM 0603 RC21 27K PM5 R
3407	212211805645	RST SM 0603 RC0603 150R PM5 R
3409	232270260224	RST SM 0603 RC21 220K PM5 R
3410	232270260273	RST SM 0603 RC21 27K PM5 R
3411	232270260279	RST SM 0603 RC21 27R PM5 R
3412	212211805639	RST SM 0603 RC0603 47R PM5 R
3413	212211805964	RST SM 0603 RC0603 75R PM1 R
3414	212211805667	RST SM 0603 RC0603 6K8 PM5 R
3415	232270260279	RST SM 0603 RC21 27R PM5 R
3416	212211805639	RST SM 0603 RC0603 47R PM5 R
3417	212211805964	RST SM 0603 RC0603 75R PM1 R
3418	232270260102	RST SM 0603 RC21 1K PM5 R
3419	232270260102	RST SM 0603 RC21 1K PM5 R
3420	232270260279	RST SM 0603 RC21 27R PM5 R
3421	232270260102	RST SM 0603 RC21 1K PM5 R
3422	212211805639	RST SM 0603 RC0603 47R PM5 R

3423	212211805964	RST SM 0603 RC0603 75R PM1 R
3424	232270260279	RST SM 0603 RC21 27R PM5 R
3425	232270260273	RST SM 0603 RC21 27K PM5 R
3426	212211805639	RST SM 0603 RC0603 47R PM5 R
3427	232270260273	RST SM 0603 RC21 27K PM5 R
3438	232270260102	RST SM 0603 RC21 1K PM5 R
3439	232270260102	RST SM 0603 RC21 1K PM5 R
3440	232270260102	RST SM 0603 RC21 1K PM5 R
3441	232270260273	RST SM 0603 RC21 27K PM5 R
3809	212211805662	RST SM 0603 RC0603 2K7 PM5 R
3810	212211805662	RST SM 0603 RC0603 2K7 PM5 R
3811	232270260512	RST SM 0603 RC21 5K1 PM5 R
3812	232270260512	RST SM 0603 RC21 5K1 PM5 R
4401	212211805631	RST SM 0603 JUMP. MAX 0R05 R
4402	212211805631	RST SM 0603 JUMP. MAX 0R05 R
4409	212211805631	RST SM 0603 JUMP. MAX 0R05 R
4854	212211805631	RST SM 0603 JUMP. MAX 0R05 R
4855	212211805631	RST SM 0603 JUMP. MAX 0R05 R
5403	242253595853	IND FXD SM 0603 0U10 PM10 R
5404	242253595853	IND FXD SM 0603 0U10 PM10 R
5405	242253595853	IND FXD SM 0603 0U10 PM10 R
5406	242253595853	IND FXD SM 0603 0U10 PM10 R
5407	242253595853	IND FXD SM 0603 0U10 PM10 R
5408	242253595853	IND FXD SM 0603 0U10 PM10 R
5409	242253595853	IND FXD SM 0603 0U10 PM10 R
5410	242253595853	IND FXD SM 0603 0U10 PM10 R
6403	932209863685	DIO SIG SM BAV99 (VISH) R
6404	932209863685	DIO SIG SM BAV99 (VISH) R
6405	932209863685	DIO SIG SM BAV99 (VISH) R
7052	313815865691	CPU IC ASSY(WE)
7055	313815865681	EEPROM ASSY(WE)
7401	933967270685	TRA SIG SM BC847CLG (ONSE) R

1. According the Ca006283, change 190G6FB/00,190G6FB/93, 190G6FB/97 Different Parts List . The difference is as the following.

REF	12NC	Description
2	863900016443	190G6FB/00
3	863900016447	190G6FB/93
1	863900016448	190G6FB/97

REF	Action	Item	12NC	Description
1	From	291	313815568572	LABEL-CPU-AP
	To	291	313815568573	LABEL-CPU-AP
2	From	291	313815568612	LABEL-CPU-WE
	To	291	313815568613	LABEL-CPU-WE
3	From	291	313815568682	LABEL-CPU-CH
	To	291	313815568683	LABEL-CPU-CH
1	From	615	313811709052	HEX CODE OF F/W (NO MATL REQ)
	To	615	313811709053	HEX CODE OF F/W(NO MATL REQ)
2	From	615	313811709062	HEX CODE OF F/W-WE
	To	615	313811709063	HEX CODE OF F/W(NO MATL REQ)
3	From	615	313811709072	HEX CODE OF F/W (NO MATL REQ)
	To	615	313811709073	HEX CODE OF F/W(NO MATL REQ)

◀◀ Go to cover page

1. According to the CA006798, 190G6FB/00, 190G6FB/93, 190G6FB/97 to solve the screen of TV cannot be displayed fully. Detail as following:

REF	12NC	Description
1	313815860581	AUDIO+USB ASSY

REF	Action	Item	12NC	Description
ALL	New	216	313815570391	LABEL - UAC

Affected Sets

REF	12NC	Description
1	863900016443	190G6FB/00
1	863900016447	190G6FB/93
1	863900016448	190G6FB/97

REF	12NC	Description
1	313815860581	AUDIO+USB ASSY
1	863900016443	190G6FB/00
1	863900016447	190G6FB/93
1	863900016448	190G6FB/97

REF	12NC	Description
1	313815865671	CPU IC ASSY(AP)
2	313815865691	CPU IC ASSY(WE)
3	313815865711	CPU IC ASSY(CHA)

Action	Item	12NC	Description
From	291	313815568573	LABEL-CPU-AP
To	291	313815568574	LABEL-CPU-AP
From	291	313815568613	LABEL-CPU-WE
To	291	313815568614	LABEL-CPU-WE
From	291	313815568683	LABEL-CPU-CH
To	291	313815568684	LABEL-CPU-CH
From	615	313811709053	HEX CODE OF F/W(NO MATL
To	615	313811709054	HEX CODE OF F/W(NO MATL
From	615	313811709063	HEX CODE OF F/W(NO MATL
To	615	313811709064	HEX CODE OF F/W(NO MATL
From	615	313811709073	HEX CODE OF F/W(NO MATL
To	615	313811709074	HEX CODE OF F/W(NO MATL

Affected Sets

REF	12NC	Description
1	313815860561	SCALER PCB ASSY
2	313815864381	SCALER ASSY(WE)
3	313815864391	SCALER ASSY(CHINA)
2	863900016443	190G6FB/00
3	863900016447	190G6FB/93
1	863900016448	190G6FB/97

2. According to the CA006815, 190G6FB/00, 190G6FB/93, 190G6FB/97 to solve the sound fragile, detail as below:

REF	12NC	Description
1	313815860581	AUDIO+USB ASSY

REF	Action	Item	12NC	Description
ALL	Del	216	313815570391	LABEL - UAC
ALL	From	7693	823827718761	128K EEPROM
	To	7693	313815869421	AUDIO PROGRAM ASSY

Affected Sets

REF	12NC	Description
1	863900016443	190G6FB/00
1	863900016447	190G6FB/93
1	863900016448	190G6FB/97

REF	12NC	Description
1	313815869421	AUDIO PROGRAM ASSY

REF	Action	Item	12NC	Description
ALL	New	216	313815570391	LABEL - UAC
ALL	New	616	313811710021	AUDIO BIN FOR 190G6
ALL	New	7693	823827718761	128K EEPROM

TELEVISION/MONITOR SAFETY GUIDELINES FOR THE PROFESSIONAL SERVICE TECHNICIAN

Safety Checks

After the original service problem has been corrected, a complete safety check should be made. Be sure to check over the entire set, not just the areas where you have worked. Some previous service may have left an unsafe condition, which could be unknowingly passed on to your customer. Be sure to check all of the following:

Fire and Shock Hazard

1. Be sure all components are positioned in such a way as to avoid the possibility of adjacent component shorts. This is especially important on those chassis which are transported to and from the service shop.
2. Never release a repaired unit unless all protective devices such as insulators, barriers, covers, strain reliefs, and other hardware have been installed in accordance with the original design.
3. Soldering and wiring must be inspected to locate possible cold solder joints, solder splashes, sharp solder points, frayed leads, pinched leads, or damaged insulation (including the ac cord). Be certain to remove loose solder balls and all other loose foreign particles.
4. Check across-the-line components and other components for physical evidence of damage or deterioration and replace if necessary. Follow original layout, lead length, and dress.
5. No lead or component should touch a receiving tube or a resistor rated at 1 watt or more. Lead tension around protruding metal surfaces or edges must be avoided.
6. Critical components having special safety characteristics are identified with an asterisk by the Ref. No. in the parts list and enclosed within a broken line * (where several critical components are grouped in one area) along with the safety symbols on the schematic diagrams and/or exploded views.
7. When servicing any unit, always use a separate isolation transformer for the chassis. Failure to use a separate isolation transformer may expose you to possible shock hazard, and may cause damage to servicing instruments.
8. Many electronic products use a polarized ac line cord (one wide pin on the plug.) Defeating this safety feature may create a potential hazard to the service and the user. Extension cords which do not incorporate the polarizing feature should never be used.
9. After reassembly of the unit, always perform a leakage test or resistance test from the line cord to all exposed metal parts of the cabinet. Also check all metal control shafts (with knobs removed), antenna terminals, handles, screws, etc. to be sure the unit may be safely operated without danger of electrical shock.

* Broken line

Implosion

1. All picture tubes used in current model receivers are equipped with an integral implosion system. Care should always be used, and safety glasses worn, whenever handling any picture tube. Avoid scratching or otherwise damaging the picture tube during installation.
2. Use only replacement tubes specified by the manufacturer.


X-radiation

1. Be sure procedures and instructions to all your service personnel cover the subject of X-radiation. Potential sources of X-rays in TV receivers are the picture tube and the high voltage circuits. The basic precaution which must be exercised is to keep the high voltage at the factory recommended level.
2. To avoid possible exposure to X-radiation and electrical shock, only the manufacturer's specified anode connectors must be used.
3. It is essential that the service technician has an accurate HV meter available at all times. The calibration of this meter should be checked periodically against a reference standard.
4. When the HV circuitry is operating properly there is no possibility of an X-radiation problem. High voltage should always be kept at the manufacturer's rated value - no higher - for optimum performance. Every time a color set is serviced, the brightness should be run up and down while monitoring the HV with a meter to be certain that the HV is regulated correctly and does not exceed the specified value. We suggest that you and your technicians review test procedures so that HV and HV regulation are always checked as a standard servicing procedure, and the reason for this prudent routine is clearly understood by everyone. It is important to use an accurate and reliable HV meter. It is recommended that the HV recorded on each customer's invoice, which will demonstrate a proper concern for the customer's safety.
5. When troubleshooting and making test measurements in a receiver with a problem of excessive high voltage, reduce the line voltage by means of a Variac to bring the HV into acceptable limits while troubleshooting. Do

6. New picture tubes are specifically designed to withstand higher operating voltages without creating undesirable X-radiation. It is strongly recommended that any shop test fixture which is to be used with the new higher voltage chassis be equipped with one of the new type tubes designed for this service. Addition of a permanently connected HV meter to the shop test fixture is advisable. The CRT types used in these new sets should never be replaced with any other types, as this may result in excessive X-radiation.
7. It is essential to use the specified picture tube to avoid a possible X-radiation problem.
8. Most TV receivers contain some type of emergency "Hold Down" circuit to prevent HV from rising to excessive levels in the presence of a failure mode. These various circuits should be understood by all technicians servicing them, especially since many hold down circuits are inoperative as long as the receiver performs normally.

Leakage Current Cold Check

1. Unplug the ac line cord and connect a jumper between the two prongs of the plug.
2. Turn on the power switch.
3. Measure the resistance value between the jumpered ac plug and all exposed cabinet parts of the receiver, such as screw heads, antennas, and control shafts. When the exposed metallic part has a return path to the chassis, the reading should be between 1 megohm and 5.2 megohms. When the exposed metal does not have a return path to the chassis, the reading must be infinity. Remove the jumper from the ac line cord.



Leakage Current Hot Check

1. Do not use an isolation transformer for this test. Plug the completely reassembled receiver directly into the ac outlet.
2. Connect a 1.5k, 10w resistor paralleled by a 0.15µf. capacitor between each exposed metallic cabinet part and a good earth ground such as a water pipe, as shown above.
3. Use an ac voltmeter with at least 5000 ohms volt sensitivity to measure the potential across the resistor.
4. The potential at any point should not exceed 0.75 volts. A leakage current tester may be used to make this test; leakage current must not exceed 0.5 milliamps. If a measurement is outside of the specified limits, there is a possibility of shock hazard. The receiver should be repaired and rechecked before returning it to the customer.
5. Repeat the above procedure with the ac plug reversed. (Note: An ac adapter is necessary when a polarized plug is used. Do not defeat the polarizing feature of the plug.)

Picture Tube Replacement

The primary source of X-radiation in this television receiver is the picture tube. The picture tube utilized in this chassis is specially constructed to limit X-radiation emissions. For continued X-radiation protection, the replacement tube must be the same type as the original, including suffix letter, or a Philips approved type.

Parts Replacement

Many electrical and mechanical parts in Philips television sets have special safety related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. The use of a substitute part which does not have the same safety characteristics as the Philips recommended replacement part shown in this service manual may create shock, fire, or other hazards.

WARNING : Before removing the CRT anode cap, turn the unit **OFF** and short the HIGH VOLTAGE to the CRT DAG ground.
SERVICE NOTE : The CRT DAG is not at chassis ground.