

# 60 MHz Dual Time Base Oscilloscope

## PM3055

### Service Manual

4822 872 05327  
880411/2



Industrial & Electro-acoustic Systems Division



Industrial &  
Electro-acoustic Systems


**PHILIPS**

# 60 MHz Dual Time Base Oscilloscope

## PM3055

### Service Manual

4822 872 05327  
880411/2



---

**WARNING:** These servicing instructions are for use by qualified personnel only.  
To reduce the risk of electric shock do not perform any servicing other  
than that specified in the Operating Instructions unless you are fully  
qualified to do so.



# PHILIPS

**IMPORTANT:** In correspondence concerning this instrument, please quote the type number and serial number as given on the type plate.

**NOTE:** The design of this instrument is subject to continuous development and improvement. Consequently, this instrument may incorporate minor changes in detail from the information contained in this manual.

CONTENTS	Page
<b>1. SAFETY INSTRUCTIONS</b>	<b>1-1</b>
1.1         Introduction .....	1-1
1.2         Safety precautions .....	1-1
1.3         Caution and warning statements .....	1-1
1.4         Symbols .....	1-1
1.5         Impaired safety-protection .....	1-2
1.6         General clauses .....	1-2
<b>2. CHARACTERISTICS</b>	<b>2-1</b>
2.1         Display .....	2-3
2.2         Vertical deflections or Y axis .....	2-3
2.2.1     Channels A and B .....	2-3
2.2.2     Triggerview .....	2-5
2.3         Horizontal deflection or X axis .....	2-6
2.3.1     Main Time Base (MTB) .....	2-6
2.3.2     Delay Time Base (DTB) .....	2-6
2.3.3     X-deflection .....	2-7
2.3.4     EXT input .....	2-7
2.4         Triggering .....	2-8
2.4.1     MTB triggering .....	2-8
2.4.2     DTB triggering .....	2-9
2.5         Power supply .....	2-9
2.6         Auxiliary input or outputs .....	2-10
2.7         Environmental characteristics .....	2-10
2.8         Safety .....	2-12
<b>3. INTRODUCTION TO CIRCUIT- AND BLOCK DIAGRAM DESCRIPTION</b>	<b>3-1</b>
3.1         Introduction to circuit description .....	3-1
3.2         Block diagram description .....	3-10
3.2.1     Introduction .....	3-10
3.2.2     Control unit .....	3-10
3.2.3     Attenuator unit .....	3-10
3.2.4     Pre-amplifier unit .....	3-10
3.2.5     Time-base unit .....	3-12
3.2.6     XYZ unit .....	3-12
3.2.7     Power supply unit .....	3-13

4.	ATTENUATOR UNIT (A1)	4-1
4.1	Vertical attenuators .....	4-1
4.2	External input .....	4-2
5.	PRE-AMPLIFIER UNIT (A2)	5-1
5.1	Vertical pre-amplifier .....	5-1
5.2	MTB trigger pre-amplifier .....	5-2
5.3	DTB trigger pre-amplifier .....	5-3
5.4	Pre-amplifier control .....	5-4
6.	XYZ-AMPLIFIER UNIT (A3)	6-1
6.1	Introduction .....	6-1
6.2	Final vertical (Y) amplifier .....	6-1
6.3	Final horizontal (X) amplifier .....	6-1
6.4	Final blanking (Z) amplifier and CRT .....	6-2
7.	TIME-BASE UNIT (A4)	7-1
7.1	Trigger amplifier .....	7-1
7.2	Timing circuit .....	7-2
7.3	Sweep generators .....	7-4
7.4	X DEFL amplifier, and display mode switch .....	7-6
7.5	Z-amplifier .....	7-6
7.6	Timing diagrams .....	7-8
8.	CRT CONTROL UNIT (A5)	8-1
9.	POWER SUPPLY UNIT (A6)	9-1
9.1	Input circuit .....	9-1
9.2	Converter circuit .....	9-1
9.3	Secondary output rectifiers .....	9-3
9.4	HT supply .....	9-3
9.5	Calibrator .....	9-3

10. FRONT UNIT (A7-A8)	10-1
10.1 Microcomputer control circuit .....	10-1
10.1.1 Introduction to MAB8052 microcomputer .....	10-1
10.1.2 Characteristics of the I <sup>2</sup> C bus .....	10-1
10.1.3 I <sup>2</sup> C structure .....	10-2
10.1.4 Microcomputer MAB8052 .....	10-3
10.1.5 I <sup>2</sup> C decoding .....	10-4
10.1.6 Status input .....	10-5
10.1.7 Probe indicator .....	10-5
10.1.8 C-Bus decoder .....	10-5
10.2 LCD display circuit .....	10-5
10.3 Front-panel controls .....	10-6
11. PERFORMANCE CHECK	11-1
11.1 General information .....	11-1
11.2 Preliminary settings .....	11-2
11.3 Recommended test equipment .....	11-2
11.4 Checking procedure .....	11-3
11.4.1 Power supply .....	11-3
11.4.2 Display .....	11-3
11.4.3 Vertical deflection or Y-axis .....	11-4
11.4.4 Trigger view .....	11-10
11.4.5 Horizontal deflection or X-axis .....	11-13
11.4.6 MTB triggering .....	11-18
11.4.7 DTB triggering .....	11-20
11.4.8 Auxiliary inputs and outputs .....	11-22
12. DISMANTLING THE INSTRUMENT	12-1
12.1 General information .....	12-1
12.2 Removing the top and bottom covers .....	12-1
12.3 Access to parts for the checking and adjusting procedures .....	12-1
13. CHECKING AND ADJUSTING	13-1
13.1 General information .....	13-1
13.2 Recommended test and calibration equipment .....	13-6
13.3 Survey of adjusting elements .....	13-7

13.4	Checking and adjusting procedure .....	13-9
13.4.1	Preparation .....	13-9
13.4.2	Power supply adjustment .....	13-9
13.4.3	CRT display adjustment .....	13-9
13.4.4	Square-wave response attenuator .....	13-10
13.4.5	Adjustment of vertical sensitivities .....	13-10
13.4.6	Adjustment of horizontal sensitivity .....	13-11
13.4.7	Offset adjustments .....	13-11
13.4.8	Adjustment of trigger sensitivity .....	13-12
13.4.9	Adjustment of the MTB sweep times .....	13-12
13.4.10	Adjustment of the DTB sweep times .....	13-12
13.4.11	Adjustment of x10 sweep times .....	13-13
13.4.12	Adjustment of delay time multiplier .....	13-13
13.4.13	Square-wave response of final Y-amplifier .....	13-13
13.4.14	Checking the AUTO SET function .....	13-14
14.	CORRECTIVE MAINTENANCE	14-1
14.1	Replacements .....	14-1
14.1.1	Standard parts .....	14-1
14.1.2	Special parts .....	14-1
14.1.3	Transistors and Integrated Circuits .....	14-1
14.1.4	Static-sensitive components .....	14-2
14.1.5	Handling MOS devices .....	14-2
14.2	Removing the units and mechanical parts .....	14-3
14.2.1	Attenuator unit (A1) .....	14-3
14.2.2	Pre-amplifier unit (A2) .....	14-4
14.2.3	XYZ-amplifier unit (A3) .....	14-4
14.2.4	Time-base unit (A4) .....	14-4
14.2.5	CRT control unit (A5) .....	14-4
14.2.6	Power supply unit (A6) .....	14-5
14.2.7	Front unit (A7) and LCD unit (A8) .....	14-6
14.2.8	Removing the delay line cable .....	14-7
14.2.9	Replacement fo CRT .....	14-7
14.3	Soldering techniques .....	14-8
14.4	Instrument repacking .....	14-8
14.5	Trouble shooting .....	14-9
14.5.1	Introduction .....	14-9
14.5.2	Trouble-shooting techniques .....	14-9
14.5.3	Power-up routine .....	14-10
14.5.4	Trouble-shooting the power supply .....	14-11
14.5.5	P.c.b. interconnections .....	14-11
14.5.6	Signal waveforms .....	14-16
14.5.7	Semi conductor pinnings .....	14-16
14.6	Special tools .....	14-16
14.6.1	Trimming kit SBC 317 .....	14-16
14.6.2	P.c.b. snapper .....	14-17
14.7	Recalibration after repair .....	14-17

15.	SAFETY INSPECTION AND TEST AFTER REPAIR AND MAINTENANCE IN THE PRIMARY CIRCUIT	15-1
15.1	General directives .....	15-1
15.2	Safety components .....	15-1
15.3	Checking the protective earth connection .....	15-1
15.4	Checking the insulation resistance .....	15-1
15.5	Checking the leakage current .....	15-1
15.6	Voltage test .....	15-2
16.	PARTS LIST	16-1
16.1	Mechanical parts .....	16-1
16.2	Units .....	16-6
16.3	Cables and connectors .....	16-7
16.3.1	Flatcables and connectors .....	16-7
16.3.2	Pcb-connectors .....	16-7
16.3.3	Miscellaneous cables .....	16-7
16.4	Electrical parts .....	16-8
16.4.1	Capacitors .....	16-8
16.4.2	Resistors .....	16-11
16.4.3	Coils .....	16-16
16.4.4	Semi-conductors .....	16-16
16.4.5	Integrated circuits .....	16-18
16.4.6	Cathode ray tube .....	16-18
16.4.7	Miscellaneous .....	16-18
17.	OPTIONS	17-1
17.1	Y-OUT .....	17-1
17.1.1	Characteristics .....	17-1
17.1.2	Circuit description .....	17-1
17.1.3	Adjusting and checking procedure .....	17-2
17.1.4	Parts list .....	17-3
17.2	MTB gate, DTB gate and MTB sweep.....	17-6
17.2.1	MTB gate .....	17-6
17.2.2	DTB gate .....	17-6
17.2.3	MTB sweep .....	17-6
17.2.4	Parts list .....	17-6

## LIST OF FIGURES

	Page
Figure 2.1 Dimensions	2-2
Figure 3.1 Block diagram	3-6
Figure 4.1 Table of attenuator settings	4-1
Figure 4.2 Attenuator unit p.c.b.	4-3
Figure 4.3 Circuit diagram of attenuator, ch. A	4-5
Figure 4.4 Circuit diagram of attenuator, ch. B	4-6
Figure 4.5 Attenuator unit p.c.b.	4-8
Figure 4.6 Circuit diagram of attenuator, EXT	4-10
Figure 5.1 The three stages of the vertical pre-amplifier	5-1
Figure 5.2 Pre-amplifier unit p.c.b.	5-5
Figure 5.3 Circuit diagram of pre-amplifier, channel switch + delay line driver	5-7
Figure 5.4 Circuit diagram of pre-amplifier, MTB trigger switch	5-8
Figure 5.5 Pre-amplifier unit p.c.b.	5-10
Figure 5.6 Circuit diagram of pre-amplifier, DTB trigger switch	5-12
Figure 5.7 Circuit diagram of pre-amplifier, logic control	5-14
Figure 6.1 XYZ amplifier unit p.c.b.	6-3
Figure 6.2 Circuit diagram of XYZ amplifier, final X and Y amplifiers	6-5
Figure 6.3 XYZ amplifier unit p.c.b.	6-6
Figure 6.4 Circuit diagram of XYZ amplifier, Z amplifier and CRT circuit	6-8
Figure 7.1 D4103 configuration	7-2
Figure 7.2 Simplified diagram of the MTB	7-4
Figure 7.3 Z-logic for the different TB modes	7-7
Figure 7.4 Free-running MTB sweep-timing diagram	7-8
Figure 7.5 Triggered MTB-sweep with a delay sweep-timing diagram	7-8
Figure 7.6 Triggered MTB- and DTB-sweep-timing diagram	7-9
Figure 7.7 Time base unit p.c.b.	7-11
Figure 7.8 Circuit diagram of time-base, trigger amplifier MTB and DTB	7-13
Figure 7.9 Circuit diagram of time base, MTB and DTB sweep circuits and final X DEFL amplifier	7-
Figure 7.10 Time base unit p.c.b.	7-
Figure 7.11 Circuit diagram of time-base, X pre-amplifier and Z switch	7-
Figure 8.1 Circuit diagram of CRT control	8-1
Figure 8.2 CRT control unit p.c.b.	8-1
Figure 9.1 Converter circuit	9-2
Figure 9.2 Timing diagram converter circuit	9-2
Figure 9.3 HT oscillator	9-3
Figure 9.4 Power supply unit p.c.b.	9-5
Figure 9.5 Circuit diagram of power supply	9-8

Figure 10.1	Bit transfer	10-1
Figure 10.2	Definition of start and stop conditions	10-2
Figure 10.3	I <sup>2</sup> C structure	10-2
Figure 10.4	Pinning of microcomputer MAB 8052	10-3
Figure 10.5	Front unit p.c.b.	10-6
Figure 10.6	Circuit diagram of front unit	10-8
Figure 10.7	LCD unit p.c.b.	10-9
Figure 10.8	Circuit diagram of LCD unit	10-10
Figure 12.1	Access to all parts for checking and adjusting	12-2
Figure 13.1	Adjusting elements	13-4
Figure 13.2	Square-wave response	13-14
Figure 14.1	Six clamping lips for XYZ-amplifier unit	14-4
Figure 14.2	Power supply unit outside the instrument	14-5
Figure 14.3	Measuring the front unit working condition	14-6
Figure 14.4	Removng the CRT	14-7
Figure 14.5	P.c.b. interconnections	14-13
Figure 14.6		14-16
Figure 14.7	Trimming tool kit	14-17
Figure 14.8	P.c.b. snapper	14-17
Figure 16.1	Exploded view	16-3
Figure 16.2	Rear view	16-5
Figure 16.3	Inside view showing the parts in the CRT compartment	16-5
Figure 16.4	View of the units	16-5
Figure 17.1	Y-OUT p.c.b.	17-4
Figure 17.2	Circuit diagram of Y-OUT option	17-5
Figure 17.3	Circuit diagram of MTB gate, DTB gate and MTB sweep options	17-7
Figure 17.4	P.c.b. for MTB gate, DTB gate and MTB sweep	17-7

## 1. SAFETY INSTRUCTIONS

Read these pages carefully before installation and use of the instrument.

### 1.1 INTRODUCTION

The following clauses contain information, cautions and warnings which must be followed to ensure safe operation and to retain the instrument in a safe condition.

Adjustment, maintenance and repair of the instrument shall be carried out only by qualified personnel.

### 1.2 SAFETY PRECAUTIONS

For the correct and safe use of this instrument it is essential that both operating and servicing personnel follow generally-accepted safety procedures in addition to the safety precautions specified in this manual.

Specific warning and caution statements, where they apply, will be found throughout the manual.

Where necessary, the warning and caution statements and/or symbols are marked on the apparatus.

### 1.3 CAUTION AND WARNING STATEMENTS

**CAUTION:** is used to indicate correct operating or maintenance procedures in order to prevent damage to or destruction of the equipment or other property.

**WARNING:** calls attention to a potential danger that requires correct procedures or practices in order to prevent personal injury.

### 1.4 SYMBOLS



High voltage  $\geq 1000$  V (red)



Live part (black/yellow)



Read the operating instructions



Protective earth (grounding) terminal (black)

## 1.5 IMPAIRED SAFETY-PROTECTION

Whenever it is likely that safety-protection has been impaired, the instrument must be made inoperative and be secured against any unintended operation. The matter should then be referred to qualified technicians.

Safety protection is likely to be impaired if, for example, the instrument fails to perform the intended measurements or shows visible damage.

## 1.6 GENERAL CLAUSES

- 1.6.1 WARNING: The opening of covers or removal of parts, except those to which access can be gained by hand, is likely to expose live parts and accessible terminals which can be dangerous to live.
- 1.6.2 The instrument shall be disconnected from all voltage sources before it is opened.
- 1.6.3 Bear in mind that capacitors inside the instrument can hold their charge even if the instrument has been separated from all voltage sources.
- 1.6.4 WARNING: Any interruption of the protective earth conductor inside or outside the instrument, or disconnection of the protective earth terminal, is likely to make the instrument dangerous. Intentional interruption is prohibited.
- 1.6.5 Components which are important for the safety of the instrument may only be renewed by components obtained through your local Philips organisation. (See also section 15).
- 1.6.6 After repair and maintenance in the primary circuit, safety inspection and tests, as mentioned in section 15 have to be performed.

## 2. CHARACTERISTICS

### A. Performance Characteristics

- Properties expressed in numerical values with stated tolerance are guaranteed by PHILIPS Specified non-tolerance numerical values indicate those that could be nominally expected from the mean of a range of identical instruments.
- This specification is valid after the instrument has warmed up for 30 minutes (reference temperature 23°C).
- For definitions of terms, reference is made to IEC Publication 351-1.

### B. Safety Characteristics

- This apparatus has been designed and tested in accordance with Safety Class I requirements of IEC Publication 348, Safety requirements for Electronic Measuring Apparatus, UL 1244 and CSA 556B and has been supplied in a safe condition.

### C. Initial Characteristics

#### . Overall dimensions:

##### - Width

Including handle	: 387 mm
Excluding handle	: 350 mm

##### - Length

Including handle, excl. knobs	: 518,5 mm
Excluding handle, excl. knobs	: 443,5 mm
Including handle, incl. knobs	: 530,5 mm
Excluding handle, incl. knobs	: 455,5 mm

##### - Height

Including feet	: 146,5 mm
Excluding feet	: 134,5 mm
Excl. under cabinet	: 132,5 mm




Figure 2.1 Dimensions

- \* Mass : 7,5 kg
- \* Operating positions:
  - a. Horizontally on bottom feet
  - b. Vertically on rear feet
  - c. On the carrying handle in two sloping positions.

#### D. CONTENTS

- 2.1. Display
- 2.2. Vertical deflection or Y axis
- 2.3. Horizontal deflection or X axis
- 2.4. Triggering
- 2.5. Power Supply
- 2.6. Auxiliary inputs or outputs
- 2.7. Environmental characteristics
- 2.8. Safety

	CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
2.1	DISPLAY		
	* CRT		
	Type No	PHILIPS D 14-372	
	Measuring area (h x w)	80 x 100 mm	8 x 10 div. 1 div. = 10 mm 1 subdiv. (sd) = 2 mm
	* Screen type		
	Standard	GH (P 31)	
	Option	GM (P 7)	Long persistence
	* Total acceleration voltage	16 kV	
	* Graticule		
	Engravings	Internal fixed	
	Division lines	1 cm	Horizontal as well as vertical
	Subdivisions	2 mm	Idem.
	Dotted lines	1,5 and 6,5 cm from top	Only horizontal.
	Percentages	0%, 10%, 90%, 100%	
	* Orthogonality	90° +/- 1°	Measured in zero point.
	* Illumination	Continuously variable	
	* Display time per channel in chopped mode	< 2 us	
	* LCD liquid crystal display		All relevant settings are visible in display.
	Type No	LC 9438130	
	Visible area	25,4 x 88,8 mm	
	Back lighting	Permanently on	
2.2	VERTICAL DEFLECTION OR Y AXIS		
2.2.1	Channels A and B		
	* Deflection coeff.	2 mV/div...10 V/div	In 1, 2, 5 sequence. If PM 8936/09 is used, deflection coeff. is automatically calculated in display.
	* Variable gain control range	1 : >2,5	
	* Error limit	< +/- 3%	Only in calibrated position.
	* Input impedance Paralleled by	1 M ohm +/-2% 20 pF +/-2pF	Measured at $f_o < 1$ MHz Measured at $f_o < 1$ MHz

CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
* Max. input voltage Max. test voltages (rms)	400 V (d.c. + a.c. peak) 500 V	Max. duration 60 sec.
* Bandwidth for 20 mV...10 V Bandwidth for 2 mV, 5 mV and 10 mV	> 60 MHz (amb.: 0...35°C) > 35 MHz	Input 6 div. sine-wave. Input 6 div. sine-wave.
* Rise-time	5,8 ns or less	Calculated from 0,35/f-3 dB
* Noise 20 mV...10 V	< 0,5 sd	Measured visually. Pick up on open BNC excluded.
* Lower - 3 dB point	< 10 Hz	In AC position, 6 div. sine-wave
* Dynamic range @ 1 MHz @ 50 MHz	> +/- 12 div. > 8 div.	Vernier in cal. position. Vernier in cal. position.
* Position range	> +/- 8 div.	Vernier in cal. position.
* Decoupling factor between channels @ 10 MHz @ 50 MHz	1 : > 100 1 : > 50	Both channels same attenuator setting. Input max. 8 div. sine-wave. 2,5 and 10 V are excluded. 2,5 and 10 V are excluded.
* Common Mode Rejection Ratio @ 1 MHz	1 : > 100	Both channels same attenuator setting, vernier adjusted for best CMRR; measured with max. 8 div. (+/- 4 div.) each channel.
* L.F. Non Linearity	< 3%	
* Visible signal delay	> 15 ns	Max. intensity, measured from line start to trigger point

CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
* Base-line jump between attenuator steps 20 mV...10 V	< 1 sd	
Additional jump between 10 mV <---> 20 mV	< 1,5 sd	
Normal Invert jump	< 1 sd	Only channel B.
ADD jump	< 0,6 div.	When A and B are positioned in screen centre (20 mV...10 V).
Variable jump	< 1 sd	Max.jump in any position of the vernier.

## 2.2.2 Triggerview

* Bandwidth via A or B channel 2 mV, 5 mV, 10 mV 20 mV...10 V	> 35 MHz (Amb.: 0...35°C)	6 div. sine-wave
Via EXT. input	> 50 MHz	6 div. sine-wave (+/- 3 div. from screen centre).
* Deflection coeff. Via channel A or B Via EXT. input	2 mV/div...10 V/div 1, 2, 5 sequence (see Channel A, B). 100 mV/div.	
Error limit	< 5%	INTERNAL, EXTERNAL.
* Lower - 3 dB point AC coupling EXT. input	< 10 Hz	Only when trigger coupling is DC.
* Line jump trigger source	< 2 sd	Jump between trigger source A, B composite and EXT.
* OFFSET trig.point	< 1,5 sd from screen centre	
* Delay EXT. trigger view and channel A or B	< 10 ns	
* Dynamic range EXT. input	@ 1 MHz > +/- 12 div. @ 50 MHz > 6 div.	

	CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
2.3	HORIZONTAL DEFLECTION OR X AXIS		
	* Horizontal display modes	MTB, MTBI, ALT.TB, DTB X-DEFL	
2.3.1	Main Time Base (MTB)		
	* Time coeff.	0,5 sec...50 ns	1, 2, 5 sequence (magn.off)
	Error limit	< 3%	Measured at -4...+4 div. from screen centre.
	* Horizontal position range	Start of sweep and 10th div. must be shifted over screen centre	
	* Variable control ratio	1 : > 2,5	
	* Time Base magnifier	Expansion *10	Not valid in X-deflection.
	Error limit	< 4%	Measured at +4...-4 div. from screen centre. Excluding first 50 ns and last 50 ns.
	* Horizontal magnifier balance	< 2,5 sd	Shift start of sweep in * 10 in mid-screen position, then switch to * 1.
	* 10 ---> * 1		
	* Hold-Off		
	Minimum to maximum hold-off time	1 : > 10 ratio	Minimum hold off time is related to time base setting.
2.3.2	Delay Time Base (DTB)		
	* Time coeff.	1 ms...50 ns	Sequence 1, 2, 5.
	Error limit		See MTB
	* Horizontal position range		See MTB
	* Time Base Mag-nifier		See MTB

CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
* Delay time Multiplier		
Error limit	3% + 1% incremental delay error + 25 ns +/- 5 ns	* 1 only
Incremental delay time error	< 1%	* 1 only
* Resolution	1 : 10 000	
* Delay Time Jitter	1 : > 20 000	
* Trace separation		Only valid in alternate time base.
Shift range	> +/- 4 div.	DTB shifts only.

### 2.3.3 X-deflection

* Deflection coeff.		
Via channel A or B	2 mV/div...10 V/div	1, 2, 5 sequence.
Via EXT. input	100 mV/div.	
* Error limit		
Via channel A or B	< +/- 5%	
Via EXT. input	< +/- 5%	
* Bandwidth	DC .... > 2 MHz	DC coupled
* Phase shift between X and Y-deflection	< 3° @ 100 kHz	
* Dynamic range	> +/- 12 div. @ 100 kHz	

### 2.3.4 EXT input

* Input impedance Paralleled by	1 M ohm +/- 2% 20 pF +/- 2 pF	$f_o < 1 \text{ MHz}$ $f_o < 1 \text{ MHz}$
* Max. input voltage	400 V (d.c. + a.c. peak)	
Max. test voltage (rms)	500 V	Max. duration 60 sec.
* Lower - 3 dB point	< 10 Hz	AC coupled

	CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
2.4	TRIGGERING		
2.4.1	MTB triggering		
	* Trig.mode AUTO (auto free run)	Bright line in absence of trigger signal	Auto free run starts 100 ms (typ.) after no trig.pulse.
	Triggered		Switches automatically to auto free run if one of the display channels is grounded.
	Single		In multi-channel mode (alternated) each channel is armed after reset; if sweep has already started, sweep is not finished. Not applicable in peak to peak coupling.
	* Trigger source A, B, Composite (AB), EXT, Line		Line trigger source always triggers on main frequency. Line trigger amplitude depends on line input voltage. Approx. 6 div. @ 220 VAC input voltage.
	* Trigger coupling Peak-to-peak (p-p), DC, TVL, TVF		
	* Level range Peak-to-peak	Related to peak-to-peak	p-p coupling is DC rejected.
	DC INTERNAL	> (+ or - 8 div.)	
	DC EXTERNAL	> (+ or - 800 mV)	
	TVL/TVF	Fixed level	
	* Trigger slope	+/-	Slope sign in LCD and + or - if TVL/F is chosen for positive or negative video.
	* Trigger sensitivity		
	INTERNAL		
	0 - 10 MHz	< 0,5 div.	Trig. coupling DC.
	@ 50 MHz	< 1,0 div.	Trig. coupling DC.
	@ 100 MHz	3,0 div.	Trig. coupling DC.
	EXTERNAL		
	0 - 10 MHz	< 50 mV	Trig. coupling DC.
	@ 50 MHz	< 150 mV	Trig. coupling DC.
	@ 100 MHz	500 mV	Trig. coupling DC.
	TVL/F INTERNAL	< 0,7 div.	Sync. pulse.
	EXTERNAL	< 70 mV	Sync. pulse.

	CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
2.4.2	DTB Triggering		
	* DTB trigger source Starts, A, B, Composite (AB), EXT and TVL		TVL has same trig. source as MTB trig. source TVL only valid if MTB trig. coupling TVL or TVF is chosen.
	* Coupling	DC	
	* Trigger sensitivity	See MTB	
	* Trigger Level range	> (+ or - 8 div.)	
	* Trigger slope	+/-	Slope sign in LCD, if TVL is chosen. Slope sign is not valid
2.5	POWER SUPPLY		
	* Line input voltage AC Nominal Limits of operation	100 - 240 V 90 - 264 V	One range.
	* Line frequency Nominal Limits of operation	50 - 400 Hz 45 - 440 Hz	
	* Safety requirements within specification of: IEC 348 CLASS I UL 1244 VDE 0411 CSA 556 B		
	* Power consumption	45 W	

	CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
2.6	AUXILIARY INPUTS OR OUTPUTS		
	* Z-MOD		TTL-compatible.
	ViH	> 2,0 V	Blanks display.
	ViL	< 0,8 V	Max. intensity
			Analogue control between ViH and ViL is possible.
	* DIN plug 9-pin (female)		For IEEE control, front-panel memory back-up.
	* CAL		To calibrate drop or tilt probes.
	Output voltage	1,2 V +/- 1%	Rectangular output pulse.
	Frequency	2 kHz	
	The output may be short-circuit to ground.		
2.7	ENVIRONMENTAL CHARACTERISTICS		
	The environmental data mentioned in this manual are based on the results of the manufacturer's checking procedures.		
	Details on these procedures and failure criteria are supplied on request by the PHILIPS organisation in your country, or by PHILIPS, INDUSTRIAL AND ELECTRO-ACOUSTIC SYSTEMS DIVISION, EINDHOVEN, THE NETHERLANDS.		
	* Meets environmental requirements of:	MIL-T-28800 C, type III, CLASS 5 Style D	
	* Temperature		
	Operation temp. range within specification	10...40°C	MIL-T-28800 C par. 3.9.2.3. tested, par. 4.5.5.1.1.
	Limits of operation temperature range	0 ...50°C	Idem.
	Non-operating (Storage)	- 40°C/+ 75°C	MIL-T-28800 C par. 3.9.2.3. tested, par. 4.5.5.1.1.
	* Max. humidity operating non-operating	95% RH	10...30°C
	* Max. altitude		MIL-T-28800 C par. 3.9.3. tested, par. 4.5.5.2.
	Operating	4,5 km (15000 feet)	Maximum (Operating Temperature derated 3°C for each km, for each 3000 feet, above sea level).
	Non-operating (storage)	12 km (40 000 feet)	

CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
* Vibration (operating)		MIL-T-28800 C par. 3.9.4.1. tested, par. 4.5.5.3.1.
Freq. 5...15 Hz	7 min.	
Sweep Time		
Excursion (p-p)	1,5 mm	
Max Acceleration	7 m/s <sup>2</sup> (0,7 x g)	@ 15 Hz
Freq. 15...25 Hz	3 min.	
Sweep Time		
Excursion (p-p)	1 mm	
Max Acceleration	13 m/s <sup>2</sup> (1,3 x g)	@ 25 Hz
Freq. 25...55 Hz	5 min.	
Sweep Time		
Excursion (p-p)	0,5 mm	
Max Acceleration	30 m/s <sup>2</sup> (3 x g)	@ 55 Hz
Resonance Dwell	10 min.	@ each resonance freq. (or @ 33 Hz if no resonance was found). Excursion, 9.7.1. to 9.7.2.
* Shock (operating)		MIL-T-28800 C par. 3.9.5.1. tested, par. 4.5.5.4.1.
Amount of shocks		
total	18	
each axis	6	(3 in each direction).
Shock Wave-form	Half sine-wave	
Duration	11 ms	
Peak Acceleration	300 m/s <sup>2</sup> (30 x g)	11 ms
* Bench handling		Mil-T-28800 C par. 3.9.5.3. tested, par. 4.5.5.4.3.
Meets requirements of	MIL-STD-810 method 516, proc. V	
* Salt Atmosphere		MIL-T-28800C par. 3.9.8.1 tested, par. 4.5.6.2.1.
Structural parts meet requirements of	MIL-T-810 methode 509, proc. I salt solution 20%	
* EMI (Electronic Magnetic Interference)		
meets requirements of	MIL-STD-461 CLASS B	Applicable requirements of part 7 : CE03, CS01, CS02, CS06, RE02, RS03
	VDE 0871 and VDE 0875 Grenzwert-klasse B	

CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
* Magnetic Radiated Susceptibility Maximum Deflection Factor		Tested in conformity with IEC 351-1 par. 5.1.3.1. Measured with instrument in a homogeneous magnetic field (in any direction with respect to instrument) with a flux intensity (p-p value) of 1,42 mT (14,2 gauss) and of symmetrical sine-wave form with a frequency of 45...66Hz.
2.8 SAFETY		
* Meets requirements of	IEC 348 CLASS I VDE 0411	Except for power cord, unless shipped with Universal European power plug.
	UL 1244 CSA 556 B	Except for power cord, unless shipped with North American power plug.
* Max. X-Radiation		Measured @ 5 cm from surface of instrument for a target area of 10 cm <sup>2</sup>
* Recovery time	15 min. 30 min. 45 min. 60 min.	-10 <sup>o</sup> C ----> + 25 <sup>o</sup> C ambient temp. -20 <sup>o</sup> C ----> + 25 <sup>o</sup> C ambient temp. -30 <sup>o</sup> C ----> + 25 <sup>o</sup> C ambient temp. -40 <sup>o</sup> C ----> + 40 <sup>o</sup> C ambient temp.

## 2. CHARACTERISTICS

### A. Performance Characteristics

- Properties expressed in numerical values with stated tolerance are guaranteed by PHILIPS Specified non-tolerance numerical values indicate those that could be nominally expected from the mean of a range of identical instruments.
- This specification is valid after the instrument has warmed up for 30 minutes (reference temperature 23°C).
- For definitions of terms, reference is made to IEC Publication 351-1.

### B. Safety Characteristics

- This apparatus has been designed and tested in accordance with Safety Class I requirements of IEC Publication 348, Safety requirements for Electronic Measuring Apparatus, UL 1244 and CSA 556B and has been supplied in a safe condition.

### C. Initial Characteristics

#### . Overall dimensions:

##### - Width

Including handle	: 387 mm
Excluding handle	: 350 mm

##### - Length

Including handle, excl. knobs	: 518,5 mm
Excluding handle, excl. knobs	: 443,5 mm
Including handle, incl. knobs	: 530,5 mm
Excluding handle, incl. knobs	: 455,5 mm

##### - Height

Including feet	: 146,5 mm
Excluding feet	: 134,5 mm
Excl. under cabinet	: 132,5 mm




Figure 2.1 Dimensions

\* Mass : 7,5 kg

\* Operating positions:

- a. Horizontally on bottom feet
- b. Vertically on rear feet
- c. On the carrying handle in two sloping positions.

D. CONTENTS

- 2.1. Display
- 2.2. Vertical deflection or Y axis
- 2.3. Horizontal deflection or X axis
- 2.4. Triggering
- 2.5. Power Supply
- 2.6. Auxiliary inputs or outputs
- 2.7. Environmental characteristics
- 2.8. Safety

	CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
2.1	DISPLAY		
	* CRT		
	Type No	PHILIPS D 14-372	
	Measuring area (h x w)	80 x 100 mm	8 x 10 div. 1 div. = 10 mm 1 subdiv. (sd) = 2 mm
	* Screen type		
	Standard	GH (P 31)	
	Option	GM (P 7)	Long persistence
	* Total acceleration voltage	16 kV	
	* Graticule		
	Engravings	Internal fixed	
	Division lines	1 cm	Horizontal as well as vertical
	Subdivisions	2 mm	Idem.
	Dotted lines	1,5 and 6,5 cm from top	Only horizontal.
	Percentages	0%, 10%, 90%, 100%	
	* Orthogonality	90° +/- 1°	Measured in zero point.
	* Illumination	Continuously variable	
	* Display time per channel in chopped mode	< 2 us	
	* LCD liquid crystal display		All relevant settings are visible in display.
	Type No	LC 9438130	
	Visible area	25,4 x 88,8 mm	
	Back lighting	Permanently on	
2.2	VERTICAL DEFLECTION OR Y AXIS		
2.2.1	Channels A and B		
	* Deflection coeff.	2 mV/div...10 V/div	In 1, 2, 5 sequence. If PM 8936/09 is used, deflection coeff. is automatically calculated in display.
	* Variable gain control range	1 : >2,5	
	* Error limit	< +/- 3%	Only in calibrated position.
	* Input impedance Paralleled by	1 M ohm +/-2% 20 pF +/-2pF	Measured at $f_o < 1$ MHz Measured at $f_o < 1$ MHz

CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
* Max. input voltage Max. test voltages (rms)	400 V (d.c. + a.c. peak) 500 V	Max. duration 60 sec.
* Bandwidth for 20 mV...10 V Bandwidth for 2 mV, 5 mV and 10 mV	> 60 MHz (amb.: 0...35°C) > 35 MHz	Input 6 div. sine-wave. Input 6 div. sine-wave.
* Rise-time	5,8 ns or less	Calculated from 0,35/f-3 dB
* Noise 20 mV...10 V	< 0,5 sd	Measured visually. Pick up on open BNC excluded.
* Lower - 3 dB point	< 10 Hz	In AC position, 6 div. sine-wave
* Dynamic range @ 1 MHz @ 50 MHz	> +/- 12 div. > 8 div.	Vernier in cal. position. Vernier in cal. position.
* Position range	> +/- 8 div.	Vernier in cal. position.
* Decoupling factor between channels @ 10 MHz @ 50 MHz	1 : > 100 1 : > 50	Both channels same attenuator setting. Input max. 8 div. sine-wave. 2,5 and 10 V are excluded. 2,5 and 10 V are excluded.
* Common Mode Rejection Ratio @ 1 MHz	1 : > 100	Both channels same attenuator setting, vernier adjusted for best CMRR; measured with max. 8 div. (+/- 4 div.) each channel.
* L.F. Non Linearity	< 3%	
* Visible signal delay	> 15 ns	Max. intensity, measured from line start to trigger point

CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
* Base-line jump between attenuator steps 20 mV...10 V	< 1 sd	
Additional jump between 10 mV <---> 20 mV	< 1,5 sd	
Normal Invert jump	< 1 sd	Only channel B.
ADD jump	< 0,6 div.	When A and B are positioned in screen centre (20 mV...10 V).
Variable jump	< 1 sd	Max.jump in any position of the vernier.

### 2.2.2 Triggerview

* Bandwidth via A or B channel 2 mV, 5 mV, 10 mV	> 35 MHz	6 div. sine-wave
20 mV...10 V	> 50 MHz (Amb.: 0...35°C)	
Via EXT. input	> 50 MHz	6 div. sine-wave (+/- 3 div. from screen centre).
* Deflection coeff. Via channel A or B Via EXT. input	2 mV/div...10 V/div 1, 2, 5 sequence (see Channel A, B). 100 mV/div.	
Error limit	< 5%	INTERNAL, EXTERNAL.
* Lower - 3 dB point AC coupling EXT. input	< 10 Hz	Only when trigger coupling is DC.
* Line jump trigger source	< 2 sd	Jump between trigger source A, B composite and EXT.
* OFFSET trig.point	< 1,5 sd from screen centre	
* Delay EXT. trigger view and channel A or B	< 10 ns	
* Dynamic range EXT. input	@ 1 MHz > +/- 12 div. @ 50 MHz > 6 div.	

	CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
2.3	HORIZONTAL DEFLECTION OR X AXIS		
	* Horizontal display modes	MTB, MTBI, ALT.TB, DTB X-DEFL	
2.3.1	Main Time Base (MTB)		
	* Time coeff.	0,5 sec...50 ns	1, 2, 5 sequence (magn.off)
	Error limit	< 3%	Measured at -4...+4 div. from screen centre.
	* Horizontal position range	Start of sweep and 10th div. must be shifted over screen centre	
	* Variable control ratio	1 : > 2,5	
	* Time Base magnifier	Expansion *10	Not valid in X-deflection.
	Error limit	< 4%	Measured at +4...-4 div. from screen centre. Excluding first 50 ns and last 50 ns.
	* Horizontal magnifier balance	< 2,5 sd	Shift start of sweep in * 10 in mid-screen position, then switch to * 1.
	* Hold-Off	* 10 ---> * 1	
	Minimum to maximum hold-off time ratio	1 : > 10	Minimum hold off time is related to time base setting.
2.3.2	Delay Time Base (DTB)		
	* Time coeff.	1 ms...50 ns	Sequence 1, 2, 5.
	Error limit		See MTB
	* Horizontal position range		See MTB
	* Time Base Mag-nifier		See MTB

CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
* Delay time Multiplier		
Error limit	3% + 1% incremental delay error + 25 ns +/- 5 ns	* 1 only
Incremental delay time error	< 1%	* 1 only
* Resolution	1 : 10 000	
* Delay Time Jitter	1 : > 20 000	
* Trace separation		Only valid in alternate time base.
Shift range	> +/- 4 div.	DTB shifts only.

### 2.3.3 X-deflection

* Deflection coeff.		
Via channel A or B	2 mV/div...10 V/div	1, 2, 5 sequence.
Via EXT. input	100 mV/div.	
* Error limit		
Via channel A or B	< +/- 5%	
Via EXT. input	< +/- 5%	
* Bandwidth	DC .... > 2 MHz	DC coupled
* Phase shift between X and Y-deflection	< 3° @ 100 kHz	
* Dynamic range	> +/- 12 div. @ 100 kHz	

### 2.3.4 EXT input

* Input impedance Paralleled by	1 M ohm +/- 2% 20 pF +/- 2 pF	$f_o < 1 \text{ MHz}$ $f_o < 1 \text{ MHz}$
* Max. input voltage	400 V (d.c. + a.c. peak)	
Max. test voltage (rms)	500 V	Max. duration 60 sec.
* Lower - 3 dB point	< 10 Hz	AC coupled

	CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
2.4	TRIGGERING		
2.4.1	MTB triggering		
	* Trig.mode AUTO (auto free run)	Bright line in absence of trigger signal	Auto free run starts 100 ms (typ.) after no trig.pulse.
	Triggered		Switches automatically to auto free run if one of the display channels is grounded.
	Single		In multi-channel mode (alternated) each channel is armed after reset; if sweep has already started, sweep is not finished. Not applicable in peak to peak coupling.
	* Trigger source A, B, Composite (AB), EXT, Line		Line trigger source always triggers on main frequency. Line trigger amplitude depends on line input voltage. Approx. 6 div. @ 220 VAC input voltage.
	* Trigger coupling Peak-to-peak (p-p), DC, TVL, TVF		
	* Level range Peak-to-peak	Related to peak-to-peak	p-p coupling is DC rejected.
	DC INTERNAL	> (+ or - 8 div.)	
	DC EXTERNAL	> (+ or - 800 mV)	
	TVL/TVF	Fixed level	
	* Trigger slope	+/-	Slope sign in LCD and + or - if TVL/F is chosen for positive or negative video.
	* Trigger sensitivity		
	INTERNAL		
	0 - 10 MHz	< 0,5 div.	Trig. coupling DC.
	@ 50 MHz	< 1,0 div.	Trig. coupling DC.
	@ 100 MHz	3,0 div.	Trig. coupling DC.
	EXTERNAL		
	0 - 10 MHz	< 50 mV	Trig. coupling DC.
	@ 50 MHz	< 150 mV	Trig. coupling DC.
	@ 100 MHz	500 mV	Trig. coupling DC.
	TVL/F INTERNAL	< 0,7 div.	Sync. pulse.
	EXTERNAL	< 70 mV	Sync. pulse.

	CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
2.4.2	DTB Triggering		
	* DTB trigger source Starts, A, B, Composite (AB), EXT and TVL		TVL has same trig. source as MTB trig. source TVL only valid if MTB trig. coupling TVL or TVF is chosen.
	* Coupling	DC	
	* Trigger sensitivity	See MTB	
	* Trigger Level range	> (+ or - 8 div.)	
	* Trigger slope	+/-	Slope sign in LCD, if TVL is chosen. Slope sign is not valid
2.5	POWER SUPPLY		
	* Line input voltage AC Nominal	100 - 240 V	One range.
	Limits of operation	90 - 264 V	
	* Line frequency Nominal	50 - 400 Hz	
	Limits of operation	45 - 440 Hz	
	* Safety requirements within specification of: IEC 348 CLASS I UL 1244 VDE 0411 CSA 556 B		
	* Power consumption	45 W	

	CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
2.6	AUXILIARY INPUTS OR OUTPUTS		
	* Z-MOD		TTL-compatible.
	ViH	> 2,0 V	Blanks display.
	ViL	< 0,8 V	Max. intensity
			Analogue control between ViH and ViL is possible.
	* DIN plug 9-pin (female)		For IEEE control, front-panel memory back-up.
	* CAL		To calibrate drop or tilt probes.
	Output voltage	1,2 V +/- 1%	Rectangular output pulse.
	Frequency	2 kHz	
	The output may be short-circuit to ground.		
2.7	ENVIRONMENTAL CHARACTERISTICS		
	The environmental data mentioned in this manual are based on the results of the manufacturer's checking procedures.		
	Details on these procedures and failure criteria are supplied on request by the PHILIPS organisation in your country, or by PHILIPS, INDUSTRIAL AND ELECTRO-ACOUSTIC SYSTEMS DIVISION, EINDHOVEN, THE NETHERLANDS.		
	* Meets environmental requirements of:	MIL-T-28800 C, type III, CLASS 5 Style D	
	* Temperature		
	Operation temp. range within specification	10...40°C	MIL-T-28800 C par. 3.9.2.3. tested, par. 4.5.5.1.1.
	Limits of operation temperature range	0 ...50°C	Idem.
	Non-operating (Storage)	- 40°C/+ 75°C	MIL-T-28800 C par. 3.9.2.3. tested, par. 4.5.5.1.1.
	* Max. humidity operating non-operating	95% RH	10...30°C
	* Max. altitude		MIL-T-28800 C par. 3.9.3. tested, par. 4.5.5.2.
	Operating	4,5 km (15000 feet)	Maximum Operating Temperature derated 3°C for each km, for each 3000 feet, above sea level).
	Non-operating (storage)	12 km (40 000 feet)	

CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
* Vibration (ope-rating)		MIL-T-28800 C par. 3.9.4.1. tested, par. 4.5.5.3.1.
Freq. 5...15 Hz	7 min.	
Sweep Time		
Excursion (p-p)	1,5 mm	
Max Acceleration	7 m/s <sup>2</sup> (0,7 x g) @ 15 Hz	
Freq. 15...25 Hz	3 min.	
Sweep Time		
Excursion (p-p)	1 mm	
Max Acceleration	13 m/s <sup>2</sup> (1,3 x g) @ 25 Hz	
Freq. 25...55 Hz	5 min.	
Sweep Time		
Excursion (p-p)	0,5 mm	
Max Acceleration	30 m/s <sup>2</sup> (3 x g) @ 55 Hz	
Resonance Dwell	10 min.	@ each resonance freq. (or @ 33 Hz if no resonance was found). Excursion, 9.7.1. to 9.7.2.
* Shock (operating)		MIL-T-28800 C par. 3.9.5.1. tested, par. 4.5.5.4.1.
Amount of shocks		
total	18	
each axis	6	(3 in each direction).
Shock Wave-form	Half sine-wave	
Duration	11 ms	
Peak Acceleration	300 m/s <sup>2</sup> (30 x g) 11 ms	
* Bench handling		Mil-T-28800 C par. 3.9.5.3. tested, par. 4.5.5.4.3.
Meets requirements of	MIL-STD-810 method 516, proc. V	
* Salt Atmosphere		MIL-T-28800C par. 3.9.8.1 tested, par. 4.5.6.2.1.
Structural parts meet requirements of	MIL-T-810 methode 509, proc. I salt solution 20%	
* EMI (Electronic Magnetic Interference)		
meets requirements of	MIL-STD-461 CLASS B	Applicable requirements of part 7 : CE03, CS01, CS02, CS06, RE02, RS03
	VDE 0871 and VDE 0875 Grenzwert-klasse B	

CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
* Magnetic Radiated Susceptibility Maximum Deflection Factor		Tested in conformity with IEC 351-1 par. 5.1.3.1. Measured with instrument in a homogeneous magnetic field (in any direction with respect to instrument) with a flux intensity (p-p value) of 1,42 mT (14,2 gauss) and of symmetrical sine-wave form with a frequency of 45...66Hz.
2.8 SAFETY		
* Meets requirements of	IEC 348 CLASS I VDE 0411	Except for power cord, unless shipped with Universal European power plug.
	UL 1244 CSA 556 B	Except for power cord, unless shipped with North American power plug.
* Max. X-Radiation		Measured @ 5 cm from surface of instrument for a target area of 10 cm <sup>2</sup>
* Recovery time	15 min. 30 min. 45 min. 60 min.	-10°C ----> + 25°C ambient temp. -20°C ----> + 25°C ambient temp. -30°C ----> + 25°C ambient temp. -40°C ----> + 40°C ambient temp.

### 3. INTRODUCTION TO CIRCUIT DESCRIPTION AND BLOCK DIAGRAM DESCRIPTION

#### 3.1 INTRODUCTION TO CIRCUIT DESCRIPTION

The functioning of the circuits is described per printed-circuit board (p.c.b.). For every p.c.b. a separate chapter (4-10) is available containing the lay out of the p.c.b., the associated circuit diagram(s) and the circuit description.

##### Location of electrical parts

The item numbers of C...., R...., V...., N...., D.... and K.... have been divided into groups which relate to the circuit and the printed-circuit board according to the following table:

Item number	unit no.	Printed-circuit board	Figure
1000-1999	A1	Attenuator unit	4
2000-2999	A2	Pre-amplifier unit	5
3000-3999	A3	XYZ amplifier unit	6
4000-4999	A4	Time-base unit	7
5000-5999	A5	CRT control unit	8
6000-6999	A6	Power supply	9
7000-7999	A7	Front unit	10
8000-8999	A8	LCD unit	10

## 3.2 BLOCK DIAGRAM DESCRIPTION (see figure 3.1).

3.2.1 Introduction

This block diagram description is based around all the important functional blocks and their interconnections. The interconnections between all p.c.b.'s are given in the interconnection diagram of figure 14.5. In order to assist in cross-reference with the circuit diagrams, the blocks include the item numbers of the active components they contain.

Furthermore, the blocks are grouped together per printed-circuit board, or a part of it. To facilitate reference, the names of the functional blocks are given in text in CAPITALS.

Signal waveforms are also indicated at block interconnections where useful.

In this instrument almost all the switches (UP-DOWN controls, softkeys and potentiometer UNCAL switches) influence the oscilloscope circuits via a microcomputer (uC) system.

## 3.2.2 Control unit

Because the functional description of the control unit (see chapter 10) is almost similar to the blockdiagram description, no specific attention is given in this chapter to this unit.

## 3.2.3 Attenuator unit

The vertical channels A and B for the signals to be displayed are identical. Each channel comprises an input SIGNAL COUPLING for AC/DC, a HIGH IMPEDANCE ATTENUATOR which gives a grounded input or a signal attenuation of  $x1-x10$  or  $x100$ , an IMPEDANCE CONVERTER, a LOW IMPEDANCE ATTENUATOR which gives signal attenuation of  $x1-x2,5$  or  $x5$  and a GAIN  $x1-x10$

AMPLIFIER block, incorporated with the CONTINUOUS CIRCUIT. This block has a variable gain, influenced by the front-panel VAR control. The gain is also increased by  $x10$  in order to obtain 2-5 and 10mV settings.

Similar to the vertical channels, the external channel attenuator also has an input SIGNAL COUPLING, HIGH IMPEDANCE ATTENUATOR and IMPEDANCE CONVERTER in line. However, the external channel has only  $x1$  attenuation and no LOW IMPEDANCE ATTENUATOR. The output of the external channel is fed to both MTB and DTB TRIGGER PRE-AMPLIFIERS.

All blocks that are capable of working in different modes are controlled by the control A or control B signals. These signals are generated by the CH.A CONTROL or CH.B CONTROL blocks.

## 3.2.4 Pre-amplifier unit

This unit incorporates the signal splitters for the vertical channels A and B, the trigger view amplifier, the trigger circuits for the MTB and DTB and the chopper oscillator circuit. All these functions are controlled by the control XYP and control XYA signals, generated by the X-Y CONTROL blocks.







Figure 3.1 Block diagram




## TIME BASE UNIT (A4)




## AMPLIFIER UNIT (A3)



## CRT CONTROL UNIT (A5)



## POWER SUPPLY UNIT (A6)



\* Vertical channels A and B:

Both channels are completely identical and receive their input signals from the ATTENUATOR UNIT. This signal is applied to the SIGNAL SPLITTER, which has three outputs:

- two outputs applied to the SLOPE/TRIGGER SELECTIONS for MTB or DTB triggering.
- a third output routed to the POSITION/NORMAL-INVERT block.

This block is incorporated with the VERTICAL CHANNEL SWITCH in a single IC. Vertical shift of the displayed signal is achieved by the front-panel POSITION control. The output of this block and the output of the TRIGGER VIEW channel are routed via the DELAY LINE DRIVER to the DELAY LINE. The TRIGGER VIEW channel enables display of the MTB trigger source and can be used as a third vertical channel with limited specifications. The front-panel TRACE SEP control influences the position of the trace of the DTB signals related to the trace of the MTB signal.

\* MTB trigger circuit:

The SLOPE/TRIGGER SELECTION block receives a trigger signal from one of the vertical channels A or B, from the EXT SIGNAL SPLITTER or from the LINE TRIGGER PICK-OFF. Inverting of the trigger signal is controlled by the CXYA signals INVAM and INVBM to obtain the MTB slope function. Routed via the TRIGGER PRE-AMPLIFIER, block the signal is split up into three different paths:

- after summation of the LEVEL signal, direct to the TRIGGER AMPLIFIER
- to the AUTO LEVEL block. This block contains the different trigger facilities and levelling of the trigger signal is influenced by the front-panel LEVEL control. The output of this path is routed again to the summation point to influence the direct trigger signal.
- to the X-DEFL AMPLIFIER for X-deflection facility. This block incorporates a phase correction circuit for the X-Y display.

The TRIGGER AMPLIFIER feeds the MTB trigger signal to the time-base unit. The trigger signal from the summation point is also routed via the TRIGGER VIEW AMPLIFIER to the vertical CHANNEL SWITCH stage to display this signal.

\* DTB trigger circuit:

Basically, for triggering purposes this circuit is identical to the MTB trigger circuit. This circuit also has a SLOPE/TRIGGER SELECTION and TRIGGER AMPLIFIER block. However, the DTB trigger circuit has no LINE trigger or AUTO LEVEL facility. The LEVEL control directly influences the SLOPE/TRIGGER SELECTION block.

\* Chopper oscillator circuit:

A square-wave signal for chopper blanking and vertical switching is generated in the CHOP OSCILLATOR. For chopper blanking the signal is routed to the Z PRE-AMPLIFIER on the time-base unit.

### 3.2.5 Time-base unit

This unit incorporates the main time-base (MTB), the delayed time-base (DTB), the horizontal amplifier and the Z amplifier circuit. All functions are controlled by the CX1 and CX2 signals, generated by the HORIZONTAL CONTROL CIRCUIT blocks.

#### \* Main time-base (MTB):

The MTB trigger signal can be either directly routed to the TIME-BASE CONTROL CIRCUIT or first routed via the TV TRIGGER SELECTION for the TV trigger coupling. When in the AUTO mode, in the absence of trigger signals, the MTB will be free running.

The MTB CURRENT SOURCE applies the sawtooth charging current to the MTB sweep circuit. This block generates the MTB sawtooth signal, which is routed to the HORIZONTAL DISPLAY MODE SWITCH.

The HOLD OFF and the ALT CLOCK PULSE blocks are also under control of the TIME BASE CONTROL CIRCUIT. Hold off time is varied by the front-panel HOLD OFF control. The output of the HOLD OFF block is routed to the TIME-BASE CONTROL CIRCUIT again.

The ALTCLN-pulse is applied to the PRE-AMPLIFIER UNIT.

### 3.2.6 XYZ unit

This unit comprises the final amplifiers for the vertical (Y) and horizontal (X) deflection and for the blanking (Z) circuit. In addition to this, the CRT control circuits are also incorporated in the unit.

#### \* Final vertical amplifier:

The output signal from the pre-amplifier unit is first routed via the DELAY LINE to give sufficient delay to ensure that the steep leading edges of fast signals are displayed and then fed to the DELAY LINE COMPENSATION. This block compensates the signal for distortion originating in the DELAY LINE before it is applied to the FINAL VERTICAL AMPLIFIER. The output of the FINAL VERTICAL AMPLIFIER feeds the vertical deflection plates of the CRT.

#### \* Final horizontal amplifier:

The horizontal deflection signal is routed to the FINAL HORIZONTAL AMPLIFIER, the output of which feeds the horizontal deflection plates of the CRT.

#### \* Blanking circuit:

The output signal from the Z PRE-AMPLIFIER of the time-base unit, that determines trace blanking or unblanking and modulation is routed to the FINAL Z-AMPLIFIER. After amplification the blanking signal is split into two paths:

- the h.f. signals are fed via a high voltage capacitor to grid G1 of the CRT.
- the l.f. signals are used to modulate the amplitude of an oscillator wave-form, which then passes via another high voltage capacitor and is demodulated in the DEMODULATOR block to retrieve the original signal.

Note that the original h.f. and l.f. signals are again recombined on the grid G1.

\* CRT control circuits:

The FOCUS AMPLIFIER block is influenced by both front-panel FOCUS and INTENS controls to provide a focus that is independent of the intensity, and drives the focusing grid G3 of the CRT.

The -100 V BLACK LEVEL block provides the correct presetting of the cathode voltage.

The CRT BIAS gives a d.c. voltage to the grids G4 and G5 to provide an optional adjustment for geometry and astigmatism.

3.2.7 Power supply unit

The mains input voltage is filtered and then applied to the RECTIFIER block to obtain a d.c. voltage source. Another output of the LINE FILTER block is routed via the LINE TRIGGER PICK-OFF and serves as a MTB LINE trigger signal. The rectified mains source is routed to the FLYBACK CONVERTER, which generates the necessary voltages for the oscilloscope circuits. Each supply voltage is rectified in the RECTIFIERS block.

The LOW-voltage supplies are stabilized by the CONTROL circuit to the converter.

The +10 V REF supply serves as a low-voltage reference and is generated in the +10 V REFERENCE source block. This reference voltage is also fed to the different circuits on the power supply or in the oscilloscope.


The EHT CONVERTER generates the -14 kV for the post-accelerator anode of the CRT and the -2 kV for the cathode circuits.

\* Auxiliary circuits:

The CALIBRATION GENERATOR generates the CAL voltage, which is applied to the output socket X1. The CAL voltage has a 1,2 V p-p level with a frequency of 2kHz square wave.

The ILLUMINATION CIRCUIT determines the amount of current passed to the graticule illumination lamp of the CRT controlled by the ILLUM control on the front-panel.

The TRACE ROTATION CIRCUIT determines the strength and sense of the current passed to the trace rotation coil around the neck of the CRT. The current is influenced by the front-panel screwdriver operated TRACE ROT control.



## 4. ATTENUATOR UNIT (A1)

### 4.1 VERTICAL ATTENUATORS

The A and B channel attenuators are identical: therefore only channel A is described.

All relay and FET switches are controlled by the microcomputer via the  $I^2C$  bus. The TEA 1017 converts this serial DATA into the parallel control signals for all relay or FET switches. A list of the control lines for all attenuator settings is given in the table below.




Figure 4.1 Table of attenuator settings

The channel A attenuator consists of in five stages:

Input coupling, where depending on the relay K1001 position, the input signal can either be d.c.-coupled (relay activated) or a.c.-coupled (relay not activated).

High impedance attenuator with three attenuator stages for the x1, x10 and x100 attenuation. The l.f. part of each stage is split via a resistor divider and routed via N1001 and V1019 to the output of this stage, where it is re-connected with the h.f. part of the input signal. Potentiometers R1036 (TRACE jump) serves as a offset compensation for N1001.

	RELAY	FET	TRIMMER FOR L.F. SQUARE WAVE	L.F. RESISTOR DIVIDER
x 1	K1004	V1011	C1033	--
x 10	K1003	V1006	C1029	R1007-R1011
x100	K1002	V1003	C1023	R1019-R1004

Note that, when "0" (GND-A) is selected, the output is connected to ground via FET V1016 and all other relay- and FET switches are switched off.

The impedance converter serves as an inverting buffer circuit for the high impedance attenuator. For the l.f.-feedback the output signal of this stage is routed to the l.f. summation point N1001-2.

The low impedance attenuator reduces the gain by  $x_1$ ,  $x_{2.5}$  and  $x_5$ , depending on which relay is activated.

	RELAY	RESISTOR DIVIDER
$x_1$	K1006	--
$x_{2.5}$	K1007	R1053 vs R1056, R1057 and R1058
$x_5$	K1008	R1053, R1056 and R1057 vs R1058

The continuous circuit (0Q0203), the differential input voltages of which are fed to pins 4 and 5.

This stage comprises the following functions:

- Continuously variable control (pin 11).
- Gain  $x_1$  (pin 2 and 3) with offset adjustment R1064 (R1164) and gain adjustment R1069 (R1169).
- Gain  $x_{10}$  (pin 6 and 7) with offset adjusting R1072 (R1172) and gain adjustment R1076 (R1176).
- $x_1/x_{10}$  control, (pin 10) to select the 2,5 and 10 mV/DIV settings.

The differential output current from pin 13 and pin 14 is routed via a common-base circuit V1063, V1064 and applied to the pre-amplifier unit.

#### 4.2 EXTERNAL INPUT

The external input can be subdivided into four stages:

Input coupling, basically similar to the ch.A input coupling.

High impedance attenuator for the  $x_1$  attenuator only, where the l.f. square-wave can be adjusted with trimmer C1206. The l.f. part is routed to the summation point N1201-2. R1217 serves as an offset compensation for N1201. For l.f.-feedback the output of the impedance converter is also routed to this summation point.

Note that the output of this stage is also a reconstituted version of the input signal.

Impedance converter, is basic similar to the ch.A impedance converter.

The differential amplifier V1211, V1212 converts the voltage from emitter-follower V1209 into the differential current signals EXT+ and EXT-. This signal is applied to the pre-amplifier unit and serves as external trigger signal or as an external deflection signal.

The current for this stage is applied from current source V1213.




Figure 4.2 Attenuator unit p.c.b.

MAT3147  
880205






Figure 4.3 Circuit diagram of attenuator, ch. A



REF NO.	TYPE
D1001	TEA1017
D1061	000203
N1001	μA714



MAT3169  
880212






Figure 4.5 Attenuator unit p.c.b.



REF. NO.	TYPE
D1101	TEA1017
D1161	QQ0203
N1101	$\mu$ A714



MAT 3170  
880212




Figure 4.4 Circuit diagram of attenuator, ch. B

INPUT COUPLING

IMPEDANCE CONVERTER

EXT. P






Figure 4.6 Circuit diagram of attenuator, EXT



REF NO	TYPE
N1201	LF356

MAT3171  
880212

EXT

## 5. PRE-AMPLIFIER UNIT (A2)

The pre-amplifier unit consists of:

- Vertical pre-amplifier
- MTB trigger pre-amplifier
- DTB trigger pre-amplifier
- Pre-amplifier control, incl. CHOPPER oscillator.

All control pulses for this unit are generated by the pre-amplifier control circuit, via the  $^{12}\text{C}$  bus (see section 5.4).

### 5.1 VERTICAL PRE-AMPLIFIER




Figure 5.1 The three stages of the vertical pre-amplifier

The vertical pre-amplifier consists of three stages.

The signal splitter (Q00205) receives its input signal for channel A (B) from the attenuator unit and copies this signal into three identical differential output current signals for:

- Vertical channel (pin 7 and 10)
- MTB triggering (pin 5 and 12), see section 5.2.
- DTB triggering (pin 4 and 13), see section 5.3.

Stage 2 (000020) consists of two integrated circuits D2201 and D2202, connected in parallel and serves as a vertical channel switch. The switch selection is as follows:

	D2201		D2202
	pin 10	pin 11	pin 10
A	1	0	0
B	0	1	0
TRIG VIEW	0	0	1
ADD	1	1	0

Further, all possible 2, 3, or 4 channel combinations are possible in alternated or chopped display (see also section 5.4).

This stage comprises the following functions:

- Position control POS A R7006 on D2201-1 for ch. A and POS B R7008 on D2201-8 for ch. B.
- Channel B normal/invert (high is INVERT) on D2201-7.  
(The balance between normal/invert can be adjusted with R2212).
- Trigger view invert (high is INVERT) on D2202-2.
- Trace separation control with R7013 on D2202-8.

Stage 3 (D2203) serves as delay line driver where the output current of both OQ0020 is converted into voltage signal applied to the delay line. The current for this stage and for D2201 and D2202 is fed via R2231 and R2246.

The current regulation for the common-mode circuit is achieved by transistor D2203 (12, 13, 14).

## 5.2 MTB TRIGGER PRE-AMPLIFIER

Trigger possibilities are:

	Signal name	Selected by: routed to	inverted by: name routed to
ch. A	TRAM+, TRAM-	D2302(3,4) AM D2302(10)	INVAM D2302(2)
ch. B	TRBM+, TRBM-	D2302(5,6) BM D2302(11)	INVB M D2302(7)
EXTERNAL line	EXT-, EXT+ LINE	D2303(3,4) D2303(5) EXTM D2303(10) LNM D2303(11)	INVAM D2303(2) INVAM D2303(7)

D2301 serves as a signal splitter and receives its input signal from the attenuator unit. This input current signal is copied into two identical differential output current signals for:

- EXT MTB signal (pin 6 and 11)
- EXT DTB signal (pin 7 and 10), (see Section 5.3).

The symmetrical output currents from D2302 (13, 14) and D2303 (13, 14) are converted into a symmetrical voltage again in the common-base circuit V2316, V2319 followed by a shunt feedback circuit V2318 and V2321. Note that the sensitivity at the collectors of V2318 and V2321 is 110 mV/DIV.

At this point the signal path is divided into:

- a trigger path, fed to both V2333 and V2334, where depending on the current to the base, levelling of the trigger signal is obtained. Two separate series feedback circuits take care of voltage-to-current conversion:
  - \* V2341 and V2342 for main time-base triggering.  
The trigger output signal, TRIGM- and TRIGM+ are fed to the time-base unit A4.
  - \* V2347 and V2349 for trigger view.  
This symmetrical output can be balanced by potentiometer R2407 (Trig view BAL).
- The TRIGV+ and TRIGV- signals are fed to D2202 (3-4).

Integrated circuit D2304 serves as an auto level circuit. The following functions are possible.

a. Peak-peak

In this case the amplitude of the trigger signal applied to D2304 (3,7) is measured by peak-peak detectors on D2304 (2,4,6,8). The output current from D2304 (14,15) is dependent on the peak-peak level and is adjustable with the LEVEL control R7012, connected to D2304(1).

b. Triggering

In this case the level range is 16 div. The level is adjustable with R7012 and the current variation on D2304 (14,15) can be varied between +or- 0,6mA.

c. TV triggering

The level control is made ineffective. In TV triggering, the LEVEL must be set to a fixed value. This is done by applying a high level current to pin 1 via diode V2326.

d. Auto

In auto the signal LEVEL ZERO is high and via diode V2325 the output level D2304 (15) is asymmetrical with output level D2304 (14). Thus the maximum signal amplitude is 2 Vp-p.

- an external deflection path, routed via the series feedback circuit V2356 and V2357, the X DEFL+ and X DEFL- signals are fed to the time base unit A2.
- R2416, R2422 and C2350 gives phase correction for the X-Y display.

### 5.3 DTB TRIGGER PRE-AMPLIFIER

Trigger possibilities are:

	Signal name	routed to	Selected by: name	routed to	Inverted by: name	routed to
ch.A	TRAD+, TRAD-	D2501(3,4)	AD	D2501(10)	INVAD	D2501(2)
ch.B	TRBD+, TRBD-	D2501(5,6)	BD	D2501(11)	INVBD	D2501(7)
EXTERNAL	EXT+, EXT-	D2502(5,6)	EXTD	D2502(11)	INVAD	D2502(7)

Similar to the main time base triggering, signal splitter D2301 applies the EXT current to the OQ0020.

The LEVEL control R7014 is connected to D2502-1 to obtain a level range of 16 div.

The output of both integrated circuits, pin 13 and 14, are routed via a shunt feedback V2512, V2513, followed by a series feedback circuit V2514, V2516 and provide the DTB trigger signals TRIGD- and TRIGD+. These signals are fed to the time-base unit A4.

#### 5.4 PRE-AMPLIFIER CONTROL

The pre-amplifier control converts the data from the  $I^2C$  bus (SDA and SCL), derived from the microcomputer, into the control pulses for the pre-amplifier unit. To eliminate interference the SDA and SCL lines can be switched off via D2601.

This integrated circuit serves as a digital switch, controlled by the VERT IIC line. Logic high connects the outputs D2601(4,14,15) to the input "1" contact (switched on); logic low connects the outputs to the "2" contact (switched off) and gives SDA a logic low level and SCL a logic high level.

When D2601 is switched on, the serial data information is converted into parallel control pulses via D2602 and D2603, provided that D2602 is enabled (D2602-5 is high). The control lines are active when the level of the line is high.

Output Q12-D2602(9) serves as a power up not line for D2603: when the oscilloscope is in the power-up routine, Q12 is high and resets D2603. After the power-up routine, Q12 goes low and enables D2603.

Integrated circuit D2603 relieves the microcomputer of a number of such functions as:

- trigger view
- chop/alt
- trace separation
- trigger select
- time-base select (fed to time base unit A4)

Adaptation of this I.C. to the oscilloscope version is made by the ADO and AD1 inputs D2603(15,16).

For this oscilloscope, ADO must be HIGH and AD1 must be LOW.

Timing for alternate and chopped mode is derived by the ALTCLN and CHOPCL pulses.

The chopper oscillator formed by V2611 and V2612 supplies a square wave voltage of 1,5 Vp-p with a frequency of 1 MHz.

This frequency is defined by two current loops:

- I1 is determined by: V2612(c-e), C2611, R2627 and R2625.
- I2 is determined by: V2611(c-e), C2611, R2628 and R2625.

The duty cycle ( $I1/I1+I2$ ) is 12% approx.

The square wave on the collector of V2612 serves as a chopper clock pulse for D2603 and gives a 500 kHz display for 2 channels CHOP, 333 kHz display for 3 channels CHOP and 250 kHz for 4 channels CHOP (A-B-TRIG VIEW-ADD).

Note that D2603(8) serves as the chopper switch, which is high when the CHOP softkey is depressed.




Figure 5.2 Pre-amplifier unit p.c.b.





Figure 5.3 Circuit diagram of pre-amplifier, channel switch + delay line driver







Figure 5.5 Pre-amplifier unit p.c.b.

MAT3149  
880212



REF NO.	TYPE
D2301	QQ0205
D2302	QQ0020
D2303	QQ0020
D2304	QQ0128

MAT3176  
880212




Figure 5.4 Circuit diagram of pre-amplifier, MTB trigger switch





Figure 5.6 Circuit diagram of pre-amplifier, DTB trigger switch



REF NO.	TYPE
D2501	000020
D2502	000020
D2301	000127

MAT3177  
880212

er, DTB trigger switch

### CONTROL CIRCUIT




Figure 5.7 Circuit diagram of pre-amplifier, logic control




Figure 5.7 Circuit dia

## 6. XYZ-AMPLIFIER UNIT (A3)

### 6.1 INTRODUCTION

Unit A3 incorporates two separate PCB's which are connected via X3001. One p.c.b. includes among other things the CRT socket and is connected at the rear of the CRT. The other p.c.b. comprising the proper final X and Z amplifiers is situated at the upper side of the CRT. For ease of description, unit A3 is described as one unit.

The XYZ-amplifier unit consists of:

- Final vertical (Y) amplifier.
- Final horizontal (X) amplifier.
- Final unblanking (Z) amplifier, incl. CRT.

### 6.2 FINAL VERTICAL (Y) AMPLIFIER

The final Y-amplifier receives its signal from the delay line and supplies the correct vertical signal to the Y-deflection plates of the CRT. For this the signal is processed in four stages:

- V3001, V3002 as a series feedback amplifier, including a delay line compensation network and potentiometer R3007 controlling current source V3003 for correction of any unbalance in the Y-deflection plates of the CRT. These circuits are connected between the emitters of both transistors.  
In this stage the input voltage is converted into a current signal.
- V3004, V3006 as a shunt feedback amplifier, which gives a voltage signal to the next stage.
- V3008, V3009 as a series feedback amplifier, including a final RC-correction network and potentiometer R3038 for gain adjustment to compensate the different CRT sensitivities. V3007 supplies a constant current of 60 mA, i.e. 30 mA for each side. Note that the output again supplies a current signal.
- V3011, V3012 as a common-base amplifier for buffering the final Y-amplifier to the Y-deflection plates. The maximum amplitude on each deflection plate is:  $30 \text{ mA} \times 660 \text{ E} = 20 \text{ V approx.}$

### 6.3 FINAL HORIZONTAL (X) AMPLIFIER

The input current for X-deflection is obtained from the time-base unit (ref: X- and X+) and processed in three stages, with circuits in the following configurations:

- V3101, V3102 as a common-base amplifier. The current "I" on the collector of both transistors determines the voltage across R3102 and R3116. This voltage is about 1,5 V p-p and feeds the next stage.
- V3103, V3106 as a series feedback amplifier, including a RC-correction network for optimum linearity of the trace and potentiometer R3118 for xl amplifier adjustment, mounted between the emitters of both transistors. V3104 serves as current source.

- V3112, V3114 are connected as a shunt feedback amplifier, with resistors R3126 and R3134 as the feedback resistors. The transistor source are emitter followers V3109, V3111. This circuit serves as the actual final amplifier, which converts the deflection current into the proper deflection voltage for the X-deflection plates of the CRT. Transistors V3108, V3116 supply the bias current for the circuit.

#### 6.4 FINAL BLANKING (Z) AMPLIFIER AND CRT

The blanking current derived from the Z pre-amplifier of the time-base unit is routed via common base amplifier V3200 and emitter-follower V3201 to the shunt-feedback amplifier V3202. This stage is fed by current source V3203, which gives a constant current of 4 mA. The voltage on the collector of V3202 can vary between +5 V for unblanking and -35 V for fully blanking.

This Z-pulse may contain d.c., l.f. and h.f. components to be applied to grid G1 of the CRT. Since G1 is at a cathode potential of -2000 V, blocking capacitors are required between G1 and the Z-amplifier output. The h.f. component is directly routed via blocking capacitor C3211 to G1. However, the d.c. and l.f. components are blocked, so these components are first modulated on a 200 kHz carrier signal by V3207 and V3208 to pass blocking capacitor C3209. Then the signal is demodulated again by V3209 and V3211. Finally, the reconstituted d.c. and l.f. components are added to the h.f. component.

Transistor V3251 forms a nominal 70 V zener circuit which provides the voltage difference between the cathode and G1 of the CRT. This bias voltage ensures blanking when there is no input signal. For adaptation to each CRT, this voltage can be varied between about 40 V and 100 V by means of R3252 (BLACK LEVEL). Resistor R3254 maintains the filament at the same potential as the cathode.

Any ripple on the cathode voltage is fed-back via transistor V3213 to the input of the Final Z-amplifier and added to the blanking signal. This means that the differential voltage between G1 and the cathode of the CRT is always fixed. Because this differential voltage determines the intensity of the spot, as a result, the intensity is almost independent of the ripple.

The amplifier stage V3253, V3254 and V3256 provides amplification for the range of the FOCUS control. The range of 0...+10 V gives a final range on G3 of the CRT of -1350 V ... -1600 V.

Resistor R3257 connects the INTENS control to the focus adjustment to maintain a sharply defined trace at varying brightness.

For optimum presetting of the GEOMETRY, the voltage on G5 of the CRT is set to a fixed level of -30 V. The ASTIGMATISM can be varied by means of potentiometer R3267.




Figure 6.1 XYZ Amplifier unit p.c.b.





Figure 6.2 Circuit diagram of XYZ




Figure 6.1 XYZ Amplifier  
Figure 6.2 Circuit diagram of XYZ amplifier, final X and Y amplifiers




Figure 6.4 Circuit diagram of XYZ amplifier, Z amplifier and CRT circuit




Figure 6.4 Circ




Figure 6.3 XYZ Amplifier unit p.c.b.

## 7. TIME-BASE UNIT (A4)

The time-base unit consists of:

- Trigger amplifier
- Timing circuit
- Sweep generators
- X DEFL amplifier, incl. display mode switch
- Horizontal pre-amplifier
- Z amplifier

As a supplement, the timing diagrams for several conditions of the time base are given in section 7.6.

All control pulses for this unit are generated by the time-base control circuit, via the I<sup>2</sup>C bus. Integrated circuits D4001 and D4002 convert this series DATA into the parallel control pulses, provided that DLEN TB1, and DLEN TB2 are HIGH.

### 7.1 TRIGGER AMPLIFIER

#### \* MTB triggering:

The symmetrical trigger current signals TRIGM+ and TRIGM- are derived from the pre-amplifier unit and converted into the asymmetrical MTB trigger voltage via the shunt feedback amplifier V4003 and V4006. The amplifier of this MTB trigger signal is the summation of the voltage swings across R4002 and R4003, which are proportional to the current swing of TRIGM+ and TRIGM-.

#### \* TV triggering:


When the signal TVMTB goes LOW, the normal trigger path is blocked via V4005 and V4007 and the trigger signal is routed via the TV trigger stage V4009...V4018. Transistor V4009 serves to clip the synchronisation pulse and LINE/FRAME selection is obtained by 4016.

#### \* DTB triggering:

The DTB triggering is almost similar to the MTB triggering. For TV triggering, the trigger signal is obtained from V4012 and, determined by C4024; only TV LINE triggering can serve as a DTB trigger signal for TV pictures.

## 7.2 TIMING CIRCUIT (see figure 7.1)

The timing for the entire time-base circuit is obtained by D4103 together with its associated components.



MAT2116  
860214

Figure 7.1 D4103 configuration

D4103 has the following relevant pin connections:

Pin	Name	INPUT-OUTPUT	Description
1	SINGLE	TTL-input	Selects the single time-base mode.
2	RESET	TTL-input	Stops the sweep and starts the hold off sweep.
3	AUTO	TTL-input	Selects the AUTO trigger mode, the MTB is free-running after the last trigger pulse.
4	TESTIN	TTL-input	Selects the possibility to drive several functions (TESTOUT) in combination with SINGLE and RESET.
5	TESTOUT	TTL-output	--
6	X DEFL	TTL-input	Activates the Z1 and Z2 outputs.
7	Vbb	-	+1,5 V supply input.
8	AUTOTIME	input	RC-time determination (100 ms) for the AUTO trigger mode.
9	BSXMTB	TTL-output	Discharges the MTB-sweep capacitor(s).
10	SMTB	SCHMITT-input	Determines the end of the MTB-sweep.
11	TMTB	SCHMITT-input	Determines the start of the MTB-sweep.
12	Z2	TTL-output	Determines the blanking of the CRT.
13	Z1	TTL-output	Determines the blanking of the CRT.
14	GND	-	Ground.
15	Vcc	-	+5 V supply input.
16	DTB1	SCHMITT-input	DTB starts, or starts after trigger pulse.
17	DTB2	-	not used, connected to ground.
18	TDTB	SCHMITT-input	Triggers the DTB-sweep when required.
19	BSXDTB	TTL-output	Discharges the DTB sweep capacitor.
20	SDTB	SCHMITT-input	Determines the end of the DTB-sweep.
21	BSXHO	TTL-output	Determines the ALT clock pulse
22	SHO	SCHMITT-input	Determines the end of the Hold-off sweep.
23	DTBS	-	not used; connected to +5 A.
24	EOS	-	Not used; connected to +5 A.
25	TBS	TTL-input	Determines the MTB-unblanking (HIGH) or the DTB-unblanking (LOW).
26	TORS	TTL-input	Determines the STARTS condition (LOW) or TRIG'D condition (HIGH) of the DTB.
27	F1	TTL-input }	Determines the selection for the different horizontal Display modes.
28	F2	TTL-input }	
			Display mode
		0 0	MTB
		0 1	MTBI
		1 0	DTB
		1 1	MTBI and DTB

NOTE: All SCHMITT-inputs are at +2,5 V level.

## 7.3 SWEEP GENERATORS

Because the MTB and DTB sweep generators are almost similar, only the MTB sweep generator is described.

\* MTB sweep generator (See figure 7.2):




Figure 7.2 Simplified diagram of the MTB

U1

The MTB sawtooth charging current R4143 (and R4144) determines the sweep speed via C4113 (+C4114).

The circuit is controlled by the following address lines:

- MA0...MA2, for interconnection of D4102-3 to an input pin, thus giving six different voltage levels U1 with respect to +14,6 V.
- MREED, for addition of R4144 to the sawtooth charging circuit.
- MC, for addition of C4114 to the sawtooth charging circuit and for switching over between calibration pot.meters R4107 (50ns...100us) and R4108 (200 us...0,5 s).

The voltage U1 can be continuously varied by moving the VAR MTB control R7009 from the CAL position. Thus a sweep variation of 1:2,5 can be obtained.

The function table for the MTB and DTB sweep generators is given below:

sweep speed	MA2 (DA2)	MA1 (DA1)	MA0 (DAO)	MREED (DREED)	MC (DC)		
50 ns	1	1	1	0	0		
.1 us	0	1	0	0	0		
.2	0	0	1	0	0		
.5	0	0	0	0	0		
1	0	1	1	0	0		
2	1	0	0	1	0		
5	1	1	1	1	0		
10	0	1	0	1	0	MTB- range	DTB- range
20	0	0	1	1	0		
50	0	0	0	1	0		
.1 ms	0	1	1	1	0		
.2	1	0	0	0	1		
.5	1	1	1	0	1		
1	0	1	0	0	1	-	- -
2	0	0	1	0	1		
5	0	0	0	0	1		
10	0	1	1	0	1		
20	1	0	0	1	1		
50	1	1	1	1	1		
.1 s	0	1	0	1	1		
.2	0	0	1	1	1		
.5	0	0	0	1	1		

NOTE: when MREED and DREED are low, then RELAY is switched on.

The MTB sawtooth current is fed to the buffer circuit, where the h.f. sweep components (to 2 usec) are routed via C4116 and V4118, V4119. The l.f. sweep components (0,5 sec...2usec) is routed via N4103.

Finally the MTB sweep and DTB sweep voltages are applied to the horizontal display mode switch.

#### \* Delay time multiplier circuit:

Output signal DTB1 of comparator stage D4402 controls the starting point of the DTB depending on the adjusting of the DTM front-panel control. This signal is applied to D4103-16.

The comparator has two inputs:

- D4402-4 receives the MTB sawtooth voltage.
- D4402-2 receives a fixed adjusted voltage between 0...5 V. Digital-to-analogue (DAC) converter D4401 converts the digital information of the DTM setting (SDA-input) into an analogue current (pin 22), which in its turn is converted into the fixed comparator voltage via N4101.

At the moment that the instantaneous d.c. value of the MTB sawtooth exceeds the voltage on D4402-2, signal DTB1 goes higher.

\* Hold-off circuit

During the MTB sweep, capacitor C4304 is discharged. In the lower sweep speeds (lower than 10us) capacitor C4302 is also discharged via V4306. After the MTB sweep, the capacitor(s) are charged via current source V4304 until the voltage across C4304 reaches the +2,5 V level. This voltage is applied to D4103 as the SHO signal and determines if the MTB can generate a new sweep.

Depending on the HOLD OFF control potentiometer R7011 adjustment, a part of the charging current leaks away via V4301 and thus continuously variation of the charging time (i.e. hold-off time) is obtained. When BSXMTB goes LOW, the MTB starts to run again and at the same time C4304 (and C4302) are discharged again via V4309.

\* Alt. clock generator:

At the end of each MTB sweep the signal BSXHO goes low. This signal is routed to V4322 to generate the ALTCLN pulse, which is applied to the pre-amplifier unit A2. The ALTCLN pulse controls the channel switch on that unit at the end of each MTB sweep. When SHO reaches the +2,5 V level, BSXHO goes HIGH again.

#### 7.4 X DEFL AMPLIFIER, AND DISPLAY MODE SWITCH

\* X DEFL amplifier

The circuit for converting the symmetrical X DEFL+ and X DEFL- signals into the asymmetrical voltage, applied to the display mode switch is identical to the MTB trigger input. However, this circuit can be switched-off by diodes V4500 and V4505, provided that the X DEFL signal is HIGH.

\* Horizontal display mode switch:


The three deflection signals MTB, DTB or X DEFL are switched to the horizontal pre-amplifier via diode switches. These switches are under control of the signals X DEFL and TBS. The output of the circuit is applied to R4701 on the horizontal pre-amplifier stage.  
The logic table is given below:

X DEFL	TBS	Output
1	*	X DEFL signal
0	0	DTB sawtooth
0	1	MTB sawtooth

## 7.5 Z-AMPLIFIER

**\* Z-switch:**

The Z-switch N4601 is configured as two differential amplifiers with a common current output to R4625. The stage is supplied by a constant current source via pin 1 and pin 8. The inputs Z1 and Z2 are derived from the timer stage D4103 and determine the unblanking of the CRT according to figure 7.3.



MAT2118  
851011

Figure 7.3 Z-logic for the different TB modes

When both Z1 and Z2 are HIGH, the trace gives normal intensity; when only Z1 or Z2 is HIGH the trace gives half intensity. This means that, in MTBI mode, the DTB part of the trace is more intensified than the MTB part of the trace. The ratio between both intensities is adjusted by R4616. The amplitude of the Z-current can be varied by the front-panel INTENS control R5001. The slider of this control potentiometer drives the base pin 2 and pin 7 of both current sources.

To prevent burn-in of the CRT in the lower sweep speeds 0,5 sec...50 usec, signal ZB is LOW and reduces the voltage to pin 2 and pin 7.

Signal ZA is a software-controlled pulse to blank the trace when the AMPL/DIV switch is used.

**\* Z Pre-amplifier:**

In normal condition, the fully current for CRT blanking derived from N4601 is routed via R4625, V4612 and R2628 to the XYZ Amplifier A3.

However, there are two conditions for additional blanking:

- In the chopped mode of the vertical channels the display is blanked during switching over between channels. This happens by connecting the CHOPBLN pulse to V4611. When this pulse is HIGH, transistor V4611 conducts and a part of the blanking current flows via V4611 e-c to the +5 kV rail.
- if a HIGH level is applied to the external Z MOD input on the rear panel, this signal causes conducting of V4616 so that a part of the blanking current flows via V4616 e-c to the +5 kV rail.

## 7.6 TIMING DIAGRAMS

The following figures gives the timing diagrams for D4103 for several conditions of the time-base. The conditions are:

- a free running MTB sweep
- a triggered MTB-sweep with a delayed sweep
- a triggered MTB-and DTB-sweep

\* Free running MTB sweep:




Figure 7.4 Free-running MTB sweep-timing diagram

\* Triggered MTB-sweep with a delayed sweep:





Figure 7.5 Triggered MTB-sweep with a delay sweep-timing diagram

\* Triggered MTB- and DTB-sweep:

SINGLE	0
RESET	0
AUTO	1
TEST IN	0
X DEFL	0
TORS	1
F1	1
F2	1
DTBS	0
EOS	1
TBS	*



MAT2230  
860210

Figure 7.6 Triggered MTB- and DTB-sweep-timing diagram




Figure 7.7 Time base unit p.c.b.





Figure 7.8 Circuit diagram of time-base, trigger amplifier MTB and DTB







Figure 7.9 Circuit diagram of time base, MTB and DTB sweep circuits and final X DEFL amplifier






Figure 7.10 Time base unit p.c.b.





Figure 7.11 Circuit diagram of time-base, pre-amplifier and Z switch



## 8. CRT CONTROL UNIT (A5)

This unit incorporates the potentiometers that control the CRT functions. These potentiometers are INTENS (R1), screwdriver operated control TRACE ROT (R2), FOCUS (R3) and ILLUM (R4). The range of these potentiometers is between 0 V and +10 V. The way these potentiometers influences the associated circuit is described together with the description of the relevant circuit part.




Figure 8.1 Circuit diagram of CRT control




Figure 8.2 CRT control unit p.c.b.



## 9. POWER SUPPLY UNIT (A6)

Basically, the power supply unit consists of:

- input circuit
- converter circuit
- secondary output rectifiers
- HT supply
- CAL oscillator
- CRT control circuit

### 9.1 INPUT CIRCUIT

The instrument may be powered from a nominal mains voltage of 100 V...240 V a.c.

The mains voltage is primary protected by a fuse of 1,6 AT, which is located on the rear of the instrument.

After rectification by the diode bridge V6001...V6004 a d.c. voltage is applied to the converter circuit.

This voltage is smoothed by capacitors C6007, C6008 and chokes L6000, L6001 and L6002.

Depending on the mains voltage, the rectified voltage is 120 V...370 V.

**WARNING:** All measurements on the INPUT CIRCUIT and the CONVERTER CIRCUIT should be done with a floating oscilloscope.  
As reference voltage can be used measure point X48.

A fixed part of the mains voltage serves as a LINE-trigger signal.  
The amplitude of the LINE trigger signal is 1/22x MAINS.

**NOTE:** The LINE trigger signal is not present when a d.c. voltage serves as MAINS.

### 9.2 CONVERTER CIRCUIT (see figure 9.1 and figure 9.2)


The flyback converters consists of transistor V6014 and V6018 and their associated components. The converter frequency depends on the LINE IN amplitude and is for 110 Vac: 30 kHz approx and for 220 Vac: 45 kHz approx.

Transistors V6014 and T6018 conduct on the forward stroke and charge transformer T6001. The thyristor V6013 fires when the voltage on the gate reaches the firing level (0,6 V approx). Consequently, V6018 blocks - V6014 blocks, for the duration of the flyback stroke, during which the secondary windings discharge via the diode rectifiers into the smoothing capacitors. The NTC resistor R6009 provides temperature compensation for the firing point of the thyristor.

During the flyback, capacitor C6009 charges again via the path T6001-1, V6012, V6009, R6004, C6009, L6002 and T6001-2.


The voltage stabilizer with transistor V6009 gives a square-wave to the gate of transistor V6014 with a maximum amplitude of 15 V.

The dv/dt limiter with L6004, L6006, V6017 and V6019 serves to eliminate the switching spikes present on the collector of V6018 (measuring point X46).



MAT2119  
860214

Figure 9.1 Converter circuit



MAT2120

Figure 9.2 Timing diagram converter circuit

### 9.3 SECONDARY OUTPUT RECTIFIERS

The output voltages taken from the secondary windings of transformer T6001 are rectified by diodes and smoothed by capacitors in conventional circuits.

A "CROWBAR" circuit with transistor V6137 and V6112 protects the +5 V supply.

When the +5 V level is too high, transistor V6137 (and V6112) conduct and the power supply goes into short circuit mode.

A voltage protection circuit using V6134, V6136 and V6112 protects against overloads protection. When the power supply is overloaded, these components conduct and the power supply goes into in the short-circuit mode.

### 9.4 HT SUPPLY




Figure 9.3 HT oscillator


The HT supply consists of an oscillator and a regulator circuit. Transformer T6201 determines the frequency (50 kHz approx.) of the oscillator. The output signal voltage on the secondary winding of T6201 is rectified by diode V6209 and smoothed by C6211. The -2,1 kV is also converted to -14,5 kV in the HT multiplier D6201 and routed via connector X6030 to the post-acceleration anode of the CRT.

To regulate this HT voltage the -2 kV is fed to the input of OP-AMP N6002.

The output level of N6002 determines the energy to T6201, and thus the amplitude of the HT-voltage.

### 9.5 CALIBRATOR

The calibrator circuit consists of two analogue switches D6501(8-9) and D6501(11-12) controlled by the active HIGH enable inputs 6 and 12 respectively, that are connected as an 2 kHz astable oscillator. Capacitor C6502 and resistor R6504 determine the 2 kHz frequency. The oscillator outputs, applied to enable inputs 5 and 13 of the second stage are in anti-phase with each other. Depending on the level of input 5 and 13, the CAL voltage will have a 1,2 V level or a 0 V level.






Figure 9.4 Power supply unit p.c.b.






Figure 9.5 Circuit diagram of power supply



## 10. FRONT UNIT (A7-A8)

The front unit consists of:

- the microcomputer control circuit
- the LCD display circuit
- the front panel controls

### 10.1 MICROCOMPUTER CONTROL CIRCUIT

#### 10.1.1 Introduction to MAB8052 microcomputer


The integrated circuit MAB8052, one of the MSC-51 family of single chip microcomputers, forms the basis of the microcomputer system of the oscilloscope. The MAB8052 has an internal 8 k ROM and 256 bytes RAM with address/data decoding facilities. In addition to this, the 8052 has 32 I/O lines. Data written to these lines remains unchanged until rewritten. Each line is able to serve as input or output, or both, even though outputs are statically latched. To provide specific serial data transfer possibilities, the microcomputer system contains an  $I^2C$  bus interface.

#### 10.1.2 Characteristics of the $I^2C$ bus

The  $I^2C$  bus is for 2-way, 3-line communication between different ICs or modules. The three lines are a serial data line (SDA), a serial clock line (SCL) and ground. Both lines must be connected to a positive supply via a pull-up resistor when connected to the output stages of a device. Data transfer may be initiated only when the bus is not busy.

##### Bit transfer:

One data bit is transferred during each clock pulse. The data on the SDA line must remain stable during the HIGH period of the clock pulse as changes in the data line at this time will be interpreted as control signals.




MAT2122  
851011

Figure 10.1 Bit transfer

**Start and stop conditions:**

Both data and clock lines remain HIGH when the bus is not busy. A HIGH-to-LOW transition of the data line, while the clock is HIGH is defined as the start condition (S). A LOW-to-HIGH transition of the data line while the clock is HIGH is defined as the stop condition (P).




MAT2123  
851011

Figure 10.2 Definition of start and stop conditions

### 10.1.3 I<sup>2</sup>C structure

The two lines SDA and SCL are fed to the various circuits, where, depending on the addressing, this serial information is converted into the different control signals (see figure 10.3).



MAT2125A  
860214

Figure 10.3 I<sup>2</sup>C structure


To select the serial-parallel conversion circuits, the bus decoder D7003 decodes the address lines A8, A9 and A11 into the DLEN (Data latch enable) signals according to the next table

ADDRESS LINES			DATA		
A11	A9	A8	A10		
0	0	0	1/0	8400H	SEL IIC
0	0	1	1/0	8500H	DLEN B
0	1	0	1/0	8600H	DLEN A
0	1	1	1/0	8700H	DLEN P
1	0	0	1/0	8C00H	DLEN TB1
1	0	1	1/0	8D00H	DLEN TB3
1	1	0	1/0	8E00H	DLEN TB2
1	1	1	1/0	8F00H	N.C.

To eliminate interference in the vertical circuits, the I<sup>2</sup>C bus can be switched off for this circuit by switch D2601. The timing is obtained by the VERT IIC line.

Note that for servicing, solder joints are added in the p.c.b. tracks connecting the circuits. These can be used to localize a fault in the I<sup>2</sup>C-bus by means of interrupting the bus connection.

#### 10.1.4. Microcomputer MAB8052



MAT2126  
860214

Figure 10.4 Pinning of microcomputer MAB 8052

The microprocessor has the following connections:

- \* Crystal connections (pin 18 and 19)  
A 12 MHz crystal is connected to the inputs XTAL1 and XTAL2 to provide an accurate timing reference source.
- \* RESET input (pin 9)  
After switching on a reset level HIGH is applied to this input. This reset signal forces the microcomputer to initiate the main program, beginning at the address 00000H. After the +5 V supply is within its specification, the RESET is released and the microcomputer is ready for use.
- \* 8-bit quasi bidirectional I/O port (pin 1...pin 8) and quasi-bidirectional I/O port (pin 10), used to read the settings of the KEY-MATRIX switches S2...S32 (excl. S12-AUTOSET)
- \* 3-bit quasi-bidirectional I/O port (pin 15...pin 17), used to read the UNCAL position of S5, S7 and S9 (UNCAL when logic HIGH).
- \* WATCHDOG input (pin 13)  
The WATCHDOG is a facility to control the correct function of the software. When HIGH the internal counter will run. The software gives a pulse every 64 ms max. to reset this counter, so that the 64 ms max. cycle starts again. If the software does not function correctly, the internal counter receives no reset pulse and the counter will overflow initiating the main program (start address 0000H).
- \* 8-bit open drain bidirectional I/O port (pin 21...pin 28) used for addressing the serial-parallel conversion circuits (see I<sup>2</sup>C structure).
- \* 8-bit quasi-bidirectional I/O port (pin 32...pin 39) used to read the status input via D7006.
- \* SDA (pin 14); SCL (pin 12)  
Bidirectional I<sup>2</sup>C lines.
- \* VERT IIC (pin 11)  
Signal used as a digital switch control to switch-off the I<sup>2</sup>C bus of the pre-amplifier control.

#### 10.1.5. I<sup>2</sup>C decoding

Integrated circuit D7002 serves as a multiplexer to make a separation between the I<sup>2</sup>C lines for the LCD drives and the I<sup>2</sup>C lines for the other circuits, controlled by the SEL IIC line. Only when SEL IIC is HIGH (address 8400H), are the SDA and SCL lines from the microcomputer connected to unit A8.

#### 10.1.6. Status input

Integrated circuit D7006 serves as an input port to read the following status info:

- TEST OUT, indication for triggered mode, HIGH when triggered.
- FOOTN, remote control for AUTO SET, LOW when active.
- NOPTION, adapts software for optional trigger coupling, LOW when optional triggering.
- REMRQN, remote request line, LOW when active.
- probe indication status, adapts V/DIV reading for probe attenuation.

When the enable inputs (pin 1 and pin 19) become LOW, the status input is read and copied in the accumulator of the microcomputer via the data lines AD0...AD7.

Note that enabling is only possible when D7002-2 is switched-on to D7002-15, i.e. when A15 is HIGH (address 8000H ... FFFFH).

#### 10.1.7 Probe indicator

Integrated circuit D7004 (000044) detects the kind of probe which is connected to the oscilloscope. Depending on the resistance between the probe indication input (pin 3 for channel A and pin 16 for channel B) and ground, the V/DIV reading of the LCD automatically increases according to the next table.

Pin 3 (16)	Pin 6 (17)	Pin 7 (12)	V/DIV attenuation
2k32	0	0	x10
6k98	1	0	x100
7k68	0	1	x1
10k	1	1	x1

#### 10.1.8 C-Bus decoder

This integrated circuit decodes the address lines A8, A9 and A11 into the DLEN signals.

During the power-up all the lines are reset to LOW.

### 10.2 LCD DISPLAY CIRCUIT

The LCD is driven by three drivers D8001, D8002 and D8003 (PCF8577). The temperature dependent supply voltage VCPCF is 4 V approx. at 25°C. When the temperature increases, this voltage decreases. The single-pin built-in oscillator on pin 37 of D8001 provides the modulation frequency for the LCD segment driver outputs. Capacitor C7008 and resistor R7038 are connected to this pin to form the oscillator, with a frequency of 150 Hz approx. Pin 36 and pin 37 are used to determine the LCD drivers address in the I<sup>2</sup>C bus.

The outputs pin 1...pin 32 directly drive the LCD.

Outputs BP1 and BP2 (pin 33 and pin 34) drive the COMMON pins of the LCD.

### 10.3 FRONT-PANEL CONTROLS

The front-panel controls give a voltage between 0 V...10 V to the various circuits.

To determine the UNCAL condition of VAR A, VAR B or VAR MTB, the d.c. voltages of the slider of the potentiometers are applied to comparator N7001. When the voltage level of the control is lower than 0,7 V, the microcomputer reads a logic LOW on its input and adapts the LCD display to indicate the CAL status (e.g. no flashing ">" sign visible).




Figure 10.5 Front unit p.c.b.





Figure 10.6 Circuit diagram of front unit







Figure 10.7 LCD unit p.c.b.



MAT 2277

Figure 10.8 Circuit diagram of LCD unit

## 11. PERFORMANCE CHECK

### 11.1 GENERAL INFORMATION

**WARNING:** Before switching-on, ensure that the instrument has been installed in accordance with the Installation Instructions outlined in section 2 of the Operating Manual.

This procedure is intended to:

- Check the instruments' specification.
- Be used for incoming inspection to determine the acceptability of newly purchased instruments and/or recently recalibrated instrument.
- Check the necessity of recalibration after the specified recalibration intervals.

**NOTE:** The procedure does not check every facet of the instruments calibration; rather, it is concerned primarily with those parts of the instrument which are essential to measurement accuracy and correct operation. Removing the instruments covers is not necessary to perform this procedure. All checks are made from the outside of the instrument.

If the test is started within a short period after switching-on, bear in mind that steps may be out of specification, due to insufficient warming-up time.

Warming-up time under average conditions is 30 minutes.

The performance checks are made with a stable, well-focussed, low-intensity display. Unless otherwise noted, adjust the intensity and trigger-level controls as needed.

#### IMPORTANT NOTES:

- \* At the start of every check, the controls always occupy the preliminary settings AUTO SET position, unless otherwise stated.
- \* The input voltage has to be supplied to the A-input; unless otherwise stated.  
Set the TIME/DIV switches to a suitable position; unless otherwise stated.
- \* Tolerances given are for the instrument under test and do not include test equipment error.
- \* In this chapter in some checks channel B is mentioned between brackets behind channel A. It is advised to perform first channel A checks. After that the checks for channel B can be done.




Figure 11.1 SOFTSTART condition

## 11.2 PRELIMINARY SETTINGS

- Switch-on the instrument (no input signal).
- Check if all LCD segments are on for approx. 1 sec.
- Press MENU and AUTO SET.
- Check if the frontcontrols are set in sequence in the softstart condition as indicated in figure 2.1.
- At the start of every check only AUTO SET must be pressed (after the input signal is applied).

## 11.3 RECOMMENDED TEST EQUIPMENT

The test equipment that must be used for this performance check is as given in section 13.2 of the Service manual, except:

Trimming tool kit  
Oscilloscope  
Digital multimeter

## 11.4 CHECKING PROCEDURE

## 11.4.1

## POWER SUPPLY (characteristics: 2.5)

*	SUBJECT	Line voltage input
	TEST EQUIPMENT	Variable mains transformer
	MAINS VOLTAGE	Between 100 V and 240 V ac (r.m.s.) Frequency: 50 Hz...400 Hz
	SETTINGS	- Press POWER ON - Apply CAL signal to input A - Press AUTO SET
	REQUIREMENTS	- Starts at any mains voltage between 100 V...264 V ac (r.m.s.) - Instruments performance does not change over indicated mains voltage range; displayed CAL signal distortion-free and with equal intensity.
	MEASURING RESULTS	.....
*	SUBJECT	Power Consumption (ac source)
	TEST EQUIPMENT	Wattmeter (moving iron meter)
	MAINS VOLTAGE	Mains voltage 220 V (r.m.s.).
	SETTINGS	Press POWER ON
	REQUIREMENTS	Consumes : 45 W
	MEASURING RESULTS	.....

## 11.4.2

## DISPLAY (characteristics section 2.1)

*	SUBJECT	Orthogonality
	TEST EQUIPMENT	LF sine-wave generator
	INPUT VOLTAGE	Sine-wave signal 50 Hz...60 Hz
	SETTINGS	- Set trace exactly in parallel with horizontal graticule line (see section: Trace rotation) - Apply a sine wave signal to input A. (50 Hz...60 Hz) - Set trace height to 8 div. - Press X DEFL. - Press TRIG or X SOURCE and select B as MTB trigger source
	REQUIREMENTS	- Check if vertical line is in parallel with the vertical graticule line in the centre of the screen. - Angle with respect to horizontal line must be $90^\circ$ +or- $1^\circ$
	MEASURING RESULTS	.....

*	SUBJECT	LCD check
TEST EQUIPMENT	-	
INPUT VOLTAGE	-	
SETTINGS	<ul style="list-style-type: none"> <li>- Press MENU and keep it pressed</li> <li>- Then press AUTO SET</li> <li>- Check if LCD indicates "1<sup>0</sup>", "2<sup>0</sup>", "AS" and "3<sup>0</sup>"</li> <li>- Press "S" of DTB UP-DOWN control</li> <li>- Press MENU, 8 times</li> <li>- All segments of the LCD should be ON according to figure 3.2 of the Operating Manual.</li> <li>- To leave this test: press MENU and then AUTO SET</li> </ul>	
REQUIREMENTS	<ul style="list-style-type: none"> <li>- Check if all segments of the LCD are on (see figure 3.2 of the Operating manual)</li> </ul>	
MEASURING RESULTS	.....	

11.4.3 VERTICAL DEFLECTION OR Y-AXIS  
(characteristics section 2.2)

*	SUBJECT	Vertical Deflection
TEST EQUIPMENT	LF Square wave generator	
INPUT VOLTAGE	Square wave signal 1 kHz to A	
SETTINGS AND REQUIREMENTS	<ul style="list-style-type: none"> <li>- Set trace height to 5 div.</li> <li>- Check if one square wave signal of 5 div. is displayed</li> <li>- Press A/B; channel A and B on</li> <li>- Check if a square wave signal (A) and a zero trace (B) is displayed and if A and B are on.</li> <li>- Press ALT/CHOP</li> <li>- Check if ALT or CHOP is active.</li> <li>- Press TRIG VIEW.</li> <li>- Check if two square wave signals (A and TRIG VIEW) and a zero trace (B) are displayed</li> <li>- Press TRIG VIEW; Check if A and B are on.</li> </ul>	
INPUT VOLTAGE	Square wave signal 1 kHz to input A and B	
SETTINGS AND REQUIREMENTS	<ul style="list-style-type: none"> <li>- Press AUTO SET</li> <li>- Check if A, B and ALT are on</li> <li>- Set trace height to 4 div.</li> <li>- Press AC/DC of channel A and B for DC input coupling</li> <li>- Press ADD/INVERT twice for ADD mode.</li> <li>- Check if 3 square wave signals are displayed: channels A and B each 4 div. trace height and A+B with 8 div. trace height.</li> <li>- Press ADD/INVERT once more for ADD and INVERT mode</li> <li>- Check if 2 square waves of 4 div. (A and B) and a line is displayed (A-B)</li> </ul>	
MEASURING RESULTS	.....	

*	SUBJECT	LCD check
TEST EQUIPMENT		-
INPUT VOLTAGE		-
SETTINGS		<ul style="list-style-type: none"> <li>- Press MENU and keep it pressed</li> <li>- Then press AUTO SET</li> <li>- Check if LCD indicates "1<sup>0</sup>", "2<sup>0</sup>", "AS" and "3<sup>0</sup>"</li> <li>- Press "S" of DTB UP-DOWN control</li> <li>- Press MENU, 8 times</li> <li>- All segments of the LCD should be ON according to figure 3.2 of the Operating Manual.</li> <li>- To leave this test: press MENU and then AUTO SET</li> </ul>
REQUIREMENTS		<ul style="list-style-type: none"> <li>- Check if all segments of the LCD are on (see figure 3.2 of the Operating manual)</li> </ul>
MEASURING RESULTS		.....

---

11.4.3 VERTICAL DEFLECTION OR Y-AXIS  
(characteristics section 2.2)

---

*	SUBJECT	Vertical Deflection
TEST EQUIPMENT		LF Square wave generator
INPUT VOLTAGE		Square wave signal 1 kHz to A
SETTINGS AND REQUIREMENTS		<ul style="list-style-type: none"> <li>- Set trace height to 5 div.</li> <li>- Check if one square wave signal of 5 div. is displayed</li> <li>- Press A/B; channel A and B on</li> <li>- Check if a square wave signal (A) and a zero trace (B) is displayed and if A and B are on.</li> <li>- Press ALT/CHOP</li> <li>- Check if ALT or CHOP is active.</li> <li>- Press TRIG VIEW.</li> <li>- Check if two square wave signals (A and TRIG VIEW) and a zero trace (B) are displayed</li> <li>- Press TRIG VIEW; Check if A and B are on.</li> </ul>
INPUT VOLTAGE		Square wave signal 1 kHz to input A and B
SETTINGS AND REQUIREMENTS		<ul style="list-style-type: none"> <li>- Press AUTO SET</li> <li>- Check if A, B and ALT are on</li> <li>- Set trace height to 4 div.</li> <li>- Press AC/DC of channel A and B for DC input coupling</li> <li>- Press ADD/INVERT twice for ADD mode.</li> <li>- Check if 3 square wave signals are displayed: channels A and B each 4 div. trace height and A+B with 8 div. trace height.</li> <li>- Press ADD/INVERT once more for ADD and INVERT mode</li> <li>- Check if 2 square waves of 4 div. (A and B) and a line is displayed (A-B)</li> </ul>
MEASURING RESULTS		.....

\* SUBJECT Vertical Deflection coefficients and input coupling of Channels A and B (characteristics section 2.2.1)

TEST EQUIPMENT Square-wave calibration generator (PG506)

INPUT VOLTAGE Square-wave signal 1 kHz to input A(B), amplitude 10 mVpp...20 Vpp in 1-2-5 steps

SETTINGS AND REQUIREMENTS

- Apply a 1 kHz square wave signal of 10 mV to input A(B)
- Set A (B) to 2 mV/div.
- Check if the amplitude of the signal is 5 div. (+or- 3%)
- Increase the input amplitude and vertical sensitivity with the following steps:

Input voltage (pp)	A (B) setting	Requirements	Measuring results
10 mV	2 mV	5 div. (+or-3%)	.....
20 mV	5 mV	4 div. (+or-3%)	.....
50 mV	10 mV	5 div. (+or-3%)	.....
0,1 V	20 mV	5 div. (+or-3%)	.....
0,2 V	50 mV	4 div. (+or-3%)	.....
0,5 V	100 mV	5 div. (+or-3%)	.....
1 V	200 mV	5 div. (+or-3%)	.....
2 V	500 mV	4 div. (+or-3%)	.....
5 V	1 V	5 div. (+or-3%)	.....
10 V	2 V	5 div. (+or-3%)	.....
20 V	5 V	4 div. (+or-3%)	.....
50 V	10 V	5 div. (+or-3%)	.....

\* SUBJECT Variable gain control range (continued procedure of previous subject)

SETTING

- Turn VAR control fully anti-clockwise

REQUIREMENTS

- Check if displayed amplitude <2 div. (1:>2,5)

MEASURING RESULTS .....

\* SUBJECT Input coupling (continued procedure of previous subject)

SETTINGS AND REQUIREMENTS

- Turn VAR control fully clockwise.
- Press "GND"; check if input signal is interrupted.
- Press "GND" again and then AC/DC
- Check if in DC position the signal shifts upwards

MEASURING RESULTS .....

\* SUBJECT Frequency response

TEST EQUIPMENT Constant amplitude sine-wave generator (SG503)

INPUT VOLTAGE Constant amplitude sine-wave signal, 120 mV frequency 50 kHz...50 MHz to input A (B).

- SETTINGS AND REQUIREMENTS**
- Set A (B) to 20 mV/div.
  - Apply 50 kHz sine-wave signal to A (B)
  - Adjust trace height to exactly 6 div.
  - Increase the frequency of the input signal up to 60 MHz.
  - Check if the vertical deflection is > 4,2 div. (-3 dB) over the complete bandwidth range (>60 MHz).
  - Reduce the amplitude of the input signal to 12 mV and the frequency to 50 kHz.
  - Set A (B) to 2 mV/div.
  - Adjust the trace height to exactly 6 div.
  - Increase the frequency up to 35 MHz.
  - Check if the vertical deflection is > 4,2 div. (-3 dB) over the complete bandwidth range (>35 MHz)

**MEASURING RESULTS** .....

- \* **SUBJECT** Rise-Time
- IMPORTANT** THE RISE TIME IS A CALCULATED VALUE, ACCORDING FORMULA: BANDWIDTH X RISE-TIME = 0,35
- TEST EQUIPMENT** Fast-rise square-wave generator (PG506)
- INPUT VOLTAGE** Fast-rise square-wave signal  $\leq$  1 ns to input A (B) frequency: 1MHz.
- SETTINGS**
- Set A(B) to 50 mV/div
  - Press TB MAGN
  - Set MAIN TB to 5 ns/div
  - Adjust the trace height exactly between the dotted lines 0% and 100% (5 div.)
- REQUIREMENTS** Important:  $T_R \text{ (measured)} =$

$$\sqrt{T_R \text{ (input signal)}^2 + T_R \text{ (oscilloscope)}^2}$$

- Check the rise-time, measured between the 10% and 90% lines (4 div.);
- \* rise-time must be: 5,8 ns or less (approx. 1,2 div. or less).

**MEASURING RESULTS** .....

*	SUBJECT	Noise
	TEST EQUIPMENT	-
	INPUT VOLTAGE	-
	SETTINGS	<ul style="list-style-type: none"> <li>- Press A/B: channel A and B on</li> <li>- Set channel A and B to 20 mV/div.</li> <li>- Press ALT/CHOP for CHOP mode</li> <li>- Press GND of both channels for grounded input coupling</li> </ul>
	REQUIREMENT	<ul style="list-style-type: none"> <li>- Check if the traces are not thicker than 0,5 subdiv.</li> </ul>
	MEASURING RESULTS	.....
*	SUBJECT	Vertical Dynamic range
	TEST EQUIPMENT	Constant amplitude sine-wave generator
	INPUT VOLTAGE	Sine-wave signal of 1 MHz, 2,4 Vpp to input A(B)
	SETTINGS	<ul style="list-style-type: none"> <li>- Apply sine-wave signal of 1 MHz, 2,4 Vpp to input A (B).</li> <li>- Set A (B) to 100 mV/div.</li> <li>- Shift with the Y POS control the sine-wave vertically over the screen.</li> </ul>
	REQUIREMENT	<ul style="list-style-type: none"> <li>- Check if the top and bottom of the sine-wave signal can be displayed distortion-free (24 div. trace height).</li> </ul>
	INPUT VOLTAGE	Sine-wave signal of 50 MHz, 1,6 Vpp to input A (B)
	SETTINGS	<ul style="list-style-type: none"> <li>- Set A (B) to 200 mV/div.</li> <li>- Set the trace height to exactly 8 div.</li> <li>- Increase the frequency of the input signal up to 50 MHz</li> </ul>
	REQUIREMENT	<ul style="list-style-type: none"> <li>- Check if a sine-wave signal of 8 div. is displayed distortion-free.</li> </ul>
	MEASURING RESULTS	.....

*	SUBJECT	Position range (vertical)
	TEST EQUIPMENT	LF Sine-wave generator
	INPUT VOLTAGE	Sine-wave signal of 1 kHz, 8 V to input A(B)
	SETTINGS	<ul style="list-style-type: none"> <li>- Set the channel A (B) input sensitivity to 1 V/div.</li> <li>- Apply a sine-wave of 1 kHz/8 div. to the channel A (B) input.</li> <li>- Set the channel A (B) input sensitivity to 500 mV/div.</li> <li>- Rotate the channel A (B) Y POS control fully clockwise and anti-clockwise</li> </ul>
	REQUIREMENT	<ul style="list-style-type: none"> <li>- Check if the top and the bottom of the signal can be positioned on the vertical centre line of the screen.</li> </ul>
	MEASURING RESULTS	.....
*	SUBJECT	Decoupling factor between channels A and B at 10 MHz
	TEST EQUIPMENT	Sine-wave calibration generator (SG503)
	INPUT VOLTAGE	Sine-wave signal 10 MHz, 4 V to input A(B)
	SETTINGS	<ul style="list-style-type: none"> <li>- Set channel A and B to 0,5 V/div.</li> <li>- Apply sine-wave input signal to input A(B)</li> <li>- Set the trace height to 8 div.</li> <li>- Press A/B (channel with input signal off).</li> </ul>
	REQUIREMENTS	<ul style="list-style-type: none"> <li>- Check if trace height of channel without input signal B(A) is &lt; 0,08 div. (1:&gt;100)</li> </ul>
	MEASURING RESULTS	.....
*	SUBJECT	Decoupling factor between channels A and B at 50 MHz
	TEST EQUIPMENT	HF sine-wave generator (SG503)
	INPUT VOLTAGE	50 MHz sine-wave signal, 4 V to input A(B)
	SETTINGS	<ul style="list-style-type: none"> <li>- Do the same settings as indicated above</li> </ul>
	REQUIREMENTS	<ul style="list-style-type: none"> <li>- Check if trace height of channel without input signal B(A) is &lt;0,16 div. (1:&gt;50)</li> </ul>
	MEASURING RESULTS	.....
*	SUBJECT	Common Mode Rejection Ratio
	TEST EQUIPMENT	HF constant Amplitude sine-wave generator (SG503)
	INPUT VOLTAGE	Sine wave signal 1 MHz, 4 Vpp to inputs A and B
	SETTINGS	<ul style="list-style-type: none"> <li>- Set A and B to 500 mV/div. (8 div.)</li> <li>- Set input coupling of channels A and B to DC</li> <li>- Press ADD/INVERT three times (ADD and INVERT on)</li> <li>- Adjust one VAR control (A or B) for minimum trace height difference of channel A and B.</li> </ul>
	REQUIREMENT	<ul style="list-style-type: none"> <li>- Check if the trace height of the A-B signal is &lt; 0,08 div.</li> </ul>
	MEASURING RESULTS	.....

*	SUBJECT	LF linearity (vertical)
	TEST EQUIPMENT	LF square-wave generator
	INPUT VOLTAGE	Square-wave signal 50 kHz, 200 mV to input A(B)
	SETTINGS	<ul style="list-style-type: none"> <li>- Set A (B) to 100 mV/div.</li> <li>- Set the square-wave signal in the vertical centre of the screen.</li> <li>- Adjust the square-wave signal to exactly 2 div. trace height.</li> <li>- Shift the signal with the Y POS control to the two upper and lower div. of the screen.</li> </ul>
	REQUIREMENT	<ul style="list-style-type: none"> <li>- Check if the trace height in the two upper and lower div. is 2 div. (max. ampl. deviation must be &lt;3%)</li> </ul>
	MEASURING RESULTS	.....
*	SUBJECT	Visual Signal Delay
	TEST EQUIPMENT	Square wave calibration generator (PG506)
	INPUT VOLTAGE	Fast-rise input signal 1 MHz, <u>&lt;1</u> ns, 0,5 V to input A
	SETTINGS	<ul style="list-style-type: none"> <li>- Apply fast-rise input signal to input A</li> <li>- Set A to 100 mV/div.</li> <li>- Set MAIN TB to 50 ns/div.</li> <li>- Press TB MAGN and turn X POS</li> <li>- Set INTENSITY fully clock-wise</li> <li>- Set trigger coupling to DC and adjust with LEVEL MTB for maximum visual signal delay.</li> </ul>
	REQUIREMENT	<ul style="list-style-type: none"> <li>- Check if visual signal delay is &gt;15 ns</li> </ul>
	MEASURING RESULTS	.....
*	SUBJECT	Base line jump
	TEST EQUIPMENT	-
	INPUT VOLTAGE	-
	SETTINGS	<u>Attenuator balance</u> <ul style="list-style-type: none"> <li>- This check must be done in the SERVICE MENU "1". To enter this menu proceed as follows:</li> <li>- Press MENU and keep it pressed and then press AUTO SET</li> <li>- Press V of channel A UP-DOWN control</li> <li>- Check LCD display: "1.0" flashing</li> <li>- The attenuator is now switched between the 1-2-5 positions</li> <li>- Check if the base line do not jump more than 1,5 subdiv.</li> </ul>
		<u>VAR balance</u>
		<ul style="list-style-type: none"> <li>- Press MENU; "1.1" flashing in LCD</li> <li>- Rotate VAR control of channel A and B</li> <li>- Check if the base lines do not jump more than 1 subdiv.</li> </ul>

X1/X10 attenuator offset

- Press MENU; "1.2" flashing in LCD
- Check if the base lines do not jump more than 1 subdiv.

NORMAL-INVERT jump

- Press MENU four times; "1.6" flashing in LCD
- Check if the displayed point does not jump more than 1 subdiv.
- Press AUTO SET two times to leave the SERVICE MENU

MEASURING RESULTS .....  


---

## 11.4.4 TRIGGER VIEW (characteristics section 2.2.2)

*	SUBJECT	Deflection coefficient via A, B and EXT.
	TEST EQUIPMENT	Square-wave calibration generator (PG506)
	INPUT SIGNAL	Square-wave signal 1 kHz, amplitude given in table.
		<u>TRIG VIEW via A(B)</u>
	SETTINGS	<ul style="list-style-type: none"> <li>- Apply the square-wave signal to input A(B)</li> <li>- Press TRIG VIEW (TRIG VIEW and A(B) on)</li> <li>- Select A(B) as MTB trigger source</li> <li>- Select DC for MTB trigger coupling</li> </ul>
	REQUIREMENT	<ul style="list-style-type: none"> <li>- Check the amplitude of the TRIG VIEW signal according the table given in section 11.4.3 of this performance check. IMPORTANT: the error limit of the amplitudes displayed via TRIG VIEW is &lt;5%!!</li> </ul>
	MEASURING RESULTS	.....
		<u>TRIG VIEW via EXT</u>
	INPUT SIGNAL	Square-wave signal 1 kHz, 500 mV to input EXT.
	SETTINGS	<ul style="list-style-type: none"> <li>- Select EXT DC as MTB trigger source.</li> </ul>
	REQUIREMENT	<ul style="list-style-type: none"> <li>- Check if the square-wave signal displayed via TRIG VIEW has an amplitude of 5 div. (+or- &lt;5%)</li> </ul>
	MEASURING RESULTS	.....
*	SUBJECT	Frequency response INT and EXT (TRIGGER VIEW)
	TEST EQUIPMENT	Constant amplitude sine-wave generator INT (via A and B)
	INPUT VOLTAGE	Constant amplitude sine-wave signal, 120 mV, freq. 50 kHz...50 MHz to input A(B)
	SETTINGS	<ul style="list-style-type: none"> <li>- Set A(B) to 20 mV/div.</li> <li>- Adjust the trace height to exactly 6 div.</li> <li>- Press TRIG VIEW (TRIG VIEW and A on)</li> </ul>

	- Select A(B) as MTB trigger source and p-p as MTB trigger coupling - Increase the frequency up to 50 MHz
REQUIREMENTS	- Check if the vertical deflection via TRIG VIEW is > 4,2 div.
MEASURING RESULTS	.....
	<u>EXT</u>
INPUT VOLTAGE	Constant amplitude sine-wave signal, 600 mV, freq. 50 kHz...50 MHz to input EXT
SETTINGS	- Select EXT DC as MTB trigger source - Adjust the trace height to exactly 6 div. - Increase the frequency up to 50 MHz.
REQUIREMENT	- Check if the vertical deflection via TRIG VIEW is > 4,2 div.
MEASURING RESULTS	.....
*	SUBJECT Lower -3dB point of trigger view
TEST EQUIPMENT	LF sine-wave generator
INPUT VOLTAGE	Sine-wave signal of 10 Hz, 600 mV to input EXT
SETTINGS	- Select EXT AC as MTB trigger source - Select TRIG VIEW as vertical display mode (TRIG VIEW) - Apply a 10 Hz, 600 mV sine-wave signal to input EXT - Set trigger coupling to DC
REQUIREMENTS	- Check if the vertical deflection via trig. view > 4,2 div.
MEASURING RESULTS	.....
*	SUBJECT Line jump trigger source
TEST EQUIPMENT	-
INPUT VOLTAGE	-
SETTINGS	- Press TRIG VIEW (TRIG VIEW and A on) - Press TRIG or X SOURCE four times
REQUIREMENTS	- Check if A, A and B, B, EXT DC and LINE are displayed in sequence via trigger view and if the jump between base line and the start of the LINE signal is < 2 subdiv.
MEASURING RESULTS	.....

*	SUBJECT	OFFSET of trigger point
	TEST EQUIPMENT	-
	INPUT VOLTAGE	-
	SETTINGS AND REQUIREMENT	<ul style="list-style-type: none"> <li>- This check must be done in the SERVICE MENU "1<sup>0</sup>" To enter this menu proceed as follows:</li> <li>- Press MENU and keep it pressed and then press AUTO SET</li> <li>- Press V of channel A UP-DOWN control</li> <li>- Press MENU three times; "1.3" in LCD flashing</li> <li>- Turn Y POS of channel B and set the point in vertical centre of the screen.</li> <li>- Check if the displayed point does not jump more than 1,5 subdiv horizontally</li> <li>- Press MENU; "1.4" in LCD flashing</li> <li>- Turn Y POS of A and set point in the vertical centre</li> <li>- Check if the displayed point does not jump more than 1,5 subdiv. horizontally</li> <li>- Press MENU; "1.5" in LCD flashing</li> <li>- Turn Y POS of B and set point in vertical centre</li> <li>- Check if the displayed point does not jump more than 1,5 subdiv.</li> <li>- Press AUTO SET two times to leave the SERVICE MENU</li> </ul>
	MEASURING RESULTS	.....
*	SUBJECT	Delay Difference between input A (B) and ext.TRIG VIEW
	TEST EQUIPMENT	Square wave calibration generator. (PG506)- 50 ohm T piece PM9584 and 50 ohm terminator (for EXT)
	INPUT VOLTAGE	Fast-rise input signal 1MHz, 0,5V, <1ns via 50 ohm T piece to input A/B and EXT input via 50 ohm terminator
	SETTINGS	<ul style="list-style-type: none"> <li>- Apply fast-rise input signal to input A and EXT</li> <li>- Press AUTO SET and TRIG VIEW</li> <li>- Press TRIG or X SOURCE for EXT DC triggering</li> <li>- Set of A to 100 mV</li> <li>- Set input coupling A to DC</li> <li>- Press TB MAGN</li> <li>- Set INTENSITY fully clock-wise</li> <li>- Adjust LEVEL MTB so that both signals covers each other</li> <li>- Set MAIN TB to 5ns</li> </ul>
	REQUIREMENTS	<ul style="list-style-type: none"> <li>- Check if delay difference between the two displayed signal slopes is &lt;10 ns (&lt;2 div.)</li> </ul>
	MEASURING RESULTS	.....
*	SUBJECT	Dynamic Range (EXT input via trigger view)
	TEST EQUIPMENT	Constant amplitude sine-wave generator
	INPUT VOLTAGE	Sine-wave signal of 1 MHz, 2,4 Vpp to input EXT
	SETTINGS	<ul style="list-style-type: none"> <li>- Press TRIG VIEW (TRIG VIEW and A on)</li> <li>- Select EXT AC as MTB trigger source</li> <li>- Apply sine-wave signal 1 MHz, 2,4 V to input EXT</li> </ul>

REQUIREMENT	<ul style="list-style-type: none"> <li>- Shift with the MTB LEVEL control the sine-wave signal displayed via TRIG VIEW vertically over the screen.</li> </ul>
MEASURING RESULTS	.....
INPUT VOLTAGE	Sine-wave signal of 50 MHz, 600 mVpp to input EXT
SETTINGS	<ul style="list-style-type: none"> <li>- Press TRIG VIEW on</li> <li>- Select EXT AC as MTB trigger source</li> <li>- Apply a sine-wave signal of 50 MHz, 600 mV to input EXT.</li> </ul>
REQUIREMENT	<ul style="list-style-type: none"> <li>- Check if a sine-wave signal of 6 div. is displayed distortion-free</li> </ul>
MEASURING RESULTS	.....
11.4.5	HORIZONTAL DEFLECTION OR X-AXIS (characteristics section 2.3)
* SUBJECT	Horizontal Display modes and trace separation
TEST EQUIPMENT	LF sine-wave generator
INPUT VOLTAGE	Sine wave signal 2 kHz, 3 div. trace height to input A
SETTINGS AND REQUIREMENTS	<ul style="list-style-type: none"> <li>- Press AUTO SET</li> <li>- Set the trace height to 3 div. (MTB trace)</li> <li>- Set the MAIN TB to 0,5 ms/div.</li> <li>- Press TB SELECT</li> <li>- Set the DEL TB to 50 us/div.</li> <li>- Check if intensified part (DTB) is visible and if it can be shifted horizontally by the DTM control</li> <li>- Press TB SELECT</li> <li>- Check if DTB and MTB INTENS are on</li> <li>- Set the MTBI trace on the upper 3 div.</li> <li>- Turn TRACE SEP fully counter clockwise</li> <li>- Check if the bottom/half of the DTB signal can be &gt; 4 div. shifted from the 100% graticule line</li> <li>- Set the MTBI trace on the lower 3 div.</li> <li>- Turn TRACE SEP fully clockwise</li> <li>- Check if the top half of the DTB signal can be &gt; 4 div shifted from the 0% graticule line</li> <li>- Press TB SELECT</li> <li>- Check if only the DTB trace is displayed</li> <li>- Press TB SELECT</li> <li>- Check if only the MTB trace is displayed</li> <li>- Press X DEFL</li> <li>- Check if only X DEFL is on</li> <li>- Select A of MTB trigger source</li> <li>- Check if a line under an angle of 45° is displayed.</li> </ul>
MEASURING RESULTS	.....

\* SUBJECT Deflection coefficient (MTB)  
 TEST EQUIPMENT Time marker generator (TG501)  
 INPUT VOLTAGE Time marker signal 50 ns...0,5 s  
 SETTINGS - Apply a time marker signal of 50 ns to input A  
 - Press AUTO SET  
 REQUIREMENT - Check the deflection coefficients in TB X1 and TB X10 according the table below:

Time marker pulse	MAIN TB setting .../div	Max. coeff. error		Measuring results
		MTB X1	MTB X10	
50 ns	50 ns	3%	4%	.....
0,1 us	0,1 us	3%	4%	.....
0,2 us	0,2 us	3%	4%	.....
0,5 us	0,5 us	3%	4%	.....
1 us	1 us	3%	4%	.....
2 us	2 us	3%	4%	.....
5 us	5 us	3%	4%	.....
10 us	10 us	3%	4%	.....
20 us	20 us	3%	4%	.....
50 us	50 us	3%	4%	.....
0,1 ms	0,1 ms	3%	4%	.....
0,2 ms	0,2 ms	3%	4%	.....
0,5 ms	0,5 ms	3%	4%	.....
1 ms	1 ms	3%	4%	.....
2 ms	2 ms	3%	4%	.....
5 ms	5 ms	3%	4%	.....
10 ms	10 ms	3%	4%	.....
20 ms	20 ms	3%	4%	.....
50 ms	50 ms	3%	4%	.....
0,1 s	0,1 s	3%	4%	.....
0,2 s	0,2 s	3%	4%	.....
0,5 s	0,5 s	3%	4%	.....

\* SUBJECT Horizontal position range  
 TEST EQUIPMENT Time marker generator (TG501)  
 INPUT VOLTAGE Time marker signal of 1 ms to input A  
 SETTINGS AND - Set MAIN TB to 0,1 ms/div.  
 REQUIREMENTS - Set a marker pulse on the first and last vertical graticule line  
 - Set X POS fully clockwise.  
 - Check if the first marker pulse is at the right side of the vertical centre line  
 - Set X POS fully anti-clockwise  
 - Check if the last marker pulse is at the left side of the vertical centre line.

MEASURING RESULTS .....


\* SUBJECT Variable control ratio (VAR MTB) and TB Magnifier balance  
 TEST EQUIPMENT Time marker generator (TG501)  
 INPUT VOLTAGE Time marker signal 1 us to input A

- SETTINGS                    - Set MAIN TB to 0,2 us/div; marker on first and sixth graticule line  
                           - Set the MTB VAR fully anti-clockwise
- REQUIREMENT                - Check if the VAR control range overlaps the time base steps 0,2 us to 0,5 us; first marker on first graticule line and second marker on the third graticule line or closer to the first marker (2,5:1)
- SETTINGS                    - Set the MTB VAR control fully clockwise  
                           - Press TB MAGN (on)  
                           - Set the top of the second marker pulse exactly in the vertical centre of the graticule  
                           - Press TB MAGN (off)
- REQUIREMENT                - Check if the top of the second marker pulse is not shifted more than 2,5 subdiv.
- MEASURING RESULTS        .....
- \* SUBJECT                  Deflection Coefficients (DTB)  
 TEST EQUIPMENT           Time marker generator (TG501)  
 INPUT VOLTAGE            Time marker signal 1 ms...50 ns to input A  
 SETTINGS                  - Press AUTO SET  
                           - Press TB SELECT; MTBI and DTB on  
                           - Set MAIN TB to 2 ms/div.  
                           - Set DEL'D TB to 1 ms/div.  
                           - Press DTB TRIG for STARTS mode  
                           - Set the delay time to 5.000 ms by means of the DTM control.
- REQUIREMENTS              - Check the deflection coefficients in TB x 1 and TB x 10 according the table below:  
 ATTENTION: To check the DTB time coefficients according the table below the uS of UP-DOWN MTB control must be operated (DTB setting is electrically coupled with MTB setting)

MAIN TB setting	Time marker pulse	DEL'D TB setting .../div.	Max.coeff.error		Measuring results
			MTB X1	MTB X10	
2 ms	1 ms	1 ms	3%	4%	.....
1 ms	0,5 ms	0,5 ms	3%	4%	.....
0,5 ms	0,2 ms	0,2 ms	3%	4%	.....
0,2 ms	0,1 ms	0,1 ms	3%	4%	.....
0,1 ms	50 us	50 us	3%	4%	.....
50 us	20 us	20 us	3%	4%	.....
20 us	10 us	10 us	3%	4%	.....
10 us	5 us	5 us	3%	4%	.....
5 us	2 us	2 us	3%	4%	.....
2 us	1 us	1 us	3%	4%	.....
1 us	0,5 us	0,5 us	3%	4%	.....
0,5 us	0,2 us	0,2 us	3%	4%	.....
0,2 us	0,1 us	0,1 us	3%	4%	.....
0,1 us	50 ns	50 ns	3%	4%	.....

*	SUBJECT	Delay Time Multiplier
	TEST EQUIPMENT	Time marker generator (TG501)
	INPUT VOLTAGE	Time marker signal 10 us to input A
	SETTINGS AND REQUIREMENTS	<ul style="list-style-type: none"> <li>- Press TB SELECT; MTB INTENS and DTB on</li> <li>- Set MAIN TB to 5 us/div</li> <li>- Set DEL'D TB to 0,5 us/div.</li> <li>- Press DTM &lt;-- (delay time: 0)</li> <li>- Check if the first marker pulse displayed via the DTB is partly visible;</li> <li>- Set the first marker displayed via the MTB exactly on the first graticule line</li> <li>- Press DTM --&gt; so that the last marker pulse displayed via the DTB is completely visible on the first vertical graticule line.</li> <li>- Check if the Delay Time displayed in the LCD is &gt;48 us.</li> </ul>
	MEASURING RESULTS	.....
*	SUBJECT	Maximum Jitter (DTB)
	TEST EQUIPMENT	Sine-wave generator
	INPUT SIGNAL	Sine-wave signal (1 MHz), 6 div. trace height to input A.
	SETTINGS	<ul style="list-style-type: none"> <li>- Set the trace height to 6 div.</li> <li>- Set MAIN TB to 1 ms</li> <li>- Press TB SELECT; MTBI and DTB on</li> <li>- Set DEL'D TB to 0,5 us</li> <li>- Set the DELAY time to 5 ms</li> <li>- Press TB SELECT; only DTB on</li> </ul>
	REQUIREMENT	<ul style="list-style-type: none"> <li>- Check if the jitter of the DTB trace is <u>&lt;=</u> 1 div (1 part per 20.000)</li> </ul>
	MEASURING RESULTS	.....
*	SUBJECT	Horizontal Deflection coefficients
	TEST EQUIPMENT	Sine wave generator
	INPUT VOLTAGE	Sine wave signal 2 kHz, 4 div. trace height to input A
	SETTINGS	<ul style="list-style-type: none"> <li>- Press EXT X DEFL</li> <li>- Press A/B twice for only ch. B display</li> <li>- Select A as X DEFL source with TRIG or X SOURCE</li> </ul>
	REQUIREMENT	<ul style="list-style-type: none"> <li>- Check if a horizontal line of 4 div. is displayed (+or- 5%).</li> </ul>
	INPUT VOLTAGE	- Sine wave signal 2 kHz, 1 V to input EXT
	SETTINGS AND REQUIREMENTS	<ul style="list-style-type: none"> <li>- Select EXT with TRIG or X SOURCE</li> <li>- Press X DEFL</li> <li>- Check if a horizontal line of 10 div. (+or- 5%) is displayed.</li> <li>- Select LINE with TRIG or X SOURCE</li> <li>- Check if a horizontal line is displayed of approx 6 div. (at 220 V mains voltage)</li> </ul>
	MEASURING RESULTS	.....

*	SUBJECT	Frequency response (horizontal)
	TEST EQUIPMENT	Constant amplitude sine-wave generator (PG506)
	INPUT VOLTAGE	Constant amplitude sine-wave signal, 30 mV, 50 kHz...2 MHz to input A
	SETTINGS	<ul style="list-style-type: none"> <li>- Set A to 5 mV/div</li> <li>- Apply a 50 kHz sine-wave signal to input A</li> <li>- Set input coupling A to DC</li> <li>- Press X DEFL</li> <li>- Select A as horizontal deflection source with TRIG or X SOURCE</li> <li>- Press A/B twice for ch. B as vertical deflection</li> <li>- Adjust the input voltage for exactly 6 div.</li> <li>- Increase the frequency of the input signal up to 2 MHz</li> </ul>
	REQUIREMENTS	<ul style="list-style-type: none"> <li>- Check if the trace width is &gt; 4,2 div. (-3 dB) over the complete bandwidth range.</li> </ul>
	MEASURING RESULTS	.....
	TEST EQUIPMENT	LF Sine-wave generator
	INPUT VOLTAGE	Sine-wave signal, 10 Hz, 6 div. trace height to input A
	SETTINGS	<ul style="list-style-type: none"> <li>- Set the vertical deflection of A to exactly 6 div</li> <li>- Select X DEFL and A as X DEFL source</li> <li>- Set input coupling A to AC</li> <li>- Press A/B twice for ch. B as vertical deflection</li> </ul>
	REQUIREMENT	<ul style="list-style-type: none"> <li>- Trace width is &gt; 4,2 div (-3 dB)</li> </ul>
	MEASURING RESULTS	.....
*	SUBJECT	Maximum phase shift between horizontal and vertical deflection.
	TEST EQUIPMENT	LF sine-wave generator
	INPUT VOLTAGE	Sine wave signal, 2 kHz...100 kHz, trace height 6 div.
	SETTINGS	<ul style="list-style-type: none"> <li>- Press X DEFL</li> <li>- Select A for horizontal deflection with TRIG or X SOURCE</li> <li>- Set the trace height to exactly 6 div.</li> <li>- Increase the input frequency up to 100 kHz.</li> </ul>
	REQUIREMENT	<ul style="list-style-type: none"> <li>- Check if the phase shift &lt; 3° (see fig. below)</li> </ul>
	MEASURING RESULTS	.....



MEASURING RESULTS .....

---

11.4.6	MTB TRIGGERING (characteristics, section 2.4.1)	
*	SUBJECT	MTB Trigger Sources and trigger coupling
	TEST EQUIPMENT	Square-wave generator
	INPUT VOLTAGE	Square-wave signal 2 kHz, 4 div. trace height to input A (EXT)
	SETTINGS AND REQUIREMENTS	<ul style="list-style-type: none"> <li>- Set the trace height to 4 div.</li> <li>- Press TRIG VIEW (A and TRIG VIEW on)</li> <li>- Press TRIG COUPL and select DC</li> <li>- Adjust LEVEL MTB for a triggered signal</li> <li>- Check if two square wave signals are displayed of 4 div. (Trigger view and A)</li> <li>- Press TRIG COUPL and select p-p</li> <li>- Turn LEVEL MTB and check if the signal is triggered over the complete level range.</li> <li>- Connect CAL signal to input B</li> <li>- Press A/B so that A, B and TRIG VIEW are on</li> <li>- Set B to 200 mV.</li> <li>- Select B as MTB trigger source with TRIG or X SOURCE (A is not triggered)</li> <li>- Check if a square wave of 6 div. is displayed</li> <li>- Increase the freq. of the square-wave signal to input A up to 20 kHz (CAL signal to B)</li> <li>- Press TRIG or X SOURCE four times (A and B selected.)</li> <li>- Check if three well triggered traces are displayed; TRIG VIEW signal derived from A.</li> <li>- Remove input signals</li> <li>- Apply a square wave signal of 500 mV to input EXT</li> <li>- Select EXT as MTB trigger source with TRIG or X SOURCE</li> <li>- Check if a square wave signal is displayed via TRIG VIEW of 5 div.</li> <li>- Select LINE as MTB trigger source with TRIG or X SOURCE</li> <li>- Set MAIN TB to 5 ms/div</li> <li>- Check if a sine-wave signal (mains frequency) is displayed.</li> </ul>
	MEASURING RESULTS	.....
*	SUBJECT	MTB Slope selection and Level control range.
	TEST EQUIPMENT	LF Sine-wave generator
	INPUT VOLTAGE	Sine-wave signal 2 kHz - 800 mV to input A(B) (EXT)
	SETTINGS AND REQUIREMENTS	<ul style="list-style-type: none"> <li>- Set A(B) to 0,1 V/div (DC input coupling)</li> <li>- Press TRIG COUPL for p-p triggering</li> <li>- Turn LEVEL MTB fully clockwise and fully anti-clockwise</li> <li>- Check if the signal is well triggered over the complete LEVEL range</li> <li>- Set the LEVEL MTB control in its mid-position</li> <li>- Start of signal display must be in the vertical centre</li> <li>- Press TB TRIG (TRIG mode)</li> </ul>

---

- Press SLOPE MTB
- Check if the sine-wave signal is inverted and is triggered on the negative slope.
- Press SLOPE MTB once again
- Press TRIG COUPL for DC coupling
- Set A(B) to 50 mV/div (16 div. trace height)
- Turn the LEVEL MTB
- Check if the LEVEL range is > +or- 8 div. and if the signal is triggered on the positive slope.
- Remove input signal
- Apply the sine-wave signal of 2 kHz, 1,6 Vpp to EXT
- Select EXT (MTB trigger source)
- Press TRIG VIEW. (TRIG VIEW and A(B) on)
- Turn the LEVEL MTB
- Check if the LEVEL range is > +or- 0,8 V (+or- 8 div.)

MEASURING RESULTS .....  
.....

*	SUBJECT	Trigger Sensitivity (MTB)
	TEST EQUIPMENT	Sine-wave generator (SG503)
	INPUT VOLTAGE	Sine-wave signal 10 MHz-(50 MHz)-(100 MHz) to input A (B) (EXT)
	SETTINGS AND REQUIREMENTS	<ul style="list-style-type: none"> <li>- Press AC/DC (input coupling of A(B) to DC)</li> <li>- Press TB TRIG MODE for TRIG mode</li> <li>- Press TRIG COUPL for DC trigger coupling</li> <li>- Apply a sine-wave signal of 10 MHz approx. 250 mVpp to input A(B)</li> <li>- Set A(B) to 0,2 V/div.</li> <li>- Decrease amplitude of input signal</li> <li>- Turn LEVEL MTB</li> <li>- Check if the signal is well-triggered at amplitudes &gt; 0,5 div.</li> <li>- Decrease the frequency of the input signal to 50 kHz</li> <li>- Check if the signal stays well triggered at amplitudes &gt; 0,5 div.</li> <li>- Increase the frequency of the input signal up to 50 MHz.</li> <li>- Increase amplitude of input signal to approx 1 div.</li> <li>- Turn LEVEL MTB</li> <li>- Check if the signal is well-triggered at amplitudes &gt; 1 div.</li> <li>- Increase the frequency of the input signal up to 100 MHz</li> <li>- Increase amplitude to approx 3 div.</li> <li>- Check if the signal is well-triggered at amplitudes &gt; 3 div.</li> <li>- Remove input signal</li> <li>- Apply a sine wave signal of 100 MHz, 500 mVpp to input EXT (via external 50 Ohm terminator)</li> <li>- Select EXT (MTB trigger source) with TRIG or X SOURCE</li> <li>- Press TRIG VIEW, (TRIG VIEW and A(B) on).</li> <li>- Turn LEVEL MTB</li> </ul>

- Check if a well triggered sine-wave of 5 div. (500 mV) is displayed (adjust LEVEL MTB).
- Decrease the frequency of the input signal to 50 MHz and the amplitude to 150 mV
- Check if the signal is well triggered (adjust LEVEL MTB)
- Decrease the frequency of the input signal to 10 MHz or lower
- Decrease the amplitude to 50 mV
- Check if the signal is well-triggered (adjust LEVEL MTB).

MEASURING RESULTS	.....
*	SUBJECT
TEST EQUIPMENT	Trigger sensitivity TVL-TVF
INPUT VOLTAGE	TV pattern generator with video output (PM5518)
SETTINGS	Video signal to input A (B)
REQUIREMENTS	<ul style="list-style-type: none"> <li>- Press TB TRIG mode for TRIG mode</li> <li>- Press AC/DC for DC input coupling</li> <li>- Apply a video signal to input A(B) with an amplitude of 0,7 div. sync. pulse amplitude</li> <li>- Press TRIG COUPL for TVL and TVF</li> <li>- Check for a stable triggering on TVL and TVF at sync. amplitudes of &gt;0,7 div.</li> </ul>
MEASURING RESULTS	.....

11.4.7	DTB TRIGGERING (characteristics, section 2.4.2)
*	SUBJECT
TEST EQUIPMENT	DTB Trigger sources and trigger coupling
INPUT VOLTAGE	Square-wave generator
SETTINGS AND	Square-wave signal 1 kHz, 4 div. trace height to input A(B) (EXT)
REQUIREMENTS	<ul style="list-style-type: none"> <li>- Set A(B) to 0,2V/div.</li> <li>- Press TB SELECT to select MTBI</li> <li>- Press DTB TRIG to select STARTS mode</li> <li>- Set MTB to 0,5 ms/div</li> <li>- Set DTB to 50 us/div</li> <li>- Set the delay to 2 ms with the DTM control</li> <li>- Turn LEVEL DTB</li> <li>- Check if the intensified part stays triggered and starts on the fifth vertical line</li> <li>- Press DTB to select A(B)</li> <li>- Check if the delay time is given in div. (4 div)</li> <li>- Turn LEVEL DTB</li> <li>- Check that in the extreme positions of the LEVEL control the DTB is not triggered.</li> <li>- Press TRIG DTB; check if A and B in composite are selected (DTB stays triggered)</li> <li>- Press TRIG DTB; check if B is selected as trigger source (DTB not triggered)</li> <li>- Press TRIG DTB; check if DTB is triggered via EXT (input signal also to input EXT)</li> <li>- Press TRIG DTB 3 times; check if A is selected</li> </ul>
MEASURING RESULTS	.....

*	SUBJECT	DTB Trigger Sensitivity
	TEST EQUIPMENT	Sine-wave generator (SG503)
	INPUT VOLTAGE	Sine-wave signal 10 MHz (50 MHz) (100 MHz) to input A(B) (EXT)
	SETTINGS AND REQUIREMENTS	<ul style="list-style-type: none"> <li>- Press TB SELECT; select MTBI</li> <li>- Press DTB TRIG; select A(B) as trigger source</li> <li>- Set MAIN B to 0,5 us/div</li> <li>- Set DEL'D TB to 50 ns/div</li> <li>- Turn LEVEL DTB to get a well triggered intensified part</li> <li>- Check the DTB trigger sensitivity according the procedure given in section 6.3 <ul style="list-style-type: none"> <li>* The EXT trigger sensitivity must be checked via channel A (input signal to EXT and A)</li> <li>* Read DTB instead of MTB</li> </ul> </li> </ul>
	MEASURING RESULTS	.....
*	SUBJECT	DTB Slope selection and Level control range
	TEST EQUIPMENT	LF Sine-wave generator
	INPUT VOLTAGE	Sine-wave signal 2 kHz - 800 mVpp to input A(B) (EXT)
	SETTINGS AND REQUIREMENTS	<ul style="list-style-type: none"> <li>- Set A(B) to 0,1 mV/div (8 div)</li> <li>- Select MTBI with TB SELECT</li> <li>- Set MAIN TB to 0,2 ms /div and DEL'D TB to 5 us/div.</li> <li>- Press DTB TRIG: source A(B)</li> <li>- Turn LEVEL DTB for a well triggered intensified part.</li> <li>- Press SLOPE DTB</li> <li>- Check if the intensified part is on the negative slope.</li> <li>- Press SLOPE DTB (positive triggering)</li> <li>- Set DEL'D TB to 0,1 ms/div.</li> <li>- Set A(B) to 50 mV/div.</li> <li>- Turn LEVEL DTB</li> <li>- Check if the LEVEL DTB range is &gt; +or- 8 div.</li> </ul>
	MEASURING RESULTS	.....

---

11.4.8	AUXILIARY INPUTS AND OUTPUTS
*	SUBJECT Z-MOD Sensitivity
TEST EQUIPMENT	Square-wave generator
INPUT VOLTAGE	Square-wave signal, 1 kHz, duty cycle 50%, amplitude 0...2,5 Vpp to input A and Z-in (rear side)
SETTINGS AND REQUIREMENTS	<ul style="list-style-type: none"> <li>- Set MAIN TB to 0,5 ms/div.</li> <li>- Set the trace of A in mid-position</li> <li>- Select DC for channel A Input coupling</li> <li>- Apply square-wave signal of 2,5 Vpp, 1 kHz to input A and Z-in. (base line 0 V)</li> <li>- Check if only the bottom half of the square wave signal is displayed (500 us blanking and 500 us unblanking)</li> <li>- Decrease the amplitude of the input signal to 1 Vpp.</li> <li>- Set A to 0,5 V/div.</li> <li>- Check if the top half of the square-wave signal is visible with a lower intensity and will be completely unblanked at an input voltage of &lt; 0,8 V</li> </ul>
MEASURING RESULTS	.....
*	SUBJECT CAL Frequency and output voltage
TEST EQUIPMENT	-
INPUT VOLTAGE	CAL output signal to input A
SETTINGS	<ul style="list-style-type: none"> <li>- Press GND of channel A</li> <li>- Set the trace in the centre of the screen</li> <li>- Press GND of channel A</li> <li>- Select DC of A input coupling</li> </ul>
REQUIREMENTS	<ul style="list-style-type: none"> <li>- Check if a positive going square wave signal is displayed of 1,2Vpp, frequency 2 kHz</li> </ul>
MEASURING RESULTS	.....

---

## 12. DISMANTLING THE INSTRUMENT

### 12.1 GENERAL INFORMATION

This section provides the dismantling procedures required for the removal of components during repair operations.

All circuit boards removed from the instrument must be adequately protected against damage, and all normal precautions regarding the use of tools must be observed.

During the dismantling a careful note must be made of all disconnected leads so that they can be reconnected to their correct terminals during assembly.

**CAUTION:** Damage may result if:

- The instrument is switched-on when a circuit board has been removed.
- a circuit board is removed within one minute after switching-off the instrument.

### 12.2 REMOVING THE TOP AND BOTTOM COVERS

The instrument is protected by two covers: a top cover and a bottom cover. To remove these covers, proceed as follows:

- Slacken the two screws that secure both covers, located at the rear of the instrument.
- Gently push each cover backwards until it can be lifted.
- The covers can be removed by lifting them clear of the instrument.

### 12.3 ACCESS TO PARTS FOR THE CHECKING AND ADJUSTING PROCEDURES

After removing both covers (section 12.2) almost all adjustment and measuring points are accessible. However, for access to the adjusting elements of the time-base unit and the pre-amplifier unit first loosen the upper time-base unit and vertically fix this unit in the available p.c.b. guide fixing.

If necessary, the power supply unit can be lifted out of the instrument. To do so, proceed as follows:

- Push both parts at the back of the extension shaft towards each other so that the extension shaft can easily be loosened from the ON/OFF switch on the power supply unit.
- Remove the complete extension shaft.
- Push both lips that secure the power supply unit sideways and gently lift this unit out of the instrument.
- Fix the power supply unit in the available p.c.b. guide fixing.




Figure 12.1 Access to all parts for checking and adjusting

NOTE: For checking and adjusting the instrument it is not necessary to remove the bottom cover.

## 13. CHECKING AND ADJUSTING

### 13.1 GENERAL INFORMATION

The following information provides the complete checking and adjusting procedure for the instrument. As various control functions are interdependent, a certain order of adjustment is necessary.

The procedure is, therefore, presented in a sequence which is best suited to this order, cross-reference being made to any circuit which may affect a particular adjustment.

Before any check or adjustment, the instrument must attain its normal operating temperature.

- Warming-up time under average conditions is 30 minutes.
- Where possible, instrument performance should be checked before any adjustment is made.
- All limits and tolerances given in this section are calibration guides, and should not be interpreted as instrument specifications unless they are also published in section 2.
- Tolerances given are for the instrument under test and do not include test equipment error.
- The most accurate display adjustments are made with a stable, well-focused low intensity display.
- All controls that are mentioned without item numbers are located on the outside of the instrument.

**WARNING:** The opening of covers or removal of parts, except those to which access can be gained by hand, is likely to expose live parts, and also accessible terminals may be live.

The instrument shall be disconnected from all voltage sources before any adjustment, replacement or maintenance and repair during which the instrument will be opened.

If afterwards any adjustment, maintenance or repair of the opened instrument under voltage is inevitable, it shall be carried out only by qualified person who is aware of the hazard involved.

Bear in mind that capacitors inside the instrument may still be charged even if the instrument has been separated from all voltage sources.





Figure 13.1 Adjusting elements



## 13.2 RECOMMENDED TEST AND CALIBRATION EQUIPMENT

Type of instrument	Required specification	Example of recommended instrument
Function generator	Freq.: 1 MHz ... 10 MHz Sine-wave/Square-wave Ampl. 0...20 Vpp DC offset 0...+5 V Rise-time <30 ns Duty cycle 50 %	Philips PM5134
Constant amplitude sine-wave generator	Freq.: 100 kHz ... 50 MHz Constant ampl. of 120 mVpp and 3 Vpp	Tektronix SG 503
Square-wave calibration generator	For ampl. calibration: Freq.: 1 kHz Ampl.: 10 mV ... 50 V For rise-time measurements: Freq.: 1 MHz Ampl.: 10 mV ... 500 mV Rise-time: <u>&lt;1</u> ns	Tektronix PG 506
Time-marker generator	Repetition rate: 0,5 s ... 0,05 /us	Tektronix TG 501
Digital multimeter	Wide voltage, current and resistance ranges. Required accuracy 0,1 %	Philips PM2524 and high-voltage probe PM9246
Oscilloscope	The bandwidth must be the same or higher than the bandwidth of the instrument under test.	Philips PM3055
Variable mains transformer	Well-insulated output voltage 90...264 Vac	Philips ord.number 2422 529 00005
Moving-iron meter		
Dummy probe 2:1	1 Megohm <u>±0,1</u> %//20 pF	
Cables, T-piece, terminations for the generators	General Radio types for fast rise-time square-wave and high freq. sine-wave. BNC-types for other applications	
Trimming tool		Philips 800NTX kit (ord. number 4822 310 50015)

## 13.2 RECOMMENDED TEST AND CALIBRATION EQUIPMENT

Type of instrument	Required specification	Example of recommended instrument
Function generator	Freq.: 1 MHz ... 10 MHz Sine-wave/Square-wave Ampl. 0...20 Vpp DC offset 0...+5 V Rise-time <30 ns Duty cycle 50 %	Philips PM5134
Constant amplitude sine-wave generator	Freq.: 100 kHz ... 50 MHz Constant ampl. of 120 mVpp and 3 Vpp	Tektronix SG 503
Square-wave calibration generator	For ampl. calibration: Freq.: 1 kHz Ampl.: 10 mV ... 50 V For rise-time measurements: Freq.: 1 MHz Ampl.: 10 mV ... 500 mV Rise-time: <u>&lt;1</u> ns	Tektronix PG 506
Time-marker generator	Repetition rate: 0,5 s ... 0,05 /us	Tektronix TG 501
Digital multimeter	Wide voltage, current and resistance ranges. Required accuracy 0,1 %	Philips PM2524 and high-voltage probe PM9246
Oscilloscope	The bandwidth must be the same or higher than the bandwidth of the instrument under test.	Philips PM3055
Variable mains transformer	Well-insulated output voltage 90...264 Vac	Philips ord.number 2422 529 00005
Moving-iron meter		
Dummy probe 2:1	1 Megohm <u>±</u> 0,1 %//20 pF	
Cables, T-piece, terminations for the generators	General Radio types for fast rise-time square-wave and high freq. sine-wave. BNC-types for other applications	
Trimming tool		Philips 800NTX kit (ord. number 4822 310 50015)

## 13.3 SURVEY OF ADJUSTING ELEMENTS

ADJUSTING ELEMENT	ADJUSTMENT	INPUT SIGNAL	SECTION
R6406	supply voltage +10 VREF	-	13.4.2
R3252	black level	-	13.4.3
R3267	astigmatism	Sine-wave 120 mV-1 kHz	13.4.3
R4616	intens ratio	-	13.4.3
C1033	l.f.square wave response ch.A at 20 mV	square-wave 120 mV - 1 kHz	13.4.4
C1029	l.f.square wave response ch.A at 0,2 V	square-wave 1,2 V - 1 kHz	13.4.4
C1023	l.f. square wave response ch.A at 2 V	square-wave 12 V - 1 kHz	13.4.4
C1133	l.f. square wave response ch.B at 20 mV	square-wave 120 mV - 1 kHz	13.4.4
C1129	l.f. square wave response ch.B at 0,2 V	square-wave 1,2 V - 1 kHz	13.4.4
C1123	l.f. square wave response ch.B at 2 V	square-wave 12 V - 1 kHz	13.4.4
C1206	l.f. square wave response EXT	square-wave 600 mV - 1 kHz	13.4.4
R2410	trig.view sensitivity	square wave 100 mV - 1 kHz	13.4.5
R3038	vertical sensitivity	square-wave 600 mV - 1 kHz	13.4.5
R1069	gain xl ch.A	square-wave 100 mV - 1 kHz	13.4.5
R1169	gain xl ch.B	square-wave 100 mV - 1 kHz	13.4.5
R1076	gain x10 ch.A	square-wave 10 mV - 1 kHz	13.4.5
R1176	gain x10 ch.B	square-wave 10 mV - 1 kHz	13.4.5
R3118	horizontal sensitivity	square-wave 100 mV - 1 kHz	13.4.6

ADJUSTING ELEMENT	ADJUSTMENT	INPUT SIGNAL	SECTION
R1036-R1136	offset ch.A (ch.B)	-	13.4.7
R1064-R1164	offset x1 ch.A (ch.B)	-	13.4.7
R1072-R1172	offset x10 ch.A (ch.B)	-	13.4.7
R2330	horizontal balance	-	13.4.7
R1091	trigger balance ch.A	-	13.4.7
R1191	trigger balance ch.B	-	13.4.7
R1217	trigger balance EXT	-	13.4.7
R2212	norm/invert balance	-	13.4.7
R2407	trig view balance	-	13.4.7
R3007	vertical balance	-	13.4.7
R4009	sensitivity MTB	Sine-wave 80 mV - 10 kHz	13.4.8
R4108	MTB gain 1 ms	time marker 1 ms	13.4.9
R4107	MTB gain 1 us	time marker 1 us	13.4.9
R4207	DTB gain 1 ms	time marker 1 ms	13.4.10
R4208	DTB gain 1 us	time marker 1 us	13.4.10
R4721	gain x10 MAGN	time marker 100 us	13.4.11
R4406-R4408	offset-gain DTM	-	13.4.12
R3017	h.f. square-wave response	square-wave 120 mV - 1 MHz rise-time <u>&lt;1 ns</u>	13.4.13
R3013			13.4.13
C3007			13.4.13
C3004			13.4.13
C3005			13.4.13
C3036			13.4.13
C3016			13.4.13

## 13.4 CHECKING AND ADJUSTING PROCEDURE

The adjusting elements and measuring points are given in figure 13.1.

NOTE: Use always an insulated adjustment tool.

### 13.4.1 Preparation

Before starting the checking and adjusting procedure, it is necessary to be aware of the following.

- Unless otherwise indicated, the MAIN TB must be triggered on the channel that is selected for vertical display and the trigger path is P-P coupled. The MAIN TB must function in the AUTO mode and its sweep speed must be adjusted to give good display of the phenomena of interest. The DEL'D TB is not used. The INTENS and FOCUS control must be adjusted to a well-defined trace display.
- Preliminary setting of the controls:  
All VAR controls must be set in CAL position  
All POS and LEVEL controls must be set in mid-position.  
The HOLD OFF control must be set to MIN position.
- Take care to remove the input voltage after each section.

For better access to the adjusting elements on the time base unit and the power supply unit, proceed as indicated in section 12.3.

**ATTENTION:** Do not readjust potentiometer R2395, situated on the Pre-amplifier unit. However, if this potentiometer is inadvertently turned, proceed as follows:

- Set R2395 in its mid-position.
- Readjust R4009 according to section 13.4.8.

### 13.4.2 Power supply adjustment

- Connect the instrument to the mains voltage and switch on the oscilloscope.
- Connect a digital multimeter to connection point X6001 (+10V REF) on the power supply unit and the instrument's ground.
- Adjust R6406 so that the supply voltage is exactly +10 V (tolerance:  $\pm 0,01$  V).

### 13.4.3 CRT display adjustment

Black level:

- Press X DEFL key
- Set the INTENS control to  $10^\circ$  from its left hand stop.
- Adjust R3252 so that the spot is just not visible.

Trace rotation:

- Press X DEFL key again for deflection via MTB.
- Adjust the front-panel TRACE ROTATION control so that the trace runs exactly in parallel with the horizontal graticule lines.

Astigmatism:

- Apply a 120 mV/1 kHz sine-wave signal to input A.
- Press AUTO SET key.
- Set the INTENS control for normal brightness.
- Adjust R3267 (and the FOCUS control) so that the trace is sharp and well-defined over the whole screen area.

**Intens ratio:**

- Press TB SELECT key for MTBI.
- Set UP-DOWN MTB to 5 microsec.
- Set UP-DOWN DTB to 1 microsec.
- Set the INTENS control so that the DTB part of the trace is clearly visible.
- Adjust R4616 for a normal visible MTB trace. The DTB part of the trace must be well distinguished from the MTB trace.

#### 13.4.4 Square-wave response attenuator

**Channels A and B:**

The vertical adjustments of channels A and B are identical.

The indication for channel B are shown in brackets behind those of channel A. It is advisable to perform first the channel A adjustments in this section.

- Apply a calibrated square-wave signal, frequency 1 kHz to input A (B).
- Press AUTO SET key.
- Press AC/DC key ch.A (ch.B) for DC input coupling.
- Set the adjusting elements for a straight pulse top with a maximum pulse top error of + or - 1,5 % (see table below).

INPUT SIGNAL YA (YB)	UP-DOWN ch.A (ch.B)	Adjusting element
120 mV	20 mV	C1033 (C1133)
1,2 V	0,2 V	C1029 (C1129)
12 V	2 V	C1023 (C1123)

**External amplifier:**

- Apply a 600 mV/1 kHz calibrated square-wave signal to input EXT.
- Press AUTO SET key.
- Press TRIG VIEW key for TRIG.VIEW.
- Press A/B key for only TRIG VIEW display.
- Press TRIG or X SOURCE key for EXT source.
- Press EXT AC/DC key for DC input coupling.
- Adjust C1206 for a straight pulse top with a maximum pulse top error of + or - 1,5 %.

#### 13.4.5 Adjustment of vertical sensitivities

**Trigger view sensitivity:**

- Apply a 100 mV/1 kHz calibrated square-wave signal to input A.
- Press AUTO SET key.
- Set UP/DOWN ch.A to 20 mV.
- Press AC/DC key ch.A for DC input coupling
- Press TRIG coupl. key for DC trigger coupling
- Press TRIG VIEW key.
- Adjust R2410 so that both signals are identical.

**Sensitivity final Y-amplifier**

- Apply a 600 mV/1 kHz calibrated square-wave signal to input EXT.
- Press TRIG VIEW key.
- Press A/B key for only TRIG VIEW display.
- Press TRIG or X SOURCE key for EXT source.
- Press EXT AC/DC key for DC input coupling.

- Press TRIG coupl. key for DC trigger coupling
- Adjust R3038 for a vertical display of exactly 6 divisions.

NOTE: The vertical position can be adjusted by the MTB LEVEL control.

#### Gain adjustment channel A (B).

The vertical adjustments of channels A and B are identical.

The indications for channel B are shown in brackets after those of channel A. It is advisable to perform first the channel A adjustments in this section.

- Apply a 100 mV/1 kHz calibrated square-wave signal to input A (B).
- Press AUTO SET key.
- Set UP-DOWN ch.A (ch.B) to 20 mV.
- Press AC/DC key ch.A (ch.B) for DC input coupling.
- Adjust R1065 (R1165) for a vertical display of exactly 5 divisions.
- Apply a 10 mV/1 kHz calibrated square-wave signal to input A (B).
- Press AUTO SET key.
- Set UP-DOWN ch.A (ch.B) to 2 mV.
- Press AC/DC key ch.A (ch.B) for DC input coupling.
- Adjust R1076 (R1176) for a vertical display of exactly 5 divisions.

#### 13.4.6 Adjustment of horizontal sensitivity

- Apply a 100 mV/1 kHz calibrated square-wave signal to input B.
- Press AUTO SET key.
- Press AC/DC key ch. B for DC input coupling.
- Press X DEFL key.
- Press A/B key for channel A selection.
- Set UP-DOWN ch.B to 20 mV.
- Adjust R3118 for a trace width of exactly 5 divisions.

#### 13.4.7 Offset adjustments

The adjustment in this Section are performed in SERVICE MENU "1". To enter this service menu, proceed as follows:

- Press MENU key.
- Keep MENU key pressed and press also AUTO SET key.
- Check LCD displays: "1", "2" and "3".
- Press V-ch.A (c.i. the left side of the channel A UP-DOWN control).
- Check LCD displays: "1.0".
- Each adjustment procedure can now be sequentially selected by pressing the MENU key. The LCD will indicate which order is selected (1.0...1.8).
- Adjust the potentiometers for minimum trace jump.

MEASURING	ADJUSTMENT	POTENTIOMETER	REMARKS
1.0	1-2-5 adjustment	R1036 (R1136)	
1.1	x1 continue	R1064 (R1164)	rotate VAR A (B)
1.2	x1/x10 offset	R1072 (R1172)	
1.3	trig. balance A	R1091	
1.4	trig. balance B	R1191	
1.5	trig. balance EXT	R1217	
1.6	NORM/INV.	R2212	
1.7	trig.view balance	R2407	
	Y balance	R3007	line in centre of screen.
1.8	DTM 1000-9000	R4406-R4408	see also section 13.4.13

- Press AUTO SET key twice to leave the service menu again.

Horizontal balance:

- Press MENU key.
- Press AUTO SET key.
- Set starting point of the trace to the first vertical graticule line.
- Press X DEFL key.
- Adjust R2330 so that the point is in the centre of the screen.

13.4.8 Adjustment of trigger sensitivity

- Apply a 80 mV/10 kHz sine-wave signal to input A
- Press AUTO SET key.
- Set UP-DOWN ch.A to 0,2 V.
- Set UP-DOWN MTB to 0,1 msec.
- Ensure that the trace height is exactly 0,4 division.
- Adjust R4009 for a well triggered display.

13.4.9 Adjustment of the MTB sweep times

Adjustment of 1 msec:

- Apply a 1 msec time marker signal to input A.
- Press AUTO SET key
- Set UP-DOWN MTB to 1 msec.
- Adjust R4108 and the X POS control so that the 2nd and 10th marker pulses coincide exactly with the 2nd and 10th vertical graticule lines.

Adjustment of 1 microsec:

- Change the time marker signal to 1 microsec.
- Set UP-DOWN MTB to 1 microsec.
- Adjust R4107 and manipulate the X POS control so that the 2nd and 10th marker pulses coincide exactly with the 2nd and 10th vertical graticule lines.

13.4.10 Adjustment of the DTB sweep times

Adjustment of 1 msec:

- Apply a 1 msec time marker signal to input A.
- Press AUTO SET key.
- Set UP-DOWN MTB to 2 msec.
- Press TB SELECT key for DTB-mode.
- Set UP-DOWN DTB to 1 msec.
- Adjust R4207 and the X POS control so that the 2nd and 10th marker pulses coincide exactly with the 2nd and 10th vertical graticule lines.

Adjustment of 1 microsec:

- Change the time marker signal to 1 microsec.
- Press AUTO SET key.
- Set UP-DOWN MTB to 2 microsec.
- Press TB SELECT key for DTB-mode.
- Set UP-DOWN DTB to 1 microsec.
- Adjust R4208 and the X POS control so that the 2nd and 10th marker pulses coincide exactly with the 2nd and 10th vertical graticule lines.

#### 13.4.11 Adjustment of x10 sweep times

Adjustment of 100 microsec:

- Apply a 100 microsec. time marker signal to input A.
- Press AUTO SET key.
- Set UP-DOWN MTB to 1 msec.
- Press TB MAGN key for x10 magnification.
- Ensure that the LCD gives a 0,1 ms display.
- Adjust R4721 and the X POS control so that the 2nd and 10th marker pulses coincide exactly with the 2nd and 10th vertical graticule lines. This must be valid over 10 % to 90 % of the total X-deflection range.

#### 13.4.12 Adjustment of delay time multiplier

The delay time multiplier adjustment can be performed with SERVICE MENU "1", measuring point 1.8 (see section 13.4.7)

- Set the start of the trace exactly on the first vertical graticule line by means of the X POS control.
- Enter SERVICE MENU "1".
- Select measuring number "1.8".
- Adjust R4406 and R4408 so that the start of the intensified part of the trace coincides with the 2nd and 10th vertical graticule lines respectively.
- Repeat the adjustments of R4406 and R4408 a couple of times since they are interdependent.
- Depress AUTO SET twice to leave the service menu again.

#### 13.4.13 Square-wave response of final Y-amplifier

Adjustment of square-wave response:

- Apply a 120 mV/1 MHz calibrated square-wave signal with rise time faster than 1 nsec to input A.
- Press AUTO SET key.
- Set UP-DOWN ch.A to 20 mV.
- Set UP-DOWN MTB to 0,5 microsec.
- Adjust the square-wave response with R3017.
- Set UP/DOWN MTB to 0,1 microsec.
- Adjust the square-wave response with R3013 and C3007.
- Press TB MAGN key for x10 magnification.
- Adjust the square-wave response with C3004, C3005, C3016 and R3036.
- Remove the input signal again.




Figure 13.2 Square-wave response

**Checking the chopper interference:**

- Press A/B key so that both channels A and B are displayed.
- Press ALT/CHOP key for a chopped display.
- Set UP-DOWN ch.A and ch.B to 1 V.
- Press TB MAGN again for xl magnification.
- Set UP-DOWN MTB to 0,5 msec.
- Press both 0 keys for channel A and B.
- Adjust Y POS A and Y POS B controls for a 6 division distance between both lines.
- Ensure that the chopper interference between both channels is as small as possible; if necessary, readjust R3017.

**NOTE:** When readjustment of R3017 is necessary, it is recommended to ensure that the h.f. square-wave response is still correct.  
If necessary, readjust the relevant adjusting components.

**Bandwidth check:**

The indications for channel B are shown in brackets after those of channel A.

- Apply a 120 mV/50 kHz calibrated sine wave signal to input A(B). This 6 division signal amplitude functions as a reference.
- Press AUTO SET key.
- Set UP-DOWN ch.A (ch.B) to 20 mV.
- Set UP-DOWN MTB to 0,1 msec.
- Ensure that the amplitude display on the screen does not become smaller than 4,2 divisions over the total frequency range up to 50 MHz.

#### 13.4.14 Checking the AUTO SET function

- Set UP-DOWN ch.A to 10 V.
- Set UP-DOWN MTB to 0,5 sec.
- Apply a 120 mV/1 kHz sine-wave to input A.
- Press AUTO SET key.
- Ensure that a triggered sine-wave signal is visible on the screen with 2...5 division amplitude and 2...5 periods.

## 14. CORRECTIVE MAINTENANCE

### 14.1 REPLACEMENTS

**WARNING:** The EHT cable is directly connected to the CRT.

When the EHT cable to the post-acceleration anode is disconnected, the cable must be discharged by shorting the terminal to the instrument's earth.

#### 14.1.1 Standard parts

Electrical and mechanical replacement parts can be obtained through your local Philips organisation or representative. However, many of the standard electronic components can be obtained from other local suppliers. Before purchasing or ordering replacement parts, check the parts list for value, tolerance, rating and description.

**NOTE:** Physical size and shape of a component may affect the instrument's performance, particularly at high frequencies.  
Always use direct-replacement components, unless it is known that a substitute will not degrade the instrument's performance.

#### 14.1.2 Special parts

In addition to the standard electronic components, some special components are used:

- Components, manufactured or selected by Philips to meet specific performance requirements.
- Components which are important for the safety of the instrument.

**ATTENTION:** Both type of components may only be replaced by components obtained through your local Philips organisation or representative.

#### 14.1.3 Transistors and Integrated Circuits

- Return transistors and IC's to their original positions, if removed during routine maintenance.
- Do not renew or switch semi-conductor devices unnecessarily, as it may affect the calibration of the instrument.
- Any replacement component should be of the original type or a direct replacement. Bend the leads to fit the socket or pcb-holes and cut the leads to the same length as on the component being renewed.
- When a device has been renewed, check the operation of the part of the instrument that may be affected.
- When re-installing power-supply transistors, use silicon grease to increase the heat-transfer capabilities.

**WARNING:** Handle silicon grease with care. Avoid contact with the eyes.  
Wash hands thoroughly after use.

#### 14.1.4 Static-sensitive components

This instrument contains electrical components that are susceptible to damage from static discharge. Servicing static-sensitive assemblies or components should be performed only at a static-free work station by qualified service personnel.

#### 14.1.5 Handling MOS devices

Though all our MOS integrated circuits incorporate protection against electrostatic discharges, they can nevertheless be damaged by accidental over-voltages. In storing and handling them, the following precautions are recommended.

**CAUTION:** Testing or handling and mounting calls for special attention regarding personal safety. Personnel handling MOS devices should normally be connected to ground via a resistor.

##### 14.1.5.1 Storage and transport

Store and transport the circuits in their original packing. Alternatively, use may be made of a conductive material or a special IC carrier that either short-circuits all leads or insulates them from external contact.

##### 14.1.5.2 Testing or handling

Work on a conductive surface (e.g. metal table top) when testing the circuits or transferring them from one carrier to another. Electrically connect the person doing the testing or handling to the conductive surface, for example by a metal bracelet and a conductive cord to a chain. Connect all testing and handling equipment to the same surface. Signals should not be applied to the same surface. Signals should not be applied to the inputs while the device power supply is off. All unused input leads should be connected either to the supply voltage or to ground.

##### 14.1.5.3 Mounting

Mount MOS integrated circuits on printed circuit boards after all other components have been mounted. Take care that the circuits themselves, metal parts of the board, mounting tools, and the person doing the mounting are kept at the same electrical (ground) potential. If it is impossible to ground the printed-circuit board, the person mounting the circuits should touch the board before bringing the MOS circuits into contact with it.

##### 14.1.5.4 Soldering

Soldering iron tips, including those of low voltage irons, or soldering baths should also be kept at the same potential as the MOS circuits and the board.

#### 14.1.5.5 Static charges

Dress personnel in clothing of non-electrostatic material (no wool, silk or synthetic fibres). After the MOS circuits have been mounted, the proper handling precautions should still be observed. Until the sub-assemblies are inserted into the complete system in which the proper voltages are supplied, the board is not more than an extension of the leads of the devices mounted on the board. To prevent static charges from being transmitted through the board wiring to the device it is recommended that conductive clips or conductive tape is put on the circuit board terminals.

#### 14.1.5.6 Transient voltages

To prevent permanent damage due to transfer voltages, do not insert or remove MOS devices, or printed-circuit boards with MOS devices, from test sockets or systems with power on.

#### 14.1.5.7 Voltage surges

Beware of voltage surges due to switching electrical equipment ON or OFF, relays and d.c. lines.

### 14.2 REMOVING THE UNITS AND MECHANICAL PARTS

NOTE: For installation, reverse the sequence.

#### 14.2.1 Attenuator unit (A1)

- Push gently both clamping lips that secure the metal locking plate for the attenuator unit and remove the locking plate.
- Push the attenuator unit backwards for about 1 cm.
- Remove the front unit (see section 14.2.7).
- Remove the control knobs of the CRT control unit.
- Pull gently both clamping lips that secure the front profile gently backwards and loosen the front profile.

**ATTENTION:** To avoid damage, ensure that the BNCs of the attenuator unit are behind the front profile before loosening the front profile.

Now the attenuator unit can easily pulled out of the instrument after removing the connector with flat cable and the ground connector.

**Dismantling the Attenuator unit:**

- For access to the components of the unit, remove both upper and bottom covers.
- When removing the BNCs first unsolder the wire to the p.c.b. and then unscrew the BNC-nut with a spanner of max. 5 mm thickness.

## 14.2.2 Pre-amplifier unit (A2)


- First remove the time-base unit (see section 14.2.4).
- Unlock the two p.c.b. supports
- The complete p.c.b. can be removed from the instrument after having removed all flat cables.

## 14.2.3 XYZ-amplifier unit (A3)

The XYZ amplifier unit incorporates two separate p.c.b.'s connected via a flat cable. One p.c.b. includes among other things the CRT socket and must be loosened first. For this, the CRT socket must be gently removed from the CRT.

Now the part situated above the CRT can be removed as follows:

- Remove all flat cables and the delay line cable plug.
- Pull all six clamping lips that secure the XYZ-amplifier unit p.c.b. outwards and take out the complete unit.



MAT 2234

Figure 14.1 Six clamping lips for XYZ-amplifier unit

## 14.2.4 Time-base unit (A4)

- Unlock the p.c.b. support with a special tool that fits the diameter of the p.c.b. support (see section 14.6.2).
- The complete p.c.b. can be taken out of the instrument after having removed all flat cables.

## 14.2.5 CRT control unit (A5)

- Remove the front unit (see section 14.2.7)
- Loosen the front profile (see section 14.2.1)
- Now the CRT control unit can be pulled out of the front profile after having removed the flat-cable and the CAL connector.

#### 14.2.6 Power supply unit (A6)

**WARNING:** Inside the power supply p.c.b. there are many parts that carry dangerous high voltages. Some of these voltages remain some time after disconnecting the instrument from the mains. Therefore, it is recommended to wait at least five minutes after having disconnected the instrument from the mains, before removing the p.c.b. If working on the power supply unit under live condition cannot be avoided, it must be done by a qualified technician who is aware of the dangers involved.

- Remove the extension shaft from the ON/OFF switch by pushing both sides of the end of the shaft together.
- Push both clamping lips that secure the power supply unit.
- Lift the power supply unit outside the instrument.
- Place the p.b.c. in the unit slider.


**NOTE:** After the above actions, the power supply unit can be measured under working conditions, provided that all cables are still connected to the unit.

**NOTE:** The flat cable to the CRT control unit can easily be removed now when removing this unit.

- Remove the two flat cables, the power supply cable, the two- and three-pole cable connectors and the EHT-connector from the CRT.

**WARNING:** The EHT cable is directly connected to the CRT. When the EHT cable to the post-acceleration anode is disconnected, the cable must be discharged by shorting the terminal to the instrument's earth.

- The power supply can now be taken out of the instrument.




MAT2235

Figure 14.2 Power supply unit outside the instrument

## 14.2.7 Front unit (A7) and LCD unit (A8)

- Unscrew the two screws, located at the rear of the front unit.
- Now the complete unit assembly can be slid out of the front profile of the instrument.

NOTE: After the above actions, the front unit can be measured under working conditions, provided that the flat cable is still connected to the unit.



MAT 2236

Figure 14.3 Measuring the front unit working condition

For accessibility to the component side of the front unit and LCD unit, proceed as follows:

- Unplug the connector with flat cable
- Remove all control knobs; the knobs can easily pulled off the potentiometer spindles
- Pull all clamping lips that secure the front unit p.c.b. gently outwards and loosen the text plate.

NOTE: The LCD unit is connected to the front unit by means of two 3-pin connectors and can be easily pulled off.  
The LCD display lamp can be reached after pulling off the LCD unit.

ATTENTION: The LCD is unbreakably connected to the LCD unit and cannot be exchanged as a separate component.  
When the LCD is defective, the complete LCD unit must be replaced.

#### 14.2.8 Removing the delay line cable


The delay line cable is a 54 cm cable that is connected to the amplifier unit and to the XYZ amplifier unit.

To remove the delay line cable, proceed as follows:

- For access to the delay line cable, remove the time-base unit (See section 14.2.4) and the pre-amplifier unit (see section 14.2.2).
- Unlock the plastic clamps that fix the cable to the instrument's chassis and to the units.
- Remove the plug that connects the delay line cable to the pre-amplifier unit.
- Unscrew the plastic clamp that fix the cable to the XYZ-amplifier unit.
- Remove the plug that connects the delay line cable to the XYZ-amplifier unit.

#### 14.2.9 Replacement of CRT

**IMPORTANT:** It is strongly recommended to study of this chapter and the associated illustration (figure 14.4) before starting replacement.



MAT 2238

Figure 14.4 Removing the CRT

- Remove the XYZ-amplifier unit, see section 14.2.3.
- Remove the graticule lamp holder (1).
- Remove the bezel with the screen filter.
- Remove the two plastic p.c.b. supports (2).
- Unlock the EHT-cable.

**WARNING:** Handle the CRT carefully. Rough handling or scratching can cause the CRT to implode.

- Push the two clamping lips that secure the CRT support (3) and gently lift the CRT, incl. metal shielding out of the instrument.

**NOTE:** Before re-assembling a new CRT, first remove its protective cover and place the CRT front rubber around the CRT-front.

## 14.3 SOLDERING TECHNIQUES

**Working method:**

- Carefully unsolder one after the other the soldering leads of the semi-conductor.
- Remove all superfluous soldering material. Use a suction iron or suction litze wire.
- Check that the leads of the replacement part are clean and pre-tinned on the soldering place.
- Locate the replacement semi-conductor exactly on its place, and solder each lead to the relevant printed conductor on the circuit board.

**NOTE:** Bear in mind that the maximum permissible soldering time is 10 seconds during which the temperature of the leads must not exceed 250°C. The use of solder with a low melting point is therefore recommended.

Take care not to damage the plastic encapsulation of the semi-conductor (softening point of the plastic is 150°C).

**ATTENTION:** When you are soldering inside the instrument, it is essential to use a low-voltage soldering iron, the tip of which must be earthed to the mass of the oscilloscope.

Suitable soldering irons are:

- ORYX micro-miniature soldering instrument, type 6 A, voltage 6 V, in combination with PLATO pin-point tip type 0-569.
- ERSA miniature soldering iron, type minor 040 B, voltage 6 V.
- Low Voltage Mini Soldering Iron, type 800/12 W-6 V, power 12 W, voltage 6 V, order no. 4822 395 10004, in combination with 1mm pin-point tip, order no. 4822 395 10012.

Ordinary 60/40 solder with core and 35 to 40 W pencil type soldering iron can be used for the majority of the soldering. If a higher wattage-rating soldering iron is used on the etched circuit boards, excessive heat can cause the etched circuit wiring to separate from the board base material.

## 14.4

## INSTRUMENT REPACKING

If the instrument is to be shipped to a Service Centre for service or repair, attach a tag showing the full address and the name of the individual at the users firm that can be contacted. The Service Centre needs the complete instrument, its serial number and a fault description. If the original packing is not available, repack the instrument in such a way that no damage occurs during transport.

## 14.5 TROUBLE SHOOTING

### 14.5.1 Introduction

The following information is provided to facilitate trouble shooting. Information contained in other sections of the manual should also be used to locate the defect. An understanding of the circuit is helpful in locating troubles, particularly where integrated circuits are used. Refer to the circuit description for this information.

### 14.5.2 Trouble-shooting techniques

If a fault appears, the following test sequence can be used to find the defective part:

- Check if the settings of the controls of the oscilloscope are correct. Consult the Operating Instructions.
- Check the equipment to which the oscilloscope is connected and the interconnection cables.
- Check if the oscilloscope is well-calibrated. If not, refer to section 13. "Checking and Adjusting".
- Visually check the part of the oscilloscope in which the fault is suspected. In this way, it is possible to find faults such as bad soldering connections, bad interconnection plugs and wires, damaged components or transistors and IC's that are not correctly plugged into their sockets.
- Location of the circuit part in which the fault is suspected: the symptom often indicates this part of the circuit. If the power supply is defective the symptom will appear in several circuit parts.

After having carried out the previous steps, individual components in the suspected circuit parts must be examined:

#### - Transistors and diodes.

Check the voltage between base and emitter (0,7 V approx. in conductive state) and the voltage between collector and emitter (0,2 V approx. in saturation) with a voltmeter or an oscilloscope. When removed from the p.c.b. it is possible to test the transistor with an ohmmeter since the base/collector junctions can be regarded as diodes. Like a normal diode, the resistance is very high in one direction and low in the other direction. When measuring take care that the current from the ohmmeter does not damage the component under test.

Replace the suspected component by a new one if you are sure that the circuit is not in such condition that the new component will be damaged.

#### - Integrated circuits.

In circuit, testing can be done with an oscilloscope or voltmeter. A good knowledge of the circuit part under test is essential. Therefore, first read the circuit descriptions in sections 3...10.

#### - Capacitors.

Leakage can be traced with an ohmmeter adjusted to its highest resistance range. When testing take care of polarity and maximum allowed voltage. An open capacitor can be checked if the response for AC signals is observed. Also a capacitance meter can be used: compare the measured value with the value and tolerance indicated in the parts list

- Resistors.

Can be checked with an ohmmeter after having unsoldered one side of the resistor from the pcb. Compare the measured value with the value and tolerance indicated in the parts list.

- Coils and transformers.

An ohmmeter can be used for tracing an open circuit. Shorted or partially shorted windings can be found by checking the waveform responses when HF signals are passed through the circuit. Also an inductance meter can be used.

- Data latches.

To measure on inputs and outputs of data latches a measuring oscilloscope can be triggered by the clock signal which is connected to the clock input of the data latch.

This measurement can only be made in this way when there is an acceptable repetition time of the clock signal. A too low clock pulse repetition time results in a low intensity of the trace on the measuring oscilloscope screen.

The outputs can easily be checked by a voltmeter or oscilloscope.

#### 14.5.3 Power-up routine

Every time the instrument is switched-on the following initialisation program is executed:

- Resetting the IIC-bus.
- Resetting D2603 (0Q 0200)
- Determinig the SLAVE-address of D2603.
- Checking if Service routine is required (if yes the program will continue with the service routine).
- Checking the "WATCH-DOG" on A7 (if HIGH, all relevant LCD-segments will be lighting for about 1 sec).
- Eventually initialisation of the IEEE-option.

If during the program-run a circuit is found to be faulty, the program stops. It is recommended to switch-off and after a few seconds switch-on again. This will reset the micro-computer controlled system automatically. If the instrument goes in the same faulty situation again, the following procedure indicates how to handle. If no faulure is found, all relevant LCD-segments will be lighting for about one second. After this the normal program is executed.

**PROCEDURE:**

Check the SDA and SCL lines after haved switched-on. On the SCL a clock-pulse must be present, while the SDA gives the data-information (looks like a random pulse). If one of these signals is not present, you can localize on what unit the fault exists. This can be done by first unplug connector X1009 or X2001 on resp. A1 and A2. To localize what serial-parallel conversion IC is defective, you can disconnect the solder joint in the SDA and SCL print track lead to that IC. The following IC's can disconnected in this way: D1001, D1101, D2602, D2603, D4001, D4002, D4401.

When the instrument restarts every time again, this means the WATCHDOG is initiating the main program (see also section 10.1.4), the watchdog can be disabled. This can be done by means of the solder joint jumper on the rear of the front unit p.c.b. (near X7001).

When disabled, pin 13 of the microcomputer is set to a low level.

#### 14.5.4 Trouble-shooting the power supply


To determine whether a certain fault condition is initiated by the power supply itself or by the connected oscilloscope circuits, a dummy load is listed in the table below. The table gives also an example of the resistor types that can be used to compose the dummy load. These resistors can be ordered at Concern Service.

Supply voltage	Output current	Dummy resistance and their service ordering numbers
+ 5 V	2,4 A	2,1E-12W: 3 x 8E (4822 112 21052) and 10E (4822 112 21054) in parallel.
- 6,4 V	930 mA	6,9E-6W: 8,2E (4822 112 41052) and 47E (4822 110 23072) in parallel.
+ 12 V	720 mA	17,2E-8,7W: 33E (4822 112 41067) and 39E (4822 112 43069) in parallel.
- 12 V	500 mA	24,7E-6W: 39E (4822 112 41069) and 68E (4822 112 41067) in parallel.
+ 17 V	340 mA	51E-6W: 1E (4822 110 23027) in serial with 2 x 100 E(4822 112 41081) in parallel.
- 17 V	100 mA	171E-1,7W: 270E (4822 110 43092) and 470E (4822 110 43098) in parallel.
+ 48 V	140 mA	341E-7W: 330E (4822 112 41094) in serial with 12E(4822 110 23056).
- 48 V	40 mA	1k22-2W: 2k2 (4822 110 23116) and 2k7 (4822 110 23118) in parallel.

#### 14.5.5 P.c.b. interconnections

Figure 14.5 gives a survey of all interconnections between the p.b.c.'s and to the CRT. Also the interconnections between the connectors on board level is given in this diagram.

An explanation of the connector indication is given below:







Figure 14.5 P.c.b. interconnections



## 14.5.6 Signal waveforms

The signal waveforms in the circuit diagrams can be measured on the measure points (X...). Condition:

- Apply the CAL voltage via a 1:10 probe to input CH A.
- Press AUTO SET

If addition operation is needed, it is stated.

## 14.5.7 Semi conductor pinnings

SEMI- CONDUCTORS CONNECTIONS




Figure 14.6

## 14.6 SPECIAL TOOLS

## 14.6.1 Trimming Kit SBC 317 - 4822 310 50095

The SBC 317 Trimming Kit matches every current trimming requirement for all products. The set contains 27 items (22 different bits, plus 3 bit holders and 2 extension pieces). The insulated holders and extension pieces make it easy to reach into a chassis and make accurate adjustments, without wasting time or risking shocks.

The SBC 317 Trimming Kit is packed in a flat transparent case. Several of the most commonly required bits are duplicated. In addition, a spare set of 8 bits is separately available as replacement (4822 310 50016).

The Trimming Kit contains the following parts:




Figure 14.7 Trimming tool kit

#### 14.6.2 P.c.b. snapper - 5322 535 91942

A special tool is available for removal of the pcb from the p.c.b. supports. Information on how to use this tool is given in chapter 14.2. The ordering number of this tool is 5322 535 91942




Figure 14.8 P.c.b. snapper

#### 14.7 RECALIBRATION AFTER REPAIR

After any electrical component has been renewed the calibration of its associated circuit should be checked, as well as the calibration of other closely-related circuits.

Since the power supply affects all circuits, calibration of the entire instrument should be checked if work has been done in the power supply or if the transformer has been renewed.

## 15. SAFETY INSPECTION AND TEST AFTER REPAIR AND MAINTENANCE IN THE PRIMARY CIRCUIT

### 15.1 GENERAL DIRECTIVES

- Take care that the creepage distances and clearances have not been reduced.
- Before soldering, the wires should be bent through the holes of solder tags, or wrapped around the tag in the form of an open U, or, wiring ridigity shall be maintained by cable clamps or cable lacing.
- Replace all insulating guards and -plates.

### 15.2 SAFETY COMPONENTS

Components in the primary circuit may only be renewed by components selected by Philips, see also section 14.1.2.

### 15.3 CHECKING THE PROTECTIVE EARTH CONNECTION

The correct connection and condition is checked by visual control and by measuring the resistance between the protective lead connection at the plug and the cabinet/frame. The resistance shall not be more than 0,1 Ohm. During measurement the mains cable should be removed from the mains. Resistance variations indicate a defect.

### 15.4 CHECKING THE INSULATION RESISTANCE

Measure the insulation resistance at  $U = 500$  V dc between the mains connections and the protective lead connections. For this purpose, set the mains switch to ON. The insulation resistance shall not be less than 2 Meg-ohm.

NOTE: 2 Meg-ohm is a minimum requirement at  $40^{\circ}\text{C}$  and 95 % Relative Humidity. Under normal conditions the insulation resistance should be much higher (10 ... 20 Meg-ohm).

### 15.5 CHECKING THE LEAKAGE CURRENT

The leakage current shall be measured between each pole of the mains supply in turn, and all accessible conductive parts connected together (including the measuring earth terminal).

The leakage current is not excessive if the measured currents from the mentioned parts does not exceed 0,5 mA rms.

## 15.6 VOLTAGE TEST

The instrument shall withstand, without electrical breakdown, the application of a test voltage between the supply circuit and accessible conductive parts that are likely to become energized. The test potential shall be 1500 V rms at supply-circuit frequency, applied for one second.

The test shall be conducted when the instrument is fully assembled, and with the primary switch in the ON position.

During the test, both sides of the primary circuit of the instrument are connected together and to one terminal of the voltage test equipment; the other voltage test equipment terminal is connected to the accessible conductive parts.


## 16. PARTS LIST

(subject to alteration without notice)

### 16.1 MECHANICAL PARTS

#### 16.1.1 Mechanical parts indicated in figure 16.1.

Item	Qty	Ordering code	Description
1	1	5322 381 10779	Bezel
2	1	5322 480 30181	Contrast filter blue
3	1	5322 455 81075	Textfilm on bezel PM3055
3	1	5322 455 81076	Textfilm on bezel PM3057
4	1	5322 268 14052	CAL socket
5	1	4822 530 70296	Clamping spring for CAL socket
6	13	5322 414 10018	Control knob with spring
7	1	5322 464 90252	Front frame
8	1	5322 455 81026	Textfilm CRT unit
9	1	5322 455 81025	Textfilm for handle
10	1	5322 498 50219	Handle assembly
11	1	5322 414 60142	Power-on knob, green-brown
12	2	5322 492 63355	Spring for handle
13	1	5322 535 80735	Extension part for power-on switch
14	1	5322 464 90248	Upper cabinet
15	2	5322 462 10265	P.c.b. support for A3
16	2	5322 462 10264	P.c.b. guiding for A6
17	1	5322 464 90486	Chassis
18	6	5322 462 30304	P.c.b. support
19	1	5322 464 90249	Bottom cabinet
20	2	5322 464 90253	Attenuator cover
21	4	5322 462 50325	Bottom foot
22	3	5322 506 41006	BNC nut
23	3	5322 532 21188	BNC spacer ring
24	3	5322 267 10004	BNC socket
25	1	5322 464 90254	Front unit frame
26	1	5322 455 81028	Textfilm for front unit
27	18	5322 276 11856	Softkey brown
28	2	5322 276 11858	Softkey beige
29	1	5322 276 11857	Softkey green
30	2	5322 277 10879	UP-DOWN key beige
31	3	5322 277 10878	UP-DOWN key brown
32	2	5322 492 63354	Range indication spring
33	1	5322 450 60952	LCD window
--	3	5322 401 10954	Delay line cable clamp
--	2	5322 255 40054	Heatsink for V3011 and V3012



## 16.1.2 Mechanical pa

Item	Qty
1	2
2	1
3	4
4	1
5	1
6	1
7	1

## 16.1.3 Mechanical pa


Item	Qty
1	1
2	1
3	1
4	1
5	1
6	1


## 16.2 UNITS (see fi

Item	Uni
1	A1
2	A2
3	A3
4	A4
5	A5
6	A6
7	A7
8	A8

MAT2252A  
871218


Figure 16.1 Exploded view





MAT2254

Figure 16.2 Rear view



MAT 2296

Figure 16.3 Inside view showing the parts in the






Figure 16.4 View of the units



MAT2254

ew




MAT 2296

view showing the parts in the CRT compartment

## 16.1.2 Mechanical pa

Item	Qt
1	2
2	1
3	4
4	1
5	1
6	1
7	1



MAT 2253

the units

## 16.2 UNITS (see fi

Item	Un
1	A1
2	A2
3	A3
4	A4
5	A5
6	A6
7	A7
8	A8

## 16.1.2 Mechanical parts indicated in figure 16.2

Item	Qty	Ordering code	Description
1	2	5322 462 50324	Rear foot
2	1	5322 267 10004	BNC socket for Z-MOD
3	4	5322 502 12003	Screw for Remote control socket and Mains socket
4	1	5322 321 22665	Remote control socket, incl. cable
5	1	5322 321 21616	Line cable, European version
	1	5322 321 10446	Line cable, USA version
	1	5322 321 21617	Line cable, British version
	1	5322 321 21618	Line cable, Swiss version
	1	5322 321 21781	Line cable, Australasian version
6	1	5322 219 81119	Mains input socket, incl. fuse holder
7	1	4822 253 30024	Fuse 1,6A (for mains input)

## 16.1.3 Mechanical parts indicated in figure 16.3

Item	Qty	Ordering code	Description
1	1	5322 460 60404	CRT front rubber
2	1	5322 462 40957	Light conductor for CRT
3	1	5322 134 40534	Lamp 28V-40mA
4	1	5322 466 30163	CRT shielding
5	1	5322 466 30164	CRT manchet, rubber
6	1	5322 462 10263	CRT support

## 16.2 UNITS (see figure 16.4)

Item	Unit nr.	Ordering code	Description
1	A1	5322 216 51114	Attenuator unit
2	A2	5322 216 51116	Pre-amplifier unit
3	A3	5322 216 51117	XYZ-amplifier unit
4	A4	5322 216 51115	Time-base unit
5	A5	5322 216 51118	CRT-control unit
6	A6	5322 216 51119	Power supply unit
7	A7	5322 216 51113	Front unit
8	A8	5322 216 51121	LCD unit

## 16.3 CABLES AND CONNECTORS

### 16.3.1 Flatcables and connectors

For the flatcables used in this oscilloscope, the required version must be made by yourself with the following parts:

- Universal flatcable, 40 wires, length 60 cm 5322 323 50112

To get the required number of wires, the flat cable must be split by means of a pair of scissors or a knife.

The cable must be cut to the required length.

- Flatcable connectors

The connectors can be mounted on the flatcable by means of a pair of pliers or in a bench-vice.

**ATTENTION:** check the position of the flatcable in the connector before pressing the connector together.

The following connectors are available:

10 pole cable connector X4016-X5007-X6007	5322 268 40234
20 pole cable connector X2010-X3002-X3003 X4002-X4010-X6009	5322 268 40235
26 pole cable connector X1009-X2009	5322 267 70175
34 pole cable connector X2001-X4001-X7001	5322 268 40236

The following AMP-connectors are available:

2 pole-single, without contact pins	5322 268 40232
3 pole-single, without contact pins	5322 268 40233
bus contact for AMP-cable connector, per piece:	5322 268 20152
5 pole connector for power-in:	5322 267 50452
bus contact for connector, per piece:	5322 268 24128
- Flatcable connector clamp	5233 401 11156

### 16.3.2 P.c.b.-connectors (male headers)

Type	Item	Ordering number
2 pole-single	X2013-X4017-X6020	5322 265 20275
3 pole-single	X6006-X6019	5322 265 30434
3 pole single	X6018 (power supply)	5322 265 40435
3 pole-single 90° type	X2004-X3004-X3005-X3008	5322 265 30433
5 pole-single	X6014	5322 265 40436
10 pole-double	X4016-X5007-X6007	5322 265 40485
20 pole-double	X2010-X3002-X3003	5322 265 51129
26 pole-double	X1009-X2009	5322 265 61071
34 pole-double	X2001-X4001	5322 265 61069
34 pole-double 90° type	X7001	5322 265 61068
CRT-socket	X3006	5322 255 40502

### 16.3.3 Miscellaneous cables

- Delay line cable, 54 cm long	5322 321 21595
- Flex jump cable, used for interconnection for A3 - 11 pole.	5322 290 60605

## 16.4 ELECTRICAL PARTS

### 16.4.1 CAPACITORS

POSNR	DESCRIPTION	ORDERING CODE	POSNR	DESCRIPTION	ORDERING CODE
C 201	-20+50% 10NF	4822 122 31414	C 1131	-20+50% 10NF	4822 122 31414
C 202	2% 100PF	4822 122 31316	C 1132	2% 33PF	5322 122 32551
C 203	7-10.0 PF	5322 125 11013	C 1133	7-10.0 PF	5322 125 11013
C 204	10% 1NF	4822 122 30027	C 1134	-20+50% 10NF	4822 122 31414
C 251	-10+50% 68UF	4822 124 20689	C 1135	-20+50% 10NF	4822 122 31414
C 252	-20+50% 10NF	4822 122 31414	C 1136	2% 39PF	4822 122 31069
C 253	-20+50% 10NF	4822 122 31414	C 1137	2% 22PF	5322 122 32143
C 254	-10+50% 68UF	4822 124 20689	C 1138	2% 100PF	4822 122 31316
C 256	-20+50% 10NF	4822 122 31414	C 1139	0.25PF 2.2PF	4822 122 31036
C 257	-20+50% 10NF	4822 122 31414	C 1141	63V 10% 100NF	5322 121 43083
C 421	-20+50% 10NF	4822 122 31414	C 1142	-20+50% 10NF	4822 122 31414
C 422	-20+50% 10NF	4822 122 31414	C 1143	-20+50% 10NF	4822 122 31414
C 423	-20+50% 10NF	4822 122 31414	C 1144	-20+50% 10NF	4822 122 31414
C 1001	-20+50% 10NF	4822 122 31414	C 1145	-20+50% 10NF	4822 122 31414
C 1002	400V 10% 22NF	5322 121 40308	C 1146	-10+50% 68UF	4822 124 20689
C 1003	-20+50% 10NF	4822 122 31414	C 1147	0.25PF 4.7PF	4822 122 31822
C 1004	-20+50% 10NF	4822 122 31414	C 1161	10% 470PF	4822 122 30034
C 1006	-20+50% 10NF	4822 122 31414	C 1162	0.25PF 3.3PF	4822 122 31821
C 1009	2% 33PF	5322 122 32072	C 1163	2% 33PF	5322 122 32072
C 1011	63V 10% 220NF	5322 121 43084	C 1164	10% 680PF	4822 122 30053
C 1012	63V 10% 220NF	5322 121 43084	C 1167	2% 68PF	4822 122 31349
C 1013	2% 15PF	4822 122 31823	C 1168	-20+50% 10NF	4822 122 31414
C 1016	0.25PF 3.3PF	5322 122 32549	C 1171	-20+50% 10NF	4822 122 31414
C 1017	0.25PF 3.3PF	4822 122 31821	C 1172	-20+50% 10NF	4822 122 31414
C 1018	0.25PF 2.7PF	5322 122 32894	C 1176	10% 1.5NF	4822 122 31169
C 1019	2% 33PF	5322 122 32072	C 1177	10% 1.5NF	4822 122 31169
C 1021	-20+50% 10NF	4822 122 31414	C 1201	-20+50% 10NF	4822 122 31414
C 1022	2% 22PF	5322 122 32143	C 1202	400V 10% 22NF	5322 121 40308
C 1023	7-10.0 PF MUR	5322 125 11013	C 1203	2% 33PF	5322 122 32551
C 1024	-20+50% 10NF	4822 122 31414	C 1204	0.25PF 3.9PF	4822 122 31217
C 1026	0.25PF 3.3PF	5322 122 32549	C 1206	7-10.0 PF	5322 125 11013
C 1027	0.25PF 2.2PF	5322 122 32774	C 1207	2% 22PF	5322 122 32143
C 1028	2% 33PF	5322 122 32072	C 1208	-20+50% 10NF	4822 122 31414
C 1029	7-10.0 PF MUR	5322 125 11013	C 1210	0.25PF 0.56PF	5322 122 32107
C 1031	-20+50% 10NF	4822 122 31414	C 1211	-20+50% 10NF	4822 122 31414
C 1032	2% 33PF	5322 122 32551	C 1212	2% 100PF	4822 122 31316
C 1033	7-10.0 PF MUR	5322 125 11013	C 1216	0.25PF 4.7PF	4822 122 31822
C 1034	-20+50% 10NF	4822 122 31414	C 1217	-20+50% 10NF	4822 122 31414
C 1035	-20+50% 10NF	4822 122 31414	C 1401	-20+50% 10NF	4822 122 31414
C 1036	2% 39PF	4822 122 31069	C 1402	-20+50% 10NF	4822 122 31414
C 1037	2% 22PF	5322 122 32143	C 1403	-20+50% 10NF	4822 122 31414
C 1038	2% 100PF	4822 122 31316	C 1404	-10+50% 68UF	4822 124 20689
C 1039	0.25PF 2.2PF	4822 122 31036	C 1411	-20+50% 10NF	4822 122 31414
C 1041	63V 10% 100NF	5322 121 43083	C 1412	-20+50% 10NF	4822 122 31414
C 1042	-20+50% 10NF	4822 122 31414	C 1413	-10+50% 47UF	4822 124 20699
C 1043	-20+50% 10NF	4822 122 31414	C 1414	-20+50% 10NF	4822 122 31414
C 1044	-20+50% 10NF	4822 122 31414	C 1420	-20+50% 10NF	4822 122 31414
C 1045	-20+50% 10NF	4822 122 31614	C 1421	-20+50% 10NF	4822 122 31414
C 1046	-10+50% 68UF	4822 124 20689	C 1422	-20+50% 10NF	4822 122 31414
C 1047	0.25PF 4.7PF	4822 122 31822	C 1423	-20+50% 10NF	4822 122 31414
C 1061	10% 470PF	4822 122 30034	C 1424	-10+50% 68UF	4822 124 20689
C 1062	0.25PF 3.3PF	4822 122 31821	C 1427	-20+50% 10NF	4822 122 31414
C 1063	2% 33PF	5322 122 32072	C 1428	-20+50% 10NF	4822 122 31414
C 1064	10% 680PF	4822 122 30053	C 1429	-10+50% 68UF	4822 124 20689
C 1067	2% 68PF	4822 122 31349	C 1431	-20+50% 10NF	4822 122 31414
C 1068	-20+50% 10NF	4822 122 31414	C 1432	-20+50% 10NF	4822 122 31414
C 1071	-20+50% 10NF	4822 122 31414	C 1433	-10+50% 47UF	4822 124 20699
C 1072	-20+50% 10NF	4822 122 31414	C 1434	-20+50% 10NF	4822 122 31414
C 1076	10% 1.5NF	4822 122 31169	C 1441	-20+50% 10NF	4822 122 31414
C 1077	10% 1.5NF	4822 122 31169	C 1442	-10+50% 68UF	4822 124 20689
C 1101	-20+50% 10NF	4822 122 31414	C 1443	-20+50% 10NF	4822 122 31414
C 1102	400V 10% 22NF	5322 121 40308	C 1444	-20+50% 10NF	4822 122 31414
C 1103	-20+50% 10NF	4822 122 31414	C 1446	-10+50% 68UF	4822 124 20689
C 1104	-20+50% 10NF	4822 122 31414	C 1447	-20+50% 10NF	4822 122 31414
C 1106	-20+50% 10NF	4822 122 31414	C 2049	10% 1.5NF	4822 122 31169
C 1109	2% 33PF	5322 122 32072	C 2050	-20+50% 10NF	4822 122 31414
C 1111	63V 10% 220NF	5322 121 43084	C 2051	10% 1.5NF	4822 122 31169
C 1112	63V 10% 220NF	5322 121 43084	C 2149	10% 1.5NF	4822 122 31169
C 1113	2% 15PF	4822 122 31823	C 2150	-20+50% 10NF	4822 122 31414
C 1116	0.25PF 3.3PF	5322 122 32549	C 2151	10% 1.5NF	4822 122 31169
C 1117	0.25PF 3.3PF	4822 122 31821	C 2201	-20+50% 10NF	4822 122 31414
C 1118	0.25PF 2.7PF	5322 122 32894	C 2203	-20+50% 10NF	4822 122 31414
C 1119	2% 33PF	5322 122 32072	C 2207	-20+50% 10NF	4822 122 31414
C 1121	-20+50% 10NF	4822 122 31414	C 2215	0.25PF 3.9PF	5322 122 34107
C 1122	2% 22PF	5322 122 32143	C 2216	0.25PF 2.7PF	4822 122 31038
C 1123	7-10.0 PF	5322 125 11013	C 2217	-20+50% 10NF	4822 122 31414
C 1124	-20+50% 10NF	4822 122 31414	C 2218	0.25PF 2.7PF	4822 122 31038
C 1126	0.25PF 3.3PF	5322 122 32549	C 2220	0.25PF 5.6PF	5322 122 32163
C 1127	0.25PF 2.2PF	5322 122 32774	C 2221	10% 1.5NF	4822 122 31169
C 1128	2% 33PF	5322 122 32072	C 2222	0.25PF 8.2PF	4822 122 31052
C 1129	7-10.0 PF	5322 125 11013	C 2223	10% 1.5NF	4822 122 31169

POSNR	DESCRIPTION	ORDERING CODE	POSNR	DESCRIPTION	ORDERING CODE
C 2224	10% 1.5NF	4822 122 31169	C 3022	-20+50% 10NF	4822 122 31414
C 2225	10% 470PF	4822 122 30034	C 3101	10% 1.5NF	4822 122 31169
C 2226	10% 470PF	4822 122 30034	C 3102	10% 1.5NF	4822 122 31169
C 2229	10% 470PF	4822 122 30034	C 3104	100V 10% 47NF	5322 121 43088
C 2230	10% 470PF	4822 122 30034	C 3105	-20+50% 10NF	4822 122 31414
C 2305	-20+50% 10NF	4822 122 31414	C 3106	63V 10% 100NF	5322 121 43083
C 2306	10% 1.5NF	4822 122 31169	C 3107	0.25PF 2.7PF	4822 122 31038
C 2307	10% 1.5NF	4822 122 31169	C 3108	0.25PF 0.82PF	4822 122 31214
C 2317	0.25PF 1.5PF	5322 122 32101	C 3109	63V 10% 100NF	5322 121 43083
C 2318	10% 470PF	4822 122 30034	C 3110	-20+50% 10NF	4822 122 31414
C 2321	0.25PF 1.5PF	5322 122 32101	C 3111	-20+50% 10NF	4822 122 31414
C 2326	-20+50% 10NF	4822 122 31414	C 3113	0.25PF 0.82PF	4822 122 31214
C 2327	-20+50% 10NF	4822 122 31414	C 3114	100V 10% 47NF	5322 121 43088
C 2328	63V 10% 100NF	5322 121 43083	C 3116	63V 10% 100NF	5322 121 43083
C 2329	63V 10% 100NF	5322 121 43083	C 3200	0.25PF 0.56PF	5322 122 32107
C 2331	63V 10% 100NF	5322 121 43083	C 3201	0.25PF 0.56PF	5322 122 32107
C 2332	63V 10% 100NF	5322 121 43083	C 3202	63V 10% 100NF	5322 121 43083
C 2333	63V 10% 100NF	5322 121 43083	C 3203	63V 10% 100NF	5322 121 43083
C 2335	2% 12PF	4822 122 31056	C 3204	-20+50% 10NF	4822 122 31414
C 2336	-20+50% 10NF	4822 122 31414	C 3206	63V 10% 100NF	5322 121 43083
C 2337	-20+50% 10NF	4822 122 31414	C 3208	10% 470PF	4822 122 30034
C 2338	10% 470PF	4822 122 30034	C 3209	-20+50% 2.2NF	5322 122 50093
C 2342	2% 22PF	5322 122 32143	C 3211	-20+50% 2.2NF	5322 122 50093
C 2345	0.25PF 01.8PF	5322 122 32162	C 3250	100V 10% 10NF	5322 121 43086
C 2346	10% 1.5NF	4822 122 31169	C 3251	63V 10% 220NF	5322 121 43084
C 2348	10% 1.5NF	4822 122 31169	C 3252	-20+50% 2.2NF	5322 122 50093
C 2350	0.25PF 2.7PF	4822 122 31038	C 3253	-20+50% 10NF	4822 122 31414
C 2507	-20+50% 10NF	4822 122 31414	C 3254	-20+50% 10NF	4822 122 31414
C 2510	2% 22PF	5322 122 32143	C 3256	0.25PF 0.56PF	5322 122 32107
C 2516	0.25PF 2.7PF	4822 122 31038	C 3257	-20+50% 10NF	4822 122 31414
C 2517	10% 470PF	4822 122 30034	C 3258	-20+50% 2.2NF	5322 122 50093
C 2518	0.25PF 2.7PF	4822 122 31038	C 3301	-20+50% 10NF	4822 122 31414
C 2519	2% 15PF	4822 122 31823	C 3302	-20+50% 10NF	4822 122 31414
C 2600	2% 22PF	5322 122 32143	C 3303	-10+50% 47UF	4822 124 20699
C 2601	63V 10% 100NF	5322 121 43083	C 3304	-20+50% 10NF	4822 122 31414
C 2602	-20+50% 10NF	4822 122 31414	C 3306	-20+50% 10NF	4822 122 31414
C 2604	10% 1.5NF	4822 122 31169	C 3307	-20+50% 10NF	4822 122 31414
C 2611	10% 1NF	4822 122 30027	C 3308	-20+50% 10NF	4822 122 31414
C 2612	-20+50% 10NF	4822 122 31414	C 3309	-20+50% 10NF	4822 122 31414
C 2613	10% 470PF	4822 122 30034	C 3311	-20+50% 10NF	4822 122 31414
C 2616	10% 470PF	4822 122 30034	C 3312	-10+50% 47UF	4822 124 20699
C 2701	-10+50% 100UF	4822 124 20679	C 3313	-20+50% 10NF	4822 122 31414
C 2702	-20+50% 10NF	4822 122 31414	C 3314	-10+50% 15UF	4822 124 20729
C 2703	-20+50% 10NF	4822 122 31414	C 3316	-20+50% 10NF	4822 122 31414
C 2704	-20+50% 10NF	4822 122 31414	C 3317	-20+50% 10NF	4822 122 31414
C 2706	-10+50% 100UF	4822 124 20679	C 3318	-20+50% 10NF	4822 122 31414
C 2707	-20+50% 10NF	4822 122 31414	C 3319	-10+50% 15UF	4822 124 20729
C 2708	-20+50% 10NF	4822 122 31414	C 3321	-20+50% 10NF	4822 122 31414
C 2709	-20+50% 10NF	4822 122 31414	C 3322	-20+50% 10NF	4822 122 31414
C 2711	-20+50% 10NF	4822 122 31414	C 3324	-20+50% 10NF	4822 122 31414
C 2716	-10+50% 68UF	4822 124 20689	C 3326	-20+50% 10NF	4822 122 31414
C 2717	-20+50% 10NF	4822 122 31414	C 4001	63V 10% 100NF	5322 121 43083
C 2718	-20+50% 10NF	4822 122 31414	C 4002	-10+50% 47UF	4822 124 20699
C 2722	-20+50% 10NF	4822 122 31414	C 4003	63V 10% 100NF	5322 121 43083
C 2726	-10+50% 68UF	4822 124 20689	C 4004	-20+50% 10NF	4822 122 31414
C 2727	-20+50% 10NF	4822 122 31414	C 4005	-20+50% 10NF	4822 122 31414
C 2728	-20+50% 10NF	4822 122 31414	C 4006	10% 4.7NF	4822 122 31125
C 2741	-20+50% 10NF	4822 122 31414	C 4007	10% 4.7NF	4822 122 31125
C 2744	-20+50% 10NF	4822 122 31414	C 4008	10% 470PF	4822 122 30034
C 2746	-20+50% 10NF	4822 122 31414	C 4009	0.25PF 3.9PF	5322 122 34107
C 2747	-10+50% 68UF	4822 124 20689	C 4011	2% 100PF	4822 122 31316
C 2748	-20+50% 10NF	4822 122 31414	C 4020	63V 10% 100NF	5322 121 43083
C 2751	-10+50% 47UF	4822 124 20699	C 4021	-10+50% 47UF	4822 124 20699
C 2752	-20+50% 10NF	4822 122 31414	C 4022	-20+50% 10NF	4822 122 31414
C 2753	-20+50% 10NF	4822 122 31414	C 4023	-20+50% 10NF	4822 122 31414
C 2754	-20+50% 10NF	4822 122 31414	C 4024	2% 47PF	4822 122 31072
C 2761	-20+50% 10NF	4822 122 31414	C 4026	0.25PF 3.9PF	5322 122 34107
C 2762	-20+50% 10NF	4822 122 31414	C 4027	2% 100PF	4822 122 31316
C 2764	-20+50% 10NF	4822 122 31414	C 4028	2% 100PF	4822 122 31316
C 2771	-20+50% 10NF	4822 122 31414	C 4029	2% 100PF	4822 122 31316
C 2772	-10+50% 150UF	4822 124 20672	C 4010	-20+50% 10NF	4822 122 31414
C 2773	-20+50% 10NF	4822 122 31414	C 4103	-20+50% 10NF	4822 122 31414
C 2774	-10+50% 68UF	4822 124 20689	C 4105	63V 10% 100NF	5322 121 43083
C 2776	-20+50% 10NF	4822 122 31414	C 4106	-10+50% 150UF	4822 124 20672
C 2777	63V 10% 100NF	5322 121 43083	C 4107	-20+50% 10NF	4822 122 31414
C 2781	-20+50% 10NF	4822 122 31414	C 4108	2% 100PF	4822 122 31316
C 3001	-20+50% 10NF	4822 122 31414	C 4109	-20+50% 10NF	4822 122 31414
C 3002	10% 1.5NF	4822 122 31169	C 4110	63V 10% 470NF	5322 121 43085
C 3003	10% 1.5NF	4822 122 31169	C 4112	-20+50% 10NF	4822 122 31414
C 3004	7-10.0 PF MUR	5322 125 11013	C 4113	630V 1% 1NF	4822 121 50591
C 3005	2-20PF MUR	5322 125 50296	C 4114	100V 10% 10UF	5322 121 41727
C 3007	7-10.0 PF MUR	5322 125 11013	C 4116	10% 1.5NF	4822 122 31169
C 3009	2% 12PF	4822 122 31056	C 4117	2% 100PF	4822 122 31316
C 3011	2% 68PF	4822 122 31349	C 4118	-20+50% 10NF	4822 122 31414
C 3013	0.25PF 2.7PF	4822 122 31038	C 4120	100V 10% 47NF	5322 121 43088
C 3014	0.25PF 2.7PF	4822 122 31038	C 4122	63V 10% 100NF	5322 121 43083
C 3016	2-20PF MUR	5322 125 50296	C 4123	-10+50% 47UF	4822 124 20699
C 3017	-20+50% 10NF	4822 122 31414	C 4124	-20+50% 10NF	4822 122 31414
C 3018	0.25PF 5.6PF	5322 122 32163	C 4126	-10+50% 47UF	4822 124 20699
C 3021	-20+50% 10NF	4822 122 31414	C 4201	-20+50% 10NF	4822 122 31414

POSNR	DESCRIPTION	ORDERING CODE	POSNR	DESCRIPTION	ORDERING CODE
C 4209	-20+50% 10NF	4822 122 31414	C 6006	ME275 20% 1NF	5322 121 42583
C 4212	-20+50% 10NF	4822 122 31414	C 6007	-20+20% 68UF	5322 124 21938
C 4213	63V 1% 1NF	4822 121 50591	C 6008	-20+20% 68UF	5322 124 21938
C 4214	63V 10% 100NF	5322 121 43083	C 6009	63V 10% 100NF	5322 121 43083
C 4216	10% 1.5NF	4822 122 31169	C 6011	-10+50% 33UF	4822 124 20712
C 4217	2% 100PF	4822 122 31316	C 6012	2% 220PF	4822 122 30094
C 4301	63V 10% 100NF	5322 121 43083	C 6013	10% 4.7NF	4822 122 31125
C 4302	-10+50% 4.7UF	4822 124 20726	C 6014	160V 1% 33NF	5322 121 50997
C 4303	100V 10% 10NF	5322 121 43086	C 6017	2000V 5% 1.5NF	4822 121 40541
C 4304	2% 330PF	4822 122 31353	C 6018	10% 4.7NF	4822 122 31125
C 4306	-20+50% 10NF	4822 122 31414	C 6031	63V 10% 2.2NF	4822 122 30114
C 4307	-20+50% 10NF	4822 122 31414	C 6032	63V 10% 220NF	5322 121 43084
C 4311	2% 100PF	4822 122 31316	C 6033	10% 4.7NF	4822 122 31125
C 4400	10% 1NF	4822 122 30027	C 6041	63V 10% 100NF	5322 121 43083
C 4401	-20+50% 10NF	4822 122 31414	C 6042	63V 10% 100NF	5322 121 43083
C 4402	10% 1NF	4822 122 30027	C 6100	20% 6800UF	4822 124 40692
C 4403	63V 10% 100NF	5322 121 43083	C 6101	20% 6800UF	4822 124 40692
C 4404	63V 10% 100NF	5322 121 43083	C 6102	-10+50% 6800UF	4822 124 20685
C 4405	-20+50% 10NF	4822 122 31414	C 6103	-10+50% 6800UF	4822 124 20685
C 4406	63V 10% 100NF	5322 121 43083	C 6104	-10+50% 220UF	4822 124 20681
C 4407	63V 10% 100NF	5322 121 43083	C 6106	-10+50% 470UF	4822 124 20695
C 4408	63V 10% 100NF	5322 121 43083	C 6107	-10+50% 150UF	4822 124 20691
C 4409	-20+50% 10NF	4822 122 31414	C 6108	-10+50% 470UF	4822 124 20695
C 4411	-20+50% 10NF	4822 122 31414	C 6109	-10+50% 150UF	4822 124 20691
C 4412	-20+50% 10NF	4822 122 31414	C 6111	-10+50% 220UF	4822 124 20704
C 4413	-20+50% 10NF	4822 122 31414	C 6112	-10+50% 100UF	4822 124 20701
C 4414	-20+50% 10NF	4822 122 31414	C 6113	-10+50% 100UF	4822 124 20701
C 4416	10% 680PF	4822 122 30053	C 6114	-10+50% 100UF	4822 124 20701
C 4418	63V 10% 100NF	5322 121 43083	C 6116	-10+50% 68UF	4822 124 20734
C 4419	-20+50% 10NF	4822 122 31414	C 6117	-10+50% 22UF	4822 124 20731
C 4421	63V 10% 100NF	5322 121 43083	C 6119	-10+50% 22UF	4822 124 20731
C 4501	-20+50% 10NF	4822 122 31414	C 6120	-20+50% 10NF	4822 122 31414
C 4502	-20+50% 10NF	4822 122 31414	C 6121	-10+50% 22UF	4822 124 20731
C 4503	0.25PF 3.9PF	5322 122 34107	C 6122	630V 1% 680PF	5322 121 51214
C 4521	63V 10% 100NF	5322 121 43083	C 6131	63V 10% 470NF	5322 121 43085
C 4522	63V 10% 100NF	5322 121 43083	C 6132	-10+50% 100UF	4822 124 20679
C 4601	63V 10% 100NF	5322 121 43083	C 6133	63V 10% 100NF	5322 121 43083
C 4602	0.25PF 8.2PF	4822 122 31052	C 6134	10% 1NF	4822 122 30027
C 4603	0.25PF 8.2PF	4822 122 31052	C 6135	-20+50% 10NF	4822 122 31414
C 4611	-20+50% 10NF	4822 122 31414	C 6201	100V 10% 47NF	5322 121 43088
C 4612	-20+50% 10NF	4822 122 31414	C 6202	2% 47PF	4822 122 31072
C 4613	2% 10PF	4822 122 32185	C 6203	63V 10% 220NF	5322 121 43084
C 4701	10% 1NF	4822 122 30027	C 6204	63V 10% 100NF	5322 121 43083
C 4702	63V 10% 100NF	5322 121 43083	C 6205	100V 10% 22NF	5322 121 43087
C 4703	10% 1NF	4822 122 30027	C 6206	10% 1NF	4822 122 30027
C 4704	-20+50% 10NF	4822 122 31414	C 6207	10% 4.7NF	4822 122 31125
C 4804	-10+50% 150UF	4822 124 20672	C 6208	-10+50% 68UF	4822 124 20734
C 4807	-20+50% 10NF	4822 122 31414	C 6209	-20+50% 2.2NF	5322 122 50093
C 4808	-10+50% 68UF	4822 124 20689	C 6211	-20+50% 10NF	5322 122 50091
C 4811	-20+50% 10NF	4822 122 31414	C 6212	-10+10% 33PF	5322 122 33081
C 4812	-10+50% 47UF	4822 124 20699	C 6213	10% 4.7NF	4822 122 31125
C 4813	-20+50% 10NF	4822 122 31414	C 6214	20% 470PF	5322 122 50086
C 4815	-20+50% 10NF	4822 122 31414	C 6311	-20+50% 10NF	4822 122 31414
C 4816	-20+50% 10NF	4822 122 31414	C 6312	-20+50% 10NF	4822 122 31414
C 4817	-20+50% 10NF	4822 122 31414	C 6401	63V 10% 100NF	5322 121 43083
C 4818	-20+50% 10NF	4822 122 31414	C 6402	-10+50% 68UF	4822 124 20689
C 4819	-20+50% 10NF	4822 122 31414	C 6500	-10+50% 68UF	4822 124 20689
C 4820	-20+50% 10NF	4822 122 31414	C 6501	-20+50% 10NF	4822 122 31414
C 4821	-20+50% 10NF	4822 122 31414	C 6502	100V 10% 10NF	5322 121 43086
C 4822	-20+50% 10NF	4822 122 31414	C 6503	2% 100PF	4822 122 31316
C 4824	-20+50% 10NF	4822 122 31414	C 6506	2% 100PF	4822 122 31316
C 4825	-20+50% 10NF	4822 122 31414	C 7001	63V 10% 220NF	5322 121 43084
C 4826	-20+50% 10NF	4822 122 31414	C 7002	2% 39PF	4822 122 31069
C 4828	-20+50% 10NF	4822 122 31414	C 7003	2% 39PF	4822 122 31069
C 4829	-20+50% 10NF	4822 122 31414	C 7004	-20+50% 10NF	4822 122 31414
C 4830	-20+50% 10NF	4822 122 31414	C 7005	63V 10% 100NF	5322 121 43083
C 4831	-20+50% 10NF	4822 122 31414	C 7006	-20+50% 10NF	4822 122 31414
C 4832	-10+50% 47UF	4822 124 20699	C 7007	63V 10% 100NF	5322 121 43083
C 4833	-20+50% 10NF	4822 122 31414	C 7008	10% 680PF	4822 122 30053
C 4835	-20+50% 10NF	4822 122 31414	C 7009	63V 10% 100NF	5322 121 43083
C 4836	-20+50% 10NF	4822 122 31414	C 7011	-20+50% 10NF	4822 122 31414
C 4837	-10+50% 47UF	4822 124 20699	C 7012	-20+50% 10NF	4822 122 31414
C 4838	-10+50% 47UF	4822 124 20699	C 7013	-20+50% 10NF	4822 122 31414
C 4839	2% 12PF	4822 122 31056	C 7017	-20+50% 10NF	4822 122 31414
C 4841	2% 12PF	4822 122 31056	C 7018	-20+50% 10NF	4822 122 31414
C 5001	-20+50% 10NF	4822 122 31414	C 7019	-20+50% 10NF	4822 122 31414
C 5002	-20+50% 10NF	4822 122 31414	C 7100	-20+50% 10NF	4822 122 31414
C 5003	-20+50% 10NF	4822 122 31414	C 7101	63V 10% 100NF	5322 121 43083
C 5004	-20+50% 10NF	4822 122 31414	C 7102	63V 10% 220NF	5322 121 43084
C 5006	-20+50% 10NF	4822 122 31414	C 7103	-20+50% 10NF	4822 122 31414
C 6001	250V 10% 220NF	5322 121 44142	C 7104	-10+50% 68UF	4822 124 20689
C 6002	ME275 20% 1NF	5322 121 42583	C 7106	-10+50% 68UF	4822 124 20689
C 6003	63V 10% 100NF	5322 121 43083			
C 6004	63V 10% 100NF	5322 121 43083			
C 6005	-20+50% 1.5NF	5322 122 50092			

## 16.4.2 RESISTORS

POSNR	DESCRIPTION	ORDERING CODE	POSNR	DESCRIPTION	ORDERING CODE
R 201	0.3W 25% 2K2	5322 116 20033	R 1055	MRS25 1% 1K78	5322 116 53208
R 202	MRS25 1% 16K2	5322 116 53589	R 1056	0.25% 375E	5322 116 53407
R 203	MRS25 1% 1K33	5322 116 53512	R 1057	0.25% 150E	5322 116 53399
R 204	MRS25 1% 1K33	5322 116 53512	R 1058	0.25% 150E	5322 116 53399
R 206	MRS25 1% 100E	5322 116 53126	R 1061	MRS25 1% 237E	5322 116 53259
R 207	MRS25 1% 100E	5322 116 53126	R 1062	MRS25 1% 133E	5322 116 53424
R 208	MRS25 1% 7K5	4822 116 53028	R 1063	MRS25 1% 26K1	5322 116 53261
R 209	0.3W 25% 2K2	5322 116 20033	R 1064	0.3W 25% 10K	4822 105 10455
R 211	MRS25 1% 348E	5322 116 53591	R 1066	MRS25 1% 16K2	5322 116 53589
R 213	MRS25 1% 51E1	5322 116 53213	R 1067	MRS25 1% 12K1	4822 116 52957
R 214	MRS25 1% 23K7	5322 116 53537	R 1068	MRS25 1% 133E	5322 116 53424
R 216	MRS25 1% 287E	5322 116 53221	R 1069	0.3W 25% 100E	5322 105 20029
R 217	MRS25 1% 287E	5322 116 53221	R 1071	MRS25 1% 26K1	5322 116 53261
R 218	MRS25 1% 100E	5322 116 53126	R 1072	0.3W 25% 10K	4822 105 10455
R 219	MRS25 1% 825E	5322 116 53541	R 1073	MRS25 1% 4K64	5322 116 53212
R 221	MRS25 1% 6K19	5322 116 53263	R 1074	MRS25 1% 5K62	5322 116 53495
R 222	MRS25 1% 1K78	5322 116 53208	R 1076	0.3W 25% 100E	5322 105 20029
R 223	0.3W 1% 470E	5322 105 20028	R 1077	MRS25 1% 31E6	5322 116 54964
R 224	MRS25 1% 10E	4822 116 52891	R 1078	MRS25 1% 12K1	4822 116 52957
R 226	MRS25 1% 825E	5322 116 53541	R 1079	MRS25 1% 1K62	5322 116 53257
R 227	MRS25 1% 1K33	5322 116 53512	R 1081	MRS25 1% 511E	5322 116 53135
R 228	MRS25 1% 287E	5322 116 53221	R 1082	MRS25 1% 100K	4822 116 52973
R 229	MRS25 1% 51E1	5322 116 53213	R 1083	MRS25 1% 11K	4822 116 52907
R 231	MRS25 1% 1K21	4822 116 52956	R 1084	MRS25 1% 82K5	5322 116 53581
R 232	MRS25 1% 1K	4822 116 53108	R 1086	MRS25 1% 12K1	4822 116 52957
R 233	MRS25 1% 348E	5322 116 53591	R 1087	MRS25 1% 1M	4822 116 52843
R 251	MRS25 1% 5E11	4822 116 52999	R 1088	MRS25 1% 100E	5322 116 53126
R 252	MRS25 1% 5E11	4822 116 52999	R 1089	MRS25 1% 422E	5322 116 53592
R 253	MRS25 1% 5E11	4822 116 52999	R 1091	0.3W 25% 100E	5322 105 20029
R 401	MRS25 1% 10E	4822 116 52891	R 1092	MRS25 1% 10E	4822 116 52891
R 402	MRS25 1% 10E	4822 116 52891	R 1093	MRS25 1% 422E	5322 116 53592
R 403	MRS25 1% 100E	5322 116 53126	R 1094	MRS25 1% 100E	5322 116 53126
R 404	MRS25 1% 100E	5322 116 53126	R 1096	MRS25 1% 100E	5322 116 53126
R 406	MRS25 1% 1E	4822 116 52976	R 1097	MRS25 1% 100E	5322 116 53126
R 407	MRS25 1% 10E	4822 116 52891	R 1098	MRS25 1% 1K21	4822 116 52956
R 408	MRS25 1% 5K11	5322 116 53494	R 1099	MRS25 1% 1K21	4822 116 52956
R 409	MRS25 1% 5K11	5322 116 53494	R 1101	MRS25 1% 1K	4822 116 53108
R 411	MRS25 1% 100E	4822 116 53108	R 1102	MRS25 1% 42E2	5322 116 53515
R 421	MRS25 1% 5E11	4822 116 52999	R 1103	MRS25 1% 61E9	5322 116 53645
R 422	MRS25 1% 5E11	4822 116 52999	R 1104	0.25% 10K1	5322 116 53404
R 423	MRS25 1% 5E11	4822 116 52999	R 1106	MRS25 1% 61E9	5322 116 53645
R 1001	MRS25 1% 1K	4822 116 53108	R 1107	0.25% 900K	5322 116 53414
R 1002	MRS25 1% 42E2	5322 116 53515	R 1108	MRS25 1% 10K	4822 116 53022
R 1003	MRS25 1% 61E9	5322 116 53645	R 1109	MRS25 1% 21K5	5322 116 53241
R 1004	0.25% 10K1	5322 116 53404	R 1111	0.25% 111K	5322 116 53409
R 1006	MRS25 1% 61E9	5322 116 53645	R 1112	0.25% 750K	5322 116 53588
R 1007	0.25% 900K	5322 116 53414	R 1113	0.25% 1M	5322 116 53398
R 1008	MRS25 1% 10K	4822 116 53022	R 1114	MRS25 1% 10K	4822 116 53022
R 1009	MRS25 1% 21K5	5322 116 53241	R 1116	MRS25 1% 21K5	5322 116 53241
R 1011	0.25% 111K	5322 116 53409	R 1117	0.25% 250K	5322 116 53587
R 1012	0.25% 750K	5322 116 53588	R 1118	MRS25 1% 10E	4822 116 52891
R 1013	0.25% 1M	5322 116 53398	R 1119	0.25% 990K	5322 116 53415
R 1014	MRS25 1% 10K	4822 116 53022	R 1122	MRS25 1% 61E9	5322 116 53645
R 1016	MRS25 1% 21K5	5322 116 53241	R 1123	VR25 10% 22M	5322 116 51785
R 1017	0.25% 250K	5322 116 53587	R 1124	MRS25 1% 10E	4822 116 52891
R 1018	MRS25 1% 10E	4822 116 52891	R 1126	MRS25 1% 51E1	5322 116 53213
R 1019	0.25% 990K	5322 116 53415	R 1127	VR25 10% 22M	5322 116 51785
R 1022	MRS25 1% 61E9	5322 116 53645	R 1128	MRS25 1% 10E	4822 116 52891
R 1023	VR25 10% 22M	5322 116 51785	R 1129	0.25% 1M	5322 116 53398
R 1024	MRS25 1% 10E	4822 116 52891	R 1131	VR25 10% 22M	5322 116 51785
R 1026	MRS25 1% 51E1	5322 116 53213	R 1132	MRS25 1% 10E	4822 116 52891
R 1027	VR25 10% 22M	5322 116 51785	R 1133	VR25 10% 22M	5322 116 51785
R 1028	MRS25 1% 10E	4822 116 52891	R 1134	MRS25 1% 1M	4822 116 52843
R 1029	0.25% 1M	5322 116 53398	R 1135	MRS25 1% 100E	5322 116 53126
R 1031	VR25 10% 22M	5322 116 51785	R 1136	0.3W 25% 22K	5322 105 20035
R 1032	MRS25 1% 10E	4822 116 52891	R 1137	MRS25 1% 100K	4822 116 52973
R 1033	VR25 10% 22M	5322 116 51785	R 1138	VR25 10% 22M	5322 116 51785
R 1034	MRS25 1% 1M	4822 116 52843	R 1139	MRS25 1% 1K96	5322 116 53237
R 1035	MRS25 1% 100E	5322 116 53126	R 1140	MRS25 1% 287E	5322 116 53221
R 1036	0.3W 25% 22K	5322 105 20035	R 1141	MRS25 1% 1K96	5322 116 53237
R 1037	MRS25 1% 100K	4822 116 52973	R 1143	MRS25 1% 100E	5322 116 53126
R 1038	VR25 10% 22M	5322 116 51785	R 1144	MRS25 1% 825E	5322 116 53541
R 1039	MRS25 1% 1K96	5322 116 53237	R 1145	MRS25 1% 100E	5322 116 53126
R 1040	MRS25 1% 287E	5322 116 53221	R 1146	MRS25 1% 511E	5322 116 53135
R 1041	MRS25 1% 1K96	5322 116 53237	R 1147	MRS25 1% 2K15	5322 116 53239
R 1043	MRS25 1% 100E	5322 116 53126	R 1153	0.25% 250E	5322 116 53406
R 1044	MRS25 1% 825E	5322 116 53541	R 1154	MRS25 1% 100E	5322 116 53126
R 1045	MRS25 1% 100E	5322 116 53126	R 1155	MRS25 1% 1K78	5322 116 53208
R 1046	MRS25 1% 511E	5322 116 53135	R 1156	0.25% 375E	5322 116 53407
R 1047	MRS25 1% 2K15	5322 116 53239	R 1157	0.25% 150E	5322 116 53399
R 1048	MRS25 1% 5K11	5322 116 53494	R 1158	0.25% 150E	5322 116 53399
R 1049	MRS25 1% 1K47	5322 116 53185	R 1161	MRS25 1% 237E	5322 116 53259
R 1050	MRS25 1% 100E	5322 116 53126	R 1162	MRS25 1% 133E	5322 116 53424
R 1051	MRS25 1% 681E	4822 116 53123	R 1163	MRS25 1% 26K1	5322 116 53261
R 1052	MRS25 1% 1K78	5322 116 53208	R 1164	0.3W 25% 10K	4822 105 10455
R 1053	0.25% 250E	5322 116 53406			
R 1054	MRS25 1% 100E	5322 116 53126			

POSNR	DESCRIPTION	ORDERING CODE	POSNR	DESCRIPTION	ORDERING CODE
R 1166	MRS25 1% 16K2	5322 116 53589	R 2221	MRS25 1% 19K6	5322 116 53258
R 1167	MRS25 1% 12K1	4822 116 52957	R 2222	MRS25 1% 1K96	5322 116 53337
R 1168	MRS25 1% 133E	5322 116 53424	R 2225	MRS25 1% 23K7	5322 116 53337
R 1169	0 .3W 25% 100E	5322 105 20029	R 2230	MRS25 1% 316E	5322 116 53514
R 1171	MRS25 1% 26K1	5322 116 53261	R 2231	MRS25 1% 261E	5322 116 53549
R 1172	0 .3W 25% 10K	4822 105 10455	R 2232	MRS25 1% 383E	5322 116 53332
R 1173	MRS25 1% 4K64	5322 116 53212	R 2234	MRS25 1% 42E2	5322 116 5315
R 1174	MRS25 1% 5K62	5322 116 53495	R 2236	MRS25 1% 681E	4822 116 53123
R 1176	0 .3W 25% 100E	5322 105 20029	R 2237	MRS25 1% 383E	5322 116 53332
R 1177	MRS25 1% 31E6	5322 116 53964	R 2239	MRS25 1% 348E	5322 116 53591
R 1178	MRS25 1% 12K1	4822 116 52957	R 2241	MRS25 1% 1K	4822 116 53108
R 1179	MRS25 1% 1K62	5322 116 53257	R 2242	MRS25 1% 383E	5322 116 53332
R 1181	MRS25 1% 511E	5322 116 53135	R 2243	MRS25 1% 681E	4822 116 53123
R 1182	MRS25 1% 100K	4822 116 52973	R 2244	MRS25 1% 42E2	5322 116 53515
R 1183	MRS25 1% 11K	4822 116 52907	R 2246	MRS25 1% 261E	5322 116 53549
R 1184	MRS25 1% 82K5	5322 116 53581	R 2247	MRS25 1% 383E	5322 116 53332
R 1186	MRS25 1% 12K1	4822 116 52957	R 2251	MRS25 1% 75E	5322 116 53339
R 1187	MRS25 1% 1M	4822 116 52843	R 2252	MRS25 1% 750E	5322 116 53265
R 1188	MRS25 1% 100E	5322 116 53126	R 2253	MRS25 1% 750E	5322 116 53265
R 1189	MRS25 1% 422E	5322 116 53592	R 2254	MRS25 1% 75E	5322 116 53339
R 1191	0 .3W 25% 100E	5322 105 20029	R 2255	MRS25 1% 287E	5322 116 53221
R 1192	MRS25 1% 10E	4822 116 52891	R 2301	MRS25 1% 19K6	5322 116 53258
R 1193	MRS25 1% 422E	5322 116 53592	R 2302	MRS25 1% 19K6	5322 116 53258
R 1194	MRS25 1% 100E	5322 116 53126	R 2303	MRS25 1% 5K62	5322 116 53495
R 1196	MRS25 1% 100E	5322 116 53126	R 2304	MRS25 1% 5K62	5322 116 53495
R 1197	MRS25 1% 100E	5322 116 53126	R 2311	MRS25 1% 2K87	5322 116 53513
R 1198	MRS25 1% 1K21	4822 116 52956	R 2317	MRS25 1% 681E	4822 116 53123
R 1199	MRS25 1% 1K21	4822 116 52956	R 2318	MRS25 1% 681E	4822 116 53123
R 1201	MRS25 1% 1K	4822 116 53108	R 2319	MRS25 1% 5E11	4822 116 52999
R 1202	MRS25 1% 61E9	5322 116 53645	R 2324	MRS25 1% 5K62	5322 116 53495
R 1203	0 .1% 1M	5322 116 51605	R 2325	MRS25 1% 5K62	5322 116 53495
R 1204	VR25 10% 22M	5322 116 51785	R 2326	MRS25 1% 2K87	5322 116 53513
R 1206	MRS25 1% 1K96	5322 116 53237	R 2327	MRS25 1% 3K83	4822 116 53079
R 1207	MRS25 1% 100E	5322 116 53126	R 2328	MRS25 1% 2K87	5322 116 53513
R 1208	MRS25 1% 825E	5322 116 53541	R 2329	MRS25 1% 825E	5322 116 53541
R 1209	MRS25 1% 1M	4822 116 52843	R 2330	0 .3W 25% 10K	4822 105 10455
R 1211	MRS25 1% 100E	5322 116 53126	R 2333	MRS25 1% 5K62	5322 116 53495
R 1213	MRS25 1% 1M	4822 116 52843	R 2334	MRS25 1% 5K62	5322 116 53495
R 1217	0 .3W 25% 22K	5322 105 20035	R 2335	MRS25 1% 10K	4822 116 53022
R 1218	MRS25 1% 100K	4822 116 52973	R 2336	MRS25 1% 31E6	5322 116 54964
R 1219	MRS25 1% 1K47	5322 116 53185	R 2337	MRS25 1% 162E	5322 116 53523
R 1221	MRS25 1% 681E	4822 116 53123	R 2338	MRS25 1% 2K61	5322 116 53327
R 1222	MRS25 1% 2K87	5322 116 53513	R 2339	MRS25 1% 237E	5322 116 53259
R 1223	MRS25 1% 1K33	5322 116 53512	R 2341	MRS25 1% 31E6	5322 116 54964
R 1224	MRS25 1% 1K	4822 116 53108	R 2342	MRS25 1% 162E	5322 116 53523
R 1226	MRS25 1% 5K11	5322 116 53494	R 2344	MRS25 1% 511E	5322 116 53135
R 1227	MRS25 1% 1K33	5322 116 53512	R 2345	MRS25 1% 100E	5322 116 53126
R 1228	MRS25 1% 100E	5322 116 53126	R 2346	MRS25 1% 681E	4822 116 53123
R 1229	MRS25 1% 750E	5322 116 53265	R 2348	MRS25 1% 8K25	5322 116 53267
R 1231	MRS25 1% 750E	5322 116 53265	R 2350	MRS25 1% 4K22	5322 116 53246
R 1232	MRS25 1% 1E	4822 116 52976	R 2351	MRS25 1% 562E	5322 116 53214
R 1233	MRS25 1% 348E	5322 116 53591	R 2352	MRS25 1% 825E	5322 116 53541
R 1234	MRS25 1% 100E	5322 116 53126	R 2357	MRS25 1% 681E	4822 116 53123
R 1236	MRS25 1% 162E	5322 116 53523	R 2358	MRS25 1% 511E	5322 116 53135
R 1237	MRS25 1% 2K61	5322 116 53327	R 2360	MRS25 1% 100E	5322 116 53126
R 1238	MRS25 1% 100E	5322 116 53126	R 2361	MRS25 1% 4K22	5322 116 53246
R 1239	MRS25 1% 7K5	4822 116 53028	R 2365	MRS25 1% 23K7	5322 116 53537
R 1401	MRS25 1% 5E11	4822 116 52999	R 2366	MRS25 1% 10K	4822 116 53022
R 1402	MRS25 1% 5E11	4822 116 52999	R 2367	MRS25 1% 16K2	5322 116 53589
R 1403	MRS25 1% 5E11	4822 116 52999	R 2369	MRS25 1% 68K1	5322 116 53338
R 1404	MRS25 1% 5E11	4822 116 52999	R 2371	MRS25 1% 42E2	5322 116 53592
R 1421	MRS25 1% 5E11	4822 116 52999	R 2372	MRS25 1% 511E	5322 116 53135
R 1422	MRS25 1% 5E11	4822 116 52999	R 2373	MRS25 1% 75K	5322 116 53266
R 1423	MRS25 1% 5E11	4822 116 52999	R 2374	MRS25 1% 511E	5322 116 53135
R 1424	MRS25 1% 5E11	4822 116 52999	R 2375	MRS25 1% 23K7	5322 116 53537
R 1441	MRS25 1% 100E	5322 116 53126	R 2376	VR25 10% 22M	5322 116 51785
R 1442	MRS25 1% 5E11	4822 116 52999	R 2377	VR25 10% 22M	5322 116 51785
R 1443	MRS25 1% 5E11	4822 116 52999	R 2378	VR25 10% 22M	5322 116 51785
R 2001	MRS25 1% 10E	4822 116 52891	R 2379	VR25 10% 22M	5322 116 51785
R 2002	MRS25 1% 10E	4822 116 52891	R 2380	MRS25 1% 750E	5322 116 53265
R 2003	MRS25 1% 51E1	5322 116 53213	R 2381	MRS25 1% 2K61	5322 116 53327
R 2004	MRS25 1% 51E1	5322 116 53213	R 2382	MRS25 1% 2K61	5322 116 53327
R 2101	MRS25 1% 10E	4822 116 52891	R 2383	MRS25 1% 1K	4822 116 53108
R 2102	MRS25 1% 10E	4822 116 52891	R 2384	MRS25 1% 750E	5322 116 53265
R 2103	MRS25 1% 51E1	5322 116 53213	R 2386	MRS25 1% 1K	4822 116 53108
R 2104	MRS25 1% 51E1	5322 116 53213	R 2387	MRS25 1% 750E	5322 116 53265
R 2201	MRS25 1% 75K	5322 116 53266	R 2388	MRS25 1% 1K	4822 116 53108
R 2202	MRS25 1% 12K1	4822 116 52957	R 2389	MRS25 1% 1K	4822 116 53108
R 2203	MRS25 1% 215K	5322 116 53425	R 2391	MRS25 1% 42E2	5322 116 53515
R 2204	MRS25 1% 10K	4822 116 53022	R 2393	MRS25 1% 3K48	4822 116 53315
R 2205	MRS25 1% 2K15	5322 116 53239	R 2394	MRS25 1% 100E	5322 116 53126
R 2206	MRS25 1% 75K	5322 116 53266	R 2395	0 .3W 25% 220E	5322 105 20031
R 2207	MRS25 1% 12K1	4822 116 52957	R 2396	MRS25 1% 3K48	4822 116 53315
R 2208	MRS25 1% 215K	5322 116 53425	R 2397	MRS25 1% 42E2	5322 116 53515
R 2209	MRS25 1% 10K	4822 116 53022	R 2398	MRS25 1% 237E	5322 116 53259
R 2210	MRS25 1% 2K15	5322 116 53239	R 2403	MRS25 1% 42E2	5322 116 53515
R 2211	MRS25 1% 5K62	5322 116 53495	R 2404	MRS25 1% 619E	5322 116 53337
R 2212	0 .3W 25% 10K	4822 105 10455	R 2406	MRS25 1% 1K62	5322 116 53257
R 2213	MRS25 1% 23K7	5322 116 53537	R 2407	0 .3W 25% 220E	5322 105 20031
R 2214	MRS25 1% 10K	4822 116 53022	R 2408	MRS25 1% 1K33	5322 116 53512
R 2215	MRS25 1% 2K15	5322 116 53239	R 2409	MRS25 1% 1K62	5322 116 53257
R 2216	MRS25 1% 5K62	5322 116 53495	R 2410	0 .3W 25% 1K	5322 105 20032
R 2217	MRS25 1% 100K	4822 116 52973	R 2411	MRS25 1% 42E2	5322 116 53515
R 2218	MRS25 1% 4K64	5322 116 53212	R 2412	MRS25 1% 619E	5322 116 53337
R 2219	MRS25 1% 316K	4822 116 53058	R 2416	MRS25 1% 1K	4822 116 53108

POSNR	DESCRIPTION	ORDERING CODE	POSNR	DESCRIPTION	ORDERING CODE
R 2418	MRS25 1% 4K22	5322 116 53246	R 3023	MRS25 1% 348E	5322 116 53591
R 2419	MRS25 1% 1K1	5322 116 53473	R 3024	MRS25 1% 750E	5322 116 53265
R 2420	MRS25 1% 825E	5322 116 53591	R 3025	MRS25 1% 10E	4822 116 52891
R 2421	MRS25 1% 4K22	5322 116 53246	R 3026	MRS25 1% 464E	5322 116 53232
R 2422	MRS25 1% 1K	4822 116 53108	R 3027	MRS25 1% 42E2	5322 116 53515
R 2430	MRS25 1% 100K	4822 116 52973	R 3028	MRS25 1% 42E2	5322 116 53515
R 2431	MRS25 1% 100K	4822 116 52973	R 3029	MRS25 1% 3K16	4822 116 53021
R 2432	MRS25 1% 100K	4822 116 52973	R 3031	MRS25 1% 402E	5322 116 53639
R 2433	MRS25 1% 100K	4822 116 52973	R 3032	MRS25 1% 31E6	5322 116 54964
R 2434	MRS25 1% 10K	4822 116 53022	R 3033	MRS25 1% 100E	5322 116 53126
R 2435	MRS25 1% 10K	4822 116 53022	R 3034	MRS25 1% 162E	5322 116 53523
R 2501	MRS25 1% 19K6	5322 116 53258	R 3036	0 .3W 25% 100E	5322 105 20029
R 2502	MRS25 1% 19K6	5322 116 53258	R 3037	MRS25 1% 100E	5322 116 53126
R 2503	MRS25 1% 5K62	5322 116 53495	R 3038	0 .3W 25% 470E	5322 105 20028
R 2504	MRS25 1% 2K87	5322 116 53513	R 3039	MRS25 1% 42E2	5322 116 53515
R 2522	MRS25 1% 5K62	5322 116 53495	R 3041	MRS25 1% 31E6	5322 116 53514
R 2523	MRS25 1% 5K62	5322 116 53495	R 3042	MRS25 1% 110E	4822 116 52906
R 2527	MRS25 1% 100K	4822 116 52973	R 3043	MRS25 1% 110E	4822 116 52906
R 2528	MRS25 1% 12K1	4822 116 52957	R 3044	MRS25 1% 110E	4822 116 52906
R 2529	MRS25 1% 316K	4822 116 53058	R 3046	MRS25 1% 110E	4822 116 52906
R 2541	MRS25 1% 162E	5322 116 53523	R 3047	MRS25 1% 42E2	5322 116 53515
R 2542	MRS25 1% 1K62	5322 116 53257	R 3048	MRS25 1% 42E2	5322 116 53515
R 2543	MRS25 1% 681E	4822 116 53123	R 3049	MRS25 1% 100K	4822 116 52973
R 2544	MRS25 1% 121E	4822 116 52955	R 3050	MRS25 1% 42E2	5322 116 53515
R 2547	MRS25 1% 511E	5322 116 53135	R 3051	MRS25 1% 100K	4822 116 52973
R 2548	MRS25 1% 1K21	4822 116 52956	R 3052	MRS25 1% 42E2	5322 116 53515
R 2549	MRS25 1% 1K33	5322 116 53512	R 3060	MRS25 1% 110E	4822 116 52906
R 2551	MRS25 1% 162E	5322 116 53523	R 3061	MRS25 1% 110E	4822 116 52906
R 2552	MRS25 1% 681E	4822 116 53123	R 3062	MRS25 1% 110E	4822 116 52906
R 2553	MRS25 1% 1K62	5322 116 53257	R 3063	MRS25 1% 110E	4822 116 52906
R 2554	MRS25 1% 42E2	5322 116 53515	R 3064	MRS25 1% 110E	4822 116 52906
R 2555	MRS25 1% 8K25	5322 116 53267	R 3066	MRS25 1% 110E	4822 116 52906
R 2556	MRS25 1% 42E2	5322 116 53515	R 3067	MRS25 1% 110E	4822 116 52906
R 2557	MRS25 1% 4K22	5322 116 53266	R 3068	MRS25 1% 110E	4822 116 52906
R 2558	MRS25 1% 4K22	5322 116 53266	R 3100	MRS25 1% 42E2	5322 116 53515
R 2559	MRS25 1% 100E	5322 116 53126	R 3101	MRS25 1% 5K62	5322 116 53495
R 2601	MRS25 1% 3K48	4822 116 53315	R 3102	MRS25 1% 562E	5322 116 53214
R 2602	MRS25 1% 5E11	4822 116 52999	R 3103	MRS25 1% 1K21	4822 116 52956
R 2603	MRS25 1% 5K11	5322 116 53494	R 3104	MRS25 1% 6K81	5322 116 53252
R 2604	MRS25 1% 5K11	5322 116 53494	R 3106	MRS25 1% 42E2	5322 116 53515
R 2605	MRS25 1% 12K1	4822 116 52957	R 3107	MRS25 1% 2K87	5322 116 53513
R 2606	MRS25 1% 1E	4822 116 52976	R 3108	MRS25 1% 825E	5322 116 53541
R 2610	MRS25 1% 10K	4822 116 53022	R 3109	MRS25 1% 6K19	5322 116 53263
R 2611	MRS25 1% 1K	4822 116 53108	R 3110	MRS25 1% 42E2	5322 116 53515
R 2621	MRS25 1% 422E	5322 116 53592	R 3111	MRS25 1% 42E2	5322 116 53515
R 2622	MRS25 1% 681E	4822 116 53123	R 3112	MRS25 1% 7K5	4822 116 53028
R 2623	MRS25 1% 1K1	5322 116 53473	R 3113	MRS25 1% 1K21	4822 116 52956
R 2624	MRS25 1% 3K48	4822 116 53315	R 3114	MRS25 1% 5K62	5322 116 53495
R 2625	MRS25 1% 681E	4822 116 53123	R 3115	MRS25 1% 42E2	5322 116 53515
R 2626	MRS25 1% 6K81	5322 116 53252	R 3116	MRS25 1% 562E	5322 116 53214
R 2627	MRS25 1% 287E	5322 116 53221	R 3117	MRS25 1% 4K64	5322 116 53212
R 2628	MRS25 1% 2K37	5322 116 53536	R 3118	0 .3W 25% 1K	5322 105 20032
R 2629	MRS25 1% 10K	4822 116 53022	R 3119	MRS25 1% 4K64	5322 116 53212
R 2631	MRS25 1% 10K	4822 116 53022	R 3120	MRS25 1% 42E2	5322 116 53515
R 2632	MRS25 1% 383E	5322 116 53332	R 3121	MRS25 1% 46K4	5322 116 53314
R 2635	MRS25 1% 10K	4822 116 53022	R 3122	MRS25 1% 6K81	5322 116 53252
R 2701	MRS25 1% 1E	4822 116 52976	R 3124	MRS25 1% 619E	5322 116 53337
R 2702	MRS25 1% 10E	4822 116 52891	R 3125	MRS25 1% 42E2	5322 116 53515
R 2703	MRS25 1% 5E11	4822 116 52999	R 3126	MRS25 1% 14K7	4822 116 53531
R 2704	MRS25 1% 5E11	4822 116 52999	R 3127	MRS25 1% 1K33	5322 116 53512
R 2712	MRS25 1% 5E11	4822 116 52999	R 3128	MRS25 1% 825E	5322 116 53541
R 2713	MRS25 1% 5E11	4822 116 52999	R 3129	MRS25 1% 1K1	5322 116 53473
R 2714	MRS25 1% 5E11	4822 116 52999	R 3130	MRS25 1% 42E2	5322 116 53515
R 2721	MRS25 1% 5E11	4822 116 52999	R 3131	MRS25 1% 1K33	5322 116 53512
R 2722	MRS25 1% 5E11	4822 116 52999	R 3132	MRS25 1% 825E	5322 116 53541
R 2723	MRS25 1% 5E11	4822 116 52999	R 3133	MRS25 1% 6K19	5322 116 53263
R 2724	MRS25 1% 5E11	4822 116 52999	R 3134	MRS25 1% 14K7	4822 116 53531
R 2727	MRS25 1% 5E11	4822 116 52999	R 3136	MRS25 1% 1K	4822 116 53108
R 2733	MRS25 1% 5E11	4822 116 52999	R 3137	MRS25 1% 46K4	5322 116 53314
R 2740	MRS25 1% 5E11	4822 116 52999	R 3138	MRS25 1% 6K81	5322 116 53252
R 2741	MRS25 1% 316E	5322 116 54964	R 3139	MRS25 1% 619E	5322 116 53337
R 2742	MRS25 1% 5E11	4822 116 52999	R 3141	MRS25 1% 316E	5322 116 53514
R 3001	MRS25 1% 147E	5322 116 53569	R 3142	MRS25 1% 6K81	5322 116 53514
R 3002	MRS25 1% 316E	5322 116 53514	R 3143	MRS25 1% 10E	4822 116 52891
R 3003	MRS25 1% 1K47	5322 116 53185	R 3144	MRS25 1% 10E	4822 116 52891
R 3004	MRS25 1% 422E	5322 116 53592	R 3147	0 .5W 10% 3K3	5322 116 30234
R 3006	MRS25 1% 2K37	5322 116 53536	R 3148	MRS25 1% 9K09	5322 116 53253
R 3007	0 .3W 25% 2K2	5322 116 20033	R 3200	MRS25 1% 6K81	5322 116 53252
R 3008	MRS25 1% 121E	4822 116 52955	R 3201	MRS25 1% 1K21	4822 116 52956
R 3009	MRS25 1% 3K83	4822 116 53079	R 3202	MRS25 1% 100E	5322 116 53126
R 3011	MRS25 1% 121E	4822 116 52955	R 3203	MRS25 1% 16K2	5322 116 53589
R 3012	MRS25 1% 316E	5322 116 53514	R 3204	MRS25 1% 562E	5322 116 53214
R 3013	0 .3W 25% 10K	4822 116 10455	R 3205	MRS25 1% 4K64	5322 116 53212
R 3014	MRS25 1% 2K87	5322 116 53513	R 3206	MRS25 1% 4K64	5322 116 53212
R 3015	MRS25 1% 316E	5322 116 53514	R 3207	MRS25 1% 82K5	5322 116 53581
R 3016	MRS25 1% 2K37	5322 116 53536	R 3208	MRS25 1% 7K5	4822 116 53028
R 3017	0 .3W 25% 22K	5322 116 20035	R 3209	MRS25 1% 1K	4822 116 53108
R 3018	MRS25 1% 8K25	5322 116 53267	R 3210	MRS25 1% 42E2	5322 116 53515
R 3020	MRS25 1% 10E	4822 116 52891	R 3211	MRS25 1% 10K	4822 116 53022
R 3021	MRS25 1% 464E	5322 116 53232	R 3212	MRS25 1% 1K47	5322 116 53185
R 3022	MRS25 1% 750E	5322 116 53265	R 3213	MRS25 1% 23K7	5322 116 53537
			R 3214	MRS25 1% 31K6	5322 116 53262
			R 3215	MRS25 1% 4K64	5322 116 53212

POSNR	DESCRIPTION	ORDERING CODE	POSNR	DESCRIPTION	ORDERING CODE
R 3216	MRS25 1% 178K	5322 116 53555	R 4117	MRS25 1% 3K16	4822 116 53021
R 3217	MRS25 1% 511E	5322 116 53135	R 4118	0.25% 50E	5322 116 53405
R 3218	MRS25 1% 61K9	5322 116 53233	R 4119	0.25% 50E	5322 116 53405
R 3219	MRS25 1% 1M	4822 116 52843	R 4120	MRS25 1% 1K	4822 116 53108
R 3221	MRS25 1% 100E	5322 116 53126	R 4121	0.25% 150E	5322 116 53399
R 3222	MRS25 1% 100K	4822 116 52973	R 4122	0.25% 250E	5322 116 53406
R 3223	MRS25 1% 38K3	4822 116 53526	R 4123	0.25% 500E	5322 116 53408
R 3224	MRS25 1% 2K37	5322 116 53536	R 4124	0.25% 1K5	5322 116 53401
R 3226	MRS25 1% 100E	5322 116 53126	R 4125	MRS25 1% 100E	5322 116 53126
R 3250	MRS25 1% 2K37	5322 116 53536	R 4126	MRS25 1% 9K09	5322 116 53253
R 3251	MRS25 1% 1M	4822 116 52843	R 4127	MRS25 1% 1K62	5322 116 53257
R 3253	MRS25 1% 75K	5322 116 53266	R 4128	MRS25 1% 5K11	5322 116 53494
R 3254	MRS25 1% 1K	4822 116 53108	R 4129	MRS25 1% 1M	4822 116 52843
R 3256	MRS25 1% 178K	5322 116 53555	R 4130	MRS25 1% 1K	4822 116 53108
R 3257	MRS25 1% 825K	5322 116 53341	R 4131	MRS25 1% 5K11	5322 116 53494
R 3258	VR25 5% 3M3	4822 110 72201	R 4132	MRS25 1% 5K11	5322 116 53494
R 3259	VR25 5% 3M3	4822 110 72201	R 4133	MRS25 1% 1K	4822 116 53108
R 3261	VR25 5% 3M3	4822 110 72201	R 4134	MRS25 1% 10K	4822 116 53022
R 3262	VR25 5% 7M5	5322 116 60131	R 4135	MRS25 1% 1K	4822 116 53108
R 3263	VR25 5% 3M3	4822 110 72201	R 4136	MRS25 1% 10K	4822 116 53022
R 3267	25% 47K	5322 105 20037	R 4137	MRS25 1% 14K7	4822 116 53531
R 3268	MRS25 1% 681K	5322 116 53593	R 4138	MRS25 1% 5E11	4822 116 52999
R 3269	MRS25 1% 15K4	5322 116 53234	R 4139	MRS25 1% 10K	4822 116 53022
R 3270	MRS25 1% 23K7	5322 116 53537	R 4140	MRS25 1% 10K	4822 116 53022
R 3271	MRS25 1% 14K7	4822 116 53531	R 4141	MRS25 1% 14K7	4822 116 53531
R 3273	MRS25 1% 215K	5322 116 53425	R 4142	MRS25 1% 100E	5322 116 53126
R 3301	MRS25 1% 10E	4822 116 52891	R 4143	0.1% 20K	5322 116 52697
R 3302	MRS25 1% 1E	4822 116 52976	R 4144	0.1% 202E	5322 116 53413
R 3303	MRS25 1% 5E11	4822 116 52999	R 4145	MRS25 1% 1K	4822 116 53108
R 3304	MRS25 1% 5E11	4822 116 52999	R 4146	MRS25 1% 10K	4822 116 53022
R 3306	MRS25 1% 2K87	5322 116 53513	R 4147	MRS25 1% 511E	5322 116 53135
R 3308	MRS25 1% 10E	4822 116 52891	R 4148	MRS25 1% 21K5	5322 116 53241
R 3309	MRS25 1% 5E11	4822 116 52999	R 4149	MRS25 1% 31F6	5322 116 54964
R 3311	MRS25 1% 5E11	4822 116 52999	R 4150	MRS25 1% 9E09	5322 116 53516
R 3312	MRS25 1% 5E11	4822 116 52999	R 4151	MRS25 1% 2K61	5322 116 53327
R 3313	MRS25 1% 10E	4822 116 52891	R 4152	MRS25 1% 162E	5322 116 53523
R 4000	MRS25 1% 51E1	5322 116 53213	R 4153	MRS25 1% 1K1	5322 116 53473
R 4001	MRS25 1% 619E	5322 116 53337	R 4154	MRS25 1% 1K78	5322 116 53208
R 4002	MRS25 1% 511E	5322 116 53135	R 4155	MRS25 1% 2K15	5322 116 53239
R 4003	MRS25 1% 511E	5322 116 53135	R 4156	MRS25 1% 1M	4822 116 52843
R 4004	MRS25 1% 6K19	5322 116 53263	R 4157	MRS25 1% 1E	4822 116 52976
R 4005	MRS25 1% 100E	5322 116 53126	R 4158	MRS25 1% 1M	4822 116 52843
R 4006	MRS25 1% 51E1	5322 116 53213	R 4159	MRS25 1% 2K15	5322 116 53239
R 4007	MRS25 1% 1K47	5322 116 53185	R 4160	MRS25 1% 100E	5322 116 53126
R 4008	MRS25 1% 100E	5322 116 53126	R 4161	MRS25 1% 10K	4822 116 53022
R 4009	0.3W 25% 1K	5322 105 20032	R 4162	MRS25 1% 100E	5322 116 53126
R 4010	MRS25 1% 511E	5322 116 53135	R 4163	MRS25 1% 5E11	4822 116 52999
R 4011	MRS25 1% 5K11	5322 116 53494	R 4207	0.3W 25% 10K	4822 105 10455
R 4012	MRS25 1% 1K78	5322 116 53208	R 4208	0.3W 25% 10K	4822 105 10455
R 4013	MRS25 1% 1M	4822 116 52843	R 4209	MRS25 1% 5K11	5322 116 53494
R 4014	MRS25 1% 5K11	5322 116 53494	R 4211	MRS25 1% 12K1	4822 116 52957
R 4015	MRS25 1% 1K	4822 116 53108	R 4217	MRS25 1% 3K16	4822 116 53021
R 4016	MRS25 1% 5K11	5322 116 53494	R 4218	0.25% 50E	5322 116 53405
R 4017	MRS25 1% 2K87	5322 116 53513	R 4219	0.25% 50E	5322 116 53405
R 4018	MRS25 1% 5K11	5322 116 53494	R 4221	0.25% 150E	5322 116 53399
R 4019	MRS25 1% 681K	5322 116 53593	R 4222	0.25% 250E	5322 116 53406
R 4020	MRS25 1% 1K62	5322 116 53257	R 4223	0.25% 500E	5322 116 53408
R 4021	MRS25 1% 10K	4822 116 53022	R 4224	0.25% 1K5	5322 116 53401
R 4022	MRS25 1% 4K22	5322 116 53246	R 4239	MRS25 1% 10K	4822 116 53022
R 4023	MRS25 1% 12K1	4822 116 52957	R 4240	MRS25 1% 10K	4822 116 53022
R 4024	MRS25 1% 1K	4822 116 53108	R 4242	MRS25 1% 100E	5322 116 53126
R 4025	MRS25 1% 1K	4822 116 53108	R 4243	0.1% 20K	5322 116 52697
R 4026	MRS25 1% 5K11	5322 116 53494	R 4244	0.1% 202E	5322 116 53413
R 4030	MRS25 1% 51E1	5322 116 53213	R 4245	MRS25 1% 1K	4822 116 53108
R 4031	MRS25 1% 619E	5322 116 53337	R 4246	MRS25 1% 10K	4822 116 53022
R 4032	MRS25 1% 511E	5322 116 53135	R 4247	MRS25 1% 511E	5322 116 53135
R 4033	MRS25 1% 511E	5322 116 53135	R 4248	MRS25 1% 21K5	5322 116 53241
R 4034	MRS25 1% 1K78	5322 116 53208	R 4249	MRS25 1% 31E6	5322 116 54964
R 4035	MRS25 1% 100E	5322 116 53126	R 4250	MRS25 1% 9E09	5322 116 53516
R 4036	MRS25 1% 51E1	5322 116 53213	R 4251	MRS25 1% 2K61	5322 116 53327
R 4037	MRS25 1% 1K78	5322 116 53208	R 4252	MRS25 1% 162E	5322 116 53523
R 4038	MRS25 1% 100E	5322 116 53126	R 4253	MRS25 1% 5K11	5322 116 53494
R 4040	MRS25 1% 511E	5322 116 53135	R 4254	MRS25 1% 6K81	5322 116 53252
R 4042	MRS25 1% 1K78	5322 116 53208	R 4258	MRS25 1% 1M	4822 116 52843
R 4043	MRS25 1% 51K1	4822 116 53121	R 4259	MRS25 1% 2K15	5322 116 53239
R 4044	MRS25 1% 51K1	4822 116 53121	R 4260	MRS25 1% 100E	5322 116 53126
R 4045	MRS25 1% 681K	5322 116 53593	R 4261	MRS25 1% 10K	4822 116 53022
R 4046	MRS25 1% 10K	4822 116 53022	R 4262	MRS25 1% 100E	5322 116 53126
R 4047	MRS25 1% 4K22	5322 116 53246	R 4301	MRS25 1% 5K11	4822 116 53121
R 4048	MRS25 1% 2K61	5322 116 53327	R 4302	MRS25 1% 5K11	4822 116 53121
R 4051	MRS25 1% 10K	4822 116 53022	R 4303	MRS25 1% 6K81	5322 116 53252
R 4052	MRS25 1% 10K	4822 116 53022	R 4304	MRS25 1% 5K11	5322 116 53494
R 4101	MRS25 1% 100K	4822 116 52973	R 4305	MRS25 1% 5K11	4822 116 53121
R 4102	MRS25 1% 4K64	5322 116 53212	R 4306	MRS25 1% 681E	4822 116 53123
R 4103	MRS25 1% 11K	4822 116 52907	R 4307	MRS25 1% 5K11	5322 116 53494
R 4104	MRS25 1% 46K4	5322 116 53314	R 4308	MRS25 1% 10K	4822 116 53022
R 4106	MRS25 1% 422E	5322 116 53592	R 4309	MRS25 1% 8K25	5322 116 53267
R 4107	0.3W 25% 10K	4822 105 10455	R 4310	MRS25 1% 100E	5322 116 53126
R 4108	0.3W 25% 10K	4822 105 10455	R 4311	MRS25 1% 10K	4822 116 53022
R 4109	MRS25 1% 5K11	5322 116 53494	R 4312	MRS25 1% 9K09	5322 116 53253
R 4111	MRS25 1% 12K1	4822 116 52957			

POSNR	DESCRIPTION	ORDERING CODE	POSNR	DESCRIPTION	ORDERING CODE
R 4314	MRS25 1% 8K25	5322 116 53267	R 4719	MRS25 1% 100E	5322 116 53126
R 4330	MRS25 1% 5K11	5322 116 53494	R 4721	0.3W 25% 1K	5322 105 20032
R 4331	MRS25 1% 21K5	5322 116 53241	R 4722	MRS25 1% 46K4	5322 116 53314
R 4332	MRS25 1% 4K22	5322 116 53246	R 4723	MRS25 1% 681K	5322 116 53593
R 4334	MRS25 1% 2K15	5322 116 53239	R 4724	MRS25 1% 42E2	5322 116 53515
R 4401	MRS25 1% 2K61	5322 116 53327	R 4725	MRS25 1% 4K22	5322 116 53246
R 4402	MRS25 1% 82E5	5322 116 53538	R 4726	MRS25 1% 100K	4822 116 52973
R 4403	MRS25 1% 681E	4822 116 53123	R 4727	MRS25 1% 6K81	5322 116 53252
R 4404	MRS25 1% 2K37	5322 116 53536	R 4728	MRS25 1% 562E	5322 116 53214
R 4406	0.3W 25% 22K	5322 105 20035	R 4801	MRS25 1% 5E11	4822 116 52999
R 4407	MRS25 1% 215K	5322 116 53425	R 4804	MRS25 1% 5E11	4822 116 52999
R 4408	0.3W 25% 22K	5322 105 20035	R 4807	MRS25 1% 5E11	4822 116 52999
R 4409	MRS25 1% 10K	4822 116 53022	R 4809	MRS25 1% 5E11	4822 116 52999
R 4411	MRS25 1% 2K57	5322 116 53536	R 4816	MRS25 1% 5E11	4822 116 52999
R 4412	MRS25 1% 100E	5322 116 53126	R 4818	MRS25 1% 5E11	4822 116 52999
R 4413	MRS25 1% 6K81	5322 116 53252	R 4819	MRS25 1% 5E11	4822 116 52999
R 4414	MRS25 1% 4K64	5322 116 53212	R 4820	MRS25 1% 5E11	4822 116 52999
R 4417	MRS25 1% 1K	4822 116 53108	R 4821	MRS25 1% 5E11	4822 116 52999
R 4419	MRS25 1% 511E	5322 116 53135	R 4822	MRS25 1% 5E11	4822 116 52999
R 4420	MRS25 1% 1K21	4822 116 52956	R 4824	MRS25 1% 5E11	4822 116 52999
R 4421	MRS25 1% 10K	4822 116 53022	R 4825	MRS25 1% 5E11	4822 116 52999
R 4422	MRS25 1% 2K87	5322 116 53513	R 4826	MRS25 1% 5E11	4822 116 52999
R 4423	MRS25 1% 9K09	5322 116 53253	R 4828	MRS25 1% 5E11	4822 116 52999
R 4427	MRS25 1% 1K96	5322 116 53237	R 4829	MRS25 1% 5E11	4822 116 52999
R 4428	MRS25 1% 100E	5322 116 53126	R 4830	MRS25 1% 5E11	4822 116 52999
R 4501	MRS25 1% 13K3	5322 116 53489	R 4831	MRS25 1% 5E11	4822 116 52999
R 4502	MRS25 1% 4K22	5322 116 53246	R 4833	MRS25 1% 5E11	4822 116 52999
R 4503	MRS25 1% 6K81	5322 116 53252	R 4835	MRS25 1% 5E11	4822 116 52999
R 4504	MRS25 1% 13K3	5322 116 53489	R 4836	MRS25 1% 5E11	4822 116 52999
R 4505	MRS25 1% 511E	5322 116 53135	R 4838	MRS25 1% 100E	5322 116 53126
R 4506	MRS25 1% 2K15	5322 116 53239	R 4839	MRS25 1% 100E	5322 116 53126
R 4507	MRS25 1% 750E	5322 116 53265	R 4841	MRS25 1% 10K	4822 116 53022
R 4508	MRS25 1% 11K	4822 116 52907	R 4902	MRS25 1% 1E	4822 116 52976
R 4509	MRS25 1% 2K15	5322 116 53239	R 4903	MRS25 1% 1E	4822 116 52976
R 4513	MRS25 1% 1K47	5322 116 53185	R 4904	MRS25 1% 1E	4822 116 52976
R 4521	MRS25 1% 16K2	5322 116 53589	R 5001	PP17 20% 10K	5322 101 30546
R 4522	MRS25 1% 23K7	5322 116 53537	R 5002	PP17 20% 10K	5322 101 30547
R 4523	MRS25 1% 16K2	5322 116 53589	R 5003	PP17 20% 10K	5322 101 30546
R 4524	MRS25 1% 14K7	4822 116 53531	R 5004	PP17 20% 10K	5322 101 30546
R 4526	MRS25 1% 2K37	5322 116 53536	R 6001	1.7A 20% 82E	4822 116 30069
R 4527	MRS25 1% 19K6	5322 116 53258	R 6002	MRS25 1% 383K	5322 116 53576
R 4528	MRS25 1% 5K62	5322 116 53495	R 6003	MRS25 1% 383K	5322 116 53576
R 4529	MRS25 1% 21K5	5322 116 53241	R 6004	MRS25 1% 316E	5322 116 53514
R 4531	MRS25 1% 10K	4822 116 53022	R 6005	MRS25 1% 464E	5322 116 53232
R 4532	MRS25 1% 10K	4822 116 53022	R 6006	MRS25 1% 10K	4822 116 53022
R 4533	MRS25 1% 3K48	4822 116 53315	R 6007	MRS25 1% 10K	4822 116 53022
R 4601	MRS25 1% 2K37	5322 116 53536	R 6008	MRS25 1% 316E	5322 116 53514
R 4602	MRS25 1% 26K1	5322 116 53261	R 6009	0.5W 10% 1K5	4822 116 30248
R 4603	MRS25 1% 23K7	5322 116 53537	R 6010	MRS25 1% 14K7	4822 116 53531
R 4604	MRS25 1% 100K	4822 116 52973	R 6011	MRS25 1% 237E	5322 116 53259
R 4606	MRS25 1% 909E	4822 116 53533	R 6012	MRS25 1% 178E	5322 116 53572
R 4607	MRS25 1% 100E	5322 116 53126	R 6013	MRS25 1% 100E	5322 116 53126
R 4608	MRS25 1% 1K	4822 116 53108	R 6014	MRS25 1% 3E16	4822 116 52993
R 4609	MRS25 1% 42E2	5322 116 53515	R 6016	MRS25 1% 10K	4822 116 53022
R 4611	MRS25 1% 10K	4822 116 53022	R 6017	MRS25 1% 1E	4822 116 52976
R 4612	MRS25 1% 7K5	4822 116 53028	R 6018	MRS25 1% 1E	4822 116 52976
R 4613	MRS25 1% 7K5	4822 116 53028	R 6019	MRS25 1% 10K	4822 116 53022
R 4614	MRS25 1% 8K25	5322 116 53267	R 6020	MRS25 1% 21E5	5322 116 53426
R 4616	0.3W 25% 1K	5322 105 20032	R 6021	MRS25 1% 10K	4822 116 53022
R 4617	MRS25 1% 6K81	5322 116 53252	R 6022	MRS25 1% 10K	4822 116 53022
R 4618	MRS25 1% 11K	4822 116 52907	R 6031	MRS25 1% 383E	5322 116 53332
R 4619	MRS25 1% 51K1	4822 116 53121	R 6032	0.25% 5K62	5322 116 80473
R 4620	MRS25 1% 10K	4822 116 53022	R 6033	0.25% 7K5	5322 116 80474
R 4621	MRS25 1% 909E	4822 116 53533	R 6034	MRS25 1% 6K19	5322 116 53263
R 4622	MRS25 1% 100E	5322 116 53126	R 6036	MRS25 1% 7K5	4822 116 53028
R 4625	MRS25 1% 100E	5322 116 53126	R 6037	MRS25 1% 31K6	5322 116 53262
R 4626	MRS25 1% 100E	5322 116 53126	R 6038	MRS25 1% 100E	5322 116 53126
R 4627	MRS25 1% 10K	4822 116 53022	R 6039	MRS25 1% 10E	4822 116 52891
R 4628	MRS25 1% 100E	5322 116 53126	R 6041	MRS25 1% 3K83	4822 116 53079
R 4629	MRS25 1% 8K25	5322 116 53267	R 6042	MRS25 1% 3K83	4822 116 53079
R 4631	MRS25 1% 1K	4822 116 53108	R 6043	MRS25 1% 100K	4822 116 52973
R 4632	MRS25 1% 100E	5322 116 53126	R 6044	MRS25 1% 100K	4822 116 52973
R 4633	MRS25 1% 1K	4822 116 53108	R 6101	MRS25 1% 100E	5322 116 53126
R 4634	MRS25 1% 1K	4822 116 53108	R 6102	MRS25 1% 100E	5322 116 53126
R 4636	MRS25 1% 1M	4822 116 52843	R 6103	MRS25 1% 1K	4822 116 53108
R 4639	MRS25 1% 383E	5322 116 53332	R 6131	MRS25 1% 10E	4822 116 52891
R 4701	MRS25 1% 42E2	5322 116 53515	R 6132	MRS25 1% 100K	4822 116 52973
R 4703	MRS25 1% 562E	5322 116 53214	R 6133	MRS25 1% 100K	4822 116 52973
R 4705	MRS25 1% 1K	4822 116 53108	R 6134	MRS25 1% 1K	4822 116 53108
R 4706	MRS25 1% 100E	5322 116 53126	R 6136	MRS25 1% 4K64	5322 116 53212
R 4707	MRS25 1% 511E	5322 116 53135	R 6137	MRS25 1% 316E	5322 116 53514
R 4708	MRS25 1% 2K87	5322 116 53513	R 6138	MRS25 1% 1K	4822 116 53108
R 4709	MRS25 1% 681E	4822 116 53123	R 6139	MRS25 1% 100E	5322 116 53126
R 4711	MRS25 1% 6K19	5322 116 53263	R 6201	0.25% 160K	5322 116 53412
R 4712	MRS25 1% 511E	5322 116 53135	R 6202	VR37 1% 31M6	5322 116 64103
R 4713	MRS25 1% 1M	4822 116 52843	R 6203	MRS25 1% 100K	4822 116 52973
R 4714	MRS25 1% 1M	4822 116 52843	R 6204	MRS25 1% 10K	4822 116 53022
R 4716	MRS25 1% 6K81	5322 116 53292	R 6205	MRS25 1% 1K	4822 116 53108
R 4717	MRS25 1% 8K25	5322 116 53267	R 6206	MRS25 1% 16K2	5322 116 53589
R 4718	MRS25 1% 1K	4822 116 53108	R 6207	MRS25 1% 51E1	5322 116 53213

POSNR	DESCRIPTION	ORDERING CODE	16.4.4	SEMI-CONDUCTORS
R 6208	MRS25 1% 464E	5322 116 53232	POSNR	DESCRIPTION
R 6209	MRS25 1% 4K64	5322 116 53212	V 201	BAW62
R 6211	MRS25 1% 4K64	5322 116 53314	V 202	BAW62
R 6212	MRS25 1% 4K64	5322 116 53212	V 203	BF324 SELECT
R 6213	MRS25 1% 215E	5322 116 53325	V 204	BAW62
R 6214	VR25 5% 10M	4822 110 72214	V 206	BF370
R 6216	MRS25 1% 100E	5322 116 53126	V 401	BC558B
R 6217	MRS25 1% 1E	4822 116 52976	V 402	BC548C
R 6300	MRS25 1% 2K61	5322 116 53327	V 1000	BA483
R 6301	MRS25 1% 464E	5322 116 53232	V 1001	BF324
R 6302	MRS25 1% 909E	4822 116 53533	V 1002	BF324
R 6303	MRS25 1% 3K83	4822 116 53079	V 1003	BF610C
R 6304	MRS25 1% 6K81	5322 116 53252	V 1004	BA483
R 6311	MRS25 1% 750E	5322 116 53265	V 1005	BA483
R 6312	MRS25 1% 4K22	5322 116 53246	V 1006	BF610C
R 6313	MRS25 1% 1K1	5322 116 53473	V 1007	BA483
R 6401	MRS25 1% 1K78	5322 116 53208	V 1008	BA483
R 6402	MRS25 1% 178K	5322 116 53555	V 1009	BA483
R 6403	MRS25 1% 215E	5322 116 53325	V 1010	BZX79-C8V2
R 6404	MRS25 1% 6K81	5322 116 53252	V 1011	BF610C
R 6406	MRS25 1% 26K1	5322 116 53261	V 1012	BA483
R 6407	MRS25 1% 3K48	4822 116 53315	V 1013	BA483
R 6408	MTP10 20% 10K	5322 100 10113	V 1014	BA483
R 6501	MRS25 1% 511E	5322 116 53135	V 1016	BF10C
R 6502	MRS25 1% 100K	4822 116 52973	V 1017	BA483
R 6503	MRS25 1% 5K11	5322 116 53494	V 1019	BF199
R 6504	MRS25 1% 19K6	5322 116 53258	V 1021	BF199
R 6506	MRS25 1% 5K62	5322 116 53495	V 1022	BF324
R 6507	MRS25 1% 511E	5322 116 53135	V 1023	BZX79-C5V6
R 6508	0.25% 3K67	5322 116 53411	V 1024	BF370
R 6509	0.25% 500E	5322 116 53408	V 1061	BAW62
R 6511	MRS25 1% 562E	5322 116 53214	V 1062	BAW62
R 7005	PP17 20% 10K	5322 101 30546	V 1063	BF324
R 7006	PP17 20% 10K	5322 101 30546	V 1064	BF324
R 7007	PP17 20% 10K	5322 101 30546	V 1100	BA483
R 7008	PP17 20% 10K	5322 101 30546	V 1101	BF324
R 7009	PP17 20% 10K	5322 101 30546	V 1102	BF324
R 7010	PP17 20% 10K	5322 101 30546	V 1103	BF410C
R 7011	PP17 20% 10K	5322 101 30546	V 1104	BA483
R 7012	PP17 20% 10K	5322 101 30546	V 1105	BA483
R 7013	PP17 20% 10K	5322 101 30546	V 1106	BF10C
R 7014	PP17 20% 10K	5322 101 30546	V 1107	BA483
R 7021	MRS25 1% 11K	4822 116 52907	V 1108	BA483
R 7022	MRS25 1% 10K	4822 116 53022	V 1109	BA483
R 7023	MRS25 1% 90K9	5322 116 53582	V 1110	BZX79-C8V2
R 7024	MRS25 1% 1K	4822 116 53108	V 1111	BF410C
R 7025	MRS25 1% 1K	4822 116 53108	V 1112	BA483
R 7026	MRS25 1% 4K64	5322 116 53212	V 1113	BA483
R 7027	MRS25 1% 3K83	4822 116 53079	V 1114	BA483
R 7028	MRS25 1% 3K83	4822 116 53079	V 1115	BA483
R 7029	MRS25 1% 1K	4822 116 53108	V 1116	BF410C
R 7031	MRS25 1% 1K	4822 116 53108	V 1117	BA483
R 7032	MRS25 1% 75K	5322 116 53266	V 1119	BF199
R 7033	MRS25 1% 5K11	5322 116 53494	V 1121	BF199
R 7034	MRS25 1% 162E	5322 116 53523	V 1122	BF324
R 7036	0.5W 10% 2K2	4822 116 30254	V 1123	BZX79-C5V6
R 7037	MRS25 1% 1K1	5322 116 53473	V 1124	BF370
R 7038	MRS25 1% 1M	4822 116 52843	V 1161	BAW62
R 7041	MRS25 1% 3K83	4822 116 53079	V 1162	BAW62
R 7042	MRS25 1% 3K83	4822 116 53079	V 1163	BF324
R 7102	MRS25 1% 100E	5322 116 53126	V 1164	BF324
R 8001	MCR18 1% 10K	4822 111 90249	V 1200	BZV46-C1V5
16.4.3	COILS		V 1201	BF410C
L 1001	0.22UH 10%	5322 157 53284	V 1202	BA483
L 1101	0.22UH 10%	5322 157 53284	V 1203	BA483
L 1401	1500UH	4822 156 21293	V 1204	BF199
L 1402	1500UH	4822 156 21293	V 1205	BZX79-C8V2
L 1403	1500UH	4822 156 21293	V 1206	BF199
L 1421	1500UH	4822 156 21293	V 1207	BF324
L 1422	1500UH	4822 156 21293	V 1208	BZX79-C5V6
L 1423	1500UH	4822 156 21293	V 1209	BF199
L 3001	2.2UH 10%	5322 157 53509	V 1211	BF324
L 3002	2.2UH 10%	5322 157 53509	V 1212	BF324
L 3003	2.7UH 10%	5322 157 53511	V 1213	BF324
L 4101	2.2UH	4822 157 51757	V 1214	BZV46-C2V0
L 6000	100UH	5322 157 52363	V 2001	BZV46-C2V0
L 6001	100UH	5322 157 52363	V 2002	BZV46-C2V0
L 6002	100UH	5322 157 52363	V 2003	BZX79-C3V0
L 6003	5.6UH	4822 157 52259	V 2004	BZV46-C1V5
L 6004	1000UH	5322 157 52718	V 2005	BZV46-C1V5
L 6006	1000UH	5322 157 52718	V 2006	BZV46-C1V5
L 6101	10UH	5322 157 52513	V 2007	BZV46-C4V3
L 6102	27UH	4822 158 10551	V 2008	BZV46-C4V3
L 6103	100UH	5322 157 52363	V 2009	BZV46-C4V3
L 6104	100UH	5322 157 52363	V 2010	BZV46-C4V3
L 6106	82UH	4822 158 10563	V 2011	BZV46-C4V3
L 6107	82UH	4822 158 10563	V 2012	BZV46-C4V3
L 6108	82UH	4822 158 10563	V 2013	BZV46-C4V3
L 6109	82UH	4822 158 10563	V 2014	BZV46-C4V3
L 6111	15UH	5322 157 52539	V 2015	BZV46-C4V3
L 6201	82UH	4822 158 10563	V 2016	BZV46-C4V3
L 6501	82UH	4822 158 10563	V 2017	BZV46-C4V3
L 7101	15UH	5322 157 52539	V 2018	BZV46-C4V3
16.4.4	SEMI-CONDUCTORS		V 2019	BZV46-C4V3
L 1001	0.22UH 10%	5322 157 53284	V 2020	BZV46-C4V3
L 1101	0.22UH 10%	5322 157 53284	V 2021	BZV46-C4V3
L 1401	1500UH	4822 156 21293	V 2022	BZV46-C4V3
L 1402	1500UH	4822 156 21293	V 2023	BZV46-C4V3
L 1403	1500UH	4822 156 21293	V 2024	BZV46-C4V3
L 1421	1500UH	4822 156 21293	V 2025	BZV46-C4V3
L 1422	1500UH	4822 156 21293	V 2026	BZV46-C4V3
L 1423	1500UH	4822 156 21293	V 2027	BZV46-C4V3
L 3001	2.2UH 10%	5322 157 53509	V 2028	BZV46-C4V3
L 3002	2.2UH 10%	5322 157 53509	V 2029	BZV46-C4V3
L 4101	2.2UH	4822 157 51757	V 2030	BZV46-C4V3
L 6000	100UH	5322 157 52363	V 2031	BZV46-C4V3
L 6001	100UH	5322 157 52363	V 2032	BZV46-C4V3
L 6002	100UH	5322 157 52363	V 2033	BZV46-C4V3
L 6003	5.6UH	4822 157 52259	V 2034	BZV46-C4V3
L 6004	1000UH	5322 157 52718	V 2035	BZV46-C4V3
L 6006	1000UH	5322 157 52718	V 2036	BZV46-C4V3
L 6101	10UH	5322 157 52513	V 2037	BZV46-C4V3
L 6102	27UH	4822 158 10551	V 2038	BZV46-C4V3
L 6103	100UH	5322 157 52363	V 2039	BZV46-C4V3
L 6104	100UH	5322 157 52363	V 2040	BZV46-C4V3
L 6106	82UH	4822 158 10563	V 2041	BZV46-C4V3
L 6107	82UH	4822 158 10563	V 2042	BZV46-C4V3
L 6108	82UH	4822 158 10563	V 2043	BZV46-C4V3
L 6109	82UH	4822 158 10563	V 2044	BZV46-C4V3
L 6111	15UH	5322 157 52539	V 2045	BZV46-C4V3
L 6201	82UH	4822 158 10563	V 2046	BZV46-C4V3
L 6501	82UH	4822 158 10563	V 2047	BZV46-C4V3
L 7101	15UH	5322 157 52539	V 2048	BZV46-C4V3

POSNR	DESCRIPTION	ORDERING CODE	POSNR	DESCRIPTION	ORDERING CODE
V 2325	BAW62	4822 130 30613	V 4006	BF763	5322 130 61148
V 2326	BAW62	4822 130 30613	V 4007	BAW62	4822 130 30613
V 2327	BC558B	4822 130 44197	V 4008	BAW62	4822 130 30613
V 2328	BZX79-C5V1	4822 130 34233	V 4009	BC548C	4822 130 44196
V 2329	BZX79-C9V1	4822 130 30862	V 4011	BZX79-C5V1	4822 130 34233
V 2331	BC558B	4822 130 44197	V 4012	BC548C	4822 130 44196
V 2332	BC558B	4822 130 44197	V 4013	BZX79-C3V6	5322 130 34834
V 2333	BC558B	4822 130 44197	V 4014	BAW62	4822 130 30613
V 2334	BC558B	4822 130 44197	V 4016	BC548C	4822 130 44196
V 2341	BF199	4822 130 44154	V 4017	BC548C	4822 130 44196
V 2342	BF199	4822 130 44154	V 4018	BC548C	4822 130 44196
V 2347	BF199	4822 130 44154	V 4031	BF199	4822 130 44154
V 2349	BF199	4822 130 44154	V 4032	BF199	4822 130 44154
V 2356	BC548C	4822 130 44196	V 4033	BF199	4822 130 44154
V 2357	BC548C	4822 130 44196	V 4034	BC548C	4822 130 44196
V 2366	BAW62	4822 130 30613	V 4036	BF763	5322 130 61148
V 2367	BAW62	4822 130 30613	V 4037	BAW62	4822 130 30613
V 2368	BAW62	4822 130 30613	V 4038	BC548C	4822 130 44196
V 2369	BAW62	4822 130 30613	V 4039	BC548C	4822 130 44196
V 2370	BC548C	4822 130 44196	V 4101	BC558B	4822 130 44197
V 2371	BC558B	4822 130 44197	V 4102	BAW62	4822 130 30613
V 2507	BAW62	4822 130 30613	V 4103	BAW62	4822 130 30613
V 2508	BAW62	4822 130 30613	V 4104	BC548C	4822 130 44196
V 2509	BC558B	4822 130 44197	V 4106	BAW62	4822 130 30613
V 2510	BC558B	4822 130 44197	V 4107	BC327	4822 130 40854
V 2511	BC548C	4822 130 44196	V 4108	BC548C	4822 130 44196
V 2512	BF324	4822 130 41448	V 4109	BC558B	4822 130 44197
V 2513	BF324	4822 130 41448	V 4110	BAW62	4822 130 30613
V 2514	BF324	4822 130 41448	V 4111	BC558B	4822 130 44197
V 2516	BF324	4822 130 41448	V 4112	BSX20	4822 130 41705
V 2601	BZX79-C6V2	4822 130 34167	V 4113	BZV46-C1V5	5322 130 34865
V 2602	BC548C	4822 130 44196	V 4114	BSX20	4822 130 41705
V 2611	BF199	4822 130 44154	V 4115	BZX79-C6V2	4822 130 34167
V 2612	BF199	4822 130 44154	V 4116	BAW62	4822 130 30613
V 2615	BC548C	4822 130 44196	V 4117	BC548C	4822 130 44196
V 2616	BZV46-C1V5	5322 130 34865	V 4118	BC548C	4822 130 44196
V 3001	BF324	4822 130 41448	V 4119	BF199	4822 130 44154
V 3002	BF324	4822 130 41448	V 4120	BAW62	4822 130 30613
V 3003	BC558B	4822 130 44197	V 4121	BC548C	4822 130 44196
V 3004	BF324	4822 130 41448	V 4122	BAW62	4822 130 30613
V 3006	BF324	4822 130 41448	V 4123	BAW62	4822 130 30613
V 3007	BC548C	4822 130 44196	V 4209	BC558B	4822 130 44197
V 3008	BF370	4822 130 42589	V 4211	BC558B	4822 130 44197
V 3009	BF370	4822 130 42589	V 4212	BSX20	4822 130 41705
V 3011	2N3866-01	5322 130 41799	V 4213	BAW62	4822 130 30613
V 3012	2N3866-01	5322 130 41799	V 4214	BSX20	4822 130 41705
V 3013	BZX79-C27	4822 130 34379	V 4215	BZX79-C6V2	4822 130 34167
V 3014	BZX79-C27	4822 130 34379	V 4216	BAW62	4822 130 30613
V 3016	BAW62	4822 130 30613	V 4217	BC548C	4822 130 44196
V 3101	BF324	4822 130 41448	V 4218	BC548C	4822 130 44196
V 3102	BF324	4822 130 41448	V 4219	BF199	4822 130 44154
V 3103	BF324	4822 130 41448	V 4300	BZX79-C6V2	4822 130 34167
V 3104	BC558B	4822 130 44197	V 4301	BC558B	4822 130 44197
V 3106	BF324	4822 130 41448	V 4302	BC548C	4822 130 44196
V 3108	BF472	5322 130 42535	V 4304	BC558B	4822 130 44197
V 3109	BF370	4822 130 42589	V 4305	BZX79-C9V1	4822 130 30862
V 3111	BF370	4822 130 42589	V 4306	BAW62	4822 130 30613
V 3112	2N5551	5322 130 44491	V 4307	BC548C	4822 130 44196
V 3113	BZX79-B5V6	4822 130 34173	V 4308	BZV46-C1V5	5322 130 34865
V 3114	2N5551	5322 130 44491	V 4309	BC548C	4822 130 44196
V 3116	BF472	5322 130 42535	V 4321	BAW62	4822 130 30613
V 3200	BF370	4822 130 42589	V 4322	BC548C	4822 130 44196
V 3201	BF370	4822 130 42589	V 4323	BC548C	4822 130 44196
V 3202	2N5401	5322 130 42534	V 4400	BZV46-C1V5	5322 130 34865
V 3203	2N5551	5322 130 44491	V 4401	BF324	4822 130 41448
V 3204	BF423	4822 130 41666	V 4402	BZX79-C6V2	4822 130 34167
V 3205	BZX79-B5V6	4822 130 34173	V 4500	BAW62	4822 130 30613
V 3206	BAW62	4822 130 30613	V 4501	BC548C	4822 130 44196
V 3207	BC548C	4822 130 44196	V 4502	BC548C	4822 130 44196
V 3208	BF423	4822 130 41666	V 4503	BC548C	4822 130 44196
V 3209	BAW62	4822 130 30613	V 4504	BC548C	4822 130 44196
V 3211	BAW62	4822 130 30613	V 4505	BAW62	4822 130 30613
V 3212	BZX79-C68	4822 130 30864	V 4506	BC548C	4822 130 44196
V 3213	BC548C	4822 130 44196	V 4510	BC558B	4822 130 44197
V 3214	BAW62	4822 130 30613	V 4511	BC558B	4822 130 44197
V 3215	BAW62	4822 130 30613	V 4512	BC558B	4822 130 44197
V 3216	BZX79-C9V1	4822 130 30862	V 4513	BC558B	4822 130 44197
V 3217	BAW62	4822 130 30613	V 4514	BC558B	4822 130 44197
V 3251	BF423	4822 130 41666	V 4516	BAW62	4822 130 30613
V 3252	BZX79-C6V2	4822 130 34167	V 4517	BAW62	4822 130 30613
V 3253	BF423	4822 130 41666	V 4518	BAW62	4822 130 30613
V 3254	BF423	4822 130 41666	V 4519	BAW62	4822 130 30613
V 3256	BF423	4822 130 41666	V 4521	BAW62	4822 130 30613
V 3257	BAV21	4822 130 30842	V 4522	BAW62	4822 130 30613
V 3301	BZX79-C6V2	4822 130 34167	V 4523	BC548C	4822 130 44196
V 4001	BF199	4822 130 44154	V 4601	BAW62	4822 130 30613
V 4002	BF199	4822 130 44154	V 4602	BAW62	4822 130 30613
V 4003	BF199	4822 130 44154	V 4611	BF199	4822 130 44154
V 4004	BC548C	4822 130 44196	V 4612	BF199	4822 130 44154
V 4005	BC558B	4822 130 44197	V 4613	BAW62	4822 130 30613

POSNR	DESCRIPTION	ORDERING CODE	POSNR	DESCRIPTION	ORDERING CODE
V 4614	BAW62	4822 130 30613	D 2501	PLIFIER	5322 209 80991
V 4616	BC548C	4822 130 44196	D 2502	PLIFIER	5322 209 80991
V 4702	BF324	4822 130 41448	D 2601	HEF4053BP	5322 209 10576
V 4703	BAW62	4822 130 30613	D 2602	TEA1017/N8	5322 209 70023
V 4704	BAW62	4822 130 30613	D 2603	OQ 0200	5322 209 82924
V 4706	BF324	4822 130 41448	D 4001	TEA1017/N8	5322 209 70023
V 4707	BC558B	4822 130 44197	D 4002	TEA1017/N8	5322 209 70023
V 4708	BF324	4822 130 41448	D 4101	HEF4053BP	5322 209 10576
V 4709	BC558B	4822 130 44197	D 4102	HEF4051BP	4822 209 10262
V 4710	BC548C	4822 130 44196	D 4202	HEF4051BP	4822 209 10262
V 4711	BAW62	4822 130 30613	D 4401	TDA1540P	4822 209 81453
V 4712	BF324	4822 130 41448	D 6201	HT MULTIPLIER	5322 321 21597
V 4713	BAW62	4822 130 30613	D 6501	HEF4066BP	5322 209 10357
V 4801	BYV46-C1V5	5322 130 34865	D 7001	UP 8052 AH	5322 209 11349
V 4806	BAX12	5322 130 34605	D 7002	HEF4053BP	5322 209 10576
V 4807	BAX12	5322 130 34605	D 7003	PC74HCT259P	5322 209 11115
V 4808	BAX12	5322 130 34605	D 7006	SN74LS244N	5322 209 86017
V 4809	BAX12	5322 130 34605	D 8001	PCF8577T	5322 209 70024
V 6001	BYV96E	5322 130 34979	D 8002	PCF8577T	5322 209 70024
V 6002	BYV96E	5322 130 34979	D 8003	PCF8577T	5322 209 70024
V 6003	BYV96E	5322 130 34979	N 201	CA3127E	5322 130 42627
V 6004	BYV96E	5322 130 34979	N 1001	UA714TC	5322 209 70275
V 6007	BAX12	5322 130 34605	N 1101	UA714TC	5322 209 70275
V 6008	BAX12	5322 130 34605	N 1201	LF356N	5322 209 86422
V 6009	BC337	4822 130 40855	N 4101	LM324N	4822 209 80587
V 6011	BAX12	5322 130 34605	N 4102	UA714TC	5322 209 70275
V 6012	BZX79-C15	4822 130 34281	N 4103	TL080CP	5322 209 72464
V 6013	BRY39	5322 130 40482	N 4202	UA714TC	5322 209 70275
V 6014	BZU80	5322 130 43926	N 4203	TL080CP	5322 209 72464
V 6016	BYV27-150	4822 130 31628	N 4402	CA3086	5322 209 11225
V 6017	BYV27-150	4822 130 31628	N 4601	TCA240	4822 209 80629
V 6018	BUN12A	5322 130 42114	N 6001	LM358N	4822 209 70672
V 6019	BYV26C	4822 130 32343	N 6002	LM358N	4822 209 70672
V 6021	BZX79-C3V0	4822 130 31881	N 7001	LM339AN	4822 209 80631
V 6031	BZX79-C3V6	5322 130 34834			
V 6101	BYV43-45	5322 130 33656	16.4.6	CATHODE RAY TUBE	
V 6102	BYV28-150	5322 130 32043	V 0001	D14-372GH	5322 131 20169
V 6103	BYV27-150	4822 130 31628	V 0001	CRT D14-372GM/123	5322 131 20171
V 6104	BYV28-150	5322 130 32043			
V 6106	BYV27-150	4822 130 31628			
V 6107	BYV95C	4822 130 41487	16.4.7	MISCELLANEOUS	
V 6108	BYV27-150	4822 130 31628	E 0001	T13/4 28V 80MA	5322 134 40534
V 6109	BYV95C	4822 130 41487	E 8001	60MA MGG9012	5322 134 40849
V 6110	BYV27-150	4822 130 31628	G 7001	KYO	5322 242 71444
V 6112	BT151-500R	5322 130 24081	H 6001	CNX35	5322 130 90137
V 6113	BYV95C	4822 130 41487	K 1001	EED-RELAIS 12V	5322 280 20125
V 6115	BYV27-150	4822 130 31628	K 1002	EED-RELAIS 12V	5322 280 20125
V 6116	BYV27-150	4822 130 31628	K 1003	EED-RELAIS 12V	5322 280 20125
V 6131	BAX12	5322 130 34605	K 1004	EED-RELAIS 12V	5322 280 20125
V 6132	BAW62	4822 130 30613	K 1005	EED-RELAIS 12V	5322 280 20125
V 6133	BZX79-C6V2	4822 130 34167	K 1006	EED-RELAIS 12V	5322 280 20125
V 6134	BC337	4822 130 40855	K 1007	EED-RELAIS 12V	5322 280 20125
V 6136	BF423	4822 130 41646	K 1008	EED-RELAIS 12V	5322 280 20125
V 6137	BF423	4822 130 41646	K 1101	EED-RELAIS 12V	5322 280 20125
V 6138	BZX79-C5V6	4822 130 34173	K 1102	EED-RELAIS 12V	5322 280 20125
V 6201	BC327	4822 130 40854	K 1103	EED-RELAIS 12V	5322 280 20125
V 6202	BZX79-C15	4822 130 34281	K 1104	EED-RELAIS 12V	5322 280 20125
V 6203	BAV21	4822 130 30842	K 1106	EED-RELAIS 12V	5322 280 20125
V 6204	BAV21	4822 130 30842	K 1107	EED-RELAIS 12V	5322 280 20125
V 6206	BAV21	4822 130 30842	K 1108	EED-RELAIS 12V	5322 280 20125
V 6207	BYV27-150	4822 130 31628	K 1201	EED-RELAIS 12V	5322 280 20125
V 6208	BUV26A	5322 130 42722	K 4101	EED-RELAIS 12V	5322 280 20125
V 6209	BY509	4822 130 41485	K 4201	EED-RELAIS 12V	5322 280 20125
V 6211	BC337	4822 130 40855	S 6001	BR	5322 276 11859
V 6301	BC548C	4822 130 44196	S 7002	BR	5322 277 10878
V 6302	BC558B	4822 130 44197	S 7004	BR	5322 277 10878
V 6303	BC337	4822 130 40855	S 7006	BR	5322 277 10878
V 6304	BC327	4822 130 40854	S 7008	BE	5322 277 10879
V 6311	BC337	4822 130 40855	S 7010	BE	5322 277 10879
V 6312	BDX78	5322 130 44278	S 7012		5322 276 11857
V 6401	BZV11	5322 130 34294	S 7013		5322 276 11856
V 6402	BAX12	5322 130 34605	S 7019		5322 276 11856
V 6403	BC337	4822 130 40855	S 7020		5322 276 11856
V 7001	BAW62	4822 130 30613	S 7021		5322 276 11856
V 7002	BC548C	4822 130 44196	S 7022		5322 276 11856
V 7101	BAW62	4822 130 30613	S 7023		5322 276 11856
			S 7024		5322 276 11856
			S 7025		5322 276 11856
			S 7026		5322 276 11856
			S 7027		5322 276 11858
			S 7028		5322 276 11858
			S 7029		5322 276 11856
			S 7030		5322 276 11856
			S 7031		5322 276 11856
			S 7032		5322 276 11856
			T 0001	T 5X20 1,6A	4822 253 30024
			T 6001	EDT-39 TRANSFORMER	5322 146 30591
			T 6201	PG1 TFE30 TRANSFORM.	5322 146 30592
16.4.5	INTEGRATED CIRCUITS				
D 401	PCT4HCT132P	4822 209 83044			
D 1001	TEA1017/N8	5322 209 70023			
D 1061	OQ 0203	5322 209 70393			
D 1101	TEA1017/N8	5322 209 70023			
D 1161	OQ 0203	5322 209 70393			
D 2002	OQ 0205	5322 209 70392			
D 2102	OQ 0205	5322 209 70392			
D 2201	PLIFIER	5322 209 80991			
D 2202	PLIFIER	5322 209 80991			
D 2203	ARRAY OQ 0127	5322 209 80992			
D 2301	OQ 0205	5322 209 70392			
D 2302	PLIFIER	5322 209 80991			
D 2303	PLIFIER	5322 209 80991			
D 2304	OQ 0128	5322 209 82925			

## 17. OPTIONS

### 17.1 Y-OUT

#### 17.1.1 Characteristics

CHARACTERISTICS	SPECIFICATION	ADDITIONAL INFORMATION
* Y-out Defl. coeff.	via channel A 100 mV/div. +/- 10% 50 mV/div. +/- 10%	at $R_{load} > 10 \text{ k}\Omega$ at $R_{load} = 50 \text{ }\Omega$
* Bandwidth	> 50 MHz	
* Pulse aberrations LF pulse drop or tilt	< 2% < 3%	at $R_{load} = 50 \text{ }\Omega$ at $R_{load} > 10 \text{ k}\Omega$ 5 div. pulse; +or- 2,5 div. from screen centre.
* HF pulse aberrations	< 6%	5 div. pulse (ac coupled)
* Dyn. range	+or- 12 div. > 6 div	at 10 MHz at 50 MHz
* DC output level Output drift (10°C-40°C)	0 V < 50 mV	

#### 17.1.2 Circuit description

The Y-OUT circuit receives its input current from the signal splitter D2002, pin 6 and 11 on the pre-amplifier unit. The symmetrical input is buffered by two common-base amplifiers V203. These two transistors are matched for a common Vbe to compensate temperature drift. The symmetrical current signals are then converted into the asymmetrical Y-OUT voltage via the short-feedback amplifier N201-6,7,8. The amplitude of this Y-OUT voltage is the summation of the voltage across resistor R219 and R226. The offset can be adjusted to 0 V by means of potentiometer R201. Transistor V206 serves as the current source of this final stage.

## 17.1.3 Adjusting and checking procedure

Refer to figure 17.1 for location of the adjusting points.

NOTE: Be sure that the oscilloscope is well adjusted before starting this adjusting procedure.

## Gain adjustment:

- Apply a 100 mV/2 kHz calibrated square-wave signal to input A.
- Connect the Y OUT output to input B by means of a coax cable.
- Press AUTO SET key.
- Set UP-DOWN ch. A to 20 mV.
- Set UP-DOWN ch. B to 0,1 V.
- Press AC/DC key ch. A for DC input coupling.
- Press AC/DC key ch. B for DC input coupling.
- Press ALT/CHOP key for chopped display.
- Press ADD/INVERT key for B-INV display.
- Adjust R209 for an equal amplitude of ch. A and ch. B (tolerance: +or- 1,5 subdiv.)

## Offset adjustment:

- Press AUTO SET key.
- Press O key ch. A.
- Connect a digital multimeter to the Y-OUT connection of the BNC socket and the BNC-ground.
- Adjust R201 so that the output voltage is 0 V (tolerance: +or- 10 mV)

## Checking the gain:

- Press AUTO SET key.
- Set UP-DOWN ch. A to 20 mV.
- Set UP-DOWN ch. B to 0,1 V.
- Press AC/DC key ch. A for DC input coupling.
- Press AC/DC key ch. B for DC input coupling.
- Press A/B key for only ch. B display.
- Ensure that the amplitude of the displayed signal is 5 div. (tolerance: +or- 1,5 subdiv.)
- Terminate ch. B with 50 Ohm.
- Set UP-DOWN ch. B to 50 mV.
- Ensure that the amplitude of the displayed signal is 5 div. (tolerance: +or- 1,5 subdiv.)

## HF square-wave response adjustment:

- Apply a 120 mV/1 MHz calibrated square-wave signal with rise time faster than 1 nsec to input A.
- Connect the Y OUT output to a PM3295 oscilloscope means of a coax cable. (Input: 50 Ohm, sensitivity: 50 mV/div)
- Press AUTO SET key
- Set UP-DOWN ch. A to 20 mV.
- Press AC/DC key ch. A for DC input coupling.
- Ensure that the PM3295 displays a square wave signal of 6 div p-p approx.
- Adjust R223 and C203 for an optimal square-wave response.

**Y-OUT bandwidth check:**

- Apply a 120 mV/1 MHz sine-wave to input A.
- Connect the Y-OUT output to a PM3295 oscilloscope by means of a coax cable. (input: 50 Ohm, sensitivity: 50 mV/div).
- Press AUTO SET key.
- Set UP-DOWN ch. A to 20 mV.
- Press AC/DC key ch. A for DC input coupling.
- Ensure that the amplitude of the displayed signal is 6 div.; if necessary, readjust the amplitude of the input signal.
- Now, increase the frequency of the input signal to 50 MHz.
- Ensure that the amplitude of the displayed signal on the PM3295 is at least 5 div. p-p.

**Checking the dynamic range:**

- Apply a 0,25 mV/50 MHz sine-wave to input A.
- Connect the Y-OUT output to PM3295 oscilloscope by means of a coax cable. (input: 50 Ohm, sensitivity: 200 mV/div).
- Press AUTO SET key.
- Set UP-DOWN ch. A to 20 mV.
- Press AC/DC key ch. A for DC input coupling.
- Ensure that the displayed signal is shown without distortion or clipping.
- Change the input signal to 0,52 V/10 MHz sine wave.
- Change UP/DOWN ch. A to 0,1 V.
- Ensure that the displayed signal is shown without distortion or clipping.

#### 17.1.4 Parts list

POS.NR	DESCRIPTION	ORDERING CODE
C201	10nF -20+150% 100V	4822 122 31414
C202	100pF -2% 100V	4822 122 31316
C203	10pF TRIM CAP	5322 125 11013
C204	1nF -10% 100V	4822 122 30027
C251	68uF -10+50% 16V	4822 124 20689
C252	10nF -20+50% 100V	4822 122 31414
C253	10nF -20+50% 100V	4822 122 31414
C254	68uF -10+50% 16V	4822 124 20689
C256	10nF -20+50% 100V	4822 122 31414
C257	10nF -20+50% 100V	4822 122 31414
R201	2K2 25% 0,3W	5322 105 20033
R202	16K2 1% MRS25	5322 116 53589
R203	1K33 1% MRS25	5322 116 53512
R204	1K33 1% MRS25	5322 116 53512
R206	100E 1% MRS25	5322 116 53126
R207	100E 1% MRS25	5322 116 53126
R208	7K5 1% MRS25	5322 116 53028
R209	2K2 25% 0,3W	5322 105 20033
R211	348E 1% MRS25	5322 116 53591
R212	51E1 1% MRS25	5322 116 53213

POS.NR	DESCRIPTION	ORDERING CODE
R213	51E1 1% MRS25	5322 116 53213
R214	23K7 1% MRS25	5322 116 53537
R216	287E 1% MRS25	5322 116 53221
R217	287E 1% MRS25	5322 116 53221
R218	100E 1% MRS25	5322 116 53126
R219	825E 1% MRS25	5322 116 53541
R221	6K19 1% MRS25	5322 116 53263
R222	1K78 1% MRS25	5322 116 53208
R223	470E 25% 0,3W	5322 105 20028
R224	10E 1% MRS25	5322 116 52891
R226	825E 1% MRS25	5322 116 53541
R227	1K33 1% MRS25	5322 116 53512
R228	287E 1% MRS25	5322 116 53221
R229	51E1 1% MRS25	5322 116 53213
R231	1K21 1% MRS25	5322 116 52956
R232	1K 1% MRS25	5322 116 53108
R233	348E 1% MRS25	5322 116 53591
R251	5E11 1% MRS25	4822 116 52999
R252	5E11 1% MRS25	4822 116 52999
R253	5E11 1% MRS25	4822 116 52999
V201	BAW62	4822 130 30613
V202	BAW62	4822 130 30613
V203	BF324 select	5322 693 90465
V204	BAW62	4822 130 30613
V206	BF370	4822 130 42589
N201	CA3127E	5322 130 42627
X204	3-P SNG-90°	5322 265 30433
3x	50 Ohm bus conn.	5322 268 24116
3x	50 Ohm pen conn.	5322 268 14141








Figure 17.1 Y-OUT p.c.b.




REF NO	TYPE
N101	CA3127



Figure 17.2 Circuit diagram of Y-OUT option



MAT 2370A



## 17.2 MTB GATE, DTB GATE AND MTB SWEEP

## 17.2.1 MTB gate

The BNC output socket gives a TTL-compatible signal, which is HIGH during the MTB sweep and LOW for other conditions.

Characteristics	Specification	Additional information
* Output voltage LOW	< 0,4 V	at +4 mA
* Output voltage HIGH	> 2,4 V	at -4 mA

## 17.2.2 DTB gate

The BNC output socket gives a TTL-compatible signal, which is HIGH during the DTB sweep and LOW for other conditions.

Characteristics	Specification	Additional information
* Output voltage LOW	< 0,4 V	at +4 mA
* Output voltage HIGH	> 2,4 V	at -4 mA

## 17.2.3 MTB sweep

The BNC output socket gives the MTB sawtooth signal.

Characteristics	Specification	Additional information
* Output voltage	0,5 V/div. +or-2,5%	at $R_{load} > 1$ Meg-Ohm
* Linearity	< 3%	for definition, see MTB spec. in this manual.
* Output impedance	1 kOhm +or-2%	
* Offset voltage	< 250 mV	

## 17.2.4 Parts list

POS.NR	DESCRIPTION	ORDERING CODE
C421	10 nF -20+50% 100 V	4822 122 31414
C422	10 nF -20+50% 100 V	4822 122 31414
C423	10 nF -20+50% 100 V	4822 122 31414
R401	10 E 1% MRS25	4822 116 52891
R402	10 E 1% MRS25	4822 116 52891
R403	100 E 1% MRS25	5322 116 53126
R404	100 E 1% MRS25	5322 116 53126
R406	1 E 1% MRS25	4822 116 52976
R407	10 E 1% MRS25	4822 116 52891
R408	5k11 1% MRS25	5322 116 53494
R409	5k11 1% MRS25	5322 116 53494
R411	1 K 1% MRS25	4822 116 53108
R421	5E11 1% MRS25	4822 116 52999
R422	5E11 1% MRS25	4822 116 52999
R423	5E11 1% MRS25	4822 116 52999
V401	BC558B	4822 130 44197
V402	BC548C	4822 130 44196
D401	PC74HCT132P	4822 209 83044
3x 50 Ohm bus		5322 268 24116
3x 50 Ohm pin		5322 268 14141




Figure 17.3 Circuit diagram of MTB gate, DTB gate and MTB sweep options




Figure 17.4 P.c.b. for MTB gate, DTB gate and MTB sweep