

EVI-D30/D31

SERVICE MANUAL

REVISED 2

*EVI-D30 (NTSC)
EVI-D31 (PAL)*




Photo:EVI-D30

3. BLOCK DIAGRAMS/SCHEMATIC DIAGRAMS

NOTE:
Contents excepting "3. BLOCK DIAGRAMS / SCHEMATIC DIAGRAMS" are mentioned in the service manual (9-923-017-13).

COLOR VIDEO CAMERA

SONY®

TABLE OF CONTENTS

1. GENERAL

• Locations of Controls	1-1
• Precautions	1-2
• Connections	1-3
• Turning on the Power	1-4
• Setting the Clock	1-4
• Pan/Tilt Operation	1-5
• Adjusting the Camera	1-5
• Having the Camera Memorize the Setting	1-6
• Tracking a Subject Automatically	1-7
• Detecting the Change Taking Place in the Picture	1-9

2. DISASSEMBLY

2-1. Camera Cabinet (Upper)	2-1
2-2. Bottom Plate Assy	2-1
2-3. Main Block	2-2
2-4. ID-11 (A)/11 (B) Board	2-2
2-5. Pan Base Assy	2-3
2-6. LI-55 (A)/55 (B) Board	2-3
2-7. Pan Cabinet	2-4
2-8. CCD Lens Assy	2-4
2-9. Camera Cabinet (Lower)	2-5
2-10. Stepping Motor	2-5
2-11. LI-59 (A)/59 (B) Board	2-6
2-12. LD-84 (A)/84 (B) Board	2-6
2-13. VC-179 (A)/179 (B) Board	2-7
2-14. RS-67 (A)/67 (B) and LB-47 (A)/47 (B) Boards	2-7
2-15. MD-68 (A) Board	2-8E
2-16. Lens Block	2-8E
2-17. CD-154 (A)/154 (B) Board	2-8E
2-18. CCD Fitting Adaptor (H)	2-8E

3. BLOCK DIAGRAMS/SCHEMATIC DIAGRAMS

3-1. Overall Block Diagram	3-1
3-2. Schematic Diagram	
• This Note is Common for Schematic Diagrams	3-5
• CD-154 (A)/154 (B) Board	3-5
• VC-179 (A)/179 (B) Board (1/4)	3-7
• VC-179 (A)/179 (B) Board (2/4)	3-9
• VC-179 (A)/179 (B) Board (3/4)	3-11
• VC-179 (A)/179 (B) Board (4/4)	3-13
• RS-67 (A)/67 (B) and LB47 (A)/47 (B) Boards	3-17
• MD-68 (A) Board	3-18
• PS-398 (A)/398 (B) Board	3-21
• ID-11 (A)/11 (B) Board	3-22
• AT-21 (A)/21 (B) Board	3-25
• LI-52 (A)/52 (B), LI-59 (A)/59 (B) and RM77 (A)/77 (B) Boards	3-29
• LI-55 (A)/55 (B) and SW-279 (A)/279 (B) Boards	3-30
• LD-84 (A)/84 (B)	3-31

4. PRINTED WIRING BOARDS

4-1. Circuit Boards Location	4-1
4-2. Printed Wiring Boards	
• This Note is Common for Printed Wiring Boards	4-2
• CD-154 (A)/154 (B) Board	4-2
• VC-179 (A)/179 (B) Board	4-3
• MD-68 (A) Board	4-5
• RS-67 (A)/67 (B) Board	4-6
• PS-398 (A)/398 (B) and LB47 (A)/47 (B) Boards	4-7
• ID-11 (A)/11 (B) Board	4-8
• AT-21 (A)/21 (B) Board	4-10
• LI-52 (A)/52 (B) and LI-59 (A)/59 (B) Boards	4-11
• LI-55 (A)/55 (B) Board	4-12
• RM-77 (A)/77 (B) Board	4-13
• SW-279 (A)/279 (B) Board	4-15
• LD-84 (A)/84 (B) Board	4-16

5. ADJUSTMENTS

5-1. Preparation for Adjustment	5-1
5-1-1. List of Servicing Jigs	5-1
5-1-2. Preparations	5-2
5-1-3. Precautions	5-5
5-1-4. Adjusting Remote Commander	5-6
5-1-5. Page D Address List	5-7
5-1-6. Page F Address List	5-9
5-1-7. Page 5 Address List	5-12
5-1-8. Data Processing	5-14
5-2. Camera System Adjustment	
5-2-1. Power Supply Voltage Check	5-15
5-2-2. Page D Data Initialization	5-15
5-2-3. Page D Data Modification 1	5-15
5-2-4. Page F Data Initialization	5-15
5-2-5. Page F Data Modification	5-15
5-2-6. 28 MHz Original Oscillation Adjustment	5-16
5-2-7. V SUB Adjustment	5-16
5-2-8. VRG Adjustment	5-16
5-2-9. Flange Back Adjustment	5-17
5-2-10. Flange Back Check	5-17
5-2-11. Hall Adjustment	5-18
5-2-12. Picture Frame Setting	5-19
5-2-13. Color Reproduction Adjustment	5-20
5-2-14. Iris IN/OUT Adjustment	5-21
5-2-15. Max Gain Adjustment	5-21
5-2-16. Auto White Balance Standard Data Input	5-22
5-2-17. Auto White Balance Adjustment	5-22
5-2-18. White Balance Check	5-23
5-2-19. VIDEO OUT Level Check	5-23
5-2-20. Page D Data Modification 2	5-24E
5-2-21. Page 5 Data Initialization	5-24E
5-2-22. Home Position Adjustment	5-24E
5-3. Electrical Block Check	
5-3-1. MIC IN/AUDIO OUT Check	5-24E
5-3-2. Pan Tilter Operation Check	5-24E
5-3-3. DATE and TIME Switch Check	5-24E
5-3-4. Camera No Switch Check	5-24E

6. VISCA COMMAND LIST


6-1. VISCA Summary	6-1
6-2. EVI-D30/D31-VISCA Connection	6-2
6-3. VISCA Communication Formats	
6-3-1. VISCA Packet Structure	6-3
6-3-2. Commands and Inquiries	6-3
6-3-3. Responses to Commands and Inquiries	6-3
6-3-4. Socket Number	6-4
6-3-5. Command Execution Stop	6-4
6-4. EVI-D30/D31 Setting Commands (Network setting)	
6-4-1. VISCA Network Management Commands	6-4
6-4-2. VISCA Interface Commands	6-4
6-5. EVI-D30/D31 Functions	6-5
6-6. EVI-D30/D31 Commands	6-7
6-7. EVI-D30/D31 Inquiry Commands	6-10
6-8. Code List	6-12
6-9. VISCA Communications Examples	6-14E

7. REPAIR PARTS LIST

7-1. EXPLODED VIEWS	
7-1-1. Camera Cabinet Section	7-1
7-1-2. Pan Base Section	7-2
7-1-3. Tilt Base Section	7-4
7-1-4. Lens Section	7-5
7-2. ELECTRICAL PARTS LIST	
• AT-21 (A)/21 (B) Board	7-6
• CD-154 (A)/154 (B) Board	7-6
• ID-11 (A)/11 (B) Board	7-7
• LB-47 (A)/47 (B) Board	7-9
• LD-84 (A)/84 (B) Board	7-9
• LI-52 (A)/52 (B) Board	7-10
• LI-55 (A)/55 (B) Board	7-10
• LI-59 (A)/59 (B) Board	7-10
• MD-68 (A) Board	7-10
• PS-398 (A)/398 (B) Board	7-11
• RM-77 (A)/77 (B) Board	7-11
• RS-67 (A)/67 (B) Board	7-12
• SW-279 (A)/279 (B) Board	7-12
• VC-179 (A)/179 (B) Board	7-12
• Accessories	7-15E
• For Camera Color Reproduction Adjustment	92

SECTION 3 BLOCK DIAGRAMS/SCHEMATIC DIAGRAMS

3-1. OVERALL BLOCK DIAGRAM







3-2. SCHEMATIC DIAGRAM


CD-154 (A)/154 (B) (CCD IMAGER) SCHEMATIC DIAGRAM
- Ref. No. CD-154 (A)/154 (B) BOARD : 1,000 series -


THIS NOTE IS COMMON FOR SCHEMATIC DIAGRAMS.

• For schematic diagrams.

- Caution when replacing chip parts.
New parts must be attached after removal of chip.
Be careful not to heat the minus side of tantalum capacitor, because it is damaged by the heat.
- All resistors are in ohms, 1/4W unless otherwise noted.
- Chip resistor are 1/8W or 1/10W unless otherwise noted.
k : 1000 Ω , M Ω : 1000k Ω .
- All capacitors are in μ F unless otherwise noted. pF : μ pF.
50V or less are not indicated except for electrolytics and tantalums.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
-  : nonflammable resistor.
-  : fusible resistor.
-  : panel designation.
-  : internal component.


When indicating parts by reference number, please include the board name.





VC-179 (A)/179 (B) (CAMERA(2)) SCHEMATIC DIAGRAM

— Ref. No. VC-179 (A)/179 (B) BOARD : 1,000 series —



– Ref. No. VC-179 (A)/179 (B) BOARD : 1,000 series –




VC-179 (A)/179 (B) (CAMERA(4))

The following have been devided into 3 sections as noted on the grid shown below.

A1	A2	A3
----	----	----









RS-67 (A)/67 (B) (BACK UP) LB-47 (A)/47(B) (BATTERY) MD-68(A)/68 (B) (MODE CONTROL)

The following have been devided into 3 sections as noted on the grid shown below.

A1	A2	A3
----	----	----

RS-67 (A)/67 (B) (BACK UP) LB-47 (A)/47 (B) (BATTERY) MD-68 (A)/68 (B) (MODE CONTROL) SCHEMATIC DIAGRAM

—Ref. No. RS-67 (A)/67 (B) BOARD : 2,000 series, LB-47 (A)/47 (B) BOARD : 2,000 series, MD-68 (A)/68 (B) BOARD : 2,000 series—




PS-398 (A)/398 (B) (POWER SWITCH) ID-11 (A)/11(B) (MOTOR DRIVE, INPUT/OUTPUT)

The following have been devided into 3 sections as noted on the grid shown below.

A1	A2	A3
----	----	----


PS398 (A)/398 (B) (POWER SWITCH) ID-11 (A)/11 (B) (MOTOR DRIVE, INPUT/OUTPUT) SCHEMATIC DIAGRAM


– Ref. No. PS-398 (A)/398 (B) BOARD : 2,000 series, ID-11 (A)/11 (B) BOARD : 2,000 series –



7 8 9 10 11 12 13 14 15 16

[A] / 11 (B) BOARD





AT-21 (A)/21 (B) (VIDEO PROCESS, MAIN CONTROL)


The following have been devided into 3 sections as noted on the grid shown below.

A1	A2	A3
----	----	----


AT-21 (A)/21 (B) (VIDEO PROCESS, MAIN CONTROL) SCHEMATIC DIAGRAM


– Ref. No. AT-21 (A)/21 (B) BOARD : 1,000 series –





LI-52 (A)/52 (B) (TILT END SENSOR) LI-59 (A)/59 (B) (TILT R SENSOR) LI-55 (A)/55 (B) (PAN R SENSOR) RM-77 (A)/77 (B) (SIRCS RECEIVE) SW-279 (A)/279 (B) (MIC AMP) SCHEMATIC DIAGRAM
- Ref. No. LI-52 (A)/52 (B) BOARD : 2,000 series, LI-59 (A)/59 (B) BOARD : 2,000 series, LI-55 (A)/55 (B) BOARD : 2,000 series, RM-77 (A)/77 (B) BOARD : 2,000 series, SW-279 (A)/279 (B) BOARD : 2,000 series-





EVI-D30 (J, UC)
EVI-D31 (CE) J, E
9-923-017-43

Sony Corporation
B&P Company

Printed in Japan
2002. 4 22
©1999