

Fig. 12-2 Adjusting parts location (2)

12-1. Power Voltage Adjustment

Connection: As shown in Fig. 12-3.

Adjusting Parts: R309 100 kΩ (B) See Fig. 12-4.

Procedures:

- Be sure that the correct power voltage is supplied.
 Place the machine in STOP mode.
 Adjust R309 to obtain 25 ~ 26V on the VTYM.




Fig. 12-3 Power voltage adjustment

★ D301 0305

CAUTION

Be careful not to short-circuit the B⁺ circuit to ground, or the transistor Q304 will be broken.




Fig. 12-4 Power voltage adjustment

R311

12-2. Tape Pass Adjustment

(A) Tape Guide (left) Adjustment

Adjusting Parts:

tape guide (left) See Fig. 12-1

- Thread a tape.
 Align the upper edge of the tape just on the upper edge of the erase head core by turning the tape guide located on the left side of the erase head.
- (3) Turn the tape guide located on the left side of the erase head clockwise by approxiedge of the tape is approximately 0.05 mm lower than that of the erase head core. mately 35° from the position obtained in the preceding procedures, so that the upper

Procedures:

- (1) Turn the azimuth adjusting screws and the angle adjusting screws so that the record head and the playback head are positioned
- nearly as shown in Fig. 12-5.

 (2) Turn the p.b. head height adjusting screw so that the upper edge of the p.b. head is 0.025 mm lower than that of the tape and memorize the angle of turns.
- (3) Turn the p.b. head zenith adjusting screw by the same angle of turns to the same direction of the p.b. head height adjusting screw.




Fig. 12-5 Tape guide (left) adjustment

Adjusting Parts: (B) Tentative Record and P.B. Heads Adjustments (See Fig. 12-1.)

- P.B. Head (1) azimuth adjusting screw
- angle adjusting screws
 height adjusting screw

- (The p.b. head and the record head adjustments should be made in numerical order.)
- so that the upper edge of the record head is 0.025 mm lower than that of the tape and memorize the angle of turns.

(4) Turn the record head height adjusting screw

- (5) Turn the record head zenith adjusting screw direction of the record head height adjusting by the same angle of turns to the same
- screw.
 (6) Set the machine at 19 cm/s (714 ips) tape
- (7) Make the tape loose a little by pushing the tion of light as shown in Fig. 12-6. adjust the p.b. head and the record head zenith adjusting screws to obtain the reflectension regulator arm pin in the direction shown with arrow in Fig. 12-6 and then