

# ICF-C273

## SERVICE MANUAL

Australian Model

Ver 1.0 2004.03



### SPECIFICATIONS

**Time display**

12 hour

**Frequency range**

Band	Channel step
FM	0.05 MHz
AM	9 kHz

**Speaker**

Approx. 6.6 cm (2 5/8 in.) dia. 8 Ω

**Power output**

200 mW (at 10% harmonic distortion)

**Power requirements**

230 V AC, 50 Hz

**Dimensions**

Approx. 173 x 57.2 x 133.5 mm (w/h/d)

(6 7/8 x 2 3/8 x 5 3/8 in.) incl. projecting parts and controls

**Mass** Approx. 630 g (1 lb 6.2 oz)

Design and specifications are subject to change without notice.

## FM/AM PLL SYNTHESIZED CLOCK RADIO

9-877-642-01

2004C02-1

© 2004.03

**Sony Corporation**

Personal Audio Company

Published by Sony Engineering Corporation

**SONY®**

**TABLE OF CONTENTS**

Specifications ..... 1

**1. GENERAL**

Location and Function of Controls ..... 3

**2. DISASSEMBLY**2-1. Switch Board, Cabinet (Upper) ..... 6  
2-2. Alarm Board, jog Board ..... 7  
2-3. Main Board ..... 7  
2-4. Trans Board ..... 8**3. ELECTRICAL ADJUSTMENTS** ..... 9**4. DIAGRAMS**4-1.IC Block Diagrams ..... 11  
4-2.Block Diagrams ..... 12  
4-3. Printed Wiring Board –Main section (1/2)– ..... 13  
4-4. Printed Wiring Board –Main section (2/2)– ..... 14  
4-5. Schematic Diagram –Main section (1/2)– ..... 15  
4-6. Schematic Diagram –Main section (2/2)– ..... 16**5. EXPLODED VIEW**5-1.Cabinet (Upper) Section ..... 17  
5-2.Cabinet (Lower) section ..... 18**6. ELECTRICAL PARTS LIST** ..... 19**SAFETY-RELATED COMPONENT WARNING!!**

COMPONENTS IDENTIFIED BY MARK  $\triangle$  OR DOTTED LINE WITH MARK  $\triangle$  ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION.

REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

**• HOW TO CHANGE THE CERAMIC FILTER**

This model is used two ceramic filters of CF2 and CF3.  
You must use same type of color marked ceramic filters in order to meet same specifications.  
Therefore, the ceramic filter must change two pieces together since it's supply two pieces in package as a spare parts.


mark	CF2	mark	CF3	Mark	Center frequency
				no mark	10.70MHz
				blue	10.67MHz
				orange	10.73MHz
				black	10.64MHz
				white	10.76MHz

# SECTION 1

## GENERAL

This section is extracted from instruction manual.

### LOCATION AND FUNCTION OF CONTROLS



## Setting the Clock and Date

- 1 Plug in the clock radio.
- The display will flash "AM12:00" or "0:00".

- 2 Press **CLOCK** for a few seconds.

You will hear a beep and the year will start to flash in the display.

- 3 Press Jog lever ▲ (up) or ▼ (down) until the correct year appears in the display.

- 4 Press **ENTER/BRIGHTNESS**.

- 5 Repeat steps 3 and 4 to set the month, day, hour, and minute.

After setting the minute, press **ENTER/ BRIGHTNESS** to start the counting of the seconds, and you will hear two short beeps.

- To set the current time rapidly, hold down Jog lever ▲ (up) or ▼ (down).

- The clock system varies depending on the model you own.

12-hour system: "AM 12:00" = midnight

24-hour system: "0:00" = midnight

- In step 5, when you press **ENTER/BRIGHTNESS** after the minute setting to activate the clock, the seconds start counting from zero.

- When the alarm setting mode is entered, the clock cannot be set.

## To display the year and date

Press **SNOOZE/DATE/SLEEP OFF** once for the date, and within 2 seconds press it again for the year.

The display shows the date or year for a few seconds and then changes back to the current time.

## To change the display to the daylight saving time (summer time) indication

Press **D.S.T./SUMMER T.**

" " is displayed and the time indication changes to summer time.

To deactivate the summer time function, press **D.S.T./SUMMER T.** again.

## To set the brightness of the backlight

If you cannot see the display clearly, press and hold **ENTER/ BRIGHTNESS** to set the desired brightness (high, middle or low).

## Changing AM (MW) Channel Step

The AM (MW) channel step differs depending on area. The channel step of this unit is factory-set to 9 kHz or 10 kHz to change the setting as shown below to be able to listen to the radio.

### Channel step

9 kHz

- 1 Plug in the clock radio.

Press **OFF/ALARM RESET** to turn off the power.

- 2 While holding down **OFF/ALARM RESET**, keep pressing **ON/BAND** for more than 5 seconds.

The AM (MW) channel step will be changed.

If you proceed to step 2 again, the channel step changes again.

### Notes

- When the AM (MW) channel step is changed, the preset stations for AM (MW) will be initialized.
- When the AM (MW) channel step is changed, the FM channel step also will be changed.

## Operating the Radio

### —Manual Tuning

- 1 Press **ON/BAND** to turn on the radio.

The display shows the band and frequency for a few seconds and then changes back to the current time.

- 2 Press **ON/BAND** repeatedly to select the desired band.

Each press changes the band as follows:



When using FM1 or FM2 preset mode, you may listen to the radio on either mode. (See "Presetting Your Favourite Station".)

- 3 Use **TUNING + or -** to tune into the desired station.

The FM channel step is set to 0.05 MHz\* and the AM (MW) channel step is set to 9 kHz.

\* The FM frequency display is raised or lowered by a step of 0.1 MHz. For example, frequency 88.00 and 88.05 MHz is displayed as "88.0 MHz."

Two short beeps sound when the minimum frequency of each band is received during tuning.

- 4 Adjust volume using **VOLUME**.

- To turn off the radio, press **OFF/ALARM RESET**.

• To listen with an earphone, connect the earphone to the  (earphone) jack. The speaker is deactivated when an earphone is connected.

- To check the station being received, press **TUNING + or - or ON/BAND** lightly. The display shows the band and frequency for a few seconds and then changes back to the current time.

## Improving the Reception

### FM:

Extend the FM wire antenna fully to increase reception sensitivity.

### AM (MW):

Rotate the unit horizontally for optimum reception. A ferrite bar is built in to the unit.

Do not operate the unit over a steel desk or metal surface, as this may lead to interference of reception.

## Presetting Your Favourite Station

### —Preset Tuning

You can preset up to 10 stations in FM (5 stations in FM1, 5 stations in FM2), and 5 stations in AM.

### Presetting a Station

- 1 Follow steps 1 to 4 in "Operating the Radio" and manually tune into the station you wish to preset.

- 2 Hold down the desired **STATION•SELECT/PRESET** button until you hear two short beeps.

**Example:** To preset AM 1 260 kHz onto preset 2 button.



The display shows the frequency for a few seconds and then changes back to the current time.

To preset another station, repeat these steps.

To change the preset station, tune into the desired station and hold down the **PRESET TUNING 1 to 5** button. The new station will replace the previous station on the preset button.

### Tuning into a preset station

- 1 Press **ON/BAND** to turn on the radio.

- 2 Press **STATION•SELECT/PRESET** where the desired station is stored.

- 3 Adjust volume using **VOLUME**.

After a few seconds, the display will return to the current time but the preset button number will remain.

## Setting the Alarm

You can choose from two types of alarm, Radio or Buzzer.

The alarm will come on at the same time everyday.

The factory setting alarm time for the radio and buzzer is 12:00am or 0:00.

### Notes

- Set the current time before setting the alarm.
- Radio reception is interrupted while the alarm time is being set.

### To set the Alarm Time

- 1 Press and hold **ALARM A** or **ALARM B** for a few seconds.

After one beep, the hour flashes in the alarm display.

- 2 Press Jog lever ▲ (up) or ▼ (down) to select the hour.

To set the hour rapidly, hold down Jog lever ▲ (up) or ▼ (down).

- 3 Press **ENTER/BRIGHTNESS**.


After one beep, the minutes flash on the alarm display.

- 4** Repeat steps **2** and **3** to set the minute.  
 A beep sounds to confirm the time setting.  
 “RADIO•SOUND” appears.  
 You can choose between “RADIO” and “SOUND” modes.  
 Set the alarm mode as follows:  
 • RADIO: see “**A** Setting the Radio Alarm”  
 • SOUND: see “**B** Setting the Sound Alarm”

### **A** Setting the Radio Alarm

For the radio alarm, the station you specified as the wake-up station is played.

**1** Perform steps **1** to **4** in “To set the Alarm Time.”  
**2** Press Jog lever ▲ (up) or ▼ (down) to select “RADIO” alarm mode.  
 “WAKE UP STATION” appears in the display.  
**3** Press **ENTER/BRIGHTNESS**.  
 After one beep, the preset number flashes in the display.  
**4** Press Jog lever ▲ (up) or ▼ (down) to select the desired wake-up station.  
 Preset number changes in the order as follows:



“P-” is the last received station.  
 You can directly select the desired wake-up station by pressing **ON/BAND** or the **STATION•SELECT/PRESET** button while the indication “P-” is not displayed.

**5** Press **ENTER/BRIGHTNESS**.

Two short beeps will confirm the setting, and the ALARM A or B display will disappear.

### **B** Setting the Sound Alarm

For the sound alarm, the sound you specified as the wake-up sound is played.

**1** Perform steps **1** to **4** in “To set the Alarm Time.”  
**2** Press Jog lever v (up) or V (down) to select “SOUND” alarm mode.  
 “WAKE UP SOUND” appears in the display.  
**3** Press **ENTER/BRIGHTNESS**.  
 The displayed wake-up sound number will sound.  
**4** Press Jog lever v (up) or V (down) to select the desired wake-up sound.  
 1: Buzzer  
 2: “Four seasons: Spring” Antonio Lucio Vivaldi  
 3: “For Eliza” Ludwig van Beethoven

**5** Press **ENTER/BRIGHTNESS**.

Two short beeps will confirm the setting, and the ALARM A or B display will disappear.

### To Use the Radio and Buzzer Alarm

- 1** Set both alarm times for ALARM A or B.  
 (see above).  
**2** Press **ALARM A** or **ALARM B**.  
 The ALARM A or B display will be turned on.

If the same alarm time is set for both Alarm A and B, Alarm A takes priority.

### To Doze for a Few More Minutes

Press **SNOOZE/DATE/SLEEP OFF**.  
 The radio or buzzer turns off but will automatically come on again after about 10 minutes. Every time you press **SNOOZE/DATE/SLEEP OFF**, the snooze time changes as follows:

10 → 20 → 30 → 40 → 10 →

The display shows the snooze time for a few seconds and returns to show the current time. When you press **SNOOZE/DATE/SLEEP OFF** after the current time appeared, the snooze time starts from 10 minutes again.

The maximum length of the snooze time is 60 minutes.

### To Stop the Alarm

Press **OFF/ALARM RESET** to turn off the alarm.  
 The alarm will come on again at the same time the next day.

### To Deactivate the Alarm


Press **ALARM A** or **ALARM B**.  
 The ALARM A or B display turns off.

---

### Using the NAP Timer

#### (Count Down Timer)

The NAP timer sounds the buzzer after a preset time duration. Press **NAP** repeatedly until the desired minutes are displayed. Every press changes the display as follows:



You will hear two beeps when the display turns from “OFF” to “10”. “NAP” appears and the NAP time is displayed for a few seconds. NAP timer starts counting down the NAP time. When selected NAP time has passed, the beep sound comes on, and “NAP” on the display flash. The buzzer is turned off automatically after about 60 minutes.

### To Stop the NAP Timer

Press **NAP** or **OFF/ALARM RESET** to turn off the buzzer.

#### To Deactive the NAP Timer

Press **NAP**.

“NAP” goes off in the display.

---

### Setting the Sleep Timer

You can fall asleep to the radio using the built-in sleep timer that turns off the radio automatically after a preset duration.

Press **SLEEP**.

The radio turns on. You can set the sleep timer to durations of 90, 60, 30, or 15 minutes. Every push changes the display as follows:



You will hear two beeps when the display turns from “OFF” to “90”. “SLEEP” will appear in the display when the duration time is set. The radio will play for the duration you set, then shut off.

• To turn off the radio before the preset time, press **SNOOZE/DATE/SLEEP OFF**.

### To Use Both Sleep Timer and Alarm


You can fall asleep to the radio and also be awakened by the radio or buzzer alarm at a preset time.

- 1** Set the alarm. (See “Setting the Alarm”.)  
**2** Set the sleep timer. (See “Setting the Sleep Timer”.)

## SECTION 2 DISASSEMBLY


### 2-1. DISASSEMBLY FLOW

- The equipment can be removed using the following procedure.




**Note :** Follow the disassembly procedure in the numerical order given.


### 2-2. SWITCH BOARD, CABINET (UPPER)




### 2-3. ALARM BOARD, JOG BOARD



### 2-4. MIAN BOARD



**2-5. TRANS BOARD**




## SECTION 3

### ELECTRICAL ADJUSTMENTS

#### 3-1.TUNER SECTION

**AM Section**
0dB=1 $\mu$ V

BAND button : AM  
Volume : MIN




*Put the lead-wire antenna close to the set.*


*30% amplitude modulation by 400Hz signal.  
Output level : as low as possible*

**FM Section**

BAND button : FM  
Volume : MIN



*22.5kHz frequency deviation by 400Hz signal.  
Output level : as low as possible*




FM FREQUENCY COVERAGE CONFIRMATION		
Adjust part	Frequency display	reading on digital voltmeter
Confirmation	87.5MHz	3.0 to 4.0V
Confirmation	108MHz	9.5 to 10.5V

FM TRACKING ADJUSTMENT		
Adjust for a maximum reading on level meter.		
L2	87.5MHz	
CT3	108MHz	

#### Frequency Coverage Adjustment

##### Connect Location :



- Repeat the procedures in each adjustment several times, and the frequency coverage and tracking adjustments should be finally done by the trimmer capacitors.

**AM IF ADJUSTMENT**

Adjust for a maximum reading on level meter.

T1	450kHz
----	--------

**AM FREQUENCY COVERAGE ADJUSTMENT**

Adjust part	Frequency display	reading on digital voltmeter.
L4	531kHz	Adjustment value: 2.7V Standad value: 2.5 to 2.9V


**AM TRACKING ADJUSTMENT**

Adjust for a maximum reading on level meter.

L1	585kHz
CT1	1,485kHz


**SECTION 4  
DIAGRAMS**

- Circuit Boards Location



#### 4-1. IC Block Diagrams

**IC1 CXA1019M**




**Note:**

- All capacitors are in  $\mu\text{F}$  unless otherwise noted. pF:  $\mu\mu\text{F}$  50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in  $\Omega$  and  $1/4\text{ W}$  or less unless otherwise specified.
- $\triangle$  : internal component.

**Note:** The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety. Replace only with part number specified.

- Voltages are dc with respect to ground under no-signal conditions.  
no mark : FM  
( ) : AM
- Voltages are taken with a VOM (Input impedance  $10\text{ M}\Omega$ ). Voltage variations may be noted due to normal production tolerances.
- Signal path.**  
 $\Rightarrow$  : FM  
 $\rightarrow$  : AM


**IC51 LC7213M-TLM-E**




**Note:**

- : parts extracted from the component side.
- $\triangle$  : internal component.
- [ ] : Pattern from the side which enables seeing.

## 4-2. BLOCK DIAGRAM




## 4-3. PRINTED WIRING BOARD – MAIN SECTION (1/2) –




- Semiconductor Location

Ref. No.	Location
D2	C-4
D3	C-4
D4	B-5
D51	C-7
D52	D-6
D53	D-6
D101	F-9
D102	F-9
D103	F-9
D104	F-10
D105	F-10
D106	E-4
D108	G-10
D109	F-9
D110	G-7
D111	F-4
D112	G-4
D201	E-9
D202	C-8
D203	D-7
D204	D-7
D205	G-11
IC1	D-4
IC51	C-6
IC101	F-6
IC102	F-4
IC103	G-4
Q3	D-2
Q4	E-2
Q101	F-9
Q102	F-11
Q103	F-11
Q104	G-2
Q105	G-2
Q106	G-2
Q107	H-3
Q108	G-4
Q109	G-4
Q201	D-6
Q202	D-6


## 4-4. PRINTED WIRING BOARD - MAIN SECTION (2/2) -



#### **4-5. SCHEMATIC DIAGRAM – MAIN SECTION (1/2)–**



## 4-6. SCHEMATIC DIAGRAM – MAIN SECTION (2/2)



## SECTION 5 EXPLODED VIEW

**NOTE :**

- XX, -X mean standardized parts, so they may have some difference from the original one.
- Color indication of Appearance Parts  
Example :  
KNOB, BALANCE (WHITE) \*\*\* (RED)


- The mechanical parts with no reference number in the exploded views are not supplied.
- Accessories and packing materials are given in the last of this parts list.

The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

Parts color Cabinet's color


- Items marked “\*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

### 5-1. CABINET (UPPER) SECTION



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
1	3-254-141-01	SCREW (B2.6), (+) BV TAPPING		* 8	1-861-136-11	ALARM BOARD	
2	3-261-891-01	CHASSIS		9	X-2022-167-1	COVER (JOG) ASSY	
* 3	1-861-132-11	SWITCH BOARD		* 10	1-861-135-11	JOG BOARD	
4	3-252-827-01	SCREW (B2.6), (+) BV TAPPING		11	3-261-887-01	ARM (JOG)	
5	3-259-210-01	CUSHION (H)		12	3-261-888-01	KNOB (JOG)	
6	X-2022-166-1	CABINET, UPPER ASSY		SP1	1-529-456-13	SPEAKER (6.6cm)	
7	3-254-070-01	SCREW					

## 5-2. CABINET (LOWER) SECTION



The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
51	3-261-883-21	CABINET (LOWER)		58	3-382-175-21	KNOB (V)	
52	3-246-344-11	FOOT, RUBBER		59	A-4541-926-A	MAIN BOARD COMPLETE	
* 53	1-861-131-11	TRANS BOARD		L1	1-428-951-21	COIL, FERRITE-ROD ANTENNA (MW)	
54	3-261-890-01	HOLDER (LCD)		LCD101	1-805-524-11	DISPLAY PANEL, LIQUID CRYSTAL	
55	3-254-070-01	SCREW		$\triangle$ P201	1-790-431-21	POWER SUPPLY CORD (7.5A/250V)	
56	3-252-827-01	SCREW (B2.6), (+) BV TAPPING		$\triangle$ T201	1-435-504-11	TRANSFORMER, POWER	
57	3-261-892-01	HOLDER (ANTENNA)		W2	1-754-330-11	ANTENNA (WIRE)	

# SECTION 6

## ELECTRICAL PARTS LIST

**ALARM****JOG****MAIN****NOTE :**

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.
- **RESISTORS**  
All resistors are in ohms  
METAL : Metal-film resistor  
METAL OXIDE :Metal oxide-film resistor  
F : nonflammable
- Items marked “ \* ” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

**SEMICONDUCTORS**

In each case, u :  $\mu$  , for example :  
 uA.... :  $\mu$  A.... , uPA.... :  $\mu$  PA....  
 uPB.... :  $\mu$  PB.... , uPC.... :  $\mu$  PC....  
 uPD.... :  $\mu$  PD....

**CAPACITORS**uF :  $\mu$  F**COILS**uH :  $\mu$  H

The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.

Replace only with part number specified.

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
*	1-861-136-11	ALARM BOARD	*****			C12	1-126-964-11	ELECT	10uF	20%	50V
		< RESISTOR >				C13	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
R196	1-216-833-11	METAL CHIP	10K	5%	1/10W	C14	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V
R197	1-216-833-11	METAL CHIP	10K	5%	1/10W	C15	1-126-964-11	ELECT	10uF	20%	50V
R198	1-216-833-11	METAL CHIP	10K	5%	1/10W	C16	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
		< SWITCH >				C17	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
S115	1-771-550-11	SWITCH, TACTILE (ALARM A)				C18	1-126-935-11	ELECT	470uF	20%	16V
S116	1-771-550-11	SWITCH, TACTILE (ALARM B)				C19	1-126-923-91	ELECT	220uF	20%	10V
S117	1-771-550-11	SWITCH, TACTILE (ENTER/BRIGHTNESS)				C20	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
		*****				C21	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
*	1-861-135-11	JOG BOARD	*****			C22	1-164-230-11	CERAMIC CHIP	220PF	5%	50V
		< RESISTOR >				C23	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
R199	1-216-833-11	METAL CHIP	10K	5%	1/10W	C24	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V
R200	1-216-833-11	METAL CHIP	10K	5%	1/10W	C25	1-162-910-11	CERAMIC CHIP	5PF	0.25PF	50V
		< SWITCH >				C26	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
S118	1-554-937-11	SWITCH, TACTILE (TIME SET +)				C27	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
S119	1-554-937-11	SWITCH, TACTILE (TIME SET -)				C28	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
		*****				C29	1-164-230-11	CERAMIC CHIP	220PF	5%	50V
		A-4541-926-A MAIN BOARD, COMPLETE	*****			C30	1-115-416-11	CERAMIC CHIP	0.001uF	5%	25V
						C31	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		3-252-827-01 SCREW (B2.6), (+) BV TAPPING				C32	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
		3-261-890-01 HOLDER (LCD)				C33	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
		3-261-892-01 HOLDER (ANTENNA)				C34	1-164-230-11	CERAMIC CHIP	220PF	5%	50V
		3-382-175-21 KNOB (V)				C35	1-115-416-11	CERAMIC CHIP	0.001uF	5%	25V
		< FILTER >				C51	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V
BPF1	1-236-022-11	FILTER, BAND PASS				C52	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
		< CAPACITOR >				C53	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V
C3	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	C54	1-162-911-11	CERAMIC CHIP	6PF	0.5PF	50V
C4	1-115-416-11	CERAMIC CHIP	0.001uF	5%	25V	C55	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V
C5	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V	C56	1-164-315-11	CERAMIC CHIP	470PF	5%	50V
C6	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C57	1-126-923-91	ELECT	220uF	20%	10V
C7	1-115-416-11	CERAMIC CHIP	0.001uF	5%	25V	C58	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C8	1-162-908-11	CERAMIC CHIP	3PF	0.25PF	50V	C60	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C9	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C61	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C10	1-126-964-11	ELECT	10uF	20%	50V	C101	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
C11	1-126-963-11	ELECT	4.7uF	20%	50V	C102	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
						C103	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
						C105	1-164-315-11	CERAMIC CHIP	470PF	5%	50V
						C106	1-164-315-11	CERAMIC CHIP	470PF	5%	50V
						C107	1-164-315-11	CERAMIC CHIP	470PF	5%	50V
						C108	1-164-315-11	CERAMIC CHIP	470PF	5%	50V
						C109	1-164-315-11	CERAMIC CHIP	470PF	5%	50V
						C110	1-126-916-11	ELECT	1000uF	20%	6.3V
						C111	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
						C112	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
						C113	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
						C115	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
						C117	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
						C118	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V

**MAIN**

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>	<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>		
C119	1-162-970-11	CERAMIC CHIP	0.01uF 10%	25V	D204	8-719-069-54	DIODE UDZSTE-175.1B		
C120	1-162-970-11	CERAMIC CHIP	0.01uF 10%	25V	D205	8-719-988-61	DIODE 1SS355TE-17		
C121	1-107-826-11	CERAMIC CHIP	0.1uF 10%	16V			< IC >		
C122	1-107-826-11	CERAMIC CHIP	0.1uF 10%	16V					
C123	1-107-826-11	CERAMIC CHIP	0.1uF 10%	16V	IC1	8-752-050-16	IC CXA1019M		
C124	1-107-826-11	CERAMIC CHIP	0.1uF 10%	16V	IC51	8-759-483-40	IC LC72137M-TLM-E		
C131	1-162-970-11	CERAMIC CHIP	0.01uF 10%	25V	IC101	6-803-950-01	IC uPD789477GC-A41-8BT		
C132	1-162-970-11	CERAMIC CHIP	0.01uF 10%	25V	IC102	6-702-604-01	IC XC61CN2002NR		
C133	1-164-156-11	CERAMIC CHIP	0.1uF 25V		IC103	6-703-937-01	IC XC6201P302MR		
C134	1-164-156-11	CERAMIC CHIP	0.1uF 25V				< SHORT >		
C135	1-162-970-11	CERAMIC CHIP	0.01uF 10%	25V	JC1	1-216-864-11	SHORT CHIP 0		
C136	1-162-970-11	CERAMIC CHIP	0.01uF 10%	25V	JC2	1-216-864-11	SHORT CHIP 0		
C137	1-162-970-11	CERAMIC CHIP	0.01uF 10%	25V	JC51	1-216-864-11	SHORT CHIP 0		
C138	1-162-970-11	CERAMIC CHIP	0.01uF 10%	25V	JC101	1-216-864-11	SHORT CHIP 0		
C201	1-162-970-11	CERAMIC CHIP	0.01uF 10%	25V	JC102	1-216-864-11	SHORT CHIP 0		
C202	1-162-970-11	CERAMIC CHIP	0.01uF 10%	25V			< COIL >		
C203	1-126-926-11	ELECT	1000uF 20%	10V	L1	1-428-951-21	COIL, FERRITE-ROD ANTENNA (MW)		
C204	1-126-934-11	ELECT	220uF 20%	16V	L2	1-406-922-11	COIL, AIR-CORE		
C205	1-126-935-11	ELECT	470uF 20%	16V	L3	1-414-690-21	INDUCTOR 82nH		
C206	1-104-666-11	ELECT	220uF 20%	25V	L4	1-406-485-11	COIL (OSC)		
C251	1-162-970-11	CERAMIC CHIP	0.01uF 10%	25V					
< FILTER >									
* CF1	1-577-319-11	FILTER, CERAMIC							
CF2	1-579-632-41	FILTER, CERAMIC							
CF3	1-579-632-41	FILTER, CERAMIC							
< CONNECTOR >									
CN201	1-568-269-11	SOCKET, CONNECTOR 3P							
* CN251	1-568-268-11	SOCKET, CONNECTOR 2P							
CN501	1-770-640-11	CONNECTOR, FFC/FPC 9P							
< TRIMMER >									
CT1	1-141-299-11	CAP, CERAMIC TRIMMER	5PF (AM TRACKING)		Q3	8-729-026-52	TRANSISTOR 2SA1576A-T106-R		
CT3	1-141-304-21	CAP, CERAMIC TRIMMER	10PF (FM TRACKING)		Q4	8-729-905-35	TRANSISTOR 2SC4081-R		
< DIODE >									
D2	8-719-084-67	DIODE HVU202ATRU			Q101	8-729-029-14	TRANSISTOR DTC144EUA-T106		
D3	8-719-084-67	DIODE HVU202ATRU			Q102	8-729-905-35	TRANSISTOR 2SC4081-R		
D4	6-500-169-01	DIODE KV1610STL1-2			Q103	8-729-905-35	TRANSISTOR 2SC4081-R		
D51	8-719-083-63	DIODE UDZSTE-1713B							
D52	8-719-991-33	DIODE 1SS133T-77			Q104	8-729-905-35	TRANSISTOR 2SC4081-R		
D53	8-719-991-33	DIODE 1SS133T-77			Q105	8-729-905-35	TRANSISTOR 2SC4081-R		
D101	8-719-988-61	DIODE 1SS355TE-17			Q106	8-729-905-35	TRANSISTOR 2SC4081-R		
D102	8-719-988-61	DIODE 1SS355TE-17			Q107	8-729-905-35	TRANSISTOR 2SC4081-R		
D103	8-719-988-61	DIODE 1SS355TE-17			Q108	8-729-905-35	TRANSISTOR 2SC4081-R		
D104	8-719-988-61	DIODE 1SS355TE-17							
D105	8-719-988-61	DIODE 1SS355TE-17			Q109	8-729-905-35	TRANSISTOR 2SC4081-R		
D106	8-719-991-33	DIODE 1SS133T-77			Q201	8-729-011-92	TRANSISTOR 2SC2001TP-K1K2		
D108	6-500-920-01	DIODE SLP-235A-51S1E			Q202	8-729-011-92	TRANSISTOR 2SC2001TP-K1K2		
D109	6-500-920-01	DIODE SLP-235A-51S1E			< RESISTOR >				
D110	6-500-920-01	DIODE SLP-235A-51S1E			R3	1-216-845-11	METAL CHIP 100K 5% 1/10W		
D111	6-500-920-01	DIODE SLP-235A-51S1E			R4	1-216-825-11	METAL CHIP 2.2K 5% 1/10W		
D112	6-500-920-01	DIODE SLP-235A-51S1E			R5	1-216-817-11	METAL CHIP 470 5% 1/10W		
D201	8-719-063-79	DIODE 1N4002B			R6	1-216-829-11	METAL CHIP 4.7K 5% 1/10W		
D202	8-719-991-33	DIODE 1SS133T-77			R7	1-216-821-11	METAL CHIP 1K 5% 1/10W		
D203	8-719-083-60	DIODE UDZSTE-174.7B			R8	1-216-845-11	METAL CHIP 100K 5% 1/10W		
					R9	1-216-833-11	METAL CHIP 10K 5% 1/10W		
					R10	1-216-861-11	METAL CHIP 2.2M 5% 1/10W		
					R11	1-216-805-11	METAL CHIP 47 5% 1/10W		
					R12	1-216-809-11	METAL CHIP 100 5% 1/10W		
					R15	1-216-853-11	METAL CHIP 470K 5% 1/10W		
					R16	1-216-833-11	METAL CHIP 10K 5% 1/10W		
					R17	1-216-821-11	METAL CHIP 1K 5% 1/10W		
					R18	1-216-845-11	METAL CHIP 100K 5% 1/10W		

The components identified by mark **▲** or dotted line with mark **△** are critical for safety.  
Replace only with part number specified.

<b>Ref. No.</b>	<b>Part No.</b>	<b>Description</b>		<b>Remark</b>	<b>Ref. No.</b>	<b>Part No.</b>	<b>Description</b>		<b>MAIN</b>	<b>SWITCH</b>	<b>Remark</b>
R19	1-216-841-11	METAL CHIP	47K	5%	1/10W	R162	1-216-833-11	METAL CHIP	10K	5%	1/10W
R51	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	R163	1-216-833-11	METAL CHIP	10K	5%	1/10W
R52	1-216-797-11	METAL CHIP	10	5%	1/10W	R164	1-216-833-11	METAL CHIP	10K	5%	1/10W
R53	1-216-837-11	METAL CHIP	22K	5%	1/10W	R165	1-216-833-11	METAL CHIP	10K	5%	1/10W
R54	1-216-833-11	METAL CHIP	10K	5%	1/10W	R166	1-216-833-11	METAL CHIP	10K	5%	1/10W
R55	1-216-833-11	METAL CHIP	10K	5%	1/10W	R167	1-216-833-11	METAL CHIP	10K	5%	1/10W
R56	1-216-813-11	METAL CHIP	220	5%	1/10W	R168	1-216-833-11	METAL CHIP	10K	5%	1/10W
R58	1-216-821-11	METAL CHIP	1K	5%	1/10W	R169	1-216-833-11	METAL CHIP	10K	5%	1/10W
R59	1-216-821-11	METAL CHIP	1K	5%	1/10W	R170	1-216-833-11	METAL CHIP	10K	5%	1/10W
R60	1-216-821-11	METAL CHIP	1K	5%	1/10W	R171	1-216-833-11	METAL CHIP	10K	5%	1/10W
R101	1-216-821-11	METAL CHIP	1K	5%	1/10W	R172	1-216-833-11	METAL CHIP	10K	5%	1/10W
R102	1-216-821-11	METAL CHIP	1K	5%	1/10W	R173	1-216-833-11	METAL CHIP	10K	5%	1/10W
R103	1-216-821-11	METAL CHIP	1K	5%	1/10W	R174	1-216-833-11	METAL CHIP	10K	5%	1/10W
R104	1-216-821-11	METAL CHIP	1K	5%	1/10W	R175	1-216-833-11	METAL CHIP	10K	5%	1/10W
R105	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	R176	1-216-833-11	METAL CHIP	10K	5%	1/10W
R106	1-216-833-11	METAL CHIP	10K	5%	1/10W	R177	1-216-833-11	METAL CHIP	10K	5%	1/10W
R107	1-216-833-11	METAL CHIP	10K	5%	1/10W	R178	1-216-833-11	METAL CHIP	10K	5%	1/10W
R108	1-216-833-11	METAL CHIP	10K	5%	1/10W	R179	1-216-833-11	METAL CHIP	10K	5%	1/10W
R109	1-216-845-11	METAL CHIP	100K	5%	1/10W	R180	1-216-833-11	METAL CHIP	10K	5%	1/10W
R110	1-216-821-11	METAL CHIP	1K	5%	1/10W	R181	1-216-833-11	METAL CHIP	10K	5%	1/10W
R111	1-216-857-11	METAL CHIP	1M	5%	1/10W	R182	1-216-833-11	METAL CHIP	10K	5%	1/10W
R112	1-216-821-11	METAL CHIP	1K	5%	1/10W	R183	1-216-833-11	METAL CHIP	10K	5%	1/10W
R114	1-216-845-11	METAL CHIP	100K	5%	1/10W	R184	1-216-833-11	METAL CHIP	10K	5%	1/10W
R115	1-216-845-11	METAL CHIP	100K	5%	1/10W	R185	1-216-833-11	METAL CHIP	10K	5%	1/10W
R119	1-216-845-11	METAL CHIP	100K	5%	1/10W	R186	1-216-833-11	METAL CHIP	10K	5%	1/10W
R120	1-216-797-11	METAL CHIP	10	5%	1/10W	R187	1-216-833-11	METAL CHIP	10K	5%	1/10W
R121	1-216-797-11	METAL CHIP	10	5%	1/10W	R188	1-216-833-11	METAL CHIP	10K	5%	1/10W
R122	1-216-797-11	METAL CHIP	10	5%	1/10W	R189	1-216-833-11	METAL CHIP	10K	5%	1/10W
R123	1-216-797-11	METAL CHIP	10	5%	1/10W	R190	1-216-833-11	METAL CHIP	10K	5%	1/10W
R125	1-216-817-11	METAL CHIP	470	5%	1/10W	R191	1-216-833-11	METAL CHIP	10K	5%	1/10W
R126	1-216-813-11	METAL CHIP	220	5%	1/10W	R192	1-216-833-11	METAL CHIP	10K	5%	1/10W
R128	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	R201	1-216-817-11	METAL CHIP	470	5%	1/10W
R129	1-216-809-11	METAL CHIP	100	5%	1/10W	R202	1-216-817-11	METAL CHIP	470	5%	1/10W
R130	1-216-805-11	METAL CHIP	47	5%	1/10W	R203	1-216-829-11	METAL CHIP	4.7K	5%	1/10W
R131	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	R211	1-216-837-11	METAL CHIP	22K	5%	1/10W
R132	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	R213	1-216-845-11	METAL CHIP	100K	5%	1/10W
R133	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	R214	1-216-845-11	METAL CHIP	100K	5%	1/10W
R134	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	R215	1-216-845-11	METAL CHIP	100K	5%	1/10W
R135	1-216-829-11	METAL CHIP	4.7K	5%	1/10W						< VARIABLE RESISTOR >
R136	1-216-829-11	METAL CHIP	4.7K	5%	1/10W						
R137	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	RV1	1-227-482-11	RES, VAR, CARBON			50K (VOL-)
R138	1-216-849-11	METAL CHIP	220K	5%	1/10W						< TRANSFORMER >
R141	1-216-797-11	METAL CHIP	10	5%	1/10W	T1	1-404-790-11	TRANSFORMER, IF (AM IF)			
R142	1-216-825-11	METAL CHIP	2.2K	5%	1/10W						< ANTENNA WIRE >
R144	1-216-821-11	METAL CHIP	1K	5%	1/10W						
R145	1-216-825-11	METAL CHIP	2.2K	5%	1/10W						
R146	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	W2	1-754-330-11	ANTENNA (WIRE)			
R147	1-216-817-11	METAL CHIP	470	5%	1/10W						< VIBRATOR >
R148	1-216-813-11	METAL CHIP	220	5%	1/10W						
R149	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	X51	1-767-388-11	VIBRATOR, CRYSTAL (75kHz)			
R150	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	X101	1-760-252-12	VIBRATOR, CRYSTAL (32.768kHz)			
R151	1-216-797-11	METAL CHIP	10	5%	1/10W	X102	1-795-054-21	VIBRATOR, CERAMIC (4.192MHz)			
R152	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	*****	*****	*****	*****	*****	*****
R153	1-216-829-11	METAL CHIP	4.7K	5%	1/10W						
R154	1-216-821-11	METAL CHIP	1K	5%	1/10W						
R155	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	*	1-861-132-11	SWITCH BOARD			
R156	1-216-829-11	METAL CHIP	4.7K	5%	1/10W						< RESISTOR >
R157	1-216-809-11	METAL CHIP	100	5%	1/10W						
R159	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	R193	1-216-833-11	METAL CHIP	10K	5%	1/10W
R160	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	R194	1-216-833-11	METAL CHIP	10K	5%	1/10W
R161	1-216-833-11	METAL CHIP	10K	5%	1/10W	R195	1-216-833-11	METAL CHIP	10K	5%	1/10W

<b>SWITCH</b>	<b>TRANS</b>
---------------	--------------

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
-----------------	-----------------	--------------------	---------------

&lt; SWITCH &gt;

S101	1-771-550-11	SWITCH, TACTILE (TUNNG +)
S102	1-771-550-11	SWITCH, TACTILE (TUNING -)
S103	1-554-937-11	SWITCH, TACTILE (CLOCK)
S104	1-771-550-11	SWITCH, TACTILE (ON/BAND)
S105	1-771-550-11	SWITCH, TACTILE (OFF/ALARM RESET)
S106	1-554-937-11	SWITCH, TACTILE (SLEEP)
S107	1-771-550-11	SWITCH, TACTILE (NAP)
S108	1-554-937-11	SWITCH, TACTILE (STATION.SELECT/PRESET 1)
S109	1-554-937-11	SWITCH, TACTILE (STATION.SELECT/PRESET 2)
S110	1-554-937-11	SWITCH, TACTILE (STATION.SELECT/PRESET 3)
S111	1-554-937-11	SWITCH, TACTILE (STATION.SELECT/PRESET 4)
S112	1-554-937-11	SWITCH, TACTILE (STATION.SELECT/PRESET 5)
S113	1-771-550-11	SWITCH, TACTILE (SNOOZE/DATE/SLEEP OFF)
S114	1-554-937-11	SWITCH, TACTILE (D.S.Y. SUMMER T)

&lt; FLAT CABLE &gt;

W500 1-829-132-11 CABLE, FLEXIBLE FLAT (9 CORE)

\*\*\*\*\*

\* 1-861-131-11 TRANS BOARD  
\*\*\*\*\*

&lt; POWER CORD &gt;

△ P201 1-790-431-21 POWER SUPPLY CORD 7.5A 250V

&lt; TRANSFORMER &gt;

△ T201 1-435-504-11 TRANSFORMER, POWER

&lt; TERMINAL &gt;

TML201 1-535-771-31 TERMINAL

TML202 1-535-771-31 TERMINAL

\*\*\*\*\*

**MISCELLANEOUS**  
\*\*\*\*\*

LCD101 1-805-524-11 DISPLAY PANEL, LIQUID CRYSTAL

L1 1-428-951-21 COIL, FERRITE-ROD ANTENNA (MW)

△ P201 1-790-431-21 POWER SUPPLY CORD (7.5A/250V)

SP1 1-529-456-13 SPEAKER (6.6cm)

△ T201 1-435-504-11 TRANSFORMER, POWER

W2 1-754-330-11 ANTENNA (WIRE)

\*\*\*\*\*

**ACCESSORIES**  
\*\*\*\*\*

3-263-574-11 MANUAL, INSTRUCTION  
(ENGLISH, FRENCH, GERMAN, SPANISH)

The components identified by mark △ or dotted line with mark △ are critical for safety.

Replace only with part number specified.

MEMO

## REVISION HISTORY

Clicking the version allows you to jump to the revised page.

Also, clicking the version at the upper right on the revised page allows you to jump to the next revised page.