

# ICF-C630

## SERVICE MANUAL

*Australian Model*

Ver 1.0 2003. 06



### SPECIFICATIONS

**Time display:**

12-hour system

**Frequency range:**

FM: 87.5 - 108 MHz

AM: 530 - 1710 kHz

**Speaker:**

Approx. 5.7 cm dia., 4 ohm

**Power output:**

120 mW (at 10% harmonic distortion)

**Power requirements:**

3 V DC, two R6 (size AA) batteries

**External power source:**

DC IN 4.5 V

**Dimensions:**

Approx. 94 × 104 × 82 mm (w/h/d)

incl. projecting parts and controls

**Mass:**

Approx. 313 g incl. batteries

**Accessories supplied:**

AC power adaptor (1)

Design and specifications are subject to change without notice.

**FM/AM CLOCK RADIO**

9-877-483-01  
2003F04-1  
© 2003. 06

**Sony Corporation**  
Personal Audio Company  
Published by Sony Engineering Corporation

**SONY®**

**Notes on Chip Component Replacement**

- Never reuse a disconnected chip component.
- Notice that the minus side of a tantalum capacitor may be damaged by heat.

**TABLE OF CONTENTS**

**1. SERVICING NOTES**  
 1-1. Dial Pointer Setting ..... 3  
 1-2. Installing the Tuner Board ..... 3

**2. GENERAL**  
 Choosing Power Sources ..... 4  
 Setting the brightness of the backlight ..... 4  
 Setting the Clock ..... 4  
 Improving the reception ..... 4  
 Operating the Radio ..... 4  
 Setting the Alarm ..... 4  
 Setting the Sleep Timer ..... 4  
 Using the NAP Timer (Count Down Timer) ..... 4

**3. DISASSEMBLY**  
 3-1. Cover Assy ..... 5  
 3-2. Tuner Board ..... 6  
 3-3. Cabinet (Upper) Assy ..... 6  
 3-4. Microcomputer Board, Key (Left) Board,  
 Key (Right) Board ..... 7

**4. ELECTRICAL ADJUSTMENTS** ..... 8

**5. DIAGRAMS**  
 5-1. IC Block Diagram ..... 10  
 5-2. Block Diagram ..... 11  
 5-3. Printed Wiring Board –Tuner Section– ..... 12  
 5-4. Printed Wiring Boards –Micon Section– ..... 13  
 5-5. Schematic Diagram ..... 14  
 5-6. IC Pin Description ..... 15

**6. EXPLODED VIEWS**  
 6-1. Cabinet (Lower) Section ..... 16  
 6-2. Cover Assy Section ..... 17


**7. ELECTRICAL PARTS LIST** ..... 18

**SAFETY-RELATED COMPONENT WARNING!!**


COMPONENTS IDENTIFIED BY MARK  $\triangle$  OR DOTTED LINE WITH MARK  $\triangle$  ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

## SECTION 1 SERVICING NOTES


### 1-1. DIAL POINTER SETTING



### 1-2. INSTALLING THE TUNER BOARD




This section is extracted from instruction manual.



There is a tactile dot beside VOL to show the direction to turn up the volume.  
Un point tactile, situé à côté de la molette de volume, indique le sens dans lequel il faut tourner pour augmenter le volume.  
Neben dem Lautstärkereglerr befindet sich ein fühlbarer Punkt. Dieser gibt die Richtung an, in der man die Lautstärke erhöht.

**A**


Bottom  
Partie inférieure de l'appareil  
Unterseite



Insert the ⊖ side of the battery first.  
Insérez d'abord le côté ⊖ de la pile.  
Zuerst die ⊖ Seite der Batterie einlegen.

**B**


Rear  
Arrière de l'appareil  
Rückseite



To DC IN 4.5 V jack  
vers la prise DC IN 4.5 V  
an Buchse DC IN 4.5 V

To a wall outlet  
à une prise murale  
an Wandsteckdose

**C**



FM wire antenna  
Antenne fil FM  
UKW-Drahtantenne

**Choosing Power Sources (See Fig. A)**

**Installing the Batteries**

Press the tab of the battery compartment lid inward and pull upward to open the lid.  
Install two R6 (size AA) batteries (not supplied) with the correct polarity and close the lid.  
"AM 12:00" or "0:00" flashes in the display when you install batteries for the first time. To stop the display from flashing, set the clock. (See "Setting the Clock")

**Note**  
When operating the unit on batteries, remove the AC power adaptor from the DC IN jack. The unit cannot be operated on batteries when the AC power adaptor is connected to the DC IN jack.

Battery Life (Approx. hours)	(JEITA*)	
When using	FM	AM
Sony alkaline LR6 (size AA)	68	71
Sony R6 (size AA)	27	30

\* Measured by JEITA (Japan Electronics and Information Technology Industries Association) standards. The actual battery life may vary depending on the circumstance of the unit.

**When to replace the batteries**  
When the batteries become weak, the sound becomes weak and distorted. "00" flashes on the display. When the batteries are completely exhausted, "00" appears on the display and the power is turned off.

**Note on replacing the batteries**  
Do not take more than 3 minutes to replace the batteries, otherwise the clock and standby settings will be deleted from the memory. Should that happen, reset the functions again.  
After the batteries are replaced, press RADIO ON/OFF to turn off "00".

- Notes on Batteries**
- Do not charge dry batteries.
  - Do not carry dry batteries together with coins or other metallic objects. It can generate heat if the positive and negative terminals of the batteries accidentally come into contact with metallic objects.
  - Do not use different types of batteries at the same time.
  - When you replace the batteries, replace all with new ones.

**Using on House Current (See Fig. B)**

Connect the Sony AC power adaptor to the DC IN 4.5 V jack firmly, and plug it into a wall outlet. The power source will automatically switch to the external power source even if batteries are installed.

**Notes on the AC power adaptor**  
When operating the unit with an external power source, do not remove the batteries. These batteries serve to backup the clock and standby settings. Since batteries discharge in this case as well, we recommend changing them about once a year.

When you connect/disconnect the external power source plug, "00" may appear in the display. If this occurs, turn on the radio to make "00" disappear.

When operating the unit with the internal batteries, remove the AC power adaptor from the wall outlet and the DC IN 4.5 V jack. Make sure that the plug of the external power source is disconnected before operating the unit.

Use the recommended Sony AC power adaptor only. The polarity of the plugs of other manufacturers may be different. Failure to use the recommended AC power adaptor may cause the unit to malfunction.




You can listen to buzzer and two kinds of melodies by pressing BACKLIGHT/SNOOZE/SLEEP OFF while "AM 12:00" or "0:00" is flashing (Demo function). To stop buzzer or melodies, press RADIO ON/OFF. To listen to buzzer or melodies again, press BACKLIGHT/SNOOZE/SLEEP OFF. To deactivate Demo function, set the clock. (See "Setting the Clock.")

**Setting the brightness of the backlight**

**Note**  
The brightness of the backlight is fixed when using the unit on batteries.

**When using batteries:**  
Press BACKLIGHT/SNOOZE/SLEEP OFF. The backlight will light for 5 seconds. If any buttons are pressed while the backlight is on, the backlight will turn off 5 seconds after pressing the button.

**When using on House current:**  
The initial setting for the brightness of the backlight is High. Press BACKLIGHT/SNOOZE/SLEEP OFF for 2 seconds. Each press changes the brightness of the backlight as follows.



**Setting the Clock**

The display will flash "AM 12:00" or "0:00" when the batteries are installed or the AC power adaptor is plugged in for the first time.

- Press and hold down CLOCK/D.S.T. for a few seconds.  
You will hear a beep and the hour will start to flash in the display.
- Press TIME SET + or - until the correct hour appears in the display.
- Press CLOCK/D.S.T. once.  
You will hear a beep and the minutes will start to flash in the display.
- Repeat steps 2 and 3 to set the minutes.  
After setting the minutes, press CLOCK/D.S.T. You will hear two beeps and the clock will start counting from zero second.

- To set the current time rapidly, hold down TIME SET + or -.
- To adjust the time exactly to the second, press CLOCK/D.S.T. simultaneously with the time signal.

**To change the display to the daylight saving time (summer time) indication**  
Press CLOCK/D.S.T. "※" is displayed and the time indication changes to summer time.  
To deactivate the summer time function, press CLOCK/D.S.T. again.

**Improving the reception**

FM: Extend the FM wire antenna fully to improve the reception (see Fig. C).  
AM: Rotate the unit horizontally for optimum reception. A ferrite bar antenna is built into the unit (see Fig. D).

Do not operate the unit over a steel desk or metal surface, as this may lead to interference of reception.

**Operating the Radio**

- Press RADIO ON/OFF to turn on the radio.
  - Press BAND to select the band.
  - Use TUNE to tune in to the desired station.
  - Adjust volume using VOL.
- To turn off the radio, press RADIO ON/OFF.

**Setting the Alarm**

Before setting the time for the radio, buzzer and melody alarms, make sure you have set the current time (see "Setting the Clock"). For the radio alarm, make sure you have tuned in to a radio station beforehand (see "Operating the Radio").

**To Set the Alarm Time**

**To Set the Radio Alarm**

- Press and hold down ALARM A for a few seconds.  
You will hear a beep. The ALARM A indication and the hour will start to flash in the display.
- Press TIME SET + or - until the correct hour appears in the display.
- Press ALARM B once.  
You will hear a beep and the minutes will start to flash in the display.
- Repeat steps 2 and 3 to set the minutes.  
After setting the minutes, press ALARM A. You will hear two beeps which confirm the setting.

**To Set the Buzzer or Melody Alarm**

- Press and hold down ALARM B for a few seconds.  
You will hear a beep. The ALARM B indication and the hour will start to flash in the display.
- Press TIME SET + or - until the correct hour appears in the display.
- Press ALARM B once.  
You will hear a beep and the minutes will start to flash in the display.
- Repeat steps 2 and 3 to set the minutes.  
After setting the alarm, press ALARM B. You will hear two beeps which confirm the setting.  
You can choose alarm sound from one of the following:  
1. Buzzer  
2. "Morning" from "Peer Gynt." by Grieg - suite No. 1, Op. 46  
3. "For Eliza" by Beethoven

**Note**  
To adjust the radio alarm volume, turn VOL. The volume for buzzer and melody is fixed.

**Alarm On-**

**To activate the alarm**

**For the radio alarm:**  
Press ALARM A. The ALARM A indication appears and the alarm time is shown.

**For the buzzer or melody alarm:**  
Press ALARM B. The ALARM B indication appears and the alarm time is shown.

The alarm will come on at the preset time and will automatically tune itself off after about 30 minutes.

- Notes**
- When the alarm comes on at the preset time, ALARM A or ALARM B indication flashes.
  - If you do not set the alarm time and ALARM A or ALARM B indication is lit, the alarm will sound at PM 12:30.
  - For the buzzer alarm, the beeping of the alarm becomes more rapid after every 15 to 20 seconds in 3 progressive stages.

**Alarm Off-**

**To Stop the Alarm**

Press RADIO ON/OFF to turn off the alarm. The alarm will come on again at the same time the next day.


**To Deactivate the Alarm**

For the radio alarm, press ALARM A to turn off ALARM A indication.  
For the buzzer or melody alarm, press ALARM B to turn off ALARM B indication.

- Notes**
- The alarm does not function unless you set the clock and activate the alarm function.
  - If both Radio alarm and Buzzer or Melody alarm are set for the same time, the radio alarm will take priority.

**To Doze for a Few More Minutes**

Press BACKLIGHT/SNOOZE/SLEEP OFF. The radio, buzzer or melody turns off but will automatically come on again after about 10 minutes. Every time you press BACKLIGHT/SNOOZE/SLEEP OFF, the snooze time changes as follows:



The display shows the snooze time for a few seconds and returns to show the current time. When you press BACKLIGHT/SNOOZE/SLEEP OFF after the current time appeared, the snooze time starts from 10 minutes again.


- The maximum length of the snooze time is 60 minutes.
- While the snooze function is operating, the alarm indication flashes.

**Setting the Sleep Timer**

By setting the sleep timer, you can fall asleep to the radio sound. The radio will turn off automatically after a set time. The sleep timer can be set to turn off after 15, 30, 60 or 90 minutes.

- Tune in to the desired station. (See "Operating the Radio.")
- Press SLEEP.  
The sleep timer setting of "90" appears and "SLEEP" lights up in the display.
- Press SLEEP repeatedly to select the desired sleep timer setting while "SLEEP" is lit.

Each press changes the display as follows:



You will hear two beeps when the display turns from "OFF" to "90".  
The radio will play for the time you set, then shut off.

**To Change the Sleep Timer Setting**

Press SLEEP repeatedly to select the desired sleep timer setting.

**To Deactivate the Sleep Timer**

Press BACKLIGHT/SNOOZE/SLEEP OFF to turn off the radio before the set time has elapsed, or press SLEEP to set the Sleep timer to "OFF" in step 3. "SLEEP" disappears from the display.

**To Use Both Sleep Timer and Alarm**


You can fall asleep to the radio and also be awakened by the radio, buzzer or melody alarm at the preset time.

- Set the alarm. (See "Setting the Alarm.")
- Set the sleep timer. (See "Setting the Sleep Timer.")

**Using the NAP Timer (Count Down Timer)**

The NAP timer sounds the buzzer after a preset time duration. Press NAP repeatedly until the desired minutes is displayed.

Each press changes the display as follows:



You will hear two beeps when the display turns from "OFF" to "10".

"NAP" appears and the NAP time are displayed for a few seconds.  
NAP timer starts counting down the NAP time. When selected NAP time has passed, the buzzer comes on, and "NAP" flashes in the display. The buzzer is turned off automatically after about 60 minutes.

**To Stop NAP Timer**


Press NAP or RADIO ON/OFF to turn off the buzzer.

**To Deactivate NAP Timer**

Press NAP. "NAP" go off.


## SECTION 3 DISASSEMBLY

**Note :** This set can be disassemble according to the following sequence.




**Note :** Follow the disassembly procedure in the numerical order given.


### 3-1. COVER ASSY




3-2. TUNER BOARD



3-3. CABINET (UPPER) ASSY




3-4. MICROCOMPUTER BOARD, KEY (LEFT) BOARD, KEY (RIGHT) BOARD



## SECTION 4 ELECTRICAL ADJUSTMENTS

**FM SECTION**    **0 dB = 1  $\mu$ V**

**Setting:**  
 RADIO ON/OFF switch: ON  
 BAND switch: FM  
 VOL control: MIN




FM FREQUENCY COVERAGE ADJUSTMENT	
Adjust for a maximum reading on level meter.	
L3	CT3
86.5 MHz	109.5 MHz

FM TRACKING ADJUSTMENT	
Adjust for a maximum reading on level meter.	
L2	CT2
86.5 MHz	109.5 MHz

AM IF ADJUSTMENT	
Adjust for a maximum reading on level meter.	
T1	
455 kHz	

**AM SECTION**

**Setting:**  
 RADIO ON/OFF switch: ON  
 BAND switch: AM  
 VOL control: MIN




AM FREQUENCY COVERAGE ADJUSTMENT	
Adjust for a maximum reading on level meter.	
L4	CT4
520 kHz	1,750 kHz

AM TRACKING ADJUSTMENT	
Adjust for a maximum reading on level meter.	
L1	CT1
600 kHz	1,400 kHz

**Adjustment Location:** See page 9.


• **Connecting Level Meter (FM and AM)**



Repeat the procedures in each adjustment several times, and the frequency coverage and tracking adjustments should be finally done by the trimmer capacitors.



Adjustment Location:



**THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS.**

**Common Note on Schematic Diagram:**

- All capacitors are in  $\mu\text{F}$  unless otherwise noted. pF:  $\mu\text{pF}$   
50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in  $\Omega$  and  $1/4\text{W}$  or less unless otherwise specified.
- $\triangle$  : internal component.
- : panel designation.

**Note:** The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.  
Replace only with part number specified.


- : B+ Line.
- : adjustment for repair.
- Power voltage is dc 4.5V and fed with regulated dc power supply from external power voltage jack.
- Voltage is dc with respect to ground under no-signal (detuned) condition.
- no mark : FM
- (  ) : AM
- Voltages are taken with a VOM (Input impedance  $10\text{M}\Omega$ ).  
Voltage variations may be noted due to normal production tolerances.
- Signal path.
- $\Rightarrow$  : FM
- $\blacktriangleright$  : AM

**Common Note on Printed Wiring Boards:**


- $\circ$  — : parts extracted from the component side.
- — : parts extracted from the conductor side.
- $\triangle$  : internal component.
- : Pattern from the side which enables seeing.

5-1. IC BLOCK DIAGRAM


IC1 CXA1019S



5-2. BLOCK DIAGRAM



5-3. PRINTED WIRING BOARD — TUNER SECTION — • Refer to page 10 for Common Note on Printed Wiring Boards.




• Semiconductor Location


Ref. No.	Location
D1	C-10
D5	C-10
IC1	F-7
IC2	D-10
Q1	H-10
Q2	D-7
Q3	D-9
Q4	E-10
Q5	D-9
Q6	B-8

11  
1-687-526-  
(11)

5-4. PRINTED WIRING BOARDS — MICON SECTION — • Refer to page 10 for Common Note on Printed Wiring Boards.



5-5. SCHEMATIC DIAGRAM • Refer to page 10 for Common Note on Schematic Diagram and IC Block Diagram.



**5-6. IC PIN DESCRIPTION****• IC105  $\mu$ PD789488GC-A23-8BT (SYSTEM CONTROL, LCD DRIVER)**


Pin No.	Pin Name	I/O	Pin Description
1	CAPH	—	Connect to capacitor (H)
2	CAPL	—	Connect to capacitor (L)
3 to 5	VLC2 to VLC0	O	LCD drive bias voltage output 2 to 0
6 to 9	COM0 to COM3	O	LCD drive common data output 0 to 3
10 to 34	S0 to S24	O	LCD drive segment data output 0 to 24
35 to 37	P85 to P87	O	Not used. (Open)
38	AVDD	—	Power supply pin (+3.3 V)
39	INIT	I	Destination setting pin (Fixed at L)
40	P66	I	Destination setting pin (Fixed at L)
41 to 46	P65 to P60	I	Not used. (Fixed at L)
47	AVSS	—	Ground
48	VDET1	I	Down voltage detection (+2.3 V)
49	VDET2	I	Down voltage detection (+2.1 V)
50	VDET3	I	Down voltage detection (+1.9 V)
51	BUZZER	O	Buzzer output
52	P30	O	Not used. (Open)
53 to 55	P25 to P23	O	Key source output 2 to 0
56 to 58	KS2 to KS0	O	Not used. (Open)
59, 60	P11, P10	O	Not used. (Open)
61 to 64	KR3 to KR0	I	Key return input 3 to 0
65	BAND	O	Band select output (L: FM, H: AM)
66	MUTING	O	Mute output
67	POWER	O	Power output
68	AC/DC	I	AC/DC mode input (L: AC, H: DC)
69	IC0	—	Not used. (Fixed at L)
70	XT1	I	Sub clock input (32.768 kHz)
71	XT2	O	Sub clock output (32.768 kHz)
72	VDD	—	Power supply pin (+2.5 V)
73	VSS	—	Ground
74	X1	I	Main clock input (4.19 MHz)
75	X2	O	Main clock output (4.19 MHz)
76	RESET	I	Reset input
77	P53	O	Not used. (Open)
78 to 80	LIGHT1 to LIGHT3	O	LCD backlight dimmer control output 1 to 3

## SECTION 6 EXPLODED VIEWS

**NOTE:**

- The mechanical parts with no reference number in the exploded views are not supplied.
- Items marked “\*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- Accessories are given in the last of this parts list.


### 6-1. CABINET (LOWER) SECTION



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
* 1	A-3347-871-A	TUNER BOARD, COMPLETE		8	3-248-598-01	CABINET (LOWER)	
	3-248-609-01	HOLDER (ANT)		9	3-246-344-11	FOOT, RUBBER	
	3-248-606-01	KNOB (TUNE)		10	3-919-268-11	KNOB (VOL)	
	3-248-610-01	TERMINAL (+), BATTERY		11	3-248-607-01	POINTER	
	3-248-611-01	TERMINAL (-), BATTERY		L1	1-456-344-11	COIL, FERRITE-ROD ANTENNA (AM)	
	3-248-600-01	LID, BATTERY CASE		#1	7-685-151-14	SCREW +P 3X20 TYPE2 NON-SLIT	
	3-248-612-01	TERMINAL (+-), BATTERY		#2	7-685-134-19	SCREW +P 2.6X8 TYPE2 NON-SLIT	



6-2. COVER ASSY SECTION



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
* 51	A-3347-982-A	MICROCOMPUTER BOARD, COMPLETE		56	3-248-604-01	BUTTON (L)	
52	3-254-545-01	SHEET (LCD)		57	3-248-605-01	BUTTON (R)	
53	3-248-608-01	HOLDER (LCD)		58	X-3384-134-1	COVER ASSY	
54	3-248-597-01	CABINET (UPPER)		LCD101	1-805-186-11	DISPLAY PANEL, LIQUID CRYSTAL	
* 55	A-3347-866-A	KEY (LEFT) BOARD, COMPLETE		#2	7-685-134-19	SCREW +P 2.6X8 TYPE2 NON-SLIT	

**ICF-C630**

**KEY (LEFT)**

**KEY (RIGHT)**

**SECTION 7**

**MICROCOMPUTER**

**ELECTRICAL PARTS LIST**

**NOTE:**

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- RESISTORS  
All resistors are in ohms.  
METAL: Metal-film resistor.  
METAL OXIDE: Metal oxide-film resistor.  
F: nonflammable

- Items marked “\*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS  
In each case, u : μ, for example:  
uA.. : μA.. uPA.. : μPA..  
uPB.. : μPB.. uPC.. : μPC.. uPD.. : μPD..
- CAPACITORS  
uF : μF
- COILS  
uH : μH

The components identified by mark  $\Delta$  or dotted line with mark  $\Delta$  are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
*	A-3347-866-A	KEY (LEFT) BOARD, COMPLETE *****		C113	1-164-315-11	CERAMIC CHIP 470PF	5% 50V
		< SWITCH >		C114	1-162-970-11	CERAMIC CHIP 0.01uF	10% 25V
S101	1-786-050-21	SWITCH, KEYBOARD (TIME SET -)		C115	1-162-970-11	CERAMIC CHIP 0.01uF	10% 25V
S102	1-786-050-21	SWITCH, KEYBOARD (TIME SET +)		C116	1-162-970-11	CERAMIC CHIP 0.01uF	10% 25V
S103	1-786-050-21	SWITCH, KEYBOARD (CLOCK/ D.S.T. SUMMER T.)		C117	1-162-970-11	CERAMIC CHIP 0.01uF	10% 25V
*****				C118	1-162-919-11	CERAMIC CHIP 22PF	5% 50V
		KEY (RIGHT) BOARD *****		C119	1-162-919-11	CERAMIC CHIP 22PF	5% 50V
		< JUMPER RESISTOR >		C120	1-125-701-11	DOUBLE LAYERS 0.047F	5.5V
JC117	1-216-864-11	METAL CHIP 0 5% 1/10W		C121	1-162-970-11	CERAMIC CHIP 0.01uF	10% 25V
		< RESISTOR >		C122	1-135-834-11	CERAMIC CHIP 2.2uF	6.3V
R162	1-216-845-11	METAL CHIP 100K 5% 1/10W		C123	1-162-923-11	CERAMIC CHIP 47PF	5% 50V
R163	1-216-845-11	METAL CHIP 100K 5% 1/10W		C124	1-162-923-11	CERAMIC CHIP 47PF	5% 50V
R164	1-216-845-11	METAL CHIP 100K 5% 1/10W		C125	1-162-970-11	CERAMIC CHIP 0.01uF	10% 25V
		< SWITCH >		C126	1-162-970-11	CERAMIC CHIP 0.01uF	10% 25V
S108	1-786-050-21	SWITCH, KEYBOARD (BAND)		C127	1-115-156-11	CERAMIC CHIP 1uF	10V
S109	1-786-050-21	SWITCH, KEYBOARD (SLEEP)		C128	1-115-156-11	CERAMIC CHIP 1uF	10V
S110	1-786-050-21	SWITCH, KEYBOARD (NAP ON/OFF)		C129	1-115-156-11	CERAMIC CHIP 1uF	10V
*****				C130	1-115-156-11	CERAMIC CHIP 1uF	10V
*	A-3347-982-A	MICROCOMPUTER BOARD, COMPLETE *****		C131	1-162-970-11	CERAMIC CHIP 0.01uF	10% 25V
	3-248-608-01	HOLDER (LCD)		C132	1-162-970-11	CERAMIC CHIP 0.01uF	10% 25V
	3-254-545-01	SHEET (LCD)		C133	1-162-927-11	CERAMIC CHIP 100PF	5% 50V
		< CAPACITOR >		C134	1-164-315-11	CERAMIC CHIP 470PF	5% 50V
C101	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V		< DIODE >			
C102	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V		D101	6-500-203-01	LED TLGE262(NP) (LCD BACK LIGHT)	
C103	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V		D102	6-500-203-01	LED TLGE262(NP) (LCD BACK LIGHT)	
C104	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V		D103	6-500-203-01	LED TLGE262(NP) (LCD BACK LIGHT)	
C105	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V		D104	8-719-071-34	DIODE RB521S-30-TE61	
C106	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V		D105	8-719-071-34	DIODE RB521S-30-TE61	
C107	1-164-315-11	CERAMIC CHIP 470PF 5% 50V		D106	8-719-069-29	DIODE RB520S-30-TE61	
C108	1-164-315-11	CERAMIC CHIP 470PF 5% 50V		D107	8-719-988-61	DIODE 1SS355TE-17	
C109	1-164-315-11	CERAMIC CHIP 470PF 5% 50V		D108	8-719-988-61	DIODE 1SS355TE-17	
C110	1-164-315-11	CERAMIC CHIP 470PF 5% 50V		D109	8-719-988-61	DIODE 1SS355TE-17	
C111	1-164-315-11	CERAMIC CHIP 470PF 5% 50V		< IC >			
C112	1-164-315-11	CERAMIC CHIP 470PF 5% 50V		IC101	8-759-565-57	IC XC62FP2202PR	
		< JUMPER RESISTOR >		IC102	6-703-784-01	IC XC61CN2302NR	
JC101	1-216-864-11	METAL CHIP 0 5% 1/10W		IC103	6-702-084-01	IC XC61CN2102NR	
				IC104	6-702-083-01	IC XC61CN1902NR	
				IC105	6-803-068-01	IC uPD789488GC-A23-8BT	
				IC106	6-702-590-01	IC XC61CN1702NR	

**MICROCOMPUTER**

**TUNER**

Ref. No.	Part No.	Description	Remark
JC102	1-216-864-11	METAL CHIP	0 5% 1/10W
JC103	1-216-864-11	METAL CHIP	0 5% 1/10W
JC104	1-216-864-11	METAL CHIP	0 5% 1/10W
JC105	1-216-864-11	METAL CHIP	0 5% 1/10W
JC106	1-216-864-11	METAL CHIP	0 5% 1/10W
JC107	1-216-864-11	METAL CHIP	0 5% 1/10W
JC108	1-216-864-11	METAL CHIP	0 5% 1/10W
JC109	1-216-864-11	METAL CHIP	0 5% 1/10W
JC110	1-216-864-11	METAL CHIP	0 5% 1/10W
JC111	1-216-864-11	METAL CHIP	0 5% 1/10W
JC113	1-216-864-11	METAL CHIP	0 5% 1/10W
JC114	1-216-864-11	METAL CHIP	0 5% 1/10W
< LIQUID CRYSTAL DISPLAY >			
LCD101	1-805-186-11	DISPLAY PANEL, LIQUID CRYSTAL	
< RESISTOR >			
R130	1-216-857-11	METAL CHIP	1M 5% 1/10W
R131	1-216-857-11	METAL CHIP	1M 5% 1/10W
R132	1-216-857-11	METAL CHIP	1M 5% 1/10W
R133	1-216-833-11	METAL CHIP	10K 5% 1/10W
R134	1-216-833-11	METAL CHIP	10K 5% 1/10W
R135	1-216-833-11	METAL CHIP	10K 5% 1/10W
R136	1-216-829-11	METAL CHIP	4.7K 5% 1/10W
R137	1-216-829-11	METAL CHIP	4.7K 5% 1/10W
R138	1-216-829-11	METAL CHIP	4.7K 5% 1/10W
R139	1-216-829-11	METAL CHIP	4.7K 5% 1/10W
R140	1-216-829-11	METAL CHIP	4.7K 5% 1/10W
R141	1-216-829-11	METAL CHIP	4.7K 5% 1/10W
R142	1-216-829-11	METAL CHIP	4.7K 5% 1/10W
R143	1-216-829-11	METAL CHIP	4.7K 5% 1/10W
R144	1-216-829-11	METAL CHIP	4.7K 5% 1/10W
R145	1-216-829-11	METAL CHIP	4.7K 5% 1/10W
R146	1-216-829-11	METAL CHIP	4.7K 5% 1/10W
R147	1-216-849-11	METAL CHIP	220K 5% 1/10W
R148	1-216-797-11	METAL CHIP	10 5% 1/10W
R149	1-216-833-11	METAL CHIP	10K 5% 1/10W
R151	1-216-789-11	METAL CHIP	2.2 5% 1/10W
R153	1-216-809-11	METAL CHIP	100 5% 1/10W
R155	1-216-797-11	METAL CHIP	10 5% 1/10W
R156	1-216-797-11	METAL CHIP	10 5% 1/10W
R157	1-216-857-11	METAL CHIP	1M 5% 1/10W
R158	1-216-789-11	METAL CHIP	2.2 5% 1/10W
R159	1-216-789-11	METAL CHIP	2.2 5% 1/10W
R160	1-216-789-11	METAL CHIP	2.2 5% 1/10W
R161	1-216-849-11	METAL CHIP	220K 5% 1/10W
< SWITCH >			
S104	1-572-697-11	SWITCH, TACTILE (RADIO ON/OFF)	
S105	1-786-050-21	SWITCH, KEYBOARD (ALARM B MELODY)	
S106	1-572-697-11	SWITCH, TACTILE (BACKLIGHT• SNOOZE/SLEEP OFF)	
S107	1-786-050-21	SWITCH, KEYBOARD (ALARM A RADIO)	
< VIBRATOR >			
X101	1-567-098-41	VIBRATOR, CRYSTAL (32.768kHz)	
X102	1-579-901-11	VIBRATOR, CERAMIC (4.19MHz)	

\*\*\*\*\*

Ref. No.	Part No.	Description	Remark
*	A-3347-871-A	TUNER BOARD, COMPLETE	*****
	3-248-609-01	HOLDER (ANT)	
	7-685-134-19	SCREW +P 2.6X8 TYPE2 NON-SLIT	
< BPF >			
BPF1	1-236-022-11	FILTER, BAND PASS	
< CAPACITOR >			
C1	1-162-910-11	CERAMIC CHIP	5PF 0.25PF 50V
C2	1-162-919-11	CERAMIC CHIP	22PF 5% 50V
C4	1-162-997-11	CERAMIC CHIP	10PF 0.5PF 50V
C5	1-162-913-11	CERAMIC CHIP	8PF 0.5PF 50V
C6	1-162-996-11	CERAMIC CHIP	7PF 0.5PF 50V
C7	1-164-315-11	CERAMIC CHIP	470PF 5% 50V
C8	1-126-157-11	ELECT	10uF 20% 16V
C9	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
C10	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
C11	1-126-160-11	ELECT	1uF 20% 50V
C12	1-164-227-11	CERAMIC CHIP	0.022uF 10% 25V
C13	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
C14	1-124-259-11	ELECT	4.7uF 20% 16V
C15	1-126-157-11	ELECT	10uF 20% 16V
C16	1-164-227-11	CERAMIC CHIP	0.022uF 10% 25V
C17	1-165-176-11	CERAMIC CHIP	0.047uF 10% 16V
C18	1-126-157-11	ELECT	10uF 20% 16V
C19	1-125-837-11	CERAMIC CHIP	1uF 10% 6.3V
C20	1-126-935-11	ELECT	470uF 20% 10V
C21	1-125-837-11	CERAMIC CHIP	1uF 10% 6.3V
C22	1-126-934-11	ELECT	220uF 20% 10V
C23	1-162-964-11	CERAMIC CHIP	0.001uF 10% 50V
C24	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
C27	1-162-939-11	CERAMIC CHIP	8PF 0.5PF 50V
C29	1-162-927-11	CERAMIC CHIP	100PF 5% 50V
C30	1-162-927-11	CERAMIC CHIP	100PF 5% 50V
C33	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
C34	1-162-964-11	CERAMIC CHIP	0.001uF 10% 50V
C35	1-162-964-11	CERAMIC CHIP	0.001uF 10% 50V
C36	1-162-927-11	CERAMIC CHIP	100PF 5% 50V
< FILTER >			
CF1	1-781-861-71	FILTER, CERAMIC (COMBINATION)	
CF2	1-781-861-71	FILTER, CERAMIC (COMBINATION)	
CF3	1-781-790-11	FILTER, AM CERAMIC	
< CONNECTOR >			
* CN1	1-568-273-11	SOCKET, CONNECTOR 7P	
* CN2	1-568-268-11	SOCKET, CONNECTOR 2P	
< VARIABLE CAPACITOR >			
CT1-4	1-141-681-11	CAP, VAR	
CV1	1-141-681-11	CAP, VAR (TUNE)	
< DIODE >			
D1	8-719-069-29	DIODE RB520S-30-TE61	
D5	8-719-069-29	DIODE RB520S-30-TE61	

# ICF-C630

## TUNER

Ref. No.	Part No.	Description	Remark
		< IC >	
IC1	8-752-037-02	IC CXA1019S	
IC2	6-704-101-01	IC XC6201P382PR	
		< JACK >	
J1	1-580-681-21	JACK, DC (POLARITY UNIFIED TYPE) (DC IN 4.5V)	
		< JUMPER RESISTOR >	
JC2	1-216-295-11	SHORT CHIP 0	
		< COIL >	
L1	1-456-344-11	COIL, FERRITE-ROD ANTENNA (AM)	
L2	1-424-793-11	COIL, AIR-CORE	
L3	1-428-229-11	COIL, AIR-CORE	
L4	1-456-345-11	COIL, AM OSC	
L5	1-410-294-31	INDUCTOR 38uH	
		< TRANSISTOR >	
Q1	8-729-026-52	TRANSISTOR 2SA1576A-T106-R	
Q2	8-729-029-14	TRANSISTOR DTC144EUA-T106	
Q3	6-550-044-01	TRANSISTOR 2SB1689-T106	
Q4	8-729-029-14	TRANSISTOR DTC144EUA-T106	
Q5	8-729-011-92	TRANSISTOR 2SC2001TP-K1K2	
Q6	8-729-029-03	TRANSISTOR DTC123EUA-T106	
		< RESISTOR >	
R1	1-216-825-11	METAL CHIP 2.2K 5% 1/10W	
R2	1-216-833-11	METAL CHIP 10K 5% 1/10W	
R3	1-216-821-11	METAL CHIP 1K 5% 1/10W	
R4	1-216-805-11	METAL CHIP 47 5% 1/10W	
R5	1-216-821-11	METAL CHIP 1K 5% 1/10W	
R6	1-216-825-11	METAL CHIP 2.2K 5% 1/10W	
R7	1-216-817-11	METAL CHIP 470 5% 1/10W	
R8	1-216-845-11	METAL CHIP 100K 5% 1/10W	
R9	1-216-825-11	METAL CHIP 2.2K 5% 1/10W	
R10	1-216-817-11	METAL CHIP 470 5% 1/10W	
R11	1-216-825-11	METAL CHIP 2.2K 5% 1/10W	
R12	1-216-797-11	METAL CHIP 10 5% 1/10W	
R14	1-216-833-11	METAL CHIP 10K 5% 1/10W	
R15	1-216-841-11	METAL CHIP 47K 5% 1/10W	
R17	1-216-829-11	METAL CHIP 4.7K 5% 1/10W	
		< VARIABLE RESISTOR >	
RV1	1-228-790-00	RES, VAR, CARBON 50K (VOL)	
		< TRANSFORMER >	
T1	1-439-678-11	TRANSFORMER, IF	
		< WIRE ANTENNA >	
W1	1-754-135-11	ANTENNA (WIRE) (FM)	

\*\*\*\*\*

Ref. No.	Part No.	Description	Remark
		ACCESSORIES *****	
△	1-477-830-11	ADAPTOR, AC (AC-E45TR1)	
	3-249-145-11	MANUAL, INSTRUCTION (ENGLISH,FRENCH, GERMAN,SPANISH,DUTCH)	

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

**MEMO**

