

**Service  
Service  
Service**

**VR330/02/07/39  
VR530/39  
VR630/02/07/16/39**

# Service Manual

**Survey of versions:**

/02	PAL B/G, VPS/PDC
/07	PAL I, Ireland
/16	PAL B/G, Spain
/39	SECAM L,L' & PAL B/G, I
/58	PAL/SECAM B/G, D/K

Safety regulations require that the set be restored to its original condition and that parts which are identical with those specified be used.




# **MAIN SECTION**

# **VIDEO CASSETTE RECORDER**

## **TABLE OF CONTENTS**

OPERATING CONTROLS AND FUNCTIONS.....	1-5-3
SIGNAL NAME ABBREVIATIONS.....	1-6-3
BLOCK DIAGRAMS.....	1-9-11
SCHEMATIC DIAGRAMS / CBA'S AND TEST POINTS.....	1-10-53
WIRING DIAGRAMS.....	1-12-3
SYSTEM CONTROL TIMING CHARTS.....	1-13-6
IC PIN FUNCTION DESCRIPTIONS.....	1-14-3
LEAD IDENTIFICATIONS.....	1-15-2
ELECTRICAL PARTSLIST.....	1-16-13
EXPLODED VIEWS.....	1-17-4
SET MECHANICAL PARTS LIST.....	1-18-2
DECK EXPLODED VIEWS.....	2-5-2
DECK PARTS LIST.....	2-6-2

## [ VR330/02, VR330/07, VR330/39 ]



### Buttons for VCR feature only


- VCR** To operate the VCR with the remote control.
- EJECT ▲** To eject the cassette.
- CLEAR** To delete last entry/Clear programmed recording (TIMER).
- RECORD/OTR ●** To record the TV channel selected at this moment or press repeatedly to start a One-Touch Recording.
- STILL** To stop the tape and slow a still picture.
- P+ P-** To select the programme number. During normal or slow motion playback, press to adjust the tracking.
- INDEX ▶** In combination with **◀▶** to search for previous or next recording on the cassette.
- SYSTEM** Doesn't work in these models. [ VR330/02, VR330/07 ]
  - To change the video (colour) system. [ VR330/39 ]
- SV/N+** To make a TIMER programming with SHOWVIEW.
- MENU** To call up main menu of VCR.
- ▲▶** To play a tape, select an item in the menu of VCR.
- ▼■** To stop the tape, select an item in the menu of VCR
- ▶▶** When tape playback is stopped, press to fast forward the tape at high speed. During playback, press to fast forward the tape while the picture stay on the screen. To store or confirm entry in the menu.
- ◀◀** When tape playback is stopped, press to rewind the tape at high speed. During playback, press to rewind the tape while the picture stay on the screen. To return the cursor in the menu.

### Buttons with TV feature

- TV** To call up additional TV functions.
- STANDBY/ON** To switch VCR or Philips TV on or off, interrupt menu function.
- STATUS/EXIT** To access or remove the VCR's on-screen status display. To exit on-screen menus. Or, to access or remove a status display or menu of Philips TV.
- 0..9** Press to select channels at VCR or Philips TV.
- MUTE** To mute the TV's sound. Press again to restore the volume.
- ▲▼** To adjust the TV's volume.

Press button VCR on the remote control before doing VCR related functions on the remote. By pressing button TV it is possible to navigate some functions on PHILIPS TV sets.

## Front of the device



**STANDBY/ON** To switch off or on, interrupt a function.

**PROGRAMME+** **PROGRAMME-** To select the programme number. During normal or slow motion playback, press to adjust the tracking.

**RECORD** To record the TV channel selected at this moments.

**▶▶** When tape playback is stopped, press to fast forward the tape at high speed. During playback, press to fast forward the tape while the picture stay on the screen.

**◀◀** When tape playback is stoped, press to rewind the tape at hight speed. During playback, press to rewind the tape while the picture stay on the screen.


**▶▶** To play a tape.

**■/▲** To stop the tape and eject the cassette.

**STILL** To stop the tape and show a still picture.

**COUNTER RESET** To reset the counter.

## Back of the set




**TV** To connect the TV set(programme number ).

**AERIAL** To connect the aerial cable.

**RF OUT** To connect the TV set.

## [ VR530/39 ]



### Buttons for VCR feature only


- VCR** To operate the VCR with the remote control.
- EJECT ▲** To eject the cassette.
- CLEAR** To delete last entry/Clear programmed recording (TIMER).
- RECORD/OTR ●** To record the TV channel selected at this moment or press repeatedly to start a One-Touch Recording.
- STILL** To stop the tape and slow a still picture.
- P+ P-** To select the programme number. During normal or slow motion playback, press to adjust the tracking.
- INDEX ►** In combination with **◀◀ ▶▶**: to search for previous or next recording on the cassette.
- SLOW** To view the picture in slow motion.
- AUDIO** To change stereo sound and 2nd language.
- SYSTEM** To change the video (colour) system.
- MENU** To call up main menu of VCR.
- When tape playback is stopped, press to fast forward the tape at high speed. During playback, press to fast forward the tape while the picture stay on the screen. To store or confirm entry in the menu.
- ◀◀** When tape playback is stopped, press to rewind the tape at high speed. During playback, press to rewind the tape while the picture stay on the screen. To return the cursor in the menu.
- ▲►** To play a tape, select an item in the menu of VCR.
- ▼■** To stop the tape, select an item in the menu of VCR.

### Buttons with TV feature

- TV** To call up additional TV functions.
- STANDBY/ON ◊** To switch VCR or Philips TV on or off, interrupt menu function.
- STATUS/EXIT** To access or remove the VCR's on-screen status display. To exit on-screen menus. Or, to access or remove a status display or menu of Philips TV.
- 0..9** Press to select channels at VCR or Philips TV.
- MUTE** To eliminate the TV's sound. Press again to restore the volume.
- ▲▼** To adjust the TV's volume.

Press button VCR on the remote control before doing VCR related functions on the remote. By pressing button TV it is possible to navigate some functions on PHILIPS TV sets.

## Front of the device



**STANDBY/ON** To switch off or on, interrupt a function.

**PROGRAMME+** | **PROGRAMME-** To select the programme number. During normal or slow motion playback, press to adjust the tracking.

**RECORD** To record the TV channel selected at this moments.

► When tape playback is stopped, press to fast forward the tape at high speed. During playback, press to fast forward the tape while the picture stay on the screen.

◀ When tape playback is stoped, press to rewind the tape at hight speed. During playback, press to rewind the tape while the picture stay on the screen.


► To play a tape.

■▲ To stop the tape and eject the cassette.

**STILL** To stop the tape and show a still picture.

**COUNTER RESET** To reset the counter.

## Back of the set




**AV2(DECODER)** To connect a satellite receiver, decoder, video recorder,etc.

**AV1(TV)** To connect the TV set(programme number).

**AERIAL** To connect the aerial cable.

**RF OUT** To connect the TV set.

## [ VR630/02, VR630/07, VR630/16, VR630/39 ]



### Buttons for VCR feature only


- VCR** To operate the VCR with the remote control.
- EJECT ▲** To eject the cassette.
- CLEAR** To delete last entry/Clear programmed recording (TIMER).
- RECORD/OTR ●** To record the TV channel selected at this moment or press repeatedly to start a One-Touch Recording.
- STILL** To stop the tape and slow a still picture.
- P+ P-** To select the programme number. During normal or slow motion playback, press to adjust the tracking.
- INDEX ▶** In combination with **◀▶** to search for previous or next recording on the cassette.
- SLOW** To view the picture in slow motion.
- AUDIO** To change stereo sound and 2nd language.
- SYSTEM** Doesn't work in these models. [ VR630/02, VR630/07, VR630/16 ]  
To change the video (colour) system. [ VR630/39 ]
- TURBO TIMER** To programme a recording with the function TURBO TIMER.
- SV/V+** To make a TIMER programming with SHOWVIEW.
- MENU** To call up main menu of VCR.
- ▲▶** To play a tape, select an item in the menu of VCR.
- ▼■** To stop the tape, select an item in the menu of VCR
- ▶** When tape playback is stopped, press to fast forward the tape at high speed. During playback, press to fast forward the tape while the picture stay on the screen. To store or confirm entry in the menu.
- ◀** When tape playback is stopped, press to rewind the tape at high speed. During playback, press to rewind the tape while the picture stay on the screen. To return the cursor in the menu.

### Buttons with TV feature

- TV** To call up additional TV functions.
- STANDBY/ON** To switch VCR or Philips TV on or off, interrupt menu function.
- STATUS/EXIT** To access or remove the VCR's on-screen status display. To exit on-screen menus. Or, to access or remove a status display or menu of Philips TV.
- 0..9** Press to select channels at VCR or Philips TV.
- MUTE** To mute the TV's sound. Press again to restore the volume.
- ◀▲ ▶▼** To adjust the TV's volume.

Press button VCR on the remote control before doing VCR related functions on the remote. By pressing button TV it is possible to navigate some functions on PHILIPS TV sets.

## Front of the device



**STANDBY/ON** To switch off or on, interrupt a function.

**PROGRAMME+** **PROGRAMME-** To select the programme number. During normal or slow motion playback, press to adjust the tracking.

**RECORD** To record the TV channel selected at this moments.

**►** When tape playback is stopped, press to fast forward the tape at high speed. During playback, press to fast forward the tape while the picture stay on the screen.

**◀** When tape playback is stoped, press to rewind the tape at hight speed. During playback, press to rewind the tape while the picture stay on the screen.


**▶** To play a tape.

**■/▲** To stop the tape and eject the cassette.

**STILL** To stop the tape and show a still picture.

**COUNTER RESET** To reset the counter.

## Back of the set



**AUDIO OUTPUT L R** To connect a HIFI-set.

**AV2(DECODER)** To connect a satellite receiver, decoder, video recorder,etc.

**AV1(TV)** To connect the TV set.

**AERIAL** To connect the aerial cable.

**RF OUT** To connect the TV set.

**IR-SAT** To connect the SAT MOUSE. [VR830]

[ VR330/02,VR330/07,VR330/39,VR530/39,VR630/02,VR630/07,VR630/16,VR630/39 ]

Signal Name	Function
8POUT-1	SCART 1 8Pin Output Control Signal
8POUT-2	SCART 2 8Pin Output Control Signal
A-MODE	Hi-Fi Tape Detection Signal
A-MUTE-H	Audio Mute Control Signal (Mute = "H")
A-PB/REC	Normal Audio Play Back/Record Signal
AFC	Automatic Frequency Control Signal
AGC	IF AGC Control Signal
AL+5V	Always +5V with AC Plug Connected
AL+9V	Always +9V with AC Plug Connected
AL+15V/+12V	Always +15V/+12V with AC Plug Connected
AMPC	CTL AMP Connected Terminal
AMPVcc	AMPVcc
AMPVREF <sub>IN</sub>	V-Ref for CTL AMP
AMPVss	AMPVss (GND)
AUDIO-SW1	Audio Input/Output Switching Control Signal 1 (Mono)
AUDIO-SW2	Audio Input/Output Switching Control Signal 2 (Mono)
AVcc	A/D Converter Power Input/ Standard Voltage Input
C	C Terminal
C-CONT	Capstan Motor Control Signal
C-F/R	Capstan Motor FWD/REV Control Signal (FWD="L"/REV="H")
C-FG	Capstan Motor Rotation Detection Pulse
C-POWER-SW	Capstan Power Switching Pulse
C-ROTA	Color Phase Rotary Changeover Signal
C-SYNC	Composite Synchronized Pulse
CLKSEL	Clock Select (GND)
COLOR-IN	SECAM or MESECAM Chroma Video Input Signal at Super Inpose

Signal Name	Function
CTL (+)	Playback/Record Control Signal (+)
CTL (-)	Playback/Record Control Signal (-)
CTLAMPout	To Monitor for CTL AMP Output
D-CONT	Drum Motor Control Signal
D-FG	Drum Motor Rotation Detection Pulse
D-PG	Drum Motor Pulse Generator
D-REC-H	Delayed Record Signal
D-V SYNC	Dummy V-sync Output
DAVN-L	VPS/PDC Data Receive = "L"
DRV-CLK	LED Clock Driver IC Control Clock
DRV-DATA	LED Clock Driver IC Control Data
DRV-STB	LED Clock Driver IC Chip Select Signal
END-S	Tape End Position Detect Signal
FE-H GND	Ground for Full Erase Head
FF/REW-L	CTL Amp Gain Switching Signal (FF/REW="L")
FSC-IN [4.43MHz]	4.43MHz Clock Input
FTV-IN	Comparator Input of Video Signal for Follow TV
H-A-COMP	Head Amp Coparator Signal
H-A-SW	Video Head Amp Switching Pulse
Hi-Fi-A (L)	Hi-Fi Audio Head (L)
Hi-Fi-A (R)	Hi-Fi Audio Head (R)
Hi-Fi-COM	Hi-Fi Audio Head Common
HiFi-H-SW	HiFi Audio Head Switching Pulse
HLF	LPF Connected Terminal (Slicer)
I <sup>2</sup> C BUS- SCL	I <sup>2</sup> C BUS Control Clock
I <sup>2</sup> C BUS- SDA	I <sup>2</sup> C BUS Control Data
JK1-8P-OUT-1	SCART 1 8Pin Output Control Signal
JK1-8P-OUT-2	SCART 2 8Pin Output Control Signal
KEY-1	Key Scan Input Signal 1
KEY-2	Key Scan Input Signal 2
LD-SW	Deck Mode Position Detector Signal

<b>Signal Name</b>	<b>Function</b>
LINK-IN	Easy Link Data Input
LINK-OUT	Easy Link Data Output
LM-FWD/REV	Loading Motor Control Signal
MOD-A	Modulator Audio Output Signal
N-A-PB	Normal Audio Playback
N-A-REC	Normal Audio Recording
OSCIN	Clock Input for letter size
OSCOUT	Clock Output for letter size
OSDVcc	OSDVcc
P-DOWN-L	Power Voltage Down Detector Signal
P-ON+5V	+5V at Power-On Signal
P-ON+9V	+9V at Power-On Signal
P-ON+44V	+44V at Power-On Signal
P-ON-H	Power On Signal at High
PG-DELAY	Video Head Switching Pulse Signal Adjusted Voltage
POW-SAF	P-ON Power Detection Input Signal
REC-SAF	Recording Safety SW Detect (With Record tab="L"/With out Record tab="H")
REMOCON-IN	Remote Control Sensor
RESET	System Reset Signal (Reset="L")
RF-SW	Video Head Switching Pulse
RGB-THROUGH	SCART 2 RGB Through Control Signal
S-REEL	Supply Reel Rotation Signal
SC2-IN	Input Signal from Pin 8 of SCART2
SD-H	SD-H
SECAM-H	SECAM Mode at High
ST-S	Tape Start Position Detector Signal
T-REEL	Take Up Reel Rotation Signal
TIMER+5V	+5V at Timer
TRICK-H	Special Playback = "H" in SECAM Mode
TU-AUDIO	Tuner Audio Input Signal
TU-VIDEO	Tuner Video Input Signal
V-ENV	Video Envelope Comparator Signal
Vcc	Vcc

<b>Signal Name</b>	<b>Function</b>
VIDEO-IN	Video Signal Input
VIDEO-OUT	Video Signal Output
Vss	Vss(GND)
X-IN	Main Clock Input
X-OUT	Main Clock Input
XC-IN	Sub Clock
XC-OUT	Sub Clock

## Servo/System Control Block Diagram

Comparison Chart of Models & Marks

Model	Mark	Model	Mark
VR330/02	D	VR630/02	H
VR330/07	E	VR630/07	I
VR330/39	F	VR630/16	J
VR530/39	G	VR630/39	K

(DECK ASSEMBLY)

AC HEAD ASSEMBLY

SENSOR CBA

SENSOR CBA

CYLINDER ASSEMBLY

DRUM MOTOR


LOADING MOTOR

"●" = SMD

## BLOCK DIAGRAMS

NOTE FOR WIRE CONNECTORS:  
 1. PREFIX SYMBOL "CN" MEANS CONNECTOR.  
 (CAN DISCONNECT AND RECONNECT.)  
 2. PREFIX SYMBOL "CL" MEANS WIRE-SOLDER  
 HOLES OF THE PCB.  
 (WIRE IS SOLDERED DIRECTLY.)

TEST POINT INFORMATION  
 ○ : INDICATES A TEST POINT WITH A JUMPER WIRE ACROSS A HOLE IN THE PCB.  
 □ : USED TO INDICATE A TEST POINT WITH A COMPONENT LEAD ON FOIL SIDE.  
 ◻ : USED TO INDICATE A TEST POINT WITH NO TEST PIN.  
 ● : USED TO INDICATE A TEST POINT WITH A TEST PIN.




## Video Block Diagram ( D, E, F )

**NOTE FOR WIRE CONNECTORS:**  
 1. PREFIX SYMBOL "CN" MEANS CONNECTOR.  
 (CAN DISCONNECT AND RECONNECT.)  
 2. PREFIX SYMBOL "CL" MEANS WIRE-SOLDER  
 HOLES OF THE PCB.  
 (WIRE IS SOLDERED DIRECTLY.)

"●" = SMD


**TEST POINT INFORMATION**  
 ○ :INDICATES A TEST POINT WITH A JUMPER WIRE ACROSS A HOLE IN THE PCB.  
 □ :USED TO INDICATE A TEST POINT WITH A COMPONENT LEAD ON FOIL SIDE.  
 ◇ :USED TO INDICATE A TEST POINT WITH NO TEST PIN.  
 ● :USED TO INDICATE A TEST POINT WITH A TEST PIN.



Comparison Chart of Models & Marks

Model	Mark
VR330/02	D
VR330/07	E
VR330/39	F
VR530/39	G
VR630/02	H
VR630/07	I
VR630/16	J
VR630/39	K

## Video Block Diagram ( G, H, I, J, K )



## Audio Block Diagram ( D, E, F )


### Comparison Chart of Models & Marks

Model	Mark
VR330/02	D
VR330/07	E
VR330/39	F
VR530/39	G
VR630/02	H
VR630/07	I
VR630/16	J
VR630/39	K

"●" = SMD

**NOTE FOR WIRE CONNECTORS:**  
 1. PREFIX SYMBOL "CN" MEANS CONNECTOR.  
 (CAN DISCONNECT AND RECONNECT.)  
 2. PREFIX SYMBOL "CL" MEANS WIRE-SOLDER  
 HOLES OF THE PCB.  
 (WIRE IS SOLDERED DIRECTLY.)

**TEST POINT INFORMATION**  
 ○ : INDICATES A TEST POINT WITH A JUMPER WIRE ACROSS A HOLE IN THE PCB.  
 □ : USED TO INDICATE A TEST POINT WITH A COMPONENT LEAD ON FOIL SIDE.  
 ◻ : USED TO INDICATE A TEST POINT WITH NO TEST PIN.  
 ● : USED TO INDICATE A TEST POINT WITH A TEST PIN.



## Audio Block Diagram ( G, H, I, J, K )

Comparison Chart of Models & Marks


Model	Mark
VR330/02	D
VR330/07	E
VR330/39	F
VR530/39	G
VR630/02	H
VR630/07	I
VR630/16	J
VR630/39	K

"●" = SMD


**NOTE FOR WIRE CONNECTORS:**  
 1. PREFIX SYMBOL "CN" MEANS CONNECTOR.  
 (CAN DISCONNECT AND RECONNECT.)  
 2. PREFIX SYMBOL "CL" MEANS WIRE-SOLDER  
 HOLES OF THE PCB.  
 (WIRE IS SOLDERED DIRECTLY.)

**TEST POINT INFORMATION**  
 ○ : INDICATES A TEST POINT WITH A JUMPER WIRE ACROSS A HOLE IN THE PCB.  
 □ : USED TO INDICATE A TEST POINT WITH A COMPONENT LEAD ON FOIL SIDE.  
 ◻ : USED TO INDICATE A TEST POINT WITH NO TEST PIN.  
 ● : USED TO INDICATE A TEST POINT WITH A TEST PIN.

PB-AUDIO SIGNAL REC-AUDIO SIGNAL Mode : SP/REC



## Hi-Fi Audio Block Diagram ( G, H, I, J, K )



## Power Supply Block Diagram


### Comparison Chart of Models & Marks

Model	Mark
VR330/02	D
VR330/07	E
VR330/39	F
VR530/39	G
VR630/02	H
VR630/07	I
VR630/16	J
VR630/39	K


**NOTE :**  
The voltage for parts in hot circuit is measured using hot GND as a common terminal.

**CAUTION**  
FOR CONTINUED PROTECTION AGAINST FIRE HAZARD,  
REPLACE ONLY WITH THE SAME TYPE T1.6AL/250V FUSE.


**CAUTION !**  
Fixed voltage (or Auto voltage selectable ) power supply circuit is used in this unit.  
If Main Fuse (F001) is blown, check to see that all components in the power supply  
circuit are not defective before you connect the AC plug to the AC power supply.  
Otherwise it may cause some components in the power supply circuit to fail.



## Main 1/6 Schematic Diagram




## Main 2/6 Schematic Diagram



Comparison Chart of Models and Marks


MODEL	MARK
VR330/02	D
VR330/07	E
VR330/39	F
VR530/39	G
VR630/02	H
VR630/07	I
VR630/16	J
VR630/39	K

## Main 3/6 Schematic Diagram



Comparison Chart of Models and Marks

MODEL	MARK
VR330/02	D
VR330/07	E
VR330/39	F
VR530/39	G
VR630/02	H
VR630/07	I
VR630/16	J
VR630/39	K



UNLESS OTHERWISE SPECIFIED:  
 NPN TRANSISTORS ARE KTC199(Y.GR). 2SC2785(F.H.J) OR 2SC1815(Y.GR) (TPE2).

## Main 4/6 Schematic Diagram


Comparison Chart of Models and Marks

MODEL	MARK
VR330/02	D
VR330/07	E
VR330/39	F
VR530/39	G
VR630/02	H
VR630/07	I
VR630/16	J
VR630/39	K


**NOTE:**  
THE VOLTAGE FOR PARTS IN HOT CIRCUIT IS MEASURED USING HOT GND AS A COMMON TERMINAL.

### CAUTION !

Fixed voltage (or Auto voltage selectable) power supply circuit is used in this unit.  
If Main Fuse (F001) is blown, check to see that all components in the power supply circuit are not defective before you connect the AC plug to the AC power supply.  
Otherwise it may cause some components in the power supply circuit to fail.




**CAUTION**  
FOR CONTINUED PROTECTION AGAINST FIRE HAZARD,  
REPLACE ONLY WITH THE SAME TYPE FUSE.



Ref No.	Position	Ref No.	Position
CAPACITORS			TRANSISTORS
C002	S-2	Q001	T-2
C003	S-2	Q002	T-2
C004	T-2	Q003	T-1
C005	T-2	Q004	U-1
C006	T-2	Q051	V-2
C007	T-1	Q052	V-2
C008	S-1	Q053	V-2
C010	S-1	Q054	V-1
C011	S-1	Q056	V-1
C012	U-2	Q057	V-2
C014	U-2	Q058	W-2
C017	U-2		
C018	U-2	R001	S-2
C020	U-2	R002	T-2
C021	U-2	R003	T-2
C022	U-1	R004	T-2
C025	U-1	R005	T-2
C026	V-2	R006	T-1
C053	V-1	R007	T-1
C056	V-1	R008	T-1
C060	V-2	R009	T-1
C061	W-2	R011	S-1
D001	S-2	R012	S-1
D002	T-2	R013	T-1
D003	S-2	R014	S-1
D004	T-2	R016	T-1
D005	T-2	R017	U-2
D006	T-2	R018	U-2
D007	T-1	R021	U-1
D008	T-1	R022	U-1
D009	T-1	R023	U-1
D010	U-2	R024	U-1
D011	U-2	R025	U-1
D012	U-2	R026	U-1
D013	U-2	R027	U-1
D014	U-2	R029	U-1
D015	U-1	R030	U-1
D016	U-1	R035	U-1
D017	U-1	R054	U-1
D018	U-1	R055	U-1
D019	U-1	R056	U-1
D020	U-1	R057	U-1
D021	U-1	R058	U-1
D022	U-1	R060	U-1
D023	U-1	R061	U-1
D024	U-1	R062	U-1
D025	U-1	R063	U-1
D026	U-1	R064	U-1
D027	U-1	R065	U-1
D028	U-1	R066	U-1
D029	U-1	R067	U-1
D030	U-1	R068	V-2
D031	U-1	R070	W-2
D032	U-1	R071	MISCELLANEOUS
D033	U-1	L003	S-2
D034	U-1	L009	S-2
D035	U-1	L010	S-2
D036	U-1	L012	T-2

## Main 5/6 Schematic Diagram ( G,H,I,J,K )




Comparison Chart of Models and Marks

MODEL	MARK
VR330/02	D
VR330/07	E
VR330/39	F
VR530/39	G
VR630/02	H
VR630/07	I
VR630/16	J
VR630/39	K

MAIN 5/6 Schematic Diagram Parts Location Guide (G,H,I,J,K)

Ref No.	Position	Ref No.	Position	
CAPACITORS			CAPACITORS	
C451	X-1	C484	Z-1	
C452	X-1	C485	Y-3	
C453	Y-1	IC		
C454	Y-1	IC451	X-2	
C455	Y-1	COILS		
C456	Y-1	L451	Z-2	
C457	Y-1	L452	Z-2	
C458	Y-1	TRANSISTOR		
C459	Z-1	Q451	Z-2	
C460	Z-1	RESISTORS		
C461	Z-2	R451	X-1	
C462	Z-2	R452	Y-1	
C463	Z-2	R453	Y-1	
C464	Z-2	R454	Y-1	
C465	Z-2	R455	Y-1	
C466	Z-2	R456	Y-1	
C467	Z-2	R457	Y-1	
C468	Z-3	R460	Z-2	
C469	Z-3	R461	Z-2	
C470	Z-3	R462	Y-3	
C471	Y-3	R463	Y-3	
C472	Y-3	R464	Y-3	
C473	Y-3	R465	Y-3	
C474	X-3	R466	X-2	
C475	X-2	R467	X-2	
C476	X-2	R468	X-2	
C477	X-2	R469	X-2	
C478	X-2	R472	X-2	
C479	X-2	R473	X-1	
C480	X-2	R474	Z-2	
C481	X-3	R479	Y-1	
C482	X-3	R480	X-2	
C483	Z-3			


## Main 6/6 Schematic Diagram ( F, G,K )



**Comparison Chart of Models and Marks**

MODEL	MARK
VR330/02	D
VR330/07	E
VR330/39	F
VR530/39	G
VR630/02	H
VR630/07	I
VR630/16	J
VR630/39	K

### MAIN CBA SECAM BLOCK




AA

BB

CC


## Function Schematic Diagram



Function Schematic Diagram  
Parts Location Guide

Ref No.	Position
CONNECTOR	
CN651	A-1
RESISTORS	
R651	A-1
R652	A-1
R653	B-1
R654	B-1
R655	B-1
SWITCHES	
SW651	A-1
SW652	A-1
SW653	B-1
SW654	B-1
SW656	B-1

## AFV Schematic Diagram ( G, H, I, J,K )



Comparison Chart of Models and Marks

MODEL	MARK	MODEL	MARK
VR330/02	D	VR630/02	H
VR330/07	E	VR630/07	I
VR330/39	F	VR630/16	J
VR530/39	G	VR630/39	K

AFV CBA


2

1

A

B



C



AFV Schematic Diagram  
Parts Location Guide ( G,H,I,J,K )

Ref No.	Position
CAPACITORS	
C1	A-1
C4	A-1
C5	B-1
C6	B-1
C7	B-1
C8	B-1
C11	C-2
C12	C-2
C13	B-2
C14	A-2
C15	A-2
C16	A-2
C17	A-2
C18	A-2
C19	A-2
C20	A-2
C21	A-1
C22	A-1
C23	A-1
C24	A-1
C25	B-2
C26	B-2
CONNECTOR	
CN1	C-1
DIODE	
D2	B-2
IC	
IC1	A-1
COILS	
L1	A-1
L2	A-2
L3	A-1
L4	C-2
RESISTORS	
R1	B-1
R2	A-1
R4	B-2
R5	A-1
R6	A-1
R7	B-1
CRYSTAL OSCILLATORS	
X1	B-1

## VPS Schematic Diagram





VPS Schematic Diagram  
Parts Location Guide

Ref No.	Position
CAPACITORS	
C640	A-1
C642	B-1
C643	B-1
C644	B-2
C645	B-2
C648	B-2
C649	A-2
IC	
IC640	A-2
RESISTORS	
R638	A-2
R641	B-1
R642	B-1
R643	B-2
R644	B-2
R645	B-2

## Jack Schematic Diagram

Comparison Chart of Models and Marks

MODEL	MARK
VR330/02	D
VR330/07	E
VR330/39	F
VR530/39	G
VR630/02	H
VR630/07	I
VR630/16	J
VR630/39	K



Jack Schematic Diagram Parts Location Guide

Ref No.	Position	Ref No.	Position
CAPACITORS			RESISTORS
C101	C-3	R101	C-3
C102	C-3	R102	C-3
C103	C-3	R103	C-3
C104	C-2	R104	C-3
C105	C-2	R105	C-3
C107	C-2	R106	C-3
C108	C-2	R107	C-2
C109	B-2	R108	C-2
C110	B-2	R109	C-2
C111	B-1	R110	C-2
C112	B-1	R111	B-2
C113	C-1	R112	B-2
C115	B-3	R113	B-1
C116	B-3	R114	B-1
C117	B-1	R115	C-1
CONNECTORS			R116
CL101	A-3	R117	C-1
CL102	A-2	R118	C-1
DIODES			R119
D101	C-2	R120	B-3
D102	C-1	R123	B-3
D103	C-1	R125	B-1
D105	B-2	R126	A-1
COILS			R127
L101	D-2	R128	B-2
L121	D-1	MISCELLANEOUS	
TRANSISTORS			JK101
Q101	B-3	JK102	D-2
Q102	B-1		


## Main CBA Top View

BECAUSE A HOT CHASSIS GROUND IS PRESENT IN THE POWER SUPPLY CIRCUIT, AN ISOLATION TRANSFORMER MUST BE USED. ALSO, IN ORDER TO HAVE THE ABILITY TO INCREASE THE INPUT SLOWLY, WHEN TROUBLESHOOTING THIS TYPE POWER SUPPLY CIRCUIT, A VARIABLE ISOLATION TRANSFORMER IS REQUIRED.

**CAUTION**  
FOR CONTINUED PROTECTION AGAINST FIRE HAZARD,  
REPLACE ONLY WITH THE SAME TYPE FUSE.

**CAUTION !**  
Fixed voltage power supply circuit is used in this unit.  
If Main Fuse (F001) is blown, check to see that all components in the power supply circuit are not defective before you connect the AC plug to the AC power supply. Otherwise it may cause some components in the power supply circuit to fail.

**NOTE :**  
The voltage for parts in hot circuit is measured using hot GND as a common terminal.




## Main CBA Bottom View

BECAUSE A HOT CHASSIS GROUND IS PRESENT IN THE POWER SUPPLY CIRCUIT, AN ISOLATION TRANSFORMER MUST BE USED. ALSO, IN ORDER TO HAVE THE ABILITY TO INCREASE THE INPUT SLOWLY, WHEN TROUBLESHOOTING THIS TYPE POWER SUPPLY CIRCUIT, A VARIABLE ISOLATION TRANSFORMER IS REQUIRED.

**CAUTION**  
FOR CONTINUED PROTECTION AGAINST FIRE HAZARD,  
REPLACE ONLY WITH THE SAME TYPE FUSE.


**CAUTION !**  
Fixed voltage power supply circuit is used in this unit.  
If Main Fuse (F001) is blown, check to see that all components in the power supply circuit are not defective before you connect the AC plug to the AC power supply. Otherwise it may cause some components in the power supply circuit to fail.

**NOTE :**  
The voltage for parts in hot circuit is measured using hot GND as a common terminal.






**Function CBA Top View**



**Function CBA Bottom View**




**Function CBA Parts Location Guide**


Ref No.	Position	Ref No.	Position
CONNECTORS		SWITCHES	
CN651	A-1	SW651	A-2
RESISTORS		SW652	A-2
R651	A-2	SW653	B-2
R652	A-1	SW654	A-2
R653	A-2	SW656	A-2
R654	A-2		
R655	A-2		

BHC400F01015-B


VPS CBA Top View



VPS CBA Bottom View




Power SW CBA Top View Power SW CBA Bottom View




VPS CBA Parts Location Guide

Ref No.	Position	Ref No.	Position
CAPACITORS		RESISTORS	
C640	A-1	R638	A-1
C642	A-1	R641	A-1
C643	A-1	R642	A-1
C644	A-1	R643	A-1
C645	A-1	R644	A-1
C648	A-1	R645	A-1
C649	A-1		
ICS			
IC640	A-1		

## Jack CBA Top View



## Jack CBA Bottom View



JACK CBA Parts Location Guide


Ref No.	Position	Ref No.	Position
<b>CAPACITORS</b>			
C101	C-1	R101	B-1
C102	B-1	R102	B-1
C103	C-1	R103	B-1
C104	C-1	R104	C-1
C105	C-1	R105	C-1
C106	C-1	R106	C-1
C107	B-1	R107	C-1
C108	B-1	R108	C-1
C109	A-1	R109	C-1
C110	A-1	R110	A-1
C111	A-1	R111	A-1
C112	A-1	R112	A-1
C113	A-1	R113	A-1
C114	C-1	R114	A-1
C115	C-1	R115	A-1
C116	B-1	R116	A-1
C117	B-1	R117	A-1
<b>CONNECTORS</b>			
CL101	C-1	R118	B-1
CL102	B-1	R119	B-1
<b>DIODES</b>			
D101	C-1	R120	C-1
D102	B-1	R123	C-1
D103	B-1	R125	B-1
D105	C-1	R126	B-1
<b>COILS</b>			
R128	C-1	R127	B-1
<b>MISCELLANEOUS</b>			
L101	C-1	JK101	C-1
L121	B-1	JK102	A-1
<b>TRANSISTORS</b>			
Q101	C-1		
Q102	B-1		

BHC400F01015-E

## Comparison Chart of Models & Marks

Model	Mark
VR330/02	D
VR330/07	E
VR330/39	F
VR530/39	G
VR630/02	H
VR630/07	I
VR630/16	J
VR630/39	K


## (DECK ASSEMBLY)



**NOTE FOR WIRE CONNECTORS:**


- PREFIX SYMBOL "CN" MEANS CONNECTOR. (CAN DISCONNECT AND RECONNECT.)
- PREFIX SYMBOL "CL" MEANS WIRE-SOLDER HOLES OF THE PCB. (WIRE IS SOLDERED DIRECTLY.)

## WIRING DIAGRAM




[ VR330/02,VR330/07,VR330/39 ]

1. EJECT (POWER OFF) -> CASSETTE IN (POWER ON) -> STOP(B) -> STOP(A) -> PLAY -> RS -> FS -> PLAY -> STILL -> PLAY -> STOP(A)



2. STOP(A) -> FF -> STOP(A) -> REW -> STOP(A) -> REC -> PAUSE -> PAUSE or REC -> STOP(A) -> EJECT



[ VR530/39,VR630/02,VR630/07,VR630/16,VR630/39]




Fig. 3




Fig. 4

1. EJECT (POWER OFF) -> CASSETTE IN (POWER ON) -> STOP(B) -> STOP(A) -> PLAY -> RS -> FS -> STILL(SLOW) -> PLAY -> PAUSE (SLOW) -> STILL(SLOW) -> PLAY -> STOP(A)




Fig. 5

2. STOP(A) -> FF -> STOP(A) -> REW -> STOP(A) -> REC -> PAUSE -> PAUSE or REC -> STOP(A) -> EJECT




Fig. 6

[ VR330/02,VR330/07,VR330/39,VR530/39,VR630/02,VR630/07,VR630/16,VR630/39 ]

### Comparison Chart of Models and Marks

Model	Mark
VR330/02	D
VR330/07	E
VR330/39	F
VR530/39	G
VR630/02	H
VR630/07	I
VR630/16	J
VR630/39	K

### IC501( SERVO / SYSTEM CONTROL IC )

"H" ≥ 4.5V, "L" ≤ 1.0V

Pin No.	Mark	IN/OUT	Signal Name	Function	Active Level
1		IN	SC2-IN	Input Signal from Pin 8 of SCART2	L/Hi-z
2		IN	PG-DELAY	Video Head Switching Pulse Signal Adjusted Voltage	A/D
3		IN	POW-SAF	P-ON Power Detection Input Signal	A/D
4		IN	END-S	Tape End Position Detect Signal	A/D
5		IN	AFC	Automatic Frequency Control Signal	A/D
6		IN	V-ENV	Video Envelope Comparator Signal	A/D
7		IN	KEY-1	Key Scan Input Signal 1	A/D
8		IN	KEY-2	Key Scan Input Signal 2	A/D
9		IN	LD-SW	Deck Mode Position Detector Signal	A/D
10		OUT	ST-S	Tape Start Position Detector Signal	A/D
11		-	N.U.	Not Used	-
12		-	N.U.	Not Used	-
13		OUT	D-V-SYNC	Dummy V-sync Output	H/Hi-z

Pin No.	Mark	IN/OUT	Signal Name	Function	Active Level
14		IN	REMOC ON-IN	Remote Control Sensor	L
15		OUT	C-ROTA	Color Phase Rotary Changeover Signal	H/L
16	D,E,F	-	N.U.	Not Used	-
	G,H,I,J,K	OUT	H-A-SW	Video Head Amp Switching Pulse	H/L
17	D,E,F	-	N.U.	Not Used	-
	G,H,I,J,K	IN	H-A-COMP	Head Amp Comparator Signal	H/L
18		OUT	RF-SW	Video Head Switching Pulse	H/L
19	D,E,F	-	N.U.	Not Used	-
	G,H,I,J,K	OUT	HiFi-H-SW	HiFi Audio Head Switching Pulse	H/L
20		IN	DAVN-L	VPS/PDC Data Receive = "L"	L
21		-	N.U.	Not Used	-
22		-	N.U.	Not Used	-
23		-	N.U.	Not Used	-
24		-	N.U.	Not Used	-
25		-	N.U.	Not Used	-
26		-	N.U.	Not Used	-
27		OUT	RGB-THROUGH	SCART 2 RGB Through Control Signal	L/Hi-z
28		-	N.U.	Not Used	-
29	D,E,G,H,I,J,K	OUT	AUDIO-SW1	Audio Input/Output Switching Control Signal 1 (Mono)	Z/L
	F	-	N.U.	Not Used	-
30	D,E,G,H,I,J,K	OUT	AUDIO-SW2	Audio Input/Output Switching Control Signal 2 (Mono)	Z/L
	F	-	N.U.	Not Used	-
31		IN	REC-SAF	Recording Safety SW Detect (With Record tab="L"/ With out Record tab="H")	H

Pin No.	Mark	IN/OUT	Signal Name	Function	Active Level
32	D,E, H,I,J	-	N.U.	Not Used	-
	F,G, K	IN	SECAM-H	SECAM Mode at High	H/L
33	D,E, H,I,J	-	N.U.	Not Used	-
	F,G, K	OUT	TRICK-H	Special Playback = "H" in SECAM Mode	H
34		IN	RESET	System Reset Signal (Reset="L")	L
35		IN	XC-IN	Sub Clock	-
36		OUT	XC-OUT	Sub Clock	-
37	-	Vcc	Vcc		-
38		IN	X-IN	Main Clock Input	-
39		OUT	X-OUT	Main Clock Input	-
40	-	Vss	Vss(GND)		-
41	-	N.U.	Not Used		-
42	-	N.U.	Not Used		-
43		IN	CLKSEL	Clock Select (GND)	L
44		IN	OSCIN	Clock Input for letter size	-
45		OUT	OSCOUT	Clock Output for letter size	-
46	-	N.U.	Not Used		-
47	-	N.U.	Not Used		-
48		IN	FSC-IN [4.43MHz]	4.43MHz Clock Input	-
49	-	OSDVss	OSDVss		-
50		IN	VIDEO-IN	Video Signal Input	-
51	-	N.U.	Not Used		-
52		OUT	VIDEO-OUT	Video Signal Output	-
53	-	OSDVcc	OSDVcc		-
54	-	HLF	LPF Connected Terminal (Slicer)		-
55	D,E, H,I,J	-	N.U.	Not Used	-
	F,G, K	IN	COLOR-IN	SECAM or MESECAM Chroma Video Input Signal at Super Impose	Z/L
56	-	N.U.	Not Used		-
57	-	N.U.	Not Used		-

Pin No.	Mark	IN/OUT	Signal Name	Function	Active Level
58		IN	C-SYNC	Composite Synchronized Pulse	PULSE
59		OUT	8POUT-1	SCART 1 8Pin Output Control Signal	H/L
60		OUT	8POUT-2	SCART 2 8Pin Output Control Signal	H/L
61	D,E, F	-	N.U.	Not Used	-
	G,H, I,J,K	IN	A-MODE	Hi-Fi Tape Detection Signal	L
62		OUT	SD-H	SD-H	-
63	-	N.U.	Not Used		-
64		IN	FTV-IN	Comparator Input of Video Signal for Follow TV	L/Hi-z
65		OUT	D-REC-H	Delayed Record Signal	L
66		OUT	C-POWER-SW	Capstan Power Switching Pulse	L/Hi-z
67		IN	P-ON-H	Power On Signal at High	H
68		OUT	DRV-DATA	LED Clock Driver IC Control Data	H/L
69		OUT	DRV-STB	LED Clock Driver IC Chip Select Signal	H/L
70		OUT	DRV-CLK	LED Clock Driver IC Control Clock	H/L
71		OUT	I <sup>2</sup> C BUS-SCL	I <sup>2</sup> C BUS Control Clock	H/L
72		IN/OUT	I <sup>2</sup> C BUS-SDA	I <sup>2</sup> C BUS Control Data	H/L
73	-	N.U.	Not Used		-
74	-	N.U.	Not Used		-
75	-	N.U.	Not Used		-
76		OUT	C-CONT	Capstan Motor Control Signal	PWM
77		OUT	D-CONT	Drum Motor Control Signal	PWM
78		OUT	C-F/R	Capstan Motor FWD/REV Control Signal (FWD="L"/REV="H")	H/L
79		IN	S-REEL	Supply Reel Rotation Signal	PULSE

<b>Pin No.</b>	<b>Mark</b>	<b>IN/OUT</b>	<b>Signal Name</b>	<b>Function</b>	<b>Active Level</b>
80		IN	T-REEL	Take Up Reel Rotation Signal	PULS E
81		OUT	LM-FWD/ REV	Loading Motor Control Signal	H/L/ Hi-z
82		-	N.U.	Not Used	-
83		OUT	A-MUTE-H	Audio Mute Control Signal (Mute = "H")	H
84		OUT	FF/REW-L	CTL Amp Gain Switching Signal (FF/REW="L")	L
85		-	N.U.	Not Used	-
86		IN	P-DOWN-L	Power Voltage Down Detector Signal	L
87		IN	C-FG	Capstan Motor Rotation Detection Pulse	PULS E
88		-	AMPVss	AMPVss (GND)	-
89		IN	D-FG	Drum Motor Rotation Detection Pulse	PULS E
90		IN	D-PG	Drum Motor Pulse Generator	PULS E
91		-	N.U.	Not Used	-
92		-	AMPVRE F <sub>IN</sub>	V-Ref for CTL AMP	-
93		-	C	C Terminal	-
94		OUT	CTL (-)	Playback/Record Control Signal (-)	H/L
95		OUT	CTL (+)	Playback/Record Control Signal (+)	H/L
96		-	AMPC	CTL AMP Connected Terminal	-
97		-	CTLAMP out	To Monitor for CTL AMP Output	PULS E
98		-	AMPVcc	AMPVcc	-
99		-	AVcc	A/D Converter Power Input/ Standard Voltage Input	-
100		IN	AGC	IF AGC Control Signal	H/L/ Hi-z


**Notes:**

Abbreviation for Active Level:


PWM -----Pulse Wide Modulation

A/D-----Analog - Digital Converter


[ VR330/02,VR330/07,VR330/39,VR530/39,VR630/02,VR630/07,VR630/16,VR630/39 ]



BN1F4M-T  
BA1F4M-T  
KTA1266(GR)  
KTC3199(Y,GR,BL)  
2SC2785(J.H.F.K)  
KRA103M  
KRC103M  
2SA1015-GR(TPE2)  
KRA104M  
2SD1246(S,T)  
KTC3205(Y)  
BN1L4M-T  
KTA1281(Y)




2SC1815-Y(TPE2)  
2SC1815-GR(TPE2)  
2SC3266-Y (TPE2)  
2SC2120-Y(TPE2)  
KTC3203(Y)  
2SC1815-BL(TPE2)  
2SA1020(Y)  
2SB892(S)





LM339DT  
KIA339F EL


BR24C02F-W  
AT24C02N-10SC  
M24C02-MN6







LTV-817(B,C)-F  
EL817(A,B,C)




LA71750AM-MTB  
QSZAD0RMB101  
QSZAE0RMB100



PT204-6B-12  
MID-32A22



MSP3407G-QG-B8  
MSP3407G-QG-B8-V8  
MSP3417G-QG-B8  
MSP3417G-QG-B8-V3



**Note:**  
A: Anode  
K: Cathode  
E: Emitter  
C: Collector  
B: Base  
R: Reference  
S: Source  
G: Gate  
D: Drain

## ELECTRICAL PARTS LIST

## ELECTRICAL PARTS LIST

Pos.	▲	12 NC	Description	VR330/02	VR330/07	VR330/39	VR530/39	VR630/02	VR630/07	VR630/16	VR630/39
C311			CHIP CERAMIC CAP. B K 0.01UF/50V or			1	1				1
C312			CERAMIC CAP.(AX) Y M 8200PF/16V	1	1	1	1	1	1	1	1
C313			CHIP CERAMIC CAP. F Z 0.1UF/50V or	1	1	1	1	1	1	1	1
C314			CHIP CERAMIC CAP. B K 0.01UF/50V or	1	1	1	1	1	1	1	1
C315			CHIP CERAMIC CAP. F Z 0.1UF/50V or	1	1	1	1	1	1	1	1
C316			CHIP CERAMIC CAP. B K 0.01UF/50V or	1	1	1	1	1	1	1	1
C317			ELECTROLYTIC CAP. 47UF/6.3V M H7	1	1	1	1	1	1	1	1
C318			ELECTROLYTIC CAP. 1UF/50V M H7	1	1	1	1	1	1	1	1
C319			ELECTROLYTIC CAP. 1UF/50V M H7	1	1	1	1	1	1	1	1
C320			CHIP CERAMIC CAP. F Z 0.1UF/50V or	1	1	1	1	1	1	1	1
C321			CHIP CERAMIC CAP. F Z 0.1UF/50V or	1	1	1	1	1	1	1	1
C322			ELECTROLYTIC CAP. 10UF/16V M H7	1	1	1	1	1	1	1	1
C323			CHIP CERAMIC CAP. F Z 0.1UF/50V or	1	1	1	1	1	1	1	1
C324			CHIP CERAMIC CAP. CH J 68PF/50V or	1	1	1	1	1	1	1	1
C325			CHIP CERAMIC CAP. F Z 0.1UF/50V or			1	1	1	1	1	1
C326			CHIP CERAMIC CAP. CH J 68PF/50V or			1	1	1	1	1	1
C327			CHIP CERAMIC CAP. F Z 0.1UF/50V or	1	1	1	1	1	1	1	1
C330			CERAMIC CAP.(AX) F Z 0.1UF/50V	1	1	1	1	1	1	1	1
C332			CHIP CERAMIC CAP. F Z 0.1UF/50V or	1	1	1	1	1	1	1	1
C333			ELECTROLYTIC CAP. 0.47UF/50V M H7	1	1	1	1	1	1	1	1
C334			ELECTROLYTIC CAP. 4.7UF/25V M NP H7	1	1	1	1	1	1	1	1
C335			ELECTROLYTIC CAP. 10UF/16V M H7	1	1	1	1	1	1	1	1
C337			CHIP CERAMIC CAP. F Z 0.1UF/50V or	1	1	1	1	1	1	1	1
C338			ELECTROLYTIC CAP. 100UF/6.3V H7	1	1	1	1	1	1	1	1
C339			ELECTROLYTIC CAP. 1UF/50V M H7	1	1	1	1	1	1	1	1
C340			CHIP CERAMIC CAP. CH J 120PF/50V or	1	1	1	1	1	1	1	1
C341			CHIP CERAMIC CAP. CH J 220PF/50V or	1	1	1	1	1	1	1	1
C342			ELECTROLYTIC CAP. 1UF/50V M H7	1	1	1	1	1	1	1	1
C343			CHIP CERAMIC CAP. F Z 0.1UF/50V or	1	1	1	1	1	1	1	1
C344			CERAMIC CAP.(AX) B K 100PF/50V or	1	1	1	1	1	1	1	1
C345			CHIP CERAMIC CAP. CH J 68PF/50V or	1	1	1	1	1	1	1	1
C346			CHIP CERAMIC CAP. CH J 68PF/50V or	1	1						
C347			CHIP CERAMIC CAP. CH J 15PF/50V or	1	1	1	1	1	1	1	1
C351			ELECTROLYTIC CAP. 220UF/6.3V M H7	1	1	1	1	1	1	1	1
C352			ELECTROLYTIC CAP. 100UF/16V M H7	1	1	1	1	1	1	1	1
C370			CHIP CERAMIC CAP. B K 0.01UF/50V or			1	1				1
C371			CHIP CERAMIC CAP. B K 0.022UF/50V or			1	1				1
C372			CHIP CERAMIC CAP. F Z 0.1UF/50V or			1	1				1
C373			CHIP CERAMIC CAP. F Z 0.1UF/50V or			1	1				1
C374			CHIP CERAMIC CAP. F Z 0.1UF/50V or			1	1				1
C375			CHIP CERAMIC CAP. B K 0.01UF/50V or			1	1				1
C376			CHIP CERAMIC CAP. B K 0.022UF/50V or			1	1				1
C377			CERAMIC CAP.(AX) Y M 0.01UF/16V			1	1				1
C378			CHIP CERAMIC CAP. B K 0.01UF/50V or			1	1				1
C379			ELECTROLYTIC CAP. 0.47UF/50V M H7			1	1				1
C381			CHIP CERAMIC CAP. F Z 0.1UF/50V or			1	1				1
C382			CHIP CERAMIC CAP. B K 2200PF/50V or			1	1				1
C383			CHIP CERAMIC CAP. B K 2200PF/50V or			1	1				1
C384			ELECTROLYTIC CAP. 2.2UF/50V M H7			1	1				1
C401			ELECTROLYTIC CAP. 47UF/6.3V M H7	1	1	1	1	1	1	1	1
C402			ELECTROLYTIC CAP. 220UF/6.3V M H7	1	1	1	1	1	1	1	1
C403			CERAMIC CAP. B K 470PF/100V or	1	1	1	1	1	1	1	1
C404			FILM CAP.(P) 0.018UF/100V J or	1	1	1	1	1	1	1	1
C411			CHIP CERAMIC CAP. CH J 820PF/50V or	1	1	1	1	1	1	1	1
C412			CERAMIC CAP.(AX) X K 1800PF/16V	1	1	1	1	1	1	1	1
C413			ELECTROLYTIC CAP. 4.7UF/25V M H7	1	1	1	1	1	1	1	1
C414			CHIP CERAMIC CAP. B K 0.01UF/50V or	1	1	1	1	1	1	1	1
C415			ELECTROLYTIC CAP. 10UF/16V M H7	1	1	1	1	1	1	1	1
C416			CHIP CERAMIC CAP. F Z 0.1UF/50V or	1	1	1	1	1	1	1	1
C417			CHIP CERAMIC CAP. B K 0.01UF/50V or	1	1	1	1	1	1	1	1
C418			CHIP CERAMIC CAP. CH J 33PF/50V or	1	1	1	1	1	1	1	1
C419			CHIP CERAMIC CAP. B K 4700PF/50V or	1	1	1	1	1	1	1	1
C421			ELECTROLYTIC CAP. 33UF/6.3V M H7	1	1	1	1	1	1	1	1
C422			ELECTROLYTIC CAP. 4.7UF/25V M H7	1	1	1	1	1	1	1	1
C423			CHIP CERAMIC CAP. F Z 0.1UF/50V or	1	1	1					

## ELECTRICAL PARTS LIST

ELECTRICAL PARTS LIST				VR330/02	VR330/07	VR330/39	VR530/39	VR630/02	VR630/07	VR630/16	VR630/39
Pos.	▲	12 NC	Description								
C530			CERAMIC CAP.(AX) F Z 0.022UF/25V	1	1	1	1	1	1	1	1
C531			CERAMIC CAP.(AX) Y M 0.01UF/16V	1	1	1	1	1	1	1	1
C535			CHIP CERAMIC CAP. B K 0.01UF/50V or	1	1	1	1	1	1	1	1
C538			CHIP CERAMIC CAP. B K 0.022UF/50V or			1					
C540			ELECTROLYTIC CAP. 470UF/6.3V M or	1	1	1	1	1	1	1	1
C541			ELECTROLYTIC CAP. 220UF/6.3V M H7	1	1	1					
C561			CHIP CERAMIC CAP. B K 0.022UF/50V or	1	1	1	1	1	1	1	1
C622			CHIP RES.(1608) 1/10W 0 OHM or	1	1	1	1	1	1	1	1
C701			CHIP CERAMIC CAP. B K 0.047UF/50V or	1	1		1	1	1	1	1
C702			CHIP CERAMIC CAP. F Z 0.1UF/50V or	1	1	1	1	1	1	1	1
C703			ELECTROLYTIC CAP. 10UF/16V M H7	1	1	1	1	1	1	1	1
C704			CHIP CERAMIC CAP. B K 0.01UF/50V or	1	1	1	1	1	1	1	1
C706			CHIP CERAMIC CAP. B K 1000PF/50V or	1	1	1	1	1	1	1	1
C707			ELECTROLYTIC CAP. 100UF/6.3V H7	1	1	1	1	1	1	1	1
C708			CHIP CERAMIC CAP. B K 0.01UF/50V or	1	1	1	1	1	1	1	1
C709			ELECTROLYTIC CAP. 1UF/50V M H7	1	1	1					
C710			CHIP CERAMIC CAP. B K 1000PF/50V or	1	1	1					
C715			CHIP CERAMIC CAP. B K 0.01UF/50V or	1	1	1	1	1	1	1	1
C771			CHIP CERAMIC CAP. F Z 0.1UF/50V or	1	1	1	1	1	1	1	1
C772			ELECTROLYTIC CAP. 10UF/16V M H7	1	1	1	1	1	1	1	1
C773			CERAMIC CAP.(AX) B K 1000PF/50V or	1	1	1	1	1	1	1	1
C774			CHIP CERAMIC CAP. B K 1000PF/50V or	1	1	1	1	1	1	1	1
C775			ELECTROLYTIC CAP. 1UF/50V M H7	1	1	1	1	1	1	1	1
C776			ELECTROLYTIC CAP. 1UF/50V M H7	1	1	1	1	1	1	1	1
C777			CERAMIC CAP.(AX) B K 180PF/50V or	1	1	1	1	1	1	1	1
C778			CHIP CERAMIC CAP. CH J 180PF/50V or	1	1	1	1	1	1	1	1
C851			CHIP CERAMIC CAP. CH J 22PF/50V or	1	1	1	1	1	1	1	1
C852			CHIP CERAMIC CAP. CH J 18PF/50V or	1	1	1	1	1	1	1	1
C853			CHIP CERAMIC CAP. B K 4700PF/50V or	1	1	1	1	1	1	1	1
C854			CHIP CERAMIC CAP. B K 0.01UF/50V or	1	1	1	1	1	1	1	1
C855			CHIP CERAMIC CAP. F Z 0.1UF/50V or	1	1	1	1	1	1	1	1
C856			CHIP CERAMIC CAP. CH J 180PF/50V or	1	1	1	1	1	1	1	1
C858			CHIP CERAMIC CAP. CH J 560PF/50V or			1	1				1
C859			ELECTROLYTIC CAP. 47UF/6.3V M H7	1	1	1	1	1	1	1	1
C862			CHIP CERAMIC CAP. B K 0.01UF/50V or	1	1	1	1	1	1	1	1
CN701		9965 000 12254	AFV PCB ASSEMBLY CP2500/C463				1				1
DIODES											
D001		4822 130 31933	RECTIFIER DIODE 1N4005	1	1	1	1	1	1	1	1
D002		4822 130 31933	RECTIFIER DIODE 1N4005	1	1	1	1	1	1	1	1
D003		4822 130 31933	RECTIFIER DIODE 1N4005	1	1	1	1	1	1	1	1
D004		4822 130 31933	RECTIFIER DIODE 1N4005	1	1	1	1	1	1	1	1
D005		4822 130 81244	RECTIFIER DIODE ERA22-10	1	1	1	1	1	1	1	1
D006		4822 130 32778	SWITCHING DIODE 1SS133(T-77)	1	1	1	1	1	1	1	1
D007		4822 130 32778	SWITCHING DIODE 1SS133(T-77)	1	1	1	1	1	1	1	1
D008		4822 130 32778	SWITCHING DIODE 1SS133(T-77)	1	1	1	1	1	1	1	1
D009		4822 130 32778	SWITCHING DIODE 1SS133(T-77)	1	1	1	1	1	1	1	1
D011		4822 130 10933	FAST RECOVERY DIODE ERA18-04	1	1	1	1	1	1	1	1
D012		4822 130 83883	RECTIFIER DIODE FR202	1	1	1	1	1	1	1	1
D013		4822 130 83883	RECTIFIER DIODE FR202	1	1	1	1	1	1	1	1
D014		4822 130 32715	SCHOTTKY BARRIER DIODE SB340				1	1	1	1	1
D015		4822 130 80319	ZENER DIODE MTZJT-779.1C	1	1	1	1	1	1	1	1
D016		4822 130 10933	FAST RECOVERY DIODE ERA18-04			1					
D018		4822 130 32778	SWITCHING DIODE 1SS133(T-77)	1	1	1	1	1	1	1	1
D019		9965 000 05249	ZENER DIODE MTZJT-775.6B	1	1	1	1	1	1	1	1
D021		4822 130 32778	SWITCHING DIODE 1SS133(T-77)	1	1	1	1	1	1	1	1
D023		9965 000 12904	ZENER DIODE DZ-5.1BSBT265 or			1					
D051		4822 130 31933	RECTIFIER DIODE 1N4005	1	1	1	1	1	1	1	1
D052		4822 130 32778	SWITCHING DIODE 1SS133(T-77)	1	1	1	1	1	1	1	1
D053		4822 130 31933	RECTIFIER DIODE 1N4005	1	1	1					
D053		9965 000 09322	RECTIFIER DIODE FR302				1				1
D053		9965 000 12176	RECTIFIER DIODE RL201 B-222-2						1	1	1
D056		9965 000 05694	ZENER DIODE MTZJT-775.1C	1	1	1	1	1	1	1	1
D057		9965 000 12891	CARBON RES. 1/4W J 3.3K OHM	1	1	1					
D057		9965 000 09283	ZENER DIODE DZ-10BSBT265 or				1	1	1	1	1
D151		9965 000 12177	ZENER DIODE DZ-6.8BSCT265 or				1	1	1	1	1



## ELECTRICAL PARTS LIST

## ELECTRICAL PARTS LIST

## ELECTRICAL PARTS LIST

## ELECTRICAL PARTS LIST



ELECTRICAL PARTS LIST				VR330/02	VR330/07	VR330/39	VR530/39	VR630/02	VR630/07	VR630/16	VR630/39
Pos.	▲	12 NC	Description								
C101			CHIP CERAMIC CAP. B K 2200PF/50V or				1	1	1	1	1
C102			CHIP CERAMIC CAP. B K 2200PF/50V or	1	1	1	1	1	1	1	1
C103			CHIP CERAMIC CAP. CH J 470PF/50V or				1	1	1	1	1
C104			CHIP CERAMIC CAP. CH J 470PF/50V or	1	1	1	1	1	1	1	1
C105			CHIP CERAMIC CAP. F Z 0.1UF/50V or	1	1	1	1	1	1	1	1
C107			ELECTROLYTIC CAP. 1UF/50V M H7	1	1	1	1	1	1	1	1
C108			CHIP CERAMIC CAP. B K 1000PF/50V or	1	1	1	1	1	1	1	1
C109			CHIP CERAMIC CAP. B K 2200PF/50V or				1	1	1	1	1
C110			CHIP CERAMIC CAP. B K 2200PF/50V or				1	1	1	1	1
C111			CHIP CERAMIC CAP. CH J 470PF/50V or				1	1	1	1	1
C112			CHIP CERAMIC CAP. CH J 470PF/50V or				1	1	1	1	1
C113			CHIP CERAMIC CAP. B K 2200PF/50V or				1	1	1	1	1
C115			ELECTROLYTIC CAP. 100UF/16V M H7	1	1	1	1	1	1	1	1
C116			ELECTROLYTIC CAP. 470UF/6.3V M or	1	1	1	1	1	1	1	1
C117			ELECTROLYTIC CAP. 470UF/6.3V M or				1	1	1	1	1
DIODES											
D101		9965 000 12178	ZENER DIODE DZ-11BSAT265 or	1	1	1	1	1	1	1	1
D102		9965 000 12178	ZENER DIODE DZ-11BSAT265 or			1	1	1	1	1	1
D103		9965 000 12178	ZENER DIODE DZ-11BSAT265 or			1	1	1	1	1	1
D105		9965 000 12178	ZENER DIODE DZ-11BSAT265 or	1	1	1	1	1	1	1	1
JK101		9965 000 12197	RGB CONNECTOR MRC-021V-01	1	1	1	1	1	1	1	1
JK102		9965 000 12197	RGB CONNECTOR MRC-021V-01			1	1	1	1	1	1
COILS											
L101		4822 526 10685	BEAD CORE B16 RH 3.5X10X1.3 or	1	1	1	1	1	1	1	1
L121		4822 526 10685	BEAD CORE B16 RH 3.5X10X1.3 or			1	1	1	1	1	1
TRANSISTORS											
Q101		4822 130 42959	TRANSISTOR KTA1266(GR) or	1	1	1	1	1	1	1	1
Q102		4822 130 42959	TRANSISTOR KTA1266(GR) or			1	1	1	1	1	1
RESISTORS											
R101			CARBON RES. 1/4W J 1K OHM	1	1	1	1	1	1	1	1
R102			CARBON RES. 1/4W J 1K OHM	1	1	1					
R103			CARBON RES. 1/4W J 1K OHM			1	1	1	1	1	1
R104			CARBON RES. 1/6W J 4.7K OHM or			1	1	1	1	1	1
R105			CARBON RES. 1/6W J 4.7K OHM or	1	1	1					
R106			CARBON RES. 1/6W J 4.7K OHM or	1	1	1	1	1	1	1	1
R107			CHIP RES.(1608) 1/10W 0 OHM or	1	1	1	1	1	1	1	1
R108			CARBON RES. 1/4W J 68 OHM	1	1	1	1	1	1	1	1
R109			CHIP RES.(1608) 1/10W J 75 OHM or	1	1	1	1	1	1	1	1
R110			CARBON RES. 1/4W J 1K OHM			1	1	1	1	1	1
R111			CARBON RES. 1/4W J 1K OHM			1					
R112			CARBON RES. 1/4W J 1K OHM			1	1	1	1	1	1
R113			CARBON RES. 1/6W J 4.7K OHM or			1	1	1	1	1	1
R114			CARBON RES. 1/6W J 4.7K OHM or			1					
R115			CARBON RES. 1/6W J 4.7K OHM or			1	1	1	1	1	1
R116			CARBON RES. 1/6W J 15K OHM or			1	1	1	1	1	1
R117			CHIP RES.(1608) 1/10W J 10K OHM or			1	1	1	1	1	1
R118			CARBON RES. 1/4W J 68 OHM			1	1	1	1	1	1
R119			CHIP RES.(1608) 1/10W J 75 OHM or			1	1	1	1	1	1
R120			CARBON RES. 1/6W J 680 OHM or	1	1	1	1	1	1	1	1
R123			CHIP RES.(1608) 1/10W J 220 OHM or	1	1	1	1	1	1	1	1
R125			CARBON RES. 1/6W J 680 OHM or			1	1	1	1	1	1
R126			CHIP RES.(1608) 1/10W J 220 OHM or			1	1	1	1	1	1
R127			CHIP RES.(1608) 1/10W 0 OHM or			1	1	1	1	1	1
R128			CHIP RES.(1608) 1/10W 0 OHM or			1	1	1	1	1	1
			<b>SENSOR CBA</b>	1	1	1	1	1	1	1	1
Q504		9965 000 08630	PHOTO TRANSISTOR PT204-6B-12 or	1	1	1	1	1	1	1	1
Q505		9965 000 08630	PHOTO TRANSISTOR PT204-6B-12 or	1	1	1	1	1	1	1	1
			<b>AFV CBA</b>				1	1	1	1	1
CAPACITORS											
C1			CHIP CERAMIC CAP. F Z 0.1UF/50V or				1	1	1	1	1
C4			CHIP CERAMIC CAP. CH J 56PF/50V or				1	1	1	1	1
C5			CHIP CERAMIC CAP. CH J 22PF/50V or				1	1	1	1	1
C6			CHIP CERAMIC CAP. CH J 56PF/50V or				1	1	1	1	1
C7			CHIP CERAMIC CAP. CH D 3PF/50V or				1	1	1	1	1
C8			CHIP CERAMIC CAP. CH D 3PF/50V or				1	1	1	1	1

ELECTRICAL PARTS LIST				VR330/02	VR330/07	VR330/39	VR530/39	VR630/02	VR630/07	VR630/16	VR630/39
Pos.	▲	12 NC	Description								
C11			CHIP CERAMIC CAP. B K 0.01UF/50V				1	1	1	1	1
C12			ELECTROLYTIC CAP. 10UF/16V M H7				1	1	1	1	1
C13			CHIP CERAMIC CAP. B K 0.01UF/50V				1	1	1	1	1
C14			CHIP CERAMIC CAP. B K 0.01UF/50V				1	1	1	1	1
C15			ELECTROLYTIC CAP. 10UF/16V M H7				1	1	1	1	1
C16			ELECTROLYTIC CAP. 10UF/16V M H7				1	1	1	1	1
C17			CHIP CERAMIC CAP. F Z 0.1UF/50V or				1	1	1	1	1
C19			CHIP CERAMIC CAP. F Z 0.1UF/50V or				1	1	1	1	1
C20			ELECTROLYTIC CAP. 3.3UF/50V M H7				1	1	1	1	1
C21			CHIP CERAMIC CAP. F Z 0.1UF/50V or				1	1	1	1	1
C22			ELECTROLYTIC CAP. 10UF/16V M H7				1	1	1	1	1
C23			CHIP CERAMIC CAP. F Z 0.47UF/10V or				1				1
C24			ELECTROLYTIC CAP. 0.22UF/50V M H7				1	1	1	1	1
CN1			ANGLE PIN HEADER, 9P 6029B-1-09Z003-T				1	1	1	1	1
DIODES											
D2		4822 130 30621	SWITCHING DIODE 1N4148M or				1	1	1	1	1
IC1		9965 000 12199	IC:AUDIO PROCESSOR MSP3417G-QG-B8 or				1		1	1	1
IC1		9965 000 12274	IC:AUDIO PROCESSOR MSP3407G-QG-B8 or				1				
COILS											
L1		4822 157 10889	INDUCTOR 10UH-K-26T				1	1	1	1	1
L2		4822 157 10332	PCB JUMPER D0.6-P5.0				1	1	1	1	1
L3		4822 157 11318	INDUCTOR 18UH-K-26T				1	1	1	1	1
L4		4822 157 10889	INDUCTOR 10UH-K-26T				1	1	1	1	1
RESISTORS											
R1			CHIP RES.(1608) 1/10W J 1K OHM				1	1	1	1	1
R2			CHIP RES.(1608) 1/10W 0 OHM				1				1
R4			CHIP RES.(1608) 1/10W J 120K OHM				1	1	1	1	1
R5			CHIP RES.(1608) 1/10W 0 OHM				1	1	1	1	1
R6			CHIP RES.(1608) 1/10W 0 OHM				1	1	1	1	1
R7			CHIP RES.(1608) 1/10W J 1.2K OHM				1				1
X1		9965 000 12200	X'TAL 18.432MHZ				1	1	1	1	1

**PRODUCT SAFETY NOTE:** Products marked with a ▲

have special characteristics important to safety.

Before replacing any of these components, read carefully the product safety notice in this service manual.

Don't degrade the safety of the product through improper servicing.

**NOTES:**

Parts that not assigned part numbers (-----) are not available.


Tolerance of Capacitors and Resistors are noted with the following symbols.

C... D.....±0.5%    F .....±1%  
 G... J.....±5%    K .....±10%  
 M... N.....±30%    Z .....+80/-20%

[ VR330/02,VR330/07,VR330/39,VR530/39,VR630/02,VR630/07,VR630/16,VR630/39 ]

## Front Panel


[ D, E, F ]



Comparison Chart of  
Models and Marks

Model	Mark
VR330/02	D
VR330/07	E
VR330/39	F
VR530/39	G
VR630/02	H
VR630/07	I
VR630/16	J
VR630/39	K

[ G, H, I, J, K ]




[ VR330/02,VR330/07,VR330/39,VR530/39,VR630/02,VR630/07,VR630/16,VR630/39 ]

## Cabinet



Comparison Chart of  
Models and Marks

Model	Mark
VR330/02	D
VR330/07	E
VR330/39	F
VR530/39	G
VR630/02	H
VR630/07	I
VR630/16	J
VR630/39	K




[ VR330/02,VR330/07,VR330/39,VR530/39,VR630/02,VR630/07,VR630/16,VR630/39 ]

## Packing



Comparison Chart of  
Models and Marks

Model	Mark
VR330/02	D
VR330/07	E
VR330/39	F
VR530/39	G
VR630/02	H
VR630/07	I
VR630/16	J
VR630/39	K



MECHANICAL PARTS LIST				VR330/02	VR330/07	VR330/39	VR530/39	VR630/02	VR630/07	VR630/16	VR630/39
Pos.	▲	12 NC	Description								
A1X		9965 000 12888	FRONT ASSEMBLY HC265ED	1							
A1X		9965 000 12900	FRONT ASSEMBLY HC266BD		1						
A1X		9965 000 12902	FRONT ASSEMBLY HC267FD			1					
A1X		9965 000 12910	FRONT ASSEMBLY HC463FD				1				
A1X		9965 000 12911	FRONT ASSEMBLY HC465ED					1			
A1X		9965 000 12163	FRONT ASSEMBLY HC466BD						1		
A1X		9965 000 12912	FRONT ASSEMBLY HC467ED							1	
A1X		9965 000 12253	FRONT ASSEMBLY HC468FD								1
A2		9965 000 12164	CASE, TOP HC460ED	1	1	1	1	1	1	1	1
A3		9965 000 12165	CHASSIS HC461BD	1	1	1	1	1	1	1	1
A7		9965 000 12166	PANEL, BOTTOM HC461BD	1	1	1	1	1	1	1	1
A10	▲		LABEL, RATING HC265ED	1							
A10	▲		LABEL, RATING HC468FD		1						1
A10	▲		LABEL, RATING HC267FD			1					
A10	▲		LABEL, RATING HC463FD				1				1
A10	▲		LABEL, RATING HC465ED					1	1		
A14			LABEL, BAR CODE HC265ED	1							
A14			LABEL, BAR CODE HC468FD		1						1
A14			LABEL, BAR CODE HC267FD			1					
A14			LABEL, BAR CODE HC463FD				1				1
A14			LABEL, BAR CODE HC465ED					1	1		
1B1		9965 000 12889	DECK ASSEMBLY CZD011/VM15A0	1	1						
1B1		9965 000 12903	DECK ASSEMBLY CZD011/VM15A1			1					
1B1		9965 000 12399	DECK ASSEMBLY CZD011/VM15E0				1	1	1	1	1
2B5		9965 000 12168	SHEILD, CYLINDER HC460ED	1	1	1	1	1	1	1	1
2B18		9965 000 12400	FIBER, TOP CASE HC460ED	1	1	1	1	1	1	1	1
2B49		9965 000 12402	CHASSIS FIBER HC460ED	1	1	1	1	1	1	1	1
2L011		9965 000 12403	SCREW, P-TIGHT 3X12 BIND HEAD+	1	1	1	1	1	1	1	1
2L012		9965 000 12403	SCREW, P-TIGHT 3X12 BIND HEAD+	1	1	1	1	1	1	1	1
2L021		4822 502 30752	SCREW, P-TIGHT M3X10 WASHER HEAD+	1	1	1	1	1	1	1	1
2L031		9965 000 12171	SCREW, B-TIGHT M3X8 BIND HEAD+	1	1	1	1	1	1	1	1
2L041		4822 502 14012	P-TIGHT SCREW 3X8 BIND +	1	1	1	1	1	1	1	1
2L042		4822 502 14012	P-TIGHT SCREW 3X8 BIND +	1	1	1	1	1	1	1	1
2L043		4822 502 14012	P-TIGHT SCREW 3X8 BIND +	1	1	1	1	1	1	1	1
2L051		4822 502 14018	SCREW, S-TIGHT M3X5 BIND HEAD+	1	1	1	1	1	1	1	1
X1		9965 000 12890	REMOTE CONTROL UNIT 364/CRC006 or	1	1	1					
X1		9965 000 12281	REMOTE CONTROL UNIT 364/CRC006 or				1				
X1		9965 000 12172	REMOTE CONTROL UNIT 364/CRC006					1	1	1	1
X3		9965 000 09742	RF CORD PAL 1.2M	1	1	1	1	1	1	1	1
X6		9965 000 12420	21P SCART CABLE or			1	1				1

**PRODUCT SAFETY NOTE:** Products marked with a ▲


have special characteristics important to safety.

Before replacing any of these components, read carefully the product safety notice in this service manual.

Don't degrade the safety of the product through improper servicing.


## [ ALL MODEL ]

### Deck Mechanism View 2



## [ ALL MODEL ]

### Deck Mechanism View 3



Some Ref. Numbers are not in sequence.

## DECK PARTS LIST

DECK PARTS LIST											
Pos.	▲	12 NC	Description	VR330/02	VR330/07	VR330/39	VR530/39	VR630/02	VR630/07	VR630/16	VR630/39
B529		9965 000 12231	CLEANER ASS'Y MK11	1	1	1	1	1	1	1	1
B551		9965 000 12232	FF ARM(HI) MK10	1	1	1	1	1	1	1	1
B553		9965 000 12233	REV SPRING MK11	1	1	1	1	1	1	1	1
B555		9965 000 12234	RACK ASS'Y MK11	1	1	1	1	1	1	1	1
B557		9965 000 08519	MOTOR PULLEY U5	1	1	1	1	1	1	1	1
B558		9965 000 12235	LOADING MOTOR M31E-1 R14 7351	1	1	1	1	1	1	1	1
B559		9965 000 12236	CLUTCH ASS'Y(HI)(2) MK11	1	1	1	1	1	1	1	1
B560		9965 000 08522	KICK SPRING MK10	1	1	1	1	1	1	1	1
B562		9965 000 08524	C DRIVE LEVER L MK10	1	1	1	1	1	1	1	1
B563		9965 000 08525	SLIDER SHAFT MK10	1	1	1	1	1	1	1	1
B564		9965 000 12237	M GEAR(HYT) N12G5F*	1	1	1	1	1	1	1	1
B565		9965 000 12238	SENSOR GEAR MK11	1	1	1	1	1	1	1	1
B567		9965 000 08544	PINCH ARM(B) MK10	1	1	1	1	1	1	1	1
B568		9965 000 08545	BT ARM MK10	1	1	1	1	1	1	1	1
B569		9965 000 12239	CAM HOLDER F MK11	1	1	1	1	1	1	1	1
B570		9965 000 12240	CAM RACK SPRING(HI) MK11	1	1	1	1	1	1	1	1
B571		4822 532 13158	P.S.W F 6*2.55*0.5	1	1	1	1	1	1	1	1
B572		4822 532 13159	P.S.W CUT 1.6X4.0X0.5T	1	1	1	1	1	1	1	1
B573		9965 000 12241	REEL S MK11	1	1	1	1	1	1	1	1
B574		9965 000 12376	REEL T MK10	1	1	1	1	1	1	1	1
B578		9965 000 12243	TR GEAR A MK10	1	1	1	1	1	1	1	1
B579		9965 000 12244	TR GEAR B MK10	1	1	1	1	1	1	1	1
B580		9965 000 12245	TR GEAR C MK11	1	1	1	1	1	1	1	1
B581		9965 000 12246	CENTER GEAR(HYT) N12G5F*	1	1	1	1	1	1	1	1
B582		9965 000 12247	TR GEAR SPRING MK10	1	1	1	1	1	1	1	1
B583		9965 000 05342	REEL WASHER MK9 5*2.1*0.5	1	1	1	1	1	1	1	1
B584		9965 000 12248	TR GEAR SHAFT MK10	1	1	1	1	1	1	1	1
B585		9965 000 12249	PSW(2957505) MK11	1	1	1	1	1	1	1	1
L1051		9965 000 05359	SCREW, B-TIGHT M2.6X6 PAN HEAD+	1	1	1	1	1	1	1	1
L1053		9965 000 05375	SCREW, S-TIGHT M2.6X8 WASHER HEAD+	1	1	1	1	1	1	1	1
L1151		9965 000 08642	SCREW, SEMS M2.6X4 PAN HEAD+	1	1	1	1	1	1	1	1
L1191		9965 000 05375	SCREW, S-TIGHT M2.6X8 WASHER HEAD+	1	1	1	1	1	1	1	1
L1321		4822 502 14009	SCREW, S-TIGHT M3X6 BIND HEAD+	1	1	1	1	1	1	1	1
L1341		4822 502 14669	SCREW, P-TIGHT M2.6X6 BIND HEAD+	1	1	1	1	1	1	1	1
L1406		9965 000 08643	AC HEAD SCREW MK9	1	1	1	1	1	1	1	1
L1407		9965 000 12250	SCREW, S-TIGHT M2.6X10 DISH HEAD+	1	1	1	1	1	1	1	1
L1450		4822 502 14671	SCREW, SEMS M2.6X5 PAN HEAD+	1	1	1	1	1	1	1	1
L1461		4822 502 30471	SCREW, P-TIGHT M2.6X6 WASHER HEAD+	1	1	1	1	1	1	1	1
L1466		9965 000 05364	SCREW, S-TIGHT M2.6X6 BIND HEAD+	1	1	1	1	1	1	1	1
L1467		9965 000 12251	SCREW, S-TIGHT M2.6X5 WASHER HEAD+	1	1	1	1	1	1	1	1
L1468		9965 000 12252	SCREW, B-TIGHT M1.7X12	1	1	1	1	1	1	1	1
L1471		9965 000 05364	SCREW, S-TIGHT M2.6X6 BIND HEAD+	1	1	1	1	1	1	1	1

**Note:** There are two different, but interchangeable types of CLEANER LEVER (B359) in this model, and have different combination with B361. Please see table 1 for details and combination.

Table 1 (B359and B361 Combination)

B359 CLEANER LEVER		B361
Type	ID No.	ID No.
A	9965 000 08449	9965 000 08450
B	9965 000 12416	not used