

SERVICE MANUAL

AEP Model



711P SYSTEM

March, 1982

Also refer to OPERATION MANUAL and ADJUSTMENT MANUAL.

SPECIFICATIONS

System

Video recording system
Video signal
FF output signal
Usable cassettes
Tape speed
Maximum recording time

Rotary two-head helical scanning
CCIR standard, PAL colour
UHF channels 30-39 (variable)
75 ohms, unbalanced
Cassettes with the **B** mark
18.73 mm/sec.
2 hours 10 min. (with Sony L-500 cassette)
3 hours 15 min. (with Sony L-750 cassette)

Fast forward/rewind time
Horizontal resolution

Under 3½ min. (with L-500 cassette)
Colour: 260 lines
B/W: 300 lines

Video S/N

Colour: Better than 40 dB
B/W: Better than 43 dB

Audio frequency response
Audio S/N

50 Hz to 10 000 Hz
Better than 40 dB

Inputs and outputs

CAMERA connector

14-pin, K-type connector
Video in: 1 V p-p ±0.5 V p-p
75 ohms unbalanced,
sync negative
Video out: 1 V p-p ±0.1 V p-p
75 ohm unbalanced,
sync negative
Audio in: -20 dBs
(0 dBs = 0.775 V rms)
Audio out: -5 dBs (at load impedance 100 kilohms)
output impedance: less than 10 kilohms
Power supply output: 12 V dc

ACCESSORY CONNECTOR

26-pin connector
Video in: 1 V p-p ±0.5 V p-p
75 ohms unbalanced,
sync negative
Video out: 1 V p-p ±0.1 V p-p
75 ohms unbalanced,
sync negative

Microphone input

Audio in: -10 dBs
input impedance 100 kilohms
Audio out: -5 dBs (at load impedance 100 kilohms)
output impedance: less than 10 kilohms

Power supply input: 12 V dc
Minijack
-60 dBs, for low-impedance microphone
Minijack
-26 dBs, for 8-ohm earpiece

Earpiece output

General

Power requirements
Power consumption
Operating position
Operating temperature
Storage temperature
Dimensions

12 V dc ±10%
8.4 W (dc, record mode without camera)
vertical or horizontal
0°C to 40°C (32°F to 104°F)
-20°C to +65°C (-4°F to +149°F)
Approx: 215 × 80 × 325 mm (w/h/d)
(8½ × 3¼ × 12⅞ inches)
not incl. projecting parts and controls
Approx. 4.3 kg (9 lb 8 oz) net

Weight



MICROFILM

Consumer
VIDEO

Beta
B PORTABLE VIDEO
CASSETTE RECORDER
SONY®

Accessories supplies

Betamax video cassette tape	(1)
75-ohm coaxial cable	(1)
Shoulder strap	(1)
Earpiece	(1)
RF channel adjustment screwdriver	(1)

While the information given is true at the time of printing, small production changes in the course of our company's policy of improvement through research and design might not necessarily be indicated in the specifications. We would ask you to check with your appointed Sony dealer if clarification on any point is required.

Note: Appliance conforms with EEC Directive 76/889 regarding interference suppression.

OPTIONAL ACCESSORIES

Betamax video cassette tape L-250, L-500, L-750
Video head cleaning cassette L-25CL
Rechargeable battery pack NP-1
AC power adaptor AC-F1E
Tuner timer unit TT-F1E
Car battery cord DCC-2500
Colour video camera HVC-2000P, HVC-3000P
Video monitor cable VMC-330
Cable attachment VMC-340
Carrying case LC-330
Carrying handle AH-330
Antenna selector ANS-33

TABLE OF CONTENTS

1. GENERAL

1-1. Location and Function of Controls	4
1-2. Power Sources	6
1-3. TV Connections	9
1-4. TV Adjustment	10
1-5. Camera Recording	13
1-6. TV Program Recording	17
1-7. Playback	18
1-8. Timer Activated Recording	19
1-9. To Obtain Variable Speed Playback Pictures	20
1-10. To Locate Particular Scenes Quickly	22
1-11. Important Rewinders	23
1-12. How is the Picture on the Screen	24
1-13. Dubbing Audio	24
1-14. Disassembly	28
1-15. Internal Views	30

2. BLOCK DIAGRAM

Overall Block Diagram	33
Video System Block Diagram	36
Video Y Signal System Block Diagram	39
Video Chroma System Block Diagram	40
System Control Block Diagram	41
System Control CPU Signal Flow	43
System Control (FR-4 Board) Block Diagram	45
System Control (MA-3 Board) Block Diagram	47
System Control Circuit and Servo Circuit Interface	49
System Control Circuit and Video Circuit Interface	49
System Control Circuit and Reel Motor Circuit Interface	51
System Control Circuit and Audio Circuit Interface	51
System Control Circuit and Tuner/Timer Circuit, Power Supply Circuit Interface	53
System Control Circuit and Slow Play Control, Circuit Interface	53
System Control Circuit and Mechanism Block Interface	55
Capstan/Drum Servo Block Diagram	57
Reel Servo Block Diagram	59
Capstan Phase Control System Timing Chart (Recording Mode)	61
Capstan Phase Control System Timing Chart (Playback Mode)	62
Capstan Speed Control System Timing Chart	62
Drum Phase System Timing Chart	63

Instrumentation Counter Timing Chart	63
Drum Speed System Timing Chart	64
Instrumentation Period Produce Timing Chart	64
FG Circuit Timing Chart	65
PG-A, PG-B, PG-S Timing Chart	66
PG-A, PG-S Timing Chart (Recording mode & Playback Mode)	66
Servo Amp Timing Chart	67
CTL Circuit of IC409 Timing Chart	68
Variable Speed Playback Circuit Timing Chart	69
Audio Circuit Block Diagram	71
Audio Level Diagram (Recording Amp)	73
Audio Level Diagram (Playback Amp)	74
Power Supply Block Diagram	75

3. PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM

Semiconductor	77
Frame Schematic Diagram	78
REC/PB Amp, SF-5, SL-3, SF-6 Board	81
MA-3 Board	89
MA-3, LS-8, BHF-1901A Board	97
MA-3, BHF-1800A Board	106
FR-4, MA-3, LM-8, LM-10 Board	112
LS-8, EH-3 Board	121

4. EXPLODED VIEWS

(1) Front Panel Assembly	129
(2) Upper Panel Assembly	130
(3) Lower Panel Assembly	131
(4) Main Board Assembly	132
(5) Cassette Compartment Assembly	133
(6) Threading Motor and ACE Head Assembly	134
(7) Lock Arm and TP Assembly	135
(8) ULE Switch and Shuttle Guide Assembly	136
(9) Pinch Roller Solenoid Assembly	137
(10) Drum Assembly	138
(11) Drive Gear and T Slider Assembly	139
(12) Threading Ring Assembly	140
(13) Capstan Motor Assembly	141
(14) Cassette Compartment Lock Assembly	142
(15) Chassis Assembly	143

5. ELECTRICAL PART LIST 144

SECTION 1 GENERAL

PRECAUTIONS

On colour broadcasting systems

This machine is designed to record and play back using the PAL colour standard. Recording and playback of video sources based on other colour systems cannot be guaranteed.

On safety

● Operate the unit only on 12 V dc. For ac operation, use the AC-F1E ac power adaptor (optional) or the TT-F1E tuner timer unit (optional). Do not use any other equipment.

For car battery operation, use the DCC-2500 car battery cord only. Do not use any other car battery cord.

● The nameplate indicating operating voltage, power consumption, etc. is located on the bottom.

● Should any solid object or liquid fall into the cabinet, turn off the unit and have it checked by qualified personnel before operating it any further.

On installation

● Do not install the unit near heat sources such as radiators or air ducts or in a place subject to direct sunlight, excessive dust, or mechanical shock.

● Keep the unit and the cassette away from equipment with strong magnets, as for example, a microwave oven or a large loudspeaker.

On operation

After playing a tape, remove the cassette from its compartment if the unit will not be used for any length of time.

On cleaning


Clean the cabinet, panel and controls with a dry soft cloth, or a soft cloth lightly moistened with a mild detergent solution. Do not use any type of solvent, such as alcohol or benzene, which might damage the finish.

On repacking


Do not throw away the carton and packing materials. They make an ideal container in which to transport the unit. When shipping the unit to another location, repack it as illustrated on the carton.

If you have any questions about this unit, contact your Sony dealer.

SAFETY-RELATED COMPONENT WARNING !!

COMPONENTS IDENTIFIED BY SHADING AND MARK  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL TO SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

1-1. LOCATION AND FUNCTION OF CONTROLS



❶ LIGHT button

Press this button to illuminate the time counter for easier reading in the dark.

❷ GO TO ZERO button

Press this button in the stop mode to return the tape to the "0:00 0" point on the time counter.

❸ RESET button

Press to set the time counter to "0:00 0".

❹ Time counter

Indicates in hours, minutes, and 10s of seconds how much the tape has advanced at normal speed.

The "⏪" indication blinks when the battery is about to be exhausted and must be replaced.

The "💧" indication blinks if there is moisture condensation inside the unit.

When the tape runs in the forward direction, "▲" mark blinks and in the reverse direction, "▼" mark blinks.



❺ ON button

Press this button to turn on the power. The lamp will light. To turn the power off, press this button again.

If a tuner timer unit is connected, the recorder is turned on and off by the switch on the tuner timer unit and this button will not function.

❻ Cassette EJECT button

Press to raise the cassette compartment lid to insert or remove a cassette. This button does not function when the recorder is turned off.

❼ TEST SIGNAL switch

Set to ON to tune your TV receiver to the recorder. You can obtain a black and white pattern from the RF OUT jack of this recorder.

❽ EARPIECE jack

Connect the supplied earpiece here to monitor the sound being recorded during audio dubbing or camera recording.

❾ TRACKING control

If streaks or snow appear in a double speed or a reverse playback picture, or during playback of a cassette recorded by another recorder, adjust this control to obtain the best possible picture. Set to the centre position when playing back cassettes recorded on this recorder.

❿ STOP button

Press to stop the tape.

⓫ SWING SEARCH buttons

These buttons are used for a slow-motion or a frame-by-frame picture. For details, see pages 36-38.

⓬ PAUSE button

Press to stop the tape for a moment during recording or playback. A still picture will be seen during playback and variable-speed playback can be realized using the SWING SEARCH buttons. Press again to release the pause mode.

⓭ x2 (double-speed) button

Press during playback to obtain a double speed picture. To resume normal playback, press the ▶ PLAY button or press this button again.

14 AUDIO DUB button

Use this button to dub audio onto a previously recorded tape.

15 FF (fast-forward) button

Press to advance the tape rapidly. This button is also used for the forward picture-search operation.

16 RECORD button

While pressing this button, press the ► PLAY button to start recording. If you press the PAUSE button while pressing this button, the recorder will enter the recording pause mode.

When a camera is connected, you can set the unit into the recording pause mode by pressing this button and the ► PLAY button. To start recording from the recording pause mode, press the PAUSE button or the tape run/stop button on the camera.

17 ► PLAY button

Press to play the tape back.

18 ◀◀ REW (rewind) button

Press to rewind the tape. This button is also used for the reverse picture-search operation.

19 Battery EJECT button


Press to remove the battery pack from its compartment.

20 BATTERY compartment

Insert a NP-1 rechargeable battery pack (optional).

21 Cassette compartment

Insert the cassette to be recorded on or played back here.



22 DC IN jack

Connect an AC-F1E ac power adaptor or the DCC-2500 car battery cord here.

23 ACCESSORY CONNECTOR

Connect a TT-F1E tuner timer unit, a VMC-330 video monitor cable or a VMC-340 cable attachment here.

24 RF OUT jack

Connect to the AERIAL IN connector on the TV receiver. The signal of a VTR programme (which is converted into an RF signal) will be supplied to the TV receiver.

25 RF CHANNEL screw

If there is interference on the factory preset channel for RF output and the signal of this recorder cannot be displayed clearly on the TV screen, adjust this screw with the adjustment tool (a small screwdriver) supplied.

26 CAMERA connector (14-pin, K-type)

Connect a video camera, such as a HVC-3000P or HVC-2000P, here.

27 MIC (microphone) jack (minitype)

Connect a microphone here. If your microphone has a phone-type plug, use a plug adaptor.

28 Shoulder strap pivot

Attach the supplied shoulder strap here.

1-2. POWER SOURCES

Operate this video cassette recorder on one of the following power sources:


- NP-1 rechargeable battery pack (optional)
- Mains supply using the ac power adaptor AC-F1E (optional)
- Mains supply using the tuner timer unit TT-F1E (optional)
- 12 V car battery using the DCC-2500 car battery cord (optional)

USING THE AC-F1E AC POWER ADAPTOR

- 1 Connect the DC OUT cord of the adaptor to the DC IN jack of the recorder.
 - Correctly align the plug and the jack then insert the plug firmly.
- 2 Connect the mains lead of the adaptor to a mains outlet.
- 3 Set to ON the POWER switch on the rear of the adaptor.

Turning the recorder on and off

- To turn the recorder on, first press the ON/STANDBY button of the ac power adaptor, then the ON button of the recorder.
- To turn it off, simply press the ON/STANDBY button on the ac power adaptor.




USING THE TT-F1E TUNER TIMER UNIT


- 1 Connect the 26-pin VTR connector of the tuner timer unit to the ACCESSORY CONNECTOR of the recorder. The plug will fit only one way.
- 2 Connect the mains lead into a mains outlet.
- 3 Depress the POWER switch on the front of the tuner timer unit.

Turning the recorder on and off

- The ON button on the tuner timer unit turns the recorder on and off.
- The ON button on the recorder will not function.



USING THE NP-1 RECHARGEABLE BATTERY PACK



Insert the battery pack into the BATTERY compartment. The ON button of the recorder turns the recorder on and off.

- To remove the battery pack, press the EJECT button just below the battery compartment.

NOTICE: When you operate the recorder on a battery pack, the recorder will be turned off automatically after about 8 minutes in the stop mode, to save the battery pack.


BEFORE OPERATING THE RECORDER, BE SURE TO RECHARGE THE BATTERY PACK

Battery life

At normal temperatures, a fully-charged battery provides 1 hour of continuous operation of both the recorder and the colour video camera.


When to replace the battery pack

The time counter warns you of a discharged battery. If "⚡" mark starts blinking on the time counter, replace the battery pack with a fully-charged one. If you do not, the recorder will be automatically turned off in about 30 seconds.



If you connect a tuner timer unit, an ac power adaptor or a car battery cord, the recorder is operated on external power even if the battery pack remains inserted.


USING THE DCC-2500 CAR BATTERY CORD



- 1 Connect the smaller plug of the car battery cord to the DC IN jack of the recorder. Be sure to align the plug and the jack.
 - 2 Plug the bigger plug into the cigarette lighter socket of your car. Your car's battery should be 12 V.
- For details, refer to the instruction manual of the DCC-2500.


CHARGING THE BATTERY PACK

Using the ac power adaptor



- 1 Insert the battery pack into the recorder.
- 2 You can also charge the battery pack by inserting it into the ac power adaptor. If battery packs are inserted into both the recorder and the ac power adaptor, only the battery pack in the ac power adaptor will be charged.
- 3 Turn off the power of the recorder so that the ON lamp goes off.
- 4 Turn on the ac power adaptor so that the ON lamp lights.
- 5 Press the CHARGE button on the adaptor. The VTR lamp (or the ADAPTOR lamp if you inserted the battery into the adaptor) lights and charging begins.

Using the tuner timer unit




- 1 Insert the battery pack into the recorder.
- 2 Turn off the power by pressing the ON button of the tuner timer unit so that the green lamp goes off.
- 3 Press the CHARGE button on the tuner timer unit. The CHARGE lamp lights and charging begins.

The charging time is about 1 hour at normal temperatures. When the battery is fully charged, the charging will stop automatically and the lamp will go off.

Notes

- Do not turn on the recorder while a battery pack is charging.
- The battery pack may not be charged if you try to recharge it immediately after it has been used. If this happens, wait for a few minutes before recharging it.

1-3. TV CONNECTIONS



First unplug your TV from the mains outlet and remove the aerial cable from its socket in the back of the TV.

- ① Connect the aerial cable to the ANT connector of the ANS-33 antenna selector (optional).
- ② Connect the TV connector of the ANS-33 to the aerial socket of the TV with a 75-ohm coaxial cable.

③ Connect the VTR connector of the ANS-33 to the RF OUT connector of the recorder.

④ Set the switch on the ANS-33 to VTR.

- With this connection, we recommend using an AC-F1E ac power adaptor.


CONNECTING A COLOUR MONITOR TV

- ① Connect the VMC-330 video monitor cable (optional) to the ACCESSORY CONNECTOR of the recorder.
- ② Connect the AUDIO OUT cord of the VMC-330 to the audio input of the colour monitor TV.
- ③ Connect the VIDEO OUT cord to the video input.


- We recommend using the AC-F1E ac power adaptor.

- To connect a system incorporating a tuner timer unit, refer to the instruction manual of the TT-F1E.

With this system, the following TV adjustment is not required.



TV CONNECTION USING A TUNER TIMER UNIT



- ❶ Connect the VTR connector cable of the tuner timer unit to the ACCESSORY CONNECTOR of the recorder.
 - ❷ Remove the aerial cable from your TV and connect it to the AERIAL IN connector of the tuner timer unit.
 - ❸ Connect the AERIAL OUT connector of the tuner timer unit to the aerial input of the TV using the supplied cable.
- The recorder's power is supplied from the tuner timer unit.






Once one of the above connections have been made, you can view TV programmes in the usual way. To view a video programme, proceed with the TV adjustment

1-4. TV ADJUSTMENT

To view a video programme or the TV programme being recorded on the TV screen, you should adjust the TV receiver so that it is tuned to the signals from the recorder.

- ❶ After making the connections, turn on the recorder and associated equipment.
 - ❷ Make sure that the recorder is in the stop mode.
 - ❸ Set the TEST SIGNAL switch to ON.
 - ❹ Turn on the TV and select a channel which is not being used to receive a TV station. Tune the channel until you see a clear black and white pattern on the TV screen and you hear a high-pitched tone. This is the recorder's test signal.
 - Note that the test signal is transmitted on a channel between UHF channels 30 and 39.
 - If you are not sure how to adjust your TV, please refer to the TV's instruction manual or consult your dealer.
- If the test picture is free of disturbance,** the TV adjustment is complete. Set the TEST SIGNAL switch to OFF.
- If the test picture is not free of disturbance,** proceed with the adjustment






Whenever you use the video recorder and the tuner timer unit, you should set the TV to the channel selected in the above adjustment.



If the test picture is not free of disturbance


- ❶ Reset the TEST SIGNAL switch to OFF.
- ❷ Adjust the channel of the TV to a channel between UHF channels 30 and 39 with the tuning control or the fine tuning control on the TV, so that the TV screen shows only "snow" and so that all you can hear is a steady rustling sound.
- ❸ Set the TEST SIGNAL switch to ON again.

- ❹ Slowly turn the RF CHANNEL screw on the back of the recorder if the TV is connected directly to the recorder, or on the back of the tuner timer unit, until you see an undistorted test picture on the TV screen.
 - For this adjustment, use the supplied small screwdriver.
- ❺ Now the TV adjustment is complete. Reset the TEST SIGNAL switch to OFF.



1-5. CAMERA RECORDING

The camera to be connected must conform to the CCIR TV standard (the PAL colour system).



First connect a power source, such as a battery pack or an ac power adaptor, then plug the K-type (14-pin) connector of a Sony HVC-2000P or HVC-3000P video camera into the CAMERA connector.

Align the camera's connector with that of the recorder.


- To disconnect the camera cable, grasp the ring of the connector and pull.

Note

- If you want to use a camera not recommended in this manual, make sure that the power requirement of the camera is DC 12 V and that the power consumption is under 10W. Otherwise, the video cassette recorder will be damaged.

When the TT-F1E tuner timer unit is connected

Be sure to set the INPUT SELECT switch on the tuner timer unit to CAMERA.




To monitor the scenes being recorded on the TV screen

Connect a TV and set it to the channel preset for the video recorder. You cannot monitor, however, if the recorder is being powered by an NP-1 battery pack. In this case, connect a video monitor or a TV receiver equipped with audio and video line inputs with a VMC-330 video monitor cable.


To record the sound from an external microphone

Plug a microphone into the MIC jack on the recorder.

The microphone built into the camera will be disconnected. If your microphone has a phone plug, use a plug adaptor such as a Sony PC-1A (optional).



OPERATING PROCEDURE




- 1 Turn on the power.
 - When using with a battery pack, simply press the ON button on the recorder (case A).
 - When using with an ac power adaptor, press the ON buttons on both the adaptor and the recorder (case B).
 - When using with a tuner timer unit, press the ON button on the tuner timer unit (case C).
 - 2 Press the EJECT button and insert a cassette with the round window to the left.
 - 3 While holding the ● RECORD button depressed, press the ► PLAY button. The recorder will be set into the recording pause mode.
 - 4 Make the necessary adjustments on the camera. For details, refer to the camera's instruction manual.
 - Before starting recording, make sure that the TEST SIGNAL switch on the recorder is set to OFF. If it remains ON, the test signal will be recorded even though you can view, on the viewfinder, the scenes you want to record.
 - 5 To start recording, press the tape run/stop button on the camera.
 - 6 To stop recording, press the ■ STOP button.
- When the tape reaches the end, it will be rewound to the beginning.

To stop the tape momentarily

Press the tape run/stop button on the camera or the PAUSE button on the recorder. To start recording again, press this button again.

Automatic release: The pause mode will be automatically released after about 8 minutes to protect the video heads and the tape. The recorder will then stop if it is being powered by a battery pack, or the record mode will be resumed if the recorder is used with another power source.

To record a tape which is to be played back from the very beginning of the tape on another recorder, run the tape for about 15 seconds before starting recording. Otherwise, you may miss the starting point during playback on the other machine.



If you use a camera with a recording review function, such as the Sony HVC-3000P and HVC-2000P*, you can check whether the recording has been made correctly immediately after you have set the recorder into the recording pause mode.


Press the recording review button in the recording pause mode. The last few seconds of the recorded scene will be played back on the viewfinder. The recorder will then enter the recording pause mode at the point where the recording review button was pressed.

To restart recording, press the tape run/stop button on the camera.

*For customers who have a HVC-3000P or HVC-200P

The small projection located near the zoom switch is the recording review button. If this button is covered with a plastic cap, carefully remove the cover over the button with a screwdriver or similar

HVC-2000P,
HVC-3000P





HOW TO RECORD WITH SMOOTHER TRANSITIONS BETWEEN SCENES

The picture transition between scenes will be smoother if you start recording after first setting the recorder in the recording pause mode, even if you use the ■ STOP button to stop recording or if you turn off the recorder between scenes.

To set the recorder into the recording pause mode:

When recording with a camera, simply press the ● RECORD and ► PLAY buttons

When recording TV programmes, press the ● RECORD and PAUSE buttons simultaneously To start recording, press the PAUSE button again.





You can start recording at any point even from the playback mode.

- 1 Stop the tape at the point which you want to start recording the next scene by pressing the PAUSE button.
- 2 Press the ● RECORD button. The recorder will be set to the recording pause mode.
- 3 Press the PAUSE button again. Recording will begin.

Why is picture transition smoother when recording is started from the recording pause mode?

When the recorder enters the recording pause mode, the tape will be automatically rewound for about 0.5 second, then stop. When the pause mode is released to start recording, the tape runs in the playback mode to synchronize the segment to be recorded next with the last segment recorded. When the tape reaches the point where the recorder entered the recording pause mode, recording starts.



1-6. TV PROGRAM RECORDING

To record TV programmes, a TT-F1E tuner timer unit is necessary.

- ❶ Turn on the TV and select the channel preset for the video recorder.
- ❷ Press the ON button on the tuner timer unit.
- ❸ Set the INPUT SELECT switch on the tuner timer unit to TUNER.
- ❹ Select the channel to be recorded with the tuner timer unit.
- ❺ Insert a cassette into the recorder with the round window to the left.
- ❻ While holding the ● RECORD button depressed, press the PLAY button. Recording will begin.
- ❼ To stop recording, press the ■ STOP button on the recorder.

To stop the tape momentarily, press the PAUSE button. During pause mode, the TV programme can be seen on the TV but the picture will not be recorded.

Automatic release: The pause mode will be released automatically after about 8 minutes and the recorder will revert to the record mode. This is to protect the video heads and the tape.


CAUTION

Television programmes, films, video tapes and other materials may be copyrighted. Unauthorized recording of such material may be contrary to the provision of the copyright laws.

RECORDING ONE TV PROGRAMME WHILE VIEWING ANOTHER

You can enjoy one TV programme while recording another TV programme as follows:


- ❶ Start recording the desired TV programme in the usual way.
- ❷ Select the channel you want to view with the TV's programme selector.



1-7. PLAY BACK

- 1 Turn on the recorder and the associated equipment.
 - 2 Set the TV to the channel preset for the video recorder.
 - 3 Insert a cassette, with the round window to the left.
 - Rewind the tape with the ◀◀ REW button, if necessary.
 - 4 Press the ▶ PLAY button on the recorder. The lamp lights up and playback begins.
 - 5 To stop playback, press the ■ STOP button.
- When the tape reaches the end, it will be automatically rewound to the beginning.

To playback from the beginning of the tape after rewinding
 Press the ▶ PLAY button while holding the ◀◀ REW button depressed during rewinding or in the stop mode
 After the tape is completely rewound, the tape will automatically replay.




1-8. TIMER ACTIVATED RECORDING

Using the TT-F1E tuner timer unit (optional), you can record a TV programme in your absence. Recording may be begun at any time on any day of the next fourteen days and stopped at a predetermined time.

Up to 8 turn-on and turn-off times can be programmed.

POINTS TO CHECK BEFORE STARTING TIMER RECORDING

- Is the tuner timer unit connected correctly?
- Does the cassette to be used have a safety tab on the bottom?
- Is the tape in the cassette long enough to record the desired programmes?



- 1 Turn on the tuner timer unit and the recorder.
- 2 Insert a cassette.
- 3 Set the INPUT SELECT switch of the tuner timer unit to TUNER.
- 4 Set the timer programme: event number, turn-on day and time, turn-off time and channel. For details, see the TT-F1E instruction manual.

- 5 Press the TIMER REC button so that the red lamp lights.

At the preset turn-on time on the preset day, recording will start automatically and continue to the preset turn-off time or to the tape end, when the recorder will be turned off.

TO OPERATE THE RECORDER OR THE TUNER TIMER UNIT AFTER THE TIMER HAS BEEN SET

Once the TIMER REC button has been pressed, the ON buttons of the tuner timer unit and the recorder will not function. This is to safeguard the timer recording.

To operate the recorder after the timer has been set, press the TIMER REC button again so that the red lamp goes off.

- The timer settings are kept in the memory even if you disengage the TIMER REC button. To restore the setting, press the TIMER REC button again.

WHEN A POWER INTERRUPTION OCCURS


If the clock shows "0:00" of the 1st day and does not advance
all the timer settings have been erased. Reset the clock time and the timer settings.

If the clock still shows the correct time...
the power has been interrupted for less than 10 minutes and the clock has been powered by the self-charging battery built into the tuner timer unit so that the timer programmes were kept in the memory. If the interruption occurs after the recording has begun, recording will be resumed when the power is restored.

1-9. TO OBTAIN VARIABLE SPEED PLAYBACK PICTURES

With this recorder, you can obtain a still, a slow motion, a double speed, a frame-by-frame or a reverse playback picture as well as a normal speed playback picture.

STILL PICTURE




During playback, press the PAUSE button.

To resume normal playback, press the PAUSE button again.

If a noise band appears, press and release the ► or ◀ button a few times until the noise band disappears


SLOW MOTION



1 During playback, press the PAUSE button.

2 Keep the ► or ◀ button depressing: the ► button for forward movement and the ◀ button for reverse movement. When you release the button, a still picture will be obtained. To resume normal playback, press the PAUSE button again.


FRAME-BY-FRAME PLAYBACK



1 During playback, press the PAUSE button.

2 Repeatedly press and release the ► or ◀ button: ► for forward movement and ◀ for reverse movement. To view fast action scenes, use the ► or ◀ button. To resume normal playback, press the PAUSE button again.


DOUBLE SPEED PICTURE



During playback, press the x2 button.

To resume normal playback, press the x2 button again or the ► PLAY button.

REVERSE PLAYBACK



1 During playback, press the PAUSE button.


2 Press the ◀ button. When you release the button, the still picture will be resumed.

For a slow motion picture in reverse playback, use the ◀◀ button.



To resume normal playback, press the PAUSE button again.

If a noise band appears during double speed or reverse playback, turn the TRACKING control until the noise band is removed

● Be sure to return the TRACKING control to the centre position after double speed or reverse viewing.



BACK AND FORTH PLAYBACK



1 During playback, press the PAUSE button.

2 Press and release the ► and ◀ buttons alternately. For slow back and forth playback, use the ►► and ◀◀ buttons.


To resume normal playback, press the PAUSE button again.

1-10. TO LOCATE PARTICULAR SCENES QUICKLY

To reference a recorded programme numerically

TIME COUNTER

The time counter indicates how much the tape has advanced at normal playback speed in hours, minutes and tens of seconds. Before starting recording or playback, press the RESET button to set the counter to "0:00 0" and write the counter readings at the point you want to remember on the label of the cassette. In this way you can easily find those points later.



- The counter reading is automatically reset to zero when the power is turned off.
- When the tape runs in reverse from "0:00 0", a minus sign "-" will be displayed to the left of the figures.

The time counter does not operate with brand-new tapes.

The time counter counts the CTL signals which are generated and recorded at the same time the video signals are recorded. Because brand-new tapes have no CTL signals recorded on them, the time counter cannot operate.



To visually search for a particular point

PICTURE SEARCH

Press the ►► FF or ◀◀ REW button during playback. While the button is depressed, a high-speed playback picture in the forward or reverse direction can be seen. Release the button for normal playback.

- Streaks will appear in the picture search mode.

If the picture rolls vertically during the picture search mode, adjust the vertical hold control on the TV.




To return to a pre-registered point → GO TO ZERO


During recording or playback, press the RESET button at the point you later want to locate.

When the recording or playback is finished, stop the tape by pressing the ■ STOP button, then press the GO TO ZERO button. The tape will rewind or advance to the point where the RESET button was pressed.

- The tape may stop a few seconds before or after 0:00 0.



1-11. IMPORTANT REWINDERS

If the  indication blinks and the recorder does not operate
Moisture has condensed on the drum assembly inside the unit*.
Remove the cassette and leave the recorder turned on until the in-
dication goes off.



If the recorder is powered by a battery pack
It may take considerable time for moisture to evaporate as it must
be done naturally, with the recorder's power off.

To cause moisture to evaporate more quickly
Connect a TT-F1E tuner timer unit or an AC-F1E ac power adaptor
and leave the recorder turned on.
A heater built into the recorder will cause the moisture to evaporate
within 1.5 hours.


*If the recorder is brought directly from a cold to a warm location, moisture
may condense on the drum assembly inside the unit.
This may create a tendency for the tape to adhere to the head drum and both
the tape and the recorder may be damaged.

TO KEEP A RECORDED PROGRAMME FROM BEING ACCIDENTALLY ERASED



When a new recording is made on a previously recorded cassette,
the previous recording will be automatically erased.

To avoid erasing a recording

Break off the safety tab on the bottom of the cassette using a
screwdriver or similar object




To re-record on a cassette which has had the safety tab removed,
cover the slot with a piece of plastic tape



1-12. HOW IS THE PICTURE ON THE SCREEN

Streaks or snow appears

Has the tape been recorded on another video cassette recorder? If so, open the front compartment and adjust the TRACKING control for the best possible picture. Return the control to the center position after viewing a tape recorded on another machine.



Noisy picture

Video-head cleaning may be needed.

After the machine has been used for an extended period of time, the video heads may have become contaminated and require cleaning. Clean the video heads with the L-25CL video head cleaning cassette (optional). For details about cleaning, refer to the instructions furnished with the cleaning cassette.

1-13. DUBBING AUDIO


You can record a music or commentary track on any recorded tape while watching the recorded picture.

CONNECTIONS

To record microphone sound

Connect a microphone to the MIC jack of the video cassette recorder. If your microphone has a phone plug, use the PC-1A plug adaptor (optional).

- The microphone sound will be recorded regardless of the position of the INPUT SELECT switch on the tuner timer unit.




To record from a monaural tape recorder or radio

If you want to connect an audio equipment directly to the recorder, use the VMC-330 video monitor cable (optional)
(For the connection using the tuner timer unit.)

- ① Connect the AUDIO IN cable of the VMC-330 to the output of the audio equipment.
- If the output is a minijack, use a PC-21 plug adaptor.


- ② Connect the 26-pin connector to the ACCESSORY CONNECTOR of the recorder.
- ③ Set the PCM switch on the VMC-330 to OFF and the INPUT SELECT switch to LINE.
- ④ Make sure that a microphone is not connected to the recorder.



To use a tuner timer unit with the recorder, make connections with the RK-50A connecting cord (optional)

- ① Connect the RK-50A to the output of the audio unit.
- If the RK-50A's plug does not match the receptacle, use a commercially-available plug adaptor.

- ② Connect the RK-50A phono plug to the AUDIO IN jack of the tuner timer unit.
- ③ Set the INPUT SELECT switch to LINE.
- The microphone should be disconnected from the recorder.



First, decide at which point on the tape you will start audio dubbing and make the necessary preparations for playing the audio source.

- ❶ Turn on the recorder and insert a cassette.
- Be sure that the safety tab has not been removed.
- ❷ Press the ► PLAY button. Playback will begin.
- ❸ Press the PAUSE button at the point where audio dubbing is to start.
- ❹ Press the AUDIO DUB button.
- ❺ Press the PAUSE button again to start audio dubbing.
- ❻ Start playing the audio source; talking into the microphone, playing the tape recorder, etc.

To stop dubbing,

Press the ■ STOP button.


To stop the tape momentarily during dubbing, use the PAUSE button.

To record from the beginning of the tape


While pressing the AUDIO DUB button, press the ► PLAY button. Audio recording and picture playback will start immediately.

If a whistle-like sound is heard during microphone recording

Point the microphone away from the TV or turn the TV volume down.



You can control almost all functions of the video recorder and the tuner timer unit from your armchair with the RMT-211 remote control unit supplied with the tuner timer unit. For details, refer to the instruction manual of the TT-F1E.




By connecting a PCM digital audio processor, such as a Sony PCM-10, you can enjoy hi-fi sound reproduction with a wide dynamic range, minimal distortion and a flat frequency response. To connect the PCM audio processor directly to the recorder

When a tuner timer unit is used, connect the processor to the VIDEO IN and OUT jacks using BNC-to-phono plug cords.

In any case, be sure to set the PCM switch to ON position and the INPUT SELECT switch to LINE.

For details on operation of this system, see the instruction manual of the PCM processor.



1-14. DISASSEMBLY

Note:

- Follow the disassembly procedure in the numerical order given.
- All screws are Phillips (cross recess) type.

1. CASSETTE COMPARTMENT COVER, UPPER PANEL, BOTTOM PANEL

Unscrew the screws shown in Fig. 1, and remove the upper and bottom panels.




Fig. 1. Panel assembly removal

2. FRONT PANEL

Extract the tracking knob, disengage the right and left hooks (A), and, while holding hooks (B) down with a screwdriver inserted between the circuit board and the front panel, remove the front panel. (Refer to Fig. 2)




Fig. 2. Front panel removal

3. MECHANISM CASSIS

With this set, the mechanism can be completely disengaged from the circuit board.

- 1) Unscrew the screws from the rear side of the MA-3 circuit board.
- 2) Disconnect the connectors. This must be done in order to remove the reel motor, capstan, and the durm.







Fig. 3. Mechanism block removal

1-15. INTERNAL VIEWS



CIRCUIT BOARDS LOCATION




BLOCK DIAGRAM


OVERALL BLOCK DIAGRAM

BLOCK DIAGRAM - OVERALL -


VIDEO CIRCUIT




DRUM SERVO CIRCUIT AND CAPSTAN SERVO CIRCUIT




SYSTEM CONTROL CIRCUIT




REEL SERVO CIRCUIT




POWER SUPPLY CIRCUIT




AUDIO CIRCUIT



REC Y





PB Y




REC CHROMA

PB CHROMA







SYSTEM CONTROL CIRCUIT AND SERVO CIRCUIT INTERFACE

SIGNAL	MODE		Pin No.	STOP	PB	REC	FF	REW	CUE	REV	PB PAUSE	REC PAUSE	THREADING	EJECT	DUB	DUB PAUSE
	I/O															
VD/CTL	I'		CPU2.3 27 Pin (TC) CPU2 4 Pin (R8) CPU3 6 Pin (R10)	---	CTL	VD	CTL	CTL	CTL	CTL	---	TAPE RUNS CTL	---	---	CTL	---
DRM ROT	I'		CPU2 15 Pin (K2)	H	L	L	L	L	L	L	L	L	H	H	L	L
CAP ROT	I'		CPU2 14 Pin (K1)	L	H	H	L	L	H	H	L	L	L	L	H	L
RF SW PLS*2	I'		IC606 (TC4013) 11 Pin IC606 (TC4013) 3 Pin	disappear	appear	appear	appear	appear	appear	appear	appear	appear	disappear	disappear	appear	appear
TAPE SPEED (A)	O	*3	CPU3 33 Pin (O0)													
TAPE SPEED (B)	O		CPU3 34 Pin (O1)													
DRM STOP	O		CPU2 9 Pin (R13)	H	L	L	L	L	L	L	L	L	H	H	L	L
CAP STOP	O		CPU2 8 Pin (R12)	H	L	L	H	H	L	L	L	L	H	H	L	L
VD INT	O		IC603 (MB8747) 12 Pin (P7)	L	H	L	L	L	H	H	H	H	L	L	H	H
REC-PAUSE*4	O		CPU2 44 Pin (R0)	H	H	L*7	H	H	H	H	H	H	H	H	H	H
CUE + REV	O		IC603 (MB8747) 5 Pin (P5)	L	L	L	L	L	H	H	L	L	L	L	L	L
CAP FWD	O		CPU2 10 Pin (R14)	H*5	H	H	H	L	H	L	*6	*6	H*5	H*5	H	H

- * 1 "L" during capstan servo unlocked, "H" locked
- * 2 30 Hz, 50% duty ratio pulse
- * 3 3 bit binary coded tape speed
- * 4 latched output by flip-flop, clock pulses for the flip-flop are rf sw pulses.
- * 5 no use in this mode
- * 6 "H" when tape runs forward, "L" when tape runs reverse, holds the previous level in stop mode
- * 7 "H" while counting 12 CTL after record pause mode, since then "L"
- * 8 holds the previous level
- * 9 when in record-review mode

SYSTEM CONTROL CIRCUIT AND VIDEO CIRCUIT INTERFACE

SIGNAL	MODE		Pin No.	STOP	PB	REC	FF	REW	CUE	REV	PB PAUSE	REC PAUSE	THREADING	EJECT	DUB	DUB PAUSE
	I/O															
OVER REC	O		IC603 (MB8747) 13 Pin (P8)	H	H	H*1	H	H	H	H	H	H	H	H	H	H
PB + DUB	O		IC2 (MB8747) 16 Pin (P11)	L	H	L	L	L	H	H	H	*10 L	L	L	H	H
VMUTE*2	O		CPU1 34 Pin (O1)	L	L*3	L	L	L	L	L	L	L	L	L	L*3	L
REC-PAUSE*4	O		CPU2 44 Pin (R0)	H	H	L*7	H	H	H	H	H	H	H	H	H	H
MC	O		IC603 (MB8747) 1 Pin (P1)	L	L	L	L	L	H	H	H	*11 L	L	L	L	H
9V CONT	O		CPU1 10 Pin (R11)	L*5	L	L	L	L	L	L	L	L	L	L	L	L
RF CONT	O		IC2 (MB8747) 13 Pin (P8)	H*6	H	H*6	H*6	H*6	H	H	H	H*6	H*6	H*6	H	H
CAME CONT*8	O		IC2 (MB8747) 14 Pin (P9)	H*9	H	H	H*9	H*9	H	H	H	H*9	H*9	H*9	H	H

- * 1 "L" is appear during 12 sec in strong signal recording for splicing
- * 2 "H" when no CTL period become 0.5 sec, the CTLs are detected during more than 0.5 sec, the level changed
- * 3 "H" is held during 3 second when in playback mode or in dubbing mode after stop mode
- * 4 output latched by flip-flop, the clock signal for the flip-flop, is rf sw pulse
- * 5 "H" during battery operate
- * 6 "L" during battery operate, "H" when in record-review mode or record/playback after releasing record pause
- * 7 "H" is held during 12 CTL in record mode after releasing record pause, since then "L"
- * 8 "L" except for camera mode
- * 9 "L" when camera mode and battery operate
- * 10 "H" during record-review mode
- * 11 "H" during record-review mode

SYSTEM CONTROL CIRCUIT AND REEL MOTOR CIRCUIT INTERFACE

SYSTEM CONTROL CIRCUIT AND TUNERTIMER CIRCUIT POWER SUPPLY CIRCUIT INTERFACE

SIGNAL	MODE		Pin No.	STOP	PB	REC	FF	REW	CUE	REV	PB PAUSE	REC PAUSE	THREADING	EJECT	DUB	DUB PAUSE	MODE	SIGNAL
	I/O																	
T FG	I		CPU2 5 Pin (R9)							*1								POWER SW (A)**
S FG	I		CPU2 6 Pin (R10)							*1								POWER SW (B)**
SLACK	I		CPU2 13 Pin (K0)				"H": NORMALITY "L": ABNORMALITY	"H": NORMALITY "L": ABNORMALITY										REC REVIEW**
BRK DOWN*2	O		CPU2 32 Pin (P3)	L	L	L	L	L	L	L	L	L	L	L	L	L		CAMERA PAUSE**
T END*6	O		IC610 () 4 Pin															CAMERA**
T LOCK	O		IC603 (MB8747) 14 Pin (P9)	L	L	L	L	L	L	L	L	L	H	H	L	L		REMOCON**
R FF	O		IC603 (MB8747) 16 Pin (P11)	L	L	L	H	L	L	L	L	L	L	L	L	L		TALLY**
R REW	O		IC603 (MB8747) 17 Pin (P12)	L	L	L	L	H	L	L	L	L	L	L	L	L		REC READY
R COM A	O		CPU2 28 Pin (P0)	*3	L	L	L	H	L	H	L*4	L*5	L	L	L	L*3		TIMER REC
R COM B	O		CPU2 29 Pin (P1)	*3	L	L	H	H	L	L	L	L	H	H	L	L*3		PB + DUB
R COM C	O		CPU2 31 Pin (P2)	*3	L	L	L	L	H	H	L	L*5	H	H	L	L*3		BATT OPERATE**
T REEL	O		CPU2 33 Pin (O0)	H	L	L	L	H	L	L	L	L	L	L	L	L		POWER ON*
S REEL	O		CPU2 34 Pin (O1)	H	L	L	H	L	L	L	L	L	L	L	L	L		POWER OFF**
T THREAD	O		CPU3 44 Pin (R0)	H	H	H	H	H	H	H	H	H	L	H	H	H		

- * 1 numbers of pulse equal to numbers of reel revolution multiplied 60
- * 2 changing signal for electrical brake
- * 3 no use in this mode
- * 4 "H" when tape runs reverse in SWING SEARCH mode
- * 5 "H" when in record-review mode
- * 6 "H" at tape end

SYSTEM CONTROL CIRCUIT AND SLOW PLAY CONTROL CIRCUIT INTERFACE

SYSTEM CONTROL CIRCUIT AND AUDIO CIRCUIT INTERFACE

SIGNAL	MODE		Pin No.	STOP	PB	REC	FF	REW	CUE	REV	PB PAUSE	REC PAUSE	THREADING	EJECT	DUB	DUB PAUSE	MODE	SIGNAL
	I/O																	
AUDIO PB*2	O		FC3-36 IC2 (MB8747) 15 Pin (P10)	L	H	L	L	L	H	H	H*1	*8 L	L	L	L	L		CAP FWD
DUB	O		FC3-35 IC2 (MB8747) 12 Pin (P7)	L*3	L	L	L	L	L	L	L	L	L	L	H	H		CAP REV
BIAS CONT	O		FC3-34 IC2 (MB8747) 17 Pin (P12)	L	L	H*4	L	L	L	L	L	L	L	L	H*5	L		FWD SLOW
A MUTE*6	O		FC3-37 CPU1 33 Pin (O0)	H	L*7	H	H	H	H	H	H	H	H	H	H	H		REV SLOW

- * 1 includes double speed play and SWING SEARCH play
- * 2 level is changed after 40 msec delay
- * 3 "H" is held during 150 msec in stop mode after dubbing, "H" since then "L"
- * 4 "L" is held during 12 CTL in record mode after record pause mode, since then "H"
- * 5 "L" is held during 50 msec in dubbing mode after stop mode, since then "H"
- * 6 "H" when no CTL period become 0.5 sec, the CTLs are detected during more than 0.5 sec, the level is changed
- * 7 "H" is held during 3 sec in playback mode after stop/FF and is held during 0.5 sec, since then "L"
- * 8 when in record-review mode
- * 9 "H" is held during 0.5 sec in record mode after record-review mode, since then "L"

SYSTEM CONTROL CIRCUIT AND TUNER/TIMER CIRCUIT, POWER SUPPLY CIRCUIT INTERFACE

SIGNAL	MODE		Pin No.	STOP	PB	REC	FF	REW	CUE	REV	PB PAUSE	REC PAUSE	THREADING	EJECT	DUB	DUB PAUSE
	I/O															
POWER SW (A)*1	I															
POWER SW (B)*1	O															
REC REVIEW*2	I		CPU1 1 Pin (R5)													
CAMERA PAUSE*3	I		CPU1 2 Pin (R6)													
CAMERA*4	I		CPU1 3 Pin (R7)													
REMOCON*5	I		CPU1 4 Pin (R8)													
TALLY*6	O		CPU1 35 Pin (O2)	H	L*7	L	H	H	H	H	H	*9 H	H	H	L	H
REC READY	O		CPU1 36 Pin (O3)										H	L	L	L
TIMER REC	I		CPU1 48 Pin (R4)										H	L	L	L
PB + DUB	O		IC2 (MB8747) 16 Pin (P11)	L	H	L	L	L	H	H	H	L	L	H	H	H
BATT OPERATE*8	I		CPU1 12 Pin (R15)													
POWER ON*1	O															
POWER OFF*1	O		CPU2 7 Pin (R11)													

*1 power on/off signal during battery operate or ac adaptor operate
 *2 "H" when RECORD REVIEW button is depressed
 *3 "H" when PAUSE button of the camera is depressed
 *4 "L" when in camera mode
 *5 SONY's infrared remote control system serial data from remote control CPU to system control CPU
 *6 TALLY will wink 1 Hz 5% duty ratio when become poor charge voltage of the battery
 *7 includes double speed mode
 *8 "H" during battery operate
 *9 "L" when in record-review mode

SYSTEM CONTROL CIRCUIT AND SLOW PLAY CONTROL CIRCUIT INTERFACE

SIGNAL	MODE		Pin No.	STOP	PB	REC	FF	REW	CUE	REV	PB PAUSE	REC PAUSE	THREADING	EJECT	DUB	DUB PAUSE
	I/O															
CAP FWD	O		FC3-27 CPU2 10 Pin (R14)	H*1	H	H	H	L	H	L	*2	*2	H*1	H*1	H	H
RVN	O		FC3-28 IC603 (MB8747) 3 Pin (P3)	L	L	L	L	L	L	L	L	*6 L	L	L	L	L
SLOW	O		FC3-24 IC603 (MB8747) 2 Pin (P2)	L	L	L	L	L	L	L	H*3	*7 H	L	L	L	H
FWD SLOW	O		FCS-26 CPU2 2 Pin (R6)	L	L	L	L	L	L	L	L*4	L	L	L	L	L
RVS SLOW	O		FCS-25 CPU2 3 Pin (R7)	L	L	L	L	L	L	L	L*5	L	L	L	L	L


*1 no use in this mode
 *2 "H" when tape runs forward, "L" when tape runs reverse, holds previous level in stop mode
 *3 "L" when tape runs normal speed forward or normal speed reverse
 *4 "H" when in forward slow motion
 *5 "H" when in reverse slow motion
 *6 "H" when in record-review mode
 *7 "L" when in record-review mode

SYSTEM CONTROL CIRCUIT AND MECHANISM BLOCK INTERFACE


SIGNAL	MODE		Pin No.
		I/O	
BRAKE PLUNGER ON* ¹	O		CN601-3
BRAKE PLUNGER OFF* ¹	O		CN601-1
PINCH PLUNGER ON* ¹	O		CN602-1
PINCH PLUNGER OFF* ¹	O		CN602-3
THREADING MOTOR (+)* ¹	O		CN603-1
THREADING MOTOR (-)* ¹	O		CN603-2
REC PROOF SW (A)* ²	I		CN604-3 CPU3 16 Pin (K3)
REC PROOF SW (B)* ²	O		CN604-4 CPU3 29 Pin (P1)
CASSETTE IN SW (A)* ²	I		CN604-1 CPU3 13 Pin (K0)
CASSETTE IN SW (B)* ²	O		CN604-2 CPU3 29 Pin (P1)
DEW SENSOR (+)* ³	I		CN606-1 IC608 (μPC339C) 6 Pin
THREADING END SW (A)* ²	I		CN607-1 CPU3 16 Pin (K3)
THREADING END SW (B)* ²	O		CN607-2 CPU3 32 Pin (P3)
UNTHREADING END SW (A)* ²	I		CN607-3 CPU3 16 Pin (K3)
UNTHREADING END SW (B)* ²	O		CN607-4 CPU3 31 Pin (P2)
S SENSOR OUT* ⁴	I		CN608-2 IC607 7 Pin
T SENSOR OUT* ⁵	I		CN609-2 IC607 3 Pin

- * 1 control signal for brake solenoid, pinch roller solenoid and threading motor
- * 2 key matrix signal
- * 3 when detecting dew
- * 4 osc freq 600 kHz at tape end
- * 5 osc freq 600 kHz at tape end


MA BOARD REEL BLOCK




CAPSTAN PHASE CONTROL SYSTEM TIMING CHART (RECORD MODE)



CAPSTAN PHASE CONTROL SYSTEM TIMING CHART (PLAYBACK MODE)




CAPSTAN SPEED CONTROL SYSTEM TIMING CHART





DRUM PHASE SYSTEM TIMING CHART

UM SPEED SYSTEM TIMING CHART




INSTRUMENTATION COUNTER TIMING CHART






INSTRUMENTATION PERIOD PRODUCE TIMING CHART




FG CIRCUIT TIMING CHART




PG-A, PG-B, PG-S TIMING CHART

TRAH3 2NIM3I 07




PG-A, PG-S TIMING CHART (RECORDING MODE & PLAYBACK MODE)




SERVO AMP TIMING CHART

TRAH3 2NIM3I 07



CTL CIRCUIT OF IC409 TIMING CHART

SERVO AMP TIMING CHART



VARIABLE SPEED PLAYBACK CIRCUIT TIMING CHART CHART-1







CHART-2






AUDIO LEVEL DIAGRAM
RECORD AMP

PLAYBACK AMP



PLA YBACK AMP

EL DIAGRAM



SECTION 3 PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM

FRAME SCHEMATIC DIAGRAM


SEMICONDUCTOR

BX-1013	BX-3971	BX-1021	BX-1023	BX-1024	BX-1026	BX-1027	BX-1028
BX-1022	BX-3976	BX-1029	BX-1030	BX-1032	BX-1033	BX-1034	BX-1035
BX-1025	BX-3977	BX-1048	BX-3973	BX-3980	BX-3999	BX-3999-1	CX-194A
BX-1036	BX-3978	BX-1048A	BX-3980	BX-3999-1	CX-7906	CX-7926	CX-20008
BX-1045	BX-3982-2						
BX-1047	BX-3983						



MB8855-139	TC40H004P	TC4069UBP	TC4051BP
MB8855-140	TC4001BP	TC4081BP	TC4052BP
MB8855-161	TC4013BP	μPC324C	TC4053BP
	TC4030BP	μPC339C	TL494CN

μPC78L05A	μPC393C	2SA881	2SA1027R
2SC2021	2SC2673	2SA1115	2SA1175
2SC2785	2SD773	2SD786	2SD1164
EA0A0206A85	RD13E-B	U05G	10E-2
RD2.7E-B	RD18E-B	U05E	
RD3.0E-B	RD22E-B		
RD3.6E-B	1SS106		
RD6.2E-B	1SS119		
RD9.1E-B	1SS133		

The components identified by shading and ⚠ mark are critical for safety. Replace only with part number specified.




REC/PB AMP (REC & PB AMP) SF-5 SF-3 (VIDEO PROCESS) VIDEO VIDEO SF-6 (VIDEO PROCESS) VIDEO VIDEO - Ref. No. SF-5, SL-3 BOARD: 3000 series -



SF-5 BOARD

Q, IC	2	2	IC6	6	IC7	7	IC3	IC8	5	IC10	IC9	3	4	IC4	Q, IC
D	2	2	4	4	4	4	4	4	4	4	4	4	4	4	D
ADJ			CV1	RV12	RV11	LVI	RV13	RV17	RV3	RV4	RV7	RV2	3	5	ADJ
			RV16	RV14	RV15	RV1	RV5	RV6	RV8	RV9	RV10				





SL-3 BOARD



The components identified by shading and Δ mark are critical for safety. Replace only with part number specified.

SF-6 BOARD











- NOTES:**
- All resistors are in ohms, 1/BW unless otherwise noted. kΩ = 1000Ω; MΩ = 1000kΩ
 - All capacitors are in μF unless otherwise noted. p : μF 50WV or less are not indicated except for electrolytics.
 - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
 - ⚡ : nonflammable resistor.
 - The red lines show the main voltages.
 - Marked * is not able to measure the voltage of its position.
 - All voltages are dc measured with a DMT (1MΩ/V).

The components identified by shading and ⚡ mark are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.



1
2
3
4
5



- NOTES:**
- All resistors are in ohms, 1/8W unless otherwise noted. k Ω = 1000 Ω ; M Ω = 1000k Ω
 - All capacitors are in μ F unless otherwise noted. p : μ F 50WV or less are not indicated except for electrolytics.
 - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
 - : nonflammable resistor.
 - The red lines show the main voltages.
 - Marked * is not able to measure the voltage of its position.
 - All voltages are dc measured with a DMT (1M Ω /V).

The components identified by shading and Δ mark are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.


1

2


3

4




5



MA-3 BOARD (I/4)



BHF-1800A BOARD



REF	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	COLLECTOR	COLLECTOR
FWD	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
REVERSE	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
CUE	4.8	0	0	0.6	0.8	0.9	0.9	1.8	0.9	0.8	1.3	1.3	0.8	1.9	1.3	0.4	4.8	0.7	2.2	
REV	4.8	0	0	0.6	0.8	0.8	1.3	1.8	0.9	0.4	1.3	1.3	2.3	1.9	1.3	0.4	2.3	2.4	4.5	
FF	0	0	0	0.6	1.7	0.8	1.7	1.8	4.8	1.6	1.3	2.0	0	1.9	1.3	1.6	4.8	3.1	10.2	
REW	0	0	0	0.6	1.9	0.8	0	1.8	4.8	1.6	1.3	2.0	1.9	1.3	0.6	4.8	10.2	3.6		

- NOTES:**
- All resistors are in ohms, 1/8W unless otherwise noted. kΩ = 1000Ω; MΩ = 1000kΩ
 - All capacitors are in μF unless otherwise noted. p : μF 50WV or less are not indicated except for electrolytics.
 - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
 - Ⓜ : nonflammable resistor.
 - The red lines show the main voltages.
 - Marked * is not able to measure the voltage of its position.
 - All voltages are dc measured with a DMT (1MΩ/V).

The components identified by shading and ⚠ mark are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

FR-4 (SYSTEM CONTROL) CPU-1
- Ref. No. 4000 series -

MA-3 (SYSTEM CONTROL) CPU-1, CPU-2
- Ref. No. 1000 series -

LM-8 (MOTOR FILTER) - Ref. No. 6000 series -

LM-10 (MOTOR RESISTOR) - Ref. No. 7000 series -


SYSTEM CONTROL

SYSTEM CONTROL


BHF-1800A (REEL MOTOR DRIVE) - Ref. No. 1000 series -

MA-3 (REEL MOTOR DRIVE) - Ref. No. 1000 series -

MA-3 (SYSTEM CONTROL) BOARD



LM-8 BOARD





LM-10 BOARD



FR-4 BOARD

Q, IC	6 ¹¹ 2 ⁸	10	IC2	17	9 ¹⁸ 12	IC1	7	14 ⁴ 15	3	Q, IC		
D	27 ²¹ 25	36	23	26	24	16 5 9 8 7 6	11,10,12,13	18	19,15,14,2	17	22 ¹	D
ADJ										RV1	29	ADJ



- NOTES:**
- All resistors are in ohms, 1/8W unless otherwise noted. kΩ = 1000Ω; MΩ = 1000kΩ
 - All capacitors are in μF unless otherwise noted. p : μμF 50WV or less are not indicated except for electrolytics.
 - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
 - : nonflammable resistor.
 - The red lines show the main voltages.
 - Marked * is not able to measure the voltage of it's position.
 - All voltages are dc measured with a DMT (1MΩ/V).

The components identified by shading and mark are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

The components identified by shading and mark are critical for safety. Replace only with part number specified.



When indicating parts by reference number, please include the board name.

MA-3 (REEL MOTOR DRIVE)
- Ref. No. 1000 series -

BHF-1800A (REEL MOTOR)
- Ref. No. 1000 series -

L2-8


MA-3



- NOTES:
- All resistors are in ohms, 1/8W unless otherwise noted.
kΩ = 1000Ω; MΩ = 1000kΩ
 - All capacitors are in pF unless otherwise noted.
p: 100pF or less are not indicated except for electrolytic
 - All variable and adjustable resistors have characteristic curve B unless otherwise noted.
 - ⊗: nonflammable resistor.
 - The red lines show the main voltage.
 - Marked * is not able to measure the voltage of it's position.
 - All voltages are dc measured with a DMM (1MΩV).

The components identified by shading and Δ mark are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.



LS-8 BOARD

Q, IC	001	IC001	010	004	005	003	IC004	011	IC003	008	208	207	206	IC202	202	204	203	IC201	IC204	Q, IC
D	001	RV001, LV001	CV001, LV002	002	006	003	RV002	RV003	005, 004	200	211	210	206	201	RV205	RV202	RV203	207	D	
ADJ											RV209	RV211	RV210							ADJ

EH-3 BOARD

I-607-162-11

LS-8 (AUDIO) BOARD

60kHz

200Vp-p

TP-6 REC

A B C D E F G H I J K


1

2

3

4

5



- NOTES:**
- All resistors are in ohms, 1/8W unless otherwise noted. kΩ = 1000Ω; MΩ = 1000kΩ
 - All capacitors are in μF unless otherwise noted. p : μμF 50WV or less are not indicated except for electrolytics.
 - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
 - : nonflammable resistor.
 - The red lines show the main voltages.
 - Marked * is not able to measure the voltage of it's position.
 - All voltages are dc measured with a DMT (1MΩ/V).

The components identified by shading and ⚠ mark are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.


SECTION 4 EXPLODED VIEWS

NOTE:

- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- As to the part numbered with E-, refer to the electrical parts list.
- Items marked "▲" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.


The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

(1) FRONT PANEL ASSEMBLY




No.	Part No	Description	Remark	No.	Part No	Description	Remark
1	X-3672-306-0	CABINET ASSY, FRONT	2---18,31,32	17	3-669-611-00	ARM (E), BOTTOM	
2	X-3669-337-0	BUTTON ASSY, PW		18	3-669-497-00	BUTTON, LCD	
3	X-3669-338-0	BUTTON ASSY, EJ		19	A-6703-195-A	PANEL ASSY, FRONT	
4	3-669-492-00	BUTTON (A), F		20	1-507-251-XX	JACK	
5	3-669-553-11	PANEL, SUB, FRONT		21	▲:1-607-162-00	EH-3 BOARD	
6	3-669-662-00	CAP (A), BUTTON		22	3-669-511-00	KNOB, TRACK CONTROL	
7	3-669-495-00	SLIDER, SWITCH		23	X-3669-339-0	BUTTON ASSY, REW	
8	▲:3-669-498-00	SHAFT (A)		24	X-3669-340-0	BUTTON ASSY, PLAY	
9	▲:3-669-499-00	SHAFT (B)		25	X-3669-341-0	BUTTON ASSY, FF	
10	▲:3-669-500-00	SHAFT (C)		26	X-3669-342-0	BUTTON ASSY, REC	
11	▲:3-669-501-00	ARM (A), BUTTON		27	3-669-563-00	BUTTON, STOP	
12	▲:3-669-502-00	ARM (B), BUTTON		28	3-669-554-00	BUTTON (B), F	
13	▲:3-669-503-00	ARM (C), BUTTON		29	X-3669-343-0	BUTTON ASSY, PD	
14	▲:3-669-504-00	ARM (D), BUTTON		30	X-3669-348-0	BUTTON ASSY, PAUSE	
15	3-669-512-00	SPRING, LEAF		31	3-669-661-00	COVER, LED	
16	3-669-529-00	KNOB, SLIDE SWITCH		32	3-672-520-00	BUTTON (C), F	

(2) UPPER PANEL ASSEMBLY




No.	Part No	Description	Remark	No.	Part No	Description	Remark
51	X-3672-304-0	CABINET (UPPER) ASSY		58	3-669-517-41	LID, BATTERY CASE	
52	X-3669-349-0	BRACKET ASSY, HANDLE	52---60,63	59	♣:3-669-521-00	SHAFT (B)	
53	X-3669-362-0	CASE ASSY, BATTERY	54,55,56,57	60	3-669-592-00	SPRING (A), TORSION	
54	X-3669-361-0	LOCK BLOCK ASSY, BATTERY	55	61	X-3672-303-0	COVER ASSY	
55	3-559-408-00	POLY-WASHER, 1.2 DIA		62	3-669-403-00	SCREW, ORNAMENTAL	
56	3-672-532-00	TERMINAL (A)		63	♣:3-672-329-00	INSULATOR (B)	
57	3-669-594-00	SPRING, COMPRESSION					

(3) LOWER PANEL ASSEMBLY




No.	Part No	Description	Remark	No.	Part No	Description	Remark
101	X-3672-305-0	CABINET (LOWER) ASSY	102,103	104	3-672-313-02	PANEL, REAR	
102	3-669-527-00	LEG, RUBBER		105	X-3672-302-0	LID ASSY, PANEL, CONNECTOR	
103	3-669-518-00	NUT, CABINET		106	3-672-302-00	LABEL, MODEL NUMBER (AEP)	

(4) MAIN BOARD ASSEMBLY




No.	Part No	Description	Remark	No.	Part No	Description	Remark
151	♣:A-6715-140-A	MA-3 BOARD, COMPLETE		165	♣:3-672-320-00	CASE (E), SHIELD	
152	♣:A-6717-251-A	FR-4 BOARD, COMPLETE		166	♣:X-3669-367-0	LID ASSY, REAR, SHIELD CASE	
153	♣:A-6713-123-A	LS-8 BOARD, COMPLETE		167	♣:X-3669-372-0	PLATE ASSY, REAR, SHIELD CASE	
154	♣:A-6711-326-A	SF-5 BOARD, COMPLETE		168	♣:X-3669-373-0	CASE (MAIN) ASSY, SHIELD, MA-S	
155	3-669-570-31	PANEL, ORNAMENTAL, CONNECTOR		169	♣:3-669-610-00	SPACER	
156	1-561-690-00	CONNECTOR, CAMERA 14P		170	1-605-077-00	FC-1 BOARD	
157	1-507-285-00	JACK		171	1-605-078-00	FC-3 BOARD	
158	♣:3-669-513-00	SPACER, MICROPHONE JACK		172	♣:3-669-565-00	HINGE (FR), CHASSIS	
159	♣:3-672-310-00	FOOT (LEFT), SF		173	♣:3-369-582-00	HINGE (MA), PC BOARD	
160	♣:3-672-311-00	FOOT (RIGHT), SF		174	1-548-562-00	COUNTER MODULE, TAPE	
161	1-561-684-00	CONNECTOR, RECEPTACLE, 26P		175	1-464-186-00	RP BLOCK (RP-1-P-2)	
162	♣:1-561-717-00	CONNECTOR, 5P		176	1-427-521-00	TRANSFORMER	
163	♣:1-606-731-00	SL-3 BOARD		177	♣:1-606-730-00	SF-6 BOARD	
164	♣:3-672-321-00	CASE (D), SHIELD					

(6) THREADING MOTOR AND ACE HEAD ASSEMBLY




No.	Part No	Description	Remark	No.	Part No	Description	Remark
251	A-6761-045-A	ACE ASSY (M-3)	254---257	261	3-669-328-02	PULLEY, GEAR	
252	3-669-480-00	+ PTPWH 2		262	3-669-332-00	GEAR (BA)	
253	3-669-318-00	NUT, ADJUSTMENT, GUIDE		263	X-3669-324-3	CHASSIS ASSY, MOTOR, L	
254	♣:3-669-537-00	SLOPE (LEFT)		264	X-3669-321-0	GEAR (C) ASSY	
255	♣:3-669-541-00	SLOPE (RIGHT)		265	3-669-333-00	GEAR (BC)	
256	♣:3-669-316-00	SPRING, COMPRESSION		266	♣:1-605-664-00	LM-10 BOARD	
257	3-669-598-00	WASHER, CTL		267	A-6737-090-A	MOTOR ASSY, L	
258	3-669-317-00	SPRING, COMPRESSION		268	♣:1-605-071-00	LM-8 BOARD	
259	3-669-327-00	BELT, RUBBER		269	♣:3-669-613-00	INSULATOR, L MOTOR	
260	3-669-465-00	WASHER (1.5), STOPPER					

(7) LOCK ARM AND TP ASSEMBLY




No.	Part No	Description	Remark	No.	Part No	Description	Remark
301	A-6742-032-A	TP ASSY	303,304	305	3-531-860-00	SPRING, TENSION	
302	X-3669-351-0	ARM ASSY, LOCK		306	1-552-664-00	SWITCH, MICRO	
303	3-669-465-00	WASHER (1.5), STOPPER		307	3-669-607-00	+PSW (SMALL ROUND) 2.6	
304	1-235-054-00	COIL, SENSOR, S		308	▲:3-669-354-00	BRACKET, SWITCH, LE	

(8) ULE SWITCH AND SHUTTLE GUIDE ASSEMBLY



No.	Part No	Description	Remark	No.	Part No	Description	Remark
351	3-669-480-11	+ PTPWH 2		364	8-825-508-10	HEAD, FE	
352	▲:3-669-621-00	PLATE, GROUND, TAPE GUIDE		365	▲:X-3669-313-0	BASE ASSY, SLANT	
353	▲:3-669-618-00	PLATE (2), ADJUST		366	▲:3-669-477-00	LINER, LINK, PIN	
354	▲:3-672-507-00	PLATE (3-1), ADJUSTMENT		367	▲:3-669-465-00	WASHER (1.5), STOPPER	
355	3-669-466-00	SCREW (M 2.6)		368	3-669-597-00	ROLLER (B), RING	
356	▲:3-669-584-00	GUIDE (1), SHUTTLE		369	3-669-630-00	ROLLER (C), RING	
357	X-3669-327-0	ARM ASSY, SWITCH, ULE		370	3-669-607-11	+PSW (SMALL ROUND) (2.6)	
358	▲:3-669-585-00	GUIDE (2), SHUTTLE		371	▲:3-669-355-00	HOLDER, SWITCH, ULE	
359	3-669-606-00	SCREW (2.6)		372	1-553-718-00	SWITCH, MICRO	
360	3-669-446-00	NUT, GUIDE, NO. 6		373	▲:X-3669-329-0	PLATE ASSY, ADJUSTMENT	
361	3-669-447-00	FLANGE, GUIDE, NO. 6		374	3-669-360-00	ROLLER, RING	
362	3-669-445-00	SPACER, GUIDE, NO. 6		375	▲:3-669-476-04	PLATE, GUIDE	
363	3-669-615-00	SPRING, COMPRESSION		376	▲:3-669-484-00	BRACKET, OPEN, LID	


(9) PINCH ROLLER SOLENOID ASSEMBLY



No.	Part No	Description	Remark	No.	Part No	Description	Remark
401	▲A-6749-058-A	SOLENOID BLOCK ASSY, PINCH	402,404,415	409	3-669-480-11	+ PTPWH 2	
402	X-3669-365-0	ARM ASSY, PINCH SOLENOID	404	410	1-235-055-00	COIL SENSOR, T	
403	3-669-465-00	WASHER (1.5), STOPPER		411	3-669-595-00	WASHER (2), STOPPER	
404	3-669-440-00	SPRING, TENSION		412	3-465-159-XX	SPRING, TENSION	
405	3-669-607-11	+PSW (SMALL ROUND) (2.6)		413	3-669-596-00	WASHER (2.3), STOPPER	
406	▲:3-669-462-00	PLATE, ADJUSTMENT, LIMITER, PINCH		414	▲:X-3669-309-4	ARM ASSY, PRESS, PINCH	
407	▲:3-669-349-00	PLATE, LOCK, T		415	▲:3-669-459-00	BRACKET, SOLENOID	
408	▲:X-3669-379-0	ARM (P) ASSY, PINCH LIMITER	412	416	▲:3-669-612-00	CLAMP (A), HARNESS	


The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

(10) DRUM ASSEMBLY



No.	Part No	Description	Remark	No.	Part No	Description	Remark
451	1-806-354-00	SENSOR, DEW CONDENSATION		459	X-3669-106-1	DAMPER ASSY	
452	▲:X-3669-381-0	STAY ASSY		460	A-6760-064-B	DRUM UPPER ASSY	
453	▲:X-3669-380-0	COVER ASSY, HEATER		461	A-6762-073-A	DISK ASSY, DSR-22	
454	1-446-961-00	HEATER, PTC		462	▲:X-3669-105-1	SPACER BLOCK ASSY	
455	3-669-600-11	WASHER, FLAT (3.5)		463	X-2621-204-0	STATOR ASSY, DRUM	
456	3-429-123-00	SPRING		464	X-2621-202-0	ROTATOR ASSY, DRUM	
457	3-669-302-00	SCREW, FITTING		465	▲:3-669-646-00	SPACER, DRUM	
458	A-6050-128-A	DSH-22A-C		466	▲:3-669-646-11	SPACER, DRUM	


(11) DRIVE GEAR AND T SLIDER ASSEMBLY



No.	Part No	Description	Remark	No.	Part No	Description	Remark
501	3-669-465-00	WASHER (1.5), STOPPER		510	3-669-443-00	BEARING, BALL (NO FLANGE)	
502	X-3669-326-0	CHASSIS ASSY, GEAR, DRIVE		511	3-669-438-00	ROLLER, GUIDE	
503	X-3669-305-0	GEAR (F) ASSY		512	3-657-841-31	SPACER (DIA. 2)	
504	3-669-338-00	GEAR (E)		513	3-669-432-00	FLANGE (LOWER), GUIDE	
505	3-669-337-00	GEAR (D)		514	3-669-452-00	SPRING, COMPRESSION	
506	3-669-596-00	WASHER (2.3), STOPPER		515	3-669-607-31	+PSW (SMALL ROUND) (2.6)	
507	X-3669-307-6	ARM ASSY, PINCH ROLLER		516	♣:3-669-350-00	STOPPER, SLIDER	
508	3-669-444-00	SPRING, TORSION		517	♣:X-3669-350-0	GEAR ASSY, SLIDER	
509	3-669-431-00	FLANGE (UPPER), GUIDE		518	3-701-439-01	WASHER	


(12) THREADING RING ASSEMBLY

(11) DRIVE GEAR AND T-SLIDER ASSEMBLY



No.	Part No	Description	Remark	No.	Part No	Description	Remark
551	X-3669-353-0	RING ASSY, THREADING, S		563	3-657-841-31	SPACER (DIA. 2)	
552	X-3669-303-0	GUIDE ASSY, NO. 2	552,560	564	3-669-667-00	FLANGE (LOWER), GUIDE	
553	3-669-473-00	SPRING, TENSION		565	3-669-666-00	SPRING, COMPRESSION	
554	3-669-478-00	SCREW (1X3), TAPPING		566	3-669-431-00	FLANGE (UPPER), GUIDE	
555	3-669-479-11	SCREW (1.4X3.5), TAPPING		567	X-3669-316-0	ROD ASSY, PUSH	
556	3-669-472-00	RETAINER, SPRING, LEAF		568	3-669-643-00	SLEEVE, GUIDE, NO. 4	
557	3-669-470-00	SPRING (2), LEAF		569	X-3669-314-0	PLATE ASSY, SHUTTLE	
558	3-669-471-00	SPRING (3), LEAF, LIMITER		570	X-3669-315-0	HEAD ASSY, TILT	
559	3-669-616-00	RETAINER		571	3-669-540-00	BLOCK, SHUTTLE	
560	X-3669-304-0	GUIDE ASSY, NO. 3		572	3-672-531-00	SPRING, COMPRESSION	
561	3-669-443-00	BEARING, BALL (NO FLANGE)		573	3-701-437-11	WASHER	
562	3-669-668-00	ROLLER, GUIDE					


(13) CAPSTAN MOTOR ASSEMBLY



No.	Part No	Description	Remark	No.	Part No	Description	Remark
601	8-838-021-03	MOTOR, DC		608	3-669-305-00	BUSHING	
602	3-669-633-00	SCREW, + PW2		609	▲:3-669-303-00	BRAKE, T	
603	3-669-602-00	SPRING, COMPRESSION		610	8-838-027-01	MOTOR, DC (BHF-1901A)	
604	▲:1-454-281-00	SOLENOID, PLUNGER		611	3-669-697-00	SPACER, CAPSTAN	
605	▲:3-669-530-00	ARM, BRAKE		612	3-669-663-00	+PSW 2.6	
606	▲:3-669-304-00	BRAKE, S		613	3-672-533-00	STUD	
607	3-491-360-00	SPRING, TENSION					


The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

(14) CASSETTE COMPARTMENT LOCK ASSEMBLY



No.	Part No	Description	Remark	No.	Part No	Description	Remark
651	▲:X-3669-323-0	MR ASSY	672	663	3-570-896-00	SPRING, TENSION	
652	1-553-717-00	SWITCH, MICRO		664	▲:X-3669-320-0	LEVER ASSY, CI	
653	3-669-480-11	+ PTPWH 2		665	3-489-310-XX	SPRING, TENSION	
654	3-669-595-00	WASHER (2), STOPPER		666	:X-3669-377-0	LEVER ASSY, LOCK	
655	3-701-438-21	WASHER		667	3-669-596-00	WASHER (2.3), STOPPER	
656	▲:X-3669-331-0	LEVER ASSY, RELEASE		668	3-509-123-00	SPRING, TENSION	
657	3-669-465-00	WASHER (1.5), STOPPER		669	▲:3-669-414-00	LEVER, HOLDING, IL	
658	▲:X-3669-378-0	CHASSIS ASSY, LOCK		670	3-480-160-XX	SPRING, TENSION	
659	1-553-718-00	SWITCH, MICRO		671	▲:3-669-670-00	LEVER, LOCK, L	
660	▲:3-669-422-00	HOLDER, MICRO SWITCH		672	▲:3-669-411-00	SPRING, TENSION	
661	▲:X-3669-376-0	PLATE ASSY, SLIDE, RELEASE		673	▲:X-3669-366-0	PLATE ASSY, SLIDE, IL	674
662	▲:3-669-671-00	PLATE, SLIDE, SWITCH					

(15) CHASSIS ASSEMBLY



No.	Part No	Description	Remark
701	▲:X-3669-345-0	FRAME (B) BLOCK ASSY, CHASSIS	
702	▲:X-3669-344-0	FRAME (A) BLOCK ASSY, CHASSIS	
703	▲:3-669-532-00	PLATE, BLIND	
704	▲:3-669-599-00	INSULATOR	

No.	Part No	Description	Remark
705	▲:X-3669-346-0	FRAME (C) BLOCK ASSY, CHASSIS	
706	3-669-519-00	PLATE, CONTACT	
707	▲:3-672-502-00	PLATE (R), CONNECTION, BRACKET	

SF-5

**SECTION 5
ELECTRICAL PART LIST**

NOTE:

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

- Items marked " **A** " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

COILS
• MMH : mH, UH : μ H

When indicating parts by reference number, please include the board name.

- =>: Due to standardization, interchangeable replacements may be substituted for parts specified in the diagrams.

- CAPACITORS
- MF : μ F, PF : $\mu\mu$ F
- RESISTORS
- All resistors are in ohms
 - F : nonflammable

Ref.No	Part No	Description	Remark
	A :A-6711-326-A	SF-5 BOARD, COMPLETE *****	
	A :3-672-306-00	INSULATOR (R)	
	A :3-672-307-00	PLATE, SHIELD, SF	
CAPACITOR			
C001	1-123-645-00	ELECT 33MF 20%	10V
C002	1-123-645-00	ELECT 33MF 20%	10V
C004	1-123-645-00	ELECT 33MF 20%	10V
C005	1-123-645-00	ELECT 33MF 20%	10V
C006	1-161-021-00	CERAMIC 0.047MF 10%	25V
C007	1-123-617-00	ELECT 10MF 20%	16V
C008	1-102-816-00	CERAMIC 120PF 5%	50V
C009	1-123-645-00	ELECT 33MF 20%	10V
C010	1-123-645-00	ELECT 33MF 20%	10V
C011	1-123-645-00	ELECT 33MF 20%	10V
C012	1-123-612-00	ELECT 2.2MF 20%	50V
C013	1-123-612-00	ELECT 2.2MF 20%	50V
C014	1-123-645-00	ELECT 33MF 20%	10V
C015	1-123-645-00	ELECT 33MF 20%	10V
C016	1-123-619-00	ELECT 4.7MF 20%	50V
C017	1-123-816-00	ELECT 47MF 20%	50V
C018	1-123-619-00	ELECT 4.7MF 20%	50V
C019	1-123-622-00	ELECT 22MF 20%	16V
C020	1-123-622-00	ELECT 22MF 20%	16V
C021	1-123-619-00	ELECT 4.7MF 20%	50V
C022	1-123-645-00	ELECT 33MF 20%	10V
C023	1-161-021-00	CERAMIC 0.047MF 10%	25V
C024	1-161-021-00	CERAMIC 0.047MF 10%	25V
C025	1-107-211-00	MICA 24PF 5%	500V
C027	1-161-021-00	CERAMIC 0.047MF 10%	25V
C028	1-161-021-00	CERAMIC 0.047MF 10%	25V
C029	1-123-611-00	ELECT 1MF 20%	50V
C030	1-161-039-00	CERAMIC 0.001MF 10%	25V
C031	1-108-561-00	MYLAR 0.0018MF 5%	50V
C032	1-123-610-00	ELECT 0.47MF 20%	50V
C033	1-123-619-00	ELECT 4.7MF 20%	50V
C034	1-123-619-00	ELECT 4.7MF 20%	50V
C035	1-123-613-00	ELECT 3.3MF 20%	50V
C036	1-123-645-00	ELECT 33MF 20%	10V
C037	1-102-512-00	CERAMIC 16PF 5%	50V
C038	1-123-645-00	ELECT 33MF 20%	10V
C039	1-123-607-00	ELECT 0.1MF 20%	50V
C040	1-123-307-00	ELECT 100MF 20%	10V
C042	1-161-021-00	CERAMIC 0.047MF 10%	25V
C043	1-123-645-00	ELECT 33MF 20%	10V
C044	1-123-617-00	ELECT 10MF 20%	16V
C045	1-161-013-00	CERAMIC 0.01MF 10%	25V
C046	1-123-622-00	ELECT 22MF 20%	16V
C047	1-102-962-00	CERAMIC 30PF 5%	50V
C048	1-123-612-00	ELECT 2.2MF 20%	50V
C049	1-161-021-00	CERAMIC 0.047MF 10%	25V

Ref.No	Part No	Description	Remark
C050	1-161-021-00	CERAMIC 0.047MF 10%	25V
C051	1-161-021-00	CERAMIC 0.047MF 10%	25V
C052	1-161-013-00	CERAMIC 0.01MF 10%	25V
C053	1-161-013-00	CERAMIC 0.01MF 10%	25V
C055	1-123-612-00	ELECT 2.2MF 20%	50V
C060	1-161-025-00	CERAMIC 0.1MF 10%	25V
C061	1-161-021-00	CERAMIC 0.047MF 10%	25V
C062	1-161-021-00	CERAMIC 0.047MF 10%	25V
C063	1-161-021-00	CERAMIC 0.047MF 10%	25V
FILTER			
CF001	1-527-875-00	FILTER, CERAMIC	
CF003	1-527-849-00	FILTER, CERAMIC	
CONNECTOR			
CN001	A :1-560-471-00	PIN, CONNECTOR 10P	
CN002	A :1-560-471-00	PIN, CONNECTOR 10P	
CN003	A :1-560-461-00	PIN, CONNECTOR 5P	
TRIMER			
CV001	1-141-246-00	CAP, TRIMER 100PF	
DIODE			
D001	8-719-911-19	DIODE 1SS119	
D002	8-719-911-19	DIODE 1SS119	
D003	8-719-911-19	DIODE 1SS119	
D004	8-719-911-19	DIODE 1SS119	
D005	8-719-911-19	DIODE 1SS119	
DELAY LINE			
DL001	1-415-273-00	DELAY LINE (1H)	
DL002	1-415-223-21	DELAY LINE	
IC			
IC001	8-759-208-94	IC CX894	
IC003	8-741-102-10	IC BX1021	
IC004	8-741-102-20	IC BX1022	
IC005	8-741-102-50	IC BX1025	
IC006	8-741-102-60	IC BX1026	
IC007	8-741-102-70	IC BX1027	
IC008	8-741-103-20	IC BX1032	
IC009	8-741-103-30	IC BX1033	
IC010	8-741-103-40	IC BX1034	
COIL			
L001	1-408-429-00	MICRO INDUCTOR 470UH	
L002	1-408-397-00	MICRO INDUCTOR 1UH	
L003	1-408-397-00	MICRO INDUCTOR 1UH	
L004	1-408-421-00	MICRO INDUCTOR 100UH	
L005	1-408-429-00	MICRO INDUCTOR 470UH	
L007	1-408-421-00	MICRO INDUCTOR 100UH	
L008	1-408-429-00	MICRO INDUCTOR 470UH	
L050	1-408-415-00	MICRO INDUCTOR 33UH	

SF-5

SF-6

Ref.No	Part No	Description	Remark
<u>VARIABLE COIL</u>			
LV001	1-408-512-00	COIL (VARIABLE) 10UH	
<u>TRANSISTOR</u>			
Q002 =>	8-729-612-77	TRANSISTOR 2SA1027R	
Q003 =>	8-724-375-01	TRANSISTOR 2SC403C	
Q004 =>	8-724-375-01	TRANSISTOR 2SC403C	
Q005	8-729-178-54	TRANSISTOR 2SC2785	
Q006	8-729-178-54	TRANSISTOR 2SC2785	
Q007	8-729-178-54	TRANSISTOR 2SC2785	
<u>RESISTOR</u>			
R001	1-246-801-00	CARBON 33K	1/8W
R002	1-246-775-00	CARBON 220	1/8W
R003	1-246-840-00	CARBON 510	1/8W
R004	1-246-782-00	CARBON 820	1/8W
R006	1-246-801-00	CARBON 33K	1/8W
R007	1-246-803-00	CARBON 47K	1/8W
R008	1-247-055-00	CARBON 300K	1/8W
R009	1-246-833-00	CARBON 130	1/8W
R011	1-247-053-00	CARBON 1M	1/8W
R012	1-246-799-00	CARBON 22K	1/8W
R013	1-246-807-00	CARBON 100K	1/8W
R014	1-246-798-00	CARBON 18K	1/8W
R015	1-246-807-00	CARBON 100K	1/8W
R016	1-246-807-00	CARBON 100K	1/8W
R017	1-247-052-00	CARBON 820K	1/8W
R018	1-247-052-00	CARBON 820K	1/8W
R019	1-246-801-00	CARBON 33K	1/8W
R020	1-246-801-00	CARBON 33K	1/8W
R021	1-246-799-00	CARBON 22K	1/8W
R022	1-246-803-00	CARBON 47K	1/8W
R023	1-246-801-00	CARBON 33K	1/8W
R024	1-246-795-00	CARBON 10K	1/8W
R025	1-246-785-00	CARBON 1.5K	1/8W
R026	1-246-863-00	CARBON 43K	1/8W
R027	1-246-800-00	CARBON 27K	1/8W
R028	1-246-783-00	CARBON 1K	1/8W
R029	1-246-804-00	CARBON 56K	1/8W
R030	1-246-806-00	CARBON 82K	1/8W
R031	1-246-777-00	CARBON 330	1/8W
R033	1-246-849-00	CARBON 3K	1/8W
R034	1-246-779-00	CARBON 470	1/8W
R036	1-246-807-00	CARBON 100K	1/8W
R037	1-246-807-00	CARBON 100K	1/8W
R038	1-246-795-00	CARBON 10K	1/8W
R039	1-246-833-00	CARBON 130	1/8W
R040	1-246-847-00	CARBON 2K	1/8W
R041	1-246-797-00	CARBON 15K	1/8W
R042	1-246-851-00	CARBON 4.3K	1/8W
R043	1-246-785-00	CARBON 1.5K	1/8W
R044	1-246-840-00	CARBON 510	1/8W

Ref.No	Part No	Description	Remark
R050	1-246-790-00	CARBON 3.9K	1/8W
R051	1-246-834-00	CARBON 160	1/8W
<u>VARIABLE RESISTOR</u>			
RV001	1-226-776-00	RES, ADJ, METAL GLAZE 220K	
RV002	1-226-773-00	RES, ADJ, METAL GLAZE 22K	
RV003	1-226-774-00	RES, ADJ, METAL GLAZE 47K	
RV004	1-226-774-00	RES, ADJ, METAL GLAZE 47K	
RV005	1-226-773-00	RES, ADJ, METAL GLAZE 22K	
RV007	1-226-703-00	RES, ADJ, METAL GLAZE 10K	
RV008	1-226-773-00	RES, ADJ, METAL GLAZE 22K	
RV009	1-226-772-00	RES, ADJ, METAL GLAZE 4.7K	
RV010	1-226-703-00	RES, ADJ, METAL GLAZE 10K	
RV011	1-226-703-00	RES, ADJ, METAL GLAZE 10K	
RV012	1-226-703-00	RES, ADJ, METAL GLAZE 10K	
RV013	1-226-770-00	RES, ADJ, METAL GLAZE 470	
RV014	1-226-773-00	RES, ADJ, METAL GLAZE 22K	
RV015	1-226-771-00	RES, ADJ, METAL GLAZE 1K	
RV016	1-226-773-00	RES, ADJ, METAL GLAZE 22K	
RV017	1-226-702-00	RES, ADJ, METAL GLAZE 2.2K	
RV018	1-226-771-00	RES, ADJ, METAL GLAZE 1K	
<u>TRANSFORMER</u>			
T001	1-426-093-00	COIL, REC C BPT	
T002	1-235-098-00	FILTER, BAND PASS: BPF	
<u>CRYSTAL</u>			
X001	1-527-345-00	CRYSTAL, OSC	

	•:1-606-730-00	SF-6 BOARD	*****
	•:3-672-322-00	CASE (MAIN) (D), SHIELD	
<u>CAPACITOR</u>			
C101	1-123-645-00	ELECT 33MF	20% 10V
C102	1-102-973-00	CERAMIC 100PF	5% 50V
C103	1-101-361-00	CERAMIC 150PF	5% 50V
C104	1-101-361-00	CERAMIC 150PF	5% 50V
C105	1-161-013-00	CERAMIC 0.01MF	10% 25V
C106	1-161-013-00	CERAMIC 0.01MF	10% 25V
C107	1-161-013-00	CERAMIC 0.01MF	10% 25V
C108	1-161-021-00	CERAMIC 0.047MF	10% 25V
C109	1-123-645-00	ELECT 33MF	20% 10V
<u>FILTER</u>			
CF101	1-527-874-00	FILTER, CERAMIC	
<u>CONNECTOR</u>			
CN101	•:1-560-741-00	PIN, CONNECTOR 12P	

When indicating parts by reference number, please include the board name.

SF-6

LS-8

Ref.No	Part No	Description	Remark
<u>IC</u>			
IC101	8-759-919-05	IC CX7905A	
IC102	8-759-919-06	IC CX7906	
IC103	8-752-000-80	IC CX20008	
IC104	8-759-108-05	IC UPC78L05A	
<u>COIL</u>			
L101	1-408-421-00	MICRO INDUCTOR 100UH	
<u>RESISTOR</u>			
R101	1-246-795-00	CARBON 10K	1/8W
R102	1-246-797-00	CARBON 15K	1/8W
R103	1-246-803-00	CARBON 47K	1/8W
R104	1-246-783-00	CARBON 1K	1/8W
R105	1-246-860-00	CARBON 24K	1/8W
R106	1-246-783-00	CARBON 1K	1/8W
R107	1-246-791-00	CARBON 4.7K	1/8W
<u>VARIABLE RESISTOR</u>			
RV101	1-226-773-00	RES, ADJ, METAL GLAZE 22K	
RV102	1-226-773-00	RES, ADJ, METAL GLAZE 22K	
RV103	1-226-773-00	RES, ADJ, METAL GLAZE 22K	

♣:A-6713-123-A	LS-8 BOARD, COMPLETE *****		
♣:3-669-625-00	LID, SHIELD CASE, LS-A		
♣:3-669-628-00	CASE (MAIN), SHIELD, LS-A		
<u>CAPACITOR</u>			
C001	1-123-647-00	ELECT 47MF	20% 6.3V
C002	1-123-822-00	ELECT 47MF	20% 10V
C003	1-123-617-00	ELECT 10MF	20% 16V
C004	1-123-622-00	ELECT 22MF	20% 16V
C005	1-123-356-00	ELECT 10MF	20% 16V
C006	1-130-493-51	MYLAR 0.068MF	5% 50V
C007	1-123-380-00	ELECT 1MF	20% 50V
C008	1-123-307-00	ELECT 100MF	20% 10V
C009	1-123-332-00	ELECT 47MF	20% 16V
C010	1-123-356-00	ELECT 10MF	20% 16V
C011	1-123-306-00	ELECT 47MF	20% 10V
C012	1-123-356-00	ELECT 10MF	20% 16V
C013	1-123-356-00	ELECT 10MF	20% 16V
C014	1-123-356-00	ELECT 10MF	20% 16V
C015	1-123-295-00	ELECT 100MF	20% 6.3V
C016	1-123-328-00	ELECT 4.7MF	20% 25V
C017	1-123-356-00	ELECT 10MF	20% 16V
C018	1-123-356-00	ELECT 10MF	20% 16V
C019	1-123-380-00	ELECT 1MF	20% 50V
C020	1-123-380-00	ELECT 1MF	20% 50V
C021	1-108-571-00	MYLAR 0.0047MF	5% 50V

Ref.No	Part No	Description	Remark
C022	1-108-567-00	MYLAR 0.0033MF	5% 50V
C023	1-123-305-00	ELECT 33MF	20% 10V
C025	1-102-961-00	CERAMIC 27PF	5% 50V
C026	1-129-710-00	FILM 0.0047MF	10% 630V
C027	1-102-980-00	CERAMIC 270PF	5% 50V
C028	1-123-356-00	ELECT 10MF	20% 16V
C029	1-102-973-00	CERAMIC 100PF	5% 50V
C030	1-123-328-00	ELECT 4.7MF	20% 25V
C032	1-123-306-00	ELECT 47MF	20% 10V
C040	1-130-474-00	MYLAR 0.0018MF	5% 50V
C041	1-130-484-00	MYLAR 0.012MF	5% 50V
C042	1-161-051-00	CERAMIC 0.01MF	10% 50V
C043	1-161-039-00	CERAMIC 0.001MF	10% 25V
C200	1-123-319-00	ELECT 47MF	20% 16V
C201	1-161-051-00	CERAMIC 0.01MF	10% 50V
C202	1-130-499-00	MYLAR 0.22MF	5% 50V
C203	1-130-495-00	MYLAR 0.1MF	5% 50V
C204	1-123-617-00	ELECT 10MF	20% 16V
C205	1-161-051-00	CERAMIC 0.01MF	10% 50V
<u>CONNECTOR</u>			
CN001	♣:1-560-469-00	PIN, CONNECTOR 6P	
CN002	♣:1-560-456-00	PIN, CONNECTOR 2P	
<u>TRIMER</u>			
CV001	1-141-215-00	CAP, TRIMER	
<u>DIODE</u>			
D001	=>8-719-901-33	DIODE 1SS133	
D002	=>8-719-901-33	DIODE 1SS133	
D003	=>8-719-901-33	DIODE 1SS133	
D004	=>8-719-901-33	DIODE 1SS133	
D005	=>8-719-901-33	DIODE 1SS133	
D006	=>8-719-901-33	DIODE 1SS133	
D007	8-719-113-07	DIODE RD13E-B	
D200	=>8-719-901-33	DIODE 1SS133	
D201	=>8-719-901-33	DIODE 1SS133	
D206	=>8-719-901-33	DIODE 1SS133	
D207	=>8-719-901-33	DIODE 1SS133	
D210	=>8-719-901-33	DIODE 1SS133	
D211	=>8-719-901-33	DIODE 1SS133	
<u>IC</u>			
IC001	8-741-103-60	IC BX1036	
IC003	8-743-973-00	IC BX3973	
IC004	=>8-749-910-35	IC BX1035A	
IC201	8-759-240-13	IC TC4013BP	

When indicating parts by reference number, please include the board name.

LS-8

MA-3

Ref.No	Part No	Description	Remark
IC202	8-759-240-52	IC TC4052BP	
IC203	8-759-240-81	IC TC40813P	
IC204	8-759-240-01	IC TC4001BP	
<u>COIL</u>			
L002	1-408-220-00	MICRO INDUCTOR 18MMH	
L003	1-407-488-00	MICRO INDUCTOR 470UH	
<u>VARIABLE COIL</u>			
LV001	1-408-523-00	COIL, VARIABLE 22MMH	
LV002	1-408-524-00	INDUCTOR, ADJ 34MMH	
<u>TRANSISTOR</u>			
Q001	8-729-908-62	TRANSISTOR 2SD786	
Q003	8-729-178-54	TRANSISTOR 2SC2785	
Q004	8-729-967-32	TRANSISTOR 2SC2673	
Q005	8-729-988-12	TRANSISTOR 2SA881	
Q008	8-729-178-54	TRANSISTOR 2SC2785	
Q010	8-729-178-54	TRANSISTOR 2SC2785	
Q011	8-729-178-54	TRANSISTOR 2SC2785	
Q202	8-729-117-54	TRANSISTOR 2SA1175	
Q203	8-729-178-54	TRANSISTOR 2SC2785	
Q204	8-729-178-54	TRANSISTOR 2SC2785	
Q205	8-729-178-54	TRANSISTOR 2SC2785	
Q206	8-729-178-54	TRANSISTOR 2SC2785	
Q207	8-729-178-54	TRANSISTOR 2SC2785	
Q208	8-729-178-54	TRANSISTOR 2SC2785	
<u>RESISTOR</u>			
R001	1-246-759-00	CARBON	10 1/8W
R002	1-202-469-00	COMPOSITION	3.9M 5% 1/4W
R003	1-246-787-00	CARBON	2.2K 1/8W
R004	1-246-797-00	CARBON	15K 1/8W
R005	1-247-049-00	CARBON	470K 1/8W
R009	1-246-768-00	CARBON	56 1/8W
R010	1-246-784-00	CARBON	1.2K 1/8W
R011	1-246-795-00	CARBON	10K 1/8W
R012	1-246-795-00	CARBON	10K 1/8W
R013	1-246-771-00	CARBON	100 1/8W
R014	1-246-801-00	CARBON	33K 1/8W
R015	1-246-795-00	CARBON	10K 1/8W
R016	1-246-465-00	CARBON	470 5% 1/4W
R017	1-212-849-00	FUSIBLE	4.7 5% 1/4W F
R018	1-246-797-00	CARBON	15K 1/8W
R019	1-246-795-00	CARBON	10K 1/8W
R020	1-246-801-00	CARBON	33K 1/8W
R021	1-246-787-00	CARBON	2.2K 1/8W
R022	1-246-807-00	CARBON	100K 1/8W
R023	1-246-801-00	CARBON	33K 1/8W
R026	1-246-840-00	CARBON	510 1/8W
R027	1-246-787-00	CARBON	2.2K 1/8W
R040	1-246-793-00	CARBON	6.8K 1/8W
R041	1-246-800-00	CARBON	27K 1/8W

Ref.No	Part No	Description	Remark
R042	1-246-785-00	CARBON	1.5K 1/8W
R043	1-246-801-00	CARBON	33K 1/8W
R044	1-246-777-00	CARBON	330 1/8W
R046	1-246-543-00	CARBON	820K 5% 1/4W
R201	1-246-795-00	CARBON	10K 1/8W
R203	1-246-795-00	CARBON	10K 1/8W
R204	1-246-795-00	CARBON	10K 1/8W
R205	1-246-795-00	CARBON	10K 1/8W
R206	1-246-795-00	CARBON	10K 1/8W
R207	1-246-807-00	CARBON	100K 1/8W
R211	1-246-807-00	CARBON	100K 1/8W
R212	1-246-783-00	CARBON	1K 1/8W
R213	1-246-803-00	CARBON	47K 1/8W
R217	1-246-783-00	CARBON	1K 1/8W
R220	1-246-803-00	CARBON	47K 1/8W
R221	1-246-807-00	CARBON	100K 1/8W
R222	1-246-803-00	CARBON	47K 1/8W
R225	1-246-811-00	CARBON	220K 1/8W
R226	1-246-803-00	CARBON	47K 1/8W
R230	1-246-857-00	CARBON	13K 1/8W
R231	1-246-799-00	CARBON	22K 1/8W
R237	1-246-795-00	CARBON	10K 1/8W
R240	1-246-803-00	CARBON	47K 1/8W
R241	1-246-807-00	CARBON	100K 1/8W
R242	1-246-803-00	CARBON	47K 1/8W

<u>VARIABLE RESISTOR</u>			
RV001	1-226-774-00	RES, ADJ, METAL GLAZE	47K
RV002	1-226-775-00	RES, ADJ, METAL GLAZE	100K
RV003	1-226-710-00	RES, ADJ, SOLID	10K
RV202	1-226-776-00	RES, ADJ, METAL GLAZE	220K
RV203	1-226-776-00	RES, ADJ, METAL GLAZE	220K
RV205	1-226-704-00	RES, ADJ, METAL GLAZE	470K
RV209	1-226-704-00	RES, ADJ, METAL GLAZE	470K
RV210	1-226-704-00	RES, ADJ, METAL GLAZE	470K
RV211	1-226-773-00	RES, ADJ, METAL GLAZE	22K

<u>RELAY</u>		
RY001	1-515-418-00	RELAY
RY002	1-515-416-00	RELAY

<u>TRANSFORMER</u>		
T001	1-433-236-00	TRANSFORMER, OSCILLATOR
T002	1-427-506-00	TRANSFORMER, OUTPUT

♣:A-6715-140-A MA-3 BOARD, COMPLETE

1-426-105-00 TRANSFORMER, MODULATION
1-464-181-00 MODULATOR, RF (RFM-110-E)
♣:1-533-087-00 HOLDER, FUSE
♣:3-669-513-00 SPACER, MICROPHONE JACK
♣:3-669-610-00 SPACER

When indicating parts by reference number, please include the board name.

MA-3

8-2

Ref.No	Part No	Description	Remark	Ref.No	Part No	Description	Remark
CAPACITOR				C219	1-161-057-00	CERAMIC	0.033MF 10% 50V
C001	1-123-645-00	ELECT	33MF 20% 10V	C220	1-123-318-00	ELECT	33MF 20% 16V
C002	1-123-645-00	ELECT	33MF 20% 10V	C221	1-161-057-00	CERAMIC	0.033MF 10% 50V
C003	1-123-645-00	ELECT	33MF 20% 10V	C222	1-123-611-00	ELECT	1MF 20% 50V
C004	1-123-645-00	ELECT	33MF 20% 10V	C223	1-123-611-00	ELECT	1MF 20% 50V
C005	1-123-645-00	ELECT	33MF 20% 10V	C224	1-161-009-00	CERAMIC	0.0047MF 10% 25V
C006	1-108-603-00	MYLAR	0.1MF 5% 50V	C226	1-161-039-00	CERAMIC	0.001MF 10% 25V
C007	1-123-645-00	ELECT	33MF 20% 10V	C228	1-123-611-00	ELECT	1MF 20% 50V
C008	1-123-619-00	ELECT	4.7MF 20% 50V	C229	1-123-613-00	ELECT	3.3MF 20% 50V
C010	1-123-822-00	ELECT	47MF 20% 10V	C230	1-123-318-00	ELECT	33MF 20% 16V
C011	1-108-603-00	MYLAR	0.1MF 5% 50V	C231	1-161-057-00	CERAMIC	0.033MF 10% 50V
C013	1-123-645-00	ELECT	33MF 20% 10V	C232	1-161-057-00	CERAMIC	0.033MF 10% 50V
C015	1-123-619-00	ELECT	4.7MF 20% 50V	C233	1-123-820-00	ELECT	33MF 20% 16V
C016	1-123-610-00	ELECT	0.47MF 20% 50V	C234	1-161-057-00	CERAMIC	0.033MF 10% 50V
C017	1-123-645-00	ELECT	33MF 20% 10V	C235	1-161-021-00	CERAMIC	0.047MF 10% 25V
C019	1-123-645-00	ELECT	33MF 20% 10V	C236	1-161-021-00	CERAMIC	0.047MF 10% 25V
C020	1-108-557-00	MYLAR	0.0012MF 5% 50V	C237	1-161-005-00	CERAMIC	0.0022MF 10% 25V
C021	1-123-622-00	ELECT	22MF 20% 16V	C238	1-123-616-00	ELECT	4.7MF 20% 25V
C025	1-161-013-00	CERAMIC	0.01MF 10% 25V	C239	1-161-057-00	CERAMIC	0.033MF 10% 50V
C026	1-123-617-00	ELECT	10MF 20% 16V	C240	1-161-057-00	CERAMIC	0.033MF 10% 50V
C028	1-123-311-00	ELECT	1000MF 20% 10V	C241	1-123-611-00	ELECT	1MF 20% 50V
C029	1-161-013-00	CERAMIC	0.01MF 10% 25V	C242	1-161-021-00	CERAMIC	0.047MF 10% 25V
C031		ELECT	10MF 50V	C243	1-161-021-00	CERAMIC	0.047MF 10% 25V
C035	1-123-310-00	ELECT	470MF 20% 10V	C244	1-161-005-00	CERAMIC	0.0022MF 10% 25V
C038	1-161-021-00	CERAMIC	0.047MF 10% 25V	C245	1-161-005-00	CERAMIC	0.0022MF 10% 25V
C040	1-123-321-00	ELECT	220MF 20% 16V	C401	1-161-021-00	CERAMIC	0.047MF 10% 25V
C041	1-161-011-00	CERAMIC	0.0068MF 10% 25V	C402	1-161-021-00	CERAMIC	0.047MF 10% 25V
C043	1-102-958-00	CERAMIC	20PF 5% 50V	C403	1-161-021-00	CERAMIC	0.047MF 10% 25V
C344		ELECT	10MF 50V	C404	1-123-613-00	ELECT	3.3MF 20% 50V
C045	1-101-880-00	CERAMIC	47PF 5% 50V	C405	1-123-613-00	ELECT	3.3MF 20% 50V
C046	1-123-661-00	ELECT	100MF 20% 6.3V	C406	1-123-613-00	ELECT	3.3MF 20% 50V
C060	1-101-884-00	CERAMIC	56PF 5% 50V	C407	1-130-483-51	MYLAR	0.01MF 5% 50V
C061	1-161-021-00	CERAMIC	0.047MF 10% 25V	C409	1-130-483-51	MYLAR	0.01MF 5% 50V
C062	1-161-021-00	CERAMIC	0.047MF 10% 25V	C410	1-123-296-00	ELECT	220MF 20% 6.3V
C201	1-123-318-00	ELECT	33MF 20% 16V	C412	1-161-016-00	CERAMIC	0.018MF 10% 25V
C202	1-161-057-00	CERAMIC	0.033MF 10% 50V	C413	1-161-945-00	CERAMIC	0.022MF 10% 50V
C203	1-123-617-00	ELECT	10MF 20% 16V	C416	1-123-622-00	ELECT	22MF 20% 16V
C204	1-123-617-00	ELECT	10MF 20% 16V	C417	1-123-611-00	ELECT	1MF 20% 50V
C205	1-161-039-00	CERAMIC	0.001MF 10% 25V	C420	1-123-318-00	ELECT	33MF 20% 16V
C206	1-123-333-00	ELECT	100MF 20% 16V	C421	1-123-820-00	ELECT	33MF 20% 16V
C207	1-123-318-00	ELECT	33MF 20% 16V	C423	1-161-947-00	CERAMIC	220PF 5% 50V
C208	1-161-057-00	CERAMIC	0.033MF 10% 50V	C424	1-161-013-00	CERAMIC	0.01MF 10% 25V
C209	1-130-482-00	MYLAR	0.0082MF 5% 50V	C425	1-161-016-00	CERAMIC	0.018MF 10% 25V
C210	1-130-482-00	MYLAR	0.0082MF 5% 50V	C426	1-127-468-00	ELECT	0.22MF 5% 16V
C211	1-123-612-00	ELECT	2.2MF 20% 50V	C427	1-123-822-00	ELECT	47MF 20% 10V
C212	1-123-612-00	ELECT	2.2MF 20% 50V	C428	1-130-483-51	MYLAR	0.01MF 5% 50V
C213	1-123-611-00	ELECT	1MF 20% 50V	C429	1-123-616-00	ELECT	4.7MF 20% 25V
C214	1-123-611-00	ELECT	1MF 20% 50V	C430	1-123-616-00	ELECT	4.7MF 20% 25V
C215	1-123-611-00	ELECT	1MF 20% 50V	C431	1-123-296-00	ELECT	220MF 20% 6.3V
C216	1-123-611-00	ELECT	1MF 20% 50V	C432	1-123-612-00	ELECT	2.2MF 20% 50V
C217	1-123-617-00	ELECT	10MF 20% 16V	C433	1-130-494-51	MYLAR	0.082MF 5% 50V
C218	1-123-318-00	ELECT	33MF 20% 16V	C435	1-123-307-00	ELECT	100MF 20% 10V
				C436	1-123-647-00	ELECT	47MF 20% 6.3V

When indicating parts by reference number, please include the board name.

Ref.No	Part No	Description	Remark	Ref.No	Part No	Description	Remark
C437	1-123-612-00	ELECT	2.2MF	20%	50V		
C438	1-123-613-00	ELECT	3.3MF	20%	50V		
C439	1-123-611-00	ELECT	1MF	20%	50V		
C441	1-161-013-00	CERAMIC	0.01MF	10%	25V		
C442	1-161-040-00	CERAMIC	0.0012MF	10%	50V		
C443	1-123-613-00	ELECT	3.3MF	20%	50V		
C444	1-123-617-00	ELECT	10MF	20%	16V		
C445	1-123-822-00	ELECT	47MF	20%	10V		
C446	1-123-647-00	ELECT	47MF	20%	6.3V		
C447	1-161-021-00	CERAMIC	0.047MF	10%	25V		
C448	1-123-333-00	ELECT	100MF	20%	16V		
C453	1-123-616-00	ELECT	4.7MF	20%	25V		
C454	1-123-616-00	ELECT	4.7MF	20%	25V		
C456	1-123-616-00	ELECT	4.7MF	20%	25V		
C458	1-161-616-00	CERAMIC	0.01MF	10%	25V		
C459	1-161-021-00	CERAMIC	0.047MF	10%	25V		
C460	1-102-114-00	CERAMIC	470PF	10%	50V		
C461	1-123-612-00	ELECT	2.2MF	20%	50V		
C462	1-123-607-00	ELECT	0.1MF	20%	50V		
C465	1-161-021-00	CERAMIC	0.047MF	10%	25V		
C466	1-130-492-51	MYLAR	0.056MF	5%	50V		
C467	1-123-616-00	ELECT	4.7MF	20%	25V		
C469	1-130-499-51	MYLAR	0.22MF	5%	50V		
C471	1-161-021-00	CERAMIC	0.047MF	10%	25V		
C601	1-123-323-00	ELECT	470MF	20%	16V		
C602	1-123-323-00	ELECT	470MF	20%	16V		
C603	1-123-622-00	ELECT	22MF	20%	16V		
C604	1-123-617-00	ELECT	10MF	20%	16V		
C605	1-123-616-00	ELECT	4.7MF	20%	25V		
C607	1-123-616-00	ELECT	4.7MF	20%	25V		
C609	1-161-021-00	CERAMIC	0.047MF	10%	25V		
C610	1-161-021-00	CERAMIC	0.047MF	10%	25V		
C611	1-161-021-00	CERAMIC	0.047MF	10%	25V		
C612	1-161-021-00	CERAMIC	0.047MF	10%	25V		
C613	1-161-021-00	CERAMIC	0.047MF	10%	25V		
C614	1-161-021-00	CERAMIC	0.047MF	10%	25V		
C615	1-161-021-00	CERAMIC	0.047MF	10%	25V		
C616	1-161-021-00	CERAMIC	0.047MF	10%	25V		
C617	1-123-645-00	ELECT	33MF	20%	10V		
C618	1-102-529-00	CERAMIC	100PF	5%	50V		
C619	1-102-529-00	CERAMIC	100PF	5%	50V		
C620	1-161-013-00	CERAMIC	0.01MF	10%	25V		
C621	1-161-013-00	CERAMIC	0.01MF	10%	25V		
C623	1-161-013-00	CERAMIC	0.01MF	10%	25V		
C680	1-101-882-00	CERAMIC	51PF	5%	50V		
C681	1-161-013-00	CERAMIC	0.01MF	10%	25V		
C801	1-123-320-00	ELECT	100MF	20%	16V		
C802	1-123-822-00	ELECT	47MF	20%	10V		
C803	1-123-617-00	ELECT	10MF	20%	16V		
C804	1-161-013-00	CERAMIC	0.01MF	10%	25V		
C805	1-123-324-00	ELECT	1000MF	20%	16V		
C806	1-161-020-00	CERAMIC	0.039MF	10%	25V		
C901	1-123-611-00	ELECT	1MF	20%	50V		
C902	1-123-617-00	ELECT	10MF	20%	16V		
C903	1-123-612-00	ELECT	2.2MF	20%	50V		
C904	1-123-644-00	ELECT	22MF	20%	10V		
C905	1-123-822-00	ELECT	47MF	20%	10V		
C906	1-123-617-00	ELECT	10MF	20%	16V		
C907	1-123-616-00	ELECT	4.7MF	20%	25V		
C908	1-123-647-00	ELECT	47MF	20%	6.3V		
C920	1-123-613-00	ELECT	3.3MF	20%	50V		
C921	1-161-022-00	CERAMIC	0.056MF	10%	25V		
C924	1-161-025-00	CERAMIC	0.1MF	10%	25V		
<u>CONNECTOR</u>							
CN001	1-560-471-00	PIN, CONNECTOR	10P				
CN002	1-560-471-00	PIN, CONNECTOR	10P				
CN201	1-560-459-00	PIN, CONNECTOR	3P				
CN202	1-560-466-00	PIN, CONNECTOR	3P				
CN203	1-560-469-00	PIN, CONNECTOR	6P				
CN401	1-560-467-00	PIN, CONNECTOR	4P				
CN403	1-560-467-00	PIN, CONNECTOR	4P				
CN404	1-560-455-00	PIN, CONNECTOR	2P				
CN406	1-560-466-00	PIN, CONNECTOR	3P				
CN407	1-560-467-00	PIN, CONNECTOR	4P				
CN601	1-560-466-00	PIN, CONNECTOR	3P				
CN602	1-560-466-00	PIN, CONNECTOR	3P				
CN603	1-560-456-00	PIN, CONNECTOR	2P				
CN604	1-560-467-00	PIN, CONNECTOR	4P				
CN605	1-560-456-00	PIN, CONNECTOR	2P				
CN606	1-560-466-00	PIN, CONNECTOR	3P				
CN607	1-560-467-00	PIN, CONNECTOR	4P				
CN608	1-560-466-00	PIN, CONNECTOR	3P				
CN609	1-560-466-00	PIN, CONNECTOR	3P				
CN801	1-561-717-00	CONNECTOR	5P				
CN802	1-561-684-00	CONNECTOR, RECEPTACLE	26P				
CN804	1-561-690-00	CONNECTOR, CAMERA	14P				
CN805	1-508-742-00	PIN, CONNECTOR	3P				

When indicating parts by reference number, please include the board name.

MA-3

Ref.No	Part No	Description	Remark	Ref.No	Part No	Description	Remark
<u>DIODE</u>				D610	8-719-200-02	DIODE 10E2	
D001	8-719-911-19	DIODE 1SS119		D611	8-719-200-02	DIODE 10E2	
D002	8-719-191-07	DIODE RD9.1E-B		D612	8-719-200-02	DIODE 10E2	
D003	8-719-191-07	DIODE RD9.1E-B		D613	8-719-200-02	DIODE 10E2	
D005	8-719-911-19	DIODE 1SS119		D614	8-719-911-19	DIODE 1SS119	
D006	8-719-911-19	DIODE 1SS119		D615	8-719-911-06	DIODE 1SS106	
D201	8-719-911-06	DIODE 1SS106		D616	8-719-911-06	DIODE 1SS106	
D202	8-719-911-06	DIODE 1SS106		D617	8-719-911-06	DIODE 1SS106	
D208	=>8-719-901-33	DIODE 1SS133		D618	8-719-911-06	DIODE 1SS106	
D209	8-719-982-04	DIODE ERB81-004		D619	8-719-113-07	DIODE RD13E-B	
D212	=>8-719-901-33	DIODE 1SS133		D620	8-719-113-07	DIODE RD13E-B	
D213	8-719-982-04	DIODE ERB81-004		D621	8-719-911-19	DIODE 1SS119	
D215	=>8-719-901-33	DIODE 1SS133		D623	8-719-113-07	DIODE RD13E-B	
D402	=>8-719-901-33	DIODE 1SS133		D624	8-719-911-19	DIODE 1SS119	
D403	8-719-982-04	DIODE ERB81-004		D631	8-719-911-19	DIODE 1SS119	
D405	=>8-719-901-33	DIODE 1SS133		D632	8-719-911-19	DIODE 1SS119	
D406	=>8-719-901-33	DIODE 1SS133		D633	8-719-911-19	DIODE 1SS119	
D407	=>8-719-901-33	DIODE 1SS133		D634	8-719-911-19	DIODE 1SS119	
D408	=>8-719-901-33	DIODE 1SS133		D635	8-719-100-19	DIODE RD3.6EB2	
D418	8-719-911-06	DIODE 1SS106		D636	8-719-911-19	DIODE 1SS119	
D419	=>8-719-901-33	DIODE 1SS133		D673	8-719-911-06	DIODE 1SS106	
D422	=>8-719-901-33	DIODE 1SS133		D678	8-719-911-06	DIODE 1SS106	
D423	=>8-719-901-33	DIODE 1SS133		D801	8-719-122-07	DIODE RD22E-B	
D424	=>8-719-901-33	DIODE 1SS133		D802	8-719-122-07	DIODE RD22E-B	
D425	=>8-719-901-33	DIODE 1SS133		D804	8-719-113-07	DIODE RD13E-B	
D601	8-719-200-02	DIODE 10E2		D805	8-719-113-07	DIODE RD13E-B	
D602	8-719-200-02	DIODE 10E2		D806	8-719-113-07	DIODE RD13E-B	
D603	8-719-911-19	DIODE 1SS119		D807	8-719-113-07	DIODE RD13E-B	
D604	8-719-200-02	DIODE 10E2		D808	8-719-113-07	DIODE RD13E-B	
D605	8-719-127-07	DIODE RD2.7E-B		D809	8-719-122-07	DIODE RD22E-B	
D606	8-719-200-02	DIODE 10E2		D810	8-719-113-07	DIODE RD13E-B	
D607	8-719-200-02	DIODE 10E2		D811	8-719-122-07	DIODE RD22E-B	
D608	8-719-911-19	DIODE 1SS119		D812	8-719-122-07	DIODE RD22E-B	
D609	8-719-911-19	DIODE 1SS119		D813	8-719-113-07	DIODE RD13E-B	
				D814	8-719-113-07	DIODE RD13E-B	
				D817	8-719-122-07	DIODE RD22E-B	
				D818	=>8-719-911-55	DIODE U05G	
				D819	8-719-982-04	DIODE ERB81-004	
				D821	8-719-162-07	DIODE RD6.2E-B	
				D822	8-719-911-19	DIODE 1SS119	
				D823	8-719-911-19	DIODE 1SS119	
				D824	8-719-911-06	DIODE 1SS106	
				D827	8-719-113-07	DIODE RD13E-B	
				D828	8-719-113-07	DIODE RD13E-B	
				D829	8-719-113-07	DIODE RD13E-B	
				D830	8-719-118-07	DIODE RD18E-B	
				D840	8-719-911-19	DIODE 1SS119	
				D841	8-719-911-19	DIODE 1SS119	
				D842	8-719-911-19	DIODE 1SS119	
				D843	8-719-982-04	DIODE ERB81-004	
				D923	8-719-122-07	DIODE RD22E-B	

When indicating parts by reference number, please include the board name.

Ref.No	Part No	Description	Remark	Ref.No	Part No	Description	Remark
<u>DELAY LINE</u>							
DL002	1-415-198-00	DELAY LINE (1H)		IC801=>	8-743-999-10	IC BX3999-1	
<u>CONVERTER</u>				IC901	8-743-971-00	IC BX3971	
DR001	1-447-210-00	CONVERTER, DC-DC		<u>JACK</u>			
DR801	1-464-156-00	CONVERTER, DC-DC (CD-02)		J901	1-507-285-00	JACK	
<u>FUSE</u>				<u>COIL</u>			
F801	1-532-350-00	FUSE, TIME-LAG 4A		L001	1-408-407-00	MICRO INDUCTOR 6.8UH	
F802	1-532-285-00	FUSE, TIME-LAG 1.25A		L002	1-408-409-00	MICRO INDUCTOR 10UH	
F803	1-532-605-00	FUSE, ELECTRIC CURRENT 0.4A		L003	1-408-409-00	MICRO INDUCTOR 10UH	
F804	1-532-637-00	FUSE, ELECTRIC CURRENT 1A		L013	1-408-458-11	MICRO INDUCTOR 220UH	
<u>FILTER</u>				L014	1-408-442-11	MICRO INDUCTOR 10UH	
FL001	1-235-097-00	FILTER, LOW PASS		L060	1-408-429-00	MICRO INDUCTOR 470UH	
<u>IC</u>				L201	1-408-519-00	COIL, CHOKE 420UH	
IC001	8-759-208-94	IC CX894		L202	1-408-519-00	COIL, CHOKE 420UH	
IC002	8-759-979-26	IC CX7926		L203	1-408-519-00	COIL, CHOKE 420UH	
IC003	8-741-102-40	IC BX1024		L401	1-459-232-00	COIL, CORE 90UH	
IC004	8-741-102-30	IC BX1023		L402	1-408-518-00	COIL, CHOKE 1MMH	
IC005	8-741-102-80	IC BX1028		<u>TRANSISTOR</u>			
IC006	8-741-102-90	IC BX1029		Q001	8-729-178-54	TRANSISTOR 2SC2785	
IC007	8-741-103-00	IC BX1030		Q002	8-729-117-54	TRANSISTOR 2SA1175	
IC008=>	8-749-910-48	IC BX1048A		Q003	8-729-178-54	TRANSISTOR 2SC2785	
IC201	8-759-103-93	IC UPC393C		Q005	8-729-113-32	TRANSISTOR 2SB733	
IC202	8-759-132-40	IC UPC324C		Q006	8-729-178-54	TRANSISTOR 2SC2785	
IC204	8-759-103-93	IC UPC393C		Q007	8-729-178-54	TRANSISTOR 2SC2785	
IC205	8-743-980-00	IC BX3980		Q201	8-729-117-54	TRANSISTOR 2SA1175	
IC206	8-743-976-00	IC BX3976		Q202	8-729-178-54	TRANSISTOR 2SC2785	
IC207	8-741-104-50	IC BX1045		Q203	8-729-178-54	TRANSISTOR 2SC2785	
IC401	8-751-940-03	IC CX194A		Q204	8-729-178-54	TRANSISTOR 2SC2785	
IC402	8-759-240-53	IC TC4053BP		Q206	8-729-178-54	TRANSISTOR 2SC2785	
IC403	8-759-132-40	IC UPC324C		Q207	8-729-178-54	TRANSISTOR 2SC2785	
IC404	8-743-983-00	IC BX3983		Q208	8-729-117-54	TRANSISTOR 2SA1175	
IC405	8-741-104-30	IC BX1043		Q209	8-729-178-54	TRANSISTOR 2SC2785	
IC406	8-759-904-94	IC TL494CN		Q210	8-729-178-54	TRANSISTOR 2SC2785	
IC407	8-759-240-51	IC TC4051BP		Q211	8-729-178-54	TRANSISTOR 2SC2785	
IC408	8-743-978-00	IC BX3978		Q212	8-729-178-54	TRANSISTOR 2SC2785	
IC409	8-743-982-20	IC BX3982-2		Q213	8-729-178-54	TRANSISTOR 2SC2785	
IC410	8-759-240-30	IC TC4030BP		Q214	8-729-178-54	TRANSISTOR 2SC2785	
IC411	8-743-977-00	IC BX3977		Q215	8-729-178-54	TRANSISTOR 2SC2785	
IC412	8-741-013-00	IC BX1013		Q216	8-729-117-54	TRANSISTOR 2SA1175	
IC601	8-759-981-40	IC MB8855-140		Q217	8-729-113-33	TRANSISTOR 2SB733-U2	
IC602	8-759-900-46	IC MB8855-161		Q218	8-729-113-33	TRANSISTOR 2SB733-U2	
IC603	8-759-987-47	IC MB8747		Q219	8-729-178-54	TRANSISTOR 2SC2785	
IC604	8-759-240-69	IC TC4069UBP		Q220	8-729-178-54	TRANSISTOR 2SC2785	
IC605	8-759-220-04	IC TC40H004P		Q221	8-729-178-54	TRANSISTOR 2SC2785	
IC606	8-759-240-13	IC TC4013BP		Q222	8-729-178-54	TRANSISTOR 2SC2785	
IC607	8-741-104-70	IC BX1047		Q223	8-729-178-54	TRANSISTOR 2SC2785	
IC608	8-759-133-90	IC UPC339C		Q224	8-729-117-54	TRANSISTOR 2SA1175	
IC609	8-741-104-60	IC BX1046		Q225	8-729-113-33	TRANSISTOR 2SB733-U2	
				Q226	8-729-113-33	TRANSISTOR 2SB733-U2	
				Q227	8-729-178-54	TRANSISTOR 2SC2785	

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

MA-3

Ref.No	Part No	Description	Remark	Ref.No	Part No	Description	Remark
Q228	8-729-178-54	TRANSISTOR 2SC2785		R006	1-246-805-00	CARBON 68K	1/8W
Q229	8-729-178-54	TRANSISTOR 2SC2785		R007	1-246-842-00	CARBON 750	1/8W
Q230	8-729-117-54	TRANSISTOR 2SA1175		R008	1-246-795-00	CARBON 10K	1/8W
Q401	8-729-178-54	TRANSISTOR 2SC2785		R009	1-246-783-00	CARBON 1K	1/8W
Q402	8-729-177-32	TRANSISTOR 2SD773		R011	1-246-786-00	CARBON 1.8K	1/8W
Q403	8-729-113-33	TRANSISTOR 2SB733-U2		R013	1-246-834-00	CARBON 160	1/8W
Q404	8-729-117-54	TRANSISTOR 2SA1175		R015	1-246-779-00	CARBON 470	1/8W
Q405	8-729-178-54	TRANSISTOR 2SC2785		R016	1-246-783-00	CARBON 1K	1/8W
Q406	8-729-178-54	TRANSISTOR 2SC2785		R017	1-246-777-00	CARBON 330	1/8W
Q407	8-729-178-54	TRANSISTOR 2SC2785		R019	1-246-779-00	CARBON 470	1/8W
Q408	8-729-117-54	TRANSISTOR 2SA1175		R021	1-246-803-00	CARBON 47K	1/8W
Q409	8-729-178-54	TRANSISTOR 2SC2785		R022	1-246-803-00	CARBON 47K	1/8W
Q411	8-729-178-54	TRANSISTOR 2SC2785		R023	1-246-795-00	CARBON 10K	1/8W
Q415	8-729-178-54	TRANSISTOR 2SC2785		R024	1-246-798-00	CARBON 18K	1/8W
Q421	8-729-178-54	TRANSISTOR 2SC2785		R025	1-246-802-00	CARBON 39K	1/8W
Q422	8-729-178-54	TRANSISTOR 2SC2785		R026	1-246-802-00	CARBON 39K	1/8W
Q424	8-729-117-54	TRANSISTOR 2SA1175		R027	1-246-795-00	CARBON 10K	1/8W
Q426	8-729-178-54	TRANSISTOR 2SC2785		R028	1-246-803-00	CARBON 47K	1/8W
Q601	8-729-113-32	TRANSISTOR 2SB733		R029	1-246-791-00	CARBON 4.7K	1/8W
Q602	8-729-113-32	TRANSISTOR 2SB733		R030	1-246-856-00	CARBON 11K	1/8W
Q603	8-729-178-54	TRANSISTOR 2SC2785		R031	1-246-782-00	CARBON 820	1/8W
Q604	8-729-178-54	TRANSISTOR 2SC2785		R036	1-246-799-00	CARBON 22K	1/8W
Q605	8-729-117-54	TRANSISTOR 2SA1175		R037	1-246-807-00	CARBON 100K	1/8W
Q606	8-729-113-32	TRANSISTOR 2SB733		R038	1-246-799-00	CARBON 22K	1/8W
Q607	8-729-113-32	TRANSISTOR 2SB733		R039	1-246-804-00	CARBON 56K	1/8W
Q608	8-729-178-54	TRANSISTOR 2SC2785		R048	1-246-802-00	CARBON 39K	1/8W
Q609	8-729-178-54	TRANSISTOR 2SC2785		R049	1-246-804-00	CARBON 56K	1/8W
Q610	8-729-178-54	TRANSISTOR 2SC2785		R050	1-246-783-00	CARBON 1K	1/8W
Q611	8-729-113-32	TRANSISTOR 2SB733		R051	1-246-801-00	CARBON 33K	1/8W
Q612	8-729-177-32	TRANSISTOR 2SD773		R052	1-246-804-00	CARBON 56K	1/8W
Q613	8-729-113-32	TRANSISTOR 2SB733		R053	1-246-869-00	CARBON 130K	1/8W
Q614	8-729-177-32	TRANSISTOR 2SD773		R054	1-246-811-00	CARBON 220K	1/8W
Q615	8-729-178-54	TRANSISTOR 2SC2785		R055	1-246-802-00	CARBON 39K	1/8W
Q616	8-729-116-42	TRANSISTOR 2SD1164		R057	1-246-830-00	CARBON 75	1/8W
Q618	8-729-117-54	TRANSISTOR 2SA1175		R058	1-246-803-00	CARBON 47K	1/8W
Q619	8-729-178-54	TRANSISTOR 2SC2785		R059	1-246-799-00	CARBON 22K	1/8W
Q623	8-729-178-54	TRANSISTOR 2SC2785		R061	1-246-805-00	CARBON 68K	1/8W
Q624	8-729-178-54	TRANSISTOR 2SC2785		R062	1-246-863-00	CARBON 43K	1/8W
Q625	8-729-178-54	TRANSISTOR 2SC2785		R201	1-246-785-00	CARBON 1.5K	1/8W
Q631	8-729-178-54	TRANSISTOR 2SC2785		R202	1-246-785-00	CARBON 1.5K	1/8W
Q634	8-729-178-54	TRANSISTOR 2SC2785		R203	1-246-799-00	CARBON 22K	1/8W
Q801	8-729-178-54	TRANSISTOR 2SC2785		R204	1-246-799-00	CARBON 22K	1/8W
Q803	8-729-178-54	TRANSISTOR 2SC2785		R211	1-246-803-00	CARBON 47K	1/8W
Q805 =>	8-729-113-32	TRANSISTOR 2SB733		R214	1-247-055-00	CARBON 300K	1/8W
Q807	8-729-178-54	TRANSISTOR 2SC2785		R215	1-246-809-00	CARBON 150K	1/8W
Q808	8-729-178-54	TRANSISTOR 2SC2785		R216	1-246-807-00	CARBON 100K	1/8W
		<u>RESISTOR</u>		R217	1-246-803-00	CARBON 47K	1/8W
R001	1-246-830-00	CARBON 75	1/8W	R218	1-246-859-00	CARBON 20K	1/8W
R002	1-246-783-00	CARBON 1K	1/8W	R219	1-246-788-00	CARBON 2.7K	1/8W
R003	1-246-783-00	CARBON 1K	1/8W	R220	1-246-793-00	CARBON 6.8K	1/8W
R004	1-246-783-00	CARBON 1K	1/8W	R221	1-246-803-00	CARBON 47K	1/8W
R005	1-246-797-00	CARBON 15K	1/8W	R222	1-246-794-00	CARBON 8.2K	1/8W
				R223	1-246-785-00	CARBON 1.5K	1/8W

When indicating parts by reference number, please include the board name.

Ref.No	Part No	Description	Remark	Ref.No	Part No	Description	Remark		
R224	1-246-847-00	CARBON	2K	1/8W	R413	1-246-803-00	CARBON	47K	1/8W
R226	1-246-798-00	CARBON	18K	1/8W	R414	1-246-801-00	CARBON	33K	1/8W
R227	1-246-783-00	CARBON	1K	1/8W	R415	1-246-795-00	CARBON	10K	1/8W
R228	1-246-854-00	CARBON	7.5K	1/8W	R416	1-246-807-00	CARBON	100K	1/8W
R229	1-246-791-00	CARBON	4.7K	1/8W	R417	1-246-807-00	CARBON	100K	1/8W
R230	1-246-803-00	CARBON	47K	1/8W	R418	1-246-801-00	CARBON	33K	1/8W
R231	1-246-791-00	CARBON	4.7K	1/8W	R423	1-246-807-00	CARBON	100K	1/8W
R232	1-246-803-00	CARBON	47K	1/8W	R424	1-246-807-00	CARBON	100K	1/8W
R236	1-246-807-00	CARBON	100K	1/8W	R427	1-246-852-00	CARBON	5.1K	1/8W
R237	1-246-783-00	CARBON	1K	1/8W	R428	△ 1-212-356-00	METAL	0.47	5% 1W F
R238	1-246-799-00	CARBON	22K	1/8W	R429	1-246-837-00	CARBON	300	1/8W
R241	1-246-799-00	CARBON	22K	1/8W	R430	1-246-787-00	CARBON	2.2K	1/8W
R242	1-246-799-00	CARBON	22K	1/8W	R431	1-246-792-00	CARBON	5.6K	1/8W
R243	1-246-795-00	CARBON	10K	1/8W	R432	1-246-803-00	CARBON	47K	1/8W
R245	1-246-449-00	CARBON	100	5% 1/4W	R439	1-214-178-00	METAL	82K	1% 1/4W
R246	1-246-457-00	CARBON	220	5% 1/4W	R440	1-246-807-00	CARBON	100K	1/8W
R255	1-244-861-00	CARBON	330	5% 1/2W	R444	1-246-801-00	CARBON	33K	1/8W
R256	1-246-783-00	CARBON	1K	1/8W	R445	1-246-801-00	CARBON	33K	1/8W
R257	△ 1-217-612-00	WIREWOUND	0.1	2W	R446	1-246-418-00	CARBON	5.1	5% 1/4W
R258	1-246-801-00	CARBON	33K	1/8W	R448	1-246-783-00	CARBON	1K	1/8W
R259	1-246-801-00	CARBON	33K	1/8W	R449	1-246-797-00	CARBON	15K	1/8W
R260	1-246-860-00	CARBON	24K	1/8W	R450	1-246-799-00	CARBON	22K	1/8W
R261	1-246-800-00	CARBON	27K	1/8W	R451	1-246-803-00	CARBON	47K	1/8W
R264	1-247-049-00	CARBON	470K	1/8W	R452	1-246-769-00	CARBON	68	1/8W
R268	1-246-795-00	CARBON	10K	1/8W	R457	1-246-800-00	CARBON	27K	1/8W
R271	1-247-057-00	CARBON	430K	1/8W	R458	1-246-866-00	CARBON	75K	1/8W
R273	1-246-795-00	CARBON	10K	1/8W	R459	1-246-807-00	CARBON	100K	1/8W
R294	1-246-795-00	CARBON	10K	1/8W	R462	1-246-810-00	CARBON	180K	1/8W
R295	1-246-449-00	CARBON	100	5% 1/4W	R463	1-246-801-00	CARBON	33K	1/8W
R296	1-246-457-00	CARBON	220	5% 1/4W	R465	1-246-810-00	CARBON	180K	1/8W
R303	1-244-861-00	CARBON	330	5% 1/2W	R472	1-246-788-00	CARBON	2.7K	1/8W
R306	1-246-783-00	CARBON	1K	1/8W	R477	1-246-795-00	CARBON	10K	1/8W
R307	1-247-049-00	CARBON	470K	1/8W	R478	1-246-783-00	CARBON	1K	1/8W
R308	1-246-803-00	CARBON	47K	1/8W	R480	1-246-795-00	CARBON	10K	1/8W
R309	1-246-783-00	CARBON	1K	1/8W	R495	1-246-795-00	CARBON	10K	1/8W
R310	1-246-811-00	CARBON	220K	1/8W	R496	1-246-795-00	CARBON	10K	1/8W
R311	1-246-803-00	CARBON	47K	1/8W	R504	1-246-797-00	CARBON	15K	1/8W
R312	1-246-851-00	CARBON	4.3K	1/8W	R505	1-246-779-00	CARBON	470	1/8W
R313	1-246-803-00	CARBON	47K	1/8W	R510	1-246-444-00	CARBON	62	5% 1/4W
R314	1-246-803-00	CARBON	47K	1/8W	R513	1-246-791-00	CARBON	4.7K	1/8W
R315	1-246-795-00	CARBON	10K	1/8W	R515	1-246-811-00	CARBON	220K	1/8W
R316	1-246-803-00	CARBON	47K	1/8W	R516	1-246-791-00	CARBON	4.7K	1/8W
R320	1-246-801-00	CARBON	33K	1/8W	R518	1-246-795-00	CARBON	10K	1/8W
R321	1-246-863-00	CARBON	43K	1/8W	R522	1-214-549-00	METAL	470	1% 1/8W
R322	1-246-797-00	CARBON	15K	1/8W	R523	1-246-791-00	CARBON	4.7K	1/8W
R323	1-246-798-00	CARBON	18K	1/8W	R524	1-246-784-00	CARBON	1.2K	1/8W
R324	1-246-789-00	CARBON	3.3K	1/8W	R525	1-246-844-00	CARBON	1.1K	1/8W
R401	1-246-783-00	CARBON	1K	1/8W	R526	1-246-861-00	CARBON	30K	1/8W
R402	1-246-799-00	CARBON	22K	1/8W	R527	1-246-786-00	CARBON	1.8K	1/8W
R404	1-246-859-00	CARBON	20K	1/8W	R528	1-246-848-00	CARBON	2.4K	1/8W
R405	1-246-803-00	CARBON	47K	1/8W	R529	1-246-779-00	CARBON	470	1/8W
R406	1-246-797-00	CARBON	15K	1/8W	R531	1-246-787-00	CARBON	2.2K	1/8W
R407	1-246-783-00	CARBON	1K	1/8W	R532	1-246-803-00	CARBON	47K	1/8W

The components identified by shading and mark △ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

MA-3

Ref.No	Part No	Description		Remark	Ref.No	Part No	Description		Remark
R537	1-246-795-00	CARBON	10K	1/8W	R630	1-246-801-00	CARBON	33K	1/8W
R540	1-246-795-00	CARBON	10K	1/8W	R631	1-246-801-00	CARBON	33K	1/8W
R542	1-246-844-00	CARBON	1.1K	1/8W	R639	1-246-791-00	CARBON	4.7K	1/8W
R543	1-246-807-00	CARBON	100K	1/8W	R640	1-246-781-00	CARBON	680	1/8W
R544	1-246-795-00	CARBON	10K	1/8W	R641	1-246-807-00	CARBON	100K	1/8W
R546	1-246-803-00	CARBON	47K	1/8W	R642	1-246-795-00	CARBON	10K	1/8W
R547	1-246-799-00	CARBON	22K	1/8W	R643	1-246-795-00	CARBON	10K	1/8W
R548	1-246-795-00	CARBON	10K	1/8W	R644	1-247-053-00	CARBON	1M	1/8W
R551	1-246-799-00	CARBON	22K	1/8W	R645	1-246-801-00	CARBON	33K	1/8W
R553	1-246-851-00	CARBON	4.3K	1/8W	R646	1-246-787-00	CARBON	2.2K	1/8W
R554	1-246-799-00	CARBON	22K	1/8W	R647	1-246-787-00	CARBON	2.2K	1/8W
R555	1-246-853-00	CARBON	6.2K	1/8W	R649	1-246-787-00	CARBON	2.2K	1/8W
R559	1-246-795-00	CARBON	10K	1/8W	R650	1-246-795-00	CARBON	10K	1/8W
R560	1-246-803-00	CARBON	47K	1/8W	R651	1-246-795-00	CARBON	10K	1/8W
R561	1-246-799-00	CARBON	22K	1/8W	R653	1-246-795-00	CARBON	10K	1/8W
R566	1-246-803-00	CARBON	47K	1/8W	R654	1-246-795-00	CARBON	10K	1/8W
R567	1-246-783-00	CARBON	1K	1/8W	R655	1-247-047-00	CARBON	330K	1/8W
R569	1-246-795-00	CARBON	10K	1/8W	R660	1-246-795-00	CARBON	10K	1/8W
R570	1-246-795-00	CARBON	10K	1/8W	R661	1-246-801-00	CARBON	33K	1/8W
R571	1-246-801-00	CARBON	33K	1/8W	R663	1-246-799-00	CARBON	22K	1/8W
R572	1-246-862-00	CARBON	36K	1/8W	R671	1-246-795-00	CARBON	10K	1/8W
R573	1-246-858-00	CARBON	16K	1/8W	R672	1-246-803-00	CARBON	47K	1/8W
R574	1-246-805-00	CARBON	68K	1/8W	R673	1-246-804-00	CARBON	56K	1/8W
R575	1-246-791-00	CARBON	4.7K	1/8W	R674	1-246-795-00	CARBON	10K	1/8W
R580	1-246-792-00	CARBON	5.6K	1/8W	R675	1-246-790-00	CARBON	3.9K	1/8W
R581	1-246-792-00	CARBON	5.6K	1/8W	R676	1-246-859-00	CARBON	20K	1/8W
R601	1-246-457-00	CARBON	220	5% 1/4W	R678	1-246-795-00	CARBON	10K	1/8W
R602	1-246-457-00	CARBON	220	5% 1/4W	R803	1-246-795-00	CARBON	10K	1/8W
R603	1-246-795-00	CARBON	10K	1/8W	R805	1-246-801-00	CARBON	33K	1/8W
R604	1-246-783-00	CARBON	1K	1/8W	R806	1-246-789-00	CARBON	3.3K	1/8W
R605	1-246-413-00	CARBON	3.3	5% 1/4W F	R807	1-246-801-00	CARBON	33K	1/8W
R606	1-246-803-00	CARBON	47K	1/8W	R810	1-246-803-00	CARBON	47K	1/8W
R607	1-246-457-00	CARBON	220	5% 1/4W	R811	1-246-795-00	CARBON	10K	1/8W
R608	1-246-457-00	CARBON	220	5% 1/4W	R812	1-246-807-00	CARBON	100K	1/8W
R609	1-246-795-00	CARBON	10K	1/8W	R813	1-246-469-00	CARBON	680	5% 1/4W
R610	1-246-795-00	CARBON	10K	1/8W	R814	1-246-807-00	CARBON	100K	1/8W
R611	1-246-795-00	CARBON	10K	1/8W	R821	1-246-783-00	CARBON	1K	1/8W
R612	1-246-795-00	CARBON	10K	1/8W	R827	1-246-795-00	CARBON	10K	1/8W
R613	1-246-789-00	CARBON	3.3K	1/8W	R901	1-246-783-00	CARBON	1K	1/8W
R614	1-246-789-00	CARBON	3.3K	1/8W	R902	1-246-783-00	CARBON	1K	1/8W
R615	1-246-799-00	CARBON	22K	1/8W	R903	1-246-799-00	CARBON	22K	1/8W
R616	1-246-789-00	CARBON	3.3K	1/8W	R904	1-246-871-00	CARBON	200K	1/8W
R617	1-246-843-00	CARBON	910	1/8W	R905	1-246-871-00	CARBON	200K	1/8W
R618	1-247-587-00	CARBON	0.47	5% 1/4W	R906	1-246-807-00	CARBON	100K	1/8W
R619	1-246-789-00	CARBON	3.3K	1/8W	R907	1-246-799-00	CARBON	22K	1/8W
R620	1-246-843-00	CARBON	910	1/8W	R908	1-246-859-00	CARBON	20K	1/8W
R622	1-246-801-00	CARBON	33K	1/8W	R909	1-246-859-00	CARBON	20K	1/8W
R623	1-246-800-00	CARBON	27K	1/8W	R910	1-246-785-00	CARBON	1.5K	1/8W
R625	1-246-799-00	CARBON	22K	1/8W	R911	1-246-787-00	CARBON	2.2K	1/8W
R626	1-246-799-00	CARBON	22K	1/8W	R920	1-246-789-00	CARBON	3.3K	1/8W
R627	1-246-801-00	CARBON	33K	1/8W	R921	1-246-796-00	CARBON	12K	1/8W
R628	1-246-865-00	CARBON	62K	1/8W	R922	1-246-793-00	CARBON	6.8K	1/8W
R629	1-246-801-00	CARBON	33K	1/8W	R923	1-246-791-00	CARBON	4.7K	1/8W

The components identified by shading and mark **▲** are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

07-MJ

8-MJ

MA-3

FR-4

Ref.No	Part No	Description	Remark
R924	1-246-807-00	CARBON 100K	1/8W
R926	1-246-797-00	CARBON 15K	1/8W
R927	1-246-787-00	CARBON 2.2K	1/8W
R928	1-246-810-00	CARBON 180K	1/8W
R929	1-246-792-00	CARBON 5.6K	1/8W
R930	1-246-799-00	CARBON 22K	1/8W
<u>VARIABLE RESISTOR</u>			
RV001	1-226-774-00	RES, ADJ, METAL GLAZE	47K
RV002	1-226-702-00	RES, ADJ, METAL GLAZE	2.2K
RV003	1-226-774-00	RES, ADJ, METAL GLAZE	47K
RV004	1-226-771-00	RES, ADJ, METAL GLAZE	1K
RV005	1-226-774-00	RES, ADJ, METAL GLAZE	47K
RV006	1-226-703-00	RES, ADJ, METAL GLAZE	10K
RV007	1-226-772-00	RES, ADJ, METAL GLAZE	4.7K
RV201	1-226-774-00	RES, ADJ, METAL GLAZE	47K
RV202	1-226-773-00	RES, ADJ, METAL GLAZE	22K
RV401	1-226-753-00	RES, ADJ, SOLID	47K
RV402	1-224-254-XX	RES, ADJ, METAL GLAZE	47K
RV403	1-226-753-00	RES, ADJ, SOLID	47K
RV405	1-226-703-00	RES, ADJ, METAL GLAZE	10K
RV407	1-226-703-00	RES, ADJ, METAL GLAZE	10K
RV409	1-226-703-00	RES, ADJ, METAL GLAZE	10K
RV410	1-226-771-00	RES, ADJ, METAL GLAZE	1K
RV413	1-226-774-00	RES, ADJ, METAL GLAZE	47K
RV414	1-226-753-00	RES, ADJ, SOLID	47K
RV415	1-226-774-00	RES, ADJ, METAL GLAZE	47K
RV416	1-226-702-00	RES, ADJ, METAL GLAZE	2.2K
RV417	1-226-702-00	RES, ADJ, METAL GLAZE	2.2K
RV420	1-226-702-00	RES, ADJ, METAL GLAZE	2.2K
RV601	1-226-711-00	RES, ADJ, SOLID	22K
<u>RELAY</u>			
RY801	1-515-323-00	RELAY	
<u>THERMISTOR</u>			
TH201	1-800-200-00	THERMISTOR S-3K	
TH401	1-800-200-00	THERMISTOR S-3K	
<u>CRYSTAL</u>			
X601	1-527-822-00	OSCILLATOR, CERAMIC	4.00MS

♣:A-6717-251-A	FR-4 BOARD, COMPLETE *****		
♣:1-548-562-00	COUNTER MODULE, TAPE		
♣:2-283-410-00	HOLDER (A), LED		
♣:3-670-095-00	HOLDER, LED		
<u>CAPACITOR</u>			
C001	1-123-611-00	ELECT	1MF 20% 50V

Ref.No	Part No	Description	Remark
C002	1-161-013-00	CERAMIC	0.01MF 10% 25V
C003	1-123-618-00	ELECT	22MF 20% 6.3V
C004	1-161-013-00	CERAMIC	0.01MF 10% 25V
C005	1-161-017-00	CERAMIC	0.022MF 10% 25V
C006	1-123-617-00	ELECT	10MF 20% 16V
C007	1-161-013-00	CERAMIC	0.01MF 10% 25V
C008	1-101-006-00	CERAMIC	0.047MF 50V
C009	1-161-021-00	CERAMIC	0.047MF 10% 25V
C010	1-161-020-00	CERAMIC	0.039MF 10% 25V
C011	1-161-039-00	CERAMIC	0.001MF 10% 25V
C012	1-161-039-00	CERAMIC	0.001MF 10% 25V
C013	1-161-039-00	CERAMIC	0.001MF 10% 25V
C014	1-161-039-00	CERAMIC	0.001MF 10% 25V
C015	1-161-013-00	CERAMIC	0.01MF 10% 25V
C016	1-123-616-11	ELECT	4.7MF 20% 25V
C017	1-161-025-00	CERAMIC	0.1MF 10% 25V
<u>CONNECTOR</u>			
CN001	♣:1-560-569-00	PIN, CONNECTOR 11P	
CN002	♣:1-560-570-00	PIN, CONNECTOR 4P	
<u>DIODE</u>			
D001	=>8-719-914-33	DIODE PG3432SY	
D002	8-719-130-07	DIODE RD3.0E-B	
D006	8-719-113-07	DIODE RD13E-B	
D007	8-719-113-07	DIODE RD13E-B	
D008	8-719-113-07	DIODE RD13E-B	
D009	8-719-113-07	DIODE RD13E-B	
D010	8-719-113-07	DIODE RD13E-B	
D011	8-719-113-07	DIODE RD13E-B	
D012	8-719-113-07	DIODE RD13E-B	
D013	8-719-113-07	DIODE RD13E-B	
D014	8-719-113-07	DIODE RD13E-B	
D015	8-719-113-07	DIODE RD13E-B	
D017	8-719-113-07	DIODE RD13E-B	
D018	8-719-911-06	DIODE 1SS106	
D019	8-719-911-06	DIODE 1SS106	
D021	=>8-719-914-02	DIODE BR3402S	
D022	=>8-719-903-42	DIODE AY3432S	
D023	=>8-719-903-42	DIODE AY3432S	
D024	=>8-719-903-42	DIODE AY3432S	
D025	=>8-719-934-34	DIODE AA3432S	
D026	=>8-719-914-33	DIODE PG3432SY	
D027	=>8-719-914-02	DIODE BR3402S	
D028	8-719-118-07	DIODE RD18E-B	
D029	8-719-113-07	DIODE RD13E-B	
D031	=>8-719-901-33	DIODE 1SS133	
D036	8-719-911-06	DIODE 1SS106	
<u>IC</u>			
IC001	8-759-986-39	IC MB8855-139	
IC002	8-759-987-47	IC MB8747	

When indicating parts by reference number, please include the board name.

FR-4

EH-3

LM-8

LM-10

Ref.No	Part No	Description	Remark
<u>TRANSISTOR</u>			
Q001	8-729-178-54	TRANSISTOR 2SC2785	
Q002	8-729-178-54	TRANSISTOR 2SC2785	
Q003	8-729-178-54	TRANSISTOR 2SC2785	
Q004	8-729-178-54	TRANSISTOR 2SC2785	
Q005	8-729-902-11	TRANSISTOR 2SC2021	
Q006	8-729-902-11	TRANSISTOR 2SC2021	
Q007	8-729-178-54	TRANSISTOR 2SC2785	
Q008	8-729-178-54	TRANSISTOR 2SC2785	
Q009	8-729-902-11	TRANSISTOR 2SC2021	
Q010	8-729-902-11	TRANSISTOR 2SC2021	
Q011	8-729-902-11	TRANSISTOR 2SC2021	
Q012	8-729-902-11	TRANSISTOR 2SC2021	
Q013	8-729-902-11	TRANSISTOR 2SC2021	
Q014	8-729-178-54	TRANSISTOR 2SC2785	
Q015	8-729-178-54	TRANSISTOR 2SC2785	
Q016	8-729-902-11	TRANSISTOR 2SC2021	
Q017	8-729-902-11	TRANSISTOR 2SC2021	
Q018	8-729-902-11	TRANSISTOR 2SC2021	
<u>RESISTOR</u>			
R001	1-246-783-00	CARBON 1K	1/8W
R002	1-246-789-00	CARBON 3.3K	1/8W
R003	1-246-799-00	CARBON 22K	1/8W
R004	1-246-803-00	CARBON 47K	1/8W
R005	1-246-801-00	CARBON 33K	1/8W
R006	1-246-795-00	CARBON 10K	1/8W
R007	1-246-801-00	CARBON 33K	1/8W
R008	1-246-799-00	CARBON 22K	1/8W
R009	1-246-799-00	CARBON 22K	1/8W
R010	1-246-799-00	CARBON 22K	1/8W
R011	1-246-799-00	CARBON 22K	1/8W
R012	1-246-854-00	CARBON 7.5K	1/8W
R013	1-246-854-00	CARBON 7.5K	1/8W
R014	1-246-801-00	CARBON 33K	1/8W
R015	1-246-801-00	CARBON 33K	1/8W
R016	1-246-801-00	CARBON 33K	1/8W
R017	1-246-777-00	CARBON 330	1/8W
R018	1-246-781-00	CARBON 680	1/8W
R019	1-246-777-00	CARBON 330	1/8W
R020	1-246-795-00	CARBON 10K	1/8W
R021	1-246-801-00	CARBON 33K	1/8W
R022	1-246-801-00	CARBON 33K	1/8W
R023	1-246-801-00	CARBON 33K	1/8W
R024	1-246-801-00	CARBON 33K	1/8W
R025	1-244-857-00	CARBON 220 5%	1/2W
R026	1-246-801-00	CARBON 33K	1/8W
R027	1-246-801-00	CARBON 33K	1/8W
R029	1-246-807-00	CARBON 100K	1/8W
R030	1-246-800-00	CARBON 27K	1/8W
R031	1-246-795-00	CARBON 10K	1/8W
R033	1-244-857-00	CARBON 220 5%	1/2W

Ref.No	Part No	Description	Remark
R040	1-246-795-00	CARBON 10K	1/8W
<u>VARIABLE RESISTOR</u>			
RV001	1-228-603-00	RES, VAR, CARBON 100K	
<u>SWITCH</u>			
S001	1-553-766-00	SWITCH, KEY BOARD	
S002	1-553-766-00	SWITCH, KEY BOARD	
S003	1-553-766-00	SWITCH, KEY BOARD	
S004	1-553-766-00	SWITCH, KEY BOARD	
S005	1-553-766-00	SWITCH, KEY BOARD	
S006	1-553-766-00	SWITCH, KEY BOARD	
S007	1-553-766-00	SWITCH, KEY BOARD	
S008	1-553-766-00	SWITCH, KEY BOARD	
S009	1-553-766-00	SWITCH, KEY BOARD	
S010	1-553-766-00	SWITCH, KEY BOARD	
S011	1-553-766-00	SWITCH, KEY BOARD	
S012	1-553-766-00	SWITCH, KEY BOARD	
S013	1-553-766-00	SWITCH, KEY BOARD	
S014	1-553-766-00	SWITCH, KEY BOARD	
S015	1-553-766-00	SWITCH, KEY BOARD	
S016	1-553-766-00	SWITCH, KEY BOARD	
S017	1-553-766-00	SWITCH, KEY BOARD	
S018	1-553-716-00	SWITCH, SLIDE	

	▲:1-607-162-00	EH-3 BOARD	*****
<u>JACK</u>			
J910	1-507-251-XX	JACK	

	▲:1-605-071-00	LM-8 BOARD	*****
<u>CAPACITOR</u>			
C001	1-161-057-00	CERAMIC 0.033MF	10% 50V
C002	1-161-057-00	CERAMIC 0.033MF	10% 50V
<u>COIL</u>			
L001	1-408-120-00	MICRO INDUCTOR 18UH	
L002	1-408-120-00	MICRO INDUCTOR 18UH	

	1-605-664-00	LM-10 BOARD	*****
<u>RESISTOR</u>			
R001	1-206-479-00	METAL 47 5% 2W	F

When indicating parts by reference number, please include the board name.

Ref.No	Part No	Description	Remark		
▲	1-606-731-00	SL-3 BOARD *****			
<u>CAPACITOR</u>					
C001	1-102-960-00	CERAMIC	24PF	5%	50V
C002	1-102-960-00	CERAMIC	24PF	5%	50V
C003	1-161-021-00	CERAMIC	0.047MF	10%	25V
C004	1-161-021-00	CERAMIC	0.047MF	10%	25V
C005	1-102-948-00	CERAMIC	11PF	5%	50V
C006	1-161-013-00	CERAMIC	0.01MF	10%	25V
C007	1-123-645-00	ELECT	33MF	20%	10V
C008	1-161-021-00	CERAMIC	0.047MF	10%	25V
<u>DIODE</u>					
D001	=>8-719-911-19	DIODE 1SS119			
D002	=>8-719-911-19	DIODE 1SS119			
<u>IC</u>					
IC001	8-759-200-60	IC TA7060AP			
<u>COIL</u>					
L001	1-408-415-00	MICRO INDUCTOR 33UH			
L002	1-408-408-00	MICRO INDUCTOR 8.2UH			
<u>RESISTOR</u>					
R001	1-246-782-00	CARBON	820		1/8W
R002	1-246-782-00	CARBON	820		1/8W
R003	1-246-783-00	CARBON	1K		1/8W
R004	1-246-783-00	CARBON	1K		1/8W

MISCELLANEOUS

A-6737-090-A	MOTOR ASSY, L
▲ A-6749-058-A	SOLENOID BLOCK ASSY, PINCH
A-6761-045-A	ACE ASSY (M-3)
1-235-054-00	COIL, SENSOR, S
1-235-055-00	COIL, SENSOR, T
1-446-961-00	HEATER, PTC
▲ 1-454-281-00	SOLENOID, PLUNGER
1-464-186-00	RP BLOCK (RP-1-P-2)
1-553-717-00	SWITCH, MICRO
1-553-718-00	SWITCH, MICRO
1-605-077-00	FC-1 BOARD
1-605-078-00	FC-3 BOARD
1-806-354-00	SENSOR, DEW CONDENSATION
8-825-508-10	HEAD, FE
8-838-021-02	MOTOR, DC (BHF-1800A)
8-838-027-00	MOTOR, DC (BHF-1901A)

Part.No	Description	Remark
ACCESSORIES AND PACKING MATERIALS *****		
1-504-059-11	MAGNETIC EARPHONE (ME-20H)	
1-551-513-00	CABLE, COAXIAL ASSY	
3-656-301-00	SCREWDRIVER, CONTROL	
3-669-635-00	BAG, PROTECTION	
3-671-419-03	LID, CASE, ACCESSORY	
3-671-424-00	CASE, ACCESSORY	
3-672-323-00	INDIVIDUAL CARTON	
3-672-325-00	CUSHION (LEFT UPPER)	
3-672-326-00	CUSHION (RIGHT UPPER)	
3-672-327-00	CUSHION (LEFT LOWER)	
3-672-328-00	CUSHION (RIGHT LOWER)	
3-701-628-00	BAG, POLYETHYLENE	
3-701-630-00	BAG, POLYETHYLENE	
3-783-868-11	MANUAL, INSTRUCTION	

The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

SONY[®] SERVICE MANUAL

AEP Model


June, 1982

CORRECTION-1

File this correction with the service manual.

SECTION 4 EXPLODED VIEWS

(10) DRUM ASSEMBLY



PAGE	CORRECT		INCORRECT	
138	458	A-6050-126-A DSH-22A-R	458	A-6050-128-A DSH-22A-C
	461	A-6762-072-A DISK ASSY, DSR-22R	461	A-6762-073-A DISK ASSY, DSR-22



9-972-167-91



Sony Corporation
Audio & Video Group © 1982

English
82F0965-1
Printed in Japan

ADJUSTMENT MANUAL

AEP Model
 UK Model
 E Model



July, 1982

711P CHASSIS

SPECIFICATIONS

System

Video recording system	Rotary two-head helical scanning
Video signal	CCIR standard, PAL colour
RF output signal	UHF channels 30-39 (variable) 75 ohms, unbalanced
Usable cassettes	Cassettes with the B mark
Tape speed	18.73 mm/sec.
Maximum recording time	2 hours 10 min. (with Sony L-500 cassette) 3 hours 15 min. (with Sony L-750 cassette)
Fast forward/rewind time	Under 3½ min. (with L-500 cassette)
Horizontal resolution	Colour: 260 lines B/W: 300 lines
Video S/N	Colour: Better than 40 dB B/W: Better than 43 dB
Audio frequency response	50 Hz to 10 000 Hz
Audio S/N	Better than 40 dB

Inputs and outputs

CAMERA connector	14-pin, K-type connector
	Video in: 1 V p-p ±0.5 V p-p 75 ohms unbalanced, sync negative
	Video out: 1 V p-p ±0.1 V p-p 75 ohm unbalanced, sync negative
	Audio in: -20 dBs (0 dBs = 0.775 V rms)
	Audio out: -5 dBs (at load impedance 100 kilohms) output impedance: less than 10 kilohms
	Power supply output: 12 V dc
ACCESSORY CONNECTOR	26-pin connector
	Video in: 1 V p-p ±0.5 V p-p 75 ohms unbalanced, sync negative
	Video out: 1 V p-p ±0.1 V p-p 75 ohms unbalanced, sync negative

Microphone input

Earpiece output

General

Power requirements	12 V dc ±10%
Power consumption	8.4 W (dc, record mode without camera)
Operating position	vertical or horizontal
Operating temperature	0°C to 40°C (32°F to 104°F)
Storage temperature	-20°C to +65°C (-4°F to +149°F)
Dimensions	Approx: 215 × 80 × 325 mm (w/h/d) (8½ × 3¼ × 12⅞ inches) not incl. projecting parts and controls
Weight	Approx. 4.3 kg (9 lb 8 oz) net

Audio in: -10 dBs
input impedance 100 kilohms

Audio out: -5 dBs (at load impedance 100 kilohms)
output impedance: less than 10 kilohms

Power supply input: 12 V dc
Minijack
-60 dBs, for low-impedance microphone
Minijack
-26 dBs, for 8-ohm earpiece



MICROFILM

Consumer
VIDEO

Beta
B PORTABLE VIDEO
 CASSETTE RECORDER
 SONY®

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
1. CHECKING, ALIGNMENT AND REPLACEMENT OF MECHANICAL SECTION			3-10.	Adjustment of No. 2 and 3 Guide Heights	19
1-1.	Removal of the Case	3	3-11.	Checking and Adjustment of Pinch Closing Limiter Clearance (Checking Procedure) ..	19
1-1-1.	Removal of Panel Assembly	3	3-12.	Brake Operation Check and Brake Plunger Adjustment	20
1-1-2.	Removal of Front Panel	4	3-13.	Checking and Adjustment of Microswitch Position	21
1-1-3.	Removal of the Mechanism Chassis ...	4	3-13-1.	Checking and Adjustment of Threading End Switch (TE Switch) Position	21
1-2.	Precautions when Servicing	5	3-13-2.	Checking and Adjustment of Unthreading End Switch (UTE Switch) Position ...	21
1-3.	Mechanical Operation without Cassette Installed	5	3-14.	Forward/Back Tension Measurement	23
1-3-1.	Completing Threading without Cassette (This state is called "STOP mode" in this guide.)	5	3-14-1.	Measurement Procedure	23
1-3-2.	Setting Playback without Cassette Installed	5	3-14-2.	Adjustment Procedure	23
1-3-3.	Setting Record Mode without a Cassette	5	4. TAPE PATH ADJUSTMENT		
1-4.	List of Service Units and Tools for SL-F1E	6	4-1.	Tracking Adjustment	25
2. PERIODIC CHECK AND MAINTENANCE			4-1-1.	Preparation	25
2-1.	Maintenance after Repair	7	4-1-2.	Entrance Side Adjustment	27
2-1-1.	Rotary Head Disc Assembly	7	4-1-3.	Exit Side Adjustment	28
2-1-2.	Cleaning of the Tape Transportation System	7	4-1-4.	Reverse Waveform Confirmation	29
2-1-3.	Cleaning of the Drive System	7	4-2.	Adjustment for Removal or Replacement of the ACE Assembly	29
2-2.	Periodic Check Items	7	4-2-1.	Tracking Adjustment	29
3. CHECK, ADJUSTMENT AND REPLACEMENT PROCEDURES			4-2-2.	Audio Azimuth Peak Adjustment	30
3-1.	Replacement of Video Head Disc Assembly	9	4-2-3.	CTL Head (ACE Assembly) Position Adjustment	30
3-1-1.	Removal of the Rotary Head Disc Assembly	9	4-2-4.	Audio Head (ACE Assembly) Height Adjustment	30
3-1-2.	Replacement	9	4-3.	Adjustment for Removal or Replacement of the Capstan Motor	31
3-2.	Video Head Dihedral Adjustment	10	5. ELECTRICAL ALIGNMENT		
3-3.	Replacement of Drum Assembly	11	5-1.	Power Supply Check (MA-3 Board)	35
3-4.	Replacement of Capstan DC Motor	12	5-2.	System Control Alignment and Check (MA-3 Board)	35
3-4-1.	Removing Capstan Motor	12	5-3.	Servo System Alignment	36
3-4-2.	Perpendicular Adjustment of Capstan Shaft	12	5-3-1.	Reel Servo System Alignment	36
3-5.	Removal of Tension Pickup Assembly ...	12	5-3-2.	Drum Servo System Alignment	36
3-6.	Removal of Cassette Compartment	13	5-3-3.	Capstan Servo System Alignment	37
3-7.	Removal of Reel Motor	14	5-3-4.	Slow Servo System Alignment	39
3-8.	Threading/Unthreading Adjustment	14	5-4.	Video System Alignment	40
3-8-1.	Checking Cassette Detection Switch Operation	14	5-4-1.	Playback System Alignment	40
3-8-2.	Unthreading Check	14	5-4-2.	Slow Motion Playback System Alignment	42
3-9.	S-Threading Ring Replacement and Adjustment	15	5-4-3.	Record System Alignment	42
3-9-1.	Removal of S-Threading Ring	15	5-5.	Audio System Adjustment (LS-8 Board)	45
3-9-2.	Removal of S-Threading Ring Assembly	17			
3-9-3.	Checking Slider Stopper Mounting ...	18			
3-9-4.	Replacement of S-Threading Ring	18			

SECTION 1

CHECKING, ALIGNMENT AND REPLACEMENT OF MECHANICAL SECTION

1-1. REMOVAL OF THE CASE

1-1-1. Removal of Panel Assembly (Fig. 1-1)

- 1) Raise the cassette compartment.
- 2) Unscrew the two screws ① on the cassette compartment cover and remove the cover by pulling it upward in the direction of arrow (A).
- 3) Unscrew the four screws ③ on the lower panel assembly and remove it.
- 4) Unscrew the two screws ② on the upper panel assembly and disconnect the battery connector.
- 5) Remove the upper panel assembly by lifting it in the direction of arrow (B).




Fig. 1-1. Removal of panel assembly

1-1-2. Removal of Front Panel (Fig. 1-2)

- 1) Open the front cover and pull out the tracking knob. (Fig. 1-1)
- 2) Disengage the four hooks (A) by pushing them outward. Disengage the four hooks (B), pull the panel down in the direction indicated by the arrow (a), then forward together with the circuit board.
- 3) Disconnect the wire harness connector from the LS-8 board.
- 4) Insert a blade-tip screwdriver between the front panel and FR-4 board and disengage the four hooks (D) while pushing hook (C) down by hand.




Fig. 1-2. Removal of front panel

1-1-3. Removal of the Mechanism Chassis (Fig. 1-3)

- 1) Remove the front panel (see Fig. 1-1-2)
- 2) Disconnect the connectors from the MA-3 board.
- 3) Disengage the two hooks (A) fixing the LS-8 board. Pull out
- 4) Unscrew the screw (1) and remove the earth panel plate.
- 5) Unscrew the four screws (2) on the rear of the MA-3 board.




Fig. 1-3. Removal of the mechanism chassis

1-2. PRECAUTIONS WHEN SERVICING

1. Attention should be paid to the positioning of the set when working with the case removed and circuit boards dismantled.
2. When making an operation check or electrical adjustment, use AC adapter AC-F1E or battery NP-1.
3. Do not use alignment tapes other than KR5-2H.




Fig. 1-5. Cassette compartment lock

1-3. MECHANICAL OPERATION WITHOUT CASSETTE INSTALLED

1-3-1. Completing Threading Without Cassette (This state is called "STOP mode" in this guide.)

- 1) Depress the cassette detection lever shown in Fig. 1-4 while lowering the cassette compartment.




Fig. 1-4. Cassette detection lever

- 2) With the cassette compartment raised, push the lock lever in Fig. 1-5 using a blade-tip screwdriver, or other tool to lock the cassette compartment, then press the cassette detection lever.

Caution: The cassette compartment lock does not release automatically. Pull the release slide panel in the direction of arrow (A) and push the lock lever assembly in the same direction to return it to its previous state.

1-3-2. Setting Playback Without Cassette Installed

Press the playback button after setting the STOP mode in step 1-3-1.

1-3-3. Setting Record Mode without a Cassette

- 1) Thread as explained in 1-3-1 and press the record proof switch as shown in Fig. 1-6.














Fig. 1-6. Record proof switch

- 2) Press the PB button while pressing the record or dubbing button, while continuously holding down the record proof switch.

Note: The pause lamp and record lamp light when the record button is pressed, and it is necessary to release pause. **Caution:** fast-forward and rewind are not possible without a cassette installed.

1-4. LIST OF SERVICE UNITS AND TOOLS FOR SL-F1E

Ref. No.	Name	Cord No.	Fixture No.
J-1	Forward-Back Tension Measurement Tape	J-6080-003-C	SL-0003C
J-2	Parallel Plate	J-6086-750-A	SL-0657
J-3	Small Adj. Mirror Spare Mirror	J-6080-029-A J-6080-030-1	SL-5052
J-4	Alignment Tape	8-969-995-52	KR5-2H
J-5	Cleaning Fluid	Y-2031-001-0	
J-6	Thickness Gauge	9-911-053-00	
J-7	Head Demagnetizer	Readily available	
J-8	Lapping Tape	8-888-004-00	
J-9	Cleaning Piece	Z-034-697-00	
J-10	Dihedral Adj. Screw	J-6080-013-1	SL-0013

J-1 	J-2 	J-3 
J-4 	J-5 	J-6 
J-7 	J-8 	J-9 
J-10 		

SECTION 2 PERIODIC CHECK AND MAINTENANCE

The following maintenance and periodic checks are recommended to ensure optimum machine function and performance and to prolong machine and tape life.

2-1. MAINTENANCE AFTER REPAIR

Carry out maintenance work for the following items after repairing the machine regardless of the period of use.

2-1-1. Rotary Head Disc Assembly

- 1) Place a piece of chamois (tool Ref. No. J9) soaked in cleaning fluid (tool Ref. No. J5) lightly against the rotary drum assembly and clean the rotary head disc assembly by slowly rotating it by hand. (Important-Do not clean by rotating with the motor on.)
- 2) Do not clean the head tip by moving the chamois in a vertical direction. This may damage the head tip.

2-1-2. Cleaning of the Tape Transportation System

Clean the tape contact surfaces, such as the tape guide, drum assembly surfaces, capstan, and pinch roller using cleaning piece etc. soaked in cleaning fluid.

2-1-3. Cleaning of the Drive System

Clean the driving elements (threading motor belt, reel base surfaces, etc.) using a cloth soaked in cleaning fluid.

2-2. PERIODIC CHECK ITEMS

Carry out maintenance checks for the following items depending on the duration of use.

Maintenance & Check		Operating Hours (H)											Remarks
		Replacement Part No.	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	
Tape Transportation System	Cleaning of tape transportation system		○	○	○	○	○	○	○	○	○	○	This cleaning must be done whenever a repair is made.
	Cleaning and degaussing of ACE assembly		○	○	○	○	○	○	○	○	○	○	
	Cleaning and degaussing of video disk assembly		○	○	○	○	○	○	○	○	○	○	The life of the head varies, depending on operational conditions and method.
Driving System	Replacement of threading DC motor belt		○	○	○	○	○	○	○	★	○	○	<ul style="list-style-type: none"> ● This cleaning must be done whenever a repair is made. ● Replacement must be done depending on operating hours on the table, or every two years.
	Cleaning of iron core and opening of solenoid		—	—	—	○	—	—	—	○	—	—	Wipe iron core and opening of solenoid with dry cloth.
Performance Confirmation	Abnormal sound		☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Adjust or replace the section which causes abnormal sound.
	Measurement of FWD back tension		—	☆	—	☆	—	☆	—	☆	—	☆	Confirmation must be made according to section Specified value: 45 ~ 48 g·cm (When measured with torque cassette tape)
	Confirmation of brake system		—	☆	—	☆	—	☆	—	☆	—	☆	Confirmation must be made according to section
	Confirmation of record & playback functions		☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Perform the confirmation whenever repair is made.

○ Cleaning ★ Replacement ☆ Confirmation

SECTION 3

CHECK, ADJUSTMENT AND REPLACEMENT PROCEDURES

3-1. REPLACEMENT OF VIDEO HEAD DISC ASSEMBLY (Fig. 3-1)

3-1-1. Removal of the Rotary Head Disc Assembly

- 1) Unscrew the screw ① which fixes the PTC heater cover and remove the PTC heater cover and the stay.
- 2) Unscrew hexagonal socket bolt ② using an Allen wrench.
- 3) Unscrew the two fixed screws ③ and remove the damper.
- 4) Unscrew the two screws ④ and remove the upper drum.

Note: Remove the upper drum while rotating it without moving the adjust plate. Be very careful not to move the adjust plate, otherwise the tape path will be affected.

- 5) Unsolder the rotary head disc circuit board (four red-and-white lead wires).
- 6) Unscrew the two hexagonal socket bolt and remove the rotary head disc assembly.

Note: Be very careful not to touch the head tip, or touch it against anything.

3-1-2. Replacement

- 1) Position the rotary head disc paying attention to the direction of the red and white lead wires.
- 2) Tighten the hexagonal socket bolt and solder the lead wires.
Note: Solder securely, being careful not to break the lead wires.
- 3) Be careful not to move the adjust plate, as when removing the upper drum. Lightly tighten the screws ④, clamp hexagonal socket bolt, then securely tighten the screws ④.

Caution: Be careful not to touch the upper drum or the head tip.

- 4) Attach the damper and fix the screws ③.
- 5) Attach the PTC heater cover and fix the screw ①.




Fig. 3-1. Removal of video head disc assembly

3-2. VIDEO HEAD DIHEDRAL ADJUSTMENT

Generally this adjustment is not necessary except after video head disc replacement. (Video head discs for repair and replacement are precision adjusted using a microscope, and there is virtually never a need for readjustment.)

When determining the appropriate video head angle, play back an alignment tape. Make sure the tracking control knob is set at the center click position. When the check is made at a position other than the center click (tracking is off), the pictures will be played back as if the angle is wrong even if it is correct.

Be sure the ACE assembly position adjustment is completed (refer to "Tape Path Adjustment") before making this adjustment.

[Checking Method]

Play back the β II monoscope signal section of the alignment tape (KR5-2H) after setting the tracking control knob at the center click position. Verify that only one monoscope perpendicular line is played back immediately underneath the switching pulse, and not two lines.

If only one perpendicular line can be seen, the angle is correct, and no adjustment is needed.

If there are two, adjust as follows.

[Adjustment Procedure]

1. As shown in Fig. 3-2, screw in the two angle adjustment screws (Jig Ref. No. J-10) so that the lead wires from the video head are on the same level as the red adjusting screw hole and the top of the adjusting screw hole, and the top of the adjusting screw is on the same level as the top of the video head disc.

(If not screwed in sufficiently, the heads of the adjustment screws hit the upper drum, and the video head disc no longer rotates. Conversely, if they are screwed in too far, the head base moves, and the angle of the video head shifts considerably.)

Caution: The white lead wire is a reference wire and should never be moved.

2. Screw in either one of the two adjustment screws until it feels tight. Additional tightening beyond this position moves the video head and so the angle can be adjusted.
3. Play back the β II monoscope signal section of the alignment tape (KR5-2H) and verify the angle. If the angle of the perpendicular line is larger than before adjustment, screw the adjustment screw counterclockwise to loosen and adjust the screw on the other side.
4. After adjusting, unscrew and check again.




Fig. 3-2. Video head dihedral adjustment

3-3. REPLACEMENT OF DRUM ASSEMBLY

1. Remove the mechanism chassis from the circuit board. (Refer to 1-1-3)
2. Measure and record the two gaps between the upper drum tape holding section and adjust plate (A in Fig. 3-3). (Do not forget to do this, as the adjust plate mounting position affects the tape path.)
3. Unscrew the screws ① shown in Fig. 3-3 and remove the tape guide ground plate and adjust plates (1) and (2).
4. Unfasten dew sensor bolt ① shown in Fig. 3-4 and remove the dew sensor.
5. Unscrew screw ② and remove the PTC heater cover, PTC heater and stay from the drum body.
6. Remove the connector, ground terminal, and three drum mounting screws from the rear of the chassis and remove the drum assembly body.
7. Re-assemble the parts in reverse order.
8. Adjust according to "Tape Path Adjustment" after replacing the drum.




Fig. 3-3. Tape guide ground plate




Fig. 3-4. Replacement of drum assembly

3-4. REPLACEMENT OF CAPSTAN DC MOTOR

3-4-1. Removing Capstan Motor (Fig. 3-5)

- 1) Remove the mechanism chassis from the circuit board. (Refer to 1-1-3)
- 2) Unscrew screws ①, ②, and ③ and remove the capstan motor from the rear of the mechanism chassis.




Fig. 3-5. Removal of capstan motor

3-4-2. Perpendicular Adjustment of Capstan Shaft

Be sure to adjust as follows after the capstan motor has been replaced or removed:

- 1) Place parallel plate (Tool Ref. No. J-2) on No. 10 guide sleeve of the pinch crimp arm assembly perpendicularly, as shown in Fig. 3-6.
- 2) Loosen Screw ②.
- 3) Rotate adjusting screw ① and align the capstan shaft perpendicularly.
- 4) Tighten screw ② and fix the capstan motor.
- 5) Adjust according to "Tape Path Adjustment".




Fig. 3-6. Perpendicular adjustment of capstan motor shaft

3-5. REMOVAL OF TENSION PICKUP ASSEMBLY

(Fig. 3-7)

1. Remove spring ① and disengage hook ② to pull out the tension pickup assembly.
2. Disconnect the wire harness from the wire harness clamp and pull out the connector.

Caution: When replacing or removing the tension pickup assembly, be sure to also adjust the back tension. See "Back Tension Check and Adjustment".




Fig. 3-7. Removal of tension pickup assembly

3-6. REMOVAL OF CASSETTE COMPARTMENT

(Fig. 3-8)

1. Unthread and lift up the cassette compartment.
2. Unscrew four screws ① and remove the cassette compartment by lifting it up.

Caution: When removing the cassette compartment be careful not to hook it on the tension pickup.




Fig. 3-8. Removal of cassette compartment assembly

3-7. REMOVAL OF REEL MOTOR (Fig. 3-9)

1. Remove the mechanism chassis from the circuit board. (Refer to Paragraph 1-1-3)
2. Unscrew the five mounting screws ① on the rear of the chassis and remove the reel motor body.

Note: The rotor section can be removed by pulling it straight up.




Fig. 3-9. Removal of reel motor

3-8. THREADING/UNTHREADING ADJUSTMENT

3-8-1. Checking Cassette Detection Switch Operation

- 1) Unthread manually without loading a cassette.
- 2) Check that the cassette detection switch in Fig. 3-10 does not trip (no click is generated) when pushed.
- 3) Press the cassette compartment lock in the diagram with blade-tip screwdriver to lock it.
- 4) Check that the cassette detection switch trips when pushed (click sound).
- 5) Push the release slide plate of the cassette compartment lock in the direction of arrow (A) and push the lock lever assembly in the same direction to return it to the previous state.




Fig. 3-10.

3-8-2. Unthreading Check

- 1) Set in STOP mode without loading a cassette.
- 2) Press the EJECT button and unthread. (Unthreading is complete when the T slider shaft returns slightly in the threading direction and stops after pushing the cassette-compartment lock release lever.)
- 3) Check that the actuator for the unthreading end switch is not tripped as shown in Fig. 3-11. (Slowly rotate the threading motor by hand and verify with a click sound.) Adjust according to Paragraph 3-13-2 if needed.




Fig. 3-11. Unthreading end switch

3-9. S-THREADING RING REPLACEMENT AND ADJUSTMENT

3-9-1. Removal of S-Threading Ring

Remove ACE head Assembly, FE Head, and Unthreading Motor (Fig. 3-12)

- 1) Unscrew the screw ①.
- 2) Remove the No. 6 guide nut ②, flange ③, spacer ④, and compression coil spring ⑤.

- 3) Remove the two guide adjusting nuts ⑥ and remove the ACE head assembly and FE head.

Caution: ACE assembly and FE head are connected by a lead. Be careful when removing them. The compression coil spring underneath the ACE assembly does not have to be removed. However, be careful not to lose it.

- 4) Unscrew the two screws ⑦ and pull up the threading motor assembly to remove.




Fig. 3-12. Removal of ACE head assembly, FE head and threading motor

Removal of Other Parts (Fig. 3-13)

- 1) Measure the gap between the upper drum and adjust the plate as for replacement of the drum assembly. (Fig. 3-3)
- 2) Unscrew the screws ① and remove the tape guide ground plate ② and adjust plate ③.
- 3) Unscrew the two screws ④ and remove the holder assembly ⑤.

- 4) Unscrew screw ⑥ and remove the guide plate ⑦.
- 5) Unscrew the two screws ⑧ and five screws ⑨ to remove the shuttle guide I ⑩ and II ⑪, as well as the slant base assembly ⑫.
- 6) Unscrew screw ⑬ and remove the pin recliner ⑭.

Caution: When the guide plate is removed, do not thread or unthread with the shuttle guide mounted.




Fig. 3-13.

3-9-2. Removal of S-Threading Ring Assembly

(Fig. 3-14)

- 1) Make sure that the drum assembly has been removed according to Paragraph 3-3.
- 2) Remove the spring of the lock arm assembly. (Refer to Paragraph 3-13-1, Fig. 3-21)
- 3) Remove stop washer ① and ring roller ②.

- 4) Remove the UTE switch subassembly. (Refer to Paragraph 3-13-2, Fig. 3-25)
- 5) Unscrew screw ③ and remove the ring roller adjust plate ④ and ring roller ⑤.
- 6) Remove the S-threading ring assembly ⑥.

Caution: Do not use the same washer twice.




Fig. 3-14. Removal of S-threading ring assembly

3-9-3. Checking Slider Stopper Mounting (Fig. 3-15)

- 1) Check that the drive gear is engaged.
- 2) Loosen screw ①, insert a spacer ($t = 0.2$) between the slider gear and slider stopper, then tighten screw ① while pushing in the directions of arrows (A) and (B).

Caution: Make sure to push it in the direction (A) to eliminate any backlash. The slider stopper rotates in the direction of arrow (A) when screw ① is tightened. Therefore, tighten the screw while holding it with blade-tip screwdriver.




Fig. 3-15. Checking slider stopper mounting

3-9-4. Replacement of S-Threading Ring (Fig. 3-16)

- 1) Mount the S-threading ring.
- 2) Insert a spacer ($t = 0.2$) and set the slider to the position where unthreading is complete. (In the diagram, the slider stopper and slider gear come into contact at (A) through the spacer.)
- 3) Match up the notch on the S-threading ring and the tab on the drive gear as shown at (B) in the diagram.
- 4) Engage the drive gear, S-threading ring, and slider gear, and position the chassis.
- 5) The gap between the tab on the slider gear and the slider stopper at section (A) is about 0.5 mm when the S-threading ring is rotated fully in the direction of arrow (a). At the same time, verify that the chassis hole ($\phi 3$) at (C) and the hole ($\phi 0.15$) of the S-threading ring match.
- 6) Engage the drive gear and the S-threading gear.

Caution: After changing and mounting, adjust the guide height according to Section 3-10. Also adjust the ACE assembly in accordance with the section on "Tape Path Adjustment".




Fig. 3-16. Replacement of S-threading ring

3-10. ADJUSTMENT OF NO. 2 AND 3 GUIDE HEIGHTS (Fig. 3-17)

1. Rotate the threading motor by hand until the No. 2 guide comes up completely.
2. Adjust the height between the upper face of the S-threading ring and guide tip as shown in the diagram, so as to attain the values indicated in the table when the guide is pushed down by hand and comes up again. Adjust with the height adjusting screw.
3. Adjust the No. 3 guide in the same manner.




Fig. 3-17. Height adjustment, Nos. 2 and 3 guides

3-11. CHECKING AND ADJUSTMENT OF PINCH CLOSING LIMITER CLEARANCE (CHECKING PROCEDURE)

1. Set in the STOP mode without loading a cassette.
2. Check that the clearance 't' of the pinch closing limiter (Fig. 3-18) is 0.2 to 0.7 mm. If it is not, adjust as follows:

[Adjustment Procedure]

- 1) Loosen screw (A) in Fig. 3-18 with the pinch solenoid held in.
- 2) Move the pinch limiter adjust plate (shaded in the diagram) fully in the direction of arrow (a). The clearance 't' in this state is 0.
- 3) Push the pinch limiter adjust plate in the direction of arrow (b) as shown at section (B) using a blade-tip screwdriver, until the clearance 't' is 0.2 to 0.7 mm.
- 4) Tighten screw (A) and lock it.




Fig. 3-18 Adjusting clearance of pinch crimp limiter

3-12. BRAKE OPERATION CHECK AND BRAKE PLUNGER ADJUSTMENT

The tape slackens particularly when the tape diameter on the take-up side in both FF and REW is small.

[Checking Procedure]

- 1) Start winding a cassette. (Rewind the tape and start forward feed)
- 2) Repeat FF→STOP several times and check that the tape does not slacken. If the tape slackens, adjust as follows.
- 3) Wind the tape to the end in forward feed.
- 4) Repeat REW→STOP several times and verify that the tape does not slacken. Adjust as follows if the tape slackens.

[Adjustment Procedure]

- 1) Remove the mechanism chassis from the circuit board.
- 2) Loosen screw (A) on the plunger solenoid (Fig. 3-19).
- 3) Push the plunger in the direction of arrow (B) by hand until fully retracted.
- 4) Adjust the plunger solenoid so as to obtain clearances of 0.2 to 0.7 mm between the two brakes and S and T reel rotors. Tighten screw (A).

Note: After tightening screw (A), check for proper clearance at (C) and (D).




Fig. 3-19. Brake plunger adjustment

3-13. CHECKING AND ADJUSTMENT OF MICROSWITCH POSITION

3-13-1. Checking and Adjustment of Threading End Switch (TE Switch) Position

[Checking Procedure] (Fig. 3-20)

Rotate the S-threading ring by hand and check that the TE switch turns on and off with a clicking noise while the lock roller is moving within the lower 2/3 of the straight portion ℓ of the recess (A) in Fig. 3-20) on the ring

If not, adjust as follows.

[Adjustment Procedure]

- 1) Bring the lock roller into the lower 2/3 of the 'ℓ' range in the recess on the S-threading ring, move the TE switch in the direction of the arrow using a blade-tip screwdriver, until the switch trips (click noise), then tighten screw (B).
- 2) Check the results of the adjustment following the check procedure given above.

[Removal]

- 1) Unhook the tension coil spring from the lock arm assembly.
- 2) Unscrew screw (1) and remove the TE switch subassembly.
- 3) Push the hook on the main chassis assembly in the direction of the arrow to unhook, and remove the lock arm assembly.




Fig. 3-20. TE switch position adjustment




Fig. 3-21. Removal of TE switch

3-13-2. Checking and Adjustment of Unthreading End Switch (UTE Switch) Position

[Checking Method]

Rotate the S-threading ring by hand. Verify that the switch trips when a pin of $\phi 1.5$ is inserted at Section (A) in Fig. 3-22 after the UTE switch arm roller assembly has dropped into the UTE switch cam groove. Verify that the switch does not trip when a pin of $\phi 0.6$ is inserted.

[Adjustment Method]

- 1) If the switch does not trip after inserting a $\phi 1.5$ pin, loosen small screw (B) and adjust by moving in the direction of the arrow little by little.
- 2) Bend the switch actuator as shown in Fig. 3-23 if the switch turns on when a $\phi 0.6$ pin is inserted.




Fig. 3-22. U. T. E switch position adjustment




Fig. 3-23.

Caution: Insert the $\phi 1.5$ and 0.6 pins in the positions shown in Fig. 3-22. (If the pins are inserted too close to the UTE roller side as shown in Fig. 3-24, the clearance inside will be less than 1.5 mm, even though it is 1.5 mm at the entrance, because of the switch construction.)




Fig. 3-24.

[Removal]

- 1) Unscrew screw (1) as shown in Fig. 3-25.
- 2) Release the switch hook from the chassis and remove the switch body while pushing the actuator to the "ON" position.




Fig. 3-25. Removal of UTE switch

3-14. FORWARD/BACK TENSION MEASUREMENT

The forward/back tension measurement for SL-F1E performed using a torque cassette (SL-0003C).

3-14-1. Measurement Procedure

- 1) Remove the top panel so that the tape path is visible.
- 2) Insert the torque cassette and put the set into replay mode.
- 3) Read the indicated value of the S-reel side meter after the pointer has made one revolution.

Specified Value 45 ~ 48 g·cm

- Notes:**
- i) The set must be level when the measurement is performed.
 - ii) After measuring, the tape may go slack if the stop button is pushed. In this case, put the set into forward mode to take up the slack before removing the tape.

3-14-2. Adjustment Procedure

If the specified value is not obtained, adjust by turning RV-202 on the MA-3 board.

SECTION 4 TAPE PATH ADJUSTMENT

4-1. TRACKING ADJUSTMENT

This adjustment has significant effect on picture quality in each mode and tape interchangeability, so please perform it very carefully.

4-1-1. Preparation

- 1) Remove the cassette cover of alignment tape KR5-2H as shown in Fig. 4-1.
- 2) Clean the tape contact surfaces (tape guides, drum, capstan spindle, pinch roller, ACE·FE head surfaces) with chamois dampened with methanol.
- 3) Oscilloscope connection: CN3-3 pin (SF-5 board)
- 4) Replay the tracking portion of the KR5-2H alignment tape.




Fig. 4-1.

- 5) Confirm that the RF output waveform is flat, with maximum amplitude. (The waveform should increase and decrease, remaining flat, when the tracking control knob is turned back and forth.) Also, when the waveform is maximum, confirm that the RF output waveform variation and contact satisfy the specifications shown in Fig. 4-2. If they do not meet the specifications, follow the instructions in 6).
- 6) If the tracking control knob is turned and the entrance waveform does not flatten as shown in Fig. 4-3(a), perform the entrance side adjustment in 4-1-2. If the exit waveform does not flatten as shown in Fig. 4-3(b), perform the exit side adjustment in 4-1-3.




Fig. 4-2.

Specifications: Tracking Control Knob at Maximum

Contact: $\frac{B}{A} \geq 0.7$

$\frac{C}{A} \geq 0.7$

Variation: $\frac{D}{A} \geq 0.9$





Fig. 4-3.

Waveform Confirmation



4-1-2. Entrance Side Adjustment

Always perform the exit side adjustment as well as the entrance side adjustment. Fig. 4-4 illustrates the guides and adjustment locations.

Turn the tracking control knob clockwise to lower the RF output waveform to about 60% of the maximum.

Note: Be sure to turn clockwise to lower the waveform. By doing this, the entrance side waveform will increase when the No. 5 guide is loosened, and when the No. 5 guide is lowered, the waveform will decrease.

- 1) First, screw the No. 4 guide down completely, then loosen the No. 6 guide to create a space and free the tape running.
- 2) Loosen the No. 5 guide lock screw ①, turn No. 5 guide so that there are no curls or spaces, and check the waveform. If the waveform does not flatten, perform adjustments as follows.

ENTRANCE SIDE FLOW CHART





Fig. 4-4.

[If the waveform entrance output does not increase]

- 1) Loosen the adjust plate screw ② on No. 3 guide, and move it towards the drum. When the waveform increases, tighten screw ②.
- 2) Flatten the waveform with No. 5 guide.

[If the waveform entrance output does not decrease]

- 1) Move the No. 3 guide adjust plate away from the drum, and tighten screw ② at the point just before the lower tension of the tape loosens.
- 2) Flatten the waveform with No. 5 guide lateral adjustment screw.
- 3) After turning and locking the No. 5 guide, flatten the waveform by raising the waveform entrance a little, and lock the No. 5 guide lock screw at this point. Press the No. 5 guide down with a screwdriver so that it does not turn when locking. (Fig. 4-5)
- 4) Check for curl or spaces at the No. 5 guide. If these appear, proceed with the following adjustments.




Fig. 4-5.

[If there is space]

Turn No. 4 guide counterclockwise to raise the tape and remove the space at No. 5 guide.

Note: Be careful not to create a large space at the bottom of No. 4 guide.

[If there is cur]

- 1) When there is a space at the bottom of No. 4 guide:
Lean the adjust plate of No. 3 guide toward the outside until the point just before the lower tape tension loosens.
- 2) When there is curl but no space at the bottom of No. 4 guide:
 - i) Confirm that No. 4 guide is not raised too high. Turn clockwise to lower if necessary.
 - ii) If this does not solve the problem, tighten No. 5 guide lateral adjustment screw by turning clockwise until the curl disappears.

4-1-3. Exit Side Adjustment

- 1) Turn the tracking control knob clockwise to lower the RF output waveform to about 60% of the maximum.
- 2) Raise No. 7, 8 guides to free the tape running, and check the waveform. (This waveform is called "exit free waveform".)

Note: Be careful not to raise the guides too much. They should be raised about 0.3 ~ 0.5 mm, and also, the tape should not touch the ACE head bottom flange. (Fig. 4-6)

- i) If the exit free waveform is within the range illustrated in Fig. 4-7(a), (b), process with exit side adjustment.
 - ii) If it is not within the specified range, follow the adjustment procedure in 4-3.
- 3) Flatten the waveform with No. 7 guide, and match No. 8 guide to the tape. (Lower the guide to the point just before the waveform changes, and where there is no curl.)
 - 4) Confirm that there is no curl at No. 7, 8 guides in forward mode.
 - 5) Confirm that curl and space do not appear at No. 8 guide in reverse mode. If curl or space appear, adjust with No. 9 guide, and perform the exit side adjustment again.




Fig. 4-6.




Fig. 4-7.

4-1-4. Reverse Waveform Confirmation

- 1) Confirm that the entrance and exit side waveforms do not bounce when the tracking control knob is turned (less than 30°) in the reverse mode. (Fig. 4-8)
- 2) If there is bounce in the entrance side waveform, readjust the entrance side in the forward mode, and if there is bounce in the exit side waveform, readjust the exit side.
- 3) Confirm the waveform in the reverse mode again.

Note: When readjusting, be sure to return the tracking control knob to the center position.




Fig. 4-8.

4-2. ADJUSTMENT FOR REMOVAL OR REPLACEMENT OF THE ACE ASSEMBLY

Perform the following adjustments when removing or replacing the ACE assembly.

4-2-1. Tracking Adjustment

- 1) Turn the tracking control knob clockwise to lower the RF output waveform to about 60% of the maximum.
- 2) Replay the tracking portion of the alignment tape (KR5-2H), raise No. 7, 8 guides about 0.3 ~ 0.5 mm, and check the exit free waveform of the RF output waveform.

Note: Be sure that the tape does not touch the bottom flange of the ACE assembly.

- i) If the waveform is within the range illustrated in Fig. 4-7(a), (b), proceed with the adjustment.
- ii) If the exit free waveform appears as shown in Fig. 4-10, turn the ACE lateral adjustment screw clockwise (less than 30°) until the waveform is within the range illustrated in Fig. 4-7(a), (b). (See Fig. 4-9)
- iii) If the exit free waveform appears as shown in Fig. 4-11, turn the ACE lateral adjustment screw counterclockwise (less than 30°), until the waveform is within the specified range.

- 4) Turn the No. 7 guide to flatten the waveform, and match the No. 8 guide to the tape. (Lower the guide until the point just before the waveform changes.)




Fig. 4-9.




Fig. 4-10.




Fig. 4-11.

4-2-2. Audio Azimuth Peak Adjustment

- 1) Connect the oscilloscope as follows:
CN804 . . . 11 pin (MA-3 board)
Replay the 5 kHz portion of the alignment tape (KR5-2H).
- 2) Turn the azimuth adjustment screw (Fig. 4-12) so that the amplitude of the 5 kHz waveform is maximum.




Fig. 4-12.




Fig. 4-13.




Fig. 4-14.

4-2-3. CTL Head (ACE Assembly) Position Adjustment

This adjustment is both mechanical and electric: mechanically, it is the adjustment of the CTL head position, and electrically, it is the tracking control center adjustment. The procedure involves performing the electrical adjustment first, then the head position adjustment.

- 1) Connect the oscilloscope as follows:
1ch: CN3 . . . 3 pin (SF-5 board)
2ch: CN804 . . . 11 pin (MA-3 board)
external trigger: CN3 . . . 5 pin (SF-5 board)
- 2) Replay the tracking portion of the alignment tape (KR5-2H).
- 3) Turn the tracking control knob back and forth, and confirm that the output waveform level is maximum at the center click position, and that the 0 level of the audio signal is at the point where the RF output waveform Bch waveform appears, as shown in Fig. 4-13. If adjustment is necessary, proceed as follows.
- 4) Tracking Control Center Adjustment (Refer to Electrical Adjustments, 5-3-3, 4)
- 5) CTL Head Position Adjustment
Set the tracking control knob at the center click position and loosen the two ACE assembly position adjustment screws ①. As shown in Fig. 4-14, slide the ACE assembly with a screwdriver until it is in the position shown in Fig. 4-13 and the RF output waveform is maximum. Tighten the screws when this position is obtained.
- 6) Replay the colour bars of the alignment tape and check the picture quality.

4-2-4. Audio Head (ACE Assembly) Height Adjustment

Perform this adjustment only after completing the exit side tracking adjustment.

- 1) Oscilloscope connection: 1ch: CN804 . . . 11 pin (MA-3 board)
Replay the 5 kHz portion of the alignment tape (KR5-2H).
- 2) Turn the audio head height adjustment screw ① and the lateral adjustment screw ② (Fig. 4-15) until the audio output waveform amplitude is maximum.

Note: Both of these adjustment screws should be turned in the same direction at the same angle, less than 30°.




Fig. 4-15.

4-3. ADJUSTMENT FOR REMOVAL OR REPLACEMENT OF THE CAPSTAN MOTOR

- 1) Perform the vertical adjustment of the capstan spindle according to 3-4, Replacement and Adjustment of Capstan Motor.
- 2) Replay the tracking portion of the alignment tape (KR5-2H). Connect the oscilloscope as follows:
1ch: CN3 . . . 3 pin (SF-5 board)
- 3) Turn the tracking control knob clockwise to lower the RF output waveform to about 60% of the maximum.
- 4) Raise No. 7, 8 guides a little, and check the exit free waveform.
 - i) If the exit free waveform is within the range indicated in Fig. 4-16(a), (b), proceed from step 5).
 - ii) If the peak of the exit free waveform is smaller than that illustrated in Fig. 4-16(a) (e.g.: Fig. 4-17), loosen the capstan lock screw, then turn the adjustment screw counterclockwise (less than 60°) until the waveform is within the specified range.
 - iii) If the peak shape of the exit free waveform differs from that shown in Fig. 4-16(b) (e.g.: Fig. 4-18), loosen the lock screw, then turn the capstan adjustment screw clockwise (less than 60°) until the waveform is within the specified range.

Note: After turning the capstan adjustment screw, wait until the waveform stabilizes (about 10–15 seconds) before continuing with the adjustment.

- 5) Lock the capstan lock screw. (Turn clockwise until it stops, then turn a little more.)
- 6) Flatten the waveform with No. 7 guide, and match No. 8 guide to the tape.
- 7) Confirm and adjust according to 4-1-3, exit side adjustment procedure, items 4), 5).




Fig. 4-16.




Fig. 4-17.




Fig. 4-18.

SECTION 5 ELECTRICAL ALIGNMENT

All the electrical alignment can be performed by using the equipment mentioned below, the alignment tape, and the PAL colour bar signal (100%).

[Equipment Required]

- (1) Colour monitor TV
- (2) Oscilloscope, Dual-trace, Bandwidth . . . more than 10 MHz with delay mode
- (3) Frequency Counter
- (4) PAL Colour-Bar Generator
- (5) Digital voltmeter
- (6) VOM (20 k Ω /V)
- (7) Audio Signal Generator
- (8) Attenuator
- (9) Alignment Tape, type: KR5-2H, Code No. 8-969-995-52

- (10) Alignment Tool (Adjusting screwdriver for semi-fixed resistors and coils)
Code No. 7-700-733-01

[Setup for Alignment]

In this alignment, video signals obtained from the pattern generator or the timer tuner unit will be used as alignment signals. Therefore, the video output signals should be within the specifications. Verify video signals by connecting an oscilloscope to pin 1 of CN804 NOTE i on the MA-3 board, or to pin ②③ of CN802 NOTE ii. Check that the video signals are flat when the amplitude of the horizontal sync signal is about 0.3V, the amplitude of the video portion is about 0.7V, and the amplitude of the burst signal is about 0.3V. The video signal (colour-bar signal) used in this alignment is shown in Fig. 5-1.

- Notes:**
- i) When the external power supply is connected to DC IN jack.
 - ii) When the tuner timer unit is connected to the ACCESSORY CONNECTOR.




Fig. 5-1. Colour-bar signal of pattern generator

[Alignment Tape]

KR5-2H

	Video signal	Audio signal	Playing time	Use for
1.	Colour bars	3 kHz – 5 dB	5 min	General performance, tape speed checks, switching position adjustment.
2.	Monoscope	333 Hz – 25 dB	5 min	Video head dihedral, audio level adjustment.
3.	RF sweep	5 kHz – 25 dB	5 min	Video, audio frequency characteristics, audio azimuth adjustment marker: 1, 2, 3.58, 4.5, 5.2 MHz
4.	Tracking 1 MHz (CH-B) *1 (Channel B is inserted in every 3 frames.)	1 kHz – 5 dB *2 (Signal is dropped out in the positions where channel B is inserted.)	5 min	Tracking, Audio height adjustments CTL Position check (Check if *1 and *2 are the same position.)

[Colour-Bar Signal]

The 100% colour bar signal recorded on the Alignment tape is shown in Fig. 5-2.




Fig. 5-2. Colour bar signal recorded on the alignment tape

[75Ω Terminating Method]

To terminate the video output terminal (pin ③ of CN804), follow the steps shown in Fig. 5-3.




Fig. 5-3. 75Ω terminating circuit

[VR Alignment Tool Screwdriver]

Use the tool screwdriver supplied for alignment of semi-fixed VRs and inductances on each printed circuit board. An ordinary screwdriver is too large and is difficult to use when adjusting VRs from the print pattern side of a board. The special alignment tool screwdriver is shown in Fig. 5-4.

The metal blade of the screwdriver is used for variable resistors and trimmer capacitors.




Fig. 5-4. Alignment tool screwdriver

[Required Levels and Impedances of Input and Output]

Inputs and outputs

- CAMERA connector 14-pin, Sony K-type connector
- Video in: 1 Vp-p ^{+1.0} _{-0.5} Vp-p
 - 75 ohms unbalanced, sync negative
 - Video out: 1 Vp-p ± 0.1 Vp-p
 - 75 ohms unbalanced, sync negative
 - Audio in: -20 dBs
 - (0 dBs = 0.775 V rms)
 - Audio out: -5 dBs (at load impedance 100 kilohms)
 - Output impedance: less than 10 kilohms
 - Power supply output: 12V DC

ACCESSORY connector 26-pin connector

- Video in: 1 Vp-p ^{+1.0} _{-0.5} Vp-p
- 75 ohms unbalanced, sync negative
- Video out: 1 Vp-p ± 0.1 Vp-p
- 75 ohms unbalanced, sync negative
- Audio in: -10 dBs
- Input impedance 100 kilohms
- Audio out: -5 dBs (at load impedance 100 kilohms)
- Output impedance: less than 10 kilohms
- Power supply input: 12V DC

MIC input


- Minijack
- 60 dBs, for low-impedance microphone

EARPIECE output

- Minijack
- 26 dBs, for 8-ohm earpiece

[Alignment Sequence]

The alignment should be performed following the sequence below.



5-1. POWER SUPPLY CHECK (MA-3 Board)

Measure in E-E mode (power supply switch ON).




Fig. 5-1-1. Component layout

1. +12V Check
UNREG 12V LINE shall be above 11.5V.
2. REG 9V Check
Pin ① of CN608 shall be $9.0V \pm 0.2V$.
3. REG 5V Check
Pin ⑭ of IC604 shall be $5V \pm 0.3V$.

5-2. SYSTEM CONTROL ALIGNMENT AND CHECK (MA-3 Board)




Fig. 5-2-1. Component layout

1. Battery Down (Prevention of Excess Discharge) Alignment
Mode: E-E
Digital voltmeter: UNREG 12V LINE
 - (1) Decrease the external power supply voltage and set at 10.8V.
 - (2) Connect VOM to TP601 (Pin ⑬ of IC608)
 - (3) Turn RV601 fully clockwise (\odot) as seen from the pattern side.
 - (4) Turn RV601 counterclockwise (\ominus) and set so that VOM changes from "H about 5V" to "L about 0V."

Note: VTR power supply is automatically cut off when the "L" state continues for more than about 30 seconds.

 - (5) Return the external power supply voltage to 12V and again slowly decrease. Check that TP601 changes from "H" \rightarrow "L" when the voltage reaches 10.8V (pin ① of CN406).
2. Clock Frequency Check
Mode: E-E
Signal: None
Frequency counter: Pin ④ of IC605
Check: Within $3.9\text{ MHz} \pm 0.1\text{ MHz}$




Fig. 5-2-2. Clock frequency

5-3. SERVO SYSTEM ALIGNMENT

Alignment Sequence

1. Reel servo system alignment
2. Drum servo system alignment
3. Capstan servo system alignment
4. Slow servo system alignment

5-3-1. Reel Servo System Alignment

- 1) FAST-FWD/REW Speed Alignment (MA-3 board)
Using VOM (20 k Ω /V)
Mode: FAST-FWD
VOM: Pin ⑦ of IC205

[Alignment method]

- i) FAST-FWD the tape center section (with the tape wound equally on T- and S-side reels)
- ii) Adjust to 4.3V \pm 0.2V with RV201.
- iii) Set up the REW mode at the tape center section.
- iv) Check that VOM shows 4.3V \pm 0.5V.

Using frequency counter:

- Mode: FAST-FWD
Frequency counter: D202 anode

[Alignment method]

- i) FAST-FWD the tape center section (with the tape wound equally on T- and S-side reels)
- ii) Adjust to 380 Hz \pm 30 Hz with RV201.
- iii) Connect the frequency counter to the anode of D201.
- iv) Set up the REW mode at the tape center section.
- v) Check that the frequency is 380 Hz \pm 50 Hz.




Fig. 5-3-1. Alignment of FAST-FWD/REW speed

- 2) FWD Back Tension Alignment (MA-3 Board)
See "Mechanical Adjustment"

5-3-2. Drum Servo System Alignment

- 1) Drum Free Speed Adjustment (MA-3 Board)
Mode: Playback
Signal: Alignment tape colour bar, or monoscope
Oscilloscope: CH-1 TP409 (pin ⑬ of IC401)
CH-2 TP401 (pin ⑳ of IC401)

[Alignment method]

Adjust to 553 μ sec \pm 10 μ sec with RV402 (See Fig. 5-3-2)




Fig. 5-3-2. Drum free speed adjustment

- 2) RF Switching Position Adjustment (MA-3 Board)
Mode: Playback
Signal: Alignment tape colour bar or monoscope
Oscilloscope CH-1 TP401 (pin ⑳ of IC401)
CH-2 Pin ④ of IC401




Fig. 5-3-3. RF switching position adjustment (1)

[Adjustment method]

- i) Adjust to $900\mu\text{sec} \pm 30\mu\text{sec}$ with RV401. (See Fig. 5-3-3)
- ii) Change connection of CH-2 only to pin ③② of IC401.
- iii) Adjust to $900\mu\text{sec} \pm 30\mu\text{sec}$ with RV403. (See Fig. 5-3-4)




Fig. 5-3-4. RF switching position adjustment (2)

- iv) Set up the pause mode and feed one frame by pressing the FORWARD ► button. Observe the amount of V-jitters. Again press the FORWARD ► button to feed one frame and compare the amount of V-jitter with the previous amount. Perform fine adjustment if they are not identical with RV403.

3) PICTURE SEARCH, Drum Free Speed Adjustment (MA-3 Board)

- Adjust both FWD/REVERSE mode.
 - REVERSE is indicated by ().
- Mode: PICTURE SEARCH (FWD/REVERSE)
 Signal: Alignment tape colour bar or monoscope
 Frequency counter: Pin ④ of CN2

[Adjustment method]

Adjust to $15.625\text{ kHz} \pm 0.05\text{ kHz}$ with RV410 (RV420) (See Fig. 5-3-5).




Fig. 5-3-5. PICTURE SEARCH, drum free speed adjustment

5-3-3. Capstan Servo System Alignment

1) Capstan DC Bias Adjustment (MA-3 Board)

Mode: Playback
 Signal: Alignment tape colour bar or monoscope
 Oscilloscope: Pin ②① of IC401

[Adjustment method]

Adjust to the relevant duty (ratio for A and B) in the play mode with the RV as shown in Table 1.

Playback Mode	Adjustment RV	Duty
PB	RV407	50%
DOUBLE SPEED	RV405	50%

Table 1.




Fig. 5-3-6. Capstan DC bias adjustment

2) PICTURE SEARCH, Capstan DC Bias Adjustment (MA-3 Board)

Mode: PICTURE SEARCH (FWD)
 Signal: Alignment tape colour bar or monoscope
 Frequency counter: TP407 (Pin ① of IC408)

[Adjustment method]

- i) Adjust to $1613\text{ Hz} \pm 5\text{ Hz}$ with RV409. (See Fig. 5-3-7)




Fig. 5-3-7. PICTURE SEARCH, capstan DC bias adjustment

- 3) **FG Amp DC Bias Adjustment (MA-3 Board)**
 Mode: Playback + x2 (Double speed)
 Signal: Alignment tape colour bar or mono-scope

[Adjustment method]

- i) Denote the voltage at TP405 (pin ⑪ of IC408) by V1.
- ii) With TP403 and TP415 shorted, V2 denotes the voltage at TP405.
- iii) Adjust RV417 to attain a voltage level of V1 = V2.
- iv) V3 denotes the voltage at TP402 (pin ⑦ of IC408).
- v) With TP403 and TP415 disconnected, V4 denotes the voltage at TP402.
- vi) Adjust RV416 to attain a voltage level of V3 = V4.

- 4) **Tracking Center Adjustment (MA-3 Board)**
 Mode: Playback
 Signal: Alignment tape colour bar, or mono-scope
 Oscilloscope: CH-1 TP409 (pin ⑬ of IC401)
 CH-2 TP411 (pin ⑮ of IC401)

[Adjustment method]

- i) Set the TRACKING knob to the center click position.
- ii) Adjust to $7.05 \text{ msec} \pm 0.05 \text{ msec}$ with RV414. (See Fig. 5-3-8)




Fig. 5-3-8. Tracking center adjustment

- 5) **Tracking FIX Adjustment (MA-3 Board)**
 Mode: Recording
 Signal: Arbitrary signal
 Oscilloscope: CH-1 TP409 (pin ⑬ of IC401)
 CH-2 TP411 (pin ⑮ of IC401)

[Adjustment method]

- i) Set the TRACKING knob to the center click position.
- ii) Adjust to $7.05 \text{ msec} \pm 0.05 \text{ msec}$ with RV413. (See Fig. 5-3-9)




Fig. 5-3-9. Tracking FIX adjustment

- 6) **CTL Delay Adjustment (MA-3 Board)**
 • Adjust using a self-recorded tape.
 Mode: Playback + Pause
 Signal: Colour bar signals recorded in β II mode.

[Adjustment method]

- i) Set the TRACKING knob to the center click position.
- ii) Adjust RV415 so that noise bars on the TV monitor screen disappear from the screen top or bottom (or are kept to a minimum) while pressing the REVERSE ◀ button (See Fig. 5-3-10)




Fig. 5-3-10. CTL delay adjustment


SONY[®] ADJUSTMENT MANUAL

AEP Model
UK Model
E Model





April, 1983

CORRECTION-1

Correct the Adjustment Manual as shown below.

 : corrected portion

Page 39 : 5-3-4. Slow Servo System Alignment

Correct	Incorrect
<p>3) Edit Adjustment (MA-3 and LS-8 Boards)</p> <p>Mode: Record</p> <p>Signal: Arbitrary signal </p> <p>Oscilloscope: Pin ④ of IC401 on MA-3 board  External trigger: pin ②① of IC401 on MA-3 board</p> <p>Trigger slope: -</p> <p>Input: DC range</p> <p>Sweep mode: NORMAL</p> <p>[Adjustment method]</p> <p>i) Set up the PAUSE mode. (more than 3 sec)</p> <p>ii) Push the PAUSE button again to clear the PAUSE mode (adjust the trigger level of the oscilloscope to triggerit), and adjust RV205 on the LS-8 board until the time T between the end of pause to the waveform rise point becomes a maximum.</p>  <p><i>Fig. 5-3-13. Edit adjustment</i></p>	<p>3) Edit Adjustment (MA-3 and LS-8 Boards)</p> <p>Mode: Record</p> <p>Signal: Arbitrary signal</p> <p>Oscilloscope: Pin ④ of IC301 on MA-3 board External trigger: pin ②① of IC301 on MA-3 board</p> <p>Trigger slope: -</p> <p>Input: DC range</p> <p>Sweep mode: NORMAL</p> <p>[Adjustment method]</p> <p>i) Set up the PAUSE mode. (more than 3 sec)</p> <p>ii) Push the PAUSE button again to clear the PAUSE mode (adjust the trigger level of the oscilloscope to triggerit), and adjust RV205 on the LS-8 board until the time T between the end of pause to the waveform rise point becomes a maximum.</p>  <p><i>Fig. 5-3-13. Edit adjustment</i></p>



9-972-167-93

Sony Corporation
Consumer Products Group
Technical Support Dept.

English
83D0989-1
Printed in Japan
© 1983


Consumer
VIDEO

5-3-4. Slow Servo System Alignment

- 1) Capstan Brake Alignment (LS-8 and MA-3 Boards)
 - Mode: Playback + Pause
 - Signal: Recorded tape
 - Oscilloscope: CH-1 TP205 (LS-8 Board)
CH-2 TP402 or TP405 (MA-3 Board)
 - Sweep mode: NORMAL
 - Trigger slope: +

[Adjustment method]

- i) Press the REVERSE ◀ button for more than one second, then release. (Adjust the trigger level of the oscilloscope so that a waveform appears.)
- ii) Repeat the process of pressing the REVERSE ◀ button for one second --- releasing --- pressing, and adjust to optimum state as shown in Fig. 5-3-11 with RV209. (See Fig. 5-3-11)



Note: So adjust RV209 to the Point where the FG signal disappears at the position where the brake pulse falls.

Fig. 5-3-11. Capstan brake alignment




Fig. 5-3-12. Tracking adjustment

- 3) Edit Adjustment (MA-3 and LS-8 Boards)
 - Mode: Record
 - Signal: Arbitrary signal
 - Oscilloscope: Pin ④ of IC301 on MA-3 board
 - External trigger: pin ② of IC301 on MA-3 board
 - Trigger slope: -
 - Input: DC range
 - Sweep mode: NORMAL

[Adjustment method]

- i) Set up the PAUSE mode. (more than 3 sec)
- ii) Push the PAUSE button again to clear the PAUSE mode (adjust the trigger level of the oscilloscope to trigger it), and adjust RV205 on the LS-8 board until the time T between the end of pause to the waveform rise point becomes a maximum.




Fig. 5-3-13. Edit adjustment

- iii) Repeat; PAUSE — release of PAUSE two or three times, and check that the result meets Paragraph (ii).
 - iv) Make self-recording the playback and check that edits are free of noise.
- 4) Slow Speed Adjustment (LS-8 Board)
 - Mode: Playback + Pause
 - Signal: Alignment tape colour bar, or monoscope
 - VOM (20kΩ/V): MA-3 board pin 2 of CN407

[Adjustment method]

- i) Turn RV210 fully clockwise (↻) as seen from the pattern side.
- ii) Adjust to 3.0V ± 0.2V with RV211 while pressing the SLOW▶ button.
- iii) Adjust RV210 so that noise bars on the monitor screen progress about four times per second from top to bottom while pressing the SLOW▶ button.

Note: The VOM voltage decreases after making the adjustment in Paragraph (3). However, there is no need for readjustment.

- 2) Tracking Adjustment (LS-8 Board)
 - Adjust using the self-recorded tape.
 - Adjust both the FWD and RVS modes.
 - Mode: Playback + Pause
 - Signal: Colour bar mentioned above

[Adjustment method]

- i) Set the TRACKING knob to the center click position.
- ii) Press the FORWARD ▶ button for about one second, then release it. (The pause mode will be set) Adjust with RV202 so that noise bars on the TV monitor screen are reduced to a minimum on the bottom of the screen. (See Fig. 5-3-12).
- iii) Press the REVERSE ◀ button for about one second, then release it. (The pause mode will be set) Adjust with RV203 so that noise bars on the TV monitor screen are reduced to a minimum on the bottom of the screen. (See Fig. 5-3-12).

5-4. VIDEO SYSTEM ALIGNMENT

As a rule, first the playback system is aligned with an alignment tape to check that it operates normally, then the recording system is aligned.

The alignment sequence is shown below. The Y signal and chroma signal systems are aligned for both playback and recording systems.

Colour video signals supplied by the pattern generator or timer tuner unit are used as video input signals for video system alignment in the record mode. Check that the sync and colour burst signals conform to the specifications designated in "Set-up for Alignment" in Fig. 5-1.

[Playback System Alignment]

1. Playback frequency characteristic adjustment
2. Playback video level adjustment
3. Y-Comb and DOC level adjustment
4. Shift adjustment
5. Expand adjustment
6. Chroma comb filter adjustment
7. Converter balance adjustment
8. White peak clip adjustment

[Slow Motion Playback System Alignment]

1. JOG AFC adjustment
2. JOG level adjustment

[Record System Alignment]

1. Sync and peak AGC adjustment
2. Carrier set adjustment
3. Deviation adjustment
4. Y record current adjustment
5. Chroma reference frequency adjustment
6. Chroma record current adjustment
7. Compress adjustment
8. Dark clip adjustment
9. White clip adjustment
10. Chroma AFC adjustment
11. Chroma peak level (ACC) adjustment
12. Pilot burst signal level adjustment
13. AFC shift adjustment
14. Pilot burst frag adjustment
15. Burst frag adjustment

5-4-1. Playback System Alignment

1) Playback Frequency Characteristic Adjustment (SF-5 Board)

Mode: Playback

Signal: Alignment tape RF sweep

Oscilloscope: Pin ③ of CN3

External trigger: Pin ⑤ of CN3

[Adjustment method]

A-CH RV1

B-CH RV3

CH balance RV2




Fig. 5-4-1. Playback amplifier frequency characteristic adjustment

- Note:**
- If the characteristic shown in Fig. 5-4-1 can not be obtained by the adjustment of RV1 or RV3, the amplitude at around 4 MHz can be increased when L8 (6.8 μ H . . . A-CH) or L9 (6.8 μ H . . . B-CH) in REC/PB AMP BLOCK is replaced by 10 μ H (1-407-157-11 or 1-407-190-11).
 - The reason for the difference (imbalance) of waveform between A-CH and B-CH is the difference in the impedance of the head signals resulting from the difference in the winding diameters of the rotary transformers.

- 2) Playback Video Level Adjustment (SF-5 Board, MA-3 Board)
 Mode: Playback
 Signal: Alignment tape colour bar
 Oscilloscope: Pin ②③ of CN802 on MA-3 board

[Adjustment method]

- i) Adjust to $1.0V \pm 0.05 V_{p-p}$ with RV9 on SF-5 board.




Fig. 5-4-2. Playback video level adjustment

- 3) Y-Comb and DOC Level Adjustment (SF-5 Board)
 Mode: Playback
 Signal: Tape with dropouts
 Adjust while observing the monitor TV screen.

[Adjustment method]

- i) Turn RV10 (Y-COMB) to eliminate dropouts, and then turn RV7 so that white dot noise just appears at the compensating section.

- 4) Shift Adjustment (MA-3 Board)
 Mode: Playback
 Signal: Alignment tape colour bar
 Oscilloscope: Pin ⑫ of IC6

[Adjustment method]

- i) Align the signal level (per 1H) with RV7.





Fig. 5-4-3. Shift adjustment

- 5) Expand Adjustment (SF-5 Board)
 Mode: Playback
 Signal: Colour bar

Digital voltmeter:



[Adjustment method]

- i) Adjust to $0.345V \pm 0.01 V_{dc}$ with RV8.

- 6) Chroma Comb Filter Adjustment (SF-5 Board)
 Mode: Playback
 Signal: Alignment tape colour bar
 Adjust while observing the monitor TV screen.

[Adjustment method]

- i) Turn RV13 and LV1 alternately to obtain a smooth picture.

- 7) Converter Balance Adjustment (SF-5 Board)
 Mode: Playback
 Signal: Alignment tape colour bar
 Adjust while observing the monitor TV screen.

[Adjustment method]

- i) Minimize beats with RV14.

- 8) White Peak Clip Adjustment (MA-3 Board)
 Use an AC adapter for adjustment because, in the case of the TT unit, power is not supplied to the RF-modulator.

Mode: Stop

Test signal switch: ON

Oscilloscope: Pin ⑰ of IC8

[Adjustment method]

- i) Turn RV6 and set it to just before the waveform clips.




Fig. 5-4-4. White peak clip adjustment

5-4-2. Slow Motion Playback System Alignment

1) JOG AFC Adjustment (MA-3 Board)

- Threading without cassette tape
- Mode: Playback
- Counter: Pin ⑮ of IC7

[Adjustment method]

- i) Adjust to $15.625 \text{ kHz} \pm 0.1 \text{ kHz}$ with RV5.




Fig. 5-4-5. JOG AFC adjustment

2) JOG Level Adjustment (MA-3 Board)

- Mode: Playback
- Signal: Self-recorded tape
- Oscilloscope: Pin ⑮ of IC5

[Adjustment method]

- i) Make a note of the output at normal PB time. (Approx. 600 mV_{p-p})
- ii) Press the PAUSE button to set STILL mode.
- iii) Equalizer the level at STILL time to the level at normal PB time with RV4.




Fig. 5-4-6. JOG level adjustment

5-4-3. Record System Alignment

1) Sync and Peak AGC Adjustment (MA-3 Board)

- Mode: Record
- Oscilloscope: Pin 25 of CN802 (Accessory Connector)
- Signal: B/W

[Adjustment method]

- i) Turn RV1 fully counterclockwise (↺) as seen from the pattern side. (Peak AGC off)
- ii) Adjust to 1 V_{p-p} with RV3.
- iii) Turn RV1 clockwise (↻) and set it so that the output level just starts to lower.




Fig. 5-4-7. Sync and peak AGC adjustment

2) Carrier Set Adjustment (SF-5 Board)

- Mode: Record
- Signal: Colour bar
- Spectrum analyzer: TP1

[Adjustment method]

- i) Adjust the sync tip section to $3.8\text{M} \pm 0.04 \text{ MHz}$ with RV5.

3) Deviation Adjustment (MA-3 Board, SF-5 Board)

- Mode: Record
- Signal: Colour bar
- Spectrum analyzer: TP1 of SF-5 board

[Adjustment method]

- i) Adjust the white peak section to $5.2\text{M} \pm 0.04 \text{ MHz}$ with RV2 on MA-3 board.

4) Y Record Current Adjustment (SF-5 Board)

- Mode: Record
- Signal: Colour bar
- Oscilloscope: Center of RV18

[Adjustment method]

- i) Adjust to $300 \text{ mV} \pm 20 \text{ mV}_{p-p}$ with RV18.




Fig. 5-4-8. Y record current adjustment

- 5) Chroma Reference Frequency Adjustment (SF-5 Board)
 Mode: Record
 Signal: None
 Counter: (Pin ⑬ of IC6) TP4

[Adjustment method]

- i) Adjust to 4.433619 MHz \pm 5 Hz with CV001.

- 6) Chroma Current Adjustment (SF-5 Board)

Mode: Record
 Signal: Colour bar
 Oscilloscope: Q5 collector

[Adjustment method]

- i) Adjust to 260 mV \pm 20 mVp-p with RV17.





Fig. 5-4-9. Chroma current adjustment

- 7) Compress Adjustment (SF-5 Board)

Mode: Record
 Signal: Colour bar
 Digital voltmeter:



[Adjustment method]

- i) Adjust to 0.3V \pm 0.01 Vdc with RV2.

- 8) Dark Clip Adjustment (SF-5 Board)

Mode: Record
 Signal: Colour bar
 Digital voltmeter: Center of RV3

[Adjustment method]

- i) Adjust to 2.1V \pm 0.05 Vdc with RV3.

- 9) White Clip Adjustment (SF-5 Board)

Mode: Record
 Signal: Colour bar
 Digital voltmeter: Center of RV4

[Adjustment method]

- i) Adjust to 2.25V \pm 0.05 Vdc with RV4.

- 10) Chroma AFC Adjustment (SF-5 Board)
 Mode: Record
 Signal: None/Colour bar signal
 Counter: Pin ① of IC7

[Adjustment method]

- i) Under the condition of no signal input, adjust to 4.8 MHz \pm 0.1 MHz with RV12.
 ii) Next, input a colour bar signal, and make sure that adjustment to 5.5 MHz \pm 0.2 MHz has been made.

- 11) Chroma Peak Level (ACC) Adjustment (SF-5 Board)

Mode: Record
 Signal: Colour bar
 Oscilloscope: Pin ① of IC5

[Adjustment method]

- i) Adjust to 700 mV \pm 5 mVp-p with RV16.




Fig. 5-4-10. Chroma peak level (ACC) adjustment

- 12) Pilot Burst Signal Level Adjustment (SF-5 Board)

Mode: Record
 Signal: Colour bar
 Oscilloscope: Pin ① of IC7

[Adjustment method]

- i) Align the pilot burst signal with the chroma signal level using RV15.




Fig. 5-4-11. Pilot burst signal level adjustment

13) AFC Shift Adjustment (SF-5 Board)

Mode: Record
 Signal: Colour bar
 Oscilloscope: Pin ③ of IC7

[Adjustment method]

- i) Adjust the DC-OFFSET to zero with RV11.




Fig. 5-4-12. AFC shift adjustment

14) Pilot Burst Flag Adjustment (SF-5, SF-6 and MA-3 Boards)

Mode: Record
 Signal: Colour bar
 Oscilloscope: CH-1: Pin ②⑤ of CN802 on MA-3 board
 CH-2: Pin ⑥ of IC5 on SF-5 board

[Adjustment method]

- i) Adjust as follows with RV101 on SF-6.




Fig. 5-4-13. Pilot burst flag adjustment

15) Burst Flag Adjustment (SF-5, SF-6 and MA-3 Boards)

Mode: Record
 Signal: Colour bar
 Oscilloscope: CH-1: Pin ②⑤ of CN802 on MA-3 board
 CH-2: Pin ⑧ of IC5 on SF-5 board

[Adjustment method]

- i) Adjust as follows with RV102 and RV103 on SF-6 board.





Fig. 5-4-14. Burst flag adjustment

5-5. AUDIO SYSTEM ADJUSTMENT (LS-8 Board)

Use a Dynamicron tape for adjustments.


[Connection of Related Equipment]

- When using AC-F1E (AC power adaptor)



- When using TT-F1E (tuner/timer unit)

Note: Set the INPUT SELECT switch on LINE.



[Adjustment Sequence]

1. ACE head adjustment . . . See "Mechanical Adjustment"
2. Playback frequency characteristic adjustment
3. Playback output level adjustment
4. Bias oscillator check
5. Bias trap adjustment
6. Record bias adjustment
7. Record current adjustment
8. Audio dubbing bias adjustment and check
9. Overall frequency characteristic check
- *10. AGC output check
- *11. Overall S/N check
- *12. Overall distortion check

Note: The adjustment items marked * are for AC-F1E and TT-F1E for which the input level is different.

1. **ACE Head Adjustment**
Refer to "Mechanical Adjustment"
2. **Playback Frequency Characteristic Adjustment**
 - (1) Play back 333 Hz and 5 kHz from the alignment tape and adjust so that the level difference between 333 Hz and 5 kHz is within 0 dB ± 1 dB with RV001.
3. **Playback Output Level Adjustment**
 - (1) Play back 333 Hz from the alignment tape and adjust so that the output level is -25 dB ± 1 dB with RV002.
4. **Bias Oscillator Check**
 - (1) Set the input signal level to zero and set up the RECORD mode.
 - (2) Connect a frequency counter to TP006. The reading should be 65 kHz ± 6.5 kHz. (See Fig. 5-5-1)




Fig. 5-5-1. Bias oscillator check

5. **Bias Trap Adjustment**
 - (1) Set the input signal level to zero and set up the RECORD mode.
 - (2) Connect an oscilloscope to TP005.
 - (3) Adjust LV001 for minimum bias leak.
Value: minimum level below 1.0 Vp-p. (See Fig. 5-5-2)




Fig. 5-5-2. Bias trap adjustment

6. Record Bias Adjustment

Check that "Playback frequency characteristic adjustment" has been made.

- (1) Connect TP007 and TP004 (GND) with a jumper wire so as to turn off the AGC operation.
- (2) Supply a 333 Hz signal.
- (3) Set up the E-E mode and adjust the oscillator output level so that the level meter reading is -25 dB.
- (4) Record signals.
- (5) Supply a frequency of 7 kHz and perform Steps (3) and (4) above.
- (6) Play back the recorded section of the tape and check that the output level at 7 kHz is ± 1 dB relative to the output level at 333 Hz. If the level is outside this range, repeat Steps (2) through (5) adjusting with CV001 until the standard is met.
- (7) Remove the jumper wire after making the adjustment.

7. Record Current Adjustment

- (1) Connect TP007 and TP004 (GND) with a jumper wire so as to turn off the AGC operation.
- (2) Supply a 333 Hz signal.
- (3) Set up the E-E mode and adjust the oscillator output level so that the level meter reading is -5 dB.
- (4) Record signals.
- (5) Play back the recorded section of the tape and check that the output level is -5 dB ± 1 dB. If the level is outside this range, repeat Steps (2) through (4) above adjusting with RV003 until the standard value is obtained.
- (6) Verify that the record current adjustment has been completed.
- (7) Remove the jumper wire after making the adjustment.

8. Audio Dubbing Bias Adjustment and Check

- (1) Connect TP007 and TP004 (GND) with a jumper wire so as to turn off the AGC operation.
- (2) Supply a 333 Hz signal.
- (3) Set up the E-E mode and adjust the oscillator output level so that the level meter reading is -25 dB.
- (4) Set up the DUB mode (Depress the playback button while pressing the DUB button).
- (5) Supply a frequency of 7 kHz and perform Steps (3) and (4).
- (6) Play back the recorded section of the tape and check that the output level at 7 kHz is ± 1 dB relative to the 333 Hz output level. If the level is outside this range, repeat Steps (2) through (5) adjusting with LV002 until the standard value is obtained.
- (7) Remove the jumper wire after making the adjustment.

9. Overall Frequency Characteristic Check

- (1) Connect TP007 and TP004 (GND) with a jumper wire so as to turn off the AGC operation.
- (2) Connect a 333 Hz signal.
- (3) Set up the E-E mode and adjust the oscillator output level so that the level meter reading is -25 dB.
- (4) Record signals.
- (5) Change the frequency to 50 Hz, 100 Hz, 5 kHz and 7 kHz and repeat Steps (3) and (4).
- (6) Play back the recorded section of the tape and verify that the level is within the specification. (See Fig. 5-5-3).

Standard values: With reference to the 333 Hz playback output level.

50 Hz $+2.5$ dB
 -12 dB

100 Hz $+2.5$ dB
 -3.5 dB

5 kHz $+2.5$ dB
 -3.5 dB

7 kHz $+2.5$ dB
 -3.5 dB

10 kHz $+2.5$ dB
 -15 dB

- (7) If the specified values cannot be attained, perform 2 again. "Playback Frequency Characteristic Adjustment" and 6. "Record Bias Adjustment".
- (8) Remove the jumper wire after making the adjustment.




Fig. 5-5-3. Overall frequency characteristic

10. AGC Output Check

- (1) Connect a 333 Hz signal at -20 dBs for AC-F1E and at -10 dBs for TT-F1E.
- (2) Record signals.
- (3) Play back the recorded section of the tape and check that the output level is -5 dB ± 2 dB.

11. Overall S/N Check

- (1) Set the input signal level to zero and record signals.
- (2) Supply a 333 Hz signal at -20 dBs for AC-F1E and at -10 dBs for TT-F1E.
- (3) Record signals.
- (4) Play back the recorded section of the tape and check that the output level difference is greater than 40 dB.

12. Overall Distortion Check

- (1) Supply a 400 Hz signal at -20 dBs for AC-F1E and at -10 dBs for TT-F1E.
- (2) Record signals.
- (3) Play back the recorded section of the tape and verify that the distortion is below 4%.

