

## General Electric Co.

**Model: 106**

**Chassis:**

**Year: Pre 1948**

**Power:**

**Circuit:**

**IF:**

**Tubes:**

**Bands:**

### Resources

**Riders Volume 21 - CHANGES 21-2**

**Riders Volume 15 - GE 15-9**

**Riders Volume 15 - GE 15-10**

**General Electric 50**

This model appears on pages 15-1 through 15-4 of *Rider's Manual Volume XV*. The following items should be added to the parts list:

Symbol	Part No.	Description
R4	RRC-013	1.0-megohm volume control
	RJS-060	Tube socket, miniature tube socket for 35W4 rectifier
	RJX-010	Assembly, tube socket and mounting plate assembly for 35W4 rectifier.
	RHH-004	Snapfastener, for mounting cabinet-back.

**General Electric 106**

This model appears on pages 16-9 through 16-10 of *Rider's Manual Volume XV*. Part no. RJX-005 should be changed to read RJX-007. Delete part no. ROP-006. Add part no. UOX-001, cone, replacement speaker cone.

**General Electric 115, 115W**

These models appear on page 18-13 of *Rider's Manual Volume XVIII*. The following changes have been made in the parts list.

Delete catalogue numbers and parts RDK-121 and RDK-122.

Add the following:

RAG-019	Grille, for Model 115 and 115W
RDK-150	Knob and bezel, brown, for Model 115
RDK-151	Knob and bezel, white, for Model 115W.

**General Electric 118, 119**

These models appear on pages 19-8 through 19-10 of *Rider's Manual Volume XIX*. The following changes should be made in the parts list. RLC-001 should be changed to RLC-061, T4, coil, oscillator coil. RAV-054 should be RAV-054.

Add:

RAV-056	Cabinet, Model 119 (oak)
RDK-037	Knob, plain, fawn colored
RDK-040	Knob, with arrow, fawn colored
RHH-004	Snapfastener, holds cabinet back to cabinet on Model 118

**General Electric 123, 124**

These models appear on pages 20-13 through 20-15 of *Rider's Manual Volume XX*. The following changes should be noted in the replacement parts list. Item RDS-083 is a metal dial scale, tan color, with red and white figures. Later production receivers use the same type scale except for color. The later scale, cat. no. RDS-091, is gold in color, with brown and white figures.

The following catalogue numbers have been changed: URD-127 should read URD-137, R5, Resistor, 4.7 megohms, ½ w, carbon; RAU-037 should read RAU-307, Cabinet, Model 124 plastic cabinet (ivory).

**General Electric 303**

This model appears on pages 15-37 through 15-39 of *Rider's Manual Volume XV*. The symbol for RSW-019, switch, tone control switch, should read S4. Stock no. RMX-013 should be changed to read stock no. RMX-079.

**General Electric 125**

This model is identical mechanically and electrically to the late production Model 123 and 124 receivers, which appear on pages 20-13 through 20-15 of *Rider's Manual Volume XX*. Model 125 is identified by its maroon color plastic cabinet. The cabinet replacement is listed as: RAU-321, Cabinet, plastic, for Model 125.

**General Electric 123, 124, 125, 135, 136, 226**

Models 123, 124, and 125 appear on pages 20-13 through 20-15 of *Rider's Manual Volume XX*. Models 135 and 136 appear on pages 20-16 through 20-18 of the same *Volume*. Model 226 appears on pages 20-27 through 20-29 of the same *Volume*.

The grid resistor, URD-113, 470,000 ohms, ½ watt, carbon, has been changed in later production receivers to URD-121, 1 megohm. This change improved the audio gain.

**General Electric 135, 136, 226**

Models 135 and 136 appear on pages 20-16 through 20-18 of *Rider's Manual Volume XX*. Model 226 appears on pages 20-27 through 20-29 of the same *Volume*.

Late production receivers use a new type output transformer having a tapped primary. The tapped section to the B+ lead is connected in series with the power-supply filter resistor at the input filter capacitor. B+ ripple current through this winding is out of phase with ripple current to the receiver tubes, thus producing bucking voltage and reducing hum. The transformer leads are connected as follows: yellow to input filter capacitor, red to filter resistor, blue to plate of input tube, and secondary leads to speaker voice coil.

The new transformer, catalogue number RTO-078, will be carried in replacement stock in place of the original early production items RTO-063 and RTO-075 for the Models 135, 136, and 226, respectively.

**General Electric 141, 143**

Instability on the high end of the broadcast band might be caused by an oscillator coil whose coupling winding has changed its coupling capacitance. This defect can be corrected by replacing the coupling winding with a capacitor C15 of the value 56  $\mu\text{f}$ , catalogue number UCG-022. This capacitor connects the "high" side of the tuning capacitor C2 with the oscillator grid, pin 4, of the tube V1, 1R5.

Late production receivers always use capacitor C15 in conjunction with a new type of oscillator coil, RLC-101. This item replaces coil formerly catalogued RLC-089.

The hinge used in these receivers can easily be removed and replaced in the plastic cabinet or cover by the application of heat. To remove the hinge from the back cover or cabinet proper, heat the hinge at the half to be removed from the cabinet with a soldering iron. The hinge may then be pulled out of the groove of the plastic hinge recess. Since the cabinet plastic softens at a relatively low temperature, it will be unnecessary to apply the heat very long. To replace the hinge into the new unit, first start the hinge into the slotted recess in the plastic, then heat the hinge with the soldering iron and gently push the hinge into place.

**General Electric 124, 135, 136**

Model 124 appears on pages 20-13 through 20-15 of *Rider's Manual Volume XX*; Models 135 and 136 appear on pages 20-16 through 20-18 of the same *Volume*.

Where speakers have broken loose from cabinet mountings, or damage occurs when servicing receiver, the speaker can be re-mounted using screws in place of the original clips where the mounting bosses are broken. It is suggested that all four bosses be re-worked to use screws for mounting, since the operation of removing the speaker may result in the breaking of additional bosses. The repair procedure is outlined as follows:

1. Cut off speaker mounting bosses and file flat to the level of the speaker baffle ring.
2. Drill hole 5/16-inch deep in each boss with #42 or 3/32-inch diameter drill.
3. Mount speaker with self-tapping screws #4 x ¼ inch long, Shakeproof Type 25, catalogue number RHS-044.

**General Electric 233 Kaiser-Frazer**

This model appears on pages 18-29 through 18-36 of *Rider's Manual Volume XVIII*. Noise in the form of rattle can be attributed to mechanical insecurity of parts, loose fittings, and screw fastenings, etc. Some of these are:


1. Loose tone control knobs and loose tone and volume control shafts may rattle against the cast grille. The keyway in the tone control shaft may be spread slightly to provide a tighter fit to the control knob.
2. If the shaft assembly seems loose or tends to rattle within the grille mounting hole, a ¼-inch length of #1 spaghetti (fabric or cambric tubing) may be slipped over the shaft assembly and into the bushing. This will displace the loose fitting and cushion against rattle.
3. Vibration of the screen which is set behind the case instrument panel grille causes a buzz sound when loose. The screen may be shimmed at its four corners to stabilize its mounting.

Suggestions for improving circuit and pick-up noise are as follows:

1. The former condition can be improved by antenna selection and careful peaking of the antenna trimmer to increase sensitivity and reduce noise. For metropolitan areas, a 62-inch antenna is quite adequate, while in outlying country areas the antenna length of 93 inches is recommended. Adjustment of the antenna trimmer is important and should not be overlooked. Every receiver installation should be adjusted for normal operation after the receiver has been operating approximately 15 minutes to reach normal operating temperatures, and with antenna fully extended. Tune in one of the weakest stations at approximately 1,200 kc, or near the higher-frequency end of the dial scale. Adjust trimmer for minimum noise level and maximum clarity on station used for test.
2. Noise pick-up may come from various sources, chiefly from ignition circuits of the car. The recommended noise suppressor and noise filter capacitor units should be checked. To eliminate wheel static insert about ½ ounce of powdered graphite through the valve of all four tire tubes. This will provide a ground leakage path to dampen static radiation.

GENERAL ELECTRIC CO.

MODEL 106




STAGE GAIN AND VOLTAGE CHECKS

Stage gain measurements by vacuum tube voltmeter or similar measuring devices may be used to check circuit performance and isolate trouble. The gain values listed may have tolerances of 20 per cent. Readings taken with low signal input so that AVC is not effective.

- (1) R-f Stage Gains.
  - Antenna post to 12SA7 grid..... 4 @ 1000 kc
  - 12SA7 grid to 12SG7 grid..... 30 @ 455 kc
  - 12SG7 grid to 12SQ7 diode plate..... 150 @ 455 kc
- (2) Audio Gain.
  - 0.06 volts at 400 cycles across volume control (R8) with control set at maximum will give approximately 1/2 watt output across speaker voice coil.
- (3) Oscillator Grid Bias.
  - D-c voltage developed across the oscillator grid leak (R3) averages 7.7 volts at 1000 kc.
- (4) Socket Pin Voltages.
  - Fig. 4 shows voltages from all tube pins to B—unless otherwise specified. Voltage readings much lower than those specified may help localize defective components or tubes.

Operating Frequencies  
 Broadcast Band..... 540-1600 kilocycles  
 I-F Amplifier..... 455 kilocycles

VIEW FROM BOTTOM OF CHASSIS



CONDITION OF TEST

MEASUREMENTS TAKEN ON 20,000 OHMS PER VOLT METER  
 MEASURED FROM PIN TO B-BUS UNLESS SHOWN OTHERWISE  
 I17 VOLTS LINE  
 VOLUME CONTROL - CLOCKWISE  
 NO SIGNAL INPUT

ELECTRICAL RATING (INPUT)

Voltage..... 105-125 volts a-c  
 Frequency..... 60 cycles  
 Wattage (Including Phonograph)..... 55 watts

5-46

IF TRANSFORMER WIRING CODE



BOTTOM VIEW

CAPACITY IN MMF UNLESS NOTED

