


# D-E707/E775

## SERVICE MANUAL

Ver 1.1 1999.02



US Model  
Canadian Model  
AEP Model  
UK Model  
E Model  
Australian Model  
Chinese Model  
D-E775  
Tourist Model  
D-E707

Model Name Using Similar Mechanism	D-E700/E705
CD Mechanism Type	CDM-2911EBA
Optical Pick-Up Name	DAX-11E

### SPECIFICATIONS

#### CD player section System

Compact disc digital audio system

#### Laser diode properties

Material: GaAlAs

Wavelength:  $\lambda=780$  nm

Emission duration: Continuous

Laser output: Less than 44.6  $\mu$ W (This output is the value measured at a distance of 200 mm from the objective lens surface on the optical pick-up block with 7 mm aperture.)

#### Error correction

Sony Super Strategy Cross Interleave Reed Solomon Code

#### D-A conversion

1-bit quartz time-axis control

#### Frequency response

20 – 20,000 Hz  $\pm 1/2$  dB (measured by EIAJ CP-307)

#### Output (at 4.5 V input level)

Headphones (stereo minijack)

15 mW + 15 mW at 16 ohms

Line output (stereo minijack)

Output level 0.7 V rms at 47 kilohms

Recommended load impedance over 10 kilohms

Optical digital output (optical output connector)

Output level: -21 to -15 dBm

Wavelength: 630 – 690 nm at peak level

#### General

##### Power requirements

For the area code of the model you purchased, check the upper left side of the bar code on the package.

- Two Sony NH-DM2AA rechargeable batteries: 2.4 V DC
- Two Sony NC-DMAA rechargeable batteries: 2.4 V DC
- Two LR6 (size AA) batteries: 3 V DC
- AC power adaptor (DC IN 4.5 V jack):  
US/Canadian model: 120 V, 60 Hz  
AEP/E13 model: 220 – 230 V, 50/60 Hz  
UK model: 230 – 240 V, 50 Hz  
Australian model: 240 V, 50 Hz  
Tourist/E33 model: 100 – 240 V, 50/60 Hz  
Hong Kong model: 220 V, 50/60 Hz  
Chinese model: 220 V, 50 Hz
- Sony DCC-E245 car battery cord for use on car battery: 4.5 V DC

##### Dimensions (w/h/d) (without projecting parts and controls)

Approx. 131.8 × 23.9 × 142.0 mm  
(5 1/4 × 31/32 × 5 5/8 in.)

##### Mass (without rechargeable batteries)

Approx. 200 g (7.0 oz)

##### Operating temperature

5 °C – 35 °C (41 °F – 95 °F)

#### Supplied accessories

For the area code of the model you purchased, check the upper left side of the bar code on the package.

- AC power adaptor (1)
- Headphones with remote control (1)\*1
- Earphones with remote control (1)\*2
- Rechargeable batteries (2)
- AC plug adaptor (1)\*3
- Battery carrying case (1)
- Carrying case (1)
- \*1 Supplied with US model
- \*2 Not supplied with US model
- \*3 Supplied with Tourist, E33 and E13 models

Design and specifications are subject to change without notice.

- Abbreviation  
E13: 220 – 230 V AC area in E model  
E33: 100 – 240 V AC area in E model

## COMPACT DISC COMPACT PLAYER



# SONY®

## TABLE OF CONTENTS

1. SERVICING NOTES .....	3
2. GENERAL .....	4
3. DISASSEMBLY .....	8
4. SERVICE MODE .....	9
5. ELECTRICAL ADJUSTMENTS .....	10
6. DIAGRAMS	
6-1. Block Diagram – MAIN Section – .....	15
6-2. Block Diagram – POWER SUPPLY Section – .....	19
6-3. IC Pin Function Description .....	21
6-4. Printed Wiring Boards (Suffix-11) .....	24
6-5. Schematic Diagram (Suffix-11) .....	27
6-6. Schematic Diagram (Suffix-12) .....	31
6-7. Printed Wiring Board (Suffix-12) .....	35
7. EXPLODED VIEWS .....	43
8. ELECTRICAL PARTS LIST .....	46

This appliance is classified as a CLASS 1 LASER product. The CLASS 1 LASER PRODUCT MARKING is located on the rear exterior.




### CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

### Discrimination of MAIN board

– MAIN BOARD (Side A) –



### Flexible Circuit Board Repairing

- Keep the temperature of the soldering iron around 270 °C during repairing.
- Do not touch the soldering iron on the same conductor of the circuit board (within 3 times).
- Be careful not to apply force on the conductor when soldering or unsoldering.

### Notes on chip component replacement

- Never reuse a disconnected chip component.
- Notice that the minus side of a tantalum capacitor may be damaged by heat.

### SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK  $\triangle$  OR DOTTED LINE WITH MARK  $\triangle$  ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

### ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE  $\triangle$  SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

## SECTION 1 SERVICING NOTES

### NOTES ON HANDLING THE OPTICAL PICK-UP BLOCK OR BASE UNIT

The laser diode in the optical pick-up block may suffer electrostatic breakdown because of the potential difference generated by the charged electrostatic load, etc. on clothing and the human body. During repair, pay attention to electrostatic breakdown and also use the procedure in the printed matter which is included in the repair parts.

The flexible board is easily damaged and should be handled with care.

#### Before Replacing the Optical Pick-Up Block

Please be sure to check thoroughly the parameters as per the "Optical Pick-Up Block Checking Procedures" (Part No.: 9-960-027-11) issued separately before replacing the optical pick-up block. Note and specifications required to check are given below.

- FOK output: IC501 ⑫ pin  
When checking FOK, remove the lead wire to disc motor.
- S curve P-to-P value: 0.6 to 1.8 Vp-p IC501 ⑓ pin  
When checking S curve P-to-P value, remove the lead wire to disc motor.
- RF signal P-to-P value: 0.8 to 1.2 Vp-p
- Traverse signal P-to-P value: 1.2 Vp-p
- The repairing grating holder is impossible.

#### Precautions for Checking Emission of Laser Diode

Laser light of the equipment is focused by the object lens in the optical pick-up so that the light focuses on the reflection surface of the disc. Therefore, be sure to keep your eyes more than 30 cm apart from the object lens when you check the emission of laser diode.

#### Laser Diode Checking Methods

During normal operation of the equipment, emission of the laser diode is prohibited unless the upper panel is closed while turning ON the S801. (push switch type)

The following two checking methods for the laser diode are operable.

#### • Method (In the service mode or normal operation): Emission of the laser diode is visually checked.

1. Open the upper lid.
2. Push the S801 as shown in Fig. 1.
3. Press the ►|| key.
4. Check the object lens for confirming normal emission of the laser diode. If not emitting, there is a trouble in the automatic power control circuit or the optical pick-up.  
During normal operation, the laser diode is turned ON about 2.5 seconds for focus searching.




Fig. 1 Method to push the S801


## SECTION 2 GENERAL

This section is extracted from instruction manual.

# Playing a CD right away!

If you want to play a CD right now, choose to use your player on house current. Other choices are the following three: rechargeable battery, dry batteries (see "Power Sources" on the reverse side) and car battery.


## 1 Connect




**For models supplied with the AC plug adaptor**  
If the AC power adaptor does not fit the wall outlet, use the AC plug adaptor.

**For models supplied with the remote control**  
• Connect the plug of the earphones/headphones to the remote control.  
• Connect the earphones/headphones to the remote control firmly. A loose connection may cause noise during playback.

## 2 Place a CD




## 3 Play



To stop play, press ■.

**To use the remote control**  
The lever marked with ◀▶ is the jog lever. When you press or slide the lever, operation starts.



To	Do this
Pause	Press the jog lever toward ►.
Resume play after pause	Press the jog lever toward ►.
Find the beginning of the current track (AMS*)	Slide the jog lever toward ◀ once.**
Find the beginning of previous tracks (AMS)	Slide the jog lever toward ◀ repeatedly.**
Find the beginning of the next track (AMS)	Slide the jog lever toward ▶ once.**
Find the beginning of succeeding tracks (AMS)	Slide the jog lever toward ▶ repeatedly.**
Go forward quickly	Slide and hold the jog lever toward ▶.**
Go backwards quickly	Slide and hold the jog lever toward ◀.**

\*AMS = Automatic Music Sensor  
\*\*These operations are possible during both play and pause.

If you press REPEAT/ENTER on the player to display "◀▶", you can locate the tracks continuously in the following order:

- When using ►: next track → next track ... last track → first track → second track ...
- When using ◀: previous track → previous track ... first track → second track ...

You can do the operations shown in the above table using the buttons with the same marks on the player.

**To remove the CD**  
Remove the CD while pressing the pivot.



**Notes on controlling the volume with the remote control**  
Set the VOL (volume) control on the remote control to the maximum. Then adjust the volume on the player to the level that you want to be the maximum volume of the remote control.

**Notes on display**

- When you press ► (when RESUME is set to OFF), the total number of tracks in the CD and the total playing time appear for about 2 seconds.
- During play, the track number and the elapsed playing time of the current track appear.
- During pause, the elapsed playing time flashes on the display.
- Between tracks, the time to the beginning of the next track will appear with the "—" indication.

### Illumination of the display on the remote control

When using the player on the AC power adaptor or car battery, the display is always illuminated. (Light of the display goes out when you press ■ and the CD stops.)

When you use the player on the rechargeable batteries or alkaline batteries, the display is illuminated for about 5 seconds when you press any operation button. But, when using the optical digital connecting cord, the display is not illuminated. When you press the LIGHT button on the remote control, the display is illuminated for about 5 seconds.

You can turn off the illumination of the display by first removing the rechargeable batteries or alkaline batteries; then while pressing the PLAY/MODE button, reinsert the batteries.

### Notes on handling CDs


- To keep the CD clean, handle it by its edge. Do not touch the surface.
- Do not stick paper or tape onto the CD.
- Do not expose the CD to direct sunlight or heat sources such as hot air ducts. Do not leave the CD in a car parked under direct sunlight.



## ► Other Operations

### Playing tracks repeatedly (Repeat Play)

You can play tracks repeatedly in normal, INTRO PGM, shuffle or RMS (Random Music Sensor) play modes. Repeat all the tracks, only one track or the specified part within the same track.



#### To repeat all the tracks

Press RPT/ENT (REPEAT/ENTER) on the player) during play. The "☀" indication appears.



To cancel repeat play, press RPT/ENT again.

#### To repeat a single track

1 Press RPT/ENT while the track you want to repeat is playing. The "☀" indication appears.



2 Press P (play) MODE (PLAY MODE) on the player) repeatedly until "1" appears.




To repeat another track, slide the jog lever toward ◀◀ or ▶▶.


To cancel repeat play, press RPT/ENT again.

#### To repeat the specified part within the same track (LOOP Play)


1 During play, press P MODE repeatedly until "A↔B" flashes in the display.



2 Press RPT/ENT to set the point (point A) where you want to start repeat play. Point A is stored in the memory.



3 Press RPT/ENT again to set the point (point B) where you want to stop repeat play. Point B is stored in the memory, and repeat play starts from point A.



To change points A and B, press and hold RPT/ENT until "A↔B" flashes in the display, then do steps 2 and 3 again.


To set points A and B on other tracks, slide the jog lever toward ◀◀ or ▶▶ to select another track, then do steps 2 and 3 again.

If you press ■, the stored points will be erased. To prevent accidental erasure, set the RESUME switch at the rear of the player to ON.


To cancel repeat play, press P MODE until "A↔B" disappears from the display.

### Playing only the tracks you want (INTRO PGM Play)

You can choose and play your favorite tracks by scanning through the beginning of each track in a CD.



1 During play, press P MODE repeatedly until "INTRO PGM" flashes.



2 Press the jog lever toward ▶▶ to start scanning.

The player plays about the first 15 seconds of each track and "INTRO PGM" flashes faster.

3 Press RPT/ENT while the track you want is playing. To skip the track, slide the jog lever toward ▶▶ or just wait for the next track.

After you have gone through the CD, "INTRO PGM" stops flashing and the tracks you have chosen play automatically.


To finish programming before going through the whole CD, press the jog lever toward ▶▶. The selected tracks will be played.

If you press ■, the program will be erased. To prevent accidental erasure, set the RESUME switch at the rear of the player to ON.

To cancel INTRO PGM play, press P MODE repeatedly until the play mode indication disappears from the display.

### Playing tracks in random order (Shuffle Play)

You can play the tracks in a CD in random order.



During play, press P MODE repeatedly until "SHUFF" appears. The tracks play in random order.




To cancel shuffle play, press P MODE repeatedly until the play mode indication disappears from the display.

#### Note

• During shuffle play, you cannot return to previous tracks by sliding the jog lever toward ◀◀.

### Playing tracks in the order you want (RMS play)

You can program up to 22 tracks to play in any order you choose.




1 During play, press P MODE repeatedly until "RMS" flashes.



\*RMS = Random Music Sensor

2 Slide the jog lever toward ◀◀ or ▶▶ to choose a track. The track number and the playing order appear.



3 Press RPT/ENT to program the track.

4 Repeat steps 2 and 3 to program the remaining tracks.

5 Press the jog lever toward ▶▶. "RMS" stops flashing and the tracks you have chosen play in the order you specified.

If you press ■, the program will be erased. To prevent accidental erasure, set the RESUME switch at the rear of the player to ON.

To cancel RMS play, press P MODE until "RMS" disappears from the display.

#### To check the program

During programming

Press RPT/ENT before step 5.

During RMS play:

Press P MODE repeatedly until "RMS" flashes, then press RPT/ENT. Each time you press RPT/ENT, the track number and the playing order appear in the order you specified.

#### Note

• If you program another track after the 22nd track, the first track programmed is cleared and the new track is programmed instead.


## Using other functions

### To minimize skipping (ESP)

The ESP (Electronic Shock Protection) function minimizes skipping by using a buffer memory that stores music data and plays it back in the event of a shock.

The new ESP<sup>2</sup> (ESP Squared) system uses a new DSP (Digital Signal Processor) which can read and store music data more efficiently and with superior sound quality, providing a level of continuous skip protection not found in traditional buffer memory units. This decreases the frequency of sound skipping and the need to utilize the buffer memory. Use this function when listening in a car or while walking.

\* Although ESP<sup>2</sup> provides excellent protection against skipping, it will not prevent skipping while jogging or running.



Press ESP.

The "ESP" indication appears.




To release the ESP function, press ESP again.

#### Notes

- Playing may stop when the player gets a strong shock even with the ESP function on.
- You may hear a noise or sound skip when:
  - listening to a dirty or scratched CD.
  - listening to an audio test CD or, the player receives continuous shock.
- Sound may drop for a while if you press ESP during play.
- When you use an optical digital connecting cord, the ESP function will be disabled.

### To enjoy more powerful bass sound (Sound function)

You can enjoy a powerful bass-booster sound.




Press SOUND to select "MB (Mega Bass)" or "GRV (Growl)". "GRV" is more effective.

#### Note

- If the sound is distorted when emphasizing bass, turn down the volume.

### To lock the buttons

You can lock your player against any accidental operations. You can still operate the player with the remote control.




Slide HOLD in the direction of the arrow. When you press any button, "Hold" appears in the display and you cannot operate the player.


To unlock, slide HOLD back.

Continue to the reverse side →

**To protect your hearing (AVLS)**  
The AVLS (Automatic Volume Limiter System) function keeps down the maximum volume to protect your ears.




Set AVLS to LIMIT.  
The AVLS indication appears.



**Note**  
• If you use the SOUND function and the AVLS function at the same time, sound may be distorted. If this happens, turn down the volume.

**To resume playing from the point you stopped the CD (Resume Play)**  
Normally, every time you stop and play, playing starts from the beginning of the CD. The resume play function, however, lets you listen to from the point at which you last turned off the player.



Set RESUME to ON.

To cancel resume play, set RESUME to OFF.

**Notes**

- Even if RESUME is set to ON, playing starts from the beginning when you open the lid.
- The resume point may be inaccurate by about 30 seconds.

**To turn off the beep**


You can turn off the beep that sounds as you operate your player.

Disconnect the power source (AC power adaptor, rechargeable battery or alkaline batteries). While you press and hold down ■, connect the power source again. To make the beep sound again, disconnect the power source, and then connect it without pressing ■.

## Connecting to other stereo equipment


You can listen to the CD through other stereo equipment or record a CD on a cassette tape or a MiniDisc. Refer to the instruction manual of the other equipment for details. Before making connections, turn off each piece of equipment.

### Using the connecting cord



**Note**  
• When you use a connecting cord, the SOUND function will be disabled.

### Using the optical digital connecting cord



\*If the OPTICAL (DIGITAL) IN jack is square-shaped, use the PCC-5AB optical digital connecting cord instead.

#### Notes on connecting to other stereo equipment

- Before you play the CD, turn down the volume of the connected equipment so as not to damage the connected speakers.
- The beep sound is not output from the LINE OUT (OPTICAL) jack.
- When you connect other equipment to the LINE OUT (OPTICAL) jack of this player, adjust the volume on the connected equipment.
- When you record a CD on a cassette tape using a tape recorder that has the blank search function, release the ESP function. If the ESP function is on, the blank search function does not work.
- Use the AC power adaptor for recording. If you use the rechargeable batteries or dry batteries as a power source, batteries may become weak during recording.

#### Recording with optical digital connection

Record a CD on a MiniDisc, DAT, etc., according to the following procedure:

1. Press ■ on the player to start play.
2. Press ■ again to pause.
3. Press ■/■ to select the track you want to record.
4. Press ● (record) on the MiniDisc recorder, DAT recorder, etc.
5. Press ■ on the player to release pause.

**Notes**

- Connect the optical digital connecting cord while the player is in stop mode.
- If you record without pausing the player, some CD may have problem with recording the first track number correctly.
- The SOUND function works on the output from the LINE OUT (OPTICAL) jack, but does not work on that from the LINE OUT (OPTICAL) jack.
- When use an optical digital connecting cord, the ESP function will be disabled.

#### Playing a CD in a car

You can use your player in a car by connecting it to the car cassette deck.

You cannot use the car mount plate for this player.

When you use the player in a car, install it securely in a location which does not interfere your driving.

To connect your player to a car cassette deck, you need the following accessories:

- Car connecting pack CPA-9
- Car battery cord DCC-E245 or,
- Car battery cord with car connecting pack DCC-E26CP

Refer to the instruction manual of each accessory for details.

**Notes**


- Do not put the player on the dashboard.
- Do not leave the player in a car parked under sunlight.
- Use a Sony car connecting pack for reducing noise.
- Use only the car battery cord listed in the recommended accessories. If you use any other car battery cord, smoke, fire or malfunction may occur.

#### Switched ignition function (when using the car battery cord)

With this feature, your player stops automatically when you turn off the engine of the car. (This function is not possible with some cars depending on the model.)

## Using the supplied remote control

You can use the remote control as the wired remote control.



- \* When you are not using the remote control, slide HOLD in the direction of the arrow to prevent any accidental operations. To unlock, slide HOLD back.
- \*\* Automatic Music Sensor
- \*\*\* Electronic Shock Protection

**Note**


- Use only the supplied remote control. You cannot operate this player with the remote control supplied with other models.

## Power Sources


### Using rechargeable batteries

Charge the rechargeable batteries before using them for the first time. Use the NH-DM2AA or NC-DM4A rechargeable batteries for this player. You cannot use any other rechargeable batteries.


1 Open the lid of the battery compartment.



2 Insert two rechargeable batteries by matching the ⊕ and ⊖ to the diagram inside the battery compartment and close the lid.




3 Connect the AC power adaptor. The indication "CHG" lights up. Charge for about 4 hours. (If the battery has been already charged, "CHG" and ● flash.)



4 When fully charged, "CHG" disappears. Disconnect the AC power adaptor.

### To take out the rechargeable batteries

Take out the batteries in the proper way as illustrated inside the lid or shown below.



### When to charge the rechargeable batteries

When the rechargeable batteries become weak, ● indication appears in the display. If the "Lo batt" appears in the display, charge the rechargeable batteries, because the batteries are used up. To keep the original battery capacity for a long time, recharge the batteries when the batteries are used up (discharged).

### When carrying the rechargeable battery

Make sure to use the supplied battery carrying case. If you carry the rechargeable battery with a metal object, short circuit, smoke or fire may occur.



### Notes


- Charging time varies depending on how the rechargeable battery is used.
- If the battery is new or has not been used for a long time, it may not be charged completely until you charge and discharge it several times.
- If the battery life becomes shorter by about half, replace it with Sony NH-DM2AA or NC-DMAA rechargeable battery. Do not use any other rechargeable battery.
- The supplied rechargeable batteries are only for this player. You cannot use them for other models.

## Using dry batteries

Insert the batteries properly in the same way as the rechargeable batteries.

**1** Disconnect the AC power adaptor and open the lid of the battery compartment.

**2** Insert two LR6 (size AA) alkaline batteries by matching the  $\oplus$  and  $\ominus$  to the diagram inside the battery compartment and close the lid.



### Note

- Do not use manganese batteries for this player.

### To take out the dry batteries

Take out the batteries properly in the same way as the rechargeable batteries.

### When to replace the dry batteries

When the battery becomes weak,  $\square$  indication appears in the display. If the batteries are used up, "Lo. batt" appears in the display. Replace all the batteries with new ones.

### Notes

- Do not charge the dry batteries.
- Do not mix new batteries with old ones.
- Do not use different types of batteries together.
- When the batteries are not to be used for a long time, remove them.
- If the battery leakage occurs, wipe off any deposit in the battery compartment, and install new batteries.

### Battery life (approx. hours) (EIAJ\*)

Battery life varies depending on how the player is used.


When using	ESP function	
	off	on
Two NH-DM2AA (charged for about 4 hours**)	13	12
Two NC-DMAA (charged for about 4 hours**)	8	7
Two alkaline batteries LR6SC	23	21

\*Measured value by the standard of EIAJ (Electronic Industries Association of Japan) (When you use the player on a flat and stable place. When you do not use the optical digital connecting cord)

\*\*Charging time varies depending on how the rechargeable battery is used.

### How to attach the battery compartment lid

If the battery compartment lid is detached by an accidental drop, excessive force, etc., attach it as illustrated in the numbered order.



## Additional Information

### Precautions

#### On safety

- Should any solid objects or liquid fall into the player, unplug it and have it checked by qualified personnel before operating it any further.
- Do not put any foreign objects in the DC IN 4.5 V (external power input) jack.

#### On power sources

- When you are not using the player for a long time, disconnect all power sources from the player.

#### On the AC power adaptor

- Use only the supplied AC power adaptor. If your player is not supplied with it, use AC-F1511-AC power adaptor. Do not use any other AC power adaptor.

#### Polarity of the plug



- To unplug the AC power adaptor from the wall outlet, grasp the adaptor itself, do not pull its cord.

#### On dry and rechargeable batteries

This player is designed so that it cannot charge any other rechargeable batteries or dry batteries for safety reasons.

The supplied rechargeable batteries (NH-DM2AA) or optional rechargeable batteries (NC-DMAA)



#### Other rechargeable batteries or dry batteries



When you replace the rechargeable batteries with new ones, make sure to use the NH-DM2AA/NC-DMAA rechargeable batteries.

- Do not throw the batteries into fire.
- Do not carry the batteries with coins or other metallic objects. It can generate heat if the positive and negative terminals of the battery are accidentally contacted by a metallic object.
- Do not mix rechargeable batteries with dry batteries.

#### On the player

- Keep the lens on the player clean and do not touch it. If you do so, the lens may be damaged and the player will not operate properly.
- Do not put any heavy object on top of the player. The player and the CD may be damaged.
- Do not leave the player in a location near heat sources, or in a place subject to direct sunlight, excessive dust or sand, moisture, rain, mechanical shock, unlevelled surface, or in a car with its condenser closed.
- If the player causes interference to the radio or television reception, turn off the player or move it away from the radio or television.
- Do not wrap the player in a cloth or blanket during use as it may cause malfunction or serious accidents.

#### On headphones/earphones

##### Road safety

Do not use headphones/earphones while driving, cycling, or operating any motorized vehicle. It may create a traffic hazard and is illegal in some areas. It can also be potentially dangerous to play your headsets at high volume while walking, especially at pedestrian crossings. You should exercise extreme caution or discontinue use in potentially hazardous situations.

##### Preventing hearing damage

Avoid using headphones/earphones at high volume. Hearing experts advise against continuous, loud and extended play. If you experience a ringing in your ears, reduce volume or discontinue use.


##### Caring for others

Keep the volume at a moderate level. This will allow you to hear outside sounds and to be considerate to the people around you.

## SECTION 3 DISASSEMBLY


**Note:** Follow the disassembly procedure in the numerical order given.

### CABINET (LOWER)



### INSTALLATION MAIN BOARD

On installation MAIN board adjust the S301, 803, 804, and knob (H-R, AVLS).






## SECTION 4 SERVICE MODE

### Service Mode (Service program)

The equipment is provided with a service program built in the microcomputer, like conventional models. Service program operation methods are described in the following.



Descriptions in [ ] indicate major operations in the service mode. For more information, see Step 2.

**Fig. 1** Layout of each key

### • Step 1 (Service mode setting methods)

1. Turn OFF the HOLD switch with external power supply disconnected. (power is not applied to the set)
2. Solder across the TEST terminals (TAP802). (pin 59, IC801 (ESP5L/TEST) is grounded)
3. Connect an external power supply.

Thus, the set is switched to the service mode.

### • Step 2 (Operation in the service mode)


1. Once the service mode is effected, the LCD displays 5 indications each of which is repeatedly displayed. However, the following operations can be activated even if LCD indication is effected.
2. By pressing the **▶▶** or **◀◀** key, the optical pick-up is movable inwardly or outwardly. However, if this is activated, tracking servo and sled servo are turned OFF, so it can be turned ON by pressing the PLAY MODE key if required.
3. By pressing the REPEAT/ENTER key, the tracking gain-up mode becomes active.

4. By pressing the **▶▶** key, focus is turned ON from focus searching while entering CLV-S. (draw-in mode) Without disc, focus searching is repeated continuously.
5. By pressing the PLAY MODE key, tracking servo, sled servo and CLV-A (servo in PLAY) are turned ON.
6. When step 4 and 5 are performed, playing begins. No muting is ON in the service mode.
7. By pressing the **■** key, all servos (focus, tracking and sled) are turned OFF. However, the disc motor revolves for a while by inertia.

### • Step 3 (Resetting of service mode)

1. Be sure to disconnect the external power supply and remove the solder bridge at the TEST terminals connected before in setting.
2. The set thus becomes available for normal operation.

– MAIN BOARD (Side A) –



## SECTION 5 ELECTRICAL ADJUSTMENTS

### Precautions for Adjustment

1. Before beginning adjustment, set the equipment to service mode.

After the completion of adjustment, be sure to reset the service mode.

For more information, see "Service Mode (service program)" on page 9.

2. Perform adjustments in the order given.
3. Use YEDS-18 disc (Part No.: 3-702-101-01) unless otherwise indicated.
4. Power supply voltage requirement: DC2.5 V in battery terminal

VOLUME knob : Minimum  
RESUME switch : OFF  
ESP switch : OFF  
AVLS switch : NORMAL  
HOLD switch : OFF

### Before Beginning Adjustment

Set the equipment to service mode (See page 9) and check the following. If there is an error, repair the equipment.

#### • Checking of the sled motor


1. Open the upper panel.
2. Press the ►► and ◄◄ keys and check that the optical pick-up can move smoothly without sluggishness or abnormal noise in innermost periphery → outermost periphery → innermost periphery  
►►: The optical pick-up moves outwardly.  
◄◄: The optical pick-up moves inwardly.

#### • Checking of focus searching

1. Open the upper panel.
2. Press the ►|| key. (Focus searching operation is activated continuously)
3. Check the object lens of the optical pick-up for smooth up/down motion without sluggishness or abnormal noise.
4. Press the ■ key.  
Check that focus searching operation is deactivated. If not, again press the ■ key slightly longer.

### VCC Adjustment

#### Adjustment Procedure:



1. Set the equipment to service mode stop state. (See page 9)
2. Connect the digital voltmeter to TP401 (VCC) on the MAIN board.
3. Adjust RV401 on the MAIN board so that the reading on digital voltmeter goes 2.53 V.

**Specifications:** 2.5 V to 2.55 V

4. After the completion of adjustment, reset service mode. (See page 9)


**Adjustment Location:** MAIN Board (SUFFIX-11: See page 12, SUFFIX-12: See page 13)

### Focus bias Check

#### Condition:

- Hold the set in horizontal state.


#### Check Procedure:



1. Set the equipment to service mode stop state. (See page 9)
2. Connect the oscilloscope to the test point TP522 (RFO) on the MAIN board.
3. Move the optical pick-up to the center by pressing the ►► and ◄◄ keys.
4. Put the disc. (YEDS-18)
5. Press the ►|| key.  
From focus searching, focus is turned ON while entering CLV drawing-in mode. Tracking and sled are turned OFF.
6. Press the PLAY MODE key. (Both tracking and sled are turned ON)
7. Check the oscilloscope waveform is as shown below.  
A good eye pattern means that the diamond shape (◊) in the center of the waveform can be clearly distinguished.

#### RF Signal Reference Waveform (Eye Pattern)

VOLT/DIV : 200 mV (With the 10:1 probe in use)  
TIME/DIV : 500 ns



To watch the eye pattern, set the oscilloscope to AC range and increase the vertical sensitivity of the oscilloscope for easy watching.

8. Stop revolving of the disc motor by pressing the ■ key.
9. After the completion of adjustment, reset service mode. (See page 9)

**Checking Location:** MAIN Board (SUFFIX-11: See page 12, SUFFIX-12: See page 13)

### Focus/Tracking Gain Adjustment

A servo analyzer is necessary in order to perform this adjustment exactly.

However, this gain has a margin, so even if it is slightly off, there is no problem. Therefore, do not perform this adjustment.

Focus/tracking gain determines the optical pick-up follow-up relative to mechanical noise and mechanical shock when the 2-axis device operates. However, as these reciprocate, the adjustment is at the point where both are satisfied.

- When gain is raised, the noise when 2-axis device operates increase.
- When gain is lowered, it is more susceptible to mechanical shock and skipping occurs more easily.

This adjustment has to be performed upon replacing any of the following parts.

- Optical pick-up
- RV503 (Focus gain VR)
- RV502 (Tracking gain VR)

Normally, be sure not to move RV503 (focus gain VR) and RV502 (tracking gain VR).

#### Adjustment procedure:

##### – Focus Gain Adjustment –


This adjustment is not performed.

If focus gain VR RV503 is turned, set to mechanical center.

**Adjustment Location:** MAIN Board (SUFFIX-11: See page 12, SUFFIX-12: See page 13)

##### – Tracking Gain Adjustment –

(perform at normal operation)



1. Place the optical pick-up level, horizontally. (If the optical pick-up is not level, the 2-axis device will be weighted and adjustment cannot be done)
2. Connect the oscilloscope to TP (TE) and TP520 (VC) on the MAIN board.
3. Set the disc (YEDS-18) and press the ►► key.
4. Turn RV502 slightly clockwise (tracking gain drops) and obtain a waveform with a fundamental wave (waveform has large waves) as in Figure 1.
5. Turn RV502 slowly counterclockwise (tracking gain rises) until the fundamental wave disappears (no large waves) as in Figure 2.
6. Set RV502 to the position about 30° counterclockwise from the position obtained in step 5. If RV502 contact point is more than 90° counterclockwise from mechanical center, tracking gain is too high. In this case, readjust from step 4.
7. Press ►► or ◄◄ key and observe the 100 track jump waveform. Check that no traverse waveform appears for both ►► or ◄◄ directions. (See Figures 3 and 4)  
It is acceptable if the traverse waveform appears only now and then, but if it appears constantly, raise tracking gain slightly and check step 7 again.
8. Check that there is not abnormal amount of operation noise (white noise) from the 2-axis device. If there is, tracking gain is too high, readjust starting with step 4.

The waveforms are those measured with the oscilloscope set as shown below.

- VOLT/DIV: 500 mV
- TIME/DIV: 5 ms

- Waveform when tracking gain is lowered. Fundamental wave appears. (large waves)



Fig. 1

- Waveform when fundamental wave disappears. (no large waves)



Fig. 2

- Waveform with no traverse waveform during 100 track jump. (Brake application is smooth because of adjustment)



Fig. 3

- Waveform with traverse waveform during 100 track jump. (Brake application is poor because of adjustment)



Fig. 4

- Waveform with traverse waveform during 100 track jump. (Brake application is poor because of adjustment)




Fig. 4


**Adjustment Location:** MAIN Board (SUFFIX-11: See page 12, SUFFIX-12: See page 13)

### Adjustment and Checking Location:

– MAIN BOARD (Side A) – (SUFFIX-11)




– MAIN BOARD (Side A) – (SUFFIX-12)



SECTION 6  
DIAGRAMS

6-1. BLOCK DIAGRAM - MAIN Section -




• SIGNAL PATH  
 - - - - - : CD PLAY (ANALOG OUT)  
 . . . . . : CD PLAY (OPTICAL OUT)

(Suffix -12)  
 176K (E)  
 (Page 19)



6-2. BLOCK DIAGRAM – POWER SUPPLY Section –



05

6-3. IC PIN FUNCTION DESCRIPTION


- MAIN BOARD IC801 (SYSTEM CONTROLLER)
- MC68HC05L24-SC440482CFU (SUFFIX-11), MC68HC05L24-SC440488CFU (SUFFIX-12)

Pin No.	Pin Name	I/O	Description
1	VDD	—	Power supply terminal (+3V)
2	DDCMUTE	O	DC/DC converter muting control signal output terminal
3	DPCON	O	DC/DC converter on/off selection signal output terminal
4	OE	O	Output enable signal output to the MPC17A51VMEL (IC504) "L" active
5	VCCMNT	I	Main DC/DC converter voltage (+2.75V) monitor input (A/D input)
6	MDL SL	I	Destination setting terminal Fixed at "H" in this set
7	LIGHT	O	Back light control signal output to the liquid crystal display on the switch unit "H": back light on Not used (open)
8	C2PO FILTER	O	C2PO (error condition monitor) filter on/off control signal output terminal
9	DACLT	O	Serial data latch pulse signal output to the D/A converter (IC301)
10	C2POEN	O	C2PO (error condition monitor) signal control output terminal "L": stop mode, "H": searching
11	CHGON	O	Charging on output to the MPC18A26VMEL (IC401) "L": charge on
12	RMDAT	I/O	Communication data in/out for the liquid crystal display with remote commander
13	VLCD3	O	Power supply output for the liquid crystal display bias
14	VLCD2	O	
15	VLCD1	O	
16	VSS	—	Ground terminal
17	VPP	—	Power supply terminal (0V)
18	TON	O	Traverse on/off control signal output to the auto traverse circuit
19	XOSC2	O	Standby control signal output to the headphone amplifier (IC302)
20	RESET	I	System reset signal input from the MPC18A26VMEL (IC401) "L": reset For several hundreds msec. after the power supply rises, "L" is input, then it changes to "H"
21	OSC1	I	Main system clock input terminal (4.195 MHz)
22	OSC2	O	Main system clock output terminal (4.195 MHz)
23	SUBQ	I	Sub-code Q data signal input from the BU9326KS (IC502)
24	CDATA	O	Serial data output to the D/A converter (IC301) and BU9326KS (IC502)
25	SQCK	O	Sub-code Q data reading clock signal output to the D/A converter (IC301) and BU9326KS (IC502)
26	RW	O	Data read/write selection signal output to the BU9326KS (IC502) "L": reading mode, "H": writing mode
27	PCON	O	Power on/off control signal output to the MPC18A26VMEL (IC401) "L": power on, "H": power off
28	AMUTE	O	Analog muting on/off control signal output terminal "H": muting on
29	XAVLS	I	AVLS (Automatic Volume Limiter System) switch (S301) input terminal "L": limit mode, "H": normal mode
30	XRST	O	System reset signal output to the BU9326KS (IC502) and D-RAM controller (IC601) "L": reset
31	XHOLD	I	HOLD switch (S804) input terminal "L": hold on, "H": hold off
32	XRCHG	I	Rechargeable battery pack detection switch input terminal "L": rechargeable battery pack in Not used (open)
33	XLMT	I	Sled limit-in detection switch (S901) input terminal The optical pick-up is inner position when "L"
34	XRSM	I	RESUME switch (S803) input terminal "L": resume on, "H": resume off
35	OPEN	I	CD door open/close detection switch (S801) input terminal The stop status is reset with the falling edge of input signal


Pin No.	Pin Name	I/O	Description
36	WP	I	Wake-up control signal input terminal The stop status is reset with the falling edge of input signal
37	XLT	O	Serial data latch pulse signal output to the D-RAM controller (IC601) (for ESP)
38	XSOE	O	Serial data output enable signal output terminal (for ESP) Not used (pull up)
39	SDTO	I	Serial data input from the D-RAM controller (IC601) (for ESP)
40	SDTI	O	Serial data output to the D-RAM controller (IC601) (for ESP)
41	SCK	O	Serial data transfer clock signal output to the D-RAM controller (IC601) (for ESP)
42	FOK	I	Focus OK signal input from the RF amplifier (IC501) "L": NG, "H": OK
43	BUSY	I	Busy signal input from the BU9326KS (IC502) "L": track jump mode, "H": servo loop on
44	BEEP	O	Beep sound output to the headphone amplifier (IC302)
45	SCOR	I	Sub-code sync (S0+S1) detection signal input from the BU9326KS (IC502)
46	IRMC	I	Attenuate display selection signal input from the RF amplifier (IC501)
47	VDD	—	Power supply terminal (+3V)
48 to 51	COM3 to COM0	O	Common drive signal output to the liquid crystal display on the switch unit
52	VREFH	I	Reference voltage input terminal (+3V) (for A/D converter)
53	VREFL	I	Reference voltage input terminal (0V) (for A/D converter)
54	ESPSL/TEST	I	Service mode setting terminal "L": service mode, Normally: fixed at "H"
55	KEY	I	Key input from the switch unit (A/D input)
56	RMKEY	I	Key input from the headphone with remote commander (A/D input)
57	DCINMNT	I	DC in voltage detection input terminal (A/D input) Also used for DC IN detection
58	BATMNT	I	Battery voltage detection input terminal Also used for rechargeable battery/dry battery detection
59	CHGMNT1	I	Battery charging voltage detection input from the MPC18A26VMEL (IC401)
60	VSS	—	Ground terminal
61	CHGMNT2	I	Battery voltage detection input terminal (A/D input) Also used for rechargeable battery/dry battery detection
62	OSMNT	I	DSP offset voltage adjustment voltage monitor input from the BU9326KS (IC502)
63 to 77	SEG0 to SEG14	O	Segment drive signal output to the liquid crystal display on the switch unit
78, 79	SEG15, SEG16	O	Segment drive signal output terminal Not used (open)
80	X9326	I/O	Error correction "L": quadruple correction, "H": double correction Suffix -11: fixed at "H", Suffix -12: fixed at "L"

• Waveforms


1 IC501 ⑩ (TEO) (PLAY MODE)  
500 mV/DIV, 1 ms/DIV




5 IC502 ⑩ (BCLK)  
1 V/DIV, 2 μs/DIV




9 Q405 ⑧  
5 V/DIV, 2 μs/DIV




2 IC501 ⑬ (FEO) (PLAY MODE)  
500 mV/DIV, 10 ms/DIV




6 IC502 ⑭ (XIN)  
500 mV/DIV, 20 ns/DIV




10 Q405 ③  
2 V/DIV, 2 μs/DIV




3 IC501 ⑲ (RFO) (PLAY MODE)  
500 mV/DIV, 1 μs/DIV




7 IC301 ⑩ (XTLO)  
1 V/DIV, 20 ns/DIV




11 IC401 ⑮ (CKOUT)  
2 V/DIV, 2 μs/DIV



4 IC502 ⑱ (LRCK) (PLAY MODE)  
1 V/DIV, 10 μs/DIV



8 IC801 ⑳ (OSC1)  
1 V/DIV, 100 ns/DIV






6-4. PRINTED WIRING BOARDS (SUFFIX-11)


• Semiconductor Location

Ref. No.	Location
D101	G-13
D201	F-13
D301	E-13
D303	C-13
D304	D-14
D305	C-14
D3-6	D-13
D402	B-15
D404	C-16
D407	D-9
D409	E-8
D410	B-8
D411	B-15
D415	B-15
D416	D-8
D601	J-18
D604	J-18
D801	J-5
D803	G-13
D804	H-10
D805	I-8
D806	F-15
D811	H-10
IC301	F-14
IC302	D-14
IC401	C-15
IC402	D-8
IC403	C-17
IC501	H-20
IC502	I-5
IC504	I-18
IC505	H-21
IC507	H-2
IC601	H-9
IC602	H-14
IC801	I-7
Q101	C-9
Q201	C-9
Q302	D-9
Q304	D-9
Q401	B-16
Q402	C-9
Q403	E-8
Q405	E-8
Q406	C-16
Q407	C-7
Q408	C-7
Q409	C-14
Q410	C-15
Q411	D-15
Q414	B-8
Q417	D-8
Q451	C-7
Q452	E-6
Q454	E-6
Q501	J-4
Q505	H-2
Q511	I-3
Q513	I-19
Q601	I-18
Q602	D-13
Q603	J-18
Q801	G-10





6-5. SCHEMATIC DIAGRAM (SUFFIX-11) • See page 23 for Waveforms. • See page 38 for IC Block Diagrams.




**Note on Schematic Diagram:**

- All capacitors are in  $\mu\text{F}$  unless otherwise noted. pF:  $\mu\text{F}$  50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in  $\Omega$  and  $\frac{1}{4}$  W or less unless otherwise specified.
- $\Delta$ : internal component.

**Note:** The components identified by mark  $\Delta$  or dotted line with mark  $\Delta$  are critical for safety. Replace only with part number specified.

- $\text{B}+$ : B+ Line.
- $\text{ADJ}$ : adjustment for repair.
- Power voltage is dc 4.5 V and fed with regulated dc power supply from external power voltage jack.
- Voltagcs and waveforms are dc with respect to ground under conditions in service mode. no mark : CD PLAY
- \* : Impossible to measure
- Voltagcs are taken with a VOM (Input impedance 10 M $\Omega$ ). Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with an oscilloscope. Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.
- Signal path.
- $\Rightarrow$  : CD PLAY (ANALOG OUT)
- $\Rightarrow$  : CD PLAY (OPTICAL OUT)



**Note on Schematic Diagram:**

- All capacitors are in  $\mu\text{F}$  unless otherwise noted.  $\text{pF}$ :  $\mu\text{pF}$  50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in  $\Omega$  and  $1/4\text{W}$  or less unless otherwise specified.
- $\Delta$ : internal component.

**Note:** The components identified by mark  $\Delta$  or dotted line with mark  $\Delta$  are critical for safety. Replace only with part number specified.

**Note:** Les composants identifiés par une marque  $\Delta$  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.


- **B+**: B+ Line.
- **ADJ**: adjustment for repair.
- Power voltage is dc 4.5 V and fed with regulated dc power supply from external power voltage jack.
- Voltages and waveforms are dc with respect to ground under conditions in service mode.
- no  $\ast$ : CD PLAY
- $\ast$ : Impossible to measure
- Voltages are taken with a VOM (Input impedance 10 M $\Omega$ ). Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with an oscilloscope. Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.
- Signal path.
- $\Rightarrow$ : CD PLAY (ANALOG OUT)
- $\Rightarrow$ : CD PLAY (OPTICAL OUT)
- Abbreviation
- FR: French model



6-7. PRINTED WIRING BOARD (SUFFIX-12)

• Semiconductor Location


Ref. No.	Location
D101	G-12
D201	G-12
D301	E-12
D303	C-12
D304	D-13
D305	C-13
D306	D-12
D402	B-14
D404	D-15
D405	F-8
D407	D-8
D409	E-8
D410	C-8
D411	C-14
D415	C-15
D416	E-8
D501	J-17
D601	J-17
D604	J-18
D801	J-5
D803	G-13
D804	H-9
D805	J-8
D806	F-14
D811	H-9
IC301	F-13
IC302	E-14
IC401	C-14
IC402	D-7
IC403	C-16
IC501	H-20
IC502	I-4
IC504	I-17
IC505	H-20
IC507	H-2
IC601	H-9
IC602	H-14
IC801	I-7
J301	D-11
Q101	D-9
Q201	C-9
Q302	D-9
Q303	F-8
Q304	D-9
Q401	C-15
Q402	D-8
Q403	E-8
Q405	E-7
Q406	C-15
Q407	C-7
Q408	C-7
Q409	C-14
Q410	C-14
Q411	D-14
Q414	B-7
Q417	D-8
Q451	D-7
Q452	C-7
Q453	F-8
Q501	J-4
Q505	I-2
Q511	J-3
Q513	J-18
Q601	J-17
Q602	D-13
Q603	J-17
Q801	H-9






• IC Block Diagrams


IC301 TC9438FNEL




IC302 TA2120FN (EL)




IC401 MPC18A26VMEL




IC501 BA6386K



**IC502 BU9326KS**




**IC601 SM5902AF**






IC504 MPC17A51VMEL






(2) CABINET SECTION-2



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
51	4-966-278-01	FOOT, RUBBER		56	4-993-134-01	PLATE, CHARGE DETECTION	
52	4-993-129-11	CABINET (LOWER) (WARM GRAY) . . . (SILVER, WHITE)		57	4-993-133-21	SPRING (-), BATTERY TERMINAL	
52	4-993-129-21	CABINET (LOWER) (BLUE) . . . (BLUE)		58	4-993-138-01	INSULATOR	
53	4-993-131-11	KNOB (HOLD) (WARM GRAY) . . . (SILVER, WHITE)		59	4-993-130-11	LID, BATTERY CASE (WARM GRAY) . . . (SILVER, WHITE)	
53	4-993-131-21	KNOB (HOLD) (BLUE) . . . (BLUE)		59	4-993-130-21	LID, BATTERY CASE (BLUE) . . . (BLUE)	
54	A-3021-145-A	MAIN BOARD, COMPLETE (EXCEPT French)		60	4-984-751-31	KNOB (AVLS) (WARM GRAY) . . . (SILVER, WHITE)	
54	A-3323-087-A	MAIN BOARD, COMPLETE (French)		60	4-984-751-41	KNOB (AVLS) (BLUE) . . . (BLUE)	
55	4-993-132-01	TERMINAL BOARD (+), BATTERY		* 61	1-673-123-11	DDC MUTE BOARD (MAIN board suffix-11)	

**(3) MECHANISM DECK SECTION  
(CDM-2911EBA)**



<p>The components identified by mark <math>\Delta</math> or dotted line with mark <math>\Delta</math> are critical for safety. Replace only with part number specified.</p>	<p>Les composants identifiés par une marque <math>\Delta</math> sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.</p>
---	---

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
101	A-3303-970-A	SCREW ASSY, FEED		109	1-667-512-11	SLIDE FLEXIBLE BOARD	
102	3-318-203-11	SCREW (B1.7), TAPPING		$\Delta$ 110	X-4950-476-1	OPTICAL PICK-UP (DAX-11E)	
103	4-972-163-04	SPRING, SLED		111	4-972-165-01	RACK	
104	1-783-093-11	LEAD (WITH CONNECTOR)		112	4-973-631-01	SCREW	
105	7-627-850-17	SCREW, PRECISION +P 1.4X2.5		M901	A-3311-902-A	MOTOR ASSY, SLED	
106	3-719-401-11	SCREW (B1.7), TAPPING		M902	A-3320-642-A	MOTOR ASSY, TURN TABLE (SPINDLE)	
* 107	4-984-320-01	CHASSIS		S901	1-571-099-21	SWITCH (1 KEY) (LIMIT)	
108	4-974-003-01	GEAR (B)					

## SECTION 8 ELECTRICAL PARTS LIST

**NOTE:**

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- **RESISTORS**  
All resistors are in ohms.  
METAL: Metal-film resistor.  
METAL OXIDE: Metal oxide-film resistor.  
F: nonflammable
- Abbreviation  
AUS : Australian model            FR : French model  
CH : Chinese model                G : German model  
CND : Canadian model            HK : Hong Kong model  
EE : East European model        JEW : Tourist model  
E13 : 220 – 230V AC area in E model  
E33 : 100 – 240V AC area in E model

- Items marked “\*\*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- **SEMICONDUCTORS**  
In each case, u:  $\mu$ , for example:  
uA. . :  $\mu$ A. .                    uPA. . :  $\mu$ PA. .  
uPB. . :  $\mu$ PB. .                uPC. . :  $\mu$ PC. .  
uPD. . :  $\mu$ PD. .
- **CAPACITORS**  
uF:  $\mu$ F
- **COILS**  
uH:  $\mu$ H

The components identified by mark  $\Delta$  or dotted line with mark  $\Delta$  are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque  $\Delta$  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
*	1-673-123-11	DDC MUTE BOARD (MAIN BOARD SUFFIX-11) *****		C306	1-164-156-11	CERAMIC CHIP 0.1uF	25V (SUFFIX-11)
		< TRANSISTOR >		C307	1-162-919-11	CERAMIC CHIP 22PF	5% 50V
				C308	1-162-919-11	CERAMIC CHIP 22PF	5% 50V
				C311	1-135-201-11	TANTALUM CHIP 10uF	20% 4V
				C312	1-135-201-11	TANTALUM CHIP 10uF	20% 4V
Q452	8-729-028-74	TRANSISTOR DTA114TUA-T106					
Q454	8-729-029-06	TRANSISTOR DTC124EUA-T106					
		< RESISTOR >		C314	1-115-156-11	CERAMIC CHIP 1uF	10V
R454	1-216-857-11	METAL CHIP 1M 5% 1/16W		C317	1-104-852-11	TANTALUM CHIP 22uF	20% 6.3V
		*****		C318	1-115-156-11	CERAMIC CHIP 1uF	10V
				C320	1-164-156-11	CERAMIC CHIP 0.1uF	25V
				C322	1-110-569-11	TANTALUM CHIP 47uF	20% 6.3V
	A-3021-145-A	MAIN BOARD, COMPLETE (EXCEPT FR)					
	A-3323-087-A	MAIN BOARD, COMPLETE (FR)		C323	1-164-156-11	CERAMIC CHIP 0.1uF	25V
		*****		C324	1-115-156-11	CERAMIC CHIP 1uF	10V
				C325	1-162-919-11	CERAMIC CHIP 22PF	5% 50V
	4-993-132-01	TERMINAL BOARD (+), BATTERY		C326	1-107-826-11	CERAMIC CHIP 0.1uF	10% 16V
	4-993-133-01	SPRING (-), BATTERY TERMINAL (SUFFIX-11)		C327	1-135-201-11	TANTALUM CHIP 10uF	20% 4V
	4-993-133-21	SPRING (-), BATTERY TERMINAL (SUFFIX-12)					
	4-993-134-01	PLATE, CHARGE DETECTION		C333	1-164-362-11	CERAMIC CHIP 470PF	5% 50V
		< CAPACITOR/RESISTOR >		C399	1-162-927-11	CERAMIC CHIP 100PF	5% 50V (SUFFIX-11)
C101	1-104-851-11	TANTALUM CHIP 10uF 20% 10V		C402	1-104-908-11	TANTALUM CHIP 47uF	20% 4V
C102	1-162-927-11	CERAMIC CHIP 100PF 5% 50V		C403	1-113-682-11	TANTALUM CHIP 33uF	20% 10V
C103	1-115-156-11	CERAMIC CHIP 1uF 10V		C404	1-164-156-11	CERAMIC CHIP 0.1uF	25V
C104	1-162-927-11	CERAMIC CHIP 100PF 5% 50V					
C105	1-113-690-11	ELECT CHIP 220uF 20% 4V		C406	1-164-505-11	CERAMIC CHIP 2.2uF	16V
				C407	1-113-690-11	ELECT CHIP 220uF	20% 4V
C106	1-162-927-11	CERAMIC CHIP 100PF 5% 50V (SUFFIX-11)		C408	1-104-851-11	TANTALUM CHIP 10uF	20% 10V
C107	1-162-927-11	CERAMIC CHIP 100PF 5% 50V		C414	1-162-970-11	CERAMIC CHIP 0.01uF	10% 25V
C111	1-165-128-11	CERAMIC CHIP 0.22uF 16V		C415	1-162-966-11	CERAMIC CHIP 0.0022uF	10% 50V
C201	1-104-851-11	TANTALUM CHIP 10uF 20% 10V					
C202	1-162-927-11	CERAMIC CHIP 100PF 5% 50V		C416	1-162-959-11	CERAMIC CHIP 330PF	5% 50V
				C417	1-104-847-11	TANTALUM CHIP 22uF	20% 4V
C203	1-115-156-11	CERAMIC CHIP 1uF 10V		C418	1-135-155-21	TANTALUM CHIP 4.7uF	10% 16V
C204	1-162-927-11	CERAMIC CHIP 100PF 5% 50V		C419	1-164-156-11	CERAMIC CHIP 0.1uF	25V
C205	1-113-690-11	ELECT CHIP 220uF 20% 4V		C420	1-110-569-11	TANTALUM CHIP 47uF	20% 6.3V (SUFFIX-12)
C206	1-162-927-11	CERAMIC CHIP 100PF 5% 50V (SUFFIX-11)					
C207	1-162-927-11	CERAMIC CHIP 100PF 5% 50V		C420	1-113-682-11	TANTALUM CHIP 33uF	20% 10V (SUFFIX-11)
				C421	1-104-851-11	TANTALUM CHIP 10uF	20% 10V
C211	1-165-128-11	CERAMIC CHIP 0.22uF 16V		C422	1-104-852-11	TANTALUM CHIP 22uF	20% 10V
C302	1-164-156-11	CERAMIC CHIP 0.1uF 25V		C423	1-107-826-11	CERAMIC CHIP 0.1uF	10% 16V
C303	1-164-156-11	CERAMIC CHIP 0.1uF 25V		C424	1-164-816-11	CERAMIC CHIP 220PF	2% 50V
C304	1-113-690-11	ELECT CHIP 220uF 20% 4V					
C305	1-135-201-11	TANTALUM CHIP 10uF 20% 4V		C425	1-164-156-11	CERAMIC CHIP 0.1uF	25V
				C426	1-104-852-11	TANTALUM CHIP 22uF	20% 10V
				C427	1-164-156-11	CERAMIC CHIP 0.1uF	25V

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
C428	1-113-682-11	TANTALUM CHIP	33uF 20% 10V	C552	1-162-913-11	CERAMIC CHIP	8PF 0.5PF 50V
C429	1-109-982-11	CERAMIC CHIP	1uF 10% 10V	C553	1-162-964-11	CERAMIC CHIP	0.001uF 10% 50V
C430	1-164-505-11	CERAMIC CHIP	2.2uF 16V	C555	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
C431	1-164-156-11	CERAMIC CHIP	0.1uF 25V	C558	1-164-156-11	CERAMIC CHIP	0.1uF 25V
C432	1-164-505-11	CERAMIC CHIP	2.2uF 16V	C560	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
C433	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C562	1-135-181-21	TANTALUM CHIP	4.7uF 20% 6.3V
C434	1-164-816-11	CERAMIC CHIP	220PF 2% 50V	C565	1-164-156-11	CERAMIC CHIP	0.1uF 25V
C436	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (SUFFIX-12)	C601	1-104-908-11	TANTALUM CHIP	47uF 20% 4V
C437	1-113-682-11	TANTALUM CHIP	33uF 20% 10V	C602	1-164-156-11	CERAMIC CHIP	0.1uF 25V
C438	1-164-156-11	CERAMIC CHIP	0.1uF 25V	C603	1-164-346-11	CERAMIC CHIP	1uF 16V
C439	1-104-851-11	TANTALUM CHIP	10uF 20% 10V	C604	1-115-467-11	CERAMIC CHIP	0.22uF 10% 10V
C443	1-115-156-11	CERAMIC CHIP	1uF 10V	C605	1-107-823-11	CERAMIC CHIP	0.47uF 10% 16V
C451	1-135-201-11	TANTALUM CHIP	10uF 20% 4V	C611	1-104-847-11	TANTALUM CHIP	22uF 20% 4V
C452	1-115-156-11	CERAMIC CHIP	1uF 10V	C613	1-117-720-11	CERAMIC CHIP	4.7uF 10V
C501	1-162-919-11	CERAMIC CHIP	22PF 5% 50V	C801	1-162-964-11	CERAMIC CHIP	0.001uF 10% 50V
C503	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C802	1-162-964-11	CERAMIC CHIP	0.001uF 10% 50V
C504	1-164-362-11	CERAMIC CHIP	470PF 5% 50V	C803	1-162-964-11	CERAMIC CHIP	0.001uF 10% 50V
C505	1-162-967-11	CERAMIC CHIP	0.0033uF 10% 50V	C804	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
C506	1-109-994-11	CERAMIC CHIP	2.2uF 10% 10V	C805	1-115-156-11	CERAMIC CHIP	1uF 10V
C509	1-164-156-11	CERAMIC CHIP	0.1uF 25V	C806	1-164-156-11	CERAMIC CHIP	0.1uF 25V
C510	1-164-156-11	CERAMIC CHIP	0.1uF 25V	C807	1-115-156-11	CERAMIC CHIP	1uF 10V
C511	1-125-817-11	CERAMIC CHIP	10uF 10% 6.3V	C808	1-135-151-21	TANTALUM CHIP	4.7uF 20% 4V
C513	1-165-176-11	CERAMIC CHIP	0.047uF 10% 16V	C809	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
C514	1-162-927-11	CERAMIC CHIP	100PF 5% 50V	C810	1-115-156-11	CERAMIC CHIP	1uF 10V
C515	1-162-927-11	CERAMIC CHIP	100PF 5% 50V	C811	1-164-156-11	CERAMIC CHIP	0.1uF 25V
C517	1-104-908-11	TANTALUM CHIP	47uF 20% 4V	C812	1-115-156-11	CERAMIC CHIP	1uF 10V
C518	1-162-966-11	CERAMIC CHIP	0.0022uF 10% 50V	C813	1-164-677-11	CERAMIC CHIP	0.033uF 10% 16V
C519	1-162-966-11	CERAMIC CHIP	0.0022uF 10% 50V	C815	1-164-156-11	CERAMIC CHIP	0.1uF 25V
C520	1-162-963-11	CERAMIC CHIP	680PF 10% 50V	C816	1-115-156-11	CERAMIC CHIP	1uF 10V
C521	1-162-966-11	CERAMIC CHIP	0.0022uF 10% 50V	C819	1-164-156-11	CERAMIC CHIP	0.1uF 25V
C522	1-164-489-11	CERAMIC CHIP	0.22uF 10% 16V	< CONNECTOR >			
C523	1-109-994-11	CERAMIC CHIP	2.2uF 10% 10V	CN501	1-779-761-21	CONNECTOR, FPC (ZIF)	
C525	1-104-908-11	TANTALUM CHIP	47uF 20% 4V	CN502	1-784-342-31	HOUSING, CONNECTOR 2P	
C526	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V	CN503	1-784-342-21	HOUSING, CONNECTOR 2P	
C527	1-164-489-11	CERAMIC CHIP	0.22uF 10% 16V	CN504	1-784-342-11	HOUSING, CONNECTOR 2P	
C528	1-164-156-11	CERAMIC CHIP	0.1uF 25V	CN801	1-766-492-21	CONNECTOR, FFC/FPC (ZIF) 24P	
C529	1-104-908-11	TANTALUM CHIP	47uF 20% 4V	< DIODE >			
C530	1-164-227-11	CERAMIC CHIP	0.022uF 10% 25V	D101	8-719-039-99	DIODE UMZ8.2T	
C531	1-109-994-11	CERAMIC CHIP	2.2uF 10% 10V	D201	8-719-039-99	DIODE UMZ8.2T	
C532	1-109-982-11	CERAMIC CHIP	1uF 10% 10V	D301	8-719-988-78	DIODE SB007W03Q	
C533	1-104-908-11	TANTALUM CHIP	47uF 20% 4V	D303	8-719-039-99	DIODE UMZ8.2T	
C534	1-162-921-11	CERAMIC CHIP	33PF 5% 50V	D304	8-719-039-99	DIODE UMZ8.2T	
C535	1-162-915-11	CERAMIC CHIP	10PF 0.5PF 50V	D305	8-719-039-99	DIODE UMZ8.2T	
C536	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V	D306	8-719-039-99	DIODE UMZ8.2T	
C537	1-104-847-11	TANTALUM CHIP	22uF 20% 4V	D402	8-719-313-73	DIODE SFPB-52	
C538	1-110-501-11	CERAMIC CHIP	0.33uF 10% 16V	D404	8-719-067-19	DIODE RB415D-T146	
C541	1-164-156-11	CERAMIC CHIP	0.1uF 25V	D405	8-719-049-09	DIODE 1SS367-T3SONY (SUFFIX-12)	
C542	1-113-677-11	CERAMIC CHIP	1uF 25V	D407	8-719-313-73	DIODE SFPB-52	
C543	1-164-156-11	CERAMIC CHIP	0.1uF 25V	D409	8-719-049-09	DIODE 1SS367-T3SONY	
C544	1-164-156-11	CERAMIC CHIP	0.1uF 25V	D410	8-719-049-09	DIODE 1SS367-T3SONY	
C545	1-164-816-11	CERAMIC CHIP	220PF 2% 50V	D411	8-719-988-61	DIODE 1SS355TE-17	
C546	1-164-816-11	CERAMIC CHIP	220PF 2% 50V	D415	8-719-049-09	DIODE 1SS367-T3SONY	
C547	1-164-816-11	CERAMIC CHIP	220PF 2% 50V	D416	8-719-049-09	DIODE 1SS367-T3SONY	
C548	1-162-927-11	CERAMIC CHIP	100PF 5% 50V	D501	8-719-049-09	DIODE 1SS367-T3SONY (SUFFIX-12)	
C549	1-104-852-11	TANTALUM CHIP	22uF 20% 10V	D601	8-719-024-81	DIODE 1SS300-TE85L	
C550	1-115-156-11	CERAMIC CHIP	1uF 10V	D604	8-719-049-09	DIODE 1SS367-T3SONY	
C551	1-162-968-11	CERAMIC CHIP	0.0047uF 10% 50V				



# MAIN

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
D801	8-719-049-09	DIODE 1SS367-T3SONY		L311	1-414-916-11	FERRITE	0uH (SUFFIX-12)
D803	8-719-941-09	DIODE DAP202U		L401	1-414-434-11	INDUCTOR	100uH
D804	8-719-941-09	DIODE DAP202U		L402	1-414-449-11	INDUCTOR CHIP	100uH
D805	8-719-158-15	DIODE RD5.6S-B		L403	1-414-398-11	INDUCTOR	10uH
D806	8-719-049-09	DIODE 1SS367-T3SONY		L404	1-414-434-11	INDUCTOR	100uH
D811	8-719-158-15	DIODE RD5.6S-B		L405	1-414-434-11	INDUCTOR	100uH
< FERRITE BEAD/COIL/RESISTOR >				L406	1-414-392-21	INDUCTOR	1uH (SUFFIX-11)
FB101	1-500-238-22	FERRITE	0uH	L406	1-500-451-11	FERRITE	0uH (SUFFIX-12)
FB102	1-216-864-11	METAL CHIP	0 5% 1/16W (SUFFIX-12)	L407	1-414-392-21	INDUCTOR	1uH (SUFFIX-11)
FB102	1-414-760-21	INDUCTOR CHIP	0uH (SUFFIX-11)	L407	1-500-451-11	FERRITE	0uH (SUFFIX-12)
FB201	1-500-238-22	FERRITE	0uH	L501	1-414-398-11	INDUCTOR	10uH
FB202	1-216-864-11	METAL CHIP	0 5% 1/16W (SUFFIX-12)	L502	1-414-398-11	INDUCTOR	10uH
FB202	1-414-760-21	INDUCTOR CHIP	0uH (SUFFIX-11)	L503	1-414-402-11	INDUCTOR	47uH
FB301	1-414-228-11	INDUCTOR CHIP	0uH	L504	1-414-398-11	INDUCTOR	10uH
FB306	1-216-864-11	METAL CHIP	0 5% 1/16W (SUFFIX-12)	L505	1-414-402-11	INDUCTOR	47uH
FB306	1-414-760-21	INDUCTOR CHIP	0uH (SUFFIX-11)	L801	1-414-916-11	FERRITE	0uH (SUFFIX-12)
FB308	1-414-235-22	INDUCTOR CHIP	0uH	L802	1-412-002-31	INDUCTOR CHIP	4.7uH
FB309	1-414-235-22	INDUCTOR CHIP	0uH (SUFFIX-11)	L803	1-412-002-31	INDUCTOR CHIP	4.7uH
FB309	1-500-444-11	FERRITE	0uH (SUFFIX-12)	L811	1-500-444-11	FERRITE	0uH (SUFFIX-12)
FB311	1-414-760-21	INDUCTOR CHIP	0uH	L812	1-414-916-11	FERRITE	0uH (SUFFIX-12)
FB502	1-412-002-31	INDUCTOR CHIP	4.7uH	L813	1-414-916-11	FERRITE	0uH (SUFFIX-12)
FB601	1-216-295-00	SHORT	0	L814	1-414-916-11	FERRITE	0uH (SUFFIX-12)
< IC >				< TRANSISTOR >			
IC301	8-759-483-60	IC TC9438FNEL		Q101	8-729-231-74	TRANSISTOR	2SC4116-GL
IC302	8-759-522-87	IC TA2120FN (EL)		Q201	8-729-231-74	TRANSISTOR	2SC4116-GL
IC401	8-759-483-61	IC MPC18A26VMEL		Q302	8-729-907-39	TRANSISTOR	IMD2
IC402	8-759-464-04	IC S-81340HG-KJ-T1		Q303	8-729-028-92	TRANSISTOR	DTA144TUA-T106 (SUFFIX-12)
IC403	8-759-387-31	IC TC75S55F (TE85R)		Q304	8-729-028-74	TRANSISTOR	DTA114TUA-T106
IC501	8-759-432-83	IC BA6386K		Q401	8-729-920-85	TRANSISTOR	2SD1664-QR
IC502	8-759-563-54	IC BU9326KS		Q402	8-729-921-93	TRANSISTOR	2SB1182F5-QR
IC504	8-759-483-62	IC MPC17A51VMEL		Q403	8-729-044-10	FET	MMBF0201NLT1
IC505	8-759-387-31	IC TC75S55F (TE85R)		Q405	8-729-320-66	TRANSISTOR	2SD1870
IC507	8-759-082-60	IC TC7S66FU		Q406	8-729-043-46	FET	MMBF2201NT1
IC601	8-759-484-37	IC SM5902AF		Q407	8-729-043-46	FET	MMBF2201NT1
IC602	8-759-538-44	IC MSM51V17400D-10TK-FS		Q408	8-729-043-46	FET	MMBF2201NT1
IC801	8-759-565-44	IC MC68HC05L24-SC440482CFU (SUFFIX-11)		Q409	8-729-230-60	TRANSISTOR	2SA1586-YG
IC801	8-759-576-65	IC MC68HC05L24-SC440488CFU (SUFFIX-12)		Q410	8-729-230-60	TRANSISTOR	2SA1586-YG
< JACK/DIODE >				Q411	8-729-028-26	FET	2SK1829 (TE85L)
J301	8-749-015-13	DIODE GP1FB200TK (LINE OUT (OPTICAL))		Q414	8-729-231-74	TRANSISTOR	2SC4116-GL
J302	1-778-368-31	JACK, HEADPHONE (⌀)/REMOTE		Q417	8-729-230-60	TRANSISTOR	2SA1586-YG
J401	1-778-153-21	JACK,DC(POLARITY UNIFIED TYPE) (DC IN 4.5V)		Q451	8-729-231-74	TRANSISTOR	2SC4116-GL
< SHORT >				Q452	8-729-028-74	TRANSISTOR	DTA114TUA-T106 (SUFFIX-12)
JC502	1-216-295-00	SHORT	0	Q453	8-729-028-26	FET	2SK1829 (TE85L) (SUFFIX-12)
JC503	1-216-295-00	SHORT	0	Q501	8-729-028-74	TRANSISTOR	DTA114TUA-T106
< COIL/FERRITE BEAD >				Q505	8-729-028-74	TRANSISTOR	DTA114TUA-T106
L111	1-414-916-11	FERRITE	0uH (SUFFIX-12)	Q511	8-729-028-74	TRANSISTOR	DTA114TUA-T106
L211	1-414-916-11	FERRITE	0uH (SUFFIX-12)	Q513	8-729-028-74	TRANSISTOR	DTA114TUA-T106
L301	1-414-916-11	FERRITE	0uH	Q601	8-729-029-06	TRANSISTOR	DTC124EUA-T106
L302	1-414-916-11	FERRITE	0uH	Q602	8-729-924-28	TRANSISTOR	DTA123YU
L306	1-414-916-11	FERRITE	0uH	Q603	8-729-029-06	TRANSISTOR	DTC124EUA-T106
< RESISTOR >				Q801	8-729-231-74	TRANSISTOR	2SC4116-GL
R1	1-216-295-00	SHORT	0	< RESISTOR >			
R3	1-216-295-00	SHORT	0 (SUFFIX-11)	R1	1-216-295-00	SHORT	0
R101	1-216-813-11	METAL CHIP	220 5% 1/16W	R3	1-216-295-00	SHORT	0 (SUFFIX-11)

Ref. No.	Part No.	Description	Quantity	Unit	Remark	Ref. No.	Part No.	Description	Quantity	Unit	Remark
R102	1-216-845-11	METAL CHIP	100K		5% 1/16W	R438	1-216-861-11	METAL CHIP	2.2M		5% 1/16W
R103	1-216-839-11	METAL CHIP	33K		5% 1/16W (EXCEPT FR)	R439	1-218-740-11	METAL CHIP	100K		0.5% 1/16W
R103	1-216-847-11	METAL CHIP	150K		5% 1/16W (FR)	R440	1-218-881-11	RES, CHIP	27K		0.5% 1/16W
R104	1-216-815-11	METAL CHIP	330		5% 1/16W	R441	1-216-833-11	METAL CHIP	10K		5% 1/16W
R105	1-216-821-11	METAL CHIP	1K		5% 1/16W	R442	1-216-833-11	METAL CHIP	10K		5% 1/16W
R107	1-216-789-11	METAL CHIP	2.2		5% 1/16W	R443	1-216-833-11	METAL CHIP	10K		5% 1/16W
R201	1-216-813-11	METAL CHIP	220		5% 1/16W	R444	1-216-853-11	METAL CHIP	470K		5% 1/16W
R202	1-216-845-11	METAL CHIP	100K		5% 1/16W	R445	1-220-800-91	RES, CHIP	1.5M		0.5%
R203	1-216-839-11	METAL CHIP	33K		5% 1/16W (EXCEPT FR)	R448	1-216-857-11	METAL CHIP	1M		5% 1/16W
R204	1-216-815-11	METAL CHIP	330		5% 1/16W	R449	1-218-446-11	METAL CHIP	1		5% 1/16W
R205	1-216-821-11	METAL CHIP	1K		5% 1/16W	R451	1-216-839-11	METAL CHIP	33K		5% 1/16W
R207	1-216-789-11	METAL CHIP	2.2		5% 1/16W	R452	1-216-845-11	METAL CHIP	100K		5% 1/16W
R208	1-216-847-11	METAL CHIP	150K		5% 1/16W (FR)	R454	1-216-857-11	METAL CHIP	1M		5% 1/16W
R302	1-216-864-11	METAL CHIP	0		5% 1/16W	R501	1-216-848-11	METAL CHIP	180K		5% 1/16W (SUFFIX-12)
R303	1-216-853-11	METAL CHIP	470K		5% 1/16W	R502	1-216-829-11	METAL CHIP	4.7K		5% 1/16W (SUFFIX-11)
R304	1-216-805-11	METAL CHIP	47		5% 1/16W	R503	1-216-829-11	METAL CHIP	4.7K		5% 1/16W
R305	1-216-864-11	METAL CHIP	0		5% 1/16W (SUFFIX-11)	R504	1-216-838-11	METAL CHIP	27K		5% 1/16W
R306	1-216-809-11	METAL CHIP	100		5% 1/16W	R504	1-216-839-11	METAL CHIP	33K		5% 1/16W (SUFFIX-11)
R311	1-216-821-11	METAL CHIP	1K		5% 1/16W	R505	1-216-832-11	METAL CHIP	8.2K		5% 1/16W (SUFFIX-11)
R312	1-216-142-00	RES, CHIP	4.7		5% 1/8W	R505	1-216-834-11	METAL CHIP	12K		5% 1/16W (SUFFIX-12)
R351	1-216-864-11	METAL CHIP	0		5% 1/16W	R506	1-216-833-11	METAL CHIP	10K		5% 1/16W
R352	1-216-295-00	SHORT	0			R509	1-216-835-11	METAL CHIP	15K		5% 1/16W
R401	1-216-815-11	METAL CHIP	330		5% 1/16W	R510	1-218-877-11	RES, CHIP	18K		0.5% 1/16W (SUFFIX-11)
R402	1-216-857-11	METAL CHIP	1M		5% 1/16W	R511	1-216-833-11	METAL CHIP	10K		5% 1/16W
R403	1-216-864-11	METAL CHIP	0		5% 1/16W (SUFFIX-11)	R512	1-216-845-11	METAL CHIP	100K		5% 1/16W
R405	1-216-837-11	METAL CHIP	22K		5% 1/16W	R513	1-216-821-11	METAL CHIP	1K		5% 1/16W
R407	1-216-825-11	METAL CHIP	2.2K		5% 1/16W	R517	1-216-837-11	METAL CHIP	22K		5% 1/16W
R408	1-216-833-11	METAL CHIP	10K		5% 1/16W	R518	1-216-833-11	METAL CHIP	10K		5% 1/16W
R410	1-216-864-11	METAL CHIP	0		5% 1/16W	R519	1-216-831-11	METAL CHIP	6.8K		5% 1/16W
R411	1-216-029-00	METAL CHIP	150		5% 1/10W	R521	1-216-836-11	METAL CHIP	18K		5% 1/16W
R412	1-216-298-00	METAL CHIP	2.2		5% 1/10W	R522	1-216-857-11	METAL CHIP	1M		5% 1/16W
R413	1-216-298-00	METAL CHIP	2.2		5% 1/10W	R523	1-216-864-11	METAL CHIP	0		5% 1/16W
R414	1-216-302-00	METAL CHIP	2.7		5% 1/10W	R524	1-216-843-11	METAL CHIP	68K		5% 1/16W (SUFFIX-11)
R415	1-216-833-11	METAL CHIP	10K		5% 1/16W	R525	1-216-821-11	METAL CHIP	1K		5% 1/16W
R417	1-218-716-11	METAL CHIP	10K		0.5% 1/16W	R526	1-216-821-11	METAL CHIP	1K		5% 1/16W
R418	1-216-857-11	METAL CHIP	1M		5% 1/16W	R528	1-216-836-11	METAL CHIP	18K		5% 1/16W (SUFFIX-11)
R419	1-216-857-11	METAL CHIP	1M		5% 1/16W	R528	1-216-837-11	METAL CHIP	22K		5% 1/16W (SUFFIX-12)
R420	1-218-728-11	METAL CHIP	33K		0.5% 1/16W	R531	1-216-821-11	METAL CHIP	1K		5% 1/16W
R421	1-216-864-11	METAL CHIP	0		5% 1/16W	R532	1-216-825-11	METAL CHIP	2.2K		5% 1/16W
R422	1-218-891-11	RES, CHIP	68K		0.5% 1/16W	R533	1-216-841-11	METAL CHIP	47K		5% 1/16W
R423	1-216-839-11	METAL CHIP	33K		5% 1/16W	R534	1-216-864-11	METAL CHIP	0		5% 1/16W
R424	1-216-845-11	METAL CHIP	100K		5% 1/16W	R535	1-216-827-11	METAL CHIP	3.3K		5% 1/16W
R427	1-216-833-11	METAL CHIP	10K		5% 1/16W	R538	1-216-833-11	METAL CHIP	10K		5% 1/16W
R428	1-216-805-11	METAL CHIP	47		5% 1/16W	R542	1-218-748-11	METAL CHIP	220K		0.5% 1/16W
R430	1-218-867-11	RES, CHIP	6.8K		0.5% 1/16W	R543	1-216-845-11	METAL CHIP	100K		5% 1/16W
R431	1-216-861-11	METAL CHIP	2.2M		5% 1/16W	R545	1-216-849-11	METAL CHIP	220K		5% 1/16W
R432	1-218-895-11	RES, CHIP	100K		0.5% 1/16W	R547	1-216-825-11	METAL CHIP	2.2K		5% 1/16W
R433	1-218-913-91	RES, CHIP	560K		0.5%	R548	1-216-825-11	METAL CHIP	2.2K		5% 1/16W
R434	1-216-861-11	METAL CHIP	2.2M		5% 1/16W	R549	1-216-833-11	METAL CHIP	10K		5% 1/16W (SUFFIX-11)
R435	1-220-800-91	RES, CHIP	1.5M		0.5%						
R436	1-218-913-91	RES, CHIP	560K		0.5%						
R437	1-216-857-11	METAL CHIP	1M		5% 1/16W						

**MAIN**

Ref. No.	Part No.	Description	Remark
R549	1-216-834-11	METAL CHIP 12K 5%	1/16W (SUFFIX-12)
R550	1-216-864-11	METAL CHIP 0	5% 1/16W
R551	1-216-845-11	METAL CHIP 100K	5% 1/16W
R552	1-216-841-11	METAL CHIP 47K	5% 1/16W (SUFFIX-12)
R567	1-218-740-11	METAL CHIP 100K	0.5% 1/16W
R569	1-216-843-11	METAL CHIP 68K	5% 1/16W (SUFFIX-12)
R569	1-216-846-11	METAL CHIP 120K	5% 1/16W (SUFFIX-11)
R570	1-216-851-11	METAL CHIP 330K	5% 1/16W
R571	1-216-829-11	METAL CHIP 4.7K	5% 1/16W
R576	1-216-829-11	METAL CHIP 4.7K	5% 1/16W
R602	1-216-833-11	METAL CHIP 10K	5% 1/16W
R603	1-216-837-11	METAL CHIP 22K	5% 1/16W
R604	1-216-833-11	METAL CHIP 10K	5% 1/16W
R605	1-216-864-11	METAL CHIP 0	5% 1/16W
R606	1-216-864-11	METAL CHIP 0	5% 1/16W
R607	1-216-864-11	METAL CHIP 0	5% 1/16W
R609	1-216-837-11	METAL CHIP 22K	5% 1/16W
R612	1-216-821-11	METAL CHIP 1K	5% 1/16W
R651	1-216-864-11	METAL CHIP 0	5% 1/16W
R652	1-216-864-11	METAL CHIP 0	5% 1/16W
R801	1-216-821-11	METAL CHIP 1K	5% 1/16W
R802	1-216-833-11	METAL CHIP 10K	5% 1/16W
R803	1-216-821-11	METAL CHIP 1K	5% 1/16W
R804	1-216-854-11	METAL CHIP 560K	5% 1/16W
R805	1-216-861-11	METAL CHIP 2.2M	5% 1/16W
R806	1-216-857-11	METAL CHIP 1M	5% 1/16W
R807	1-216-857-11	METAL CHIP 1M	5% 1/16W
R808	1-216-845-11	METAL CHIP 100K	5% 1/16W
R809	1-216-857-11	METAL CHIP 1M	5% 1/16W
R810	1-216-857-11	METAL CHIP 1M	5% 1/16W
R811	1-216-845-11	METAL CHIP 100K	5% 1/16W
R812	1-216-857-11	METAL CHIP 1M	5% 1/16W
R814	1-216-829-11	METAL CHIP 4.7K	5% 1/16W
R815	1-216-833-11	METAL CHIP 10K	5% 1/16W
R818	1-216-864-11	METAL CHIP 0	5% 1/16W
R819	1-216-857-11	METAL CHIP 1M	5% 1/16W (SUFFIX-11)
R820	1-216-857-11	METAL CHIP 1M	5% 1/16W (SUFFIX-12)
R822	1-218-883-11	RES, CHIP 33K	0.5% 1/16W
R823	1-216-849-11	METAL CHIP 220K	5% 1/16W
R824	1-216-845-11	METAL CHIP 100K	5% 1/16W
R825	1-216-851-11	METAL CHIP 330K	5% 1/16W
R826	1-216-851-11	METAL CHIP 330K	5% 1/16W
R827	1-216-851-11	METAL CHIP 330K	5% 1/16W
R828	1-218-897-11	RES, CHIP 120K	0.5% 1/16W
R829	1-218-891-11	RES, CHIP 68K	0.5% 1/16W
R830	1-218-887-11	RES, CHIP 47K	0.5% 1/16W
R835	1-216-821-11	METAL CHIP 1K	5% 1/16W
R836	1-218-740-11	METAL CHIP 100K	0.5% 1/16W
R837	1-218-740-11	METAL CHIP 100K	0.5% 1/16W
R840	1-216-857-11	METAL CHIP 1M	5% 1/16W
R849	1-216-821-11	METAL CHIP 1K	5% 1/16W
R853	1-216-821-11	METAL CHIP 1K	5% 1/16W

Ref. No.	Part No.	Description	Remark
R855	1-216-821-11	METAL CHIP 1K	5% 1/16W
R856	1-216-821-11	METAL CHIP 1K	5% 1/16W
R857	1-216-821-11	METAL CHIP 1K	5% 1/16W
R858	1-216-821-11	METAL CHIP 1K	5% 1/16W
< VARIABLE RESISTOR >			
RV301	1-225-468-21	RES, VAR, CARBON 10K/10K	◀ VOL
RV401	1-241-395-11	RES, ADJ, METAL GLAZE 10K	
RV502	1-223-996-21	RES, CARBON ADJ VAR 22K	
RV503	1-223-996-21	RES, CARBON ADJ VAR 22K	
< SWITCH >			
S301	1-762-078-11	SWITCH, SLIDE (AVLS)	
S801	1-692-366-31	SWITCH, PUSH (1 KEY) (OPEN)	
S803	1-762-078-11	SWITCH, SLIDE (RESUME)	
S804	1-762-078-11	SWITCH, SLIDE (HOLD)	▶
< TRANSFORMER >			
T401	1-431-557-11	TRANSFORMER, DC-DC CONVERTER	
< VIBRATOR >			
X301	1-767-605-11	VIBRATOR, LITHIUM TANTALATE	(16.9344MHZ)
X801	1-767-192-11	VIBRATOR, CERAMIC (4.195MHZ)	
*****			
MISCELLANEOUS			
*****			
8	1-475-998-11	SWITCH UNIT	
104	1-783-093-11	LEAD (WITH CONNECTOR)	
109	1-667-512-11	SLIDE FLEXIBLE BOARD	
△ 110	X-4950-476-1	OPTICAL PICK-UP (DAX-11E)	
M901	A-3311-902-A	MOTOR ASSY, SLED	
M902	A-3320-642-A	MOTOR ASSY, TURN TABLE (SPINDLE)	
S901	1-571-099-21	SWITCH (1 KEY) (LIMIT)	
*****			
ACCESSORIES & PACKING MATERIALS			
*****			
△	1-467-007-21	ADAPTOR, AC (AC-E455) (AUS)	
△	1-467-009-21	ADAPTOR, AC (AC-E455) (US, CND)	
△	1-467-550-11	ADAPTOR, AC (AC-E455A) (E33, JEW)	
△	1-473-115-11	ADAPTOR, AC (AC-E455D) (UK)	
△	1-473-116-35	ADAPTOR, AC (AC-E455D)	(AEP, FR, G, EE, E13)
△	1-475-622-11	ADAPTOR, AC (AC-E455) (CH)	
△	1-475-623-11	ADAPTOR, AC (AC-E455) (HK)	
△	1-475-995-11	REMOTE CONTROL UNIT (RM-DM32EL)	
△	1-569-007-11	ADAPTOR, CONVERSION 2P (E33, JEW)	
△	1-569-008-21	ADAPTOR, CONVERSION 2P (E13)	
	3-864-764-01	MANUAL, INSTRUCTION (JAPANESE, ENGLISH) (JEW)	
	3-864-764-11	MANUAL, INSTRUCTION (SPANISH)	(AEP, E33, JEW)
	3-864-764-21	MANUAL, INSTRUCTION (ENGLISH)	(EXCEPT G, E13, HK, CH)
	3-864-764-31	MANUAL, INSTRUCTION (FRENCH)	(CND, AEP, FR, JEW)

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
	3-864-764-41	MANUAL, INSTRUCTION (DUTCH) (AEP, EE)	
	3-864-764-51	MANUAL, INSTRUCTION (SWEDISH) (AEP)	
	3-864-764-61	MANUAL, INSTRUCTION (PORTUGUESE)	(AEP)
	3-864-764-71	MANUAL, INSTRUCTION (GERMAN) (AEP, G)	
	3-864-764-81	MANUAL, INSTRUCTION (ITALIAN) (AEP)	
	3-864-764-91	MANUAL, INSTRUCTION (FINNISH) (AEP)	
	3-864-765-11	MANUAL, INSTRUCTION (CHINESE) (E13, HK)	
	3-864-765-21	MANUAL, INSTRUCTION (ENGLISH)	(E13, HK, CH)
	3-864-765-31	MANUAL, INSTRUCTION (CHINESE) (CH)	
	3-864-766-51	MANUAL, INSTRUCTION (KOREAN) (JEW)	
	3-864-766-61	MANUAL, INSTRUCTION (CHINESE) (JEW)	
	4-993-659-01	CASE, CARRYING	
	8-953-218-91	RECEIVER MDR-E838SP/SK SET (EXCEPT US)	
	8-953-276-90	HEADPHONE MDR-24SP SET (US)	
	X-4949-267-1	CASE ASSY, BATTERY	

