

SL-HF900

RMT-1E

SERVICE MANUAL

US Model
Canadian Model



Super Beta

711B2 CHASSIS

This manual contains the Adjustment method.

SPECIFICATIONS

System

Video recording system

Rotary two-head helical scanning

Audio recording system

Beta hi-fi system (2 channels)
(Recording on the conventional
audio track is monaural)

Video signal

EIA standard, NTSC color

Usable cassettes

Cassettes having the mark **B**

BIII: 1.33 cm/sec.

BII: 2.0 cm/sec.

BI: 4.0 cm/sec. (only for playback)

Maximum recording time

BIII: 5 hours

BII: 3 hours 20 min.

(with Sony L-830 cassette)

Fast-forward and rewind time

Approx. 3½ min. (L-500)

Audio frequency response

Beta hi-fi MPX FILTER OFF

BII, **BIII**: 20-20,000 Hz

Wow and flutter

Beta hi-fi ON

Less than 0.005% WRMS

Dynamic range

Beta hi-fi ON

More than 80 dB

Tuner section

Channel coverage

VHF channels 2 to 13

UHF channels 14 to 69

CATV channels 1-125

VHF output signal

Channel 3 or 4 (selected)

75 ohms, unbalanced

Antenna

75-ohm antenna terminal for
RF IN ANT/CABLE, TO CONV, and
AUX

Inputs and outputs

Video input

LINE IN VIDEO/PCM (phono jack)

1 V p-p ± 0.5 V p-p, 75 ohms,
unbalanced, sync negative

Video outputs

LINE OUT 1, 2 VIDEO/PCM (phono
jacks)

1 V p-p ± 0.5 V p-p, 75 ohms,
unbalanced, sync negative

Audio inputs

LINE IN R-AUDIO-L (phono jacks)

-10 dBs (0 dBs = 0.775 V rms),
more than 47 k ohms

- Continued on page 2 -



Audio outputs LINE OUT 1, 2 R-AUDIO-L (phono jacks)
 -10 dBs (at load impedance 47k ohms)
 more than 10 k ohms

CONTROL S IN Minijack
 CONTROL S OUT (EDIT) Minijack

CAMERA REMOTE Special minijack

CAMERA REMOTE OUT (EDIT) Special minijack

Microphone input Minijack
 -60 dBs, for low-impedance microphone

HEADPHONES jack Stereo phone jack
 -26 dBs, 8 ohms

Timer section
 Clock Synchronized with the power frequency
 Time indication 12-hour cycle
 Timer setting Only for recording
 8 programs 21 days at max.
 Power back up Self-charging battery incorporated
 Back-up duration: up to 10 minutes at one time (after the battery has been charged at least 40 hours.)

General

Power requirements 120 V ac $\pm 10\%$, 50/60 Hz $\pm 0.5\%$

Power consumption 50 W

AC outlet Unswitched max. 400 W

Operating temperature 5°C to 40°C (41°F to 104°F)

Storage temperature -20°C to +60°C (-4°F to + 140°F)

Dimensions Approx. 430 x 105 x 382 mm (w/h/d)
 (17 x 4 $\frac{1}{4}$ x 15 $\frac{1}{8}$ inches)
 incl. projecting parts and controls

Weight Approx. 11.5 kg (26 lb) net

Accessories supplied

Betamax video cassette tape.....1
 75-ohm coaxial cable with F-type connectors
 (2 m, 6 feet).....1
 Antenna connector EAC-25.....1
 Connecting cord RK-74A.....1
 Remote Commander RMT-125 with two size
 AA batteries.....1

Design and specifications subject to change without notice.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK Δ ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL TO SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!!

LES COMPOSANTS IDENTIFIÉS PAR UN TRAMÉ ET UNE MARQUE Δ SUR LES DIAGRAMMES SCHEMATIQUES, LES VUES EXPLOSEES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DES SUPPLÉMENTS PUBLIÉS PAR SONY. LES RÉGLAGES DU CIRCUIT QUI SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT SONT IDENTIFIÉS DANS CE MANUEL. SUIVRE LES PROCÉDURES QUAND LES COMPOSANTS CRITIQUES SONT REMPLACÉS OU LE FONCTIONNEMENT IMPROPRE EST SUSPECTÉ.

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
5. Check the line cord for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
6. Check the B+ voltage to see it is at the values specified.
7. Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)




Fig. A. Using an AC voltmeter to check AC leakage.

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
1.	GENERAL		3-10.	Audio Level Diagram	94
1-1.	Features	5	3-11.	Timer Block Diagram	97
1-2.	Location and Function of Parts and Controls	6	3-12.	Tuner Block Diagram	100
1-3.	Antenna/Cable and TV Connection	11	3-13.	Power Block Diagram	103
1-4.	Connection to AN Audio System	15	3-14.	Remote Control Block Diagram	105
1-5.	Setting the Clock	16	4.	SCHEMATIC DIAGRAM, PRINTED WIRING BOARDS	
1-6.	Adjusting the TV	17	4-1.	Frame Schematic Diagram	107
1-7.	Selecting channels	18	4-2.	VI-10, RP-24 Schematic Diagram	111
1-8.	Inserting/Ejecting Cassettes	19	4-3.	SS-53, RD-12, UD-2 Schematic Diagram	120
1-9.	Recording TV Programs	21		SS-53, RD-12, UD-2, LM-8 Schematic Diagram	130
1-10.	Playback	23		Reel Motor/Capstan Motor Schematic Diagram	137
1-11.	Timer-Activated Recording	26	4-4.	AU-13, TI-4 Schematic Diagram	144
1-12.	Beta HI-FI Audio Recording	33	4-5.	AF-9 Schematic Diagram	154
1-13.	PCM Recording and Playback	35	4-6.	TM-75, FP-4, FF-3, FR-14, HP-12, JG-2, CH-38 Schematic Diagram	163
1-14.	Camera Recording	36	4-7.	PT-48, PA-4, PI-2, PS-65, PV-1, PR-6, PC-19 Schematic Diagram	171
1-15.	Editing Tapes	37	4-8.	Semiconductors	175
1-16.	Audio and Video Insert	39	4-9.	UHF/VHF Tuner Schematic Diagram	177
1-17.	Automatic Assembly Editing	42	5.	EXPLODED VIEWS	
1-18.	Using the SONY Control System	44	5-1.	Front Panel and Cabinet Assemblies	179
2.	DISASSEMBLY		5-2.	Tuner, Timer and Power Assemblies	180
2-1.	Disassembly of Cabinet	47	5-3.	Front Loading Assembly	181
2-2.	Removal of the RP-24 Board	48	5-4.	Chassis Assembly 1	182
2-3.	Removal of the SS-53 Board	49	5-5.	Chassis Assembly 2	183
2-4.	Removal of the VI-10 Board	49	5-6.	Drum Assembly	184
2-5.	Removal of the TI-4 Board	50	5-7.	Reel Block Assembly	185
2-6.	Removal of the Timer Block	50	5-8.	Hardware List	186
2-7.	Removal of the FR-14 Board	51	6.	ELECTRICAL PARTS LIST	187
2-8.	Removal of the Power Block	51		ADJUSTMENT	221
2-9.	Removal of the FL Cassette Compartment Assembly	52		REMOTE COMMANDER (RMT-125)	285
2-10.	Removal of the Reel Block Assembly	52	1.	Remote Control Operation	286
2-11.	Internal Views	53	2.	Schematic Diagram	289
3.	BLOCK DIAGRAMS		3.	Printed Wiring Boards	290
3-1.	Circuit Boards Location	54	4.	Semiconductors	290
3-2.	Video Block Diagram	55	5.	Exploded View	291
3-3.	Servo Block Diagram	60	6.	Electrical Parts List	292
3-4.	Timing Chart	63			
3-5.	JOG Block Diagram	73			
3-6.	System Control Block Diagram	76			
3-7.	System Control Interface	79			
3-8.	Audio Block Diagram (1)	88			
3-9.	Audio Block Diagram (2)	91			

SECTION 1



GENERAL

WHAT IS BETA HI-FI RECORDING?

In conventional recording, audio signals are recorded on the audio track and video signals on the video track. In Beta hi-fi recording, audio signals are recorded on the video track together with the video signals using 2 rotary video heads.

The Beta hi-fi audio signals are frequency-modulated and recorded on 2 channels, so that you can record a stereo program with sound quality far superior to that of the conventional audio recording.

Beta hi-fi recording pattern on the video tape



When the BETA HI-FI switch is set to ON, this recorder records audio signals on the video track (Beta hi-fi recording) and on the conventional audio track at the same time, so that these tapes can also be played back on any ordinary video cassette recorder without a Beta hi-fi system.

1-1. FEATURES

Beautiful pictures, outstanding sound, sophisticated, easy operation—the SL-HF900 incorporates the best of Sony video and audio technologies in an advanced Beta hi-fi VCR. It will bring years of enjoyment to any audio-visual system.

SHARP, CLEAR PICTURES

- **Dramatically sharp and accurate picture of high resolution and contrast**—especially as the result of Sony's totally new technology, this VCR assures beautiful, professional quality home video recordings and reproduction.
- **Crystal clear freeze frame** provides sharp, clear pictures for precise viewing of any selected frame on the tape.
- **EDIT switch** ensures optimum picture quality of edited tapes.

OUTSTANDING SOUND QUALITY

- **Beta hi-fi recording** provides beautiful, audiophile-quality sound reproduction.
- **Independent left and right channel sound level slide controls**
- **Simulcast recordings can be enjoyed**, using the built in TV tuner for the picture and a separate audio system for the sound.

SOPHISTICATED ARRAY OF FUNCTIONS, EASY OPERATION


Versatile JOG Dial/SHUTTLE Ring

- **Triple-function JOG dial**—special effects playback, channel selection, timer setting.
 - Slow motion in both the forward and reverse directions.
 - High-speed tuning ideal for CATV systems.
 - Quick setting of hours and days for easy timer setup.
- **SHUTTLE ring** allows forward or reverse playback at the desired (X1/5, x1 or x2) speed and "Betascan" of the tape.

Editing Functions

- **Easy audio or video insert editing function** allows insertion of pictures and sound from a camera or other source on previously recorded tapes.
- **Automatic assemble editing function** enables the start and stop of recording of another connected Sony VCR simultaneously with the playback of this VCR within the preset start and stop points on the tape.

Convenience Functions

- **Automatic 8-program timer for unattended recording**, for this week, next week and the week after next.
- **Quick timer** allows you to record on a single channel up to 5 hours automatically (each push of button equals 30 minute increments).
- **Quick location of index signals** allows easy program confirmation.
- **Multi-function video/TV Remote Commander** can also be used with Sony remote control TVs (bearing the  mark).

Versatile auto functions


- **Auto play function** starts playback automatically after tape is fully rewound.
- **Tape return/Tape return play function** allows automatic playback or tape stop when the tape is wound to the 0H00M00S position on the counter.
- **Auto rewind** automatically rewinds the tape when the end of the tape is reached during recording or playback.
- **Auto eject** automatically ejects the tape if the tab on the cassette has been removed and the VCR has been engaged in the record mode.
- **Power turns on automatically** when a cassette is loaded with the power off.
- If the eject button is pressed when the VCR's power is off, the power will automatically be turned on for the cassette to be ejected, and then turn back off again.

Various Connection Arrangements

A variety of terminals are provided for connection to an optional video editing controller, and several video and audio components, making the SL-HF900 a central part of an audio-visual system.

GENERAL

1-2. LOCATION AND FUNCTION OF PARTS AND CONTROLS



1 POWER switch and lamp

Press to turn the power on. The lamp will light up. To turn the unit off, press this switch again. The timer section will continue to operate and the current time will be displayed even when the POWER switch is off, as long as the ac power cord is plugged into a working outlet.

2 Cassette compartment and ▲ EJECT button

Insert a cassette here. To eject the cassette, press ▲ EJECT button. When ▲ EJECT button is pressed during playback, rewind or fast-forward operations, the tape transportation will stop and the cassette will be ejected.

3 TAPE RETURN buttons

Press, when the tape is in the stop mode, to wind the tape to the point where the time counter reads "0H00M00S" point.

4 RESET button

Press to reset the time counter to "0H00M00S".

5 TV/VTR button


To view the TV program of the channel selected on this VTR, or to monitor the picture being recorded, press this button so that the button lights up. The recorder will be automatically set in this mode when the ► (play) button is pressed.

To view the TV program of the channel selected by the channel selectors of the TV, press this button again so that the light goes off. The lamp of this button will always be off when the power of this VTR is turned on newly.

6 Remote sensor

Detects the infrared transmitting signal from the supplied Remote Commander.

7 Display window



e Lights up when the EDIT PLAY button is pressed for the automatic assemble editing operation.

b Indicates that the starting time of a timer recording or the playback starting point on the tape for the automatic assemble editing operation is being displayed.

c Selected week for the timer recording

d Selected day of the week for the timer recording

e Selected channel number

f Time counter which indicates the approximate tape running time by the hour (H), minute (M) and second (S).

The starting time of timer recordings and the playback starting point for the automatic assemble editing operation will also be displayed here.

g Selected channel of stereo TV programs being played back.

i Present day of the week

j Current time display.


The ending time of timer recordings and the playback ending point on the tape for the automatic assemble editing operation will also be displayed here.

- ① Indicates that the ending time of a timer recording or the playback ending point for the automatic assemble editing operation is being displayed.
- ② Lights up when a cassette is inserted.
- ③ Recording tape mode (speed)
- ④ Flashes during the index search and index scan operation
- ⑤ Index number for indexed programs to be searched or scanned/Program number of timer recordings
- ⑥ Lights up when the TIMER REC ON/OFF or QUICK TIMER key is pressed for timer recordings. Only "TIMER" will appear while presetting the timer.

⑦ OPEN button

Press to open the JOG dial door.

⑧ Tuning compartment



⑨ COMMAND MODE selector

To remotely control this VTR with the supplied Remote Commander, set this switch to the same position as that of the corresponding selector on the back of the Remote Commander.

⑩ ADD button, ERASE button

Adds or erases channels that can be selected with the +/- channel buttons.

⑪ AUTO STEREO ON/OFF selector

Normally keep this switch to ON so that MTS (Multi-channel TV Sound) broadcasts can be received. Only when there seems to be much noise interference in the stereo broadcasts, set this switch to OFF in which case all the TV programs will be received monaural.

⑫ RF UNIT selector

Set this selector to 3CH (channel 3) or 4CH (channel 4) whichever is not active in your area. This selector converts the VHF output of the VCR to either channel 3 or 4 so that you will be able to view the picture of the VCR by selecting either of these channels on the TV.

⑬ CATV/NORMAL button

If you have connected this VCR to a cable antenna (CATV) system to view cable TV programs, press this button so that the "CATV" indicator in the display window lights up. To view regular "off-the-air" broadcasts, press again so that the indicator turns off.

⑭ AUX PRESET button

Press this button to preset the output channel of a decoder (converter) that is required for certain cable TV systems.

⑮ STILL ADJ (adjustment) control

If the still playback picture stopped with the **||** pause button seems to shake, turn this control until it stabilizes.

⑯ INDEX button

Press before pressing **◀** (rewind) or **▶** (fast-forward) for the index-search or index-scan operation.

⑰ Channel +/- buttons

Press + to select higher numbered channels or - to select lower numbered channels.

The channels will change consecutively when these buttons are held down.

⑱ Tape transport button

◀ (rewind) button: Press to rewind the tape. A fast reverse picture can be viewed when double-pressed or when pressed during normal playback. (Betascan, Beta SkipScan operations)

▶ (play) button: Press to play back the tape.

▶▶ (fast-forward) button: press to advance the tape rapidly. A fast picture can be viewed when double-pressed or when pressed during normal playback. (Betascan, Beta SkipScan operations)

■ (stop) button: Press to stop the tape.

|| (pause) button: Press to stop the tape momentarily during recording or playback. A still picture will be displayed when pressed during playback. Press again to release the pause mode.

x2 button: Press this button after pressing **▶** button for double speed playback. (Not functional for tapes recorded in the **||** mode).

⑲ TRACKING NORM (normal)/SLOW controls

Normally keep these controls at the center detent position. Turning either of these controls may help clear possible streaks on the screen especially for cassettes recorded on other recorders. Turn **NORM control** when playing back the tape at the normal speed or at double speed. Turn **SLOW control** when playing back the tape at a slow speed by turning the JOG dial or the SHUTTLE ring or by pressing the 1/5 button on the Remote Commander.

⑳ REC (record) switch

Slide to the right to start recording. The red lamp on the button will light up.

㉑ REC (recording) LEVEL controls

Adjust the recording sound volume of the L (left) and R (right) channels of Beta hi-fi recordings. Normally keep these controls at the center detent position "5".

㉒ Beta hi-fi indicator

Lights up when a recording is being made in the Beta hi-fi system with the BETA HI-FI switch set to ON, or when a tape that has been recorded in the Beta hi-fi system is being played back.

㉓ PEAK LEVEL METER

Indicates the peak volume level of the Beta hi-fi recording being made or being played back.


㉔ HEADPHONES Jack (stereo phone) and LEVEL control

Connect headphones here to monitor the sound. The sound volume can be adjusted with the LEVEL control.

㉕ MIC (microphone) jack

By connecting a microphone here, you will be able to record the sound from the microphone on the conventional audio track.

Inside the front panel



20 NORM (normal) AUDIO MAIN/SAP selector

If you desire to listen to (and record) the SAP (Second Audio Program) of TV broadcasts, set this selector to "SAP".

Keep this selector to "MAIN" if you do not listen to or do not desire to record the sound of Second Audio Programs.

21 INPUT SELECT switch

Select the input signal to be recorded.

Tuner: for TV programs

LINE AUDIO: for recording simultaneously the video (picture) of TV programs received through the 49 RF IN terminals and the audio (sound) of the audio source (such as an FM tuner) connected to the 50 LINE IN AUDIO (input) jacks

LINE/PCM: for the video and/or signal received through the 48 LINE IN VIDEO/PCM (input) jack

22 REC (recording) MODE selector

Selects the recording tape speed II or III .

The playback speed will be set automatically regardless of the position of this switch.

23 EDIT switch

Normally keep this switch at the left position.

When editing a tape by connecting another VCR, set to the right "EDIT" position.

24 SHARPNESS control

Adjust the sharpness of the picture if necessary. Normally, set this control at the center detent position.

25 SUPER BETA switch

Normally, keep this switch at "ON" to obtain high-quality recording/playback picture.

Only if by setting this switch to "OFF", noise in the playback of tapes recorded or played back on other VCRs seem to be eliminated, set this switch to "OFF".

26 DETAIL NORM (normal)/HIGH switch

Normally, keep this switch at NORM.

When a tape of good quality, such as the Sony HG or PRO-X type, is being used, a sharper picture will be obtained by setting this switch to "HIGH" during playback.

27 MPX (ON/OFF)/PCM selector

When making a recording other than regular TV recordings, set as follows.

OFF: For recording the sound from a record player or a compact disk player

ON: For recording FM radio broadcast programs (If your FM tuner is equipped with an MPX filter, set this selector to OFF).

PCM: For PCM recording and playback.

(Regardless of the setting of this selector, TV programs are automatically recorded in the "ON" mode so that the internal MPX filter cuts off the unpleasant sound of high frequency.)

28 AUDIO MONITOR selector

Selects the sound (audio track on the tape) to be played back and monitored.

BETA HI-FI: The Beta hi-fi sound recorded on the Beta hi-fi audio track will be heard.

MIX: The sound recorded on both the Beta hi-fi audio track and on the conventional audio track will be heard.

NORM: Only the sound recorded on the conventional audio track will be heard.

29 BETA HI-FI switch


ON: Normally, keep this switch in this position.

Recording and playback will be made in the Beta hi-fi system that produces the sound of high fidelity. (Recording in the conventional monaural system will be made together so that tapes recorded on this VCR can be played back on VCRs that are not Beta hi-fi.)

Tapes not recorded in the Beta hi-fi system will be played back in the conventional system automatically.


OFF: Set this selector in this position if you desire to record and playback the sound only in the conventional (not Beta hi-fi) system.

Inside the JOG dial door



⑩ Playback Indicators

Indicate the forward or reverse movement or the pause mode of the tape during playback.



⑪ INDEX MARK/ERASE key

Press during playback or recording to record index signals on the tape. Erasing the index signals can also be done by pressing this key after pressing ⑩ INDEX button.

⑫ AUX key

Press to select the channel received through the decoder (converter) that is connected to the TO CONV and AUX terminals. To return to the regular channel received from the ANT/CABLE terminal, press again.

⑬ STEREO (L-CH/R-CH) key

Selects the R (right) or L (left) channel of stereo recorded tapes to be played back. Observe ④ of the display window as you select the desired channel. Each time you press this key, the indicator for the selected channel will change.

STEREO: You will hear the stereo of stereo broadcasts or of the playback of stereo tapes.

This indicator will light up automatically when a stereo program is received.

L-CH: Only the sound of the left channel will be heard.

R-CH: Only the sound of the right channel will be heard.

Note that even with Beta hi-fi recorded tapes, the sound will be monaural when the ⑭ AUDIO MONITOR selector is set to "NORM".

⑮ QUICK TIMER key

Press consecutively to start a quick timer recording and then to set the duration of the recording. The duration can be set in 30-minute intervals up to 5 hours so that the power will turn off. To stop a quick timer recording, press TIMER REC ON/OFF key.

⑯ TIMER REC ON/OFF key

Press after programming VCR for timer recordings so that the timer activates. To deactivate the timer, press again.

⑰ CHECK key

Press to check the contents of the timer presettings.

⑱ NEXT button

Press to advance to the next item to be set while setting the timer or the clock.

⑲ MARK button

Press to preset the starting and ending point of the automatic assemble editing operation.

⑳ EDIT START button

Press to start the playback (and the recording of the connected VCR) for the automatic assemble editing operation.

㉑ SHUTTLE ring


When this ring is turned and held during the playback pause mode, you will be able to play back the tape at double, normal or one-fifth of normal speed. The more it is turned, the faster the playback will be and when fully turned, you will be able to "Betascan (See page 24,)" the picture. Turn to the right or left for forward or reverse playback.

㉒ JOG dial

Turn to the right to select higher numbered channels or to the left to select lower numbered channels. When this dial is turned during the playback pause mode, the picture will be played back at a speed according to the speed you are turning the dial. Turn to the right or left for forward or backward playback. This dial is also used to preset timer recordings.

㉓ JOG dial function indicators

Light up to indicate for what purpose the JOG dial is being turned.



㉔ VIDEO INSERT/AUDIO INSERT button

Press to "insert" a new recording onto a part of a recorded tape.

㉕ EDIT PLAY button

Press as the first step of the automatic assemble editing operation.

㉖ BACK key

Press to go back to the previous step during clock or timer setting.

㉗ CLEAR key

Press to cancel a timer setting.


㉘ TIMER SET key

Press as the first step to preset the timer.

㉙ CLOCK SET button

Press this button as the first step to set the clock.

Rear



49 RF IN terminals

ANT/CABLE: Connect a VHF and/or UHF TV antenna or CATV cable here.

TO CONV, AUX: If you desire to watch cable TV programs that require a decoder (converter), connect the decoder (converter) here.

Connect the input of the decoder (converter) to the TO CONV terminal and the output of the decoder (converter) to the AUX terminal.

50 RF OUT (TO TV) terminal

Connect to the VHF and/or UHF antenna terminal(s) of the TV receiver. The output of this VCR converted to channel 3 or 4 and the VHF/UHF TV signals received by this VCR will be supplied to the TV receiver by this connection.

51 CONTROL S IN (input) jack (mini jack)

Connect to the CONTROL S OUT (output) jack of other Sony products for various systematic operations.

52 CONTROL S OUT (EDIT) jack (mini jack)

Connect to the CONTROL IN (input), or CONTROL S IN (input) of another Sony VCR for the automatic editing operation.

53 AC OUTLET (unswitched)

Supplies ac power to video or audio equipment with power consumption of under 400 watts.

54 CAMERA REMOTE OUT (EDIT) jack (special mini jack)

Connect to the CAMERA PAUSE or CAMERA PAUSE IN (input) jack of another Sony VCR for the automatic assemble editing operation.

55 CAMERA REMOTE IN (input) jack (special mini jack)

When recording with a video camera, connect the Sony HVA-220 ac adaptor to this jack.

56 LINE OUT (output) 1, 2 VIDEO/PCM jacks (phono jacks)

Connect to the video input of a color monitor, TV or another VCR. For PCM playback, connect a PCM digital audio processor.

57 LINE OUT (output) 1, 2 R-AUDIO-L jacks (phono jacks)

Connect to the audio input of a color monitor, TV, or another VCR, or to a stereo system.

58 LINE IN (input) VIDEO/PCM Jack (phono jack)

Connect to the video output of another VCR, camera adaptor, video disc player etc., for recording. For PCM recording, connect a PCM digital audio processor.

59 LINE IN (input) R-AUDIO-L jacks (phono jacks)

Connect to the line output of a sound source such as a tape recorder, an amplifier, a radio, or the audio output of another VCR. For FM simulcast recording, connect an FM tuner here.

CONNECTIONS

Before making connections


- Turn off the TV.
- Connect the ac power cord after all the connections of the video cassette recorder and the TV have been completed.
- Make connections firmly. A loose connection may cause a distorted picture.

1-3. ANTENNA/CABLE AND TV CONNECTION


Disconnect the TV antenna cables from the TV receiver and connect them to the recorder, then connect the recorder and the TV. See page 12 on how to attach the optional/supplied connectors and separators, if necessary.

CATV (Cable TV) cable

We recommend that you consult your cable company to make sure that the cable is properly connected.




Connecting a decoder (converter)



When your TV is not a Cable TV compatible type

Connect the Cable TV channel converter between the recorder and the TV so that you will be able to watch another CATV program while recording one Cable TV program.




Note to CATV system installer in the U.S.A.:

This reminder is provided to call the CATV system installer's attention to Article 820-22 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

Combination VHF/UHF antenna

Most combination antennas are equipped with a UV band separator (signal splitter). Take off the separator and connect the cable directly to the recorder.

Use the removed separator to connect the recorder and the TV.




If you need a separator or a complete antenna system, consult your Sony dealer or a qualified technician.

* Use an optional RFC-8 extension cable (available in the U.S.A. and Canada), 8 m (25 ft) long, if the supplied 75-ohm coaxial cable is not long enough.


VHF antenna

When the cable is a 300-ohm ribbon type lead-in (flat)


When the cable is a 75-ohm coaxial type (round)




How to attach an F-type connector



How to attach an EAC-25 external antenna connector




How to attach an EAC-66 U/V band separator (mixer)



UHF antenna


Attach an optional EAC-66 U/V band separator to the RF OUT connector of the recorder, and connect to the VHF and UHF antenna terminals of the TV.



When both VHF and UHF antennas are connected

Attach an optional EAC-66 U/V band separator (mixer) to the ANT/CABLE (RF IN) connector of the recorder, and connect the antennas to the U/V band separator. Then attach another optional U/V band separator to the RF OUT connector of the recorder, and connect to the VHF and UHF antenna terminals of the TV.

When your TV has a 75-ohm UHF/VHF antenna terminal Easy connection of the recorder to the TV can be made with the supplied 75-ohm coaxial cable regardless of the types of antenna.



Caution


Connections between the recorder's RF OUT connector and the antenna terminals of a TV receiver should be made only as shown in these instructions. Failure to do so may result in operation that violates the regulations of the Federal Communications Commission regarding the use and operation of rf devices. Never connect the output of the recorder to an antenna or make simultaneous (parallel) antenna and recorder connections at the antenna terminals of your receiver.

- Once the connections explained above have been made, the antenna TV signals, as well as the signal from the recorder, will be fed to the TV and you can view TV programs in the usual way.

CONNECTION TO A TV SET EQUIPPED WITH VIDEO AND AUDIO INPUT JACKS

If your TV set is equipped with video and audio input jacks, connect the LINE OUT 1 or 2 jacks of this VCR to the input jacks of the TV in addition to the antenna connection you have made to the TV as described on pages 11–13.

Better picture and sound from the VCR will be obtained than if the TV is connected only to the antenna (RF OUT) terminal of this VCR.




Such TV sets should have a TV/VCR input selector (often named TV/VIDEO button). By pressing or switching the position of this selector you will be able to view the picture of the connected VCR on the TV screen instead of by selecting channel 3 or 4 on the TV. "ADJUSTING THE TV" on page 17 is not necessary if the above connection is made.

CONNECTING A COLOR MONITOR

To obtain better-quality picture, connect a color monitor, such as the Sony Profeel Trinitron Component TV, instead of a conventional TV receiver.


If a component TV is combined with a speaker system as illustrated, you will be able to enjoy the stereo sound of tapes recorded in the Beta hi-fi system through the speaker system.

If you use a component TV tuner together with the monitor, connect the recorder and the TV tuner in the same way as in the case of the recorder and the conventional TV receiver as described on pages 11 and 12. For details on the connection of the TV tuner and the monitor, refer to the instruction manual of the TV tuner.




1-4. CONNECTION TO AN AUDIO SYSTEM

You can experience a more dynamic sound of tapes recorded in Beta hi-fi when the recorder is connected to an audio system.




To record audio signals from your audio system

You can record only, or together with video, the audio (sound) of an audio source, such as an FM tuner or a CD player, in the Beta hi-fi system with the following connection.



Connection to a receiver equipped with VIDEO connectors




For details, see the instruction manual of the receiver.

Notes

- If the VCR is installed near a tuner or a radio, noise may be heard in AM reception. In this case, keep the VCR away from the tuner or the radio, adjust the AM bar antenna for minimum noise, or connect an external AM antenna to the tuner.
- Before connecting or disconnecting the power cord of the VCR, be sure to turn the connected amplifier off.

POWER CONNECTION



AC OUTLET

This socket provides a convenient ac power source for other video or audio equipment whose power consumption is under 400 watts. Power will be supplied to the connected equipment even when the recorder is turned off.


- Do not connect here any electrical home appliances whose power consumption exceeds 400 watts, such as an electric iron or fan.

When disconnecting the power cord from the wall outlet be sure that the POWER switch of this unit is turned off.

Occasionally, when the POWER switch is turned on and off immediately after plugging the set to a wall outlet, the VCR becomes unoperational. If this occurs, press the CLOCK SET button inside the JOG dial door, set the clock and then operate the set.

1-5. SETTING THE CLOCK


When you connect the ac power cord to a wall outlet, the clock shows "SU AM12:00" indicating that it must be set.




Example: To set for Wednesday afternoon at 7:30

Turn the JOG dial clockwise for advancing the number and counterclockwise for reverse.


- 1 Press CLOCK SET.
The day of the week indicator will blink.
- 2 Set the day by turning the JOG dial until "WE" (for Wednesday) appears.




- 3 Press NEXT.
Set the hour by turning the JOG dial.
Make sure that "AM" or "PM" is correctly set.



- 4 Press NEXT.
Set the minute by turning the JOG dial.



- 5 For accurate setting, press NEXT at the same time as an announced time signal. The clock will start.




The dots of the colon (:) alternately blink every 30 seconds.

ADJUSTMENT

1-6. ADJUSTING THE TV

Your TV must be adjusted to receive the signal transmitted by your VCR. The VCR transmits its signal on either channel 3 or 4 and this is why you will be selecting channel 3 or 4 on the TV whenever viewing the VCR picture. If you have connected a color monitor or a TV set equipped with video and audio input jacks, this adjustment is not necessary.



- 1 Set the RF UNIT selector located in the tuning compartment to "3 CH" or "4 CH" whichever channel is not active in your area.
- 2 Press POWER switch to turn on the power.

If you do not have a recorded cassette tape

If you have a recorded cassette tape

- 3 Press TV/VTR button so that the button lights up.
- 4 Check that the INPUT SELECT switch is set to TUNER, then select an active channel (Observe the channel display) in your area by turning the JOG dial.
For cable TV channels, the "CATV" indicator should be displayed above the channel display.
For off-the-air channels the "CATV" indicator should be off. To turn on/off the indicator, press CATV/NORMAL button.

- 5 Insert the cassette into the cassette compartment.
- 6 Press ► (play) button.

- 7 Turn on the TV.
- 8 Select either VHF channel 3 or 4 on your TV to agree with the setting of the RF UNIT selector of the VCR.
The TV program selected on the VCR or the playback of the inserted cassette tape will be displayed on the TV screen.
If a picture does not appear or is not clear, fine tune the selected channel 3 or 4 with the controls of the TV. For fine tuning the channel, read the instruction manual of the TV.

Now your TV receiver is tuned to the VCR. Whenever using the VCR, you should set the TV to the channel 3 or 4 (whichever you selected).

BASICS


1-7. SELECTING CHANNELS

Receivable channels of your VCR are:

- VHF: 2-13
- UHF: 14-69

Cable TV: 1-125 (See Cable TV channel chart.)


The channel selected on this VCR will be displayed in the display window.



For Cable TV broadcasts, the "CATV" indicator should be displayed. For off-the-air broadcasts, the indicator should be off. If necessary, turn on (or off) the indicator by pressing the NORMAL/CATV selector button in the tuning compartment.


There are 3 ways to select the channels on your VCR.

● By turning the JOG dial




● By pressing the channel number buttons and the ENTER button of the Remote Commander

Press the numeral(s) of the channel and then press ENTER button.
Ex. To select channel 6, press 6 and then ENTER.



To select channel 42, press 4, 2 and then ENTER.



The channel will not be selected if the ENTER button is not pressed and the previously selected channel number will be displayed again after a few seconds.

● By pressing the channel +/- buttons



The channels will change consecutively if you hold the button down.

By adding and erasing channels, you can preset your VCR so that only the desired channels appear in sequence when the channel +/- button is pressed. (See next page.)

Cable TV channel chart*

Cable TV systems use letters or numbers to designate channels. To tune in a channel, refer to this chart.


Number on this VCR	1	5	6	14	15	16	17					
Corresponding Cable TV channel	A-8	A-7	A-6	A	B	C	D					
18	19	20	21	22	23	24	25	26	27	28	29	30
E	F	G	H	I	J	K	L	M	N	O	P	Q
31	32	33	34	35	36	37	38	39	93	94	
R	S	T	U	V	W	W+1	W+2	W+3	W+57	W+58	
95	96	97	98	99	100	101	102	123	124	125	
A-5	A-4	A-3	A-2	A-1	W+59	W+60	W+61	W+82	W+83	W+84	

Check with your local cable TV company for more complete information on the available channels.

*The designation of the cable TV channels conforms to the EIA/NCTA recommended standards.

PRESETTING CHANNELS

PRESETTING CHANNELS TO BE SELECTED WITH THE CHANNEL +/- BUTTONS



Adding channels

1 Select the channel to be added with the JOG dial or the Remote Commander.

2 Press ADD button.

A “—” will appear for an instant in the channel display, indicating that the channel will appear in the proper numerical sequence when you press the channel +/- button.

Repeat steps 1 and 2 for other channels to be added.

Erasing channels

1 Select the channel to be erased.

2 Press ERASE button.

A “—” will appear for an instant in the channel display, indicating that the channel has been erased. When channel +/- button is pressed, you will see that the channel is skipped over in the numerical sequence.

Repeat steps 1 and 2 for other channels to be erased. To add erased channels again, follow the steps in “Adding channels”.

Non-existent channels (channels other than those listed on the previous page) cannot be preset and the “—” indicator will not appear when the ADD or ERASE button is pressed.

TO PRESET THE OUTPUT CHANNEL OF THE DECODER CONNECTED TO THE AUX TERMINAL

You can preset your VCR so that the channel received through the decoder connected to the AUX terminal can be selected simply by pressing the AUX key on the VCR or on the Remote Commander.

1 Select the output channel of the decoder (generally 3 or 4) by turning the JOG dial.

2 Press AUX PRESET button.

A “—” will appear for an instant and then “PP (preset program)” will appear in the channel display.

The output channel that you have selected in step 1 is preset.


By pressing the AUX key inside the JOG dial door or on the Remote Commander you will be able to view the programs received through the decoder. “PP” will be displayed whenever this channel is selected.

To return to viewing regular channels, simply select another channel or press the AUX key again. (Selection will start from 103 or 199 when the JOG dial is turned.)

If you desire to select the decoder’s channel with the TV’s channel selectors without using the VCR, simply press the AUX key so that “PP” is lit (it will light up even without the power turned on), then select the channel.


1-8. INSERTING/EJECTING CASSETTES

Insert cassettes gently into the compartment until it starts sliding in. There should be a direction on the cassette showing in which way the cassette should be inserted.



The cassette indicator will light up.

The power of this VCR will turn on automatically whenever a cassette is newly inserted.



To eject the cassette, press the EJECT button. The cassette indicator will turn off.


If the EJECT button is pressed when the power is turned off, the power will turn on for the cassette to be ejected and then turn off again automatically.

USE OF THE SAFETY TAB

When a new recording is made on a previously recorded cassette, the previous recording will be automatically erased.

To avoid erasing the recording

Break off the safety tab using a screwdriver or similar object. The cassette will be ejected automatically when you slide the REC (recording) switch to the right.




To re-record on a cassette which has had its safety tab removed

Cover the hole with a piece of plastic tape.




OPENING AND CLOSING THE JOG DIAL DOOR

To open the JOG dial door, press OPEN button.
To close the door, gently push the door up.



ABOUT THE CONVENTIONAL AND BETA HI-FI AUDIO TRACK

In the Beta hi-fi recording system, sound is recorded simultaneously on 2 tracks on the tape as illustrated below.



On track (A), a monaural recording is made so that tapes recorded on this VCR can also be played back on VCRs that are not Beta hi-fi.

It is on track (B) that the Beta hi-fi recording of high-fidelity stereo sound is made. The Beta hi-fi recordings can only be played back on Beta hi-fi VCRs.



The BETA HI-FI switch should be set to ON to make Beta hi-fi recordings. When it is set to OFF, sound recordings will be made only on the conventional audio track.

In the illustrations of the tape in this instruction manual, Track (A) is referred to the conventional audio track and Track (B) to the Beta hi-fi audio track.

Selecting the audio track to be monitored

You can listen to the sound of each track separately or together by setting the AUDIO MONITOR selector as follows during recording or playback.



Position	Selected sound
BETA HI-FI	Beta hi-fi recording sound (Track (B))
MIX	Mixed sound of Beta hi-fi and conventionally recorded sound (Track (A) and (B))
NORM	Conventionally recorded sound (Track (A))

When tapes recorded on other non-Beta hi-fi VCRs are played back, the conventional audio track of such tapes will be automatically selected and played back regardless of the switch position.

OPERATIONS


1-9. RECORDING TV PROGRAMS

Caution

Television programs, films, video tapes and other materials may be copyrighted. Unauthorized recording of such material may be contrary to the provisions of the copyright laws.

Also, use of this recorder with cable television transmission may require authorization from the cable television transmitter and/or program owner.

Before recording




Recording time available in each mode

Cassette used	II	III
L-125	30 min.	45 min.
L-250	1 hr.	1 hr. 30 min.
L-500	2 hr.	3 hr.
L-750	3 hr.	4 hr. 30 min.
L-830	3 hr. 20 min.	5 hr.

The **III** mode is recommended for higher quality of sound and picture.

Recording

Numbers in the illustration show the sequence of operation.



- 1 Turn on the TV and select the channel for the video recorder 3 or 4*.
- 2 Press POWER on the recorder to turn the power on.
- 3 Insert a cassette.
- 4 Press TV/VTR to select the VTR mode.
- 5 Select the channel to be recorded with the JOG dial, channel + or - button, or the Remote Commander.
- 6 Slide REC to the right. The red lamp by the switch will light up and recording will start.
If the tape reaches the end during recording, the tape will be rewound to the beginning automatically.

*If your TV has a TV/VCR input selector (TV/VIDEO button) select the "VCR input" with the selector.

To stop recording, press ■ STOP.

To eject the cassette, press ■ STOP, then ▲ EJECT.

To stop the tape momentarily, press || PAUSE.

To resume recording, press the button again. If you do not resume recording for more than about 8 minutes, the pause mode will be automatically released and the tape will stop.

For tapes to be recorded on other VCRs

On some VCRs, if the tape is fully rewound, a part at the very beginning of the tape will not be played back. We recommend that you run the tape for about 15 seconds before starting your actual recording.



TO VIEW ONE TV PROGRAM WHILE RECORDING ANOTHER

Press the TV/VTR button so that the lamp of the button turns off, then select the channel you want to view with the channel selectors on the TV.*

*If your TV has a TV/VCR input selector, simply select "TV" with the selector and then choose the desired channel.

TO START RECORDING IN THE MIDDLE OF A RECORDED TAPE


- 1 Play back the recorded tape by pressing the ► (play) button.
- 2 At the point where you wish to start a new recording, press || (pause) button.
- 3 Slide the REC switch to the right.
The VCR will be in the recording pause mode and the picture selected by the INPUT SELECT switch (if it is set to "TUNER", the TV program) will appear on the monitor screen.
- 4 Press || (pause) to release the pause mode.
Recording will begin.

The picture may be a little distorted in between the recordings, which is due to the stopping and starting of the tape.

RECEIVING/RECORDING MULTICHANNEL TV SOUND (MTS) BROADCASTS (STEREOCASTS)

In the years to come, an increasing number of programs will be broadcast in stereo. Called Multichannel TV Sound or MTS, the new technology will greatly enhance TV viewing by bringing you programs with high fidelity stereo sound.

MTS also provides for an extra channel called the Second Audio Program or SAP which broadcasters can use to transmit a second language for bilingual transmissions or some other sound track.



The MTS programs can be received with the AUTO STEREO switch set to ON.

To receive and record a stereo program

With the BETA HI-FI switch and the AUTO STEREO switch in the tuning compartment both set to ON, you will be able to receive, and record the stereo programs in the Beta hi-fi system. Whenever an MTS broadcast is being received, the "STEREO" indicator in the display window will light up.

On the conventional audio track of the tape, a monaural recording will be made.

Tape


Track (A) Monaural recording

Track (B) Stereo recording

To receive and record SAP (Second Audio Program) broadcasts


If you desire to receive and record the SAP broadcasts, set the NORM (normal) AUDIO selector to SAP.

To listen to the SAP being received or recorded, set the AUDIO MONITOR selector to "NORM (normal)" (also making sure that the AUTO STEREO switch in the tuning compartment is set to ON).



The SAP will be recorded on the conventional audio track of the tape. The main sound (stereo or monaural) of the program will also be recorded on the Beta hi-fi audio track as long as the BETA HI-FI switch is set to ON.

Tape



To listen to the SAP and the main sound at the same time, set the AUDIO MONITOR selector to "MIX".



If during recording, there is no SAP being broadcast and the NORM AUDIO selector is set to "SAP", nothing will be recorded on the conventional audio track.

Only when there seems to be much noise interference in the MTS broadcasts, set the AUTO STEREO switch to OFF, in which case all the TV programs will be received with the monaural main sound.

NOTE

ABOUT THE SUPER BETA SWITCH


Normally keep this switch in the "ON" position to obtain high picture quality recordings and playback.

Tapes recorded in other non-SuperBeta VCRs can be played on SuperBeta VCRs.

Tapes recorded in SuperBeta can be played on other non-SuperBeta VCRs: However, some over-modulation noise may appear in the picture during playback. If you intend to play back on other non-SuperBeta VCRs, then set the SuperBeta switch to "OFF" position when making your recordings.

1-10. PLAYBACK

Before playing back the tape



- 1 Turn on POWER switch.
- 2 Insert a cassette.
- 3 Turn on the TV and select the channel for the VCR channel 3 or 4*.
- 4 Press ► (play) button. Playback will start.

To stop the playback, press ■ (stop) button. If the tape reaches the end during playback, the tape will be automatically rewound to the beginning.

*If your TV has a TV/VCR input selector (TV/VIDEO button) select the "VCR input" with the selector.


When changing the channel on your TV from channel 3 or 4 to which you have been viewing the picture of the VCR to another channel, first press TV/VTR button and then select the desired channel. If you change the channel first and then press TV/VTR button, a picture may sometimes not appear at all. If this happens, select another different channel on the TV, and then select the desired channel again.

Playback of Beta hi-fi stereo sound recordings

If the VCR's LINE OUT 1 or 2 AUDIO jacks are connected to the stereo audio (L, R) input jacks of a TV that is stereo broadcast ready or to a stereo system, or if you have stereo headphones connected to the HEADPHONES jacks, you will be able to enjoy the stereo sound reproduction of stereo programs recorded in the Beta hi-fi system.

Be sure that the AUDIO MONITOR selector is set at BETA HI-FI (or at MIX) when playing back stereo programs. Only the monaural sound recorded on the conventional audio track will be heard if it is set to NORM.


If you desire to listen only to the left or right channel of the stereo program, select the desired channel with the STEREO L-CH/R-CH (left channel/right channel) key behind the JOG dial door. Each time you press the key, the indicator for the selected channel will appear in the display window.



If the connected TV is a monaural TV or (even when the TV is stereo broadcast ready) if this VCR is connected only to the antenna terminal of the TV, the left and right channels of stereo will be mixed and reproduced monaural.

Playback of SAP (Second Audio Program) recordings

When playing back the SAP recorded on the conventional audio track of the tape, be sure to set the AUDIO MONITOR selector to NORM (for listening only to the SAP) or to MIX (for listening to both the SAP and the main sound of the program recorded on the Beta hi-fi audio track).



PICTURE ADJUSTMENTS

- To adjust the sharpness of the playback picture, turn the SHARPNESS control.
- If the picture of a tape played back at the normal or double speed seems distorted or snowy, turn the TRACKING NORMAL control for the best possible picture.
Be sure to return the control to the center detent position after viewing that particular tape.

Note


The playback picture may blank out for an instant at a spot on the tape where the switching of the recording mode from **BI** to **BP** had been made.

AUTO PLAY

To have the tape automatically be played back after the tape has fully rewound itself.

Press **◀◀** (rewind) button and while holding it down, press **▶** (play) button.

Blinks while rewinding.




The tape will be rewound and playback will begin.

BETASCAN

Viewing the picture at a fast speed to find a particular scene


Press **▶▶** or **◀◀** during playback. When you release the button, the normal playback will resume.




BETA SKIPSCAN

Viewing the picture momentarily during fast-forward or rewind

Press **▶▶** or **◀◀** during fast-forward or rewind mode. When you release the button, the fast-forward or rewind mode will resume.



Streaks will appear and sound will be muted in the Betascan and Beta SkipScan pictures.




During Betascan, the Beta hi-fi indicator may sometimes not light even when a Beta hi-fi recorded tape is played back.

VARIOUS PLAYBACK MODES

FREEZE PICTURE

Press **■** PAUSE during playback.




To resume playback press **■** (pause) again.

- If the displayed still picture seems to shake, turn the STILL ADJ (adjustment) control in the tuning compartment until the picture stabilizes. As long as the same TV is used with this VCR, it should not be necessary to make this adjustment so frequently.
This control may not work for particular tapes recorded in the **BI** mode.
- If streaks or noise appear, play back the tape at slow speed (see next page), adjust the TRACKING SLOW control and then freeze the picture with the **■** (pause) button again.
- To protect the video heads and the tape, the pause mode will be automatically released after about 8 minutes and playback will resume.

DOUBLE-SPEED PLAYBACK

(for tapes recorded in the **BI** or **BP** mode)

Press the x2 button during normal playback.




The tape will be played back at double speed and if the tape was recorded in the Beta hi-fi system the sound will be played back at double speed also. (Adjust TRACKING NORMAL control if necessary.)

This button will not function for tapes recorded in the **BI** mode.

To return to normal playback, press the **▶** (play) button.

PLAYBACK USING THE JOG DIAL AND THE SHUTTLE RING

Lights up during the playback pause mode.



Indicate the forward or reverse playback of the tape.

Press the OPEN button to open the JOG dial door.



JOG dial (can be turned also from the outside of the door)

SHUTTLE ring

Using the JOG dial

- 1 Play back a tape and stop the playback with the **||** (pause) button.
- 2 Turn the JOG dial.



The tape will be played back at the speed you are turning the dial. Turn it clockwise for forward playback or counterclockwise for reverse playback.

Using the SHUTTLE ring

- 1 Play back a tape and stop the playback with the **||** (pause) button.
- 2 Turn and hold the SHUTTLE ring.



Turn it as much as desired for the playback at one-fifth the normal speed, normal speed, or at double speed.


When it is fully turned you will be able to "Betascan" the picture. Turn it clockwise for forward playback or counterclockwise for reverse playback.

When the SHUTTLE ring is released, the picture will freeze again.

Streaks will appear in the playback at a speed other than the normal speed. The sound will be muted.

If the picture of a tape played back at a speed slower than the normal speed seems distorted or snowy, turn the TRACKING SLOW control for the best possible picture. (By this picture adjustment of slow playback, the still picture of that recording will be adjusted as well.)


Be sure to return the control to the center detent position after viewing that particular tape.



1-11. TIMER-ACTIVATED RECORDING


The timer of this VCR can be preset to record up to 8 programs within this week, the next week and the week after next.

Before setting the timer



SETTING THE TIMER

Buttons and keys to be used




Suppose you want to make a recording of channel 10 from 8:15 p.m. to 10:00 p.m. on Saturday next week.

You will be using the JOG dial and the NEXT button. Every time the NEXT button is pressed, the item to be preset will blink and you will be setting the item by turning the JOG dial.

Press the BACK key if you desire to go back a step and change the setting of a particular item.


1 Press TIMER SET.

The program number (up to 8) will appear. "1" indicates that you are making the first timer setting.




2 Set the day and week for recording by turning the JOG dial.

(By turning the dial clockwise, the day and week will advance.)




3 Press NEXT.



Set the turn-on hour by turning the JOG dial. Make sure that A.M. or P.M. is properly set.




- 4 Press NEXT.
Set the minute by turning the JOG dial.



- 5 Press NEXT.
Set the turn-off time (hour and minute) as in steps 3-4.



- 6 Set the channel to be recorded by turning the JOG dial or by pressing the channel +/-.



- 7 Press NEXT.
The memorized turn-on and turn-off times will be displayed for about 3 seconds, and then the time counter and the present time will reappear.

To preset another program, press TIMER SET again and repeat steps 2-7.

When eight programs have been preset, you cannot set any more programs.

- 8 Press TIMER REC ON/OFF.
The power will be turned off and the VCR will be in the standby mode.



"TIMER REC" will light up and the present time will be displayed.

Recording will start at the preset time and will automatically stop when the recording is completed.

The succeeding program numbers of other preset programs will shift automatically by the number of completed recordings.

- If the cassette's safety tab is removed, the cassette will be ejected automatically when TIMER REC ON/OFF is pressed.
- "TIMER REC" will not light up if the preset turn-on time is earlier than the present time.

NOTICE:

ONCE THE "TIMER REC" INDICATOR HAS LIT UP, only the functions of CHECK, AUX, and TIMER REC ON/OFF on the recorder can be activated. To turn on the power again for the usual manual operations, press TIMER REC ON/OFF again so that the indicator turns off. This does "not" affect the memory of the timer. As long as you press it again, timer recording will be made exactly as preset.

To record up to the very end of the tape


Figure out how long a recording can be made with the remaining tape and then set the turn-off time so that it will be after the tape reaches its end.

To set the channel received through the AUX terminal
Press AUX key so that "PP" lights up for the channel display in step 6.

EVERY WEEK/EVERY DAY TIMER RECORDINGS

To record at the same time every day


When setting the day of the week, turn the JOG dial counterclockwise one notch so that all the day-of-the-week indicators are lit.



Recording will be made every day at the preset time until the end of the tape.

To record at the same time and day every week

When setting the day of the week turn the JOG dial counterclockwise until the "EVERY WEEK" and the desired day-of-the-week indicator lights up.



Recording will be made every week at the preset time until the end of the tape.

To temporarily cancel out every week/every day recordings

Press TIMER REC ON/OFF key so that the "TIMER REC" indicator disappears.

The recordings will not be made.

When TIMER REC ON/OFF key is pressed again and the "TIMER REC" is lit, every week/every day recordings will be made just as preset.

BEFORE THE TIMER-ACTIVATED RECORDING STARTS...

To check the timer settings

Press the CHECK key. Every time you press CHECK, each preset time will be displayed.

To change the settings

- 1 Press TIMER REC ON/OFF.
- 2 Press CHECK to select the program to be changed.
- 3 Press TIMER SET.
- 4 Press NEXT consecutively until the item to be changed blinks.
- 5 Change the setting with the JOG dial.
- 6 Press NEXT so that the current time appears.
- 7 Press TIMER REC ON/OFF again to reactivate the timer.

To erase the memory of a particular program

- 1 Press TIMER REC ON/OFF.
- 2 Press CHECK to select the program to be erased.
- 3 Press CLEAR. The memory of the program will be eliminated.
- 4 If other programs have been preset for recording, press TIMER REC ON/OFF again to reactivate the timer.

AFTER A TIMER RECORDING HAS STARTED...

To stop the recording momentarily.

Press **||** (pause) button.

To resume the recording press **||** again. (Recording will automatically resume if this is not done for more than about 8 minutes.)

To stop a timer recording completely


Press the **TIMER REC ON/OFF** key.

The recording will stop and the power will be turned off.

SPECIFIC NOTES ON TIMER-ACTIVATED RECORDINGS

When the presettings of your timer-activated recordings overlap

There will be no error indication to inform you of the overlap. Even if there is an overlap, a recording will be made.



In this case, the recording of program 2 will begin before the first recording is completely finished. Consequently, program 1 will be cut off in the middle of its recording.

If the power should be interrupted before a timer recording

If a power interruption occurs, the clock will stop and the time indication will be "AM12:00". This means that the memory of the timer has been completely erased. Set the clock and the timer again.

A short power interruption of less than approx. 10 minutes will not affect the memory of the timer. The timer programs will be retained and performed and the clock will show the correct time.

If the power was interrupted during a timer or quick timer recording

Recording will stop and the power will be turned off.


If the interruption was less than approximately 10 minutes, the recording will resume.

QUICK TIMER RECORDING

You can immediately start a recording and set the duration as well simply by pressing the **QUICK TIMER** key. The duration can be set for up to 5 hours by 30 minute intervals so that the power will turn off automatically.

1 Press QUICK TIMER.

The power will be turned on had it not been turned on already.



Cassette is inserted.


Channel previously selected

2 Choose the channel to be recorded.

If you do not advance to the next step within 30 seconds, power will turn off.

3 Press QUICK TIMER again so that the recording starts.

Now decide the recording duration.



Every time you press **QUICK TIMER**, the recording duration indication will change as follows:

0:30 → 1:00 → 1:30 5:00 → 0:00
 30 minutes one hour one and a half hour five hours zero hours

When the recording starts, the displayed duration will decrease minute by minute to 0:00. The recorder will turn off automatically after the recording is finished.

To stop a quick timer recording

Press **TIMER REC ON/OFF**. The power will be turned off as well.

Once the quick timer recording has started

No function button except for the following will activate:

QUICK TIMER.....to change the recording duration

TIMER REC ON/OFF.....to interrupt the quick timer recording

PAUSE.....to stop the quick timer recording momentarily

CHECK.....to check the timer programs preset


During regular non-timer recording

You can set the recording duration during regular non-timer recording as well by consecutively pressing the **QUICK TIMER** key just as in step 3.

The power will turn off automatically after the recording is over.

USE OF THE TIME COUNTER

The time counter indicates the approximate running time of the tape and the relative position of programs on the tape.



Before starting recording or playback, press RESET button to set the counter to "0H00M00s".

By noting the counter reading at the desired point, you can easily find that point later by referring to the counter.

Use the label on the cassette to list the programs and their counter readings.

Notes

- The counter reading is automatically reset to zero when a cassette is newly inserted.
- The counter reading will be retained in the memory even after the power is turned off, as long as the cassette is kept inserted in the cassette compartment.
- The counter will not operate when a blank, unrecorded tape is being used. Therefore, you can easily find a blank part of the tape by observing where the counter stops.

TAPE RETURN/TAPE RETURN PLAY

By using the TAPE RETURN button, you can easily find and review the desired section of the tape after recording or playback.

- 1 During recording or playback, press the RESET button at the point you later want to return to.
- 2 When the recording or playback is finished, stop the tape by pressing the ■ (stop) button.
- 3 Press TAPE RETURN.

TAPE RETURN




The tape will be rewound or (had it been rewound already) advanced close to the point where the counter reads "0H00M00s".

Depending on the movement of the tape, the lamp on either the ◀◀ or ▶▶ button will light up.

If you desire to have the tape play back automatically from the "0H00M00S" point

Press the ▶ (play) button after pressing the TAPE RETURN button.





INDEX FUNCTION

Easy location (and playback) of the desired program can be done with the index function of this VCR. Programs will be located by their index signals recorded on the tape.

The length of the index signal recorded with this VCR varies according to the setting of the REC MODE selector:

- ◻ I : approx. 4 seconds
- ◻ II : approx. 8 seconds
- ◻ III : approx. 12 seconds

An index signal is automatically recorded on the tape when the REC switch is slid to the right or when timer recording starts.





"INDEX" blinks while the index signal is being recorded.

Notes

- Index signals will not be recorded on the tape when the recording is started by releasing the recording pause mode.
- The index function operates also with index signals recorded on other VCRs with an index function, such as the Sony SL-2700/2700B or SL-2500.

Index signals can be recorded at any desired point on the tape during recording or playback.

At the point where an index signal is to be recorded, press the INDEX MARK/ERASE key inside the JOG dial door.



"INDEX" blinks while the index signal is being recorded.

Notes


- During playback, the sound recorded on the conventional audio track will be muted while the index signal is being recorded, but the recording will not be affected.
- Do not attempt to insert an index signal immediately before a point on the tape where the recording tape speed (PAL or NTSC) changes. In such a case, the index signal may not be registered.
- Index signals can be recorded on cassette tapes without the safety tab (including commercially available pre-recorded video tapes).

HOW TO ACTUATE THE INDEX FUNCTION

—There are two ways.

Index scan

This function allows you to play back the beginning of each program on the tape.





- 1 Insert a cassette that has index signals recorded.
- 2 Press the INDEX button once. The "INDEX" and "SCAN" indications will flash alternately.
- 3 When scanning the previous programs, press the ◀◀ (rewind) button. When scanning the programs ahead, press the ▶▶ (fast forward) button. The "INDEX" and "SCAN" indications will light steadily and the tape will be rewind or advanced rapidly to the next index signal recorded.
Whenever an index signal is detected, the tape will be played back for approx. 10 seconds, and then rewind or advanced rapidly again to the next index signal.
- 4 At the desired program, press the ▶ (play) button. Playback of that program will begin.

Index search

You can have the desired program located and then played back automatically by designating the number of its index signal.

Up to the ninth index signal away from the present position on the tape can be located.



- 1 Insert a cassette that has index signals recorded.
- 2 Press the INDEX button several times until the number of the desired program is displayed.
For instance, to locate the second program ahead, two index signals will have to be detected, so press the button until "2" is displayed. On the other hand, to locate the second program behind, three signals will have to be detected, so press the button until "3" is displayed.
- 3 When locating a previous program on the tape, press the ◀◀ (rewind) button. When locating a program ahead, press the ▶▶ (fast forward) button.

The tape will be rewind or advanced rapidly. Every time an index signal is detected, the displayed number will decrease. When the number reaches 0, playback of your desired program will start.

Notes

- The index function can be activated during playback, as well as from the stop mode.
- While the index signals are being scanned or searched for, there will be no picture or sound.
- If the tape is rewind to the beginning during index scan, playback will begin automatically.

When the desired program cannot be played back with the index function, check the following:

- Is there a program of less than one minute? Such a program will not be counted.
- The nearest index signal may not have been counted. If the point where you pressed the ◀◀ or ▶▶ button is fairly close (within one minute of the normal tape-run) to the nearest index signal, the nearest index signal will not be counted. In such a case, designate one number less than the actual number.
- Is there a space of more than 2 minutes between each index signal? If there is more than one index signal recorded within a space of two minutes of the normal tape-run, the mechanism may not function properly.

TO ERASE INDEX SIGNALS

Note

Index signals that were recorded by sliding the REC switch to the right from an unrecorded portion of the tape cannot be erased.

Scan-erasing —erasing all the index signals

- 1 Stop the tape with the ■ (stop) button.
- 2 Press the INDEX button. The "INDEX" and "SCAN" indications will blink alternately.
- 3 Press the INDEX MARK/ERASE key. "SCAN" stops blinking.
- 4 To scan-erase the previous index signals on the tape, press the ◀◀ (rewind) button. To scan-erase index signals ahead, press the ▶▶ (fast forward) button. The tape will be rewound or advanced rapidly to the nearest index signal. At each index signal found, the tape will be played back for approx. 10 seconds during which index signals will be erased. During the erasure, the sound recorded on the conventional audio track will be muted but the recording will not be affected.

To stop the scan erasing, press the ■ (stop) button.

Search erasing —designating the index signal to be erased


- 1 Stop the tape with the ■ (stop) button.
- 2 Count the number of the index signals from the present position of the tape to the signal you want to erase and set the number (on the left of the time counter) with the INDEX button.
- 3 Press the INDEX MARK/ERASE key. The "INDEX" indication will flash.
- 4 To search and erase a previous index signal, press the ◀◀ button. To search and erase an index signal ahead, press the ▶▶ button. The designated index signal will be searched for and when detected, playback will begin and the signal will be erased at the same time. Every time an index signal is detected, the displayed number will decrease until it reaches 1, which indicates that the designated index signal has been found. At this point a slight automatic adjustment of the tape position will be made and then playback/erasing will begin. When the erasing of the index signal ends, the displayed number will become 0.

ADVANCED OPERATIONS

1-12. BETA HI-FI AUDIO RECORDING

RECORDING FROM YOUR AUDIO SYSTEM


To connect the VCR to your audio system, see page 15.
Set the switches as shown below.
To start recording, insert a cassette and slide the REC switch to the right.



*When recording from an FM tuner without an MPX filter, set the MPX/PCM switch to ON.

FM SIMULCAST RECORDING

By connecting an FM tuner to the LINE IN AUDIO jacks in addition to the CATV cable connection, you can record a CATV program with stereo sound, such as MTV (music TV), whose audio signals are divided into the FM tuner from the cable. For FM simulcast recording, set the INPUT SELECT switch to LINE AUDIO. The sound from the FM tuner is recorded on the video track (Beta hi-fi recording) together with the picture, while the normal TV sound is recorded on the conventional audio track.




Note

If there has been a switching of the broadcasting source during FM simulcast recording, the sound may be distorted when that part of tape is played back.

TIMER-ACTIVATED FM RECORDING

Use an optional program timer to turn the audio system on and off.




The setting of the controls is the same as in "RECORDING FROM YOUR AUDIO SYSTEM".


Set the VCR's timer and the program timer to the same turn-on and turn-off times. The setting of the VCR's timer is the same as in "TIMER-ACTIVATED RECORDING" on page 26.

1-13. PCM RECORDING AND PLAYBACK

Connect a PCM digital audio processor as shown below.



For PCM recording, set the INPUT SELECT switch to LINE/PCM and MPX/PCM switch to PCM.

For optimum performance, use a video cassette with a model number of L-500 or under, (L-250, L-125, etc.), and select the tape speed .


After the PCM recording or playback is finished, be sure to set the MPX/PCM switch to OFF. Otherwise, the still picture of regular video tapes may be distorted.

For details, refer to the Instruction manual supplied with the digital audio processor.

1-14. CAMERA RECORDING

CONNECTIONS

- The camera must conform to American TV (EIA) standards.
- The use of a Sony HVA-220 ac adaptor is required.



OPERATION

Set the INPUT SELECT switch to LINE/PCM.

To start recording, slide the REC switch to the right. Once the recording is started, you can stop (pause) and start the recording with the tape run/stop button on your camera as well as with the **||** (pause) button on the VCR or on the Remote Commander.

To stop the recording completely, press the **■** (stop) button on the VCR or the camera.

FRAME-BY-FRAME SHOOTING

To tape an animated program of your own, follow the steps below.

- 1 Shoot an object, a doll for example, with your camera for several seconds, then set the VCR in the recording pause mode with the **||** button.
- 2 Move the object a little and slide the REC switch of the VCR to the right or press the record switch of the Remote Commander.
A very short recording of approximately seven frames will be made and then the VCR will automatically go into the pause mode again.

Repeat Step 2 as many times as you like.

When such recordings are played back continuously, the object will seem as if it is moving.

Notes

- This function can also be used when recording from the TV.
- The picture may be a little distorted when the frame-by-frame recordings are played back.
- If the VCR is kept in the pause mode for more than about 8 minutes, the pause mode will be automatically released and the tape will stop.


1-15. EDITING TAPES

To edit a tape, you will need two VCRs: one is to play back the original tape and the other is to record.


As illustrated below, by setting the EDIT switch at the "EDIT" position, the quality of the edited picture can be improved. Be sure to return the switch to the left position when you have finished editing.

If your other VCR is a Sony remote control VCR, see also pages 44-46 for further systematic operations.


To record the playback of another VCR



Video camera recorders, such as the Sony CCD-V8, that use 8 mm cassettes can also be connected so that you can edit and transfer what you have filmed on an 8 mm format cassette to a Beta format cassette.



To record the playback of this VCR on another VCR



* If your other VCR is a monaural VCR, use the optional RK-105A (and, if the audio input jack is a phono-type jack, the optional PC-5A plug adaptor).

When recording the playback of this VCR on a VCR that is not of the Beta hi-fi system


If the sound on the Beta hi-fi audio track and on the conventional audio track of the tape were originally recorded separately (such as when the SAP of a TV program is recorded on the conventional audio track and the main sound is recorded on the Beta hi-fi audio track), be sure to select the audio track to be played back with the AUDIO MONITOR selector. The selected (and only the selected) sound will be recorded by the other VCR. Note that if the switch is set to "MIX", the sound of the two audio tracks will be mixed and with VCRs that are not of the Beta hi-fi system, they will be reproduced mixed as well.

CAUTION

Television programs, films, video tapes and other materials may be copyrighted. Unauthorized duplication of such material may be contrary to the provisions of the copyright laws.

1-16. AUDIO AND VIDEO INSERT
(Continued on next page.)

By using the INSERT buttons inside the JOG dial door, you can easily "insert" (re-record) new sound or picture onto a recorded tape.



Audio insert —Inserting new sound (monaural) without erasing the original picture of the tape

If the original tape was recorded in the Beta hi-fi system, the original sound of the Beta hi-fi audio track will remain also.

Video insert —Inserting new picture and Beta hi-fi sound, without erasing the original sound on the conventional audio track

Audio and video insert —Inserting new sound and picture onto a part of the tape

The recording on the tape after audio, video or audio/video insertion


	Tape		
Audio insert	<table border="1"> <tr> <td>Track (A) newly inserted monaural sound</td> </tr> <tr> <td>Track (B) Original picture*</td> </tr> </table>	Track (A) newly inserted monaural sound	Track (B) Original picture*
Track (A) newly inserted monaural sound			
Track (B) Original picture*			
Video insert	<table border="1"> <tr> <td>Track (A) Original sound of the conventional audio track</td> </tr> <tr> <td>Track (B) Newly Inserted picture and or Beta hi-fi sound</td> </tr> </table>	Track (A) Original sound of the conventional audio track	Track (B) Newly Inserted picture and or Beta hi-fi sound
Track (A) Original sound of the conventional audio track			
Track (B) Newly Inserted picture and or Beta hi-fi sound			
Audio/Video insert	<table border="1"> <tr> <td>Track (A) newly inserted monaural sound</td> </tr> <tr> <td>Track (B) Newly inserted picture and Beta hi-fi sound</td> </tr> </table>	Track (A) newly inserted monaural sound	Track (B) Newly inserted picture and Beta hi-fi sound
Track (A) newly inserted monaural sound			
Track (B) Newly inserted picture and Beta hi-fi sound			

*"and Beta hi-fi sound," if the tape was originally recorded in the Beta hi-fi system.


When playing back the tape (or also while the insertion is being made), you can select the sound on Track (A) or on Track (B) to listen to by setting the AUDIO MONITOR selector to the desired position. (See page 20.)

PREPARATION

Select the desired audio and/or video source for the insertion and connect the source to the VCR. Examples are shown below.



After the connection is made, set the switches on the VCR as follows:




INPUT SELECT

- For inserting TV programs → **TUNER**
- For inserting the picture of TV programs with the sound of the audio source connected to the LINE IN AUDIO jacks → **LINE AUDIO**
- For inserting the sound of the microphone → Any position
- For other insertion → **LINE/PCM**

STEPS

Press the OPEN button to open the JOG dial door.



- 1 Playback the original tape that you like to record on.
- 2 At the point where you want to stop the insertion to be made, press the **||** (pause) button.



(If necessary, turn the JOG dial or the SHUTTLE ring for deciding on the point more accurately.)

- 3 Press RESET button.
The time counter will be reset to "0H00M00S".
- 4 Turn the JOG dial or the SHUTTLE ring counterclockwise or press the **◀◀** (rewind) button and at the point where you desire to start the insertion, release the dial, ring or the button.



- 5 Turn on the audio and/or video source that you have connected.
- 6 For "Audio insert", press AUDIO INSERT button.
For "Video insert", press VIDEO INSERT button.
For "Audio and Video insert", press VIDEO INSERT button and then the AUDIO INSERT button.




When these buttons are pressed, you will be able to monitor the sound and/or picture of the connected source.

- 7 Press the **||** (pause) button.

The video and/or audio insertion will start.

Had the original tape been recorded in the Beta hi-fi system, and you are inserting new sound onto the tape, you will be able to hear both the original audio recordings and the new sound being inserted.

At the point where you have pressed the RESET button in step 3, the recording will stop.




The picture of the connected video source will still be displayed even after the insertion is stopped.

Audio and/or video insertion can be made simply by stopping the playback with the **||** (pause) button and then going through steps 6 and 7, however, remember that the recording will stop at the point where the counter reads "0H00M00S".

To stop the insertion that has started, press the **■** (stop) button.

Notes


- During the insertion, the **▶** (play), **◀◀** (rewind) and **▶▶** (fast-forward) buttons will not function.
- If a microphone is connected to the MIC jack, the sound from the microphone will always be recorded on the conventional audio track.
- Insertions can be made just as described above without setting the AUDIO MONITOR selector to "MIX", but you will only be able to hear either the new sound being recorded or the originally recorded sound.
- If the safety tab of the tape is removed, the cassette indicator in the display window will blink when the INSERT buttons are pressed and insertion will not be made.
- As the time counter does not work with blank tapes, if there is a part that is unrecorded in between the starting and stopping points, the video and/or audio insertions will stop earlier than the preset stopping point by the amount of the unrecorded part.



1-17. AUTOMATIC ASSEMBLE EDITING


If you have another Sony VCR as designated on page 44, you can preset the VCR so that, with a push of a button, the desired (and only the desired) part of the tape will be played back while the connected VCR records the playback simultaneously. You can easily "assemble" parts of the recording of one or of many tapes onto a single cassette using this function.

PREPARATION




STEPS


Press the OPEN button to open the JOG dial door.





Press EDIT PLAY button



2 Play back the original tape and at the start of the scene to be recorded on the connected VCR, press MARK button.




- 3** Continue the playback and at the end of the scene to be recorded, press MARK button again. Use the Betascan or Beta SkipScan function for quick searching of the ending point.



The ending point will be memorized.

- 4** Set the connected VCR to the recording pause mode. (For details, read the instruction manual of the other VCR.)
- 5** Press EDIT START button. The tape on this VCR will be rewound to the starting point you chose in step 2 and playback will begin, and at the same time, the connected VCR will start recording.



Automatic start and stop (pause) of playback



Automatic start and stop (pause) of recording

Connected VCR

At the stopping point you chose in step 3, this VCR will be in the playback pause mode and the connected VCR will be in the recording pause mode. The lamp on the EDIT PLAY button will blink.

To repeat the same recording again, press the EDIT START button again.

The preset starting and ending points may shift by a small amount if you repeat this several times.

The tape transport buttons, ■, ▶, ◀◀ and ▶▶, can be used as usual after presetting the starting and ending points. When the EDIT START button is pressed, the playback and recording will be made as preset.

To preset another scene of the same tape

By "Betascan" or by turning the JOG dial/SHUTTLE ring or simply by releasing the pause mode with the || (pause) button, play back the tape and repeat steps 2-5.

To stop the tape during the automatic assemble editing, Press the ■ (stop) button.

To put the VCR back to the normal recording/playback mode

Press the EDIT PLAY button so that the lamp of the button turns off.

The current time will be displayed again.

To change the preset starting or ending point before pressing the EDIT START button

Press the EDIT PLAY button once so that the lamp of the button turns off, then repeat steps 1-3.

Notes

- The || (pause), ▶▶ (fast-forward) and ◀◀ (rewind) buttons will not function while the automatic assemble editing is being carried out.
- The preset starting and ending points will be erased if you turn off the power or eject the cassette.
- You cannot set the ending point at a point on the tape that comes before the starting point.
- With certain other VCRs, the starting and ending points of the recording will be shifted a little behind the preset points.

The starting/ending points can be selected more accurately using the JOG dial or the SHUTTLE ring

Before pressing the MARK button in steps 2 and/or 3, press the || (pause) button. Then turn the JOG dial or SHUTTLE ring to playback the desired starting/ending point. The playback pause mode need not be released to press the MARK button or the EDIT START button.

1-18. USING THE SONY CONTROL SYSTEM

- When two VCRs are connected for editing tapes, isn't there an easy way to operate both recorders?
- When more than one remote control video/audio component is used, shouldn't it be possible to operate both with the same Remote Commander or remote sensor?

Many owners want to incorporate their various audio and video components into a single audio-video entertainment system. To make this wish a reality, Sony audio and video components are equipped with various terminals that make intercomponent control possible.

The SL-HF900 is fully capable of operating as the part of the most advanced control systems. By connecting various components you can discover the exciting possibilities of the AV (Audio/Video) age for yourself.


Operating by remote control through a TV set or component TV tuner

If your Sony TV set or component TV tuner is equipped with a CONTROL OUT (output) jack, you can operate the SL-HF900 by remote control through the TV or TV tuner. This is especially handy for operating the VCR by remote control while watching TV when the two are located apart from each other.

If your TV is a Sony model KV-25DXR

If connected as shown at right, automatic timer playback for the VCR is possible within the time limits set on the TV's timer, and the start and stop times for automatic preset recording can be set on the TV. For details, please refer to the KV-25DXR's instruction manual.

*If a VTX-1000R/1100R component TV tuner is used, connect to the CONTROL jack of the MONITOR OUTPUT.




Assemble editing using one more VCR


One of the biggest problems that goes with tape editing using two VCRs is getting the timing right when starting and stopping recording on the recording VCR while the playback VCR is playing. However, connecting the SL-HF900 and another Sony (infrared remote control) VCR as shown in the diagram below, you can avoid this pro-

blem. First set the scene you want to record in the SL-HF900's automatic assemble editing function for the start and stop playback on the SL-HF900 and the start and stop of recording on the second VCR at the same time. Connections on the second Sony VCR are made as follows.


● Connection to VCR with CONTROL IN or CONTROL S IN (Input) minijack




② Connection to VCR with CAMERA PAUSE (Input) special mini jack



③ Connection to VCR with CAMERA 14-Pin, K type connector




④ Connection to Sony infrared remote control VCR other than ①, ② or ③ above



EDITING THE RECORDING ON 8MM FORMAT TAPES ONTO BETA TAPES WITH THE RM-E100 VIDEO EDITING CONTROLLER

If you own an 8 mm video camera recorder (such as the Sony CCD-V8) equipped with a 5-pin REMOTE connector, you can connect the RM-E100 video editing controller between the camera recorder and this VCR for easier and much faster tape editing, i.e., editing 8 mm tapes onto Beta format tapes.


With this controller, you will be able to preset the locations of the scenes you want to record (up to 8) in the controller and with a press of a button, these scenes will be recorded by this VCR automatically in the order preset. For details, refer to the instruction manual of the RM-E100.



BUILD YOUR OWN AV HOME ENTERTAINMENT SYSTEM!

As the number of AV (audio/video) components grows, so does the enjoyment of using them as part of a home entertainment system. Unfortunately, the complexity of connecting all these components and using them effectively also grows. To solve this problem, you need a home AV center.

With all your AV components connected to a system center, you can be the director of your own home entertainment programming at the flip of a switch. Watch TV, listen to the stereo, have programs recorded, edited, or played for your enjoyment—an AV center serves as the focal point for a whole wide world of entertainment in your home.




SB-V5W Audio/Video Selector

Equipped with five line inputs and three line outputs, and EDIT buttons for easy tape editing control of two components

AVH-555ES Hi-fi Audio/Video selector (soon to be on sale)


Besides five audio and five video components, a component TV, a graphic equalizer, and a PCM processor can be connected. Remote controllable.



SECTION 2 DISASSEMBLY


2-1. DISASSEMBLY OF CABINET

- 1) Remove the four case screws ①.
- 2) Remove the upper case ② in the direction shown by the arrow A.
- 3) Remove the six screws ③ (BVTT3 x 8), then loosen the two screws ⑤ (BVTT3 x 8).
- 4) Remove the lower case ④ in the direction shown by the arrow B.
- 5) Remove the four screws ⑤, ⑥.
- 6) Remove the four right and left claws of the front panel in the direction shown by the arrow C, then remove the front panel in the direction shown by the arrow D.
- 7) Remove the two screws ⑦ (BVTT3 x 8).
- 8) Remove the JOG DIAL assembly ⑩ in the direction shown by the arrow E.




2-2. REMOVAL OF RP-24 BOARD

- 1) Remove the two screws ① (BVTT3 x 8).
- 2) Remove the RP-24 board block.
- 3) Remove the two shield cases ③ in the direction shown by the arrow.
- 4) Pull out the five connectors ④.




2-3. REMOVAL OF THE SS-53 BOARD

- 1) Remove the four screws ❶ (BVTT3 x 8).
- 2) Remove the SS-53 board in the direction shown by the arrow.




2-4. REMOVAL OF THE VI-10 BOARD

- 1) Remove the four screws ❶ (BVTT3x8).
- 2) Remove the VI-10 board in the direction shown by the arrow.




2.5. REMOVAL OF THE TI-4 BOARD

- 1) Remove the five screws ❶ (BVTT3 x 8).
- 2) Remove the TI-4 board in the direction shown by the arrow.




2.6. REMOVAL OF THE TIMER BLOCK

- 1) Remove the three screws ❶ (BVTT3 x 8).
- 2) Remove the TM-75 board.




2-7. REMOVAL OF THE FR-14 BOARD

- 1) Remove the two screws ① (BVTT3 x 8).
- 2) Remove the claw ③, remove the FP-4 board.
- 3) Remove the claw ⑤, remove the FF-3 board.
- 4) Remove the claw ⑥ of the chassis, pull out the level meter ⑦.
- 5) Remove the FR-14 board in the direction shown by the arrow.




2-8. REMOVAL OF THE POWER BLOCK

- 1) Remove the six screws ① (BVTT3 x 8).
- 2) Pull out the six connectors ②.
- 3) Remove the power block ③.




2-9. REMOVAL OF THE FL CASSETTE COMPARTMENT ASSEMBLY

- 1) Remove the four screws ① (BVTT3 x 8).
- 2) Remove the internal gear flange ②.
- 3) Remove the timing belt ③.
- 4) Remove the FL cassette compartment assembly ④.




2-10. REMOVAL OF THE REEL BLOCK ASSEMBLY

- 1) Remove the four screws ① (B3 x 14).
- 2) Remove the reel block assembly ② in the direction indicated by the arrow.




2-11. INTERNAL VIEWS

— Top Side —




— Bottom Side —





SECTION 3 BLOCK DIAGRAMS

3-1. CIRCUIT BOARDS LOCATION




3.2. VIDEO BLOCK DIAGRAM






3.3. SERVO BLOCK DIAGRAM



SS-53 BOARD

RD-12 BOARD




3-4. TIMING CHART


[CAPSTAN PHASE SYSTEM (REC) TIMING CHART]

	2FG	4FG
βI 360	βI 720	1440 \rightarrow 1/16 \rightarrow 90Hz
βII 180	βII 360	720 \rightarrow 1/8 \rightarrow 90Hz
βIII 120	βIII 240	480 \rightarrow 1/8 \rightarrow 60Hz


βII MODE




[CAPSTAN PHASE SYSTEM (PB) TIMING CHART]




[CAPSTAN SPEED SYSTEM TIMING CHART]




[DRUM PHASE SYSTEM TIMING CHART]




[INSTRUMENTATION COUNTER TIMING CHART]




[FG CIRCUIT TIMING CHART I]




[FG CIRCUIT TIMING CHART II]




[PG-A, B, S TIMING CHART]




[DRUM SPEED SYSTEM TIMING CHART]



[PG-B, (REC/PB) TIMING CHART]



[CTL CIRCUIT TIMING CHART]



[2FG SIGNAL GENERATOR TIMING CHART]

FG (A)

FG (B)

FG (A)
RECTANGLE
WAVE OUT

FG (B)
RECTANGLE
WAVE OUT

IC514 (3)
FG (A)


IC514 (4)
FG (B)

IC513 (4)

D507 (2)


IC514 (10)
FG (B)

IC514 (11)
FG (A)




[8FG SIGNAL GENERATOR TIMING CHART]


IC508 (1)
FG (A)




IC508 (7)
FG (B)




IC518 (1)
FG (B)




IC518 (1)
FG (A) US.
FG (B)




IC518 (7)
FG (A) US.
FG (B)




IC519 (3)
2FG



IC514 (10)
2FG




IC519 (4)
4FG



IC519 (13)




IC519 (11)
8FG




20μs

[HEAD CONTROL TIMING CHART]




*1 β I: 48 pulse β II: 32 pulse

3.5. JOG BLOCK DIAGRAM





SS-5:



SS-53 BOARD

3-6. SYSTEM CONTROL BLOCK DIAGRAM





3-7. SYSTEM CONTROL INTERFACE

[SERVO SYSTEM CONTROL CIRCUIT AND VIDEO BLOCK INTERFACE]

SIGNAL	MODE I/O	PIN No.	STOP	FF	REW	FR SEARCH		PB	PICTURE SEARCH		PB-P	X2	REC	REC-P	A-IN	A-IN-P	V-IN	V-IN-P	AV-IN	AV-IN-P	JOG/SHUTTLE																										
						CUE	REV		CUE	REV											β 1 : L β II : H	RF SWP	β 1 : L β II : H	RF SWP	β 1 : L β II : H	RF SWP	β 1 : L β II : H	RF SWP	β 1 : L β II : H	RF SWP	β 1 : L β II : H	RF SWP	β 1 : L β II : H	RF SWP	β 1 : L β II : H	RF SWP	β 1 : L β II : H	RF SWP									
																																							X1/5	X1	X2	X-1/5	X-1				
PB+DUB	0	CN414-⑨	L	L	L	H	H	H	H	H	H	H	L	L	L	L	L	L	L	L	L	H	H	H	H	H	L	L	L	L	L	L	L	L	L	L	L	L	L								
V REC.P	0	CN414-⑨	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L			
OVER REC	0	CN414-⑨	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L		
V. MUTE	0	CN414-②	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
MC	0	CN414-⑦	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
β 1	0	CN402-③	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
β 1I	0	CN402-④	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
β 1II	0	IC402-⑧	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
β 1I(0)	0	IC414-⑩	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
VD	0	IC803-⑩	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
DOC CONT	0	IC801-②②	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	
DOC CONT2	0	Q803-⑩	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
JOG CONT	0	IC804-⑩	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L

[SYSTEM CONTROL AUDIO BLOCK INTERFACE]

SIGNAL	MODE I/O	PIN No.	STOP	FF	REW	FR SEARCH		PB	PICTURE SEARCH		PB-P	X2	REC	REC-P	A-IN	A-IN-P	V-IN	V-IN-P	AV-IN	AV-IN-P	JOG/SHUTTLE																									
						CUE	REW		CUE	REW											β 1 : L β II : H	RF SWP	β 1 : L β II : H	RF SWP	β 1 : L β II : H	RF SWP	β 1 : L β II : H	RF SWP	β 1 : L β II : H	RF SWP																
																							X1/5	X1	X2	X-1/5	X-1																			
BIAS CONT	0	CN412-②	H	H	H	H	H	H	H	H	H	H	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L		
SLOW	0	CN412-③	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
AUDIO PB	0	FR-14 BOARD IC001-⑦	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
AFM MUTE	0	FR-14 BOARD IC001-⑧	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H
LINE MUTE	0	FR-14 BOARD IC001-⑨	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H
NORMAL CONT	0	FR-14 BOARD IC001-⑩	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H
A-IN	0	FR-14 BOARD IC001-⑪	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
V-IN	0	FR-14 BOARD IC001-⑫	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L

PB	PICTURE SEARCH		PB-P	X2	REC	REC-P	A-IN	A-IN-P	V-IN	V-IN-P	AV-IN	AV-IN-P	JOG/SHUTTLE						LOADING	UNLOADING
	CUE	REV											X1/5	X1	X2	X-1/5	X-1	X-2		
H	H	H	H	H	L	L	H	H	L	L	L	L	H	H	H	H	L	L		
L	L	L	L	L	H	L	L	L	H	L	H	L	L	L	L	L	L	L		
L	L	L	L	L	*1	L	L	L	H	L	L	L	L	L	L	L	L	L		
#2	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L		
L	H	H	H	H	L	L	L	L	L	L	L	L	H	H	H	L	L	L		
#5	#5	#5	#5	#5	#3	#3	#5	#5	#5	#5	#5	#5	#4	#5	#5	#5	#3	#3		
#5	#5	#5	#5	#5	#3	#3	#5	#5	#5	#5	#5	#5	#4	#5	#5	#5	#3	#3		
#5	#5	#5	#5	#5	#3	#3	#5	#5	#5	#5	#5	#5	#4	#5	#5	#5	#3	#3		
#5	#5	#5	#5	#5	#3	#3	#5	#5	#5	#5	#5	#5	#4	#5	#5	#5	#3	#3		
L	V D	V D	V D	V D	L	L	L	L	L	L	L	L	V D	V D	V D	V D	L	L		
H	$\beta I/\beta II$: L βIII : H	$\beta I/\beta II$: L βIII : H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H		
L	L	L	L	L	βI : L $\beta II/\beta III$: H	βI : L $\beta II/\beta III$: H	βI : L $\beta II/\beta III$: H	βI : L $\beta II/\beta III$: H	βI : L $\beta II/\beta III$: H	βI : L $\beta II/\beta III$: H	βI : L $\beta II/\beta III$: H	βI : L $\beta II/\beta III$: H	βI : L $\beta II/\beta III$: H	βI : L $\beta II/\beta III$: H	βI : L $\beta II/\beta III$: H	βI : L $\beta II/\beta III$: H	βI : L $\beta II/\beta III$: H	βI : L $\beta II/\beta III$: H		
L	RF SWP	RF SWP	RF SWP	RF SWP	βI : L $\beta II/\beta III$: H	RF SWP	βI : L $\beta II/\beta III$: H	RF SWP	βI : L $\beta II/\beta III$: H	RF SWP	βI : L $\beta II/\beta III$: H	RF SWP	βI : L $\beta II/\beta III$: H	RF SWP	βI : L $\beta II/\beta III$: H	RF SWP	βI : L $\beta II/\beta III$: H	RF SWP		

*1 "H" for 12 seconds only at REC start.
 *2 "H" when there is no CTL.
 *3 Depends on front β switch.
 *4 Outputs Beta mode identified last time.
 *5 Outputs Beta mode currently being played back.
 *6 βI : "L", βII : "L" only when tape is moving, βIII : "H"
 *7 RF SWP when tape is stopped, "L" when tape is moving.

} Refer to Timing Chart.

PB	PICTURE SEARCH		PB-P	X2	REC	REC-P	A-IN	A-IN-P	V-IN	V-IN-P	AV-IN	AV-IN-P	JOG/SHUTTLE						LOADING	UNLOADING
	CUE	REW											X1/5	X1	X2	X-1/5	X-1	X-2		
H	H	H	H	H	L	L	H	H	L	L	L	L	H	H	H	H	L	L		
L	L	L	L	L	L	L	L	L	H	L	H	L	L	L	L	L	L	L		
H	H	H	H	H	L	L	L	L	H	L	L	L	L	L	L	L	L	L		
H	L	L	L	L	H	H	H	H	H	H	H	H	L	L	L	L	L	L		
L	L	L	L	L	L	L	L	L	H	L	L	L	L	L	L	L	L	L		
L	L	L	L	L	L	L	L	L	H	L	L	L	L	L	L	L	L	L		
L	L	L	L	L	L	L	L	L	H	L	L	L	L	L	L	L	L	L		
L	L	L	L	L	L	L	L	L	H	L	L	L	L	L	L	L	L	L		

[SYSTEM CONTROL AND SLOW MICRO COMPUTER BLOCK INTERFACE]

SIGNAL	MODE	PIN No.	STOP	FF	REW	FR SEARCH		PB	PICTURE SEARCH		PB-P	X2	REC	REC-P	A-IN	A-IN-P	V-IN	V-IN-P	AV-IN	AV-IN-P	JOG/SHUTTLE					
						CUE	REV		CUE	REV											X1/5	X1	X2	X-1/5	X-1	
SLOW	0	IC801-28	L	L	L	L	L	L	L	L	H	L	L	H	L	H	L	H	L	H	H	L	L	L		
CAP FWD	0	IC801-29	H	H	H	H	H	H	H	H	---	H	H	H	H	H	H	H	H	H	H	H	H	L	L	
X2	0	IC801-30	L	L	L	L	L	L	L	L	L	H	L	L	L	L	L	L	L	L	L	L	L	L	L	
TOP/END	0	IC801-31	L	L	H	L	H	L	L	L	---	L	L	---	L	---	L	---	L	---	L	L	L	L	H	
STEP	0	IC801-32	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
MC	0	IC801-33	L	L	L	H	H	L	L	H	H	H	L	L	L	H	L	L	L	L	L	L	H	H	H	
β I	0	IC801-34	*2	*2	*2	*3	*3	*4	*4	*4	*4	*4	*2	*2	*4	*4	*4	*4	*4	*4	*4	*4	*3	*4	*3	*4
β III	0	IC801-35	*2	*2	*2	*3	*3	*4	*4	*4	*4	*4	*2	*2	*4	*4	*4	*4	*4	*4	*4	*4	*3	*4	*3	*4

- * 1 Refer to Slow Servo Timing Chart.
- * 2 Depends on front Beta mode switch.
- * 3 Outputs Beta mode identified the previous time.
- * 4 Outputs Beta mode of tape presently running.

[JOG AND SERVO BLOCK INTERFACE]

SIGNAL	MODE	PIN No.	STOP	FF	REW	FR SEARCH		PB	PICTURE SEARCH		PB-P	X2	REC	REC-P	A-IN	A-IN-P	V-IN	V-IN-P	AV-IN	AV-IN-P	JOG/SHUTTLE					
						CUE	REV		CUE	REV											X1/5	X1	X2	X-1/5	X-1	
TPS	0	IC801-36	L	L	L	L	L	L	L	L	H	L	L	H	L	H	L	H	L	H	H	L	L	L	L	
DRUM CMP	0	IC801-37	H	H	H	H	H	H	H	H	L	H	H	L	H	L	H	L	H	L	L	L	L	L	L	H
D FAST	0	IC801-38	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
D SLOW	0	IC801-39	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H	H
X1 RVS	0	IC801-40	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	H
β II NP	0	IC801-41	<div style="text-align: center;"> β II MODE: "H" </div>																							
β III NP	0	IC801-42	<div style="text-align: center;"> β III MODE: "H" </div>																							
REEL RVS	0	IC801-43	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	H
STEP PLS	0	IC801-44	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
CAP RVS	0	IC801-45	H	H	H	H	H	H	H	H	---	H	H	H	H	H	H	H	H	H	H	H	H	H	H	L

* 1 Refer to Slow Servo Timing Chart.


SYSTEM CONTROL CIRCUIT AND SERVO BLOCK INTERFACE


SIGNAL	MODE I/O	Pin No.	PB	REC	FF	REW	CUE	REV	PB PAUSE	REC PAUSE	LOADING	EJECT	A.INSERT	A.INSERT	コマ送り	逆コマ送り	AV INSERT	AV INSERT PAUSE	V INSERT	V INSERT PAUSE	JOG X 2	JOG 1/5	JOG-X2	JOG->	
																									CTL
VD/CTL	I	IC405-⑬ IC401-⑭	—	CTL	V/D	CTL	CTL	CTL	CTL	—	TAPE RUNS CTL	—	—	CTL	—	CTL	CTL ^{*12}	—	CTL ^{*12}	—	CTL	CTL	CTL	CTL	CTL
HC CONT.	O	IC401-⑫	L ^{*8}	L	H	L	L	L	L	L	L	L	L	L	L	L	L ^{*13}	L	H ^{*13}	L	L	L	L	L	
REC	O	IC401-⑩	L	L	H	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
CAP LOCK	I	IC401-⑫	H	L ^{*1}	L ^{*1}	H	H	L ^{*1}	L ^{*1}	L ^{*1}	H	H	H	L ^{*1}	H	H	L ^{*1}	H	L ^{*1}	H	L ^{*1}	L ^{*1}	L ^{*1}	L ^{*1}	
RF SW PLS ^{*2}	I	IC401-⑬	disappear	appear	appear	appear	appear	appear	appear	appear	appear	disappear	disappear	appear	appear	appear	appear	appear	appear	appear	appear	appear	appear	appear	
TAPE SPEED (A) ^{*1}	O	IC401-⑬																							
TAPE SPEED (B) ^{*1}	O	IC401-⑬																							
TOP/END	O	IC401-⑫	L	L	L	L	H	L	H	PB → PAUSE X1 L X2 L ^{*10}	*9	H	H	L	L	L	L	*9	L	L	L	L	L	H	
DRM STOP	O	IC401-⑫	H	L	L	L	L	L	L	L	L	H	H	L	L	L	L	L	L	L	L	L	L	L	
CAP STOP	O	IC401-⑫	H	L	L	H	H	L	L	L	L	H	H	L	L	L	L	L	L	L	L	L	L	L	
VD INT	O	IC401-⑫	L	H	L	L	L	H	H	H	L	L	L	H	H	H	L	L	L	L	H	H	H	H	
REC PAUSE ^{*1}	O	IC401-⑫	L	L	H ^{*7}	L	L	L	L	L	L	L	L	L	L	L	L ^{*11}	L	L ^{*11}	L	L	L	L	L	
CUE+REV	O	IC401-⑫	L	L	L	L	L	H	H	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
CAP FWD	O	IC401-⑫	H ^{*3}	H ^{*4}	H	H	L	H	L	*6	*6	*5	*5	H	H	H	H	*6	H	H	H	H	H	L	
V/D CTL	I	IC401-⑩	—	CTL	V/D	CTL	CTL	CTL	CTL	—	TAPE RUNS CTL	—	—	CTL	—	CTL ^{*12}	CTL ^{*12}	CTL	CTL ^{*12}	CTL	CTL	CTL	CTL	CTL	
IND WRT	O	IC401-⑩	L	INDEX REC: H L	INDEX REC: H L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
IND ERA	O	IC401-⑩	L	INDEX ERASE: H L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
X2	O	IC401-⑩	L	X2: "H" L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	

REV	PB PAUSE	REC PAUSE	LOADING	EJECT	A.INSERT	A.INSERT	コクタリ	逆コクタリ	AV INSERT	AV INSERT PAUSE	V INSERT	V INSERT PAUSE	JOG X 2	JOG X 1	JOG 1/5	JOG-X2	JOG-X1	JOG-1/5	F/R SEARCH
CTL	CTL	---	TAPE RUNS CTL	---	---	CTL	---	CTL	CTL #12	---	CTL #12	---	CTL	CTL	CTL	CTL	CTL	CTL	CTL
L	L	L	L	L	L	L	L	L	L #13	L	H #13	L	L	L	L	L	L	L	L
L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
L #1	L #1	H	H	H	H	L #1	H	H	L #1	H	L #1	H	L #1	L #1	H	L #1	L #1	H	H
appear	appear	appear	appear	disappear	disappear	appear	appear	appear	appear	appear	appear	appear	appear	appear	appear	appear	appear	appear	appear
L	H	PB PAUSE X1 L #10 X2		L	H	L	L	L	L	#9	L	#9	L	L	L	H	H	H	FWD: "L" RVS: "H"
L	L	L	L	H	H	L	L	L	L	L	L	L	L	L	L	L	L	L	L
L	L	L	L	H	H	L	L	L	L	L	L	L	L	L	L	L	L	L	L
L	L	L	L	H	H	L	L	L	L	L	L	L	L	L	L	L	L	L	H
H	H	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
H	L	#6	#5	#5	#5	H	H	H	H	#6	H	#6	H	H	H	L	L	L	FWD: "H" RVS: "L"
CTL	CTL	---	TAPE RUNS CTL	---	---	CTL	---	CTL	CTL #12	CTL	CTL #12	CTL	CTL	CTL	CTL	CTL	CTL	CTL	CTL
L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L

- * 1 "H" during capstan servo unlocked, "L" locked.
- * 2 30 Hz, 50% duty ratio pulse.
- * 3 3 bit binary coded tape speed.
- * 4 latched output by flip-flop, clock pulses for the flip-flop are RF SW PLS.
- * 5 No use in this mode.
- * 6 "H" when tape runs forward, "L" when tape runs reverse, holds the previous level in stop mode.
- * 7 "L" while counting 15 CTL after record review mode and reverse playback mode, since then "H".
- * 8 INDEX MARK/ERASE when "pulse".
- * 9 "L" during Forward running, "H" during Reverse.
- * 10 "H" during switching between PB and PAUSE, due to (-X1, -X1/5, -X2).
- * 11 Goes to "H" in sync with RF SWP when PB CTL ceases after VIDEO REC start, and after time equivalent to 10 CTL has elapsed.
- * 12 Switches to VD when PB CTL ceases after VIDEO REC start, and after time equivalent to 10 CTL has elapsed.
- * 13 Goes to "H" in sync with the fall of the first CTL IN, when PB CTL ceases after VIDEO REC start, and after time equivalent to 10 CTL has elapsed.


3-8. AUDIO BLOCK DIAGRAM (1)







IC 301
IC 302
IC 303
IC 304


3-9. AUDIO BLOCK DIAGRAM (2)






I-13 BOARD









TM-75 BOARD




3-10. AUDIO LEVEL DIAGRAM
— REC (NORMAL) —




— REC (BETA HI-FI) —







— PB (NORMAL) —




— PB (BETA HI-FI) —




- REC (BETA HI-FI) -





- PB (BETA HI-FI) -




3-12 TUNER-BLOCK DIAGRAM








3-14. REMOTE CONTROL BLOCK DIAGRAM



SECTION 4
SCHEMATIC DIAGRAM, PRINTED WIRING BOARDS


FRAME FRAME

4.1. FRAME SCHEMATIC DIAGRAM 4 5 6 7 8 9 10 11 12 13 14 15 16 17



Note: The components identified by **A** are critical for part number specificity.


15 16 17 18 19 20 21 22 23 24



Note: The components identified by shading and mark **Δ** are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un trame et une marque **Δ** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

VI-10 BOARD




VIDEO VIDEO

Note:
 • All resistors are in ohms, 1/4W unless otherwise noted.
 • All capacitors are in μF unless otherwise noted. P: $\mu P F$
 • All voltages are dc measured with a VOM (10 M Ω).
 • All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

• All capacitors are in μF unless otherwise noted. P: $\mu P F$
 • All voltages are dc measured with a VOM (10 M Ω).
 • All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

• All voltages are dc measured with a VOM (10 M Ω).
 • All variable and adjustable resistors have characteristic curve B, unless otherwise noted.



When indicating parts by reference number, please include the board name.



VIDEO VIDEO

15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30


by refer-
include



CHASSIS (REF)

1	2	3	4	5	6	7	8	9	10
1	2	3	4	5	6	7	8	9	10
1	2	3	4	5	6	7	8	9	10
1	2	3	4	5	6	7	8	9	10
1	2	3	4	5	6	7	8	9	10
1	2	3	4	5	6	7	8	9	10
1	2	3	4	5	6	7	8	9	10
1	2	3	4	5	6	7	8	9	10
1	2	3	4	5	6	7	8	9	10
1	2	3	4	5	6	7	8	9	10


1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17




009	0	8A1
015		
1C,004		
1C,002		
1C,008		
011		
004,006		
005 014		
003 010		
001 007		

RV702	RV701,104	RV301	RV501	RV403	RV502	RV503	RV504
-------	-----------	-------	-------	-------	-------	-------	-------

10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27




ADJ. TP	D. IC	D
RV501	IC901 907 908 906 910 415, 414 502, 501 409 413 658	653 903 904 503
RV403	801	504
RV402, 401	411, 412 509, 607 IC2	501 601, 602
RV503	IC4	657 651
RV502	402, 410 161 405 651 505 653, 652 507 403 510 503	401 202 648 203
RV404	509 508 504 404, 405 110 603 201	101 208, 207
RV504	803, 804 409, 407 109, 103, 103, 104 303 902 904 304	103, 214 901 104 302, 105 301 204 707 709
RV103	711 901, 903 912 204, 202	205 706, 705
RV201	IC3 720 713, 712 710 704 IC1 705 705 709 102 725, 701 205 702 210, 207, 206	704 102 217 703 702, 701 209 205
RV702	715 106	710
RV701, 104	RV203, 207	211
RV301	RV208, 208 301, 724, 716, 722, 721 511, 510 717 107, 108 905	902 212










17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33






ADU-1P	Q, IC	D
	IC901	653
	907	
	908 401 657	
	906	
	910	602
	656, 655	903
		904
RV501	415, 414	503
	502, 501	504
	409	601, 602
	413 658	
RV405	801	
RV402, 401	411, 412 603, 607	
	IC2	
RV303	IC4	
	402, 410 161	657
	406	651
RV502	505	401
	507 403	202
	653, 652	648 203
RV404	510	
	503	
RV504	509 508	
	504 404, 405 110	
	603	101
RV103	803, 804	208, 207
	408, 407 109, 103, 104	103 214
	303	901
	902	104
	304	302 105
		301 204
		707 208
	711	205
	901, 903 912	
	204, 202	
RV201	IC3	706, 705
	720 713, 712	
	IC1	704
	705	
RV702	718	102
	709 102	703
	725, 701	217
	205	102, 701 209
	702	
	210, 201, 206	
RV1, 104	715	
RV203, 207	106	
	714, 709, 707	710
	706, 703	211
RV301		
RV204, 208	301, 724, 716, 722, 721	902
	511, 510	212
	717 107, 108	
	905	



[V1-10 BOARD]



[V1-2 BOARD]







Note:

- : Indicates a leadwire mounted on the component side.
- : Indicates a leadwire mounted on the printed side.
- : soldering side.
- : B + pattern

4.3. SS-53 (SYSTEM CONTROL, SERVO/RD-12 (REEL DETECT)/UD-2 (CHANNEL UP/DOWN COMP) SCHEMATIC DIAGRAMS
 - SS-53 BOARD Ref. No. 2,000 series, RD-12 BOARD Ref. No. 2,100 series, UD-2 BOARD Ref. No. 2,200 series -


1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17

- Notes:**
- All resistors are in ohms, $\frac{1}{4}$ W unless otherwise noted.
 - All capacitors are in μ F unless otherwise noted. P: μ FD 50WV or less are not indicated except for electrolytics.
 - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
 -  : nonflammable resistor.
 - The red lines show the main voltages.
 - All voltages are dc measured with a VOM (10 M Ω).
 -  : B + bus.
 -  : B - bus.
- When indicating parts by reference number, please include the board name.




SERVO, SYSTEM CONTROL SERVO, SYSTEM

11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27



SERVO, SYSTEM CONTROL SERVO, SYSTEM CONTROL


17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33




Note:

- — : Indicates a leadwire mounted on the component side.
- — : Indicates a leadwire mounted on the printed side.
- ▨ : B + pattern soldering side.
- ▩ : B + pattern soldering side.
- ▧ : component-side.





Q.I.C	0	ADJ. TP
708	902	ADJ. TP
901, 906	901	526, 702, 201
IC302	902	RN517
IC309	903	901, 525
IC310	904	RN504
IC311	905	RN505, RN506
IC312	906	RN507
IC313	907	RN508, RN509
IC314	908	RN510, RN511
IC315	909	RN512
IC316	910	RN513, RN514
IC317	911	RN515
IC318	912	RN516
IC319	913	RN517
IC320	914	RN518
IC321	915	RN519
IC322	916	RN520
IC323	917	RN521
IC324	918	RN522
IC325	919	RN523
IC326	920	RN524
IC327	921	RN525
IC328	922	RN526
IC329	923	RN527
IC330	924	RN528
IC331	925	RN529
IC332	926	RN530
IC333	927	RN531
IC334	928	RN532
IC335	929	RN533
IC336	930	RN534
IC337	931	RN535
IC338	932	RN536
IC339	933	RN537
IC340	934	RN538
IC341	935	RN539
IC342	936	RN540
IC343	937	RN541
IC344	938	RN542
IC345	939	RN543
IC346	940	RN544
IC347	941	RN545
IC348	942	RN546
IC349	943	RN547
IC350	944	RN548
IC351	945	RN549
IC352	946	RN550
IC353	947	RN551
IC354	948	RN552
IC355	949	RN553
IC356	950	RN554
IC357	951	RN555
IC358	952	RN556
IC359	953	RN557
IC360	954	RN558
IC361	955	RN559
IC362	956	RN560
IC363	957	RN561
IC364	958	RN562
IC365	959	RN563
IC366	960	RN564
IC367	961	RN565
IC368	962	RN566
IC369	963	RN567
IC370	964	RN568
IC371	965	RN569
IC372	966	RN570
IC373	967	RN571
IC374	968	RN572
IC375	969	RN573
IC376	970	RN574
IC377	971	RN575
IC378	972	RN576
IC379	973	RN577
IC380	974	RN578
IC381	975	RN579
IC382	976	RN580
IC383	977	RN581
IC384	978	RN582
IC385	979	RN583
IC386	980	RN584
IC387	981	RN585
IC388	982	RN586
IC389	983	RN587
IC390	984	RN588
IC391	985	RN589
IC392	986	RN590
IC393	987	RN591
IC394	988	RN592
IC395	989	RN593
IC396	990	RN594
IC397	991	RN595
IC398	992	RN596
IC399	993	RN597
IC400	994	RN598
IC401	995	RN599
IC402	996	RN600
IC403	997	RN601
IC404	998	RN602
IC405	999	RN603
IC406	1000	RN604







9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26



ISS-53 BOARD



17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33



J I H G F E D C B A

SERVO, SYSTEM CONTROL

SS-53 (SYSTEM CONTROL, SERVO)/RD-12 (REL DETECT)/UD-2 (CHANNEL UP/DOWN COMP/LM-8 (LOADING MOTOR) SCHEMATIC DIAGRAMS
- SS-53 BOARD Ref. No. 2,000 series, RD-12 BOARD Ref. No. 2,100 series, UD-2 BOARD Ref. No. 2,200 series, LM-8 BOARD Ref. No. 9,100 series -


1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17

- Note:
- All resistors are in ohms, $\frac{1}{4}$ W unless otherwise noted.
 - K Ω : 1000 Ω , M Ω : 1000 K Ω
 - All capacitors are in μ F unless otherwise noted. p: pF
 - 50WV or less are not indicated except for electrolytics.
 - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
 - **FR**: nonflammable resistor.
 - The red lines show the main voltages.
 - All voltages are dc measured with a VOM (10 M Ω).
 - **8+**: 8+ bus.
 - **8-**: 8- bus.

Note: The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un trame et une marque **A** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.


When indicating parts by reference number, please include the board name.




SERVO, SYSTEM CONTROL

SERVO, SYSTEM CONTI


9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25





SERVO, SYSTEM CONTROL SERVO, SYSTEM CONTROL



SERVO, SYSTEM CONTROL SERVO, SYSTEM CONTROL




1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15




- Note:
- — Indicates a leadwire mounted on the component side.
 - — Indicates a leadwire mounted on the printed side.
 - ⊙ — Soldering side.
 - ⊙ — B+ pattern.
 - ⊙ — Component side.



Q.I.C.	D	ADJ. TP
708	902	526 501 702 801
901 906 IC 902 IC 909	709 710 IC 906 IC 906	RV517 902
903 903 IC 904 530 IC 901	424 423 IC 809 IC 801	901 525 RV901 RV505 RV603 RV506 525
905	IC 517 424 425	RV507 RV508/RV909
907 904	801 802	
521	IC 805 IC 403	RV902 RV901 RV907 RV905 RV902 RV904 RV905 RV906
IC 501	IC 805 IC 403	RV916 RV915 RV915 RV914
525 527 525	IC 403	RV916 RV915 RV915 RV914
IC 501	419 426 420 423 501 412 415	RV916 RV915 RV915 RV914
501	IC 513 IC 511 IC 507 516	509 510 512
503	523 524 702 701 322 533 IC 401	506 505 RV512 511 507 513 514
IC 312	IC 701 405 408 409 404 407 427	508
IC 510	505	524 RV511 RV910
IC 510	IC 514 422 702 704 421	
IC 502	IC 514 515 IC 405 513 IC 402 410	515 407 407 407 407
509	510 515	RV504 517 510 516 516
IC 319	517 414 413 418 416	RV516 515
IC 316	IC 503 403 508 406 402	RV515
505 528	IC 404 405 402 411	
Q.I.C.	D	ADJ. TP




10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26



[SS-53 BOARD]





-141-

-142-

-143-

AUDIO, TUNER AUDIO, TUNER

4.4. AU-13 (AUDIO)/TI-4 (SOUND MULTIPLEX) SCHEMATIC DIAGRAMS
 - AU-13 BOARD Ref. No. 3,000 series, TI-4 BOARD Ref. No. 4,000 series -


1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17

- Note:**
- All resistors are in ohms, 1/2 W unless otherwise noted.
 - K Ω : 1000 Ω , M Ω : 1000 K Ω
 - All capacitors are in μ F unless otherwise noted. P: μ F 50WV or less are not indicated except for electrolytics.
 - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
 - : nonflammable resistor.
 - The red lines show the main voltages.
 - All voltages are dc measured with a VOM (110 M Ω).
 - : B+ bus.
 - : B- bus.

Note: The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.


Note: Les composants identifiés par un trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.





AUDIO, TUNER AUDIO, TUNER

7 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33




AU-13 (AUDIO)/T1-4 (SOUND MULTIPLEX) PRINTED WIRING BOARDS
 - AU-13 BOARD Ref. No. 3,000 series, T1-4 BOARD Ref. No. 4,000 series -

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17





Q, IC	D	A0, TP
701	304	701
702	303	701
704	301	302
602, 601	305	RVN02
801, 115, 116	109	RVN04
703	108	RVN04
IC602	109	RVN04
IC101	113	103
IC103	110, 109	104
104	104	RVN01
108, 107	105	RVN01
401, 402, IC401, 406	105	RVN01
Q, IC	D	A0, TP

NO MARK, PB MODE
 1. REC. MODE
 2. PRINTER MODE





AUDIO, TUNER AUDIO, TUNER

10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27



Q, IC	D	ADJ. TP
701	304	701
702	303	701
IC601	704	301
602	501	302
	305	
IC602	703	706
		705
		303
		RV104
		103
		104
IC103	110, 109	114
	103	103
	104	104
	111, 101	101
	108, 107	102
	105	105
		RV101
401, 402, IC401	106	
		ADJ. TP




Q, IC	D	ADJ. TP
301	301	
302	302	
304	304	
305	305	
870	870	
805	805	
804	804	
IC801	108	902
107	107	801
205	205	
206	206	
202	202	
IC201	201	103
		105
		106
		IC202
		IC203
		RV101
		RV202
		RV804
		RV805
		RV803
		RV801
		RV906
		RV832, RV201
		RV831


AUDIO, TUNER AUDIO, TUNER

AUDIO, TUNER

7 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33



[T1-4 BOARD]



Q	301	302	304	305	670	805	803	803	804	203	IC801	802	801	105	IC102	102	IC104
IC	109	101	104	671	IC670	208	209	205	206	202	IC201	106	103	832	833	101	105
0	303	302	301	103	103	RV101	RV202	RV804	RV805	RV803	RV806	RV801	RV831	RV832	RV201	RV830	RV1
ADJ	104	104															

Note:
 ○ : Indicates a leadwire mounted on the component side.
 ● : Indicates a leadwire mounted on the printed side.
 ● : soldering side.
 ● : B+ pattern
 ● : B- pattern





J

AUDIO AUDIO


4.5. AF-9 (AFM SIGNAL REC/P8 PROCESS) SCHEMATIC DIAGRAMS

— AF-9 BOARD Ref. No. 8,000 series —


1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17

- Note:
- All resistors are in ohms, $\frac{1}{2}W$ unless otherwise noted.
 - K Ω : 1000 Ω , M Ω : 1000 K Ω
 - All capacitors are in μF unless otherwise noted. p: pF
 - 50WV or less are not indicated except for electrolytics.
 - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
 -  : nonflammable resistor.
 -  : fusible resistor.
 - The red lines show the main voltages.
 - All voltages are dc measured with a VOM (10 M Ω).
 -  : B+ bus.
 -  : B- bus.

When indicating parts by reference number, please include the board name.





AF-9 BOARD



AUDIO AUDIO

18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33




A B C D E F G H I J


AUDIO AUDIO

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17

[AF-9 BOARD]

Q	IC601	601	IC602	IC604	IC607	104	101	102	103	IC001
Q	603	IC608	IC607	IC605	IC606	IC207	201	202	203	IC001
Q	604	301	IC301	302	606	404	402	401	403	IC002
IC	101	IC301	302	608	610, 611	609	607, 605, 615, 503, 504	505	504	IC501
D	103	102	301	302	609	610	603	408	505	IC502
D	103	102	301	302	609	610	603	408	505	IC000






- All resistors are in ohms, 1/4W unli
- K31: 1000 Ω, MΩ: 1000 KΩ
- All capacitors are in μF unless othe
- 50WV or less are not indicated exp
- All variable and adjustable resistors
- curve B, unless otherwise noted.


TIMER TIMER

IRD Ref. No. 5,600 series — 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30


- Notes:**
- All resistors are in ohms, 1/4 W unless otherwise noted.
 - All capacitors are in μF unless otherwise noted. p: pF
 - 50WV or less are not indicated except for electrolytics.
 - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
 - The red lines show the main voltages.
 - All voltages are dc measured with a VOM (10 M Ω).
 - — : B+ bus.
 - — : B- bus.




TM-75 BOARD







When indicating parts by reference number, please include the board name.








1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17




- Note:
- : Indicates a leadwire mounted on the component side.
 - : Indicates a leadwire mounted on the printed side.
 - : soldering side.
 - ⋄ : component side.
 - ⋅ : B + pattern
 - ⊙ : B - pattern



TIMER TIMER





- Note:
- All resistors are in ohms, $\frac{1}{2}$ W unless otherwise noted. k Ω : 1000 Ω , M Ω : 1000 k Ω
 - All capacitors are in μ F unless otherwise noted. p: μ F
 - 50WV or less are not indicated except for electrolytics.
 - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
 - \square : fusible resistor.
 - The red lines show the main voltages.
 - All voltages are dc measured with a VOM (10 M Ω).
 - --- : B+ bus.
 - --- : B- bus.

Note: The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

POWER POWER

15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30

Y101 (HEU)	10	10	10
AC 3.8V	10V	10V	10V
AC 3.8V	10V	10V	10V
AC 3.8V	10V	10V	10V
POWER CONT	10V	10V	10V
5V	10V	10V	10V
5V	10V	10V	10V
GND	10V	10V	10V


Y102 (LWMT)	10	10	10
5V	10V	10V	10V
5V	10V	10V	10V
5V	10V	10V	10V
GND	10V	10V	10V
GND	10V	10V	10V
GND	10V	10V	10V

Y104 (LWMT)	10	10	10
5V	10V	10V	10V
5V	10V	10V	10V
5V	10V	10V	10V
GND	10V	10V	10V
GND	10V	10V	10V
GND	10V	10V	10V

Y106 (YECL)	10	10	10
5V	10V	10V	10V
5V	10V	10V	10V
5V	10V	10V	10V
GND	10V	10V	10V
GND	10V	10V	10V
GND	10V	10V	10V


Y105 (HEU)	10	10	10
5V	10V	10V	10V
5V	10V	10V	10V
5V	10V	10V	10V
GND	10V	10V	10V
GND	10V	10V	10V
GND	10V	10V	10V

Q, IC	Q
002	016, 018, 005, 001, 017
	014
	015
	019
IC001	
IC002, IC003	
IC004	
Q, IC	0




8. SEMICONDUCTORS

A4558
6218P
JM4558D
JM4560D
PC358C
PC383C
CC4558C




CX20039
CX894
LA7205
NUM4560S

X1013
X1090
X3978
X3983




CX20073
CX7982
CX7982A
CXK1001P
HD14066BP
NUM2901N
TC4001BP
TC4011BP
TC4013BP
TC4030BP
TC4066BP
TC4071BP
TC4081BP
μPC324C
μPC339C
μPD40118C

X194B-0
X194B-5
X20097A
X20097
X10021B-NP




EWA129
HD14053BP
MB3759
MB84052B
MB84053B
SN74LS138N
TC40H138P
TC4049BP
TC4051BP
TC4052BP
TC4053BP
TC4538BP
TL494CN
μPD4051BC
μPD4051BP
μPS4053BC

X20014A
X20043
X20069
X20104
X862
X863
X866B



MB8851H-572L
MB88525B-125M

CX20061
MS201L
MS230L




LA7048
MS076-690P


CX20061
MS201L
MS230L




MSL915RS




ME0763-632SP




MS4543L



MB8851-155M




NJM78M05A




NJM79L12A




SI3052V




2SA1175
2SC2785
2SC2785-F




STK5441A




μPC78M12H




LM6417E-577




2SA933S
2SC1740S
2SC2001
2SD786




2SC2673




2SD1146




2SB733
2SD734
2SD773
2SD774




2SB740
2SD788



2SK381




2SB772



1SS119
1SS133
1SS148




10E2
11E2




2SK118




2SK118




2SK118




2SK118




1SS106
EQA02-05F
EQA02-06A
EQA02-06B
EQA02-06D5
EQA02-08B
EQA02-09A
EQA02-10A
H210E-B2
H233E-B2
H25.6EB1
H25.6EB2
H25.6EB3
H26C2
H27A3L
H28.2EB1
H29.1EB1
RD33E-B
RD33E-B2
RD33E-B3
RD5.1E-B3
RD5.1E-L1
RD5.6E-B
RD6.2E-B
RD7.5E-B
RD8.2EB1
RD9.1E-B1




10E2
11E2




2SK118




2SK118




2SK118




2SK118



MC931




DSB10
DSRB20




GP2S02B
NLS141E




SG206D
SR606D
SY406D



TLG123A
TLR123
TLV123




SEL1413E



MC921

4-9. UHF/VHF TUNER SCHEMATIC DIAGRAM
 — BT-893 —



0101-104, 155, 162, 163 1T 42
 0105 1S599
 0107, 164-175 1S5162
 0151-154, 156-161 1T 33
 0176-182 1S5119
 0183 89S, 2E82

- C299 0.002
- C251 50
- CA
- C298 0.002
- A6C
- +5V
- +9V
- 19V
- 1K
- 1AT
- 11N
- +30V

SECTION 5

EXPLODED VIEWS


NOTE:

- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

5-1. FRONT PANEL AND CABINET ASSEMBLES




No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
1	3-691-733-01	CASE, UPPER		24	*X-3691-608-1	HOLDER ASSY, DAMPER	
2	3-703-713-41	STICKER, SONY SYMBOL (10)		25	3-701-437-21	WASHER	
3	3-684-184-31	PLATE, TRANSPARENT		26	3-691-641-01	GEAR, DAMPER	
4	4-886-821-01	SCREW, M3 CASE		27	3-676-638-00	DAMPER, CASSETTE COMPARTMENT	
5	*3-691-734-01	PLATE, BOTTOM		28	3-691-635-01	SPACER, SHUTTLE	
6	X-3691-656-1	PANEL ASSE, FRONT		29	3-691-647-01	BRACKET	
7	3-691-701-01	BUTTON, NEXT		30	X-3691-621-1	PANEL (F) ASSY, JOG	
8	X-3684-146-2	LID ASSY, PRESET (CANADIAN MODEL ONLY)		31	X-3691-622-1	PANEL (R) ASSY, JOG	
9	3-684-339-11	KNOB, HP		33	3-320-412-01	WASHER (1.4), SPECIAL	
10	X-3691-650-1	DOOR ASSY, FRONT		34	*3-691-657-01	PLATE, LOCK	
11	X-3691-615-1	PLATE ASSY, DIAL, SHUTTLE		35	X-3691-610-1	BUTTON ASSY, REW	
12	3-691-640-01	GEAR (R), JOG		36	X-3691-611-1	BUTTON ASSY, PLAY	
13	3-691-642-01	GEAR (A), LIMITER		37	X-3691-612-1	BUTTON ASSY, FF	
14	3-691-664-01	GEAR (B), LIMITER		38	3-691-670-01	BUTTON, STOP	
15	3-691-634-01	SPRING, TORSION		39	X-3691-613-1	BUTTON ASSY, PAUSE	
16	3-691-632-02	DIAL, SHUTTLE		40	3-701-439-21	WASHER (3)	
17	X-3691-607-1	HINGE (R) ASSY		41	3-669-465-01	WASHER (1.5), STOPPER	
18	3-576-098-00	SPRING, COMPRESSION		42	3-691-690-01	PUSH BUTTON	
19	4-812-499-XX	SPRING		43	X-3691-604-1	DIAL (F) ASSY, JOG	
20	X-3691-609-1	PANEL ASSY, SUB FRONT		44	3-691-648-01	ROLLER	
21	X-3691-605-1	PLATE ASSY, SLIDE		45	3-701-437-11	WASHER	
22	3-691-699-01	HINGE (F)					
23	X-3691-623-3	DIAL (R) ASSY, JOG					

5-2. TUNER, TIMER AND POWER ASSEMBLES


The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.




No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
50	X-3691-651-1	KEY ASSY, SHEET		75	2-291-041-00	BUTTON (A), PRESET	
51	*3-691-724-11	PANEL, POWER		76	1-507-242-11	UV-ANT/PAR-SS	
52	*3-691-779-01	LABEL, MODEL NUMBER (US MODEL)		77	*3-691-783-01	PANAL ASSY, PRESET	
53	*3-691-780-01	LABEL, MODEL NUMBER (CANADIAN MODEL)		78	3-670-155-11	LEG	
54	3-684-366-11	SCREW (M3X6) (G), WH TAPPING		79	3-691-764-01	KNOB (B), SELECTION SWITCH	
55	3-691-730-11	PANEL (LOWER), REAR		80	Δ 2-231-019-01	CHAMFER, CORD	
56	Δ 1-456-905-00	CORD, POWER		81	*X-3676-444-0	LID ASSY, REAR, SHIELD CASE, MA	
57	Δ 1-526-982-00	OUTLET, 240		82	*X-3676-443-0	CASE ASSY, SHIELD, MA	
58	Δ 1-448-225-11	TRANSFORMER, POWER (T901)		83	*3-691-759-01	LID, SHIELD CASE (1), AU	
59	*1-614-951-13	PT-48 BOARD		84	3-691-611-01	KNOB (S), CONTROL	
60	*A-6722-270-A	PC-19 BOARD, COMPLETE		85	3-691-696-01	KNOB (L), CONTROL	
61	*1-614-950-13	PR-6 BOARD		86	1-520-478-11	METER, LEVEL (LED)	
62	*1-614-954-13	PV-1 BOARD		87	3-691-784-01	COLLAR, KNOB, CONTROL	
63	*1-614-948-13	PI-2 BOARD		88	3-670-148-11	KEY (P), SLIDE	
64	*1-614-952-13	PA-4 BOARD		89	3-682-691-00	NUT, WASHER HEXAGON	
65	*1-614-946-13	HP-12 BOARD		90	*3-684-367-01	HINGE, PCB	
66	*1-614-947-13	FP-4 BOARD		91	3-684-413-11	KNOB, CONTROL	
67	*A-6717-398-A	FR-14 BOARD, COMPLETE		92	*3-691-753-02	LID, SHIELD CASE, RP	
68	*A-6724-440-A	TM-75 BOARD, COMPLETE		93	*3-691-754-02	LID, REAR, SHIELD CASE, RP	
69	*A-6711-614-A	VI-10 BOARD, COMPLETE		94	*A-6711-644-A	RP-24 BOARD, COMPLETE	
70	*A-6725-402-A	AF-9 BOARD, COMPLETE		95	*3-684-436-01	PLATE, MOUNT	
71	*A-6715-264-A	SS-53 BOARD, COMPLETE		96	3-691-771-01	SHEET, INSULATING	
72	*A-6713-226-A	AU-13 BOARD, COMPLETE		97	2-832-007-00	BUSHING (K), INSULATING	
73	*A-6722-256-A	PS-65 BOARD		98	*3-684-363-01	PLATE, BLIND	
74	*A-6721-234-A	COMPLETE PCB, T1-4		99	*3-682-024-00	SHEET (A), INSULATING	

5.3. FRONT LOADING ASSEMBLY




No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
101	*A-6751-253-A	THREADING BLOCK ASSY, FRONT		112	X-3684-116-1	SHAFT ASSY, MIDWAY GEAR	
102	*X-3684-117-1	PLATE ASSY, SIDE, BASE (LEFT)		113	*3-684-166-01	ARM (LEFT), DRIVING	
103	3-684-258-01	SPRING, TENSION		114	X-3684-123-1	GEAR ASSY, DRIVING	
104	X-3684-125-1	RETAINER (LEFT) ASSY, CASSETTE		115	1-554-840-11	SWITCH, LEAF (S904)	
105	*X-3684-118-1	PLATE ASSY, SIDE, RIGHT		117	3-684-111-01	GEAR (B), LIMITER	
106	*3-684-108-01	ARM, LID OPEN		118	3-684-115-01	SPRING	
107	X-3684-124-1	RETAINER (RIGHT) ASSY, CASSETTE		119	3-684-109-01	GEAR (A), LIMITER	
108	3-679-123-00	SHAFT, GEAR, WORM		120	3-684-163-01	GEAR, DRIVING ARM	
109	3-684-164-01	GEAR, WORM		121	3-684-165-01	ARM (RIGHT), DRIVING	
110	*3-684-195-11	PLATE, TOP		122	3-684-162-01	ARM, SWITCHING, DOOR	
111	X-3691-652-1	DOOR ASSY					

5-4. CAHSSIS ASSEMBLY 1




The components identified by shading and mark **▲** are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque **▲** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.




No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
151	3-684-264-01	BELT, TIMING		173	*3-669-613-00	INSULATOR, L MOTOR	
152	3-684-152-01	FLANGE, INTERNAL GEAR		174	3-669-318-00	NUT, ADJUSTMENT, GUIDE	
153	3-683-454-01	WASHER, POLYETHYLENE		175	3-684-135-01	WASHER (UPPER), GUIDE, #7.8	
154	3-684-178-01	GEAR, INTERNAL		176	3-684-133-01	SLEEVE, GUIDE, #7.8	
155	3-679-104-05	GEAR		178	3-669-317-00	SPRING, COMPRESSION	
156	X-3679-111-0	CARRIER ASSY		179	X-3684-109-1	ARM ASSY, PINCH SOLENOID	
157	3-669-465-00	WASHER (1.5), STOPPER		180	3-669-595-00	WASHER (2), STOPPER	
158	A-6740-083-B	GEAR ASSY		181	*X-3684-112-1	ARM ASSY, PINCH LIMITER	
159	3-681-231-00	SCREW (+PW 2.6X8), TAPPING		182	3-515-170-00	SPRING, TENSION	
161	3-679-115-00	GEAR (LARGE), LOADING		183	▲ 1-454-393-11	SOLENOID, PLUNGER (PM901)	
162	3-669-480-11	+ PTPNH 2		184	3-669-607-31	+PSW (SMALL ROUND) (2.6)	
163	3-684-167-01	ARM, STOPPER		185	1-464-329-21	SENSOR, T COIL (L902)	
164	3-684-227-01	SPRING, TENSION		186	*3-684-119-01	LINK, TAKE-UP SENSOR	
165	3-684-116-01	LIMITER, STOPPER		187	3-684-157-04	SPRING (T SENSOR), TENSION	
166	X-3684-129-1	CHASSIS ASSY, PLANET GEAR		188	3-669-596-00	WASHER (2.3), STOPPER	
168	X-3669-321-0	GEAR (C) ASSY		189	X-3684-113-1	ARM ASSY, PINCH PRESS	
169	3-679-114-00	GEAR (SMALL), LOADING		190	*X-3691-602-1	LEVER ASSY (M), COMMUNICATION	
170	X-3679-268-1	MOTOR ASSY, L (M904)		191	X-3691-648-1	ARM ASSY (B), REVIEW BRAKE	
172	*1-605-071-00	LM-8 BOARD		192	3-681-154-00	SPRING, TORSION	

5-5. CHASSIS ASSEMBLY 2



No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
201	3-669-480-11	+ PTPMH 2		226	*X-3669-429-0	HOLDER BLOCK ASSY, #2 GUIDE	
202	*3-684-158-01	PLATE, GROUND, TAPE GUIDE		227	3-684-161-01	SPRING (S SENSOR), TENSION	
203	*3-669-618-00	PLATE (2), ADJUST		228	1-464-330-21	SENSOR, S COIL	
204	*3-672-507-00	PLATE (3-1), ADJUSTMENT		229	3-669-607-00	+PSW (SMALL ROUND) 2.6	
205	3-669-466-21	SCREW (M 2.6)		230	*X-3669-329-0	PLATE ASSY, ADJUSTMENT	
206	3-684-217-04	GUIDE (2), SHUTTLE		231	3-669-360-00	ROLLER, RING	
207	*3-679-290-00	GUIDE (1-YA), SHUTTLE		232	3-669-476-04	PLATE, GUIDE	
208	*X-3679-263-1	BASE ASSY, SLANT		233	1-554-840-11	SWITCH, LEAF (S903)	
209	3-669-446-00	NUT, GUIDE, NO. 6		234	*X-3684-130-1	ARM ASSY, LOCK	
210	3-679-910-00	FLANGE (S), GUIDE, NUMBER 6		235	3-669-465-00	WASHER (1.5), STOPPER	
211	3-669-445-00	SPACER, GUIDE, NO. 6		236	3-669-630-00	ROLLER (C), RING	
212	3-669-615-00	SPRING, COMPRESSION		237	3-669-597-00	ROLLER (B), RING	
213	3-669-606-00	SCREW (2.6)		238	3-669-596-00	WASHER (2.3), STOPPER	
214	8-825-508-11	HEAD, FE		239	X-3691-646-1	ARM ASSY, PINCH ROLLER	
215	A-6750-158-B	SHUTTLE (2) BLOCK ASSY		240	3-683-441-01	SPRING	
218	X-3679-150-0	RING (YA) ASSY, S LOADING		241	3-676-649-11	ROLLER (#9), GUIDE	
219	*3-669-616-00	RETAINER		242	3-676-650-00	FLANGE (UPPER) (#9), GUIDE	
220	*X-3669-430-0	HOLDER BLOCK ASSY, #3 GUIDE		243	3-672-559-00	SLEEVE, GUIDE	
221	3-669-478-00	SCREW (1X3), TAPPING		244	3-672-558-00	FLANGE (LOWER) (#9), GUIDE	
222	3-669-479-11	SCREW (1.4X3.5), TAPPING		245	3-669-452-00	SPRING, COMPRESSION	
223	*3-669-472-02	RETAINER, SPRING, LEAF		246	A-6750-165-A	GEAR ASSY, SLIDER	
224	3-672-583-00	SPRING		247	*X-3679-265-1	SLIDER ASSY (2), T	
225	3-672-586-00	SCREW (1.4X3), TAPPING		248	3-549-014-00	SPRING, TENSION	

5-6. DRUM ASSEMBLY




No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
251	A-6050-320-A	DRUM ASSY (DSH-57A-R)		273	3-679-362-00	SCREW (M2X4), PAN	
252	A-6760-066-B	SPRING ASSY, TAPE RETAINER		274	3-669-595-00	WASHER (2), STOPPER	
253	A-6060-138-A	DRUM ASSY, UPPER		275	X-3679-147-0	CHASSIS (B) ASSY, DRIVE GEAR	
254	3-669-157-00	BOLT (WASHER) (2.6X8)		276	X-3679-148-0	GEAR (F) ASSY (D)	
255	A-6762-208-A	DISK ASSY (DSR-57-R)		277	3-669-338-00	GEAR (E)	
256	X-3669-105-0	SPACER BLOCK ASSY		278	3-669-337-00	GEAR (D)	
257	X-2621-204-3	STATOR ASSY, D		279	3-669-465-00	WASHER (1.5), STOPPER	
258	X-2621-202-2	ROTOR ASSY, D		280	8-838-068-01	MOTDR, DC (BHF-1909B) (M902)	
259	3-669-646-00	SPACER, DRUM		281	3-669-600-11	WASHER, FLAT (3.5)	
260	3-669-646-11	SPACER, DRUM		282	3-429-123-00	SPRING	
261	*X-3691-620-1	CHASSIS ASSY, MECHANICAL		283	3-669-302-00	SCREW, FITTING	
262	3-683-483-01	PROTECTOR (M)		284	*3-669-477-00	LINER, LINK, PIN	
263	A-6761-083-A	ACE ASSY		285	3-684-382-01	PROTECTOR (B)	
271	*3-669-541-00	SLOPE (RIGHT)					

5-7. REEL BLOCK ASSEMBLY

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque **A** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.



No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
301	3-669-596-00	WASHER (2.3), STOPPER		320	A 1-454-397-11	SOLENOID, PLUNGER	
302	A-6759-074-A	ARM BLOCK ASSY, PENDULUM		321	1-554-839-11	SWITCH, LEAF (2 GANG) (S901)	
303	3-679-318-00	WASHER, PENDULUM ARM		322	*X-3691-643-1	CHASSIS ASSY, SUB	
304	X-2622-201-0	ROTOR ASSY, R		323	3-691-775-01	SPRING, TENSION	
305	*A-4910-049-A	R STATOR (REEL MOTOR) BOARD, COMPLETE (M903)		324	3-691-776-01	SPRING, TENSION	
306	X-3684-121-1	LEVER ASSY, TENSION REGULATOR		325	*3-691-728-01	LEVER, RD	
307	3-679-151-00	SPRING		326	3-691-680-01	WASHER, STOPPER	
308	*1-614-964-11	RD-12 BOARD		327	3-691-606-01	RING, UD	
309	X-3691-642-1	BAND ASSY, TENSION REGULATOR		328	*3-691-681-01	SHAFT, ARM, UD	
310	3-684-192-01	ARM, BRAKE, SUPPLY SOFT		329	3-679-379-11	SPACER, PENDULUM	
311	3-684-235-01	SPRING, TENSION		330	3-307-313-00	PLATE, YOKE	
312	X-3684-137-1	BRAKE ASSY, T SOFT		331	3-691-787-01	SPRING, COMPRESSION	
313	X-3691-649-1	BRAKE ASSY (B), SUPPLY		332	*3-691-608-01	LIMITER, PL	
314	3-701-748-00	CLAMP		333	*3-691-607-01	FLANGE, PL	
315	X-3684-108-1	BRAKE ASSY, TAKE-UP		334	3-691-786-01	SPRING, TENSION	
316	X-3691-626-1	TABLE ASSY, REEL, TAKE-UP		335	*3-691-694-01	LEVER, LIMITER	
317	3-684-193-01	ARM, PENDULUM STOPPER		336	*X-3691-601-3	ARM ASSY, RD	
318	*3-684-183-01	LINK, L		337	X-3691-627-1	TABLE ASSY, REEL, SUPPLY	
319	A 1-454-396-11	SOLENOID, PLUNGER (PM902)		338	3-682-683-00	BALANCER, PENDULUM	

5-8. HARDWARE LIST

SCREW

7-621-770-87 SCREW +P 2.6X5
7-621-559-30 SCREW +K 2.6X5
7-621-591-00 SCREW +K 2X4
7-621-772-20 SCREW +B 2X5
7-627-551-08 SCREW, PRECISION +P 1.4X1.6

7-627-551-28 SCREW, PRECISION +P 1.4X2.5
7-627-552-38 SCREW, PRECISION +P 1.7X3
7-628-253-15 SCREW +PS 2X5
7-628-253-95 SCREW +PS 2.6X4
7-682-549-04 SCREW +P 3X10

7-682-949-01 SCREW +PSW 3X10
7-685-133-14 SCREW +P 2.6X6 TYPE1
7-685-134-14 SCREW +P 2.6X8 TYPE2 NON-SLIT
7-685-135-14 SCREW +P 2.6X10 TYPE2 NON-SLIT
7-685-645-71 SCREW +BVTP 3X6 TYPE2 IT-3

7-685-645-81 SCREW +BVTP 3X6 TYPE2
7-685-646-71 SCREW +BVTP 3X8 TYPE2 IT-3
7-685-646-79 SCREW +BVTP 3X8 TYPE2 IT-3
7-685-646-81 SCREW +BVTP 3X8 TYPE2
7-685-646-89 SCREW +BVTP 3X8 TYPE2

7-685-649-71 SCREW +BVTP 3X14 TYPE2 IT-3
7-685-649-81 SCREW +BVTP 3X14 TYPE2
7-685-791-04 SCREW +PTT 2.6X5 (S)
7-685-791-04 SCREW +BVTT 2.6X5 (S)
7-685-862-01 SCREW +BVTT 2.6X6 (S)

SET-SCREW

7-621-712-26 SET-SCREW, SLOT 2.6X3FLAT POINT
7-621-712-35 SET-SCREW, SLOT 2.6X4CONE POINT
7-621-712-46 SET-SCREW, SLOT 2.6X5FLAT POINT
7-621-731-08 SET-SCT, HEX. 2X2.5, FLAT POINT
7-621-732-08 SET-SCT, HEX. 2X3 FLAT POINT

+PSW

7-621-759-35 +PSW, 2.6X5
7-621-759-45 +PSW, 2.6X6
7-621-759-65 +PSW, 2.6X8

NUT

7-622-205-05 NUT M2 TYPE2

RING

7-624-101-01 RING, RETAINING E-1.2
7-624-102-04 STOP RING 1.5, TYPE -E
7-624-105-04 STOP RING 2.3, TYPE -E
7-624-118-01 RING, RETAINING E-2.5
7-624-190-61 STOP RING 2.4, TYPE-CS

TAPPING

7-685-105-14 TPG +P 2X8, TYPE 2, NON-SLIT

WASHER

7-688-001-01 W 2, SMALL
7-688-002-11 W 2.6, MIDDLE
7-688-004-02 W 4, SMALL

SECTION 6 ELECTRICAL PARTS LIST

R STATOR

VI-10

NOTE:

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.

- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

RESISTORS

- All resistors are in ohms
- F : nonflammable

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

CAPACITORS

- MF : μ F, PF : μ MF

COILS

- MMH : mH, UH : μ H

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
*A-4910-049-A		R STATOR (REEL MOTOR) BOARD, COMPLETE *****		C110	1-161-013-00	CERAMIC 0.01MF	10% 25V
				C111	1-102-959-00	CERAMIC 22PF	5% 50V
				C112	1-161-013-00	CERAMIC 0.01MF	10% 25V
				C113	1-161-013-00	CERAMIC 0.01MF	10% 25V
				C114	1-161-039-00	CERAMIC 0.001MF	10% 25V
*1-560-460-00		PIN, CONNECTOR 4P		C115	1-102-820-00	CERAMIC 330PF	5% 50V
		<u>CAPACITOR</u>		C116	1-102-973-00	CERAMIC 100PF	5% 50V
C1	1-123-821-00	ELECT 47MF	20% 16V	C117	1-161-059-00	CERAMIC 0.047MF	10% 25V
C2	1-123-821-00	ELECT 47MF	20% 16V	C118	1-102-116-00	CERAMIC 680PF	10% 50V
C3	1-123-821-00	ELECT 47MF	20% 16V	C120	1-161-013-00	CERAMIC 0.01MF	10% 25V
C4	1-123-821-00	ELECT 47MF	20% 16V	C121	1-161-013-00	CERAMIC 0.01MF	10% 25V
		<u>DIODE</u>		C123	1-102-822-00	CERAMIC 390PF	5% 50V
D1	8-719-941-48	DIODE 1N4148TP		C124	1-161-059-00	CERAMIC 0.047MF	10% 25V
		<u>IC</u>		C125	1-161-013-00	CERAMIC 0.01MF	10% 25V
IC1	8-759-108-77	IC CX-877		C126	1-161-013-00	CERAMIC 0.01MF	10% 25V
		<u>TRANSISTOR</u>		C127	1-161-059-00	CERAMIC 0.047MF	10% 25V
Q1	8-729-100-01	TRANSISTOR 2SD992-N		C128	1-161-013-00	CERAMIC 0.01MF	10% 25V
Q2	8-729-100-01	TRANSISTOR 2SD992-N		C129	1-102-973-00	CERAMIC 100PF	5% 50V
Q3	8-729-100-01	TRANSISTOR 2SD992-N		C130	1-161-013-00	CERAMIC 0.01MF	10% 25V
Q4	8-729-100-01	TRANSISTOR 2SD992-N		C131	1-161-059-00	CERAMIC 0.047MF	10% 25V
Q5	8-729-100-01	TRANSISTOR 2SD992-N		C132	1-161-013-00	CERAMIC 0.01MF	10% 25V
Q6	8-729-100-01	TRANSISTOR 2SD992-N		C133	1-102-816-00	CERAMIC 120PF	5% 50V
		<u>RESISTOR</u>		C134	1-161-025-00	CERAMIC 0.1MF	10% 25V
R1	1-247-823-00	CARBON 470 5% 1/6W		C135	1-123-356-00	ELECT 10MF	20% 16V
R2	1-247-823-00	CARBON 470 5% 1/6W		C136	1-136-165-00	MYLAR 0.1MF	10% 50V
R3	1-247-823-00	CARBON 470 5% 1/6W		C137	1-123-382-00	ELECT 3.3MF	20% 50V
R4	1-247-829-00	CARBON 820 5% 1/6W		C138	1-123-380-00	ELECT 1MF	20% 50V
R5	1-247-871-00	CARBON 47K 5% 1/6W		C139	1-123-306-00	ELECT 47MF	20% 10V
R6	1-247-871-00	CARBON 47K 5% 1/6W		C140	1-161-013-00	CERAMIC 0.01MF	10% 25V
R7	1-247-871-00	CARBON 47K 5% 1/6W		C141	1-123-330-00	ELECT 22MF	20% 16V
R8	1-247-871-00	CARBON 47K 5% 1/6W		C142	1-161-013-00	CERAMIC 0.01MF	10% 25V
		<u>DIODE</u>		C143	1-123-306-00	ELECT 47MF	20% 10V
S1	8-719-810-31	DIODE THS103-1		C158	1-102-978-00	CERAMIC 220PF	5% 50V
S2	8-719-810-31	DIODE THS103-1		C160	1-102-820-00	CERAMIC 330PF	5% 50V
		*****		C161	1-102-952-00	CERAMIC 16PF	5% 50V
*A-6711-614-A		VI-10 BOARD, COMPLETE *****		C162	1-102-961-00	CERAMIC 27PF	5% 50V
		<u>CAPACITOR</u>		C201	1-101-059-00	CERAMIC 510PF	5% 50V
C101	1-123-306-00	ELECT 47MF	20% 10V	C202	1-102-821-00	CERAMIC 360PF	5% 50V
C103	1-102-963-00	CERAMIC 33PF	5% 50V	C203	1-102-976-00	CERAMIC 180PF	5% 50V
C104	1-123-318-00	ELECT 33MF	20% 10V	C204	1-123-382-00	ELECT 3.3MF	20% 50V
C105	1-123-356-00	ELECT 10MF	20% 16V	C205	1-123-380-00	ELECT 1MF	20% 50V
C106	1-123-306-00	ELECT 47MF	20% 10V	C206	1-101-059-00	CERAMIC 510PF	5% 50V
C107	1-161-013-00	CERAMIC 0.01MF	10% 25V	C207	1-102-822-00	CERAMIC 390PF	5% 50V
C108	1-161-013-00	CERAMIC 0.01MF	10% 25V	C209	1-102-978-00	CERAMIC 220PF	5% 50V
C109	1-161-013-00	CERAMIC 0.01MF	10% 25V	C210	1-102-980-00	CERAMIC 270PF	5% 50V
				C211	1-123-356-00	ELECT 10MF	20% 16V
				C212	1-123-306-00	ELECT 47MF	20% 10V
				C213	1-161-059-00	CERAMIC 0.047MF	10% 25V
				C231	1-123-306-00	ELECT 47MF	20% 10V
				C232	1-161-013-00	CERAMIC 0.01MF	10% 25V
				C301	1-101-880-00	CERAMIC 47PF	5% 50V
				C302	1-123-381-00	ELECT 2.2MF	20% 50V
				C303	1-102-963-00	CERAMIC 33PF	5% 50V

VI-10

Ref.No	Part No.	Description		Remark	Ref.No	Part No.	Description		Remark		
C304	1-101-888-00	CERAMIC	68PF	5%	50V	C428	1-123-369-00	ELECT	4.7MF	20%	25V
C305	1-101-880-00	CERAMIC	47PF	5%	50V	C429	1-161-013-00	CERAMIC	0.01MF	10%	25V
C306	1-123-622-00	ELECT	22MF	20%	16V	C430	1-102-971-00	CERAMIC	82PF	5%	50V
C307	1-123-330-00	ELECT	22MF	20%	16V	C431	1-161-013-00	CERAMIC	0.01MF	10%	25V
C308	1-123-369-00	ELECT	4.7MF	20%	25V	C432	1-102-516-00	CERAMIC	27PF	5%	50V
C309	1-123-330-00	ELECT	22MF	20%	16V	C433	1-101-888-00	CERAMIC	68PF	5%	50V
C310	1-123-330-00	ELECT	22MF	20%	16V	C434	1-123-380-00	ELECT	1MF	20%	50V
C311	1-101-884-00	CERAMIC	56PF	5%	50V	C435	1-161-024-00	CERAMIC	0.082MF	10%	25V
C312	1-101-888-00	CERAMIC	68PF	5%	50V	C436	1-123-356-00	ELECT	10MF	20%	16V
C313	1-102-936-00	CERAMIC	3PF	0.25PF	50V	C437	1-123-356-00	ELECT	10MF	20%	16V
C314	1-123-306-00	ELECT	47MF	20%	10V	C438	1-161-013-00	CERAMIC	0.01MF	10%	25V
C315	1-161-013-00	CERAMIC	0.01MF	10%	25V	C439	1-161-013-00	CERAMIC	0.01MF	10%	25V
C316	1-102-965-00	CERAMIC	39PF	5%	50V	C440	1-101-361-00	CERAMIC	150PF	5%	50V
C317	1-161-039-00	CERAMIC	0.001MF	10%	25V	C441	1-161-013-00	CERAMIC	0.01MF	10%	25V
C318	1-161-013-00	CERAMIC	0.01MF	10%	25V	C442	1-161-013-00	CERAMIC	0.01MF	10%	25V
C319	1-123-356-00	ELECT	10MF	20%	16V	C443	1-102-949-00	CERAMIC	12PF	5%	50V
C320	1-102-820-00	CERAMIC	330PF	5%	50V	C444	1-161-013-00	CERAMIC	0.01MF	10%	25V
C321	1-123-356-00	ELECT	10MF	20%	16V	C445	1-102-973-00	CERAMIC	100PF	5%	50V
C322	1-161-013-00	CERAMIC	0.01MF	10%	25V	C446	1-123-306-00	ELECT	47MF	20%	10V
C323	1-123-306-00	ELECT	47MF	20%	10V	C447	1-102-961-00	CERAMIC	27PF	5%	50V
C324	1-123-381-00	ELECT	2.2MF	20%	50V	C448	1-161-013-00	CERAMIC	0.01F	10%	25V
C325	1-123-381-00	ELECT	2.2MF	20%	50V	C449	1-102-978-00	CERAMIC	220PF	5%	50V
C326	1-102-980-00	CERAMIC	270PF	5%	50V	C450	1-161-013-00	CERAMIC	0.01MF	10%	25V
C331	1-123-356-00	ELECT	10MF	20%	16V	C451	1-161-013-00	CERAMIC	0.01MF	10%	25V
C332	1-102-947-00	CERAMIC	10PF	5%	50V	C452	1-123-306-00	ELECT	47MF	20%	10V
C333	1-123-306-00	ELECT	47MF	20%	10V	C453	1-123-356-00	ELECT	10MF	20%	16V
C401	1-161-013-00	CERAMIC	0.01MF	10%	25V	C454	1-123-306-00	CERAMIC	47MF	20%	10V
C402	1-161-055-00	CERAMIC	0.022MF	10%	25V	C455	1-161-013-00	CERAMIC	0.01MF	10%	25V
C403	1-102-815-00	CERAMIC	110PF	5%	50V	C461	1-101-880-00	CERAMIC	47PF	5%	50V
C404	1-101-880-00	CERAMIC	47PF	5%	50V	C462	1-102-963-00	CERAMIC	33PF	5%	50V
C405	1-102-962-00	CERAMIC	30PF	5%	50V	C501	1-123-822-00	ELECT	47MF	20%	10V
C406	1-123-306-00	ELECT	47MF	20%	10V	C502	1-161-013-00	CERAMIC	0.01MF	10%	25V
C407	1-161-013-00	CERAMIC	0.01MF	10%	25V	C503	1-123-379-00	ELECT	0.47MF	20%	50V
C408	1-123-369-00	ELECT	4.7MF	20%	25V	C504	1-161-013-00	CERAMIC	0.01MF	10%	25V
C409	1-123-380-00	ELECT	1MF	20%	50V	C505	1-161-013-00	CERAMIC	0.01MF	10%	25V
C410	1-161-013-00	CERAMIC	0.01MF	10%	25V	C506	1-161-025-00	CERAMIC	0.1MF	10%	25V
C411	1-123-380-00	ELECT	1MF	20%	50V	C507	1-161-039-00	CERAMIC	0.001MF	10%	25V
C412	1-161-013-00	CERAMIC	0.01MF	10%	25V	C508	1-161-025-00	CERAMIC	0.1MF	10%	25V
C413	1-161-013-00	CERAMIC	0.03MF	10%	25V	C509	1-161-013-00	CERAMIC	0.01MF	10%	25V
C414	1-161-003-00	CERAMIC	0.0015MF	10%	25V	C510	1-161-013-00	CERAMIC	0.01MF	10%	25V
C415	1-161-003-00	CERAMIC	0.0015MF	10%	25V	C511	1-101-888-00	CERAMIC	68PF	5%	50V
C416	1-123-306-00	ELECT	47MF	20%	10V	C512	1-161-059-00	CERAMIC	0.047MF	10%	25V
C417	1-161-013-00	CERAMIC	0.01MF	10%	25V	C514	1-161-043-00	CERAMIC	0.0022MF	10%	25V
C418	1-102-521-00	CERAMIC	43PF	5%	50V	C515	1-102-980-00	CERAMIC	270PF	5%	50V
C419	1-102-949-00	CERAMIC	12PF	5%	50V	C516	1-101-081-00	CERAMIC	130PF	5%	50V
C420	1-101-880-00	CERAMIC	47PF	5%	50V	C517	1-123-369-00	ELECT	4.7MF	20%	25V
C421	1-101-361-00	CERAMIC	150PF	5%	50V	C518	1-161-013-00	CERAMIC	0.01MF	10%	25V
C422	1-102-978-00	CERAMIC	220PF	5%	50V	C519	1-123-306-00	ELECT	47MF	20%	10V
C423	1-161-047-00	CERAMIC	0.0047MF	10%	25V	C520	1-127-460-00	ELECT(SOLID)	1MF	20%	25V
C424	1-123-380-00	ELECT	1MF	20%	50V	C521	1-127-460-00	ELECT(SOLID)	1MF	20%	25V
C425	1-123-380-00	ELECT	1MF	20%	50V	C522	1-127-460-00	ELECT(SOLID)	1MF	20%	25V
C426	1-161-013-00	CERAMIC	0.01MF	10%	25V	C523	1-161-013-00	CERAMIC	0.01MF	10%	25V
C427	1-123-306-00	ELECT	47MF	20%	10V	C524	1-161-013-00	CERAMIC	0.01MF	10%	25V

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
C525	1-161-013-00	CERAMIC	0.01MF 10% 25V	C707	1-161-059-00	CERAMIC	0.047MF 10% 25V
C526	1-161-013-00	CERAMIC	0.01MF 10% 25V	C708	1-123-306-00	ELECT	47MF 20% 10V
C527	1-123-369-00	ELECT	4.7MF 20% 25V	C709	1-102-947-00	CERAMIC	10PF 5% 50V
C528	1-161-059-00	CERAMIC	0.047MF 10% 25V	C711	1-102-973-00	CERAMIC	100PF 5% 50V
C529	1-123-822-00	ELECT	47MF 20% 10V	C712	1-123-613-00	ELECT	3.3MF 20% 50V
C530	1-161-013-00	CERAMIC	0.01MF 10% 25V	C713	1-102-971-00	CERAMIC	82PF 5% 50V
C531	1-161-013-00	CERAMIC	0.01MF 10% 25V	C714	1-123-380-00	ELECT	1MF 20% 50V
C532	1-123-306-00	ELECT	47MF 20% 10V	C715	1-161-047-00	CERAMIC	0.0047MF 10% 25V
C535	1-123-612-00	ELECT	2.2MF 20% 50V	C716	1-123-380-00	ELECT	1MF 20% 50V
C536	1-161-013-00	CERAMIC	0.01MF 10% 25V	C717	1-161-059-00	CERAMIC	0.047MF 10% 25V
C537	1-102-961-00	CERAMIC	27PF 5% 50V	C718	1-123-822-00	ELECT	47MF 20% 10V
C539	1-102-961-00	CERAMIC	27PF 5% 50V	C719	1-102-953-00	CERAMIC	18PF 5% 50V
C540	1-102-961-00	CERAMIC	27PF 5% 50V	C720	1-123-306-00	ELECT	47MF 20% 10V
C545	1-161-013-00	CERAMIC	0.01MF 10% 25V	C721	1-102-980-00	CERAMIC	270PF 5% 50V
C601	1-102-824-00	CERAMIC	470PF 5% 50V	C722	1-123-306-00	ELECT	47MF 20% 10V
C602	1-102-944-00	CERAMIC	7PF 1PF 50V	C723	1-130-478-00	MYLAR	0.0039MF 5% 50V
C603	1-102-824-00	CERAMIC	470PF 5% 50V	C724	1-102-820-00	CERAMIC	330PF 5% 50V
C604	1-161-013-00	CERAMIC	0.01MF 10% 25V	C725	1-101-880-00	CERAMIC	47PF 5% 50V
C605	1-161-059-00	CERAMIC	0.047MF 10% 25V	C726	1-102-980-00	CERAMIC	270PF 5% 50V
C606	1-161-055-00	CERAMIC	0.022MF 10% 25V	C727	1-130-471-00	MYLAR	0.001MF 5% 50V
C608	1-101-884-00	CERAMIC	56PF 5% 50V	C728	1-102-976-00	CERAMIC	180PF 5% 50V
C609	1-101-890-00	CERAMIC	75PF 5% 50V	C729	1-101-880-00	CERAMIC	47PF 5% 50V
C610	1-102-824-00	CERAMIC	470PF 5% 50V	C730	1-161-059-00	CERAMIC	0.047MF 10% 25V
C612	1-161-059-00	CERAMIC	0.047MF 10% 25V	C731	1-102-973-00	CERAMIC	100PF 5% 50V
C613	1-161-013-00	CERAMIC	0.01MF 10% 25V	C732	1-123-380-00	ELECT	1MF 20% 50V
C614	1-123-306-00	ELECT	47MF 20% 10V	C734	1-101-059-00	CERAMIC	510PF 5% 50V
C617	1-161-013-00	CERAMIC	0.01MF 10% 25V	C735	1-123-318-00	ELECT	33MF 20% 10V
C622	1-161-013-00	CERAMIC	0.01MF 10% 25V	C736	1-102-976-00	CERAMIC	180PF 5% 50V
C623	1-102-978-00	CERAMIC	220PF 5% 50V	C737	1-123-306-00	ELECT	47MF 20% 10V
C625	1-123-380-00	ELECT	1MF 20% 50V	C738	1-101-884-00	CERAMIC	56PF 5% 50V
C650	1-102-947-00	CERAMIC	10PF 5% 50V	C801	1-123-356-00	ELECT	10MF 20% 16V
C651	1-161-013-00	CERAMIC	0.01MF 10% 25V	C901	1-161-013-00	CERAMIC	0.01MF 10% 25V
C652	1-161-013-00	CERAMIC	0.01MF 10% 25V	C902	1-123-369-00	ELECT	4.7MF 20% 25V
C653	1-102-951-00	CERAMIC	15PF 5% 50V	C903	1-161-039-00	CERAMIC	0.001MF 10% 25V
C654	1-102-964-00	CERAMIC	36PF 5% 50V	C904	1-123-356-00	ELECT	10MF 20% 16V
C655	1-123-306-00	ELECT	47MF 20% 10V	C906	1-123-613-00	ELECT	3.3MF 20% 50V
C656	1-161-059-00	CERAMIC	0.047MF 10% 25V	C907	1-161-013-00	CERAMIC	0.01MF 10% 25V
C657	1-161-059-00	CERAMIC	0.047MF 10% 25V	C908	1-161-013-00	CERAMIC	0.01MF 10% 25V
C658	1-102-973-00	CERAMIC	100PF 5% 50V				
C659	1-161-055-00	CERAMIC	0.022MF 10% 25V	<u>FILTER</u>			
C660	1-101-361-00	CERAMIC	150PF 5% 50V	CF401	1-231-302-00	CERAMIC FILTER (4.27MHZ)	
C661	1-161-059-00	CERAMIC	0.047MF 10% 25V	CF402	1-527-823-00	FILTER, CERAMIC	
C662	1-101-890-00	CERAMIC	75PF 5% 50V	CF501	1-527-823-00	FILTER, CERAMIC	
C663	1-161-013-00	CERAMIC	0.01MF 10% 25V	<u>CONNECTOR</u>			
C664	1-102-961-00	CERAMIC	27PF 5% 50V	CN201	*1-560-890-00	PIN, CONNECTOR 2P	
C665	1-102-824-00	CERAMIC	470PF 5% 50V	CN202	*1-564-037-11	PIN, CONNECTOR 12P	
C666	1-161-059-00	CERAMIC	0.047MF 10% 25V	CN203	*1-564-029-21	PIN, CONNECTOR 4P	
C667	1-161-055-00	CERAMIC	0.022MF 10% 25V	CN204	*1-564-036-21	PIN, CONNECTOR 11P	
C702	1-102-953-00	CERAMIC	18PF 5% 50V	CN205	*1-560-894-00	PIN, CONNECTOR 6P	
C703	1-102-965-00	CERAMIC	39PF 5% 50V	CN206	*1-560-896-00	PIN, CONNECTOR 8P	
C704	1-102-965-00	CERAMIC	39PF 5% 50V	CN207	*1-564-028-00	PIN, CONNECTOR 3P	
C705	1-102-947-00	CERAMIC	10PF 5% 50V	CN208	*1-560-892-00	PIN, CONNECTOR 4P	
C706	1-123-306-00	ELECT	47MF 20% 10V				

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description
<u>DIODE</u>		
D101	8-719-911-19	DIODE 1SS119
D102	8-719-000-06	DIODE MC921
D103	8-719-911-19	DIODE 1SS119
D104	8-719-911-19	DIODE 1SS119
D105	8-719-911-19	DIODE 1SS119
D202	8-719-911-19	DIODE 1SS119
D203	8-719-911-19	DIODE 1SS119
D204	8-719-911-19	DIODE 1SS119
D205	8-719-911-19	DIODE 1SS119
D206	8-719-911-19	DIODE 1SS119
D207	8-719-911-19	DIODE 1SS119
D208	8-719-911-19	DIODE 1SS119
D209	8-719-000-04	DIODE MC911
D211	8-719-911-19	DIODE 1SS119
D212	8-719-000-06	DIODE MC921
D214	8-719-911-19	DIODE 1SS119
D217	8-719-911-19	DIODE 1SS119
D301	8-719-911-19	DIODE 1SS119
D302	8-719-911-19	DIODE 1SS119
D401	8-719-911-19	DIODE 1SS119
D501	8-719-175-07	DIODE RD7.5E-B
D502	8-719-000-06	DIODE MC921
D503	8-719-911-19	DIODE 1SS119
D504	8-719-000-12	DIODE MC931
D601	8-719-911-19	DIODE 1SS119
D602	8-719-911-19	DIODE 1SS119
D648	8-719-911-19	DIODE 1SS119
D651	8-719-911-19	DIODE 1SS119
D652	8-719-911-19	DIODE 1SS119
D653	8-719-911-19	DIODE 1SS119
D654	8-719-911-19	DIODE 1SS119
D657	8-719-911-19	DIODE 1SS119
D701	8-719-911-19	DIODE 1SS119
D702	8-719-911-19	DIODE 1SS119
D703	8-719-911-19	DIODE 1SS119
D704	8-719-911-19	DIODE 1SS119
D705	8-719-000-12	DIODE MC931
D706	8-719-000-12	DIODE MC931
D707	8-719-911-19	DIODE 1SS119
D708	8-719-911-19	DIODE 1SS119
D710	8-719-911-19	DIODE 1SS119
D901	8-719-911-19	DIODE 1SS119
D902	8-719-000-06	DIODE MC921
D903	8-719-911-19	DIODE 1SS119
D904	8-719-911-19	DIODE 1SS119
D905	8-719-911-19	DIODE 1SS119
<u>DELAY LINE</u>		
DL101	1-415-107-31	DELAY LINE, 1H
DL301	1-415-285-00	DELAY LINE (1H)

Remark	Ref.No	Part No.	Description	Remark
	<u>IC</u>			
	IC001	8-759-101-62	IC CX20043	
	IC002	8-759-203-99	IC CX10021B-NP	
	IC003	8-758-662-00	IC CX-866B	
	IC004	8-759-204-43	IC CX-7989A	
	IC901	8-759-240-13	IC TC40138P	
	<u>COIL</u>			
	L101	1-408-419-00	MICRO INDUCTOR 68UH	
	L102	1-408-418-00	MICRO INDUCTOR 56UH	
	L104	1-408-421-00	MICRO INDUCTOR 100UH	
	L105	1-408-605-00	MICRO INDUCTOR 15UH	
	L201	1-408-413-00	MICRO INDUCTOR 22UH	
	L301	1-408-418-00	MICRO INDUCTOR 56UH	
	L302	1-408-419-00	MICRO INDUCTOR 68UH	
	L303	1-408-399-00	MICRO INDUCTOR 1.5UH	
	L304	1-408-399-00	MICRO INDUCTOR 1.5UH	
	L305	1-408-418-00	MICRO INDUCTOR 56UH	
	L401	1-408-404-00	MICRO INDUCTOR 3.9UH	
	L402	1-408-425-00	MICRO INDUCTOR 220UH	
	L403	1-408-427-00	MICRO INDUCTOR 330UH	
	L404	1-408-498-31	MICRO INDUCTOR 3.3MMH	
	L405	1-408-426-00	MICRO INDUCTOR 270UH	
	L406	1-408-426-00	MICRO INDUCTOR 270UH	
	L407	1-408-423-00	MICRO INDUCTOR 150UH	
	L501	1-408-414-00	MICRO INDUCTOR 27UH	
	L503	1-408-409-00	MICRO INDUCTOR 10UH	
	L504	1-408-421-00	MICRO INDUCTOR 100UH	
	L505	1-408-421-00	MICRO INDUCTOR 100UH	
	L506	1-408-418-00	MICRO INDUCTOR 56UH	
	L601	1-408-605-00	MICRO INDUCTOR 15UH	
	L602	1-408-413-00	MICRO INDUCTOR 22UH	
	L603	1-408-422-00	MICRO INDUCTOR 120UH	
	L604	1-408-425-00	MICRO INDUCTOR 220UH	
	L605	1-408-422-00	MICRO INDUCTOR 120UH	
	L606	1-408-419-00	MICRO INDUCTOR 68UH	
	L651	1-408-414-00	MICRO INDUCTOR 27UH	
	L652	1-408-408-00	MICRO INDUCTOR 8.2UH	
	L653	1-408-623-00	MICRO INDUCTOR 470UH	
	L654	1-408-422-00	MICRO INDUCTOR 120UH	
	L701	1-408-421-00	MICRO INDUCTOR 100UH	
	L702	1-408-422-00	MICRO INDUCTOR 120UH	
	L703	1-408-421-00	MICRO INDUCTOR 100UH	
	L704	1-408-416-00	MICRO INDUCTOR 39UH	
	L705	1-408-425-00	MICRO INDUCTOR 220UH	
	L706	1-408-420-00	MICRO INDUCTOR 82UH	
	L707	1-408-413-00	MICRO INDUCTOR 22UH	
	L708	1-408-418-00	MICRO INDUCTOR 56UH	
	L709	1-408-419-00	MICRO INDUCTOR 68UH	
	<u>VARIABLE COIL</u>			
	LV101	1-408-512-00	COIL (VARIABLE)	

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
<u>TRANSISTOR</u>							
Q102	8-729-900-89	TRANSISTOR DTC144ES		Q610	8-729-900-65	TRANSISTOR DTA144ES	
Q103	8-729-900-89	TRANSISTOR DTC144ES		Q611	8-729-900-89	TRANSISTOR DTC144ES	
Q104	8-729-900-89	TRANSISTOR DTC144ES		Q651	8-729-178-54	TRANSISTOR 2SC2785	
Q105	8-729-900-89	TRANSISTOR DTC144ES		Q652	8-729-178-54	TRANSISTOR 2SC2785	
Q106	8-729-245-83	TRANSISTOR 2SC2458		Q653	8-729-178-54	TRANSISTOR 2SC2785	
Q107	8-729-900-89	TRANSISTOR DTC144ES		Q654	8-729-178-54	TRANSISTOR 2SC2785	
Q108	8-729-900-89	TRANSISTOR DTC144ES		Q655	8-729-900-89	TRANSISTOR DTC144ES	
Q109	8-729-900-65	TRANSISTOR DTA144ES		Q656	8-729-117-54	TRANSISTOR 2SA1175	
Q110	8-729-900-89	TRANSISTOR DTC144ES		Q657	8-729-117-54	TRANSISTOR 2SA1175	
Q161	8-729-900-89	TRANSISTOR DTC144ES		Q658	8-729-178-54	TRANSISTOR 2SC2785	
Q201	8-729-117-54	TRANSISTOR 2SA1175		Q701	8-729-900-89	TRANSISTOR DTC144ES	
Q202	8-729-117-54	TRANSISTOR 2SA1175		Q702	8-729-245-83	TRANSISTOR 2SC2458	
Q204	8-729-117-54	TRANSISTOR 2SA1175		Q703	8-729-178-55	TRANSISTOR 2SC2785-E	
Q205	8-729-178-55	TRANSISTOR 2SC2785-E		Q704	8-729-900-61	TRANSISTOR DTA144ES	
Q206	8-729-117-54	TRANSISTOR 2SA1175		Q705	8-729-245-83	TRANSISTOR 2SC2458	
Q207	8-729-117-54	TRANSISTOR 2SA1175		Q706	8-729-178-55	TRANSISTOR 2SC2785-E	
Q210	8-729-117-54	TRANSISTOR 2SA1175		Q707	8-729-117-54	TRANSISTOR 2SA1175	
Q301	8-729-245-83	TRANSISTOR 2SC2458		Q708	8-729-117-54	TRANSISTOR 2SA1175	
Q303	8-729-900-89	TRANSISTOR DTC144ES		Q709	8-729-900-89	TRANSISTOR DTC144ES	
Q304	8-729-900-89	TRANSISTOR DTC144ES		Q710	8-729-900-89	TRANSISTOR DTC144ES	
Q401	8-729-245-83	TRANSISTOR 2SC2458		Q711	8-729-900-65	TRANSISTOR DTA144ES	
Q402	8-729-900-89	TRANSISTOR DTC144ES		Q712	8-729-245-83	TRANSISTOR 2SC2458	
Q403	8-729-245-83	TRANSISTOR 2SC2458		Q713	8-729-117-54	TRANSISTOR 2SA1175	
Q404	8-729-245-83	TRANSISTOR 2SC2458		Q714	8-729-178-55	TRANSISTOR 2SC2785-E	
Q405	8-729-900-89	TRANSISTOR DTC144ES		Q715	8-729-178-55	TRANSISTOR 2SC2785-E	
Q406	8-729-245-83	TRANSISTOR 2SC2458		Q716	8-729-900-89	TRANSISTOR DTC144ES	
Q407	8-729-117-54	TRANSISTOR 2SA1175		Q717	8-729-900-89	TRANSISTOR DTC144ES	
Q408	8-729-245-83	TRANSISTOR 2SC2458		Q718	8-729-245-83	TRANSISTOR 2SC2458	
Q409	8-729-245-83	TRANSISTOR 2SC2458		Q720	8-729-900-89	TRANSISTOR DTC144ES	
Q410	8-729-900-65	TRANSISTOR DTA144ES		Q721	8-729-900-89	TRANSISTOR DTC144ES	
Q411	8-729-245-83	TRANSISTOR 2SC2458		Q722	8-729-900-89	TRANSISTOR DTC144ES	
Q412	8-729-117-54	TRANSISTOR 2SA1175		Q724	8-729-900-89	TRANSISTOR DTC144ES	
Q413	8-729-900-89	TRANSISTOR DTC144ES		Q725	8-729-900-89	TRANSISTOR DTC144ES	
Q414	8-729-117-54	TRANSISTOR 2SA1175		Q801	8-729-900-89	TRANSISTOR DTC144ES	
Q415	8-729-117-54	TRANSISTOR 2SA1175		Q803	8-729-117-54	TRANSISTOR 2SA1175	
Q501	8-729-245-83	TRANSISTOR 2SC2458		Q804	8-729-900-89	TRANSISTOR DTC144ES	
Q502	8-729-245-83	TRANSISTOR 2SC2458		Q901	8-729-900-89	TRANSISTOR DTC144ES	
Q503	8-729-117-54	TRANSISTOR 2SA1175		Q902	8-729-900-89	TRANSISTOR DTC144ES	
Q504	8-729-245-83	TRANSISTOR 2SC2458		Q903	8-729-900-89	TRANSISTOR DTC144ES	
Q505	8-729-900-89	TRANSISTOR DTC144ES		Q904	8-729-900-89	TRANSISTOR DTC144ES	
Q507	8-729-245-83	TRANSISTOR 2SC2458		Q905	8-729-245-83	TRANSISTOR 2SC2458	
Q508	8-729-245-83	TRANSISTOR 2SC2458		Q906	8-729-245-83	TRANSISTOR 2SC2458	
Q509	8-729-245-83	TRANSISTOR 2SC2458		Q907	8-729-245-83	TRANSISTOR 2SC2458	
Q510	8-729-245-83	TRANSISTOR 2SC2458		Q908	8-729-245-83	TRANSISTOR 2SC2458	
Q602	8-729-178-54	TRANSISTOR 2SC2785		Q910	8-729-900-89	TRANSISTOR DTC144ES	
Q604	8-729-178-54	TRANSISTOR 2SC2785		Q911	8-729-900-89	TRANSISTOR DTC144ES	
Q605	8-729-178-54	TRANSISTOR 2SC2785		Q912	8-729-900-89	TRANSISTOR DTC144ES	
Q606	8-729-900-89	TRANSISTOR DTC144ES		<u>RESISTOR</u>			
Q607	8-729-178-54	TRANSISTOR 2SC2785		R098	1-247-807-00	CARBON 100 5%	1/6W
Q608	8-729-178-54	TRANSISTOR 2SC2785		R101	1-247-831-00	CARBON 1K 5%	1/6W
Q609	8-729-178-54	TRANSISTOR 2SC2785		R102	1-247-831-00	CARBON 1K 5%	1/6W
				R106	1-247-831-00	CARBON 1K 5%	1/6W

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description				Remark
R111	1-247-839-00	CARBON	2.2K	5%	1/6W	
R112	1-247-861-00	CARBON	18K	5%	1/6W	
R113	1-247-857-00	CARBON	12K	5%	1/6W	
R114	1-247-899-00	CARBON	680K	5%	1/6W	
R115	1-247-841-00	CARBON	2.7K	5%	1/6W	
R117	1-247-861-00	CARBON	18K	5%	1/6W	
R118	1-247-883-00	CARBON	150K	5%	1/6W	
R119	1-247-851-00	CARBON	6.8K	5%	1/6W	
R121	1-247-814-00	CARBON	200	5%	1/6W	
R122	1-247-827-00	CARBON	680	5%	1/6W	
R125	1-247-827-00	CARBON	680	5%	1/6W	
R126	1-247-843-00	CARBON	3.3K	5%	1/6W	
R127	1-247-859-00	CARBON	15K	5%	1/6W	
R128	1-247-855-00	CARBON	10K	5%	1/6W	
R129	1-247-799-00	CARBON	47	5%	1/6W	
R130	1-247-879-00	CARBON	100K	5%	1/6W	
R131	1-247-831-00	CARBON	1K	5%	1/6W	
R132	1-247-838-00	CARBON	2K	5%	1/6W	
R133	1-247-835-00	CARBON	1.5K	5%	1/6W	
R134	1-247-839-00	CARBON	2.2K	5%	1/6W	
R135	1-247-831-00	CARBON	1K	5%	1/6W	
R136	1-247-855-00	CARBON	10K	5%	1/6W	
R137	1-247-855-00	CARBON	10K	5%	1/6W	
R138	1-247-855-00	CARBON	10K	5%	1/6W	
R143	1-247-843-00	CARBON	3.3K	5%	1/6W	
R144	1-247-883-00	CARBON	150K	5%	1/6W	
R145	1-247-829-00	CARBON	820	5%	1/6W	
R146	1-247-852-00	CARBON	7.5K	5%	1/6W	
R147	1-247-835-00	CARBON	1.5K	5%	1/6W	
R149	1-247-867-00	CARBON	33K	5%	1/6W	
R150	1-247-855-00	CARBON	10K	5%	1/6W	
R168	1-247-843-00	CARBON	3.3K	5%	1/6W	
R172	1-247-855-00	CARBON	10K	5%	1/6W	
R173	1-247-847-00	CARBON	4.7K	5%	1/6W	
R176	1-247-899-00	CARBON	680K	5%	1/6W	
R180	1-247-855-00	CARBON	10K	5%	1/6W	
R181	1-247-807-00	CARBON	100	5%	1/6W	
R201	1-247-835-00	CARBON	1.5K	5%	1/6W	
R202	1-247-821-00	CARBON	390	5%	1/6W	
R203	1-247-823-00	CARBON	470	5%	1/6W	
R204	1-247-831-00	CARBON	1K	5%	1/6W	
R205	1-247-833-00	CARBON	1.2K	5%	1/6W	
R206	1-247-859-00	CARBON	15K	5%	1/6W	
R207	1-247-835-00	CARBON	1.5K	5%	1/6W	
R208	1-247-799-00	CARBON	47	5%	1/6W	
R209	1-247-869-00	CARBON	39K	5%	1/6W	
R210	1-247-859-00	CARBON	15K	5%	1/6W	
R211	1-247-863-00	CARBON	22K	5%	1/6W	
R212	1-247-851-00	CARBON	6.8K	5%	1/6W	
R213	1-247-839-00	CARBON	2.2K	5%	1/6W	
R214	1-247-838-00	CARBON	2K	5%	1/6W	
R215	1-247-817-00	CARBON	270	5%	1/6W	
R216	1-247-832-00	CARBON	1.1K	5%	1/6W	

Ref.No	Part No.	Description				Remark
R217	1-247-817-00	CARBON	270	5%	1/6W	
R218	1-247-822-00	CARBON	430	5%	1/6W	
R219	1-247-813-00	CARBON	180	5%	1/6W	
R220	1-247-856-00	CARBON	11K	5%	1/6W	
R221	1-247-856-00	CARBON	11K	5%	1/6W	
R222	1-247-813-00	CARBON	180	5%	1/6W	
R223	1-247-865-00	CARBON	27K	5%	1/6W	
R224	1-247-851-00	CARBON	6.8K	5%	1/6W	
R228	1-247-847-00	CARBON	4.7K	5%	1/6W	
R229	1-247-867-00	CARBON	33K	5%	1/6W	
R230	1-247-843-00	CARBON	3.3K	5%	1/6W	
R232	1-247-839-00	CARBON	2.2K	5%	1/6W	
R233	1-247-855-00	CARBON	10K	5%	1/6W	
R236	1-247-855-00	CARBON	10K	5%	1/6W	
R273	1-247-831-00	CARBON	1K	5%	1/6W	
R301	1-247-821-00	CARBON	390	5%	1/6W	
R302	1-247-847-00	CARBON	4.7K	5%	1/6W	
R303	1-247-847-00	CARBON	4.7K	5%	1/6W	
R304	1-247-821-00	CARBON	390	5%	1/6W	
R305	1-247-827-00	CARBON	680	5%	1/6W	
R306	1-247-828-00	CARBON	750	5%	1/6W	
R307	1-247-833-00	CARBON	1.2K	5%	1/6W	
R308	1-247-865-00	CARBON	27K	5%	1/6W	
R309	1-247-872-00	CARBON	51K	5%	1/6W	
R310	1-247-841-00	CARBON	2.7K	5%	1/6W	
R311	1-247-835-00	CARBON	1.5K	5%	1/6W	
R312	1-247-832-00	CARBON	1.1K	5%	1/6W	
R313	1-247-831-00	CARBON	1K	5%	1/6W	
R314	1-247-849-00	CARBON	5.6K	5%	1/6W	
R315	1-247-812-00	CARBON	160	5%	1/6W	
R316	1-247-812-00	CARBON	160	5%	1/6W	
R317	1-247-819-00	CARBON	330	5%	1/6W	
R318	1-247-847-00	CARBON	4.7K	5%	1/6W	
R319	1-247-813-00	CARBON	180	5%	1/6W	
R320	1-247-831-00	CARBON	1K	5%	1/6W	
R323	1-247-855-00	CARBON	10K	5%	1/6W	
R324	1-247-855-00	CARBON	10K	5%	1/6W	
R325	1-247-830-00	CARBON	910	5%	1/6W	
R331	1-247-827-00	CARBON	680	5%	1/6W	
R332	1-247-857-00	CARBON	12K	5%	1/6W	
R337	1-247-822-00	CARBON	430	5%	1/6W	
R401	1-247-839-00	CARBON	2.2K	5%	1/6W	
R403	1-247-843-00	CARBON	3.3K	5%	1/6W	
R404	1-247-865-00	CARBON	27K	5%	1/6W	
R405	1-247-863-00	CARBON	22K	5%	1/6W	
R406	1-247-833-00	CARBON	1.2K	5%	1/6W	
R407	1-247-837-00	CARBON	1.8K	5%	1/6W	
R408	1-247-891-00	CARBON	330K	5%	1/6W	
R409	1-247-835-00	CARBON	1.5K	5%	1/6W	
R410	1-247-807-00	CARBON	100	5%	1/6W	
R411	1-247-831-00	CARBON	1K	5%	1/6W	
R412	1-247-879-00	CARBON	100K	5%	1/6W	
R413	1-247-855-00	CARBON	10K	5%	1/6W	

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
R414	1-247-861-00	CARBON	18K 5% 1/6W	R470	1-247-823-00	CARBON	470 5% 1/6W
R415	1-247-839-00	CARBON	2.2K 5% 1/6W	R471	1-247-831-00	CARBON	1K 5% 1/6W
R416	1-247-835-00	CARBON	1.5K 5% 1/6W	R501	1-247-803-00	CARBON	68 5% 1/6W
R417	1-247-843-00	CARBON	3.3K 5% 1/6W	R502	1-247-881-00	CARBON	120K 5% 1/6W
R418	1-247-881-00	CARBON	120K 5% 1/6W	R503	1-247-901-00	CARBON	820K 5% 1/6W
R419	1-247-887-00	CARBON	220K 5% 1/6W	R504	1-247-887-00	CARBON	220K 5% 1/6W
R420	1-247-849-00	CARBON	5.6K 5% 1/6W	R505	1-247-863-00	CARBON	22K 5% 1/6W
R421	1-247-831-00	CARBON	1K 5% 1/6W	R506	1-247-855-00	CARBON	10K 5% 1/6W
R422	1-247-855-00	CARBON	10K 5% 1/6W	R507	1-247-839-00	CARBON	2.2K 5% 1/6W
R423	1-247-835-00	CARBON	1.5K 5% 1/6W	R508	1-247-857-00	CARBON	12K 5% 1/6W
R424	1-247-819-00	CARBON	330 5% 1/6W	R509	1-247-819-00	CARBON	330 5% 1/6W
R425	1-247-855-00	CARBON	10K 5% 1/6W	R510	1-247-867-00	CARBON	33K 5% 1/6W
R426	1-247-819-00	CARBON	330 5% 1/6W	R511	1-247-853-00	CARBON	8.2K 5% 1/6W
R427	1-247-824-00	CARBON	510 5% 1/6W	R512	1-247-825-00	CARBON	560 5% 1/6W
R428	1-247-831-00	CARBON	1K 5% 1/6W	R513	1-247-839-00	CARBON	2.2K 5% 1/6W
R429	1-247-863-00	CARBON	22K 5% 1/6W	R514	1-247-835-00	CARBON	1.5K 5% 1/6W
R430	1-247-813-00	CARBON	180 5% 1/6W	R515	1-247-871-00	CARBON	47K 5% 1/6W
R431	1-247-879-00	CARBON	100K 5% 1/6W	R516	1-247-831-00	CARBON	1K 5% 1/6W
R432	1-247-845-00	CARBON	3.9K 5% 1/6W	R517	1-247-871-00	CARBON	47K 5% 1/6W
R435	1-247-841-00	CARBON	2.7K 5% 1/6W	R518	1-247-831-00	CARBON	1K 5% 1/6W
R436	1-247-873-00	CARBON	56K 5% 1/6W	R519	1-247-841-00	CARBON	2.7K 5% 1/6W
R437	1-247-843-00	CARBON	3.3K 5% 1/6W	R520	1-247-855-00	CARBON	10K 5% 1/6W
R438	1-247-867-00	CARBON	33K 5% 1/6W	R521	1-247-841-00	CARBON	2.7K 5% 1/6W
R439	1-247-833-00	CARBON	1.2K 5% 1/6W	R522	1-247-855-00	CARBON	10K 5% 1/6W
R441	1-247-867-00	CARBON	33K 5% 1/6W	R523	1-247-841-00	CARBON	2.7K 5% 1/6W
R442	1-247-855-00	CARBON	10K 5% 1/6W	R524	1-247-855-00	CARBON	10K 5% 1/6W
R443	1-247-855-00	CARBON	10K 5% 1/6W	R525	1-247-829-00	CARBON	820 5% 1/6W
R444	1-247-844-00	CARBON	3.6K 5% 1/6W	R529	1-247-835-00	CARBON	1.5K 5% 1/6W
R445	1-247-835-00	CARBON	1.5K 5% 1/6W	R530	1-247-838-00	CARBON	2K 5% 1/6W
R446	1-247-030-11	CARBON	18 5% 1/6W F	R531	1-247-809-00	CARBON	120 5% 1/6W
R447	1-247-835-00	CARBON	1.5K 5% 1/6W	R532	1-247-837-00	CARBON	1.8K 5% 1/6W
R448	1-247-828-00	CARBON	750 5% 1/6W	R533	1-247-861-00	CARBON	18K 5% 1/6W
R449	1-247-845-00	CARBON	3.9K 5% 1/6W	R534	1-247-853-00	CARBON	8.2K 5% 1/6W
R450	1-247-839-00	CARBON	2.2K 5% 1/6W	R535	1-247-831-00	CARBON	1K 5% 1/6W
R451	1-247-820-00	CARBON	360 5% 1/6W	R536	1-247-815-00	CARBON	220 5% 1/6W
R452	1-247-839-00	CARBON	2.2K 5% 1/6W	R537	1-247-821-00	CARBON	390 5% 1/6W
R453	1-247-883-00	CARBON	150K 5% 1/6W	R538	1-247-821-00	CARBON	390 5% 1/6W
R454	1-247-891-00	CARBON	330K 5% 1/6W	R542	1-247-871-00	CARBON	47K 5% 1/6W
R455	1-247-863-00	CARBON	22K 5% 1/6W	R544	1-247-807-00	CARBON	100 5% 1/6W
R456	1-247-855-00	CARBON	10K 5% 1/6W	R545	1-247-831-00	CARBON	1K 5% 1/6W
R457	1-247-839-00	CARBON	2.2K 5% 1/6W	R546	1-247-831-00	CARBON	1K 5% 1/6W
R458	1-247-831-00	CARBON	1K 5% 1/6W	R547	1-247-863-00	CARBON	22K 5% 1/6W
R459	1-247-819-00	CARBON	330 5% 1/6W	R548	1-247-863-00	CARBON	22K 5% 1/6W
R460	1-247-843-00	CARBON	3.3K 5% 1/6W	R549	1-247-863-00	CARBON	22K 5% 1/6W
R461	1-247-831-00	CARBON	1K 5% 1/6W	R550	1-247-831-00	CARBON	1K 5% 1/6W
R462	1-247-831-00	CARBON	1K 5% 1/6W	R551	1-247-807-00	CARBON	100 5% 1/6W
R463	1-247-831-00	CARBON	1K 5% 1/6W	R552	1-247-801-00	CARBON	56 5% 1/6W
R464	1-247-831-00	CARBON	1K 5% 1/6W	R601	1-247-855-00	CARBON	10K 5% 1/6W
R465	1-247-855-00	CARBON	10K 5% 1/6W	R602	1-247-861-00	CARBON	18K 5% 1/6W
R466	1-247-855-00	CARBON	10K 5% 1/6W	R603	1-247-809-00	CARBON	120 5% 1/6W
R467	1-247-871-00	CARBON	47K 5% 1/6W	R605	1-247-865-00	CARBON	27K 5% 1/6W
R468	1-247-855-00	CARBON	10K 5% 1/6W	R606	1-247-819-00	CARBON	330 5% 1/6W
R469	1-247-855-00	CARBON	10K 5% 1/6W	R607	1-247-843-00	CARBON	3.3K 5% 1/6W

The components identified by shading and mark Δ are critical for safety. Replace only with part numer specified.

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

VI-10

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
R609	1-247-829-00	CARBON	820 5% 1/6W	R702	1-247-855-00	CARBON	10K 5% 1/6W
R610	1-247-827-00	CARBON	680 5% 1/6W	R704	1-247-839-00	CARBON	2.2K 5% 1/6W
R611	1-247-821-00	CARBON	390 5% 1/6W	R705	1-247-861-00	CARBON	18K 5% 1/6W
R614	1-247-831-00	CARBON	1K 5% 1/6W	R706	1-247-861-00	CARBON	18K 5% 1/6W
R615	1-247-863-00	CARBON	22K 5% 1/6W	R707	1-247-831-00	CARBON	1K 5% 1/6W
R616	1-247-861-00	CARBON	18K 5% 1/6W	R708	1-247-819-00	CARBON	330 5% 1/6W
R617	1-247-865-00	CARBON	27K 5% 1/6W	R709	1-247-783-00	CARBON	10 5% 1/6W
R618	1-247-825-00	CARBON	560 5% 1/6W	R710	1-247-831-00	CARBON	1K 5% 1/6W
R619	1-247-867-00	CARBON	33K 5% 1/6W	R711	1-247-861-00	CARBON	18K 5% 1/6W
R620	1-247-867-00	CARBON	33K 5% 1/6W	R712	1-247-829-00	CARBON	820 5% 1/6W
R621	1-247-839-00	CARBON	2.2K 5% 1/6W	R713	1-247-823-00	CARBON	470 5% 1/6W
R625	1-247-812-00	CARBON	160 5% 1/6W	R714	1-247-861-00	CARBON	18K 5% 1/6W
R626	1-247-815-00	CARBON	220 5% 1/6W	R715	1-247-821-00	CARBON	390 5% 1/6W
R627	1-247-797-00	CARBON	39 5% 1/6W	R716	1-247-809-00	CARBON	120 5% 1/6W
R628	1-247-815-00	CARBON	220 5% 1/6W	R717	1-247-843-00	CARBON	3.3K 5% 1/6W
R629	1-247-843-00	CARBON	3.3K 5% 1/6W	R718	1-247-861-00	CARBON	18K 5% 1/6W
R630	1-247-823-00	CARBON	470 5% 1/6W	R719	1-247-839-00	CARBON	2.2K 5% 1/6W
R631	1-247-823-00	CARBON	470 5% 1/6W	R720	1-247-865-00	CARBON	27K 5% 1/6W
R632	1-247-847-00	CARBON	4.7K 5% 1/6W	R721	1-247-855-00	CARBON	10K 5% 1/6W
R633	1-247-845-00	CARBON	3.9K 5% 1/6W	R722	1-247-822-00	CARBON	430 5% 1/6W
R650	1-247-865-00	CARBON	27K 5% 1/6W	R723	1-247-831-00	CARBON	1K 5% 1/6W
R651	1-247-823-00	CARBON	470 5% 1/6W	R724	1-247-797-00	CARBON	39 5% 1/6W
R652	1-247-859-00	CARBON	15K 5% 1/6W	R725	1-247-863-00	CARBON	22K 5% 1/6W
R653	1-247-833-00	CARBON	1.2K 5% 1/6W	R726	1-247-859-00	CARBON	15K 5% 1/6W
R654	1-247-823-00	CARBON	470 5% 1/6W	R727	1-247-822-00	CARBON	430 5% 1/6W
R655	1-247-823-00	CARBON	470 5% 1/6W	R728	1-247-834-00	CARBON	1.3K 5% 1/6W
R656	1-247-823-00	CARBON	470 5% 1/6W	R729	1-247-867-00	CARBON	33K 5% 1/6W
R657	1-247-807-00	CARBON	100 5% 1/6W	R730	1-247-819-00	CARBON	330 5% 1/6W
R658	1-247-841-00	CARBON	2.7K 5% 1/6W	R731	1-247-819-00	CARBON	330 5% 1/6W
R659	1-247-863-00	CARBON	22K 5% 1/6W	R732	1-247-856-00	CARBON	11K 5% 1/6W
R660	1-247-863-00	CARBON	22K 5% 1/6W	R733	1-247-831-00	CARBON	1K 5% 1/6W
R661	1-247-853-00	CARBON	8.2K 5% 1/6W	R734	1-247-856-00	CARBON	11K 5% 1/6W
R662	1-247-831-00	CARBON	1K 5% 1/6W	R735	1-247-815-00	CARBON	220 5% 1/6W
R663	1-247-855-00	CARBON	10K 5% 1/6W	R736	1-247-823-00	CARBON	470 5% 1/6W
R664	1-247-872-00	CARBON	51K 5% 1/6W	R738	1-247-813-00	CARBON	180 5% 1/6W
R665	1-247-833-00	CARBON	1.2K 5% 1/6W	R739	1-247-815-00	CARBON	220 5% 1/6W
R666	1-247-815-00	CARBON	220 5% 1/6W	R740	1-247-829-00	CARBON	820 5% 1/6W
R667	1-247-827-00	CARBON	680 5% 1/6W	R741	1-247-813-00	CARBON	180 5% 1/6W
R668	1-247-863-00	CARBON	22K 5% 1/6W	R742	1-247-885-00	CARBON	180K 5% 1/6W
R669	1-247-853-00	CARBON	8.2K 5% 1/6W	R743	1-247-817-00	CARBON	270 5% 1/6W
R670	1-247-855-00	CARBON	10K 5% 1/6W	R744	1-247-803-00	CARBON	68 5% 1/6W
R671	1-247-813-00	CARBON	180 5% 1/6W	R745	1-247-831-00	CARBON	1K 5% 1/6W
R673	1-247-855-00	CARBON	10K 5% 1/6W	R746	1-247-835-00	CARBON	1.5K 5% 1/6W
R674	1-247-843-00	CARBON	3.3K 5% 1/6W	R747	1-247-827-00	CARBON	680 5% 1/6W
R675	1-247-839-00	CARBON	2.2K 5% 1/6W	R748	1-247-823-00	CARBON	470 5% 1/6W
R676	1-247-823-00	CARBON	470 5% 1/6W	R750	1-247-839-00	CARBON	2.2K 5% 1/6W
R678	1-247-843-00	CARBON	3.3K 5% 1/6W	R751	1-247-867-00	CARBON	33K 5% 1/6W
R679	1-247-871-00	CARBON	47K 5% 1/6W	R752	1-247-855-00	CARBON	10K 5% 1/6W
R680	1-247-831-00	CARBON	1K 5% 1/6W	R753	1-247-825-00	CARBON	560 5% 1/6W
R681	1-247-863-00	CARBON	22K 5% 1/6W	R754	1-247-831-00	CARBON	1K 5% 1/6W
R683	1-247-823-00	CARBON	470 5% 1/6W	R755	1-247-811-00	CARBON	150 5% 1/6W
R684	1-247-827-00	CARBON	680 5% 1/6W	R756	1-247-863-00	CARBON	22K 5% 1/6W
R701	1-247-837-00	CARBON	1.8K 5% 1/6W	R757	1-247-863-00	CARBON	22K 5% 1/6W

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description	Remark
R758	1-247-855-00	CARBON 10K 5%	1/6W
R759	1-247-855-00	CARBON 10K 5%	1/6W
R760	1-247-839-00	CARBON 2.2K 5%	1/6W
R761	1-247-831-00	CARBON 1K 5%	1/6W
R762	1-247-827-00	CARBON 680 5%	1/6W
R763	1-247-855-00	CARBON 10K 5%	1/6W
R765	1-247-855-00	CARBON 10K 5%	1/6W
R766	1-247-839-00	CARBON 2.2K 5%	1/6W
R801	1-247-851-00	CARBON 6.8K 5%	1/6W
R802	1-247-847-00	CARBON 4.7K 5%	1/6W
R803	1-247-879-00	CARBON 100K 5%	1/6W
R804	1-247-847-00	CARBON 4.7K 5%	1/6W
R901	1-247-883-00	CARBON 150K 5%	1/6W
R903	1-247-879-00	CARBON 100K 5%	1/6W
R905	1-247-861-00	CARBON 18K 5%	1/6W
R906	1-247-869-00	CARBON 39K 5%	1/6W
R907	1-247-847-00	CARBON 4.7K 5%	1/6W
R908	1-247-855-00	CARBON 10K 5%	1/6W
R909	1-247-839-00	CARBON 2.2K 5%	1/6W
R910	1-247-871-00	CARBON 47K 5%	1/6W
R912	1-247-855-00	CARBON 10K 5%	1/6W
R913	1-247-849-00	CARBON 5.6K 5%	1/6W
R915	1-247-867-00	CARBON 33K 5%	1/6W
R916	1-247-867-00	CARBON 33K 5%	1/6W
R917	1-247-843-00	CARBON 3.3K 5%	1/6W
R918	1-247-855-00	CARBON 10K 5%	1/6W
R919	1-247-849-00	CARBON 5.6K 5%	1/6W
R920	1-247-855-00	CARBON 10K 5%	1/6W
R921	1-247-855-00	CARBON 10K 5%	1/6W
R922	1-247-847-00	CARBON 4.7K 5%	1/6W

VARIABLE RESISTOR

RV103	1-228-996-00	RES, ADJ, CARBON 47K
RV104	1-228-989-00	RES, ADJ, CARBON 470
RV201	1-228-993-00	RES, ADJ, CARBON 4.7K
RV203	1-228-994-00	RES, ADJ, CARBON 10K
RV204	1-228-995-00	RES, ADJ, CARBON 22K
RV207	1-228-989-00	RES, ADJ, CARBON 470
RV208	1-228-995-00	RES, ADJ, CARBON 22K
RV301	1-228-993-00	RES, ADJ, CARBON 4.7K
RV401	1-228-991-00	RES, ADJ, CARBON 2.2K
RV402	1-228-996-00	RES, ADJ, CARBON 47K
RV403	1-228-994-00	RES, ADJ, CARBON 10K
RV404	1-228-990-00	RES, ADJ, CARBON 1K
RV501	1-228-995-00	RES, ADJ, CARBON 22K
RV502	1-228-995-00	RES, ADJ, CARBON 22K
RV503	1-228-995-00	RES, ADJ, CARBON 22K
RV504	1-228-995-00	RES, ADJ, CARBON 22K
RV701	1-228-989-00	RES, ADJ, CARBON 470
RV702	1-228-991-00	RES, ADJ, CARBON 2.2K

TRANSFORMER

T101	1-426-141-00	COIL (EQT)
------	--------------	------------

Ref.No	Part No.	Description	Remark
T301	1-426-070-00	COIL (EQT)	
T401	1-235-216-00	FILTER, BAND PASS	
T402	1-235-220-00	B.P.F	
T403	1-404-410-00	COIL, TRAP	

CRYSTAL

X401	1-527-396-00	CRYSTAL, OSC
------	--------------	--------------

*1-615-666-11 VJ-2 BOARD

CAPACITOR

C449	1-102-978-00	CERAMIC 220PF	5%	50V
------	--------------	---------------	----	-----

DIODE

D502	8-719-000-06	DIODE MC921
------	--------------	-------------

TRANSISTOR

Q501	8-729-900-89	TRANSISTOR DTC144ES
------	--------------	---------------------

RESISTOR

R504	1-247-887-00	CARBON 220K	5%	1/6W
R505	1-247-863-00	CARBON 22K	5%	1/6W
R543	1-247-863-00	CARBON 22K	5%	1/6W

*A-6711-644-A RP-24 BOARD, COMPLETE

*3-691-752-01 CASE (MAIN), SHIELD, RP
*3-691-753-02 LID, SHIELD CASE, RP
*3-691-754-02 LID, REAR, SHIELD CASE, RP

CAPACITOR

C003	1-123-821-00	ELECT 47MF	20%	16V
C005	1-161-013-00	CERAMIC 0.01MF	10%	25V
C006	1-161-057-00	CERAMIC 0.033MF	10%	25V
C007	1-161-057-00	CERAMIC 0.033MF	10%	25V
C008	1-161-057-00	CERAMIC 0.033MF	10%	25V
C009	1-123-821-00	ELECT 47MF	20%	16V
C010	1-161-057-00	CERAMIC 0.033MF	10%	25V
C011	1-123-821-00	ELECT 47MF	20%	16V
C014	1-161-013-00	CERAMIC 0.01MF	10%	25V
C015	1-123-821-00	ELECT 47MF	20%	16V
C016	1-161-013-00	CERAMIC 0.01MF	10%	25V
C017	1-161-057-00	CERAMIC 0.033MF	10%	25V
C018	1-161-057-00	CERAMIC 0.033MF	10%	25V
C019	1-161-057-00	CERAMIC 0.033MF	10%	25V
C020	1-123-619-00	ELECT 4.7MF	20%	50V
C021	1-123-616-00	ELECT 4.7MF	20%	25V
C022	1-123-610-00	ELECT 0.47MF	20%	50V

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description	Remark
C023	1-102-953-00	CERAMIC 18PF	5% 50V
C024	1-123-616-00	ELECT 4.7MF	20% 25V
C025	1-123-610-00	ELECT 0.47MF	20% 50V
C026	1-102-965-00	CERAMIC 39PF	5% 50V
C027	1-123-616-00	ELECT 4.7MF	20% 25V
C028	1-123-610-00	ELECT 0.47MF	20% 50V
C029	1-102-953-00	CERAMIC 18PF	5% 50V
C030	1-161-013-00	CERAMIC 0.01MF	10% 25V
C031	1-161-013-00	CERAMIC 0.01MF	10% 25V
C032	1-161-039-00	CERAMIC 0.001MF	10% 25V
C033	1-161-039-00	CERAMIC 0.001MF	10% 25V
C035	1-123-821-00	ELECT 47MF	20% 16V
C036	1-161-013-00	CERAMIC 0.01MF	10% 25V
C037	1-161-013-00	CERAMIC 0.01MF	10% 25V
C038	1-161-013-00	CERAMIC 0.01MF	10% 25V
C039	1-161-013-00	CERAMIC 0.01MF	10% 25V
C040	1-161-057-00	CERAMIC 0.033MF	10% 25V
C041	1-161-039-00	CERAMIC 0.001MF	10% 25V
C042	1-161-039-00	CERAMIC 0.001MF	10% 25V
C043	1-130-499-51	MYLAR 0.22MF	5% 50V
C044	1-123-821-00	ELECT 47MF	20% 16V
C045	1-123-610-00	ELECT 0.47MF	20% 50V
C047	1-123-610-00	ELECT 0.47MF	20% 50V
C048	1-123-610-00	ELECT 0.47MF	20% 50V
C050	1-123-610-00	ELECT 0.47MF	20% 50V
C051	1-161-057-00	CERAMIC 0.033MF	10% 25V
C052	1-123-616-00	ELECT 4.7MF	20% 25V
C053	1-101-880-00	CERAMIC 47PF	5% 50V
C054	1-161-057-00	CERAMIC 0.033MF	10% 25V
C055	1-161-039-00	CERAMIC 0.001MF	10% 25V
C056	1-161-039-00	CERAMIC 0.001MF	10% 25V
C057	1-161-013-00	CERAMIC 0.01MF	10% 25V
C058	1-123-610-00	ELECT 0.47MF	20% 50V
C059	1-102-945-00	CERAMIC 8PF	0.5PF 50V
C061	1-161-039-00	CERAMIC 0.001MF	10% 25V
C062	1-161-039-00	CERAMIC 0.001MF	10% 25V
C063	1-161-013-00	CERAMIC 0.01MF	10% 25V
C064	1-123-821-00	ELECT 47MF	20% 16V
C067	1-123-619-00	ELECT 4.7MF	20% 50V
C072	1-101-004-00	CERAMIC 0.01MF	50V

CONNECTOR

CN210	*1-564-032-41	PIN, CONNECTOR 7P
CN211	*1-560-900-00	PIN, CONNECTOR 12P
CN212	*1-508-850-00	PIN, CONNECTOR 12P
CN213	*1-564-030-00	PIN, CONNECTOR 5P
CN214	*1-564-027-00	PIN, CONNECTOR 2P

IC

IC001	8-758-620-00	IC CX-862
IC002	8-759-906-30	IC CX-863
IC004	8-759-240-30	IC TC4030BP

Ref.No	Part No.	Description	Remark
<u>COIL</u>			
L001	1-408-405-00	MICRO INDUCTOR 4.7UH	
L002	1-408-405-00	MICRO INDUCTOR 4.7UH	
L003	1-410-293-11	MICRO INDUCTOR 0.47UH	
L004	1-410-074-51	MICRO INDUCTOR 0.27UH	
L005	1-410-293-11	MICRO INDUCTOR 0.47UH	
L006	1-408-425-00	MICRO INDUCTOR 220UH	
L007	1-408-425-00	MICRO INDUCTOR 220UH	
L008	1-408-413-00	MICRO INDUCTOR 22UH	
L009	1-408-605-00	MICRO INDUCTOR 15UH	
L010	1-408-413-00	MICRO INDUCTOR 22UH	
L011	1-408-425-00	MICRO INDUCTOR 220UH	
L012	1-408-878-00	MICRO INDUCTOR 0.33UH	
L013	1-408-411-00	MICRO INDUCTOR 15UH	

TRANSISTOR

Q001	8-729-967-32	TRANSISTOR 2SC2673
Q002	8-729-204-83	TRANSISTOR 2SA1048-GR
Q003	8-729-245-83	TRANSISTOR 2SC2458
Q004	8-729-245-83	TRANSISTOR 2SC2458
Q005	8-729-245-83	TRANSISTOR 2SC2458
Q006	8-729-245-83	TRANSISTOR 2SC2458
Q007	8-729-245-83	TRANSISTOR 2SC2458
Q009	8-729-245-83	TRANSISTOR 2SC2458
Q010	8-729-245-83	TRANSISTOR 2SC2458
Q011	8-729-900-33	TRANSISTOR DTC144EF
Q013	8-729-245-83	TRANSISTOR 2SC2458
Q014	8-729-245-83	TRANSISTOR 2SC2458
Q015	8-729-245-83	TRANSISTOR 2SC2458

RESISTOR

R002	1-247-833-00	CARBON	1.2K	5%	1/6W
R003	1-247-821-00	CARBON	390	5%	1/6W
R004	1-247-831-00	CARBON	1K	5%	1/6W
R005	1-247-815-00	CARBON	220	5%	1/6W
R006	1-247-831-00	CARBON	1K	5%	1/6W
R007	1-247-815-00	CARBON	220	5%	1/6W
R008	1-247-823-00	CARBON	470	5%	1/6W
R009	1-247-831-00	CARBON	1K	5%	1/6W
R010 A	1-212-853-81	FUSIBLE	638	5%	1/4W F
R011	1-247-839-00	CARBON	2.2K	5%	1/6W
R012	1-247-853-00	CARBON	8.2K	5%	1/6W
R013	1-247-855-00	CARBON	10K	5%	1/6W
R014	1-247-863-00	CARBON	22K	5%	1/6W
R015	1-247-851-00	CARBON	6.8K	5%	1/6W
R017	1-247-835-00	CARBON	1.5K	5%	1/6W
R018	1-247-835-00	CARBON	1.5K	5%	1/6W
R019	1-247-835-00	CARBON	1.5K	5%	1/6W
R020	1-247-827-00	CARBON	680	5%	1/6W
R021	1-247-867-00	CARBON	33K	5%	1/6W
R022	1-247-867-00	CARBON	33K	5%	1/6W
R023	1-247-831-00	CARBON	1K	5%	1/6W

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque **A** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description	6.8K	5%	1/6W
R024	1-247-851-00	CARBON	6.8K	5%	1/6W
R026	1-247-867-00	CARBON	33K	5%	1/6W
R027	1-247-831-00	CARBON	1K	5%	1/6W
R028	1-247-851-00	CARBON	6.8K	5%	1/6W
R029	1-247-875-00	CARBON	68K	5%	1/6W
R030	1-247-831-00	CARBON	1K	5%	1/6W
R031	1-247-875-00	CARBON	68K	5%	1/6W
R032	1-247-851-00	CARBON	6.8K	5%	1/6W
R038	1-247-841-00	CARBON	2.7K	5%	1/6W
R039	1-247-841-00	CARBON	2.7K	5%	1/6W
R040	1-247-859-00	CARBON	15K	5%	1/6W
R041	1-247-865-00	CARBON	27K	5%	1/6W
R042	1-247-847-00	CARBON	4.7K	5%	1/6W
R043	1-247-867-00	CARBON	33K	5%	1/6W
R044	1-247-835-00	CARBON	1.5K	5%	1/6W
R045	1-247-867-00	CARBON	33K	5%	1/6W
R046	1-247-875-00	CARBON	68K	5%	1/6W
R047	1-247-831-00	CARBON	1K	5%	1/6W
R048	1-247-851-00	CARBON	6.8K	5%	1/6W
R050	1-247-847-00	CARBON	4.7K	5%	1/6W
R051	1-247-847-00	CARBON	4.7K	5%	1/6W
R052	1-247-867-00	CARBON	33K	5%	1/6W
R053	1-247-875-00	CARBON	68K	5%	1/6W
R054	1-247-867-00	CARBON	33K	5%	1/6W
R055	1-247-875-00	CARBON	68K	5%	1/6W
R056	1-247-867-00	CARBON	33K	5%	1/6W
R057	1-247-875-00	CARBON	68K	5%	1/6W
R058	1-247-875-00	CARBON	68K	5%	1/6W
R061	1-247-867-00	CARBON	33K	5%	1/6W
R062	1-247-875-00	CARBON	68K	5%	1/6W
R067	1-247-831-00	CARBON	1K	5%	1/6W
R070	1-247-115-00	CARBON	220	5%	1/4W
R071	1-247-855-00	CARBON	10K	5%	1/6W
R072	1-247-851-00	CARBON	6.8K	5%	1/6W
R073	1-247-843-00	CARBON	3.3K	5%	1/6W
R074	1-247-831-00	CARBON	1K	5%	1/6W
R079	1-247-783-00	CARBON	10	5%	1/6W
R080	1-247-783-00	CARBON	10	5%	1/6W
R081	1-247-831-00	CARBON	1K	5%	1/6W
R084	1-247-807-00	CARBON	100	5%	1/6W
R086	1-247-807-00	CARBON	100	5%	1/6W
R087	1-247-807-00	CARBON	100	5%	1/6W

VARIABLE RESISTOR

RV001	1-228-920-00	RES, ADJ, CARBON 2.2K
RV002	1-228-920-00	RES, ADJ, CARBON 2.2K
RV003	1-228-920-00	RES, ADJ, CARBON 2.2K
RV004	1-228-920-00	RES, ADJ, CARBON 2.2K
RV005	1-228-920-00	RES, ADJ, CARBON 2.2K
RV006	1-228-920-00	RES, ADJ, CARBON 2.2K
RV007	1-228-920-00	RES, ADJ, CARBON 2.2K
RV008	1-228-919-00	RES, ADJ, CARBON 1K

Ref.No	Part No.	Description	Remark
*A-6713-226-A	AU-13 BOARD, COMPLETE	*****	
*3-691-760-01	LID, REAR, SHIELD CASE (1), AU		
*3-691-762-01	LID, SHIELD CASE (2), AU		
*3-691-763-01	LID, REAR, SHIELD CASE (2), AU		
CAPACITOR			
C101	1-123-333-00	ELECT	100MF 20% 16V
C102	1-123-356-00	ELECT	10MF 20% 16V
C103	1-123-306-00	ELECT	47MF 20% 10V
C105	1-130-495-00	MYLAR	0.1MF 5% 50V
C106	1-123-356-00	ELECT	10MF 20% 16V
C107	1-123-356-00	ELECT	10MF 20% 16V
C109	1-130-487-00	MYLAR	0.022MF 5% 50V
C110	1-123-330-00	ELECT	22MF 20% 16V
C111	1-123-306-00	ELECT	47MF 20% 6.3V
C112	1-123-380-00	ELECT	1MF 20% 50V
C113	1-102-980-00	CERAMIC	270PF 5% 50V
C114	1-130-471-00	MYLAR	0.001MF 5% 50V
C115	1-130-472-00	MYLAR	0.0012MF 5% 50V
C116	1-130-471-00	MYLAR	0.001MF 5% 50V
C117	1-123-330-00	ELECT	22MF 20% 16V
C118	1-123-369-00	ELECT	4.7MF 20% 25V
C119	1-130-485-00	MYLAR	0.015MF 5% 50V
C120	1-123-356-00	ELECT	10MF 20% 16V
C121	1-123-356-00	ELECT	10MF 20% 16V
C122	1-123-333-00	ELECT	100MF 20% 16V
C123	1-123-356-00	ELECT	10MF 20% 16V
C124	1-130-475-00	MYLAR	0.0022MF 5% 50V
C125	1-123-356-00	ELECT	10MF 20% 16V
C126	1-130-489-00	MYLAR	0.033MF 5% 50V
C127	1-130-484-00	MYLAR	0.012MF 5% 50V
C128	1-130-484-00	MYLAR	0.012MF 5% 50V
C129	1-123-356-00	ELECT	10MF 20% 16V
C130	1-130-471-00	MYLAR	0.001MF 5% 50V
C131	1-130-479-00	MYLAR	0.0047MF 5% 50V
C132	1-123-381-00	ELECT	2.2MF 20% 50V
C133	1-107-169-00	MICA	100PF 5% 500V
C134	1-123-369-00	ELECT	4.7MF 20% 25V
C135	1-123-356-00	ELECT	10MF 20% 16V
C136	1-102-074-00	CERAMIC	0.001MF 10% 50V
C137	1-102-963-00	CERAMIC	33PF 5% 50V
C301	1-123-356-00	ELECT	10MF 20% 16V
C302	1-136-049-11	FILM	0.0047MF 10% 630V
C303	1-130-477-00	MYLAR	0.0033MF 5% 50V
C304	1-130-479-00	MYLAR	0.0047MF 5% 50V
C305	1-123-332-00	ELECT	47MF 20% 16V
C306	1-123-356-00	ELECT	10MF 20% 16V
C307	1-123-330-00	ELECT	22MF 20% 16V
C308	1-123-330-00	ELECT	22MF 20% 16V
C401	1-123-356-00	ELECT	10MF 20% 16V
C402	1-123-306-00	ELECT	47MF 20% 10V

When indicating parts by reference number, please include the board name.

AU-13

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
C403	1-130-471-00	MYLAR	0.001MF	5%	50V		
C404	1-123-306-00	ELECT	47MF	20%	10V		
C405	1-102-824-00	CERAMIC	470PF	5%	50V		
C406	1-123-356-00	ELECT	10MF	20%	16V		
C407	1-123-356-00	ELECT	10MF	20%	16V		
C408	1-123-356-00	ELECT	10MF	20%	16V		
C409	1-123-356-00	ELECT	10MF	20%	16V		
C410	1-123-356-00	ELECT	10MF	20%	16V		
C411	1-123-330-00	ELECT	22MF	20%	16V		
C601	1-161-013-00	CERAMIC	0.01MF	10%	25V		
C602	1-161-013-00	CERAMIC	0.01MF	10%	25V		
C603	1-123-306-00	ELECT	47MF	20%	10V		
C604	1-161-013-00	CERAMIC	0.01MF	10%	25V		
C605	1-123-306-00	ELECT	47MF	20%	10V		
C606	1-161-013-00	CERAMIC	0.01MF	10%	25V		
C607	1-123-333-00	ELECT	100MF	20%	25V		
C608	1-124-471-00	ELECT	1000MF	20%	6.3V		
C609	1-124-471-00	ELECT	1000MF	20%	6.3V		
C610	1-123-356-00	ELECT	10MF	20%	16V		
C701	1-123-307-00	ELECT	100MF	20%	10V		
C702	1-123-382-00	ELECT	3.3MF	20%	50V		
C703	1-161-059-00	CERAMIC	0.047MF	10%	50V		
C704	1-125-388-11	DOUBLE LAYERS	0.1F				
C705	1-161-013-00	CERAMIC	0.01MF	10%	25V		
<u>CONNECTOR</u>							
CN351	*1-560-891-00	PIN, CONNECTOR	3P				
CN352	*1-560-892-00	PIN, CONNECTOR	4P				
CN353	*1-560-893-00	PIN, CONNECTOR	5P				
CN354	*1-560-896-00	PIN, CONNECTOR	8P				
CN355	*1-560-898-00	PIN, CONNECTOR	10P				
CN356	*1-560-891-00	PIN, CONNECTOR	3P				
CN357	*1-560-891-00	PIN, CONNECTOR	3P				
CN358	*1-560-892-00	PIN, CONNECTOR	4P				
CN359	*1-560-894-00	PIN, CONNECTOR	6P				
CN360	*1-560-894-00	PIN, CONNECTOR	6P				
<u>DIODE</u>							
D101	8-719-911-19	DIODE	1SS119				
D102	8-719-911-19	DIODE	1SS119				
D105	8-719-911-19	DIODE	1SS119				
D106	8-719-911-19	DIODE	1SS119				
D107	8-719-911-19	DIODE	1SS119				
D108	8-719-911-19	DIODE	1SS119				
D109	8-719-911-19	DIODE	1SS119				
D301	8-719-911-19	DIODE	1SS119				
D302	8-719-100-57	DIODE	RD10EB2				
D303	8-719-100-57	DIODE	RD10EB2				
D701	8-719-812-31	DIODE	TLR123				
D705	8-719-100-31	DIODE	RD5.1EB3				
D706	8-719-911-19	DIODE	1SS119				
<u>IC</u>							
IC101	8-759-800-79	IC	LA7048				
IC103	8-759-145-58	IC	UPC4558C				
IC401	8-752-006-10	IC	CX20061				
IC601	8-759-208-94	IC	CX-894				
IC602	8-752-003-90	IC	CX20039				
<u>COIL</u>							
L101	1-407-508-00	MICRO INDUCTOR	22MMH				
L102	1-407-506-00	MICRO INDUCTOR	15MMH				
L301	1-408-429-00	MICRO INDUCTOR	470UH				
L701	1-408-421-00	MICRO INDUCTOR	100UH				
<u>INDUCTOR</u>							
LV301	1-408-713-00	VARIABLE INDUCTOR					
<u>TRANSISTOR</u>							
Q101	8-729-245-83	TRANSISTOR	2SC2458				
Q102	8-729-245-83	TRANSISTOR	2SC2458				
Q103	8-729-900-89	TRANSISTOR	DTC144ES				
Q104	8-729-245-83	TRANSISTOR	2SC2458				
Q105	8-729-245-83	TRANSISTOR	2SC2458				
Q106	8-729-900-89	TRANSISTOR	DTC144ES				
Q107	8-729-900-63	TRANSISTOR	DTA124ES				
Q108	8-729-900-89	TRANSISTOR	DTC144ES				
Q109	8-729-900-63	TRANSISTOR	DTA124ES				
Q110	8-729-900-89	TRANSISTOR	DTC144ES				
Q111	8-729-245-83	TRANSISTOR	2SC2458				
Q113	8-729-245-83	TRANSISTOR	2SC2458				
Q114	8-729-900-36	TRANSISTOR	DTC124ES				
Q115	8-729-900-65	TRANSISTOR	DTA144ES				
Q116	8-729-900-89	TRANSISTOR	DTC144ES				
Q301	8-729-245-83	TRANSISTOR	2SC2458				
Q302	8-729-967-32	TRANSISTOR	2SC2673				
Q303	8-729-177-32	TRANSISTOR	2SD773				
Q304	8-729-113-33	TRANSISTOR	2SB733-4				
Q305	8-729-177-32	TRANSISTOR	2SD773				
Q401	8-729-908-62	TRANSISTOR	2SD786				
Q402	8-729-245-83	TRANSISTOR	2SC2458				
Q601	8-729-900-89	TRANSISTOR	DTC144ES				
Q602	8-729-245-83	TRANSISTOR	2SC2458				
Q701	8-729-245-83	TRANSISTOR	2SC2458				
Q702	8-729-245-83	TRANSISTOR	2SC2458				
Q703	8-729-177-43	TRANSISTOR	2SD774				
Q704	8-729-204-83	TRANSISTOR	2SA1048-GR				
Q801	8-729-900-89	TRANSISTOR	DTC144ES				
<u>RESISTOR</u>							
R101	1-247-857-00	CARBON	12K	5%	1/6W		
R102	1-247-847-00	CARBON	4.7K	5%	1/6W		
R103	1-247-809-00	CARBON	120	5%	1/6W		
R104	1-247-863-00	CARBON	22K	5%	1/6W		
R105	1-247-839-00	CARBON	2.2K	5%	1/6W		

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description	Quantity	Power	Voltage	Remark
R106	1-247-879-00	CARBON	100K	5%	1/6W	
R107	1-247-843-00	CARBON	3.3K	5%	1/6W	
R108	1-247-855-00	CARBON	10K	5%	1/6W	
R109	1-247-859-00	CARBON	15K	5%	1/6W	
R110	1-247-831-00	CARBON	1K	5%	1/6W	
R112	1-247-855-00	CARBON	10K	5%	1/6W	
R113	1-247-867-00	CARBON	33K	5%	1/6W	
R114	1-202-465-00	SOLID	2.7M	5%	1/4W	
R115	1-247-783-00	CARBON	10	5%	1/6W	
R116	1-247-867-00	CARBON	33K	5%	1/6W	
R118	1-247-863-00	CARBON	22K	5%	1/6W	
R119	1-247-875-00	CARBON	68K	5%	1/6W	
R120	1-247-879-00	CARBON	100K	5%	1/6W	
R121	1-247-861-00	CARBON	18K	5%	1/6W	
R122	1-247-791-00	CARBON	22	5%	1/6W	
R123	1-247-855-00	CARBON	10K	5%	1/6W	
R124	1-247-855-00	CARBON	10K	5%	1/6W	
R125	1-247-847-00	CARBON	4.7K	5%	1/6W	
R126	1-247-831-00	CARBON	1K	5%	1/6W	
R127	1-247-887-00	CARBON	220K	5%	1/6W	
R128	1-247-871-00	CARBON	47K	5%	1/6W	
R129	1-247-863-00	CARBON	22K	5%	1/6W	
R130	1-247-887-00	CARBON	220K	5%	1/6W	
R131	1-247-859-00	CARBON	15K	5%	1/6W	
R132	1-247-871-00	CARBON	47K	5%	1/6W	
R133	1-247-863-00	CARBON	22K	5%	1/6W	
R134	1-247-855-00	CARBON	10K	5%	1/6W	
R135	1-247-855-00	CARBON	10K	5%	1/6W	
R136	1-247-839-00	CARBON	2.2K	5%	1/6W	
R137	1-247-861-00	CARBON	18K	5%	1/6W	
R138	1-247-841-00	CARBON	2.7K	5%	1/6W	
R139	1-247-857-00	CARBON	12K	5%	1/6W	
R141	1-247-859-00	CARBON	15K	5%	1/6W	
R142	1-247-863-00	CARBON	22K	5%	1/6W	
R143	1-247-839-00	CARBON	2.2K	5%	1/6W	
R144	1-247-831-00	CARBON	1K	5%	1/6W	
R145	1-247-863-00	CARBON	22K	5%	1/6W	
R147	1-247-855-00	CARBON	10K	5%	1/6W	
R148	1-247-879-00	CARBON	100K	5%	1/6W	
R149	1-247-819-00	CARBON	330	5%	1/6W	
R301	1-247-843-00	CARBON	3.3K	5%	1/6W	
R302	1-247-843-00	CARBON	3.3K	5%	1/6W	
R303	1-247-879-00	CARBON	100K	5%	1/6W	
R304	1-247-859-00	CARBON	15K	5%	1/6W	
R305	1-247-855-00	CARBON	10K	5%	1/6W	
R306	1-247-855-00	CARBON	10K	5%	1/6W	
R307	1-247-847-00	CARBON	4.7K	5%	1/6W	
R308	1-247-771-00	CARBON	3.3	5%	1/8W	F
R309	1-247-843-00	CARBON	3.3K	5%	1/6W	
R310	1-247-771-00	CARBON	3.3	5%	1/8W	F
R401	1-247-887-00	CARBON	220K	5%	1/6W	
R402	1-247-879-00	CARBON	100K	5%	1/6W	
R403	1-247-831-00	CARBON	1K	5%	1/6W	

Ref.No	Part No.	Description	Quantity	Power	Voltage	Remark
R404	1-247-855-00	CARBON	10K	5%	1/6W	
R405	1-247-831-00	CARBON	1K	5%	1/6W	
R406	1-247-855-00	CARBON	10K	5%	1/6W	
R407	1-247-847-00	CARBON	4.7K	5%	1/6W	
R408	1-247-855-00	CARBON	10K	5%	1/6W	
R409	1-247-879-00	CARBON	100K	5%	1/6W	
R410	1-247-855-00	CARBON	10K	5%	1/6W	
R411	1-247-807-00	CARBON	100	5%	1/8W	F
R412	1-247-807-00	CARBON	100	5%	1/6W	
R413	1-247-831-00	CARBON	1K	5%	1/6W	
R414	1-247-879-00	CARBON	100K	5%	1/6W	
R601	1-247-823-00	CARBON	470	5%	1/6W	
R602	1-247-869-00	CARBON	39K	5%	1/6W	
R604	1-247-804-00	CARBON	75	5%	1/6W	
R605	1-247-804-00	CARBON	75	5%	1/6W	
R606	1-247-823-00	CARBON	470	5%	1/6W	
R607	1-247-855-00	CARBON	10K	5%	1/6W	
R608	1-247-855-00	CARBON	10K	5%	1/6W	
R610	1-247-855-00	CARBON	10K	5%	1/6W	
R611	1-247-855-00	CARBON	10K	5%	1/6W	
R612	1-247-847-00	CARBON	4.7K	5%	1/6W	
R615	1-247-855-00	CARBON	10K	5%	1/6W	
R616	1-247-871-00	CARBON	47K	5%	1/6W	
R701	1-247-807-00	CARBON	100	5%	1/6W	
R702	1-247-867-00	CARBON	33K	5%	1/6W	
R703	1-247-874-00	CARBON	62K	5%	1/6W	
R704	1-247-872-00	CARBON	51K	5%	1/6W	
R705	1-247-873-00	CARBON	56K	5%	1/6W	
R706	1-247-831-00	CARBON	1K	5%	1/6W	
R707	1-247-869-00	CARBON	39K	5%	1/6W	
R708	1-247-881-00	CARBON	120K	5%	1/6W	
R709	1-247-879-00	CARBON	100K	5%	1/6W	
R801	1-247-855-00	CARBON	10K	5%	1/6W	
VARIABLE RESISTOR						
RV101	1-228-994-00	RES, ADJ, CARBON 10K				
RV102	1-228-989-00	RES, ADJ, CARBON 470				
RV104	1-228-635-00	RES, ADJ, METAL GLAZE 220K				
RELAY						
RY101	1-515-418-00	RELAY				
RY301	1-515-513-00	RELAY				
TRANSFORMER						
T301	1-433-236-00	TRANSFORMER, OSCILLATOR				

*A-6715-264-A SS-53 BOARD, COMPLETE						

CAPACITOR						
C401	1-102-518-00	CERAMIC	33PF	5%	50V	

When indicating parts by reference number, please include the board name.

SS-53

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
C402	1-102-518-00	CERAMIC	33PF 5%	50V	C536	1-123-607-00	ELECT 0.1MF 20% 50V
C403	1-161-059-00	CERAMIC	0.047MF 10%	25V	C537	1-123-612-00	ELECT 2.2MF 20% 50V
C404	1-123-822-00	ELECT	47MF 20%	10V	C538	1-101-059-00	CERAMIC 510PF 5% 50V
C405	1-161-059-00	CERAMIC	0.047MF 10%	25V	C539	1-131-375-00	TANTALUM 4.7MF 10% 10V
C406	1-123-306-00	ELECT	47MF 20%	10V	C540	1-102-978-00	CERAMIC 220PF 5% 50V
C407	1-123-618-00	ELECT	22MF 20%	6.3V	C541	1-161-059-00	CERAMIC 0.047MF 10% 25V
C408	1-161-059-00	CERAMIC	0.047MF 10%	25V	C542	1-102-114-00	CERAMIC 470PF 10% 50V
C409	1-161-059-00	CERAMIC	0.047MF 10%	25V	C543	1-123-821-00	ELECT 47MF 20% 16V
C410	1-161-059-00	CERAMIC	0.047MF 10%	25V	C544	1-123-821-00	ELECT 47MF 20% 16V
C411	1-129-794-00	FILM	0.0033MF 5%	100V	C545	1-123-821-00	ELECT 47MF 20% 16V
C412	1-129-794-00	FILM	0.0033MF 5%	100V	C546	1-123-333-00	ELECT 100MF 20% 16V
C413	1-123-611-00	ELECT	1MF 20%	50V	C547	1-130-475-00	MYLAR 0.0022MF 5% 50V
C414	1-102-529-00	CERAMIC	100PF 5%	50V	C548	1-123-661-00	ELECT 100MF 20% 6.3V
C415	1-102-529-00	CERAMIC	100PF 5%	50V	C549	1-131-502-61	TANTALUM 4.7MF 10% 6.3V
C416	1-161-059-00	CERAMIC	0.047MF 10%	25V	C550	1-131-502-61	TANTALUM 4.7MF 10% 6.3V
C417	1-123-616-00	ELECT	4.7MF 20%	25V	C551	1-123-608-00	ELECT 0.22MF 20% 50V
C418	1-123-612-00	ELECT	2.2MF 20%	50V	C552	1-123-821-00	ELECT 47MF 20% 16V
C419	1-123-617-00	ELECT	10MF 20%	16V	C553	1-123-821-00	ELECT 47MF 20% 16V
C501	1-130-483-00	MYLAR	0.01MF 5%	50V	C554	1-130-495-00	MYLAR 0.1MF 5% 50V
C502	1-130-483-00	MYLAR	0.01MF 5%	50V	C556	1-124-475-11	ELECT 470MF 20% 16V
C503	1-123-613-00	ELECT	3.3MF 20%	50V	C557	1-136-162-00	MYLAR 0.056MF 5% 50V
C504	1-130-491-00	MYLAR	0.047MF 5%	50V	C558	1-161-059-00	CERAMIC 0.047MF 10% 25V
C505	1-130-491-00	MYLAR	0.047MF 5%	50V	C559	1-131-383-00	TANTALUM 10MF 10% 6.3V
C506	1-123-613-00	ELECT	3.3MF 20%	50V	C560	1-131-383-00	TANTALUM 10MF 10% 6.3V
C507	1-130-491-00	MYLAR	0.047MF 5%	50V	C561	1-130-772-00	FILM 0.22MF 5% 63V
C508	1-123-613-00	ELECT	3.3MF 20%	50V	C562	1-130-772-00	FILM 0.22MF 5% 63V
C509	1-130-483-00	MYLAR	0.01MF 5%	50V	C563	1-123-616-00	ELECT 4.7MF 20% 25V
C510	1-123-661-00	ELECT	100MF 20%	6.3V	C564	1-123-618-00	ELECT 22MF 20% 6.3V
C511	1-123-661-00	ELECT	100MF 20%	6.3V	C565	1-123-616-00	ELECT 4.7MF 20% 25V
C512	1-102-961-00	CERAMIC	27PF 5%	50V	C567	1-123-618-00	ELECT 22MF 20% 6.3V
C513	1-102-961-00	CERAMIC	27PF 5%	50V	C569	1-123-611-00	ELECT 1MF 20% 50V
C514	1-123-821-00	ELECT	47MF 20%	16V	C570	1-130-479-00	MYLAR 0.0047MF 5% 50V
C515	1-130-772-00	FILM	0.22MF 5%	63V	C571	1-130-478-00	MYLAR 0.0039MF 5% 50V
C516	1-130-493-00	MYLAR	0.068MF 5%	50V	C572	1-130-772-11	FILM 0.22MF 5% 63V
C517	1-123-647-00	ELECT	47MF 20%	6.3V	C701	1-161-013-00	CERAMIC 0.01MF 10% 25V
C518	1-161-054-00	CERAMIC	0.018MF 10%	25V	C704	1-123-611-00	ELECT 1MF 20% 50V
C519	1-161-013-00	CERAMIC	0.01MF 10%	25V	C803	1-130-473-00	MYLAR 0.0015MF 5% 50V
C520	1-108-582-00	MYLAR	0.013MF 5%	50V	C804	1-130-483-00	MYLAR 0.01MF 5% 50V
C521	1-161-042-00	CERAMIC	0.0018MF 10%	25V	C805	1-130-483-00	MYLAR 0.01MF 5% 50V
C522	1-131-356-00	TANTALUM	3.3MF 10%	25V	C806	1-123-822-00	ELECT 47MF 20% 10V
C523	1-161-013-00	CERAMIC	0.01MF 10%	25V	C807	1-161-059-00	CERAMIC 0.047MF 10% 25V
C524	1-161-054-00	CERAMIC	0.018MF 10%	25V	C808	1-102-513-00	CERAMIC 18PF 5% 50V
C525	1-161-059-00	CERAMIC	0.047MF 10%	25V	C809	1-102-513-00	CERAMIC 18PF 5% 50V
C526	1-161-059-00	CERAMIC	0.047MF 10%	25V	C810	1-130-483-00	MYLAR 0.01MF 5% 50V
C527	1-123-612-00	ELECT	2.2MF 20%	50V	C812	1-123-616-00	ELECT 4.7MF 20% 25V
C528	1-123-612-00	ELECT	2.2MF 20%	50V	C813	1-131-404-00	ELECT(SOLID) 0.22MF 10% 25V
C529	1-123-618-00	ELECT	22MF 20%	6.3V	C814	1-131-404-00	ELECT(SOLID) 0.22MF 10% 25V
C530	1-123-647-00	ELECT	47MF 20%	6.3V	C815	1-123-617-00	ELECT 10MF 20% 16V
C531	1-123-616-00	ELECT	4.7MF 20%	25V	C816	1-161-055-00	CERAMIC 0.022MF 20% 25V
C532	1-123-611-00	ELECT	1MF 20%	50V	C817	1-123-661-00	ELECT 100MF 20% 6.3V
C533	1-123-646-00	ELECT	33MF 20%	6.3V	C818	1-161-059-00	CERAMIC 0.047MF 10% 25V
C534	1-161-055-00	CERAMIC	0.022MF 20%	25V	C819	1-123-822-00	ELECT 47MF 20% 10V
C535	1-123-612-00	ELECT	2.2MF 20%	50V	C820	1-136-162-00	MYLAR 0.056MF 5% 50V

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
C821	1-130-477-00	MYLAR	0.0033MF	5%	50V		
C901	1-123-821-00	ELECT	47MF	20%	16V		
C902	1-102-529-00	CERAMIC	100PF	5%	50V		
C903	1-123-613-00	ELECT	3.3MF	20%	50V		
C904	1-130-493-00	MYLAR	0.068MF	5%	50V		
C905	1-161-045-00	CERAMIC	0.0033MF	10%	50V		
C906	1-130-483-00	MYLAR	0.01MF	5%	50V		
C907	1-123-612-00	ELECT	2.2MF	20%	50V		
C908	1-161-039-00	CERAMIC	0.001MF	10%	25V		
C909	1-161-059-00	CERAMIC	0.047MF	10%	25V		
C910	1-123-821-00	ELECT	47MF	20%	16V		
C911	1-123-610-00	ELECT	0.47MF	20%	50V		
C912	1-123-612-00	ELECT	2.2MF	20%	50V		
C913	1-123-822-00	ELECT	47MF	20%	10V		
C914	1-123-617-00	ELECT	10MF	20%	16V		
C915	1-123-617-00	ELECT	10MF	20%	16V		
<u>CONNECTOR</u>							
CN401	*1-560-893-00	PIN, CONNECTOR	5P				
CN402	*1-564-010-11	PIN, CONNECTOR	11P				
CN403	*1-564-008-41	PIN, CONNECTOR	9P				
CN404	*1-560-890-00	PIN, CONNECTOR	2P				
CN405	*1-560-891-00	PIN, CONNECTOR	3P				
CN406	*1-560-890-00	PIN, CONNECTOR	2P				
CN407	*1-560-891-00	PIN, CONNECTOR	3P				
CN409	*1-564-008-21	PIN, CONNECTOR	9P				
CN410	*1-560-890-00	PIN, CONNECTOR	2P				
CN412	*1-564-005-00	PIN, CONNECTOR	6P				
CN414	*1-564-010-21	PIN, CONNECTOR	11P				
CN415	*1-564-005-00	PIN, CONNECTOR	6P				
CN416	*1-564-028-00	PIN, CONNECTOR	3P				
CN417	*1-560-891-00	PIN, CONNECTOR	3P				
CN418	*1-560-891-00	PIN, CONNECTOR	3P				
CN419	*1-560-890-00	PIN, CONNECTOR	2P				
CN420	*1-560-890-00	PIN, CONNECTOR	2P				
CN501	*1-560-890-00	PIN, CONNECTOR	2P				
CN502	*1-564-003-00	PIN, CONNECTOR	4P				
CN503	*1-560-892-00	PIN, CONNECTOR	4P				
CN504	*1-560-466-00	PIN, CONNECTOR	3P				
CN505	*1-564-003-00	PIN, CONNECTOR	4P				
CN506	*1-564-003-00	PIN, CONNECTOR	4P				
CN507	*1-564-003-00	PIN, CONNECTOR	4P				
CN508	*1-564-003-00	PIN, CONNECTOR	4P				
CN509	*1-560-891-00	PIN, CONNECTOR	3P				
CN510	*1-564-028-00	PIN, CONNECTOR	3P				
CN511	*1-560-891-00	PIN, CONNECTOR	3P				
CN801	*1-560-890-00	PIN, CONNECTOR	2P				
CN802	*1-564-003-00	PIN, CONNECTOR	4P				
CN803	*1-564-003-00	PIN, CONNECTOR	4P				
<u>COMPOSITION CIRCUIT BLOCK</u>							
CP804	1-232-761-11	COMPOSITION CIRCUIT BLOCK					
D401	8-719-911-19	DIODE	1SS119				
D402	8-719-911-19	DIODE	1SS119				
D403	8-719-911-19	DIODE	1SS119				
D404	8-719-911-19	DIODE	1SS119				
D405	8-719-911-19	DIODE	1SS119				
D406	8-719-911-19	DIODE	1SS119				
D407	8-719-911-19	DIODE	1SS119				
D409	8-719-911-19	DIODE	1SS119				
D410	8-719-000-06	DIODE	MC921				
D411	8-719-911-19	DIODE	1SS119				
D412	8-719-911-19	DIODE	1SS119				
D413	8-719-911-19	DIODE	1SS119				
D414	8-719-911-19	DIODE	1SS119				
D415	8-719-911-19	DIODE	1SS119				
D501	8-719-911-19	DIODE	1SS119				
D502	8-719-911-19	DIODE	1SS119				
D503	8-719-101-49	DIODE	RO5.1EL1				
D504	8-719-911-19	DIODE	1SS119				
D505	8-719-911-19	DIODE	1SS119				
D506	8-719-000-06	DIODE	MC921				
D507	8-719-000-06	DIODE	MC921				
D508	8-719-911-19	DIODE	1SS119				
D509	8-719-000-06	DIODE	MC921				
D510	8-719-000-06	DIODE	MC921				
D511	8-719-911-19	DIODE	1SS119				
D512	8-719-000-06	DIODE	MC921				
D513	8-719-000-06	DIODE	MC921				
D514	8-719-982-04	DIODE	ERB81-004				
D515	8-719-911-19	DIODE	1SS119				
D516	8-719-911-19	DIODE	1SS119				
D517	8-719-000-12	DIODE	MC931				
D518	8-719-911-19	DIODE	1SS119				
D519	8-719-000-06	DIODE	MC921				
D520	8-719-911-19	DIODE	1SS119				
D521	8-719-910-73	DIODE	HZ7A3L				
D523	8-719-911-19	DIODE	1SS119				
D524	8-719-812-33	DIODE	TLG123A				
D527	8-719-911-19	DIODE	1SS119				
D529	8-719-911-19	DIODE	1SS119				
D530	8-719-911-19	DIODE	1SS119				
D801	8-719-911-19	DIODE	1SS119				
D802	8-719-000-06	DIODE	MC921				
D804	8-719-000-12	DIODE	MC931				
D805	8-719-911-19	DIODE	1SS119				
D806	8-719-000-06	DIODE	MC921				
D807	8-719-000-06	DIODE	MC921				
D808	8-719-911-19	DIODE	1SS119				
D809	8-719-911-19	DIODE	1SS119				
D811	8-719-000-06	DIODE	MC921				
D901	8-719-911-19	DIODE	1SS119				
D902	8-719-911-19	DIODE	1SS119				

When indicating parts by reference number, please include the board name.

SS-53

Ref.No	Part No.	Description
D903	8-719-911-19	DIODE 1SS119
D904	8-719-911-19	DIODE 1SS119
D907	8-719-000-06	DIODE MC921
<u>IC</u>		
IC401	8-759-913-28	IC MB88551-155M
IC402	8-759-602-21	IC M50760-690P
IC403	8-759-800-72	IC LA7205
IC404	8-759-600-24	IC M54543L
IC405	8-759-801-75	IC LM6417E-577
IC406	8-759-133-90	IC UPC339C
IC407	8-759-240-13	IC TC4013BP
IC501	8-751-941-05	IC CX-194B-5
IC502	8-741-109-00	IC BX-1090
IC503	8-743-983-00	IC BX-3983
IC504	8-759-240-51	IC TC4051BP
IC505	8-759-904-94	IC TL494CN
IC506	8-741-013-00	IC BX-1013
IC507	8-759-240-66	IC TC4066BP
IC508	8-743-978-00	IC BX-3978
IC509	8-759-103-93	IC UPC393C
IC510	8-759-240-53	IC TC4053BP
IC511	8-759-240-01	IC TC4001BP
IC512	8-759-240-53	IC TC4053BP
IC513	8-759-240-81	IC TC4081BP
IC514	8-759-240-30	IC TC4030BP
IC515	8-759-240-11	IC TC4011BP
IC516	8-759-345-38	IC HD14538BP
IC517	8-759-240-53	IC TC4053BP
IC518	8-759-132-40	IC UPC324C
IC519	8-759-240-30	IC TC4030BP
IC701	8-759-915-74	IC EMA129
IC801	8-759-913-29	IC MB8851H-572L
IC802	8-759-240-49	IC TC4049BP
IC803	8-759-240-30	IC TC4030BP
IC804	8-759-240-81	IC TC4081BP
IC805	8-759-132-40	IC UPC324C
IC806	8-759-240-71	IC TC4071BP
IC809	8-759-240-66	IC TC4066BP
IC901	8-752-006-90	IC CX20069
IC902	8-759-240-66	IC TC4066BP
<u>COIL</u>		
L401	1-408-421-00	MICRO INDUCTOR 100UH
L501	1-408-857-00	COIL, CHOKE 820UH
L502	1-408-859-00	COIL, CHOKE 220UH
L801	1-408-421-00	MICRO INDUCTOR 100UH
<u>TRANSISTOR</u>		
Q404	8-729-900-33	TRANSISTOR DTC144EF
Q405	8-729-900-39	TRANSISTOR DTA124EF
Q406	8-729-967-32	TRANSISTOR 2SC2673
Q407	8-729-967-32	TRANSISTOR 2SC2673

Remark	Ref.No	Part No.	Description	Remark
	Q408	8-729-967-32	TRANSISTOR 2SC2673	
	Q409	8-729-967-32	TRANSISTOR 2SC2673	
	Q410	8-729-967-32	TRANSISTOR 2SC2673	
	Q413	8-729-116-42	TRANSISTOR 2SD1164	
	Q414	8-729-177-32	TRANSISTOR 2SD773	
	Q415	8-729-116-42	TRANSISTOR 2SD1164	
	Q416	8-729-116-42	TRANSISTOR 2SD1164	
	Q417	8-729-116-42	TRANSISTOR 2SD1164	
	Q418	8-729-177-32	TRANSISTOR 2SD773	
	Q419	8-729-900-89	TRANSISTOR DTC144ES	
	Q420	8-729-245-83	TRANSISTOR 2SC2458	
	Q421	8-729-900-89	TRANSISTOR DTC144ES	
	Q422	8-729-245-83	TRANSISTOR 2SC2458	
	Q423	8-729-967-32	TRANSISTOR 2SC2673	
	Q424	8-729-900-65	TRANSISTOR DTA144ES	
	Q425	8-729-900-89	TRANSISTOR DTC144ES	
	Q426	8-729-900-89	TRANSISTOR DTC144ES	
	Q427	8-729-900-33	TRANSISTOR DTC144EF	
	Q428	8-729-900-89	TRANSISTOR DTC144ES	
	Q501	8-729-178-54	TRANSISTOR 2SC2785-F	
	Q502	8-729-178-54	TRANSISTOR 2SC2785-F	
	Q503	8-729-245-83	TRANSISTOR 2SC2458	
	Q504	8-729-211-81	TRANSISTOR 2SK118	
	Q505	8-729-211-81	TRANSISTOR 2SK118	
	Q506	8-729-211-81	TRANSISTOR 2SK118	
	Q507	8-729-245-83	TRANSISTOR 2SC2458	
	Q508	8-729-177-32	TRANSISTOR 2SD773	
	Q509	8-729-245-83	TRANSISTOR 2SC2458	
	Q510	8-729-245-83	TRANSISTOR 2SC2458	
	Q511	8-729-245-83	TRANSISTOR 2SC2458	
	Q512	8-729-900-89	TRANSISTOR DTC144ES	
	Q513	8-729-245-83	TRANSISTOR 2SC2458	
	Q514	8-729-204-83	TRANSISTOR 2SA1048-GR	
	Q515	8-729-177-23	TRANSISTOR 2SB772	
	Q516	8-729-900-89	TRANSISTOR DTC144ES	
	Q517	8-729-204-83	TRANSISTOR 2SA1048-GR	
	Q518	8-729-100-13	TRANSISTOR 2SC2001	
	Q519	8-729-245-83	TRANSISTOR 2SC2458	
	Q520	8-729-900-80	TRANSISTOR DTC114ES	
	Q521	8-729-900-65	TRANSISTOR DTA144ES	
	Q522	8-729-900-36	TRANSISTOR DTC124ES	
	Q523	8-729-900-61	TRANSISTOR DTA114ES	
	Q524	8-729-900-89	TRANSISTOR DTC144ES	
	Q525	8-729-900-61	TRANSISTOR DTA114ES	
	Q526	8-729-900-61	TRANSISTOR DTA114ES	
	Q527	8-729-900-89	TRANSISTOR DTC144ES	
	Q528	8-729-900-80	TRANSISTOR DTC114ES	
	Q529	8-729-900-89	TRANSISTOR DTC144ES	
	Q530	8-729-900-33	TRANSISTOR DTC144EF	
	Q531	8-729-245-83	TRANSISTOR 2SC2458	
	Q533	8-729-204-83	TRANSISTOR 2SA1048-GR	
	Q701	8-729-900-89	TRANSISTOR DTC144ES	
	Q702	8-729-245-83	TRANSISTOR 2SC2458	

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
Q703	8-729-900-89	TRANSISTOR DTC144ES		R443	1-247-867-00	CARBON 33K 5%	1/6W
Q704	8-729-900-89	TRANSISTOR DTC144ES		R446	1-247-807-00	CARBON 100 5%	1/6W
Q705	8-729-177-32	TRANSISTOR 2SD773		R447	1-247-879-00	CARBON 100K 5%	1/6W
Q708	8-729-900-89	TRANSISTOR DTC144ES		R448	1-247-865-00	CARBON 27K 5%	1/6W
Q709	8-729-900-65	TRANSISTOR DTA144ES		R450	1-247-831-00	CARBON 1K 5%	1/6W
Q710	8-729-245-83	TRANSISTOR 2SC2458		R451	1-247-855-00	CARBON 10K 5%	1/6W
Q801	8-729-245-83	TRANSISTOR 2SC2458		R452	1-247-879-00	CARBON 100K 5%	1/6W
Q802	8-729-900-89	TRANSISTOR DTC144ES		R453	1-247-855-00	CARBON 10K 5%	1/6W
Q803	8-729-900-89	TRANSISTOR DTC144ES		R454	1-247-867-00	CARBON 33K 5%	1/6W
Q804	8-729-204-83	TRANSISTOR 2SA1048-GR		R455	1-247-879-00	CARBON 100K 5%	1/6W
Q805	8-729-900-89	TRANSISTOR DTC144ES		R456	1-247-855-00	CARBON 10K 5%	1/6W
Q806	8-729-900-89	TRANSISTOR DTC144ES		R457	1-247-839-00	CARBON 2.2K 5%	1/6W
Q807	8-729-900-89	TRANSISTOR DTC144ES		R458	1-247-847-00	CARBON 4.7K 5%	1/6W
Q808	8-729-900-89	TRANSISTOR DTC144ES		R459	1-247-847-00	CARBON 4.7K 5%	1/6W
Q809	8-729-900-89	TRANSISTOR DTC144ES		R460	1-247-839-00	CARBON 2.2K 5%	1/6W
Q811	8-729-900-89	TRANSISTOR DTC144ES		R501	1-247-102-00	CARBON 62 5%	1/4W
Q901	8-729-900-89	TRANSISTOR DTC144ES		R502	1-247-863-00	CARBON 22K 5%	1/6W
Q902	8-729-245-83	TRANSISTOR 2SC2458		R503	1-247-863-00	CARBON 22K 5%	1/6W
Q903	8-729-900-89	TRANSISTOR DTC144ES		R504	1-247-855-00	CARBON 10K 5%	1/6W
Q904	8-729-900-80	TRANSISTOR DTC114ES		R505	1-247-851-00	CARBON 6.8K 5%	1/6W
Q905	8-729-204-83	TRANSISTOR 2SA1048-GR		R506	1-247-871-00	CARBON 47K 5%	1/6W
Q906	8-729-245-83	TRANSISTOR 2SC2458		R507	1-247-833-00	CARBON 1.2K 5%	1/6W
Q907	8-729-900-89	TRANSISTOR DTC144ES		R508	1-247-871-00	CARBON 47K 5%	1/6W
<u>RESISTOR</u>				R509	1-247-844-00	CARBON 3.6K 5%	1/6W
R401	1-247-831-00	CARBON 1K 5%	1/6W	R510	1-247-871-00	CARBON 47K 5%	1/6W
R402	1-247-831-00	CARBON 1K 5%	1/6W	R511	1-247-844-00	CARBON 3.6K 5%	1/6W
R403	1-247-831-00	CARBON 1K 5%	1/6W	R512	1-247-090-00	CARBON 20 5%	1/4W
R404	1-247-831-00	CARBON 1K 5%	1/6W	R513	1-247-855-00	CARBON 10K 5%	1/6W
R409	1-247-833-00	CARBON 1.2K 5%	1/6W	R514	1-247-867-00	CARBON 33K 5%	1/6W
R410	1-247-837-00	CARBON 1.8K 5%	1/6W	R515	1-247-855-00	CARBON 10K 5%	1/6W
R411	1-247-837-00	CARBON 1.8K 5%	1/6W	R516	1-247-887-00	CARBON 220K 5%	1/6W
R412	1-247-873-00	CARBON 56K 5%	1/6W	R517	1-247-879-00	CARBON 100K 5%	1/6W
R413	1-247-863-00	CARBON 22K 5%	1/6W	R518	1-247-879-00	CARBON 100K 5%	1/6W
R414	1-247-863-00	CARBON 22K 5%	1/6W	R519	1-247-847-00	CARBON 4.7K 5%	1/6W
R415	1-247-871-00	CARBON 47K 5%	1/6W	R520	1-247-867-00	CARBON 33K 5%	1/6W
R416	1-247-809-00	CARBON 120 5%	1/6W	R521	1-247-883-00	CARBON 150K 5%	1/6W
R417	1-247-829-00	CARBON 820 5%	1/6W	R522	1-247-883-00	CARBON 150K 5%	1/6W
R418	1-247-843-00	CARBON 3.3K 5%	1/6W	R523	1-247-847-00	CARBON 4.7K 5%	1/6W
R419	1-247-855-00	CARBON 10K 5%	1/6W	R524	1-247-855-00	CARBON 10K 5%	1/6W
R420	1-247-863-00	CARBON 22K 5%	1/6W	R525	1-247-883-00	CARBON 150K 5%	1/6W
R421	1-247-855-00	CARBON 10K 5%	1/6W	R526	1-247-867-00	CARBON 33K 5%	1/6W
R422	1-247-807-00	CARBON 100 5%	1/6W	R527	1-247-895-00	CARBON 470K 5%	1/6W
R423	1-247-867-00	CARBON 33K 5%	1/6W	R528	1-247-849-00	CARBON 5.6K 5%	1/6W
R424	1-247-831-00	CARBON 1K 5%	1/6W	R529	1-247-879-00	CARBON 100K 5%	1/6W
R425	1-247-903-00	CARBON 1M 5%	1/6W	R530	1-247-879-00	CARBON 100K 5%	1/6W
R426	1-247-843-00	CARBON 3.3K 5%	1/6W	R531	1-247-879-00	CARBON 100K 5%	1/6W
R427	1-247-867-00	CARBON 33K 5%	1/6W	R532	1-247-867-00	CARBON 33K 5%	1/6W
R428	1-247-855-00	CARBON 10K 5%	1/6W	R533	1-247-846-00	CARBON 4.3K 5%	1/6W
R429	1-247-831-00	CARBON 1K 5%	1/6W	R534	1-247-846-00	CARBON 4.3K 5%	1/6W
R431	1-247-863-00	CARBON 22K 5%	1/6W	R535	1-247-855-00	CARBON 10K 5%	1/6W
R437	1-247-867-00	CARBON 33K 5%	1/6W	R536	1-247-895-00	CARBON 470K 5%	1/6W
R442	1-247-855-00	CARBON 10K 5%	1/6W	R537	1-247-873-00	CARBON 56K 5%	1/6W
				R538	1-247-853-00	CARBON 8.2K 5%	1/6W

When indicating parts by reference number, please include the board name.

SS-53

Ref.No	Part No.	Description	Quantity	Unit	Remark	Ref.No	Part No.	Description	Quantity	Unit	Remark
R539	1-247-843-00	CARBON	3.3K	5%	1/6W	R592	1-247-879-00	CARBON	100K	5%	1/6W
R540	1-247-851-00	CARBON	6.8K	5%	1/6W	R593	1-247-867-00	CARBON	33K	5%	1/6W
R541	1-247-870-00	CARBON	43K	5%	1/6W	R594	1-247-883-00	CARBON	150K	5%	1/6W
R542	1-247-867-00	CARBON	33K	5%	1/6W	R595	1-247-867-00	CARBON	33K	5%	1/6W
R543	1-247-834-00	CARBON	1.3K	5%	1/6W	R596	1-247-867-00	CARBON	33K	5%	1/6W
R544	1-247-837-00	CARBON	1.8K	5%	1/6W	R597	1-215-413-00	METAL	470	1%	1/6W
R545	1-247-836-00	CARBON	1.6K	5%	1/6W	R598	1-215-467-00	METAL	82K	1%	1/6W
R546	1-247-859-00	CARBON	15K	5%	1/6W	R599	1-247-849-00	CARBON	5.6K	5%	1/6W
R547	1-247-865-00	CARBON	27K	5%	1/6W	R600	1-247-867-00	CARBON	33K	5%	1/6W
R548	1-247-869-00	CARBON	39K	5%	1/6W	R601	1-247-871-00	CARBON	47K	5%	1/6W
R549	1-247-863-00	CARBON	22K	5%	1/6W	R602	1-247-879-00	CARBON	100K	5%	1/6W
R550	1-247-873-00	CARBON	56K	5%	1/6W	R603	1-247-839-00	CARBON	2.2K	5%	1/6W
R551	1-247-835-00	CARBON	1.5K	5%	1/6W	R604	1-247-818-00	CARBON	300	5%	1/6W
R552	1-247-862-00	CARBON	20K	5%	1/6W	R605	1-247-845-00	CARBON	3.9K	5%	1/6W
R553	1-247-878-00	CARBON	91K	5%	1/6W	R606	1-247-847-00	CARBON	4.7K	5%	1/6W
R554	1-247-871-00	CARBON	47K	5%	1/6W	R607	1-212-360-00	METAL OXIDE	1	5%	1W F
R555	1-247-855-00	CARBON	10K	5%	1/6W	R608	1-247-851-00	CARBON	6.8K	5%	1/6W
R556	1-247-855-00	CARBON	10K	5%	1/6W	R609	1-247-851-00	CARBON	6.8K	5%	1/6W
R557	1-247-855-00	CARBON	10K	5%	1/6W	R611	1-247-867-00	CARBON	33K	5%	1/6W
R558	1-247-847-00	CARBON	4.7K	5%	1/6W	R612	1-247-841-00	CARBON	2.7K	5%	1/6W
R559	1-247-859-00	CARBON	15K	5%	1/6W	R613	1-247-879-00	CARBON	100K	5%	1/6W
R560	1-247-847-00	CARBON	4.7K	5%	1/6W	R614	1-247-855-00	CARBON	10K	5%	1/6W
R561	1-247-879-00	CARBON	100K	5%	1/6W	R615	1-247-831-00	CARBON	1K	5%	1/6W
R562	1-247-861-00	CARBON	18K	5%	1/6W	R616	1-247-871-00	CARBON	47K	5%	1/6W
R563	1-247-848-00	CARBON	5.1K	5%	1/6W	R617	1-247-871-00	CARBON	47K	5%	1/6W
R564	1-247-831-00	CARBON	1K	5%	1/6W	R618	1-247-867-00	CARBON	33K	5%	1/6W
R565	1-212-356-00	METAL OXIDE	0.47	5%	1W F	R619	1-247-867-00	CARBON	33K	5%	1/6W
R566	1-246-981-00	CARBON	4.7	5%	1/8W F	R620	1-247-873-00	CARBON	56K	5%	1/6W
R567	1-247-855-00	CARBON	10K	5%	1/6W	R621	1-247-863-00	CARBON	22K	5%	1/6W
R568	1-247-863-00	CARBON	22K	5%	1/6W	R622	1-247-847-00	CARBON	4.7K	5%	1/6W
R569	1-247-837-00	CARBON	1.8K	5%	1/6W	R623	1-247-831-00	CARBON	1K	5%	1/6W
R570	1-215-437-00	METAL	4.7K	1%	1/6W	R624	1-247-889-00	CARBON	270K	5%	1/6W
R571	1-215-437-00	METAL	4.7K	1%	1/6W	R625	1-215-443-00	METAL	8.2K	1%	1/6W
R572	1-215-437-00	METAL	4.7K	1%	1/6W	R626	1-215-445-00	METAL	10K	1%	1/6W
R573	1-215-437-00	METAL	4.7K	1%	1/6W	R627	1-247-839-00	CARBON	2.2K	5%	1/6W
R574	1-247-875-00	CARBON	68K	5%	1/6W	R628	1-247-855-00	CARBON	10K	5%	1/6W
R575	1-247-831-00	CARBON	1K	5%	1/6W	R629	1-247-871-00	CARBON	47K	5%	1/6W
R576	1-247-865-00	CARBON	27K	5%	1/6W	R632	1-247-867-00	CARBON	33K	5%	1/6W
R577	1-247-861-00	CARBON	18K	5%	1/6W	R633	1-247-867-00	CARBON	33K	5%	1/6W
R578	1-247-831-00	CARBON	1K	5%	1/6W	R637	1-247-867-00	CARBON	33K	5%	1/6W
R579	1-247-855-00	CARBON	10K	5%	1/6W	R701	1-247-851-00	CARBON	6.8K	5%	1/6W
R580	1-247-855-00	CARBON	10K	5%	1/6W	R702	1-247-846-00	CARBON	4.3K	5%	1/6W
R581	1-247-855-00	CARBON	10K	5%	1/6W	R703	1-247-871-00	CARBON	47K	5%	1/6W
R582	1-247-855-00	CARBON	10K	5%	1/6W	R704	1-247-863-00	CARBON	22K	5%	1/6W
R583	1-247-819-00	CARBON	330	5%	1/6W	R705	1-247-843-00	CARBON	3.3K	5%	1/6W
R584	1-247-855-00	CARBON	10K	5%	1/6W	R706	1-247-860-00	CARBON	16K	5%	1/6W
R585	1-247-851-00	CARBON	6.8K	5%	1/6W	R707	1-247-852-00	CARBON	7.5K	5%	1/6W
R586	1-247-825-00	CARBON	560	5%	1/6W	R708	1-247-861-00	CARBON	18K	5%	1/6W
R587	1-247-831-00	CARBON	1K	5%	1/6W	R709	1-247-871-00	CARBON	47K	5%	1/6W
R588	1-247-872-00	CARBON	51K	5%	1/6W	R710	1-246-981-00	CARBON	4.7	5%	1/8W F
R589	1-247-893-00	CARBON	390K	5%	1/6W	R711	1-212-366-00	METAL OXIDE	3.3	5%	1W F
R590	1-247-857-00	CARBON	12K	5%	1/6W	R721	1-247-865-00	CARBON	27K	5%	1/6W
R591	1-247-871-00	CARBON	47K	5%	1/6W	R722	1-247-888-00	CARBON	240K	5%	1/6W

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
R723	1-247-901-00	CARBON	820K 5% 1/6W	R909	1-247-883-00	CARBON	150K 5% 1/6W
R724	1-247-897-00	CARBON	560K 5% 1/6W	R910	1-247-853-00	CARBON	8.2K 5% 1/6W
R725	1-247-855-00	CARBON	10K 5% 1/6W	R911	1-247-866-00	CARBON	30K 5% 1/6W
R726	1-247-855-00	CARBON	10K 5% 1/6W	R912	1-247-859-00	CARBON	15K 5% 1/6W
R728	1-247-831-00	CARBON	1K 5% 1/6W	R913	1-247-866-00	CARBON	30K 5% 1/6W
R811	1-247-841-00	CARBON	2.7K 5% 1/6W	R914	1-247-893-00	CARBON	390K 5% 1/6W
R812	1-247-839-00	CARBON	2.2K 5% 1/6W	R915	1-247-864-00	CARBON	24K 5% 1/6W
R813	1-247-821-00	CARBON	390 5% 1/6W	R916	1-247-859-00	CARBON	15K 5% 1/6W
R814	1-247-837-00	CARBON	1.8K 5% 1/6W	R917	1-247-861-00	CARBON	18K 5% 1/6W
R815	1-247-841-00	CARBON	2.7K 5% 1/6W	R918	1-247-879-00	CARBON	100K 5% 1/6W
R816	1-247-826-00	CARBON	620 5% 1/6W	R919	1-247-895-00	CARBON	470K 5% 1/6W
R817	1-247-873-00	CARBON	56K 5% 1/6W	R921	1-247-871-00	CARBON	47K 5% 1/6W
R818	1-247-881-00	CARBON	120K 5% 1/6W	R922	1-247-855-00	CARBON	10K 5% 1/6W
R819	1-247-837-00	CARBON	1.8K 5% 1/6W	R923	1-247-871-00	CARBON	47K 5% 1/6W
R820	1-247-841-00	CARBON	2.7K 5% 1/6W	R924	1-247-855-00	CARBON	10K 5% 1/6W
R821	1-247-825-00	CARBON	560 5% 1/6W	R925	1-247-879-00	CARBON	100K 5% 1/6W
R822	1-247-863-00	CARBON	22K 5% 1/6W	R926	1-247-896-00	CARBON	510K 5% 1/6W
R823	1-247-857-00	CARBON	12K 5% 1/6W	R927	1-247-859-00	CARBON	15K 5% 1/6W
R824	1-247-863-00	CARBON	22K 5% 1/6W	R928	1-247-861-00	CARBON	18K 5% 1/6W
R825	1-247-845-00	CARBON	3.9K 5% 1/6W	R929	1-247-865-00	CARBON	27K 5% 1/6W
R826	1-247-871-00	CARBON	47K 5% 1/6W	R930	1-247-891-00	CARBON	330K 5% 1/6W
R827	1-247-873-00	CARBON	56K 5% 1/6W	R932	1-247-831-00	CARBON	1K 5% 1/6W
R828	1-247-855-00	CARBON	10K 5% 1/6W	R933	1-247-831-00	CARBON	1K 5% 1/6W
R829	1-247-849-00	CARBON	5.6K 5% 1/6W	R934	1-247-831-00	CARBON	1K 5% 1/6W
R830	1-247-837-00	CARBON	1.8K 5% 1/6W	R935	1-247-873-00	CARBON	56K 5% 1/6W
R831	1-247-881-00	CARBON	120K 5% 1/6W	R936	1-247-855-00	CARBON	10K 5% 1/6W
R832	1-247-867-00	CARBON	33K 5% 1/6W	R937	1-247-855-00	CARBON	10K 5% 1/6W
R833	1-247-867-00	CARBON	33K 5% 1/6W	R938	1-247-871-00	CARBON	47K 5% 1/6W
R834	1-247-831-00	CARBON	1K 5% 1/6W	R939	1-247-873-00	CARBON	56K 5% 1/6W
R835	1-247-873-00	CARBON	56K 5% 1/6W				
R836	1-247-855-00	CARBON	10K 5% 1/6W	VARIABLE RESISTOR			
R837	1-247-855-00	CARBON	10K 5% 1/6W	RV501	1-228-996-00	RES, ADJ, CARBON 47K	
R838	1-247-871-00	CARBON	47K 5% 1/6W	RV502	1-228-996-00	RES, ADJ, CARBON 47K	
R841	1-247-879-00	CARBON	100K 5% 1/6W	RV503	1-228-996-00	RES, ADJ, METAL GLAZE 47K	
R842	1-247-855-00	CARBON	10K 5% 1/6W	RV504	1-228-990-00	RES, ADJ, METAL GLAZE 1K	
R843	1-247-855-00	CARBON	10K 5% 1/6W	RV505	1-228-994-00	RES, ADJ, METAL GLAZE 10K	
R844	1-247-821-00	CARBON	390 5% 1/6W	RV506	1-228-994-00	RES, ADJ, METAL GLAZE 10K	
R845	1-247-855-00	CARBON	10K 5% 1/6W	RV507	1-228-994-00	RES, ADJ, METAL GLAZE 10K	
R846	1-215-445-00	METAL	10K 1% 1/6W	RV508	1-228-994-00	RES, ADJ, METAL GLAZE 10K	
R847	1-215-445-00	METAL	10K 1% 1/6W	RV509	1-228-996-00	RES, ADJ, METAL GLAZE 47K	
R848	1-247-903-00	CARBON	1M 5% 1/6W	RV510	1-228-989-00	RES, ADJ, METAL GLAZE 470	
R849	1-247-821-00	CARBON	390 5% 1/6W	RV511	1-228-989-00	RES, ADJ, METAL GLAZE 470	
R850	1-247-877-00	CARBON	82K 5% 1/6W	RV512	1-228-996-00	RES, ADJ, METAL GLAZE 47K	
R851	1-247-844-00	CARBON	3.6K 5% 1/6W	RV513	1-228-993-00	RES, ADJ, METAL GLAZE 4.7K	
R857	1-247-826-00	CARBON	620 5% 1/6W	RV514	1-228-998-00	RES, ADJ, METAL GLAZE 220K	
R901	1-247-851-00	CARBON	6.8K 5% 1/6W	RV515	1-228-998-00	RES, ADJ, METAL GLAZE 220K	
R902	1-247-859-00	CARBON	15K 5% 1/6W	RV516	1-228-993-00	RES, ADJ, METAL GLAZE 4.7K	
R903	1-247-903-00	CARBON	1M 5% 1/6W	RV517	1-228-996-00	RES, ADJ, METAL GLAZE 47K	
R904	1-247-831-00	CARBON	1K 5% 1/6W	RV518	1-228-995-00	RES, ADJ, CARBON 22K	
R905	1-247-835-00	CARBON	1.5K 5% 1/6W	RV519	1-228-995-00	RES, ADJ, CARBON 22K	
R906	1-247-851-00	CARBON	6.8K 5% 1/6W	RV520	1-228-999-00	RES, ADJ, METAL GLAZE 470K	
R907	1-247-847-00	CARBON	4.7K 5% 1/6W	RV801	1-228-989-00	RES, ADJ, METAL GLAZE 470	
R908	1-247-859-00	CARBON	15K 5% 1/6W	RV802	1-228-989-00	RES, ADJ, METAL GLAZE 470	

When indicating parts by reference number, please include the board name.

SS-53

UD-2

JG-2

CH-38

Ref.No	Part No.	Description
RV803	1-228-998-00	RES, ADJ, METAL GLAZE 220K
RV804	1-228-998-00	RES, ADJ, METAL GLAZE 220K
RV805	1-228-995-00	RES, ADJ, METAL GLAZE 22K
RV806	1-228-995-00	RES, ADJ, CARBON 22K
RV807	1-228-998-00	RES, ADJ, CARBON 220K
RV808	1-228-989-00	RES, ADJ, METAL GLAZE 470
RV901	1-228-996-00	RES, ADJ, METAL GLAZE 47K
<u>THERMISTOR</u>		
TH801	1-800-200-00	THERMISTOR S-3K
TH802	1-800-200-00	THERMISTOR S-3K
TH803	1-800-200-00	THERMISTOR S-3K
<u>CRYSTAL</u>		
X401	1-527-992-11	OSCILLATOR, CERAMIC
X402	1-527-965-00	OSCILLATOR, CERAMIC
X801	1-527-992-11	OSCILLATOR, CERAMIC

Ref.No	Part No.	Description
	*1-615-762-11	UD-2 BOARD *****
<u>CAPACITOR</u>		
C568	1-123-612-00	ELECT 2.2MF 20% 50V
C810	1-123-612-00	ELECT 2.2MF 20% 50V
<u>DIODE</u>		
D002	8-719-911-19	DIODE 1SS119
D416	8-719-911-19	DIODE 1SS119
D417	8-719-911-19	DIODE 1SS119
D418	8-719-911-19	DIODE 1SS119
D525	8-719-911-19	DIODE 1SS119
D526	8-719-911-19	DIODE 1SS119
<u>IC</u>		
IC001	8-759-240-13	IC TC4013BP
<u>TRANSISTOR</u>		
Q429	8-729-900-33	TRANSISTOR DTC144EF
Q532	8-729-900-33	TRANSISTOR DTC144EF
Q534	8-729-900-33	TRANSISTOR DTC144EF
Q810	8-729-900-33	TRANSISTOR DTC144EF

Ref.No	Part No.	Description	Value	Tolerance	Power
R003	1-247-875-00	CARBON	68K	5%	1/6W
R432	1-247-873-00	CARBON	56K	5%	1/6W
R433	1-247-867-00	CARBON	33K	5%	1/6W
R461	1-247-855-00	CARBON	10K	5%	1/6W
R634	1-247-869-00	CARBON	39K	5%	1/6W
R636	1-247-855-00	CARBON	10K	5%	1/6W
R639	1-247-855-00	CARBON	10K	5%	1/6W

Ref.No	Part No.	Description	Value	Tolerance	Power
	*1-614-961-13	JG-2 BOARD *****			
<u>DIODE</u>					
D101	8-719-104-37	DIODE SR506D			
D102	8-719-104-37	DIODE SR506D			
D103	8-719-102-06	DIODE SG206D			
D104	8-719-104-37	DIODE SR506D			
D105	8-719-102-06	DIODE SG206D			
D106	8-719-114-06	DIODE SY406D			
D107	8-719-812-33	DIODE TLG123A			
D108	8-719-812-33	DIODE TLG123A			
D109	8-719-812-32	DIODE TLY123			
D201	8-719-921-03	DIODE GP-2S02B			
D202	8-719-921-03	DIODE GP-2S02B			
D203	8-719-921-03	DIODE GP-2S02B			
<u>RESISTOR</u>					
R101	1-247-824-00	CARBON	510	5%	1/6W
R104	1-247-854-00	CARBON	9.1K	5%	1/6W
R105	1-247-843-00	CARBON	3.3K	5%	1/6W
R106	1-247-837-00	CARBON	1.8K	5%	1/6W
R107	1-247-833-00	CARBON	1.2K	5%	1/6W
R108	1-247-817-00	CARBON	270	5%	1/6W
R109	1-247-817-00	CARBON	270	5%	1/6W
R110	1-247-811-00	CARBON	150	5%	1/6W
R210	1-247-817-00	CARBON	270	5%	1/6W
R211	1-247-811-00	CARBON	150	5%	1/6W
R212	1-247-817-00	CARBON	270	5%	1/6W
R213	1-247-811-00	CARBON	150	5%	1/6W
R214	1-247-811-00	CARBON	150	5%	1/6W
R215	1-247-817-00	CARBON	270	5%	1/6W
<u>SWITCH</u>					
S101	1-553-856-00	SWITCH, KEY BOARD			
S102	1-553-856-00	SWITCH, KEY BOARD			
S103	1-553-856-00	SWITCH, KEY BOARD			
S104	1-553-856-00	SWITCH, KEY BOARD			
S105	1-553-856-00	SWITCH, KEY BOARD			

Ref.No	Part No.	Description
	*1-614-960-13	CH-38 BOARD *****
<u>CONNECTOR</u>		
CN620	*1-564-001-11	PIN, CONNECTOR 2P
CN621	*1-564-005-00	PIN, CONNECTOR 6P
CN622	*1-564-002-00	PIN, CONNECTOR 3P
CN623	*1-564-004-00	PIN, CONNECTOR 5P

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
*A-6717-398-A	FR-14 BOARD, COMPLETE	*****		R012	1-247-815-00	CARBON 220 5%	1/6W
3-691-610-01	KNOB (A), SELECTION SWITCH			R013	1-247-811-00	CARBON 150 5%	1/6W
8-741-131-70	IC BX-1317			R014	1-247-811-00	CARBON 150 5%	1/6W
	<u>CAPACITOR</u>			R015	1-247-815-00	CARBON 220 5%	1/6W
C001	1-102-114-00	CERAMIC 470PF 10%	50V	R016	1-247-815-00	CARBON 220 5%	1/6W
C002	1-102-114-00	CERAMIC 470PF 10%	50V	R017	1-247-833-00	CARBON 1.2K 5%	1/6W
C003	1-102-114-00	CERAMIC 470PF 10%	50V	R018	1-247-837-00	CARBON 1.8K 5%	1/6W
C004	1-123-822-00	ELECT 47MF 20%	10V	R019	1-247-843-00	CARBON 3.3K 5%	1/6W
C005	1-162-306-31	CERAMIC 0.01MF 20%	16V	R020	1-247-854-00	CARBON 9.1K 5%	1/6W
	<u>CONNECTOR</u>			R021	1-247-833-00	CARBON 1.2K 5%	1/6W
CN001	*1-564-004-00	PIN, CONNECTOR 5P		R023	1-247-831-00	CARBON 1K 5%	1/6W
	<u>COMPOSITION CIRCUIT BLOCK</u>			R024	1-247-831-00	CARBON 1K 5%	1/6W
CP005	1-232-762-11	COMPOSITION CIRCUIT BLOCK		R025	1-247-855-00	CARBON 10K 5%	1/6W
	<u>DIODE</u>			R026	1-247-831-00	CARBON 1K 5%	1/6W
D007	8-719-812-33	DIODE TLG123A		R027	1-247-847-00	CARBON 4.7K 5%	1/6W
D008	8-719-812-33	DIODE TLG123A		R041	1-247-119-00	CARBON 330 5%	1/4W
D009	8-719-812-32	DIODE TLY123		R045	1-247-853-00	CARBON 8.2K 5%	1/6W
D010	8-719-812-32	DIODE TLY123		R046	1-247-853-00	CARBON 8.2K 5%	1/6W
D011	8-719-911-19	DIODE 1SS119		R047	1-247-831-00	CARBON 1K 5%	1/6W
D012	8-719-911-06	DIODE 1SS106			<u>REMOCON RECIVER</u>		
D013	8-719-911-19	DIODE 1SS119		RP001	8-741-131-70	REMOCON RECIVER BX1317	
D014	8-719-911-06	DIODE 1SS106			<u>VARIABLE RESISTOR</u>		
D016	8-719-300-77	DIODE SEL1413E		RV001	1-230-695-11	RES, VAR, SLIDE 20K/20K	
D017	8-719-300-77	DIODE SEL1413E		RV002	1-230-122-00	RES, VAR, CARBON 100K	
D018	8-719-300-77	DIODE SEL1413E		RV003	1-230-122-00	RES, VAR, CARBON 100K	
D020	8-719-812-32	DIODE TLY123		RV005	1-230-613-11	RES, VAR, CARBON 5K	
D021	8-719-812-31	DIODE TLR123			<u>SWITCH</u>		
	<u>IC</u>			S001	1-554-174-00	SWITCH, KEY BOARD	
IC001	8-759-602-20	IC M50763-632SP		S002	1-554-174-00	SWITCH, KEY BOARD	
	<u>COIL</u>			S003	1-554-174-00	SWITCH, KEY BOARD	
L002	1-408-421-00	MICRO INDUCTOR 100UH		S004	1-554-174-00	SWITCH, KEY BOARD	
	<u>HOLDER</u>			S005	1-554-174-00	SWITCH, KEY BOARD	
LH002	*3-691-612-01	HOLDER (B), LED		S006	1-554-174-00	SWITCH, KEY BOARD	
LH003	*3-691-613-01	HOLDER (C), LED		S007	1-554-378-00	SWITCH, SLIDE	
LH004	*3-674-372-00	HOLDER (A), LED		S008	1-554-174-00	SWITCH, KEY BOARD	
LH005	*3-674-372-00	HOLDER (A), LED		S009	1-554-174-00	SWITCH, KEY BOARD	
LH006	*3-674-372-00	HOLDER (A), LED		S010	1-554-174-00	SWITCH, KEY BOARD	
LH007	*3-674-372-00	HOLDER (A), LED		S011	1-554-174-00	SWITCH, KEY BOARD	
LH008	3-655-122-00	TIRE, S BRAKE		S012	1-553-716-00	SWITCH, SLIDE	
	<u>RESISTOR</u>			S013	1-553-716-00	SWITCH, SLIDE	
R001	1-247-879-00	CARBON 100K 5%	1/6W	S014	1-553-754-00	SWITCH, SLIDE	
R011	1-247-815-00	CARBON 220 5%	1/6W	S015	1-553-754-00	SWITCH, SLIDE	

When indicating parts by reference number, please include the board name.

TI-4

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
*A-6721-234-A TI-4 BOARD, COMPLETE *****				C238	1-102-759-00	CERAMIC 62PF	5% 50V
				C239	1-102-939-61	CERAMIC 2PF	0.5PF 50V
				C240	1-102-953-00	CERAMIC 18PF	5% 50V
				C241	1-123-307-00	ELECT 100MF	20% 10V
				C243	1-102-074-00	CERAMIC 0.001MF	10% 50V
CAPACITOR				C244	1-130-478-00	MYLAR 0.0039MF	5% 50V
C101	1-123-357-00	ELECT	22MF 20% 50V	C245	1-123-308-00	ELECT 220MF	20% 10V
C102	1-102-112-00	CERAMIC	330PF 10% 50V	C251	1-102-816-00	CERAMIC 120PF	5% 50V
C103	1-102-112-00	CERAMIC	330PF 10% 50V	C252	1-102-973-00	CERAMIC 100PF	5% 50V
C104	1-102-112-00	CERAMIC	330PF 10% 50V	C253	1-123-379-00	ELECT 0.47MF	20% 50V
C105	1-101-004-00	CERAMIC	0.01MF 50V	C261	1-123-369-00	ELECT 4.7MF	20% 25V
C106	1-123-356-00	ELECT	10MF 20% 16V	C262	1-161-047-00	CERAMIC 0.0047MF	10% 25V
C107	1-161-059-00	CERAMIC	0.047MF 10% 25V	C263	1-123-380-00	ELECT 1MF	20% 50V
C108	1-101-004-00	CERAMIC	0.01MF 50V	C301	1-123-307-00	ELECT 100MF	20% 10V
C109	1-102-959-00	CERAMIC	22PF 5% 50V	C302	1-123-381-00	ELECT 2.2MF	20% 50V
C110	1-102-959-00	CERAMIC	22PF 5% 50V	C801	1-123-356-00	ELECT 10MF	20% 16V
C111	1-123-330-00	ELECT	22MF 20% 16V	C802	1-101-004-00	CERAMIC 0.01MF	50V
C112	1-123-307-00	ELECT	100MF 20% 10V	C803	1-136-157-00	MYLAR 0.022MF	10% 50V
C114	1-101-004-00	CERAMIC	0.01MF 50V	C804	1-123-356-00	ELECT 10MF	20% 16V
C201	1-102-634-11	CERAMIC	8PF 0.5PF 50V	C805	1-123-356-00	ELECT 10MF	20% 16V
C202	1-102-637-00	CERAMIC	12PF 5% 50V	C808	1-123-356-00	ELECT 10MF	20% 16V
C203	1-101-004-00	CERAMIC	0.01MF 50V	C809	1-130-489-00	MYLAR 0.033MF	5% 50V
C204	1-102-121-00	CERAMIC	0.0022MF 10% 50V	C810	1-123-356-00	ELECT 10MF	20% 16V
C205	1-102-121-00	CERAMIC	0.0022MF 10% 50V	C811	1-130-021-00	FILM 0.0018MF	5% 50V
C206	1-102-121-00	CERAMIC	0.0022MF 10% 50V	C812	1-123-380-00	ELECT 1MF	20% 50V
C207	1-102-121-00	CERAMIC	0.0022MF 10% 50V	C813	1-123-356-00	ELECT 10MF	20% 16V
C208	1-102-121-00	CERAMIC	0.0022MF 10% 50V	C815	1-123-356-00	ELECT 10MF	20% 16V
C209	1-102-121-00	CERAMIC	0.0022MF 10% 50V	C816	1-123-308-00	ELECT 220MF	20% 10V
C210	1-102-112-00	CERAMIC	330PF 10% 50V	C817	1-123-356-00	ELECT 10MF	20% 16V
C211	1-102-851-00	CERAMIC	15PF 5% 50V	C818	1-123-369-00	ELECT 4.7MF	20% 25V
C212	1-102-525-00	CERAMIC	68PF 5% 50V	C820	1-123-356-00	ELECT 10MF	20% 16V
C213	1-102-074-00	CERAMIC	0.001MF 10% 50V	C821	1-123-356-00	ELECT 10MF	20% 16V
C214	1-123-356-00	ELECT	10MF 20% 16V	C822	1-123-306-00	ELECT 47MF	20% 10V
C215	1-102-074-00	CERAMIC	0.001MF 10% 50V	C823	1-130-481-00	MYLAR 0.0068MF	5% 50V
C216	1-102-114-00	CERAMIC	470PF 10% 50V	C824	1-130-477-00	MYLAR 0.0033MF	5% 50V
C217	1-161-059-00	CERAMIC	0.047MF 10% 25V	C830	1-123-308-00	ELECT 220MF	20% 10V
C218	1-161-059-00	CERAMIC	0.047MF 10% 25V	C832	1-130-022-00	FILM 0.0022MF	10% 50V
C219	1-123-308-00	ELECT	220MF 20% 10V	C833	1-131-343-00	TANTALUM 0.22MF	10% 35V
C220	1-102-121-00	CERAMIC	0.0022MF 10% 50V	C834	1-131-343-00	TANTALUM 0.22MF	10% 35V
C221	1-102-525-00	CERAMIC	68PF 5% 50V	C835	1-130-022-00	FILM 0.0022MF	10% 50V
C222	1-102-510-00	CERAMIC	12PF 5% 50V	C836	1-123-356-00	ELECT 10MF	20% 16V
C223	1-101-837-00	CERAMIC	0.5PF 0.25PF 50V	C837	1-123-380-00	ELECT 1MF	20% 50V
C224	1-102-525-00	CERAMIC	68PF 5% 50V	C838	1-130-022-00	FILM 0.0022MF	10% 50V
C225	1-101-837-00	CERAMIC	0.5PF 0.25PF 50V	C840	1-130-024-00	FILM 0.0033MF	10% 50V
C226	1-102-510-00	CERAMIC	12PF 5% 50V	C841	1-130-024-00	FILM 0.0033MF	10% 50V
C227	1-161-013-00	CERAMIC	0.01MF 10% 25V	C842	1-131-345-00	TANTALUM 0.47MF	10% 35V
C228	1-123-379-00	ELECT	0.47MF 20% 50V	C843	1-130-994-11	FILM 0.033MF	10% 50V
C229	1-102-121-00	CERAMIC	0.0022MF 10% 50V	C844	1-130-024-00	FILM 0.0033MF	10% 50V
C230	1-123-380-00	ELECT	1MF 20% 50V	C845	1-130-024-00	FILM 0.0033MF	10% 50V
C231	1-123-356-00	ELECT	10MF 20% 16V	C846	1-131-371-00	TANTALUM 10MF	10% 16V
C232	1-102-121-00	CERAMIC	0.0022MF 10% 50V	C847	1-123-306-00	ELECT 47MF	20% 10V
C233	1-121-257-00	ELECT	4.7MF 16V	C848	1-102-125-00	CERAMIC 0.0047MF	10% 50V
C234	1-102-884-00	CERAMIC	33PF 5% 50V	C849	1-123-380-00	ELECT 1MF	20% 50V
C235	1-123-381-00	ELECT	2.2MF 20% 50V				
C236	1-102-121-00	CERAMIC	0.0022MF 10% 50V				

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
C850	1-123-380-00	ELECT	1MF 20%	50V	IC831	8-759-145-58	IC UPC4558C
C851	1-123-306-00	ELECT	47MF 20%	10V	IC870	8-759-602-48	IC M5201L
C852	1-123-380-00	ELECT	1MF 20%	50V			
C853	1-123-356-00	ELECT	10MF 20%	16V			
C854	1-123-306-00	ELECT	47MF 20%	10V			
						<u>COIL</u>	
C855	1-123-382-00	ELECT	3.3MF 20%	50V	L102	1-408-417-00	MICRO INDUCTOR 47UH
C856	1-102-125-00	CERAMIC	0.0047MF 10%	50V	L201	1-410-073-11	MICRO INDUCTOR 0.22UH
C857	1-131-368-00	TANTALUM	3.3MF 10%	16V	L202	1-408-709-00	MICRO INDUCTOR 0.68UH
C858	1-130-030-00	FILM	0.01MF 10%	50V	L203	1-408-602-00	MICRO INDUCTOR 8.2UH
C870	1-130-497-00	MYLAR	0.15MF 10%	50V	L204	1-408-596-00	MICRO INDUCTOR 2.7UH
C871	1-130-491-00	MYLAR	0.047MF 5%	50V	L205	1-408-602-00	MICRO INDUCTOR 8.2UH
C872	1-130-479-00	MYLAR	0.0047MF 5%	50V	L208	1-408-606-00	MICRO INDUCTOR 18UH
C873	1-130-475-00	MYLAR	0.0022MF 5%	50V	L209	1-408-411-00	MICRO INDUCTOR 15UH
C874	1-123-380-00	ELECT	1MF 20%	50V	L260	1-410-091-31	MICRO INDUCTOR 22MMH
C876	1-102-121-00	CERAMIC	0.0022MF 10%	50V			
						<u>IC LINK</u>	
C877	1-123-306-00	ELECT	47MF 20%	10V	PS001	1-532-727-11	LINK, IC
		<u>FILTER</u>				<u>TRANSISTOR</u>	
CF201	1-527-943-00	FILTER, CERAMIC			Q101	8-729-177-32	TRANSISTOR 25D773
CF202	1-409-332-00	CERAMIC TRAP			Q102	8-729-900-89	TRANSISTOR DTC144ES
		<u>CONNECTOR</u>			Q103	8-729-900-89	TRANSISTOR DTC144ES
CN101	*1-560-894-00	PIN, CONNECTOR 6P			Q104	8-729-245-83	TRANSISTOR 25C2458
CN102	*1-560-891-00	PIN, CONNECTOR 3P			Q105	8-729-245-83	TRANSISTOR 25C2458
CN103	*1-560-895-00	PIN, CONNECTOR 7P			Q106	8-729-245-83	TRANSISTOR 25C2458
CN104	*1-560-892-00	PIN, CONNECTOR 4P			Q107	8-729-900-89	TRANSISTOR DTC144ES
CN105	*1-560-892-00	PIN, CONNECTOR 4P			Q108	8-729-900-63	TRANSISTOR DTA124ES
CN106	*1-560-898-00	PIN, CONNECTOR 10P			Q109	8-729-178-54	TRANSISTOR 25C2785-F
		<u>JACK</u>			Q201	8-729-266-93	TRANSISTOR 25C2669
CNJ001	1-507-678-21	JACK			Q202	8-729-245-83	TRANSISTOR 25C2458
CNJ002	1-507-678-21	JACK			Q203	8-729-117-54	TRANSISTOR 25A1175-F
		<u>DIODE</u>			Q205	8-729-245-83	TRANSISTOR 25C2458
D101	8-719-911-06	DIODE 1SS106			Q206	8-729-245-83	TRANSISTOR 25C2458
D104	8-719-101-04	DIODE RD33EB2			Q208	8-729-204-83	TRANSISTOR 25A1048-GR
D105	8-719-101-04	DIODE RD33EB2			Q209	8-729-245-83	TRANSISTOR 25C2458
D201	8-719-911-19	DIODE 1SS119			Q301	8-729-900-89	TRANSISTOR DTC144ES
D202	8-719-911-19	DIODE 1SS119			Q302	8-729-900-63	TRANSISTOR DTA124ES
D301	8-719-911-19	DIODE 1SS119			Q303	8-729-900-89	TRANSISTOR DTC144ES
D302	8-719-102-74	DIODE RD6.2EN2			Q304	8-729-900-89	TRANSISTOR DTC144ES
D303	8-719-102-74	DIODE RD6.2EN2			Q305	8-729-900-89	TRANSISTOR DRC144ES
D830	8-719-102-74	DIODE RD6.2EN2			Q801	8-729-900-89	TRANSISTOR DTC144ES
		<u>IC</u>			Q802	8-729-900-89	TRANSISTOR DTC144ES
IC101	8-755-641-51	IC CX564-151			Q803	8-729-245-83	TRANSISTOR 25C2458
IC102	8-752-320-11	IC CXX10001P			Q804	8-729-245-83	TRANSISTOR 25C2458
IC104	8-759-920-28	IC S-8054HN			Q805	8-729-178-54	TRANSISTOR 25C2785-F
IC201	8-752-001-41	IC CX20014A			Q832	8-729-245-83	TRANSISTOR 25C2458
IC202	8-752-007-30	IC CX20073			Q833	8-729-245-83	TRANSISTOR 25C2458
IC801	8-752-011-20	IC CX20112			Q870	8-729-245-83	TRANSISTOR 25C2458
IC830	8-759-400-88	IC AN6291			Q871	8-729-245-83	TRANSISTOR 25C2458
						<u>RESISTOR</u>	
					R102	1-247-863-00	CARBON 22K 5% 1/6W
					R104	1-247-819-00	CARBON 330 5% 1/6W
					R105	1-210-859-00	CARBON 1.2 5% 1/8W F

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description				Remark
R106	1-247-717-11	CARBON	2.2K	5%	1/6W	
R108	1-247-871-00	CARBON	47K	5%	1/6W	
R109	1-247-855-00	CARBON	10K	5%	1/6W	
R110	1-247-867-00	CARBON	33K	5%	1/6W	
R111	1-247-849-00	CARBON	5.6K	5%	1/6W	
R114	1-247-831-00	CARBON	1K	5%	1/6W	
R115	1-247-831-00	CARBON	1K	5%	1/6W	
R116	1-247-831-00	CARBON	1K	5%	1/6W	
R118	1-247-871-00	CARBON	47K	5%	1/6W	
R119	1-247-871-00	CARBON	47K	5%	1/6W	
R120	1-247-871-00	CARBON	47K	5%	1/6W	
R121	1-247-871-00	CARBON	47K	5%	1/6W	
R124	1-247-855-00	CARBON	10K	5%	1/6W	
R125	1-247-855-00	CARBON	10K	5%	1/6W	
R201	1-247-857-00	CARBON	12K	5%	1/6W	
R202	1-247-855-00	CARBON	10K	5%	1/6W	
R203	1-247-803-00	CARBON	68	5%	1/6W	
R204	1-247-833-00	CARBON	1.2K	5%	1/6W	
R205	1-247-817-00	CARBON	270	5%	1/6W	
R206	1-247-801-00	CARBON	56	5%	1/6W	
R207	1-247-837-00	CARBON	1.8K	5%	1/6W	
R208	1-247-883-00	CARBON	150K	5%	1/6W	
R209	1-247-843-00	CARBON	3.3K	5%	1/6W	
R210	1-247-883-00	CARBON	150K	5%	1/6W	
R211	1-247-843-00	CARBON	3.3K	5%	1/6W	
R212	1-247-871-00	CARBON	47K	5%	1/6W	
R213	1-247-871-00	CARBON	47K	5%	1/6W	
R214	1-247-833-00	CARBON	1.2K	5%	1/6W	
R215	1-247-807-00	CARBON	100	5%	1/6W	
R216	1-247-845-00	CARBON	3.9K	5%	1/6W	
R217	1-247-839-00	CARBON	2.2K	5%	1/6W	
R218	1-247-839-00	CARBON	2.2K	5%	1/6W	
R219	1-247-883-00	CARBON	150K	5%	1/6W	
R220	1-247-815-00	CARBON	220	5%	1/6W	
R221	1-247-839-00	CARBON	2.2K	5%	1/6W	
R223	1-247-819-00	CARBON	330	5%	1/6W	
R224	1-247-807-00	CARBON	100	5%	1/6W	
R226	1-247-895-00	CARBON	470K	5%	1/6W	
R227	1-247-787-00	CARBON	15	5%	1/6W	
R228	1-247-807-00	CARBON	100	5%	1/6W	
R229	1-247-807-00	CARBON	100	5%	1/6W	
R230	1-247-845-00	CARBON	3.9K	5%	1/6W	
R231	1-247-819-00	CARBON	330	5%	1/6W	
R232	1-247-817-00	CARBON	270	5%	1/6W	
R251	1-247-831-00	CARBON	1K	5%	1/6W	
R252	1-247-855-00	CARBON	10K	5%	1/6W	
R253	1-247-887-00	CARBON	220K	5%	1/6W	
R260	1-247-831-00	CARBON	1K	5%	1/6W	
R261	1-247-839-00	CARBON	2.2K	5%	1/6W	
R262	1-247-851-00	CARBON	6.8K	5%	1/6W	
R263	1-247-879-00	CARBON	100K	5%	1/6W	
R264	1-247-839-00	CARBON	2.2K	5%	1/6W	
R301	1-247-825-00	CARBON	560	5%	1/6W	

Ref.No	Part No.	Description				Remark
R302	1-247-873-00	CARBON	56K	5%	1/6W	
R303	1-247-863-00	CARBON	22K	5%	1/6W	
R802	1-215-469-00	METAL	100K	1%	1/6W	
R803	1-215-469-00	METAL	100K	1%	1/6W	
R804	1-247-879-00	CARBON	100K	5%	1/6W	
R805	1-247-831-00	CARBON	1K	5%	1/6W	
R808	1-247-859-00	CARBON	15K	5%	1/6W	
R809	1-247-825-00	CARBON	560	5%	1/6W	
R810	1-247-839-00	CARBON	2.2K	5%	1/6W	
R811	1-247-839-00	CARBON	2.2K	5%	1/6W	
R813	1-215-430-00	METAL	2.4K	1%	1/6W	
R814	1-247-853-00	CARBON	8.2K	5%	1/6W	
R815	1-247-843-00	CARBON	3.3K	5%	1/6W	
R819	1-247-903-00	CARBON	1M	5%	1/6W	
R820	1-247-851-00	CARBON	6.8K	5%	1/6W	
R821	1-247-851-00	CARBON	6.8K	5%	1/6W	
R822	1-247-839-00	CARBON	2.2K	5%	1/6W	
R823	1-247-839-00	CARBON	2.2K	5%	1/6W	
R824	1-247-859-00	CARBON	15K	5%	1/6W	
R825	1-247-873-00	CARBON	56K	5%	1/6W	
R826	1-247-843-00	CARBON	3.3K	5%	1/6W	
R827	1-247-843-00	CARBON	3.3K	5%	1/6W	
R828	1-247-843-00	CARBON	3.3K	5%	1/6W	
R832	1-247-811-00	CARBON	150	5%	1/6W	
R834	1-247-867-00	CARBON	33K	5%	1/6W	
R835	1-247-843-00	CARBON	3.3K	5%	1/6W	
R836	1-247-885-00	CARBON	180K	5%	1/6W	
R837	1-247-844-00	CARBON	3.6K	5%	1/6W	
R838	1-247-885-00	CARBON	180K	5%	1/6W	
R839	1-215-421-00	METAL	1K	1%	1/6W	
R840	1-247-811-00	CARBON	150	5%	1/6W	
R841	1-247-885-00	CARBON	180K	5%	1/6W	
R842	1-247-848-00	CARBON	5.1K	5%	1/6W	
R843	1-247-885-00	CARBON	180K	5%	1/6W	
R844	1-247-844-00	CARBON	3.6K	5%	1/6W	
R845	1-247-893-00	CARBON	390K	5%	1/6W	
R846	1-247-863-00	CARBON	22K	5%	1/6W	
R847	1-247-865-00	CARBON	27K	5%	1/6W	
R848	1-247-843-00	CARBON	3.3K	5%	1/6W	
R849	1-247-843-00	CARBON	3.3K	5%	1/6W	
R850	1-247-847-00	CARBON	4.7K	5%	1/6W	
R851	1-247-847-00	CARBON	4.7K	5%	1/6W	
R852	1-247-847-00	CARBON	4.7K	5%	1/6W	
R853	1-247-847-00	CARBON	4.7K	5%	1/6W	
R854	1-247-811-00	CARBON	150	5%	1/6W	
R855	1-247-869-00	CARBON	39K	5%	1/6W	
R856	1-247-887-00	CARBON	220K	5%	1/6W	
R857	1-247-843-00	CARBON	3.3K	5%	1/6W	
R858	1-247-893-00	CARBON	390K	5%	1/6W	
R859	1-247-855-00	CARBON	10K	5%	1/6W	
R862	1-247-843-00	CARBON	3.3K	5%	1/6W	
R870	1-247-859-00	CARBON	39K	5%	1/6W	
R871	1-247-865-00	CARBON	27K	5%	1/6W	

When indicating parts by reference number, please include the board name.

TI-4

PS-65

PV-1

PA-4

PI-2

PC-19

Ref.No	Part No.	Description	Remark
R872	1-247-853-00	CARBON 8.2K 5%	1/6W
R873	1-247-863-00	CARBON 22K 5%	1/6W
R874	1-247-863-00	CARBON 22K 5%	1/6W
R875	1-247-855-00	CARBON 10K 5%	1/6W
R876	1-247-847-00	CARBON 4.7K 5%	1/6W
R877	1-247-855-00	CARBON 10K 5%	1/6W
R878	1-247-851-00	CARBON 6.8K 5%	1/6W
R881	1-247-871-00	CARBON 47K 5%	1/6W
R882	1-247-855-00	CARBON 10K 5%	1/6W

MODULATOR

ARFU001 1-464-447-11 MODULATOR, RF (RFU-742)

VARIABLE RESISTOR

RV001	1-230-694-11	RES, VAR, CARBON 250K
RV101	1-228-989-00	RES, ADJ, CARBON 470
RV201	1-228-993-00	RES, ADJ, CARBON 4.7K
RV202	1-228-994-00	RES, ADJ, CARBON 10K
RV203	1-228-998-00	RES, ADJ, CARBON 220K

RV801	1-228-996-00	RES, ADJ, CARBON 47K
RV803	1-228-997-00	RES, ADJ, CARBON 100K
RV804	1-228-999-00	RES, ADJ, CARBON 470K
RV805	1-228-994-00	RES, ADJ, CARBON 10K
RV806	1-228-994-00	RES, ADJ, CARBON 10K

RV830	1-228-991-00	RES, ADJ, CARBON 2.2K
RV831	1-228-995-00	RES, ADJ, CARBON 22K
RV832	1-228-994-00	RES, ADJ, CARBON 10K

SWITCH

S001	1-554-174-00	SWITCH, KEY BOARD
S002	1-554-174-00	SWITCH, KEY BOARD
S003	1-554-174-00	SWITCH, KEY BOARD
S004	1-554-174-00	SWITCH, KEY BOARD
S006	1-553-716-00	SWITCH, SLIDE

S007	1-553-716-00	SWITCH, SLIDE
S008	1-553-716-00	SWITCH, SLIDE

SHIELD CASE

SC001	*3-682-155-00	CASE, SHIELD, VIF
SC002	*3-682-156-00	LID, UPPER, SHIELD CASE, VIF
SC003	*3-682-157-00	LID, REAR, SHIELD CASE, VIF

FILTER

SWF201 1-404-479-00 SAWF

TRANSFORMER

T201	1-404-541-11	
T202	1-404-467-00	COIL, VIF
T203	1-404-505-00	COIL
T204	1-404-467-00	COIL, VIF
T205	1-404-012-00	COIL
T206	1-404-489-00	COIL

Ref.No	Part No.	Description	Remark
--------	----------	-------------	--------

T207 1-405-873-00 COIL, OSCILLATOR

TUNER

TU001A 1-463-603-21 TUNER, ET (BTP-201D)

CRYSTAL

X101 1-567-192-11 OSCILLATOR, CERAMIC

*1-614-953-13 PS-65 BOARD

IC

IC001A 8-749-954-41 IC STK5441

*1-614-954-13 PV-1 BOARD

CAPACITOR

C034 1-161-379-00 CERAMIC 0.01MF 20% 25V

IC

IC002A 8-749-930-52 IC ST-3052V

*1-614-952-13 PA-4 BOARD

*1-614-948-13 PI-2 BOARD

CAPACITOR

C033 1-161-013-00 CERAMIC 0.01MF 20% 25V

IC

IC003A 8-759-170-12 IC UPC78M12H

*A-6722-270-A PC-19 BOARD, COMPLETE

CAPACITOR

C006	1-123-373-00	ELECT	47MF	20%	63V
C007	1-123-376-00	ELECT	330MF	20%	63V
C010	1-123-370-00	ELECT	10MF	20%	63V
C011	1-123-343-00	ELECT	33MF	20%	35V
C012	1-123-343-00	ELECT	33MF	20%	35V

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

PC-19

PR-6

PT-48

TM-75

Ref.No	Part No.	Description	Remark
C013	1-123-332-00	ELECT 47MF 20%	16V
C014	1-123-332-00	ELECT 47MF 20%	16V
C015	1-123-332-00	ELECT 47MF 20%	16V
C016	1-123-332-00	ELECT 47MF 20%	16V
C017	1-123-332-00	ELECT 47MF 20%	25V
C018	1-123-381-00	ELECT 2.2MF 20%	50V
C019	1-123-333-00	ELECT 100MF 20%	16V
C022	1-123-306-00	ELECT 47MF 20%	10V
C030	1-161-070-00	CERAMIC 0.01MF 20%	50V
C035	1-161-070-00	CERAMIC 0.01MF 20%	50V
C036	1-123-356-00	ELECT 10MF 20%	25V

CONNECTOR

CN701	*1-560-894-00	PIN, CONNECTOR 6P
CN702	*1-560-893-00	PIN, CONNECTOR 5P
CN703	*1-560-890-00	PIN, CONNECTOR 2P
CN704	*1-560-893-00	PIN, CONNECTOR 5P
CN705	*1-560-894-00	PIN, CONNECTOR 6P
CN708	*1-560-890-00	PIN, CONNECTOR 2P
CN709	*1-560-892-00	PIN, CONNECTOR 4P

DIODE

D013	8-719-200-02	DIODE 10E-2
D014	8-719-200-02	DIODE 10E-2
D016	8-719-100-50	DIODE RD9.1EB1
D017	8-719-200-02	DIODE 10E-2
D018	8-719-107-07	DIODE RD33EB3
D019	8-719-162-07	DIODE RD6.2E-B

IC

IC004	8-759-700-69	IC KM79C12A
-------	--------------	-------------

TRANSISTOR

Q002	8-729-103-43	TRANSISTOR 258734
------	--------------	-------------------

RESISTOR

R002	1-217-434-00	FUSIBLE 10 5% 1/2W F
R003	1-213-135-00	METAL OXIDE 220 5% 1W F
R005	1-247-853-00	CARBON 8.2K 5% 1/6W
R009	1-247-821-00	CARBON 390 5% 1/6W
R010	1-247-821-00	CARBON 390 5% 1/6W
R015	1-247-855-00	CARBON 10K 5% 1/6W
R016	1-247-807-00	CARBON 100 5% 1/6W

*1-614-950-13 PR-6 BOARD *****

CAPACITOR

C004	1-125-298-11	ELECT (BLOCK) 10000MF 20% 25V
C005	1-125-298-11	ELECT (BLOCK) 10000MF 20% 25V

Ref.No	Part No.	Description	Remark
--------	----------	-------------	--------

CONNECTOR

CN710	*1-564-241-00	PIN, CONNECTOR 4P
-------	---------------	-------------------

DIODE

D001	8-719-500-18	DIODE D53820
D005	8-719-500-18	DIODE D53820

FUSE

F002	1-532-578-00	FUSE GLASS TUBE (2A0.25V)
F003	1-532-567-00	FUSE GLASS TUBE (3A.125V)

FUSE HOLDER

FH001	1-533-162-00	HOLDER, FUSE
FH002	1-533-162-00	HOLDER, FUSE
FH003	1-533-162-00	HOLDER, FUSE
FH004	1-533-162-00	HOLDER, FUSE

*1-614-951-13 PT-48 BOARD *****

CAPACITOR

C001	1-130-680-11	FILM 0.1MF 20% 25V
C002	1-161-742-12	CERAMIC 0.0022MF 20% 50V
C003	1-161-742-12	CERAMIC 0.0022MF 20% 50V

CONNECTOR

CN711	*1-560-436-00	HORIZONTAL PIN ASSY 3P
-------	---------------	------------------------

FUSE

F001	1-532-593-11	FUSE GLASS TUBE
------	--------------	-----------------

RESISTOR

R001	1-202-723-11	SOL 10 5% 2W 10% 1/2W
------	--------------	-----------------------

TRANSFORMER

T001	1-421-357-31	TRANSFORMER, LINE FILTER
------	--------------	--------------------------

*A-6724-440-A TM-75 BOARD, COMPLETE *****

CAPACITOR

C101	1-161-013-00	CERAMIC 0.01MF 10% 25V
C102	1-123-380-00	ELECT 1MF 20% 50V
C103	1-123-380-00	ELECT 1MF 20% 50V
C104	1-123-379-00	ELECT 0.47MF 20% 50V
C105	1-161-013-00	CERAMIC 0.01MF 10% 25V
C106	1-161-013-00	CERAMIC 0.01MF 10% 25V
C107	1-123-369-00	ELECT 4.7MF 20% 25V

The components identified by shading and mark **▲** are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque **▲** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description	Remark
C108	1-123-616-00	ELECT 4.7MF	20% 25V
C109	1-102-518-00	CERAMIC 33PF	5% 50V
C110	1-102-518-00	CERAMIC 33PF	5% 50V
C111	1-102-852-00	CERAMIC 47PF	5% 50V

CONNECTOR

CN601	*1-564-005-00	PIN, CONNECTOR 6P
CN602	*1-564-008-21	PIN, CONNECTOR 9P
CN603	*1-564-006-11	PIN, CONNECTOR 7P
CN604	*1-564-001-11	PIN, CONNECTOR 2P
CN605	*1-564-002-00	PIN, CONNECTOR 3P

CN606	*1-564-003-00	PIN, CONNECTOR 4P
-------	---------------	-------------------

COMPOSITION CIRCUIT BLOCK

CP001	1-235-339-11	RES BLOCK 47KX8
CP002	1-235-339-11	RES BLOCK 47KX8
CP003	1-235-339-11	RES BLOCK 47KX8
CP004	1-235-339-11	RES BLOCK 47KX8

DIODE

D101	8-719-911-19	DIODE 1SS119
------	--------------	--------------

IC

IC101	8-759-913-30	IC MB88525B-125M
IC102	8-759-200-22	IC TC40H138P
IC103	8-759-909-15	IC MSL915RS

INDICATOR

ND101	1-519-360-11	INDICATOR TUBE, FLUORESCENT
-------	--------------	-----------------------------

TRANSISTOR

Q101	8-729-245-83	TRANSISTOR 2SC2458
Q102	8-729-900-63	TRANSISTOR DTA124ES
Q103	8-729-900-36	TRANSISTOR DTC124ES

RESISTOR

R101	1-247-847-00	CARBON 4.7K 5% 1/6W
R102	1-247-855-00	CARBON 10K 5% 1/6W
R103	1-247-879-00	CARBON 100K 5% 1/6W
R104	1-247-871-00	CARBON 47K 5% 1/6W
R105	1-247-855-00	CARBON 10K 5% 1/6W

R109	1-247-859-00	CARBON 15K 5% 1/6W
R110	1-247-855-00	CARBON 10K 5% 1/6W

SWITCH

S101	1-554-174-00	SWITCH, KEY BOARD
S102	1-554-174-00	SWITCH, KEY BOARD
S103	1-554-174-00	SWITCH, KEY BOARD
S104	1-554-174-00	SWITCH, KEY BOARD
S105	1-554-174-00	SWITCH, KEY BOARD

S106	1-554-174-00	SWITCH, KEY BOARD
S107	1-554-174-00	SWITCH, KEY BOARD

Ref.No	Part No.	Description	Remark
S108	1-554-174-00	SWITCH, KEY BOARD	
S109	1-554-174-00	SWITCH, KEY BOARD	
S110	1-554-174-00	SWITCH, KEY BOARD	
S111	1-554-174-00	SWITCH, KEY BOARD	

CRYSTAL

X101	1-527-997-00	VIBRATOR, CRYSTAL
------	--------------	-------------------

*A-6725-402-A AF-9 BOARD, COMPLETE

1-123-306-00	ELECT	47MF	20%	10V
1-124-069-11	ELECT	100MF	20%	10V
1-123-308-00	ELECT	220MF	20%	10V
*3-669-610-00	SPACER			

CAPACITOR

C001	1-101-888-00	CERAMIC 68PF	5%	50V
C002	1-101-003-00	CERAMIC 0.0047MF		50V
C003	1-101-003-00	CERAMIC 0.0047MF		50V
C004	1-123-306-00	ELECT 47MF	20%	10V
C005	1-130-471-00	MYLAR 0.001MF	5%	50V
C006	1-130-482-00	MYLAR 0.0082MF	5%	50V
C007	1-130-477-00	MYLAR 0.0033MF	5%	50V
C008	1-102-824-00	CERAMIC 470PF	5%	50V
C009	1-123-356-00	ELECT 10MF	20%	25V
C010	1-123-356-00	ELECT 10MF	20%	25V

C011	1-101-003-00	CERAMIC 0.0047MF		50V
C012	1-101-003-00	CERAMIC 0.0047MF		50V
C013	1-123-318-00	ELECT 33MF	20%	16V
C014	1-101-003-00	CERAMIC 0.0047MF		50V
C015	1-101-003-00	CERAMIC 0.0047MF		50V

C016	1-101-003-00	CERAMIC 0.0047MF		50V
C017	1-101-003-00	CERAMIC 0.0047MF		50V
C018	1-101-888-00	CERAMIC 68PF	5%	50V
C019	1-123-330-00	ELECT 22MF	20%	16V
C024	1-123-309-00	ELECT 330MF	20%	10V

C026	1-123-620-00	ELECT 10MF	20%	25V
C027	1-101-003-00	CERAMIC 0.0047MF		50V
C028	1-123-308-00	ELECT 220MF	20%	10V
C029	1-123-820-00	ELECT 33MF	20%	16V
C030	1-123-318-00	ELECT 33MF	20%	16V

C031	1-102-958-00	CERAMIC 20PF	5%	50V
C032	1-136-155-00	MYLAR 0.015MF	10%	50V
C033	1-102-936-00	CERAMIC 3PF	0.5PF	50V
C034	1-136-155-00	MYLAR 0.015MF	10%	50V
C035	1-130-498-00	MYLAR 0.18MF	5%	50V

C036	1-136-161-00	MYLAR 0.047MF	10%	50V
C037	1-130-469-00	MYLAR 680PF	5%	50V
C038	1-102-936-00	CERAMIC 3PF	0.5PF	50V
C039	1-130-475-00	MYLAR 0.0022MF	5%	50V
C040	1-130-493-00	MYLAR 0.068MF	5%	50V

When indicating parts by reference number, please include the board name.

AF-9

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark	
C041	1-130-485-00	MYLAR	0.015MF 5%	50V	C220	1-136-165-00	MYLAR 0.1MF 10% 50V	
C042	1-123-380-00	ELECT	1MF 20%	50V	C221	1-123-369-00	ELECT 4.7MF 20% 25V	
C043	1-123-356-00	ELECT	10MF 20%	25V	C222	1-130-483-00	MYLAR 0.01MF 5% 50V	
C046	1-123-356-00	ELECT	10MF 20%	25V	C223	1-130-471-00	MYLAR 0.001MF 5% 50V	
C047	1-123-356-00	ELECT	10MF 20%	25V	C226	1-123-620-00	ELECT 10MF 20% 25V	
C050	1-101-003-00	CERAMIC	0.0047MF	50V	C227	1-101-003-00	CERAMIC 0.0047MF	50V
C051	1-101-003-00	CERAMIC	0.0047MF	50V	C228	1-123-308-00	ELECT 220MF	20% 10V
C053	1-123-330-00	ELECT	22MF 20%	16V	C229	1-123-820-00	ELECT 33MF	20% 16V
C054	1-101-003-00	CERAMIC	0.0047MF	50V	C230	1-123-820-00	ELECT 33MF	20% 16V
C056	1-123-382-00	ELECT	3.3MF 20%	50V	C231	1-102-958-00	CERAMIC 20PF	5% 50V
C057	1-123-382-00	ELECT	3.3MF 20%	50V	C232	1-136-155-00	MYLAR 0.015MF	10% 50V
C058	1-101-003-00	CERAMIC	0.0047MF	50V	C233	1-102-936-00	CERAMIC 3PF	0.5PF 50V
C059	1-101-003-00	CERAMIC	0.0047MF	50V	C234	1-136-155-00	MYLAR 0.015MF	10% 50V
C060	1-101-003-00	CERAMIC	0.0047MF	50V	C235	1-130-498-00	MYLAR 0.18MF	5% 50V
C061	1-101-003-00	CERAMIC	0.0047MF	50V	C236	1-136-161-00	MYLAR 0.047MF	10% 50V
C063	1-123-306-00	ELECT	47MF 20%	10V	C237	1-130-469-00	MYLAR 680PF	5% 50V
C064	1-101-003-00	CERAMIC	0.0047MF	50V	C238	1-102-936-00	CERAMIC 3PF	0.5PF 50V
C065	1-123-333-00	ELECT	100MF 20%	25V	C239	1-130-475-00	MYLAR 0.0022MF	5% 50V
C066	1-101-001-00	CERAMIC	0.001MF	50V	C240	1-130-493-00	MYLAR 0.068MF	5% 50V
C067	1-123-309-00	ELECT	330MF 20%	6.3V	C241	1-130-485-00	MYLAR 0.015MF	5% 50V
C099	1-123-306-00	ELECT	47MF 20%	10V	C242	1-123-380-00	ELECT 1MF	20% 50V
C103	1-123-330-00	ELECT	22MF 20%	16V	C243	1-123-356-00	ELECT 10MF	20% 25V
C104	1-130-497-00	MYLAR	0.15MF 10%	50V	C244	1-101-003-00	CERAMIC 0.0047MF	50V
C105	1-130-497-00	MYLAR	0.15MF 10%	50V	C245	1-124-069-11	ELECT 100MF	20% 10V
C106	1-123-330-00	ELECT	22MF 20%	16V	C246	1-123-356-00	ELECT 10MF	20% 25V
C107	1-123-330-00	ELECT	22MF 20%	16V	C247	1-123-356-00	ELECT 10MF	20% 25V
C108	1-123-330-00	ELECT	22MF 20%	16V	C250	1-101-003-00	CERAMIC 0.0047MF	50V
C110	1-101-003-00	CERAMIC	0.0047MF	50V	C251	1-101-003-00	CERAMIC 0.0047MF	50V
C111	1-101-003-00	CERAMIC	0.0047MF	50V	C253	1-123-330-00	ELECT 22MF	20% 16V
C112	1-101-003-00	CERAMIC	0.0047MF	50V	C254	1-101-003-00	CERAMIC 0.0047MF	50V
C113	1-123-330-00	ELECT	22MF 20%	16V	C256	1-123-382-00	ELECT 3.3MF	20% 50V
C114	1-101-003-00	CERAMIC	0.0047MF	50V	C257	1-123-382-00	ELECT 3.3MF	20% 50V
C115	1-123-330-00	ELECT	22MF 20%	16V	C258	1-101-003-00	CERAMIC 0.0047MF	50V
C116	1-123-330-00	ELECT	22MF 20%	16V	C259	1-101-003-00	CERAMIC 0.0047MF	50V
C201	1-101-888-00	CERAMIC	68PF 5%	50V	C260	1-101-003-00	CERAMIC 0.0047MF	50V
C202	1-101-003-00	CERAMIC	0.0047MF	50V	C261	1-101-003-00	CERAMIC 0.0047MF	50V
C203	1-101-003-00	CERAMIC	0.0047MF	50V	C263	1-123-306-00	ELECT 47MF	20% 10V
C204	1-123-306-00	ELECT	47MF 20%	10V	C299	1-123-306-00	ELECT 47MF	20% 10V
C205	1-130-471-00	MYLAR	0.001MF 5%	50V	C301	1-123-356-00	ELECT 10MF	20% 16V
C206	1-130-482-00	MYLAR	0.0082MF 5%	50V	C302	1-123-356-00	ELECT 10MF	20% 16V
C207	1-130-477-00	MYLAR	0.0033MF 5%	50V	C303	1-123-356-00	ELECT 10MF	20% 16V
C208	1-102-824-00	CERAMIC	470PF 5%	50V	C304	1-102-074-00	CERAMIC 0.001MF	10% 50V
C209	1-123-356-00	ELECT	10MF 20%	25V	C305	1-123-356-00	ELECT 10MF	20% 16V
C210	1-123-356-00	ELECT	10MF 20%	25V	C306	1-102-074-00	CERAMIC 0.001MF	10% 50V
C211	1-101-003-00	CERAMIC	0.0047MF	50V	C307	1-161-039-00	CERAMIC 0.001MF	10% 25V
C212	1-101-003-00	CERAMIC	0.0047MF	50V	C308	1-161-039-00	CERAMIC 0.001MF	10% 25V
C213	1-123-318-00	ELECT	33MF 20%	16V	C309	1-123-318-00	ELECT 33MF	20% 16V
C214	1-101-003-00	CERAMIC	0.0047MF	50V	C310	1-123-356-00	ELECT 10MF	20% 16V
C215	1-101-003-00	CERAMIC	0.0047MF	50V	C311	1-123-356-00	ELECT 10MF	20% 16V
C216	1-101-003-00	CERAMIC	0.0047MF	50V	C401	1-130-479-00	MYLAR 0.0047MF	5% 50V
C217	1-101-003-00	CERAMIC	0.0047MF	50V	C402	1-130-476-00	MYLAR 0.0027MF	5% 50V
C218	1-101-888-00	CERAMIC	68PF 5%	50V	C403	1-123-356-00	ELECT 10MF	20% 16V
C219	1-123-330-00	ELECT	22MF 20%	16V	C404	1-130-476-00	MYLAR 0.0027MF	5% 50V

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
C405	1-130-471-00	MYLAR	0.001MF	5%	50V		
C406	1-130-471-00	MYLAR	0.001MF	5%	50V		
C410	1-123-308-00	ELECT	220MF	20%	6.3V		
C421	1-123-356-00	ELECT	10MF	20%	25V		
C422	1-123-356-00	ELECT	10MF	20%	25V		
C506	1-123-356-00	ELECT	10MF	20%	16V		
C507	1-123-356-00	ELECT	10MF	20%	16V		
C551	1-123-332-00	ELECT	47MF	20%	16V		
C552	1-123-332-00	ELECT	47MF	20%	16V		
C553	1-123-306-00	ELECT	47MF	20%	10V		
C554	1-123-369-00	ELECT	4.7MF	20%	25V		
C555	1-123-381-00	ELECT	2.2MF	20%	50V		
C556	1-123-306-00	ELECT	47MF	20%	10V		
C557	1-161-051-00	CERAMIC	0.01MF	10%	50V		
C558	1-123-332-00	ELECT	47MF	20%	16V		
C559	1-123-308-00	ELECT	220MF	20%	6.3V		
C560	1-123-380-00	ELECT	1MF	20%	50V		
C561	1-101-003-00	CERAMIC	0.0047MF	50V			
C601	1-123-356-00	ELECT	10MF	20%	16V		
C602	1-123-356-00	ELECT	10MF	20%	16V		
C603	1-102-978-00	CERAMIC	220PF	5%	50V		
C604	1-102-978-00	CERAMIC	220PF	5%	50V		
C605	1-123-356-00	ELECT	10MF	20%	16V		
C606	1-123-356-00	ELECT	10MF	20%	16V		
C607	1-123-356-00	ELECT	10MF	20%	16V		
C608	1-123-356-00	ELECT	10MF	20%	16V		
C609	1-102-121-00	CERAMIC	0.0022MF	10%	50V		
C610	1-102-121-00	CERAMIC	0.0022MF	10%	50V		
C611	1-101-001-00	CERAMIC	0.001MF	50V			
C612	1-101-001-00	CERAMIC	0.001MF	50V			
C615	1-123-306-00	ELECT	47MF	20%	10V		
C616	1-123-306-00	ELECT	47MF	20%	10V		
C617	1-123-356-00	ELECT	10MF	20%	16V		
C618	1-130-483-00	MYLAR	0.01MF	5%	50V		
C619	1-123-608-00	ELECT	0.22MF	20%	50V		
C630	1-102-973-00	CERAMIC	100PF	5%	50V		
C631	1-102-973-00	CERAMIC	100PF	5%	50V		
C632	1-123-308-00	ELECT	220MF	20%	10V		
C633	1-123-675-12	ELECT	1000MF	20%	10V		
<u>CONNECTOR</u>							
CN301	*1-560-898-00	PIN, CONNECTOR	10P				
CN302	*1-560-893-00	PIN, CONNECTOR	5P				
CN303	*1-560-898-00	PIN, CONNECTOR	10P				
CN304	*1-560-893-00	PIN, CONNECTOR	5P				
CN305	*1-560-894-00	PIN, CONNECTOR	6P				
CN306	*1-560-895-00	PIN, CONNECTOR	7P				
CN307	*1-560-894-00	PIN, CONNECTOR	6P				
CN308	*1-560-898-00	PIN, CONNECTOR	10P				
CN309	*1-560-893-00	PIN, CONNECTOR	5P				
CN310	*1-560-892-00	PIN, CONNECTOR	4P				
CN311	*1-560-894-00	PIN, CONNECTOR	6P				
CN364	*1-560-891-00	PIN, CONNECTOR	3P				
<u>JACK</u>							
CNJ001	1-536-893-11	TERMINAL BOARD					
<u>DIODE</u>							
D001	8-719-000-12	DIODE	MC931				
D101	8-719-156-07	DIODE	RD5.6E-B				
D102	8-719-156-07	DIODE	RD5.6E-B				
D103	8-719-156-07	DIODE	RD5.6E-B				
D201	8-719-000-12	DIODE	MC931				
D301	8-719-911-19	DIODE	1SS119				
D302	8-719-911-19	DIODE	1SS119				
D408	8-719-100-47	DIODE	RD8.2EB1				
D505	8-719-911-19	DIODE	1SS119				
D506	8-719-000-06	DIODE	MC921				
D601	8-719-156-07	DIODE	RD5.6E-B				
D602	8-719-156-07	DIODE	RD5.6E-B				
D603	8-719-911-19	DIODE	1SS119				
D604	8-719-000-04	DIODE	MC911				
D608	8-719-911-19	DIODE	1SS119				
D609	8-719-911-19	DIODE	1SS119				
D610	8-719-911-19	DIODE	1SS119				
<u>FILTER</u>							
FL001	1-235-372-11	FILTER, BAND PASS					
FL002	1-235-373-11	FILTER, BAND PASS					
FL003	1-235-374-11	FILTER, BAND PASS					
FL004	1-235-375-11	FILTER, BAND PASS					
FL101	1-464-400-11	L.P.F UNIT					
FL102	1-235-370-11	FILTER (LPF)					
FL202	1-235-369-11	FILTER (LPF)					
<u>IC</u>							
IC001	8-752-009-70	IC	CX20097				
IC002	8-752-010-50	IC	CX20105				
IC003	8-752-010-40	IC	CX20104				
IC004	8-757-982-00	IC	CX-7982				
IC007	8-752-006-10	IC	CX20061				
IC202	8-752-010-50	IC	CX20105				
IC207	8-752-006-10	IC	CX20061				
IC301	8-759-135-80	IC	UPC358C				
IC501	8-759-602-66	IC	M5230L				
IC502	8-759-700-11	IC	NJM78M05A				
IC601	8-759-601-02	IC	M5218P				
IC602	8-759-240-53	IC	TC4053BP				
IC604	8-759-745-60	IC	NJM4560D				
IC605	8-759-145-58	IC	UPC4558C				
IC606	8-759-240-52	IC	TC4052BP				
IC607	8-759-240-53	IC	TC4053BP				
IC608	8-759-745-60	IC	NJM4560D				

When indicating parts by reference number, please include the board name.

AF-9

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
<u>COIL</u>							
L201	1-410-120-11	MICRO INDUCTOR 1.2MMH		R021	1-247-843-00	CARBON 3.3K 5%	1/6W
				R022	1-247-859-00	CARBON 15K 5%	1/6W
				R023	1-247-852-00	CARBON 7.5K 5%	1/6W
				R024	1-247-824-00	CARBON 510 5%	1/6W
				R025	1-247-857-00	CARBON 12K 5%	1/6W
<u>TRANSISTOR</u>							
Q001	8-729-900-36	TRANSISTOR DTC124ES		R026	1-247-855-00	CARBON 10K 5%	1/6W
Q002	8-729-900-36	TRANSISTOR DTC124ES		R027	1-247-852-00	CARBON 7.5K 5%	1/6W
Q003	8-729-900-36	TRANSISTOR DTC124ES		R028	1-247-843-00	CARBON 3.3K 5%	1/6W
Q104	8-729-900-36	TRANSISTOR DTC124ES		R029	1-247-834-00	CARBON 1.3K 5%	1/6W
Q201	8-729-900-36	TRANSISTOR DTC124ES		R030	1-247-804-00	CARBON 75 5%	1/6W
Q202	8-729-900-36	TRANSISTOR DTC124ES		R031	1-247-858-00	CARBON 13K 5%	1/6W
Q203	8-729-900-36	TRANSISTOR DTC124ES		R032	1-247-858-00	CARBON 13K 5%	1/6W
Q301	8-729-245-83	TRANSISTOR 2SC2458		R033	1-247-833-00	CARBON 1.2K 5%	1/6W
Q302	8-729-245-83	TRANSISTOR 2SC2458		R034	1-247-838-00	CARBON 2K 5%	1/6W
Q401	8-729-204-83	TRANSISTOR 2SA1048-GR		R035	1-247-834-00	CARBON 1.3K 5%	1/6W
Q402	8-729-245-83	TRANSISTOR 2SC2458		R036	1-247-885-00	CARBON 180K 5%	1/6W
Q403	8-729-204-83	TRANSISTOR 2SA1048-GR		R037	1-247-849-00	CARBON 5.6K 5%	1/6W
Q404	8-729-245-83	TRANSISTOR 2SC2458		R038	1-247-865-00	CARBON 27K 5%	1/6W
Q503	8-729-900-89	TRANSISTOR DTC144ES		R040	1-215-437-00	METAL 4.7K 1%	1/6W
Q504	8-729-245-83	TRANSISTOR 2SC2458		R041	1-247-824-00	CARBON 510 5%	1/6W
Q505	8-729-900-65	TRANSISTOR DTA144ES		R042	1-247-825-00	CARBON 560 5%	1/6W
Q506	8-729-900-65	TRANSISTOR DTA144ES		R043	1-247-855-00	CARBON 10K 5%	1/6W
Q507	8-729-900-89	TRANSISTOR DTC144ES		R044	1-247-895-00	CARBON 470K 5%	1/6W
Q508	8-729-900-89	TRANSISTOR DTC144ES		R045	1-247-807-00	CARBON 100 5%	1/6W
Q551	8-729-177-32	TRANSISTOR 2SD773		R046	1-247-817-00	CARBON 270 5%	1/6W
Q601	8-729-245-83	TRANSISTOR 2SC2458		R047	1-247-867-00	CARBON 33K 5%	1/6W
Q603	8-729-245-83	TRANSISTOR 2SC2458		R050	1-247-863-00	CARBON 22K 5%	1/6W
Q604	8-729-245-83	TRANSISTOR 2SC2458		R051	1-247-831-00	CARBON 1K 5%	1/6W
Q605	8-729-900-89	TRANSISTOR DTC144ES		R052	1-215-453-00	METAL 22K 1%	1/6W
Q606	8-729-245-83	TRANSISTOR 2SC2458		R053	1-247-864-00	CARBON 24K 5%	1/6W
Q607	8-729-900-89	TRANSISTOR DTC144ES		R054	1-247-855-00	CARBON 10K 5%	1/6W
Q608	8-729-245-83	TRANSISTOR 2SC2458		R055	1-247-863-00	CARBON 22K 5%	1/6W
Q609	8-729-245-83	TRANSISTOR 2SC2458		R056	1-247-839-00	CARBON 2.2K 5%	1/6W
Q610	8-729-900-89	TRANSISTOR DTC144ES		R057	1-247-861-00	CARBON 18K 5%	1/6W
Q611	8-729-900-89	TRANSISTOR DTC144ES		R059	1-247-855-00	CARBON 10K 5%	1/6W
Q612	8-729-900-89	TRANSISTOR DTC144ES		R064	1-247-817-00	CARBON 270 5%	1/6W
Q615	8-729-900-89	TRANSISTOR DTC144ES		R065	1-247-885-00	CARBON 180K 5%	1/6W
<u>RESISTOR</u>							
R001	1-247-898-00	CARBON 620K 5%	1/6W	R071	1-247-895-00	CARBON 470K 5%	1/6W
R002	1-247-843-00	CARBON 3.3K 5%	1/6W	R072	1-247-895-00	CARBON 470K 5%	1/6W
R003	1-247-843-00	CARBON 3.3K 5%	1/6W	R083	1-215-439-00	METAL 5.6K 1%	1/6W
R004	1-247-843-00	CARBON 3.3K 5%	1/6W	R085	1-247-860-00	CARBON 16K 5%	1/6W
R005	1-247-845-00	CARBON 3.9K 5%	1/6W	R088	1-247-818-00	CARBON 300 5%	1/6W
R006	1-215-429-00	METAL 2.2K 1%	1/6W	R089	1-247-859-00	CARBON 15K 5%	1/6W
R007	1-247-877-00	CARBON 82K 5%	1/6W	R093	1-247-831-00	CARBON 1K 5%	1/6W
R008	1-215-458-00	METAL 36K 1%	1/6W	R094	1-247-825-00	CARBON 560 5%	1/6W
R010	1-247-857-00	CARBON 12K 5%	1/6W	R095	1-247-853-00	CARBON 8.2K 5%	1/6W
R011	1-215-441-00	METAL 6.8K 1%	1/6W	R097	1-247-817-00	CARBON 270 5%	1/6W
R012	1-247-838-00	CARBON 2K 5%	1/6W	R098	1-247-813-00	CARBON 180 5%	1/6W
R016	1-247-698-11	CARBON 68 5%	1/4W F	R099	1-247-852-00	CARBON 7.5K 5%	1/6W
R017	1-247-863-00	CARBON 22K 5%	1/6W	R101	1-247-859-00	CARBON 15K 5%	1/6W
R020	1-247-849-00	CARBON 5.6K 5%	1/6W				

When indicating parts by reference number, please include the board name.

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
R104	1-247-857-00	CARBON	12K 5% 1/6W	R242	1-247-825-00	CARBON	560 5% 1/6W
R105	1-247-891-00	CARBON	330K 5% 1/6W	R243	1-247-855-00	CARBON	10K 5% 1/6W
R106	1-247-891-00	CARBON	330K 5% 1/6W	R244	1-247-895-00	CARBON	470K 5% 1/6W
R107	1-247-891-00	CARBON	330K 5% 1/6W	R245	1-247-807-00	CARBON	100 5% 1/6W
R108	1-247-891-00	CARBON	330K 5% 1/6W	R250	1-247-861-00	CARBON	18K 5% 1/6W
R109	1-247-857-00	CARBON	12K 5% 1/6W	R251	1-247-831-00	CARBON	1K 5% 1/6W
R111	1-247-859-00	CARBON	15K 5% 1/6W	R252	1-215-453-00	METAL	22K 1% 1/6W
R113	1-247-879-00	CARBON	100K 5% 1/6W	R254	1-247-855-00	CARBON	10K 5% 1/6W
R114	1-247-860-00	CARBON	16K 5% 1/6W	R255	1-247-861-00	CARBON	18K 5% 1/6W
R115	1-247-860-00	CARBON	16K 5% 1/6W	R264	1-247-817-00	CARBON	270 5% 1/6W
R116	1-247-831-00	CARBON	1K 5% 1/6W	R265	1-247-885-00	CARBON	180K 5% 1/6W
R117	1-247-831-00	CARBON	1K 5% 1/6W	R266	1-247-823-00	CARBON	470 5% 1/6W
R118	1-247-831-00	CARBON	1K 5% 1/6W	R269	1-215-438-00	METAL	5.1K 1% 1/6W
R119	1-247-831-00	CARBON	1K 5% 1/6W	R270	1-247-895-00	CARBON	470K 5% 1/6W
R120	1-247-831-00	CARBON	1K 5% 1/6W	R271	1-247-895-00	CARBON	470K 5% 1/6W
R121	1-247-831-00	CARBON	1K 5% 1/6W	R272	1-247-895-00	CARBON	470K 5% 1/6W
R122	1-247-831-00	CARBON	1K 5% 1/6W	R283	1-215-441-00	METAL	6.8K 1% 1/6W
R123	1-247-831-00	CARBON	1K 5% 1/6W	R288	1-247-815-00	CARBON	220 5% 1/6W
R125	1-247-849-00	CARBON	5.6K 5% 1/6W	R289	1-247-850-00	CARBON	6.2K 5% 1/6W
R201	1-247-898-00	CARBON	620K 5% 1/6W	R293	1-247-824-00	CARBON	510 5% 1/6W
R202	1-247-843-00	CARBON	3.3K 5% 1/6W	R294	1-247-825-00	CARBON	560 5% 1/6W
R203	1-247-843-00	CARBON	3.3K 5% 1/6W	R297	1-247-819-00	CARBON	330 5% 1/6W
R204	1-247-843-00	CARBON	3.3K 5% 1/6W	R298	1-247-811-00	CARBON	150 5% 1/6W
R205	1-215-437-00	METAL	4.7K 1% 1/6W	R299	1-247-843-00	CARBON	3.3K 5% 1/6W
R206	1-215-433-00	METAL	3.3K 1% 1/6W	R301	1-247-889-00	CARBON	270K 5% 1/6W
R207	1-247-873-00	CARBON	56K 5% 1/6W	R302	1-247-891-00	CARBON	330K 5% 1/6W
R208	1-215-457-00	METAL	33K 1% 1/6W	R303	1-247-853-00	CARBON	8.2K 5% 1/6W
R210	1-247-851-00	CARBON	6.8K 5% 1/6W	R304	1-247-889-00	CARBON	270K 5% 1/6W
R211	1-215-439-00	METAL	5.6K 1% 1/6W	R305	1-247-891-00	CARBON	330K 5% 1/6W
R212	1-247-838-00	CARBON	2K 5% 1/6W	R306	1-247-853-00	CARBON	8.2K 5% 1/6W
R214	1-247-869-00	CARBON	39K 5% 1/6W	R307	1-247-861-00	CARBON	18K 5% 1/6W
R215	1-247-883-00	CARBON	150K 5% 1/6W	R308	1-247-861-00	CARBON	18K 5% 1/6W
R217	1-247-863-00	CARBON	22K 5% 1/6W	R309	1-247-869-00	CARBON	39K 5% 1/6W
R220	1-247-855-00	CARBON	10K 5% 1/6W	R310	1-247-857-00	CARBON	12K 5% 1/6W
R221	1-247-843-00	CARBON	3.3K 5% 1/6W	R311	1-247-857-00	CARBON	12K 5% 1/6W
R222	1-247-859-00	CARBON	15K 5% 1/6W	R312	1-247-869-00	CARBON	39K 5% 1/6W
R223	1-247-852-00	CARBON	7.5K 5% 1/6W	R313	1-247-895-00	CARBON	470K 5% 1/6W
R224	1-247-824-00	CARBON	510 5% 1/6W	R314	1-247-895-00	CARBON	470K 5% 1/6W
R225	1-247-857-00	CARBON	12K 5% 1/6W	R315	1-247-863-00	CARBON	22K 5% 1/6W
R226	1-247-855-00	CARBON	10K 5% 1/6W	R316	1-247-863-00	CARBON	22K 5% 1/6W
R227	1-247-852-00	CARBON	7.5K 5% 1/6W	R317	1-247-151-00	CARBON	6.8K 5% 1/4W
R228	1-247-843-00	CARBON	3.3K 5% 1/6W	R318	1-247-853-00	CARBON	8.2K 5% 1/6W
R229	1-247-834-00	CARBON	1.3K 5% 1/6W	R319	1-247-881-00	CARBON	120K 5% 1/6W
R230	1-247-804-00	CARBON	75 5% 1/6W	R320	1-247-791-00	CARBON	22 5% 1/6W
R231	1-247-858-00	CARBON	13K 5% 1/6W	R321	1-247-881-00	CARBON	120K 5% 1/6W
R232	1-247-858-00	CARBON	13K 5% 1/6W	R322	1-247-791-00	CARBON	22 5% 1/6W
R233	1-247-833-00	CARBON	1.2K 5% 1/6W	R401	1-247-855-00	CARBON	10K 5% 1/6W
R234	1-247-838-00	CARBON	2K 5% 1/6W	R402	1-247-879-00	CARBON	100K 5% 1/6W
R235	1-247-834-00	CARBON	1.3K 5% 1/6W	R403	1-247-839-00	CARBON	2.2K 5% 1/6W
R236	1-247-885-00	CARBON	180K 5% 1/6W	R404	1-247-864-00	CARBON	24K 5% 1/6W
R237	1-247-849-00	CARBON	5.6K 5% 1/6W	R405	1-247-875-00	CARBON	68K 5% 1/6W
R238	1-247-865-00	CARBON	27K 5% 1/6W	R406	1-247-849-00	CARBON	5.6K 5% 1/6W
R241	1-247-824-00	CARBON	510 5% 1/6W	R408	1-247-863-00	CARBON	22K 5% 1/6W

When indicating parts by reference number, please include the board name.

AF-9

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
R409	1-247-819-00	CARBON	330 5% 1/6W	R629	1-247-863-00	CARBON	22K 5% 1/6W
R411	1-247-887-00	CARBON	220K 5% 1/6W	R630	1-247-855-00	CARBON	10K 5% 1/6W
R412	1-247-819-00	CARBON	330 5% 1/6W	R631	1-247-861-00	CARBON	18K 5% 1/6W
R413	1-247-875-00	CARBON	68K 5% 1/6W	R632	1-247-861-00	CARBON	18K 5% 1/6W
R414	1-247-875-00	CARBON	68K 5% 1/6W	R633	1-247-807-00	CARBON	100 5% 1/6W
R415	1-247-887-00	CARBON	220K 5% 1/6W	R634	1-247-807-00	CARBON	100 5% 1/6W
R416	1-247-847-00	CARBON	4.7K 5% 1/6W	R635	1-247-867-00	CARBON	33K 5% 1/6W
R419	1-247-847-00	CARBON	4.7K 5% 1/6W	R636	1-247-879-00	CARBON	100K 5% 1/6W
R420	1-247-847-00	CARBON	4.7K 5% 1/6W	R637	1-247-879-00	CARBON	100K 5% 1/6W
R505	1-247-863-00	CARBON	22K 5% 1/6W	R638	1-247-879-00	CARBON	100K 5% 1/6W
R506	1-247-863-00	CARBON	22K 5% 1/6W	R639	1-247-879-00	CARBON	100K 5% 1/6W
R508	1-247-867-00	CARBON	33K 5% 1/6W	R640	1-247-867-00	CARBON	33K 5% 1/6W
R509	1-247-863-00	CARBON	22K 5% 1/6W	R641	1-247-879-00	CARBON	100K 5% 1/6W
R510	1-247-879-00	CARBON	100K 5% 1/6W	R642	1-247-879-00	CARBON	100K 5% 1/6W
R511	1-247-849-00	CARBON	5.6K 5% 1/6W	R643	1-247-863-00	CARBON	22K 5% 1/6W
R512	1-247-841-00	CARBON	2.7K 5% 1/6W	R645	1-247-863-00	CARBON	22K 5% 1/6W
R513	1-247-851-00	CARBON	6.8K 5% 1/6W	R646	1-247-831-00	CARBON	1K 5% 1/6W
R514	1-247-855-00	CARBON	10K 5% 1/6W	R647	1-247-831-00	CARBON	1K 5% 1/6W
R515	1-247-851-00	CARBON	6.8K 5% 1/6W	R648	1-247-871-00	CARBON	47K 5% 1/6W
R516	1-247-855-00	CARBON	10K 5% 1/6W	R649	1-247-871-00	CARBON	47K 5% 1/6W
R517	1-247-863-00	CARBON	22K 5% 1/6W	R650	1-247-879-00	CARBON	100K 5% 1/6W
R518	1-247-817-00	CARBON	270 5% 1/6W	R651	1-247-879-00	CARBON	100K 5% 1/6W
R519	1-247-817-00	CARBON	270 5% 1/6W	R652	1-247-839-00	CARBON	2.2K 5% 1/6W
R520	1-247-815-00	CARBON	220 5% 1/6W	R653	1-247-859-00	CARBON	15K 5% 1/6W
R521	1-247-815-00	CARBON	220 5% 1/6W	R654	1-247-839-00	CARBON	2.2K 5% 1/6W
R551	1-247-903-00	CARBON	1M 5% 1/6W	R555	1-247-859-00	CARBON	15K 5% 1/6W
R552	1-215-449-00	METAL	15K 1% 1/6W	R556	1-247-861-00	CARBON	18K 5% 1/6W
R553	1-215-445-00	METAL	10K 1% 1/6W	R557	1-247-861-00	CARBON	18K 5% 1/6W
R554	1-215-449-00	METAL	15K 1% 1/6W	R558	1-247-871-00	CARBON	47K 5% 1/6W
R555	1-215-433-00	METAL	3.3K 1% 1/6W	R559	1-247-871-00	CARBON	47K 5% 1/6W
R557	1-247-851-00	CARBON	6.8K 5% 1/6W	R660	1-247-835-00	CARBON	1.5K 5% 1/6W
R601	1-247-887-00	CARBON	220K 5% 1/6W	R661	1-247-835-00	CARBON	1.5K 5% 1/6W
R602	1-247-887-00	CARBON	220K 5% 1/6W	R662	1-247-839-00	CARBON	2.2K 5% 1/6W
R603	1-247-875-00	CARBON	68K 5% 1/6W	R663	1-247-839-00	CARBON	2.2K 5% 1/6W
R604	1-247-875-00	CARBON	68K 5% 1/6W	R666	1-247-879-00	CARBON	100K 5% 1/6W
R605	1-247-831-00	CARBON	1K 5% 1/6W	R668	1-247-865-00	CARBON	27K 5% 1/6W
R606	1-247-831-00	CARBON	1K 5% 1/6W	R669	1-247-847-00	CARBON	4.7K 5% 1/6W
R609	1-247-875-00	CARBON	68K 5% 1/6W	R670	1-247-831-00	CARBON	1K 5% 1/6W
R610	1-247-875-00	CARBON	68K 5% 1/6W	R671	1-247-831-00	CARBON	1K 5% 1/6W
R611	1-247-879-00	CARBON	100K 5% 1/6W	R672	1-247-847-00	CARBON	4.7K 5% 1/6W
R612	1-247-879-00	CARBON	100K 5% 1/6W	R673	1-247-865-00	CARBON	27K 5% 1/6W
R613	1-247-879-00	CARBON	100K 5% 1/6W	R674	1-247-865-00	CARBON	27K 5% 1/6W
R614	1-247-871-00	CARBON	47K 5% 1/6W	R675	1-247-847-00	CARBON	4.7K 5% 1/6W
R615	1-247-871-00	CARBON	47K 5% 1/6W	R676	1-247-865-00	CARBON	27K 5% 1/6W
R616	1-247-857-00	CARBON	12K 5% 1/6W	R677	1-247-891-00	CARBON	330K 5% 1/6W
R617	1-247-855-00	CARBON	10K 5% 1/6W	R678	1-247-887-00	CARBON	220K 5% 1/6W
R618	1-247-855-00	CARBON	10K 5% 1/6W	R679	1-247-855-00	CARBON	10K 5% 1/6W
R619	1-247-855-00	CARBON	10K 5% 1/6W	R681	1-247-855-00	CARBON	10K 5% 1/6W
R620	1-247-879-00	CARBON	100K 5% 1/6W	R682	1-247-865-00	CARBON	27K 5% 1/6W
R621	1-247-867-00	CARBON	33K 5% 1/6W	R683	1-247-855-00	CARBON	10K 5% 1/6W
R622	1-247-867-00	CARBON	33K 5% 1/6W	R684	1-247-855-00	CARBON	10K 5% 1/6W
R627	1-247-863-00	CARBON	22K 5% 1/6W	R685	1-247-879-00	CARBON	100K 5% 1/6W
R628	1-247-855-00	CARBON	10K 5% 1/6W	R696	1-247-771-00	CARBON	3.3 5% 1/8W F

When indicating parts by reference number, please include the board name.

AF-9 LM-8 RD-12 HP-12 FF-3 FP-4

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
R697	1-247-771-00	CARBON	3.3 5% 1/8W F			IC	
R698	1-247-823-00	CARBON	470 5% 1/6W	IC002	8-759-700-40	IC NJM4560S	
R701	1-247-859-00	CARBON	15K 5% 1/6W			JACK	
R702	1-247-859-00	CARBON	15K 5% 1/6W	J001	1-507-995-11	JACK, MICROPHONE	
R703	1-247-717-11	CARBON	2.2K 5% 1/4W	J002	1-507-796-21	JACK	
R704	1-247-717-11	CARBON	2.2K 5% 1/4W			RESISTOR	
R705	1-247-717-11	CARBON	2.2K 5% 1/4W	R034	1-247-803-00	CARBON	68 5% 1/6W
R706	1-247-717-11	CARBON	2.2K 5% 1/4W	R036	1-247-803-00	CARBON	68 5% 1/6W
R707	1-247-807-00	CARBON	100 5% 1/6W	*****			
R801	1-247-804-00	CARBON	75 5% 1/6W			*1-614-947-13	FF-3 BOARD
<u>CRYSTAL</u>							*****
X001	1-567-262-11	VIBRATOR, CRYSTAL					CONNECTOR
*****				CN004	*1-564-006-11	PIN, CONNECTOR 7P	
	*1-605-071-00	LM-8 BOARD					DIODE
		*****		D019	8-719-114-06	DIODE SY406D	
		<u>CAPACITOR</u>				RESISTOR	
C101	1-162-449-11	CERAMIC	0.033MF 20% 25V	R042	1-247-815-00	CARBON	220 5% 1/6W
C102	1-162-449-11	CERAMIC	0.033MF 20% 25V			SWITCH	
<u>COIL</u>				S020	1-554-174-00	SWITCH, KEY BOARD	
L101	1-408-120-00	MICRO INDUCTOR 18UH		S021	1-554-174-00	SWITCH, KEY BOARD	
L102	1-408-120-00	MICRO INDUCTOR 18UH		S022	1-554-174-00	SWITCH, KEY BOARD	
		<u>RESISTOR</u>		*****			
R101	1-206-479-00	METAL OXIDE	47 5% 2W F			*1-614-946-13	FP-4 BOARD
*****							*****
	*1-614-964-11	RD-12 BOARD					CAPACITOR
		*****		C010	1-123-306-00	ELECT	47MF 20% 6.3V
	*3-691-653-01	HOLDER, SENSOR		C011	1-123-306-00	ELECT	47MF 20% 6.3V
		<u>DIODE</u>				CONNECTOR	
D001	8-719-751-42	DIODE NJL5141E		CN002	*1-564-013-00	PIN, CONNECTOR 3P	
D002	8-719-751-42	DIODE NJL5141E		CN003	*1-564-013-00	PIN, CONNECTOR 3P	
*****						DIODE	
	*1-614-965-13	HP-12 BOARD		D015	8-719-812-33	DIODE TLG123A	
		*****				HOLDER	
		<u>CAPACITOR</u>		LH001	*3-674-372-00	HOLDER (A), LED	
C007	1-123-822-00	ELECT	47MF 20% 10V			RESISTOR	
C008	1-123-822-00	ELECT	47MF 20% 10V	R040	1-247-825-00	CARBON	560 5% 1/6W
		<u>DIODE</u>					
D022	8-719-113-07	DIODE RD13E-B					
D023	8-719-113-07	DIODE RD13E-B					

When indicating parts by reference number, please include the board name.

<u>Ref.No</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
<u>VARIABLE RESISTOR</u>			
RV004	1-228-988-21	RES, VAR, CARBON 10K/10K	
<u>SWITCH</u>			
S018	1-554-174-00	SWITCH, KEY BOARD	

MISCELLANEOUS

A-1-464-397-11	SOLENOID, PLUNGER		
1-464-330-21	SENSOR, S COIL		
A-1-526-382-00	OUTLET, SAC		
A-1-556-305-00	CORD		
A-2-231-019-00	CLEANER, BOARD		
L902	1-464-329-21	SENSOR, T COIL	
M903	*A-4910-049-A	R STATOR (REEL MOTOR) BOARD, COMPLETE	
M904	X-3679-268-1	MOTOR ASSY, L	
M901A	SOLENOID, PLUNGER		
M902A	SOLENOID, PLUNGER		
S901	1-554-839-11	SWITCH, LEAF (2 GANG)	
S903	1-554-840-11	SWITCH, LEAF	
S904	1-554-840-11	SWITCH, LEAF	
ST901	A-1-448-225-11	TRANSFORMER, POWER	

ACCESSORIES AND PACKING MATERIALS

<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
A-6765-731-A	COMMANDER ASSY	
1-513-379-00	CONVERTER (EAC-25)	
1-551-644-41	CORD, CONNECTION	
1-551-734-11	CORD, CONNECTION (RK-74A)	
3-795-581-21	INSTRUCTION	

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque **A** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

ADJUSTMENT

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
1.	PREPARATION FOR MECHANICAL SECTION CHECK, ADJUSTMENT AND REPLACEMENT		3-8-3.	Checking and Adjustment of the Cassette Door Assembly	241
1-1.	Disassembly of Cabinet	223	3-8-4.	Mounting the FL Cassette Compartment Assembly	241
1-2.	Removal of the RP-24 Board	224	3-9.	Removal of the No. 2 and No. 3 Guides	242
1-3.	Removal of the SS-53 Board	225	3-9-1.	Removal of the No. 2 Guide	242
1-4.	Removal of the VI-10 Board	225	3-9-2.	Removal of the No. 3 Guide	242
1-5.	Removal of the TI-4 Board	226	3-10.	Replacement and Adjustment of the S Threading Ring	243
1-6.	Removal of the Timer Block	226	3-10-1.	Preparation to Remove the S Threading Ring Removal of the ACE Assembly, FE Head and Threading Motor	243
1-7.	Removal of the FR-14 Board	227	3-10-2.	Removal of the S Threading Ring	245
1-8.	Removal of the Power Block	227	3-10-3.	S Threading Ring Mounting and Position Adjustment	246
1-9.	Removal of the FL Cassette Compartment Assembly	228	3-11.	Pinch Snap-Fit Limiter Gap Check and Adjustment	247
1-10.	Removal of the Reel Block Assembly	228	3-12.	Threading End Switch and T Coil Sensor	248
1-11.	Operation of the Unit With the FL Cassette Compartment Removed	229	3-12-1.	Threading End Switch (TE Switch) Position Check and Adjustment	248
1-11-1.	How to put the Unit into Threading Completed Mode when the FL Cassette Compartment is Removed	229	3-12-2.	T Coil Sensor Mounting and Operation Check	249
1-11-2.	Playback Without Cassette Installed	229	3-13.	Removal and Adjustment of the Reel Block Assembly	250
1-11-3.	How to put in Recording Mode Without Cassette Installed	229	3-13-1.	Removal of the Reel Block Assembly	250
1-12.	How to Load, Thread, Unload and Unthread With the Power Off	230	3-13-2.	Adjustment of the Position of the Tension Regulation Lever	250
1-12-1.	Manual Loading and Unloading	230	3-14.	Adjustment of the Forward and Back Tension	251
1-12-2.	Manual Threading and Unthreading	230	3-15.	Adjustment of the Reverse Torque	251
1-13.	Tools and Fixtures Required For Servicing	231	3-16.	Adjustment of the Forward Torque	251
2.	PERIODIC CHECK AND MAINTENANCE		4.	TAPE PATH ADJUSTMENT	
2-1.	Post-Repair Maintenance	232	4-1.	Tracking Adjustment	252
2-1-1.	Cleaning of Rotating Head Disk Assembly	232	4-1-1.	Preparation for Adjustment	253
2-1-2.	Cleaning of the Tape Movement System	232	4-1-2.	Entrance Side Adjustment	253
2-1-3.	Cleaning the Drive System	232	4-1-3.	Exit Side Adjustment	255
2-2.	Periodic Check Items	233	4-2.	Adjustments After Replacement of the ACE Assembly	256
3.	CHECK, ADJUSTMENT AND REPLACEMENT PROCEDURES		4-2-1.	Exit Side Tracking Adjustment	256
3-1.	State of Wear of Video Heads Check	234	4-2-2.	Audio Head (ACE Assembly) Azimuth Adjustment	258
3-2.	Replacement of Rotating Head Disk Assembly	235	4-2-3.	CTL Head (ACE Assembly) Position Adjustment	259
3-2-1.	Removal of the Rotating Head Disk Assembly	235	4-2-4.	Audio Head (ACE Assembly) Height Adjustment	260
3-2-2.	Mounting of the Rotating Head Disk Assembly	235	4-3.	Adjustment for Removal or Replacement of the Capstan Motor	261
3-3.	Video Head Dihedral Check and Adjustment	236	5.	ELECTRICAL ALIGNMENT	262
3-4.	Replacement and Adjustment of the Drum Assembly	237	5-1.	Power Supply Check (PC-19 board)	263
3-4-1.	Replacement of the Drum Assembly	237	5-2.	System Control Check (SS-53 board)	263
3-4-2.	Adjustment of the Motor Gap when Replacing the Drum Assembly	238	5-3.	Servo System Alignment	264
3-5.	Replacement of the Capstan Motor	238	5-3-1.	Reel Servo System Alignment	264
3-5-1.	Removal of the Capstan Motor	238	5-3-2.	Drum Servo System Alignment	264
3-6.	Removal of the S Coil Sensor	239	5-3-3.	Capstan Servo System Alignment	267
3-7.	Removal of the FL Cassette Compartment Assembly	239	5-3-4.	Swing Search Servo System Alignment	269
3-8.	Adjustment of the FL Cassette Compartment	240	5-4.	Video System Alignment	272
3-8-1.	Adjustment of the Position of the Right Gear of the FL Cassette Compartment Assembly	240	5-4-1.	Playback System Alignment	272
3-8-2.	Cassette ON Switch Operation Check and Adjustment	240	5-4-2.	Record System Alignment	273
			5-4-3.	Slow Motion Playback System Alignment	276
			5-5.	Audio System Adjustment (AU-13 board)	277
			5-6.	Tuner System Adjustment (TI-4 board)	280

SECTION 1

PREPARATION FOR MECHANICAL SECTION CHECK, ADJUSTMENT AND REPLACEMENT

1-1. DISASSEMBLY OF CABINET

- 1) Remove the four case screws ① .
- 2) Remove the upper case ② in the direction shown by the arrow A .
- 3) Remove the six screws ③ (BVTT3 x 8), then loosen the two screws ⑤ (BVTT3 x 8).
- 4) Remove the lower case ④ in the direction shown by the arrow B .
- 5) Remove the four screws ⑤ , ⑥ .
- 6) Remove the four right and left claws of the front panel in the direction shown by the arrow C , then remove the front panel in the direction shown by the arrow D .
- 7) Remove the two screws ⑨ (BVTT3 x 8).
- 8) Remove the JOG DIAL assembly ⑩ in the direction shown by the arrow E .




Fig. 1-1. Disassembly of cabinet

1-2. REMOVAL OF RP-24 BOARD

- 1) Remove the two screws ① (BVTT3 x 8).
- 2) Remove the RP-24 board block.
- 3) Remove the two shield cases ③ in the direction shown by the arrow.
- 4) Pull out the five connectors ④.




Fig. 1-2. Removal of RP-24 board

1-3. REMOVAL OF THE SS-53 BOARD

- 1) Remove the four screws ❶ (BVTT3 x 8).
- 2) Remove the SS-53 board in the direction shown by the arrow.




Fig. 1-3. Removal of the SS-53 board

1-4. REMOVAL OF THE VI-10 BOARD

- 1) Remove the four screws ❶ (BVTT3x8).
- 2) Remove the VI-10 board in the direction shown by the arrow.




Fig. 1-4. Removal of the VI-10 board

1-5. REMOVAL OF THE TI-4 BOARD

- 1) Remove the five screws ① (BVTT3 x 8).
- 2) Remove the TI-4 board in the direction shown by the arrow.




Fig. 1-5. Remal of the TI-4 board

1-6. REMOVAL OF THE TIMER BLOCK

- 1) Remove the three screws ① (BVTT3 x 8).
- 2) Remove the TM-75 board.




Fig. 1-6. Removal of the timer block

1-7. REMOVAL OF THE FR-14 BOARD

- 1) Remove the two screws ① (BVTT3 x 8).
- 2) Remove the claw ③, remove the FP-4 board.
- 3) Remove the claw ⑤, remove the FF-3 board.
- 4) Remove the claw ⑥ of the chassis, pull out the level meter ⑦.
- 5) Remove the FR-14 board in the direction shown by the arrow.




Fig. 1-7. Removal of the FR-14 board

1-8. REMOVAL OF THE POWER BLOCK

- 1) Remove the six screws ① (BVTT3 x 8).
- 2) Pull out the six connectors ②.
- 3) Remove the POWER block ③.




Fig. 1-8. Removal of the power block

1-9. REMOVAL OF THE FL CASSETTE COMPARTMENT ASSEMBLY

- 1) Remove the four screws ① (BVTT3 x 8).
- 2) Remove the internal gear flange ②.

- 3) Remove the timing belt ③.
- 4) Remove the FL cassette compartment assembly ④.




Fig. 1-9. Removal of the FL cassette compartment assembly

1-10. REMOVAL OF THE REEL BLOCK ASSEMBLY

- 1) Remove the four screws ① (B3 x 14).
- 2) Remove the reel block assembly ② in the direction indicated by the arrow.




Fig. 1-10. Removal of the reel block assembly

1-11. OPERATION OF THE UNIT WITH THE FL CASSETTE COMPARTMENT REMOVED

1-11-1. How to Put the Unit into Threading Completed Mode when the FL Cassette Compartment is Removed

- 1) Connect ordinary screwdriver to short the leaf switch (cassette-on switch).

Note:

Be careful that the ordinary screwdriver do not touch any other parts (use tape or other insulation).

- 2) Press the cassette-down switch and leave it pressed in. When the power button is turned ON threading starts.
* Refer to section 3-6 for instructions on how to remove the FL cassette compartment.

[How to EJECT in this condition]

- Press the EJECT button. When unthreading is completed and the internal gear starts to turn, turn the power OFF.




Fig. 1-11. How to thread the tape when the FL cassette compartment has been removed

1-11-2. Playback Without Cassette Installed

Complete threading by the procedure described in 1-12-1, then press the playback button.

1-11-3. How to Put in Recording Mode Without Cassette Installed

- 1) Thread by the procedure in 1-11-1, then press the accidental erasure prevention switch shown in Fig. 1-12.
- 2) With the accidental erasure prevention switch pressed down, press the recording button.




Fig. 1-12. How to put the recorder in recording mode with the FL cassette compartment removed

1-12. HOW TO LOAD, THREAD, UNLOAD AND UNTHREAD WITH THE POWER OFF

1-12-1. Manual Loading and Unloading




Fig. 1-13. Manual loading and unloading

- 1) Release the right accidental insertion prevention lever inside the cassette compartment, then press the stopper arm in the direction of arrow **C** and release the internal gear stop.
- 2) Turn the internal gear manually in the direction of arrow **A** until loading is completed.
- 3) To unload, turn the internal gear in the direction of arrow **B**.

Note:

When the loading belt has been removed, load and unload by turning the worm gear manually.

1-12-2. Manual Threading and Unthreading




Fig. 1-14. Manual threading and unthreading

- 1) Turn the loading gear in the direction of arrow **A** until loading is completed.
- 2) To unthread, turn the loading gear in the direction of arrow **B**.

Note:

Always turn the loading gear sideways by hand.
Never use a screwdriver or other tool.

1-13. TOOLS AND FIXTURES REQUIRED FOR SERVICING

Ref. No.	Name	Part Code	Carved Jig No.	Use and Remarks
J-1	Torque Measurement Tape	J-6080-003-C	SL-0003C	forward torque and back tension measurement
J-2	Parallel Plate	J-6086-750-A	SL-0657	audio/CTL head lateral adjustment capstan shaft vertical adjustment
J-3	Dental Mirror (handle) Dental Mirror (mirror)	J-6080-029-A J-6080-030-1	SL-5052	tape path and tape traveling adjustment check
J-4	Alignment Tape (KR5-1V) Alignment Tape (KP5-1G)	8-969-995-92 8-969-995-61	—	tracking, overall adjustment of picture quality, etc.
J-5	Cleaning Fluid	Y-2031-001-0	—	
J-6	Thickness Gauge	9-911-053-00	—	
J-7	Chamois Cloth	2-034-697-00	—	cleaning
J-8	Head Demagnetizer	widely available	—	demagnetization of video head and audio head
J-9	Cleaning Cassette Tape	8-888-004-00	—	video head cleaning
J-10	Dihedral Adjustment Screw	J-6080-013-A	SL-0013	video dihedral adjustment
J-11	Video Head Checker	7-732-080-01	SL-5151	video head check




Fig. 1-15. Tools and fixtures required for servicing

SECTION 2 PERIODIC CHECK AND MAINTENANCE

In order to obtain the best performance from this unit and make full use of its capabilities, and to extend the life of the unit and tapes, it is recommended that the following periodic checks and maintenance be performed.

2-1. POST-REPAIR MAINTENANCE

The following must be done after every repair regardless of how many hours the user has operated the machine.

2-1-1. Cleaning of Rotating Head Disk Assembly

- 1) Press a chamois cloth (Jig Ref. No. J-7) which has been dipped in cleaning fluid (Jig Ref. No. J-5) lightly against the rotating drum assembly, then do the cleaning by slowly rotating the rotating head disk by hand. (Never try to clean by using the motor to turn it.)
- 2) Never try to clean by moving the chamois cloth at a right angle to the head tip. There is a very great danger of damaging the head tip if this is done.

2-1-2. Cleaning of the Tape Movement System

- 1) Clean the surfaces which the tape contacts during its movement (tape guide, drum assembly surface, capstan, pinch roller, etc.) with a chamois cloth that has been dipped in cleaning fluid.

2-1-3. Cleaning the Drive System

- 1) Clean the driving parts with a cloth that has been dipped in cleaning fluid.

parts requiring cleaning




Fig. 2-1. Parts requiring cleaning

2.2. PERIODIC CHECK ITEMS

Perform the maintenance and check listed on the table below, according to users operating hours.

Maintenance & Check		Replacement Part No.	Operating Hours (H)										Remarks
			500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	
Tape Transportation System	Cleaning of tape transportation system		○	○	○	○	○	○	○	○	○	○	This cleaning must be done whenever a repair is made.
	Cleaning and degaussing of ACE ass'y		○	○	○	○	○	○	○	○	○	○	
	Cleaning & degaussing of video disk ass'y		○	○	○	○	○	○	○	○	○	○	The life of the head varies, depending on operational conditions and method.
Driving System	Loading belt (synchro belt)	3-684-264-00	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	• This cleaning must be done whenever a repair is made.
	Cleaning of iron core and opening of solenoid		-	-	-	○	-	-	-	○	-	-	Wipe iron core and opening of solenoid with dry cloth.
Performance Confirmation	Abnormal sound		☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Adjust or replace the section which causes abnormal sound.
	Measurement of FWD back tension		-	☆	-	☆	-	☆	-	☆	-	☆	Confirmation must be made according to section 3-13. Specified value: adjust to 44 ± 4 g·cm (When measured with torque cassette tape)
	Confirmation of brake system		-	☆	-	☆	-	☆	-	☆	-	☆	Confirmation must be made according to section
	Confirmation of record & playback functions		☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Perform the confirmation whenever repair is made.
	Measurement of forward torque		☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Adjust to 45 ~ 90 g·cm (SL-0003C)

○ Cleaning ☆ Replacement ☆ Confirmation

Note:

On overhaul

When overhauling the unit, replace parts as indicated in the above table.

SECTION 3

CHECK, ADJUSTMENT AND REPLACEMENT PROCEDURES

3-1. STATE OF WEAR OF VIDEO HEADS CHECK

As the accuracy of the check depends on the state of the heads and precision of the checker, the results should be taken only as an indication of the state of wear.

[Adjustment of video head checker]

- 1) **Mechanical zero**
Verify that the pointer of the video head checker is at the mechanical zero position. If it is not at this position, adjust the mechanical zero control.
- 2) **Battery voltage check**
Set the MODE switch to "BATT" and set the POWER switch to "ON". The deflection of the pointer should be within the range marked "BATT". If not, replace the battery (use a 6F22 battery) as follows.
- 3) **Calibration check**
Set the POWER switch to "ON" and the MODE switch to "CAL", then adjust the CAL control so that the pointer is on the CAL mark.

Note 1: Be sure to carry out this adjustment whenever the RANGE switch is changed.

Note 2: Be sure to check CAL before measuring the head and proceed the measurement after adjusting CAL, if CAL is not properly set.

[Method of measurement]

- 1) Remove the two screws that hold the damper assembly in place, then remove the damper assembly.
- 2) Detach the lead wires on the 4 video heads.
- 3) Attach the measuring clips to the head leads. Be sure to separate the leads by at least 1.5 cm.
- 4) Set RANGE switch to "B" and MODE switch to "MEAS". The pointer will deflect to indicate the state of wear of the heads.

Note: The deflection for the 4 video heads may be different so be sure to measure both.




Fig. 3-1.




Fig. 3-2. Measured value

3-2. REPLACEMENT OF ROTATING HEAD DISK ASSEMBLY

3-2-1. Removal of the Rotating Head Disk Assembly (Fig. 3-3)

- ① Remove the two screws that hold the damper assembly in place, then remove the damper assembly.
- ② Use a hexagonal wrench to remove the hexagonal socket bolt that holds the upper drum assembly in place, then remove the upper drum assembly.

Note:

Turn the upper drum to remove, being careful not to move the adjusting plate. Movement of the adjusting plate will have a great effect on the tape path, so caution is required.

- ③ Unsolder the rotating head disk relay plate (4 red and white leads).
- ④ Remove the two hexagonal socket bolts holding rotating head disk assembly ⑤ in place, then remove the rotating head disk assembly.

Note:

Be careful not to touch the head tip with the hand or bang anything against it.

3-2-2. Mounting of the Rotating Head Disk Assembly (Fig. 3-3)

- 1) Insert rotating head disk ⑤ in place, being careful of the direction so that the red and white leads are in the right places.
- 2) Tighten hexagonal socket bolt ④ and solder the lead wires.

Note:

Be careful to solder the lead wires correctly and not to break any wires.

- 3) Attach the upper drum, being careful (as during removal) not to move the adjusting plate. While pressing the two points that determine the height, tighten hexagonal socket bolt ②.

Note:

When inserting the upper drum, be careful that it does not touch the head tip.

Note:

When replacing the rotating drum head, it can happen that the rotating head disk assembly will be hard to remove. In such a case, remove it using the method explained below (Fig. 3-4).

- ① Remove the hexagonal socket bolts that hold the rotating head disk assembly in place.
- ② When the head disk is jammed on tight and is hard to remove, screw the hexagonal socket bolts removed in step ① into the threaded holes removed from the original holes by 90°. Tighten them a little at a time. The head disk will be lifted up by the two screws and will come off easily.




Fig. 3-3 Removal of the rotating head disk assembly I




Fig. 3-4. Removal of the rotating head disk assembly II

3-3. VIDEO HEAD DIHEDRAL CHECK AND ADJUSTMENT

This adjustment is generally unnecessary, but it is sometimes necessary when the video head disk is replaced. (The video head disk used for maintenance has been precision adjusted at the factory using a microscope and almost never needs to be readjusted.)

When judging whether the video head dihedral angle is correct, the alignment tape is played back. When this is done the tracking control knob must be in the centering position. If the check is done with this knob in other than the center click position (if the tracking is off-center), even if the dihedral angle is correct the picture will be reproduced as if it were off.

Before this adjustment is performed, the AC assembly position adjustment (refer to the section where the tape path adjustment is described) must be completed.

[Method of checking]

With the tracking control knob set to the center click position, play back the β II monoscope section of the alignment tape. Check to see if any of the vertical monoscope lines immediately below the switching pulse are reproduced double. If not, the dihedral angle is correct and does not have to be adjustment. If so, perform the adjustment as explained below.

[Method of adjustment]

- 1) As shown in Fig. 3-5, screw two dihedral angle adjustment screws (Jig Ref. No. J-10) into the adjustment screw holes on the side on which the red lead wires from the video head are connected, until the top of the screw is level with the video head disk. (If they are not screwed in far enough, the video head disk will not turn past the point where the top of the adjustment screw strikes the upper drum. Conversely, if it is screwed in too far, the head base will be moved, throwing the video head dihedral angle way off.)

Note:

The side on which the white lead wires are connected is the reference side and must not be moved.

- 2) Screw one of the two adjustment screws in a little bit farther until resistance is felt. Beyond this point, turning the screw still farther will move the video head, adjusting the dihedral angle.
- 3) With the adjustment screws in place, play the β II monoscope signal section of the alignment tape and see how the lines are reproduced. If the vertical lines are split apart more than before, turn the screw which was screwed in more tightly counterclockwise to loosen it, then adjust by tightening the other screw.
- 4) After the adjustment is completed, remove the adjustment screws and play the tape again to reconfirm that the adjustment is correct.




Fig. 3-5. Video head dihedral adjustment




Fig. 3-6.

3.4. REPLACEMENT AND ADJUSTMENT OF THE DRUM ASSEMBLY

3.4.1. Replacement of the Drum Assembly

- ① Measure gap **A** between adjusting plate 2 and the upper drum holder section, and record the measurement.

Note:

The position where the adjusting plate is mounted has a large effect on the tape path, so this measurement must be performed.

- ② Measure gap **B** between adjusting plate 3-1 and the upper drum holder section, and record the measurement.

Note:

The position where the adjusting plate is mounted has a large effect on the tape path, so this measurement must be performed.

- ③ Remove the screws shown in Fig. 3-7, then remove the tape guide ground plate and adjusting plates 1 and 2.
- ④ Remove the 3 connectors from the rear of the chassis as shown in Fig. 3-8.
- ⑤ Remove the 3 drum mounting screws from the rear of the chassis, then remove the main body of the drum assembly. After the replacement has been completed, adjust the drum path.




Fig. 3-7. Measurement of the position of adjusting plates 2 and 3-1




Fig. 3-8. Removal of the drum assembly

3-4-2. Adjustment of the Motor Gap when Replacing the Drum Assembly

After replacing the drum assembly, adjust the gap between the motor rotor and the coil to 0.3 mm to 0.6 mm (Fig. 3-9).

[Procedure]

- 1) When re-assembling the drum, use the spacers which were removed to produce a gap of between 0.3 mm and 0.6 mm. Measure the gap using the gauge that comes with the drum for assembly and maintenance use. One side of the gauge is 0.3 mm and the other side is 0.6 mm. If the gap is adjusted correctly, the 0.3 mm side should fit in and the 0.6 mm side should not.
- 2) If this fails to give the correct gap width, do not use the spacers which were removed; instead, use a combination of the 40.3 mm accessory spacers to obtain the correct width.




Fig. 3-9. Checking the motor gap width after replacing the drum assembly

Removal of the stator and rotor when replacing the drum

- ① Remove the nut and washer.
- ② Remove the rotor from the stator.
- ③ Remove the 2 screws, then remove the stator from the main body of the drum.




Fig. 3-10. Removal of the stator and rotor when replacing the drum

3-5. REPLACEMENT OF THE CAPSTAN MOTOR

3-5-1. Removal of the Capstan Motor (Fig. 3-11)

- Remove screw ①, then remove the capstan motor from the rear of the mechanical chassis.




Fig. 3-11. Removal of the capstan motor

3-6. REMOVAL OF THE S COIL SENSOR (Fig. 3-12)

- 1 Remove the spring.
- 2 Remove the claw in the direction of arrow **A**, then pull the S coil sensor out.
- 3 Unplug the connector from CN420 on SS-53 board.




Fig. 3-12. Removal of the S coil sensor

3-7. REMOVAL OF THE FL CASSETTE COMPARTMENT ASSEMBLY (Fig. 3-13)

- 1 Remove the screws (BVTP3 x 8).
- 2 Remove the internal gear flange.
- 3 Remove the timing belt.
- 4 Pull connector CN406 (yellow) out.
- 5 Remove the FL cassette compartment section in the direction of arrow **A**.




Fig. 3-13. Removal of the FL cassette compartment assembly

3-8. ADJUSTMENT OF THE FL CASSETTE COMPARTMENT

3-8-1. Adjustment of the Position of the Right Gear of the FL Cassette Compartment Assembly

In the FL cassette compartment assembly, the cassette holder must always move parallel to the mechanical chassis. The gear system is used to control the amount by which the cassette holder advances so that this will be the case. Consequently, if the gears in this section slip out of mesh, the next time the unit is assembled the gear mesh must be adjusted to the correct position, otherwise the cassette will not feed properly.

[Adjustment of the gear positions]

- 1 Get a positioning rod about 200 mm long and 1.5 mm in diameter ready.
- 2 While passing the positioning rod through the combination of the drive arm right and cassette ON cam, fit the latter on the right side plate. Similarly, fit the drive arm left onto the left side plate.
- 3 Similarly, while passing the positioning rod through the worm wheel, fit the latter onto the right side plate.
- 4 Similarly, while passing the positioning rod through the combination of the limiter gear and cassette OFF cam, fit the latter onto the right side plate.




Fig. 3-14. Positioning of the FL cassette compartment gears

3-8-2. Cassette ON Switch Operation Check and Adjustment

[Method of checking]

When inserting a cassette into the FL cassette compartment assembly, confirm that, as the cassette is inserted, the microswitch comes ON when the center of the drive roller is 10 to 13 mm from the end of the guide groove, as shown in Fig. 3-15. (A clicking sound can be heard after the switch is pressed.)

[Method of adjustment]

Bend the tip of the cassette ON switch in the direction of the arrow.

Adjust so that the cassette ON switch comes ON when the above distance is 10 to 13 mm, and finally tighten the screw.




Fig. 3-15. Cassette ON switch operation check and adjustment

3-8-3. Checking and Adjustment of the Cassette Door Assembly

[Method of checking]

With the door opening and closing arm returned all the way in the direction of arrow **A**, check to make sure that the upper and lower doors are vertical.




Fig. 3-16. Adjustment of the position of the cassette door assembly

[Method of adjustment]

Check to make sure that the door opening and closing rack plate has returned all the way. Then, close the upper door together in the direction of arrow **B** so that it is vertical, and mesh the gears.

3-8-4. Mounting the FL Cassette Compartment Assembly (Fig. 3-17)

- 1 Hook the two holes of the FL cassette compartment assembly onto the mechanical chassis, then place the compartment in the specified position on the chassis.
- 2 Loosely tighten the 4 mounting screws of the FL cassette compartment assembly. Move the FL cassette compartment assembly forward and backward with respect to the mechanical chassis, set it in the correct position, then tighten the mounting screws all the way.
- 3 Connect the timing belt (loading belt) between the threading motor and the worm gear, then hold it in place with the internal gear flange.
- 4 Press the tension roller arm in the direction of the arrow to adjust the tension of the timing belt (loading belt), then fix it in place with the arm fixing screw.
- 5 Insert the harness sticking out from the FL cassette compartment into connector CN406 on SS-53 board.




Fig. 3-17. Mounting the FL cassette compartment assembly

3-9. REMOVAL OF THE No. 2 AND No. 3 GUIDES

3-9-1. Removal of the No. 2 Guide

- ① Remove the 1 x 3 tap-in screw.
- ② Remove the 1.4 x 3 tap-in screw.
- ③ Remove the No. 2 guide assembly.




Fig. 3-18. Removal of the no. 2 guide

3-9-2. Removal of the No. 3 Guide

- ① Remove the 1 x 3 tap-in screw.
- ② Remove the 1.4 x 3.5 tap-in screw.
- ③ Remove the limiter spring.
- ④ Remove the No. 3 guide assembly.




Fig. 3-19. Removal of the no. 3 guide

3-10. REPLACEMENT AND ADJUSTMENT OF THE S THREADING RING

3-10-1. Preparation to Remove the S Threading Ring Removal of the ACE Assembly, FE Head and Threading Motor (Fig. 3-20)

- ① Remove the cross-recessed head screw.
- ② Remove the No. 6 guide nut.
- ③ Remove the No. 6 washer.
- ④ Remove the No. 6 guide spacer.
- ⑤ Remove the compression coil spring.
- ⑥ Remove the 2 screws and ACE bush, then remove the ACE assembly and the FE head.

Note:

Since the ACE assembly and the FE head are connected by a lead wire, be careful when removing them. It is not necessary to remove the compression coil spring below the ACE assembly, but be careful not to use it.

- ⑦ Remove the 3 screws, then remove the threading motor assembly by pulling it up and out.




Fig. 3-20. Removal of the ACE assembly, FE head and TE motor assembly

Removal of Miscellaneous Parts (Fig. 3-21)

Proceeding in the same manner as in replacement of the drum assembly, measure the width of the gap between the upper drum and the adjusting plates (Fig. 3-7).

- ① Remove the screw, then remove the tape guide ground plate and adjusting plates 1 and 2.
- ② Remove the two screws, then remove the tape holder assembly.
- ③ Remove the screw, then remove the guide plate.
- ④ Remove the 2 PTPWH2 x 8 screws and the 2.6 x 24 screw, then remove shuttle guide 2.

- ⑤ Remove the 3 PTPWH2 x 8 screws and the 2.6 x 24 screw. Then remove the 2 claws holding shuttle guide 1-YA in place, and finally remove shuttle guide 1-YA.
- ⑥ Remove the slant base assembly.
- ⑦ Remove the BVT2.6 x 6 screw, then remove the pinch liner link.

Note:

After removing the guide plate, do not thread or unthread a tape with the shuttle guide mounted.




Fig. 3-21 Removal of miscellaneous parts

3-10-2. Removal of the S Threading Ring (Fig. 3-22)

- 1 Turn the stop washer and remove the ring roller (B) and (C).
- 2 Remove the screw, then remove the ring roller adjustment plate.
- 3 Remove the S threading ring.

Note:

Once a stop washer has been removed, do not use it again.




Fig. 3-22. Removal of the S threading ring

3-10-3. S Threading Ring Mounting and Position Adjustment (Fig. 3-23)

- 1 Set the slider gear assembly in the unthreading completed position.
(Slider gear assembly set so that it is up against part T slider stop mold.)
- 2 In this condition, fit the threading ring into place, match the chassis hole ($\phi 3$) of part A with the S threading ring hole ($\phi 1.5$), and mesh with the drive gear teeth.
- 3 Attach ring roller (B) and fix in place with a stop washer.
- 4 Attach the ring roller, and fix in place with the adjustment plate.

Note:

After replacement and mounting are completed, adjust the AC assembly as explained in the section on tape path adjustment.




Fig. 3-23. S threading ring position adjustment

3-11. PINCH SNAP-FIT LIMITER GAP CHECK AND ADJUSTMENT

[Method of checking]

- 1) Set in the threading completed condition.
- 2) With the plunger pushed in all the way, confirm that the thickness of the pinch snap-fit limiter gap is 0.4 mm to 0.6 mm. If it is not, adjust as explained under [method of adjustment] below.

[Method of adjustment]

- ① With the pinch solenoid in the absorbed condition (when the plunger is pushed in all the way), loosen the adjustment screw.
- ② Press the pinch limiter adjustment plate in the direction of arrow ③ with an ordinary screwdriver, as in section A in the diagram, and adjust until the thickness of the gap in 0.4 mm to 0.6 mm.
Tighten the adjustment screw and then lock it to fix everything in place.




Fig. 3-24. Pinch snap-fit limiter gap adjustment plate

3-12. THREADING END SWITCH AND T COIL SENSOR

3-12-1. Threading End Switch (TE Switch) Position Check and Adjustment

[Method of checking]

Turn the S threading ring manually. Check to make sure that, when the lock roller moves from above the straight line part of the notch in the ring (Fig. 3-25 section A) to 1/3 of the way down it and back, the TE switch turns ON and OFF. This can be confirmed from the clicking sound. If the lock roller has to move outside of this range before the switch will turn ON and OFF, adjust as explained below.

[Method of adjustment]

- 1) Set the lock roller between the top of the notch in the S threading ring and 1/3 of the way down it, turn the TE switch in the direction of the arrow and, when the switch turns ON (with a clicking sound), fix the TE switch in place.
- 2) When the adjustment is completed, repeat the check as described under [method of checking].

[Removal]

- 1 Remove the tension coil spring that is attached to the S coil sensor assembly, then remove the S coil sensor.
- 2 Remove the lock arm assembly in the direction of arrow A.




Fig. 3-25. TE switch position adjustment




Fig. 3-26. Removal of the TE switch assembly and lock arm assembly

3-12-2. T Coil Sensor Mounting and Operation Check

[Method of checking]

Confirm that T coil sensor link ① is pressed and T coil sensor ② moves in the direction of arrow ③ when the T slider gear assembly is moved in the direction of arrow ④.




Fig. 3-27. T coil sensor operation check

[Method of mounting]

- 1 Place T coil sensor link in the prescribed position.
- 2 Match up the T coil sensor hole with the chassis shaft (A) and insert. Place so that it engages with T coil sensor link.
- 3 Hook the tension coil spring on the T coil sensor and chassis claw.




Fig. 3-28. T coil sensor link and T coil sensor mounting

3-13. REMOVAL AND ADJUSTMENT OF THE REEL BASE ASSEMBLY

3-13-1. Removal of the Reel Base Assembly

- ① Turn the unit so that the top surface of the main body faces down.
- ② Remove the 4 BVTP3 x 8 tap-in screws.
- ③ Remove the reel base assembly.




Fig. 3-29. Removal of the reel base assembly

3-13-2. Adjustment of the Position of the Tension Regulating Lever

[Method of adjustment]

- 1) Put the unit in playback mode.
- 2) Loosen the adjustment spring until the tape guide pin of the tension regulating lever assembly is positioned to the outside of the outer circumference of shuttle guide 1-YA, as shown in Fig. 3-30. Then adjust by moving the tension regulating band assembly in the direction of arrow A.
- 3) After adjustment, tighten the adjustment screw, being careful that the tension regulating band assembly does not move.




Fig. 3-30. Adjustment of the position of the tension regulating lever

3-14. ADJUSTMENT OF THE FORWARD AND BACK TENSION

[Method of measurement]

- 1) Insert the torque cassette (SL-0003C) and put the unit in playback mode.
- 2) Read the value on the meter on the S reel side after the needle has gone around about once.
The correct value is $44 \text{ g}\cdot\text{cm} \pm 4 \text{ g}\cdot\text{cm}$.

Notes:

- i) The set must be perfectly level during this measurement.
- ii) After the measurement, the tape can become slack when the stop button is pressed. If this happens set the unit in forward mode to take up the slack before removing the tape.

[Method of adjustment]

Move the position of the tension coil spring that is hooked on the tension regulating lever assembly in the direction of arrow **A** until the measured value falls within the correct range.




Fig. 3-31. Adjustment of the back tension

3-15. ADJUSTMENT OF THE REVERSE TORQUE

[Method of measurement]

- 1) Insert a recorded torque cassette (SL-0003C in β II mode and set for X1 reverse mode.
- 2) Read the S reel meter value after the needle has made about one cycle. The specified value is $90 - 160 \text{ g/cm}$ (the torque cassette scale does not go above 150 g/cm , so read from the scale). If the specifications are not met, replace the S reel table assembly with a new one.

3-16. ADJUSTMENT OF THE FORWARD TORQUE

[Method of measurement]

- 1) Insert the torque cassette (SL-0003C) and start to record a telecast in β II mode.
- 2) Read the value on the meter on the T reel side after the needle has gone around about once. The correct range is $45 \text{ g}\cdot\text{cm} - 90 \text{ g}\cdot\text{cm}$.
When the specifications are not met, replace the T reel table assembly with a new one.

SECTION 4 TAPE PATH ADJUSTMENT

4-1. TRACKING ADJUSTMENT

The adjustment has a large effect on the picture quality in each mode and on the interchangeability of tapes, so it should be done carefully.

4-1-1. Preparation for adjustment

4-1-2. Entrance side adjustment

4-1-3. Exit side adjustment




Fig. 4-1.

4-1-1. Preparation for Adjustment

- 1) Remove the cassette cover of the alignment tape in accordance with Fig. 4-1.
- 2) Clean the surface contacted by traveling tape (tape guide, drum tape trailing surface, capstan shaft, pitch roller, ACE-FE head surface) with a chamois cloth dipped in methanol.
- 3) Connect the oscilloscope as follows:
channel 1: CN213-pin ③ (RP-24 board)
external trigger: CN213-pin ① (RP-24 board)
- 4) Play back the 1 kHz signal on the tracking section of the alignment tape.
- 5) Confirm that the oscilloscope RF output waveform is flat, and that the amplitude is maximum. (It should increase and decrease, remaining flat, when the tracking knob is turned back and forth.) Also, when it is 2/3 of the maximum level of Fig. 4-2. A waveform, the minimum level (relative to whole area from entrance to exit) and fluctuation amount should be within the specifications in Fig. 4-2.
- 6) If the entrance waveform cannot be made flat, as shown in Fig. 4-3 (a), by turning the tracking knob, go through the "entrance side adjustment" described in 4-1-2; if the exit waveform shown in Fig. 4-3 (b) cannot be made flat, go through the "exit side adjustment" in 4-1-3.




Fig. 4-2.






Fig. 4-3.

4-1-2. Entrance Side Adjustment

Whenever the entrance side adjustment is performed, the exit side adjustment must also be performed. The various tape guides and adjustment positions are shown in Fig. 4-5.

- 1) Turn the No. 6 guide counterclockwise to free the movement of the tape as it enters the drum.
- 2) Turn the tracking control knob until the amplitude of the waveform is about 60% of its maximum.
- 3) Loosen No. 5 guide lock screw ① and turn the No. 5 guide until the entrance waveform sticks up a little above flat, as shown in the figure below. Then tighten the No. 5 guide lock screw (Fig. 4-6).

Note:

After tightening No. 5 guide lock screw ①, confirm that it is as in the figure below.




Fig. 4-4.

- 4) Next, lower the No. 6 guide until the waveform is flat.
- 5) Press the tape down between the No. 4 and No. 5 guide with a finger to lower the entrance side radio frequency waveform, then let go and confirm that the waveform returns to what it was before.
- 6) In this condition, check the clearance and curl of the No. 5 guide. If there are clearance and curl, adjust as explained in subsequent sections.

Note:

The tape tension between the No. 3, No. 4 and No. 5 guides must be balanced. If it is not, adjust the tilt of the No. 3 and No. 5 guides. If the waveform cannot be made to look as shown in Fig. 4-4, or if when the tape is pressed and released on the entrance side it takes time for the waveform to return to what it was before, or if it does not return to what it was before, adjust according to the instructions given below.

[What to do when the waveform entrance output will not rise]

- 1) Check to see if the up-down tension between the No. 3, No. 4 and No. 5 guides is uniform. If it is not, adjust the tilt of the No. 3 and No. 5 guides.

Note:

The lower flange of the No. 4 guide must not protrude.

- 2) Raise the lower flange of the No. 4 guide to raise the entrance output.

Note:

It is sufficient to raise the lower flange of the No. 4 guide to 0.4 mm from its lowest position (within a rotation angle of 360°).

- 3) If the operation performed in step 2) fails to raise the waveform output, turn the No. 5 guide tilt adjustment screw slightly to the left, and the entrance output should rise.

[What to do when the waveform entrance output will not drop]

- 1) Remove the adjusting plate 3-1 of the No. 3 guide from the drum. Just before the lower tension of the tape becomes slack, tighten screw ②.
- 2) If the tape is in contact with the lower flange of the No. 4 guide, lower the flange. If the tape is sticking up from the lower flange, adjust the tilt of the No. 5 guide so that the tape does not stick up from the lower flange of the No. 4 guide.

[What to do when there is a clearance in the No. 5 guide]

Turn the No. 4 guide counterclockwise to run the tape upward and eliminate the clearance in the No. 5 guide.

Note:

At this time make sure that a large curl is not produced below the No. 4 guide.




Fig. 4-5. Tape guide layout diagram

[What to do when there is a curl]

- 1) When there is a gap below the No. 4 guide. Just before the lower tension on the tape becomes slack, move adjusting plate 3-1 of the No. 3 guide to the outside.
- 2) When there is not a gap below the No. 4 guide (when there is a curl below the No. 4 guide):
 - i) Check to see if the No. 4 guide has been raised up too high. If it has been raised up too high, turn the adjusting plate clockwise to lower the No. 4 guide.
 - ii) If the curl still has not been removed after i), tighten the No. 5 guide tilt adjustment screw in the clockwise direction until the curl is removed.




Fig. 4-6.

4-1-3. Exit Side Adjustment

- 1) Connect the oscilloscope to the No. ③ terminal on connector CN213 (on RP-24 board). Connect the external trigger to the No. ① terminal on CN213.
- 2) Play the tracking section of the alignment tape. Adjust the tracking knob to reduce the amplitude of the radio frequency output waveform to 60% of its maximum level.
- 3) Watch the radio frequency output waveform when the No. 7 and No. 8 guides are raised (by turning the respective guide nuts counterclockwise) to let the tape run free. This waveform is called to exit free waveform.

Note:
Be careful not to raise the guides too far. They should be raised only about 0.3 to 0.5 mm, and the tape should not contact the lower flange of the AC head.




Fig. 4-7.

- 4) At this time, confirm that the exit free waveform is within the range shown in Fig. 4-8 (a) and (b).
 - If it is outside of this range, adjust according to the procedure in 4-3.




Fig. 4-8.

- 5) Flatten the waveform with No. 7 guide, and line No. 8 guide up to the tape. (Lower the guide until just before the waveform changes and there is no curl.) At this time the exit waveform may float slightly, so lower it again with No. 7 guide, flatten the waveform, and line No. 8 guide up to the tape.
- 6) Confirm that there is no curl at No. 7 and No. 8 guides in forward mode.
- 7) Confirm that there is no space or curl at No. 8 guide in reverse mode. If there is, adjust with No. 9 guide.

4-2 ADJUSTMENTS AFTER REPLACEMENT OF THE ACE ASSEMBLY

After removal or replacement of the ACE assembly perform the adjustments listed below.

- 4-2-1. Exit side tracking adjustment
- 4-2-2. Audio head (ACE assembly) azimuth adjustment
- 4-2-3. CTL head (ACE assembly) position adjustment
- 4-2-4. Audio head (ACE assembly) height adjustment

4-2-1. Exit Side Tracking Adjustment

- 1) Set the parallel plate (SL-0657 in the list of fixtures and tools) up against the unit as shown in Fig. 4-9, and turn the tilt adjustment screw to adjust the audio head vertically.




Fig. 4-9.

- 2) Connect the oscilloscope to terminal ③ of connector CN213 (on RP-24 board). Connect the external trigger to terminal ① of CN213.
- 3) Play the tracking section of the alignment tape. Adjust the tracking knob until the radio frequency output waveform amplitude is reduced to about 60% of its maximum level.
- 4) Raise the No. 7 and No. 8 guides (turn the respective guide nuts counterclockwise) and observe the radio frequency exit free waveform then the tape runs free.

Note:

Be careful not to raise the guide too far. Raise it about 0.3 to 0.5 mm, and be careful that the tape does not contact the lower flange of the ACE head.




Fig. 4-10.

- 5) At this time, confirm that the exit free waveform is within the range shown in Fig. 4-11 (a) and (b).




Fig. 4-11.

[When the waveform is outside this range]

- When the waveform is outside this range and has the form shown in Fig. 4-12, turn the tilt adjustment screw clockwise to adjust until the waveform is within the required range.

Note:

Complete the adjustment by turning the adjustment screw in the direction of tightening (clockwise).




Fig. 4-12.

- When the exit free waveform is outside of the required range and has the form shown in Fig. 4-13, turn the tilt adjustment screw counterclockwise to produce waveform A (Fig. 4-12), then turn it clockwise to bring the waveform within the required range.

Note:

Finish the adjustment by turning the adjustment screw in the direction of tightening (clockwise).

- 6) Turn No. 7 guide and ~~flatten~~ the waveform, and line No. 8 guide up to the tape. (Lower the guide until just before curl appears at No. 8 guide flange.)
- 7) If RF output waveform exit side floats up, lower No. 7 and No. 8 guides again to flatten it.






Fig. 4-13.

[Adjustment point]



no. 7 guide

no. 8 guide

4-2-2. Audio Head (ACE Assembly) Azimuth Adjustment

[Connections]

- 1) Playback




Fig. 4-14.

[Method of adjustment]

- 1) Play the 5 kHz -25 dB audio signal section (RF sweep section) of the alignment tape.
- 2) Adjust the azimuth adjustment screw until the output level (VTVM indication) is a maximum.

Note:

Complete the adjustment by turning the adjustment screw in the direction of tightening (clockwise).

- 3) After adjustment, lock the adjustment screw.

[Adjustment point]






Fig. 4-15.

4-2-3. CTL Head (ACE Assembly) Position Adjustment

This adjustment includes the mechanical CTL head mounting position adjustment and the electrical tracking control center adjustment. The tracking control center adjustment is to be performed first, followed by the mechanical adjustment of the head mounting position.

[Connections]

- 1) Playback



[Method of adjustment] Fig. 4-16.

- 1) Play the tracking signal section of the alignment tape.
- 2) Turn the tracking control knob clockwise or counter-clockwise to the center click position. Confirm that the amplitude of the radio frequency output signal is at its maximum level. Also confirm that the audio signal 0 level position occurs at the location of the channel B waveform. If the necessary standards are not met follow the procedure in 3).




Fig. 4-17.

- 3) Tracking center adjustment
Refer to electrical adjustment 4 in section 5-3-3.
- 4) CTL head position adjustment
 - a. Set the tracking control knob at the center click position.
 - b. Loosen the 2 ACE assembly position adjustment screws, then use a tool such as an ordinary screwdriver to slide the ACE assembly to where the radio frequency output waveform amplitude becomes a maximum (Fig. 4-18).
 - c. Play the color bar signal on the alignment tape and check the picture quality.
 - d. Tighten the position adjustment screws, then lock them.






Fig. 4-18.

[Adjustment point]



CTL head position adjustment screws

4-2-4. Audio Head (ACE Assembly) Height Adjustment

- Height adjustment is not required when replacing the ACE assembly, as the core position relative to the tape guide flange is precisely adjusted during assembly, but height adjustment may have to be performed when the channel level difference is noticeable and cannot be adjusted with the circuit system.

- 1) Perform exit side tracking adjustment.
- 2) Perform audio head (ACE assembly) azimuth adjustment.
- 3) Mark the positions of the audio height adjustment screw and lateral adjustment screw in Fig. 4-19 and the azimuth adjustment screw in Fig. 4-15.




Fig. 4-19.

- 4) Rotate the audio height adjustment screw and lateral adjustment screw counterclockwise 90° each.

Note:

Turn **lightly past the 90° position, then return to it.**

- 5) Turn the azimuth adjustment screw 90° counterclockwise.
- 6) Play back the 333 Hz portion of the alignment tape (KR5-1V) and perform Playback Amplitude 1 Adjustment (AU-13 board RV102) so that CH-1 output (CH1 OUT) is -25 dB.
- 7) Turn the audio head height adjustment screw and lateral adjustment screw 180° clockwise each (90° clockwise past the marked position), and turn the azimuth adjustment screw 180° counterclockwise (90° counterclockwise past the marked position).

Note:

The same as in step 4), first loosen, then tighten.

- 8) Play back the 333 Hz portion of the alignment tape (KR5-1V) and perform Playback Amplitude 2 Adjustment (AU-13 board RV202) so that CH-2 output (CH2 OUT) is -25 dB.
- 9) Return all three screws to the marked positions.
- 10) Perform audio head (ACE assembly) azimuth adjustment.
- 11) Play back the tracking portion of the alignment tape (KR5-1V) and confirm that the level difference between the two channels is within 2 dB.

If not, adjust according to the following procedure.

- (i) When CH-1 is larger

Turn the audio head height adjustment screw and lateral adjustment screw and azimuth adjustment screw counterclockwise to the same angle, so that the specifications are satisfied.

The specification is channel level difference within 1.5 dB for this adjustment.

Note:

Turn the screws 30° each, check, then turn 30° again after adjusting. Finish the adjustment by turning to the right.

- (ii) When CH-2 is larger

Perform the same as in step (i), but rotate in the reverse direction.

- (iii) In either case, perform audio head (ACE assembly) azimuth adjustment after the adjustment.

4-3. ADJUSTMENT FOR REMOVAL OR REPLACEMENT OF THE CAPSTAN MOTOR

- 1) Remove and replace the capstan motor according to 3-5 Removal of Capstan Motor.
- 2) Play back the tracking portion of the alignment tape (KR5-1V). Connect the oscilloscope as follows:
1ch: CN213 3 pin (RP-24 board)
2ch: CN213 1 pin (RP-24 board)
- 3) Turn the tracking control knob clockwise to lower the RF output waveform to about 60% of the maximum.
- 4) Raise No. 7, 8 guides a little, and check the exit free waveform.
 - i) If the exit free waveform is within the range indicated in Fig. 4-20 (a), (b), proceed from ste 5).




Fig. 4-20.

- ii) If the peak of the ~~exit free~~ waveform is smaller than that illustrated in Fig. 4-20 (a) (e.g. Fig. 4-21), loosen the lock screw, then turn the capstan adjustment screw until the waveform is within the specified range.




Fig. 4-21.

- iii) If the peak shape of the exit free waveform differs from that shown in Fig. 4-20 (b) (e.g. Fig. 4-22), loosen the lock screw, then turn the capstan adjustment screw clockwise until the waveform is within the specified range.




Fig. 4-22.

Note:

After turning the capstan adjustment screw, wait until the waveform stabilizes (about 10 – 15 seconds) before continuing with the adjustment.

- 5) Lock the capstan lock screw. (Turn clockwise until it stops, then turn about 30° more. At this point, the exit free waveform will change slightly, and if it goes out of the range shown in Fig. 4-20 (a), (b) return to ste 4) and re-adjust.
- 6) Flatten the waveform with No. 7 guide, and match No. 8 guide to the tape. If the exit waveform rises, flatten it again with No. 7 guide and match No. 8 guide to the tape again.
- 7) Confirm and adjust according to 4-1-3, exit side adjustment procedure items 4), 5).

SECTION 5 ELECTRICAL ALIGNMENT

This section provides all necessary information and instructions for complete alignment of the electronic circuits in this machine.

EQUIPMENT REQUIRED

- (1) Color TV receiver
- (2) Oscilloscope Dual-trace, Bandwidth more than 15 MHz with delay mode
- (3) Frequency counter (more than four digits)
- (4) NTSC pattern generator
- (5) Digital voltmeter (10 M Ω /V)
- (6) VOM (20 k Ω /V)
- (7) Audio generator
- (8) Level meter
- (9) Distortion meter
- (10) Spectrum analyzer
- (11) Alignment tape
Type KR5-1V Code No. 8-969-995-92
- (12) Alignment tool
(adjusting screwdriver for semi-fixed resistor coil) Code No. 7-700-733-01

[Preparatory Set-up for Alignment]

For these alignment procedures involving use of a video input signal the NTSC pattern generator is to be connected to the VHF antenna terminals of the SL-HF900. This RF signal is processed by the tuner and I.F. circuits within the VTR. It is important that the video out signal from the I.F. circuit satisfies the specifications. The video signal must be checked with an oscilloscope connected to pin 3 of CN205 on the VI-10 board. Check that the video signals are flat when the amplitude of the horizontal sync signal is about 0.3 V, the amplitude of the video portion is about 0.7 V, and the amplitude of the burst signal is about 0.3 V. The video signal (color-bar signal) used in this alignment is shown in Fig. 5-1.




Fig. 5-1 Color-bar signal of pattern generator

[Alignment Tape]

KR5-1V

Tape speed	Video signal	Audio signal	Playing time
20.0 mm/sec. (β II)	Color-bars	3 kHz - 5 dB	4 min. for each segment
	Monoscope	333 Hz - 30 dB	
	RF sweep	5 kHz - 30 dB	
	Tracking	1 kHz - 10 dB	
Color-bars	Beta hi-fi 400 Hz \pm 25 kHz DEV		
13.3 mm/sec. (β III)	Monoscope	5 kHz - 30 dB	
	Color-bars	3 kHz - 10 dB	

[Color-Bar Signal]

The 75% color-bar signal recorded on the alignment tape is shown in Fig. 5-2.

Note:

Measure at CN205 (3) on the VI-10 board.




Fig. 5-2. Color-bar signal of alignment tape

[VR Alignment Tool Screwdriver]

Use the tool screwdriver supplied for alignment of semi-fixed VRs and inductances on each printed circuit board. An ordinary screwdriver is too large and is difficult to use when adjusting VRs from the print pattern side of a board. The special alignment tool screwdriver is shown in Fig. 5-3.

The metal blade of the screwdriver is used for variable resistors and trimmer capacitors.




Fig. 5-3. Alignment tool screwdriver


[Required Levels and Impedances of Input and Output]

Inputs and outputs

Video input	LINE IN VIDEO/PCM (phono jack) 1 V _{p-p} ±0.5 V _{p-p} , 75 ohms, unbalanced, sync negative
Video outputs	LINE OUT 1, 2 VIDEO/PCM (phono jacks) 1 V _{p-p} ±0.5 V _{p-p} , 75 ohms, unbalanced, sync negative
Audio inputs	LINE IN R-AUDIO-L (phono jacks) -10 dBs (0 dBs = 0.775 V rms), more than 47 k ohms
Audio outputs	LINE OUT 1, 2 R-AUDIO-L (phono jacks) -10 dBs (at load impedance 47 k ohms) more than 10 k ohms

[Alignment Sequence]

The alignment should be performed following the sequence below.



5-1. POWER SUPPLY CHECK (PC-19 board)

Measure in E-E mode (power supply switch ON).




Fig. 5-4.

1. SWD +12 V Check
Pin ① of CN702 shall be 12.0 ±0.3 V.
2. SWD +9 V Check
Pin ② of CN702 shall be 9.0 ±0.2 V.
3. UNSWD +5 V Check
Pin ③ of CN702 shall be 5 ±0.2 V.
4. UNSWD +45 V Check
Pin ② of CN702 shall be 45 ±5 V.
5. UNSWD -26 V Check
Pin ① of CN701 shall be -26 ±3 V.
6. UNSWD -30 V Check
Pin ⑤ of CN705 shall be -30 ±2.8 V.
7. AC3.8 V Check
Pin ②, ③ of CN701 shall be AC3.8 ±0.3 V.

5-2. SYSTEM CONTROL CHECK (SS-53 board)

1. Clock Frequency Check

Mode: E-E

Signal: None

Frequency counter: Pin ⑤ of IC401

Check: Within 6.0 MHz ±0.1 MHz




Fig. 5-5. Clock frequency

5-3. SERVO SYSTEM ALIGNMENT

Alignment Sequence

- 5-3-1. Reel servo system alignment
- 5-3-2. Drum servo system alignment
- 5-3-3. Capstan servo system alignment
- 5-3-4. Swing search servo system alignment

5-3-1. Reel Servo System Alignment

1. Reel Voltage Check

- (1) Pin ④ of CN506 (TP523) shall be $6_{-0.1}^{+0.2}$ V when REV.
- (2) Pin ④ of CN506 (TP523) shall be 8.8 ± 0.2 V when FF or REW.
- (3) Pin ④ of CN506 (TP523) shall be 2.7 ± 0.2 V when PB.

5-3-2. Drum Servo System Alignment

1. Voltage Check

- (1) Pin ⑩ of IC501 shall be 5.6 ± 0.3 V.
- (2) Pin ⑩ of IC501 shall be 3.5 ± 0.2 V or 5 ± 0.2 V.

2. Clock Check

- (1) Pin ⑳ of IC501 shall be above 0.4 V_{p-p}.

3. Drum Free Speed Adjustment (SS-53 board)

Mode: Playback

Signal: Alignment tape β II color-bar, or monoscope

Oscilloscope: CH-1 Pin ⑬ of IC501 (TP512)

CH-2 Pin ⑳ of IC501 (TP501)

Alignment method:

Adjust to $547 \mu\text{sec} \pm 10 \mu\text{sec}$ with RV503

(See Fig. 5-6)




Fig. 5-6. Drum free speed adjustment

4. RF Switching Position Adjustment I (SS-53 board)

Mode: Record (β I)

Signal: None

Oscilloscope: CH-1 TP501 (pin ⑳ of IC501)

CH-2 { TP502 (pin ⑳ of IC501)
TP504 (pin ④ of IC501)

Adjustment method:

- (1) Connect CH-2 to IC501 pin ⑳ (TP502) and adjust to $670 \mu\text{sec} \pm 20 \mu\text{sec}$ with RV501. (β I switching pulse A) (Refer to Fig. 5-7)
- (2) Change the CH-2 connection to IC501 pin ④ (TP504) and adjust to $670 \mu\text{sec} \pm 20 \mu\text{sec}$ with RV502. (β I switching pulse B) (See Fig. 5-8)
- (3) Be sure to perform "RF Switching Position Adjustment II", which follows, after performing this adjustment.




Fig. 5-7. RF switching position adjustment (1)




Fig. 5-8. RF switching position adjustment (2)

5. RF Switching Position Adjustment II (SS-53 board)

Mode: Playback (β II)

Signal: Alignment tape β II color-bar or monoscope

Oscilloscope: CH-1 TP501 (pin 39 of IC501)

CH-2 { TP502 (pin 32 of IC501)
TP504 (pin 40 of IC501)

Adjustment method:

- (1) Connect CH-2 with pin 32 of IC501 (TP502), and then adjust to 750 μ sec \pm 30 μ sec with RV518. (β I switching pulse A) (See Fig. 5-9)
- (2) Change connection of CH-2 only to pin 40 of IC501 (TP504), and then adjust to 750 μ sec \pm 30 μ sec with RV519. (β I switching pulse B) (See Fig. 5-10)




Fig. 5-9. RF switching position adjustment (1)




Fig. 5-10. RF switching position adjustment (2)

6. Picture Search Drum Free Speed Adjustment (SS-53 board)

Mode: Picture search (CUE)

Signal: For βI , record and playback any tape. For βII and βIII , playback the alignment tape color-bar or monoscope portion.

Oscilloscope: Pin ① of CN502

Adjustment method:

- (1) Record and playback any signal in βI mode, and then in CUE mode adjust to $63.89 \mu\text{sec} \pm 0.07 \mu\text{sec}$ with SS-53 board RV802.
- (2) Playback in βII , and in CUE mode, adjust to $64.22 \mu\text{sec} \pm 0.07 \mu\text{sec}$ with SS-53 board RV801.
- (3) Playback in βIII , and in CUE mode, adjust to $63.89 \mu\text{sec} \pm 0.07 \mu\text{sec}$ with SS-53 board RV808. (See Fig. 5-11).




Fig. 5-11. Picture search drum free speed adjustment

7. F/R Search f_H Adjustment (SS-53 board)

Mode: REW search

Signal: Alignment tape βIII color-bar, or monoscope

Oscilloscope: Collector of Q521

Adjustment method:

Adjust $63.45 \mu\text{sec} \begin{matrix} +0.06 \\ -0.1 \end{matrix} \mu\text{sec}$. (See Fig. 5-12)




Fig. 5-12. F/R search f_H adjustment

5-3-3. Capstan Servo System Alignment

1. Capstan Error Cancel Adjustment (SS-53 board)

Mode: β III record

Signal: Arbitrary signal

Oscilloscope: Pin ② of CN505 (TP515)

Adjustment method:

- (1) Decrease the wave form level A to minimum with RV516.




Fig. 5-13. Capstan error cancel adjustment

2. Capstan DC Bias Adjustment (SS-53 board)

Mode: Playback

Signal: Alignment tape β II and β III color-bar or monoscope

Oscilloscope: Pin ⑳ of IC501 (TP506)

Adjustment method:

- Adjustment to the relevant duty (ratio for A and B) in the playback mode with the RV as shown in Table 1.

Playback Mode	Adjustment	DUTY
β III	RV509	50% \pm 3%
β II	RV506	50% \pm 3%
β II x 2	RV508	50% \pm 3%
β III x 2	RV507	50% \pm 3%
β III REV	RV505	50% \pm 3%

Table 1.




Fig. 5-14. Capstan DC bias adjustment

3. FG Amp DC Bias Adjustment (SS-53 board)

Mode: REC

Signal: Alignment tape β II color-bar or monoscope

Oscilloscope: CH-1 Pin ① of IC508

CH-2 Pin ⑤ of IC508

Adjustment method:

- (1) Short pin ⑧ of IC506 (TP514) and TP507 (5 V) and adjust the duty ratio (between A and B) to about 50% with RV510 and RV511.

(See Fig. 5-15)

Note:

When the waveform does not lock and the playback picture is disturbed during adjustment, the video cassette recorder stops automatically. Set up the playback mode and adjust again.




Fig. 5-15. FG amp DC bias adjustment (1)

- (2) Repeat shorting and opening pin ⑧ of IC506 (TP514) and TP507 (5 V) successively and adjust so that the duty ratio (between A and B) of CH-1 waveform does not change, with RV511.

(See Fig. 5-16)




Fig. 5-16. FG amp DC bias adjustment (2)

- (3) Connect CH-2 of the oscilloscope to pin ⑳ of IC501 (TP506).

- (4) Short pin ⑧ of IC506 (TP514) and TP507 (5 V) and adjust with RV510 so that the duty ratio of CH-2 waveform becomes 45%. (See Fig. 5-17)




Fig. 5-17. FG amp DC bias adjustment (3)

4. Tracking Center Adjustment (SS-53 board)

Mode: Playback

Signal: Alignment tape β II or β III color-bar or monoscope

Oscilloscope: CH-1 Pin ⑬ of IC501 (TP512)

CH-2 Pin ⑮ of IC501 (TP513)

Adjustment method:

- (1) Set the TRACKING knob to the center click position.
- (2) Adjust to 860 μ sec \pm 20 μ sec with RV512. (See Fig. 5-18)




Fig. 5-18. Tracking center adjustment

5. Edit Tracking Center Adjustment (SS-53 board)

Mode: Recording

Signal: Alignment tape β II or β III color bar

Oscilloscope: CH-1 Pin ⑬ of IC501 (TP512)

CH-2 Pin ⑮ of IC501 (TP513)

Adjustment method:

- (1) Set the TRACKING knob to the center click position. (See Fig. 5-19)




Fig. 5-19. Edit tracking center adjustment

6. CTL Delay Adjustment (SS-53 board)

Mode: X1 RVS (BETA Scan)

Signal: Color-bar signals recorded in β II mode.

Adjustment method:

- (1) Set the TRACKING knob to the center click position.
- (2) Adjust RV901 so that noise bars on the TV monitor screen disappear from the screen top or bottom (or are kept to a minimum). (See Fig. 5-20)




Fig. 5-20. CTL delay adjustment

5-3-4. Swing Search Servo System Alignment

1. β I RVS (X1) Tracking Shift Adjustment

Mode: β II playback (β I reverse tracking control shift is adjusted with a β II tape.)

Signal: Arbitrary signal

Oscilloscope: CH-1 Pin ⑤ of IC516

CH-2 Pin ⑥ of IC516

Adjustment method:

- (1) Adjust to $T = 16.7 \text{ msec} \pm 0.5 \text{ msec}$ with RV517.




Fig. 5-21. β I RVS (X1) tracking shift adjustment

2. Edit Adjustment (SS-53 board)

- Adjust in both β II and β III modes.

Mode: Record

Signal: Arbitrary signal

Oscilloscope: Pin ⑳ of IC501

External trigger: Pin ⑨ of IC801

Trigger slope: -

Input: DC range

Sweep mode: NORMAL

Adjustment method:

- (1) Set up the PAUSE mode. (more than 3 seconds)
- (2) Press the pause button again, and adjust RV514 (β II) and RV515 (β III) so that the time T , between release of pause (at this time adjust trigger level before oscilloscope trigger is applied) and fall of the waveform, is minimum. (See Fig. 5-22)




Fig. 5-22. Edit adjustment

- (3) Repeat; PAUSE release of PAUSE two or three times, and check that the result meets Paragraph (2).
- (4) Make self-recording the playback and check that edits are free of noise.

3. VD Adjustment

Mode: STILL

Signal: Alignment tape β III color-bar signal or monoscope signal.

Oscilloscope: CH-1 TP501

CH-2 Pin ① of CN802

Adjustment method:

- (1) Adjust as shown in Fig. 5-23 with RV803.




Fig. 5-23. VD adjustment

4. Slow Motion Adjustment

[Tracking Center Adjustment]

- Adjust in the β II mode.
- Record an arbitrary signal in β II mode.

Mode: 1/5 FWD slow motion

Oscilloscope: CH-1 Pin ③ of CN213 on RP-24 board

CH-2 Pin ① of CN213 on RP-24 board

Adjustment method:

- (1) Set the slow motion tracking knob at the center click position.
- (2) Adjust the waveform peak to be in center of A-CH with RV806. (See Fig. 5-24)




Fig. 5-24. Tracking center adjustment

5. Drum Shift Adjustment

[STILL f_H Adjustment]

Mode: STILL

Signal: Alignment tape β II color-bar signal, or monoscope signal.

Oscilloscope: Pin ② of IC2 in VI-10 board

Adjustment method:

- (1) Adjust f_H during the STILL mode with RV805 to be equal to f_H in the E-E mode. (See Fig. 5-25)




Fig. 5-25. STILL f_H adjustment

[SLOW f_H Adjustment]

Mode: 1/5 FWD slow motion and 1/5 RVS slow motion.

Signal: Alignment tape β II color-bar signal, or monoscope signal.

Oscilloscope: Pin ② of IC2 in VI-10 board

Adjustment method:

- (1) Reduce the shaking width of f_H with RV804 during 1/5 FWD slow motion to a minimum. (See Fig. 5-26)
- (2) Reduce the shaking width of f_H during the 1/5 RVS slow motion by using RV807 to a minimum.
- (3) Repeat Steps (1) and (2) alternately to reduce the shaking width for both FWD and RVS to a minimum. (See Fig. 5-26)




Fig. 5-26. SLOW f_H adjustment

5.4. VIDEO SYSTEM ALIGNMENT

As rule, first the playback system is aligned with an alignment tape to check that it operates normally, then the recording system is aligned.

The alignment sequence is shown below. The Y signal and chroma signal systems are aligned for both playback and recording systems.

Color video signals supplied by the pattern generator is used for video system alignment in the record mode. Check that the sync and color burst signals conform to the specifications designated in "Preparatory Set-up for Alignment" in Fig. 5-1.

[Playback system alignment]

1. Playback amplifier frequency response adjustment
2. Playback Y, A'-ch and B'-ch frequency response adjustment
3. De-emphases level adjustment
4. Playback Y signal level adjustment

[Record system alignment]

1. VCO frequency alignment and VCO lock check
2. Comb filter adjustment
3. Comb AGC adjustment
4. Sync AGC adjustment
5. Y-FM carrier 1 adjustment
6. FM modulator deviation adjustment
7. Y-FM carrier 3 adjustment
8. Y-FM carrier 2 adjustment
9. Dark clip adjustment
10. Y-FM record current adjustment
11. fsc adjustment
12. Carrier balance adjustment
13. Chroma record current adjustment

[Slow motion playback system alignment]

1. Skew frequency adjustment
2. Slow AGC adjustment
3. Adjustment of output level during pause

5.4-1. Playback System Alignment

1. Playback Amplifier Frequency Response Adjustment (RP-24 board)

- Adjust both A-ch and B-ch.
- B-ch is indicated by ().

Mode: Playback

Signal: Alignment tape β II RF sweep

Oscilloscope: Pin ③ of CN213

External trigger: Pin ① of CN213

Adjustment method:

- (1) Adjust output level to maximum with the tracking knob.
- (2) Set the trigger slope to - (+).
- (3) Adjust so that the 5.1 MHz level about 75% of 3.58 MHz level with RP-24 board RV005 (RV001). (See Fig. 5-27)
- (4) Adjust RV002 so that BCH level and ACH level are equal.




Fig. 5-27. Playback amplifier frequency response adjustment

2. A'-ch, B'-ch Playback Frequency Response Adjustment

- B'-ch is indicated by ().

Mode: Playback

Signal: Alignment tape β II RF sweep

Oscilloscope: Pin ③ of CN213

External trigger: Pin ① of CN213
(RF SWP)

Adjustment method:

- (1) Adjust output level to maximum with the tracking knob.
- (2) Set trigger slope to - (+).
- (3) Connect SS-53 board IC517 pins ⑨ and ⑩.
- (4) Connect RP-24 board IC004 pins ⑫ and ⑬.
- (5) Adjust so that 5.1 MHz level is 75% of 3.5 MHz level. (See Fig. 5-27)
- (6) Adjust RV004 (RV007) so that A'-ch and B'-ch levels are the same as A-ch.
- (7) Remove the connection between SS-53 board IC517 pins ⑨ and ⑩.
- (8) Remove the connection between RP-24 board IC004 pins ⑫ and ⑬.

3. De-emphases Level Adjustment (VI-10 board)

Mode: Playback
 Signal: Alignment tape β II color-bar
 Oscilloscope: Emitter of Q715
 Adjustment method:
 Adjust to $1.3 \text{ V} \pm 0.05 \text{ V}_{p-p}$ with RV701.
 (See Fig. 5-28)




Fig. 5-28. De-emphases level adjustment

4. Playback Y Signal Level Adjustment (VI-10 board)

Mode: Playback
 Signal: Alignment tape β II color-bar
 Oscilloscope: Pin ⑤ of CN205
 Adjustment method:
 Adjust to $2.0 \text{ V} \pm 0.1 \text{ V}_{p-p}$ with RV702.
 (See Fig. 5-29)




Fig. 5-29. Playback Y signal level adjustment

5-4-2. Record System Alignment

1. VCO Frequency Alignment and VCO Lock Check (VI-10 board)

Mode: Record or E-E
 Signal: Color-bar
 Frequency counter: Pin ③③ of IC2
 Digital voltmeter: Pin ②⑥ of IC2
 Adjustment method:
 Adjust to $3.4 \text{ V} \pm 0.1 \text{ V}$ dc with RV403.

Note:

The frequency also changes when RV403 is turned.
 Verify that the frequency is locked to $f=4.27 \text{ MHz}$.
 Be sure to use digital voltmeter to measure voltage.




Fig. 5-30. VCO frequency alignment and VCO lock check

2. Comb Filter Adjustment (VI-10 board)

Mode: Record or E-E
 Signal: Color-bar
 Oscilloscope: Pin ④② of IC1
 Adjustment method:
 Minimize the residual chroma signal by alternately adjusting RV104 and LV101. (See Fig. 5-31)




Fig. 5-31. Comb filter adjustment

3. Comb AGC Adjustment (VI-10 board)

Mode: Playback
 Signal: Monoscope or prerecorded tape
 Oscilloscope: Pin ⑤ of CN205
 Adjustment method:
 Adjust with RV301 so that the dropout corrected portion level is the same as the value before dropout.
 (See Fig. 5-32)




Fig. 5-32.

4. Sync AGC Adjustment (VI-10 board)

Mode: Record or E-E

Signal: Color-bar

Oscilloscope: Pin ⑤ of CN205

Adjustment method:

Adjust to $2.0 \text{ Vp-p} \pm 0.1 \text{ Vp-p}$ with RV103.

(See Fig. 5-33).




Fig. 5-33. Sync AGC adjustment

5. Y-FM Carrier 1 Adjustment (VI-10 board)

BETA HI-FI selector switch: OFF,

HI-BAND switch: PFF

Mode: Record or E-E

Signal: None

Frequency counter: Pin ②⑤ of IC1

Adjustment method:

(1) Set to NORMAL recording mode.

(2) Adjust to $3.7 \text{ MHz} \pm 0.05 \text{ MHz}$ with RV201.

(See Fig. 5-34)




Fig. 5-34. Y-FM carrier 1 adjustment

6. FM Modulator Deviation Adjustment (VI-10 board)

Mode: Record or E-E

Signal: Color-bar

Spectrum analyzer: Pin ①① of CN202

Adjustment method:

(1) Adjust the spacing between f_2 and f_1 to $1.27 \text{ MHz} \pm 0.05 \text{ MHz}$ with RV207. (See Fig. 5-35)

(2) Adjust according to step 5 and 6 (1) repeatedly so that Y signal carrier and deviation adjustments are both satisfied.




Fig. 5-35. FM modulator deviation adjustment

7. Y-FM Carrier 3 Adjustment (VI-10 board)

HI-BAND switch: ON

Mode: Record or E-E

Signal: None

Frequency counter: Pin ②⑤ of IC1

Adjustment method:

Set to HI-BAND mode

Adjust to $4.4 \text{ MHz} \pm 0.05 \text{ MHz}$ with RV208.

8. Y-FM Carrier 2 Adjustment (VI-10 board)

BETA HI-FI selector switch: ON

HI-BAND switch: OFF

Mode: Record or E-E

Signal: None

Adjustment method:

(1) Set to BETA HI-FI recording mode (BETA HI-FI selector switch: ON)

(2) Adjust to $4.1 \text{ MHz} \pm 0.05 \text{ MHz}$ with RV204. (See Fig. 5-36)




Fig. 5-36. Y-FM carrier 2 adjustment

9. Dark Clip Adjustment (VI-10 board)

Mode: Record

Signal: None

Digital voltmeter: See Fig. 5-37

Adjustment method:

Adjust to 0 V ± 0.05 V potential difference with RV203.




Fig. 5-37.

10. Y-FM Record Current Adjustment (RP-24 board)

Mode: β II record (BETA HI-FI selector switch: ON)

Signal: None

Oscilloscope: Pin ① of CN214

Adjustment method:

Adjust RV008 to obtain the level listed below.
(See Fig. 5-38)




Fig. 5-38. Y-FM record current adjustment

11. fsc Adjustment (VI-10 board)

Mode: Playback

Signal: Color-bar

Frequency counter: Pin ④ of CN203

Adjustment method:

(1) Set to playback mode.

(2) Adjust to 3.579545 Hz ± 10 Hz with RV404.

12. Carrier Balance Adjustment (VI-10 board)

Mode: Playback

Signal: Alignment tape β II color-bar

Spectrum analyzer: Pin ③9 of IC2

Adjustment method:

Adjust 4.27 MHz component with RV402 to a level lower than the 3.58 MHz component by -30 dB.

(See Fig. 5-39)




Fig. 5-39. Carrier balance adjustment

13. Chroma Record Current Adjustment (VI-10 board)

Mode: Record

Signal: Color-bar

Oscilloscope: Emitter of Q658 (See Fig. 5-40)




Fig. 5-40.

Adjustment method:

Adjust the level of the color-bar "cyan" to 160 mV \pm 10 mVp-p with RV401. (See Fig. 5-41)




Fig. 5-41. Chroma record current adjustment

5-4-3. Slow Motion Playback System Alignment

1. Skew Frequency Adjustment (VI-10 board)

Mode: Playback + Pause

Signal: Alignment tape β II color-bar

Adjustment method:

Adjust RV501 to remove skew. (Adjust after more than 2 minutes have elapsed in playback mode.)

2. Slow AGC Adjustment (VI-10 board)

Mode: Playback + Pause

Signal: Alignment tape β II or β III color-bar

Oscilloscope: Pin ⑤ of CN205

Adjustment method:

Set for identical output levels during both playback and pause with RV502, 503. (See Fig. 5-42)




Fig. 5-42. Slow AGC adjustment

3. Adjustment of Output Level During Pause (VI-10 board)

Mode: Playback + Pause

Signal: Alignment tape β III color-bar

Oscilloscope: Pin ⑤ of CN205

Adjustment method:

Adjust with RV504 so that the output level during pause is the same as that during playback.

5-5. AUDIO SYSTEM ADJUSTMENT (AU-13 board)

- Adjustments of the audio system shall be made in the β III mode, otherwise note. Use a Dynamicon tape (normal type, L125 - L500) for adjustments.

[Connection of Related Equipment]




Fig. 5-43.

[Adjustment Sequence]

1. ACE head adjustment ... See "Mechanical Adjustment"
2. Playback frequency characteristic adjustment
3. Playback output level adjustment
4. E-E output level check
5. Bias oscillator and bias trap check
6. Record bias adjustment
7. Record level adjustment
8. Overall frequency characteristic check (NORMAL)
9. Overall S/N check (NORMAL)
10. Overall S/N check (BETA HI-FI)
11. Overall distortion check (NORMAL)
12. Overall distortion check (BETA HI-FI)
13. BETA FI-FI recording carrier wave level check
14. Dynamic emphasis decoder gain and playback L-CH (R-CH) adjustment
15. BETA HI-FI deviation adjustment

1. ACE Head Adjustment

Refer to "Mechanical Adjustment"

2. Playback Frequency Characteristic Check

Mode: Playback

Signal: Alignment tape β II 333 Hz (monoscope) and 7 kHz (RF sweep) portions

Check method:

- (1) Playback 333 Hz and 7 kHz from the alignment tape and confirm that the level difference between 333 Hz and 7 kHz $0\ \text{dB} \pm 3\ \text{dB}$.

3. Playback Output Level Adjustment

Mode: Playback

Signal: Alignment tape β II 333 Hz (monoscope) portion
Adjustment method:

- (1) Playback 333 Hz from the alignment tape and adjust so that the output level is $-30\ \text{dB} \pm 1\ \text{dB}$ with RV102.

4. E-E Output Level Check

- (1) Input a 333 Hz, $-30\ \text{dBs}$ signal on L-CH and R-CH simultaneously so audio line input.
- (2) Confirm that the audio line output level is $-30\ \text{dBs} \pm 3\ \text{dBs}$.

5. Bias Oscillator Frequency and Bias Trap Check

Input is "AUDIO LINE IN", inputs pins for both L-CH and R-CH are shorted.

- (1) Input is no-signal, in recording mode.
- (2) Bring the oscilloscope probe close to T301 inside the shield case, via the frequency counter. Confirm that the oscillation frequency is $65\ \text{kHz} \pm 6.5\ \text{kHz}$.
- (3) Connect the oscilloscope to TP103 and check that bias leak is minimum (less than 4 Vp-p).

6. Record Bias Adjustment

Tape path adjustment should be completed.

- (1) Supply a 333 Hz signal.
- (2) Terminate the audio line output pin with a 47 k Ω resistor and connect a level meter.
- (3) Turn the attenuator and adjust the input signal so that the level meter indication is -30 dBs.
- (4) Set to β III recording mode.
- (5) Record in this state for 10 seconds.
- (6) Supply a 5 kHz signal, and record for 10 seconds.
- (7) Playback the recorded section of the tape and check that the output level at 333 Hz and 5 kHz.
- (8) Confirm that the output level at 5 kHz is 0 dB \pm 1 dB relative to the output level at 333 Hz.
- (9) When the specifications are not met, adjust RV104 and repeat items (1) - (8).

7. Record Level Adjustment

- (1) (2) and (4) are the same as in 6. Recording Bias Adjustment.
- (3) Playback the recorded portion, and confirm that the output level is -9 \pm 2 dBs.
- (6) If not within the specifications, adjust RV101 and repeat steps (1) - (6).

8. Overall Frequency Characteristic Check

REC LVEVL control: Center

REC mode selector switch: β II

REC BALANCE control: Center

- (1) Apply a 333 Hz signal simultaneously to L-CH and R-CH audio line input.
- (2) Set up the E-E mode and adjust the attenuator output level so that the level meter reading is -30 dB.
- (3) Record signals.
- (4) Change the frequency to 50 Hz, 100 Hz, 333 Hz, 7 kHz, and 10 kHz and repeat Steps (2) and (3).
- (5) Playback the recorded section of the tape and verify that the level is within the specification.
(See Fig. 5-44)




Fig. 5-44. Overall frequency characteristic check

- (6) Turn the ~~AUDIO SELECT~~ switch to ON, the MPX FILTER/PCM switch to OFF, and apply a 400 Hz signal to audio line input pin.
- (7) Adjust the attenuator output level so that the level meter reading is -20 dB.
- (8) Record signals for 5 seconds by the tape counter.
- (9) Change the frequency to 20 Hz, 100 Hz, 400 Hz, 10 kHz and 20 kHz and repeat Step (8).
- (10) Playback the recorded section of the tape and verify that the level is within the specification.
(See Fig. 5-45)
- (11) Turn the MPX FILTER/PCM switch ON, and repeat item (8) with input signal frequency of 16 kHz.
- (12) Confirm that the output level at 16 kHz is -20 dB or less relative to the output level at 400 Hz.




Fig. 5-45.

9. Overall S/N Check (NORMAL)

AUDIO SELECT switch: OFF

REC mode selector switch: β II

- (1) Apply a 333 Hz signal simultaneously to L-CH and R-CH audio line input and adjust so that audio line input level is -10 dB.
- (2) Record signals.
- (3) Switch to no-signal input while continuing in record mode. (Ground-input for both L-CH and R-CH.)
- (4) Playback the recorded portion, and confirm that the level difference between the 333 Hz signal and no-signal portion (the portion immediately after the 333 Hz signal) is more than 33 dB.

10. Overall S/N Check (BETA HI-FI)

AUDIO SELECT switch: ON

REC mode selector switch: β II

- (1) Terminate the audio line output pin with a 47 k Ω resistor and connect a level meter.
- (2) Apply a 400 Hz signal simultaneously to L-CH and R-CH audio line input and adjust so that audio line input level is -10 dB.
- (3) Record signals for 5 seconds by the tape counter.
- (4) Ground the audio line input, and record for 5 seconds by the tape counter.
- (5) Playback the recorded portion, and confirm that the level difference between the 400 Hz signal and no-signal portion is more than 65 dB.
Apply IHF-A curve when reading the level in item (3).

11. Overall Distortion Check (NORMAL)

AUDIO SELECT switch: OFF

REC mode selector switch: β II

- (1) Apply a 333 Hz signal simultaneously to L-CH and R-CH audio line input and adjust the attenuator output level so that R-CH level is -10 dB.
- (2) Record signals.
- (3) Playback the recorded section of the tape and verify that the distortion is below 4%.

12. Overall Distortion Check (BETA HI-FI)

AUDIO SELECT switch: ON

REC mode selector switch: β II

- (1) Apply a 400 Hz signal simultaneously to L-CH and R-CH audio line input and adjust so that R-CH level is -10 dB.
- (2) Record signals.
- (3) Playback the recorded section of the tape and verify that the distortion is below 0.5%.

13. BETA HI-FI Recording Carrier Wave Level Check (AF-9 board)

AUDIO SELECT switch: ON

Signal: None

- (1) Carrier wave 1 (1.38 MHz) level check
 1. Connect the oscilloscope to pin $\textcircled{39}$ of IC3.
 2. Confirm that peak value is 0.8 Vp-p \pm 0.1 Vp-p.
- (2) Carrier wave 2 (1.53 MHz) level check
 1. Connect the oscilloscope pin $\textcircled{36}$ of IC3.
 2. Confirm that peak value is 0.8 Vp-p \pm 0.1 Vp-p.
- (3) Carrier wave 3 (1.68 MHz) level check
 1. Connect the oscilloscope pin $\textcircled{11}$ of IC3.
 2. Confirm that peak value is 0.8 Vp-p \pm 0.1 Vp-p.
- (4) Carrier wave 4 (1.83 MHz) level check
 1. Connect the oscilloscope to pin $\textcircled{9}$ of IC3.
 2. Confirm that peak value is 0.8 Vp-p \pm 0.1 Vp-p.




Fig. 5-46. Recording carrier wave level adjustment

* Interchangeability Check

Low level noise should not be noticeably large on a commercially sold soft tape BETA HI-FI signal portion.

14. Dynamic Emphasis Decoder Gain and Playback L-CH (R-CH) Check

AUDIO SELECT switch: ON

- (1) Playback alignment tape in the BETA HI-FI mode.
- (2) Confirm that the level meter to pin $\textcircled{5}$ and $\textcircled{11}$ of FL101 becomes -20 dB \pm 3 dB.
- (3) Connect the level meter to audio line output pin.
- (4) BETA HI-FI mode and confirm that level meter is -10 dB \pm 3 dB.

15. BETA HI-FI Deviation Check

BETA HI-FI selector switch: ON

- (1) Terminate the audio line output pin with a 47 k Ω resistor and connect a level meter.
- (2) Apply a 400 Hz signal simultaneously to audio line input and adjust so that audio line input level is -10 dB.
- (3) Confirm that E-E mode audio line output and output when self-recording is played back are the same.

5-6. TUNER SYSTEM ADJUSTMENT (TI-4 board)

1. AFT Adjustment

- (1) Receive a TV broadcast signal.
- (2) Turn the AFT switch off.
- (3) Press the tuning button and set for the optimum state while observing the monitor TV screen. (There should be no beat.)
- (4) Connect the digital voltmeter to pin (7) of IC201.
- (5) Adjust T202 so that the level is 4.6 V dc.
- (6) Turn the AFT switch on, receive each channel, and check to make sure that there is no beat or picture disturbance.

2. RF AGC Adjustment

- (1) Adjust the monitor TV for best contrast and receive a broadcast signal.
- (2) Adjust RV201 so that snow noise is visible.
- (3) Turn RV201 in the opposite direction to that in (2) and set at the point where snow noise disappears.
- (4) Receive each channel and confirm that there is no beat, picture disturbance or snow noise.

3. Audio Carrier Lock SIF Adjustment

- Set the audio carrier lock switch to ON before adjusting.

3-1. VCO voltage adjustment

- (1) Short IC202 pin (9) and pin (10) across the shortest distance.
- (2) Connect a digital voltmeter to IC202 pin (4).
- (3) Adjust to 2.7 V \pm 0.05 V DC with RV203.
- (4) Return IC202 pins (9) and (10) to normal.

3-2. T206 adjustment

- (1) Receive a TV broadcast signal.
- (2) Connect a digital voltmeter to IC202 pin (4).
- (3) Adjust the 2.7 V \pm 0.05 V DC with T206. Audio should be output normally at this time.

Note:

2.7 V voltage is generated at several points, not just one, so find the point that varies between 1 V - 4 V.

3-3. SIF discriminator adjustment

- (1) Receive a TV broadcast signal.
- (2) Connect a digital voltmeter to IC201 pin (13).
- (3) Adjust to 3.9 V \pm 0.2 V DC with T203.

4. Multiplex Decoder Adjustment

4-1. SAP-BPF adjustment

- (1) Remove the solder between IC801 pin (1) and RV203 to open the pattern and input a 62.94 kHz 0.42 Vp-p sine wave to IC810 pin (1).
- (2) Adjust RV801 so that IC801 pin (6) output is minimum.
- (3) Set the frequency to 78.67 kHz and confirm that IC801 pin (37) output is less than 30 mVp-p.

4-2. Stereo VCO adjustment

- (1) Remove the solder between IC801 pin (1) and RV203 to open the pattern and short IC801 pin (1) to ground with a chemical capacitor.
- (2) Connect a frequency counter to IC801 pin (32) and adjust RV805 so that the frequency is 62.94 \pm 0.1 kHz.

4-3. SAP VCO adjustment

- (1) Select an illegal channel (channel 0, etc.) to make MUTE high and read IC801 pin (25) DC voltage VM.
- (2) Remove the solder between IC801 pin (1) and RV203 to open the pattern and input 78.67 kHz 0.42 Vp-p to IC801 pin (1) and adjust RV803 so that IC801 pin (25) DC voltage is VM \pm 0.1 V.

4-4. Pilot cancel adjustment

- (1) Remove the solder between IC801 pin (1) and RV203 to open the pattern and input 15.75 kHz 0.14 Vp-p to IC801 pin (1).
- (2) Adjust RV804 so that IC801 pin (40) output 15.75 kHz output is minimum. (If it is turned too much, output will become zero and operation will be mono.)

4-5. Output level check

Remove the solder between IC801 pin (1) and RV203 to open the pattern and input 300 Hz 0.7 Vp-p to IC801 pin (1). Check CN106 pin (1) output V_L and (2) output V_R . $V_L = 447 \pm 45$ mVrms. $V_R = V_L \pm 25$ mVrms.


5. Noise Reduction Adjustment

5-1. Time constant adjustment

Adjust RV830 so that the voltage drop at both sides of R839 is 15 ± 1 mVp-p.

5-2. Variable de-emphasis adjustment

- (1) Set RV832 to mechanical center.
- (2) Apply 5.5 V bias to IC801 pin (24), cut DC with a capacitor and input 300 Hz -24.3 dBs.



- (3) Adjust RV831 so that CN106 (1) and (2) output is $V_L/7 \pm 5$ mV, and read IC830 pin (7) output V_a .
- (4) In the same way, input 8 kHz -17.2 dBs and adjust RV831 so that IC830 pin (7) output is V_a -11.3 dBs.

6. Separation Check

6-1. Indicator check

Receive an MTS signal channel and check that the stereo indicator lights up. (AUTO STEREO SW should be ON)

6-2. Main level, L-R adjustment

Receive an MTS signal and adjust RV202 and RV806 (L-R) so that separation is maximum.


(RV202 should be near MAX and RV806 near center)

1. "H" for 12 seconds only when REC starts.
 2. "H" when there is no CTL.
 3. Depends on front panel β switch.
 4. Outputs Beta mode set the time before.
 5. Outputs Beta mode of the tape currently being played back.
 6. β I: "L", β II: "L" only when tape moves, β III: "H".
 7. (RF SWP) when tape is stopped, "L" when tape is moving.
- } Refer to Timing Chart.


7. Video Modulation Adjustment

- Receive VTR RF modulator output on a TV. Observe the TV video output in level on an oscilloscope, and select the same channel with the VTR. Receive RF modulator output on that TV, and adjust RV101 so that the video output level is about $91\% \pm 3\%$ relative to the previous level. In other words, the same picture will be a little darker when seen on the VTR.


AU-13 board
(Component side)




TI-4 board
(Component side)




**VI-10 board
(Pattern side)**



**RP-24 board
(Pattern side)**



SS-53 board
(Pattern side)



RMT-125

SERVICE MANUAL



SPECIFICATIONS

Remote control system	Infrared control
Power requirements	3 V dc, 2 size AA batteries (IEC designation R6)
Dimensions	Approx. 57 × 20 × 175 mm (w/h/d) (2 1/4 × 7/8 × 7 inches) incl. projecting parts and controls
Weight	Approx. 98 g (3.6 oz) without batteries


REMOTE COMMANDER
SONY[®]

1. REMOTE CONTROL OPERATION

(Continued on next page)

You can control almost all the functions of this video cassette recorder from your armchair using the supplied Remote Commander.

BATTERY INSERTION




Battery life

In normal operation, batteries will last for about six months. If the range of the Remote Commander becomes noticeably shorter, replace the batteries with new ones. When the batteries are exhausted, the indicator will not light when the buttons on the Commander are pressed.

If the Remote Commander is not to be used for a long period of time, remove the batteries to avoid possible damage from battery leakage.


SETTING THE COMMAND MODE SELECTOR

For remote control of this VCR, set the COMMAND MODE selector inside the tuning compartment and on the back of the Remote Commander to the same "VTR-1" or "VTR-2" position as illustrated below.



Ex.1	VTR-1 VTR-2	VTR-1 VTR-2
Ex.2	VTR-1 VTR-2	VTR-1 VTR-2

For details on the difference between the "VTR-1" and "VTR-2" remote control mode, read "FOR OWNERS OF ANOTHER SONY VIDEO EQUIPMENT" below.



FOR OWNERS OF ANOTHER SONY VIDEO EQUIPMENT

The COMMAND MODE selector on the Remote Commander selects the mode (code) in which the signals of the Commander will be sent. On the other hand, the corresponding selector on the VCR selects the mode in which the VCR detects the signals. This VCR will accept only signals in the mode (VTR-1 or VTR-2) selected by this selector. Most Sony Betamax infrared remote control VCRs detect signals in the VTR-1 mode and therefore, can be controlled by the supplied RMT-125 Remote Commander when the COMMAND MODE selector of the Commander is set to "VTR-1". If you desire to avoid having this VCR and the other VCR to function simultaneously, set the COMMAND MODE selector in the tuning compartment of this VCR to "VTR-2". (If, such as the Sony TT-V8 tuner timer unit, the other Sony video equipment detects VTR-2 mode signals, set the selector to


"VTR-1".) Then, by simply switching the position of the selector on the back of the Remote Commander, you will be able to remote control this VCR and the other video equipment separately.

The buttons on the Remote Commander that can be used to control other video equipment are limited by the functions of the other equipment.

If you have set the VCR's COMMAND MODE selector at "VTR-2"

As the remote control mode will automatically be VTR-1 when the remote control TV/VTR selector is set to "TV", always set the Remote control TV/VTR selector to "VTR" whenever controlling the VCR.

USE AND FUNCTIONS OF THE BUTTONS



The buttons other than buttons ①, ②, ③ and ④ will function the same as the buttons on the recorder with the similar name or mark. (The auto play cannot be operated.)

The buttons marked with an "" are buttons that can be used also on certain Sony remote control TV sets. To use these buttons on the TV, set the remote control TV/VTR selector to "TV" and then direct the Commander to the Remote control detector of the TV. The buttons that can be used on the TV are limited by the functions of your TV.

① Channel number buttons and "ENTER" button
Select channels. After pressing the digits of the desired channel one by one, press "ENTER" button (See page 18).

Note
Channel selection on certain Sony TV sets can also be made with these buttons in the similar way by setting the remote control TV/VTR selector to "TV". With some TV models that have only 14 channel (program) positions, channel positions 1 through 9 will be selected simply by pressing buttons "1" through "9", channel position 10 by pressing "0" button, and channel position 12 by pressing the "ENTER" button. For such models, use the channel +/- button to select channel positions 11, 13 and 14.

- ② These are buttons for use with Sony remote control TV sets only.


VOL (volume) button

Press the + side to increase the volume of the TV and the - side to decrease it.

DISPLAY button

The on-screen displays of certain TV models can be kept turned on or off with this button.

③ Various playback buttons



④ a, b, c x1/5, x1, x2 buttons

By pressing these buttons during playback or while a still picture is displayed with the || or >>> button, you will be able to switch the playback speeds to slow (one-fifth the normal speed), normal, or double speed.

To view the reverse playback at the same speed, press <<< (reverse) button.

⑤ >>> (forward) button

Press during reverse playback for forward playback. When this button is pressed while a still picture is being displayed with the || or >>> button, you will be able to view the picture one action at a time (stop-action advance operation).



⑥ >>> (still) button

Press while the tape is being played back with the >>> (playback), x1/5, x1, or x2 button for a still picture. To start playback again, press x1, >>> (playback) or || (pause) button.

⑦ <<< (reverse) button

Press during playback for reverse playback at the same playback speed.

To return to the forward playback, press >>> (forward) button.

When this button is pressed while a still picture is being displayed with the || or >>> button, you will be able to view the reverse picture one action at a time (stop-action advance operation).


Normal playback will resume whenever the >>> (playback) button is pressed.

⑧ REC HOLD (recording hold) switch

When this switch is set at the lower position, the ■ (stop) button of this Commander will not function. It can be used to prevent accidental stopping the unit during a recording.

SCHEMATIC DIAGRAM

1 2 3 4 5 6 7




1	2	3	4	5	6	7
1.1	51	52	53	54	55	56
1.2	57	58	59	60	61	62
1.3	63	64	65	66	67	68
1.4	69	70	71	72	73	74
1.5	75	76	77	78	79	80
1.6	81	82	83	84	85	86

- Note:
- All capacitors are in μF unless otherwise noted. pF: pF; μM : 50mV or less are not indicated except for electrolytics and tantalums.
 - All resistors are in Ω and $\frac{1}{4}\text{W}$ or less unless otherwise specified.
 - : adjustment for repair.
 - : B+ bus.






3. PRINTED WIRING BOARD

1 2 3 4 5 6 7



4. SEMICONDUCTORS


- CX23094
- 2SC2673
- 1SS119
- SLR-932A
- SR106C



- Note:
- : parts extracted from the component side.
 - : carbon pattern
 - : soldering side
 - : component-side pattern.
 - : B+ pattern

5. EXPLODED VIEW

- NOTE:
- Items with no part number and no description are not stocked because they are seldom required for routine service. Some delay should be anticipated when ordering these items.
 - The construction parts of an assembled part are indicated with a collation number in the remark column.
 - Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
 - The mechanical parts with no reference number in the exploded views are not supplied.



No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
401	X-2387-102-1	CASE ASSY, UPPER		409	2-387-134-01	COVER, BATTERY RUBBER (A), CONTACT	
402	2-387-127-11	BUTTON, SLIDE		410	2-387-135-11	RUBBER (A), CONTACT	
403	2-387-101-11	BUTTON, RECORDING		411	2-387-136-11	CASE, LOWER	
404	2-387-102-11	BUTTON, SLIDE		412	2-387-118-11	BUTTON, SLIDE	
405	2-387-128-01	KEY TOP (A)		413	2-387-133-01	PLATE, FROSTED	
406	2-387-129-01	KEY TOP (B)		414	*1-614-838-11	A-200 BOARD	
407	2-387-130-01	KEY TOP (C)		415	*1-614-843-11	B-200 BOARD	
408	2-387-132-01	RUBBER, CONTACT					

A-200 B-200

6. ELECTRICAL PARTS LIST

NOTE: When indicating parts by reference number, please include the board name.

- Due to standardization, replacements in the parts list may be different from the components used on the set.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- RESISTORS
- All resistors are in ohms
- F : nonflammable
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- CAPACITORS
- MF : μF , PF : μF
- COILS
- MMH : mH, UH : μH

Ref.No	Part No.	Description	Remark
	*1-614-838-11	A-200 BOARD	

	2-387-103-01	TERMINAL (A), BATTERY	
	2-387-104-01	TERMINAL (B), BATTERY	
	8-759-918-7D	JC-CX23094-01	
		CAPACITOR	
C1	1-102-107-00	CERAMIC	120PF 10% 50V
C2	1-102-107-00	CERAMIC	120PF 10% 50V
		DIODE	
D1	8-719-912-39	DIODE SLR-932A	
D2	8-719-107-95	DIODE SR106C-4	
D3	8-719-911-19	DIODE ISS119	
		TRANSISTOR	
Q1	8-729-967-32	TRANSISTOR 2SC2673-Q	
		RESISTOR	
R1	1-246-405-25	CARBON	1.5 5% 1/4W
R2	1-247-809-00	CARBON	120 5% 1/6W
R3	1-247-797-00	CARBON	39 5% 1/8W
R4	1-247-903-00	CARBON	1M 5% 1/6W
		SWITCH	
S1	1-554-364-00	SWITCH, SLIDE	
S2	1-553-977-00	SWITCH, SLIDE	
S3	1-554-663-00	SWITCH, SLIDE	
S4	1-553-977-31	SWITCH, SLIDE	
		CRYSTAL	
X1	1-527-476-41	OSCILLATOR, CERAMIC	

	*1-614-843-11	B-200 BOARD	
