

SLV-495/495PX/675HF/675HFPX/676HF/685HF/695HF/L40CS/L40MX/L40PA/L50CS/L50MX/
L50PA/L60HFCS/L60HFMX/L60HFPA/L70HFCS/L70HFMX/L70HFPA/X5MX/X6HFMX
RMT-V198C/V201A/V202A/V203/V203A/V203B

SERVICE MANUAL

US Model

SLV-495/675HF/676HF/685HF/695HF

Canadian Model

SLV-495/675HF/695HF

Mexican Model

SLV-L40MX/L50MX/L60HFMX/
L70HFMX/X5MX/X6HFMX

Panamanian Model

SLV-L40PA/L50PA/L60HFPA/L70HFPA

Chilean Model

SLV-L40CS/L50CS/L60HFCS/L70HFCS

PX Model

SLV-495PX/675HFPX



Photo : SLV-675HF

VHS

H MECHANISM

- Refer to the **SERVICE MANUAL of VHS MECHANICAL ADJUSTMENTS IV** for **MECHANICAL ADJUSTMENTS.**
(9-973-623-11)

SPECIFICATIONS

System

- Format
 - VHS NTSC standard
- Video recording system
 - Rotary head helical scanning FM system
- Video heads
 - Double azimuth four heads
- Video signal
 - NTSC color, EIA standards
- Tape speed
 - SP: 33.35 mm/s (1 3/8 inches/s)
 - EP: 11.11 mm/s (7/16 inches/s)
 - LP: 16.67 mm/s (11/16 inches/s), playback only
- Maximum recording/playback time
 - 8 hrs. in EP mode (with T-160 tape)
- Fast-forward and rewind time
 - Approx. 3 min. (with T-120 tape)

Tuner section

- Channel coverage
 - VHF 2 to 13
 - UHF 14 to 69
 - CATV A-8 to A-1, A to W, W+1 to W+84
- Antenna
 - 75-ohm antenna terminal for VHF/UHF

Inputs and outputs

- LINE IN
 - VIDEO IN, phono jack
 - Input signal: 1 Vp-p, 75 ohms, unbalanced, sync negative
 - AUDIO IN, phono jack
 - Input level: 327 mVrms
 - Input impedance: more than 47 kilohms
- LINE OUT
 - VIDEO OUT, phono jack
 - Output signal: 1 Vp-p, 75 ohms, unbalanced, sync negative
 - AUDIO OUT, phono jack
 - Standard output: 327 mVrms
 - Load impedance: 47 kilohms
 - Output impedance: less than 10 kilohms

Timer section

- Clock
 - Quartz locked
- Timer indication
 - 12-hour cycle
- Timer setting
 - 8 programs per month (max.)
- Power back-up
 - Built-in self-charging capacitor
 - Back-up duration: up to 1 hour at a time

General

- Power requirements
 - See next page.
- Power consumption
 - See next page.
- Operating temperature
 - 5°C to 40°C (41°F to 104°F)
- Storage temperature
 - 20°C to 60°C (-4°F to 140°F)
- Dimensions
 - Approx. 355 × 102 × 280 mm (w/h/d)
 - (Approx. 14 × 4 1/8 × 11 1/8 inches) including projecting parts and controls
- Mass
 - Approx. 4.0 kg (8 lb 13 oz)
- Supplied accessories
 - Remote commander (1)
 - Size AA (R6) batteries (2)
 - 75-ohm coaxial cable with F-type connectors (1)
 - Audio/video cable (3 phono to 3 phono) (1) (HiFi model)
 - Plug adaptor (1) (Chilean, PX models)

Design and specifications are subject to change without notice.

VIDEO CASSETTE RECORDER

SONY®



992162811

• DIFFERENT SPECIFICATIONS LIST

SPECIFICATION \ MODEL	SLV-495	SLV-495PX	SLV-675HF	SLV-676HF	SLV-675HFPX	SLV-685HF	SLV-695HF
AUDIO SYSTEM	MONAURAL		HI-FI-STEREO			HI-FI-STEREO	
TUNER AUDIO (STEREO) SYSTEM	—		SAP			SAP	
VCR+ SYSTEM	BUILT-IN		—			BUILT-IN	
LINE 2 INPUT	BUILT-IN		—			BUILT-IN	
BODY COLOR	BLACK		BLACK	GRAY	BLACK	BLACK	
DUAL MODE SHUTTLE	—		—			—	
POWER REQUIREMENTS	120V AC 60Hz	110-240V AC 50/60Hz	120V AC 60Hz		110-240V AC 50/60Hz	120V AC 60Hz	
POWER CONSUMPTION	23W		24W			* 24W	
REMOTE COMMANDER	RMT-V203A		RMT-V203			RMT-V203A	RMT-V202A

SPECIFICATION \ MODEL	SLV-L40CS	SLV-L40MX	SLV-L40PA	SLV-L60CS	SLV-L50MX	SLV-L50PA	SLV-X5MX
AUDIO SYSTEM	MONAURAL			MONAURAL			
TUNER AUDIO (STEREO) SYSTEM	—			—			
VCR+ SYSTEM	—			—			
LINE 2 INPUT	—			BUILT-IN			
BODY COLOR	BLACK			BLACK			GRAY
DUAL MODE SHUTTLE	—			BUILT-IN			
POWER REQUIREMENTS	110-240V AC 50/60Hz	120V AC 60Hz		110-240V AC 50/60Hz	120V AC 60Hz		
POWER CONSUMPTION	18W			18W			
REMOTE COMMANDER	RMT-V198C			RMT-V201A			

SPECIFICATION \ MODEL	SLV-L60HFCS	SLV-L60HFMX	SLV-L60HFPA	SLV-X6HFMX	SLV-L70HFCS	SLV-L70HFMX	SLV-L70HFPA
AUDIO SYSTEM	HI-FI-STEREO			HI-FI-STEREO			
TUNER AUDIO (STEREO) SYSTEM	SAP			SAP			
VCR+ SYSTEM	—			—			
LINE 2 INPUT	—			BUILT-IN			
BODY COLOR	BLACK		GRAY		BLACK		
DUAL MODE SHUTTLE	—			BUILT-IN			
POWER REQUIREMENTS	110-240V AC 50/60Hz	120V AC 60Hz		110-240V AC 50/60Hz	120V AC 60Hz		
POWER CONSUMPTION	19W			19W			
REMOTE COMMANDER	RMT-V203B			RMT-V201A			

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK Δ OR DOTTED LINE WITH MARK Δ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE Δ SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer.

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
5. Check the line cord for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
6. Check the B+ voltage to see it is at the values specified.
7. Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA TW-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75V, so analog meters must have an accurate low voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)




Fig. A. Using an AC voltmeter to check AC leakage.

TABLE OF CONTENTS

SERVICE NOTE

1. HOW TO RETURN THE PINCH ROLLER, GUIDE ROLLER AND ELEVATOR CAM TO STOP MODE 6
2. HOW TO RETURN A TAPE INTO CASSETTE HALF 6
3. HOW TO REMOVE A CASSETTE FROM A MACHINE IF A CASSETTE IS LEFT IN A MACHINE IN TROUBLE 6
4. HOW TO REMOVE DRUM ASSEMBLY 6
5. HOW TO REPLACE A ROTARY UPPER DRUM (SLV-675HF/676HF/675HFPX/685HF/695HF/L60HFCS/L60HFMX/L60HFPA/X6HFMX/L70HFCS/L70HFMX/L70HFPA) 7
- 5-1. HOW TO REMOVE A ROTARY UPPER DRUM 7
- 5-2. HOW TO ATTACH A NEW ROTARY UPPER DRUM ... 7

1. GENERAL

Getting Started

- Unpacking 1-1
- Setting up the remote commander 1-1
- Hookups 1-1
- Selecting a language 1-4
- Setting the clock 1-4
- Pre-etting channels 1-4

Basic Operations

- Playing a tape 1-5
- Recording TV programs 1-6
- Recording TV programs using the timer 1-7

Additional Operations

- Playing/searching at various speeds 1-7
- Recording TV programs using the quick timer 1-8
- Checking/chaging/canceling timer settings 1-8
- Recording stereo and bilingual programs 1-8
- Adjusting the picture 1-9
- Changing menu options 1-9
- Editing with another VCR 1-9
- General setup information 1-10
- Index to parts and controls 1-10

2. DISASSEMBLY

- 2-1. CASE AND FRONT PANEL ASSEMBLY 2-1
- 2-2. POWER BLOCK 2-1
- 2-3. MA-289 BOARD WITH MECHANISM DECK ASSEMBLY 2-2
- 2-4. MECHANISM DECK ASSEMBLY 2-3
- 2-5. CIRCUIT BOARDS LOCATION 2-3

3. BLOCK DIAGRAMS

- 3-1. OVERALL BLOCK DIAGRAM 3-1
- 3-2. VIDEO BLOCK DIAGRAM 3-3
- 3-3. SERVO, SYSTEM CONTROL BLOCK DIAGRAM 3-5
- 3-4. AUDIO BLOCK DIAGRAM 3-7
- 3-5. TUNER BLOCK DIAGRAM 3-9
- 3-6. POWER SUPPLY BLOCK DIAGRAM 3-11

4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

- 4-1. FRAME SCHEMATIC DIAGRAM 4-1
 - MA-289 (MAIN) PRINTED WIRING BOARD 4-6
 - MA-289 (REC/PB AMP) SCHEMATIC DIAGRAM 4-8
 - MA-289 (VIDEO, TUNER, AUDIO), JK-151(LINE IN 2) PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM 4-11

- MA-289 (SERVO, SYSTEM CONTROL), DS-75 (OPERATON SWITCHES) PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM 4-16
- MA-289 (POWER SUPPLY) SCHEMATIC DIAGRAM 4-21
- POWER BLOCK SR701 (SWITCHING REGULATOR) PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM 4-23
- POWER BLOCK HS-821SF (SWITCHING REGULATOR) PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM 4-25

5. REPAIR PARTS LIST

- 5-1. EXPLODED VIEWS 5-1
 - 5-1-1. FRONT PANEL ASSEMBLY AND CASE 5-1
 - 5-1-2. CHASSIS ASSEMBLY 5-2
 - 5-1-3. MECHANISM DECK ASSEMBLY-1 5-3
 - 5-1-4. MECHANISM DECK ASSEMBLY-2 5-4
 - 5-1-5. MECHANISM DECK ASSEMBLY-3 5-5
 - 5-1-6. MECHANISM DECK ASSEMBLY-4 5-6
- 5-2. ELECTRICAL PARTS LIST 5-7

6. INTERFACE, IC PIN FUNCTION DESCRIPTION

- 6-1. SYSTEM CONTROL — MECHANISM BLOCK INTERFACE (MA-289 board IC160) 6-1
- 6-2. SYSTEM CONTROL — SERVO PERIPHERAL CIRCUIT INTERFACE (MA-289 board IC160) 6-1
- 6-3. SYSTEM CONTROL — SYSTEM CONTROL PERIPHERAL CIRCUIT INTERFACE (MA-289 board IC160) 6-2
- 6-4. SYSTEM CONTROL AND RF MODULATOR — INPUT SELECTION BLOCK INTERFACE (MA-289 board IC501) 6-2
- 6-5. SYSTEM CONTROL — VIDEO/RP BLOCK INTERFACE (MA-289 board IC160) 6-2
- 6-6. SYSTEM CONTROL — AUDIO BLOCK INTERFACE (MA-289 board IC160) 6-2
- 6-7. SERVO/SYSTEM CONTROL MICROPROCESSOR (MA-289 board IC160) 6-3

7. ADJUSTMENTS

- 7-1. MECHANICAL ADJUSTMENTS 7-1
- 7-2. ELECTRICAL ADJUSTMENTS 7-1
- 2-1. PREPARATION BEFORE ADJUSTMENT 7-1
 - 2-1-1. Equipment Required 7-1
 - 2-1-2. Equipment Connection 7-1
 - 2-1-3. Input Signal Check 7-1
 - 2-1-4. Alignment Tape 7-1
 - 2-1-5. Input/Output Levels and Impedance 7-2
 - 2-1-6. Adjustment Sequence 7-2
- 2-2. POWER SUPPLY CHECK 7-2
 - 2-2-1. Output Voltage Check (MA-289 Board) 7-2
- 2-3. SERVO SYSTEM CHECK 7-3
 - 2-3-1. RF Switching Position Adjustment (MA-289 Board) 7-3
- 2-4. VIDEO SYSTEM CHECKS 7-3
 - 2-4-1. X'tal OSC Check (MA-289 Board) 7-3
 - 2-4-2. SYNC AGC Check (MA-289 Board) 7-4
 - 2-4-3. White Clip/Dark Clip Check (MA-289 Board) 7-4
 - 2-4-4. Recording Y Level Check (MA-289 Board) 7-4
 - 2-4-5. Recording Chroma Level Check (MA-289 Board) 7-4

2-4-6. Playback Level Check (MA-289 Board)	7-5
2-5. AUDIO SYSTEM ADJUSTMENT	7-5
2-5-1. AF Switching Position Adjustment (MA-289 Board)	7-5
2-5-2. ACE Head Adjustment	7-6
2-5-3. E-E Output Level Check	7-6
2-5-4. Overall Output Level and Distortion Factor Check	7-6
2-5-5. Overall Noise Level Check	7-6
2-6. TUNER SYSTEM ADJUSTMENT	7-6
2-6-1. Separation Adjustrment (MA-289 Board)	7-6
2-7. ADJUSTMENT PARTS LOCATION DIAGRAM	7-8

SERVICE NOTE

1. HOW TO RETURN THE PINCH ROLLER, GUIDE ROLLER AND ELEVATOR CAM TO STOP MODE

- 1) Remove the VHS MD assembly from the machine. (Refer to section 2-4. Removal.)
- 2) Rotate the worm gear-1 of the cam motor beneath the MD assembly in the direction arrow (A) using a screw driver tip.




Fig. 1

2. HOW TO RETURN A TAPE INTO CASSETTE HALF

A tape can be rewound into a cassette half by rotating the flywheel-1 of the capstan motor in the direction of (A) with hand.




Fig. 2

3. HOW TO REMOVE A CASSETTE FROM A MACHINE IF A CASSETTE IS LEFT IN A MACHINE IN TROUBLE

Execute the section 2, and keep rotating the flywheel-1.

When executing section 1 to 3, take care that a tape slack should not be caught by a mechanism or a tape should not be damaged.

4. HOW TO REMOVE DRUM ASSEMBLY




Illustration : SLV-675HF/676HF/675HFPX/685HF/695HF/
L60HFCS/L60HFMX/L60HFPA/X6HFMX/L70HFCS/
L70HFMX/L70HFPA

Fig. 3

5. HOW TO REPLACE A ROTARY UPPER DRUM (SLV-675HF/676HF/675HFPX/685HF/695HF/L60HFCS/L60HFMX/L60HFPA/X6HFMX/L70HFCS/L70HFMX/L70HFPA)

5-1. HOW TO REMOVE A ROTARY UPPER DRUM

- 1) Remove screw ① (+P3×8) and remove the ground shaft assembly ②. (Refer to Fig. 4.)
- 2) Remove soldering which is marked by arrow and remove the rotary upper drum board completely.
- 3) Remove two screws ③ (PSW3×8) and remove the rotary upper drum in the direction of ④. (Refer to Fig. 5.)
If removal is difficult, remove it while rotating it slowly.

Note: If removal is difficult, check again if soldering is removed completely.




Fig. 4

5-2. HOW TO ATTACH A NEW ROTARY UPPER DRUM

- 1) Pay attention so that finger print or like must not be put when inserting a new upper drum into lower drum.
- 2) Align ⇒ mark of the rotary upper drum board with the ⇒ mark of the rotary transformer board so that the screw hole on the upper drum and that on the lower drum are aligned. (Refer to Fig. 5.)
- 3) If attaching is difficult, attach a upper drum while rotating it slowly.

Note: Pay attention not to damage the video heads.
Confirm that the upper drum is inserted completely.

- 4) Tighten the two screws ③ (PSW3×8). (Refer to Fig. 5.)
- 5) Fix the earth shaft ② by tightening the screw ① (+P3×8) so that protrusion at the tip of the earth shaft contacts the center of the drum shaft.

Note: When attaching the ground shaft assembly ②, never give force to the plate spring ④.




Fig. 5

**SLV-495/495PX/675HF/675HFPX/676HF/685HF/695HF/L40CS/L40MX/L40PA/L50CS/L50MX/
L50PA/L60HFCS/L60HFMX/L60HFPA/L70HFCS/L70HFMX/L70HFPA/X5MX/X6HFMX**






SECTION 1
GENERAL

This section is extracted from the SLV-675HF/675HFPX/676HF instruction manual.

Getting Started

Step 1
Unpacking

Check that you have received the following items with the VCR

- Remote commander 
- Size AA (R6) batteries 
- Audio/video cable (3-phono to 3-phono) 
- 75-ohm coaxial cable with F-type connectors 
- Plug adaptor (SLV-675HF PX) 
- If the plug supplied with your VCR does not fit your power outlet, attach the supplied adaptor to the plug

Step 2
Setting up the remote commander


Inserting the batteries

Insert two size AA (R6) batteries by matching the + and - on the batteries to the diagram inside the battery compartment



Using the remote commander

You can use this remote commander to operate this VCR and a Sony TV. Buttons on the remote commander marked with a dot (•) can be used to operate your Sony TV.



To operate the VCR	Set TV/VTR to VTR and point at the remote sensor on the VCR
a Sony TV	TV and point at the remote sensor on the TV

- Notes
- With normal use, the batteries should last about three to six months.
 - If you do not use the remote commander for an extended period of time, remove the batteries to avoid possible damage from battery leakage
 - Do not use a new battery with an old one.
 - Do not use different types of batteries

continued

Step 2: Setting up the remote commander (continued)

Controlling other TVs with the remote commander

The remote commander is preprogrammed to control non-Sony TVs. If your TV is listed in the table below, set the appropriate manufacturer's code number.

- 1 Set **TV/VTR** at the top of the remote commander to **TV**.
- 2 Hold down **POWER**, and enter your TV's code number(s) using the number buttons. Then release **POWER**.

Now you can use the **POWER**, **VOL +/-**, **CH +/-** and **TV/VTR** buttons to control your TV. You can also use the buttons marked with a dot (•) to control a Sony TV. To control the VCR, reset **TV/VTR** to **VTR**.

Code numbers of controllable TVs

If more than one code number is listed, try entering them one at a time until you find the one that works with your TV.

Manufacturer	Code number	Manufacturer	Code number	Manufacturer	Code number
Sony	01	JVC	09	RCA	04,10
Alto	04	KMC	03	Sampo	12
AOC	04	Magnavox	03,06,12	Sanyo	11
Centron	12	Mamont	04,13	Scott	12
Coronado	03	MGA/Mitsubishi	04,12,13,17	Saars	07,10,11
Curta-Mathes	12	NBC	04,12	Sharp	03,06,16
Daytron	12	Panasonic	06,19	Sylvania	08,12
Emerson	03,04,14	Phico	03,04	Telovika	03,06,14
Fisher	11	Philips	08	Yoshida	07
General Electric	06,10	Pioneer	16	Wards	03,04,12
Gold Star	03,04,17	Portland	03	Yors	12
Hitachi	02,03	Quasar	06,18	Zenith	15
J.C. Penney	04,12	Radio Shack	06,14		

- Notes
- If the TV uses a different remote control system from the one programmed to work with the VCR, you cannot control your TV with the remote commander
 - If you enter a new code number, the code number previously entered will be erased
 - When you replace the batteries of the remote commander, the code number automatically resets to 01 (Sony). Reset the appropriate code number

Step 3
Hookups

Selecting the best hookup option

There are many ways in which your VCR can be hooked up. To hook up your VCR so that it works best for you, first scan through the table below. Then use the accompanying diagrams and procedures on the following pages to set up your VCR.

If you have	Use	Refer to
TV that has audio/video input	Audio/video (A/V) hookup, then follow one of the hookups below.	Page 8
Antenna only, no cable TV	Hookup 1	Pages 9 and 10
Cable box with many scrambled channels	Hookup 2	Pages 11 and 12
No cable box or cable box with only a few scrambled channels	Hookup 3	Pages 13 and 14
Cable box with only a few scrambled channels, using an A/B switch	Hookup 4	Pages 15 and 16

After you've completed the connections, follow the instructions for setup. During setup, if you need more details on the procedure described, page numbers are provided where you can find complete, step-by-step instructions.

After you've completed the setup, you're ready to use your VCR. Procedures differ depending on the hookup you used. For an overview, refer to "Quick reference to using the VCR" on the back cover.

Before you get started

- Turn off the power to all equipment.
- Do not connect the AC power cords until all of the connections are completed.
- Be sure you make connections firmly. Loose connections may cause picture distortion.
- If your TV doesn't match any of the examples provided, see your nearest Sony dealer or qualified technician.

Caution

Connections between the VCR's VHF/UHF connector and the antenna terminals of the TV receiver should be made only as shown in the following instructions. Failure to do so may result in operation that violates the regulations of the Federal Communications Commission regarding the use and operation of RF devices. Never connect the output of the VCR to an antenna or make simultaneous (parallel) antenna and VCR connections at the antenna terminals of your receiver.


Audio/video (A/V) hookup

Page 8

If your TV has audio/video (A/V) input jacks, you will get a better picture and sound if you hook up your VCR using these connections. In addition, for a true "home theater" experience, you should connect the audio outputs of your VCR or TV to your stereo system. If your TV doesn't have A/V inputs, see the following pages for antenna or cable hookups.


If you're not planning to use your VCR to record programs, you're finished setting up the VCR after you've made the connections shown on this page. If you want to record off-air or off your cable TV system, complete these connections first, and then go to the following pages for antenna or cable hookups.

A Use this hookup if your TV has stereo jacks



Audio/video cable (supplied)

B Use this hookup if your TV doesn't have stereo jacks



Video cable (not supplied)

Audio cable (not supplied)

Note

To play a tape in stereo, you must use the A/V connection.

Note to CATV system installer (in USA)

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

Hookup 1


Pages 9 and 10

Antenna hookup

Make the following connections if you're using an antenna (if you don't have cable TV)


A Use this hookup if you're using:

- VHF/UHF antenna (you get channels 2-13 and channels 14 and higher)
- UHF-only antenna (you get channels 14 and higher)
- Separate VHF and UHF antennas



Match the type of connector on your TV: A, B, or C

B Use this hookup if you're using a VHF-only antenna (you get channels 2-13 only)



Match the type of connector on your TV: A, B, or C. For connector types B and C, no UHF connection is required.

If you cannot connect your antenna cable to the VCR directly

If your antenna cable is a flat cable (300-ohm twin lead cable), attach an external antenna connector (not supplied) so you can connect the cable to the VHF/UHF IN connector. If you have separate cables for VHF and UHF antennas, you should use a U/V band mixer (not supplied). For details, see page 41.


Getting Started

Step 3: Hookups (continued)

Hookup 1: VCR setup

1 Set the RF UNIT switch to CH 3 or CH 4, whichever channel is not used in your area. If both are used, set the switch to either channel.

For details, see page 40. If you made A/V connections (page 8), you can skip this step.







2 Press EASY SET UP on the VCR.

• The LANGUAGE menu appears. Change the on-screen display language to Spanish (ESPAÑOL) or French (FRANÇAIS) if desired, and press EXECUTE. For details, see page 17.

• The CLOCK SET menu appears. Set the clock and press EXECUTE. For details, see page 18.

• The TUNER PRESET menu appears. Set ANTENNA/CABLE to ANT and press EXECUTE. For details, see page 19.

• The AUTO PRESET starts.



Hookup 2

Pages 11 and 12

Cable box with many scrambled channels

Recommended use


Use this hookup if your cable system scrambles all or most channels.

What you can do with this hookup

- Record any channel by selecting the channel on the cable box.

What you can't do

- Record one channel while watching another channel.



Match the type of connector on your TV: A, B, or C.

For connector types B and C, no UHF connection is required.


Getting Started

continued


Step 3: Hookups (continued)

Hookup 2: VCR setup

- 1 Set the RF UNIT switch to CH 3 or CH 4, whichever channel is not used in your area. If both are used, set the switch to either channel. For details, see page 40. If you made A/V connections (page 8), you can skip this step.
- 2 Turn on your cable box.
- 3 Press EASY SET UP on the VCR.



- The LANGUAGE menu appears. Change the on-screen display language to Spanish (ESPAÑOL) or French (FRANÇAIS) if desired, and press EXECUTE. For details, see page 17.
- The CLOCK SET menu appears. Set the clock and press EXECUTE. For details, see page 18.
- The TUNER PRESET menu appears. Set ANTENNA/CABLE to ANT and press EXECUTE. For details, see page 19.
- The AUTO PRESET starts.



Normal display

Hookup 3

Pages 13 and 14


No cable box, or cable box with only a few scrambled channels

Recommended use

Use this hookup if you do not have a cable box. Also use this hookup if your cable system scrambles only a few channels.

What you can do with this hookup

- Record any unscrambled channel by selecting the channel on the VCR.
- What you can't do
 - Record scrambled channels that require a cable box.



Connect this cable directly to your TV if you don't have a cable box.


continued

Getting Started


Step 3: Hookups (continued)

Hookup 3: VCR setup

- 1 Set the RF UNIT switch to CH 3 or CH 4, whichever channel is not used in your area. If both are used, set the switch to either channel. For details, see page 40. If you made A/V connections (page 8), you can skip this step.
- 2 Turn on your cable box.
- 3 Press EASY SET UP on the VCR.



- The LANGUAGE menu appears. Change the on-screen display language to Spanish (ESPAÑOL) or French (FRANÇAIS) if desired, and press EXECUTE. For details, see page 17.
- The CLOCK SET menu appears. Set the clock and press EXECUTE. For details, see page 18.
- The TUNER PRESET menu appears. Set ANTENNA/CABLE to CABLE and press EXECUTE. For details, see page 19.
- The AUTO PRESET starts.



Normal display

Hookup 4

Pages 15 and 16


Cable box with only a few scrambled channels, using an A/B switch

Recommended use

By using an A/B switch (not supplied), this hookup allows you to record both scrambled and unscrambled channels conveniently.

What you can do with this hookup

- Record any unscrambled channel by selecting the channel directly on the VCR (the A/B switch is set to A).
- Record any scrambled channel by selecting the channel on the cable box (the A/B switch is set to B).
- What you can't do
 - Record one scrambled channel while watching another channel (the A/B switch is set to B).



Match the type of connector on your TV A, B, or C. For connector types B and C, no UHF connection is required.

continued

Getting Started

Step 3: Hookups (continued)

Hookup 4: VCR setup

- 1 Set the RF UNIT switch to CH 3 or CH 4, whichever channel is not used in your area. If both are used, set the switch to either channel.

For details, see page 40. If you made A/V connections (page 8), you can skip this step.



- 2 Set the A/B switch to "A"
- 3 Press EASY SET UP on the VCR.

- 1 The LANGUAGE menu appears. Change the on-screen display language to Spanish (ESPAÑOL) or French (FRANÇAIS) if desired, and press EXECUTE. For details, see page 17.

- 2 The CLOCK SET menu appears. Set the clock and press EXECUTE. For details, see page 18.

- 3 The TUNER PRESET menu appears. Set ANTENNA/CABLE to CABLE and press EXECUTE. For details, see page 19.

- 4 The AUTO PRESET starts.




- 4 Preset the cable box output channel (usually 2, 3 or 4). For details, see page 21.

- 1 Press MENU and select TUNER PRESET.
- 2 Enter the cable box output channel.
- 3 Set MANUAL SET to ADD and press EXECUTE.

Selecting a language

You can change the on-screen display language.




Getting Started

- 1 Press MENU, then press CURSOR \uparrow/\downarrow to move the cursor (P) to LANGUAGE and press EXECUTE.

When using the EASY SET UP procedure, skip this step.

- 2 Press CURSOR \uparrow/\downarrow to select ENGLISH, ESPAÑOL, or FRANÇAIS, then press EXECUTE.




Setting the clock

Set the time and date to use the tuner feature for recording programs.

Before you start...

- Turn on the VCR and the TV.
- Set the TV to the VCR channel (channel 3 or 4). If your TV is connected to the VCR using A/V connections, set the TV to video input.
- Press TV/VTR to display the VTR indicator in the VCR's display window.



- 1 Press MENU, then press CURSOR \uparrow/\downarrow to move the cursor (P) to CLOCK SET and press EXECUTE.



When using the EASY SET UP procedure, skip this step.

- 2 Press CURSOR \uparrow/\downarrow to set the month.

- 3 Press CURSOR \rightarrow/\leftarrow to flash the day and press CURSOR \uparrow/\downarrow to set the day. The day of the week is set automatically.

- 4 Set the year, hour and minutes in the same way as the day.

- 5 Press EXECUTE to start the clock.




Presetting channels

This VCR is capable of receiving VHF channels 2 to 13, UHF channels 14 to 69 and unscrambled CATV channels 1 to 125. First, we recommend that you preset the receivable channels in your area using automatic presetting. Then, if there are any unwanted channels, disable them manually. If you have decided which channels you wish to preset, set them directly using manual presetting.

Before you start...

- Turn on the VCR and the TV.
- Set the TV to the VCR channel (channel 3 or 4). If your TV is connected to the VCR using A/V connections, set the TV to video input.
- Press TV/VTR to display the VTR indicator in the VCR's display window.




Getting Started

Presetting all receivable channels automatically

- 1 Press MENU, then press CURSOR \uparrow/\downarrow to move the cursor (P) to TUNER PRESET and press EXECUTE.

When using the EASY SET UP procedure, skip this step.

- 2 Press CURSOR \uparrow/\downarrow to select ANTENNA/CABLE.



continued

Presetting channels (continued)

3

- To preset cable TV channels
Press CURSOR \leftarrow/\rightarrow to set ANTENNA/CABLE to CABLE

4

- To preset VHF and UHF channels
Press CURSOR \leftarrow/\rightarrow to set ANTENNA/CABLE to ANT

4

- Press CURSOR \uparrow/\downarrow to select AUTO PRESET, then press EXECUTE
- All receivable channels are preset in numerical sequence. When no more receivable channels can be found, presetting stops and the picture from the lowest numbered channel is displayed on the TV screen

Presetting/disabling channels manually

1

- Press MENU and select TUNER PRESET, then press EXECUTE

2

- To preset a channel
1 Press the number buttons to enter the channel number, then press ENTER
2 Press CURSOR \leftarrow/\rightarrow to set MANUAL SET to ADD
- To disable a channel
1 Press CH +/- to select the channel number
2 Press CURSOR \leftarrow/\rightarrow to set MANUAL SET to ERASE

3

- Repeat step 2 to preset or disable channels as required, then press EXECUTE

Presetting channels (continued)

If the picture is not clear

Normally, the Auto Fine Tuning (AFT) function automatically tunes in channels clearly. If, however, the picture of a channel is not clear, you can also use the manual tuning function.

1

- Press MENU and select TUNER PRESET, then press EXECUTE

2

- Press the number buttons to select the channel you want to fine-tune, then press ENTER

3

- Press CURSOR \uparrow/\downarrow to select FINE TUNING
The fine tuning meter appears

4

- Press CURSOR \leftarrow/\rightarrow to adjust to a clearer picture, then press EXECUTE
Note that the AFT setting switches to OFF

Basic Operations

Playing a tape

1


- Turn on your TV and set it to the video channel

2

- Insert a tape
The VCR turns on and starts playing automatically if you insert a tape with its safety tab removed

continued

Playing the tape (continued)


- 3  Press \blacktriangleright PLAY
When the tape reaches the end, it will rewind automatically

Additional tasks

To	Press
Stop play	\blacksquare STOP
Pause play	II PAUSE
Resume play after pause	II PAUSE or \blacktriangleright PLAY
Search forward	\blacktriangleright FF or SEARCH during playback
Search backward	\blacktriangleleft REW or SEARCH during playback
Fast-forward the tape	\blacktriangleright FF during stop
Rewind the tape	\blacktriangleleft REW during stop
Eject the tape	EJECT

To use the time counter

At the point on the tape that you want to find later, press COUNTER RESET. The counter in the display window resets to "00:00:00". Search for the point afterwards by referring to the counter.




To display the counter on the TV screen, press DISPLAY.

Notes

- Tapes recorded in the LP mode on other VCRs can be played back on this VCR but the picture quality cannot be guaranteed.
- The counter resets to "00:00:00" whenever a tape is reinserted.
- The counter stops counting when it comes to a portion with no recording.

Recording TV programs





Basic Operations


- 1 Turn on your TV and set it to the video channel.
To record from a cable box, turn it on.
- 2 Insert a tape with its safety tab in place.


continued


Recording TV programs (continued)


- 3  Press INPUT SELECT until a channel number appears in the display window.



- 4  Press CH +/- to select the channel you want to record.



- 5  Press TAPE SPEED to select the tape speed, SP or EP. EP provides recording time three times as long as SP; however, SP produces better picture and audio quality.




- 6  Press \bullet REC to start recording.

To stop recording

Press \blacksquare STOP.

To check the remaining tape length

Press DISPLAY. The white bar indicates the approximate length of tape remaining. The remaining time indicator also appears in the display window.



To check the remaining time of a T-140, T-180 or longer tape, set TAPE SELECT in the ADVANCED OPTIONS menu to "180" (For details, see page 37.)

To watch another TV program while recording

- 1 Press TV/VTR to turn off the VTR indicator in the display window.
- 2 If the TV is connected to the VCR's LINE OUT jacks, set the TV to TV input; if not, skip this step.
- 3 Select another channel on the TV.

To save a recording

To prevent accidental erasure, break off the safety tab as illustrated. To record on a tape again, cover the tab hole with adhesive tape.



Safety tab

Tips

- To select a channel, you can use the number buttons on the remote commander. Enter the channel number, then press ENTER.
- You can select a video source from the LINE IN jacks using INPUT SELECT.
- The display appears on the TV screen indicating information about the tape, but the information won't be recorded on the tape.
- If you don't want to watch TV while recording, you can turn off the TV. When using a cable box, make sure to leave it on.

Notes

- The remaining tape length may not be indicated accurately for short tapes such as T-20 or T-30, or tapes recorded in the LP mode.
- The display doesn't appear during still (pause) mode, search mode or slow-motion playback.
- It may take up to one minute for the VCR to calculate and display the remaining tape length after you press DISPLAY.


Basic Operations

Recording TV programs using the timer

You can preset up to eight programs at a time

Before you start ..

- Check that the VCR clock is set to the correct time
- Turn on your TV and set it to the video channel. When using a cable box, turn it on
- Insert a tape with its safety tab in place. Make sure the tape is longer than the total recording time



- Set the date, start and stop times, channel number and tape speed

 - 1 Press CURSOR → to flash each item in turn
 - 2 Press CURSOR ↑/↓ to set each item. To correct a setting, press CURSOR ← to return to that setting and reset.

To record the same program every day or the same day every week, press CURSOR ↓ while the date is flashing. For details, see "Daily/weekly recording" on this page.

To record from a source connected to the LINE IN jacks, press INPUT SELECT to display "L" in the "CH" position.
- Press CURSOR → to confirm the setting. The cursor (→) appears at the beginning of the line. To enter another setting, move the cursor to the next line and repeat step 2.
- Press EXECUTE
- Press POWER to turn off the VCR. The TIMER indicator on the VCR lights up and the VCR stands by for recording. When using a cable box, leave it on.

TIMER SET / CHECK	DATE	START	STOP	CH
DATE	---	---	---	---
START	---	---	---	---
STOP	---	---	---	---
CH	---	---	---	---

- Press MENU and select TIMER SET / CHECK, then press EXECUTE

TIMER SET / CHECK	DATE	START	STOP	CH
DATE	---	---	---	---
START	---	---	---	---
STOP	---	---	---	---
CH	---	---	---	---

To stop recording

To stop the VCR while recording, press STOP

Daily/weekly recording

In step 2 above, press CURSOR ↓ to select the recording pattern. Each time you press CURSOR ↓, the indication changes as shown below:

the current date → SU-SA → MO-SA → MO-FR → EVERY SA → . → EVERY MO → EVERY SU → 1 month later → (dates count down) → the current date

Tips

- To set the channel, you can also use the CH+/- or number buttons
- To set the tape speed, you can also use TAPE SPEED

continued

Recording TV programs using the timer (continued)

To use the VCR after setting the timer

To use the VCR before a timer recording begins, just press POWER. The TIMER indicator turns off and the VCR switches on. Remember to press POWER to reset the VCR in timer recording standby, after using the VCR.

You can also do the following tasks while the VCR is recording:

- Reset the counter
- Display tape information on the TV screen
- Check the timer settings
- Watch another TV program


To lock the VCR after setting the timer (Child Lock)

Hold down POWER on the VCR until the VCR beeps. The VCR turns off and the → indicator appears in the display window. The VCR will not work except for timer recording.

To unlock the VCR, hold down POWER on the VCR until the VCR beeps. The VCR turns on and the → indicator disappears from the display window.

Additional Operations

Playing/searching at various speeds



Playback options	Operation
Fast-forward/rewind	During stop, press FF or REW
View the picture during fast-forward or rewind	During fast-forward, keep pressing FF. During rewind, keep pressing REW
Play at high speed	During playback or pause, press SEARCH or SEARCH. To change direction, press > or <
Play in slow motion	During playback or pause, press SLOW. To change direction, press > or <
Play frame by frame	During pause, press FRAME or FRAME. Hold the button down to play one frame each second
Play in reverse	During playback, press <
Rewind and start play	During stop, press PLAY on the VCR while pressing REW on the VCR

To resume normal playback

Press PLAY

Tip


- Adjust the picture using the TRACKING +/- buttons on the VCR if
 - Streaks appear while playing in slow motion
 - The picture shakes while pausing

Notes


- The sound is muted during these operations
- Tapes recorded in the LP mode on other VCRs can be played back on this VCR but the picture quality cannot be guaranteed.
- The picture may have streaks
 - when playing at high speed in reverse
 - when playing in reverse, slow motion
 - when playing in reverse

Recording TV programs using the quick timer


After starting recording in the normal way, you can have the VCR stop recording automatically after a specified duration.



- 1 While recording, press QUICK TIMER once



- 2 Press QUICK TIMER repeatedly to set the duration. Each press advances the time in increments of 30 minutes.



The duration decreases minute by minute to 0:00, then the VCR stops recording and turns off automatically.

To extend the duration

Press QUICK TIMER repeatedly to set to the new duration.

To stop the VCR while recording

Press ■ STOP


Using the quick timer during stop mode

- 1 Press QUICK TIMER
- 2 Press CH +/- or INPUT SELECT to select the channel you want to record.
- 3 Press QUICK TIMER repeatedly to set the recording duration. The recording starts.


Checking/ changing/ canceling timer settings

Before you start ..

- Turn on your TV and set it to the video channel.



- 1 Press POWER to turn on the VCR.
- 2 Press MENU and select TIMER SET/CHECK.
 - If you want to change a setting, go on to the next step.
 - If you do not need to change the settings, press EXECUTE, then turn off the VCR to return to recording standby.




- 3 Press CURSOR ↑/↓ to select the setting you want to change or cancel.
 - To change the setting, press CURSOR ←/→ to flash the item you want to change, and press CURSOR ↑/↓ to reset it. Then, press CURSOR → repeatedly until the cursor (■) appears at the beginning of the line.
 - To cancel the setting, press TIMER CLEAR.

- 4 Press EXECUTE

If any timer settings remain, turn off the VCR to return to recording standby.

When the timer settings overlap

The program that starts first has priority and the second program starts recording only after the first program has finished. If the programs start at the same time, the program listed first in the menu has priority.



Recording stereo and bilingual programs

Recording stereo programs

This VCR automatically receives and records stereo programs. When a stereo program is received, the STEREO indicator lights up. If there is noise in the stereo program, set AUTO STEREO in the ADVANCED OPTIONS menu to OFF. The sound will be recorded in monaural (on both hi-fi and normal audio tracks) but with less noise. For details, see page 37.

Recording bilingual programs

Normally, this VCR records only the main sound. When a SAP (Second Audio Program) is received, the SAP indicator lights up. To record only SAP sound, set TUNER AUDIO in the ADVANCED OPTIONS menu to SAP. For details, see page 37.

Selecting the sound while playing

Press AUDIO MONITOR to select the desired sound. (The sound being recorded will not change.)


Stereo program

To listen to	Indicator on the TV screen
Stereo	STEREO
Left channel	L
Right channel	R
Monaural sound on the normal audio track*	No indicator appears

* Usually the mixed sound of left and right channels.

How sound is recorded on a video tape

The VCR records sound onto two separate tracks. Hi-fi audio is recorded onto the main track along with the picture. Monaural sound is recorded onto the normal audio track along the edge of the tape.





Notes

- To play a tape in stereo, you must use the A/V connections.
- When you play a tape recorded in monaural, the sound is heard in monaural regardless of the AUDIO MONITOR setting.

Adjusting the picture

Adjusting the tracking

Although the VCR automatically adjusts the tracking when playing a tape (the tracking indicator  flashes in the display window, then goes off), distortion may occur if the tape was recorded in poor condition. In this case, manually adjust the tracking.

Press the TRACKING +/- buttons on the VCR to display the tracking meter. The distortion should disappear as you press one of the two buttons (the  indicator lights up). To resume automatic tracking adjustment, eject the tape and reinsert it.



Tracking meter

About Adaptive Picture Control (APC)

Adaptive Picture Control (APC) automatically improves recording and playback quality by adjusting the VCR to the condition of the video heads and tape. To maintain better picture quality, we recommend that you set APC to ON in the ADVANCED OPTIONS menu (with the APC indicator in the display window lit).




APC playback

The APC function automatically works on all types of tapes, including rental tapes and tapes that were not recorded with APC.

APC recording

Whenever you insert a tape and first start recording, the VCR adjusts to the tape using the APC function (the APC indicator flashes rapidly). This adjustment is retained until the tape is ejected.





Notes

- The auto tracking adjustment cannot be used on tapes recorded in the LP mode on other VCRs.
- The APC function doesn't work if the tape speed is automatically changed from the SP to EP mode during a timer recording, unless the tape has been recorded in the EP mode with the APC function.
- There is a delay of a few seconds before the VCR actually starts recording while the VCR analyzes the tape. To avoid the delay, first set the VCR to recording pause (the APC indicator flashes slowly) and press  to have the VCR analyze the tape. After the APC indicator stops flashing, press  to start recording immediately. If you press  before the APC indicator stops flashing, the APC function is canceled.

Changing menu options

- Press MENU and select ADVANCED OPTIONS.

ADVANCED OPTIONS			
AUTO STEREO	ON	OFF	
TUNER AUDIO	MAIN	SAP	
APC	ON	OFF	
TAPE SELECT	AUTO	180	
AUTO TAPE SPEED	ON	OFF	
SHARPNESS	L-H		

- Press CURSOR  /  to select the option to change, then press CURSOR  /  to change the setting.
- Press EXECUTE to return to the original screen.


Menu choices

Initial settings are indicated in bold print.

Menu option	Set this option to
AUTO STEREO	ON to receive stereo programs. OFF to reduce noise, the sound changes to monaural.
TUNER AUDIO	MAIN to record the main sound, SAP to record the SAP (Second Audio Program) sound.
APC	OFF to switch on the APC (Adaptive Picture Control) function and improve picture quality. OFF to switch off APC.
TAPE SELECT	AUTO or 180 (when using a T-140, T-180 or longer tape) to select the tape length and display the remaining time correctly.
AUTO TAPE SPEED	ON to change the timer recording tape speed automatically to the EP mode when the remaining tape becomes shorter than the recording time, OFF to keep the set tape speed.
SHARPNESS	L (Low) through H (High) to adjust the sharpness of the picture. L to turn off the sharpness control.

Editing with another VCR

How to hook up to record on this VCR



How to hook up to a stereo system

Connect LINE IN AUDIO on this VCR to the audio output jacks on the stereo system, using the RK-C510KS audio cable (not supplied).


Notes




- Make sure you connect the plugs to jacks of the same color.
- If the other VCR is a monaural type, use a connecting cable such as Sem VMC-910MS.
- If you connected this VCR to both the LINE IN and LINE OUT jacks of the other VCR, select the input correctly to prevent a humming noise.

Operation (when recording on this VCR)

Before you start editing

- Turn on your TV and set it to the video channel.
- Press INPUT SELECT on the remote commander to display "L" in the display window.
- Press TAPE SPEED on the remote commander to select the tape speed, SP or EP.






- Insert a source tape with its safety tab removed into the other (playback) VCR. Search for the point to start playback and set it to playback pause.
- Insert a tape with its safety tab in place into this (recording) VCR. Search for the point to start recording and press .
- Press  on this VCR and set it to recording pause.
- To start editing, press the  buttons on both VCRs at the same time.

To stop editing

Press the  buttons on both VCRs.


Note

- If you start recording following the procedure above, the VCR won't start recording with the APC function. To record a tape with the APC function, press  again during recording pause in step 3 so that the VCR analyzes the tape. Then when you start recording in step 4, press  immediately after the APC indicator stops flashing. If you press  before the APC indicator stops flashing, the APC function is canceled.

General setup information

Setting the RF unit


When connecting the VCR to the TV using only the antenna cable, you must set the RF UNIT switch on the rear of the VCR so that the TV can receive the correct signal from the VCR.



- 1 Set the RF UNIT switch on the rear of the VCR to CH 3 or CH 4, whichever channel is not used in your area. If both are used, set the switch to either channel.
 - 2 Press POWER to turn on the VCR.
 - 3 Press TV/VTR on the remote commander to turn on the VTR indicator in the VCR's display window.
 - 4 Press CHANNEL +/- to display a channel number in the display window. Select an active channel number in your area.
 - 5 Turn on your TV and set it to the channel you selected in step 1 (channel 3 or 4).
- The selected TV channel broadcast appears on the TV screen. If the channels change when you press CHANNEL +/-, you have made the correct setting.
- Whenever you use the VCR, set the TV to the channel selected in step 1.

Attaching the external antenna connector


When using a 300-ohm twin lead cable for VHF/UHF antenna, use the EAC-32 antenna connector (not supplied) to connect the antenna to the VCR.



- 1 Loosen the screws on the antenna connector.
- 2 Wind the twin leads around the screws on the antenna connector.
- 3 Retighten the screws.

Attaching a UHF/VHF band mixer

When using both 75-ohm coaxial cable and 300-ohm twin lead cable for VHF/UHF antenna, use the EAC-66 UHF/VHF band separator/mixer (not supplied) to connect the antenna to the VCR.




- 1 Loosen the screws on the mixer.
- 2 Wind the twin leads around the screws on the mixer.
- 3 Retighten the screws.
- 4 Connect the 75-ohm coaxial cable to the mixer.

Index to parts and controls

Refer to the pages indicated in parentheses () for details.


Front panel



- | | |
|----------------------------|--|
| 1 POWER switch/indicator | 8 PAUSE button (23, 39) |
| 2 Tape compartment | 9 CHANNEL/TRACKING +/- buttons (26, 31, 36) |
| 3 <<< REW button (23, 31) | 10 EASY SET UP button (10, 12, 14, 16) |
| 4 >>> PLAY button (23, 31) | 11 Remote sensor (5) |
| 5 >>> FF button (23, 31) | 12 < EJECT button (23) |
| 6 ● REC button (26, 39) | 13 LINE-2 IN AUDIO/VIDEO jacks (SLV-495/L50/X5) |
| 7 ■ STOP button (23, 26) | 14 LINE-2 IN AUDIO L/R/VIDEO jacks (SLV-685HF/695HF/L70HF) |
| | 15 JOG button (SLV-L50/L70HF/X5) |
| | 16 CLICK JOG SHUTTLE ring (SLV-L50/L70HF/X5) |


Index to parts and controls (continued)

Display window



- | | |
|--|--|
| 1 TIMER indicator (29) | 8 APC indicator (36) |
| 2 REC (recording) indicator | 9 Time counter/clock/line/channel indicator (24, 26) |
| 3 VTR indicator (27) | 10 Tape speed indicator (26) |
| 4 < (Child Lock) indicator (30) | 11 Tape indicator |
| 5 SAP indicator (34) | 12 STEREO indicator (34) |
| 6 Remaining time indicator (26) (EXCEPT SLV-L40/L50/L60HF/L70HF/X5/X6HF) | |
| 7 < (tracking) indicator (36) | |

Rear panel




- 1 AC power cord
- 2 LINE IN or LINE-1 IN AUDIO/VIDEO jacks (Mono model)
LINE IN or LINE-1 IN AUDIO L/R/VIDEO jacks (HiFi model)
- 3 VHF/UHF IN/OUT connectors (9, 11, 13, 15)
- 4 RF UNIT switch (40)
- 5 LINE OUT AUDIO L/R/VIDEO jacks (8)
- 6 CABLE BOX CONTROL CTRL 5 OUT jack (SLV-495/685HF/695HF)

continued


Additional information | 47

Index to parts and controls (continued)

Remote commander



- 1 TV / VTR remote control switch (5)
- 2 EJECT button (23)
- 3 Menu operation buttons (17, 37)
MENU button
CURSOR $\uparrow/\downarrow/\leftarrow/\rightarrow$ buttons
EXECUTE button
- 4 COUNTER RESET button (24)
- 5 DISPLAY button (26)
- 6 TIMER CLEAR button (33)
- 7 QUICK TIMER button (32)
- 8 INPUT SELECT button (27, 29, 39)
- 9 TAPE SPEED button (26)
- 10 REC button (26, 39)
- 11 SLOW button (31)
- 12 \ll/\gg FRAME \ll/\gg buttons (31)




- 13 POWER switch (29)
- 14 AUDIO MONITOR button (34)
- 15 TV/VTR button (27)
- 16 Channel number/ENTER buttons (21, 22)
- 17 CH +/- buttons (21, 26)
- 18 VOL +/- buttons
- 19 IF PAUSE button (23)
- 20 \odot/\otimes SEARCH buttons (23, 31)
- 21 PLAY button (23, 31)
- 22 FF button (23, 31)
- 23 STOP button (23, 26)
- 24 REW button (23, 31)


SECTION 2 DISASSEMBLY

NOTE : Follow the disassembly procedure in the numerical order given.


2-1. CASE AND FRONT PANEL ASSEMBLY




2-2. POWER BLOCK




2-3. MA-289 BOARD WITH MECHANISM DECK ASSEMBLY



2-4. MECHANISM DECK ASSEMBLY




2-5. CIRCUIT BOARDS LOCATION




SECTION 3
BLOCK DIAGRAMS


3-1. OVERALL BLOCK DIAGRAM




3-3. SERVO, SYSTEM CONTROL BLOCK DIAGRAM



3-5. TUNER BLOCK DIAGRAM




3-6. POWER SUPPLY BLOCK DIAGRAM



SECTION 4

PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

4-1. FRAME SCHEMATIC DIAGRAM



THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS.
(In addition to this, the necessary note is printed in each block.)

- For printed wiring boards.
 - : Pattern from the side which enables seeing.

Caution :
 Pattern face side (Conductor Side) : Parts on the pattern face side seen from the pattern face are indicated.
 Pattern face side (Component Side) : parts on the parts face side seen from the parts face are indicated

- For schematic diagrams.
 - Caution when replacing chip parts. New parts must be attached after removal of chip. Be careful not to heat the minus side of tantalum capacitor, because it is damaged by the heat.
 - All resistor are in ohms, 1/4W unless otherwise noted. Chip resistor are 1/10W unless otherwise noted. kΩ: 1000Ω, MΩ, · 1000kΩ.
 - All capacitors are in μF unless otherwise noted. pF · μ μF. 50V or less are not indicated except for electrolytics and tantalums.
 - : panel designation
 - : internal component.
 - : B-Line *
 - : B-Line *
 - : IN/OUT direction of (+,-) B LINE *
 - Circled numbers refer to waveforms. *
 - Readings are taken with a color-bar signal input.
 - Voltage are dc between ground and measurement points *
 - Readings are taken with a digital multimeter (DC10MΩ).*
 - Voltage variations may be noted due to normal production tolerances.*


When indicating parts by reference number, please include the board name.

- * : indicated by the color red.


MA-289 (MAIN) PRINTED WIRING BOARD
— Ref. No. MA-289 Board, 1,000 Series —

MA-289 BOARD

CJ540	A-4	IC403	I-9
CN1980	A-3		
CN101	A-7	IC420	H-7
CN102	D-3	IC461	H-9
CN103	F-3	IC462	F-9
		IC501	A-2
		IC540	A-3
CN104	G-3		
CN140	H-12	IC600	G-2
CN260	A-10	IC733	G-13
CN261	A-8	IC980	A-1
CN301	A-5		
CN302	A-5		
CN341	A-11	PH100	G-5
CN401	H-1	PH101	H-8
CN423	E-12		
CN601	F-1		
		Q100	E-11
		Q101	E-2
D102	E-7	Q102	E-7
D161	H-8	Q201	B-5
D162	H-8	Q202	B-6
D301	C-7		
D302	D-8	Q208	C-5
		Q209	E-6
D361	D-11	Q210	D-6
D401	I-13	Q211	D-6
D501	B-1	Q260	A-9
D540	A-4		
D600	E-2	Q301	C-7
		Q302	C-7
D601	C-2	Q321	B-7
D602	D-2	Q361	C-12
D702	A-12	Q362	C-11
D980	A-2		
D981	A-2	Q363	C-12
		Q364	D-11
D982	A-1	Q501	B-2
		Q502	A-2
		Q600	E-2
IC131	G-1	Q601	E-2
IC160	H-10	Q602	C-1
IC201	C-6	Q681	A-4
IC202	D-6	Q731	G-13
IC260	B-9		
IC301	B-7		
IC340	A-11		
IC360	D-10		
IC361	D-9		




MA-289 BOARD (CONDUCTOR SIDE)




There are few cases that the part printed on this diagram isn't mounted in this model

VW / ZHF
IN / OUT

MA-289 (REC/PB AMP) SCHEMATIC DIAGRAM
— Ref. No. MA-289 Board, 1,000 Series —



MA-289 BOARD (1/3)




TO12/41
(SEE PAGE 4-12)


TO13/41
(SEE PAGE 4-17)

TO14/41
(SEE PAGE 4-21)



MA-289 (VIDEO, TUNER, AUDIO), JK-151(LINE IN 2) PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM
— Ref No MA-289 Board, 1,000 Series, JK-151 Board, 2,000 Series —



There are few cases that the part printed on this diagram isn't mounted in this model







MA-289 BOARD (2/3)



MA-289 (SERVO, SYSTEM CONTROL), DS-75 (OPERATION SWITCHES) PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM
— Ref. No. MA-289 Board, 1,000 Series, DS-75 Board; 1,000 Series —

• See page 4-6 for MA-289 printed wiring board.

There are few cases that the part printed on this diagram isn't mounted in this model



SIGNAL PATH


	CHROMA	Y	V/CHROMA	AUDIO SIGNAL
REC	→	→	→	→
PB	→	→	→	→

Note:
The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

MA-289 (POWER SUPPLY) SCHEMATIC DIAGRAM
— Ref No. MA-289 Board; 1,000 Series —

• See page 4-6 for MA-289 printed wiring board




POWER BLOCK SR701 (SWITCHING REGULATOR) PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM



— Ref. No. SR701 Board; 5,000 Series —

EXCEPT CHILEAN, PX MODELS

POWER BLOCK SR701 (EXCEPT CHILEAN, PX MODELS)



16



Note:
The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

CN1	1	2	3	4	5	6	7
	+35V	+13V	+13V	GND	GND	+6V	-9V

TO MA-289 BOARD
CN601


Symbol	min	typ	max
*R110	560	750	820
*R203	12K	15K	22K

POWER BLOCK HS-821SF (SWITCHING REGULATOR) PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM


— Ref No HS-821SF Board, 6.000 Series —

CHILEAN, PX MODELS

POWER BLOCK HS-821SF (CHILEAN, PX MODEL)




16



4-25

Note :
The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Note :
Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.



4-26E

SWITCHING REGULATOR
POWER BLOCK HS-821SF

**SECTION 5
REPAIR PARTS LIST**

5-1. EXPLODED VIEWS

NOTE:


- -XX, -X mean standardized parts, so they may have some differences from the original one.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (#mark) list is given in the last of this part list.

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.


Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

5-1-1. FRONT PANEL ASSEMBLY AND CASE



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
1	X-3946-580-1	PANEL ASSY, FRONT (675HF)		Δ 9	1-777-857-21	CORD, POWER(Chilean, PX)	
1	X-3946-596-1	PANEL ASSY, FRONT (L70HF)		* 10	1-664-504-11	DS-75 BOARD	
1	X-3946-748-1	PANEL ASSY, FRONT (695HF)		11	1-762-844-21	SWITCH, ROTARY (L50, L70HF, X5)	
1	X-3946-751-1	PANEL ASSY, FRONT (495)		12	3-972-782-01	BUTTON, CENTER (L50, L70HF)	
1	X-3946-754-1	PANEL ASSY, FRONT (L60HF)		12	3-972-782-51	BUTTON, CENTER (X5)	
1	X-3946-756-1	PANEL ASSY, FRONT (L50)		13	3-972-783-01	RING, JOG (L50, L70HF, X5)	
1	X-3946-758-1	PANEL ASSY, FRONT (L40)		14	X-3946-598-1	BUTTON ASSY, FUNCTION (676HF, X6HF)	
1	X-3947-032-1	PANEL ASSY, FRONT (676HF)		15	1-475-026-11	REMOTE COMMANDER(RMT-V198C)(L40)	
1	X-3947-034-1	PANEL ASSY, FRONT (X5)		15	1-475-027-21	REMOTE COMMANDER(RMT-V202A)(695HF)	
1	X-3947-036-1	PANEL ASSY, FRONT (X6HF)		15	1-475-032-11	REMOTE COMMANDER(RMT-V203)	(675HF, 676HF)
1	X-3947-069-1	PANEL ASSY, FRONT (685HF)		15	1-475-032-21	REMOTE COMMANDER(RMT-V203A)	(495, 685HF)
2	3-972-774-01	DOOR, CASSETTE (EXCEPT 676HF, X5, X6HF)		15	1-475-032-31	REMOTE COMMANDER(RMT-V203B)	(L60HF, X6HF)
2	3-972-774-21	DOOR, CASSETTE (676HF, X5, X6HF)		16	3-709-128-01	COVER, BATTERY	(EXCEPT 695HF, L40, L50, L70HF, X5)
3	3-953-432-01	SPRING (GE), FL		16	3-709-129-01	COVER, BATTERY (695HF)	
* 4	3-972-521-01	JACK, COVER (685HF, 695HF, L70HF)		16	3-709-133-01	COVER, BATTERY (L40)	
* 4	3-972-521-11	JACK, COVER (495, L50, X5)		17	1-475-031-21	REMOTE COMMANDER (RMT-V201A)	(L50, L70HF, X5)
* 5	1-664-505-11	JK-151 BOARD	(495, 685HF, 695HF, L50, L70HF, X5)	18	3-709-126-01	COVER, BATTERY (L50, L70HF, X5)	
6	4-921-277-41	SCREW (B2 6X8), TAPPING, BIND		19	3-972-783-21	RING, JOG (L50, L70HF, X5)	
7	3-710-901-11	SCREW, TAPPING		20	3-972-850-01	BUTTON, FUNCTION (L50, L70HF, X5)	
* 8	3-972-502-01	CASE, UPPER BA (EXCEPT 676HF, X5, X6HF)					
* 8	3-972-502-31	CASE, UPPER BA (676HF, X5, X6HF)					
Δ 9	1-777-851-21	CORD, POWER(US, Canadian)					
Δ 9	1-777-854-21	CORD, POWER(Mexican, Panamanian)					

5-1-2. CHASSIS ASSEMBLY




Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
* 51	3-959-381-01	BASE (L), MD		* 57	3-972-504-11	PANEL, REAR (L40)	
* 52	3-966-865-01	BASE, INDICATION TUBE		* 57	3-972-504-21	PANEL, REAR (L50, X5HF)	
* 53	3-959-388-01	BASE (L), FL		* 57	3-972-504-31	PANEL, REAR (L70HF)	
54	3-970-608-21	SUMITITE (B3), +BV		* 57	3-972-504-41	PANEL, REAR (L60HF, X6HF)	
* 55	3-959-389-01	BASE (R), FL		* 57	3-972-504-71	PANEL, REAR (685HF, 695HF)	
* 56	A-6791-105-A	MA-289B COMPLETE PCB BOARD, COMPLETE (675HF, 676HF)		* 57	3-972-504-81	PANEL, REAR (495)	
* 56	A-6791-110-A	MA-289A COMPLETE PCB BOARD, COMPLETE (685HF, 695HF)		△ 58	1-468-168-11	POWER BLOCK SR701(EXCEPT Chilean, PX)	
* 56	A-6791-124-A	MA-289C COMPLETE PCB BOARD, COMPLETE (495)		△ 58	1-468-169-11	POWER BLOCK HS-821SF (Chilean, PX)	
* 56	A-6791-125-A	MA-289D COMPLETE PCB BOARD, COMPLETE (L70HF)		* 59	3-959-383-01	BASE (R), MD	
* 56	A-6791-126-A	MA-289E COMPLETE PCB BOARD, COMPLETE (L60HF, X6HF)		* 60	3-960-273-01	SPACER, TOP END	
* 56	A-6791-127-A	MA-289F COMPLETE PCB BOARD, COMPLETE (L50, X5)		* 61	3-960-274-01	SPACER, LED	
* 56	A-6791-128-A	MA-289G COMPLETE PCB BOARD, COMPLETE (L40)		D102	8-719-048-26	DIODE GL528V1	
* 57	3-972-504-01	PANEL, REAR (675HF, 676HF)		ND420	1-517-595-11	TUBE, FLUORESCENT INDICATOR	
				Q100	8-729-025-92	PHOTO TRANSISTOR PT380F	
				Q101	8-729-025-92	PHOTO TRANSISTOR PT380F	

Note :
 The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Note :
 Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifique.

5-1-3. MECHANISM DECK ASSEMBLY-1



<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>	<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>
151	A-6759-603-A	FL BLOCK ASSY		165	1-506-485-11	PIN, CONNECTOR 6P	
152	3-958-467-01	SPRING, TENSION COIL		166	3-960-439-02	SPRING (ACE), COMPRESSION	
153	3-970-471-01	SPRING, TORSION		167	3-942-867-01	NUT, ACE HEIGHT ADJUSTMENT	
154	3-958-488-03	PLATE, LIGHT GUIDE, END SENSOR		168	3-958-491-01	BASE, ACE	
155	3-970-473-01	PLATE, LIGHT GUIDE, TOP SENSOR		169	A-6746-072-A	PRESS BLOCK ASSY, PINCH	
				170	3-958-505-01	SPRING (SOFT BRAKE T), TENSION	
157	3-958-487-01	SPRING, (ACE) TORSION COIL		171	3-958-455-01	SPRING (PINCH), TENSION	
158	1-500-144-11	HEAD, FE		172	3-958-151-01	GEAR, ELEVATOR	
159	X-3945-348-2	FEH ASSY		173	3-958-454-01	OPNER, LID	
160	3-982-298-01	BRACKET, TG7 TAPE		174	3-958-501-01	SCREW, ACE ADJUSTMENT	
161	X-3944-797-1	TG8 ASSY		175	3-958-153-01	GEAR, PRESS	
162	3-958-421-01	HOLDER, TG8		176	3-958-462-01	SPRING (RVS BRAKE), TENSION	
163	3-958-152-01	GEAR, TG8		177	X-3943-885-1	ARM ASSY, RVS BRAKE	
164	A-6736-103-A	ACE BLOCK ASSY		178	X-3943-882-1	BRAKE (T) ASSY, SOFT	

5-1-4. MECHANISM DECK ASSEMBLY-2





Illustration 675HF/676HF/685HF/695HF/L60HF/L70HF/X6HF


Ref. No.	Part No	Description	Remarks	Ref. No.	Part No	Description	Remarks
201	X-3943-899-8	GROUND ASSY, SHAFT(EXCEPT L2)		212	X-3945-444-1	ARM (T) ASSY, MAIN BRAKE	
202	2-643-205-01	SCREW		214	X-3947-255-1	ROLLER ASSY, HC	
203	8-848-576-02	UPPER DRUM ASSY DZR-45-R (M901) (675HF/676HF/685HF/695HF/L60HF/L70HF/ X6HF)		215	3-975-724-01	ARM, HC	
204	3-958-443-01	SPRING, STRETCH COIL SPRING		216	3-960-139-01	ARM, NEUTRALITY	
205	3-669-595-00	WASHER (2), STOPPER		217	3-958-535-01	SPRING, TENSION	
206	3-958-450-01	BRAKE (S), SOFT		218	3-960-138-01	ARM, PENDULUM COMPULSION	
207	3-958-390-01	SHAFT, PC BOARD		219	X-3943-902-1	TABLE, REEL (S) ASSY	
208	3-958-391-01	PLATE, LIGHT GUIDE, LED		220	X-3943-903-1	TABLE, REEL (T) ASSY	
209	3-961-441-01	SCREW (3x8)		221	8-848-666-11	LOWER DRUM ASSY DZL-51B/J-RP (M901) (675HF/676HF/685HF/695HF/L60HF/L70HF/ X6HF)	
210	X-3945-443-1	BRAKE (S) ASSY, MAIN		222	8-848-681-11	DRUM ASSY DZH-73B/Q-RP (M901) (495/L40/L50/X)	
211	3-958-517-01	SPRING, TENSION COIL		223	3-969-629-01	DRUM BASE	

5-1-5. MECHANISM DECK ASSEMBLY-3



<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>	<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>
252	3-959-840-11	RUBBER, JOINT		262	3-958-156-03	GEAR, FL DRIVING	
253	3-958-159-01	WORM		263	3-958-445-01	SPRING, TORSION COIL (CAP BRAKE)	
254	3-958-460-01	SPRING, ONE-WAY		264	X-3943-888-1	BRAKE ASSY, CAP	
255	3-958-160-01	PROPELLOR		265	X-3943-889-1	ARM ASSY, TENSION VEHICLE	
256	3-958-155-01	BEARING, CAM MOTOR		266	3-958-361-01	BELT, TIMING	
* 257	X-3943-884-1	CHASSIS ASSY, CAM MOTOR		267	3-958-448-01	WHEEL, TENSION	
258	3-958-157-02	WHEEL, WORM		* 268	3-959-763-01	RETAINER	
259	3-669-595-00	WASHER (2), STOPPER		269	3-958-163-04	SLIDER, MAIN	
260	1-762-076-11	SWITCH, ROTARY		270	3-958-162-02	GEAR, UPPER/LOWER COMMUNICATION	
261	3-958-161-07	GEAR, CAM		M903	X-3943-883-1	MOTOR ASSY, CAM	

5-1-6. MECHANISM DECK ASSEMBLY-4



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
301	A-6739-102-A	RKB BLOCK ASSY		316	3-962-960-01	GEAR (T-K), IDLER	
302	X-3943-897-1	LEVER ASSY, TRIGGER		317	3-962-959-01	GEAR (S-K), IDLER	
303	3-958-485-02	GEAR (T), LOADING		318	3-958-533-01	CLAW, S WINDING	
304	3-960-449-01	SPRING (T), TORSION COIL		319	3-958-532-01	ARM, S WINDING	
305	X-3943-891-3	LEVER (T) ASSY, LOADING		320	3-958-534-01	SPRING, TORSION	
306	3-958-476-01	GEAR (S), LOADING		321	3-966-092-01	RING, RETAINING, SLIT WASHER	
307	3-960-448-01	SPRING (S), TORSION COIL		322	X-3943-886-1	TG1 ASSY	
308	X-3943-890-2	LEVER (S) ASSY, LOADING		323	3-958-492-01	SPRING (TG1), TENSION COIL	
309	3-958-529-01	SPRING (MOMENT), TENSION		324	A-6750-325-A	T BLOCK ASSY, SHUTTLE	
310	3-959-840-11	RUBBER, JOINT		325	X-3944-378-1	ROLLER ASSY, GUIDE	
311	3-960-720-01	SCREW		326	A-6750-316-A	SHUTTLE (S) BLOCK ASSY	
312	3-960-688-01	SPRING, LEAF (T), LOADING		327	3-958-504-01	ARM, FIXED RELEASE	
313	3-960-687-01	SPRING, LEAF (S), LOADING		329	3-965-178-01	SPRING	
314	X-3945-485-4	CHASSIS ASSY, MECHANICAL		M902	1-698-409-14	MOTOR, DC (CAPSTAN)	
315	3-669-595-00	WASHER (2), STOPPER					

5-2. ELECTRICAL PARTS LIST

NOTE:

When indicating parts by reference number, please include the board name.

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- CAPACITORS:
uF: μ F

- RESISTORS
All resistors are in ohms.
METAL: metal-film resistor
METAL OXIDE: Metal Oxide-film resistor
F: nonflammable
- COILS
uH. μ H
- SEMICONDUCTORS
In each case, u: μ , for example:
uA...: μ A..., uPA..., μ PA...,
uPB..., μ PB..., uPC..., μ PC...,
uPD..., μ PD...

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
*	1-664-504-11	DS-75 BOARD (Ref.No.:1,000 Series) *****				< JACK >	
		< CONNECTOR >		CJ801	1-774-509-11	JACK, PIN 3P(LINE IN 2) (685HF,695HF,L70HF)	
				CJ801	1-774-510-11	JACK, PIN 2P(LINE IN 2)(495,L50,X5)	
CN442	1-774-471-41	CONNECTOR, FFC/FPC 5P (L50,L70HF,X5)				< CONNECTOR >	
		< DIODE >		CN801	1-506-483-21	PIN, CONNECTOR 4P (495,L50,X5)	
D441	8-719-056-06	DIODE SLR-342DC3F (L50,L70HF,X5)		CN801	1-506-484-11	PIN, CONNECTOR 5P (685H,695HF,L70HF)	
		< JUMPER RESISTOR >				< DIODE >	
JR700	1-216-296-91	CONDUCTOR, CHIP (3216)		D802	8-719-108-12	DIODE RD9.1E-W (685HF,695HF,L70HF)	
JR701	1-216-295-91	CONDUCTOR, CHIP (2012)		D801	8-719-108-12	DIODE RD9.1E-W	
JR702	1-216-296-91	CONDUCTOR, CHIP (3216)		D803	8-719-109-84	DIODE RD5.1ESB2	
JR703	1-216-296-91	CONDUCTOR, CHIP (3216)		D804	8-719-108-12	DIODE RD9.1E-W	
JR704	1-216-296-91	CONDUCTOR, CHIP (3216)				< JUMPER RESISTOR >	
JR705	1-216-296-91	CONDUCTOR, CHIP (3216)		JS801	1-216-295-91	CONDUCTOR, CHIP (2012) (495,L50,X5)	
JR706	1-216-296-91	CONDUCTOR, CHIP (3216)				< RESISTOR >	
JR707	1-216-295-91	CONDUCTOR, CHIP (2012)					
		< RESISTOR >		R801	1-216-295-91	CONDUCTOR, CHIP(2012)	
R451	1-216-053-00	METAL CHIP 1.5K 5% 1/10W		R802	1-216-295-91	CONDUCTOR, CHIP(2012)(685HF,695HF,L70HF)	
R452	1-216-053-00	METAL CHIP 1.5K 5% 1/10W		R803	1-216-022-00	METAL CHIP 75 5% 1/10W	
R454	1-216-041-00	METAL CHIP 470 5% 1/10W (L50,L70HF,X5)					
		< SWITCH >		*	A-6791-105-A	MA-289B BOARD, COMPLETE (675HF,676HF) *****	
S441	1-571-977-11	SWITCH, TACTIL(FF) (495,675HF,676HF,685HF,695HF,L40,L60HF,X6HF)		*	A-6791-110-A	MA-289A BOARD, COMPLETE (685HF,695HF) *****	
S442	1-571-977-11	SWITCH, TACTIL(PB) (495,675HF,676HF,685HF,695HF,L40,L60HF,X6HF)		*	A-6791-124-A	MA-289C BOARD, COMPLETE (495) *****	
S443	1-571-977-11	SWITCH, TACTIL(STOP) (495,675HF,676HF,685HF,695HF,L40,L60HF,X6HF)		*	A-6791-125-A	MA-289D BOARD, COMPLETE (L70HF) *****	
S444	1-571-977-11	SWITCH, TACTIL(REW) (495,675HF,676HF,685HF,695HF,L40,L60HF,X6HF)		*	A-6791-126-A	MA-289E BOARD, COMPLETE (L60HF,X6HF) *****	
S445	1-571-977-11	SWITCH, TACTIL (JOG) (L50,L70HF,X5)		*	A-6791-127-A	MA-289F BOARD, COMPLETE (L50, X5) *****	
S446	1-571-977-11	SWITCH, TACTIL (FF) (L50,L70HF,X5)		*	A-6791-128-A	MA-289G BOARD, COMPLETE (L40) *****	
S447	1-571-977-11	SWITCH, TACTIL (REW) (L50,L70HF,X5)				(Ref.No.:1,000 Series)	
*	1-664-505-11	JK-151 BOARD ***** (495,685HF,695HF,L50,L70HF,X5) (Ref.No.:2,000 Series)		*	3-960-273-01	SPACER, TOP END	
		< CAPACITOR >		*	3-960-274-01	SPACER, LED	
C803	1-163-009-11	CERAMIC CHIP 0.001uF 10% 50V		*	3-966-865-01	BASE, INDICATION TUBE	
C805	1-163-009-11	CERAMIC CHIP 0.001uF 10% 50V (685HF,695HF,L70HF)				< BUZZER >	
C806	1-163-009-11	CERAMIC CHIP 0.001uF 10% 50V		BZ160	1-529-080-11	BUZZER, PIEZOELECTRIC	
		< CAPACITOR >				< CAPACITOR >	
C102	1-163-251-11	CERAMIC CHIP 100PF 5% 50V		C102	1-163-251-11	CERAMIC CHIP 100PF 5% 50V	
C103	1-163-251-11	CERAMIC CHIP 100PF 5% 50V		C103	1-163-251-11	CERAMIC CHIP 100PF 5% 50V	
C104	1-124-261-00	ELECT 10uF 20% 50V		C104	1-124-261-00	ELECT 10uF 20% 50V	
C106	1-104-760-11	CERAMIC CHIP 0.047uF 10% 50V		C106	1-104-760-11	CERAMIC CHIP 0.047uF 10% 50V	
C111	1-163-031-11	CERAMIC CHIP 0.01uF 50V		C111	1-163-031-11	CERAMIC CHIP 0.01uF 50V	

Ref No	Part No	Description	Remarks	Ref. No.	Part No.	Description	Remarks
C112	1-163-031-11	CERAMIC CHIP	0.01uF	50V	C239	1-124-589-11	ELECT 47uF 20% 16V
C113	1-163-031-11	CERAMIC CHIP	0.01uF	50V	C240	1-126-160-11	ELECT 1uF 20% 50V
C114	1-163-031-11	CERAMIC CHIP	0.01uF	50V	C241	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V
C115	1-163-038-00	CERAMIC CHIP	0.1uF	25V	C242	1-126-160-11	ELECT 1uF 20% 50V
C118	1-124-589-11	ELECT	47uF	20% 16V	C243	1-164-232-11	CERAMIC CHIP 0.01uF 50V
C119	1-124-589-11	ELECT	47uF	20% 16V	C244	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V
C120	1-163-031-11	CERAMIC CHIP	0.01uF	50V	C245	1-163-809-11	CERAMIC CHIP 0.047uF 10% 25V
C131	1-163-031-11	CERAMIC CHIP	0.01uF	50V	C246	1-126-160-11	ELECT 1uF 20% 50V
C132	1-124-589-11	ELECT	47uF	20% 16V	C247	1-163-809-11	CERAMIC CHIP 0.047uF 10% 25V
C134	1-163-031-11	CERAMIC CHIP	0.01uF	50V	C248	1-164-232-11	CERAMIC CHIP 0.01uF 50V
C140	1-164-161-11	CERAMIC CHIP	0.0022uF	10% 100V	C249	1-124-589-11	ELECT 47uF 20% 16V
C141	1-124-234-00	ELECT	22uF	20% 16V	C250	1-163-038-00	CERAMIC CHIP 0.1uF 25V
C142	1-124-234-00	ELECT	22uF	20% 16V	C251	1-163-038-00	CERAMIC CHIP 0.1uF 25V
C144	1-163-251-11	CERAMIC CHIP	100PF	5% 50V	C252	1-164-232-11	CERAMIC CHIP 0.01uF 50V
C146	1-124-234-00	ELECT	22uF	20% 16V	C253	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V
C147	1-124-584-00	ELECT	100uF	20% 10V	C254	1-163-038-00	CERAMIC CHIP 0.1uF 25V
C148	1-163-038-00	CERAMIC CHIP	0.1uF	25V	C255	1-163-038-00	CERAMIC CHIP 0.1uF 25V
C160	1-163-038-00	CERAMIC CHIP	0.1uF	25V	C256	1-163-038-00	CERAMIC CHIP 0.1uF 25V
C161	1-124-584-00	ELECT	100uF	20% 10V	C260	1-163-229-11	CERAMIC CHIP 12PF 5% 50V
C162	1-104-905-11	CAPACITOR	0.22F	5 5V	C261	1-163-229-11	CERAMIC CHIP 12PF 5% 50V
C163	1-163-227-11	CERAMIC CHIP	10PF	0.5PF 50V	C264	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V
C164	1-163-227-11	CERAMIC CHIP	10PF	0.5PF 50V	C265	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V
C165	1-163-099-00	CERAMIC CHIP	18PF	5% 50V	C266	1-164-232-11	CERAMIC CHIP 0.01uF 50V
C166	1-163-099-00	CERAMIC CHIP	18PF	5% 50V	C267	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V
C167	1-163-125-00	CERAMIC CHIP	220PF	5% 50V	C268	1-163-241-11	CERAMIC CHIP 39PF 5% 50V
C168	1-124-261-00	ELECT	10uF	20% 50V	C269	1-163-241-11	CERAMIC CHIP 39PF 5% 50V
C170	1-124-234-00	ELECT	22uF	20% 16V	C270	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V
C171	1-163-019-00	CERAMIC CHIP	0.0068uF	10% 50V	C271	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V
C172	1-163-125-00	CERAMIC CHIP	220PF	5% 50V	C272	1-163-241-11	CERAMIC CHIP 39PF 5% 50V
C201	1-126-160-11	ELECT	1uF	20% 50V	C273	1-163-241-11	CERAMIC CHIP 39PF 5% 50V
C202	1-163-809-11	CERAMIC CHIP	0.047uF	10% 25V	C274	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V
C204	1-163-031-11	CERAMIC CHIP	0.01uF	50V	C276	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V
C205	1-163-037-11	CERAMIC CHIP	0.022uF	10% 25V	C277	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V
C206	1-164-232-11	CERAMIC CHIP	0.01uF	50V	C278	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V
C207	1-164-232-11	CERAMIC CHIP	0.01uF	50V	C279	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V
C208	1-163-241-11	CERAMIC CHIP	39PF	5% 50V	C280	1-124-584-00	ELECT 100uF 20% 10V
C209	1-124-234-00	ELECT	22uF	20% 16V	C281	1-163-038-00	CERAMIC CHIP 0.1uF 25V
C210	1-163-131-00	CERAMIC CHIP	390PF	5% 50V	C282	1-164-232-11	CERAMIC CHIP 0.01uF 50V
C211	1-163-239-11	CERAMIC CHIP	33PF	5% 50V	C283	1-163-038-00	CERAMIC CHIP 0.1uF 25V
C213	1-163-257-11	CERAMIC CHIP	180PF	5% 50V	C284	1-163-038-00	CERAMIC CHIP 0.1uF 25V
C214	1-163-235-11	CERAMIC CHIP	22PF	5% 50V	C286	1-124-584-00	ELECT 100uF 20% 10V
C217	1-126-160-11	ELECT	1uF	20% 50V	C287	1-163-227-11	CERAMIC CHIP 10PF 0.5PF 50V
C219	1-163-038-00	CERAMIC CHIP	0.1uF	25V	C288	1-163-227-11	CERAMIC CHIP 10PF 0.5PF 50V
C220	1-126-160-11	ELECT	1uF	20% 50V	C289	1-163-038-00	CERAMIC CHIP 0.1uF 25V
C222	1-163-038-00	CERAMIC CHIP	0.1uF	25V	C301	1-163-038-00	CERAMIC CHIP 0.1uF 25V
C223	1-124-589-11	ELECT	47uF	20% 16V	C302	1-124-589-11	ELECT 47uF 20% 16V
C224	1-163-038-00	CERAMIC CHIP	0.1uF	25V	C303	1-126-160-11	ELECT 1uF 20% 50V
C226	1-163-038-00	CERAMIC CHIP	0.1uF	25V			(495,L40,L50,X5)
C227	1-163-091-00	CERAMIC CHIP	8PF	50V	C304	1-126-160-11	ELECT 1uF 20% 50V
C228	1-124-261-00	ELECT	10uF	20% 50V			(495,L50,X5)
C229	1-163-038-00	CERAMIC CHIP	0.1uF	25V	C305	1-126-160-11	ELECT 1uF 20% 50V
C230	1-124-589-11	ELECT	47uF	20% 16V	C306	1-126-160-11	ELECT 1uF 20% 50V
C231	1-124-261-00	ELECT	10uF	20% 50V	C307	1-124-261-00	ELECT 10uF 20% 50V
C232	1-126-160-11	ELECT	1uF	20% 50V	C308	1-124-589-11	ELECT 47uF 20% 16V
C233	1-126-160-11	ELECT	1uF	20% 50V	C309	1-126-963-11	ELECT 4.7uF 20% 50V
C234	1-164-232-11	CERAMIC CHIP	0.01uF	50V	C310	1-163-009-11	CERAMIC CHIP 0.001uF 10% 50V
C235	1-164-232-11	CERAMIC CHIP	0.01uF	50V	C311	1-164-161-11	CERAMIC CHIP 0.0022uF 10% 100V
C236	1-126-160-11	ELECT	1uF	20% 50V	C312	1-137-370-11	FILM 0.01uF 5% 50V
C237	1-164-232-11	CERAMIC CHIP	0.01uF	50V	C313	1-126-964-11	ELECT 10uF 20% 50V
C238	1-163-038-00	CERAMIC CHIP	0.1uF	25V	C314	1-164-232-11	CERAMIC CHIP 0.01uF 50V
					C315	1-126-160-11	ELECT 1uF 20% 50V
					C317	1-126-963-11	ELECT 4.7uF 20% 50V

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
C318	1-126-967-11	ELECT	47uF 20% 16V	C379	1-124-257-00	ELECT 2.2uF 20% 50V	
C321	1-124-589-11	ELECT	47uF 20% 16V			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C322	1-164-232-11	CERAMIC CHIP	0.01uF 50V	C380	1-124-261-00	ELECT 10uF 20% 50V	
C323	1-164-232-11	CERAMIC CHIP	0.01uF 50V			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C324	1-104-697-11	FILM	0.047uF 5% 100V	C381	1-126-967-11	ELECT 47uF 20% 50V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C341	1-124-584-00	ELECT	100uF 20% 10V	C382	1-137-437-11	FILM 0.0056uF 5% 50V	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C342	1-164-232-11	CERAMIC CHIP	0.01uF 50V	C383	1-137-378-11	FILM 0.22uF 5% 50V	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C343	1-124-257-00	ELECT	2.2uF 20% 50V				
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C384	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V	
C344	1-164-232-11	CERAMIC CHIP	0.01uF 50V			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C385	1-124-589-11	ELECT 47uF 20% 16V	
C345	1-126-160-11	ELECT	1uF 20% 50V			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C386	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C346	1-164-232-11	CERAMIC CHIP	0.01uF 50V	C387	1-124-589-11	ELECT 47uF 20% 16V	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C347	1-163-031-11	CERAMIC CHIP	0.01uF 50V	C388	1-124-589-11	ELECT 47uF 20% 16V	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C350	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V				
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C389	1-104-760-11	CERAMIC CHIP 0.047uF 10% 50V	
C351	1-163-135-00	CERAMIC CHIP	560PF 5% 50V			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C390	1-164-222-11	CERAMIC CHIP 0.22uF 25V	
C352	1-163-031-11	CERAMIC CHIP	0.01uF 50V			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C391	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C353	1-163-038-00	CERAMIC CHIP	0.1uF 25V	C392	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C356	1-163-135-00	CERAMIC CHIP	560PF 5% 50V				
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C405	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C357	1-163-031-11	CERAMIC CHIP	0.01uF 50V				
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C406	1-104-760-11	CERAMIC CHIP 0.047uF 10% 50V	
C358	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C407	1-104-760-11	CERAMIC CHIP 0.047uF 10% 50V	
C361	1-164-222-11	CERAMIC CHIP	0.22uF 25V				
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C421	1-124-589-11	ELECT 47uF 20% 16V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C362	1-164-222-11	CERAMIC CHIP	0.22uF 25V	C422	1-124-589-11	ELECT 47uF 20% 16V	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C363	1-126-160-11	ELECT	1uF 20% 50V	C423	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)				
C364	1-126-160-11	ELECT	1uF 20% 50V				
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C424	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C365	1-126-160-11	ELECT	1uF 20% 50V			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C460	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C366	1-126-160-11	ELECT	1uF 20% 50V			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C461	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C369	1-124-261-00	ELECT	10uF 20% 50V	C462	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C370	1-124-261-00	ELECT	10uF 20% 50V	C501	1-163-099-00	CERAMIC CHIP 18PF 5% 50V	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)				
C371	1-124-261-00	ELECT	10uF 20% 50V				
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C502	1-163-237-11	CERAMIC CHIP 27PF 5% 50V	
C372	1-124-261-00	ELECT	10uF 20% 50V			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C503	1-163-239-11	CERAMIC CHIP 33PF 5% 50V	
C373	1-124-261-00	ELECT	10uF 20% 50V			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C504	1-163-239-11	CERAMIC CHIP 33PF 5% 50V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C374	1-126-160-11	ELECT	1uF 20% 50V	C505	1-124-589-11	ELECT 47uF 20% 16V	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C375	1-137-378-11	FILM	0.22uF 5% 50V	C506	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)				
C376	1-137-437-11	FILM	0.0056uF 5% 50V				
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C507	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C377	1-126-967-11	ELECT	47uF 20% 50V			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C508	1-124-589-11	ELECT 47uF 20% 16V	
C378	1-124-261-00	ELECT	10uF 20% 50V			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
			(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	C509	1-126-160-11	ELECT 1uF 20% 50V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
				C510	1-163-125-00	CERAMIC CHIP 220PF 5% 50V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
				C512	1-126-160-11	ELECT 1uF 20% 50V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
				C513	1-163-227-11	CERAMIC CHIP 10PF 0.5PF 50V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
				C541	1-126-935-11	ELECT 470uF 20% 6.3V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
				C542	1-124-589-11	ELECT 47uF 20% 16V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
				C543	1-124-589-11	ELECT 47uF 20% 16V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
				C544	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
				C570	1-124-261-00	ELECT 10uF 20% 50V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
				C571	1-124-261-00	ELECT 10uF 20% 50V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
				C572	1-124-261-00	ELECT 10uF 20% 50V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
				C573	1-124-261-00	ELECT 10uF 20% 50V	
						(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
				C574	1-163-031-11	CERAMIC CHIP 0.01uF 50V	

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
C575	1-124-589-11	ELECT	47uF 20% 16V	* CN341	1-560-890-00	PIN, CONNECTOR 2P (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C600	1-128-131-11	ELECT	22uF 20% 50V	CN401	1-506-469-11	PIN, CONNECTOR 4P(EXCEPT L50,L70HF,X5)	
C602	1-124-589-11	ELECT	47uF 20% 16V	CN401	1-506-474-11	PIN, CONNECTOR 9P(L50,L70HF,X5)	
C604	1-163-031-11	CERAMIC CHIP	0.01uF 50V	CN423	1-506-469-11	PIN, CONNECTOR 4P(495,L50,X5)	
C605	1-124-589-11	ELECT	47uF 20% 16V	CN423	1-506-470-11	PIN, CONNECTOR 5P(685HF,695HF,L70HF)	
C606	1-128-131-11	ELECT	22uF 20% 50V	CN601	1-569-667-11	CONNECTOR, BOARD TO BOARD 8P	
C608	1-124-589-11	ELECT	47uF 20% 16V	< DIODE >			
C701	1-124-589-11	ELECT	47uF 20% 16V	D102	8-719-048-26	DIODE 6L528V1	
C704	1-163-031-11	CERAMIC CHIP	0.01uF 50V	D161	8-719-200-82	DIODE 11ES2	
C706	1-126-964-11	ELECT	10uF 20% 50V	D162	8-719-200-82	DIODE 11ES2	
C707	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V	D301	8-719-911-19	DIODE 1SS119 (495,L40,L50,X5)	
C708	1-124-589-11	ELECT	47uF 20% 16V	D302	8-719-911-19	DIODE 1SS119 (495,L40,L50,X5)	
C709	1-163-031-11	CERAMIC CHIP	0.01uF 50V	D361	8-719-911-19	DIODE 1SS119 (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
C710	1-163-031-11	CERAMIC CHIP	0.01uF 50V	D401	8-719-054-09	DIODE MP65304S	
C711	1-163-024-00	CERAMIC CHIP	0.018uF 10% 50V (495,L40,L50,X5)	D501	8-719-911-19	DIODE 1SS119	
C731	1-124-261-00	ELECT	10uF 20% 50V (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	D540	8-719-109-84	DIODE RD5.1ES-B1	
C732	1-124-261-00	ELECT	10uF 20% 50V (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	D600	8-719-200-82	DIODE 11ES2	
C733	1-124-261-00	ELECT	10uF 20% 50V	D601	8-719-911-19	DIODE 1SS119	
C735	1-124-261-00	ELECT	10uF 20% 50V (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	D602	8-719-109-85	DIODE RD5.1ES-B2	
C736	1-124-589-11	ELECT	47uF 20% 16V (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	D702	8-719-110-78	DIODE RD33ES-B2	
C980	1-163-038-00	CERAMIC CHIP	0.1uF 25V (495,685HF,695HF)	D980	8-719-110-08	DIODE RD8.2ES-B2 (495,685HF,695HF)	
C981	1-124-589-11	ELECT	47uF 20% 16V (495,685HF,695HF)	D981	8-719-110-08	DIODE RD8.2ES-B2 (495,685HF,695HF)	
C982	1-163-038-00	CERAMIC CHIP	0.1uF 25V (495,685HF,695HF)	D982	8-719-911-19	DIODE 1SS119 (495,685HF,695HF)	
C983	1-163-038-00	CERAMIC CHIP	0.1uF 25V (495,685HF,695HF)	< IC >			
C984	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V (495,685HF,695HF)	IC131	8-759-353-59	IC LB1643	
C985	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V (495,685HF,695HF)	IC160	8-759-462-97	IC M37777M7A-VSX8521-2 (495,685HF,695HF)	
C986	1-163-038-00	CERAMIC CHIP	0.1uF 25V (495,685HF,695HF)	IC160	8-759-462-98	IC M37776M5A-VSX8513-2 (EXCEPT 495,685HF,695HF)	
< JACK >				IC201	8-759-439-49	IC LA71530M	
CJ540	1-779-010-11	JACK, PIN 4P (LINE IN/OUT)(495,L40)		IC202	8-759-439-51	IC LC89978M-TE-L	
CJ540	1-779-011-11	JACK, PIN 6P (LINE IN/OUT) (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)		IC260	8-759-352-17	IC HA118195NT	
CJ540	1-779-012-11	JACK, PIN 5P (LINE IN/OUT)(L50,X5)		IC301	8-759-089-84	IC BA7755AF-T1	
CNJ980	1-779-013-11	JACK, MINIATURE(CABLE BOX CONTROL) (495,685HF,695HF)		IC340	8-759-055-49	IC AN3327K (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
< CONNECTOR >				IC360	8-759-445-22	IC TDA9603H/N2,557 (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
CN101	1-506-470-11	PIN, CONNECTOR 5P		IC361	8-759-708-05	IC NJM78L05A (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
* CN102	1-766-538-11	CONNECTOR, BOARD TO BOARD 8P		IC403	8-742-042-00	RE CEIVER MIC SBX1986-51	
* CN103	1-766-537-11	CONNECTOR (HMD) 5P		IC420	8-759-366-44	IC uPD16312GB-3B4	
* CN104	1-766-716-11	CONNECTOR, BOARD TO BOARD 3P		IC461	8-759-248-87	IC MM1256XF-BE	
CN140	1-506-468-11	PIN, CONNECTOR 3P		IC462	8-759-433-52	IC AT24C01A-10SC-#B (EXCEPT 495,685HF,695HF)	
CN260	1-563-585-11	CONNECTOR, FLEXIBLE 8P (495,L40,L50,X5)		IC462	8-759-433-53	IC AT24C02N-10SC-#B (495,685HF,695HF)	
CN260	1-766-986-11	CONNECTOR, FFC/FPC 13P (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)		IC501	8-759-354-26	IC BU6188FS-E2	
* CN261	1-560-892-00	PIN, CONNECTOR 4P		IC540	8-759-100-96	IC uPC4558G2	
CN301	1-506-469-11	PIN, CONNECTOR 4P		IC600	8-759-438-18	IC PQ12RD08	
CN302	1-506-468-11	PIN, CONNECTOR 3P		IC733	8-742-037-00	IC SBX1837-51 (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
< JUMPER RESISTOR >				IC980	8-759-356-27	IC NJM2129M-TE2 (495,685HF,695HF)	
JR100	1-216-296-00	METAL CHIP	0 5% 1/8W	JR100	1-216-296-00	METAL CHIP	0 5% 1/8W
JR101	1-216-296-00	METAL CHIP	0 5% 1/8W	JR101	1-216-296-00	METAL CHIP	0 5% 1/8W
JR102	1-216-296-00	METAL CHIP	0 5% 1/8W	JR102	1-216-296-00	METAL CHIP	0 5% 1/8W
JR105	1-216-296-00	METAL CHIP	0 5% 1/8W	JR105	1-216-296-00	METAL CHIP	0 5% 1/8W
JR106	1-216-296-00	METAL CHIP	0 5% 1/8W	JR106	1-216-296-00	METAL CHIP	0 5% 1/8W

Ref. No.	Part No.	Description	Quantity	Percentage	Remarks	Ref. No.	Part No.	Description	Quantity	Percentage	Remarks
JR107	1-216-296-00	METAL CHIP	0	5%	1/8W	JR346	1-216-296-00	METAL CHIP	0	5%	1/8W
JR108	1-216-296-00	METAL CHIP	0	5%	1/8W	JR347	1-216-295-00	METAL CHIP	0	5%	1/10W
JR111	1-216-296-00	METAL CHIP	0	5%	1/8W	JR350	1-216-296-00	METAL CHIP	0	5%	1/8W
JR112	1-216-296-00	METAL CHIP	0	5%	1/8W	JR351	1-216-296-00	METAL CHIP	0	5%	1/8W
JR113	1-216-296-00	METAL CHIP	0	5%	1/8W	JR352	1-216-296-00	METAL CHIP	0	5%	1/8W
JR114	1-216-296-00	METAL CHIP	0	5%	1/8W	JR354	1-216-296-00	METAL CHIP	0	5%	1/8W
JR115	1-216-295-00	METAL CHIP	0	5%	1/10W	JR355	1-216-296-00	METAL CHIP	0	5%	1/8W
JR116	1-216-295-00	METAL CHIP	0	5%	1/10W	JR402	1-216-296-00	METAL CHIP	0	5%	1/8W
JR117	1-216-295-00	METAL CHIP	0	5%	1/10W	JR403	1-216-296-00	METAL CHIP	0	5%	1/8W
JR119	1-216-296-00	METAL CHIP	0	5%	1/8W	JR405	1-216-295-00	METAL CHIP	0	5%	1/10W
JR120	1-216-296-00	METAL CHIP	0	5%	1/8W	JR500	1-216-296-00	METAL CHIP	0	5%	1/8W
JR221	1-216-296-00	METAL CHIP	0	5%	1/8W	JR501	1-216-296-00	METAL CHIP	0	5%	1/8W
JR222	1-216-296-00	METAL CHIP	0	5%	1/8W	JR502	1-216-296-00	METAL CHIP	0	5%	1/8W
JR250	1-216-296-00	METAL CHIP	0	5%	1/8W	JR503	1-216-296-00	METAL CHIP	0	5%	1/8W
JR251	1-216-296-00	METAL CHIP	0	5%	1/8W	JR505	1-216-296-00	METAL CHIP	0	5%	1/8W
JR253	1-216-296-00	METAL CHIP	0	5%	1/8W	JR506	1-216-295-00	METAL CHIP	0	5%	1/10W
JR257	1-216-296-00	METAL CHIP	0	5%	1/8W	JR507	1-216-296-00	METAL CHIP	0	5%	1/8W
JR258	1-216-295-00	METAL CHIP	0	5%	1/10W	JR508	1-216-296-00	METAL CHIP	0	5%	1/8W
JR259	1-216-296-00	METAL CHIP	0	5%	1/8W	JR509	1-216-296-00	METAL CHIP	0	5%	1/8W
JR260	1-216-295-00	METAL CHIP	0	5%	1/10W	JR510	1-216-296-00	METAL CHIP	0	5%	1/8W
JR301	1-216-295-00	METAL CHIP	0	5%	1/10W	JR511	1-216-296-00	METAL CHIP	0	5%	1/8W
JR302	1-216-296-00	METAL CHIP	0	5%	1/8W	JR512	1-216-295-00	METAL CHIP	0	5%	1/10W
JR303	1-216-295-00	METAL CHIP	0	5%	1/10W	JR513	1-216-295-00	METAL CHIP	0	5%	1/10W
JR304	1-216-296-00	METAL CHIP	0	5%	1/8W						
JR305	1-216-295-00	METAL CHIP	0	5%	1/10W			< JUMPER RESISTOR >			
JR306	1-216-295-00	METAL CHIP	0	5%	1/10W	JS702	1-216-296-00	METAL CHIP	0	5%	1/8W (495,L40,L50,X5)
JR307	1-216-295-00	METAL CHIP	0	5%	1/10W			< COIL >			
JR308	1-216-295-00	METAL CHIP	0	5%	1/10W	L130	1-403-588-11	COIL, CHOKE	22uH		
JR309	1-216-295-00	METAL CHIP	0	5%	1/10W	L140	1-410-513-11	INDUCTOR	22uH		
JR310	1-216-296-00	METAL CHIP	0	5%	1/8W	L161	1-410-513-11	INDUCTOR	22uH		
JR311	1-216-295-00	METAL CHIP	0	5%	1/10W	L162	1-410-513-11	INDUCTOR	22uH		
JR312	1-216-296-00	METAL CHIP	0	5%	1/8W	L163	1-410-513-11	INDUCTOR	22uH		
JR313	1-216-296-00	METAL CHIP	0	5%	1/8W	L164	1-410-519-11	INDUCTOR	68uH		
JR314	1-216-296-00	METAL CHIP	0	5%	1/8W	L201	1-410-516-11	INDUCTOR	39uH		
JR316	1-216-296-00	METAL CHIP	0	5%	1/8W	L202	1-410-521-11	INDUCTOR	100uH		
JR317	1-216-295-00	METAL CHIP	0	5%	1/10W	L204	1-410-501-11	INDUCTOR	2.2uH		
JR318	1-216-296-00	METAL CHIP	0	5%	1/8W	L205	1-410-513-11	INDUCTOR	22uH		
JR319	1-216-295-00	METAL CHIP	0	5%	1/10W	L206	1-410-501-11	INDUCTOR	2.2uH		
JR320	1-216-295-00	METAL CHIP	0	5%	1/10W	L207	1-410-518-41	INDUCTOR	56uH		
JR321	1-216-295-00	METAL CHIP	0	5%	1/10W	L262	1-408-982-11	INDUCTOR	100uH		
JR323	1-216-296-00	METAL CHIP	0	5%	1/8W	L263	1-408-982-11	INDUCTOR	100uH		
JR324	1-216-296-00	METAL CHIP	0	5%	1/8W	L301	1-410-521-11	INDUCTOR	100uH		
JR325	1-216-296-00	METAL CHIP	0	5%	1/8W	L321	1-408-982-11	INDUCTOR	100uH		
JR326	1-216-296-00	METAL CHIP	0	5%	1/8W	L341	1-408-982-11	INDUCTOR	100uH		
JR327	1-216-296-00	METAL CHIP	0	5%	1/8W	L361	1-408-982-11	INDUCTOR	100uH		(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
JR329	1-216-296-00	METAL CHIP	0	5%	1/8W	L501	1-410-513-11	INDUCTOR	22uH		
JR330	1-216-296-00	METAL CHIP	0	5%	1/8W	L502	1-412-470-21	INDUCTOR	22uH		
JR331	1-216-296-00	METAL CHIP	0	5%	1/8W	L503	1-410-513-11	INDUCTOR	22uH		
JR332	1-216-295-00	METAL CHIP	0	5%	1/10W	L540	1-408-982-11	INDUCTOR	100uH		
JR333	1-216-296-00	METAL CHIP	0	5%	1/8W	L570	1-408-982-11	INDUCTOR	100uH		
JR334	1-216-295-00	METAL CHIP	0	5%	1/10W	L600	1-410-519-11	INDUCTOR	68uH		
JR335	1-216-296-00	METAL CHIP	0	5%	1/8W	L601	1-408-970-21	INDUCTOR	10uH		
JR336	1-216-295-00	METAL CHIP	0	5%	1/10W	L702	1-408-978-21	INDUCTOR	47uH		
JR337	1-216-295-00	METAL CHIP	0	5%	1/10W	L703	1-410-501-11	INDUCTOR	2.2uH		
JR338	1-216-296-00	METAL CHIP	0	5%	1/8W	L704	1-410-501-11	INDUCTOR	2.2uH		
JR339	1-216-296-00	METAL CHIP	0	5%	1/8W	L731	1-410-513-11	INDUCTOR	22uH		(675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
JR340	1-216-296-00	METAL CHIP	0	5%	1/8W						
JR341	1-216-296-00	METAL CHIP	0	5%	1/8W						
JR342	1-216-295-00	METAL CHIP	0	5%	1/10W						
JR345	1-216-296-00	METAL CHIP	0	5%	1/8W						

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
		< FLUORECENT INDICATOR >					
ND420	1-517-595-11	TUBE, FLUORESCENT INDICATOR		R117	1-216-041-00	METAL CHIP 470	5% 1/10W
		< PHOTO INTERRUPTER >		R124	1-216-041-00	METAL CHIP 470	5% 1/10W
PH100	8-749-010-20	PHOTO INTERRUPTER GP3S114		R125	1-216-041-00	METAL CHIP 470	5% 1/10W
PH101	8-749-010-19	PHOTO INTERRUPTER GP3S113		R126	1-216-041-00	METAL CHIP 470	5% 1/10W
		< IC LINK >		R130	1-216-041-00	METAL CHIP 470	5% 1/10W
△ PS403	1-533-586-31	LINK, IC 315mA		R131	1-216-041-00	METAL CHIP 470	5% 1/10W
△ PS600	1-532-841-21	LINK, IC 1 6A		R132	1-216-089-00	METAL CHIP 47K	5% 1/10W
		< TRANSISTOR >		R133	1-216-081-00	METAL CHIP 22K	5% 1/10W
Q100	8-729-025-92	PHOTO TRANSISTOR PT380F		R140	1-216-065-00	METAL CHIP 4.7K	5% 1/10W
Q101	8-729-025-92	PHOTO TRANSISTOR PT380F		R160	1-216-295-00	METAL CHIP 0	5% 1/10W
Q102	8-729-281-53	TRANSISTOR 2SC1815-GR		R161	1-216-049-00	METAL CHIP 1K	5% 1/10W (495,L40 L70HF)
Q201	8-729-230-49	TRANSISTOR 2SC2712-G		R162	1-216-049-00	METAL CHIP 1K	5% 1/10W (L60HF,L70HF,X6HF)
Q202	8-729-230-49	TRANSISTOR 2SC2712-G		R163	1-216-049-00	METAL CHIP 1K	5% 1/10W (L50,X5)
Q208	8-729-230-49	TRANSISTOR 2SC2712-G		R164	1-216-121-91	METAL GLAZE 1M	5% 1/10W
Q209	8-729-216-21	TRANSISTOR 2SA1162Y		R165	1-216-039-00	METAL CHIP 390	5% 1/10W
Q210	8-729-230-49	TRANSISTOR 2SC2712-G		R166	1-216-041-00	METAL CHIP 470	5% 1/10W
Q211	8-729-230-49	TRANSISTOR 2SC2712-G		R167	1-216-295-00	METAL CHIP 0	5% 1/10W
Q260	8-729-230-49	TRANSISTOR 2SC2712-G		R168	1-216-295-00	METAL CHIP 0	5% 1/10W
Q301	8-729-281-53	TRANSISTOR 2SC1815-GR		R169	1-216-049-00	METAL CHIP 1K	5% 1/10W (495,685HF,695HF)
Q302	8-729-424-67	TRANSISTOR UN2216 (495,L40,L50,X5)		R170	1-216-049-00	METAL CHIP 1K	5% 1/10W
Q321	8-729-802-91	TRANSISTOR 2SD879		R171	1-216-073-00	METAL CHIP 10K	5% 1/10W
Q361	8-729-102-14	TRANSISTOR 2SD1021-F (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)		R172	1-216-049-00	METAL CHIP 1K	5% 1/10W
Q362	8-729-102-14	TRANSISTOR 2SD1021-F (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)		R173	1-216-049-00	METAL CHIP 1K	5% 1/10W
Q363	8-729-102-14	TRANSISTOR 2SD1021-F (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)		R174	1-216-049-00	METAL CHIP 1K	5% 1/10W
Q364	8-729-010-05	TRANSISTOR MSB709-RT1 (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)		R175	1-216-051-00	METAL CHIP 1.2K	5% 1/10W
Q501	8-729-216-21	TRANSISTOR 2SA1162Y		R176	1-218-179-11	METAL GLAZE 10M	5% 1/10W
Q502	8-729-010-05	TRANSISTOR MSB709-RT1		R177	1-216-049-00	METAL CHIP 1K	5% 1/10W
Q600	8-729-140-93	TRANSISTOR 2SB733-34		R179	1-216-295-00	METAL CHIP 0	5% 1/10W
Q601	8-729-010-25	TRANSISTOR MSD601-RT1		R180	1-216-295-00	METAL CHIP 0	5% 1/10W
Q602	8-729-140-98	TRANSISTOR 2SD773-34		R181	1-216-073-00	METAL CHIP 10K	5% 1/10W
Q681	8-729-010-05	TRANSISTOR MSB709-RT1		R185	1-216-089-00	METAL CHIP 47K	5% 1/10W
Q731	8-729-421-19	TRANSISTOR UN2213 (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)		R201	1-216-041-00	METAL CHIP 470	5% 1/10W
		< RESISTOR >		R202	1-216-069-00	METAL CHIP 6 8K	5% 1/10W
R100	1-216-081-00	METAL CHIP 22K	5% 1/10W	R203	1-216-049-00	METAL CHIP 1K	5% 1/10W
R101	1-216-033-00	METAL CHIP 220	5% 1/10W	R204	1-216-047-91	METAL GLAZE 820	5% 1/10W
R102	1-216-033-00	METAL CHIP 220	5% 1/10W	R205	1-216-037-00	METAL CHIP 330	5% 1/10W
R103	1-216-081-00	METAL CHIP 22K	5% 1/10W	R206	1-216-037-00	METAL CHIP 330	5% 1/10W
R104	1-216-113-00	METAL CHIP 470K	5% 1/10W	R207	1-216-073-00	METAL CHIP 10K	5% 1/10W
R105	1-216-113-00	METAL CHIP 470K	5% 1/10W	R208	1-216-073-00	METAL CHIP 10K	5% 1/10W
R106	1-216-057-00	METAL CHIP 2.2K	5% 1/10W	R209	1-216-295-00	METAL CHIP 0	5% 1/10W
R107	1-216-049-00	METAL CHIP 1K	5% 1/10W	R214	1-216-045-00	METAL CHIP 680	5% 1/10W
R108	1-247-807-31	CARBON 100	5% 1/4W	R218	1-208-798-11	METAL GLAZE 4 7K	0.50% 1/10W
R109	1-247-807-31	CARBON 100	5% 1/4W	R219	1-216-053-00	METAL CHIP 1.5K	5% 1/10W
R111	1-216-089-00	METAL CHIP 47K	5% 1/10W	R220	1-216-295-00	METAL CHIP 0	5% 1/10W
R112	1-216-089-00	METAL CHIP 47K	5% 1/10W	R222	1-216-051-00	METAL CHIP 1 2K	5% 1/10W
R113	1-216-089-00	METAL CHIP 47K	5% 1/10W	R223	1-216-295-00	METAL CHIP 0	5% 1/10W
R114	1-216-089-00	METAL CHIP 47K	5% 1/10W	R224	1-216-295-00	METAL CHIP 0	5% 1/10W (495,685HF,695HF,L50,L70HF,X5)
R115	1-216-089-00	METAL CHIP 47K	5% 1/10W	R225	1-216-295-00	METAL CHIP 0	5% 1/10W
				R226	1-216-025-91	METAL GLAZE 100	5% 1/10W
				R227	1-216-025-91	METAL GLAZE 100	5% 1/10W

<p>Note : The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.</p>	<p>Note : Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.</p>
---	---

Ref. No.	Part No.	Description	Quantity	Material	Remarks	Ref. No.	Part No.	Description	Quantity	Material	Remarks
R228	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	R310	1-216-129-00	METAL CHIP	2.2M	5%	1/10W
R229	1-216-055-00	METAL CHIP	1.8K	5%	1/10W	R311	1-216-053-00	METAL CHIP	1.5K	5%	1/10W
R230	1-216-045-00	METAL CHIP	680	5%	1/10W	R312	1-216-079-00	METAL CHIP	18K	5%	1/10W
R231	1-216-071-00	METAL CHIP	8.2K	5%	1/10W	R313	1-216-109-00	METAL CHIP	330K	5%	1/10W
R232	1-216-056-00	METAL CHIP	1.8K	5%	1/10W	R314	1-216-035-00	METAL CHIP	270	5%	1/10W
R234	1-216-049-00	METAL CHIP	1K	5%	1/10W	R315	1-216-073-00	METAL CHIP	10K	5%	1/10W
R235	1-216-073-00	METAL CHIP	10K	5%	1/10W	R316	1-216-071-00	METAL CHIP	8.2K	5%	1/10W
R236	1-216-049-00	METAL CHIP	1K	5%	1/10W	R317	1-216-079-00	METAL CHIP	18K	5%	1/10W
R237	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	R318	1-216-075-00	METAL CHIP	12K	5%	1/10W
R238	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	R319	1-216-043-91	METAL GLAZE	560	5%	1/10W (495,L40,L50,X5)
R239	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	R319	1-216-295-00	METAL CHIP	0	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R240	1-216-049-00	METAL CHIP	1K	5%	1/10W	R320	1-216-047-91	METAL GLAZE	820	5%	1/10W
R243	1-216-061-00	METAL CHIP	3.3K	5%	1/10W	R321	1-216-017-91	METAL GLAZE	47	5%	1/10W
R260	1-216-044-00	METAL CHIP	620	5%	1/10W	R322	1-216-063-91	METAL GLAZE	3.9K	5%	1/10W
R261	1-216-044-00	METAL CHIP	620	5%	1/10W	R323	1-217-671-11	METAL CHIP	1	5%	1/10W
R262	1-216-021-00	METAL CHIP	68	5%	1/10W (495,L40,L50,X5)	R324	1-216-031-00	METAL CHIP	180	5%	1/10W
R262	1-216-025-91	METAL GLAZE	100	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	R341	1-216-067-00	METAL CHIP	5.6K	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R263	1-216-021-00	METAL CHIP	68	5%	1/10W (495,L40,L50,X5)	R342	1-216-051-00	METAL CHIP	1.2K	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R263	1-216-025-91	METAL GLAZE	100	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	R343	1-216-073-00	METAL CHIP	10K	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R264	1-216-021-00	METAL CHIP	68	5%	1/10W (495,L40,L50,X5)	R344	1-216-079-00	METAL CHIP	18K	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R264	1-216-025-91	METAL GLAZE	100	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	R345	1-216-097-91	METAL GLAZE	100K	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R265	1-216-021-00	METAL CHIP	68	5%	1/10W (495,L40,L50,X5)	R346	1-216-065-00	METAL CHIP	4.7K	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R265	1-216-025-91	METAL GLAZE	100	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	R347	1-216-065-00	METAL CHIP	4.7K	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R266	1-216-053-00	METAL CHIP	1.5K	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	R350	1-216-033-00	METAL CHIP	220	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R266	1-216-055-00	METAL CHIP	1.8K	5%	1/10W (495,L40,L50,X5)	R351	1-216-035-00	METAL CHIP	270	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R267	1-216-073-00	METAL CHIP	10K	5%	1/10W	R356	1-216-035-00	METAL CHIP	270	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R268	1-216-081-00	METAL CHIP	22K	5%	1/10W	R361	1-216-033-00	METAL CHIP	220	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R269	1-216-061-00	METAL CHIP	3.3K	5%	1/10W	R362	1-216-033-00	METAL CHIP	220	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R270	1-216-081-00	METAL CHIP	22K	5%	1/10W	R363	1-216-033-00	METAL CHIP	220	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R271	1-216-049-00	METAL CHIP	1K	5%	1/10W	R364	1-216-049-00	METAL CHIP	1K	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R272	1-216-077-00	METAL CHIP	15K	5%	1/10W	R365	1-216-049-00	METAL CHIP	1K	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R273	1-216-077-00	METAL CHIP	15K	5%	1/10W	R366	1-216-049-00	METAL CHIP	1K	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R274	1-216-073-00	METAL CHIP	10K	5%	1/10W	R367	1-216-049-00	METAL CHIP	1K	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R275	1-216-073-00	METAL CHIP	10K	5%	1/10W	R368	1-216-133-00	METAL CHIP	3.3M	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R276	1-216-049-00	METAL CHIP	1K	5%	1/10W	R369	1-216-689-11	METAL CHIP	39K	0.5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R301	1-216-089-00	METAL CHIP	47K	5%	1/10W (495,L40,L50,X5)	R370	1-216-061-00	METAL CHIP	3.3K	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R301	1-216-093-00	METAL CHIP	68K	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	R371	1-216-689-11	METAL CHIP	39K	0.5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R302	1-216-067-00	METAL CHIP	5.6K	5%	1/10W	R372	1-216-061-00	METAL CHIP	3.3K	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R303	1-216-093-00	METAL CHIP	68K	5%	1/10W (495,L40,L50,X5)	R373	1-216-689-11	METAL CHIP	39K	0.5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R304	1-216-093-00	METAL CHIP	68K	5%	1/10W (495,L50,X5)	R374	1-216-295-00	METAL CHIP	0	5%	1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)
R305	1-216-067-00	METAL CHIP	5.6K	5%	1/10W (495,L40,L50,X5)						
R306	1-216-073-00	METAL CHIP	10K	5%	1/10W						
R307	1-216-061-00	METAL CHIP	3.3K	5%	1/10W						
R308	1-216-067-00	METAL CHIP	5.6K	5%	1/10W (495,L50,X5)						
R309	1-216-067-00	METAL CHIP	5.6K	5%	1/10W						

Ref. No.	Part No.	Description	Remarks
R375	1-216-049-00	METAL CHIP 1K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R376	1-216-097-91	METAL GLAZE 100K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R377	1-216-097-91	METAL GLAZE 100K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R378	1-216-083-00	METAL CHIP 27K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R379	1-216-073-00	METAL CHIP 10K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R380	1-216-065-00	METAL CHIP 4.7K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R381	1-216-065-00	METAL CHIP 4.7K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R382	1-216-065-00	METAL CHIP 4.7K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R383	1-216-065-00	METAL CHIP 4.7K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R386	1-216-295-00	METAL CHIP 0 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R387	1-216-295-00	METAL CHIP 0 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R388	1-216-295-00	METAL CHIP 0 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R401	1-249-407-11	CARBON 150 5% 1/4W F	
R405	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R406	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R407	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R408	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R409	1-216-013-00	METAL CHIP 33 5% 1/10W	
R410	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R411	1-216-013-00	METAL CHIP 33 5% 1/10W	
R412	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R413	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R414	1-216-053-00	METAL CHIP 1.5K 5% 1/10W	
R415	1-216-053-00	METAL CHIP 1.5K 5% 1/10W	
R417	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R418	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R419	1-216-059-00	METAL CHIP 2.7K 5% 1/10W	
R420	1-216-059-00	METAL CHIP 2.7K 5% 1/10W	
R421	1-216-295-00	METAL CHIP 0 5% 1/10W	
R422	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R423	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R424	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R425	1-216-085-00	METAL CHIP 33K 5% 1/10W	
R426	1-216-065-00	METAL CHIP 4.7K 5% 1/10W	
R440	1-216-065-00	METAL CHIP 4.7K 5% 1/10W	
R441	1-216-089-00	METAL CHIP 6.8K 5% 1/10W (495 675HF,676HF,685HF,695HF)	
R442	1-216-077-00	METAL CHIP 15K 5% 1/10W (495 675HF,676HF,685HF,695HF)	
R445	1-216-065-00	METAL CHIP 4.7K 5% 1/10W (L50,L70HF,X5)	
R446	1-216-069-00	METAL CHIP 6.8K 5% 1/10W (L50,L70HF,X5)	
R447	1-216-077-00	METAL CHIP 15K 5% 1/10W (L50,L70HF,X5)	
R448	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R462	1-216-105-91	METAL GLAZE 220K 5% 1/10W	
R463	1-216-113-00	METAL CHIP 470K 5% 1/10W	
R464	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R502	1-216-049-00	METAL CHIP 1K 5% 1/10W	

Ref. No.	Part No.	Description	Remarks
R503	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R504	1-216-045-00	METAL CHIP 880 5% 1/10W	
R505	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R506	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R507	1-216-097-91	METAL GLAZE 100K 5% 1/10W	
R540	1-216-021-00	METAL CHIP 68 5% 1/10W	
R541	1-249-407-11	CARBON 150 5% 1/4W F	
R543	1-249-408-11	CARBON 180 5% 1/4W F	
R544	1-216-025-91	METAL GLAZE 100 5% 1/10W	
R560	1-216-022-00	METAL CHIP 75 5% 1/10W	
R570	1-216-041-00	METAL CHIP 470 5% 1/10W	
R571	1-216-041-00	METAL CHIP 470 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R572	1-216-097-91	METAL GLAZE 100K 5% 1/10W	
R573	1-216-097-91	METAL GLAZE 100K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R574	1-216-097-91	METAL GLAZE 100K 5% 1/10W	
R575	1-216-097-91	METAL GLAZE 100K 5% 1/10W	
R600	1-249-417-11	CARBON 1K 5% 1/4W F	
R601	1-216-430-11	METAL OXIDE 390 5% 1W F	
R602	1-216-085-00	METAL CHIP 4.7K 5% 1/10W	
R603	1-216-065-00	METAL CHIP 4.7K 5% 1/10W	
R604	1-249-413-11	CARBON 470 5% 1/4W F	
R605	1-215-857-11	METAL OXIDE 10 5% 1W F	
R606	1-215-908-00	METAL OXIDE 33 5% 3W F	
R608	1-249-413-11	CARBON 470 5% 1/4W F	
R609	1-249-413-11	CARBON 470 5% 1/4W F	
R610	1-249-413-11	CARBON 470 5% 1/4W F	
R701	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R702	1-216-295-00	METAL CHIP 0 5% 1/10W	
△R705	1-212-893-00	FUSIBLE 330 5% 1/4W F	
R706	1-216-113-00	METAL CHIP 470K 5% 1/10W	
R708	1-216-295-00	METAL CHIP 0 5% 1/10W	
R712	1-216-295-00	METAL CHIP 0 5% 1/10W	
R731	1-216-049-00	METAL CHIP 1K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R732	1-216-049-00	METAL CHIP 1K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R733	1-216-065-00	METAL CHIP 4.7K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R734	1-216-049-00	METAL CHIP 1K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R735	1-216-049-00	METAL CHIP 1K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R736	1-218-067-00	METAL CHIP 5.6K 5% 1/10W (495,L40,L50,X5)	
R736	1-216-295-00	METAL CHIP 0 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R737	1-216-081-00	METAL CHIP 22K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R738	1-216-081-00	METAL CHIP 22K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R739	1-216-073-00	METAL CHIP 10K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R740	1-216-295-00	METAL CHIP 0 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R741	1-216-295-00	METAL CHIP 0 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R742	1-216-295-00	METAL CHIP 0 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	

<p>Note : The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.</p>	<p>Note : Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifique</p>
---	--

Ref. No.	Part No.	Description	Remarks
R747	1-216-065-00	METAL CHIP 4.7K 5% 1/10W (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
R980	1-216-295-00	METAL CHIP 0 5% 1/10W (495,685HF,695HF)	
< VARIABLE RESISTOR >			
RV731	1-241-766-11	RES, ADJ, CERMET 47K (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
< SWITCH >			
S100	1-570-953-11	SWITCH, PUSH (1 KEY)(REC PROOF)	
S401	1-571-532-32	SWITCH, TACTIL (POWER)	
S402	1-571-532-32	SWITCH, TACTIL (EJECT)	
S403	1-571-532-32	SWITCH, TACTIL (REC)	
S404	1-571-532-32	SWITCH, TACTIL (PAUSE)	
S405	1-571-532-32	SWITCH, TACTIL (CH +)	
S406	1-571-532-32	SWITCH, TACTIL (CH -)	
S412	1-571-532-32	SWITCH, TACTIL (EASY SET UP) (495 675HF,676HF,685HF,695HF)	
S701	1-571-588-11	SWITCH, SLIDE (3CH/4CH)	
< TRANSFORMER >			
T321	1-431-097-11	TRANSFORMER, BIAS OSCILLATION	
< TUNER >			
TU701	1-693-353-11	TUNER, (IF) SOLID TYPE (495,L40,L50,X5)	
TU701	1-XXX-XXX-XX	TUNER, (IF) SOLID TYPE (675HF,676HF,685HF,695HFL60HF,L70HF,X6HF)	
< VIBRATOR >			
X160	1-760-494-11	VIBRATOR, CRYSTAL 16MHz	
X161	1-579-463-11	VIBRATOR, CRYSTAL 32.768kHz	
X202	1-577-380-11	VIBRATOR, CRYSTAL 3.579545MHz	
X501	1-567-307-11	OSCILLATOR, CRYSTAL	
Δ	1-468-168-11	POWER BLOCK SR701 (EXCEPT CHILEAN,PX) ***** (Ref.No.:5,000 Series)	
< CAPACITOR >			
C101	9-902-834-01	METALIZED 0.1uF	250V
C108	9-980-070-01	ELECT 120uF	200V
C109	1-126-963-11	ELECT 4.7uF	50V
C114	1-130-491-51	FILM 0.047uF	50V
C202	1-126-967-11	ELECT 47uF	50V
C203	1-126-183-11	ELECT 1000uF	16V
C204	1-126-935-11	ELECT 470uF	16V
C205	1-126-797-11	ELECT 1000uF	10V
C206	1-126-935-11	ELECT 470uF	16V
C207	1-126-933-11	ELECT 100uF	16V
C208	1-126-960-11	ELECT 1uF	50V
< DIODE >			
D101	8-719-047-70	DIODE 1A4	
D102	8-719-047-70	DIODE 1A4	
D103	8-719-047-70	DIODE 1A4	
D104	8-719-047-70	DIODE 1A4	

Ref. No.	Part No.	Description	Remarks
D105	8-719-054-32	DIODE ERA15-06	
D106	8-719-058-91	DIODE AG01A	
D107	8-719-920-32	DIODE ERA15-02	
D108	8-719-911-19	DIODE 1SS119	
D109	8-719-109-61	DIODE RD30ES	
D201	9-900-535-01	DIODE AU02Z	
D202	8-719-052-52	DIODE 31DF2-FC5	
D203	8-719-018-83	DIODE D2S4M	
D204	9-900-535-01	DIODE AU02Z	
D205	8-719-160-62	DIODE RD15FB2	
< FUSE >			
Δ F101	1-533-296-11	FUSE,	
< IC >			
Δ IC201	8-759-420-19	IC AN1431T	
< COIL >			
L101	1-403-598-11	LINE FILTER	
< PHOTOCOUPLER >			
Δ PC101	8-719-018-29	PHOTOCOUPLER ON3131	
< TRANSISTOR >			
Q101	8-729-904-98	TRANSISTOR 2SC4054	
Q102	8-729-012-31	TRANSISTOR 2SC4040Q	
< RESISTOR >			
R108	1-260-314-51	CARBON 68	1/2W
R109	1-260-314-51	CARBON 68	1/2W
R110	1-244-867-11	CARBON 560	1/4W
R110	1-244-868-11	CARBON	
R110	1-244-869-11	CARBON	
R110	1-244-870-11	CARBON	
R110	1-244-871-11	CARBON	
Δ	1-468-169-11	POWER BLOCK HS-821SF (CHILEAN,PX) ***** (Ref.No.:6,000 Series)	
< CAPACITOR >			
C108	9-980-072-01	ELECT 150uF	400V
C112	1-107-882-11	ELECT 100uF	16V
C201	1-126-967-11	ELECT 47uF	50V
C202	1-111-040-11	ELECT 820uF	16V
C203	1-126-936-11	ELECT 470uF	16V
C204	9-980-071-01	ELECT 1000uF	10V
C205	1-126-925-11	ELECT 470uF	10V
C206	1-104-661-11	ELECT 330uF	16V
C207	1-126-960-11	ELECT 1uF	50V
C212	1-126-964-11	ELECT 10uF	50V

Note :
The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Note :
Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifique.

POWER BLOCK

Ref. No.	Part No.	Description	Remarks
< DIODE >			
D101	8-719-510-88	DIODE	S1WBA60
D102	8-719-312-16	DIODE	EG01
D104	9-980-073-01	DIODE	1SS270A
D106	8-719-110-30	DIODE	RD12S
D201	8-719-052-89	DIODE	D1NL40
D202	8-719-018-25	DIODE	D2L20U
D203	8-719-018-83	DIODE	D2S4M
D204	8-719-026-52	DIODE	10ELS2
△D205	8-719-160-68	DIODE	RD18FB
< FUSE >			
△F101	1-532-203-11	FUSE	2A 250V
< IC >			
△IC101	9-939-634-01	IC	MIP164
△IC201	8-759-420-19	IC	AN1431T
< PHOTOCOUPLER >			
△PC101	8-749-924-84	PHOTOCOUPLER	PS2561
MISCELLANEOUS *****			
△11	1-762-844-21	SWITCH, ROTARY (L50, L70HF, X5)	
△58	1-468-168-11	POWER BLOCK SR701(EXCEPT Chilean, PX)	
△58	1-468-169-11	POWER BLOCK HS-821SF (Chilean, PX)	
△9	1-777-851-21	CORD, POWER(US, Canadian)	
△9	1-777-854-21	CORD, POWER(Mexican, Panamanian)	
△9	1-777-857-21	CORD, POWER(Chilean, PX)	

Ref. No.	Part No.	Description	Remarks
ACCESSORIES & PACKING MATERIALS *****			
	1-575-334-11	CORD, CONNECTION (FOR AUDIO/VIDEO)(1.5m)	
	1-696-592-11	CORD, CONNECTION (NTSC)(FOR RF)(1.5m)	
	1-769-181-41	MOUSE, INTERIENET CABLE (495, 695HF)	
	3-856-995-11	MANUAL, INSTRUCTION (ENGLISH) (675HF,676HF)	
	3-856-995-21	MANUAL, INSTRUCTION (FRENCH) (675HF:Canadian)	
	3-858-077-11	MANUAL, INSTRUCTION (SPANISH) (L50, L70HF, X5)	
	3-858-382-11	MANUAL, INSTRUCTION (SPANISH)(L40)	
	3-858-384-11	MANUAL, INSTRUCTION (SPANISH) (L60HF, X6HF)	
	3-858-385-11	MANUAL, INSTRUCTION (ENGLISH)(495)	
	3-858-385-21	MANUAL, INSTRUCTION (FRENCH) (495:Canadian)	
	3-858-386-11	MANUAL, INSTRUCTION (ENGLISH)(695HF)	
	3-858-386-21	MANUAL, INSTRUCTION (FRENCH) (695HF Canadian)	
	3-859-040-11	MANUAL, INSTRUCTION (ENGLISH)(685HF)	
*	3-961-581-01	SHEET, PROTECTION	
*	3-972-522-01	INDIVIDUAL CARTON (675HF)	
*	3-972-522-11	INDIVIDUAL CARTON (695HF)	
*	3-972-522-21	INDIVIDUAL CARTON (495)	
*	3-972-522-31	INDIVIDUAL CARTON (676HF)	
*	3-972-522-41	INDIVIDUAL CARTON (685HF)	
*	3-972-523-01	CUSHION	
*	3-972-525-01	SPACER	
*	3-973-678-02	INDIVIDUAL CARTON (L40)	
*	3-973-678-12	INDIVIDUAL CARTON (L50)	
*	3-973-678-22	INDIVIDUAL CARTON (L70HF)	
*	3-973-678-32	INDIVIDUAL CARTON (L60HF)	
*	3-973-678-42	INDIVIDUAL CARTON (X6HF)	
*	3-973-678-52	INDIVIDUAL CARTON (X5)	
***** HARDWARE LIST *****			
#1	7-682-547-04	SCREW +P 3X6	
#2	7-685-646-79	SCREW (3X8)	
#5	7-624-190-61	STOP RING 2 4, TYPE-CS	
#6	7-628-254-10	SCREW +PS2.6X6	
#7	7-624-106-04	STOP RING 3.0, TYPE-E	
#8	7-682-645-01	SCREW +PS3X4	

Note :
The components identified by mark △ or dotted line with mark △ are critical for safety
Replace only with part number specified

Note :
Les composants identifiés par une marque △ sont critiques pour la sécurité
Ne les remplacer que par une pièce portant le numéro spécifié.

SECTION 6 INTERFACE, IC PIN FUNCTION DESCRIPTION

6-1. SYSTEM CONTROL — MECHANISM BLOCK INTERFACE (MA-289 board IC160)

Signal	Pin No.	I/O	EJECTED	CASSETTE LOADING	CASSETTE UNLOADING	TAPE THREADING	TAPE UNTHREADING	STOP	FF	REW	PB	REC
CW	MA-289 Board IC160 ⑤	O	*5	H	L	H	L	*5	*5	*5	*5	*5
CAM	MA-289 Board IC160 ⑥	O	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5
MODE 1	MA-289 Board IC160 ⑦	I	—	—	—	—	—	H	H	H	H	H
MODE 2	MA-289 Board IC160 ⑧	I	—	—	—	—	—	L	L	L	H	H
MODE 3	MA-289 Board IC160 ⑨	I	—	—	—	—	—	H	H	H	L	L
MODE 4	MA-289 Board IC160 ⑩	I	—	—	—	—	—	H	L	L	L	L
REC PRF	MA-289 Board IC160 ⑪	I	L	*1	*1	*1	*1	*1	*1	*1	*1	*1
T REEL	MA-289 Board IC160 ⑫	I	H/L	H/L	H/L	H/L	H/L	H/L	*2	*2	*2	*2
S REEL	MA-289 Board IC160 ⑬	I	H/L	H/L	H/L	*2	*2	H/L	*2	*2	*2	*2
END LED	MA-289 Board IC160 ⑭	O	L	*3	*3	*3	*3	*3	*3	*3	*3	*3
T SENS	MA-289 Board IC160 ⑮	I	*3	*3	*3	*4	*4	*4	*4	*4	*4	*4
S SENS	MA-289 Board IC160 ⑯	I	*3	*3	*3	*4	*4	*4	*4	*4	*4	*4

- *1. "L" When erasing protection tab is bent. "H" when not bent.
- *2. Pulse of period in proportion to reel rotating speed.
- *3. Approx. 2 msec period "H" pulse when tape top or end is detected.
- *4. Normally "L". 2 msec period "H" pulse when tape top or end is detected.
- *5. Hi-Z

6-2. SYSTEM CONTROL — SERVO PERIPHERAL CIRCUIT INTERFACE (MA-289 board IC160)

Signal	Pin No.	I/O	STOP	FF	REW	TAPE THREADING	TAPE UNTHREADING	PB	REC
CTL IN+	MA-289 Board IC160 ⑰	O	*7	*7	*7	*7	*7	*7	*1
DRUM PG	MA-289 Board IC160 ⑱	I	*3	*3	*3	*3	*3	*3	*3
DRUM FG	MA-289 Board IC160 ⑲	I	*4	*4	*4	*4	*4	*4	*4
CAP FG	MA-289 Board IC160 ⑳	I	H/L	*2	*2	*5	*5	*2	*2
CAP REV	MA-289 Board IC160 ㉑	O	H/L	L	H	L	H	L	L
CAP ERR	MA-289 Board IC160 ㉒	O	L	*6	*6	*6	*6	*6	*6
DRUM ERR	MA-289 Board IC160 ㉓	O	*6	*6	*6	*6	*6	*6	*6

- *1. 30 Hz pulse
- *2. Pulse of period in proportion to tape speed.
- *3. 30 Hz "H" pulse.
- *4. 720 Hz pulse.
- *5. Unstable period pulse.
- *6. DC voltage 1 ~ 5V.
- *7. Hi-Z (2.5V).

6-3. SYSTEM CONTROL — SYSTEM CONTROL PERIPHERAL CIRCUIT INTERFACE (MA-289 board IC160)

Signal	Pin No.	I/O	I/O level
RESET	MA-289 Board IC160 ④	I	Normally "H". "L" when service interruption detected or restored.
I2C DATA I	MA-289 Board IC160 ⑤	I/O	Serial communication data to audio microprocessor.
I2C CLOCK I	MA-289 Board IC160 ⑥	O	Serial communication clock to audio microprocessor.
I2C DATA VIDEO	MA-289 Board IC160 ⑦	I/O	Serial communication data to video microprocessor.
I2C CLOCK VIDEO	MA-289 Board IC160 ⑧	O	Serial communication clock to video microprocessor.
(RP) S OUT1	MA-289 Board IC160 ⑨	I/O	Serial communication data to RP microprocessor
(RP) S CLK1	MA-289 Board IC160 ⑩	O	Serial communication clock to RP microprocessor.

6-4. SYSTEM CONTROL AND RF MODULATOR — INPUT SELECTION BLOCK INTERFACE (MA-289 board IC501)

Signal	Pin No.	I/O	I/O level
ANT SEL	MA-289 Board IC160 ⑪	O	"L" when RF modulator through.

6-5. SYSTEM CONTROL — VIDEO/RP BLOCK INTERFACE (MA-289 board IC160)

Signal	Pin No.	I/O	STOP/FF /REW	TAPE LOADING	TAPE UNLOADING	PB	REC	REC PAUSE
RF SWP	MA-289 Board IC160 ⑫	O	*1	*1	*1	*1	*1	*1
QVD	MA-289 Board IC160 ⑬	O	L	L	L	*2	L	L
REC P	MA-289 Board IC160 ⑭	O	L	L	L	L	L	H
C SYNC	MA-289 Board IC160 ⑮	I	*3	*3	*3	*3	*3	*3

- *1. Synchronized with drum rotation. 30Hz 50% duty pulse.
- *2. Normal "L". "H" when video signal is not rgenerated.
- *3. Composite sync signal (positive).

6-6. SYSTEM CONTROL — AUDIO BLOCK INTERFACE (MA-289 board IC160)

Signal	Pin No.	I/O	STOP/FF /REW	TAPE LOADING	TAPE UNLOADING	PB	REC	REC PAUSE
A MUTE	MA-289 Board IC160 ⑯	O	L	L	L	L	L	H

6-7. SERVO/SYSTEM CONTROL MICROPROCESSOR (MA-289 BOARD IC160)

Pin No.	Signal	I/O	Function
1	—	—	—
2	—	—	—
3	TU APT	I	Tuner analog AFT input
4	FUNC KEY 2	I	9 key input
5	FUNC KEY 1	I	9 key input
6	SSENS	I	Tape eod sensor
7	TSENS	I	Tape top sensor
8	VIDEO RF	I	Video RF input
9	AF ENV	I	HiFi envelope
10	—	—	—
11	—	—	—
12	STEREO	I	Tuner stereo detection input L Stereo
13	OVD	O	Quasi VD
14	REMOCON	I	Infrared ray catcher
15	F MONO	O	Forced mono
16	CAP RVS	O	Capstan reverse
17	I2C CLOCK 1	O	I2C clock (EEPROM, HiFi, PLL, MOD)
18	RF SWP	O	RF switching pulse
19	AF SWP	O	HiFi switching pulse
20	END LED	O	Eod sensor LED output
21	ANT SEL	O	TV/VTR RF modulator
22	PLL DATA	I/O	Tuner PLL data (TU/DEC data (EEPROM, HiFi, PLL, MOD))
23	PLL CLK	O	Tuner PLL clock
24	TENABLE	O	Tuner enable
25	SAP	I	SAP discrimination
26	MODE 4	I	Can encoding data 4
27	MODE 3	I	Can encoding data 3
28	MODE 2	I	Can encoding data 2
29	MODE 1	I	Can encoding data 1
30	RECPRF	I	Mis-record prevention switch signal input
31	DEST1	I	Destination discrimination input 1
32	DEST2	I	Destination discrimination input 2
33	DEST3	I	Destination discrimination input 3
34	NUB	I	Ground
35	NUA	I	Ground
36	CLKSEL	I	5V
37	VCC	I	5V
38	XIN	I	16MHz
39	XOUT	O	16MHz
40	VSS	I	Ground
41	XGIN	I	32kHz
42	XGOUT	O	32kHz
43	RESET	I	Reset signal input
44	NT JUDGE	I	L-NTSC
45	—	—	—
46	CBC ON	O	Cable box control signal output
47	VMUTE	O	Video-mute for EDS
48	AMUTE	O	Audio mute
49	REC P	O	HiFi audio record control
50	VFB	O	Audio record control L Playback

Pin No.	Signal	I/O	Function
51	I2C CLOCK VI	O	I2C clock (Video)
52	I2C DATA VI	O	I2C data (Video)
53	TA MUTE	O	Tuner-audio mute
54	DMS UP	I	DMS control
55	DMS DOWN	I	DMS control
56	P CONT M12	O	Motor 12V control
57	CAM	I/O	Cam motor control 1
58	CW	I/O	Cam motor control 2
59	P CONT SW12	O	SW 12V control
60	—	—	—
61	—	—	—
62	—	—	—
63	—	—	—
64	OSD CS	O	OSD chip select
65	SOUT 1	O	Serial out Ch1 (RP)
66	FLD CS	O	Fluorescent display driver chip select
67	SCLK 1	O	Serial clock Ch1 (RP)
68	SOUT 0	O	Serial out Ch0 (FLD, OSD)
69	SIN 0	I	Serial in Ch0 (FLD, OSD)
70	SCLK 0	O	Serial clock Ch0 (FLD, OSD)
71	—	—	—
72	BUTZER	I/O	Buzzer
73	SIRCS OUT	O	Remote control signal output (CBC)
74	MAINSAP	O	MAINSAP select
75	PFALL	I	Power fail detection input
76	T-OUT	O	Tuning-out
77	CAP ERR	O	Capstan error output
78	DRUM ERR	O	Drum error output
79	SREEL	I	Supply reel sensor
80	TREEL	I	Take-up reel sensor
81	—	—	—
82	CHECK	I	Check input
83	—	—	—
84	CSYNC	I	Composite sync signal input
85	CAPPG	I	Capstan PG signal input
86	DRMPG	I	Drum PG signal input
87	DRMPG	I	Drum PG signal input
88	AMP VSS	I	CTL-amp
89	AMP VREF OUT	O	CTL-amp
90	AMP VREF IN	I	CTL-amp
91	CTLIN-	I/O	CTL signal I/O
92	CTLIN+	I/O	CTL signal I/O
93	CTL SWOUT	O	CTL-amp
94	CTL AMP IN	I	CTL-amp
95	AMPFC	I	CTL-amp
96	CTL VSS	I	CTL-amp
97	CTL AMP OUT	O	CTL-amp
98	AMPVCC	I	CTL-amp
99	AVCC	I	ANSV
100	CTL-GAIN	O	CTL gain adjustment

SECTION 7 ADJUSTMENTS

7-1 MECHANICAL ADJUSTMENTS

For the mechanical adjustments, please refer to the "VHS MECHANICAL ADJUSTMENT MANUAL IV (H MECHANISM)" (9-973-623-11).

7-2. ELECTRICAL ADJUSTMENTS

See the adjusting part location diagram from on page 7-8 for the adjustment.

2-1. PREPARATION BEFORE ADJUSTMENT

2-1-1. Equipment Required

The measuring instruments used for this alignment include:

- 1) Monitor TV
- 2) Oscilloscope, dual-trace, bandwidth of 30MHz or more, with delay mode (A probe 10:1 should be used unless otherwise specified.)
- 3) Frequency counter
- 4) Pattern generator
- 5) Digital voltmeter
- 6) Audio generator
- 7) Audio level meter
- 8) Audio distortion meter
- 9) Audio attenuator
- 10) Alignment tapes
KRV-51N2 Part No. : 8-192-605-32

2-1-2. Equipment Connection

Unless otherwise specified, connect and adjust the measuring instruments as shown in the following diagram.




Fig. 7-2-1.

2-1-3. Input Signal Check

Video signal produced by a pattern generator is used as an adjustment signal to perform electrical alignment for this unit. This video signal must satisfy the specification.

Unless otherwise specified, place the switches and controls of this unit in the following positions:

- CHANNEL switch LINE

Connect an oscilloscope to the Video Input terminal. Check that the synchronizing signal of the Y signal has an amplitude of approximately 0.7V and that the burst signal has an amplitude of approximately 0.3V and its waveform is flat. And check that the level ratio of burst signal to "red" signal is 0.30 : 0.66. The video signal (color bar) used for electrical aligning this unit is shown in Fig. 7-2-2.




Fig. 7-2-2. Color Bar Signals of Pattern Generator

2-1-4. Alignment Tape

- Contents of KRV-51N2

	Mode	Period	Video signal	Audio signal	
				Hi-Fi	Normal
1	SP	7 minutes	Color bar	400Hz	400Hz
2		3 minutes	Monoscope		
3	EP	7 minutes	Color bar		
4		3 minutes	Monoscope		

2-1-5. Input/Output Levels and Impedance

Video input: LINE IN
 (phone jack) (1)
 Input signal: 1Vp-p, 75ohms, unbalanced, sync negative


Video output: LINE OUT
 (phone jack) (1)
 Output signal: 1Vp-p, 75ohms, unbalanced, sync negative

Audio input: LINE IN
 (phone jack) (1 : Monaural, 2 : Stereo)
 Input level: -7.5 dBs
 (0dBs= 0.775Vrms)
 Input impedance: more than 47 kilohms

Audio output: LINE OUT
 (phone jack) (1 : Monaural, 2 : Stereo)
 Standard level: -7.5dBs at load impedance 47 kilohms
 Output impedance: less than 10 kilohms

2-1-6. Adjustment Sequence

The adjustments should be performed in the following sequence.



2-2. POWER SUPPLY CHECK

2-2-1. Output Voltage Check (MA-289 Board)

Mode	E-E
Measuring Instrument	Digital voltmeter
SW 12V Check	
Measurement point	IC600 pin ②
Specified value	12.0 ± 0.3V
MTR12V Check	
Measurement point	D600 cathode
Specified value	12.4 ± 1.0V
SW5V Check	
Measurement point	Q602 emitter
Specified value	5.1 ± 0.2Vdc
D5V Check	
Measurement point	D161 cathode
Specified value	5.1 ± 0.3V

[Check Method]

1) Each of these supply voltages must meet its specified value.

2-3. SERVO SYSTEM CHECK

Unless otherwise specified, set the switches to the following positions.

- **CHANNEL** switch LINE
- **TAPE SPEED** switch SP

2-3-1. RF Switching Position Adjustment (MA-289 Board)

[Adjustment Purpose]

To adjust the link of the A-ch and B-ch of the tape playback outputs. To make the unit compatible with other tapes and units. If this specification is not satisfied, the link will appear on the screen and the screen will be disrupted, etc.

Mode	Playback
Signal	Alignment tape: SP color bar portion
Measurement point	CH1: Video LINE OUT terminal CH2: CN261 pin ③ (RF SWP)
Measuring instrument	Oscilloscope
Specified value	$6.5 \pm 0.5H$ ($410 \pm 32 \mu\text{sec}$)

[Adjustment Method]

- 1) Short-circuit between JS401 and ground on MA-289 board for about 1 second to activate the RF switching position adjustment mode.
- 2) Check that "ADJ" is indicated on FL display.
- 3) Using the channel + and - buttons, adjust to $410 \pm 32 \mu\text{sec}$ ($6.5 \pm 0.5H$).
- 4) Press the PAUSE button.
- 5) Press the EJECT button.




Fig. 7-2-3.

2-4. VIDEO SYSTEM CHECKS

For the video system checks, follow the checking procedures given below as a rule. The color bar video signal supplied from the pattern generator is used as the video input signal for the video system adjustment of the recording mode. Check that the signal satisfies the specified value designated in the "Check of input signal" (Fig. 7-2-2)

Unless otherwise specified, set the switches to the following positions.

- **CHANNEL** switch LINE
- **TAPE SPEED** switch SP

[Checking Sequence]

- 1) X'tal OSC Check
- 2) SYNC AGC Check
- 3) White clip/Dark clip Check
- 4) Recording Y Level Check
- 5) Recording Chroma Level Check
- 6) Playback Level Check

2-4-1. X'tal OSC Check (MA-289 Board)

Mode	Playback
Signal	Alignment tape: SP Color bar portion
Measurement point	IC201 pin ⑥
Measuring instrument	Oscilloscope and Frequency counter
Specified value	$3,579,545 \pm 70\text{Hz}$

Note: A frequency counter should be connected through a buffer amplifier (oscilloscope, etc.) having a high impedance and a low capacitance.

[Check Method]

- 1) Check that the oscillation frequency satisfies the specified value and that the oscillation voltage is $450 \pm 200\text{mVp-p}$.



$3,579,545 \pm 70\text{Hz}$

Fig. 7-2-4.

2-4-2. SYNC AGC Check (MA-289 Board)

Mode	E-E
Signal	Color bar
Measurement point	Video LINE OUT terminal
Measuring instrument	Oscilloscope
Specified value	$A=1.00 \pm 0.05V_{p-p}$ (75Ω terminated)

[Check Method]

- 1) Check that the Video signal level (A) satisfies the specified value.




Fig. 7-2-5.

2-4-3. White Clip/Dark Clip Check (MA-289 Board)

Mode	E-E
Signal	Color bar
Measurement point	IC201 pin ⑩
Measuring instrument	Oscilloscope
Specified value	White clip: $190 \pm 15\%$ Dark clip: $50 \pm 10\%$

[Check Method]

- 1) Check that the white clip level is $190 \pm 15\%$ to the white (100%) level.
- 2) Check that the dark chip level is $50 \pm 10\%$ to the white (100%) level.




Fig. 7-2-6.

2-4-4. Recording Y Level Check (MA-289 Board)

Mode	E-E
Signal	No-signal
Measurement point	IC201 pin ⑩
Measuring instrument	Oscilloscope
Specified value	$A=320mV$

[Check Method]

- 1) Check that the recording RF signal satisfies the specified value.




Fig. 7-2-7.

2-4-5. Recording Chroma Level Check (MA-289 Board)

Mode	Recording
Signal	Color bar
Measurement point	IC201 pin ⑩
Measuring instrument	Oscilloscope
Specified value	$A=380 \pm 40mV$

[Check Method]

- 1) Confirm the amplitude of recording chroma level becomes the specified value.




Fig. 7-2-8.

2-4-6. Playback Level Check (MA-289 Board)

Mode	Playback
Signal Alignment	Tape: SP mode color bar portion
Measurement point	Video LINE OUT terminal
Measuring instrument	Oscilloscope
Specified value	$A=1.00 \pm 0.02V_{p-p}$ (75 Ω terminated)

[Check Method]

- 1) Check that the playback level satisfies the specified value.




Fig. 7-2-9.

2-5. AUDIO SYSTEM ADJUSTMENT

- For the adjustment of the audio system, perform in the SP mode if there is no special notes. Use the alignment tape.
- Adjust both L-CH and R-CH (SLV-675HF/676HF/685HF/695HF/L60HF/L70HF/X6HF).

[Connecting Instruments]




Fig. 7-2-10.

- Hi-Fi Audio System Adjustment (SLV-675HF/676HF/685HF/695HF/L60HF/L70HF/X6HF)

Perform the adjustment setting the switches and controls on the following positions if there is no special indications.

- **CHANNEL** switch LINE
- **CHANNEL** switch ON *1)
- **TAPE SPEED** switch SP *1)

*1) Set by remote commander

2-5-1. AF Switching Position Adjustment (MA-289 Board)

[Adjustment purpose]

To adjust the link of the A-ch and B-ch of the tape playback outputs. If this specification is not satisfied, the noise will increase and cracking sounds will be produced.

Mode	Playback
Signal	Alignment tape: SP color bar portion
Measurement point	CH1: CN341 pin ① (AF ADJ) CH2: CN261 pin ③ (RF SWP)
Measuring instrument	Oscilloscope
Specified value	No dropouts in the RF signal

[Adjustment Method]

- 1) Short-circuit between JS401 and ground on MA-289 board for about 1 second to activate the RF switching position adjustment mode.
- 2) Check that "ADJ" is indicated on FL display.
- 3) Press the REC button to activate the AF switching position adjustment mode.
- 4) Using the channel + and - buttons, minimize a chipped portion. At this time, confirm that a noisy sound is not heard.
- 5) Press the PAUSE button.
- 6) Press the EJECT button TAPE SPEED




Fig. 6-2-11.

- Normal Audio System Adjustment
- Adjust in the SP mode if there is no special indications.
- Perform the adjustment setting the switch on the following positions.

- **CHANNEL** switch LINE
- **AUTO STEREO** switch OFF *1

*1) Set by remote commander. (SLV-675HF/676HF/685HF/695HF/L60HF/L70HF/X6HF)

[Adjustment Method]

1. ACE head adjustment....Refer to the VHS mechanical adjustment manual IV.
2. E-E output level check
3. Overall Output level and distortion factor check
4. Overall noise level check.

2-5-2. ACE Head Adjustment

Refer to the "VHS mechanical adjustment manual IV" (9-973-623-11).

2-5-3. E-E Output Level Check

Mode	E-E
Signal	400Hz, -7.5dBs: Audio LINE IN
Measurement point	Audio LINE OUT terminal
Measuring instrument	Audio level meter
Specified value	-7.5 ± 2dBs

[Check Method]

- 1) Input signal of 400Hz and -7.5dBs to the audio input.
- 2) Check that the audio output level is -7.5 ± 2dBs.

2-5-4. Overall Output Level and Distortion Factor Check

Mode	Self-record playback
Signal	400Hz, -7.5dBs: Audio LINE IN
Measurement point	Audio LINE OUT terminal
Measuring instrument	Audio level meter and Distortion meter
Specified value	Playback Level: -7.5 ± 3dBs Distortion: 4.0% or less

[Check Method]

- 1) Input signal of 400Hz and -7.5dBs to the audio input.
- 2) Record signal.
- 3) Playback the recorded portion.
- 4) Check that the output level is -7.5 ± 3dBs.
- 5) Check that the distortion factor is 4.0% or less.

2-5-5. Overall Noise Level Check

Mode	Self-record playback
Signal	No signal (Insert a shorting plug into the Audio LINE IN terminal)
Measurement point	Audio LINE OUT terminal
Measuring instrument	Audio level meter (IHF-A weighing filter is used)
Specified value	- 46dBs or less

[Check Method]

- 1) Record.
- 2) Playback recorded portion.
- 3) Check that noise level is - 46dBs or less.

2-6. TUNER SYSTEM ADJUSTMENT

2-6-1. Separation Adjustment (MA-289 Board)

Mode	E-E
Signal	RF signal Video : Color bar (100%) white modulation Audio : Mono 400Hz 100% modulation Electrical field: 60-80dBm/75Ω terminated
Measuring instrument	Audio level meter
Measuring point	IC733 pin ⑬ (MPX IN)
Adjusting element	RV731
Specified value	- 9.9 ± 0.1dbm

[Adjustment Method]

- 1) Feed the RF signal from RF IN terminal.
- 2) Adjust with RV731 so that the output level satisfies the specified value.

2-7. ADJUSTMENT PARTS LOCATION DIAGRAM

MA-289 BOARD (CONDUCTOR SIDE)

