

**SLV-640HF/733HF/733HFCS/733HFMX/733HFPA/740HF/740HFPX
/741HF/780HF/781HF/940HF/940HFCS/940HFMX/940HFPX
RMT-V154C/V158/V161/V162/V164B**

SERVICE MANUAL

SLV-640HF/740HF/740HFPX/741HF/780HF/781HF/940HF/940HFPX



Photo: SLV-940HF/RMT-V158

Remote commander is available as a unit. See page 5-1 for repair parts.

Refer to the SERVICE MANUAL of VHS MECHANICAL ADJUSTMENT IV (H MECHA) for MECHANICAL ADJUSTMENTS. (9-973-623-11)

US Model

Canadian Model

SLV-640HF/740HF/741HF/780HF/940HF

Mexican Model

SLV-733HFMX/940HFMX

Panama Model

SLV-733HFPA

Chilean Model

SLV-733HFCS/940HFCS

Tourist Model

SLV-733HF



H MECHANISM

SPECIFICATIONS

System

Format

VHS NTSC standard

Video recording system

Rotary two-head helical scanning FM system

Video signal

NTSC color, EIA standards

Tape speed

SP: 33.33 mm/s (1.318 inches/s)
EP: 11.11 mm/s (0.716 inches/s)
LP: 16.67 mm/s (1.176 inches/s),
playback only

Maximum recording/playback time

8 hrs. in EP mode (with T-160 tape)

Fast-forward and rewind time

Approx. 3 min. (with T-130 tape)

Tuner section

Channel coverage

VHF 2 to 13
UHF 34 to 69
CATV A-6 to A-1, A to W, W-1 to
W+84

Antenna

75-ohm antenna terminal for
VHF/UHF

Inputs and outputs

LINE IN 1 and 2

VIDEO IN, phono jack (1 each)
Input signal: 1 V_{pp}, 75 ohms,
unbalanced, sync negative
AUDIO IN, phono jack (2 each)
Input level: -7.5 dBs (0 dBs =
0.775 Vrms)
Input impedance: more than
47 kilohms

LINE OUT

VIDEO OUT, phono jack (1)
Output signal: 1 V_{pp}, 75 ohms,
unbalanced, sync negative
AUDIO OUT, phono jack (2)
Standard output: -2.5 dBs
Load impedance: 47 kilohms
Output impedance: less than
10 kilohms

CONTROL 5 IN

Mini jack (1)

**CABLE BOX CONTROL
(CONTROL 5 OUT)**

Mini jack (plug in power) (1)

Timer section

Clock

Quartz locked

Timer indication

12-hour cycle

Timer setting

Only for recording 8 programs in
one month at max.

Power back-up

Pull-in self-charging capacitor
Back-up duration:
up to three hours at time time (for
SLV-940HF/940HF PX)
up to one hour at one time (for
SLV-940HF CS/940HF ATX)

General

Power requirements

110 V AC, 60 Hz
(for SLV-640HF/940HF MX)
110 V AC to 240 V AC, 50/60 Hz
(for SLV-940HF CS/940HF PX)

Power consumption

27 W (max.) (for SLV-940HF)
24 W (max.) (for SLV-940HF CS/
940HF MX/940HF PX)

Operating temperature

5°C to 40°C (41°F to 104°F)

— continued on next page —



VIDEO CASSETTE RECORDER
SONY

Storage temperature

-20°C to 60°C (-4°F to 140°F)

Dimensions

Approx. 430 x 103 x 323 mm
 (w/h/d)
 Approx. (17 x 4 x 12 1/4 inches)
 Including projecting parts and
 controls

Weight

Approx. 5.2 kg (11 lb 7 oz)

Supplied accessories

Remote commander (1)
 Size AA (R6) batteries (2)
 75-ohm coaxial cable with F-type
 connectors (1)
 AC power cord (1)
 Audio/video cable (3 phono to 3 phono)
 (1)
 Cable Mouse (cable box controller) (1)
 Plug adaptor (1)
 (SLV-940HF/CS990HF/PX only)

The remote commander used for each model is as follows.

- RMT-V154C: SLV-640HF
- RMT-V162: SLV-740UF/740HFPX/741BF
- RMT-V164B: SLV-733HF/733HFPX/733HFMX/733HFPX
- RMT-V161: SLV-780HF/7811F
- RMT-V155: SLV-940HF/940HFPX/940HFMX/940HFPX

Design and specifications are subject to
 change without notice.

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
5. Check the line cord for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
6. Check the B+ voltage to see it is at the value specified.
7. Check the antenna terminals, metal trim, "metalized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)




Fig. A. Using an AC voltmeter to check AC leakage.

SAFETY-RELATED COMPONENT WARNING!

COMPONENTS IDENTIFIED BY MARK Δ OR DOTTED LINE WITH MARK Δ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE Δ SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY OÙ LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
SERVICE NOTE					
1	Removal of Drum Assembly	5			
2	Upper Drum Replacement	5			
2-1	Removal of Upper Drum	5			
2-2	Mounting Upper Drum	5			
3	Periodic Check and Replacement	6			
3-1	Cleaning of Rotating Head Disk Assembly	6			
3-2	Cleaning of the Tape Movement System	6			
3-3	Cleaning the Drive System	6			
1. GENERAL					
•	Welcome/	1-1			
•	Step 1: Unpacking	1-1			
•	Step 2: Setting up the remote commander	1-2			
•	Step 3: Hookups	1-3			
•	Selecting a language (Canadian Model only)	1-9			
•	Setting the clock	1-10			
•	Presetting channels	1-11			
•	Setting up cable box control	1-13			
•	Setting up VCR Plus+	1-14			
•	Using the ADVANCED OPTIONS	1-15			
•	Playing a tape	1-16			
•	Recording TV programs	1-18			
•	Recording TV programs using the timer	1-20			
•	Recording TV programs using VCR Plus+	1-21			
•	Checking/charging/cancelling timer settings	1-22			
•	Playing/searching at various speeds	1-23			
•	Adjusting the picture	1-24			
•	Searching using the Index function	1-24			
•	Editing with another VCR	1-25			
•	Insert editing	1-26			
•	Synchronized editing	1-27			
•	General setup information	1-28			
•	Index to parts and controls	1-28			
2. DISASSEMBLY					
2-1	Removal of Upper Case	2-1			
2-2	Removal of Front Panel Assembly	2-1			
2-3	Removal of Control Switch Block	2-2			
2-4	Removal of MF-253/274 Board	2-2			
2-5	Removal of HI-5/19 Board	2-3			
2-6	Removal of Bottom Plate	2-3			
2-7	Removal of PS-327/349 Board	2-4			
2-8	Removal of ED-40/43 Board and HF-34 Board	2-4			
2-9	Removal of RV-36/45 Board	2-5			
2-10	Removal of MA-214 Board	2-5			
2-11	Removal of MD Block Assembly	2-6			
2-12	Mechanical Internal Views	2-7			
2-13	Circuit Boards Location	2-8			
3. BLOCK DIAGRAMS					
3-1	Overall Block Diagram	3-1			
3-2	Video Block Diagram	3-5			
3-3	Servo/System Control Block Diagram	3-9			
3-4	Tuner/Tuner/Mode Control Block Diagram	3-11			
3-5	Audio Block Diagram	3-14			
3-6	Tuner Block Diagram	3-17			
3-7	Power Block Diagram	3-19			
4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS					
4-1	Frame Schematic Diagram	4-1			
4-2	Printed wiring Boards and Schematic Diagrams	4-3			
•	This Note is Common for Printed Wiring Boards and Schematic Diagrams	4-3			
•	RV-36/45 Board	4-4			
•	MA-214 (SERVO/SYSCON) and IC-37/65 Board	4-13			
•	MA-214 (INPUT/OUTPUT, TUNER)	4-17			
•	ED-40/43 Board	4-21			
•	HF-34 Board	4-25			
•	HI-5/19 and MF-253/274 Board	4-30			
•	PS-327/349 Board	4-37			
5. REPAIR PARTS LIST					
5-1	EXPLODED VIEWS	5-1			
5-1-1	Case Assembly	5-1			
5-1-2	Front Panel Assembly	5-2			
5-1-3	Chassis Assembly	5-4			
5-1-4	Mechanical Deck Assembly (1)	5-6			
5-1-5	Mechanical Deck Assembly (2)	5-7			
5-1-6	Mechanical Deck Assembly (3)	5-8			
5-1-7	Mechanical Deck Assembly (4)	5-9			
5-2	ELECTRICAL PARTS LIST	5-10			
•	DC-57/65 Board	5-10			
•	ED-40/43 Board	5-10			
•	HF-34 Board	5-11			
•	HI-5/19 Board	5-12			
•	MA-214 Board	5-14			
•	MF-253/274 Board	5-21			
•	PS-327/349 Board	5-21			
•	RV-36/45 Board	5-23			
•	Hardware List	5-27			
6. INTERFACE AND IC PIN FUNCTION					
6-1	System Control—Video Block Interface (MA-214 Board IC201)	6-1			
6-2	System Control—Servo Peripheral Circuit Interface (MA-214 Board IC201)	6-2			
6-3	System Control—Mechanism Block Interface (MA-214 Board IC201)	6-3			
6-4	System Control—System Control Peripheral Circuit Interface (MA-214 Board IC201)	6-4			
6-5	System Control—Audio Block Interface (MA-214 Board IC201)	6-4			
6-6	System Control—RF Modulator, Input Section Block Interface (MA-214 Board IC201)	6-4			
6-7	Servo/System Control Microprocessor CXP87240 057Q (MA-214 Board IC201) Port Function Description	6-5			
6-8	Timer/Tuner Control Microprocessor MR89096PP-G-156-BND (HI-5/19 Board IC302) Port Function Description	6-7			

<u>Section</u>	<u>Title</u>	<u>Page</u>
7.	ADJUSTMENTS	
7-1.	MECHANICAL ADJUSTMENTS	7-1
7-2.	ELECTRICAL ADJUSTMENTS	7-1
2-1.	Preparation Before Adjustment	7-1
2-1-1.	Equipment Required	7-1
2-1-2.	Equipment Connection	7-2
2-1-3.	Check of Input Signal	7-2
2-1-4.	Alignment Tape	7-2
2-1-5.	Specified Input - Output Level and the Impedance	7-2
2-1-6.	Adjustment Procedures	7-2
2-2.	Power Supply Check	7-3
2-2-1.	Output Voltage Check	7-3
2-3.	Servo System Adjustment	7-3
2-4.	System Control/Timer System Adjustment	7-4
2-4-1.	Clock Adjustment	7-4
2-5.	Video System Adjustment	7-4
2-5-1.	X'tal OSC Check	7-4
2-5-2.	SYNC AGC Check	7-5
2-5-3.	White Clip/Dark Clip Check	7-5
2-5-4.	Y FM Carrier Frequency Check	7-5
2-5-5.	Playback Y Level Check	7-6
2-6.	Audio System Adjustment	7-6
2-6-1.	VCO f_0 Adjustment	7-7
2-6-2.	Deviation Check	7-7
2-6-3.	Band Pass Filter f_0 Adjustment	7-8
2-6-4.	AF Switching Position Adjustment	7-8
2-6-5.	ACE Head Adjustment	7-9
2-6-6.	Recording Bias Adjustment	7-9
2-6-7.	E-E Output Level Check	7-9
2-6-8.	Overall Output Level and Distortion Factor Check	7-9
2-6-9.	Overall Noise Level Check	7-9
2-7.	Adjustment Parts Location Diagram	7-10

SERVICE NOTE

1. REMOVAL OF DRUM ASSEMBLY

- 1) Remove the screw ① (P3×8)
- 2) Remove the shaft ground assembly ②.
- 3) Remove three screws ③ (P3×6).
- 4) Remove the drum assembly ④.

Note: When attaching the drum assembly, be careful not to blur the contacting surface with fingerprint or like.

When attaching the shaft ground assembly, be careful not to apply force to the spring section of it.




Fig. 1.

2. UPPER DRUM REPLACEMENT

2-1. Removal of Upper Drum

- 1) Remove the screw ① (P3×8).
- 2) Remove the shaft ground assembly ②.
- 3) Completely remove the rotary upper drum board and desolder the soldering indicated by the arrows. (16 points)
- 4) Remove the screws ③ (PSW 3×8) and tap out the rotary upper drum assembly in the direction of arrow. (See Fig. 3.)

If it is difficult, remove by shaking the rotary upper drum gradually.

Note: If the drum can not be removed, check whether the solders have been removed or not again.

2-2. Mounting Upper Drum

- 1) Mount the rotary upper drum assembly by aligning marked \blacktriangle with marked \blacktriangle of rotary transformer board (lower drum) so that the screw holes of both upper and lower drums match.




Fig. 2.

Note: When inserting the rotary upper drum assembly into the lower drum, be careful not to blur the contacting surface with fingerprint or like.

- 2) If it is difficult, mount the upper drum by shaking it gradually.

Note: Be careful not to damage the head.

Make sure that the upper drum is tightly inserted.

- 3) Tighten two screws ④ (PSW3×8).
- Note:** Temporary tighten two screws. After making sure that upper drum is tightly inserted, tighten the screws.




Fig. 3.

- 4) Solder 16 points on the rotary upper drum board (See FIG. 2)
- 5) Fix the shaft ground assembly ② using the screw ① (P3 - 8) so that the protrusion of the shaft ground assembly end contacts the center of the drum shaft. (See Fig. 2.)
Note: When attaching the shaft ground assembly, be careful not to apply force to the spring section of it.
- 6) Tighten the screw ③ (P3-8).

3. PERIODIC CHECK AND REPLACEMENT

In order to obtain the best performance from this unit and make full use of its capabilities, and to extend the life of the unit and tapes, it is recommended that the following periodic checks and maintenance be performed.

- The following must be done after every repair regardless of how many hours the user has operated the machine.

3-1. CLEANING OF ROTATING HEAD DISK ASSEMBLY

- 1) Press a chamouis cloth (Jig Ref. No. J-9) which has been dipped in cleaning fluid (Jig Ref. No. J-5) lightly against the rotating drum assembly, then do the cleaning by slowly rotating the rotating head disk by hand. (Never try to clean by using the motor to turn it.)
- 2) Never try to clean by moving the chamouis cloth at a

vertical angle to the head tip. There is a very great danger of damaging the head tip if this is done.

3-2. CLEANING OF THE TAPE MOVEMENT SYSTEM

- 1) Clean the surfaces which the tape contacts during its movement (tape guide, drum assembly surface, capstan, pinch roller, etc.) with a chamouis cloth that has been dipped in cleaning fluid.

3-3. CLEANING THE DRIVE SYSTEM

- 1) Clean the driving parts with a cloth that been dipped in cleaning fluid.




Fig. 4. Parts requiring cleaning

SECTION 1
GENERALThis section is extracted from
SLV-940HF instruction manual.

Welcome!

Thank you for purchasing the Sony Video Cassette Recorder (VCR).
Here are some of the features you'll enjoy with your VCR.

- Easy Set-Up feature allows you to use the clock, cable box control and preset channels easily using the EASY SET UP button.
- Auto-Link™ Set feature that sets and adjusts the time and date automatically.
- Cable box control line allows your VCR to control digital satellite receivers and cable boxes.
- VCR Tracer™ system helps you quickly and easily locate the VCR in record progress.
- Adaptive Picture Control (APC) that automatically optimizes recording and playback performance.
- Remote controls that feature multi-direction TV control.
- Ejecting tape head that allows faster cassette ejection with less noise.

* To obtain useful data, refer to the Customer Development Center. VCR
has a system requiring special tape from Special Equipment Company.

Check that you have the following items:

- Remote controller



- Size AA (R6) batteries



- Audio/Video cable
(3 options to 3-pins)



- Cable Modem (cable box
controller)



- 75-ohm coaxial cable with
F-type connectors



- AC power cord
(SLV-3000V/3000V MF)



- Plug adapter
(SLV-3000V/3000V FX only)




SLV-3000V/3000V FX



Step 2: Setting up the remote commander


- Notes**
- With instruction, the remote commander is pre-programmed to control most Sony TVs. If your TV is listed below, you can set the appropriate model's (MFR's) code number.
 - If you do not see the code number listed for your TV, you can use the manual method for setting up the remote commander.
 - Do not use a new battery.
 - Do not use alkaline (1.5V) or lithium (3V) batteries.

Inserting the batteries
Insert two size AA (LR6) batteries by pushing the slider on the battery holder in the direction inside the battery compartment.



Using the remote commander

You can use the remote commander to operate the VCR and a Sony TV. To operate the VCR, set the COMMAND MODE switch on the remote commander to the VCR position. To operate the TV, set the switch to any of the TV positions. The POWER, VCR, TV, CH 1-7, TV/VIDEO, and SLEEP buttons are used to operate the VCR and TV. Holding on the remote commander makes sense to operate your TV.



6 Getting started

Getting started 7

Controlling other TVs with the remote commander
The remote commander is pre-programmed to control most Sony TVs. If your TV is listed below, you can set the appropriate model's (MFR's) code number.

- 1 Set **[0000]** on the top of the remote commander to **[0000]**.
- 2 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 3 Press **[TV]** on the top of the remote commander to **[0000]**.
- 4 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 5 Press **[TV]** on the top of the remote commander to **[0000]**.
- 6 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 7 Press **[TV]** on the top of the remote commander to **[0000]**.
- 8 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 9 Press **[TV]** on the top of the remote commander to **[0000]**.
- 10 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 11 Press **[TV]** on the top of the remote commander to **[0000]**.
- 12 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 13 Press **[TV]** on the top of the remote commander to **[0000]**.
- 14 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 15 Press **[TV]** on the top of the remote commander to **[0000]**.
- 16 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 17 Press **[TV]** on the top of the remote commander to **[0000]**.
- 18 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 19 Press **[TV]** on the top of the remote commander to **[0000]**.
- 20 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 21 Press **[TV]** on the top of the remote commander to **[0000]**.
- 22 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 23 Press **[TV]** on the top of the remote commander to **[0000]**.
- 24 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 25 Press **[TV]** on the top of the remote commander to **[0000]**.
- 26 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 27 Press **[TV]** on the top of the remote commander to **[0000]**.
- 28 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 29 Press **[TV]** on the top of the remote commander to **[0000]**.
- 30 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 31 Press **[TV]** on the top of the remote commander to **[0000]**.
- 32 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 33 Press **[TV]** on the top of the remote commander to **[0000]**.
- 34 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 35 Press **[TV]** on the top of the remote commander to **[0000]**.
- 36 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 37 Press **[TV]** on the top of the remote commander to **[0000]**.
- 38 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 39 Press **[TV]** on the top of the remote commander to **[0000]**.
- 40 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 41 Press **[TV]** on the top of the remote commander to **[0000]**.
- 42 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 43 Press **[TV]** on the top of the remote commander to **[0000]**.
- 44 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 45 Press **[TV]** on the top of the remote commander to **[0000]**.
- 46 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 47 Press **[TV]** on the top of the remote commander to **[0000]**.
- 48 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 49 Press **[TV]** on the top of the remote commander to **[0000]**.
- 50 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 51 Press **[TV]** on the top of the remote commander to **[0000]**.
- 52 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 53 Press **[TV]** on the top of the remote commander to **[0000]**.
- 54 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 55 Press **[TV]** on the top of the remote commander to **[0000]**.
- 56 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 57 Press **[TV]** on the top of the remote commander to **[0000]**.
- 58 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 59 Press **[TV]** on the top of the remote commander to **[0000]**.
- 60 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 61 Press **[TV]** on the top of the remote commander to **[0000]**.
- 62 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 63 Press **[TV]** on the top of the remote commander to **[0000]**.
- 64 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 65 Press **[TV]** on the top of the remote commander to **[0000]**.
- 66 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 67 Press **[TV]** on the top of the remote commander to **[0000]**.
- 68 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 69 Press **[TV]** on the top of the remote commander to **[0000]**.
- 70 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 71 Press **[TV]** on the top of the remote commander to **[0000]**.
- 72 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 73 Press **[TV]** on the top of the remote commander to **[0000]**.
- 74 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 75 Press **[TV]** on the top of the remote commander to **[0000]**.
- 76 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 77 Press **[TV]** on the top of the remote commander to **[0000]**.
- 78 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 79 Press **[TV]** on the top of the remote commander to **[0000]**.
- 80 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 81 Press **[TV]** on the top of the remote commander to **[0000]**.
- 82 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 83 Press **[TV]** on the top of the remote commander to **[0000]**.
- 84 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 85 Press **[TV]** on the top of the remote commander to **[0000]**.
- 86 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 87 Press **[TV]** on the top of the remote commander to **[0000]**.
- 88 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 89 Press **[TV]** on the top of the remote commander to **[0000]**.
- 90 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 91 Press **[TV]** on the top of the remote commander to **[0000]**.
- 92 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 93 Press **[TV]** on the top of the remote commander to **[0000]**.
- 94 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 95 Press **[TV]** on the top of the remote commander to **[0000]**.
- 96 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 97 Press **[TV]** on the top of the remote commander to **[0000]**.
- 98 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.
- 99 Press **[TV]** on the top of the remote commander to **[0000]**.
- 100 Press **[POWER]** and **[TV]** simultaneously for 5 seconds. The TV code number will be stored in the remote commander's memory.

Code numbers of compatible TVs
If you do not see the code number in the list, you can set a code number to the remote commander by using the manual method.

Manufacturer	Code number	Manufacturer	Code number
Sony	0	Hitachi	10
Aiat	1	Philips	8
AOC	4	Thorn	16
Commax	22	Vertical	3
Conquest	3	Quasar	6, 15
Crownpoint	12	Tele-Track	5, 11
Genpak	42	VCA	4, 18
Inter	11	Sharp	17
General Electric	4, 16	Sony	18
Hitachi	2, 5	Sony	12
JCI Video	5, 12	Sony	2, 10, 11
JVC	9	Sony	2, 3, 16
MMC	3	Sony	6, 12
Hi-Fi	2, 5, 12	Toshiba	3, 6, 14
Hi-Fi	6, 11	Toshiba	7
Hi-Fi	6, 11, 17	Thorn	1, 2, 3, 4, 13
MRC	5, 12	Von	12
Thorn	8, 15	Zenith	15

Step 3: Hookups

Caution
 Connecting the power cable to the TV without first making sure that the correct settings are in place may result in damage to the TV. Before connecting the power cable, be sure to read the instructions for the TV.

Connections Overview
 The connections for the VCR are shown in the diagram on the right. The VCR is connected to the TV by the video and audio cables. The VCR is also connected to the TV by the power cable.

Note on CATV systems
 This receiver is provided in a standard configuration. It is not intended for use with CATV systems.

Power
 The receiver is provided in a standard configuration. It is not intended for use with CATV systems. The receiver is provided in a standard configuration. It is not intended for use with CATV systems.

Selecting the best hookup option

Before you use your VCR for the first time, you need to connect it to your TV, and set it up to receive programs by viewing and recording. This section explains how to hook up and set up your VCR so that you can start enjoying it right away. There are, however, many types of TVs on the market, and many different models of VCRs. You have to choose the best hookup option for your TV and VCR.

To hook up your VCR so that it works best for you, first turn through the steps below. Then use the accompanying diagrams and procedures on the following pages to set up your VCR.

Step	What to do	Refer to
1	TV that has audio/video inputs	Audio/video (A/V) hookups, Page 9
2	TV that has audio/video inputs	Audio/video (A/V) hookups, Page 9
3	Check the video compatibility with the TV	Page 10
4	Check the video compatibility with the VCR	Page 10
5	Check the video compatibility with the VCR	Page 10
6	Check the video compatibility with the VCR	Page 10
7	Check the video compatibility with the VCR	Page 10
8	Check the video compatibility with the VCR	Page 10
9	Check the video compatibility with the VCR	Page 10
10	Check the video compatibility with the VCR	Page 10
11	Check the video compatibility with the VCR	Page 10
12	Check the video compatibility with the VCR	Page 10
13	Check the video compatibility with the VCR	Page 10
14	Check the video compatibility with the VCR	Page 10
15	Check the video compatibility with the VCR	Page 10
16	Check the video compatibility with the VCR	Page 10
17	Check the video compatibility with the VCR	Page 10
18	Check the video compatibility with the VCR	Page 10

After you've completed the connections, follow the instructions for setting up the VCR. Make sure you read the instructions for the VCR. The instructions for the VCR are provided in the manual that came with the VCR. If you need more details on the procedure described, page numbers are provided where you can find complete, step-by-step instructions.

After you've completed the setup, you're ready to use your VCR. For more information, see the instructions for the VCR. The instructions for the VCR are provided in the manual that came with the VCR.

Before you get started:

- Read the power and safety instructions.
- Check the power and safety instructions for the TV and the connections are completed.
- Be sure you make connections firmly. Loose connections may cause picture distortions.
- If your TV doesn't match any of the examples provided, see your nearest Sears dealer or qualified installation.


Audio-video (A/V) hookups

If your TV has audio-video (A/V) inputs, you will just need to connect the VCR to the TV. The VCR will be connected to the TV by the video and audio cables. The VCR will be connected to the TV by the video and audio cables. The VCR will be connected to the TV by the video and audio cables.


If you're planning to use your VCR only to play back pictures and movies, you'll need to hook up the VCR to your TV. The VCR will be connected to the TV by the video and audio cables. The VCR will be connected to the TV by the video and audio cables. The VCR will be connected to the TV by the video and audio cables.

For more information, see the instructions for the VCR. The instructions for the VCR are provided in the manual that came with the VCR.

A. Use this hookup if your TV has stereo jacks




B. Use this hookup if your TV doesn't have stereo jacks



A/V Hookups VCR Setup

After you've connected your TV and completed power or cable hookup, use the following procedure to set up the VCR.



For details, see page 10.


Make sure you've read the power and safety instructions for the VCR.

Hookup 3


Make the following connections if you're using an antenna (if you don't have cable TV).

Antenna hookup

- Use the hookup if you're using:
 - UHF antenna (see page 16)
 - UHF antenna (see page 16) and separate L or H antenna
 - separate VHF and UHF antenna



- Use this hookup if you're using a VHF-only antenna (you get channels 3-13 only)



If you don't connect your antenna cable to the VCR directly, a power antenna cable or a flat cable (200-ohm twin lead cable), which is a special antenna connector that supplies the two you can connect the cable to the UHF/LIGHT connections. If you have separate cables for VHF and UHF antennas, you may use a U-V band filter (see page 16). For details, see page 18.

Hookup 3: VCR setup


- 1 Set the UHF/LIGHT switch on CH 3 on CH 4, whichever channel you use to receive cable TV. If both are set, set the switch to either channel. If you use a VHF connection (see page 16), you can skip this step.




- 2 Press **BACK** SET UP on the VCR. The SET UP screen appears.




- 3 Channel master code? Change the UHF/VHF filter frequency if you're using a power antenna and need UHF/LIGHT.




- 4 No UHF/LIGHT switch? Press **UHF/LIGHT** on the remote control. For details, see page 12.




- 5 The cable is not connected. Check the cable connections on the TV, VCR, or L. For details, see page 12.



- 6 The VCR is not ready to receive cable. Check the cable connections on the TV, VCR, or L. For details, see page 12.




- 7 The VCR is not ready to receive cable. Check the cable connections on the TV, VCR, or L. For details, see page 12.



Hookup 3: VCR Plus+ channel setup

- 1 Find the VCR Plus+ Channel List on your program guide. For details on the VCR Plus+ Channel List, see page 21.

- 2 If the channels in the program guide are different from the channels that you should see on your TV, set the channels that are different to follow.



For details, see page 21.

Automatic check setting

Once you've set up the VCR, it automatically sets the clock. The first time you turn off the VCR. After that, whenever you turn off the VCR, it checks if the clock displays the current time. If not, it adjusts the clock automatically. The clock is set to the time zone that the start is provided by some TV channels. You can set the date and even adjust the Daylight Saving Time. If you want to make a time to record right away, or if you want to make a time to record on the day, you can set the clock manually. For details, see page 19-24.

You are now ready to use your VCR

A Quick reference to operations is provided on the back cover to help you quickly enjoy the basic functions. These procedures differ slightly depending on the hookup used. Make a note of which hookup you used (Hookup 1) so that you can always follow the correct instructions.

Insidup 6


Incompatible cable box with many scrambled channels

Recommended use

Use this hookup for cable boxes that cannot accept a cable box that is incompatible with the VCR. Cable box channel numbers and your cable system locations all are used **UNLESS**.

When you can and want to do with this hookup:

- Record any channel by entering the channel on the cable box
- When you want to:
 - Record with the cable box, record all
 - Record with the VCR, record all
 - Record by entering the channel directly with the VCR



Insidup 4: VCR setup

- 1 Set the TV UNIT switch on CH3 or CH4, whichever channel is not used by your system. Turn the switch on the TV set with an antenna or cable. If you make A/V connections from page 16, you can skip this step.



2 Turn on your cable box

- 3 Press **FAST SET UP** on the VCR.



- 4 **Channel number** (1-99) Change the channel with language in French (FR), Spanish (ES), and other languages. For details, see page 21.

- 5 The **VIDEO** (1) menu. The menu shows the video format and video DISPLAY. For details, see page 24.

- 6 The **VIDEO** (2) menu. The menu shows the video format and video DISPLAY. For details, see page 24.


- 7 The **VIDEO** (3) menu. The menu shows the video format and video DISPLAY. For details, see page 24.

- 8 The **VIDEO** (4) menu. The menu shows the video format and video DISPLAY. For details, see page 24.

- 9 The **VIDEO** (5) menu. The menu shows the video format and video DISPLAY. For details, see page 24.

Insidup 3: VCR Plus! channel setup

- 1 Press the VCR Plus! Channel Setup key on your remote. For details on the VCR Plus! Channel Setup, see page 31.
- 2 Enter all the channels you want to record with the cable box output channel locally 2, 3, or 4:



Make sure you have set the channel correctly on the cable box for each recording.

Automatic channel setting

Since the channels have to be selected manually on the cable box with this hookup, the Auto-CH3 Set (option) will not function fully (page 22). If you want to set the Auto-CH3 Set, set feature to help available, proceed as follows:

- 1 Turn the cable box to a channel that carries a live signal.
- 2 Leave the cable box on.
- 3 Turn on the Auto-CH3 Set feature.
- 4 Turn off the VCR.

You are now ready to use your VCR

A Quick reference to operation is provided on the back cover to help you quickly program the VCR. However, there are some important details that you should know. Make sure you read the hookup you used (Insidup 1) so that you can always follow the correct connections.

Hi-setup 5

Incompatible cable box with only a few scrambled channels, using an A/B switch

Recommended use

By using an A/B switch, non-compliant sub-assembly hi-setup allows you to record both scrambled and unscrambled channels on the same VCR. With the A/B switch set to "A", you can record unscrambled channels by selecting channels directly with the VCR. You can use position "B" and the cable box to record a scrambled channel.


*When your own sub-assembly is to be used, see the back cover.

When you can do

- Record any unscrambled channel by selecting the channel on the VCR (the A/B switch is set to "A").
- Record any scrambled channel by selecting the channel on the cable box (the A/B switch is set to "B").


When you can't do

- Record two channels with a single, another channel.



Hi-setup 5: VCR setup

- 1 Set the **UNIT** switch to CH 5 or CH 4, whichever channel is not used in your area. If both are used, set the switch to either channel. If you have a 4/3 conversion tuner (page 9), you can set your VCR to channel 5 or 4.



Front panel view.

- 2 Set the **A/B** switch to "A".

- 3 Press **LAST SET UP** under **VCR**.

The **SET UP** screen appears.

- 4 Press the cable box output channel (usually 2, 3 or 4).

Getting Started

Hi-setup 5: VCR channel setup

- 1 Find the **VCR Plus-1** Channel Listing in your program guide for details on the **VCR Plus-1** Channel Listing, see page 8.

- 2 For unscrambled channels 7 on channels 10 in the program guide or channels 10 on channels 7 in the program guide, set on your TV, set the channel that are different at 10:00am.

- 3 For scrambled channels, enter all the scrambled channels you want to record and the cable box output channel (usually 2, 3, or 4).

Backup 5

Incompatible cable box with only a few scrambled channels, using an A/B switch (continued)

You are now ready to use your VCR

To accept an unscrambled channel:

1. Set the A/B switch to "A."
2. Refer to Backup 4.

To record a scrambled channel:


1. Set the A/B switch to "B."
2. Refer to Backup 4 or the cable box for details on the cable rec. see page 243.

To watch TV:

1. Turn off your VCR, so your TV/VCR/VTR button on the VTR.
2. Turn on the VCR.
3. Turn on the VCR.
4. Turn on your cable box.
5. Set the TV to the cable box output channel (usually 2, 3, or 4).
6. Set the cable box to the channel you want to watch.


Selecting a language

(Cannot be accepted any)



If you prefer French or English, you can change the on-screen display language.

When you put up your VCR for the first time, you can select the on-screen display language. For example, press 11, 13, 15, 17 and 19. The on-screen display language using the menu.




1. Press 11 (1), 13 (3), 15 (5), 17 (7) and 19 (9). The on-screen display language using the menu.



2. Press the **OPTION** (14) button to select the color (0) to LANGUAGE. The LANGUAGE menu appears on the TV screen.

3. Using the **CANCEL** (14) button, select **FRANCAIS** or **ENGLISH**, then press **0** (0000).

Setting the clock



The VCR controls the internal clock using a quartz crystal oscillator circuit. The clock is set automatically by the VCR.

- To set the clock, press the **CLOCK** button.
- The VCR automatically sets the clock to the current date and time.
- The clock is set to the current date and time.
- The clock is set to the current date and time.
- The clock is set to the current date and time.

Set the time and date to use the timer (auto) for recording programs. When you set your VCR for the first time, you can set the clock using the **CLOCK SET** button (PAGES 17, 18, 19 and 20). You can also set the clock using the timer.

Using the Auto Clock Set feature

Some TV and video channels have timed to transmit their signals with their broadcast. Your VCR can pick up this time signal to automatically set the clock. After completing the setup below, when you turn off the VCR, it will automatically search for external time signals from your TV set. The Auto-Clock Set feature only works if a time signal is received by your VCR. The Auto-Clock Set feature only works if a time signal is received by your VCR. The Auto-Clock Set feature only works if a time signal is received by your VCR.

- 1 Press the **MEMORY** button. The **MEMORY** appears on the TV screen.

- 2 Press the **CLOCK** (clock) button to select **CLOCK SET**. The **CLOCK SET** menu appears on the TV screen.

- 3 Press the **CLOCK** (arrow) button to select **AVT**, then press **ENTER**. The **AVT** menu appears on the TV screen.


- 4 Press the **CLOCK** (arrow) button to select **AVT**, then press **ENTER**.

- 5 To set the clock, press the **CLOCK SET** button. The **CLOCK SET** menu appears on the TV screen. The VCR automatically sets the clock to the current date and time. The clock is set to the current date and time. The clock is set to the current date and time. The clock is set to the current date and time.

Getting Started

If the clock time is not set, follow the steps below to set the clock.


- 1 Follow the steps below to set the clock. The **CLOCK SET** menu appears.
- 2 Press the **CLOCK** (arrow) button to select **CLOCK SET**. The **CLOCK SET** menu appears. Press the **CLOCK SET** button (PAGES 17, 18, 19 and 20).
- 3 Press the **CLOCK** (arrow) button to select **AVT** or **MANUAL**. The VCR automatically searches for a time signal. If you select **MANUAL**, you can set the clock manually. Press the **CLOCK** (arrow) button to select **AVT** or **MANUAL**. The VCR automatically searches for a time signal. If you select **MANUAL**, you can set the clock manually. Press the **CLOCK** (arrow) button to select **AVT** or **MANUAL**. The VCR automatically searches for a time signal. If you select **MANUAL**, you can set the clock manually.
- 4 Press **ENTER**. The **YOUR TIME** menu appears. The **YOUR TIME** menu appears.
- 5 Press the **CLOCK** (arrow) button to select **AVT** or **MANUAL**. The VCR automatically sets your time zone and daylight saving time. Press the **CLOCK** (arrow) button to select **AVT** or **MANUAL**. The VCR automatically sets your time zone and daylight saving time. Press the **CLOCK** (arrow) button to select **AVT** or **MANUAL**. The VCR automatically sets your time zone and daylight saving time. Press the **CLOCK** (arrow) button to select **AVT** or **MANUAL**. The VCR automatically sets your time zone and daylight saving time.
- 6 Press **ENTER**.
- 7 To set the clock, press the **CLOCK SET** button. The **CLOCK SET** menu appears.



The VCR controls the internal clock using a quartz crystal oscillator circuit. The clock is set automatically by the VCR.

- To set the clock, press the **CLOCK** button.
- The VCR automatically sets the clock to the current date and time.
- The clock is set to the current date and time.
- The clock is set to the current date and time.

Setting the clock (continued)




Using the Manual Clock Set

- 1 Press **MANUAL**.
The word **MANUAL** appears on the TV screen.
- 2 Press the **CURSOR (left)** buttons to move the cursor (B) to **CLOCK SET**. Then press **EXECUTE**.
- 3 Press the **CURSOR (center)** buttons to select **MANUAL**. Then press **EXECUTE**.
- 4 Set the month using the **CURSOR (left)** buttons.
- 5 Press **CURSOR (right)** to highlight the day and set the day using the **CURSOR (left)** buttons.
The day of the week will automatically appear.
- 6 Press **CURSOR (right)** to highlight the year and set the year using the **CURSOR (left)** buttons.
- 7 Press **CURSOR (right)** to highlight the hour and set the hour using the **CURSOR (left)** buttons.
- 8 Press **CURSOR (right)** to highlight the minutes and set the minutes using the **CURSOR (left)** buttons.
- 9 Press **EXECUTE** to save the clock.

Presetting channels

(Skip this section if you are using cable box control.)



The **MEMORY** button is used to store a TV channel in a **MEMORY** channel. The **MEMORY** channels are numbered 1 through 99. Press the **MEMORY** button to store a channel in a **MEMORY** channel.

Channel numbers are stored in the **MEMORY** channels. Press the **MEMORY** button to store a channel in a **MEMORY** channel.

The VCR is capable of receiving VHF channels 2 to 13, UHF channels 14 through 69, and automatic CATV channels 1 to 120. However, we recommend that you preset the receivable channels in your area using automatic presetting. Then, if there are any unassigned channels, change these manually. It may have appeared which channel you wish to preset, set them directly using the manual presetting. Also, you can preset the channels using the **EAS/SETUP** button (pages 11, 13, 15, 17 and 19). You should preset the channels using the menu.


- Before you start, make sure that the TV is connected to the VCR using AV connections on the TV to video input.
- Press **TV/VTR** to display the VTR indicator in the VCR's display.
 - Press **STOP/SELECT** so that a channel number appears in the VCR's display window.

Presetting all receivable channels automatically

- 1 Press **MEMORY**.
The word **MEMORY** appears on the TV screen.
- 2 Press the **CURSOR (left)** buttons to move the cursor (B) to **TUNING**. Press the **EXECUTE** button to select **ALL**. Then press **EXECUTE** again to select **ALL** on the TV screen.
- 3 Press the **CURSOR (left)** buttons to move the cursor (B) to **MEMORY**. Press the **EXECUTE** button to select **MEMORY** on the TV screen.
- 4 Select **ALL** or **CABLE** using the **CURSOR (right)** buttons.
 - To preset cable TV channels, select **CABLE**.
 - To preset VHF and UHF channels, select **ALL**.





Continued

Presetting channels (continued)



- Press the **CUSTOM (P13)** button to move the cursor to **MEMO**.
 All presettable channels preset in manual sequence when in **MEMO** mode. Press the **VIEW** button to return to the previous menu and the power from the screen returns to normal (standby) on the TV set.

Presetting disabling channels manually

- Display the **TUNING PRESET** menu.
 For automatic tuning steps 1 and 2 in "Presetting all receivable channels automatically."

- Select the channel to preset or disable.
 To preset channel, enter the channel number on the numeric keypad.
 To disable a channel, select the channel number by pressing **CH. LK.**

- Set **MANUAL SET TO AUTO or SEARCH**, using the **CUSTOM (P13)** button:
 To preset channel, enter **MEMO**.
 To disable channel, enter **EXIT**.

- Repeat steps 2 and 3 to preset or disable channels as required. Then press **EXECUTE**.






Cable TV channel assignment

Cable TV channels use letters or numbers to designate (number). This VCR is designed to correspond with standard CATV systems. The cable TV channel numbers on this VCR and the corresponding channel numbers on the TV set must be the same. The channel number on the chart may not correspond to the channel number used by your local cable company. Check with your local cable TV company for more information on the available channels.

Channel No. on VCR	1	2	3	4	5	6	7	8	9	10	11	12
Channel No. on TV	44	2	3	4	5	6	7	8	9	10	11	12
1	12	13	14	15	16	17	18	19	20	21	22	23
2	24	25	26	27	28	29	30	31	32	33	34	35
3	36	37	38	39	40	41	42	43	44	45	46	47
4	48	49	50	51	52	53	54	55	56	57	58	59
5	60	61	62	63	64	65	66	67	68	69	70	71
6	72	73	74	75	76	77	78	79	80	81	82	83
7	84	85	86	87	88	89	90	91	92	93	94	95
8	96	97	98	99	100	101	102	103	104	105	106	107
9	108	109	110	111	112	113	114	115	116	117	118	119
10	120	121	122	123	124	125	126	127	128	129	130	131

If the picture is not clear

Normally, the Auto Fine Tuning (AFT) function automatically tunes in channels clearly. If, however, the picture of a channel is not clear, you may also use the manual tuning function.

- Display the **TUNING PRESET** menu.
 Press the **VIEW** button to step 1 and 2 in "Presetting all receivable channels automatically."

- Select the channel you want to fine-tune by pressing the number buttons and then **ENTER**.

- Press the **CUSTOM (P13)** button to move the cursor to **Start channel**. The following menu appears:

- Press the **CUSTOM (P13)** button to get a clearer picture. Then press **EXECUTE**. Note that the AFT setting returns to OFF.


Using the ADVANCED OPTIONS (continued)

Menu choices
Initial settings are indicated in bold letters

Menu system AUTO-ADJUST	<p>Select this option as:</p> <ul style="list-style-type: none"> • Only if your TV is connected to a VCR. The TV will automatically adjust itself to the VCR. (An external cable set for the TV is required.) • Off if your TV is connected to a VCR, but you do not want the TV to adjust itself to the VCR.
AUDIO/VIDEO	<ul style="list-style-type: none"> • Off to master stereo program. • Off to receive external audio program. <p>For details, see page 33.</p>
CHANNEL	<ul style="list-style-type: none"> • Off to receive digital stereo data.
AUDIO/VIDEO	<ul style="list-style-type: none"> • On to receive the sound received on the TV as well as the external audio signal. <p>For details, see page 33.</p>
INTERNAL AUDIO	<ul style="list-style-type: none"> • On to receive the sound using the AUDIO/VIDEO input. • On to receive the sound received on the TV and the external audio signal. • Off to receive only the external audio signal. The main sound is received on the TV's speaker track. <p>For details, see page 33.</p>
ARC	<ul style="list-style-type: none"> • On to receive the ARC Composite Video Channel function. The picture is receiving from the VCR. • Off to receive only the external audio signal. <p>For details, see page 33.</p>
CLERK LAMP	<ul style="list-style-type: none"> • On to indicate the location of the digital VCR channel required for the external audio quality. (Only VCRs with digital audio can use VCR.) • Off to receive only the external audio signal. <p>For details, see page 33.</p>
TAPE SELECT	<ul style="list-style-type: none"> • On to allow the TV to receive the external audio signal from the VCR. <p>For details, see page 33.</p>

Basic Operations Playing a tape




Fig. 1 For detailed information on features and controls, see the "Basic Operations" section of the manual.

Fig. 1

For detailed information on features and controls, see the "Basic Operations" section of the manual.

The section shows you how to play back a video tape.

- 1 Press the power key and turn on the VCR.
 - If the TV is not connected to the VCR, the video/audio cables on the TV to video/audio.
 - If the TV is connected to the VCR, set the external cable on the TV to video/audio.
- 2 Open the tape door panel and insert a video cassette. The VCR will automatically detect the tape and start playing. (The power remains on.)
- 3 Press the PLAY key to start playing. Press the STOP key to stop the tape. Press the PAUSE key to pause the tape. (The power remains on.)

Additional buttons	Power
Stop play	STOP
Pause play	PAUSE
Resume play after pause	REPAUSE (or PAUSE)
Search forward	Fast Forward (FF) or F.F. (or FF)
Search backward	Reverse (RR) or R.F. (or RR)
Fast forward by tape	Fast Forward by Tape (FF) or FF by Tape
Fast backward by tape	Fast Backward by Tape (BB) or BB by Tape
Stop by tape	STOP

Recording TV programs (Continued)

- Watching a TV program while recording another**
You can watch a TV program and record another at the same time.
- 1 Press TV/VCR to turn on the VCR indicator on the display window.
 - 2 If the TV is connected to the VCR using the audio-video cable, set the TV to **VIDEO**.
 - 3 Use the TV's channel selector to select the channel you wish to watch.
 - 4 When the channel changes on the TV.

Recording stereo and bilingual programs

Stereo programs
The VCR automatically records stereo programs as stereo. When stereo programs are recorded, the STEREO indicator on the VCR lights up. If you want to record a stereo program, record the program in **STEREO**. Refer to the setup manual.

Bilingual programs
The VCR records audio tracks on both main and normal audio tracks. To record bilingual Audio Programs, refer to the normal audio track, below. The steps below:

- 1 Press **MEMO** and select **ADVANCED-OPTIONS**.



- 2 To record stereo programs as mono:
Set **AUTOSTEREO** to **OFF** using the **CURSOR** (left/right) buttons.



- 3 To record SMP sound on normal audio track:
Set **AUTOSTEREO** to **ON** using the **CURSOR** (left/right) buttons.



- 3 Press **DISCLOSE** to return the screen.

To monitor SMP sound while recording
Press **ALTIMONITOR** until the SMP indicator lights up on the display window.

Setting a recording

Video tapes have a safety tab to prevent accidental recording. To prevent accidental erasure of a recording, break off the safety tab with a sharp object such as a paper toothpick. Unintentional erasure if you try to record again.

To record on a tape with a safety tab removed, cover the tab both with adhesive tape.



Remove tape

Checking channel assignments Timer settings (continued)

Case 1
Program 1 10:00-10:30
Program 2 10:30-11:00
Point start 10:00
will be repeated 10:00

Case 2
Program 1 10:00-10:30
Program 2 10:30-11:00
Point start 10:00
will be repeated 10:00

Case 3
Program 1 10:00-10:30
Program 2 10:30-11:00
Point start 10:00
will be repeated 10:00

When the timer settings overlap

The VCR will not record overlapping programs. If any of your timer settings overlap, change the timing.

Case 1: If you enter two programs to start recording at the same time.
The program listed first in the TIMER SET/CHECK menu has priority over the other program. The start timing of the later program will be erased from the TIMER SET/CHECK menu to start the first program before recording.

Case 2: If you enter two programs to start recording at the same time.
The last 30 seconds of program 1 will not be recorded because the VCR will start recording first for program 2 before program 1 is finished.

Case 3: If you enter program 2 to start recording before program 1 is finished recording.
Program 2 will start recording before program 1 has finished.

Additional Operations Playing/searching at various speeds




Fig. 1

- Push the green stop button to stop the VCR.
- Push the yellow STILL button to stop the VCR.
- Push the red PLAY button to start the VCR.
- Push the yellow 1/2, 1, 2, 4, or 8 buttons to play back at the selected speed.
- Push the yellow STILL button to stop the VCR.
- Push the red PLAY button to start the VCR.

Note

- There are several built-in modes for the VCR. For more information, see the VCR manual.
- The VCR will not record overlapping programs.
- The VCR will not record overlapping programs.

You can play back a tape at various speeds: high speed, slow motion, still, and so on. These options are also useful for searching for a specific point during playback. The manual is useful during these operations.


Playback option	Operation	From (to) timer
Playing at various speeds	During playback or pause state, press the 1/2 , 1 , 2 , 4 , or 8 buttons to play back at the selected speed.	Release the stop button.
Overplay the recorded tape	Press the 1/2 button to play back at 1/2 speed.	From (to) PAUSE
Fast-forwarding/rewinding	During stop state, press the FF (fast forward) or REW (rewind) buttons to play back at the selected speed.	From (to) PAUSE
Viewing the picture during the search	During playback or pause state, press the SEARCH (still search) or SEARCH (still search) buttons to play back at the selected speed.	From (to) PAUSE
Looking for a high-speed scene	During playback or pause state, press the SEARCH (still search) or SEARCH (still search) buttons to play back at the selected speed.	From (to) PAUSE
Looking for a slow scene	During playback or pause state, press the SEARCH (still search) or SEARCH (still search) buttons to play back at the selected speed.	From (to) PAUSE
Pausing timer by timer	During playback, press the PAUSE button to stop the VCR. Press the PAUSE button again to resume the playback.	From (to) PAUSE
Stopping a timer	During playback, press the STOP button to stop the VCR.	The VCR returns to normal playback.
Advanced timer search	During playback, press the SEARCH (still search) button to play back at the selected speed.	From (to) PAUSE

Editing with another VCR


- Tip:**
- Use the same video connection as you did when you first recorded the tape.
 - Turn on the other VCR. You can use the EJECT key to start the VCR. Press the EJECT key to start the VCR.
 - If the other VCR is a standard VCR, have the red pins connected.
- Notes:**
- When connecting the VCRs, connect the VCR to the VCR. Do not connect the VCR to the VCR. Do not connect the VCR to the VCR.

This section shows you how to edit or insert another VCR or camcorder. You can make a copy of a tape using the VCR for recording or playback.

How to hook up to record on this VCR



How to hook up to record to another VCR



Operation (when recording on this VCR)

- Before you start editing:
- Press **STOP** or **PAUSE** on the other VCR.
 - Press **STOP** or **PAUSE** on the other VCR.
 - On the VCR, set the EJECT switch to ON. In the other VCR, set a similar switch, set it to ON as well.


1 Insert a source tape with its safety tab removed into the other VCR. Press the EJECT key to start the tape. Press the EJECT key to start the playback again.

2 Insert a tape into this (recording) VCR. Search for the point to start recording and press **PAUSE**.

3 Press **REC** on this VCR and set it to recording phase.

4 To start editing, press **PAUSE** on the other VCR. Press **STOP** or **PAUSE** on the other VCR. Press **STOP** or **PAUSE** on the other VCR. Press **STOP** or **PAUSE** on the other VCR. Press **STOP** or **PAUSE** on the other VCR.

To stop editing:
Press **STOP** or **PAUSE** on both VCRs.



- Tip:**
- To edit on the VCR, press **STOP** or **PAUSE** on the other VCR. Press **STOP** or **PAUSE** on the other VCR. Press **STOP** or **PAUSE** on the other VCR. Press **STOP** or **PAUSE** on the other VCR.
 - You can't connect the VCR to the VCR. Press **STOP** or **PAUSE** on the other VCR. Press **STOP** or **PAUSE** on the other VCR. Press **STOP** or **PAUSE** on the other VCR.


Synchronized editing

NOTE

- THE CABLE BOX: This device is used to connect the VCR to the CONTROL 5 unit. The additional connection also connects both VCRs from one VCR to start editing.

How to hook up via the CONTROL 5 feeds

The CONTROL 5 connection only enables you to pause and release feeds.



Operation (when recording on the other VCR)


As before, see page 44.

- On the VCR, with the EDIT switch in ON, if the other VCR has a similar switch, set it to ON as well.

- 1 Insert a tape into the other (recording) VCR, switch for the point to start recording and press **REWIND**.
- 2 Insert a tape into the other (recording) VCR, switch for the point to start recording and press **REWIND**.
- 3 Press **REC** on the other VCR to check for recording.
- 4 To start editing, press **STOP/PAUSE** on the other VCR.
- 5 As the edit you want to make recoding, press **EDIT/RECALL** to stop editing. Don't VCRs begin to edit.

To stop editing

Press the **STOP** buttons on both VCRs.



Setting the RF unit

When connecting the VCR to the TV, using only the antenna cable, you need to set the RF Unit to the correct channel in the VCR so that the TV can receive the signal from the VCR.

If you connect the VCR to the TV using the supplied audio/video cable, you can skip this step.

1 Set the RF UNIT switch on the rear of the VCR to CH2 or CH1, whichever channel is not used in your area. It is here you would set the switch to other channels.

2 Press **POWER** to turn on the VCR.

3 Press **TV/VIDEO** to turn on the VTR indicator in the VCR's display window.

4 Press **CHANNEL** until a display channel number is in the display window. When a color channel number is shown:

• Turn on your TV and set it to the channel you selected in step 4.

The selected TV channel broadcast appears on the TV screen. If the channel is being used by your local station, you may need to scan the channels. To do so, use the VCR for the TV to make channel selection in step 1.

Attaching the external antenna connector

When using an antenna (as indicated for VHF/UHF signals), use the EAC-33 antenna connector (not supplied) to connect the antenna to the VCR.

1 Loosen the screws on the antenna connector.

2 Wind the ferris beads around the screws on the antenna connector.

3 Tighten the screws.

Attaching an UHF/UHF lead cable

When using both 75-ohm coaxial cable and 300-ohm twin lead cable for VHF/UHF signals, use the EAC-35 UHF/UHF lead cable (not supplied) to connect the antenna to the VCR.

1 Loosen the screws on the rear.

2 Wind the ferris beads around the screws on the plate.



3 Tighten the screws.

4 Connect the 300-ohm coaxial cable to the rear.

Index to parts and controls

Refer to the pages indicated by C, F or S.

Display window



1 POWER indicator (see page 58)

2 EJECT button (see page 59)

3 PAUSE button (see page 59)

4 PLAY/REVERSE button (see page 59)

5 STOP button (see page 59)

6 EJECT button (see page 59)

7 DUAL MODE SHUTTLE (see page 59)

8 EASY SET button (see page 60)

9 EDIT button (see page 60)

10 CORRECT button (see page 60)

11 LOCK IN 2 button/AUDIO LOCK (see page 60)

12 TYPE button

13 COUNTER indicator (see page 60)

14 REMAIN indicator (see page 60)

15 STEREO indicator (see page 61)

16 SAT indicator (see page 61)

17 AUDIO TRACKING indicator (see page 61)

18 TYPE indicator (see page 61)

19 COUNTER indicator (see page 61)

20 TYPE indicator (see page 61)


21 TYPE indicator (see page 61)

22 TYPE indicator (see page 61)


23 TYPE indicator (see page 61)

General setup

Information




EAC-33 antenna connector (not supplied)




EAC-35 UHF/UHF lead cable (not supplied)

SECTION 2 DISASSEMBLY


2-1. REMOVAL OF UPPER CASE



2-2. REMOVAL OF FRONT PANEL ASSEMBLY




2-3. REMOVAL OF CONTROL SWITCH BLOCK (780HF, 781HF, 940HF/HFCS/HFMX/HFPX)




2-4. REMOVAL OF MF-253, MF-274 BOARD

(MF-253 BOARD: EXCEPT 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)
(MF-274 BOARD: 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)




2-5. REMOVAL OF HI-5, HI-19 BOARD

(HI-5 BOARD . EXCEPT 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)
(HI-19 BOARD . 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)




2-6. REMOVAL OF BOTTOM PLATE




2-7. REMOVAL OF PS-327, PS-349 BOARD

{PS-327 BOARD : EXCEPT 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL}
{PS-349 BOARD : 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL}




2-8. REMOVAL OF ED-40, ED-43 BOARD AND HF-34 BOARD

{ED-40 BOARD : 740HF, 741HF, 780HF, 781HF, 940HF/HFMX MODEL}
{ED-43 BOARD : 740HFPX, 940HFCS/HFPX MODEL}




2-9. REMOVAL OF RV-36, RV-45 BOARD


(RV-36 BOARD : EXCEPT 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)
 (RV-45 BOARD : 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)



2-10. REMOVAL OF MA-214 BOARD



2-11. REMOVAL OF MD BLOCK ASSEMBLY




2-12. MECHANICAL INTERNAL VIEWS


—Upper side—

M901


Drum Assy	8-848-576-12 (D2H-45A-R) (EXCEPT 940HF/HFCS/HFMX/HFPX)
	8-848-599-12 (D2H-51A-R) (940HF/HFCS/HFMX/HFPX)
Rotary taper drum Assy	8-846-576-02 (D2R-45-R) (EXCEPT 940HF/HFCS/HFMX/HFPX)
	8-846-594-02 (D2R-51-R) (940HF/HFCS/HFMX/HFPX)



—Lower side—



2-13. CIRCUIT BOARDS LOCATION




SLV-733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL	EXCEPT SLV-733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL	SLV-740HFPX, 940HFCS/HFPX MODEL	SLV-740HF, 741HF, 780HF, 781HF, 940HF/HFMS MODEL
DC-65 BOARD HI-19 BOARD MF-274 BOARD PS-349 BOARD RV-45 BOARD	DC-57 BOARD HI-5 BOARD MF-253 BOARD PS-327 BOARD RV-36 BOARD	ED-43 BOARD	ED-40 BOARD

SECTION 3 BLOCK DIAGRAMS


3-1. OVERALL BLOCK DIAGRAM

• The boards which signals only pass through may be omitted.




3-3. SERVO, SYSTEM CONTROL BLOCK DIAGRAM

* The boards which signals only pass through may be omitted.




3-4. TIMER, TUNER, MODE CONTROL BLOCK DIAGRAM

• The boards which signals only pass through may be omitted.




3-5. AUDIO BLOCK DIAGRAM

• The boards which signals only pass through may be omitted.




I4 BOARD
ICB007, ICB08
(See page 4-27)




3-6. TUNER BLOCK DIAGRAM

•The boards which signals only pass through may be omitted.




3-6. TUNER BLOCK DIAGRAM

• The boards which signals only pass through may be omitted.




SECTION 4
PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

4-1. FRAME SCHEMATIC DIAGRAMS




RV-36/45 (Y/C VIDEO PROCESS, HIFI AUDIO, HEAD AMP) SCHEMATIC DIAGRAM
 — Ref. No. RV-36/45 BOARD) : 2,000 series —

RV-36/45 BOARD




* Signal path

	VIDEO Signal		AUDIO Signal	
	CHROMA	Y	CHROMA	Y
#FC	→	→	→	→
PB	→	→	→	→





9 10 11 12 13 14 15 16 17 18 19 20 21 22





MA-214 (SERVO/SYSTEM CONTROL), DC-57/65 (RELAY) PRINTED WIRING BOARDS


-- Ref. No. MA-214 BOARD: 1,000 series, DC-57/65 BOARD: 4,000 series --


MA-214 BOARD			
0051	W 9	0001	1 1
0061	M 2	0072	2 14
0161	L 18	0069	1 6
0164	G 16	0351	1 11
0280	D 16	0352	1 12
0480	G 17	0354	1 14
0522	G 18	0482	2 6
0680	L 20	0484	1 5
0803	L 15	0485	1 2
0808	M 19	0487	1 5
0809	M 17	0523	1 17
0840	C 5	0529	1 9
0858	C 11	0524	1 2
0849	A 7	0525	1 10
0870	L 1	0526	1 6
0812	S 31	0521	1 4
		0522	1 4
		0523	1 6
		0524	1 6
		0525	1 5
		0526	1 5
		0527	1 5
		0528	1 5
		0529	1 3
		0530	1 5
		0531	1 5
		0532	1 5
		0533	1 5
		0534	1 5
		0535	1 5
		0536	1 5
		0537	1 5
		0538	1 5
		0539	1 5
		0540	1 5
		0541	1 5
		0542	1 5
		0543	1 5
		0544	1 5
		0545	1 5
		0546	1 5
		0547	1 5
		0548	1 5
		0549	1 5
		0550	1 5
		0551	1 5
		0552	1 5
		0553	1 5
		0554	1 5
		0555	1 5
		0556	1 5
		0557	1 5
		0558	1 5
		0559	1 5
		0560	1 5
		0561	1 5
		0562	1 5
		0563	1 5
		0564	1 5
		0565	1 5
		0566	1 5
		0567	1 5
		0568	1 5
		0569	1 5
		0570	1 5
		0571	1 5
		0572	1 5
		0573	1 5
		0574	1 5
		0575	1 5
		0576	1 5
		0577	1 5
		0578	1 5
		0579	1 5
		0580	1 5
		0581	1 5
		0582	1 5
		0583	1 5
		0584	1 5
		0585	1 5
		0586	1 5
		0587	1 5
		0588	1 5
		0589	1 5
		0590	1 5
		0591	1 5
		0592	1 5
		0593	1 5
		0594	1 5
		0595	1 5
		0596	1 5
		0597	1 5
		0598	1 5
		0599	1 5
		0600	1 5
		0601	1 5
		0602	1 5
		0603	1 5
		0604	1 5
		0605	1 5
		0606	1 5
		0607	1 5
		0608	1 5
		0609	1 5
		0610	1 5
		0611	1 5
		0612	1 5
		0613	1 5
		0614	1 5
		0615	1 5
		0616	1 5
		0617	1 5
		0618	1 5
		0619	1 5
		0620	1 5
		0621	1 5
		0622	1 5
		0623	1 5
		0624	1 5
		0625	1 5
		0626	1 5
		0627	1 5
		0628	1 5
		0629	1 5
		0630	1 5
		0631	1 5
		0632	1 5
		0633	1 5
		0634	1 5
		0635	1 5
		0636	1 5
		0637	1 5
		0638	1 5
		0639	1 5
		0640	1 5
		0641	1 5
		0642	1 5
		0643	1 5
		0644	1 5
		0645	1 5
		0646	1 5
		0647	1 5
		0648	1 5
		0649	1 5
		0650	1 5
		0651	1 5
		0652	1 5
		0653	1 5
		0654	1 5
		0655	1 5
		0656	1 5
		0657	1 5
		0658	1 5
		0659	1 5
		0660	1 5
		0661	1 5
		0662	1 5
		0663	1 5
		0664	1 5
		0665	1 5
		0666	1 5
		0667	1 5
		0668	1 5
		0669	1 5
		0670	1 5
		0671	1 5
		0672	1 5
		0673	1 5
		0674	1 5
		0675	1 5
		0676	1 5
		0677	1 5
		0678	1 5
		0679	1 5
		0680	1 5
		0681	1 5
		0682	1 5
		0683	1 5
		0684	1 5
		0685	1 5
		0686	1 5
		0687	1 5
		0688	1 5
		0689	1 5
		0690	1 5
		0691	1 5
		0692	1 5
		0693	1 5
		0694	1 5
		0695	1 5
		0696	1 5
		0697	1 5
		0698	1 5
		0699	1 5
		0700	1 5



DC-57BOARD (EXCEPT 733HF/HFCS,740HFPX,940HFCS/HFPX MODEL)
DC-65BOARD(733HF/HFCS,740HFPX,940HFCS/HFPX MODEL)







(See page 4-9)
10 BY 20V 2.5MM CUSST

(See page 4-8)
10 BY 20V 2.5MM CUSST

(See page 4-19)
10 BY 20V 2.5MM CUSST

PS-2053 BOARD
(See page 4-38)


DC-S7 BOARD
R XFFPT 256P/11.5 240VDC 1000 L/1000 1000
DC-S5 BOARD
19.500/2.000 19.500/2.000 940HF/781HF/940HF
RELAY

CAM ENCODER

Note:
The components identified by mark (A) or star (*) are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque (A) sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.


MA-214 (INPUT/OUTPUT, TUNER) SCHEMATIC DIAGRAM
 — Ref. No. MA 214 BOARD : 1400 series —
 • Refer to page 4-10 for Printed Wiring Board.



• Signal path

	VIDEO Signal	AUDIO Signal
REC	CHROMA	Y ... I, CHROMA
PB		

22 23 24 25 26 27 28 29 30 31 32 33 34




<p>Note: The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.</p>	<p>Note: Les composants identifiés par une marque Δ ou trait en pointillés pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.</p>
--	--


ED-40/43 (EDS CONTROL) SCHEMATIC DIAGRAM

- Ref. No. ED-40/43 BOARD : 3,000 series -

IFMX MODEL)




ED-40/43 BOARD



HF-34 (AUDIO PROCESS) PRINTED WIRING BOARD
 -- Ref. No. HF-34 BOARD - 1000 series

HF-34 BOARD (COMPONENT SIDE)


- HF-34 BOARD
- 2N103 D-1
- 2N103 D-1
- 2N103 A-1
- EL34 C-2
- 6X41 B-1
- 6X41 C-2
- 6X42 C-3





HF-34 (AUDIO PROCESS) PRINTED WIRING BOARD
 Ref. No. HF-34 BOARD : 4000 series

HF-34 BOARD
 Q101 D-1
 LK101 D-5
 P101H X-7
 Q101 C-4
 LK101 B-7
 Q101 C-2
 Q101 C-4

HF-34 BOARD (COMPONENT SIDE)




HF-34 BOARD (CONDUCTOR SIDE)



HF-34 (AUDIO PROCESS) SCHEMATIC DIAGRAM


Ref. No. HF-31 BOARD : 4000 series




MF-5/19 (TIMER/TUNER/MODE CONTROL), MF-253/274 (LED CONTROL) SCHEMATIC DIAGRAMS

— Ref. No. HI-5/19 BOARD; MF-253/274 BOARD, 3000 series —

HI-5/19 BOARD



19 20 21 22 23 24 25 26 27 28 29 30 31



(See page 4-38)

* Signal path

	ChROMA	VIDEO	Y	V/CHROMA	AUDIO
REC	→	→	→	→	→
PB	→	→	→	→	→


TIMER/TUNER/MODE, LED CONTROL

BOARD

US —

4	5	6	7	8	9	10	11	12	13	14	15
---	---	---	---	---	---	----	----	----	----	----	----

733HF/734HF



GREEN: 100% TOLERANCE TO 1000 PPM (1000 PARTS PER MILLION)
 YELLOW: 5% TOLERANCE TO 1000 PPM (1000 PARTS PER MILLION)
 RED: 20% TOLERANCE TO 1000 PPM (1000 PARTS PER MILLION)
 BLUE: 5% TOLERANCE TO 1000 PPM (1000 PARTS PER MILLION)
 PURPLE: 10% TOLERANCE TO 1000 PPM (1000 PARTS PER MILLION)
 BROWN: 1% TOLERANCE TO 1000 PPM (1000 PARTS PER MILLION)


PP 327-349
 (See page 4-16)

PP 327-349
 (See page 4-16)

PS-327/349 (POWER) SCHEMATIC DIAGRAM

Ref. No. PS-327/349 (BOARD: 2,000 series)


PS-327 BOARD (EXCEPT 733HF/
 PS-349 BOARD (733HF/HFCS, 7




04 1 2 3

3 (POWER) SCHEMATIC DIAGRAM
 PS-327/319 BOARD) : 3,000 series

7 BOARD (EXCEPT 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)
 8 BOARD (733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)



PS-327/319 BOARD	
733HF	A-22
740HFPX	C-23
C-01	D-1
C-02	B-11
C-10	B-4
C-11	C-9
C-14	B-4
C-15	B-10
C-16	C-1
C-17	C-10



SECTION 5 REPAIR PARTS LIST

5-1. EXPLODED VIEWS

NOTE:


- The mechanical parts with no reference number in the exploded views are not supplied.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- "X" and "Y" mean standardized parts, so they may have some difference from the original one.
- Hardware (8 items) list and necessary part packing materials are given in the last of this parts list.

Les composants identifiés par une marque X ou pointillés avec une croix sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Les composants identifiés par une marque X sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.


5-1-1. CASE ASSEMBLY



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
1	X-3844-290-1	BUTTON ASSY, FUNCTION (640HF, 740HF/ HFPS, 740HF, 940HF/HFCS/HPNA/HFSS)		4	1-467-947-11	REMOTE COMMANDER (RM-11611) (740HF, 741HF)	
1	X-3844-308-1	BUTTON ASSY, FUNCTION (733HF/HFCS/HPNA/ HFPA, 741HF, 741HF)		5	1-467-947-21	REMOTE COMMANDER (RM-11648) (741HF/HFCS/HPNA/HFPA)	
2	X-3844-285-1	RMG ASSY, SHUTTLE (640HF, 740HF/HFPA, 740HF, 940HF/HFCS/HPNA/HFPA)		6	1-467-948-11	REMOTE COMMANDER (RM-11559) (640HF/HFCS/HPNA/HFPS)	
2	X-3844-309-1	RMG ASSY, SHUTTLE (733HF/HFCS/HPNA/HFPA, 741HF, 741HF)		8	1-467-951-11	REMOTE COMMANDER (RM-11540) (640HF)	
3	7-040-080-01	KNOB (RP), SLIDE (940HF/HFCS/HPNA/HFPS)		8	1-467-951-11	REMOTE COMMANDER (RM-11582) (740HF/HFPA, 741HF)	
*4	1-940-969-01	CASE, UPPER (640HF, 740HF/HFPA, 740HF, 940HF/HFCS/HPNA/HFPS)		9	3-957-513-11	RMG, SHUTTLE (EXCEPT 640HF)	
*4	1-940-068-11	CASE, UPPER (733HF/HFCS/HPNA/HFPA)		10	3-748-817-01	COVER, BATTERY (EXCEPT 640HF)	
*4	1-940-069-21	CASE, UPPER (740HF, 741HF)		11	3-900-080-01	KNOB (RP), SLIDE (940HF/HFCS/HPNA/HFPS)	
5	3-730-901-11	SCREW, TAPPING		12	1-467-951-11	REMOTE COMMANDER (RM-11540) (640HF)	
*6	3-940-061-01	PLATE, BUTTON		13	3-708-923-01	COVER, BATTERY (640HF)	
7	3-900-082-01	INSULATOR					


5-1-2. FRONT PANEL ASSEMBLY

(SLV-780HF, 781HF, 940HF/HFCS/HFMX/HFPX MODEL)




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
51	1-467-943-11	SWITCH BLOCK, CONTROL (940HF/HFCS/HFMX/HFPX)		59	3-957-389-01	BUTTON, POWER/EJECT (780HF, 940HF/HFCS/HFMX/HFPX)	
51	1-467-943-21	SWITCH BLOCK, CONTROL (780HF)		59	3-957-389-21	BUTTON, POWER/EJECT (781HF)	
51	1-473-020-E1	SWITCH BLOCK, CONTROL (781HF)		60	3-957-386-01	SPRING, COMPRESSION	
* 52	3-960-077-01	SHIELD (LEFT), PULCHUM		61	3-944-564-01	CLAMP, LOCK	
53	X-2944-487-1	PLATE (RIGHT) ASSY, PULCHUM DOOR		* 62	3-940-556-01	SPRING, DOOR LOCK	
* 54	3-940-676-01	PLATE (LEFT), PULCHUM DOOR		* 63	3-940-090-01	LENS, TH ILLUMINATION	
55	3-961-745-01	SHIELD, OIL		* 64	3-940-089-01	LENS, REC ILLUMINATION	
56	X-2944-293-1	PANEL ASSY, FRONT (780HF)		* 65	3-957-546-01	HOLDER, LOCK CLAMP	
56	X-2944-708-1	PANEL ASSY, FRONT (940HF/HFCS/HFMX/HFPX)		* 66	3-940-086-01	BASE (L), TR (780HF, 940HF/HFCS/HFMX/HFPX)	
56	X-2944-701-1	PANEL ASSY, FRONT (781HF)		* 66	3-940-086-11	BASE (L), TR (781HF)	
57	3-960-093-01	DOOR, JACK (780HF)		67	3-953-432-01	SPRING (GE), FL	
57	3-960-093-11	DOOR, JACK (940HF/HFCS/HFMX/HFPX)		68	3-940-094-01	DOOR, CASSETTE (780HF, 940HF/HFCS/HFMX/HFPX)	
57	3-960-093-21	DOOR, JACK (781HF)		68	3-940-094-71	DOOR, CASSETTE (781HF)	
58	4-921-277-41	SCREW (Ø2.6X2), TAPPING END					

(SLV-640HF, 733HF/HFCS/HFMX/HFPA, 740HF/HFPX, 741HF MODEL)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
	4-121-277-01	SCREW (Ø2.4X10), TAPPING, BLIND		20	3-900-054-00	DOOR JACK (640HF, 740HF/HFPX)	
+ 62	3-960-556-01	SPRING, DOOR LOCK		20	3-900-053-21	DOOR JACK (733HF/HFCS/HFMX/HFPA)	
+ 63	3-960-090-01	LENS, TR. ILLUMINATION		20	3-900-055-21	DOOR JACK (541HF)	
+ 64	3-960-099-01	LENS, REC. ILLUMINATION		71	3-901-992-00	BUTTON, RF	
67	3-953-432-01	SPRING (GEL), PL.		72	3-957-257-00	BUTTON, POWER/EJECT (640HF, 740HF/HFPX)	
68	3-960-094-91	DOOR CASSETTE (733HF/HFCS/HFMX/HFPA, 740HF/HFPX)		72	3-957-257-11	BUTTON, POWER/EJECT (733HF/HFCS/HFMX/HFPA, 741HF)	
69	3-960-094-71	DOOR CASSETTE (741HF)		73	3-900-814-00	TR. POWER BUTTON	
69	X-2844-267-1	PANEL ASSY. FRONT (740HF/HFPX)		74	3-900-324-01	BUTTON, QUICK TIMER	
69	X-2844-704-1	PANEL ASSY. FRONT (741HF)		+ 75	3-900-005-03	BASE, TR. (640HF, 740HF/HFPX)	
69	X-2844-705-1	PANEL ASSY. FRONT (640HF)		+ 75	3-900-009-11	BASE, TR. (733HF/HFCS/HFMX/HFPA, 741HF)	
69	X-2844-704-1	PANEL ASSY. FRONT (733HF/HFCS/HFMX/HFPA)					

5-1-3. CHASSIS ASSEMBLY




Ref. No.	Part No.	Description	Remark
* 104	3-960-107-02	TRIGGER, MA	
* 102	A-6794-032-A	40-57 BOARD, COMPLETE (EXCEPT 733HF/740FS, 740HPX, 940HFS/HPFS)	
		40-45 BOARD, COMPLETE (733HF/HPFS, 740HPFX, 940HFS/HPFS)	
* 100	A-6782-126-A	34-36 BOARD, COMPLETE (733HPX/HPFA, 700ME, 181HE)	
		HP-45 BOARD, COMPLETE (733HF/HPFS)	
* 103	A-6782-433-A	HP-78 BOARD, COMPLETE (640HE, 740HF, 741HF)	
		HP-45 BOARD, COMPLETE (740HPX)	
* 103	A-6782-436-A	HP-26 BOARD, COMPLETE (640HF/HPFS)	
		HP-45 BOARD, COMPLETE (940HFS/HPFS)	
104	1-789-354-13	CABLE, FLEXIBLE (FLAT (190)IN)	
* 105	3-960-066-01	HOLDER (A), PL	
* 106	A-6782-429-A	HI-5 BOARD, COMPLETE (731HPFA, 740HF/US, 743HF)	
* 106	A-6782-425-A	HI-3 BOARD, COMPLETE (940HF/US/HPFS)	
* 106	A-6782-442-A	HI-5 BOARD, COMPLETE (780HF/US, 741HF)	
* 106	A-6782-060-A	HI-10 BOARD, COMPLETE (740HPX)	
* 106	A-6782-500-A	HI-10 BOARD, COMPLETE (733HF/HPFS)	
* 106	A-6782-507-A	HI-10 BOARD, COMPLETE (940HFS/HPFS)	
* 106	A-6782-625-A	HI-5 BOARD, COMPLETE (640HF/US)	
* 106	A-6782-026-A	HI-5 BOARD, COMPLETE (640HF/Canadian)	
* 106	A-6782-927-A	HI-5 BOARD, COMPLETE (640HF/Canadian)	
* 106	A-6782-928-A	HI-5 BOARD, COMPLETE (733HE/US)	
* 106	A-6782-929-A	HI-5 BOARD, COMPLETE (730HE/Canadian)	
* 106	A-6782-930-A	HI-5 BOARD, COMPLETE (940HF/Canadian)	
* 107	3-960-059-01	PLATE (PS), ORNAMENTAL, REAR JACK	
* 108	3-960-060-01	PLATE (PS), ORNAMENTAL, REAR JACK (700HF)	
* 108	3-960-060-01	PLATE (PS), ORNAMENTAL, REAR JACK (940HF)	
* 108	3-960-060-21	PLATE (PS), ORNAMENTAL, REAR JACK (940HPFS)	
* 108	3-960-060-31	PLATE (PS), ORNAMENTAL, REAR JACK (740HF)	
* 108	3-960-060-41	PLATE (PS), ORNAMENTAL, REAR JACK (740HPFS)	
* 108	3-960-060-51	PLATE (PS), ORNAMENTAL, REAR JACK (640HF)	
* 108	3-960-060-61	PLATE (PS), ORNAMENTAL, REAR JACK (741HF)	
* 108	3-960-060-71	PLATE (PS), ORNAMENTAL, REAR JACK (741HF)	
* 108	3-960-060-81	PLATE (PS), ORNAMENTAL, REAR JACK (940HFS)	
* 108	3-960-060-91	PLATE (PS), ORNAMENTAL, REAR JACK (940HPFS)	
* 108	3-962-034-01	PLATE (PS), ORNAMENTAL, REAR JACK (733HF/FA)	
* 108	3-962-034-11	PLATE (PS), ORNAMENTAL, REAR JACK (733HFS)	
* 108	3-962-034-21	PLATE (PS), ORNAMENTAL, REAR JACK (733HE/FA)	
* 108	3-962-034-31	PLATE (PS), ORNAMENTAL, REAR JACK (733HF)	

Ref. No.	Part No.	Description	Remark
* 109	3-960-058-01	PLATE (IO), ORNAMENTAL, REAR JACK (290HF, 701HE, 940HE)	
* 109	3-960-058-11	PLATE (IO), ORNAMENTAL, REAR JACK (940HFS/HPFS/HPFS)	
* 109	3-960-058-21	PLATE (IO), ORNAMENTAL, REAR JACK (640HE, 740HF, 741HF)	
* 109	3-960-058-31	PLATE (IO), ORNAMENTAL, REAR JACK (733HF/HPFS/HPFS/HPFA, 740HPX)	
* 110	3-951-093-01	NEAT STRIP	
111	3-960-387-01	STRIPPER, WINDING	
* 112	A-6782-428-A	MA-214 BOARD, COMPLETE (700HF, 701HF)	
* 112	A-6782-437-A	MA-214 BOARD, COMPLETE (740HF/HPFS, 741HF)	
* 112	A-6782-934-A	MA-214 BOARD, COMPLETE (733HF/HPFS/HPFA/HPFA)	
* 112	A-6782-437-A	MA-214 BOARD, COMPLETE (940HF/HPFS/HPFA/HPFA)	
* 112	A-6782-438-A	MA-234 BOARD, COMPLETE (640HF)	
* 113	A-6782-425-A	ED-40 BOARD, COMPLETE (740HF/741HF, 740HF, 741HF, 940HF/HPFS)	
		ED-42 BOARD, COMPLETE (740HPX, 940HFS/HPFS)	
* 114	A-6782-500-A	HE-34 BOARD, COMPLETE	
* 115	A-6782-424-A	HE-253 BOARD, COMPLETE (700HF, 701HF, 940HF/HPFS)	
* 115	A-6782-430-A	HE-253 BOARD, COMPLETE (640HF, 733HPX/HPFA, 741HF, 741HF)	
* 115	A-6782-503-A	HE-274 BOARD, COMPLETE (733HF/HPFS, 740HPX)	
* 115	A-6782-502-A	HE-274 BOARD, COMPLETE (940HFS/HPFS)	
* 116	3-960-274-01	SPACER, L2D	
* 117	3-940-275-01	SPACER, TOP END	
118	1-555-110-06	CABLE, PIN	
* 119	A-6782-427-A	PS-323 BOARD, COMPLETE (EXCEPT 733HF/HPFS, 740HPX, 940HFS/HPFS)	
* 119	A-6782-419-A	PS-349 BOARD, COMPLETE (733HF/HPFS, 740HPX, 940HFS/HPFS)	
* 120	3-960-064-01	INDICATOR, PSI	
120	8-119-048-24	DIODE (125V) (TUBE TON-ER)	
120	1-576-226-11	FUSE (IN H.C.) (250V/2A) (733HF/HPFS, 740HPX, 940HFS/HPFS)	
120	1-532-743-11	FUSE, GLASS (ELECTRONIC) (125V/2A) (EXCEPT 733HF/HPFS, 740HPX, 940HFS/HPFS)	
F201	1-533-293-11	FUSE, HOLDER	
F202	1-533-233-01	FUSE, HOLDER	
F203	1-517-325-01	TUBE, #CDOSSEMENT INDICATOR	
10341	8-758-180-48	IC P2120E11	
Q001	8-121-025-02	PHOTO TRANSISTOR P1200F (TUBE TOP)	
Q002	8-121-025-02	PHOTO TRANSISTOR P1100F (TUBE END)	

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.


Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

5-1.4. MECHANISM DECK ASSEMBLY 1




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
151	A-6751-406-A	PL. BEACH ASSY		168	3-958-439-01	SPRING (ACE), COMPRESSION	
152	3-958-483-01	SPRING, TENSION COIL		169	3-942-847-01	NUT, AG HEIGHT ADJUSTMENT	
153	3-958-495-01	SPRING, TENSION		168	3-958-491-01	BASE, ACE	
154	3-960-215-01	PLATE, LIGHT GUIDE, END SENSOR		169	N-6746-072-A	PRESS BLOCK ASSY, PUNCH	
155	3-940-216-01	PLATE, LIGHT GUIDE, TOP SENSOR		170	3-958-505-01	SPRING (SOFT BRAKE T), TENSION	
156	X-3944-408-1	ROLLER ASSY, T02		171	3-958-435-01	SPRING (PENCE), TENSION	
157	3-958-437-01	SPRING, GEAR'S TENSION COIL		172	3-958-151-01	GEAR, PLEXTON	
158	1-590-144-11	HEAD, FE		173	3-958-454-01	OPNER, LID	
159	3-958-141-01	HOLDER, FEH		174	3-958-501-01	SCREW, ACE ADJUSTMENT	
160	3-942-298-01	BRACKET, TGT TAPE		175	3-958-151-01	GEAR, PRESS	
161	X-3944-397-1	TGB ASSY		176	3-958-482-01	SPRING (ING BRAKE), TENSION	
162	3-958-421-01	HOLDER, TGE		177	X-3943-885-1	WIN ASSY, BUS DRANE	
163	3-958-152-01	GEAR, TGB		178	X-1943-682-1	BRAKE TD ASSY, SOFT	
164	A-6770-103-A	ACE BLOCK ASSY (INCLUDING AG-104 BOARD)		170	3-701-934-11	WASHER, 2.5	
165	3-594-945-11	PH, CONNECTOR EP					

5-1-6. MECHANISM DECK ASSEMBLY 2




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
201	X-3943-889-1	GROUND ASSY. SHAFT		212	3-324-593-01	WASHER, STOPPER	
202	3-643-205-01	SCREW (PSM) 3/8		214	X-3943-303-1	ROLLER ASSY. HC	
203	3-648-570-02	DRUM ASSY. ROTARY UPPER (GR-45-R) (EXCEPT 94HF/AFCS/AFMK/AFYX)		215	X-3943-306-1	ARM ASSY. HC	
204	B-848-594-02	MAIN ASSY. ROTARY UPPER (GR-51-R) (94HF/AFCS/AFMK/AFYX)		216	3-960-139-01	ARM. REDUNDANTLY	
205	3-958-443-01	SPRING, STRETCH COIL SPRING		217	3-958-535-01	SPRING, TENSION	
206	3-669-595-00	WASHER (2), STOPPER		218	3-960-136-01	ARM, PENDULUM COMPULSION	
207	3-954-450-01	BRACE (5), SOFT		219	X-3943-502-1	TABLE, REEL (2) ASSY	
208	3-954-390-02	SHAFT, PC BOARD		220	X-3943-503-1	TABLE, REEL (7) ASSY	
209	3-969-381-01	PLATE, LIGHT GUIDE, LED		221	X-3943-548-01	CAP ASSY. MAIN BRIDGE	
210	3-958-369-01	CATCHER		222	3-958-411-01	SCREW (PS 3/8)	
211	X-3944-539-1	BRACE (5) ASSY. MAIN		M901	6-048-575-12	DRUM ASSY. (GR-45A-R) (EXCEPT 94HF/AFCS/AFMK/AFYX)	
212	3-958-517-01	SPRING, TENSION COIL		M902	6-048-593-12	DRUM ASSY. (GR-51A-R) (94HF/AFCS/AFMK/AFYX)	
213	X-3943-303-1	ROLLER ASSY. HC					
214	X-3943-306-1	ARM ASSY. HC					
215	X-3943-306-1	ARM ASSY. HC					
216	3-960-139-01	ARM. REDUNDANTLY					
217	3-958-535-01	SPRING, TENSION					
218	3-960-136-01	ARM, PENDULUM COMPULSION					
219	X-3943-502-1	TABLE, REEL (2) ASSY					
220	X-3943-503-1	TABLE, REEL (7) ASSY					
221	X-3943-548-01	CAP ASSY. MAIN BRIDGE					
222	3-958-411-01	SCREW (PS 3/8)					

5-1-6. MECHANISM DECK ASSEMBLY 3



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
251	3-701-439-01	WASHER		202	3-058-156-01	GEAR, FL. DRIVING	
252	3-959-800-01	BURRBEIL JOINT		203	3-058-415-01	SPRING, TENSION/COIL (CAP DRIVE)	
253	3-958-150-01	WORM		204	X-3943-216-1	BRAKE ASSY, CAP	
254	3-958-150-01	SPRING, ONE-WAY		205	X-3943-209-1	ARM ASSY, TENSION VEHICLE	
255	1-958-100-01	PROPELLOR		206	3-058-361-01	BELT, TENSION	
256	3-958-155-01	BEARING, CAM MOTOR		267	3-058-448-01	WHEEL, TENSION	
257	X-3943-604-1	CHAIRSS ASSY, CAM MOTOR		268	3-959-793-01	RETAINER	
258	3-958-157-01	WHEEL, ROLL		269	3-058-143-01	SLIDER, ALUM	
259	3-958-595-00	WASHER (2), STOPPER		270	3-058-162-01	GEAR, UPPER/LOWER COMMUNICATION	
260	1-582-076-11	SWITCH, ROTARY		M500	X-3943-213-1	MOTOR ASSY, CAM	
261	3-950-161-01	GEAR, CAM					

5-1-7. MECHANISM CHASSIS ASSEMBLY 4



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
301	A-678-102-A	HUB ASSY		314	3-962-940-01	GEAR (T-K), JULEX	
302	X-1943-890-01	LEVER ASSY, TRIGGERED		317	3-962-924-01	GEAR (S-K), JULEX	
303	3-950-485-01	GEAR (CT), LOADING		318	3-950-524-01	CLAW, S WINDING	
304	3-960-449-01	SPRING (CT), TENSION COIL		319	3-054-632-01	ARM, S WINDING	
305	X-1943-891-01	LEVER (T) ASSY, LOADING		320	3-950-524-01	SPRING, TENSION	
306	3-950-478-01	GEAR (S), LOADING		321	3-960-212-01	SCREW (2-K)	
307	3-960-448-01	SPRING (S), TENSION COIL		322	X-1943-896-1	LEVER ASSY	
308	X-1943-890-1	LEVER (S) ASSY, LOADING		323	3-950-542-01	SPRING (TG), TENSION COIL	
309	3-056-529-01	SPRING (MOUNT), TENSION		324	A-6750-314-A	T BLOCK ASSY, SHUTTLE	
310	3-950-940-01	RUBBER JOINT		325	L-1944-328-1	ROLLER ASSY, GUIDE	
311	3-990-720-01	NUT		326	A-6750-310-A	SHUTTLE (S) BLOCK ASSY	
312	3-908-688-01	SPRING LEAF (T), LOADING		327	3-050-504-01	ARM, FIXED RELEASE	
313	3-900-687-01	SPRING LEAF (S), LOADING		328	3-952-914-01	U-BOLT	
314	X-1943-874-1	CHASSIS ASSY, MECHANICAL		M912	1-698-604-11	ROTOR, DC (CAPSTAR)	
315	3-460-595-01	WASHER (2), STOPPER					

5-2. ELECTRICAL PARTS LIST

NOTE:

- Use to standardization, replacements in the parts list may be different from the parts specified in the diagram or the components used on the set.
- -X and -Y mean standardized parts, so they may have some differences from the original one.
- RESISTORS
All resistors are in Ohms.
METAL: Metal-film resistor.
METAL OXIDE: Metal oxide-film resistor.
Enameleable

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
In each case, U.C.A. for example:
u1 : 2CA, u2 : 2PA,
u3B : 2CB, u4C : 2CC, u5D : 2CD.
- CAPACITORS
u1 : 2F
u2 : 2F
- COILS
u1 : 2H

The components identified by mark Δ or Δ in the line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
*	A-5794-032-A	DC-57 BOARD, COMPLETE (EXCEPT 733MF/10CS, 740MF/10, 900MFCS/10FF)				< DIODE >	
*	A-5794-032-A	DC-55 BOARD (733MF/10CS, 740MF/10, 900MFCS/10FF)		1401	8-719-914-19	DIODE 1SS119-25	
		***** (Ref. No 4,000 series)				< IC >	
		< CONNECTOR >		1C501	8-759-152-51 IC	MS68HC05CWB-4.5(261)	
>	C0701	1-746-714-11 CONNECTOR, BOARD TO BOARD 5P		1C502	8-759-164-09 IC	LA72126	
>	C0702	1-746-713-11 CONNECTOR, BOARD TO BOARD 5P				< JUMPER RESISTOR >	
		*****		J0003	1-216-296-00	METAL CHIP 0 5% 1/2W	
>	A-5782-425-A	ED-40 BOARD, COMPLETE (700MF, 741MF, 760MF, 781MF, 940MF/READ)				< COIL >	
		ED-43 BOARD, COMPLETE (740MF/10, 900MFCS/10FF)		L542	1-410-508-11	INDUCTOR 10uH	
		***** (Ref. No 3,000 series)				< TRANSISTOR >	
		< CAPACITOR >		0601	8-729-010-25	TRANSISTOR MS6801-BTL	
C001	1-163-019-00	CERAMIC CHIP 0.006uF	10% 50V	0602	8-729-010-25	TRANSISTOR MS6801-BTL	
C002	1-124-126-00	ELECT 47uF	20% 16V	0603	8-729-901-06	TRANSISTOR 2EA344EX	
C003	1-163-031-13	CERAMIC CHIP 0.01uF	5% 50V			< RESISTOR >	
C004	1-163-155-00	CERAMIC CHIP 500PF	5% 50V	R901	1-216-049-90	METAL CHIP 1K 5% 1/10W	
C005	1-604-340-11	CERAMIC CHIP 1uF	15V	R902	1-216-049-00	METAL CHIP 1K 5% 1/10W	
C006	1-164-329-13	CERAMIC CHIP 0.1uF	10% 50V	R903	1-216-049-40	METAL CHIP 1K 5% 1/10W	
C007	1-163-091-13	CERAMIC CHIP 0.01uF	5% 50V	R904	1-216-149-40	METAL CHIP 1K 5% 1/10W	
C008	1-163-263-13	CERAMIC CHIP 330PF	5% 50V	R905	1-216-149-01	METAL CHIP 1K 5% 1/10W	
C009	1-163-179-00	CERAMIC CHIP 47PF	5% 50V	R906	1-216-088-00	METAL CHIP 22K 5% 1/10W	
C010	1-177-370-11	FILM 0.01uF	5% 50V	R907	1-216-073-00	METAL CHIP 10K 5% 1/10W	
C011	1-163-063-00	CERAMIC CHIP 0.022uF	10% 20V	R908	1-216-057-00	METAL CHIP 1.0K 5% 1/10W	
C012	1-163-342-11	CERAMIC CHIP 0.05uF	10% 25V	R909	1-216-043-91	METAL GLAZE 560 5% 1/10W	
C013	1-124-425-13	ELECT 2.2uF	20% 100	R910	1-216-043-91	METAL GLAZE 560 5% 1/10W	
C014	1-163-031-13	CERAMIC CHIP 0.01uF	50V	R911	1-216-296-99	CONDUCTOR, CHIP (2032)	
C015	1-124-426-00	ELECT 47uF	20% 10V	R912	1-216-033-00	METAL CHIP 330 5% 1/10W	
C016	1-163-091-13	CERAMIC CHIP 0.01uF	50V	R913	1-216-043-91	METAL GLAZE 560 5% 1/10W	
C017	1-124-903-13	ELECT 1uF	20% 50V	R914	1-216-049-00	METAL CHIP 1K 5% 1/10W	
C018	1-163-159-00	CERAMIC CHIP 820PF	5% 50V	R915	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
		< CONNECTOR >		R916	1-216-073-00	METAL CHIP 10K 5% 1/10W	
C091	1-746-710-11	CONNECTOR, BOARD TO BOARD 10P		R917	1-216-088-00	METAL CHIP 22K 5% 1/10W	
				R918	1-216-088-00	METAL CHIP 22K 5% 1/10W	

Ref. No.	Part No.	Description	Remark
R619	1-216-104-00	METAL CHIP	150K 5% 1/10W
R620	1-216-043-00	METAL CHIP	3.9K 5% 1/10W
R621	1-216-043-91	METAL GLAZE	560 5% 1/10W
R622	1-216-070-00	METAL CHIP	10K 5% 1/10W
R623	1-216-070-60	METAL CHIP	10K 5% 1/10W
< VIBRATOR >			
Z601	1-579-125-11	VIBRATOR, CERAMIC (8.0MHz)	
Z602	1-577-165-11	VIBRATOR, CERAMIC (20.0MHz)	

4-6721-500-A HF-34 BOARD, COMPLETE			

(Ref. No. 4.000 series)			
< CAPACITOR >			
C101	1-124-997-11	ELECT	10uF 20% 50V
C102	1-124-967-11	ELECT	10uF 20% 50V
C103	1-124-827-11	ELECT	4.7uF 20% 100V
C104	1-124-917-11	ELECT	4.7uF 20% 100V
C105	1-124-126-00	ELECT	47uF 20% 10V
C106	1-124-126-00	ELECT	47uF 20% 10V
C107	1-124-126-00	ELECT	47uF 20% 10V
C108	1-126-962-11	ELECT	1.2uF 20% 50V
C109	1-126-962-11	ELECT	3.3uF 20% 50V
C110	1-124-962-11	ELECT	1.2uF 20% 50V
C111	1-126-962-11	ELECT	1.2uF 20% 50V
C112	1-126-223-11	ELECT	22uF 20% 50V
C113	1-126-213-11	ELECT	22uF 20% 50V
C114	1-124-252-00	ELECT	0.33uF 20% 50V
C115	1-124-443-00	ELECT	100uF 20% 10V
C116	1-124-443-00	ELECT	100uF 20% 10V
C117	1-131-732-11	ELECT	33uF 20% 10V
C118	1-131-372-11	FILM	0.022uF 5% 50V
C119	1-131-372-11	FILM	0.022uF 5% 50V
C120	1-131-370-11	FILM	0.01uF 5% 50V
C121	1-131-370-11	FILM	0.01uF 5% 50V
C122	1-131-367-11	FILM	0.0033uF 5% 50V
C123	1-131-367-11	FILM	0.0033uF 5% 50V
C124	1-131-364-11	FILM	0.001uF 5% 50V
C125	1-163-006-11	CERAMIC CHIP	500PF 10% 50V
C126	1-163-006-11	CERAMIC CHIP	500PF 10% 50V
C127	1-163-006-11	CERAMIC CHIP	500PF 10% 50V
C128	1-163-006-11	CERAMIC CHIP	500PF 10% 50V
C129	1-163-007-11	CERAMIC CHIP	600PF 10% 50V
C130	1-163-007-11	CERAMIC CHIP	600PF 10% 50V
C131	1-131-372-11	FILM	0.022uF 5% 50V
C132	1-131-372-11	FILM	0.022uF 5% 50V
C133	1-163-145-00	CERAMIC CHIP	0.0015uF 5% 50V
C134	1-163-145-00	CERAMIC CHIP	0.0015uF 5% 50V

Ref. No.	Part No.	Description	Remark
C135	1-163-018-11	CERAMIC CHIP	0.1uF 25V
< CONNECTOR >			
* CH101	1-573-825-11	CONNECTOR, BOARD TO BOARD 13P	
* CH102	1-573-825-11	CONNECTOR, BOARD TO BOARD 13P	
* CH103	1-544-913-11	PLG. CONNECTOR 3P	
< DIODE >			
D101	8-719-404-06	DIODE 1N410	
< IC >			
IC101	8-759-486-01	TC 54RH7768-VP	
< TRANSISTOR >			
Q101	8-729-804-81	TRANSISTOR 2SD1422-S	
Q102	8-729-820-68	TRANSISTOR 2SD1802FA-S	
< RESISTOR >			
R101	1-209-306-11	METAL GLAZE	10K 0.50% 1/10W
R102	1-209-309-11	METAL GLAZE	12K 0.50% 1/10W
R103	1-216-043-00	METAL CHIP	27K 5% 1/10W
R104	1-216-043-00	METAL CHIP	22K 5% 1/10W
R105	1-216-089-00	METAL CHIP	47K 5% 1/10W
R106	1-216-089-00	METAL CHIP	47K 5% 1/10W
R107	1-216-043-00	METAL CHIP	27K 5% 1/10W
R108	1-216-075-00	METAL CHIP	12K 5% 1/10W
R109	1-216-075-00	METAL CHIP	12K 5% 1/10W
R110	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R111	1-216-168-91	METAL GLAZE	220K 5% 1/10W
R112	1-216-169-91	METAL GLAZE	250K 5% 1/10W
R113	1-216-169-00	METAL CHIP	330K 5% 1/10W
R114	1-216-069-00	METAL CHIP	6.8K 5% 1/10W
R115	1-216-069-00	METAL CHIP	6.8K 5% 1/10W
R116	1-216-077-00	METAL CHIP	15K 5% 1/10W
R118	1-216-123-00	METAL CHIP	2.2K 5% 1/10W
R120	1-216-295-91	CONNECTOR, CHIP (2012)	
R121	1-216-295-91	CONNECTOR, CHIP (2012)	
R124	1-216-006-00	METAL CHIP	5.1K 5% 1/10W
R125	1-216-045-60	METAL CHIP	1K 5% 1/10W
R130	1-216-049-00	METAL CHIP	1K 5% 1/10W
< VARIABLE RESISTOR >			
RV101	1-241-764-31	RES. ADJ. CERMET 10K	
RV102	1-241-763-21	RES. ADJ. CERMET 4.7K	
RV103	1-241-763-31	RES. ADJ. CERMET 4.7K	

Ref. No	Part No	Description	Remark
*	A-6782-429-A	HI-5 BOARD, COMPLETE (73XHPA, 7401F; US, 7411F)	
*	A-6782-435-A	HI-5 BOARD, COMPLETE (6401F; US/FRN)	
*	A-6782-442-A	HI-5 BOARD, COMPLETE (6301F; US, 5811F)	
*	A-6782-505-A	HI-19 BOARD, COMPLETE (7301F; F)	
*	A-6782-500-A	HI-19 BOARD, COMPLETE (7301F; AFCS)	
*	A-6782-507-A	HI-19 BOARD, COMPLETE (5401F; AFCS)	
*	A-6782-525-A	HI-5 BOARD, COMPLETE (6401F; OS)	
*	A-6782-526-A	HI-5 BOARD, COMPLETE (6401F; Canadian)	
*	A-6782-527-A	HI-5 BOARD, COMPLETE (7401F; Canadian)	
*	A-6782-528-A	HI-5 BOARD, COMPLETE (7301F; F)	
*	A-6782-529-A	HI-5 BOARD, COMPLETE (6301F; Canadian)	
*	A-6782-531-A	HI-5 BOARD, COMPLETE (9401F; Canadian)	
		***** (Ref. No. 8, 100 series)	
*	J-960-968-01	WASHER (A), FL < BRUSH >	
B201	L-529-104-11	TRIGGER, MICRO ELECTRIC < CAPACITOR >	
C102	L-160-346-11	CERAMIC CHIP 1uF	10V
C104	L-160-009-11	CERAMIC CHIP 8, 001uF 10% 50V (EXCEPT 600F, 7301F; AFPA/7401F, 7411F)	
C105	L-160-009-11	CERAMIC CHIP 9, 001uF 10% 50V (EXCEPT 600F, 7301F; AFPA/7401F, 7411F)	
C106	L-160-009-11	CERAMIC CHIP 9, 001uF 10% 50V (EXCEPT 600F, 7301F; AFPA/7401F, 7411F)	
C107	L-160-239-11	CERAMIC CHIP 100F 5% 50V	
C109	L-160-031-11	CERAMIC CHIP 0, 01uF 50V	
C110	L-160-031-11	CERAMIC CHIP 0, 01uF 50V	
C111	L-160-031-11	CERAMIC CHIP 0, 01uF 50V	
C112	L-160-346-11	CERAMIC CHIP 1uF 15V	
C113	L-165-219-11	CERAMIC CHIP 0, 1uF 50V	
C114	L-160-031-11	CERAMIC CHIP 0, 01uF 50V	
C115	L-160-036-91	CERAMIC CHIP 0, 1uF 25V	
C116	J-128-057-11	ELECT 200uF 20% 0.3V	
C117	L-160-036-91	CERAMIC CHIP 0, 1uF 25V	
C118	J-125-705-11	Cap. DOUBLE LAYERS, 0, 22F	
C120	L-160-035-00	CERAMIC CHIP 0, 64uF 50V	
C121	L-124-261-00	ELECT 10uF 20% 0.3V	
C122	L-128-754-11	ELECT 47uF 20% 0.3V	
C130	L-124-594-00	ELECT 10uF 20% 31V	
		< CONNECTOR >	
CN01	L-491-051-21	HOUSING, CONNECTOR 10P	
CN02	L-491-051-21	HOUSING, CONNECTOR 10P	
CN03	J-508-673-11	CONNECTOR, BOARD TO BOARD 14P	

Ref. No.	Part No.	Description	Remark
CN04	J-686-038-21	PIA, CONNECTOR (PC BOARD) 4P 1701F, 7611F, 9401F; AFCS, AFPO, AFPS)	
CN05	J-508-669-11	PIA, CONNECTOR 4P TRIGGER >	
CT01	J-141-432-91	TRIGGER, CERAMIC < DIODE >	
D001	8-719-445-04	LED SLD-342MC-A-47 (POWER)	
D002	8-719-445-04	LED SLD-342MC-A-47 (POWER)	
D004	8-719-811-19	DIODE 1ES119-25 (EXCEPT 6401F, 7301F; F) HFPA, 7401F, 7411F)	
D002	8-719-811-19	DIODE 1ES119-25	
D013	8-719-200-82	DIODE 1ES22	
D020	8-719-110-08	DIODE 1ES2-2ES-82 < FLUORESCENT INDICATOR >	
FL004	L-517-315-11	TUBE, FLUORESCENT INDICATOR < IC >	
IC001	8-759-279-61	IC STRONGARM	
IC002	8-759-288-09	IC WE9000P-6-154-B40	
IC003	8-759-248-67	IC 9402840F-8E	
IC005	L-460-833-11	IC DAY-GATHER BLOCK, REMOVED < JUMPER RESISTOR >	
JR001	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR005	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR009	L-216-294-00	METAL, CHIP 0 5% 1/8W	
JR010	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR011	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR012	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR013	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR018	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR021	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR032	L-214-296-91	CONDUCTOR, CHIP (2012) (7301F, 7311F, 9401F; AFCS/HFPA/HFPA)	
JR043	L-216-296-00	METAL, CHIP 0 5% 1/8W	
JR054	L-216-296-00	METAL, CHIP 0 5% 1/8W	
JR055	L-216-296-00	METAL, CHIP 0 5% 1/8W	
JR066	L-214-296-00	METAL, CHIP 0 5% 1/8W	
JR057	L-216-296-00	METAL, CHIP 0 5% 1/8W	
JR058	L-216-296-00	METAL, CHIP 0 5% 1/8W	
JR059	L-216-296-00	METAL, CHIP 0 5% 1/8W	
JR040	L-216-296-00	METAL, CHIP 0 5% 1/8W	
JR041	L-216-296-00	METAL, CHIP 0 5% 1/8W	

Ref. No.	Part No.	Description	QTY	UNIT	REMARKS
JR342	1-216-296-00	METAL CHIP	6	EA	1/200
JR345	1-216-296-00	METAL CHIP	6	EA	1/200
JR373	1-216-295-01	CONDUCTOR, CHIP (2012)			
JR375	1-216-295-01	CONDUCTOR, CHIP (2012)			
JR376	1-216-295-01	CONDUCTOR, CHIP (2012)			
		< COIL >			
R097	1-414-107-41	INDUCTOR 10uH			
R110	1-410-513-11	INDUCTOR 22uH			
		< JACK >			
R306	1-786-061-11	JACK, FIM (3P) 4.0H (W 2) (780HF, 781HF)			
R308	1-786-061-21	JACK, FIM (3P) 6.2H (W 2) (940HF/AFCS, 940HF/AFPS)			
		< TRANSISTOR >			
Q301	8-726-421-19	TRANSISTOR, 0W2210			
		< RESISTOR >			
R210	1-216-057-00	METAL CHIP 2.2K 5% 1/10W			
R202	1-216-020-00	METAL GLAZE 62 5% 1/10W			
R104	1-216-057-00	METAL CHIP 2.2K 5% 1/10W (640HF, 733HF/AFCS, 940HF/AFPS, 940HF/AFPA, 740HF/AFPK, 741HF)			
R105	1-216-061-00	METAL CHIP 3.3K 5% 1/10W (640HF, 733HF/AFCS, 940HF/AFPS, 940HF/AFPA, 740HF/AFPK, 741HF)			
R107	1-216-020-00	METAL CHIP 75 5% 1/10W (780HF, 781HF, 940HF/AFCS, 940HF/AFPS, 940HF/AFPA)			
R210	1-216-296-00	METAL CHIP 0 5% 1/200			
R212	1-216-073-00	METAL CHIP 10K 5% 1/10W (640HF, 733HF/AFCS, 940HF/AFPS, 940HF/AFPA, 740HF/AFPK, 741HF)			
R242	1-216-111-00	METAL CHIP 100K 5% 1/10W (780HF, 781HF, 940HF/AFCS, 940HF/AFPS, 940HF/AFPA)			
R343	1-216-073-00	METAL CHIP 10K 5% 1/10W (640HF, 733HF/AFCS, 940HF/AFPS, 940HF/AFPA, 740HF/AFPK, 741HF)			
R343	1-216-111-00	METAL CHIP 100K 5% 1/10W (780HF, 781HF, 940HF/AFCS, 940HF/AFPS, 940HF/AFPA)			
R354	1-249-424-11	CARBON 10K 5% 1/4W			
R395	1-216-073-00	METAL CHIP 10K 5% 1/10W			
R346	1-216-073-00	METAL CHIP 10K 5% 1/10W			
R377	1-216-222-00	METAL GLAZE 10K 5% 1/200			
R348	1-216-093-00	METAL CHIP 10K 5% 1/10W			
R321	1-216-073-00	METAL CHIP 10K 5% 1/10W			
R322	1-216-049-00	METAL CHIP 1K 5% 1/10W			
R323	1-216-222-00	METAL GLAZE 10K 5% 1/200			
R324	1-216-222-00	METAL GLAZE 10K 5% 1/200			
R325	1-216-295-01	CONDUCTOR, CHIP (2012)			

Ref. No.	Part No.	Description	QTY	UNIT	REMARKS
R326	1-249-424-11	CARBON 4.7K 5% 1/4W F			
R327	1-216-041-00	METAL CHIP 470 5% 1/10W (780HF, 781HF, 940HF/AFCS, 940HF/AFPS, 940HF/AFPA)			
R328	1-216-041-00	METAL CHIP 470 5% 1/10W (780HF, 781HF, 940HF/AFCS, 940HF/AFPS, 940HF/AFPA)			
R329	1-216-073-00	METAL CHIP 10K 5% 1/10W			
R330	1-216-073-00	METAL CHIP 10K 5% 1/10W			
R331	1-216-089-00	METAL CHIP 47K 5% 1/10W			
R332	1-216-111-00	METAL CHIP 470K 5% 1/10W			
R333	1-216-199-01	METAL GLAZE 1K 5% 1/200			
R334	1-216-096-00	METAL CHIP 61K 5% 1/10W			
R336	1-216-057-00	METAL CHIP 2.2K 5% 1/10W (640HF, 733HF/AFCS, 940HF/AFPS, 940HF/AFPA, 740HF/AFPK, 741HF)			
R336	1-216-295-01	CONDUCTOR, CHIP (2012) (780HF, 781HF, 940HF/AFCS, 940HF/AFPS)			
R337	1-216-296-00	METAL GLAZE 2.2K 5% 1/200 (640HF, 733HF/AFCS, 940HF/AFPS, 940HF/AFPA, 740HF/AFPK, 741HF)			
R337	1-216-296-00	METAL CHIP 0 5% 1/200 (780HF, 781HF, 940HF/AFCS, 940HF/AFPS, 940HF/AFPA)			
R338	1-216-295-01	CONDUCTOR, CHIP (2012) (780HF, 781HF, 940HF/AFCS, 940HF/AFPS, 940HF/AFPA)			
R340	1-216-061-00	METAL CHIP 3.3K 5% 1/10W			
R341	1-216-057-00	METAL CHIP 2.2K 5% 1/10W (640HF, 733HF/AFCS, 940HF/AFPS, 940HF/AFPA, 740HF/AFPK, 741HF)			
R342	1-216-045-00	METAL CHIP 4.7K 5% 1/10W (640HF, 733HF/AFCS, 940HF/AFPS, 940HF/AFPA, 740HF/AFPK, 741HF)			
R344	1-247-858-11	CARBON 47K 5% 1/4W (940HF/AFCS, 940HF/AFPS, 940HF/AFPA)			
R345	1-216-073-00	METAL CHIP 10K 5% 1/10W (640HF/AFCS, 940HF/AFPS, 940HF/AFPA)			
R346	1-249-413-11	CARBON 22K 5% 1/4W (940HF/AFCS, 940HF/AFPS)			
R347	1-247-810-11	CARBON 47K 5% 1/4W (940HF/AFCS, 940HF/AFPS, 940HF/AFPA)			
R348	1-249-437-11	CARBON 47K 5% 1/4W			
R349	1-216-222-00	METAL GLAZE 10K 5% 1/200			
R350	1-216-073-00	METAL CHIP 10K 5% 1/10W			
R351	1-216-073-00	METAL CHIP 10K 5% 1/10W			
R360	1-216-113-00	METAL CHIP 470K 5% 1/10W			
R361	1-249-417-11	CARBON 1K 5% 1/4W F			
R362	1-249-417-11	CARBON 1K 5% 1/4W F			
R363	1-249-417-11	CARBON 1K 5% 1/4W F			
R364	1-249-417-11	CARBON 1K 5% 1/4W F			
R365	1-249-417-11	CARBON 1K 5% 1/4W F			
		< SWITCH >			
S301	1-021-077-11	SWITCH TACTIL 00000			

Ref. No.	Part No.	Description	Remark
C362	1-163-317-00	CERAMIC CHIP (733HF/AFCS/AFMS/AFPA, 703HF, 703HF, 910HF/AFCS/AFMS/AFPA)	300PF 5% 50V
C404	1-163-035-00	CERAMIC CHIP	20PF 5% 50V
C402	1-163-034-14	CERAMIC CHIP	0.01uF 50V
C406	1-126-765-14	ELECT	45k 20% 10V
C407	1-163-034-00	CERAMIC CHIP	0.01uF 10% 50V
C408	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C409	1-126-765-11	ELECT	47k 20% 10V
C410	1-163-227-13	CERAMIC CHIP	10PF 0.5PF 50V
C411	1-163-235-13	CERAMIC CHIP	22PF 5% 50V
C412	1-163-239-13	CERAMIC CHIP	30PF 5% 50V
C413	1-163-235-14	CERAMIC CHIP	22PF 5% 50V
C414	1-124-257-00	ELECT	2.2k 20% 50V
C417	1-163-037-11	CERAMIC CHIP	0.022uF 10% 25V
C418	1-163-037-11	CERAMIC CHIP	0.022uF 10% 25V
C419	1-124-126-00	ELECT	47uF 20% 16V
C420	1-163-031-13	CERAMIC CHIP	0.01uF 50V
C421	1-162-305-11	CERAMIC	0.01uF 20% 16V
C422	1-124-905-11	ELECT	1uF 50% 50V
C423	1-163-139-00	CERAMIC CHIP	010PF 5% 50V
C424	1-126-765-14	ELECT	47uF 20% 10V
C425	1-163-044-11	CERAMIC CHIP	0.1uF 10% 25V
C427	1-163-038-91	CERAMIC CHIP	0.1uF 25V
C431	1-126-096-11	ELECT	10k 20% 35V
C432	1-126-096-11	ELECT	10k 20% 35V
C433	1-124-907-11	ELECT	10uF 20% 50V
C434	1-124-126-00	ELECT	47uF 20% 10V
C437	1-163-031-14	CERAMIC CHIP	0.01uF 50V
C438	1-124-124-00	ELECT	47uF 20% 10V
C439	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C421	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C422	1-124-437-11	ELECT	47k 20% 25V
C423	1-124-426-00	ELECT	47k 20% 10V
C424	1-124-472-11	ELECT	470uF 20% 10V
C425	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V
C426	1-163-009-13	CERAMIC CHIP	0.003uF 10% 50V
C703	1-124-261-00	ELECT	10uF 20% 50V
C704	1-163-031-14	CERAMIC CHIP	0.001uF 10% 50V
C706	1-124-281-00	ELECT	10uF 20% 50V
C707	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C708	1-124-477-11	ELECT	47k 20% 25V
C709	1-163-031-13	CERAMIC CHIP	0.01uF 50V
C710	1-164-163-11	CERAMIC CHIP	0.0022uF 10% 100V
C711	1-124-103-11	ELECT	100uF 20% 16V
C712	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C713	1-124-126-00	ELECT	47uF 20% 10V
C714	1-163-031-91	CERAMIC CHIP	0.01uF 50V
C716	1-124-261-00	ELECT	10uF 20% 50V

Ref. No.	Part No.	Description	Remark
C717	1-124-261-00	ELECT	10uF 20% 50V
C718	1-124-263-00	ELECT	22uF 20% 35V
C719	1-164-161-11	CERAMIC CHIP	0.0022uF 10% 100V
C721	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C723	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C724	1-124-263-00	ELECT	30uF 20% 50V
C727	1-124-269-11	ELECT	57uF 20% 16V
C728	1-107-602-11	CERAMIC CHIP (700HF, 701HF, 910HF/AFCS/AFMS/AFPA)	1uF 10% 16V
C761	1-103-662-11	CERAMIC CHIP (EXCEPT 610HF, 733HF/AFCS/AFMS/AFPA)	1uF 10% 16V
C801	1-164-159-11	CERAMIC	0.1uF 50V
C853	1-164-159-11	CERAMIC	0.1uF 50V
C854	1-124-905-11	ELECT	1uF 20% 50V
C855	1-164-160-11	CERAMIC	0.1uF 50V
C856	1-137-370-11	FILM	0.01uF 5% 50V
C857	1-126-163-11	ELECT	4.7uF 20% 50V
C860	1-126-962-11	ELECT	1.3uF 20% 50V
C859	1-163-664-00	CERAMIC CHIP	0.0022uF 5% 50V
C860	1-163-643-00	CERAMIC CHIP	0.0015uF 5% 50V
C861	1-124-925-11	ELECT	2.2uF 20% 100V
C862	1-163-151-00	CERAMIC CHIP	0.001uF 5% 50V
C863	1-163-141-00	CERAMIC CHIP	0.001uF 5% 50V
C864	1-124-231-11	ELECT	22uF 20% 50V
C865	1-124-231-11	ELECT	22uF 20% 50V
C866	1-124-252-00	ELECT	0.3uF 20% 50V
C867	1-124-907-11	ELECT	10uF 20% 50V
C881	1-104-400-11	FILM (EXCEPT 540HF/AFCS/AFMS/AFPA)	0.015uF 5% 100V
C881	1-137-612-11	FILM (540HF/AFCS/AFMS/AFPA)	0.0068uF 5% 100V
C882	1-164-232-11	CERAMIC CHIP	0.01uF 50V
C883	1-163-011-11	CERAMIC CHIP	0.0015uF 10% 50V
C884	1-124-120-11	ELECT (EXCEPT 940HF/AFCS/AFMS/AFPA)	220uF 20% 25V
C884	1-126-801-11	ELECT (940HF/AFCS/AFMS/AFPA)	10uF 20% 16V
C889	1-137-452-11	FILM 540HF	5% 100V
C891	1-104-097-11	FILM (540HF/AFCS/AFMS/AFPA)	0.047uF 5% 100V
C902	1-164-232-11	CERAMIC CHIP	0.01uF 50V
C913	1-163-011-11	CERAMIC CHIP	0.0015uF 10% 50V
C934	1-124-120-11	ELECT (EXCEPT 940HF/AFCS/AFMS/AFPA)	220uF 20% 25V
C934	1-126-104-11	ELECT (940HF/AFCS/AFMS/AFPA)	100uF 20% 16V
C901	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C902	1-124-843-00	ELECT	100uF 20% 10V
C904	1-163-031-91	CERAMIC CHIP	0.1uF 50V
C905	1-126-916-11	ELECT (EXCEPT 610HF, 733HF/AFCS/AFMS/AFPA)	100uF 20% 6.3V

Ref. No.	Part No.	Description	Remark
		. JACK >	
CJ002	1-766-222-11	JACK, PIN 6P (LINE IN / LINE OUT)	
CJ754	1-566-862-11	JACK (CONTROL S (1)) (740HF, 740HF, 940HF, 940HF/AFCS/AFMA/AFPA)	
CJ764	1-566-872-11	JACK (CONTROL S (0)) (EXCEPT 640WF, 733HF, 733HF/AFCS/AFMA/AFPA)	
		. CONNECTOR >	
* CW651	1-766-537-11	CONNECTOR (HMD) 5P	
* CW671	1-766-716-11	CONNECTOR, BOARD TO BOARD 3P	
CK101	1-506-466-11	PIN, CONNECTOR 3P	
CR681	1-506-469-11	PIN, CONNECTOR 4P	
* CW692	1-506-391-00	PIN, CONNECTOR 3P	
CR693	1-506-468-11	PIN, CONNECTOR 3P	
* CW901	1-573-949-11	CONNECTOR, BOARD TO BOARD 11P	
* CW902	1-573-949-11	CONNECTOR, BOARD TO BOARD 11P	
* CW903	1-766-715-11	CONNECTOR, BOARD TO BOARD 19P (740HF/AFPA, 741HF, 780HF, 781HF, 940HF/AFCS/AFMA/AFPA)	
CW904	1-766-992-11	CONNECTOR, FFC/FFC (LIE) 19P	
CW905	1-766-992-11	CONNECTOR, FFC/FFC (LIE) 19P	
CK907	1-573-944-11	CONNECTOR, BOARD TO BOARD 14P	
CK908	1-573-946-11	CONNECTOR, BOARD TO BOARD 14P	
* CW909	1-766-536-11	CONNECTOR, BOARD TO BOARD 8P	
CK910	1-770-017-11	CONNECTOR, BOARD TO BOARD 19P	
* CW912	1-766-717-11	CONNECTOR, BOARD TO BOARD 5P	
		< DIODE >	
D001	8-719-043-26	LED, GL5291 (TOP/END LED)	
D006	8-719-109-91	DIODE, 80V, 2ES-82	
D097	8-719-109-80	DIODE, 80V, 2ES-82	
D071	8-719-110-14	DIODE, 80V, JES-83	
D096	8-719-081-43	DIODE, 1SS187	
D251	8-719-091-43	DIODE, 1SS180	
D252	8-719-101-50	DIODE, 80V, 3E-12	
D253	8-719-101-47	DIODE, 80V, 3E-12	
D402	8-719-091-43	DIODE, 1SS183	
D604	8-719-109-75	DIODE, 80V, 3ES-82	
D605	8-719-109-75	DIODE, 80V, 3ES-82	
ΔD702	8-719-010-76	DIODE, 1SS220	
D703	8-719-979-94	DIODE, D73-T111-30C	
D704	8-719-200-82	DIODE, 1JES2	
D751	8-719-001-78	DIODE, 1SS164 (740HF, 741HF, 940HF/AFCS/AFMA/AFPA)	
D752	8-719-110-08	DIODE, 80V, 2ES-82 (740HF, 741HF, 940HF/AFCS/AFMA/AFPA)	
D841	8-719-001-78	DIODE, 1SS164 (EXCEPT 640WF, 733HF/AFCS/AFMA/AFPA)	
D842	8-719-010-08	DIODE, 80V, 2ES-82 (EXCEPT 640WF, 733HF/AFCS/AFMA/AFPA)	

Ref. No.	Part No.	Description	Remark
D724	8-719-001-48	DIODE, 1SS163 (EXCEPT 640WF, 733HF/AFCS/AFMA/AFPA)	
D772	8-719-109-51	DIODE, 80V, 2ES82 (EXCEPT 640WF, 733HF/AFCS/AFMA/AFPA)	
D772	8-719-110-08	DIODE, 80V, 2ES-82 (EXCEPT 640WF, 733HF/AFCS/AFMA/AFPA)	
D851	8-719-001-78	DIODE, 1SS164	
D901	8-719-001-48	DIODE, 1SS163	
D902	8-719-200-82	DIODE, 1JES2	
D907	8-719-200-82	DIODE, 1JES2	
D904	8-719-001-75	DIODE, 1SS160	
		. IC >	
IC002	8-759-100-95	IC, μPC2140Z	
IC011	8-759-244-26	IC, BA6201-Y2	
IC191	8-759-246-14	IC, TAD622M	
IC201	8-759-051-50	IC, CP67249-0510 (EXCEPT 640WF, 733HF/AFCS/AFMA/AFPA)	
IC201	8-759-040-49	IC, CP67249-0574 (640WF, 733HF/AFCS/AFMA/AFPA)	
IC251	8-759-702-02	IC, NJM452M	
IC351	8-759-097-20	IC, HD4933FP (EXCEPT 640WF, 740HF/AFPA, 741HF)	
IC401	8-759-288-96	IC, M70303FP-118-ED	
IC402	8-759-164-09	IC, LA1215M	
IC601	8-759-927-56	IC, BA7021	
IC606	8-759-099-06	IC, MC1405ZF	
IC607	8-759-924-46	IC, BA1560F	
IC701	8-759-701-59	IC, NJM4569M	
IC851	8-759-049-02	IC, BA7786FS-E2	
		< RESISTOR >	
J010	1-216-296-00	METAL CHIP, 0 Ω, 5%, 1/8W	
J011	1-216-296-00	METAL CHIP, 0 Ω, 5%, 1/8W	
J012	1-216-295-91	CONDUCTOR, CHIP (2012)	
J013	1-216-296-81	CONDUCTOR, CHIP (2012)	
J014	1-216-296-00	METAL CHIP, 0 Ω, 5%, 1/8W	
J015	1-216-295-91	CONDUCTOR, CHIP (2012)	
J016	1-216-295-91	CONDUCTOR, CHIP (2012)	
J017	1-216-296-00	METAL CHIP, 0 Ω, 5%, 1/8W	
J018	1-216-296-00	METAL CHIP, 0 Ω, 5%, 1/8W	
J019	1-216-296-01	CONDUCTOR, CHIP (2012)	
J020	1-216-295-91	CONDUCTOR, CHIP (2012)	
J021	1-216-295-91	CONDUCTOR, CHIP (2012)	
J022	1-216-295-91	CONDUCTOR, CHIP (2012)	
J023	1-216-296-00	METAL CHIP, 0 Ω, 5%, 1/8W	
J024	1-216-295-91	CONDUCTOR, CHIP (2012)	
J025	1-216-295-91	CONDUCTOR, CHIP (2012)	
J026	1-216-295-91	CONDUCTOR, CHIP (2012)	
J027	1-216-295-01	CONDUCTOR, CHIP (2012)	
J028	1-216-295-91	CONDUCTOR, CHIP (2012)	
J029	1-216-295-91	CONDUCTOR, CHIP (2012)	

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	QTY	UOM
JR706	1-216-295-09	METAL CHIP	0	EA 1/30
JR710	1-216-295-01	CONDUCTOR, CHIP (2012)		
JR716	1-216-295-91	CONDUCTOR, CHIP (2012)		
JR891	1-216-295-91	CONDUCTOR, CHIP (2012)		
JR901	1-216-295-91	(EXCEPT 940HF, 9FCS, 9FMC, 9FFX) CONDUCTOR, CHIP (2012) (740HF, 9FPA, 741UF, 730HF, 731HF, 940HF, 9FUS, 9FVCL, 9FFX)		
JR806	1-216-295-91	CONDUCTOR, CHIP (2012)		
		< COIL >		
L101	1-410-482-31	INDUCTOR 100uH		
L202	1-410-419-11	INDUCTOR 15uH		
L251	1-410-512-11	INDUCTOR 20uH		
L401	1-410-482-31	INDUCTOR 100uH		
L403	1-405-974-21	INDUCTOR 20uH		
L404	1-410-482-31	INDUCTOR 100uH		
L401	1-410-509-11	INDUCTOR 10uH		
L403	1-410-482-31	INDUCTOR 100uH		
L404	1-410-482-31	INDUCTOR 100uH		
L405	1-410-482-31	INDUCTOR 100uH		
L506	1-410-501-11	INDUCTOR 2.2uH		
L701	1-414-163-40	INDUCTOR 10uH		
L702	1-414-169-31	INDUCTOR 100uH		
L703	1-414-163-40	INDUCTOR 10uH		
L712	1-410-589-11	INDUCTOR 2.2uH		
L851	1-410-482-31	INDUCTOR 100uH		
L881	1-410-587-11	INDUCTOR 1.2uH		
L891	1-410-587-11	INDUCTOR 1.2uH (940HF, 9FCS, 9FMC, 9FFX)		
		< FIB CABLE >		
P701	1-565-110-00	CABLE, FIB		
		< PHOTO INTERUMPTER >		
PH001	6-749-010-19	PHOTO INTERUMPTER GP33113		
PH002	6-749-010-20	PHOTO INTERUMPTER GP33114		
		< IC LINK >		
ΔPS201	1-512-727-11	LINK, IC 0.25A (1CP-NS)		
ΔPS301	1-512-727-11	LINK, IC 0.25A (1CP-NS)		
		< TRANSISTOR >		
Q101	8-729-025-92	PHOTO TRANSISTOR PT330F		
Q102	8-729-025-92	PHOTO TRANSISTOR PT330F		
Q601	8-729-016-05	TRANSISTOR 2SC1415-UB		
Q351	8-729-011-06	TRANSISTOR 2SA1428X (EXCEPT 640HF, 740HF, 9FFX, 741HF)		
Q253	8-729-012-19	TRANSISTOR 2N213 (EXCEPT 640HF, 740HF, 9FFX, 741HF)		

Ref. No.	Part No.	Description	Remark
Q354	8-729-010-25	TRANSISTOR 2SD4041-RT1 (EXCEPT 640HF, 740HF, 9FFX, 741HF)	
Q402	8-729-011-06	TRANSISTOR 2SA1428X	
Q404	8-729-010-05	TRANSISTOR 2SD109-RT1	
Q410	8-729-010-05	TRANSISTOR 2SD109-RT1	
Q407	8-729-010-05	TRANSISTOR 2SD109-RT1	
Q603	8-729-010-05	TRANSISTOR 2SD109-RT1	
Q202	8-729-021-19	TRANSISTOR 2N2213	
ΔQ203	8-729-173-30	TRANSISTOR 2SA1733-B	
Q205	8-729-010-25	TRANSISTOR 2SD4041-RT1	
Q906	8-729-010-25	TRANSISTOR 2SD4041-RT1	
Q751	8-729-021-19	TRANSISTOR 2N2213 (280HF, 730HF, 940HF/ 9FCS, 9FVCL, 9FFX)	
Q752	8-729-010-05	TRANSISTOR 2SD109-RT1 (730HF, 731HF, 940HF, 9FCS, 9FVCL, 9FFX)	
Q761	8-729-010-25	TRANSISTOR 2SD4041-RT1 (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q762	8-729-010-05	TRANSISTOR 2SD109-RT1 (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q763	8-729-010-05	TRANSISTOR 2SD109-RT1 (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q764	8-729-021-19	TRANSISTOR 2N2213 (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q776	8-729-100-07	TRANSISTOR 2SD174-3A (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q777	8-729-010-25	TRANSISTOR 2SD4041-RT1 (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q778	8-729-010-05	TRANSISTOR 2SD109-RT1 (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q779	8-729-010-05	TRANSISTOR 2SD109-RT1 (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q781	8-729-010-05	TRANSISTOR 2SD109-RT1 (640HF, 731HF, 940HF, 9FCS, 9FVCL, 9FFX)	
Q792	8-729-010-05	TRANSISTOR 2SD109-RT1 (740HF, 731HF, 940HF, 9FCS, 9FVCL, 9FFX)	
Q793	8-729-010-25	TRANSISTOR 2SD4041-RT1 (740HF, 731HF, 940HF, 9FCS, 9FVCL, 9FFX)	
Q811	8-729-012-21	TRANSISTOR 2SC4040-TL2-0	
Q812	8-729-216-22	TRANSISTOR 2SA1162	
Q819	8-729-010-25	TRANSISTOR 2SD4041-RT1	
Q821	8-729-012-21	TRANSISTOR 2SC4040-TL2-0 (940HF, 9FCS/ 9FVCL, 9FFX)	
Q822	8-729-216-22	TRANSISTOR 2SA1162-0 (940HF, 9FCS/ 9FVCL, 9FFX)	
		< RESISTOR >	
R001	1-216-104-00	METAL CHIP	50K 5% 1/30
R002	1-247-391-00	CARBON	120K 5% 1/4W
R003	1-249-937-11	CARBON	47K 5% 1/4W
R004	1-216-089-00	METAL CHIP	47K 5% 1/30
R005	1-249-913-11	CARBON	470 5% 1/4W 7

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.
--	--

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
W06	1-216-037-00	METAL CHIP	100K 5% 1/10W	R277	1-216-068-00	METAL CHIP	8.2K 5% 1/10W
W07	1-216-043-00	METAL CHIP	100K 5% 1/10W	R278	1-216-234-91	METAL GLAZE	10K 5% 1/10W
W08	1-216-065-00	METAL CHIP	4.7K 5% 1/10W	R351	1-216-226-00	METAL GLAZE	15K 5% 1/10W
W09	1-216-031-00	METAL CHIP	100 5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	
W10	1-216-059-00	METAL CHIP	2.7K 5% 1/10W	R352	1-216-073-00	METAL CHIP	100 5% 1/10W
						(EXCEPT 740HF, 740HF/HPX, 740HF)	
W11	1-216-089-00	METAL CHIP	47K 5% 1/10W	R353	1-216-073-00	METAL CHIP	100 5% 1/10W
W12	1-216-051-00	METAL CHIP	2.2K 5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	
W15	1-216-090-00	METAL CHIP	47K 5% 1/10W	R354	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
W16	1-249-421-11	CARBON	2.2K 5% 1/10W F			(EXCEPT 740HF, 740HF/HPX, 740HF)	
W17	1-249-400-11	CARBON	39 5% 1/10W F	R355	1-216-073-00	METAL CHIP	100 5% 1/10W
						(EXCEPT 740HF, 740HF/HPX, 740HF)	
W18	1-249-400-11	CARBON	39 5% 1/10W F	R361	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
W19	1-249-421-11	CARBON	2.2K 5% 1/10W F			(EXCEPT 740HF, 740HF/HPX, 740HF)	
W51	1-216-089-00	METAL CHIP	47K 5% 1/10W	R361	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
W52	1-216-089-00	METAL CHIP	47K 5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	
W53	1-216-089-00	METAL CHIP	47K 5% 1/10W	R361	1-216-295-91	CONNECTOR, CHIP (2012)	
						(640HF, 740HF/HPX, 740HF)	
W54	1-216-089-00	METAL CHIP	47K 5% 1/10W	R362	1-216-049-00	METAL CHIP	1K 5% 1/10W
W71	1-216-073-00	METAL CHIP	100 5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	
W72	1-216-073-00	METAL CHIP	100 5% 1/10W	R363	1-216-049-00	METAL CHIP	1K 5% 1/10W
R101	1-216-119-00	METAL CHIP	820K 5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	
R102	1-216-093-00	METAL CHIP	50K 5% 1/10W	R364	1-216-232-00	METAL GLAZE	20K 5% 1/10W
						(EXCEPT 740HF, 740HF/HPX, 740HF)	
R103	1-216-093-00	METAL CHIP	100K 5% 1/10W	R365	1-216-063-00	METAL CHIP	6.2K 5% 1/10W
R104	1-216-093-00	METAL CHIP	100K 5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	
R105	1-216-085-00	METAL CHIP	30K 5% 1/10W	R366	1-216-069-00	METAL CHIP	6.8K 5% 1/10W
R106	1-216-065-00	METAL CHIP	6.7K 5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	
R107	1-216-057-00	METAL CHIP	330 5% 1/10W	R367	1-216-069-00	METAL CHIP	6.8K 5% 1/10W
						(EXCEPT 740HF, 740HF/HPX, 740HF)	
R108	1-216-121-00	METAL CHIP	1M 5% 1/10W	R368	1-216-069-00	METAL CHIP	6.8K 5% 1/10W
R109	1-216-659-11	METAL CHIP	2.2K 0.5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	
R110	1-216-651-11	METAL CHIP	1K 0.5% 1/10W	R369	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R111	1-216-037-00	METAL CHIP	100K 5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	
R126	1-216-654-11	METAL CHIP	2.2K 0.5% 1/10W	R370	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
						(EXCEPT 740HF, 740HF/HPX, 740HF)	
R214	1-216-049-00	METAL CHIP	1K 5% 1/10W	R371	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R217	1-216-073-00	METAL CHIP	100 5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	
R219	1-216-073-00	METAL CHIP	100 5% 1/10W	R372	1-216-060-00	METAL CHIP	6.8K 5% 1/10W
R220	1-216-065-00	METAL CHIP	4.7K 5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	
R224	1-249-421-11	CARBON	2.2K 5% 1/10W F	R310	1-216-085-00	METAL CHIP	4.3K 5% 1/10W
						(EXCEPT 740HF, 740HF/HPX, 740HF)	
R225	1-216-090-00	METAL CHIP	47K 5% 1/10W	R311	1-216-295-91	CONNECTOR, CHIP (2012)	
R226	1-216-689-11	METAL CHIP	30K 0.5% 1/10W			(640HF, 740HF/HPX, 740HF)	
R227	1-216-689-11	METAL CHIP	30K 0.5% 1/10W	R314	1-216-063-00	METAL CHIP	1.9K 5% 1/10W
R257	1-249-429-11	CARBON	100 5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	
R258	1-216-049-00	METAL CHIP	1K 5% 1/10W	R401	1-216-049-00	METAL CHIP	1K 5% 1/10W
						(EXCEPT 740HF, 740HF/HPX, 740HF)	
R262	1-216-057-00	METAL CHIP	2.2K 5% 1/10W	R404	1-216-073-00	METAL CHIP	100 5% 1/10W
R267	1-216-053-00	METAL CHIP	2.2K 5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	
R264	1-216-103-91	METAL GLAZE	100K 5% 1/10W	R405	1-216-295-91	CONNECTOR, CHIP (2012)	
R265	1-216-073-00	METAL CHIP	100 5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	
R266	1-216-079-00	METAL CHIP	18K 5% 1/10W	R409	1-249-114-11	CARBON	550 5% 1/10W F
				R409	1-216-101-00	METAL CHIP	150K 5% 1/10W
R271	1-216-065-00	METAL CHIP	4.7K 5% 1/10W	R409	1-216-063-00	METAL CHIP	3.9K 5% 1/10W
R274	1-216-083-00	METAL CHIP	27K 5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	
R275	1-216-093-00	METAL CHIP	82K 5% 1/10W	R410	1-216-043-91	METAL GLAZE	550 5% 1/10W
R276	1-216-056-00	METAL GLAZE	2K 5% 1/10W			(EXCEPT 740HF, 740HF/HPX, 740HF)	

Ref. No.	Part No.	Description	QTY	UOM	Notes
8411	1-216-025-00	METAL CHIP	105	EA	1/10M
8412	1-216-025-91	CONDUCTOR, CHIP (2612)			
8413	1-216-295-91	CONDUCTOR, CHIP (2612)			
8414	1-216-081-00	METAL CHIP	228	EA	1/10M
8415	1-216-051-00	METAL CHIP	1.2K	EA	1/10M
8416	1-216-059-00	METAL CHIP	2.7K	EA	1/10M
8417	1-216-013-00	METAL CHIP	220	EA	1/10M
8418	1-216-295-91	CONDUCTOR, CHIP (2612)			
8421	1-216-081-00	METAL CHIP	218	EA	1/10M
8422	1-216-073-00	METAL CHIP	108	EA	1/10M
8423	1-216-017-00	METAL CHIP	47	EA	1/10M
8424	1-216-017-00	METAL CHIP	47	EA	1/10M
8429	1-216-081-00	METAL CHIP	228	EA	1/10M
		(780HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
8431	1-216-230-00	METAL GLAZE	728	EA	1/8M
		(780HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
8432	1-216-081-00	METAL CHIP	228	EA	1/10M
8433	1-216-095-00	METAL CHIP	21K	EA	1/10M
		(780HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
8434	1-216-295-91	CONDUCTOR, CHIP (2012) (640HF, 733HF/AFCS/AFMG/AFPA, 740HF/AFPA, 741HF)			
8434	1-216-085-00	METAL CHIP	33K	EA	1/10M
8435	1-216-085-00	METAL CHIP	33K	EA	1/10M
8436	1-216-295-91	CONDUCTOR, CHIP (2012)			
8438	1-216-084-00	METAL CHIP	22K	EA	1/10M
8439	1-216-084-00	METAL CHIP	22K	EA	1/10M
8440	1-216-085-90	METAL CHIP	33K	EA	1/10M
8441	1-216-085-00	METAL CHIP	33K	EA	1/10M
		(780HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
8441	1-216-295-91	CONDUCTOR, CHIP (2012) (640HF, 733HF/AFCS/AFMG/AFPA, 740HF/AFPA, 741HF)			
8442	1-216-295-91	CONDUCTOR, CHIP (2012)			
8443	1-216-085-00	METAL CHIP	33K	EA	1/10M
8444	1-216-081-00	METAL CHIP	22K	EA	1/10M
8445	1-216-085-00	METAL CHIP	33K	EA	1/10M
8446	1-249-435-11	CARBON	35K	EA	1/4M
8453	1-216-037-00	METAL CHIP	281	EA	1/10M
8455	1-249-408-11	CARBON	140	EA	1/4M F
8456	1-247-813-21	CARBON	150	EA	1/4M
8457	1-216-022-00	METAL CHIP	68	EA	1/10M
8458	1-216-190-00	METAL GLAZE	470	EA	1/8M
8459	1-216-041-00	METAL CHIP	470	EA	1/10M
8460	1-216-043-91	METAL GLAZE	540	EA	1/10M
8461	1-216-043-91	METAL GLAZE	540	EA	1/10M
8462	1-216-022-00	METAL CHIP	35	EA	1/10M
8462	1-216-041-00	METAL CHIP	470	EA	1/10M
8463	1-216-295-91	CONDUCTOR, CHIP (2012)			
8464	1-216-295-91	CONDUCTOR, CHIP (2012)			
8466	1-216-067-00	METAL CHIP	2.2K	EA	1/10M

Ref. No.	Part No.	Description	QTY	UOM	Notes
8466	1-216-065-00	METAL CHIP	4.7K	EA	1/10M
8468	1-216-025-00	METAL CHIP	100	EA	1/10M
8469	1-216-080-00	METAL CHIP	47K	EA	1/10M
8470	1-216-049-00	METAL CHIP	1K	EA	1/10M
8471	1-216-037-00	METAL CHIP	130	EA	1/10M
8474	1-216-037-00	METAL CHIP	130	EA	1/10M
8475	1-216-025-00	METAL CHIP	100	EA	1/10M
8476	1-216-071-00	METAL CHIP	8.2K	EA	1/10M
8477	1-216-075-00	METAL CHIP	12K	EA	1/10M
8478	1-216-025-00	METAL CHIP	100	EA	1/10M
8479	1-216-089-00	METAL CHIP	1K	EA	1/10M
8480	1-216-085-00	METAL CHIP	1K	EA	1/10M
8481	1-216-037-00	METAL CHIP	330	EA	1/10M
8482	1-249-423-11	CARBON	3.3K	EA	1/4M F
8483	1-216-073-00	METAL CHIP	10K	EA	1/10M
8486	1-216-049-00	METAL CHIP	1K	EA	1/10M
8487	1-216-084-00	METAL CHIP	22K	EA	1/10M
8488	1-249-417-11	CARBON	1K	EA	1/4M F
8489	1-216-210-91	CONDUCTOR, CHIP (2012)			
8490	1-216-242-91	METAL GLAZE	62K	EA	1/8M
8494	1-216-295-91	CONDUCTOR, CHIP (2012)			
8494	1-216-045-00	METAL CHIP	4.7K	EA	1/10M
		(780HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
8495	1-216-087-00	METAL CHIP	100K	EA	1/10M
		(780HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
8495	1-216-106-91	METAL GLAZE	220K	EA	1/10M
		(780HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
8496	1-216-057-00	METAL CHIP	2.2K	EA	1/10M
		(780HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
8496	1-247-807-31	CARBON	100	EA	1/4M
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
8496	1-216-041-00	METAL CHIP	470	EA	1/10M
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
8496	1-216-065-00	METAL CHIP	4.7K	EA	1/10M
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
8496	1-216-073-00	METAL CHIP	10K	EA	1/10M
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
8496	1-216-089-00	METAL CHIP	47K	EA	1/10M
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
8496	1-216-075-00	METAL CHIP	10K	EA	1/10M
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
8497	1-216-057-00	METAL CHIP	2.2K	EA	1/10M
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
8498	1-216-105-91	METAL GLAZE	220K	EA	1/10M
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
8499	1-216-057-00	METAL CHIP	100K	EA	1/10M
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
8499	1-216-065-00	METAL CHIP	4.7K	EA	1/10M
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
8499	1-216-101-00	METAL CHIP	150K	EA	1/10M
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			

Ref. No.	Part No.	Description	Remark
R776	1-216-049-00	METAL CHIP (EXCEPT 640HF, 730HF/AFC5/AFM4, HPFA)	1K 5% 1/10W
R777	1-216-049-00	METAL CHIP (EXCEPT 640HF, 730HF/AFC5/AFM4, HPFA)	10 5% 1/10W
R778	1-216-049-00	METAL CHIP (EXCEPT 640HF, 730HF/AFC5/AFM4, HPFA)	10 5% 1/10W
R779	1-216-073-00	METAL CHIP (EXCEPT 640HF, 730HF/AFC5/AFM4, HPFA)	10K 5% 1/10W
R780	1-216-049-00	METAL CHIP (EXCEPT 640HF, 730HF/AFC5/AFM4, HPFA)	1K 5% 1/10W
R781	1-216-025-00	METAL CHIP (EXCEPT 640HF, 730HF/AFC5/AFM4, HPFA)	150 5% 1/10W
R784	1-216-097-00	METAL CHIP 4700H, 701HE, 940HF/AFC5/AFM4/HPFX	100K 5% 1/10W
X782	1-216-093-00	METAL CHIP (700HF, 701HE, 940HF/AFC5/AFM4/HPFX)	100W 5% 1/10W
R793	1-216-089-00	METAL CHIP (700HF, 701HE, 940HF/AFC5/AFM4/HPFX)	47K 5% 1/10W
R794	1-216-073-00	METAL CHIP (700HF, 701HE, 940HF/AFC5/AFM4/HPFX)	10K 5% 1/10W
R851	1-216-081-00	METAL CHIP	22K 5% 1/10W
R852	1-216-071-00	METAL CHIP	2.2K 5% 1/10W
R855	1-216-093-00	METAL CHIP	10K 5% 1/10W
R856	1-216-071-00	METAL CHIP	8.2K 5% 1/10W
R857	1-216-085-00	METAL CHIP	33K 5% 1/10W
R858	1-216-129-00	METAL CHIP	2.2K 5% 1/10W
R859	1-216-295-91	CONDUCTOR, CHIP (2012)	
R860	1-216-083-00	METAL CHIP	27K 5% 1/10W
R861	1-216-073-00	METAL CHIP	10K 5% 1/10W
R862	1-216-109-00	METAL CHIP	1500K 5% 1/10W
R863	1-216-089-00	METAL CHIP	6.8K 5% 1/10W
R864	1-216-041-00	METAL CHIP	470 5% 1/10W
R865	1-216-049-00	METAL CHIP	47K 5% 1/10W
R866	1-216-099-00	METAL CHIP	120W 5% 1/10W
R867	1-216-075-00	METAL CHIP	82K 5% 1/10W
R868	1-216-089-00	METAL CHIP	47K 5% 1/10W
R869	1-216-075-00	METAL CHIP	10K 5% 1/10W
R870	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
R871	1-216-073-00	METAL CHIP	10K 5% 1/10W
R872	1-216-097-00	METAL CHIP	100K 5% 1/10W
R873	1-216-295-91	CONDUCTOR, CHIP (2012)	
R875	1-249-430-11	CARBON	32K 5% 1/4W
R876	1-216-091-00	METAL CHIP	10 5% 1/10W
R877	1-216-049-00	METAL CHIP	1K 5% 1/10W
R881	1-216-081-00	METAL CHIP	22K 5% 1/10W
ΔR882	1-249-349-11	CARBON (EXCEPT 940HF/AFC5/AFM4/HPFX)	4.7 5% 1/4W F
ΔR883	1-249-395-11	CARBON (940HF/AFC5/AFM4/HPFX)	15 5% 1/4W F
R901	1-249-417-11	CARBON	1K 5% 1/4W F

Ref. No.	Part No.	Description	Remark
R904	1-216-099-11	METAL CHIP (EXCEPT 940HF/AFC5/AFM4/HPFX)	39K 0.5% 1/10W
R904	1-216-097-00	METAL CHIP (940HF/AFC5/AFM4/HPFX)	100K 5% 1/10W
R907	1-216-295-91	CONDUCTOR, CHIP (2012)	
R991	1-216-083-00	METAL CHIP (940HF/AFC5/AFM4/HPFX)	27K 5% 1/10W
ΔR992	1-249-394-11	CARBON (940HF/AFC5/AFM4/HPFX)	12 5% 1/4W F
R993	1-249-417-11	CARBON (940HF/AFC5/AFM4/HPFX)	1K 5% 1/4W F
R994	1-216-097-00	METAL CHIP (940HF/AFC5/AFM4/HPFX)	100K 5% 1/10W
R996	1-216-089-00	METAL CHIP	47K 5% 1/10W
R997	1-216-073-00	METAL CHIP	10K 5% 1/10W
R998	1-216-085-00	METAL CHIP	33K 5% 1/10W
R999	1-216-095-00	METAL CHIP	82K 5% 1/10W
R999	1-216-090-11	METAL CHIP	5.1K 0.50% 1/10W
R999	1-216-094-11	METAL CHIP	1.2K 0.50% 1/10W
R999	1-216-099-00	METAL CHIP	1K 5% 1/10W
R999	1-216-049-00	METAL CHIP	1K 5% 1/10W
R999	1-216-057-00	METAL CHIP (700HF/AFC5, 701HE, 700HF, 701HE, 940HF/ AFC5/AFM4/HPFX)	2.2K 5% 1/10W
		< RF INDUCTOR >	
ΔR999	1-454-989-11	INDUCTOR, RF	
		< VARIABLE RESISTOR >	
R999	1-238-602-11	RES, ADJ, CARBON 40W	
R999	1-238-602-11	RES, ADJ, CARBON 40W	
R999	1-238-602-11	RES, ADJ, CARBON 40W	
		< SWITCH >	
S992	1-579-993-11	SWITCH PUSH (1 NEED) (REC PROOF)	
		< TRANSFORMER >	
T991	1-423-413-11	TRANSFORMER, BIAS OSCILLATION (940HF/AFC5/AFM4/HPFX)	
T991	1-423-414-11	TRANSFORMER, BIAS OSCILLATION (EXCEPT 940HF/AFC5/AFM4/HPFX)	
T991	1-423-415-11	TRANSFORMER, BIAS OSCILLATION (940HF/AFC5/AFM4/HPFX)	
		< TUNER >	
ΔT991	8-590-254-00	TUNER BEE-W402	
		< VIBRATOR >	
X996	1-789-494-11	VIBRATOR, CRYSTAL (14MHz)	
X996	1-577-251-11	VIBRATOR, CRYSTAL (14.3MHz)	

The components identified by
mark Δ or dotted line with
mark Δ are critical for
safely. Replace only with
part number specified.

Les composants identifiés
par une marque Δ sont
critiques pour la sécurité.
Ne les remplacez que par une pièce
portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark
X402	1-077-165-11	VIOLATOR CERAMIC (500PCS)	

*	A-6782-424-A	MF-253 BOARD, COMPLETE (300PF, 700PF, 300PF, 400PF)	
*	A-6782-430-A	MF-253 BOARD, COMPLETE (600PF, 700PF, 700PF, 700PF)	
*	A-6782-501-A	MF-274 BOARD, COMPLETE (730PF, 400PF, 340PF)	
*	A-6782-502-A	MF-274 BOARD, COMPLETE (340PFCS, 400PF)	

(Ref No 1,000 series)			
< CAPACITOR >			
C401	1-163-108-31	CERAMIC CHIP	0.1uF 25V
C402	1-124-584-00	ELECT	100uF 20% 50V
< CONNECTOR >			
C403	1-766-850-11	CONNECTOR, BOARD TO BOARD 14P	
* C402	1-695-822-11	CONNECTOR, BOARD TO BOARD 2P	
< DIODE >			
D403	8-719-045-62	LED SLR-342YC-A-47 (● REC)	
D404	8-719-045-63	LED SLR-342YC-A-47 (● REC (TUM))	
D405	8-719-045-68	LED SLR-342YC-A-47 (● REC (TUM))	
D406	8-719-045-62	LED SLR-342YC-A-47 (TIMER)	
D408	8-719-045-63	LED SLR-342YC-A-47 (TIMER (TUM))	
D409	8-719-045-63	LED SLR-342YC-A-47 (TIMER (TUM))	
D410	8-719-051-17	LED SLR-342DCT31 (● PAUSE)	
D415	8-719-200-82	DIODE 1E132	
D424	8-719-015-63	LED SLR-342YC-A-47 (REC (TUM))	
D425	8-719-045-63	LED SLR-342YC-A-47 (REC (TUM))	
D428	8-719-045-63	LED SLR-342YC-A-47 (TIMER (TUM))	
D429	8-719-045-63	LED SLR-342YC-A-47 (TIMER (TUM))	
< IC >			
IC103	8-752-815-76	IC CAP201M	
< RESISTOR >			
R001	1-216-012-00	METAL CHIP	200 5% 1/10W
R002	1-216-032-00	METAL CHIP	200 5% 1/10W
R003	1-216-032-00	METAL CHIP	200 5% 1/10W
R004	1-216-168-00	METAL GLAZE	47 5% 1/8W
R005	1-216-017-00	METAL CHIP	47 5% 1/10W
R006	1-216-032-00	METAL CHIP	200 5% 1/10W
R008	1-216-017-00	METAL CHIP	47 5% 1/10W
R009	1-216-032-00	METAL CHIP	47 5% 1/10W
R010	1-216-168-11	METAL GLAZE	200 5% 1/8W
R015	1-216-057-00	METAL CHIP	1.2K 5% 1/10W

Ref. No.	Part No.	Description	Remark
R416	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R417	1-216-049-00	METAL CHIP	1K 5% 1/10W
R418	1-216-049-00	METAL CHIP	1K 5% 1/10W
R419	1-216-072-00	METAL CHIP	200 5% 1/10W
R420	1-216-032-00	METAL CHIP	200 5% 1/10W
R422	1-216-032-00	METAL CHIP	200 5% 1/10W
R423	1-216-032-00	METAL CHIP	200 5% 1/10W
R424	1-216-032-00	METAL CHIP	200 5% 1/10W
R425	1-216-032-00	METAL CHIP	200 5% 1/10W
R426	1-216-032-00	METAL CHIP	200 5% 1/10W
R427	1-216-032-00	METAL CHIP	200 5% 1/10W
R428	1-216-206-00	METAL GLAZE	2.2K 5% 1/8W
R429	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R430	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
< SWITCH >			
S401	1-762-172-11	SWITCH, ROTARY (ON) (640PF, 730PF, 400PFCS, 100PF, 240PF, 240PF, 241PF)	
S401	1-762-172-21	SWITCH, ROTARY (ON) (700PF, 700PF, 340PF, 400PFCS, 100PF, 240PF)	
S403	1-571-977-11	SWITCH, TACTIL (● REC)	
S420	1-571-977-11	SWITCH, TACTIL (● PAUSE)	

*	A-6782-427-A	PS-327 BOARD, COMPLETE (EXCEPT 730PF, 400PF, 240PFCS, 940PFCS, 940PFCS)	
*	A-6782-439-A	PS-349 BOARD, COMPLETE (730PF, 400PF, 740PFCS, 940PFCS, 940PFCS)	

(Ref. No 1,000 series)			
*	Q-951-093-01	HEAT SINK	
	7-688-648-79	SCREW +W/TP 3/16 TYPES 4T-7	
< CAPACITOR >			
△C101	1-104-795-31	FILM	0.1uF 20% 250V
△C102	1-104-705-11	FILM	0.1uF 20% 250V
△C103	1-107-401-11	ELECT	150uF 20% 200V
△C103	1-107-114-11	ELECT	220uF 20% 400V
△C104	1-101-740-00	CERAMIC	470PF 10% 500V (EXCEPT 730PF, 400PF, 240PFCS, 940PFCS, 940PFCS)
△C104	1-104-720-11	CERAMIC	0.001uF 10% 400V (730PF, 400PF, 240PFCS, 940PFCS, 940PFCS)
△C105	1-101-740-00	CERAMIC	470PF 10% 400V (EXCEPT 730PF, 400PF, 240PFCS, 940PFCS, 940PFCS)
△C105	1-161-120-13	CERAMIC	0.001uF 10% 400V (730PF, 400PF, 240PFCS, 940PFCS, 940PFCS)
△C106	1-104-320-31	CERAMIC	0.001uF 10% 400V (730PF, 400PF, 240PFCS, 940PFCS, 940PFCS)
△C107	1-101-068-11	CERAMIC	0.0015uF 20% 300V (EXCEPT 730PF, 400PF, 240PFCS, 940PFCS, 940PFCS)

The components identified by mark △ or dotted line with * are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark
△C107	1-164-320-11	CERAMIC (733HF/MFCS, 740HFPL, 940HFCS/HPFS)	0.002uF 10% 90V
△C108	1-164-320-11	CERAMIC (733HF/MFCS, 740HFPL, 940HFCS/HPFS)	0.001uF 10% 90V
C121	1-126-103-81	ELECT	470uF 20% 16V
C122	1-124-473-11	ELECT	1000uF 20% 10V
C125	1-126-213-81	ELECT	22uF 20% 50V
C131	1-126-490-11	ELECT	220uF 20% 16V
C132	1-126-233-11	ELECT	22uF 20% 50V
C133	1-124-477-11	ELECT	47uF 20% 25V
C141	1-124-477-11	ELECT	47uF 20% 25V
C142	1-126-161-11	ELECT	100uF 20% 16V
C161	1-124-126-00	ELECT	47uF 20% 10V
C162	1-124-442-00	ELECT	220uF 20% 6.3V
C171	1-124-604-00	ELECT	330uF 20% 10V
C181	1-163-091-11	CERAMIC CHIP	0.01uF 50V
C182	1-124-477-11	ELECT	47uF 20% 25V
C183	1-163-071-11	CERAMIC CHIP	0.01uF 50V
C184	1-124-916-11	ELECT	47uF 20% 50V
C185	1-163-071-11	CERAMIC CHIP	0.01uF 50V
C186	1-124-916-11	ELECT	47uF 20% 50V
C187	1-163-071-11	CERAMIC CHIP	0.01uF 50V
C188	1-124-916-11	ELECT	47uF 20% 50V
C189	1-163-071-11	CERAMIC CHIP	0.01uF 50V
C190	1-163-071-11	CERAMIC CHIP	0.01uF 50V
C191	1-124-916-11	ELECT	22uF 20% 50V
< AC INLET >			
△C1101	1-251-134-81	INLET, AC (HORIZONTAL) (AC IN-)	
△C1101	1-251-135-81	INLET, AC (AC IN-) (EXCEPT 733HF/MFCS, 740HFPL, 940HFCS/HPFS)	
< CONNECTOR >			
C1011	1-770-015-11	CONNECTOR, BOARD TO BOARD 19P	
C1012	1-495-821-11	CONNECTOR, BOARD TO BOARD 8P	
< COMPOSITION CIRCUIT BLOCK >			
△CP101	1-413-895-11	POWER BLOCK (EXCEPT 733HF/MFCS, 740HFPL, 940HFCS/HPFS)	
△CP101	1-413-206-11	POWER BLOCK (733HF/MFCS, 740HFPL, 940HFCS/HPFS)	
△CP102	1-447-811-11	UNIT, DC-DC CONVERTER	
< DIODE >			
△D101	8-719-510-00	DIODE 3A6F50	
D121	8-719-200-82	DIODE 136S2	
D102	8-719-911-19	DIODE 1SS145-25	
D102	8-719-109-85	DIODE 1R6, 1R62C	

Ref. No.	Part No.	Description	Remark
< FUSE >			
△F101	1-532-743-11	FUSE, GLASS CILINDRICAL (DIA. 5) (2A/125V) (EXCEPT 733HF/MFCS, 740HFPL, 940HFCS/HPFS)	
△T101	1-576-228-11	FUSE (R.B.C.) (72AH/250V) (733HF/MFCS, 740HFPL, 940HFCS/HPFS)	
< FUSE HOLDER >			
FH01	1-533-203-11	FUSE HOLDER	
FH02	1-576-292-11	FUSE HOLDER	
< IC >			
△IC101	3-759-189-80	IC PIC22E11	
< COIL >			
△L121	1-403-206-11	COIL, CHoke 22uH	
△L122	1-403-586-11	COIL, CHoke 22uH	
L131	1-400-409-00	INDUCTOR 10uH	
L132	1-404-142-11	INDUCTOR 1uH	
L133	1-404-142-11	INDUCTOR 1uH	
< LINE FILTER >			
△LF101	1-009-976-11	FILTER, LINE	
△LF102	1-009-976-11	FILTER, LINE (733HF/MFCS, 740HFPL, 940HFCS/HPFS)	
< IC LINK >			
△PS121	1-532-437-00	LINK, IC 1.6A (ICP-R25)	
△PS122	1-532-437-00	LINK, IC 1.6A (ICP-R25)	
△PS123	1-532-437-00	LINK, IC 1.6A (ICP-R25)	
△PS131	1-532-436-00	LINK, IC 0.4A (ICP-R10)	
< TRANSISTOR >			
△Q131	8-729-140-80	TRANSISTOR 2SD238-04	
Q132	8-729-421-22	TRANSISTOR UM211	
△Q141	8-729-140-50	TRANSISTOR 2SD273-04	
< RESISTOR >			
△R101	1-214-947-60	RESISTOR 2.7K 5% 1/2W (733HF/MFCS, 740HFPL, 940HFCS/HPFS)	
△R102	1-202-729-00	RESISTOR 6.0K 20% 1/2W (EXCEPT 733HF/MFCS, 740HFPL, 940HFCS/HPFS)	
R125	1-210-323-11	CARBON 3.3K 5% 1/4W F	
R131	1-249-413-11	CARBON 1K 5% 1/4W F	
R132	1-216-430-11	RESISTOR METAL OXIDE 50 5% 1/4 W	
R133	1-216-061-00	METAL CHIP 5.1K 5% 1/10W	
R141	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R141	1-249-412-11	CARBON 300 5% 1/4W F	
R152	1-249-478-11	CARBON 2.2 5% 1/2W F	

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with parts number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	QTY	SA	3M	F	Remark
R183	1-218-478-13	METAL OXIDE	340	SA	3M	F	

*	A-6782-424-A	RY-45 BOARD, COMPLETE (940HF/AFCS/AFMC/AFPC/AFPS, 300HE, 281HF)					
*	A-6282-021-A	RV-36 BOARD, COMPLETE (640HE, 340HF/AFPC, 341HF)					
*	A-6782-430-A	RY-45 BOARD, COMPLETE (940HF/AFCS/AFMC/AFPC)					

(Ref. No 2.000 see 142)							
CAPACITOR >							
C002	1-162-123-00	CERAMIC CHIP	100PF	SA		50V	
C003	1-162-105-00	CERAMIC CHIP	50PF	SA		50V	
C006	1-128-157-11	ELECT	10uF	20%	16V		
C007	1-128-154-11	ELECT	47uF	20%	6.3V		
C008	1-128-164-11	ELECT	47uF	20%	6.3V		
C009	1-128-154-11	ELECT	47uF	20%	6.3V		
C010	1-128-154-21	ELECT	47uF	20%	6.3V		
C011	1-162-031-11	CERAMIC CHIP	0.1uF			50V	
C012	1-124-638-11	ELECT	32uF	20%	10V		
C013	1-162-103-00	CERAMIC CHIP	22PF	SA		50V	
C017	1-162-105-00	CERAMIC CHIP	23PF	SA		50V	
C019	1-162-117-00	CERAMIC CHIP	100PF	SA		50V	
C025	1-162-127-00	CERAMIC CHIP	210PF	SA		50V	
C029	1-162-031-11	CERAMIC CHIP	0.1uF			50V	
C030	1-124-638-11	ELECT	22uF	20%	10V		
C039	1-162-031-11	CERAMIC CHIP	0.1uF			50V	
C040	1-162-031-11	CERAMIC CHIP	0.1uF			50V	
C042	1-128-164-11	ELECT	3uF		20%	50V	
C046	1-164-252-11	CERAMIC CHIP	0.1uF			50V	
C047	1-162-251-11	CERAMIC CHIP	100PF	SA		50V	
C054	1-162-121-00	CERAMIC CHIP	150PF	SA		50V	
C055	1-162-245-11	CERAMIC CHIP	56PF	SA		50V	
C056	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C057	1-128-157-11	ELECT	10uF	20%	16V		
C059	1-162-077-91	CERAMIC CHIP	0.1uF			50V	
C060	1-162-088-00	CERAMIC CHIP	50PF	SA		50V	
C062	1-162-109-00	CERAMIC CHIP	47PF	SA		50V	
C063	1-162-021-11	CERAMIC CHIP	0.1uF			50V	
C070	1-162-031-11	CERAMIC CHIP	0.1uF			50V	
C071	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C074	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C075	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C076	1-124-740-11	ELECT	3uF	20%	50V		
C078	1-162-031-11	CERAMIC CHIP	0.04uF			50V	
C081	1-162-032-91	CERAMIC CHIP	0.022uF			50V	
C082	1-162-032-91	CERAMIC CHIP	0.022uF			50V	
C083	1-162-032-91	CERAMIC CHIP	0.022uF			50V	
C084	1-162-077-91	CERAMIC CHIP	0.1uF			50V	
C085	1-162-032-91	CERAMIC CHIP	0.022uF			50V	
C086	1-162-117-00	CERAMIC CHIP	100PF	SA		50V	
C087	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
CONNECTOR >							
C001	1-572-828-11	CONNECTOR, BOARD TO BOARD 14P					
C002	1-572-828-11	CONNECTOR, BOARD TO BOARD 14P					
C003	1-548-988-11	CONNECTOR, FCC/AFPC (LIF) 13P					
* C002	1-584-025-00	PLK, CONNECTOR 4P					
* C003	1-564-013-11	PLK, CONNECTOR 3P					

Ref. No.	Part No.	Description	QTY	SA	3M	F	Remark
C004	1-124-589-00	ELECT	100uF		20%	10V	
C005	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C010	1-124-584-00	ELECT	100uF		20%	10V	
C011	1-162-032-11	CERAMIC CHIP	0.01uF			50V	
C017	1-104-326-11	CERAMIC CHIP	0.1uF			25V	
C084	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C015	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C016	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C017	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C018	1-162-031-11	CERAMIC CHIP	0.01uF			50V	
C022	1-162-129-00	CERAMIC CHIP	330PF	SA		50V	
C024	1-124-259-00	ELECT	33uF		20%	16V	
C027	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C029	1-162-034-11	CERAMIC CHIP	0.01uF			50V	
C030	1-162-111-00	CERAMIC CHIP	56PF	SA		50V	
C034	1-162-099-00	CERAMIC CHIP	10PF	SA		50V	
C038	1-162-031-11	CERAMIC CHIP	0.01uF			50V	
C039	1-162-099-00	CERAMIC CHIP	10PF	SA		50V	
C040	1-162-031-11	CERAMIC CHIP	0.01uF			50V	
C042	1-128-164-11	ELECT	3uF		20%	50V	
C046	1-164-252-11	CERAMIC CHIP	0.1uF			50V	
C047	1-162-251-11	CERAMIC CHIP	100PF	SA		50V	
C054	1-162-121-00	CERAMIC CHIP	150PF	SA		50V	
C055	1-162-245-11	CERAMIC CHIP	56PF	SA		50V	
C056	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C057	1-128-157-11	ELECT	10uF	20%	16V		
C059	1-162-077-91	CERAMIC CHIP	0.1uF			50V	
C060	1-162-088-00	CERAMIC CHIP	50PF	SA		50V	
C062	1-162-109-00	CERAMIC CHIP	47PF	SA		50V	
C063	1-162-021-11	CERAMIC CHIP	0.1uF			50V	
C070	1-162-031-11	CERAMIC CHIP	0.01uF			50V	
C071	1-162-038-91	CERAMIC CHIP	0.04uF			50V	
C074	1-162-038-91	CERAMIC CHIP	0.022uF			50V	
C075	1-162-038-91	CERAMIC CHIP	0.022uF			50V	
C076	1-124-740-11	ELECT	3uF	20%	50V		
C078	1-162-031-11	CERAMIC CHIP	0.022uF			50V	
C081	1-162-032-91	CERAMIC CHIP	0.022uF			50V	
C082	1-162-032-91	CERAMIC CHIP	0.022uF			50V	
C083	1-162-032-91	CERAMIC CHIP	0.022uF			50V	
C084	1-162-077-91	CERAMIC CHIP	0.1uF			50V	
C085	1-162-032-91	CERAMIC CHIP	0.022uF			50V	
C086	1-162-117-00	CERAMIC CHIP	100PF	SA		50V	
C087	1-162-038-91	CERAMIC CHIP	0.1uF			25V	

Qty	Part No.	Description	Remark	Qty	Part No.	Description	Remark
		< DIODE >					
0001	8-719-911-19	DIODE 35S119-25 (723HF/AFCS/AFMS/AFPA/340HF, 740HF)		1004	1-408-976-21	INDUCTOR 30uH	
0001	8-719-901-28	DIODE 35S144		1005	1-810-521-11	INDUCTOR 100uH	
0002	8-719-901-28	DIODE 35S144		1006	1-410-516-11	INDUCTOR 27uH	
0003	8-719-901-28	DIODE 35S144		1006	1-410-513-11	INDUCTOR 22uH	
		< IC >		1007	1-410-525-11	INDUCTOR 250uH	
10001	1-510-713-21	IC VC MONORE. 2 (MISC) JFAL117		1008	1-410-521-11	INDUCTOR 100uH	
10002	8-750-055-49	IC 4MS27K		1009	1-408-982-21	INDUCTOR 100uH	
10001	8-789-263-76	IC BALL1191AMZ		1009	1-408-918-00	INDUCTOR 220uH	
		< JUMPER RESISTOR >		1002	1-408-949-00	INDUCTOR 220uH	
J0001	1-216-295-91	CONDUCTOR, CHIP (2012)		1000	1-408-982-21	INDUCTOR 100uH	
J0003	1-216-295-91	CONDUCTOR, CHIP (2012)		1000	1-408-985-21	INDUCTOR 100uH	
J0021	1-216-296-00	METAL CHIP 0 5% 1/8W		1002	1-408-942-21	INDUCTOR 100uH	
J0022	1-216-296-00	METAL CHIP 0 5% 1/8W		1004	1-408-970-21	INDUCTOR 10uH (940HF/AFCS/AFMS/AFPA)	
J0023	1-216-296-00	METAL CHIP 0 5% 1/8W		1004	1-408-970-21	INDUCTOR 10uH (940HF/AFCS/AFMS/AFPA)	
J0025	1-216-296-00	METAL CHIP 0 5% 1/8W		1000	1-408-963-21	INDUCTOR 6.8uH (940HF/AFCS/AFMS/AFPA)	
J0026	1-216-295-91	CONDUCTOR, CHIP (2012)		1000	1-410-521-11	INDUCTOR 100uH (940HF/AFCS/AFMS/AFPA)	
J0027	1-216-296-00	METAL CHIP 0 5% 1/8W		1001	1-408-977-21	INDUCTOR 30uH	
J0028	1-216-296-00	METAL CHIP 0 5% 1/8W		1005	1-410-521-11	INDUCTOR 100uH	
J0030	1-216-295-91	CONDUCTOR, CHIP (2012)		1005	1-408-938-21	INDUCTOR 50uH	
J0031	1-216-296-00	METAL CHIP 0 5% 1/8W		1001	1-408-977-21	INDUCTOR 30uH	
J0032	1-216-295-91	CONDUCTOR, CHIP (2012)				< TRANSISTOR >	
J0033	1-216-296-00	METAL CHIP 0 5% 1/8W		0002	8-729-424-19	TRANSISTOR 0R2113	
J0034	1-216-296-00	METAL CHIP 0 5% 1/8W		0005	8-720-230-49	TRANSISTOR 2SC2712-V6	
J0035	1-216-296-00	METAL CHIP 0 5% 1/8W				(EXCEPT 640HF, 740HF/AFPA, 741HF)	
J0036	1-216-296-00	METAL CHIP 0 5% 1/8W		0006	8-729-424-19	TRANSISTOR 0R2113 (J219HF/AFCS/AFMS/AFPA/ (EXCEPT 640HF, 740HF/AFPA, 741HF)	
J0037	1-216-296-00	METAL CHIP 0 5% 1/8W		0007	8-729-218-21	TRANSISTOR 2SA1162-Y (723HF/AFCS/AFMS/ (EXCEPT 640HF, 740HF/AFPA, 741HF)	
J0038	1-216-296-00	METAL CHIP 0 5% 1/8W		0008	8-729-424-67	TRANSISTOR 0R2110 (723HF/AFCS/AFMS/ (EXCEPT 640HF, 740HF/AFPA, 741HF)	
J0039	1-216-296-00	METAL CHIP 0 5% 1/8W		0009	8-729-424-67	TRANSISTOR 0R2116 (723HF/AFCS/AFMS/ (EXCEPT 640HF, 740HF/AFPA, 741HF)	
J0040	1-216-296-00	METAL CHIP 0 5% 1/8W		0006	8-729-230-49	TRANSISTOR 2SC2712-V6	
J0041	1-216-296-00	METAL CHIP 0 5% 1/8W		0010	8-729-421-19	TRANSISTOR 0R2113	
J0042	1-216-296-00	METAL CHIP 0 5% 1/8W		0010	8-729-421-19	TRANSISTOR 0R2113	
J0043	1-216-296-00	METAL CHIP 0 5% 1/8W		0011	8-729-523-12	TRANSISTOR 2SA1854	
J0044	1-216-296-00	METAL CHIP 0 5% 1/8W		0017	8-729-230-49	TRANSISTOR 2SC2712-V6	
J0045	1-216-296-00	METAL CHIP 0 5% 1/8W		0018	8-729-421-19	TRANSISTOR 0R2113	
J0046	1-216-296-00	METAL CHIP 0 5% 1/8W		0019	8-729-230-49	TRANSISTOR 2SC2712-V6	
J0047	1-216-295-91	CONDUCTOR, CHIP (2012)		0040	8-729-230-49	TRANSISTOR 2SC2712-V6	
J0048	1-216-296-00	METAL CHIP 0 5% 1/8W		0041	8-729-216-21	TRANSISTOR 2SA1162-Y	
J0049	1-216-295-91	CONDUCTOR, CHIP (2012)		0040	8-729-216-22	TRANSISTOR 2SA1162-Y (940HF/AFCS/AFMS/ (MISC)	
J0050	1-216-295-91	CONDUCTOR, CHIP (2012)		0091	8-729-216-22	TRANSISTOR 2SA1162-Y (940HF/AFCS/AFMS/ (MISC)	
		< COIL >		0092	8-729-421-19	TRANSISTOR 0R2113 (940HF/AFCS/AFMS/ (MISC)	
L001	1-408-976-21	INDUCTOR 30uH		0094	8-729-230-49	TRANSISTOR 2SC2712-V6	
L002	1-408-982-21	INDUCTOR 100uH		0096	8-729-230-49	TRANSISTOR 2SC2712-V6	

Req. No	Part No.	Description	Remark
Q011	8-729-236-99	TRANSISTOR	252212-Y6
Q012	8-729-216-24	TRANSISTOR	22A162 Y
		RESISTOR	
R002	1-216-035-06	METAL CHIP	170 5% 1/10W
R003	1-216-052-00	METAL CHIP	1.5K 5% 1/10W
R004	1-216-067-13	METAL CHIP	4.7K 4.5% 1/10W
R005	1-216-036-00	METAL CHIP	170 5% 1/10W
R009	1-216-059-13	METAL CHIP	2.2K 0.5% 1/10W (EXCEPT 640HF, 740HF/HP73, 741HF)
R010	1-216-059-18	METAL CHIP	2.2K 0.5% 1/10W (EXCEPT 640HF, 740HF/HP73, 741HF)
R012	1-216-039-00	METAL CHIP	120K 5% 1/10W (EXCEPT 640HF, 740HF/HP73, 741HF)
R014	1-216-117-00	METAL CHIP	470W 5% 1/10W (EXCEPT 640HF, 740HF/HP73, 741HF)
R082	1-216-035-00	METAL CHIP	1.2K 5% 1/10W
R083	1-216-063-00	METAL CHIP	27K 5% 1/10W
R084	1-216-063-00	METAL CHIP	47K 5% 1/10W
R085	1-216-045-00	METAL CHIP	600 5% 1/10W
R086	1-216-067-00	METAL CHIP	5.6K 5% 1/10W
R087	1-216-295-91	CONDUCTOR, CHIP	420(2)
R088	1-216-421-11	CARDOM	2.2K 5% 1/4W F
R282	1-216-405-90	METAL CHIP	230 5% 1/10W
R283	1-216-067-00	METAL CHIP	5.6K 5% 1/10W
R285	1-216-093-00	METAL CHIP	230 5% 1/10W
R286	1-216-051-00	METAL CHIP	1.2K 5% 1/10W
R287	1-216-035-00	METAL CHIP	270 5% 1/10W
R288	1-210-097-00	METAL CHIP	180K 5% 1/10W
R211	1-216-079-00	METAL CHIP	18K 5% 1/10W
R258	1-216-073-00	METAL CHIP	180 5% 1/10W
R054	1-216-023-00	METAL CHIP	62 5% 1/10W
R062	1-216-037-00	METAL CHIP	230 5% 1/10W
R067	1-216-081-00	METAL CHIP	22K 5% 1/10W
R069	1-216-404-21	METAL CHIP	13 0.5% 1/10W
R066	1-216-023-00	METAL CHIP	62 5% 1/10W
R067	1-216-023-00	METAL CHIP	62 5% 1/10W
R071	1-216-037-00	METAL CHIP	330 5% 1/10W
R072	1-216-023-00	METAL CHIP	62 5% 1/10W
R070	1-216-041-00	METAL CHIP	52K 5% 1/10W
R036	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R017	1-216-049-00	METAL CHIP	1K 5% 1/10W
R035	1-216-051-00	METAL CHIP	1.2K 5% 1/10W
H026	1-216-047-00	METAL CHIP	820 5% 1/10W
H038	1-216-075-00	METAL CHIP	12K 5% 1/10W
H042	1-216-619-11	METAL CHIP	47 0.5% 1/10W
H043	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R244	1-216-423-11	CARDOM	3.2K 5% 1/4W F
R046	1-216-059-00	METAL CHIP	2.7K 5% 1/10W

Req. No	Part No.	Description	Remark
R047	1-216-078-00	METAL GLAZE	16K 5% 1/10W
R056	1-216-033-00	METAL CHIP	230 5% 1/10W
R057	1-216-037-00	METAL CHIP	230 5% 1/10W
R058	1-216-063-00	METAL CHIP	4.7K 5% 1/10W
R059	1-216-063-00	METAL CHIP	47K 5% 1/10W
K060	1-216-433-11	CARDOM	22K 5% 1/4W
R061	1-216-264-00	METAL GLAZE	1.5K 5% 1/8W
R062	1-216-064-00	METAL CHIP	3.2K 5% 1/10W
R063	1-216-047-00	METAL CHIP	820 5% 1/10W
R091	1-216-021-00	METAL CHIP	27 5% 1/10W (930HF/HP63/HP63/HP73)
R094	1-216-041-00	METAL CHIP	670 5% 1/10W (930HF/HP63/HP63/HP73)
K095	1-216-054-00	METAL GLAZE	1.6K 5% 1/10W (940HF/HP63/HP63/HP73)
R096	1-216-095-00	METAL CHIP	82K 5% 1/10W (930HF/HP63/HP63/HP73)
R097	1-216-093-00	METAL CHIP	47K 5% 1/10W (940HF/HP63/HP63/HP73)
R098	1-216-083-11	METAL CHIP	39K 0.5% 1/10W (940HF/HP63/HP63/HP73)
R099	1-216-063-00	METAL CHIP	1.5K 5% 1/10W
R082	1-216-215-91	CONDUCTOR, CHIP	22(2)
R084	1-216-077-00	METAL CHIP	35K 5% 1/10W
R097	1-216-075-00	METAL CHIP	82K 5% 1/10W
R098	1-216-043-91	METAL GLAZE	560 5% 1/10W
R044	1-216-077-00	METAL CHIP	85K 5% 1/10W
R045	1-216-075-00	METAL CHIP	12K 5% 1/10W
R046	1-216-295-01	CONDUCTOR, CHIP	20(2)
R047	1-216-045-00	METAL CHIP	680 5% 1/10W
R048	1-216-039-00	METAL CHIP	330 5% 1/10W
R077	1-216-030-00	METAL CHIP	390 5% 1/10W
R028	1-216-047-00	METAL CHIP	320 5% 1/10W
R019	1-216-049-00	METAL CHIP	8K 5% 1/10W
R068	1-216-205-91	CONDUCTOR, CHIP	20(2)
R070	1-216-039-00	METAL CHIP	390 5% 1/10W
R071	1-216-036-00	METAL CHIP	360 5% 1/10W

Ref. No.	Part No.	Description	Remark
		ACCESSORIES	

51	1-467-943-11	SWITCH BLOCK, CONTROL (840HF, 940HFC/AFCS)	
51	1-467-943-21	SWITCH BLOCK, CONTROL (780HF)	
51	1-473-029-11	SWITCH BLOCK, CONTROL (781HF)	
104	1-789-354-11	CABLE, FLEXIBLE FLAT (1900IE)	
118	1-555-110-00	CABLE, P37	
156	1-500-144-11	HEAD, EC	
165	1-506-465-11	PJW, CONNECTOR 6P	
202	8-848-576-02	DHDM ASSY, ROTARY UPPER (848-45-R) (EXCEPT 840HF/AFCS/AFNFC/AFPC)	
203	8-848-594-02	DHDM ASSY, ROTARY UPPER (848-51-R) (840HF/AFCS/AFNFC/AFPC)	
260	1-782-076-11	SWITCH, ROTARY	
MSD1	8-848-575-10	DHDM ASSY (DHM-45-R) (EXCEPT 840HF/AFCS/AFNFC/AFPC)	
MSD1	8-848-593-10	DHDM ASSY (DHM-51-R) (840HF/AFCS/AFNFC/AFPC)	
MSD2	X-3943-003-11	ROTARY ASSY, CAM	
MSD2	1-589-409-11	ROTARY, DC (CAPSTAN)	

		ACCESSORIES & PACKING MATERIALS	

	1-447-947-11	REMOTE COMMANDER (INT-V114) (780HF, 781HF)	
	1-467-947-21	REMOTE COMMANDER (INT-V154B) (733HF/AFCS/AFNFC/AFPC)	
	1-467-948-11	REMOTE COMMANDER (INT-V153) (840HF/AFCS/AFNFC/AFPC)	
	1-467-951-11	REMOTE COMMANDER (INT-V154C) (840HF)	
	1-467-953-11	REMOTE COMMANDER (INT-V152) (740HF/AFPC, 741HF)	
	1-467-951-11	REMOTE COMMANDER (INT-V154C) (840HF)	
	1-543-908-11	ADAPTER, CONVERSION 2P (733HF, AFCS, 740HF/AFPC, 940HFC/AFPC)	
Δ	1-575-121-11	CORD, POWER SUPPLY (733HF/AFCS, 740HF/AFPC, 940HFC/AFPC) (2500V, 2, 5A)	
	1-575-334-11	CORD, CONNECTION	
	1-606-582-11	CORD, CONNECTION (RFS3C)	
Δ	1-754-676-11	CORD, POWER (EXCEPT 733HF/AFCS, 740HF/AFPC, 940HFC/AFPC)	
	1-789-121-11	HOUSE, INTERJECT CABLE (740HF/AFPC, 741HF, 760HF, 761HF, 840HF/AFCS/AFNFC/AFPC)	
	1-789-397-11	WIRE, FLAT TYPE 1W	
	3-759-161-22	MANUAL, INSTRUCTION (740HF/AFPC, 741HF) (ENGLISH)	
	3-759-161-32	MANUAL, INSTRUCTION (740HF-Canadian, 741HF-Canadian) (FRENCH)	

Ref. No.	Part No.	Description	Remark
	3-759-161-22	MANUAL, INSTRUCTION (740HF, 760HF) (ENGLISH)	
	3-759-161-32	MANUAL, INSTRUCTION (740HF-Canadian) (FRENCH)	
	3-759-079-12	MANUAL, INSTRUCTION (733HF/AFCS/AFNFC/AFPC) (ENGLISH, JAPANESE)	
	3-759-080-22	MANUAL, INSTRUCTION (940HF/AFCS/AFNFC/AFPC) (ENGLISH)	
	3-759-080-32	MANUAL, INSTRUCTION (940HF-Canadian) (FRENCH)	
	3-759-080-42	MANUAL, INSTRUCTION (940HFC/AFPC) (SPANISH)	
	3-759-081-22	MANUAL, INSTRUCTION (840HF) (ENGLISH)	
	3-759-081-32	MANUAL, INSTRUCTION (840HF-Canadian) (FRENCH)	
*	3-900-054-01	INDIVIDUAL CARTON (740HF/AFPC)	
*	3-900-054-01	CUSHION (CUPPER) (840HF, 733HF/AFCS/AFNFC/AFPC, 740HF/AFPC, 741HF)	
*	3-900-056-01	CUSHION (LOWER) (840HF, 733HF/AFCS/AFNFC/AFPC, 740HF/AFPC, 741HF)	
*	3-900-081-01	INDIVIDUAL CARTON (730HF)	
*	3-900-082-01	CUSHION (CUPPER) (780HF, 781HF, 840HF/AFCS/AFNFC/AFPC)	
*	3-900-083-01	CUSHION (LOWER) (780HF, 781HF, 840HF/AFCS/AFNFC/AFPC)	
*	3-902-317-01	INDIVIDUAL CARTON (840HF/AFPC)	
*	3-902-318-01	INDIVIDUAL CARTON (781HF)	
*	3-902-319-01	INDIVIDUAL CARTON (840HFC/AFPC)	
*	3-902-320-01	INDIVIDUAL CARTON (741HF)	
*	3-902-321-01	INDIVIDUAL CARTON (840HF)	
*	3-902-322-01	INDIVIDUAL CARTON (733HF/AFCS/AFNFC/AFPC)	

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une croix Δ ou une ligne pointillée avec une croix Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark
----------	----------	-------------	--------

HARDWARE LIST

41	7-685-648-79	SCREW -DTP 3/12 TYPE2 IT-1	
42	7-682-645-01	SCREW +PS 3/16	
43	7-621-255-15	SCREW +S 3/16	
44	7-602-547-04	SCREW +P 3/16	
45	7-685-646-79	SCREW -DTP 3/14 TYPE2 IT-1	
46	7-685-646-79	SCREW -DTP 3/16 TYPE2 IT-1	
47	7-024-106-04	STOP RING 3 0. TYPE -E	

SECTION 6
INTERFACE AND IC PIN FUNCTION

6-1. SYSTEM CONTROL—VIDEO BLOCK INTERFACE (MA-214 BOARD IC201)

Signal	Pin No.	I/O	STOP	FF	REW	TAPE THREADING	TAPE UNTHREADING	PB	PB + PAUSE	SLOW	x 2	PICTURE CUE	SEARCH REVIEW	REC	REC + PAUSE
V-EB	IC104	O	H	H	H	H	H	L	L	L	L	L	L	H	H
RF-SW P (SW2H)	IC105	O	H	H	H	H	H	H	H	H	H	H	H	H	H
CLIPBY PRUTE	IC106	O	L	L	L	L	L	H	H	H	H	H	H	L	L
HA-SP	IC107	O	H	L	L	L	L	H	H	H	H	H	H	L	L
LP	IC108	O	H	H	H	H	H	H	H	H	H	H	H	H	H
REC-P	IC109	O	L	L	L	L	L	L	L	L	L	L	L	H	H
REC	IC110	O	L	L	L	L	L	L	L	L	L	L	L	L	L
V SYNC	IC111	I	H	H	H	H	H	H	H	H	H	H	H	H	H
OSD MUTE	IC112	O	H	H	H	H	H	H	H	H	H	H	H	H	H
CTL REC	IC113	O	L	L	L	L	L	L	L	L	L	L	L	L	L
SYNC	IC114	O	L	L	L	L	L	L	L	L	L	L	L	L	L
PAS	IC115	O	L	L	L	L	L	L	L	L	L	L	L	L	L
CRS SETTEL	IC116	O	L	L	L	L	L	L	L	L	L	L	L	L	L

- * 1. 3R15 30V delay pulse synchronizing with drum rotation.
 * 2. Normally "L" or "H" when the video signal is not detected.
 * 3. V period "ff" pulse.
 * 4. "L" in the SP mode. Selected according to the recording mode.
 * 5. Selected according to the tape recording mode.

- * 6. Composite sync signal (positives).
 * 7. "H" when menu screen or 4/99 back screen.
 * 8. Selected by BEZ mode. "L" in the SP mode.
 * 9. "H" while APV is set.

Mode	SP	LP	EP
Signal			
SP	L	H	H
EP	L	L	L

6-2. SYSTEM CONTROL—SERVO PERIPHERAL CIRCUIT INTERFACE (MA-214 BOARD IC201)

Signal	Pin No.	I/O	STOP	FF	REW	TAPE TIMEAD- RING	TAPE UNTH- READING	PB	PB - PAUSE	SLOW	X2	PICTURE		SEARCH	REC	REC - PAUSE	PB INDEX WRT/ERS
												VIEW	PAUSE				
REC CTL	K201①	0	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	
CAP STOP	K201②	0	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	L	*3	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	
STEP PLS	K201③	0	L	L	L	L	L	L	L	*2	L	L	L	L	L	L	
CTL REC	K201④	0	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
CTL INDEX	K201⑤	0	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
PB CTL	K201⑥	1	H	*8	*8	*1	*1	*1	H/L	*2	*6	*6	*6	*8	*1	H	H
DRUM PG	K201⑦	1	*4	*7	*7	*5	*5	*7	*7	*2	*7	*7	*7	*7	*7	*7	*7
DRUM FG	K201⑧	1	*2	*8	*8	*5	*5	*8	*8	*8	*8	*8	*8	*8	*8	*8	*8
CAP FC	K201⑨	1	H/L	*6	*8	*5	*5	*6	H/L	*9	*8	*8	*8	*8	*6	H/L	
CAP DA	K201⑩	0	*10	*10	*10	*10	*10	*11	*10	*10	*11	*11	*11	*11	*11	*11	
DRUM STA	K201⑪	0	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	
CTL STEP	K201⑫	0	L	L	L	L	L	L	L	*15	L	L	L	L	L	L	

- * 1. 30Hz pulse.
- * 2. Pulse in tape running.
- * 3. Reverse logic pulse of STEP PLS.
- * 4. "L" when drum rotation stops
- * 5. Unstable period pulse.
- * 6. Pulse of period proportionate to tape speed.
- * 7. 30Hz pulse
- * 8. 360Hz pulse.
- * 9. Pulse in tape running.
- * 10. Approx. 2 msec. period "H" or "L" pulse.
- * 11. Approx. 1.5 msec. period "H" or "L" pulse.
- * 12. Approx. 3 msec. period "H" or "L" pulse.
- * 13 "H" in FWD direction and STEP drive.

6-3. SYSTEM CONTROL - MECHANISM BLOCK INTERFACE (MA-214 BOARD IC201)

Signal	Pin No.	V/O	ELECTED LOADING	CASSETTE UNLOAD- ING	TAPE THREAD- ING	TAPE LURTH- READING	STOP	FF	REW	PB PAUSE	SLOW	XZ	PICTURE CUE	SEARCH REVIEW	REC PAUSE
CAM LOAD	IC200②	0	L	H	L	H	L	L	L	L	L	L	L	L	L
CAM UNLOAD	IC200③	0	L	L	H	L	L	L	L	L	L	L	L	L	L
CAM LV	IC200④	0	L	L	L	H	L	L	L	L	L	L	L	L	L
MODE 1	IC200⑤	1	H	L	L	H	H	H	H	H	H	H	H	H	H
MODE 2	IC200⑥	1	L	L	H	L	L	L	L	L	L	L	L	L	L
MODE 3	IC200⑦	1	L	L	L	H	H	H	H	H	H	H	H	H	H
MODE 4	IC200⑧	1	L	L	H	L	L	L	L	L	L	L	L	L	L
REC PRF	IC200⑨	1	L	H	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L
T REEL FG	IC200⑩	1	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L
S REEL FG	IC200⑪	1	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L
END LED	IC200⑫	0	0(D)	H	H	H	H	H	H	H	H	H	H	H	H
CAP TRQ 1	IC200⑬	0	0(D)	0	0	0	0	0	0	0	0	0	0	0	0
CAP TRQ 2	IC200⑭	0	0(D)	0	0	0	0	0	0	0	0	0	0	0	0
CAP TRQ 3	IC200⑮	0	0(D)	0	0	0	0	0	0	0	0	0	0	0	0
CAP STOP	IC200⑯	0	L	L	L	H	H	H	H	H	H	H	H	H	H
CAP RVS	IC200⑰	0	H	L	L	H	H/L	L	H	L	L	L	L	L	L
CAP DA	IC200⑱	0	H	L	L	H	H/L	L	H	L	L	L	L	L	L
T SENS	IC200⑲	1	H	H	H	H	H	H	H	H	H	H	H	H	H
S SENS	IC200⑳	1	H	H	H	H	H	H	H	H	H	H	H	H	H

- * 1. Uncertainty
- * 2. "L" when the eaving protection tab is bent, "H" when not bent.
- * 3. Pulse of period proportionate to reel rotating speed.
- * 4. Approx. 2 msec. period "H" pulse.
- * 5. Pulse in tape running.
- * 6. "L" only in tape running and when CAP RVS is "H".
- * 7. Normally "L". 2 msec. period "H" pulse when tape top or tape end is detected

6-4. SYSTEM CONTROL — SYSTEM CONTROL PERIPHERAL CIRCUIT INTERFACE (MA-214 BOARD IC201)

Signal	Pin No.	I/O	I/O Level
ASUBRA DRSFT	IC201④	I	Normally "H", "L" when service interruption is detected or restored.
ASUBRA CR	IC201⑤	I	Chip select signal from the drive microprocessor. V period "L" pulse.
SE BUS	IC201⑥	I	Serial communication data from the timer microprocessor. V period "L" pulse.
SD BUS	IC201⑦	I	Serial communication data to the timer microprocessor. V period "L" pulse.
S CLIC	IC201⑧	I	Serial communication clock with the timer microprocessor. V period "L" pulse.

6-5. SYSTEM CONTROL — AUDIO BLOCK INTERFACE (MA-214 BOARD IC201)

Signal	Pin No.	I/O	STOP	FF	REW	TAPE LOADING	TAPE UNLOADING	PB	PB PAUSE	SLOW	X-2	PICTURE CUE	SEARCH REVIEW	REC PAUSE	REC PAUSE
AF ENVELOP	IC201①	I	L	L	L	L	L	H	H	H	H	H	H	L	L
NA PG	IC201②	O	L	L	L	L	L	H	H	H	H	H	H	L	L
A BUTE	IC201③	O	L	L	L	L	L	H	H	H	H	H	H	L	L
RA SP	IC201④	O	L	L	L	L	L	H	H	H	H	H	H	L	L
NA REC-P	IC201⑤	O	L	L	L	L	L	H	H	H	H	H	H	L	L
AF REC-F	IC201⑥	O	L	L	L	L	L	H	H	H	H	H	H	L	L
AF SW-P	IC201⑦	O	L	L	L	L	L	H	H	H	H	H	H	L	L
AF SW POSITION	IC201⑧	O	L	L	L	L	L	H	H	H	H	H	H	L	L
FULLER	IC201⑨	O	L	L	L	L	L	H	H	H	H	H	H	L	L

① L: 20Hz 50% duty pulse approximately 5 msec, derived from RE SW-P.

② L: Selected according to SP/EP selector. "L" in the SP mode, "H" in the EP mode.

③ L: Selected according to tape recording mode. "L" in the SP mode, "H" in the EP mode.

6-6. SYSTEM CONTROL — RF MODULATOR, INPUT SELECTION BLOCK INTERFACE (MA-214 BOARD IC201)

Signal	Pin No.	I/O	I/O Level	
LINE 1	IC201①	O	L	LINE 1 H
LINE 2	IC201②	O	L	LINE 2 H

6-7. SERVO/SYSTEM CONTROL MICROPROCESSOR EXP87240-057Q (MA-214 BOARD KC203) PORT FUNCTION DESCRIPTION

Pin No.	Signal	I/O	Device	Function
1	REF SWP	O	DE	Resetting pulse
2	QVDT	O	False VD	
3	QVDP ENBL	O	False HD voltage and current	
4	XF RES F	O	RFN recording control	
5	REC P	O	Start/stop signal	
6	PE ON	O	Flang error	
7	REC CTL	I/O	REC CTL	
8	CAP PRO1	O	Capstan current control	
9	HEATVAL	I/O	VCR control	
10	ENF	O	EDIT control	
11	RV REC P	I/O	Normal audio recording mode R recording mode	
12	LP	O	H & L P mode	
13	CANLOAD	I/O	Load & motor status data into control	
14	CANLOAD	I/O	Head change control	
15	UNREPROFF	O	Generate IR and erasing protection the operation while input	
16	HEAD CONT	I/O	Head change control	
17	T SENS	I	Tape top sensor input	
18	S SENS	I	Tape web sensor input	
19	MAID CONT	O	Modulator power supply (R/D) control	
20	AV CONT	O	ON/OFF control (R/D) control	
21	NR SGRAM	I	H-ME SGRAM (R/D) control	
22	SGRAM	I	H-SGRAM (R/D) control	
23	VPH	O	Variable VPH R/P/AB	
24	STEP PUL	O	Step pulse, R/Capstan step driving	
25	PAL W	O	H: EPSC on PAL TV, R/D used signal	
26	NR BTSC	O	Color subcarrier signal, H: 2.5X XTAL, R/D used signal	
27	LE TUNE	I	H: PAL (R/D) used (input)	
28	LOL	O	H: H: R/C type (R/D) used (output)	
29	C+CONT	O	H: output: BS terminal mode (R/D) used (output)	
30	CAM LV	O	CAM motor release driver	
31	QVDP TRQ	O	Variable deceleration limit driving control	
32	CAP TRQ	O	Capstan current control signal 2 L: FF/NEW, to STOP	
33	CAP TRQ	O	Capstan current control signal L: SLOW speed down	
34	PAL	O	H: PAL (R/D) used (input)	
35	FULL SRS	O	Full erase control (R/D) used (output)	
36	A-MUTE	O	Audio mute, H: mute	
37	CAP STOP	O	Capstan step reversal, L: Capstan stop	
38	MR	I	Fixed to L	

Pin No.	Signal	I/O	Function
39	ASURA RESET	I	System reset input
40	VSS		GND
41	X FAL		System clock, 26.812
42	ASURA CS	I	Chip select signal, H: 15:19 board (CA2)
43	ST BUS	O	Serial communication signal
44	3 CLK	I	Destimize judge input, (R/D) used, top up
45	DEST 2	I	AD input for APV 2
46	AD	O	PG-OUT (R/D) output
47	APSV LOS	I	H: FF switching position adjustment
48	A VSS		GND
49	A VPH	O	AD port reference input, (UNSW) 3:0
50	A VYD	I	UPSIR 3V
51	MODE 4	I	Cam encoder data 4
52	MODE 2	I	Cam encoder data 2
53	MODE 3	I	Cam encoder data 3
54	MODE 1	I	Cam encoder data 1
55	REV	I	Confirmation sensor input, H: 1: 2nd compensation
56	RV ENV	I	Video playback signal envelope
57	RV ENV	I	H: FF audio playback signal envelope
58	RV SRS VOS	I	Video head overdrive position adjustment
59	RV JUDGE	I	4:3/LSI judge input, (R/D) used, top up
60	RV BEL PO	I	3: side reel PG output
61	RV BEL PU	I	3: side reel PG input
62	V SW CTL	I	Composite sync input
63	DRM PG	I	Servo-CTL input
64	DRM PG	I	Drum PG input
65	CAP PG	I	Capstan PG input
66	USP-MUTE	O	Video output mute signal, H: Gray back, (R/D) used, (input)
67	CAP RVS	O	Capstan reverse control, H: Reverse
68	TRM DA	O	Capstan D/A output
69	TRM DA	O	Drum D/A output
70	FF	O	H: FF (R/D) used (output)
71	UNC-SBTEI	O	H: UNC message
72	VP CTL	I	CTL counter input, (Fixed to "H")
73	DEST 1	I	Destination index input

Pin No.	Signal	IO	Function
79	LINE 1	0	Input selection control signal
80	SD 1	UX	Expanded port data
81	CLK 1	UX	Expanded port clock
82	LINE 2	0	Input selection control signal
83	NAFB	0	Audio output control signal. N - Normal work playback.
84	FBW1	U	PAWN output for ADC2
85	W TAPE	0	W - Write blank
86	N C	1	Not used (open)
87	TX		Not used (open)
88	VSS		GND
89	VDD		VCC5V 40
90	VDD		VCC5V 50
91	NA SF	0	For normal audio L: SF mode
92	ENV GAIN	0	Video envelope gain enable
93	CTL STEP	0	CTL step STEP operation control
94	CTL RE	0	H: CTL write
95	VFB	0	Video system feedback mode reversal L: Playback.
96	CTL BTRX	0	Index control output reverse. R : Erase
97	JOG	0	H: JOG
98	REC	0	Head amplifier recording power supply
99	ST	0	L: SF mode
100	SP SWF	U	AF selection pulse

6-8. TIMER/TUNER CONTROL MICROPROCESSOR MB89096PF-G-159-BND (HI-5/19 BOARD IC302) PORT FUNCTION DESCRIPTION

Pin No.	Signal	I/O	Function
1	CL1		
2	CL2		Liquid crystal oscillation pin (IC 114-3 for ICR4)
3	MDIO-GRND		Operation mode identification pin (IC20 when open)
4	MDIO-GRND		
5	X.0		Liquid crystal oscillation pin (IC 114-1 for analog)
6	X.1		
7	VSS		GNL
8	RESSET	I	Reset input pin
9-12	N. C.		Not used pins
13	S-SHORT CS	O	S-SHORT chip select signal
14	TUNER V	I	TUNER V Syno signal input
15	RAMBUS RESET	O	5.55-mHz (MR-24 board) (CR11 reset signal)
16	CS CS	O	Character generator chip select signal (MR-24 board IC10)
17	POWER PATT	I	Power voltage drop detection pin
18	V SYNC	I	V sync input
19	POWER CONV	O	Main power supply control signal
20	ASPECT CS	O	5.55-mHz chip select signal (MR-24 board IC8)
21	R DET	I	R DET signal input
22	FRG-DS	O	EDS chip select signal (ED-1048 board IC40)
23	SEL	I/O	T BUS, SELECT V BUS, ASPECT
24	SIA	I/O	IC BUS DATA
25	NOT SYNC	I/O	Syn. detection error
26	N. C.	E	Not used signal
27	F MONO	O	Tuner radio detect
28	VIDEO	I	Normally CH-D. V. Connected to ground by IC10
29	MAR/SARF	I/O	MAR/SARF input signal output
30	STREED	I/O	Strobe input/output
31	SP	I/O	MAR/SARF input/output
32	SIRCS-1H	E	Reserve control input
33	PILL CLOCK	O	Tuner PLL clock
34	PILL DATA	O	Tuner PLL data
35	PILL ENABLE	O	Tuner chip select
36	TUN MUTE	O	Tuner video mute
37	SIRCS-OUT	O	SIRCS signal output
38	A PREST	O	Tuner MEMOIR, select signal for auto preset
39-41	N. C.		Not used pins
42-48	SD-S11	O	RF6 segment 30-35
49	VDD		D. V.
50-52	S14-S16	O	RF7 segment 14-16

Pin No.	Signal	I/O	Function
53	VDDP		3V.
54-59	S11-S16	O	RF6 segment 11-16
60	VSS		GRD
60-65	S17-S21	O	RF6 segment 17-21
66	RD	O	RF6 grid 6
67	VDD		D. V.
68-71	TU-TC	O	RF6 Grid 7-1
72	LEAD-DS	O	LEAD-DS chip select signal (MR-232/271 board IC41)
76	POWER CONV 2	O	Tuner power supply control
77	S1 HAF	I	Serial data input
78	S0 BIF5	O	Serial data output
79	S CLR	O	Serial communication clock
80	DSM CS	O	DSM CS. III (210 board IC80)
81	MEM CLK	O	MEMORIAM CLOCK
82	MEM DATA	I/O	MEMORIAM DATA
83	AVSS		GNL
84	AFT	I	Ground sense input AFT detection
85	AV1	I	Key input
85-87	AVD-1-3	I	Membrane key reading
92	AV1D	I	D. V.
93	AVDA	I	Membrane key reading
94	DEST 1	I	Destination discrimination
95	DEST 2	I	
96	AVD II	I	Membrane key reading
97	LANC IN	I	LANC input
98	LANC OUT	O	LANC output
99	BUSZEE	O	Header output/clock input crystal frequency down/up output
100	VDD		D. V.

SECTION 7 ADJUSTMENTS

7-1. MECHANICAL ADJUSTMENTS

For the procedures how to adjust and check the mechanism, as well as how to replace mechanical parts, refer to the VHS Mechanical Adjustment Manual IV (H MECHANISM) (9-973-623-11).

However, for the procedures how to set the Track Shift mode, refer to the following text.

7-2. ELECTRICAL ADJUSTMENTS

See the adjusting part location diagram from on page 7-10 for the adjustment.

SLV-733HF/HFCS, 740HF/XP, 940HFCS/HFPX MODEL	DC-85 BOARD HI-19 BOARD MF-274 BOARD PS-349 BOARD RV-45 BOARD
EXCEPT SLV-733HF/ HFCS, 740HF/XP, 940HFCS/HFPX MODE	DC-87 BOARD HI-5 BOARD MP-253 BOARD PS-327 BOARD RV-36 BOARD
SLV-740HFPX, 940HFCS/HFPX MODEL	ED-43 BOARD
SLV-740HF, 741HF, 780HF, 781HF, 940HF/HFMX MODEL	ED-40 BOARD

2-1. PREPARATION BEFORE ADJUSTMENT

2-1-1. Equipment Required

The measuring instruments used for this alignment include:

(Instruments for Use)

- Monitor TV
- Oscilloscope, dual-trace, bandwidth of 30MHz or more, with delay mode (A probe to; 1 should be used unless otherwise specified).
- Frequency counter (8 columns or more)
- NTSC pattern generator
- Digital voltmeter
- Audio level meter
- Audio generator
- Attenuator
- Distortion rate meter
- Sound dual multiplex signal generator
- Alignment tape.
 - Normal VHS (KRV-51N2)
Part No.: 8-192-605-32
- Extension cable
 - ① HI-5/19 Board
 - HI-5/19 board CN301 - MA-214 board CN904
 - HI-5/19 board CN302 - MA-214 board CN905
Part No.: J-6090-053-A (18 pin)




Fig. 7-2-1.

- ② RV-36/45 Board
 - RV-36/45 board CN001 - MA-214 board CN906
 - RV-36/45 board CN002 - MA-214 board CN907
Part No.: J-6090-025-A (14 pin)
 - RV-36/45 board CN801 - Drum Head flexible
Part No.: J-6090-054-A (13 pin)
- ③ HF-34 Board
 - HF-34 board CN101 - MA-214 board CN902
 - HF-34 board CN102 - MA-214 board CN904
Part No.: J-6090-047-A (11 pin)
- ④ ED-40/43 Board
 - ED-40/43 board CN601 - MA-214 board CN903
Part No.: J-6090-048-A (10 pin)




Fig. 7-2-2.

2-1-2. Equipment Connection

Unless otherwise specified, connect and adjust the measuring instruments as shown in the following diagram.




Fig. 7-2-3.

Unless otherwise specified, place the switches and controls of this unit in the following positions:

- CHANNEL switch LINE 1
- TAPE SPEED (SP/EP) switch

2-1-3. Check of Input Signal

Because the video signal obtained from the pattern generator is used as the adjustment signal for the adjustment, the video output signal is required to satisfy the specified value.

Connect the oscilloscope to the picture input terminal (terminal board). And check that the synchronizing signal amplitude of the video signal is approximately 0.3V, the amplitude of the picture part is approximately 0.7V, the amplitude of the burst signal is approximately 0.3V and is flat, and the ratio of level between the burst signal and the "red" signal is 0.30 : 0.66. The video signal (color bar) used for the adjustment is shown in the fig. 7-2-4.




Fig. 7-2-4. Color bar signal of the pattern generator

2-1-4. Alignment Tape

● Contents of KRV-GIN? (Normal-VHS)

	Mode	Period	Video signal	Audio signal	
				Hi-Fi	Normal
1	SP	7 minutes	Color bar	400Hz	400Hz
2	SP	9 minutes	Mono scope	400Hz	400Hz
3	EP	7 minutes	Color bar	400Hz	400Hz
4	EP	3 minutes	Mono scope	400Hz	400Hz

2-1-5. Specified input-output Level and the Impedance

LINE IN 1 and 2

VIDEO IN Phono jack (1 each)
Input signal: 1 V_{p-p}, 75Ω,
unbalanced, sync negative

AUDIO IN Phono jack (2 each)
Input level: -7.5dBs (0 dBs=0.775 Vrms)
Input impedance: more than 47kΩ

LINE OUT

VIDEO OUT Phono Jack (1)
Output signal: 1 V_{p-p}, 75Ω,
unbalanced, sync negative

AUDIO OUT Phono jack (2)
Standard output: -7.5dBs
Load impedance: 47kΩ
Output impedance: less than 10kΩ

CONTROL

S IN


CABLE BOX

CONTROL

(CONTROL) S OUT (plug in power)

2-1-6. Adjustment Procedures

Perform the adjustment following the procedures given below



2-2. POWER SUPPLY CHECK

2-2-1. Output Voltage Check (PS-327/349 Board)

Mode	B.R
Measuring instrument	Digital voltmeter
38V check	
Measurement point	CN101 Pin ①
Specified value	$38 \pm 3Vdc$
13V check	
Measurement point	CN101 Pin ③④
Specified value	$13 \pm 1Vdc$
MTR 12V check	
Measurement point	CN101 Pin ⑤⑥
Specified value	$12.7 \pm 10Vdc$
SW 12V check	
Measurement point	CN101 Pin ⑦
Specified value	$12.0 \pm 0.5Vdc$
SW 5V check	
Measurement point	CN101 Pin ⑧
Specified value	$5.0 \pm 0.5Vdc$
D 6V check	
Measurement point	CN101 Pin ⑨
Specified value	$5.9 \pm 0.5Vdc$
-8V check	
Measurement point	CN101 Pin ⑩
Specified value	$-13 \pm 2Vdc$
D 6V check	
Measurement point	CN102 Pin ②
Specified value	$5.9 \pm 0.5Vdc$
-30V check	
Measurement point	CN102 Pin ③
Specified value	$-29 \pm 3Vdc$

2-3. SERVO SYSTEM ADJUSTMENT

2-3-1. RF Switching Position Adjustment (MA-214 Board)

[Adjustment Object]

To adjust the link of the Ach and Bch of the tape playback outputs.

To make the unit compatible with other tapes and units. If this specification is not satisfied, the link will appear on the screen and the screen will be disrupted, etc.

Mode	Playback (SP)
Signal	Alignment tape: KR-V-S1N2 SP color bar portion
Measurement point	CH1: Video Line out terminal CH2: CN802 pin ② (RF SWP) (RV.36/45 board)
Measuring instrument	Oscilloscope
Adjustment element	RV202
Specified value	$6.5 \pm 0.5H$ ($410 \pm 32\mu sec$)

[Adjustment Method]

- 1) Set **TRACKING** switch (Remote commander) to MANUAL ("Auto tracking" display will disappear on the display window indicator.)
- 2) Press the tracking buttons **▼** and **▲** and adjust the tracking position to the center.
- 3) Adjust to $410 \pm 32\mu sec$ ($6.5 \pm 0.5H$) using RV202.




Fig. 7-25.

2-4. SYSTEM CONTROL/TIMER SYSTEM ADJUSTMENT

2-4-1. Clock Adjustment (H1-5/19 Board)

(Adjustment Object)

To raise the accuracy of the clock.

If the clock is not accurate, its error difference will gradually increase.

Measurement point	IC302 pin ⑨ (BUZZER OUT)
Measuring instrument	Frequency counter (Interval counter mode)
Measuring element	CT301
Specified value	$0.1249995 \pm 0.0000005 \text{sec}$

Note: Do not adjust CT301 except when replacing IC302.

(Adjustment Method)

- 1) Connect 47k Ω resistor (J-249-487-11) between pin ⑨ of IC302 and ground. (This sets the adjustments mode.)
- 2) Connect the frequency counter as shown in the figure below.
- 3) Adjust the oscillation frequency to the specified value using CT301.
- 4) After this adjustment, remove the resistor.




Fig. 7-2-6.

2-5. VIDEO SYSTEM ADJUSTMENT

For the video system adjustment, follow the adjustment procedures given below as a rule. The color bar video signal supplied from the pattern generator is used as the video input signal for the video system adjustment of the recording mode. Check that this signal satisfies the specified value designated in the "Check of input signal" (Fig. 7-2-4).

(Adjustment Sequence)

- 1) X'tal OSC Check
- 2) SYNC AGC Check
- 3) White clip/Dark clip check
- 4) Y FM carrier frequency check
- 5) Playback Y Level check

2-5-1. X'tal OSC Check (RV-36/45 Board)

Mode	Playback
Signal	Alignment tape. Color bar portion
Measurement point	IC001 pin ②
Measuring instrument	Oscilloscope and Frequency counter
Specified value	$3.579545 \pm 82 \text{Hz}$

Note: A frequency counter should be connected through a buffer amplifier (oscilloscope, etc.) having a high impedance and a low capacitance.

(Check Method)

- 1) Check that the oscillation frequency is $3.579545 \pm 82 \text{Hz}$ and that the oscillation voltage is $450 \pm 200 \text{mVpp}$.




Fig. 7-2-7.

2-5-2. SYNC AGC Check (RV-36/45 Board)

Mode	E-E
Signal	Color bar
Measurement point	Video output terminal
Measuring instrument	Oscilloscope
Specified value	$A = 2.0 \pm 0.14V_{p-p}$

[Check Method]

- 1) Check that the SYNC AGC level (A) satisfies the specified value.




Fig. 7-2-8.

2-5-3. White Clip/Dark Clip Check (RV-36/45 Board)

Mode	E-E
Signal	Color bar
Measurement point	IC001 pin ⑦
Measuring instrument	Oscilloscope
Specified value	White clip: $190 \pm 15\%$ Dark clip: $52 \pm 10\%$

[Check Method]

- 1) Check that the white clip level is $190 \pm 15\%$ to the white (100%) level.
- 2) Check that the dark clip level is $52 \pm 10\%$ to the white (100%) level.




Fig. 7-2-9.

2-5-4. Y FM Carrier Frequency Check (RV-36/45 Board)

Mode	E-E
Signal	No-signal
Measurement point	Q34 Emitter
Measuring instrument	Frequency counter
Specified value	$3.40 \pm 0.18MHz$

Note: A frequency counter should be connected through a buffer amplifier (oscilloscope, etc.) having a high impedance and a low capacitance.

[Check Method]

- 1) Check that the carrier frequency satisfies the specified value.



$3.40 \pm 0.18MHz$

Fig. 7-2-10.

2-5-5. Playback Y Level Check (RV-36/45 Board)

Mode	Playback
Signal	Alignment tape - SP mode color bar portion
Measurement point	Video output terminal
Measuring instrument	Oscilloscope
Specified value	$A = 1.96 \pm 0.18V_{p-p}$

[Check Method]

- i) Check that the playback Y level satisfies the specified value.




Fig. 7-2-11.

2-6. AUDIO SYSTEM ADJUSTMENT

- For the adjustment of the audio system, perform in the SP mode if there is no special notes. Use the alignment tape.
- Adjust both LCH and RCH.

[Connecting Instruments]




Fig. 7-2-12.

• Hi-Fi Audio System Adjustment

Perform the adjustment setting the switches and controls on the following positions if there is no special indications

- CHANNEL** switch LINE 1
AUDIO MONITOR Stereo

[Adjustment Sequence]

1. VCO f_c adjustment
2. Deviation adjustment
3. Band pass filter f_c Adjustment
4. AF Switching pulse position adjustment

2-6-1. VCO f₀ Adjustment (HF-34 Board) (Adjustment Object)

To attain HiFi audio compatibility.
If this specification is not satisfied, the sound will be distorted.

Mode	Recording
Signal	No-signal
Measuring instrument	Frequency counter
1.3MHz adjustment	
Measurement point	IC101 pin ③ (Lch RF) (JL111)
Adjustment element	RV103 (Lch)
Specified value	1300 ± 1kHz
1.7MHz adjustment	
Measurement point	IC101 pin ④ (Rch RF) (JL110)
Adjustment element	RV102 (Rch)
Specified value	1700 ± 1kHz

Note: Connect the frequency counter through the buffer amplifier (oscilloscope, etc) with high input resistance (1MΩ or more) and low capacity (10pF or less).

[Adjustment Method]

- 1) Connect the frequency counter with each measurement points.
- 2) Adjust with RV103 and RV102 so that the frequency satisfies each specified value.

2-6-2. Deviation Check (HF-34 Board)

Mode	Recording
Signal	400Hz, ~12dBs: CN102 pin ①, ②
Measurement point	IC101 pin ③ (Lch) (JL111) IC101 pin ④ (Rch) (JL110)
Measuring instrument	Frequency counter
Specified value	50 ± 5kHz

[Check Method]

- 1) Check that the frequency satisfies the specified value.

○ HF-34 Board (COMPONENT SIDE)




Fig. 7-2-13.

2-6-3. Band Pass Filter f_0 Adjustment (HF-34 board)

(Adjustment Object)

To separate the carrier accurately and ensure that the filter for cutting the video signal functions normally

If this specification is not satisfied, the sound will be distorted.

Mode	Playback
Signal	1.505MHz, 200mVp-p · CN103 pin ①
Measurement point	IC101 pin ③ (Lch RF) (JL111) IC101 pin ④ (Rch RF) (JL110)
Measuring instrument	Oscilloscope
Adjustment element	RV101
Specified value	Adjust the A and B amplitudes to the same level. (A - B = $\pm 2mVp-p$)

(Connection)

- 1) Disconnect CN103 of the HF-34 board and input the 1.505MHz and 200mVp-p sine wave from the signal generator to Pin ① of CN103.




Fig. 7-2-14.

(Adjustment Method)

- 1) Rotate RV101 fully in the counterclockwise direction (C) as seen from the component side.
- 2) Rotate RV101 slowly in the clockwise direction (C) until the amplitudes of Pin ③ of IC101 and Pin ④ of IC101 become equal.




Fig. 7-2-15.

2-6-4. AF Switching Position Adjustment (MA-214 Board)

(Adjustment Object)

To adjust the link of the Ach and Bch of the tape playback outputs.


If this specification is not satisfied, the noise will increase and cracking sounds will be produced.

Mode	Playback
Signal	Alignment tape: Hi-Fi 400Hz portion
Measurement point	CH1: IC101 pin ③ (Lch RF) (JL111) (HF-31 board) CH2: CN802 pin ③ (RF SWP) (RV-35/45 board)
Measuring instrument	Oscilloscope
Adjustment element	RV201
Specified value	No dropouts in the RF signal

(Adjustment Method)

- 1) Set **TRACKING** switch (Remote comander) to MANUAL ("Auto tracking" display will disappear on the display window indicator.)
- 2) Press tracking buttons ∇ and \blacktriangle and adjust the tracking position to the center.
- 3) Adjust to the minimum specified value using RV501.

TV screen



Moves to the right when the \blacktriangle button is pressed and to the left when the ∇ button is pressed.




Fig. 7-2-16.

● Normal Audio System Adjustment

- Adjust in the SP mode if there is no special indications.
- Perform the adjustment, setting the switch on the following positions.

CHANNEL switch LINE 1

AUDIO MONITOR switch NORMAL

- 1: No indicators on the display window indicator and monitor TV

[Adjustment Method]

- ACE head adjustment. Refer to the VHS mechanical adjustment manual IV
- Recording bias adjustment
- E-E output level check
- Overall output level and distortion factor check
- Overall noise level check

2-6-5. ACE Head Adjustment

Refer to the "VHS Mechanical adjustment manual IV" (9-973-623-11).

2-6-6. Recording Bias Adjustment (MA-214 Board)

Mode	Self-record playback
Signal	400Hz, -27.5dBs } Audio line in 1 7kHz, -27.5dBs } (L or R)
Measurement point	Audio line out (L or R)
Measuring instrument	Audio level meter
Adjustment element	RV887
Specified value	0±1dBs

[Adjustment Method]

- Supply a signal of 400Hz, -27.5dBs to Audio Line Input
- Connect the audio level meter to the Audio Line Output.
- Adjust the attenuator so that the audio level meter will indicate -27.5dBs.
- Make recording in the SP mode.
- Set an audio line input signal to 7kHz and make recording.
- Playback a recorded portion, and measure output levels at 400Hz and 7kHz.
- Confirm that the 7kHz playback output levels within a range of the ±0dB; playback output level 0±1dB. When it is out of this range, adjust RV887 and repeat the steps 1) through 7) above.

	Direction of Rotating RV887
400Hz level > 7kHz level	Clockwise (C)
400Hz level < 7kHz level	Counterclockwise (C)

2-6-7. E-E Output Level Check

Mode	E-E
Signal	400Hz, -7.5dBs; Audio Line in 1
Measurement point	Audio line output terminal
Measuring instrument	Audio level meter
Specified value	-7.5±3dBs

[Checking Method]

- Input signal of 400Hz and -7.5dBs to the L and R channel of the audio input at the same time.
- Check that the audio output level is -7.5±3dBs.

2-6-8. Overall Output Level and Distortion Factor Check

Mode	Self-record playback
Signal	400Hz, -7.5dBs; Audio Line Input 1 terminals, left and right
Measurement point	Audio Line Output terminals, left and right
Measuring instrument	Audio level meter and Distortion meter
Specified value	Playback Level: -7.5±3dBs Distortion: 40% or less

[Check Method]

- Record signal.
- Playback the recorded portion.
- Check that the output level is -7.5±3dBs.
- Check that the distortion factor is 40% or less on the left and right side.

2-6-9. Overall Noise Level Check


Mode	Self-record playback
Signal	No signal (insert a shorting plug into the Audio Line Input jacks, left and right.)
Measurement point	Audio Line Output terminals, left and right
Measuring instrument	Audio level meter
Specified value	Less than -46dBs

[Checking Method]


- Record.
- Playback recorded portion.
- Check that noise level is -46dBs or less on the left side and right side.

2-7. ADJUSTMENT PARTS LOCATION DIAGRAM

MA-214 BOARD (COMPONENT SIDE)




HI-5/19 BOARD (COMPONENT SIDE)




2-7. ADJUSTMENT PARTS LOCATION DIAGRAM


MA-214 BOARD (COMPONENT SIDE)




RV-36/45 BOARD (COMPONENT SIDE)



HF-34 BOARD (COMPONENT SIDE)



HI-5/19 BOARD (COMPONENT SIDE)



*Part on the conductor side.



VHS MECHANICAL ADJUSTMENT MANUAL IV



V03056

H MECHANISM

Please use with the service manual.



VHS VIDEO CASSETTE RECORDER
SONY.



TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
1.	PREPARATION FOR MECHANISM CHECK ADJUSTMENT AND REPLACEMENT		3-11.	Slit Brake T Assembly (Fig. 3-13)	21
			3-12.	RVS Brake Ann Assembly, Reel Table (T) Assembly (Fig. 3-14)	22
1-1.	Loading and Threading Procedure When the Power Turns Off (Fig. 1-1)	3	3-13.	TGB Assembly (Fig. 3-15)	23
1-1-1.	Loading and Threading Procedure With Hands	3	3-14.	TGB Holder (Fig. 3-18)	24
1-1-2.	Loading and Threading Procedure With Regulated DC Power Supply	3	3-15.	TGB and Press Gears (Fig. 3-17)	25
1-2.	Unloading and Unthreading Procedure When the Power Turns Off (Figs. 1-2 and 1-3)	4	3-18.	Cam Motor Chassis Block Assembly, Upper/Lower Communication Gear (Fig. 3-18)	26
1-2-1.	Unloading and Unthreading Procedure With Hands	4	3-17.	Rotary Encoder Switch (Fig. 3-18)	27
1-2-2.	Unloading and Unthreading Procedure With Regulated DC Power Supply	4	3-18.	Main Sactor (Fig. 3-20)	28
1-3.	How to Complete Threading Without Cassette Compartment (Fig. 1-4)	6	3-19.	Shuttle T Block and Loading Gear T Block Assemblies (Fig. 3-21)	29
2.	PERIODIC CHECK AND REPLACEMENT		3-20.	Shuttle S Block and Loading Gear S Block Assemblies (Fig. 3-22)	30
2-1.	Cleaning of Rotating Head Disk Assembly	7	3-21.	Reel Table (S) Assembly (Fig. 3-23)	31
2-2.	Cleaning of the Tape Movement System	7	3-22.	TG1 Assembly (Fig. 3-24)	32
2-3.	Cleaning the Drive System	7	3-23.	S Winding Block Assembly (Fig. 3-25)	33
2-4.	Periodic Check Items	8	3-24.	Trigger Lever and RKB Block Assemblies (Fig. 3-26)	34
2-5.	Tools and Fixtures Required for Servicing	8	4.	ADJUSTMENT	
3.	MAINLY MECHANICAL PARTS REPLACEMENT		4-1.	Tape Path Adjustment	35
3-1.	FL Block Assembly (Fig. 3-1)	10	4-1-1.	Tension Regulator (TG1) Position/ Tension Adjustment (Fig. 4-1)	35
3-2.	Drum Assembly (Fig. 3-2)	11	4-1-2.	TGB Guide Roller Height Adjustment (Fig. 4-2)	36
3-3.	Timing Belt (Fig. 3-3)	12	4-1-3.	Height Adjustment of Guide Rollers No. 3 and No. 6 (Fig. 4-3)	38
3-4.	CSB Brake Assembly (Fig. 3-4)	13	4-1-4.	Ace Head Assembly Adjustment (Rough Adjustment) (Figs. 4-4 and 4-5)	37
3-5.	TQ2 Roller, FE Head Assembly (Fig. 3-5)	14	4-1-6.	Ace Head Assembly Adjustment (Precision Adjustment)	38
3-6.	Pinch Press Block Assembly, Elevator Gear (Fig. 3-6)	15	4-1-6.	X-Velux Adjustment	38
3-7.	Ace Block Assembly (Fig. 3-7)	19	4-1-7.	Adjustments After Replacing the Drum (Video Head)	40
3-8.	TGB, TGB Guide Roller Assemblies (Fig. 3-8)	17	4-1-8.	Checking the Tension and Torque	42
3-9.	Cassette Motor (Fig. 3-11)	19			
3-10.	Main Brake Assemblies S and T (Fig. 3-12)	20			

1. PREPARATION FOR MECHANISM CHECK ADJUSTMENT AND REPLACEMENT

Refer to the service manual, "DISASSEMBLY" for removal of the cabinet and boards.

1-1. LOADING AND THREADING PROCEDURE WHEN THE POWER TURNS OFF (Fig. 1-1)

1-1-1. LOADING AND THREADING PROCEDURE WITH HANDS

- 1) Turn cam motor in the arrow \odot direction until loading and threading are end.

1-1-2. LOADING AND THREADING PROCEDURE WITH REGULATED DC POWER SUPPLY

- 1) Applying approx. +9 V (300 mA) to cam motor with regulated DC power supply makes it loading and threading.

Note: When loading and threading without cassette, claws are caught in four positions as following figure (in the order ① → ② → ③ → ④).

So release them with hands.









Fig. 1-1

1-2. UNLOADING AND UNTHREADING PROCEDURE WHEN THE POWER TURNS OFF (Figs. 1-2 and 1-3)

1-2-1. UNLOADING AND UNTHREADING PROCEDURE WITH HANDS

- 1) Turn cam motor in the arrow  direction until unthreading is end.
- 2) Turn capstan motor in the arrow  direction to take up tape in cassette.
- 3) Turn cam motor in the arrow  direction until unloading is end.

1-2-2. UNLOADING AND UNTHREADING PROCEDURE WITH REGULATED DC POWER SUPPLY

- 1) Apply approx. +9 V (300 mA) to contrary polarities of cam motor
- 2) Unthreading operation begins, tape guides return to their original positions (Unthreading operation is end but tape remains), then stop cam motor by turning power off
- Note:** When unloading begins and cassette lid is closed, turn cam motor in the arrow  direction to open tape guard.
- 3) Turn capstan motor in the arrow  direction to take up tape in cassette

Note: That tape is not caught at pinch roller. (Fig. 1-3)

- 4) Check that tape is not loosened completely, and apply approx. +9 V (300 mA) to contrary polarities of cam motor with regulated DC power supply. (Fig. 1-2)




Fig. 1-2




Fig 1-3

1-3. HOW TO COMPLETE THREADING WITHOUT CASSETTE COMPARTMENT (Fig. 1-4)

Note 1: Put the FL block assembly removed the FL top plate on the bottom not to put dust or grease the top sensor and the end sensor luminous plates or not to scratch them.
(Fig. A)

- 1) Pull out AC plug from wall outlet.
- 2) Shade near the end and top sensors with a black masking tape on the like.
- 3) Press cassette in/rec proof switch with a tip of screwdriver or the like.
- 4) Connect AC plug to wall outlet.
- 5) Release cassette in/rec proof switch by putting off a tip of screwdriver or the like.

(At this time, power turns on, rewind operates for 10 seconds, after that power turns off.)

Note 2: In this condition, each mode can be set to video cassette recorder. (including recording mode)
However, fast forward should be done after rewinding for 15 seconds or more.

Note 3: After above mentioned operation, be sure to return the mode in the following order.

- 1) Remove the tape near the end and top sensors.
- 2) Pull out AC plug from wall outlet to reset the system control microcomputer.




Fig. 1-4

2. PERIODIC CHECK AND REPLACEMENT

In order to obtain the best performance from this unit and make full use of its capabilities, and to extend the life of the unit and tapes, it is recommended that the following periodic checks and maintenance be performed.

* The following must be done after every repair regardless of how many hours the user has operated the machine.

2-1. CLEANING OF ROTATING HEAD DISK ASSEMBLY

- 1) Press a chamois cloth (Jig Ref. No. J-9) which has been dipped in cleaning fluid (Jig Ref. No. J-3) lightly against the rotating drum assembly, then do the cleaning by slowly rotating the rotating head disk by hand. (Never try to clean by using the motor to turn it.)
- 2) Never try to clean by moving the chamois cloth at a vertical angle to the head tip. There is a very great danger of damaging the head tip if this is done.

2-2. CLEANING OF THE TAPE MOVEMENT SYSTEM

- 1) Clean the surfaces which the tape contacts during its movement (tape guide, drum assembly surface, capstan, pinch roller, etc.) with a chamois cloth that has been dipped in cleaning fluid.

2-3. CLEANING THE DRIVE SYSTEM

- 1) Clean the driving parts with a cloth that been dipped in cleaning fluid.




Fig. 2-1 Parts requiring cleaning

2-4. PERIODIC CHECK ITEMS

Perform the maintenance and check listed on the table below, according to users operating hours.

Maintenance & Check		Operating Hours (H)										Remarks
		500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	
Tape Transportation System	Cleaning of tape transportation system	○	○	○	○	○	○	○	○	○	○	This cleaning must be done whenever a repair is made.
	Cleaning and degaussing of ACE assembly	○	○	○	○	○	○	○	○	○	○	
	Cleaning & degaussing of upper drum assembly	○	○	○	○	○	○	○	○	○	○	
Performance Confirmation	Abnormal sound	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Adjust or replace the sections which causes abnormal sound.
	Measurement of FWD back torque	-	☆	-	☆	-	☆	-	☆	-	☆	Confirmation must be made according to 4-1-2. Specified value: adjust to 36 to 44 gram (when measured with torque cassette tape)
	Confirmation of brake system	-	☆	-	☆	-	☆	-	☆	-	☆	Confirmation must be made according to section
	Confirmation of record & playback functions	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Perform the confirmation whenever repair is made
	Measurement of forward torque	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Adjust to 70 to 120 gram


○ Cleaning ☆ Confirmation

Note: On overhaul

When overhauling the unit, replace parts as indicated in the above table.

2-5. TOOLS AND FIXTURES REQUIRED FOR SERVICING

Ref No.	Name	Part No.	Corved Jig No.	Remarks
J-1	Master Plane	H-7099-279-H		Applicable to S-VHS
J-2	Reel Disk Height Jig	H-7099-038-F		
J-3	Torque Gauge Adapter	H-7099-035-H		
J-4	0.93 mm Torque Gauge	H-7099-039-H		
J-5	Hex Wrench	H-7099-202-H		
J-6	Torque Measurement Cassette VHT-063S	J-6062-011-A		For PWD & back stretch torque measurement
	Torque Measurement Cassette VHT-404S	J-6062-012-A		For CUE and reverse torque measurement.
J-7	Alignment Tape			
	JVC-MH-1 (NTSC)	H-7099-046-H		
	24HASP-2 (NTSC Hi-Fi)	H-7099-153-H		
	JVC-MH-2 (PAL)	H-7099-052-H		
JVC-MH-4 (SECAM)	H-7099-053-H			
J-8	Cleaning Fluid	Y-2031-001-0		
J-9	Charon's Leather	2-034-697-00		
J-10	Head Disassembler	Widely available		Demagnetize video heads and audio heads.
J-11	Dental Mirror (With handle)	J-6060-029-A	SL-5052	Tape path and tape traveling adjustments or checks.
J-12	Dental Mirror (Mirror)	J-6060-030-1		
J-12	FLOBL SG-655G	7-651-000-09		
J-13	Diamond Oil NT-68	7-661-018-18		
J-14	Screw Lock G (H401R)	7-632-114-11		



3. MAINLY MECHANICAL PARTS REPLACEMENT

Notes:

- Refer to the service manual, "DISASSEMBLY" for removal of the cabinet and boards.
- On mounting, while referring to notes on mounting perform reversely in the removal order.
- When replacing greased parts, grease them in the same way.
- Do not oil, grease or touch with bare hands the surfaces contacts tape of guides and brake shoes.
- Install gears to engage each other.
- Basically, disassembling and assembling should be done in the unthreading-end condition.

3-1. FL BLOCK ASSEMBLY (Fig. 3-1)

- 1) Remove screws ①.
- 2) Remove FL block assembly ② in the arrow direction.

Note: Be careful not to damage claws on the bottom and front.

[Note on Mounting]

- First insert claws on the bottom and front not to damage.
- Engage FL slide plate to FL driving gear with slightly sliding FL slide plate. (Fig. A)
- Keep clean top sensor and end sensor luminous plates. (Refer to 1-3.)




Fig. 3-1

3-2. DRUM ASSEMBLY (Fig. 3-2)

- 1) Remove screw ①.
- 2) Remove ground shaft assembly ② not to touch its tip with bare hand or tools.
- 3) Remove screws ③ to remove drum assembly ④.

[Note on Mounting]

- Don't touch head chips ⑤ and ground shaft assembly ② with bare hand or tools.
- Keep clean the surface contacts tape of drum assembly ④.

[Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-2

3-3. TIMING BELT (Fig. 3-3)

- 1) Remove screw ① to remove tension vehicle arm assembly ②.
- 2) Remove timing belt ③.

[Note on Mounting]

- Tighten screw ① while pressing tension vehicle arm in the arrow direction.




Fig. 3-3

3-4. CAP BRAKE ASSEMBLY (Fig. 3-4)

- 1) Remove tension vehicle arm assembly. (Refer to 3-3)
- 2) Remove torsion coil spring ① from portion ② to remove CAP brake assembly.

[Note on Mounting]

- Mount torsion coil spring ① to CAP brake assembly ② in the order ③ and ④. (Fig. A)
- Put the fulcrum of CAP brake assembly ② to CAP brake shaft ③ and the tip of torsion coil spring to ④.
- Don't touch brake shoe ⑤ with bare hand.




Fig. 3-4

3-5. TG2 ROLLER, FE HEAD ASSEMBLY

(Fig. 3-5)

- 1) Remove claw ② to pull out TG2 roller ①.
- 2) Remove screw ③ to pull out FE head assembly.

[Note on Mounting]

- Keep clean the surface contacts tape of TG2 roller ①.




Fig. 3-5

3-6. PINCH PRESS BLOCK ASSEMBLY, ELEVATOR GEAR (Fig. 3-6)

- 1) Remove E ring ① to pull out pinch press block assembly ②.
- 2) Remove lid opener ③ by pressing claw ④ in the arrow direction.
- 3) Pull out elevator gear ⑤.

[Note on Mounting]

- Apply grease FLOIL SG-055G (Jug Ref. No. J-12) to ☆ marked portions.
- Be sure to match the phase ④ between elevator gear ④ and press gear ⑤ on mounting elevator gear ④.




Fig. 3-6

3-7. ACE BLOCK ASSEMBLY (Fig. 3-7)

- 1) Move torsion coil spring (ACE) ① in the arrow ➀ direction.
- 2) Remove ACE adjustment screw ②.
- 3) Remove AC height adjustment nut ③ to pull out ACE block assembly ④.

[Note on Mounting]

- Keep clean the surface contacts tape of ACE block assembly ④.
- Be sure to bang torsion coil spring (ACE) ① in the arrow ➀ direction.
- Set ACE adjustment screw ② to the height as shown in Fig. A.

[Adjustment after Mounting]

- 4-1. Tape path adjustment.
- After adjustment apply Screw Lock G (1401B) (Jlg Ref. No. J-14) at ☆ marked portion.




Fig. 3-7

3-8. TG3, TG6 GUIDE ROLLER ASSEMBLIES

(Fig. 3-8)

- 1) Loosen screw ① and pull out TG3 guide roller assembly ② by turning it in the arrow ③ direction.
- 2) Loosen screw ④ and pull out TG6 guide roller assembly ⑤ by turning it in the arrow ⑥ direction.

[Note on Mounting]

- Keep clean the surface contacts tape of TG3 and TG6 guide roller assemblies ②, ⑤.

[Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-8




Fig. 3-9




Fig. 3-10

3-9. CAPSTAN MOTOR (Fig. 3-11)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove screws ① to pull out capstan motor ②.

[Note on Mounting]

- Keep clean the surface contacts tape of capstan motor ②.
- On tightening screws ①, first tighten screw A temporarily, next tighten screws in the order B to C to A.

[Adjustment after Mounting]

- 4-1. Tape path adjustment




Fig. 3-11

3-10. MAIN BRAKE ASSEMBLIES S AND T
(Fig. 3-12)

- 1) Remove tension spring ①.
- 2) Remove stopper washer (2) ② to remove neutrality arm ③.
- 3) Remove pendulum compulsion arm ④ and tension coil spring ⑤.
- 4) Remove stopper washer (2) ⑥ to remove main brake S assembly ⑦.
- 5) Remove stopper washer (2) ⑧ to remove main brake T assembly ⑨.

[Note on Mounting]

- Don't touch brake shoes ⑩ and ⑪ with bare hand.
- Apply FLOIL PG-055G (Fig Ref. No. J-12) to ☆ marked portions.




Fig. 3-12

3-11. SOFT BRAKE T ASSEMBLY (Fig. 3-13)

- 1) Remove pinch press block assembly. (Refer to 3-6.)
- 2) Remove lid opener ① carefully not to damage claw ②.
- 3) Remove tension spring ③ from side ④ to pull out soft brake T assembly ⑤.

[Note on Mounting]

- Don't touch brake shoes ⑥ with bare hand.




Fig. 3-13

3-12. RVS BRAKE ARM ASSEMBLY, REEL TABLE (T) ASSEMBLY (Fig. 3-14)

- 1) Remove main brake T assembly (Refer to 3-10.)
- 2) Remove soft brake T assembly. (Refer to 3-11.)
- 3) Remove tension coil spring ① in the order ⑥ to ⑤.
- 4) Remove RVS brake arm assembly ②.
- 5) Remove stopper washer (2) ③ to pull out reel table (T) assembly ④.

[Note on Mounting]

- Apply one drop of Diamond Oil NT-68 (Jlg Ref. No. J-13) to ☆ marked portion before mounting reel table (T) assembly ④. (Fig. A)
- Don't touch the hatched portion on reel table (T) assembly ④ and brake shoe ⑥ of RVS brake arm assembly ② with bare hand.




Fig. 3-14

3-13. TGS ASSEMBLY (Fig. 3-15)

- 1) Remove TGS retainer ① to pull out TGS assembly ②.

[Note on Mounting]

- Apply FLOIL SG-055G (fig Ref No. J-12) to ☆ marked portion.
- Keep clean the surface contacts tape of TGS assembly ②.
- Be careful not to change the shape of TGS retainer ①.

[Adjustment after Mounting]

- 4-L. Tape path adjustment.




Fig. 3-15

3-14. TGS HOLDER (Fig. 3-16)

- 1) Remove TGS assembly. (Refer to 3-13)
- 2) Pull out TGS holder ①.

[Note on Mounting]

- Be careful about the direction of TGS holder ①. (② of Fig. A)

[Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-16

3-15. TGS AND PRESS GEARS (Fig. 3-17)

- 1) Remove pinch press block assembly. (Refer to 3-6.)
- 2) Remove soft brake T assembly. (Refer to 3-11.)
- 3) Remove TGS assembly. (Refer to 3-13.)
- 4) Remove TGS holder. (Refer to 3-14.)
- 5) Pull out TGS gear ① or press gear ②.

[Note on Mounting]

- Adjust the holes on gears to the holes on chassis. (Fig. A)
- Adjust the arrows carved on gears each other. (Fig. A)




Fig. 3-17

3-16. CAM MOTOR CHASSIS BLOCK ASSEMBLY, UPPER/LOWER COMMUNICATION GEAR (Fig. 3-18)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove screws ① to remove cam motor chassis assembly ②.
- 4) Pull out upper/lower communication gear ③.

[Note on Mounting]

- First, check main slider ④ slides fully in the arrow direction.
- Set rotary encoder switch position to "B" seen from the window of cam motor chassis. (Fig. A)
- Tighten screws ① in the order ② to ③ to ④ to ⑤.




Fig. 3-18

3-17. ROTARY ENCODER SWITCH (Fig. 3-19)

- 1) Remove timing belt. (Refer to 3-3)
- 2) Remove CAP brake assembly. (Refer to 3-4)
- 3) Remove cam motor chassis block assembly (Refer to 3-15.) and turn upside out the bottom.
- 4) Remove stopper washer (2) ① to pull out worm wheel ②.
- 5) Remove stopper washer (2) ③ to pull out cam gear ④.
- 6) Pull out FL driving gear ⑤ and rotary encoder switch ⑥.

[Note on Mounting]

- Apply FLOIL SG-055C (Jig Ref. No. J-12) to ☆ marked portions. (Fig. 3-19, A)
- Adjust the hole ⑦ to the hole on cam motor chassis. (Fig. B)
- Adjust the holes ⑧ and ⑨ to the hole on cam motor chassis. (Fig. C)




Fig. 3-19

3-18. MAIN SLIDER (Fig. 3-20)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove cam motor chassis block assembly. (Refer to 3-16.)
- 4) Remove screw ① to remove retainer ②.
- 5) Pull out main slider ③.

[Note on Mounting]

- Apply FLOLIL SG-055G (Jig Ref. No. J-12) as shown in Fig. A.
- At the last, slide main slider fully in the arrow direction.




Fig. 3-20

3-19. SHUTTLE T BLOCK AND LOADING GEAR T BLOCK ASSEMBLIES (Fig. 3-21)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove card motor chassis block assembly. (Refer to 3-16.)
- 4) Remove main slider. (Refer to 3-18.)
- 5) Remove screw ① to remove loading leaf (T) spring ② and shuttle T block assembly ③.
- 6) Pull out loading gear T block assembly ④.

[Note on Mounting]

- Adjust the phase ⑤ between loading gear (T) and loading gear (S). (Fig. A)
- Keep clean the surface contacts tape of shuttle T block assembly ③.




Fig. 3-21

3-20. SHUTTLE S BLOCK AND LOADING GEAR S BLOCK ASSEMBLIES (Fig. 3-22)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove cam motor chassis block assembly. (Refer to 3-16.)
- 4) Remove main slider. (Refer to 3-15.)
- 5) Remove screw ① to remove loading leaf (S) spring ② and shuttle S block assembly ③.
- 6) Pull out loading gear S block assembly ④.

[Note on Mounting]

- Adjust the phase Ⓞ between loading gear (S) and loading gear (T). (Fig. A)
- Keep clean the surface contacts type of shuttle S block assembly ④.




Fig. 3-22

3-21. REEL TABLE (S) ASSEMBLY (Fig. 3-23)

- 1) Remove tension spring ① from the chassis side.
- 2) Remove stopper washer (2) ② to pull out soft brake (S) ③.
- 3) Move TGI band ④ over the reel table.
- 4) Remove stopper washer (2) ⑤.
- 5) While pressing main brake S assembly ⑥, pull out reel table (S) assembly ⑦.

[Note on Mounting]

- Apply one drop of Diamond Oil NT-68 (Jlg Ref. No. J-13) to ☆ marked portion before mounting reel table (S) assembly ⑦ (Fig. A)
- Don't touch the hatched portion on reel table (S) assembly ⑦ with bare hand.




Fig. 3-23

3-22. TG1 ASSEMBLY (Fig. 3-24)

- 1) Set the mechanism to the loading-end condition referring to 1-1. (Cam gear indicates "LE". (Refer to Fig. A and B of Fig. 3-18.))
- 2) Remove tension spring ① in the order ④ to ③.
- 3) Remove stopper washer (2) ② to pull out TG1 assembly ③.

[Note on Mounting]

- Apply one drop of Diamond Oil NT-68 (Jig Ref. No. J-13) to ☆ marked portion.
- Keep clean the felt side of TG1 assembly




Fig. 3-24

3-23. S WINDING BLOCK ASSEMBLY (Fig. 3-25)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove cam motor chassis block assembly. (Refer to 3-16.)
- 4) Remove main slider. (Refer to 3-18.)
- 5) Remove stopper washer (2) ① to pull out S winding block assembly ②.
- 6) Remove torsion spring ③.

[Note on Mounting]

- At the last, hang torsion spring ③ to the position ④.
- Apply FLOIL SG-055G (Jig Ref. No. J-12) to ☆ marked portions.




Fig. 3-25

3-24. TRIGGER LEVER AND RKB BLOCK ASSEMBLIES (Fig. 3-26)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove cam motor chassis block assembly. (Refer to 3-16.)
- 4) Remove main slider. (Refer to 3-18.)
- 5) Remove tension spring ① in the order ② to ④ to remove trigger lever assembly ⑤.
- 6) Remove screws (3 x 6) ③ to remove RKB block assembly ④.

[Note on Mounting]

- Apply FLOIL SG-055G (Jig Ref. No. J-12) to ☆ marked portions on trigger lever assembly. (Fig. A)




Fig. 3-26

4. ADJUSTMENT

4-1. TAPE PATH ADJUSTMENT

The "Tape path" refers to the route of the tape from the supply reel disk to the take-up reel disc via the video heads.

Each component part of the tape transport system particularly the surface of parts which make direct contact with the tape must always be kept clean, free of dust, oil, scratches and so forth.

The tape path system is factory preadjusted, when parts of the tape transport system are replaced, be sure to make the required adjustments as precisely as possible in order to ensure stable tape transport.

4-1-1. TENSION REGULATOR (TG1) POSITION/ TENSION ADJUSTMENT (Fig. 4-1)

Purpose: stabilizes contact of the video head and the tape to maintain the tension of the tape so that it feeds at a constant level.

• Position adjustment

Mode	Treading is completed without a cassette loaded
Adjustment locations	Eccentric pin of TGI1 band assembly

[Adjustment Method]

- 1) Allow the unit to go through the threading procedure without a cassette loaded.

- 2) Set the unit to play back, then turn the eccentric pin so that the tip of tension arm goes to the left side line carved on the mechanical chassis. (Fig. A)

- 3) After adjustment, go through the loading procedure once more without a cassette loaded, then check the position of the tension arm.

• Tension adjustment

Mode	Playback
Measuring instrument/tool	Torque cassette
Adjustment locations	Position for backing the tension spring
Specified value	36 to 44 g/cm

[Adjustment Method]

- 1) Playback the torque cassette.
- 2) Check that the center value deviation reading on the torque cassette meets with the standards.
- 3) When the reading is higher than the standards: Move the spring toward direction ②.
When the reading is less than the standards: Move the spring toward direction ①.




Fig. 4-1

4-1-2. TGS GUIDE ROLLER HEIGHT ADJUSTMENT (Fig. 4-2)

Mode	Playback
Jig	Blank tape
Adjustment locations	Guide roller height adjustment screw
Specified value	0 to 0.1 mm

Procedure:

- 1) Set the tape, during CUE playing back, check the height from lower flange of TG7 to the running tape (Fig. A)
- 2) During REV playing back, check the height from lower flange of TG7 to the running tape. (Fig. B)
- 3) When the difference between items 1) and 2) doesn't go to specified value, adjust by turning TGS guide roller height adjustment screw.
- 4) Check the tape is crossed or not between the capstan and TGS, adjust with TGS guide roller height adjustment screw so that the tape is not crossed during normal playback, CUE and REV.




Fig. 4-2

4-1-3. HEIGHT ADJUSTMENT OF GUIDE ROLLERS NO. 3 AND NO. 6 (Fig. 4-3)

Mode	Playback
Signal	Alignment tape
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SW P pin for RF PC board check.
Adjustment locations	Guide roller height adjuster screw

[Adjustment Method]

- 1) Tracking (playback) Turn off the auto tracking, then press the tracking buttons \square and \square simultaneously to set the tracking at the center position.
(If adjustment is made after the drum is replaced, the tracking must be set at the max. RF output position.)
- 2) Height adjuster screw: Even out the RF output waveforms.
- 3) Press the tracking buttons (playback): \square and \square alternately.
- 4) Check that RF output drops the same amount at the front and rear edges.




Fig. 4-3

**4-1-4. ACE HEAD ASSEMBLY ADJUSTMENT
(ROUGH ADJUSTMENT) (Figs. 4-4 and 4-5)**

Purpose: Allows the tape to make even contact with the head for recording and playback of the specified track.

Mode	Playback
Tool	Blank tape
Adjustment locations	Height adjuster nut, Tilt adjuster screw

[Adjustment Method]

- 1) Mount the ACE head assembly. At this time, adjust the height so that the height of guide flange No. 7 matches the level of the lower edge of the control head.
- 2) Remove the adjustment tool and load a new tape, then set the unit for playback.
- 3) Check that the tape does not curl or rise up noticeably near the ACE head.
- 4) If the tape curls up or rises noticeably, readjust the tilt adjuster screw, the azimuth adjuster screw and the height adjuster nut.
(The height of the ACE head should be adjusted so that the lower edge of the tape is approx. 0.1 to 0.15 mm from the control head.)
- 5) Perform precision adjustment.




Fig. 4-4




Fig. 4-5

4-1-5. ACE HEAD ASSEMBLY ADJUSTMENT (PRECISION ADJUSTMENT)

Mode	Playback
Signal	Alignment tape (1kHz track)
Measuring instrument	Oscilloscope
Measuring point	Audio output terminal
Adjustment locations	Azimuth adjuster screw, Height adjuster nut, Tilt adjuster screw

[Adjustment Method]

- 1) Adjust the tilt adjuster screw in the FWD or REV mode so that the lower flange of guide No. 7 does not curl up or rise.
- 2) Alternately adjust the azimuth adjuster screw, the height adjuster nut, and the tilt adjuster screw to maintain even audio output at maximum with minimum deviation.



Fig. 4-6

4-1-6. X-VALUE ADJUSTMENT

Purpose: To obtain compatibility with other VTR.

Precaution: Be sure to perform the preset tracking adjustment before perform this adjustment (Refer to the Service Guide.)

Turn off the auto tracking and set the VTR for manual tracking mode.

Mode	Playback
Signal	Alignment tape
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SW P pin for RF PC board check.
Adjustment locations	X-value adjuster screw

[Adjustment Method]

- Adjustment by Hi-Fi alignment tape (NTSC only)
When the tracking is set at the center position (by pressing the ∇ and Δ keys simultaneously), adjust the RF output to maximum.




Fig. 4-7

• **Adjustment by alignment tape**

Adjust the X-value adjuster screw so that maximum RF output is obtained and also that the RF output drops to the same position on pressing the respective ∇ and Δ buttons while the tracking is set at the center position.




Fig. 4-8


4-1-7. ADJUSTMENTS AFTER REPLACING THE DRUM (VIDEO HEAD)

Purpose: Co-relative height, X-value and other factors of the drum will deviate from those of the guide roller. If the drum is replaced properly, these deviations are extremely small.

Precaution: Turn off the auto tracking and set the manual tracking mode


Mode	Playback
Signal	Alignment tape, blank tape
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SW P pin for RF PC board check.
Adjustment locations	Guide roller (refer to 4-1-2, 4-1-3.) Switching position, Tracking preset, SP delay mono-multi (Refer to the Service Manual), X-value. (refer to 4-1-6.)

[Adjustment Method]




[Checking the evenness and fluctuation of the RF output]


- 1) Set the RF output to the maximum level using the tracking buttons.



- 2) Perform fine adjustment of the voltage level range of the oscilloscope, then adjust the RF output deviation to within 4 gradations.



- 3) Press the tracking buttons and adjust the maximum amplitude of the RF output to within 3 gradations.
- 4) At this time, check if the minimum amplitude is more than 2 gradations.



- 5) Check that the RF output fluctuation between minimum and maximum levels is within 13%.

4-1-8. CHECKING THE TENSION AND TORQUE

Purpose: To check that the tension, torque and compression force of the tape take-up section and mobile sections to ensure smooth tape run and achieve standard VTR performance.

If the tape transport is not smooth or problems occur in relation to the tape transport speed, perform the following check.

Mode	Each operation mode without loading a cassette tape. (Refer to section 1-3.)
Measuring instrument	Torque gauge, Torque gauge adaptor

Item	VTR operation mode	Reel to be measured	Measurement value
Main brake torque	Stop	Supply and take-up reels	170 g/cm or more
Review torque	Review	Supply reel	180 \pm 30 g/cm (using the torque cassette)
Take-up torque	Playback	Take-up reel	95 \pm 25 g/cm (using the torque cassette)
Back tension torque	Playback	Take-up reel	33 to 44 g/cm (using the torque cassette)

[Check Method]

Measure the torque using the torque gauge and torque gauge adaptor with the torque gauge fixed.




Fig. 4-8

VHS MECHANICAL ADJUSTMENT MANUAL IV

VHS MECHANICAL ADJUSTMENT MANUAL IV

SONY SERVICE MANUAL

H MECHANISM

SUPPLEMENT-1

1. How to Use the Mode Selector II for Adjusting H Type Mechanism Assembly.
2. Adjusting Mechanism Using New Alignment Tape (KRV-52NE For NTSC).

File this supplement with the VHS mechanical adjustment (V).

TABLE OF CONTENTS

Section	Title	Page
1.	HOW TO USE THE MODE SELECTOR II FOR ADJUSTING H TYPE MECHANISM ASSEMBLY	2
1-1	Outline	2
1-2	Preparation	2
1-3	Connection	2
1-4	Operation	2
1-5	Precautions	2
2.	ADJUSTING THE MECHANISM USING NEW ALIGNMENT TAPE (KRV-52NE for NTSC)	4
2-1.	Adjustment Using Alignment Tape (KRV-52NE for NTSC having no version No.)	4
2-1-1.	X-Value Adjustment (Using the tape having no version No.)	4
2-2.	Adjustment Using Alignment Tape (KRV-52NE for NTSC having the version No.)	6
2-2-1.	X-Value Adjustment (Using the tape having the version No.)	6
2-3.	Adjusting the Mechanism Using Alignment Tape (KRV-52NE for NTSC)	10
2-3-1.	Height Adjustment of Guide Rollers No. 3 and No. 8	10
2-3-2.	ACE Head Assembly Adjustment (Rough Adjustment)	11
2-3-3.	ACE Head Assembly Adjustment (Precision Adjustment)	11
2-3-4.	Adjustments After Replacing the Drum (Video Head)	12



1. HOW TO USE THE MODE SELECTOR II FOR ADJUSTING H TYPE MECHANISM ASSEMBLY

1-1. OUTLINE

To activate the VHS system H type mechanism assembly using mode selector II (J-6062-282-A), use connector conversion jig (J-6090-052-A). By using the connector conversion jig, the following operations are possible.

- Loading and unloading action by the loading motor
- Reading of the current setting of the mode switch
- Normal and reverse rotation of the capstan motor

1-2. PREPARATION

1-2-1. ADDITION OF POWER SUPPLY CABLE

(Already added Mode Selector II also available)

In order to drive the capstan motor, the power +5 V and +12 V are supplied from the Mode Selector II. Disassemble the D-SUB connector of the Mode Selector cable, then solder the following three places.

Supplied 3-pin cable	DSUB connector of the mode selector II	Voltage
Pin 1 (Red index)	Pin 20	+12 V
Pin 2	Pin 25	GND
Pin 3	Pin 24	+5 V

- Connector pin number assignment of the DSUB connector (From the soldering side)



- When connections are made, check that +5 V and +12 V are available at the 3-pin cable connector.

1-2-2. CHECKING THE SOFTWARE VERSION

Turn on the power of the mode selector II.

If the reading for the software version on the mode selector II is not 1.10 or higher, replace the New ROM (J-6062-314-A).

1-3. CONNECTION

1-3-1. CONNECTION BETWEEN THE CONNECTOR CONVERSION JIG AND THE MODE SELECTOR II (See Fig. 1-1)

Insert the connectors of the two 6-pin cables (one is white and the other is black) and the 3-pin cable from the mode selector II to the corresponding connectors on the connector conversion jig (J-6090-052-A).

1-3-2. CONNECTION BETWEEN THE CONNECTOR CONVERSION JIG AND THE H TYPE MECHANISM ASSEMBLY

With the power of the mode selector II turned off, insert the following three connectors to the corresponding connectors on the H type mechanism assembly.

- 3-pin connector for the loading motor
- 5-pin connector for the mode switch
- 8-pin connector for the capstan motor

Set the speed control for the minimum setting (fully counterclockwise).

1-4. OPERATION

1-4-1. OPERATION OF THE LOADING MOTOR ON THE H TYPE MECHANISM ASSEMBLY

(1) Select the H type mechanism assembly setting on the mode selector II.

(2) After this, procedures are the same as those for the previous model types.

For the operating method, see pages 3 to 5 of "8 mm Video Mechanism Manual VI (TK Mechanism) Supplement-1".

For the loading method, see page 3 of "VHS Mechanical Adjustment Manual IV (H Mechanism)".

1-4-2. OPERATION OF THE CAPSTAN MOTOR ON THE H TYPE MECHANISM ASSEMBLY

- (1) For the loading motor operation under Section 1-4-1, change the mode setting to the FF/REW mode with the mode switch.
- (2) Turn the speed control gradually in clockwise direction, and the capstan motor starts rotating. To turn the capstan motor in desired rotating direction, change the FWD/RVS setting of the rotating direction switch.

1-5. PRECAUTIONS

- Turn the speed control only when necessary. Otherwise, hold the speed control turned at fully counterclockwise direction. If the power of the mode selector II is turned on with the speed control turned in clockwise direction, +12V power fails and the power of the mode selector II cannot be turned on.
- Although the connector conversion jig (J-6090-052-A) has rubber feet, do not make a short circuit on the bottom surface of the connector conversion jig via foreign conductive materials.




Fig. 1-1


2. ADJUSTING THE MECHANISM USING NEW ALIGNMENT TAPE (KRV-52NE for NTSC)

The conventional alignment tape (For NTSC) is now replaced with alignment tape KRV-52NE, and the following describes how to align the mechanism using the KRV-52NE. For details on the use of KRV-51N2 for each model, refer to the service manuals which will be issued in the future.

Name	Parts No.	Remarks
Alignment tape KRV-52NE for NTSC	8-192-605-41	For tape path, audio azimuth, and X-value adjustments
Alignment tape KRV-51N2 for NTSC	8-192-605-32	For electrical adjustments (RF, AF, and switching position) and operation check

Note: The KRV-52NE has or does not have Ver No. depending on new or old type as shown below. (New one has Ver No.)

Note that an adjusting method of X-value is different.



Contents:
KRV-52NE (NTSC)

Time	Video	Audio
20 min.	Recording only at 1 MHz, A-ch. EP mode RF skipping once per 5 frames	5 kHz full tracks

KRV-51N2 (NTSC)

Class	Mode	Time	Video	Audio (RF/Normal)
1	SP	7 min.	Color bar	400 Hz
2	SP	3 min.	Mono. scope	400 Hz
3	EP	7 min.	Color bar	400 Hz
4	EP	3 min.	Mono. scope	400 Hz

2-1. ADJUSTMENT USING ALIGNMENT TAPE (KRV-52NE for NTSC having no version No.)


2-1-1. X-VALUE ADJUSTMENT (Using the tape having no version No.)

Purpose: To obtain compatibility with other VCRs.

Precaution: Before starting to adjust X-value, set the tracking control at the center position. To set the tracking

control at the center position for the VCRs equipped with the and tracking control keys, press both the and tracking control keys at the same time. For the VCRs not equipped with the tracking control keys, deactivate the automatic tracking control by pressing the tracking key on the remote control unit during threading operation (after a tape is inserted but before the VCR starts playing back the tape).

Mode	Playback
Signal	Alignment tape KRV-52NE (For NTSC having no version No.)
Measuring instrument	Oscilloscope TIM/DIV: 2ms Trigger source: CH2 Trigger slope: \uparrow
Measuring point	CH-1: Connector PB RF pin for RF PC board check CH-2: Connector RF SWP pin for RF PC board check
Adjustment location	X-value adjuster screw




RF output shall be maximum at the center position of the tracking control

[Adjustment Method]

Set the tracking control at the center position. For the VCRs equipped with narrow gap video heads, set the X-value adjustment screw where a maximum RF output is obtained. For the VCRs equipped with wide gap video heads, set the X-value adjustment screw both where a maximum RF output is obtained and where the RF output decreases immediately when the tracking control key is pressed

X-VALUE ADJUSTMENT (Using the tape having no version No.)








When adjustment is complete, adjust the height of No. 3 and No. 6 guide rollers on page 10.


2-2. ADJUSTMENT USING ALIGNMENT TAPE (KRV-52NE for NTSC having the version No.)

2-2-1. X-VALUE ADJUSTMENT (Using the tape having the version No.)

Purpose: To obtain compatibility with other VCRs.

Precaution: Before starting to adjust X-value, set the tracking control at the center position. To set the tracking control at the center position for the VCRs equipped with the  and  tracking control keys, press both the  and  tracking control keys at the same time. For the VCRs not equipped with the tracking control keys, deactivate the automatic tracking control by pressing the tracking  key on the remote control unit during threading operation (after a tape is inserted but before the VCR starts playing back the tape).

Mode	Playback
Signal	Alignment tape KRV-52NE (For NTSC having the version No.)
Measuring instrument	Oscilloscope TIM/DIV: 2ms Trigger source: CH2 Trigger slope: +
Measuring point	CH-1: Connector PB RF pin for RF PC board check CH-2: Connector RF SWP pin for RF PC board check
Adjustment locations	X-value adjuster screw




RF output shall be maximum at the center position of the tracking control.


[Adjustment Method]

Set the tracking control at the center position. For the VCRs equipped with narrow gap video heads, set the X-value adjustment screw where a maximum RF output is obtained. For the VCRs equipped with wide gap video heads, set the X-value adjustment screw both where a maximum RF output is obtained and where the RF output decreases immediately when the ∇ tracking control key is pressed.


1. Adjusting X-value (Using the tape having the version No.)



2. Checking false tracking (Using the tape having the version No.)



Using the tape having the version No.



2-3. ADJUSTING THE MECHANISM USING ALIGNMENT TAPE (KRV-52NE for NTSC)

2-3-1. HEIGHT ADJUSTMENT OF GUIDE ROLLERS NO. 3 AND NO. 6


Mode	Playback
Signal	Alignment tape KRV-52NE (For NTSC)
Measuring instrument	Oscilloscope TIM/DIV: 2ns Trigger source: CH2 Trigger slope: +
Measuring point	CH-1: Connector PB RF pin for RF PC board check CH-2: Connector RF SWP pin for RF PC board check
Adjustment locations	Height adjustment screw for No.3 tape guide roller Height adjustment screw for No.6 tape guide roller

[Adjustment Method]

The following adjustment shall be carried out after completed Section 2-1-1 "X-value adjustment and check".


- 1) Deactivate the automatic tracking control, and set the tracking control at the center position. To set the tracking control at the center position for the VCRs equipped with the **▲** and **▼** tracking control keys, press both the **▲** and **▼** tracking control keys at the same time. For the VCRs not equipped with the tracking control keys, deactivate the automatic tracking control by pressing the tracking **AUTOMANUAL** key on the remote control unit during threading operation (after a tape is inserted but before the VCR starts playing back the tape).

- 2) Check if the RF output changes in amplitude by pressing the tracking control key. The RF output should change periodically (changes from a minimum amplitude to a maximum amplitude, and to the minimum amplitude again).



- 3) Turn the height adjustment screws of tape guide rollers No.3 and No.6 so that the RF output envelope becomes as flat as possible.
- 4) Press the **▲** tracking control key, and check that both the beginning and end of the RF output change together the same in amplitude.
- 5) Press the **▼** tracking control key, and check that both the beginning and end of the RF output change together the same in amplitude.

Turn the height adjustment screws of tape guide rollers No.3 and No.6 into by little so that the RF output envelope becomes as flat as possible.



Height adjustment screw of tape guide roller No.3
Tape guide No.4
Tape guide No.6
Height adjustment screw of tape guide roller No.6

Press the **▼** tracking control key, then the **▲** tracking control key, and check that both the beginning and end of the RF output change together the same in amplitude.

When the **▲** tracking control key is pressed.



At the tracking center position.



When the **▼** tracking control key is pressed.



**2-3-2. ACE HEAD ASSEMBLY ADJUSTMENT
(ROUGH ADJUSTMENT) (Figs. 2-1 and 2-2)**

Purpose: Allows the tape to make even contact with the head for recording and playback of the specified track.

Mode	Playback
Jig	Blank tape
Adjustment locations	Height adjuster nut, Tilt adjuster screw

[Adjustment Method]

- 1) Mount the ACE head assembly. At this time, adjust the height so that the height of guide flange No. 7 matches the level of the lower edge of the control head.
- 2) Remove the adjustment tool and load a new tape, then set the unit for playback.
- 3) Check that the tape does not curl or rise up noticeably near the ACE head.
- 4) If the tape curls up or rises noticeably, readjust the tilt adjuster screw and the height adjuster nut.
(The height of the ACE head should be adjusted so that the lower edge of the tape is approx. 0.1 to 0.15 mm from the control head.)
- 5) Perform precision adjustment.




Fig. 2-1




Fig. 2-2

**2-3-3. ACE HEAD ASSEMBLY ADJUSTMENT
(PRECISION ADJUSTMENT)**

Mode	Playback
Signal	Alignment tape (KRV-52NE 5 kHz) (For NTSC)
Measuring instrument	Oscilloscope
Measuring point	Audio output terminal
Adjustment locations	Azimuth adjuster screw, Height adjuster nut, Tilt adjuster screw

[Adjustment Method]

- 1) Adjust the tilt adjuster screw in the FWD or REV mode so that the lower flange of guide No. 7 does not curl up or rise.
- 2) Alternately adjust the azimuth adjuster screw, the height adjuster nut, and the tilt adjuster screw to maintain even audio output at maximum with minimum deviation.




Fig. 2-3

2-3-4. ADJUSTMENTS AFTER REPLACING THE DRUM (VIDEO HEAD)


Purpose: Co-relative height, X-value and other factors of the drum will deviate from those of the guide roller. If the drum is replaced properly, these deviations are extremely small.

Note 1: Deactivate the automatic tracking control for setting the mechanism in manual tracking control mode.

Note 2: To set the tracking control at the center position, deactivate the automatic tracking control by pressing the tracking [AUTO/MANUAL] key on the remote control unit during threading operation (after a tape is inserted but before the VCR starts playing back the tape).


Mode	Playback
Signal	Alignment tape KRV-52NE (For NTSC), blank tape
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SWP pin for RF PC board check.
Adjustment locations	Guide roller (Refer to 2-3-1.) Switching position (Refer to the Service Manual) X-value (Refer to 2-1-1, 2-1-2.)

[Adjustment Method]




[Checking the evenness and fluctuation of the RF output]


- 1) Set the RF output to the maximum level using the tracking buttons.



- 2) Perform fine adjustment of the voltage level range of the oscilloscope, then adjust the RF output deviation to within 4 gradations.



- 3) Press the tracking buttons and adjust the maximum amplitude of the RF output to within 3 gradations.
- 4) At this time, check if the minimum amplitude is more than 2 gradations.



- 5) Check that the RF output fluctuation between minimum and maximum levels is within 13%

VHS MECHANICAL ADJUSTMENT MANUAL IV

VHS MECHANICAL ADJUSTMENT MANUAL IV

SONY SERVICE MANUAL

VHS MECHANISM

SUPPLEMENT-2

File this supplement with the VHS mechanical adjustment IV and supplement-1.

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>
1.	CORRECTION	1
1-1.	Adjustment Sequence	1
2.	MODIFICATION	2
2-1.	Changing the Recorded Contents of Alignment Tape	2
2-2.	TG2 Roller, FE Head Assembly	2
2-3.	TG3, TG6 Guide Roller Assembly	3
2-4.	TG8 Assembly	4
2-5.	Tension Regulator (TG1) Position Tension Adjustment	5
2-6.	TG8 Guide Roller Height Adjustment	6

1. CORRECTION

In the VHS Mechanism Adjustment Manual IV (Supplement-1), an adjustment sequence was wrong, and it is corrected as follows:

1-1. Adjustment Sequence (VHS Mechanism Adjustment Manual IV (Supplement-1) Page 6 to 11)

(1) Adjustment of No. 3 and No. 6 guide roller height

Delete the "The following adjustment shall be carried out after completed Section 2-1-1 "X-value adjustment and check" under "Adjustment Method" on page 10.

(2) Adjustment of ACE head assembly

Note: In the adjustment of ACE head assembly (coarse adjustment and fine adjustment), if an azimuth, height and tilt were adjusted, again adjust the height of No. 3 and No. 6 guide rollers

(3) Adjustment of X value



2. MODIFICATION

2-1. CHANGING THE RECORDED CONTENTS OF ALIGNMENT TAPE

KRV-S2NE (NTSC) (Ver. 1.2)

Time	Video	Audio
20 min.	Recording only at 1 MHz. A-eb. EP mode RF flipping once per 5 frames	5 kHz → 4.5 kHz full tracks

2-2. TG2 ROLLER, FE HEAD ASSEMBLY (Refer to VHS Mechanical Adjustment Manual IV page14)

- The TG2 roller is provided with either of two types, fixed or straight. For the fixed type, section 3-5 is added.

3-5. TG2 ROLLER, FE HEAD ASSEMBLY (Fig. 3-5)

- 1) Remove screw ① to pull out FE head assembly ②.

[Note on Mounting]

- Keep clean the surface contacts tape of TG2 roller.




Fig. 3-5

2-3. TG3, TG6 GUIDE ROLLER ASSEMBLIES
(Refer to VHS Mechanical Adjustment Manual [V page 17])

- There is another type in TG3 and TG6 guide roller assemblies, which is not attached with a screw (B2X3). For the screwless type, section 3-8 is added.

3-8. TG3, TG6 GUIDE ROLLER ASSEMBLIES
(Fig. 3-8)

- 1) TG3 guide roller assembly ① by turning it in arrow ④ direction.
- 2) Removal the spring ②.
- 3) TG6 guide roller assembly ③ by turning it in arrow ④ direction.
- 4) Removal the spring ⑤.

[Note on Mounting]

- Keep clean the surface contacts tape of TG3 and TG6 guide roller assemblies ①, ③.

[Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-8

2-4. TGS ASSEMBLY
(Refer to VHS Mechanical Adjustment
Manual IV page 23)

- As the shape of TGS assembly was changed, Section 3-13 is changed.

 : Changed portion

3-13. TGS ASSEMBLY (Fig. 3-15)

- Remove TG7 tape retainer ① to pull out TGS assembly ②.

[Note on Mounting]

- Apply FLOIL SG-055G (Jig Ref. No J-12) to ☆ marked portion
- Keep clean the surface contacts top of TGS assembly ②.
- Be careful not to change the shape of TG7 tape retainer ①.
- After attaching the TG7 tape retainer ①, check that side ③ of ① is below side ④ of the stepped-part of the TG7 shaft. (Fig. A)

[Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-15

**2-5. TENSION REGULATOR (TG1) POSITION/
TENSION ADJUSTMENT**
(Refer to VHS Mechanical Adjustment
Manual IV page 35)

- As the tension regulator position and tension adjustment were changed, the tension adjustment and Fig. 4-1 are changed.

Changed portion

• Tension adjustment

Mode	Playback
Measuring instrument/tool	Torque cassette
Adjustment locations	Position for hooking the tensioned spring
Specified value	34 ± 4 gcm




Fig. 4-1

VHS MECHANICAL ADJUSTMENT MANUAL IV

2-6. TG8 GUIDE ROLLER HEIGHT ADJUSTMENT (Refer to VHS Mechanical Adjustment Manual IV page 36)

* As the use of TG8 height adjusting screw was cancelled, section 4-1-2 is changed.

4-1-2. TG7 TAPE PATH ADJUSTMENT (Fig. 4-2)

[Adjustment Method]

1) Load a tape, and playback the tape in the CUE mode, confirm the distance between lower flange of No. 7 guide roller and lower side of tape (Fig. A).

- 2) Then, feeding the tape in the REV mode, confirm the distance between lower flange of No. 7 guide roller and lower side of tape.
- 3) If the tape height in the REV feed is higher than in the CUE playback (Fig. B), rotate the ACE head flapping adjust screw in the direction \odot so that a difference in tape height between CUE mode and REV mode becomes zero.
- 4) If the tape height in the REV feed is lower than in the CUE playback (Fig. C), rotate the ACE head flapping adjust screw in the direction \ominus so that a difference in tape height between CUE mode and REV mode becomes zero.




Fig. 4-2

Sony Corporation
Consumer A&V Products Company
Home A&V Products Div.

Published by Personal A&V Products Div.
Quality Engineering Dept.

VHS MECHANICAL ADJUSTMENT MANUAL IV

SONY

H MECHANISM

SERVICE MANUAL

SUPPLEMENT-3

File this supplement with the VHS mechanical adjustment IV and supplement-1, 2.

Subject: Mechanism chassis assembly changed.
PAL alignment tape changed.

(SL-600060)

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>
1.	MODIFICATION	2
1-1	Parts Requiring Clearing	2
1-2	Drum Assembly, Drum Base	3
1-3	TG2 Roller, FE Head Assembly	4
1-4	TG3, TG8 Guide Roller Assemblies	5
1-5	Shuttle T Block and Loading Gear T Block Assemblies	6
1-6	Shuttle S Block and Loading Gear S Block Assemblies	7
2.	ADJUSTING THE MECHANISM USING NEW ALIGNMENT TAPE (KRV-S2PL for PAL)	8
2-1	Height Adjustment of Guide Rollers No. 3 and No. 6	8
2-2	ACE Head Assembly Adjustment (Rough Adjustment)	9
2-3	ACE Head Assembly Adjustment (Precision Adjustment)	9
2-4	X-Value Adjustment	10
2-5	Adjustments After Replacing the Drum (Video Head)	14

1. MODIFICATION

1-1. PARTS REQUIRING CLEANING (Refer to VHS Mechanical Adjustment Manual IV page 7)

- Parts requiring a cleaning were changed in shape, and therefore, Fig. 2-1 for new type is added.

 : Modified portion




Fig. 2-1 Parts Requiring Cleaning

1-2. DRUM ASSEMBLY, DRUM BASE (Refer to VHS Mechanical Adjustment Manual IV page 11)

- The ground shaft assembly was changed and the drum base was added, and therefore Section 3-2 for new type is added.

3-2. DRUM ASSEMBLY, DRUM BASE (Fig. 3-2)

- 1) Remove screw ①.
- 2) Remove ground shaft assembly ② not to touch its tip with bare hand or tools.
- 3) Remove screws ③ to remove drum assembly ④.
- 4) Remove screws ⑤ to remove drum base ⑥.

[Note on Mounting]

- Don't touch bead chips and ground shaft assembly ④ with bare hand or tools.
- Keep clean the surface contacts tape of drum assembly ④.

[Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-2

1-3. TG2 ROLLER, FE HEAD ASSEMBLY (Refer to VHS Mechanical Adjustment Manual IV page 14)

- The TG2 roller was assembled to the FE head assembly, and therefore Section 3-5 for new type is added.

3-5. TG2 ROLLER, FE HEAD ASSEMBLY (Fig. 3-5)

- 1) Remove screw ①.
- 2) Pull out FE head assembly ②.

[Notes on Mounting]

- Keep clean the surface contacts tape of TG2 roller.




Fig. 3-5

1-4. TG3, TG6 GUIDE ROLLER ASSEMBLIES (Refer to VHS Mechanical Adjustment Manual IV page 17)

- The TG3 and TG6 guide roller assemblies were changed, and therefore Section 3-8 for new type is added.

3-8. TG3, TG6 GUIDE ROLLER ASSEMBLIES (Fig. 3-8)

- 1) TG3 guide roller assembly ① by turning it in the arrow ② direction
- 2) Removal the spring ③.
- 3) TG6 guide roller assembly ④ by turning it in the arrow ⑤ direction.
- 4) Removal the spring ⑥.

[Note on Mounting]

- Keep clean the surface contacts tape of TG3 and TG6 guide roller assemblies ①, ④.

[Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-8

1-5. SHUTTLE T BLOCK AND LOADING GEAR T BLOCK ASSEMBLIES (Refer to VHS Mechanical Adjustment Manual IV page 29)

- The shuttle T block and loading gear T block assemblies were changed, and therefore Section 3-19 for new type is added.

3-19. SHUTTLE T BLOCK AND LOADING GEAR T BLOCK ASSEMBLIES (Fig. 3-21)

- 1) Remove drum assembly and drum base. (Refer to 3-2.)
- 2) Remove timing belt. (Refer to 3-3.)
- 3) Remove CAP brake assembly. (Refer to 3-4.)
- 4) Remove cam motor chassis block assembly. (Refer to 3-18.)
- 5) Remove main slider. (Refer to 3-20.)
- 6) Sliding the shuttle T block assembly ① toward the direction ②, remove it through the hole ③.
- 7) Pull out loading gear T block assembly ②.

[Note on Mounting]

- Adjust the phase ④ between loading gear (T) and loading gear (S). (Fig. A)
- Keep clean the surface contacts tape of shuttle T block assembly ①.




Fig. 3-21

1-6. SHUTTLE S BLOCK AND LOADING GEAR S BLOCK ASSEMBLIES
(Refer to VHS Mechanical Adjustment Manual IV page 30)

- The shuttle S block and loading gear S block assemblies were changed, and therefore Section 3-20 for new type is added.

3-20. SHUTTLE S BLOCK AND LOADING GEAR S BLOCK ASSEMBLIES
(Fig. 3-22)

- 1) Remove drum assembly and drum base. (Refer to 3-2.)
- 2) Remove timing belt. (Refer to 3-3.)
- 3) Remove CAP brake assembly. (Refer to 3-4.)
- 4) Remove cam motor chassis block assembly. (Refer to 3-18.)
- 5) Remove main slider. (Refer to 3-20.)
- 6) Sliding the shuttle S block assembly ① toward the direction ②, remove it through the hole ③.
- 7) Pull out loading gear S block assembly ④.

[Note on Mounting]

- Adjust the phase ⑤ between loading gear (S) and loading gear (T) (Fig. A)
- Keep clean the surface contacts tape of shuttle S block assembly ①.




Fig. 3-22

2. ADJUSTING THE MECHANISM USING NEW ALIGNMENT TAPE (KRV-52PL for PAL)

The conventional alignment tape (For PAL) is now replaced with alignment tape KRV-52PL, and the following describes how to align the mechanism using the KRV-52PL. For details on the use of KRV-51P for each model, refer to the service manuals which will be issued in the future.

Name	Parts No.	Remarks
Alignment tape KRV-52PL for PAL	8-192-605-46	For tape path, audio, azimuth, and X-value adjustments
Alignment tape KRV-51P for PAL	8-192-605-36	For electrical adjustments (RF, AF, and switching position) and operation check

Contents:

KRV-52PL (PAL)

Time	Video	Audio
20 min.	Recording only at 1 MHz, A-cl, EP mode RF skipping once per 5 frames	4 kHz full tracks

KRV-51P (PAL)

Class	Mode	Time	Video	Audio (HFV/Normal)
1	SP	7 min.	Color bar	400 Hz
2	SP	3 min.	Mono scope	400 Hz
3	EP	7 min.	Color bar	400 Hz
4	EP	3 min.	Mono scope	400 Hz

2-1. HEIGHT ADJUSTMENT OF GUIDE ROLLERS NO. 3 AND NO. 6

Mode	Playback
Signal	Alignment tape KRV-52PL (For PAL)
Measuring instrument	Oscilloscope TIM/DIV: 2us Trigger source: CH2 Trigger slope: +
Measuring point	CH-1: Connector PB RF pin for RP PC board check CH-2: Connector RF SWP pin for RP PC board check
Adjustment locations	Height adjustment screw for No. 3 tape guide roller Height adjustment screw for No. 6 tape guide roller

[Adjustment Method]

- Deactivate the automatic tracking control, and set the tracking control at the center position. To set the tracking control at the center position for the VCRs equipped with the **[A]** and **[V]** tracking control keys, press both the **[A]** and **[V]** tracking control keys at the same time. For the VCRs not equipped with the tracking control keys, deactivate the automatic tracking control by pressing the tracking **[AUTO/MANUAL]** key on the remote control unit during the ejection operation (after a tape is inserted but before the VCR starts playing back the tape).
- Turn the height adjustment screws of tape guide rollers No. 3 and No. 6 so that the RF output envelope becomes as flat as possible.
- Press the **[A]** tracking control key, and check that both the beginning and end of the RF output change together the same in amplitude.
- Press the **[V]** tracking control key, and check that both the beginning and end of the RF output change together the same in amplitude.




Fig. 2-1




Fig. 2-2

2-2. ACE HEAD ASSEMBLY ADJUSTMENT (ROUGH ADJUSTMENT) (Figs. 2-3 and 2-4)

Purpose: Allows the tape to make even contact with the head for recording and playback of the specified track.

Mode	Playback
Jig	Blank tape
Adjustment locations	Height adjuster nut, Tilt adjuster screw

[Adjustment Method]

- 1) Mount the ACE head assembly. At this time, adjust the height so that the height of guide flange No. 7 matches the level of the lower edge of the control head.
- 2) Remove the adjustment tool and load a new tape, then set the unit for playback.
- 3) Check that the tape does not curl or rise up noticeably near the ACE head.
- 4) If the tape curls up or rises noticeably, readjust the tilt adjuster screw and the height adjuster nut. (The height of the ACE head should be adjusted so that the lower edge of the tape is approx. 0.1 to 0.15 mm from the control head.)
- 5) Perform precision adjustment.




Fig. 2-3




Fig. 2-4

2-3. ACE HEAD ASSEMBLY ADJUSTMENT (PRECISION ADJUSTMENT)

Mode	Playback
Signal	Alignment tape (KRV-52PL 4 kHz) (For PAL)
Measuring instrument	Oscilloscope
Measuring point	Audio output terminal
Adjustment locations	Azimuth adjuster screw, Height adjuster nut, Tilt adjuster screw

[Adjustment Method]

- 1) Adjust the tilt adjuster screw in the FWD or REV mode so that the lower flange of guide No. 7 does not curl up or rise.
- 2) Alternately adjust the azimuth adjuster screw, the height adjuster nut, and the tilt adjuster screw to maintain even audio output at maximum with minimum deviation.




Fig. 2-5


Note: In the adjustment of ACE head assembly (coarse adjustment and fine adjustment), if a azimuth, height and tilt were adjusted, again adjust the height of No. 5 and No. 6 guide rollers.

2-4. X-VALUE ADJUSTMENT

Purpose: To obtain compatibility with other VCRs.

Precaution: Before starting to adjust X-value, set the tracking control at the center position. To set the tracking control at the center position for the VCRs equipped with the **A** and **V** tracking control keys, press both the **A** and **V** tracking control keys at the same time. For the VCRs not equipped with the tracking control keys, deactivate the automatic tracking control by pressing the tracking **AUTO/MANUAL** key on the remote control unit during threading operation (after a tape is inserted but before the VCR starts playing back the tape).

Mode	Playback
Signal	Alignment tape KRV-52PL
Measuring instrument	Oscilloscope TIM/DIV: 2ms Trigger source: CH2 Trigger slope: +
Measuring point	CH-1: Connector PB RF pin for RF PC board check CH-2: Connector RF SWP pin for RF PC board check
Adjustment locations	X-value adjuster screw



RF output shall be maximum at the center position of the tracking control.

Fig. 2-6

2. Checking false tracking




Fig. 2-8




Fig. 2-9

2-5. ADJUSTMENT AFTER REPLACING THE DRUM (VIDEO HEAD)

Purpose: Co-relative height, X-value and other factors of the drum will deviate from those of the guide roller. If the drum is replaced properly, these deviations are extremely small.

Note 1: Deactivate the automatic tracking control for setting the mechanism in manual tracking control mode.

Note 2: To set the tracking control at the center position, deactivate the automatic tracking control by pressing the tracking [AUTOMANUAL] key on the remote control unit during the loading operation (after a tape is inserted but before the VCR starts playing back the tape).

Mode	Playback
Signal	Alignment tape KRV-52PL (For PAL), blank tape
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SWP pin for RF PC board check.
Adjustment locations	Guide roller (Refer to 2-1.) Switching position (Refer to the Service Manual) X-value (Refer to 2-5.)

[Adjustment Method]






Fig. 2-10

[Checking the evenness and fluctuation of the RF output]


- 1) Set the RF output to the maximum level using the tracking buttons.



- 2) Perform fine adjustment of the voltage level range of the oscilloscope, then adjust the RF output deviation to within 4 gradations.



- 3) Press the tracking buttons and adjust the maximum amplitude of the RF output to within 3 gradations.
- 4) AT this time, check if the minimum amplitude is more than 2 gradations.



- 5) Check that the RF output fluctuation between minimum and maximum levels is within 13%.

Fig. 2-11