

**SLV-760HF/760HFPX/761HF/790HF/960HF/960HFCS/960HFMX/
960HFPX/L5CS/L5MX/L5PA/L7HFCS/L7HFMX/L7HFPA
RMT-V158C/V161A/V181K/V184A/V186/V186A**

SERVICE MANUAL



Photo: SLV-960HF

• Refer to the **SERVICE MANUAL of VHS MECHANICAL ADJUSTMENTS IV** for **MECHANICAL ADJUSTMENTS**.
(9-973-823-11)

US Model
SLV-760HF/761HF/790HF/960HF

Canadian Model
SLV-760HF/790HF/960HF

PX Model
SLV-760HFPX, 960HFPX

Chielean Model
SLV-960HFCS/L5CS/L7HFCS

Mexican Model
SLV-960HFMX/L5MX/L7HFMX

Panamanian Model
SLV-L5PAL7HFPX

H MECHANISM

* The abbreviations of 760, 761, 790, 960, L5 and L7 contained in this service manual are indicated when these models are common to all their corresponding models as given below.

Abbreviated model name	760	761	790	960	L5	L7
All model names SLV-	760HF (US) 760HF (Canadian) 760HFPX	761HF	790HF (US) 790HF (Canadian)	960HF (US) 960HF (Canadian) 960HFCS 960HFMX 960HFPX	L5CS L5MX L5PA	L7HFCS L7HFMX L7HFPA

SPECIFICATIONS

System

Format
VHS NTSC standard

Video recording system
Rotary head helical scanning FM system

Video heads
Double azimuth four heads

Video signal
NTSC color, EIA standards

Tape Speed
SP: 33.35 mm/s (1 3/8 inches/s)
EP: 11.11 mm/s (7/16 inches/s)
LP: 16.67 mm/s (1 1/16 inches/s),
playback only

Maximum recording/playback time
8 hrs. in EP mode (with T-160 tape)

Fast-forward and rewind time
Approx. 3 min. (with T-120 tape)

Tuner section

Channel coverage
VHF 2 to 13
UHF 14 to 69
CATV A-8 to A-1, A to W, W+1 to W+84

Antenna
75-ohm antenna terminal for VHF/UHF

Inputs and outputs

LINE-1 IN and -2 IN (SLV-760/761/790/960)
VIDEO IN, phono jack (1 each)
Input signal: 1 Vp-p, 75 ohms, unbalanced,
sync negative
AUDIO IN, phono jack (2 each)
Input level: 327 mVrms
Input Impedance: more than 47 kilohms

LINE-1 IN (SLV-L5/L7)

VIDEO IN, phono jack (1)
Input signal: 1 Vp-p, 75 ohms, unbalanced,
sync negative
AUDIO IN, phono jack (1)
(SLV-L5)
Input level: 327 mVrms
Input impedance: more than 47 kilohms
AUDIO IN, phono jack (2 each) (SLV-L7)
Input level: 327 mVrms
Input impedance: more than 47 kilohms
LINE OUT (SLV-760/761/790/960/L5/L7)
VIDEO OUT, phono jack (1)
Output signal: 1 Vp-p, 75 ohms, unbalanced,
sync negative

- Continued on next page -



VHS Hi-Fi VIDEO CASSETTE RECORDER
VCR plus+
SONY®

AUDIO OUT, phonojack (2)
 Standard output: 327 mVrms
 Load impedance: 47 kilohms
 Output impedance: less than 10 kilohms
SYSTEMLINK (CONTROL S IN)
 (SLV-790/960)
 Mini jack (1)
CABLE BOX CONTROL (CONTROL S OUT)
 (SLV-790/960)
 stereo mini jack (plug in power) (1)

Timer section

Clock
 Quarts locked
Timer indication
 12-hour cycle
Timer setting
 8 programs per month (max.)
Power back-up
 Built-in self-charging capacitor
 Back-up duration: up to 3 hours at a time

General

Power requirements
 120 V AC, 60 Hz (SLV-760HF/790/960HF/
 960HFMX/L5MX/L5PA/L7HFMX/
 L7HFPA)
 110 V AC to 240 V AC, 50/60 Hz
 (SLV-760HFPX/960HFPX/960HFCS/
 L5CS/L7HFCS)
Power consumption
 18 W (max.) (SLV-L5)
 24 W (max.) (SLV-760HFPX/960HFCS/
 960HFMX/960HFPX/L7)
 27 W (max.) (SLV-760HF/761HF/790/
 960HFMX)
Operating temperature
 5 °C to 40 °C (41 °F to 104 °F)
Storage temperature
 -20 °C to -60 °C (-4 °F to 140 °F)
Dimensions
 Approx. (17×4³/₈×12¹/₈ inches) including
 projecting parts and controls
 Approx. 430×109×310 mm (w/h/d)
 (SLV-760/761/L5/L7)
 Approx. (17×4³/₈×12¹/₈ inches) including
 projecting parts and controls
 Approx. 430×109×323 mm (w/h/d)
 (SLV-790/960)
 Approx. (17×4³/₈×12³/₈ inches) including
 projecting parts and controls

Mass

Approx. 4.3 kg (9 lb 8 oz)
 (SLV-760/761/L5/L7)
 Approx. 4.5 kg (9 lb oz) (SLV-790/960)

Supplied accessories

Remote commander (1)
 Size AA (R6) batteries (2)
 75-ohm coaxial cable with F-type connectors (1)
 AC power cord (1)
 Audio/video cable (3 phono, 1 mini to 3 phono,
 1 mini) (1) (SLV-790/960)
 Audio/video cable (3 phono to 3 phono) (1)
 (SLV-760/761/L7)
 Cable Mouse (cable box controller) (1) (SLV-
 790/960)
 Plug adaptor (1) (SLV-760HFPX/960HFPX/
 960HFCS/L5CS/L7HFCS)

Design and specifications are subject to change
 without notice.

• **Feature Difference**

SLV- FEATURE	760, 761	790	960	L5	L7
AUDIO SYSTEM	HIFI	HIFI	HIFI	MONO	HIFI
OPERATING SWITCH BLOCK	X	O	O	X	X
FRONT LINE-2IN	O	O	O	X	X
CONTROL S IN/OUT	X	O	O	X	X
DUAL MODE SHUTTLE	O	O	O	O	O
REMOTE COMMANDER RMT-	V184A	V161A	V158C	V186A	V186

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK Δ OR DOTTED LINE WITH MARK Δ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE Δ SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
5. Check the line cord for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
6. Check the B+ voltage to see it is at the values specified.
7. Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)




TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
Feature Difference		2		MA-252 (TUNER) Schematic Diagram (SLV-760/761/L5/L7)	4-44
Service Note		6		DM-47/51, HI-23/36, MF-283/289, LE-12/15 Printed Wiring Boards and Schematic Diagram (SLV-790/960)	4-47
1. GENERAL				DM-48/52, HI-24/37, MF-284/290 Printed Wiring Boards and Schematic Diagram (SLV-760/761/L5/L7)	4-51
Getting Started		1-1		PS-355/356/367/368 Printed Wiring Board and Schematic Diagram	4-55
Basic Operations		1-23			
Additional Operations		1-28			
Editing		1-32			
Additional Information		1-34			
2. DISASSEMBLY			5. REPAIR PARTS LIST		
2-1. Front Panel Assembly, Case and MF-284/290 Board		2-1	5-1. Exploded Views		5-1
2-2. Front Panel Assembly and Case		2-1	5-1-1. Front Panel and Cabinet Assemblies (SLV-760/761/L5/L7)		5-1
2-3. Control switch Block and MF-283/289 Board		2-2	5-1-2. Front Panel and Cabinet Assemblies (SLV-790/960) ..		5-3
2-4. DM-47/48/51/52 Board and PS-355/356/367/368 Board		2-2	5-1-3. Chassis Assembly		5-5
2-5. Cassette Compartment Assembly and HI-23/24/36/37 Board		2-3	5-1-4. Mechanism Chassis Assembly (1)		5-7
2-6. RP-197/198/202/203 Board		2-3	5-1-5. Mechanism Chassis Assembly (2)		5-8
2-7. Mechanism Chassis Assembly		2-4	5-1-6. Mechanism Chassis Assembly (3)		5-9
2-8. MA-251/252 Board		2-4	5-1-7. Mechanism Chassis Assembly (4)		5-10
2-9. Internal Views		2-5	5-2. Electrical Parts List		5-11
2-10. Circuit Boards Location		2-6			
3. BLOCK DIAGRAMS			6. INTERFACE, IC PIN FUNCTION DESCRIPTION		
3-1. Overall Block Diagram		3-1	6-1. System Control-Video Block Interface (MA-251 Board) ..		6-1
3-2. Video Block Diagram		3-5	6-2. System Control-Servo Peripheral Circuit Interface (MA-251 board)		6-2
3-3. Servo, System Control Block Diagram		3-9	6-3. System Control-Mechanism Interface (MA-251 board) ...		6-3
3-4. Mode Control Block Diagram		3-13	6-4. System Control-System control Peripheral circuit Interface (MA-251 board)		6-4
3-5. Tuner Block Diagram		3-17	6-5. System Control-Audio Block Interface (MA-251 board) ...		6-4
3-6. Audio/IO Block Diagram		3-22	6-6. System Control and RF Modulator-Input Selection Block interface (MA-251 board)		6-4
3-7. Power Supply Block Diagram		3-24	6-7. Servo System Control Microprocessor Pin Function (MA-251 board)		6-5
4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS			6-8. Tuner/Timer Mode Control Pin Function (MA-251 board)		6-6
4-1. Frame Schematic Diagram		4-1	6-9. System Control-Video Block Interface (MA-252 board) ...		6-7
4-2. Printed Wiring Boards and Schematic Diagrams		4-4	6-10. System Control-Servo Peripheral Circuit Interface (MA-252 Board)		6-8
RP-197/198/202/203 Printed Wiring Board		4-4	6-11. System Control-Mechanism Interface (MA-252 board) ...		6-9
RP-197/202 Schematic Diagram (SLV-790/960)		4-7	6-12. System Control-System Control Peripheral Circuit Interface (MA-252 Board)		6-10
RP-198/203 Schematic Diagram (SLV-760/761/L5/L7)		4-10	6-13. System Control-HiFi Audio Block Interface (MA-252 Board)		6-10
MA-251, DC-68/77 Printed Wiring Boards (SLV-790/960)		4-13	6-14. System Control-Normal Audio Block Interface (MA-252 Board)		6-11
MA-252, DC-69/78 Printed Wiring Boards (SLV-760/761/L5/L7)		4-16	6-15. System Control and RF Modulator-Input Selection Block Interface (MA-252 Board)		6-11
MA-251 (Video) Schematic Diagram (SLV-790/960)		4-19	6-16. Servo System Control Microprocessor Pin Function (MA-252 Board)		6-12
MA-252 (Video) Schematic Diagram (SLV-760/761/L5/L7)		4-22			
MA-251, DC-68/77 (Servo, System Control) Schematic Diagram (SLV-790/960)		4-25	7. ADJUSTMENTS		
MA-252, DC-69/78 (Servo, System Control) Schematic Diagram (SLV-760/761/L5/L7)		4-30	7-1. Mechanical Adjustments		7-1
MA-251 (Audio/IO) Schematic Diagram (SLV-790/960) ...		4-35	7-2. Electrical Adjustments		7-1
MA-252 (Audio/IO) Schematic Diagram (SLV-760/761/L5/L7)		4-38	2-1. Pre-Adjustment Preparations		7-1
MA-251 (TUNER) Schematic Diagram (SLV-790/960)		4-41	2-1-1. Instruments to be Used		7-1
			2-1-2. Connection		7-1
			2-1-3. Set-up of Adjustment		7-1

2-1-4. Alignment Tape	7-1
2-1-5. Specified I/O Level and Impedance	7-2
2-1-6. Adjusting Sequence	7-2
2-2. Power Supply Check	7-2
2-3. System Control Check	7-3
2-3-1. Clock Check	7-3
2-4. Servo System Adjustment	7-3
2-4-1. Switching Position Adjustment	7-3
2-5. Video System Adjustment	7-4
2-5-1. Recording Y Signal Level Check	7-4
2-5-2. White Clip, Dark Clip Check	7-4
2-5-3. Playback Y signal Level Check	7-4
2-5-4. Recording Chroma Level Check	7-5
2-5-5. Sync. AGC Check	7-5
2-5-6. X'tal Oscillation Frequency Check	7-5
2-5-7. VCO Oscillation Frequency Adjustment	7-5
2-6. Audio System Adjustment	7-6
2-6-1. Hi-Fi Audio System Adjustment	7-6
1. VCO f_0 Adjustment	7-6
2. Deviation Check	7-6
3. BPF f_0 Adjustment	7-6
4. AF Switching Position Adjustment	7-7
2-6-2. Normal Audio System Adjustment	7-7
1. ACE Head Adjustment	7-7
2. E-E Output Level Check	7-7
3. Recording Bias Adjustment	7-7
4. Overall Level Characteristic and Distortion Factor Check	7-8
5. Overall S/N Check	7-8
2-7. Parts Arrangement Diagram for Adjustments	7-10

SERVICE NOTE

1. UPPER DRUM REPLACEMENT (EXCEPT L5)

1-1. Removal of Upper Drum

- 1) Remove the screw ① (BV3 × 8) and take out the ground shaft assembly ②. (See Fig. 1.)
- 2) Completely remove the rotary upper drum board and desolder the soldering indicated by the arrows.
- 3) Remove two screw ③ (PSW3 × 8) and take out the rotary upper drum in the arrow direction ④. (See Fig. 2.)
If it difficult, remove by shaking the rotary upper drum gradually.

Note: If the drum can not be removed, check whether the solders have been removed or not again.

Drum viewed from up




Fig. 1

1-2. Mounting Upper Drum

- 1) When inserting the rotary drum into the lower drum, be careful not to blur the contacting surface with fingerprint or the like.
- 2) Mount the rotary upper drum board so that the screw holes of both upper and lower drums match. (See Fig. 2.)
- 3) If it is difficult, mount the upper drum by shaking it gradually.
Note: Be careful not to damage the head. Make sure that the upper drum is tightly inserted.
- 4) Tighten two screws ③ (PSW3 × 8). (See Fig. 2.)
Note: Temporary tighten two screws. After making sure that upper drum is tightly inserted, tighten the screws.
- 5) Solder points on the board of the rotary upper drum.
- 6) Fix the ground shaft assembly ② using the screw ① (BV3 × 8) so that the protrusion of ground shaft assembly end contacts the center of the drum shaft.
Note: When attaching the ground shaft assembly ②, be careful not to apply force to the spring section of it.












Fig. 2


Step 1**Unpacking**

Check that you have received the following items with the VCR:

- Remote commander 
- Size AA (R6) batteries 
- Audio/video cable (3-phono, 1 mini to 3-phono, 1-mini) 
- Cable Mouse (cable box controller) 
- 75-ohm coaxial cable with F-type connectors 
- AC power cord  (SLV-960HF/960HF MX)
- Plug adaptor (SLV-960HF PX/960HF CS)  (SLV-960HF PX/960HF CS)
- Plug adaptor (SLV-960HF PX/960HF CS) 

Step 2**Setting up the remote commander****Getting Started****Inserting the batteries**

Insert two size AA (R6) batteries by matching the + and - on the batteries to the diagram inside the battery compartment.


**Using the remote commander**

You can use this remote commander to operate this VCR and a Sony TV. The POWER, VOL +/-, CH +/-, TV/VTR, channel number, ENTER, DISPLAY, and AUDIO MONITOR buttons on the remote commander can be used to operate your Sony TV.

To operate Set [TV]/[VTR] to

the VCR [VTR] and point at the remote sensor on the VCR

a Sony TV [TV] and point at the remote sensor on the TV


**Notes**

- With normal use, the batteries should last for approximately three to six months.
- If you do not use the remote commander for an extended period of time, remove the batteries to avoid possible damage from battery-leakage.
- Do not use a new battery with an old one.
- Do not use different types of batteries.

Setting the COMMAND MODE switch

To remotely control the VCR with the commander, set COMMAND MODE on the remote commander to the same position as that on the VCR. Usually set to VTR 3. Change the position as shown below to control other Sony VCRs:

- VTR 1: For Sony Betamax format VCRs
- VTR 2: For Sony 8mm format VCRs
- VTR 3: For Sony VHS format VCRs



continued

**SECTION 1
GENERAL**

This section is extracted from SLV-960HF/960HFCS, 960HFMX, 960HF PX instruction manual.

Step 2: Setting up the remote commander (continued)

Controlling other TVs with the remote commander

The remote commander is preprogrammed to control non-Sony TVs. If your TV is listed in the table below, set the appropriate manufacturer's code number.

- 1 Set **[TV/VTR]** at the top of the remote commander to **[TV]**.
- 2 Hold down **POWER**, and enter your TV's code number(s) using the number buttons. Then release **POWER**.

Now you can use the **POWER**, **VOL +/-**, **CH +/-** and **TV/VTR** buttons to control your TV. You can also use the buttons marked with a dot (•) to control a Sony TV. To control the VCR, reset **[TV/VTR]** to **[VTR]**.

Code numbers of controllable TVs

If more than one code number is listed, try entering them one at a time until you find the one that works with your TV.

Manufacturer	Code number	Manufacturer	Code number	Manufacturer	Code number
Sony	01	KMC	03	RCA	04,10
Akat	04	Magnavox	03,08,12	Sampo	12
AOC	04	Marantz	04,13	Sanyo	11
Centurion	12	MGA/Mitsubishi	04,12,13,17	Scott	12
Coronado	03	NEC	04,12	Sears	07,10,11
Curis-Mathes	12	Panasonic	06,19	Sharp	03,05,18
Daytron	12	Philco	03,04	Sylvania	08,12
Fisher	11	Philips	08	Teknika	03,08,14
General Electric	06,10	Pioneer	16	Toshiba	07
Hitachi	02,03	Portland	03	Wards	03,04,12
J.C.Penny	04,12	Quasar	06,18	Yorx	12
JVC	09	Radio Shack	05,14	Zenith	15

Notes

- If the TV uses a different remote control system from the one programmed to work with the VCR, you cannot control your TV with the remote commander.
- If you enter a new code number, the code number previously entered will be erased.
- When you replace the batteries of the remote commander, the code number automatically resets to 1 (Sony). Reset the appropriate code number.

Step 3

Hookups

Selecting the best hookup option

There are many ways in which your VCR can be hooked up. To hook up your VCR so that it works best for you, first scan through the table below. Then use the accompanying diagrams and procedures on the following pages to set up your VCR.

If you have	Use	Refer to
TV that has audio/video inputs	Audio/video (A/V) hookup, then follow one of the hookups below.	Pages 8 to 9
Cable box that is compatible with the VCR's cable box control feature	Hookup 1	Pages 10 to 12
No cable box or incompatible cable box with only a few scrambled channels	Hookup 2	Pages 13 to 15
Antenna only, no cable TV	Hookup 3	Pages 16 to 18
Incompatible cable box with many scrambled channels	Hookup 4	Pages 19 to 21
DSS* receiver	Hookup 5	Pages 22 to 24
Incompatible cable box with only a few scrambled channels, using an A/B switch	Hookup 6	Pages 25 to 28

After you've completed the connections, follow the instructions for setup. During setup, if you need more details on the procedure described, page numbers are provided where you can find complete, step-by-step instructions.

After you've completed the setup, you're ready to use your VCR. Procedures differ depending on the hookup you used. For an overview, refer to "Quick reference to using the VCR" on the back cover.

Before you get started

- Turn off the power to all equipment.
- Do not connect the AC power cords until all of the connections are completed.
- Be sure you make connections firmly. Loose connections may cause picture distortion.
- If your TV doesn't match any of the examples provided, see your nearest Sony dealer or qualified technician.

* DSS is a registered trademark of DIRECTV, Inc., a unit of Hughes Electronics Corporation.

continued

Audio/Video (A/V) hookup


Pages 8 to 9

If your TV has audio/video (A/V) input jacks, you will get a better picture and sound if you hook up your VCR using these connections. In addition, for a true "home theater" experience, you should connect the audio outputs of your VCR or TV to your stereo system. If your TV doesn't have A/V inputs, see the following pages for antenna or cable hookups.

If your TV has the SystemLink (A/V bus control) function, hook up your VCR using the connection shown on page 9. Your TV will automatically switch to the A/V inputs for your VCR when you play back or operate menu on the VCR.

If you're not planning to use your VCR to record programs, you're finished setting up the VCR after you've made the connections shown on pages 8 and 9. If you want to record off-air or off your cable TV system, complete these connections first, and then go to the following pages for antenna or cable hookups.


A Use this hookup if your TV has stereo jacks



Audio/video cable (supplied)

* Do not connect the miniplugs for this hookup.


B Use this hookup if your TV doesn't have stereo jacks



Note

To play a tape in stereo, you must use the A/V connection.

C Use this hookup if your TV has the SystemLink function




Audio/video cable (supplied)


A/V hookup: VCR setup

After you've connected your TV and completed antenna or cable hookup, use the following procedure to set up the VCR.

Press MENU and select ADVANCED OPTIONS.



Set AUTO ANT SEL to OFF and press EXECUTE.



For details, see page 66.

Caution

Connections between the VCR's VHF/UHF connector and the antenna terminals of the TV receiver should be made only as shown in the following instructions. Failure to do so may result in operation that violates the regulations of the Federal Communications Commission regarding the use and operation of RF devices. Never connect the output of the VCR to an antenna or make simultaneous (parallel) antenna and VCR connections at the antenna terminals of your receiver.

Note to CATV system installer

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

Hookup 1

Pages 10 to 12


Using cable box control

Recommended use

You should use this hookup if you have a cable box, especially if your cable system scrambles all or most channels. This hookup allows the VCR's cable box control feature to control the channel on the cable box, simplifying the recording process. A list of compatible cable boxes is on page 37.


What you can do with this hookup

- Record any channel using the VCR's cable box control feature to select channels on the cable box
- What you can't do**
 - Record with the cable box turned off
 - Record one channel while watching another channel




Hookup 1: VCR setup

- 1 Set the RF UNIT switch to CH 3 or CH 4, whichever channel is not used in your area. If both are used, set the switch to either channel.




For details, see page 72. If you made A/V connections (from page 8), you can skip this step.



- 2 Turn on your cable box.
- 3 Press EASY SET UP on the VCR.


The LANGUAGE menu appears. Change the on-screen display language to French (FRANÇAIS) or Spanish (ESPAÑOL) if desired, and press EXECUTE. For details, see page 29.




- 4 The CLOCK SET menu appears. Select AUTO and press EXECUTE. For details, see page 30.




- 5 The CABLE BOX CONTROL menu appears. Select ON.



- 6 Enter your cable box number and press CURSOR.



- 7 Select your cable box output channel and press EXECUTE.





Normal display

continued

Hookup 1: VCR Plus+ channel setup

- 1 Find the VCR Plus+ Channel Listing in your program guide. For details, see page 45.
- 2 If the channels in the program guide are different from the channels that you actually use on your TV, set the channels that are different as follows. For details, see page 46.
 - 1 Press MENU and select SET VCR Plus+ CHANNELS.
- 2 Enter the program guide channel, then the channel you use on your TV.
 - 3 Press EXECUTE.



Automatic clock setting

Once you've set up the VCR, it automatically sets the clock the first time you turn off the VCR. After that, whenever you turn off the VCR, it checks the time and adjusts the clock, even for Daylight Saving Time. The VCR sets the clock by picking up a time signal provided by some TV channels.

If you want to use the timer to record right away, or if the channels in your area do not carry time signals, set the clock manually. For details, see pages 34–35.

Note
To use the automatic clock setting feature, leave the cable box on.

Hookup 2


No cable box, or incompatible cable box with only a few scrambled channels

Recommended use

Use this hookup if you do not have a cable box. Also use this hookup if your cable company cannot supply a cable box that is compatible with the VCR's cable box control feature, and your cable system scrambles only a few channels.

What you can do with this hookup

- Record any unscrambled channel by selecting the channel on the VCR
- What you can't do**
 - Record scrambled channels that require a cable box



continued

Step 3: Hookups (continued)

Hookup 2: VCR setup

1 Set the RF UNIT switch to CH 3 or CH 4, whichever channel is not used in your area. If both are used, set the switch to either channel.

For details, see page 72.

If you made A/V connections (from page 8), you can skip this step.

2 Press EASY SET UP on the VCR.







1 The LANGUAGE menu appears. Change the on-screen display language to French (FRANÇAIS) or Spanish (ESPAÑOL) if desired, and press EXECUTE. For details, see page 29.

2 The CLOCK SET menu appears. Select AUTO and press EXECUTE. For details, see page 30.

3 The CABLE BOX CONTROL menu appears. Select OFF and press EXECUTE. For details, see page 36.

4 The TUNER PRESET menu appears. Set ANTENNA/CABLE and press EXECUTE. For details, see page 41.

5 The AUTO PRESET starts.




Normal display

Hookup 2: VCR Plus+ channel setup


1 Find the VCR Plus+ Channel Listing in your program guide. For details, see page 45.

2 If the channels in the program guide are different from the channels that you actually use on your TV, set the channels that are different as follows. For details, see page 46.

1 Press MENU and select SET VCR Plus+ CHANNELS.



2 Enter the program guide channel, then the channel you use on your TV.



3 Press EXECUTE.

Program guide channel
Your actual TV channel

Automatic clock setting

Once you've set up the VCR, it automatically sets the clock the first time you turn off the VCR. After that, whenever you turn off the VCR, it checks the time and adjusts the clock, even for Daylight Saving Time. The VCR sets the clock by picking up a time signal provided by some TV channels.

If you want to use the timer to record right away, or if the channels in your area do not carry time signals, set the clock manually. For details, see pages 34-35.


Hookup 3

Pages 16 to 18


Antenna hookup

Make the following connections if you're using an antenna (if you don't have cable TV).

- A** Use this hookup if you're using:
 - VHF/UHF antenna (you get channels 2-13 and channels 14 and higher)
 - UHF-only antenna (you get channels 14 and higher)
 - Separate VHF and UHF antennas



- B** Use this hookup if you're using a VHF-only antenna (you get channels 2-13 only)




If you cannot connect your antenna cable to the VCR directly


If your antenna cable is a flat cable (300-ohm twin lead cable), attach an external antenna connector (not supplied) so you can connect the cable to the VHF/UHF IN connector. If you have separate cables for VHF and UHF antennas, you should use a U/V band mixer (not supplied). For details, see page 72.

Hookup 3: VCR setup


- 1** Set the RF UNIT switch to CH 3 or CH 4, whichever channel is not used in your area. If both are used, set the switch to either channel.



- 2** For details, see page 72. If you made A/V connections (from page 8), you can skip this step.




- 3** Press EASY SET UP on the VCR. The LANGUAGE menu appears. Change the on-screen display language to French (FRANÇAIS) or Spanish (ESPAÑOL) if desired, and press EXECUTE. For details, see page 29.




- 4** The CLOCK SET menu appears. Select AUTO and press EXECUTE. For details, see page 30.




- 5** The CABLE BOX CONTROL menu appears. Select OFF and press EXECUTE. For details, see page 36.



- 6** The TUNER PRESET menu appears. Set ANTENNA/CABLE to ANT and press EXECUTE. For details, see page 41.



- 7** The AUTO PRESET starts.





Normal display

continued
Getting Started

Hookup 3: VCR Plus+ channel setup

- 1 Find the VCR Plus+ Channel Listing in your program guide. For details, see page 45.
- 2 If the channels in the program guide are different from the channels that you actually use on your TV, set the channels that are different as follows. For details, see page 46.



- 1 Press MENU and select SET VCR Plus+ CHANNELS.
- 2 Enter the program guide channel, then the channel you use on your TV.
- 3 Press EXECUTE.

Automatic clock setting

Once you've set up the VCR, it automatically sets the clock the first time you turn off the VCR. After that, whenever you turn off the VCR, it checks the time and adjusts the clock, even for Daylight Saving Time. The VCR sets the clock by picking up a time signal provided by some TV channels.

If you want to use the timer to record right away, or if the channels in your area do not carry time signals, set the clock manually. For details, see pages 34-35.

Incompatible cable box with many scrambled channels

Recommended use


Use this hookup if your cable company cannot supply a cable box that is compatible with the VCR's cable box control feature, and your cable system scrambles all or most channels.

What you can do with this hookup

- Record any channel by selecting the channel on the cable box

What you can't do


- Record with the cable box turned off
- Record one channel while watching another channel
- Select channels directly on the VCR





continued

Step 3: Hookups (continued)


Hookup 4: VCR setup

- 1 Set the RF UNIT switch to CH 3 or CH 4, whichever channel is not used in your area. If both are used, set the switch to either channel.

- 2 For details, see page 72. If you made A/V connections (from page 8), you can skip this step.
- 3 Turn on your cable box.


- 4 Press EASY SET UP on the VCR.

- 5 The LANGUAGE menu appears. Change the on-screen display language to French (FRANÇAIS) or Spanish (ESPAÑOL) if desired, and press EXECUTE. For details, see page 29.




- 6 The CLOCK SET menu appears. Select MANUAL and press EXECUTE. For details, see page 30.





- 7 The CABLE BOX CONTROL menu appears. Select OFF and press EXECUTE. For details, see page 36.



- 8 The TUNER PRESET menu appears. Set ANTENNA/CABLE to ANT and press EXECUTE. For details, see page 41.



- 9 The AUTO PRESET starts.




Getting Started


Hookup 4: VCR Plus+ channel setup

- 1 Find the VCR Plus+ Channel Listing in your program guide. For details, see page 45.
- 2 Enter all the channels you want to record and the cable box output channel (usually 2, 3, or 4). For details, see page 46.

- 3 Press MENU and select SET VCR Plus+ CHANNELS.



- 4 Enter the program guide channel, then the cable box output channel.



- 5 Press EXECUTE.

Program guide channel
 Cable box output channel

Automatic clock setting

To use the Auto Clock Set feature with this hookup, you need to manually select a channel that carries a time signal:

- 1 Tune the cable box to a channel that carries a time signal.
- 2 Select AUTO in the CLOCK SET menu to turn on the Auto Clock Set feature.
- 3 Turn off the VCR. It automatically sets the clock and adjusts for Daylight Saving Time by picking up the time signal.

If you want to use the timer to record right away, or if the channels in your area do not carry time signals, set the clock manually. For details, see pages 34-35.


Note

To use the automatic clock setting feature, leave the cable box on.


SECTION 2 DISASSEMBLY

Note: Follow the disassembly procedure in the numerical order given.


2-1. FRONT PANEL ASSEMBLY, CASE AND MF-284/290 BOARD (760, 761, L5, L7)




2-2. FRONT PANEL ASSEMBLY AND CASE (790, 960)




2-3. CONTROL SWITCH BLOCK AND MF-283/289 BOARD (790, 960)




2-4. DM-47/48/51/52 BOARD AND PS-355, 356, 367, 368 BOARD




2-5. CASSETTE COMPARTMENT ASSEMBLY AND HI-23/24/36/37 BOARD




2-6. RP-197/198/202/203 BOARD



2-7. MECHANISM CHASSIS ASSEMBLY



2-8. MA-251/252 BOARD



2-9. INTERNAL VIEWS

Rotary upper drum assembly
(DZR-45-R) 8-848-576-02
(760, 761, 790, L7)


Rotary upper drum assembly (DZR-51-R)
8-848-594-02 (960)

Drum assembly
(DZH-73B/Q-RP)
8-848-681-11 (L5)

Lower drum assembly (DZL-45B/J-RP)
8-848-658-11 (760, 761, 790, L7)

Lower drum assembly (DZH-51B/J-RP)
8-848-666-11 (960)

FE head
1-500-144-11



M902
Capstan motor (SCV-0801A/Z-NP)
1-698-409-11

Lower drum assembly (DZL-45B/J-RP)
8-848-658-11 (760, 761, 790, L7)

Lower drum assembly (DZH-51B/J-RP)
8-848-666-11 (960)

Drum assembly (DZH-73B/Q-RP)
8-848-681-11


Q261
Tape top sensor
8-729-025-92

Q262
Tape end sensor
8-729-025-92

Rotary switch
1-762-076-11

M903
cam motor assembly
X-3943-883-1

D261
Tape top/end LED
8-719-048-26



2-10. CIRCUIT BOARDS LOCATION

MA-251 (790, 960)

(SERVO/SYSTEM/TUNER/TIMER/MODE CONTROL,
VIDEO, AUDIO, TUNER, LINE IO)

MA-252 (EXCEPT 790, 960)

(SERVO/SYSTEM CONTROL, VIDEO,
AUDIO, TUNER, LINE IO)

RP-197 (790, 960HF/HFMX)

RP-198 (760HF, 761, L5MX/PA,
L7HFMX/HFPA)

RP-202 (960HFCS/HFPX)

RP-203 (760HFPX, L5CS, L7HFCS)
(HEAD AMP)

DRUM ASSEMBLY

DC-68 (790, 960HF/HFMX)

DC-69 (760HF, 761, L5MX/PA, L7HFMX/HFPA)

DC-77 (960HFCS/HFPX)

DC-78 (760HFPX, L5CS, L7HFCS)
(RELAY)

ACE HEAD

CAPSTAN MOTOR

CAM MOTOR
ASSEMBLY

MF-283 (790, 960HF/HFMX)

MF-284 (760HF, 761,
L5MX/PA, L7HFMX/HFPA)

MF-289 (960HFCS/HFPX)

MF-290 (760HFPX, L5CS, L7HFCS)
(POWER SWITCH)

PS-355 (790, 960HF/HFMX)

PS-356 (760HF, 761, L5MX/PA,
L7HFMX/HFPA)

PS-367 (960HFCS/HFPX)

PS-368 (760HFPX, L5CS, L7HFCS)
(POWER SUPPLY)

HI-23 (790, 960HF/HFMX)

HI-24 (760HF, 761, L5MX/PA,
L7HFMX/HFPA)

HI-36 (960HFCS/HFPX)

HI-37 (760HFPX, L5CS, L7HFCS)
(FL DRIVER)

DM-47 (790, 960HF/HFMX)


DM-48 (760HF, 761, L5MX/PA,
L7HFMX/HFPX)

DM-51 (960HFCS/HFPX)

DM-52 (760HFPX, L5CS, L7HFCS)
(MODE CONTROL)


LE-12 (790, 960HF/HFMX)

LE-15 (960HFCS/HFPX)
(LED)





SECTION 3 BLOCK DIAGRAMS

3-1. OVERALL BLOCK DIAGRAM




0/850)
 3. 25. 36. 41)
 0/781/L5/L7)
 2. 30. 38. 44)







3-2. VIDEO BLOCK DIAGRAM




MA-1 (SEE MA-2 (SEE


MA-251 BOARD (1/8) (790/000)
 (SEE PAGE 4-19)
 MA-252 BOARD (1/8) (760/761/LS/L7)
 (SEE PAGE 4-22)








3-3. SERVO SYSTEM CONTROL BLOCK DIAGRAM



4-1. FRAME SCHEMATIC DIAGRAM



**SECTIONN 4
PRINTED WIRING BOARDS
AND
SCHEMATIC DIAGRAMS**

THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS. (In addition to this, the necessary note is printed in each block.)

- For printed wiring boards:**
- : indicates a lead wire mounted on the component side.
 - : indicates a lead wire mounted on the printed side.
 - : Through hole.
 - : Parts mounted on the conductor side.
 - : Pattern on the side which enables seeing.
 - : Pattern of the rear side.*
 - : Circled numbers refer to waveforms.

Caution:
Pattern face side: Parts on the pattern face side seen from the (Conductor Side) the pattern face are indicated.
Parts face side: Parts on the parts face side seen from the (Component Side) the parts face are indicated.

- For schematic diagram:**
- Caution when replacing chip parts.
 - New parts must be attached after removal of chip.
 - Be careful not to heat the minus side of tantalum capacitor, because it is damaged by the heat.
 - All resistors are in ohms, 1/4W (Chip resistors: 1/10W) unless otherwise noted.
 - kΩ: 1000Ω, MΩ: 1000kΩ.
 - All capacitors are in μF unless otherwise noted. pF: μF/50V or less are not indicated except for electrolytics and tantalums.
 - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
 - : nonflammable resistor.
 - : fusible resistor.
 - : panel designation.
 - : internal component.
 - △ : adjustment for repair.*
 - : B + Line.*
 - : B - Line.*
 - : IN/OUT direction of B line (+, -).*
 - Circled numbers refer to waveforms.*
 - Voltages are dc between measurement point.*
 - Readings are taken with a color-bar signal input.*
 - Readings are taken with a digital multimeter (DC10MΩ).*
 - Voltage variations may be noted due to normal production tolerances.*

Note:
The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.
Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.


When indicating parts by reference number, please include the board name.

* : Indicated by the color red.

4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

There are cases that the part isn't mounted in this model is printed on this diagram.

RP-197/198/202/203 (HEAD AMP) PRINTED WIRING BOARD
 - Ref. No.: RP-197/202 Board; 1,000 series, RP-198/203 Board; 2,000 series -



• Signal path


	VIDEO SIGNAL			AUDIO
	CHROMA	Y	Y/CHROMA	SIGNAL
REC	→	→	→	→
PB	→	→	→	→

• Signal path


	REC	REC/PB	PB
Ref. signal	→	→	→

• Waveforms


① IC501 ④ REC 5Vp-p (H)




② IC501 ⑥ PB 480mVp-p (H)




③ IC501 ② REC/PB 4.4Vp-p (2V)




④ IC501 ① REC/PB 5Vp-p (2V)




⑤ IC501 ③ REC 380mV (H)




⑦ IC501 ⑤ PB 400mVp-p (H)



⑥ IC501 ⑦ REC/PB 2.4Vp-p (H)



PR-197/202 (HEAD AMP) (SLV-790/960) SCHEMATIC DIAGRAM
- Ref. No.: RP-197/202 Board; 1,000 series -



SECTION 5

REPAIR PARTS LIST

5-1. EXPLODED VIEWS

NOTE:

- -XX and -X mean standardized parts, so they may have some difference from the original one.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- Color Indication of Appearance Parts
Example:
KNOB, BALANCE (WHITE) ... (RED)




- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list and accessories and packing materials are given in the last of the electrical parts list.

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.


5-1-1. FRONT PANEL AND CABINET ASSEMBLIES (760, 761, L5, L7)



Ref. No.	Part No.	Description	Remark
1	X-3945-621-1	BUTTON ASSY, FUNCTION (TITANIUM) (761)	
1	X-3945-890-1	BUTTON ASSY, FUNCTION (760, L5, L7)	
2	3-966-886-01	RING, SHUTTLE (TITANIUM) (761)	
2	3-966-886-31	RING, SHUTTLE (EXCEPT 761)	
3	3-966-890-01	RING, MODE (760, 761)	
3	3-966-890-41	RING, MODE (L5, L7)	
4	X-3945-518-1	PANEL ASSY, FRONT (760)	
4	X-3945-689-1	PANEL ASSY, FRONT (TITANIUM) (761)	
4	X-3945-699-1	PANEL ASSY, FRONT (L5)	
4	X-3945-715-1	PANEL ASSY, FRONT (L7)	
5	3-966-214-01	DOOR (A), JACK (EXCEPT 761)	
5	3-966-214-11	DOOR (A), JACK (TITANIUM) (761)	
6	3-966-216-01	BUTTON, TV (EXCEPT 761)	
6	3-966-216-11	BUTTON, TV (TITANIUM) (761)	
7	3-953-432-01	SPRING (GE), FL	
8	3-946-611-01	TIP, POWER BUTTON	
9	3-966-213-01	BUTTON, POWER (EXCEPT 761)	
9	3-966-213-11	BUTTON, POWER (TITANIUM) (761)	
10	3-966-858-01	DOOR, CASSETTE (L5)	
10	3-966-858-11	DOOR, CASSETTE (760, L7)	
10	3-966-858-31	DOOR, CASSETTE (TITANIUM) (761)	


Ref. No.	Part No.	Description	Remark
11	3-966-217-01	BUTTON (A), EP (760)	
11	3-966-217-11	BUTTON (A), EP (L5, L7)	
11	3-966-217-21	BUTTON (A), EP (TITANIUM) (761)	
* 12	A-6782-794-A	MF-284 BOARD, COMPLETE (760HF, 761, L5MX/PA, L7HFMX/HFPA)	
* 12	A-6782-795-A	MF-290 BOARD, COMPLETE (760HFPX, L5CS, L7HFCS)	
13	1-776-226-11	CABLE, FLAT (FHM-1) 9P	
16	1-473-487-11	REMOTE COMMANDER (RMT-V186) (L7)	
16	1-473-487-21	REMOTE COMMANDER (RMT-V186) (L5)	
16	1-473-515-11	REMOTE COMMANDER (RMT-V184A) (760, 761)	
17	3-708-817-01	COVER, BATTERY (V184A, V186)	
18	3-957-513-11	RING, SHUTTLE (V184A, V186)	
19	X-3944-446-2	BUTTON ASSY (C) (V184A, V186)	
20	3-710-901-11	SCREW, TAPPING	
* 21	3-966-225-21	CASE, UPPER (760)	
* 21	3-966-225-31	CASE, UPPER (L5, L7)	
* 21	3-966-225-61	CASE, UPPER (TITANIUM) (761)	
* 22	3-966-226-02	PLATE, BOTTOM	
23	3-966-219-01	BUTTON (A), REC (EXCEPT 761)	
23	3-966-219-11	BUTTON (A), REC (TITANIUM) (761)	

5-1-2. FRONT PANEL AND CABINET ASSEMBLIES
(790, 960)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
51	3-966-252-01	BUTTON, PB/STOP		67	3-944-564-01	CLAW, LOCK	
52	3-966-251-01	BASE, BUTTON		68	3-957-388-01	SPRING, COMPRESSION	
53	3-966-253-01	RING, SHUTTLE		69	3-946-611-01	TIP, POWER BUTTON	
54	3-966-807-01	PLATE, INDICATION, SHUTTLE		70	3-966-213-01	BUTTON, POWER	
55	1-473-518-11	SWITCH BLOCK, CONTROL (790)		* 71	3-957-548-01	HOLDER, LOCK CLAW	
55	1-473-518-21	SWITCH BLOCK, CONTROL (960)		72	1-776-227-11	CABLE, FLAT (FMM-13) 7P	
* 56	3-960-077-01	SHAFT (LEFT), FULCRUM		* 73	A-6782-798-A	MF-283 BOARD, COMPLETE (790, 960HF/HFMX)	
57	X-3945-519-1	PANEL ASSY, FRONT (790)		* 73	A-6782-806-A	MF-289 BOARD, COMPLETE (960HFCS/HFPX)	
57	X-3945-717-1	PANEL ASSY, FRONT (960)		74	1-473-483-11	REMOTE COMMANDER (RMT-V158C) (960)	
58	3-966-244-01	DOOR (B), JACK (790)		74	1-473-483-21	REMOTE COMMANDER (RMT-V161A) (790)	
58	3-966-244-11	DOOR (B), JACK (960)		75	X-3944-446-2	BUTTON ASSY (C) (V158C, V161A)	
59	3-966-241-01	PLATE, LIGHT GUIDE, SHUTTLE		76	3-957-513-11	RING, SHUTTLE (V158C, V161A)	
60	3-966-250-01	BASE, SHUTTLE RING		77	3-708-817-01	COVER, BATTERY (V158C, V161A)	
61	3-966-242-01	BUTTON (B), REC		78	3-710-901-11	SCREW, TAPPING	
62	3-966-245-01	BUTTON (B), EP		79	3-966-255-21	CASE, UPPER	
63	4-921-277-41	SCREW (B2 6X8), TAPPING, BIND		* 80	3-966-226-02	PLATE, BOTTOM	
* 64	3-960-556-01	SPRING, DOOR LOCK		* 81	3-960-076-01	PLATE (LEFT), FULCRUM, DOOR	
65	3-960-094-01	DOOR, CASSETTE		82	3-961-745-01	DAMPER, OIL	
66	3-953-432-01	SPRING (GE), FL		83	X-3944-447-1	PLATE (RIGHT) ASSY, FULCRUM, DOOR	


5-1-3. CHASSIS ASSEMBLY



Ref. No.	Part No.	Description	Remark
* 101	A-6794-139-A	LE-12 BOARD, COMPLETE (790, 960HF/HFMX)	
* 101	A-6794-141-A	LE-15 BOARD, COMPLETE (960HFCS/HFPX)	
* 102	3-966-254-01	HOLDER, LE PC BOARD (790, 960)	
103	1-776-228-11	CABLE, FLAT (FDL-1) 10P (790, 960)	
104	3-966-255-01	KNOB (3P), SLIDE (790, 960)	
105	3-966-256-01	KNOB (4P), SLIDE (790, 960)	
* 106	A-6782-790-A	HI-24 BOARD, COMPLETE (760HF, 761)	
* 106	A-6782-797-A	HI-37 BOARD, COMPLETE (L7HFCS)	
* 106	A-6782-801-A	HI-24 BOARD, COMPLETE (L5MX/PA)	
* 106	A-6782-805-A	HI-37 BOARD, COMPLETE (760HFPX)	
* 106	A-6782-807-A	HI-36 BOARD, COMPLETE (960HFCS/HFPX)	
* 106	A-6782-810-A	HI-23 BOARD, COMPLETE (960HF/HFMX)	
* 106	A-6782-813-A	HI-23 BOARD, COMPLETE (790)	
* 106	A-6782-816-A	HI-24 BOARD, COMPLETE (L7HFMX/HFPA)	
* 106	A-6782-822-A	HI-37 BOARD, COMPLETE (L5CS)	
107	1-776-225-11	CABLE, FLAT (FMH-9) 15P	
* 108	A-6794-137-A	DC-68 BOARD, COMPLETE (790, 960HF/HFMX)	
* 108	A-6794-137-A	DC-69 BOARD, COMPLETE (760HF, 761, L5MX/PA, L7HFMX/HFPA)	
* 108	A-6794-137-A	DC-77 BOARD, COMPLETE (960HFCS/HFPX)	
* 108	A-6794-137-A	DC-78 BOARD, COMPLETE (760HFPX, L5CS, L7HFCS)	
* 109	3-966-237-01	HOLDER (ST), MA	
* 110	A-6782-791-A	RP-198 BOARD, COMPLETE (760HF, 761, L7HFMX/HFPA)	
* 110	A-6782-796-A	RP-203 BOARD, COMPLETE (760HFPX, L7HFCS)	
* 110	A-6782-799-A	RP-197 BOARD, COMPLETE (790)	


Ref. No.	Part No.	Description	Remark
* 110	A-6782-808-A	RP-202 BOARD, COMPLETE (960HFCS/HFPX)	
* 110	A-6782-811-A	RP-197 BOARD, COMPLETE (960HF/HFMX)	
* 110	A-6782-821-A	RP-203 BOARD, COMPLETE (L5CS)	
* 110	A-6782-832-A	RP-198 BOARD, COMPLETE (L5MX/PA)	
* 111	A-6782-792-A	MA-252 BOARD, COMPLETE (760, 761)	
* 111	A-6782-800-A	MA-251 BOARD, COMPLETE (790)	
* 111	A-6782-802-A	MA-252 BOARD, COMPLETE (L5)	
* 111	A-6782-815-A	MA-251 BOARD, COMPLETE (960)	
* 111	A-6782-817-A	MA-252 BOARD, COMPLETE (L7)	
* 112	A-6782-789-A	PS-356 BOARD, COMPLETE (760HF, 761, L7HFMX/HFPA)	
* 112	A-6782-804-A	PS-367 BOARD, COMPLETE (960HFCS/HFPX)	
* 112	A-6782-812-A	PS-355 BOARD, COMPLETE (790, 960HF/HFMX)	
* 112	A-6782-819-A	PS-368 BOARD, COMPLETE (760HFPX, L7HFCS)	
* 112	A-6782-820-A	PS-368 BOARD, COMPLETE (L5CS)	
* 112	A-6782-830-A	PS-356 BOARD, COMPLETE (L5MX/PA)	
113	3-966-229-01	INSULATOR (ST) (EXCEPT 761)	
113	3-966-229-31	INSULATOR (ST) (TITANIUM) (761)	
* 114	A-6782-788-A	DM-48 BOARD, COMPLETE (760HF, 761, L5MX/PA, L7HFMX/HFPA)	
* 114	A-6782-803-A	DM-51 BOARD, COMPLETE (960HFCS/HFPX)	
* 114	A-6782-809-A	DM-47 BOARD, COMPLETE (790HF, 960HF/HFMX)	
* 114	A-6782-818-A	DM-52 BOARD, COMPLETE (760HFPX, L5CS, L7HFCS)	
* 115	3-704-386-11	LABEL, TELESONIC (790, 960)	
S410	1-572-662-11	SWITCH, ROTARY (DUAL MODE SHUTTLE)	

5-1-4. MECHANISM CHASSIS ASSEMBLY (1)




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
151	X-3945-348-1	FEH ASSY		165	3-958-491-01	BASE, ACE	
152	1-500-144-11	HEAD, FE		166	3-942-867-01	NUT, AC HEIGHT ADJUSTMENT	
153	X-3944-460-1	ROLLER ASSY, TG2		167	A-6746-072-A	PRESS BLOCK ASSY, PINCH	
154	3-958-421-01	HOLDER, TG8		168	3-958-455-01	SPRING (PINCH), TENSION	
155	X-3944-797-1	TG8 ASSY		169	3-958-487-01	SPRING, (AEC) TORSION COIL	
156	3-962-298-01	BRACKET, TG7 TAPE		170	3-958-152-01	GEAR, TG8	
157	A-6751-496-C	FL BLOCK ASSY		171	3-958-501-01	SCREW, ACE ADJUSTMENT	
158	3-958-467-01	SPRING, TENSION COIL		172	3-958-151-01	GEAR, ELEVATOR	
159	3-958-195-01	SPRING, TORSION		173	3-958-454-01	OPNER, LID	
160	3-960-215-01	PLATE, LIGHT GUIDE, END SENSOR		174	3-958-153-01	GEAR, PRESS	
161	3-960-216-01	PLATE, LIGHT GUIDE, TOP SENSOR		175	3-958-462-01	SPRING (RVS BRAKE), TENSION	
162	A-6736-103-A	ACE BLOCK ASSY		176	X-3943-885-1	ARM ASSY, RVS BRAKE	
163	3-960-439-02	SPRING (ACE), COMPRESSION		177	X-3943-882-1	BRAKE (T) ASSY, SOFT	
164	1-506-485-11	PIN, CONNECTOR 6P		178	3-958-505-01	SPRING (SOFT BRAKE T), TENSION	

5-1-5. MECHANISM CHASSIS ASSEMBLY (2)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
201	X-3943-903-1	TABLE, REEL (T) ASSY		215	X-3945-651-1	ARM (T) ASSY, MAIN BRAKE	
202	X-3943-902-1	TABLE, REEL (S) ASSY		216	3-960-139-01	ARM, NEUTRALITY	
203	3-669-595-00	WASHER (2), STOPPER		217	X-3943-896-1	ARM ASSY, HC	
204	3-958-390-01	SHAFT, PC BOARD		218	3-958-535-01	SPRING, TENSION	
205	3-958-450-01	BRAKE (S), SOFT		219	3-960-138-01	ARM, PENDULUM COMPUSSION	
206	3-958-443-01	SPRING, STRETCH COIL SPRING		220	8-848-576-02	DRUM ASSY, ROTARY UPPER (DZR-45-R)	(760, 761, 790, L7)
207	3-961-441-01	SCREW (3X8)		220	8-848-594-02	DRUM ASSY, ROTARY UPPER (DZR-51-R) (960)	
208	X-3945-650-1	BRAKE (S) ASSY, MAIN		221	8-848-658-11	DRUM ASSY, LOWER (DZL-45B/J-RP)	(760, 761, 790, L7)
209	3-958-391-01	PLATE, LIGHT GUIDE, LED		221	8-848-666-11	DRUM ASSY, LOWER (DZH-51B/J-RP) (960)	
210	3-958-389-01	CATCHER		222	2-643-205-01	SCREW, +PW 3X8	
211	X-3943-899-5	GROUND ASSY, SHAFT		223	8-848-681-11	DRUM ASSY (DZH-73B/Q-RP) (L5)	
212	3-321-393-01	WASHER, STOPPER					
213	X-3944-363-1	ROLLER ASSY, HC					
214	3-958-517-01	SPRING, TENSION COIL					

5-1-6. MECHANISM CHASSIS ASSEMBLY (3)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
251	3-669-595-00	WASHER (2), STOPPER		262	3-958-162-01	GEAR, UPPER/LOWER COMMUNICATION	
252	3-958-161-04	GEAR, CAM		263	3-958-445-01	SPRING, TORSIONCOIL (CAP BRAKE)	
253	3-958-155-01	BEARING, CAM MOTOR		264	X-3943-888-1	BRAKE ASSY, CAP	
254	3-958-160-01	PROPELLOR		265	3-958-361-01	BELT, TIMING	
255	3-958-460-01	SPRING, ONE-WAY		266	X-3943-889-1	ARM ASSY, TENSION VEHICLE	
256	3-958-159-01	WORM		267	3-958-448-01	WHEEL, TENSION	
257	3-959-840-11	RUBBER, JOINT		268	1-762-076-11	SWITCH, ROTARY	
* 258	X-3943-884-1	CHASSIS ASSY, CAM MOTOR		* 269	3-959-763-01	RETAINER	
259	3-701-439-21	WASHER		270	3-958-163-04	SLIDER, MAIN	
260	3-958-157-01	WHEEL, WORM		271	3-965-977-01	RETAINER, CAM GEAR	
261	3-958-156-02	GEAR, FL DRIVING		M903	X-3943-883-1	MOTOR ASSY, CAM	

SECTION 6
INTERFACE, ICPIN FUNCTION DESCRIPTION

6-1. SYSTEM CONTROL - VIDEO BLOCK INTERFACE (MA-251 BOARD IC201)

Signal	Pin No.	I/O	STOP FF/ REW	TAPE THREAD- ING	TAPE UNTREAD- ING	PB	PB • PAUSE	SLOW	×2	CUE	REVIEW	REC	REC • PAUSE
V PB	MA-251 IC201⑤	O	H	H	H	L	L	L	L	L	L	H	H
RF SWP (SW30)	MA-251 IC201①	O	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2
QVD	MA-251 IC201③	O	L	L	L	*3	*4	*4	*4	*4	*4	L	L
SP	MA-251 IC201④	O	*6	*6	*6	*7	*7	*7	*7	*7	*7	*6	*6
SP/EP: HI - IMP	MA-251 IC201⑨	O	*12	*12	*12	*7	*7	*7	*7	*7	*7	*12	*12
V SYNC	MA-251 IC201⑥	I	*8	*8	*8	*8	*8	*8	*8	*8	*8	*8	*8
CTL REC	MA-251 IC201⑦	O	L	L	L	L	L	L	L	L	L	H	L
LINE 1	MA-251 IC201④	O	L	L	L	L	L	L	L	L	L	L	L
JOG	MA-251 IC201⑤	O	L	L	L	L	H	H	H	H	H	L	L
ORC SETTEI	MA-251 IC201⑥	O	L	L	L	L	L	L	L	L	L	*13	*13

- *1. Forward slow mode: "H-Z (2.5 V)" in tape stop, "L" in tape running (approx. 40 msec.).
Forward slow mode: "H-Z (2.5 V)" in tape stop, "H" in tape running SP mode (approx. 40 msec.).
- *2. Synchronized with drum rotation, 30 Hz 50% duty pulse.
- *3. Normally "L", "H" when CTL signal is not generated.
- *4. V period "H" pulse.
- *5. "H" in SP mode, "L" in LP/EP mode.
- *6. Selected by REC mode. SP mode: "L".
Selected by tape recording mode.
- *7. Composite Sync signal (positive).
- *8. "H" when menu screen or blue back screen.
- *9. "H-Z (2.5 V)" in LP/EP mode, "H" in SP mode.
- *10. Selected by REC mode: "H" EP mode.
- *11. Selected by REC mode: "H" LP mode.
- *12. Selected by REC mode: "H" LP mode.
- *13. "H" during APC measurement.

Mode	SP	LP	EP
Signal			
SP ①	L	H	H
LP ②	L	H	L

6-2. SYSTEM CONTROL - SERVO PERIPHERAL CIRCUIT INTERFACE (MA-251 BOARD IC201)

Signal	Pin No.	I/O	STOP	FF	REW	TAPE TH-READ -ING	TAPE UNTH-READ -ING	PB PAUSE	SLOW	CUE	x 2	REVIEW	REC	REC • PAUSE	PB INDEX WRITERS
REC CTL	MA-251 IC201①	O	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	
CAP STOP	MA-251 IC201②	O (O.D)	L	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	L	*3	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	
STEP PLS	MA-251 IC201③	O	L	L	L	L	L	L	*2	L	L	L	L	L	
CTL REC	MA-251 IC201④	O	L	L	L	L	L	L	L	L	L	L	H	L	H
CTL-INDEX	MA-251 IC201⑤	O	L	L	L	L	L	L	L	L	L	L	L	L	H
PB CTL	MA-251 IC201⑥	I	H	*6	*6			H/L	*2	*6	*6	*6	*1	H	
DRM PG	MA-251 IC201⑦	I	*4	*7	*7	*5	*5	*7	*7	*7	*7	*7	*7	*7	
DRM FG	MA-251 IC201⑧	I	*4	*8	*8	*5	*5	*8	*8	*8	*8	*8	*8	*8	
CAP FG	MA-251 IC201⑨	I	H/L	*6	*6	*5	*5	H/L	*9	*6	*6	*6	*6	H/L	
CAP DA	MA-251 IC201⑩	O	*10	*10	*10	*10	*10	*10	*10	*11	*11	*11	*11	*10	
DRM DA	MA-251 IC201⑪	O	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	
CTL STEP	MA-251 IC201⑫	O	L	L	L	L	L	L	*13	L	L	L	L	L	

*1. 30 Hz or 25 Hz pulse.

*2. Pulse at tape running.

*3. Reverse logic pulse of STEP PLS.

*4. "L" when drum rotation stop.

*5. Unstable period pulse.

*6. Pulse of period in proportion to tape speed.

*7. 30 Hz or 25 Hz pulse.

*8. 360 Hz or 300 Hz or 180/150 Hz pulse.

*9. Pulse at tape running.

*10. Approx. 2 msec period "H" or "L" pulse.

*11. Approx. 1.5 msec period "H" or "L" pulse.

*12. Approx. 3 msec period "H" or "L" pulse.

*13. "H" when FWD direction STEP drive.

6-3. SYSTEM CONTROL - MECHANISM INTERFACE (MA-251 BOARD IC201)

Signal	Pin No.	IVO	EJECTED	CASSETTE LOADING	CASSETTE UNLOADING	TAPE THREADING	TAPE UNTHREADING	STOP	FF	REW	PB	PB PAUSE	SLOW	x 2	CUE	REVIEW	REC	REC PAUSE
CAM LOAD	MA-251 IC201①	O	L	H	L	H	L	L	L	L	L	L	L	L	L	L	L	L
CAM UNLOAD	MA-251 IC201②	O	L	L	H	L	H	L	L	L	L	L	L	L	L	L	L	L
CAM 12V	MA-251 IC201③	O		H	L	H	L											
MODE 1	MA-251 IC201④	I	H	L	L	*8	*8	H	H	H	H	H	H	H	H	L	H	H
MODE 2	MA-251 IC201⑤	I	L	L	L	*8	*8	L	L	L	H	H	H	H	H	H	H	H
MODE 3	MA-251 IC201⑥	I	L	L	L	*8	*8	H	H	H	L	H	H	L	L	H	L	H
MODE 4	MA-251 IC201⑦	I	L	H	H	*8	*8	H	L	L	L	L	L	L	L	L	L	L
REC PRF	MA-251 IC201⑧	I	L	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2
TREEL FG	MA-251 IC201⑨	I	H/L	H/L	H/L	H/L	H/L	H/L	*3	*3	*3	H/L	*3	*3	*3	*3	*3	H/L
SREEL FG	MA-251 IC201⑩	I	H/L	H/L	H/L	*3	*3	H/L	*3	*3	*3	H/L	*3	*3	*3	*3	*3	H/L
T/E LED	MA-251 IC201⑪	O (O.D)	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4
CAP TRQ 1	MA-251 IC201⑫	O (O.D)											*8					
CAP TRQ 2	MA-251 IC201⑬	O (O.D)										L	*8					L
CAP TRQ 3	MA-251 IC201⑭	O (O.D)							H	H			*8		H	H		
CAP STOP	MA-251 IC201⑮	O (O.D)	L	L	L	H	H	L	H	H	H	L	*5	H	H	H	H	L
CAP RVS	MA-251 IC201⑯	O	H	L	L	L	H	H/L	L	H	L	L	L/*5	L	L	H	L	L
CAP DA	MA-251 IC201⑰	O																
T SENS	MA-251 IC201⑱	I	*4	*4	*4	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7
S SENS	MA-251 IC201⑲	I	*4	*4	*4	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7

*1. "H" when mechanism mode transition.
 *2. "L" when erasing protection tab is bent, "H" when not bent.
 *3. Pause of period in proportion to reel rotating speed.
 *4. Approx. 2 msec period "H" pulse.
 *5. Pulse at tape running.
 *6. "L" when tape running and CAP RVS is "H".
 *7. Normally "L". 2 msec period "H" pulses when tape top or tape end is detected.
 *8. Uncertainty.

6-4. SYSTEM CONTROL - SYSTEM CONTROL PERIPHERAL CIRCUIT INTERFACE (MA-251 BOARD IC201)

Signal	Pin No.	I/O	I/O level
ASURA RESET	MA-251 IC201	I	Normally "H", "L" when service interruption is detected or restored.
ASURA CS	MA-251 IC201	I	Chip select signal from timer microprocessor. V period "L" pulse.
S IN 0	MA-251 IC201	I	Serial communication data from timer microprocessor. V period "L" pulse.
S OUT 0	MA-251 IC201	O	Serial communication data to timer microprocessor. V period "L" pulse.
S CLK	MA-251 IC201	I	Serial communication clock with timer microprocessor. V period "L" pulse.

6-5. SYSTEM CONTROL - AUDIO BLOCK INTERFACE (MA-251 BOARD IC201)

Signal	Pin No.	I/O	STOP/FF/REW	TAPE LOADING	TAPE UNLOADING	PB	PB PAUSE	SLOW	x 2	CUE	REVIEW	REC	REC PAUSE
AF ENV	MA-251 IC201	I	AF RF envelope signal input terminal for automatic tracking.										
A MUTE	MA-251 IC201 (O.D.)	O	L	L	L	*1	H	H	H	H	H	L	L
NA REC P	MA-251 IC201	O	L	L	L	L	L	L	L	L	L	H	L
AF REC P	MA-251 IC201	O	L	L	L	L	L	L	L	L	L	H	L
AF SWP	MA-251 IC201	O	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1
FULLERS	MA-251 IC201 (O.D.)	O	H	H	H	H	H	H	H	H	H	L	H

*1. 30 Hz 50% duty pulse approx. 5 msec delayed from RF SW P.

*2. Selected by REC mode selector. SP mode: "L".

*3. Selected by tape recording mode. SP mode: "L".

6-6. SYSTEM CONTROL AND RF MODULATOR - INPUT SELECTION BLOCK INTERFACE

Signal	Pin No.	I/O	I/O level
LINE 1	MA-251 IC201	O	*1. Input select control signal.
LINE 2	MA-251 IC201	O	

Input Signal	Tuner	LINE 1	LINE 2
LINE 1	L	H	L
LINE 2	L	L	H

*1.

**6-7. SERVO/SYSTEM CONTROL MICROPROCESSOR PIN FUNCTION
(MA-251 BOARD IC201 CXP-87248A-008Q: SLV-790, 960)**

Pin No.	Pin name	IO	Function
1	RF SWP	O	RF switching pulse output
2	DVD	O	Quasi I/O pulse output
3	CHD ENABLE	O	Quasi I/O voltage level control
4	AF REC P	O	"H" output when Hi-Fi audio REC
5	NTSC	O	"H" PNL "L" when NTSC mode
6	FE ON	O	Flying erase ON/OFF
7	REC CTL	O	REC CTL signal output
8	CAP TR02	O	Capstan current control
9	APC2	O	APC control input terminal 2
10	APC1	O	APC control input terminal 1
11	NA REC P	IO	Normal audio recording mode H: recording mode "L" when SP mode "H" when EPALP mode
12	SPEALP	O	Leading motor rotating direction control
13	CAM LOAD	I	Leading motor rotating direction control
14	CAM UNLOAD	I	Leading motor rotating direction control
15	CLN (REC PRF)	I	Erasing protection lead, cassette IN detection input
16	RENTAL	IO	YNR control
17	NC	O	Not used
18	359 NTSC	I	Tuner audio selection signal H: 3.59 XTAL
20	HT JUDGE	I	4.095 MHz judge input
21	BACK ON	O	Not used
22	PAL 60	O	NTSC PB control signal "H" when NTSC PB on pal TV
23	TV/ATR	O	"L" when VTR mode "H" when TV mode
24	AV CONT	O	ON/OFF control
25	MESOCAM	IO	"L" in AT mode
26	CBC ON	O	Cable box control bit
27	MODE 4	I	Mechanism section CAM encoder input
28	MODE 3	I	Mechanism section CAM encoder input
29	MODE 2	I	Mechanism section CAM encoder input
30	MODE 1	I	Mechanism section CAM encoder input
31	CAM TV	O	CAM motor reference voltage
32	VE LED	O	VE LED output
33	CAP TR02	O	Capstan current control signal 2 L: FF/REW to STOP
34	CAP TR01	O	Capstan current control signal 1 L: SLOW speed down
35	CAP STOP	O	Capstan STOP signal output
36	FULLERS	O	Full erase control
37	NC	O	Not used
38	NC	O	Not used
39	AP	I	Fixed to L
40	ASURA RESET	I	System reset input
41	VSS	-	GND
42	XTAL	-	System clock 16 MHz
43	EXTRAL	-	System clock 16 MHz
44	ASURA CS	I	S/S microcomputer chip select signal
45	S IN 0	I	Serial communication signal
46	S OUT 0	O	Serial communication signal
47	SCLK	O	Serial communication signal
48	MICOL ON	O	?
49	F MONO	O	Tuner Audio Select
50	EDIT	O	EDIT control

Pin No.	Pin name	IO	Function
51	LINE 3 CONT	O	Input selection control signal 3
52	AVSS	-	UNSW GND
53	AVREF	-	AD port reference input UNSW 5V
54	AVCO	-	UNSW 5V
55	APC ERROR	I	APC error input
56	NTPB SW	I	NTSC PB switch
57	DESTE DEW	I	DEW sensor input Not used
58	VA ADJ	I	ADJ mode ON: SWP Adj 2.5V: HRT Adj
59	AF SW	I	Hi-Fi audio playback signal envelope
60	RF SW	I	Video playback signal envelope
61	T SENS	I	Tape up and sensor input
62	S SENS	I	Supply end sensor input
63	S REEL FG	I	S side reel FG input
64	T REEL FG	I	T side reel FG input
65	VDD	I	5V
66	V SYNC	I	Composite sync input
67	PB CTL	I	Playback CTL input
68	DRM PG	I	Drum PG input
69	DRM FG	I	Drum FG input
70	CAP FG	I	Capstan FG input
71	POWER SAVE CONT	O	Power save control signal output
72	CAP RVS	O	Capstan reverse control H when Reverse
73	CAP DA	O	Capstan error D/A output
74	DRUM DA	O	Drum FG input
75	CTL RED	O	"H" CTL write
76	CTL STEP	O	CTL emp. STEP operation control
77	VDD	I	5V
78	VDD	O	5V
79	CTL INDEX	O	CTL INDEX signal input
80	S01	IO	Signal for serial communication
81	S02	IO	Signal for serial communication
82	LINE 2 CONT	I	Input selection control signal 2
83	LINE 1 CONT	O	Input selection control signal
84	APC PWM	O	PWM output for APC
85	NC	I	Not used
86	NC	-	Not used
87	NC	-	Not used
88	VSS	-	GND
89	VDD	-	5V
90	NC	-	Not used
91	ORC SETTEI	O	H when ORC measurement
92	A MUTE	O	"H" when audio mute
93	SP	O	Tape speed Select
94	POWER CONT 2	O	Power control signal 2
95	NA PB	O	Audio output control signal H when normal audio playback
96	AF REC	O	"H" output when Hi-Fi audio REC
97	JOB	O	"H" when this play mode
98	V PB	O	Video system playback mode "L" when playback
99	STEP PLS	O	Step pulse H when Capstan stop driving
100	AF SWP	O	AF switching pulse output

6-8. TUNER/TIMER MODE CONTROL PIN FUNCTION (MA-251 BOARD IC151 CXP82948-002Q)

Pin No.	Pin Name	IO	Function
1	EDS DV1	1	Line 21H output pulse. Pulse signal synchronized with line 21 of input video signal.
2	POWER FAIL	1	Power failure detect signal input.
3	H DET	1	Video signal detect signal input
4	SIRCS IN	1	SIRCS signal input
5	EEP BUSY	1	EEP Busy signal input
6	SIRCS OUT	0	SIRCS signal output
7	BUZZER	0	Buzzer output
8	STEREO	0	Tuner audio mode input (stereo)
9	EEP RET	0	EEP ROM test signal output (beep)
10	SOCK0	0	Clock for serial communication
11	S0	1	Serial data input
12	SO0	0	Serial data output
13	EEP CS	0	EEP ROM chip select signal output
14	LANC IN	1	LANC input
15	LANCE OUT	0	LANC output
16	A00	1	Key reading A/D input
17	A01	1	Key reading A/D input
18	A02	1	Key reading A/D input
19	A03	1	Key reading A/D input
20	A04	1	Key reading A/D input
21	A05	1	Key reading A/D input
22	A06	1	Key reading A/D input
23	A07	1	Key reading A/D input
24	A000	-	UNSW SV
25	AV REF	-	AD port reference input UNSW SV
26	SCLO	0	PC BUS (clock)
27	CG CS	0	Character generator chip select signal
28	SDA0	0	PC BUS (data)
29	LED CS	0	LED driver chip select signal
30	AVSS	-	UNSW GND
31	EXTAL	-	System clock Not used
32	XTAL	-	GND
33	VSS	-	GND
34	RST	1	Reset signal in
35	PLL CLK	0	Tuner clock signal
36	PLL DATA	0	Tuner data signal
37	PLL ENABLE	0	Tuner enable signal
38	MANVSRP	0	Normal audio MANVSRP select control
39	SAP	1	MANVSRP logic input
40	EDS CS	0	EDS microcomputer chip select

Pin No.	Pin Name	IO	Function
41	TA MUTE	0	Tuner audio mode control signal
42	AUTO RESET	0	T1' during auto preset
43	VFDP	-	-30V
44-42	SEG 1-19	0	LCD segment output
53	N.C.	-	Not used
54	N.C.	-	Not used
55	N.C.	-	Not used
56-71	GRID 0-1	0	LCD grid output
72	VDD	-	UNSW SV
73	TX	-	Connected to oscillator for clock
74	TEX	-	Connected to -5V
75	NCVPP	-	Connected to -5V
76	ASUPA CS	0	S/S microcomputer chip select
77	SYS RESET	0	System reset signal output
78	POWER CONT 1	0	Power supply control signal output
79	POWER CONT 2	0	Power supply control signal output for EDS
80	CG V	1	Vertical sync signal input

6-9. SYSTEM CONTROL - VIDEO BLOCK INTERFACE (MA-252 BOARD IC201)

Signal	Pin No.	VO	STOP FF/ REW	TAPE THREAD- ING	TAPE UNTHREAD- ING	PB	PB • PAUSE	SLOW	× 2	CUE	REVIEW	REC	REC • PAUSE
V PB	MA-252 IC201⑤	O	H	H	H	L	L	L	L	L	L	H	H
RF SWP (SW30)	MA-252 IC201①	O	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2
QVD	MA-252 IC201②	O	L	L	L	*3	*4	*4	*4	*4	*4	L	L
SP	MA-252 IC201③	O	*6	*6	*6	*7	*7	*7	*7	*7	*7	*6	*6
SP/EP	MA-252 IC201④	O	*12	*12	*12	*7	*7	*7	*7	*7	*7	*12	*12
V SYNC	MA-252 IC201⑥	I	*9	*8	*8	*8	*8	*8	*8	*8	*8	*8	*8
CTL REC	MA-252 IC201⑦	O	L	L	L	L	L	L	L	L	L	H	L
LINE 1	MA-252 IC201⑧	O	L	L	L	L	L	L	L	L	L	L	L
JOG	MA-252 IC201⑨	O	L	L	L	L	H	H	H	H	H	L	L
ORC SETTEI	MA-252 IC201⑩	O	L	L	L	L	L	L	L	L	L	*13	*13

*1. Forward slow mode: "H-Z (2.5 V)" in tape stop, "L" in tape running (approx. 40 msec.).

Forward slow mode: "H-Z (2.5 V)" in tape stop, "H" in tape running SP mode (approx. 40 msec.).

"L" in tape running EP mode (approx. 40 msec.).

*2. Synchronized with drum rotation, 30 Hz 50% duty pulse.

*3. Normally "L", "H" when CTL signal is not generated.

*4. V period "H" pulse.

*5. "H" in SP mode, "L" in LP/EP mode.

*6. Selected by REC mode. SP mode: "L"

*7. Selected by tape recording mode.

*8. Composite Sync signal (positive).

*9. "H" when menu screen or blue back screen.

*10. "H-Z (2.5 V)" in LP/EP mode, "H" in SP mode.

*11. Selected by REC mode: "H" EP mode.

*12. Selected by REC mode: "H" LP mode.

*13. "H" during APC measurement.

Mode	SP	LP	EP
Signal			
SP ①	L	H	H
LP ②	L	H	L

6-10. SYSTEM CONTROL - SERVO PERIPHERAL CIRCUIT INTERFACE (MA-252 BOARD IC201)

Signal	Pin No.	VO	STOP	FF	REW	TAPE THREAD -ING	TAPE UNTHREAD -ING	PB	PB * PAUSE	SLOW	CUE	x 2	REVIEW	REC	REC * PAUSE	PB INDEX WRITERS
REC CTL	MA-252 IC201①	O	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	
CAP STOP	MA-252 IC201②	O (O.D)	L	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	L	*3	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	
STEP PLS	MA-252 IC201③	O	L	L	L	L	L	L	L	*2	L	L	L	L	L	
CTL REC	MA-252 IC201④	O	L	L	L	L	L	L	L	L	L	L	L	H	L	H
CTL-INDEX	MA-252 IC201⑤	O	L	L	L	L	L	L	L	L	L	L	L	L	L	H
PB CTL	MA-252 IC201⑥	I	H	*6	*6			*1	H/L	*2	*6	*6	*6	*1	H	
DRM PG	MA-252 IC201⑦	I	*4	*7	*7	*5	*5	*7	*7	*7	*7	*7	*7	*7	*7	
DRM FG	MA-252 IC201⑧	I	*4	*8	*8	*5	*5	*8	*8	*8	*8	*8	*8	*8	*8	
CAP FG	MA-252 IC201⑨	I	H/L	*6	*6	*5	*5	*6	H/L	*9	*6	*6	*6	*6	H/L	
CAP DA	MA-252 IC201⑩	O	*10	*10	*10	*10	*10	*11	*10	*10	*11	*11	*11	*11	*10	
DRM DA	MA-252 IC201⑪	O	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	
CTL STEP	MA-252 IC201⑫	O	L	L	L	L	L	L	L	*13	L	L	L	L	L	

- *1. 30 Hz or 25 Hz pulse.
- *2. Pulse at tape running.
- *3. Reverse logic pulse of STEP PLS.
- *4. "L" when drum rotation stop.
- *5. Unstable period pulse.
- *6. Pulse of period in proportion to tape speed.
- *7. 30 Hz or 25 Hz pulse.
- *8. 390 Hz or 300 Hz or 180/150 Hz pulse.
- *9. Pulse at tape running.
- *10. Approx. 2 msec period "H" or "L" pulse.
- *11. Approx. 1.5 msec period "H" or "L" pulse.
- *12. Approx. 3 msec period "H" or "L" pulse.
- *13. "H" when FWD direction STEP drive.

6-11. SYSTEM CONTROL - MECHANISM INTERFACE (MA-252 BOARD IC201)

Signal	Pin No.	IO	EJECTED	CASSETTE LOADING	CASSETTE UNLOADING	TEPE THREAD-ING	TAPE UNTHREAD-ING	STOP	FF	REW	PB	PB PAUSE	SLOW	x2	CUE	REVIEW	REC	REC PAUSE
CAM LOAD	MA-252 IC201⑬	O	L	H	L	H	L	L	L	L	L	L	L	L	L	L	L	L
CAM UNLOAD	MA-252 IC201⑭	O	L	L	H	L	H	L	L	L	L	L	L	L	L	L	L	L
CAM 12V	MA-252 IC201⑮	O		H	L	H	L											
MODE 1	MA-252 IC201⑯	I	H	L	L	*8	*8	H	H	H	H	H	H	H	H	L	H	H
MODE 2	MA-252 IC201⑰	I	L	L	L	*8	*8	L	L	L	H	H	H	H	H	H	H	H
MODE 3	MA-252 IC201⑱	I	L	L	L	*8	*8	H	H	H	L	H	H	L	L	L	L	H
MODE 4	MA-252 IC201⑲	I	L	H	H	*8	*8	H	L	L	L	L	L	L	L	L	L	L
C IN (REC PRF)	MA-252 IC201⑳	I	L	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2
TREEL FG	MA-252 IC201㉑	I	H/L	H/L	H/L	H/L	H/L	H/L	*3	*3	*3	H/L	*3	*3	*3	*3	*3	H/L
SREEL FG	MA-252 IC201㉒	I	H/L	H/L	H/L	*3	*3	H/L	*3	*3	*3	H/L	*3	*3	*3	*3	*3	H/L
T/IE LED	MA-252 IC201㉓	O	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4
CAP TRQ 1	MA-252 IC201㉔	O											*8					
CAP TRQ 2	MA-252 IC201㉕	O											*8					L
CAP TRQ 3	MA-252 IC201㉖	O							H	H			*8		H	H		
CAP STOP	MA-252 IC201㉗	O	L	L	L	H	H	L	H	H	H	L	*5	H	H	H	H	L
CAP RVS	MA-252 IC201㉘	O	H			L	H	H/L	L	H	L	L	L/*5	L	H	L	L	L
CAP DA	MA-252 IC201㉙	O																
T SENS	MA-252 IC201㉚	I	*4	*4	*4	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7
S SENS	MA-252 IC201㉛	I	*4	*4	*4	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7

*1. "H" when mechanism mode transition.
 *2. "L" when erasing protection tab is bent. "H" when not bent.
 *3. Pause of period in proportion to reel rotating speed.
 *4. Approx. 2 msec period "H" pulse.
 *5. Pulse at tape running.
 *6. "L" when tape running and CAP RVS is "H".
 *7. Normally "L". 2 msec period "H" pulse when tape top or tape end is detected.
 *8. Uncertainty.

SECTION 7 ADJUSTMENTS

During the adjustment, see the Parts Arrangement Diagram for Adjustment on page 7-10.

7-1. MECHANICAL ADJUSTMENTS

Refer to the SERVICE MANUAL of VHS MECHANICAL ADJUSTMENT IV.

7-2. ELECTRICAL ADJUSTMENTS

2-1. PRE-ADJUSTMENT PREPARATIONS

Necessary items and indications for total adjustment of electric circuit of this machine will be described in this chapter.

2-1-1. Instruments to be Used.

- 1) Color TV
- 2) Oscilloscope for 2 phenomena, band more than 30 MHz, deley mode, as provided.
- 3) Frequency counter (min. 8 digits)
- 4) NTSC pattern generator
- 5) Digital voltmeter
- 6) Audio level meter
- 7) Audio generator
- 8) Modulation Analyzer
- 9) Distortion factor meter
- 10) Attenuator
- 11) Alignmeter tape
Part Code: 8-192-605-32 (KRV-51N2)
- 13) Extension cable (13P)
Part code: J-6090-054-A
RP-197/198/202/203 (CN501) ↔ DRUM

2-1-2. Connection

Unless otherwise specified, connect and adjust the measuring instruments as shown in the following diagram.




Fig. 7-2-1

2-1-3. Set-up of Adjustment

In this adjustment, NTSC pattern generator is connected with LINE input signal terminal. When check to tuner, connected AERIAL terminal. Check that the amplitudes of video signal NTSC signal, of picture portions, and of burst signals are flat at approximately 0.3, 0.7 and 0.3 V, respectively, and that the level ratio of the burst signal and "red" signal are 0.30: 0.66. Fig. 7-2-2. shows video signals (color bars) used in adjusting the video section.




Fig. 7-2-2.

2-1-4. Alignment Tape

[Alignment Tape (KRV-51N2)]

	Mode	Time	Video signal	Audio signal (HiFi/Normal)
1	SP	Seven minutes	Color bar	400Hz
2		Three minutes	Monoscope	400Hz
3	EP	Seven minutes	Color bar	400Hz
4		Three minutes	Monoscope	—


2-1-5. Specified I/O Level and Impedance

Input/output terminal

Video inputs	LINE IN : phono jack 1 Vp-p, 75Ω, unbalanced, sync negative
Audio inputs	LINE IN : phono jacks 47 kΩ, -7.5 dBs (0 dBs = 0.775 Vrms) More than 10 kΩ+, -4 dBs
Video outputs	LINE OUT : phono jack 1 Vp-p, 75Ω, unbalanced, sync negative
Audio outputs	LINE OUT : phono jacks -7.5 dBs at load impedance 47kΩ Output impedance : less than 10Ω

2-1-6. Adjusting Sequence

Make the electrical adjustment in the following sequence.



2-2. POWER SUPPLY CHECK (PS-355/356/367/368 BOARD)

Mode	E-E
Measuring Instrument	Digital voltmeter
+F, -F check	
Measurement Point	Pin ④ (+), ①(-) of CN101
Specified Value	4.3±1Vdc
-30V check	
Measurement Point	Pin ② of , CN101
Specified Value	-30±3Vdc
-8V check	
Measurement Point	Pin ⑤ of CN101
Specified Value	13.5±2Vdc
D6V check	
Measurement Point	Pin ⑥ of CN101
Specified Value	5.9±0.5V
SW12V	
Measurement Point	Pin ⑧ of CN101
Specified Value	12±1Vdc
MTR12V check	
Measurement Point	Pin ⑫ of CN101
Specified Value	12±0.5Vdc
13 V check	
Measurement Point	Pin ⑭ of CN101
Specified Value	13±1Vdc
+38V check	
Measurement Point	Pin ⑯ of CN101
Specified Value	38.0±3Vdc
SW5 V check	
Measurement Point	Pin ⑰ of CN101
Specified Value	5 ±0.5 Vdc

Checking Method:

- 1) Confirm that each voltage meets its specified value.

2-3. SYSTEM CONTROL CHECK

2-3-1. Clock Check (MA-251/252)

Purpose:

Adjust to improve the clock precision. When it is out of order, errors gradually increases.

Measurement point	Pin ⑦ of IC151 : MA-251 Board Pin ⑧ of IC201 : MA-252 Board
Measurement Equipment	Frequency counter (Interval counter mode)
Specified Value	0.1249995 ± 0.0000005 sec

Confirmation Method:

- 1) Connect to the GND from IC151 pin ⑧ through a resistor 22k Ω (1-249-489-00): MA-251 board
- 2) Connect Pin ④ of IC401 to ground. (The set goes to adjusting mode.): MA-252 Board
- 3) Connect the frequency counter as shown below.
- 4) Confirm that the oscillation frequency is the specified value.




Fig. 7-2-3.

2-4. SERVO SYSTEM Adjustment

2-4-1. Switching Position Adjustment (MA-251/252 Board)

Purpose:

Adjust the interval between A ch and B ch of tape playback output. Improve the interchangeability with other tapes and sets.

When it is out of order, the interval appears on the screen, the screen is disturbed.

Mode	PB
Signal	Alignment tape SP mode color bar
Measurement Point	CH1: VIDEO LINE OUT CH2: Pin ③ of CN502 (RP-197/198/202/203 board) (RF SWP)
Measuring Instrument	Oscilloscope
Specified Value	$6.5 \pm 0.5H$ ($410 \pm 32\mu\text{sec}$)

Adjusting Method:

- 1) Connect IC201 pin ⑧ to the GND for about 1 second to activate the RF switching position adjustment mode.
- 2) Using the channel + and - buttons, adjust to $410 \pm 32\mu\text{sec}$ ($6.5 \pm 0.5H$).




Fig. 7-2-4.

2-5. VIDEO SYSTEM ADJUSTMENT

Adjust the video system in the following sequence as a rule. The color video signal supplied from the pattern generator is used as a video input signal for video system adjustment in the recording mode. Make sure that sync. and color burst signals meet requirements specified at set up of adjustment shown in Fig. 7-2-1.

[Adjustment Sequence]

- 2-5-1. Recording Y Signal Level Check
- 2-5-2. White Clip, Dark Clip Check
- 2-5-3. Playback Y Signal Level Check
- 2-5-4. Recording Chroma Level Check
- 2-5-5. Sync. AGC Check
- 2-5-6. X'tal Oscillation Frequency Check
- 2-5-7. VCO Oscillation Frequency Adjustment

2-5-1. Recording Y Signal Level Check (MA-251/252 Board)

Purpose:

Check the brightness signal level after passing through the V/C separating circuit.

Mode	E-E
Signal	Color bar
Measurement point	Emitter of Q352
Measurement equipment	Oscilloscope
Specified value	$950 \pm 100 \text{mVp-p}$

Confirmation Method:

- 1) Confirm that the record Y level is $950 \pm 100 \text{mVp-p}$.




Fig. 7-2-5.

2-5-2. White Clip, Dark Clip Check (MA-251/252 Board)

Purpose:

Confirm that no overshoot is generated by the pre-emphasis circuit. If shifted, the signals are overmodulated, thus causing a noise in the images.

Mode	E-E
Signal	Color bar
Measurement point	Pin 7 of IC302
Measurement equipment	Oscilloscope
Specified value	White clip: $190 \pm 15\%$ Dark clip: $52 \pm 10\%$

Confirmation Method:

- 1) Confirm that the white clip is $190 \pm 15\%$, on condition that the level between white and sync. is 100%.
- 2) Confirm that the dark clip is $52 \pm 10\%$, on condition that the level between white and sync. is 100%




Fig. 7-2-6.

2-5-3. Playback Y Signal Level Check (MA-251/252 Board)

Purpose:

Confirm that the playback Y signal level is correct.

Mode	PB
Signal	Alignment tape SP color bar
Measurement point	VIDEO LINE OUT
Measurement equipment	Oscilloscope
Specified value	$2.05 \pm 0.18 \text{Vp-p}$

Note: Make this adjustment with the EDIT switch turned off.
(MA-251 Board)

Confirmation Method:

- 1) Confirm that the play Y level is $2.05 \pm 0.18 \text{Vp-p}$.




Fig. 7-2-7.

**2-5-4. Recording Chroma Level Check
(MA-251/252 Board)**

Purpose:

Check the chroma signal level after passing through the Y/C separating circuit.

If shifted, the image is roughened and another color may appear on the edges.

Mode	E-E
Signal	Color bar
Measurement point	Pin ② of IC302
Measurement equipment	Oscilloscope
Specified value	190±30mVp-p

Confirmation Method:

- 1) Confirm that the record chroma level is 190±30mVp-p.



Fig. 7-2-8.

**2-5-5. Sync. AGC Check
(MA-251/252 Board)**

Purpose:

Confirm that the video level is correct.

Mode	E-E
Signal	Color bar
Measurement point	VIDEO LINE OUT
Measurement equipment	Oscilloscope
Specified value	2.05±0.14Vp-p

Note: Video output terminal must be terminated at 75Ω.

Confirmation Method:

- 1) Confirm that the sync. AGC level is 2.05±0.14Vp-p.




Fig. 7-2-9.

**2-5-6. X'tal Oscillation Frequency Check
(MA-251/252)**

Purpose:

Confirm that the fsc is correct.

Mode	PB
Signal	Alignment tape SP color bar
Measurement point	Pin ② of IC302
Measurement equipment	Frequency counter, Oscilloscope
Specified value	3,579,545±82Hz

Note: connect the frequency counter through a probe of high input impedance (about 10MΩ) and low capacity (10pF or less).

Confirmation Method:

- 1) Confirm that the frequency is 3,579,545±82Hz
- 2) Confirm that the amplitude is 450±200mVp-p.




Fig. 7-2-10.

**2-5-7. VCO Oscillation Frequency Adjustment
(MA-252 Board)**

Purpose:

Adjust to set the character position on the screen.

Mode	E-E
Signal	Color bar
Measurement point	Pin ② of IC401
Measuring Instrument	Oscilloscope (DC mode)
Adjusting Element	CT401
Specified value	+2.75±0.05 V



Fig. 7-2-11.

2-6. AUDIO SYSTEM ADJUSTMENTS

Adjust both Lch and Rch.

[Connection]




Fig. 7-2-12

2-6-1. Hi-Fi Audio System Adjustment

Set switches and knobs to the following positions to make adjustment unless otherwise specified.

INPUT SELECT switch LINE
AUDIO MONITOR STEREO

[Adjusting Sequence]

1. VCO f_0 adjustment
2. Deviation check
3. BPF f_0 adjustment
4. AF switching position

1. VCO f_0 Adjustment (MA-251/252 Board)

Purpose:

Adjust to have interchangeability in HiFi audio.
When it is out of order, the sound is distorted.

Mode	REC
Signal	No signal
Measuring Instrument	Frequency counter
1.3 MHz Adjustment	
Measurement Point	Pin ① of CN501 Auto tracking ON (Remote commander)
Adjusting Element	RV521 (R CH)
Specified Value	1.3 MHz \pm 1 kHz
1.7 MHz Adjustment	
Measurement Point	Pin ① of CN501 Auto tracking OFF (Remote commander)
Adjusting Element	RV531 (R CH)
Specified Value	1.7 MHz \pm 1 kHz

Note: Connect the frequency counter through a probe of high input impedance (more than 1 M Ω) and low capacity (10 pF or less).

Connection:

Connect pin ② and ③ of CN881 with a jumper wire.

Adjusting Method:

- 1) Connect the frequency counter to pin ① of CN501.
- 2) Adjust each volume so that each frequency meets its specified value.

2. Deviation Check (MA-251/252 Board)

Purpose:

Set the HiFi audio signal level to specified value.
Adjust to have interchangeability with other tapes and sets.
When it is out of order, the volume of sound is different on playback.

Mode	REC
Signal	Pin ② (Lch), ① (Rch) of IC501 400Hz -7.5 dBs (920m Vp-p)
Measurement Point	pin ① of CN501 Lch: Auto tracking ON (Remote commander) Rch: Auto tracking OFF (Remote commander)
Measurement Equipment	Modulation analyzer
Specified Value	50 \pm 5kHz

Connection:

Connect pin ② and ③ of CN881 with a jumper wire.

3. BPF f_0 Adjustment (MA-251/252 Board)

Purpose:

Adjust to separate carrier component precisely and to operate normally the filter for cutting video signal.
When it is out of order, the sound is distorted.

Mode	PB
Signal	1.505 MHz Input 200 mVp-p: Pin ③ of CN501
Measurement point	Pin ① of CN501
Measuring Instrument	Oscilloscope
Adjusting Element	RV541

Note: Take a trigger from AF SWP (Pin ⑥ of CN501).

Connection:

- 1) Feed 1.505 MHz, 200 mVp-p sine wave to Pin ③ of CN501.






Fig. 7-2-13.

Adjusting method:

- 1) In the play mode, turn off the auto tracking from the remote controller.
- 2) Adjust RV541 so that the amplitudes of A and B are on the same level ($\pm 2\text{mVp-p}$).



Disordered condition



Adjusted condition

Fig. 7-2-14

4. AF Switching Position Adjustment (MA-251/252 Board)

Purpose:

Adjust the interval between A CH and B CH of tape playback output. Improve the interchangeability with other tapes and sets. When it is out of order, noisy sound is increased and big noise is heard.

Mode	PB
Signal	Alignment tape SP mode color bar
Measurement point	CH1: Pin ③ of CN502 (RP-197/198/201/202 Board) CH2: Pin ① of CN707 (RP-197/198/201/202 Board)
Measuring Instrument	Oscilloscope
Specified Value	Fig. 7-2-15

Adjusting method:

- 1) Connect IC201 pin 58 to the GND for about 1 second to activate the RF switching position adjustment mode.
- 2) Press the record button to activate the AF switching position adjustment mode.
- 3) Using the channels + and - buttons, minimize a chipped portion. At this time, confirm that a noisy sound is not heard.




Fig. 7-2-15.

2-6-2. Normal Audio System Adjustment

- Make adjustment in the SP mode, unless otherwise specified.
- Use a normal VHS cassette for an adjustment tape.
- Set AUDIO MONITOR to normal.

[Adjustment Sequence]

1. ACE Head Adjustment
2. E-E Output Level Check
3. Recording Bias Adjustment
4. Overall Level Characteristic and Distortion Factor Check
5. Overall S/N Check

1. ACE Head Adjustment

Refer to the service manual of VHS MECHANICAL ADJUSTMENT IV.

2. E-E Output Level Check

Purpose:

Confirm that the output level against the reference input is within the specification.

Mode	E-E
Signal	L, R: 400Hz, -7.5 dBs
Measurement point	Audio output terminal
Measurement equipment	Audio level meter
Specified value	-7.5 \pm 2dBs

Confirmation Method:

- 1) Simultaneously input a signal of 400Hz, -7.5dBs to both L and R channels of Audio Line Input.
- 2) Confirm that the audio output level is -7.5 \pm 2dBs.

3. Recording Bias Check (MA-251/252 Board)

Purpose:

Confirm that the frequency characteristic is within the specification.

Mode	REC and PB (SP mode)
Signal	400Hz, -27.5 dBs 7kHz, -27.5 dBs
Measurement point	Audio output terminal
Measurement equipment	Audio level meter
Specified value	0 \pm 3dB

Note: Tape path adjustment must have been completed.

Confirmation Method:

- 1) Supply a signal of 400 Hz, -27.5 dBs to both L and R channels of Audio Line Input.
- 2) Connect the audio level meter to the Audio Line Output.
- 3) Adjust the attenuator so that the audio level meter will indicate -27.5 dBs.
- 4) Make recording in the SP mode.
- 5) Set an audio line input signal to 7 kHz and make recording.
- 6) Playback a recorded portion, and measure output levels at 400 Hz and 7 kHz.
- 7) Confirm that the 7 kHz playback output level within a range of the 400 Hz playback output level 0 \pm 1 dB.

4. Overall Level Characteristic and Distortion Factor Check

Purpose:

Check the record level, play level, and distortion factor against the reference input.

Mode	REC and PB (SP mode)
Signal	400Hz, -7.5 dBs
Measurement point	Audio output terminal
Measurement equipment	Audio level meter and distortion factor meter
Specified value	Playback level: -7.5 ± 3 dBs Distortion factor: 4% or less

Confirmation Method:

- 1) Supply an audio signal of 400Hz, -7.5 dBs simultaneously to both L and R channels of Audio Line Input.
- 2) Make recording
- 3) Play back a recorded portion.
- 4) Confirm that a playback level is -7.5 ± 3 dBs.
- 5) Confirm that a distortion factor is within 4%.

5. Overall S/N Check

Purpose:

Confirm that the S/N is within the specification.

Mode	REC and PB (SP mode)
Signal	No signal
Measurement point	Audio output terminal
Measurement equipment	Audio level meter
Specified value	-46dB or more

Confirmation Method:

- 1) Connect both L and R channels of audio line input to the GND.
- 2) Start recording.
- 3) Play the recorded part to confirm that the noise is below -46dB.

Hookup 5

Pages 22 to 24

DSS (Digital Satellite System) receiver

Recommended use

Use this hookup if you have a DSS receiver. It allows the VCR's cable box control feature to control the channel on the DSS receiver, simplifying the recording process. A list of compatible DSS receivers is on page 38.

DSS (Digital Satellite System) is a satellite broadcast that provides superior digital-quality video and crisp digital-quality audio. A variety of program packages are available through your program providers. It also has program guides that are sorted by program categories.


What you can do with this hookup

- Record any channels using the VCR's cable box control feature to select channels on the DSS receiver.

What you can't do


- Record with the DSS receiver turned off
- Record any channels from cable or an antenna (To record channels from cable or an antenna, turn off the cable box control feature.)

- Use a cable box
- Record programs with VCR Plus+




Hookup 5: VCR setup

- 1 Set the RF UNIT switch to CH3 or CH4, whichever channel is not used in your area. If both are used, set the switch to either channel.



For details, see page 72.


- 2 If you made A/V connections (from page 8), you can skip this step.




- 3 Turn on your DSS receiver.

- 4 Press EASY SET UP on the VCR.


The LANGUAGE menu appears. Change the on-screen display language to French (FRANCAIS) or Spanish (ESPAÑOL) if desired, and press EXECUTE. For details, see page 29.




- 5 The CLOCK SET menu appears. Select AUTO and press EXECUTE. For details, see page 30.




- 6 The CABLE BOX CONTROL menu appears. Select ON. For details, see page 36.



- 7 Enter your DSS receiver code number and press CURSOR. For details, see page 36.



- 8 Set your DSS receiver output channel (BOX OUTPUT CH) to LINE and press EXECUTE.



Normal display

Hookup 5: VCR setup

Automatic clock setting

Once you've set up the VCR, it automatically sets the clock the first time you turn off the VCR. After that, whenever you turn off the VCR, it checks the time and adjusts the clock, even for Daylight Saving Time. The VCR sets the clock by picking up a time signal provided by some TV channels.

If you want to use the timer to record right away, or if the channels in your area do not carry time signals, set the clock manually. For details, see pages 34-35.

Notes

- To successfully record a program from the DSS receiver, proceed as follows:
 - Leave the DSS receiver on all the time.
 - Turn off the display (menu screen, channel number, etc.) of the DSS receiver.
 - To record or receive locked channels, unlock the channel before the VCR starts recording.
 - To set pay-per-view programs in the timer setting, order the pay-per-view program before the VCR starts recording.
 - Some programs are copy protected. You cannot record these programs.

Getting Started

Incompatible cable box with only a few scrambled channels, using an A/B switch

Recommended use


By using an A/B switch (not supplied), this hookup allows you to record both scrambled and unscrambled channels conveniently.

What you can do with this hookup

- Record any unscrambled channel by selecting the channel directly on the VCR (the A/B switch is set to A)
- Record any scrambled channel by selecting the channel on the cable box (the A/B switch is set to B)

What you can't do

- Record one scrambled channel while watching another channel (the A/B switch is set to B)




Match the type of connector on your TV: A, B, or C.
For connector types B and C, no UHF connection is required.

continued


Step 3: Hookups (continued)

Hookup 6: VCR setup

1 Set the RF UNIT switch to CH 3 or CH 4, whichever channel is not used in your area. If both are used, set the switch to either channel.




For details, see page 72. If you made A/V connections (from page 8), you can skip this step.




2 Set the A/B switch to "A."

3 Press EASY SET UP on the VCR.


1 The LANGUAGE menu appears. Change the on-screen display language to French (FRANÇAIS) or Spanish (ESPAÑOL) if desired, and press EXECUTE. For details, see page 29.




2 The CLOCK SET menu appears. Select AUTO and press EXECUTE. For details, see page 30.



3 The CABLE BOX CONTROL menu appears. Select OFF and press EXECUTE. For details, see page 36.



4 The TUNER PRESET menu appears. Set ANTENNA/CABLE to CABLE and press EXECUTE. For details, see page 41.




5 The AUTO PRESET starts.




4 Preset the cable box output channel (usually 2, 3 or 4). For details, see page 36.

1 Press MENU and select TUNER PRESET.



2 Enter the cable box output channel. Set MANUAL SET to ADD and press EXECUTE.




Step 3: Hookups (continued)


Hookup 6: VCR Plus+ channel setup

- 1 Find the VCR Plus+ Channel Listing in your program guide. For details, see page 45.
- 2 For unscrambled channels, if the channels in the program guide are different from the channels that you actually use on your TV, set the channels that are different as follows. For details, see page 46.

- 1 Press MENU and select SET VCR Plus+ CHANNELS.



- 2 Enter the program guide channel, then the channel you use on your TV.




Program guide channel

Your actual TV channel


- 3 Press EXECUTE.

- 3 For scrambled channels, enter all the scrambled channels you want to record and the cable box output channel (usually 2, 3, or 4). For details, see page 46.

- 1 Press MENU and select SET VCR Plus+ CHANNELS.



- 2 Enter the program guide channel, then the cable box output channel.




Program guide channel

Cable box output channel


Selecting a language

If you prefer French or Spanish to English, you can change the on-screen display language.



- 1 Press MENU, then press CURSOR \uparrow/\downarrow to move the cursor (0) to LANGUAGE and press EXECUTE.

When using the EASY SET UP procedure, skip this step.




- 2 Press CURSOR \uparrow/\downarrow to select ENGLISH, FRANCAIS or ESPAÑOL, then press EXECUTE.

Setting the clock


Using the Auto Clock Set feature

Some TV and cable channels transmit time signals with their broadcasts. Your VCR can pick up this time signal to automatically set the clock.

The Auto Clock Set feature works only if a channel in your area is broadcasting a time signal. If broadcasters in your area are not yet sending time signals, set the time manually (page 34).





1 Press **MENU**, then press **CURSOR** \uparrow/\downarrow to move the cursor (0) to **CLOCK SET** and press **EXECUTE**.




When using the **EASY SET UP** procedure, skip this step.

2 Press **CURSOR** \leftarrow/\rightarrow to select **AUTO**, then press **EXECUTE**.



3 Press **CURSOR** \leftarrow/\rightarrow to select **YES**, then press **EXECUTE**.



4 To activate the Auto Clock Set function, turn off the VCR.

The VCR automatically sets the clock by searching for a channel that carries a time signal and sets your time zone and Daylight Saving Time (if applicable).

If your clock is set to the wrong time zone or Daylight Saving Time, you can adjust these settings without turning off the Auto Clock Set feature (page 32).


Notes

- The clock cannot be set automatically if you don't receive a channel that carries a time signal in your area. If so, set the clock manually.
- If there are only a few channels in your area that carry time signals, setting the clock automatically may take up to about 30 minutes. If nothing happens even after you wait about 30 minutes, set the clock manually.
- If you use Hookup 1 or Hookup 4, make sure you leave the cable box on.


continued

Setting the clock (continued)


If the clock is not activated



1 Follow steps 1 and 2 in "Using the Auto Clock Set feature."
The AUTO CLOCK SET menu is displayed.



2 Press CURSOR ←/→ to select NO for FULL AUTO.




Getting Started

3



Press CURSOR ←/→ to highlight the item you want to set, then press CURSOR ←/→ to make the setting.

- For CLOCK SET CH: Leave the setting to "—" to have the VCR automatically search for a channel that carries a time signal. Press the number buttons to select a channel that carries a time signal. Use this option if you know of a channel that carries a time signal. Most PBS member stations broadcast a time signal. For the fastest response, select your local PBS station.



• For TIME ZONE

- Select the time zone of your area, or select AUTO to have the VCR automatically set your time zone. The options are: AUTO → ATLANTIC → EASTERN → CENTRAL → MOUNTAIN → PACIFIC → ALASKA → HAWAII → AUTO.

• For DAYLIGHT SAVING

- Select ON or OFF (standard time), or AUTO to have the VCR automatically set the daylight saving time.

4



Press EXECUTE that carries a time signal.

5

To activate the Auto Clock Set function, turn off the VCR.


Note

- If you use both the cable box control feature and the Auto Clock Set feature, the VCR automatically changes channels on the cable box until a channel that carries a time signal is found, whenever you turn off the VCR. If you want to stop the search, change the channel on the cable box with the channel buttons either on the VCR or on the remote commander.

continued

Setting the clock (continued)

Using Manual Clock Set




5 Set the year, hour and minutes in the same way as the day.



6 Press EXECUTE to start the clock.




1 Press MENU, then press CURSOR \uparrow/\downarrow to move the cursor (I) to CLOCK SET and press EXECUTE.




When using the EASY SET UP procedure, skip this step.


2 Press CURSOR \leftarrow/\rightarrow to select MANUAL, then press EXECUTE.



3 Press CURSOR \uparrow/\downarrow to set the month.



4 Press CURSOR \rightarrow to highlight the day and press CURSOR \uparrow/\downarrow to set the day. The day of the week is set automatically.




Setting up cable box control

(Skip this section if you are using Hookup 2, 3, 4 or 6.)

Your VCR includes a cable box control feature that allows the VCR to control most brands of cable boxes/DSS receivers via the Cable Mouse. With cable box control, the VCR controls channels on the cable box/DSS receiver for timer recording. You can also use the VCR's remote commander to change channels on the cable box/DSS receiver whenever the cable box/DSS receiver is turned on even if the VCR is turned off. To use cable box control, you need to connect the Cable Mouse (pages 10 and 22) and set the code number and output channel.


This VCR is programmed with codes necessary to control channel selection on most brands of cable boxes at the time this VCR was manufactured. It is possible that new cable boxes may be introduced that cannot be controlled with this VCR's Cable Mouse. If you have a cable box that is incompatible with this VCR, contact your cable operator — they may be able to provide you with a compatible cable box.



- 3 Press the number buttons to enter the cable box/DSS receiver code number, then press CURSOR →
- Find your cable box/DSS receiver code number from the chart below.



- 4 If you want to control a cable box, press CURSOR ←/→ to select the output channel for the cable box, then press EXECUTE.
- If you want to control a DSS receiver, select LINE, then press EXECUTE.




Use F1 to select CABLE BOX. Then push EXECUTE.

Cable box and DSS receiver brand and the corresponding code numbers
If more than one code number is listed, try entering them one by one, until you come to the correct code for your equipment.

Cable box brand	Code numbers
ABC	018, 022, 024, 028, 217
Antronix	218
Archer	033, 050, 164, 218
BBT	278
Cable Star	067
Cabletenna	033
Cable time	172, 282, 388, 459
Century	164
Citizen	164, 326, 327
Clyde Cablevision	097
Colour Voice	036, 042
Comband	243, 244
Comtronics	051, 071
Decsat	434
Diamond	046
Eagle Comtronics	051


Cable box brand	Code numbers
Eastern	013, 285
Electricord	089
Electus	055
Filmnet	454
Focus	411
Garrard	164
GC Electronics	027, 067, 341
GE	243, 244
CEC	097
Gemini	026, 068, 081, 253
General Instrument	022, 287, 487
Hamlin	020, 031, 045, 270, 284
Hitachi	022
Jasco	164, 326
Jerrold	014, 022, 025, 026, 035, 037, 058, 109, 287, 487



Use F1 to select CABLE BOX. Then push MENU to quit.

- 1 Press MENU, then press CURSOR ↑/↓ to move the cursor (0) to CABLE BOX CONTROL and press EXECUTE.

When using the EASY SET UP procedure, skip this step.



Enter your CABLE BOX Code No. using [6-9] keys. Refer to the Operating Manual for the Code

- 2 Press CURSOR ←/→ to select ON.



continued


Setting up cable box control (continued)

Cable box brand	Code numbers	Cable box brand	Code numbers
Linsay	451	Stargate	026, 051
Macomb	044	STS	167
Magnavox	038, 043, 080, 345	Sylvania	012
Memorex	011	T-Cable Teletext	116
Movie Time	089, 167, 214	Tandy	269
Northcruz	325	Tatung	108
Novaplex	629	Teknica	157
NSC	074, 081, 167, 214	Tele +1	454
Oak	018, 030, 259	TeleCaption	232
Omniview	382	Teleservice	242
Panasonic	032, 118	Texascan	012, 107
Paragon	011	TFC	321
Philips	036, 038, 039, 040, 041, 042, 071, 301, 345	Timeless	429
Philips ECC	253	Txcom	023, 024, 070
Pioneer	034, 155, 271, 544	Toshiba	011
Popular Mechanics	411	Tudi	247
Pulsar	011	TV86	074
RCA	032	TV COM	018, 030, 259
Realistic	218	Uniden	236
Reconon	411	Unika	033, 164, 218
Regal	031, 270, 284, 290	United Artists	018
Regency	013	United Cable	014
Rembrandt	081	Universal	033, 050, 067, 088, 089, 164, 202, 218, 333
RK	315, 317, 490	Videoway	261
Samsung	051, 155	Vidtech	255
Satbax	386	Viewstar	038, 071, 074, 122, 222, 269, 300
Scientific Atlanta	017, 019, 028, 288, 338	Westminster cable	116
Seam	521	Zenith	011, 065, 536
Sharp	324	Zontek	411
Signal	051	Wave Master	576
Signature	022		
SL Marx	051	DSS receiver brand	Code numbers
SpectraVision	049	Sony	650
Sprucer	032, 318	RCA	577
Standard Components	107, 166		
Starcom	014, 026, 058, 109		

Getting Started

To ensure correct operation

- Place the Cable Mouse so that it hangs out over the cable box/DSS receiver front.
- Do not place the cable box/DSS receiver on top of the VCR.
- Position the cable box/DSS receiver away from the VCR.
- Point the remote commander at the VCR, not at the cable box/DSS receiver.



To check the cable box control setting

- Press CH +/- on the remote commander. Does the channel indicator on the cable box/DSS receiver change? (Point the remote commander at the VCR, not at the cable box/DSS receiver.)
- Press all 10 number buttons (0 to 9) on the remote commander. Does the channel indicator on the cable box/DSS receiver change? If the answer to both 1 and 2 is "yes," you have made the correct setting.

continued

Setting up cable box control (continued)

If you cannot get your VCR to control the cable box/DSS receiver

- Check that the Cable Mouse is connected to the CABLE BOX CONTROL jack on the VCR.
- Check the position of the Cable Mouse.
- Place the cable box/DSS receiver and VCR away from each other. Do not place the cable box/DSS receiver on top of the VCR.
- Try the setup again making sure to use the correct control code. If the cable box still does not respond, try the other codes that are listed.

If your cable box still does not operate with the Cable Mouse, contact your cable company to see if they can provide you with a compatible cable box.

Note

- Make sure you turn off the VCR when you plug in or unplug the Cable Mouse. If you unplug the Cable Mouse and plug it in again, turn on the VCR before you use the cable box/DSS receiver control feature.

Presetting channels

(Skip this section if you are using cable box/DSS receiver control.)

This VCR is capable of receiving VHF channels 2 to 13, UHF channels 14 to 69 and unscrambled CATV channels 1 to 125. First, we recommend that you preset the receivable channels in your area using automatic presetting. Then, if there are any unwanted channels, disable them manually. If you have decided which channels you wish to preset, set them directly using manual presetting.

Before you start...


- Turn on the VCR and the TV.
- Set the TV to the VCR channel (channel 3 or 4). If your TV is connected to the VCR using A/V connections, set the TV to video input.
- Press TV/VTR to display the VTR indicator in the VCR's display window.
- Press INPUT SELECT so that a channel number appears in the VCR's display window.

Presetting all receivable channels automatically

1 MENU 

Press MENU, then press CURSOR \uparrow/\downarrow to move the cursor (0) to TUNER PRESET and press EXECUTE.


When using the EASY SET UP procedure, skip this step.




continued

Presetting channels (continued)


- 2
- To preset cable TV channels:
Press CURSOR \leftarrow / \rightarrow to set ANTENNA/CABLE to CABLE.



- To preset VHF and UHF channels:
Press CURSOR \leftarrow / \rightarrow to set ANTENNA/CABLE to ANT.




- 3
- Press CURSOR \uparrow / \downarrow to select AUTO PRESET then press EXECUTE.
- All receivable channels are preset in numerical sequence. When no more receivable channels can be found, presetting stops and the picture from the lowest numbered channel is displayed on the TV screen.




Tip


- When receiving a VHF, UHF or CATV channel, the display changes as follows each time you press the DISPLAY button.




Presetting/disabling channels manually




- 1 Press MENU and select TUNER/PRESET.



- 2
- To preset a channel:
1 Press the number buttons to enter the channel number, then press ENTER.
2 Press CURSOR \leftarrow / \rightarrow to set MANUAL SET to ADD.



- To disable a channel:
1 Press CH +/- to select the channel number.
2 Press CURSOR \leftarrow / \rightarrow to set MANUAL SET to ERASE.



- 3 Repeat step 2 to preset or disable channels as required, then press EXECUTE.



Setting up VCR Plus+

How VCR Plus+ works

Whenever you want to record a TV program, all you need to do is look up the program's "PlusCode," a number assigned to each program that's published in the TV section of most newspapers, cable TV listings, and even TV GUIDE magazine. Then, just enter the PlusCode of the program you want and the VCR is automatically programmed to record that show. It's that simple.

Example of "PlusCode"

5:30	MOVIE - Musical (2hrs.)	53024	PlusCode
6:30	SPORT - Golf (1hr, 25min.)	42080	
	NEWS - WS 9974		
	DRAMA - Comedy (2hrs.)	17390	
	SCIENCE AND TECHNOLOGY (1hr, 15min.)	73457	

Example of "Channel Line-up Chart"

CABLE CH	CABLE TV	VCR Plus+ GUIDE CH
16	AMC American Movie Classics	35
17	ABC News (program grid only)	54
20	CNN Cable News Network	42
21	CSPN C-SPAN	28
22	DIS The Disney Channel	53
25	DISC The Discovery Channel	37
34	ESPN	34
35	ESPN2	47
5	HBO Home Box Office	33
27	LIVE! Live!	48
29	MAX Max	45
30	MUSC Music Television	49
31	NICK Nick	36
38	SPN Sports Channel	59
39	SPCA Sports Channel Antenna	70
45	STW Showtime	41
17	TBS TBS SuperStation	43
44	TNN The Movie Channel	56
49	TNN The Nashville Network	49
50	TURN Turner Network Television	52
51	USA USA Network	44



How to set up your VCR

Setting up your VCR involves coordinating the TV channel number (the number you turn on your TV or VCR to watch a program) with the guide channel (the number that's assigned to that channel in your program guide). To get the guide channel numbers, find the "Channel Line-up Chart" in the program guide for your area that features VCR PlusCodes. It usually looks like the example to the right.


For each channel your VCR receives, use the Channel Line-up Chart to check that the channel numbers match. For example, if HBO is listed in the Channel Line-up Chart on channel 33, and your VCR receives HBO on channel 5, you need to coordinate these numbers using the following procedure. For channels in which the numbers are the same, you can skip this procedure.

If the picture is not clear


Normally, the Auto Fine Tuning (AFT) function automatically tunes in channels clearly. If, however, the picture of a channel is not clear, you can also use the manual tuning function.





1 Press MENU and select TUNER/PRESET.



2 Press the number buttons to select the channel you want to fine-tune, then press ENTER.





3 Press CURSOR \uparrow/\downarrow to select FINE TUNING. The fine tuning meter appears.





4 Press CURSOR \leftarrow/\rightarrow to adjust to a clearer picture. Note that the AFT setting switches to OFF.










5 EXECUTE  When you have set all channels, press EXECUTE to confirm your channel settings.















6 MENU  When you've finished, press MENU to exit.







1 MENU  CURSOR  EXECUTE  Press MENU, then press CURSOR \uparrow/\downarrow to move the cursor (0) to SET VCR Plus+ CHANNELS and press EXECUTE.



2           ENTER  Enter the channel number assigned in the program guide and press ENTER.




3 ENTER  ENTER  ENTER  If you made Hookup 1, 2 or 3: Enter the actual number on your TV (and VCR) and press ENTER.
If you made Hookup 4: Enter the cable output channel (usually 2, 3 or 4) and press ENTER.
If you made Hookup 6: Enter the actual number on your TV (and VCR) for an unscrambled channel and press ENTER. For a scrambled channel, enter the cable box output channel (usually 2, 3 or 4) and press ENTER.



4 Repeat steps 2 and 3 for each channel whose numbers don't match.

Playing a tape




Additional tasks

To	Press
Stop play	■ STOP
Pause play	⏸ PAUSE
Resume play after pause	⏸ PAUSE or ▷ PLAY
Search forward	Turn the DUAL MODE SHUTTLE (DMS) ring to ⏪ during playback
Search backward	Turn the DMS ring to ⏩ during playback
Fast-forward the tape	Turn the DMS ring to ⏩ FF during stop
Rewind the tape	Turn the DMS ring to ⏪ REW during stop
Eject the tape	▲ EJECT

To use the time counter

At the point on the tape that you want to find later, press COUNTER RESET. The counter in the display window resets to "0H00M00S." Search for the point afterwards by referring to the counter.



To display the counter on the TV screen, press DISPLAY.

Notes

- Tapes recorded in the LP mode on other VCRs can be played back on this VCR but the picture quality cannot be guaranteed.
- The counter resets to "0H00M00S" whenever a tape is reinserted.
- The counter stops counting when it comes to a portion with no recording.

1 Turn on your TV and set it to the video channel.


2 Open the drop down panel and insert a tape.
The VCR turns on and starts playing automatically if you insert a tape with its safety tab removed.



3 Press ▷ PLAY.
When the tape reaches the end, it will rewind automatically.



Recording TV programs



5 Press TAPE SPEED to select the tape speed, SP or EP. EP provides recording time three times as long as SP, however, SP produces better picture quality.





6 Press ●REC to start recording.



To stop recording
Press ■ STOP.

To check the remaining tape length

Press DISPLAY. The white bar indicates the approximate length of tape remaining. With the display on, press COUNTER/REMAIN to check the remaining time. Each time you press COUNTER/REMAIN, the time counter and the remaining time appear alternately. The remaining time also appears in the display window.




To check the remaining time of a tape more than two hours long, set TAPE SELECT in the ADVANCED OPTIONS menu to "-160." (For details, see page 66.)



1 Turn on your TV and set it to the video channel. To record from a cable box, turn it on.

2 Insert a tape with its safety tab in place.

3 Press INPUT-SELECT until a channel number appears in the display window.



4 Press CH +/- to select the channel you want to record.



Safety tab

continued

Recording TV programs (continued)

Tips

- To select a channel, you can use the number buttons on the remote commander. Enter the channel number, then press ENTER.
- The display appears on the TV screen indicating information about the tape, but the information won't be recorded on the tape.
- If you don't want to watch TV while recording, you can turn off the TV. When using a cable box, make sure to leave it on.

Notes


- The remaining time may not be indicated accurately for short tapes such as T-20 or T-30, or tapes recorded in the LP mode.
- The display does not appear during still mode or slow-motion playback.

Recording TV programs using VCR Plus+


Just enter the program's PlusCode listed in the TV program guide. The date, times and channel number of that program are set automatically. You can preset up to eight programs at a time.

Before you start...


- Check that the VCR clock is set to the correct time.
- Turn on your TV and set it to the video channel. When using a cable box, turn it on.
- Insert a tape with its safety tab in place. Make sure the tape is longer than the total recording time.




1 VCR Plus+ Press VCR Plus+.



2 Press the number buttons to enter the program's PlusCode. If you make a mistake, press TIMER CLEAR and re-enter the correct number.




3 Press TAPE SPEED to select SP or EP.



4 Press ONCE, DAILY or WEEKLY:



To record	Press
Only once	ONCE
Everyday Monday to Friday	DAILY
Once a week	WEEKLY



The date, start and stop times, channel number and tape speed appear on the TV screen. If the information is not correct, press TIMER CLEAR to cancel the setting.

5 To enter another setting, repeat steps 1 to 4.

6 Press POWER to turn off the VCR.



The TIMER indicator on the VCR lights up and the VCR stands by for recording. When using a cable box, leave it on.

To stop recording

To stop the VCR while recording, press ■STOP.

To use the VCR after setting the timer

To use the VCR before a timer recording begins, just press POWER. The "TIMER" indicator turns off and the VCR switches on. Remember to press POWER to reset the VCR in timer recording standby after using the VCR.

You can also do the following tasks while the VCR is recording:

- Reset the counter.
- Display tape information on the TV screen.
- Check the timer settings.
- Watch another TV program.

To lock the VCR after setting the timer

Hold down POWER on the VCR until the VCR beeps. The VCR turns off and the "LOC" indicator appears on the display window. The VCR will not work except for timer recording.

To unlock the VCR, hold down POWER on the VCR until the VCR beeps.

Tips

- To cancel the procedure, press VCR Plus+ before pressing ONCE, DAILY or WEEKLY.
- When you are recording a program in the SP mode and the remaining tape becomes shorter than the recording time, the tape speed is automatically changed to the EP mode. Note that some noises will appear on the picture when the tape speed is changed. If you want to keep the tape speed, set AUTO TAPE SPEED to OFF in the ADVANCED OPTIONS menu (page 66).

Notes


- If the VCR beeps, this means that:
 - The PlusCode is incorrect.
 - ONCE, DAILY or WEEKLY was selected incorrectly. You cannot select DAILY or WEEKLY for a program that airs more than seven days ahead.
- The VCR will be unlocked when:
 - you stop timer recording by pressing ■ STOP
 - you insert a tape
 - the AC power cord is disconnected or power supply stops

Setting the timer manually

If VCR Plus+ is not available in your area, follow the instructions below to set the timer to record programs.

Before you start...


- Check that the VCR clock is set to the correct time.
- Turn on your TV and set it to the video channel. When using a cable box, turn it on.
- Insert a tape with its safety tab in place. Make sure the tape is longer than the total recording time.



2

Set the date, start and stop times, channel number and tape speed:

- 1 Press CURSOR → to highlight each item in turn.
- 2 Press CURSOR ↓/↑ to set each item. To correct a setting, press CURSOR ← to return to that setting and reset.



To record the same program every day or the same day every week, press CURSOR ↓. For details, see "Daily/weekly recording" on page 55.

To record from a source connected to the LINE -1 IN or LINE -2 IN jacks, press INPUT SELECT to display "L1" or "L2" in the "CH" position.

3

- Press CURSOR → to confirm the setting. The cursor (I) appears at the top of the line. To enter another setting, move the cursor to the next line and repeat step 2.

4

Press EXECUTE.

5

- Press POWER to turn off the VCR. The TIMER indicator on the VCR lights up and the VCR stands by for recording. When using a cable box, leave it on.

Daily/weekly recording

In step 2 above, press CURSOR ↓ to select the recording pattern. Each time you press CURSOR ↓, the indication changes as shown below. Press CURSOR ↑ to change the indication in reverse order.

the current date → SUN-SAT → MON-SAT → MON-FRI → EVERY SAT
→ EVERY MON → EVERY SUN → 1 month later → (cycles backward) →
the current date


Tips

- To set the channel, you can also use the CH+/- or number buttons.
- To set the tape speed, you can also use TAPE SPEED.
- When you are recording a program in the SP mode and the remaining tape becomes shorter than the recording time, the tape speed is automatically changed to the EP mode. Note that some noises will appear on the picture when the tape speed is changed. If you want to keep the tape speed, set AUTO TAPE SPEED to OFF in the ADVANCED OPTIONS menu (page 66).
- To lock the VCR after setting the timer, see page 54.


Note

- If you are using cable box control, you cannot select "L1" or "L2."

- 1 MENU Press MENU and select TIMER SET/CHECK.



Playing/searching at various speeds



To resume normal playback

Press **▷** PLAY.

Tip


- Adjust the picture using the **▽/▲** TRACKING/STILL ADJUST buttons if:
 - Sreaks appear while playing in slow motion.
 - Bands appear at the top or bottom while pausing.
 - The picture shakes while pausing.

Notes

- The sound is muted during these operations.
- Tapes recorded in the LP mode on other VCRs can be played back on this VCR but the picture quality cannot be guaranteed.

Playback options	Operation
Play at various speeds	During playback, turn the DMS ring and hold at the speed you want.
Fast-forward/rewind	During stop, turn the DMS ring to ▶▶FF or ◀◀REW and release.
View the picture during fast-forward or rewind	During fast-forward, turn the DMS ring to ▶▶FF . During rewind, turn the DMS ring to ◀◀REW .
Play at twice the normal speed	During playback, turn the DMS ring to x2 .
Play at high speed	During playback or pause, press SEARCH or SEARCH . To change direction, press ▶▶FRAME or ◀◀FRAME .
Play in slow motion	During playback or pause, press ▶▶SLOW+/- . Press the +/- buttons to change the speed. To change direction, press ▶▶FRAME or ◀◀FRAME .
Play frame by frame	During pause, press ▶▶FRAME or ◀◀FRAME . Hold the button down to play one frame each second.
Play in reverse	During playback, press ◀◀FRAME .
Skip a scene	During playback, press SKIP . Pressing once skips about 30 seconds.
Rewind and start play	During stop, press ▷ PLAY on the VCR while holding the DMS ring on the VCR at the ◀◀REW position.

Recording TV programs using the quick timer




After starting recording in the normal way, you can have the VCR stop recording automatically after a specified duration.

- 1 While recording, press QUICK TIMER once.



- 2 Press QUICK TIMER repeatedly to set the duration.

Each press advances the time in increments of 30 minutes.




To check or extend the duration

Press QUICK TIMER once. The duration is displayed for 10 seconds. If you want to extend the time, press QUICK TIMER within 10 seconds to set to the new duration.

To stop while recording

Press ■STOP.

Checking/ changing/ cancelling timer settings



Before you start...

- Turn on your TV and set it to the video channel.

- 1 Press POWER to turn on the VCR.
- 2 Press MENU and select TIMER SET/CHECK:

- If you want to change a setting, go on to the next step.

- If you do not need to change the settings, press EXECUTE, then turn off the VCR to return to recording standby.

DATE	START	STOP	CH
7/5	7:00	8:00	6
7/12	10:30	11:30	5
MON - SUN	1:00	3:00	J&E
OPER	8:00	1:30	12
- / -	- / -	- / -	- / -
- / -	- / -	- / -	- / -

- 3 Press CURSOR ↓/↑ to select the setting you want to change:


- To change the setting, press CURSOR ←/→ to highlight the item you want to change, and press CURSOR ↓/↑ to reset it. Then, press CURSOR → repeatedly until the cursor (I) appears at the top of the line.

- 4 To cancel the setting, press TIMER CLEAR.
- Press EXECUTE.

If any timer settings remain, turn off the VCR to return to recording standby.

When the timer settings overlap

The program that starts first has priority and the second program starts recording only after the first program has finished. If the programs start at the same time, the program listed first in the menu has priority.



Recording stereo and bilingual programs

Recording stereo programs

This VCR automatically receives and records stereo programs. When a stereo program is received, the STEREO indicator lights up. If there is noise in the stereo program, set AUTO STEREO in the ADVANCED OPTIONS menu to OFF. The sound will be recorded in monaural (on both hi-fi and normal audio tracks) but with less noise. For details, see page 66.

Recording bilingual programs

Normally, this VCR records only the main sound on both hi-fi and normal audio tracks. To record SAP (Second Audio Program) sound on the normal audio track, set NORMAL AUDIO in the ADVANCED OPTIONS menu to SAP (the SAP indicator lights up). For details, see page 66.

To select the bilingual sound while recording


Press AUDIO MONITOR to select the sound you want.

Selecting the sound during playback

Press AUDIO MONITOR to select the sound you want.

To listen to	On-screen display	Display window
Stereo/main (left and right channels)	STEREO	STEREO
Left channel only	LEFT CH	STEREO
Right channel only	RIGHT CH	STEREO
Monaural (SAP)	No indicator	No indicator

Searching using the index function



The VCR marks the tape with an index signal at the point where each recording begins. Use these signals as references to find a specific recording. The VCR can search up to 99 index signals ahead of or behind the current position.

- 1 Insert an indexed tape into the VCR.
- 2 Press **INDEX SEARCH** repeatedly to specify how many index signals ahead or behind you want to search:

- To search ahead, press **INDEX SEARCH**.
- To search backwards, press **INDEX SEARCH**.

The VCR starts searching and the index number on the TV screen counts down to zero. Playback starts automatically from that point.

To stop searching


Press **STOP**.

Adjusting the picture

Adjusting the tracking

Although the VCR automatically adjusts the tracking when playing a tape (the **AUTO TRACKING** indicator flashes in the display window, then lights steadily), distortion may occur if the tape was recorded in poor condition. If so, manually adjust the tracking.

Press the **▼/▲** **TRACKING NORMAL/SLOW** buttons to display the tracking meter. The distortion should disappear as you press one of the two buttons. If you cannot get a clear picture with manual adjustment, press **TRACKING AUTO/MANUAL** to return to automatic adjustment.



Tracking meter

About Adaptive Picture Control (APC)

Adaptive Picture Control (APC) automatically improves recording and playback quality by adjusting the VCR to the condition of the video heads and tape. To maintain better picture quality, we recommend that you set APC to **ON** in the **ADVANCED OPTIONS** menu (with the APC indicator in the display window lit).

APC playback

The APC function automatically works on all types of tapes, including rental tapes and tapes that were not recorded with APC.

APC recording

Whenever you insert a tape and first start recording, the VCR adjusts to the tape using the APC function (the APC indicator flashes rapidly). This adjustment is retained until the tape is ejected.

Notes

- Auto tracking adjustment cannot be used on tapes recorded in the LP mode on other VCRs.
 - The APC function does not work if the tape speed is automatically changed from the SP to EP mode during a timer recording, unless the tape has been recorded in the EP mode with the APC function.
 - There is a delay of a few seconds before the VCR actually starts recording while the VCR analyzes the tape. To avoid the delay, first set the VCR to recording pause (the APC indicator flashes slowly) and press **●** **REC** to have the VCR analyze the tape (the APC indicator flashes rapidly). After the APC indicator stops flashing, press **■** **PAUSE** to start recording immediately.
- If you want to start recording quickly without using the APC function, first set the VCR to recording pause (the APC indicator flashes slowly) and press **■** **PAUSE** to start recording.

Changing menu options

- 1 Press **MENU** and select **ADVANCED OPTIONS**.

ADVANCED OPTIONS	
AUTO ANT SEL	ON OFF
AUTO STEREO	ON OFF
AUDIO MIX	ON OFF
NORMAL AUDIO	ON OFF
APC	ON OFF
SHARPNESS	-20 160
TAPE SELECT	ON OFF
AUTO TAPE SPEED	ON OFF

- 2 Press **CURSOR** **↑/↓** to select the option to change, then press **CURSOR** **←/→** to change the setting.
- 3 Press **EXECUTE** to return to the original screen.

Menu choices

Initial settings are indicated in bold print.


Menu option	Set this option to
AUTO ANT SEL	ON if your TV is connected only to VHF/UHF OUT on the VCR. To play a tape, set the TV to the VCR channel (channel 3 or 4). OFF if your TV is connected to both VHF/UHF OUT and LINE OUT on the VCR. To play a tape, set the TV to the VCR input.
AUTO STEREO	ON to receive stereo programs, OFF to reduce noise. The sound changes to monaural.
DIMMER	ON to make the display window dim, OFF to make it brighter.
AUDIO MIX	ON to listen to the sound recorded on hi-fi and normal audio tracks at the same time. The AUDIO MONITOR button will not function. OFF to listen to hi-fi and normal audio tracks separately. Select the sound using the AUDIO MONITOR button.
NORMAL AUDIO	MAIN to record the main sound on both hi-fi and normal audio tracks. SAP to record the SAP (Second Audio Program) sound on the normal audio track. The main sound is recorded on the hi-fi audio track.
APC	ON to switch on the APC (Adaptive Picture Control) function and improve picture quality, OFF to switch off APC.
SHARPNESS	ON to get a sharp picture, OFF to clear the sharpness control.
TAPE SELECT	"-120" or "-160" to select the tape length and display the remaining time correctly.
AUTO TAPE SPEED	ON to change the timer recording tape speed automatically to the EP mode when the remaining tape becomes shorter than the recording time, OFF to keep the tape speed.

Editing methods

This section introduces you to various ways to edit tape recordings.

Basic editing

You can make a copy of a tape.




Insert editing

You can replace an existing scene with material from another recording. There are three kinds of insert editing.


Video insert

Replaces the original video and hi-fi audio. The monaural sound on the normal audio track is retained.



Audio insert

Replaces the original monaural sound on the normal audio track. The video and hi-fi sound are left intact. For example, you can use this feature to add commentary to a tape recorded on a camcorder.




A/V insert

Replaces the original video and both hi-fi and monaural sound.

Hooking up to a VCR or stereo system

How to hook up to record on this VCR



If the other VCR has a **CONTROL S OUT** jack for synchronized editing Hook up to record on the other VCR, then connect the VCRs via the **CONTROL S** jacks. The **CONTROL S** connection lets you control (pause and release pause) both VCRs from the recording VCR.

Notes

- Make sure you connect the plugs to jacks of the same color.
- If the other VCR is a monaural type, leave the red plugs unconnected.
- If you connected this VCR to both the **LINE IN** and **LINE OUT** jacks of the other VCR, select the input correctly to prevent a humming noise.
- If the **CONTROL S IN** jack is used for SystemLink (A/V bus control) with a TV, the **CONTROL S** connection cannot be used for editing.


How to hook up to a stereo system

Connect **LINE-2 IN AUDIO** on this VCR to the audio output jacks on the stereo system, using the RK-C510KS audio cable (not supplied).

Insert editing

Before you start editing

- Turn on your TV and set it to the video channel.
- Press INPUT SELECT to display "L2" in the display window.
- Press TAPE SPEED on the remote commander to select the tape speed, SP or EP.
- On this VCR, set the EDIT switch to ON. If the other VCR has a similar switch, set it to ON as well.



To stop editing

Press the **STOP** buttons on this VCR and the other VCR (or stereo system).

To listen to both the hi-fi and normal audio

Set AUDIO MIX to ON in the ADVANCED OPTIONS menu (page 66). Use this feature to listen to inserted audio together with the original hi-fi audio. When AUDIO MIX is set to ON, the AUDIO MONITOR button does not function. Remember to reset AUDIO MIX to OFF after playing the tape.

Note

- To use the INSERT function, this VCR must be set to playback pause, not recording pause.

- 1 Insert a source tape into the playback VCR or the stereo system. Search for the point to start playback and set it to playback pause.
- 2 Insert a prerecorded tape into this (recording) VCR. Search for the end of the scene to be replaced and press **PAUSE**.
- 3 Press COUNTER RESET on this VCR to reset the counter to "0H00M00S."
- 4 Rewind the prerecorded tape to the beginning of the scene to be replaced.
- 5 The VCR pauses.
Press the INSERT buttons:


To replace	Press
Picture and hi-fi sound	INSERT VIDEO "VID INSH" appears on the TV screen and "V INSERT" appears in the display window.
Monaural sound only	INSERT AUDIO "A INSH" appears in the display window.
Picture, hi-fi and monaural sound	INSERT AUDIO, then INSERT VIDEO "A/V INSH" appears on the TV screen and "AV INSERT" appears in the display window.

- 6 To start editing, press the **PAUSE** buttons on this VCR and the other VCR (or stereo system) at the same time.

General setup information

Setting the RF unit


When connecting the VCR to the TV using only the antenna cable, you must set the RF UNIT switch on the rear of the VCR so that the TV can receive the correct signal from the VCR.



- 1 Set the RF UNIT switch on the rear of the VCR to CH3 or CH4, whichever channel is not used in your area. If both are used, set the switch to either channel.
 - 2 Press POWER to turn on the VCR.
 - 3 Press TV/VTR to turn on the VTR indicator in the VCR's display window.
 - 4 Press CHANNEL +/- to display a channel number in the display window. Select an active channel number in your area.
 - 5 Turn on your TV and set it to the channel you selected in step 1 (channel 3 or 4).
- The selected TV channel broadcast appears on the TV screen. If the channels change when you press CHANNEL +/- on the VTR, you have made the correct setting.
- Whenever you use the VCR, set the TV to the channel selected in step 1.

Attaching the external antenna connector

When using a 300-ohm twin lead cable for VHF/UHF antenna, use the EAC-32 antenna connector (not supplied) to connect the antenna to the VCR.




- 1 Loosen the screws on the antenna connector.
- 2 Wind the twin leads around the screws on the antenna connector.
- 3 Retighten the screws.

Index to parts and controls


Refer to the pages indicated in parentheses () for details.

Front panel




- | | |
|-----------------------------------|---|
| 1 POWER switch/indicator | 8 EASY SET UP button (11, 14, 17, 20, 23) |
| 2 EJECT button (49) | 9 COMMAND MODE switch (5) |
| 3 PLAY button (49) | 10 EDIT switch (69) |
| 4 STOP button (49) | 11 LINE-2 IN VIDEO/AUDIO L/R jacks (68) |
| 5 REC button (50) | 12 Remote sensor |
| 6 DUAL MODE SHUTTLE ring (49, 58) | |
| 7 PAUSE button (49) | |

Front panel, with cover opened




- 1 Tape compartment
- 2 QUICK TIMER button (60)
- 3 TAPE SPEED (SP/EP) button (51)
- 4 COUNTER RESET button (49)
- 5 CHANNEL +/- buttons (50)
- 6 INPUT SELECT button (50, 69)
- 7 TV/VTR button (51)

Display window



- 1 AUTO TRACKING indicator (65)
- 2 Tape speed indicator (51)
- 3 APC indicator (65)
- 4 AV INSERT indicator (70)
- 5 REMAIN indicator (51)
- 6 STEREO indicator (62)
- 7 SAP indicator (62)
- 8 VTR indicator (51)
- 9 Line/channel indicator (50, 69)
- 10 Time counter/remaining time counter/clock
- 11 REC indicator
- 12 Tape indicator
- 13 TIMER indicator


Rear panel



- 1 AC IN connector
- 2 LINE OUT AUDIO L/R/VIDEO jacks (8)
- 3 LINE-1 IN AUDIO L/R/VIDEO jacks (68)
- 4 SYSTEMLINK (CONTROLS IN) jack (9, 68)
- 5 CABLE BOX CONTROL (CONTROL S OUT) jack (10, 22)
- 6 RF UNIT switch (72)
- 7 VHF/UHF IN/OUT connectors (10, 13, 16, 19, 22, 25)


Index to parts and controls (continued)

- 19 VCR Plus+ buttons (53)
- VCR Plus+ button
- ONCE button
- DAILY button
- WEEKLY button
- 20 AUDIO/VIDEO INSERT buttons (70)
- 21 COUNTER/REMAIN button (51)
- 22 DISPLAY button (51)
- 23 TAPE SPEED button (51)
- 24 INPUT SELECT button (50, 69)
- 25 CH +/- buttons (50)
- 26 VOL +/- buttons (5)
- 27 PAUSE button (49)
- 28 REC button (50)
- 29 DUAL MODE SHUTTLE ring (49, 58)











Remote commander

- 1 COMMAND MODE switch (5)
- 2 EJECT button (49)
- 3 Menu operation buttons (29)
- MENU button
- CURSOR $\uparrow/\downarrow/\leftarrow/\rightarrow$ buttons
- EXECUTE button
- 4 COUNTER RESET button (49)
- 5 Channel number buttons and ENTER button (43, 46)
- 6 SKIP button (58)
- 7 TRACKING buttons (65)
- ∇/\blacktriangle NORMAL/SLOW (STILL) ADJUST buttons
- AUTO/MANUAL button
- 8 SLOW buttons (58)
- 9 \lll/\lll FRAME buttons (58)
- 10 \lll/\lll INDEX SEARCH buttons (64)
- 11 TV/VTR SEARCH buttons (58)
- 12 \blacktriangle PLAY button (58)
- 13 \blacksquare STOP button (49)
- 14 TV/VTR remote control switch (5)
- 15 POWER button
- 16 TIMER CLEAR button (53)
- 17 TV/VTR button (51)
- 18 AUDIO MONITOR button (62)





continued


-68/77
RD (2/3)
10/860
PAGE 4-29)
-69/78
RD (2/3)
761/L5/L7)
PAGE 4-33)



IC201 (2/3) (MA-251/252)
SYSTEM CONTROL










3-4. MODE CONTROL BLOCK DIAGRAM

—SLV-760/761/L5/L7—



05










BOARD (760/761/L5/L6/L7)
3-51)

DM-48/52 BOARD (760/761/L5 /L7)
(SEE PAGE 4-51)

HI-23/3
(SEE PAGE




SERVO/
SYSTEM
CONTROL
(SEE PAGE 3-12)







3-5. TUNER BLOCK DIAGRAM

—HI-FI Model (SLV-760/761/790/960/L7)—


MA-251 BOARD (4/8) (790/960)
 (SEE PAGE 4-41)
 MA-252 BOARD (4/8) (760/761/L7)
 (SEE PAGE 4-44)









05




24)






3-6. AUDIO/IO BLOCK DIAGRAM







3-7. POWER SUPPLY BLOCK DIAGRAM



05

DIAGRAM






• Waveforms

• Signal path


	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA	
REC	→	→	→	→
PB	↔	↔	↔	↔

• Signal path

	REC	REC/PB	PB
Ref. signal	→	↔	↔



RP-198/203 (HEAD AMP) (SLV-760/761/L5/L7) SCHEMATIC DIAGRAM • See page 4-4 to 4-6 for printed wiring board.
- Ref. No.: RP-198/203 Board; 2,000 series -



RP-198 BOARD (760HF, 761HF, L5MX/PA, L7HF MX/HF PA)
RP-203 BOARD (760HF PX, L5CS, L7HFCS)


MA-252 BOARD (1/5)
CN501
SEE PAGE 4-22

no mark: REC/PB mode
R: REC mode
P: PB mode


There are cases that the part isn't mounted in this model is printed on this diagram.

MA-251 (SERVO/SYSTEM/TUNER/TIMER/MODE CONTROL, VIDEO, AUDIO, IO, TUNER) (SLV-790/960), DC-68/77 (REALY) PRINTED WIRING BOARDS
- Ref. No.: MA-251 Board: 3,000 series, DC-68/77 Board: 1,000 series -


MA-251 BOARD





- MA251 BOARD
- CN101 I-11
- CN271 E-2
- CN276 C-7
- CN281 H-2
- CN291 I-1
- CN301 B-9
- CN501 B-5
- CN511 B-2
- CN581 B-1
- CN601 H-6
- CN602 I-5
- CN603 I-3
- CN606 G-1
- CN807 G-11
- D151 G-8
- D152 G-8
- D201 F-6
- D202 H-7
- D251 H-9
- D251 G-6
- D266 I-7
- D267 I-4
- D291 F-5
- D301 C-9
- D402 F-8
- D403 F-8
- D581 E-3
- D610 A-5
- D631 A-7
- D632 A-8
- D633 A-8
- D635 A-7
- D701 B-11
- D702 C-12
- D703 C-12
- D902 H-4
- IC101 I-12
- IC131 G-8
- IC151 H-9
- IC152 H-7
- IC153 H-6
- IC201 H-6
- IC251 I-2
- IC291 E-5
- IC302 D-11
- IC401 E-8
- IC402 E-8
- IC461 B-11
- IC501 D-4
- IC511 D-2
- IC631 B-7
- IC701 D-11
- Q131 G-8
- Q132 G-7
- Q201 I-5
- Q202 H-4
- Q261 F-1
- Q262 G-10
- Q263 E-6
- Q301 C-9
- Q306 D-11
- Q352 G-8
- Q353 C-8
- Q402 E-8
- Q404 E-8
- Q406 F-9
- Q407 I-10
- Q413 E-9
- Q501 E-3
- Q502 E-2
- Q681 A-6
- Q701 E-12
- Q703 C-12
- Q705 E-12
- Q707 D-12
- Q708 D-12
- Q709 E-12
- Q715 D-12
- Q716 D-12
- Q717 C-12
- Q811 B-2
- Q812 B-2
- Q886 B-2
- Q891 E-2
- Q892 E-2



- DC-68 BOARD: 1-659-441-
- DC-69 BOARD: 1-659-454-
- DC-77 BOARD: 1-659-448-
- DC-78 BOARD: 1-659-460-



MA-251 (VIDEO) (SLV-790/960) SCHEMATIC DIAGRAM • See page 4-13 to 4-15 for printed wiring board.
 - Ref. No.: MA-251 Board; 3,000 series -




• Signal path

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC	→	⇒	⇒⇒
PB	⇨	⇨⇨	⇨⇨⇨


• Signal path

Ref. signal	REC	REC/PB	PB
		→	⇒

MA-252 (VIDEO) (SLV-760/761/L5/L7) SCHEMATIC DIAGRAM • See page 4-16 to 4-18 for printed wiring board.
 - Ref. No.: MA-252 Board; 4,000 series -



• Waveforms







• Signal path

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC	➔	➔	➔
PB	➔	➔	➔

• Signal path

Ref. signal	REC	REC/PB	PB
		➔	➔

MA-251 (SERVO/SYSTEM/TUNER/TIMER/MODE CONTROL) (SLV-790/960), DC-68/77 (REALY) SCHEMATIC DIAGRAM • See page 4-13 to 4-15 for printed wiring board.
 - Ref. No.: MA-251 Board: 3,000 series, DC-68/77 Board: 1,000 series -




Signal path

	VIDEO SIGNAL	AUDIO	Y/CHROMA SIGNAL
REC	→	→	→
PB	→	→	→

Signal path

	REC	REC/PB	PB
Drum speed servo	→	→	→
Drum phase servo	→	→	→
Drum servo (speed and phase)	→	→	→
Capstan speed servo	→	→	→
Capstan servo (speed and phase)	→	→	→
Ref. signal	→	→	→




• Signal path


	VIDEO SIGNAL	AUDIO
REC	→	→
PB	→	→

• Signal path

	REC	REC/PB	PB
Drum speed servo		→	
Drum phase servo		→	
Drum servo (speed and phase)		→	
Capstan speed servo		→	
Capstan servo (speed and phase)		→	
Ref. signal	→		→



MA-251 (AUDIO, IO) (SLV-790/960) SCHEMATIC DIAGRAM • See page 4-13 to 4-15 for printed wiring board.
 - Ref. No.: MA-251 Board; 3,000 series -




MA-251 BOARD (3/5)

MA-251 BOARD (2/3) (SEE PAGE 4-28)

MA-251 BOARD (1/3) (SEE PAGE 4-13)

MA-251 BOARD (2/3) (SEE PAGE 4-28)

RP-197/202 BOARD CN701 (SEE PAGE 4-7)



• Signal path

	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA	
REC	→	→	→	→
PB	⇨	⇨	⇨	⇨


RP-198, 203 BOARD
 CN701
 SEE PAGE 4-18

3 MA-252 BOARD (1/5)
 SEE PAGE 4-22

4 MA-252 BOARD (2/5)
 SEE PAGE 4-23

5 MA-252 BOARD (2/5)
 SEE PAGE 4-23


MA-251 (TUNER) (SLV-790/960) SCHEMATIC DIAGRAM • See page 4-13 to 4-15 for printed wiring board.
 - Ref. No.: MA-251 Board; 3,000 series -



2
 MA-251 BOARD (2/5)
 (SEE PAGE 4-26)

• Signal path

	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA	
REC	→	→	→	→
PB	→	→	→	→



2
 MA-252 BOARD (2/5)
 (SEE PAGE 4-30)

• Signal path


	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA	
REC	→	→	→	→
PB	→	→	→	→

There are cases that the part isn't mounted in this model is printed on this diagram.

DM-48/52 (MODE CONTROL), HI-24/37 (FL DRIVER), MF-284/290 (POWER SWITCH)
 (SLV-760/761/L5/L7) PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAM

- Ref. No.: DM-48/52 Board, HI-24/37 Board and MF-284/290 Board; 2,000 series -


HI-24/37 BOARD




- HI-24/37 BOARD**
- CN301 A-3
 - CN302 B-10
 - CN303 A-10
 - CN304 B-1
 - D301 B-9
 - D302 B-9
 - D303 B-9
 - D304 B-9
 - D305 A-4
 - D306 A-4
 - D307 B-3
 - D308 B-3
 - D309 B-4
 - D310 B-4
 - D320 B-1
 - D321 A-4
 - D324 A-2
 - IC301 A-6
 - IC302 A-8

HI-24 BOARD: 1-659-450-
 HI-37 BOARD: 1-659-456-


DM-48/52 BOARD



- DM-48/52 BOARD**
- CN401 A-1
 - CN402 C-2
 - D401 C-2
 - D402 B-2
 - D403 C-3
 - D404 C-2
 - D405 B-2
 - D406 B-3




MF-284/290 BOARD




• Signal path

	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	YCHROMA	
REC	1	1	1	1
PB				1



5-1-7. MECHANISM CHASSIS ASSEMBLY (4)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
301	3-958-534-01	SPRING, TORSION		316	3-958-476-01	GEAR (S), LOADING	
302	3-958-532-01	ARM, S WINDING		317	3-960-448-01	SPRING (S), TORSION COIL	
303	3-958-533-01	CLAW, S WINDING		318	X-3943-890-1	LEVER (S) ASSY, LOADING	
304	3-962-959-01	GEAR (S-K), IDLER		319	3-960-720-01	SCREW	
305	3-962-960-01	GEAR (T-K), IDLER		320	3-960-688-01	SPRING, LEAF (T), LOADING	
306	3-669-595-00	WASHER (2), STOPPER		321	3-960-687-01	SPRING, LEAF (S), LOADING	
307	A-6739-102-A	RKB BLOCK ASSY		322	X-3945-485-1	CHASSIS ASSY, MECHANICAL	
308	3-966-092-01	RING, RETAINING, SLIT WASHER		323	3-958-504-01	ARM, FIXED RELEASE	
309	3-961-441-01	SCREW (3X8)		324	A-6750-316-A	SHUTTLE (S) BLOCK ASSY	
310	3-959-840-11	RUBBER, JOINT		325	3-962-874-01	O-RING	
311	3-958-529-01	SPRING (MOMENT), TENSION		326	X-3944-378-1	ROLLER ASSY, GUIDE	
312	X-3943-897-1	LEVER ASSY, TRIGGER		327	A-6750-314-A	T BLOCK ASSY, SHUTTLE	
313	3-958-485-02	GEAR (T), LOADING		328	3-958-492-01	SPRING (TG1), TENSION COIL	
314	3-960-449-01	SPRING (T), TORSION COIL		329	X-3943-886-1	TG1 ASSY	
315	X-3943-891-1	LEVER (T) ASSY, LOADING		M902	1-698-409-11	MOTOR, DC SCV-0801A/2-NP (CAPSTAN)	

5-2. ELECTRICAL PARTS LIST

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, -so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms.
METAL: Metal-film resistor.
METAL OXIDE: Metal oxide-film resistor.
F: nonflammable

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
In each case, u: μ , for example:
uA ..: μ A. uPA ..: μ PA.
uPB ..: μ PB. uPC ..: μ PC. uPD ..: μ PD.
- CAPACITORS
uF: μ F
- COILS
uH: μ H

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description	Remark
*	A-6794-137-A	DC-68 BOARD, COMPLETE (790, 960HF/HFMX)	
*	A-6794-137-A	DC-69 BOARD, COMPLETE (760, 761, L5MX/PA, L7HFMX/HFPA)	
	A-6794-137-A	DC-77 BOARD, COMPLETE (960HFGS/HFPX)	
	A-6794-137-A	DC-78 BOARD, COMPLETE (760HFPX, L5CS, L7HFGS)	

(Ref. No. 1,000 Series)			
< CONNECTOR >			
* CN001	1-766-714-11	CONNECTOR, BOARD TO BOARD 5P	
* CN002	1-766-713-11	CONNECTOR, BOARD TO BOARD 5P	

*	A-6782-809-A	DM-47 BOARD, COMPLETE (790, 960HF/HFMX)	
*	A-6782-803-A	DM-51 BOARD, COMPLETE (960HFGS/HFPX)	

(Ref. No. 1,000 Series)			
< CAPACITOR >			
C401	1-163-038-91	CERAMIC CHIP 0.1uF 25V	
C402	1-126-933-11	ELECT 100uF 20% 10V	
C405	1-163-181-00	CERAMIC CHIP 100PF 5% 50V	
< CONNECTOR >			
CN401	1-568-665-11	CONNECTOR, BOARD TO BOARD 11P	
CN402	1-580-850-11	CONNECTOR (DMS) 8P	
CN403	1-695-371-31	CONNECTOR, FFC/FPC 10P	
< IC >			
IC401	8-759-366-45	IC NJU3713G(TE2)	
< RESISTOR >			
R401	1-216-033-00	METAL CHIP 220 5% 1/10W	
R402	1-216-033-00	METAL CHIP 220 5% 1/10W	
R403	1-216-033-00	METAL CHIP 220 5% 1/10W	
R404	1-216-033-00	METAL CHIP 220 5% 1/10W	
R405	1-216-033-00	METAL CHIP 220 5% 1/10W	
R406	1-216-033-00	METAL CHIP 220 5% 1/10W	
R407	1-216-033-00	METAL CHIP 220 5% 1/10W	
R408	1-216-033-00	METAL CHIP 220 5% 1/10W	

Ref. No.	Part No.	Description	Remark
R409	1-216-049-91	METAL GLAZE 1K 5% 1/10W	
R410	1-216-049-91	METAL GLAZE 1K 5% 1/10W	
R411	1-216-198-91	METAL GLAZE 1K 5% 1/8W	
R412	1-216-049-91	METAL GLAZE 1K 5% 1/10W	
R413	1-247-815-91	CARBON 220 5% 1/4W	
R414	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R415	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R416	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R417	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R420	1-216-222-00	METAL GLAZE 10K 5% 1/8W	
< SWITCH >			
S402	1-571-977-11	SWITCH, TACTIL (● REC)	
S403	1-571-977-11	SWITCH, TACTIL (■ PAUSE)	
S404	1-571-977-11	SWITCH, TACTIL (Δ EJECT)	
S410	1-572-662-11	SWITCH, ROTARY (DUAL MODE SHUTTLE)	

*	A-6782-788-A	DM-48 BOARD, COMPLETE (760, 761, L5MX/PA, L7HFMX/HFPA)	
*	A-6782-818-A	DM-52 BOARD, COMPLETE (760HFPX, L5CS, L7HFGS)	

(Ref. No. 2,000 Series)			
< CONNECTOR >			
CN401	1-770-031-11	CONNECTOR, BOARD TO BOARD 7P	
CN402	1-580-850-11	CONNECTOR (DMS) 8P	
< DIODE >			
D401	8-719-911-19	DIODE 1SS119-25	
D402	8-719-911-19	DIODE 1SS119-25	
D403	8-719-911-19	DIODE 1SS119-25	
D404	8-719-911-19	DIODE 1SS119-25	
D405	8-719-911-19	DIODE 1SS119-25	
D406	8-719-911-19	DIODE 1SS119-25	

DM-48**DM-52****HI-23****HI-36****HI-24****HI-37**

Ref. No.	Part No.	Description	Remark
< SWITCH >			
S401	1-571-977-11	SWITCH, TACTIL (■ PAUSE)	
S406	1-571-977-11	SWITCH, TACTIL (● REC)	
S407	1-571-977-11	SWITCH, TACTIL (▲ EJECT)	
S410	1-572-662-11	SWITCH, ROTARY (DUAL MODE SHUTTLE)	
<hr/>			
*	A-6782-813-A	HI-23 BOARD, COMPLETE (790)	
*	A-6782-810-A	HI-23 BOARD, COMPLETE (960HF/HFEX)	
*	A-6782-807-A	HI-36 BOARD, COMPLETE (960HFCS/HFPX)	

(Ref. No. 1,000 Series)			
< CAPACITOR >			
C302	1-163-009-11	CERAMIC CHIP 0.001uF	10% 50V
C305	1-163-009-11	CERAMIC CHIP 0.001uF	10% 50V
C307	1-163-009-11	CERAMIC CHIP 0.001uF	10% 50V
< CONNECTOR >			
CN301	1-774-461-11	CONNECTOR, FFC/FPC 15P	
CN302	1-506-484-11	PIN, CONNECTOR 5P	
CN303	1-774-461-11	CONNECTOR, FFC/FPC 15P	
CN304	1-774-461-11	CONNECTOR, FFC/FPC 15P	
CN305	1-568-671-11	CONNECTOR, BOARD TO BOARD 11P	
CN306	1-691-036-21	PIN, CONNECTOR (PC BOARD) 4P	
< DIODE >			
D301	8-719-108-12	DIODE RD9. 1E-W	
D302	8-719-109-81	DIODE RD4. 7ES-B2	
D303	8-719-108-12	DIODE RD9. 1E-W	
D304	8-719-108-12	DIODE RD9. 1E-W	
D306	8-719-110-08	DIODE RD8. 2ES-B2	
< FLUORESCENT INDICATOR TUBE >			
FL301	1-517-477-11	TUBE, FLUORESCENT INDICATOR	
< JUMPER RESISTOR >			
JR001	1-216-295-00	METAL CHIP 0 5%	1/10W
JR002	1-216-296-00	METAL CHIP 0 5%	1/8W
JR003	1-216-296-00	METAL CHIP 0 5%	1/8W
JR004	1-216-296-00	METAL CHIP 0 5%	1/8W
JR005	1-216-295-00	METAL CHIP 0 5%	1/10W
< JACK >			
PJ301	1-766-861-11	JACK, PIN (3P) (LINE-2 IN)	
< RESISTOR >			
R301	1-216-022-00	METAL CHIP 75 5%	1/10W
R302	1-216-295-00	METAL CHIP 0 5%	1/10W

Ref. No.	Part No.	Description	Remark
R303	1-216-295-00	METAL CHIP 0 5%	1/10W
R304	1-216-069-00	METAL CHIP 6.8K 5%	1/10W
R308	1-216-073-00	METAL CHIP 10K 5%	1/10W
R309	1-216-073-00	METAL CHIP 10K 5%	1/10W
R310	1-249-429-11	CARBON 10K 5%	1/4W
R311	1-249-429-11	CARBON 10K 5%	1/4W
R312	1-216-073-00	METAL CHIP 10K 5%	1/10W
R313	1-216-057-00	METAL CHIP 2.2K 5%	1/10W
R324	1-216-224-91	METAL GLAZE 12K 5%	1/8W (960)
R325	1-216-073-00	METAL CHIP 10K 5%	1/10W (960)
R326	1-216-081-00	METAL CHIP 22K 5%	1/10W (960)
< SWITCH >			
S301	1-572-908-11	SWITCH, SLIDE (EDIT)	(960)
S302	1-762-171-11	SWITCH, SLIDE (COMMAND MODE)	(960)
S304	1-571-977-11	SWITCH, TACTIL (EASY SET UP)	
<hr/>			
*	A-6782-790-A	HI-24 BOARD, COMPLETE (760, 761)	
*	A-6782-801-A	HI-24 BOARD, COMPLETE (L5MX/PA)	
*	A-6782-816-A	HI-24 BOARD, COMPLETE (L7HFHX/HFPA)	

(Ref. No. 2,000 Series)			
*	3-966-234-01	HOLDER (A), FL	
< CAPACITOR >			
C302	1-163-009-11	CERAMIC CHIP 0.001uF	10% 50V (760, 761)
C305	1-163-009-11	CERAMIC CHIP 0.001uF	10% 50V (760, 761)
C307	1-163-009-11	CERAMIC CHIP 0.001uF	10% 50V (760, 761)
C309	1-126-967-11	ELECT 47uF	20% 16V
C310	1-163-059-00	CERAMIC CHIP 0.01uF	10% 50V
C313	1-163-035-00	CERAMIC CHIP 0.047uF	50V
< CONNECTOR >			
CN301	1-774-461-11	CONNECTOR, FFC/FPC 15P	
CN302	1-506-484-11	PIN, CONNECTOR 5P	(760, 761)
CN303	1-691-068-21	HOUSING, CONNECTOR 9P	
* CN304	1-691-406-11	CONNECTOR, BOARD TO BOARD 7P	
< DIODE >			
D301	8-719-108-12	DIODE RD9. 1E-W	(760, 761)
D302	8-719-109-81	DIODE RD4. 7ES-B2	(760, 761)
D303	8-719-108-12	DIODE RD9. 1E-W	(760, 761)

HI-24
HI-37
LE-12
LE-15
MA-251

Ref. No.	Part No.	Description	Remark
D304	8-719-108-12	DIODE RD9. 1E-W	(760, 761)
D305	8-719-911-19	DIODE 1SS119-25	
D306	8-719-911-19	DIODE 1SS119-25	
D307	8-719-911-19	DIODE 1SS119-25	
D308	8-719-911-19	DIODE 1SS119-25	
D309	8-719-911-19	DIODE 1SS119-25	
D310	8-719-911-19	DIODE 1SS119-25	
D320	8-719-911-19	DIODE 1SS119-25	
D321	8-719-110-08	DIODE RD8. 2ES-B2	
D324	8-719-911-19	DIODE 1SS119	
< FLUORESCENT INDICATOR TUBE >			
FL301	1-517-478-11	TUBE, FLUORESCENT INDICATOR	
< IC >			
IC301	8-759-366-44	IC uPD16312GB-3B4	
IC302	1-466-833-11	IC RAY-CATCHER BLOCK, REMOCAN	
< JUMPER RESISTOR >			
JR001	1-216-295-00	METAL CHIP 0 5% 1/10W	(760, 761)
JR302	1-216-296-00	METAL CHIP 0 5% 1/10W	
< COIL >			
L303	1-410-509-11	INDUCTOR 10uH	
< JACK >			
PJ301	1-774-509-11	JACK, PIN 3P (LINE-2 IN) (760, 761)	
< RESISTOR >			
R301	1-216-022-00	METAL CHIP 75 5% 1/10W	(760, 761)
R302	1-216-295-00	METAL CHIP 0 5% 1/10W	(760, 761)
R303	1-216-295-00	METAL CHIP 0 5% 1/10W	(760, 761)
R304	1-216-069-00	METAL CHIP 6.8K 5% 1/10W	
R306	1-249-435-11	CARBON 33K 5% 1/4W	
R307	1-249-425-11	CARBON 4.7K 5% 1/4W	
R308	1-216-295-00	METAL CHIP 0 5% 1/10W	
R309	1-216-049-91	METAL GLAZE 1K 5% 1/10W	
R310	1-216-049-91	METAL GLAZE 1K 5% 1/10W	
R311	1-216-049-91	METAL GLAZE 1K 5% 1/10W	
R312	1-216-295-00	METAL CHIP 0 5% 1/10W	
R313	1-216-295-00	METAL CHIP 0 5% 1/10W	
R314	1-216-295-00	METAL CHIP 0 5% 1/10W	
R315	1-216-295-00	METAL CHIP 0 5% 1/10W	

Ref. No.	Part No.	Description	Remark
R316	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R317	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R318	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R319	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R327	1-216-089-91	METAL GLAZE 47K 5% 1/10W	
< SWITCH >			
S304	1-571-977-11	SWITCH, TACTIL (CHANNEL -)	
S305	1-571-977-11	SWITCH, TACTIL (CHANNEL +)	
S306	1-571-977-11	SWITCH, TACTIL (INPUT SELECT) (760, 761)	
S307	1-571-977-11	SWITCH, TACTIL (TV/VTR)	
S308	1-571-977-11	SWITCH, TACTIL (TAPE SPEED) (760, 761)	
S312	1-571-977-11	SWITCH, TACTIL (TAPE SPEED) (L5, L7)	

*	A-6794-139-A	LE-12 BOARD, COMPLETE (790, 960HF/HFMX)	
*	A-6794-141-A	LE-15 BOARD, COMPLETE (960HFCS/HFPX)	

(Ref. No. 1,000 Series)			
< CONNECTOR >			
CN601	1-691-069-11	HOUSING, CONNECTOR 10P	
< LED >			
D601	8-719-056-07	LED SLR-342MC3F (REW)	
D602	8-719-056-07	LED SLR-342MC3F (REW)	
D603	8-719-056-07	LED SLR-342MC3F (REW)	
D604	8-719-056-07	LED SLR-342MCF3F (REW)	
D605	8-719-056-06	LED SLR-342DCT31 (PLAY/FF/REW)	
D606	8-719-056-07	LED SLR-342MC3F (PLAY/FF)	
D607	8-719-056-07	LED SLR-342MC3F (PLAY/FF)	
D608	8-719-056-07	LED SLR-342MC3F (FF)	
D609	8-719-056-07	LED SLR-342MC3F (FF)	

*	A-6782-800-A	MA-251 BOARD, COMPLETE (790)	
*	A-6782-815-A	MA-251 BOARD, COMPLETE (960)	

(Ref. No. 3,000 Series)			
*	3-960-273-01	SPACER, TOP END	
*	3-960-274-01	SPACER, LED	
< BUZZER >			
BZ151	1-529-104-11	BUZZER, PIEZOELECTRIC	
< CAPACITOR >			
C101	1-164-232-11	CERAMIC CHIP 0.01uF	50V
C102	1-126-967-11	ELECT 47uF	20% 16V
C103	1-164-344-11	CERAMIC CHIP 0.068uF	10% 25V

MA-251

Ref. No.	Part No.	Description		Remark
C104	1-124-248-00	ELECT	22uF	20% 35V
C105	1-124-584-00	ELECT	100uF	20% 10V
C106	1-163-009-11	CERAMIC CHIP	0.001uF	10% 50V
C107	1-163-017-00	CERAMIC CHIP	0.0047uF	5% 50V
C108	1-163-077-00	CERAMIC CHIP	0.1uF	10% 25V
C109	1-124-257-00	ELECT	2.2uF	20% 50V
C111	1-124-257-00	ELECT	2.2uF	20% 50V
C114	1-163-009-11	CERAMIC CHIP	0.001uF	10% 50V
C133	1-163-009-11	CERAMIC CHIP	0.001uF	10% 50V
C134	1-124-257-00	ELECT	2.2uF	20% 50V
C135	1-163-038-91	CERAMIC CHIP	0.1uF	25V
C136	1-163-038-91	CERAMIC CHIP	0.1uF	25V
C137	1-109-982-11	CERAMIC CHIP	1uF	10% 10V
C138	1-164-161-11	CERAMIC CHIP	0.0022uF	10% 100V
C139	1-126-964-11	ELECT	10uF	20% 50V
C140	1-163-038-91	CERAMIC CHIP	0.1uF	25V
C151	1-163-031-11	CERAMIC CHIP	0.01uF	50V
C152	1-163-031-11	CERAMIC CHIP	0.01uF	50V
C153	1-163-031-11	CERAMIC CHIP	0.01uF	50V
C154	1-163-099-00	CERAMIC CHIP	18PF	5% 50V
C155	1-163-231-11	CERAMIC CHIP	15PF	5% 50V
C156	1-163-031-11	CERAMIC CHIP	0.01uF	50V
C157	1-164-004-11	CERAMIC CHIP	0.1uF	10% 25V
C158	1-128-057-11	ELECT	330uF	20% 6.3V
C159	1-163-038-91	CERAMIC CHIP	0.1uF	25V
C160	1-125-507-11	CAPACITOR	0.22F	5.5V
C161	1-128-057-11	ELECT	330uF	20% 6.3V
C162	1-163-031-11	CERAMIC CHIP	0.01uF	50V
C163	1-163-038-91	CERAMIC CHIP	0.1uF	25V
C164	1-163-059-00	CERAMIC CHIP	0.01uF	10% 50V
C165	1-163-038-91	CERAMIC CHIP	0.1uF	25V
C166	1-126-916-11	ELECT	1000uF	20% 6.3V
C201	1-163-229-11	CERAMIC CHIP	12PF	5% 50V
C202	1-163-038-91	CERAMIC CHIP	0.1uF	25V
C203	1-163-229-11	CERAMIC CHIP	12PF	5% 50V
C204	1-163-009-11	CERAMIC CHIP	0.001uF	10% 50V
C205	1-163-081-00	CERAMIC CHIP	0.22uF	25V
C206	1-163-038-91	CERAMIC CHIP	0.1uF	25V
C207	1-164-004-11	CERAMIC CHIP	0.1uF	10% 25V
C208	1-124-584-00	ELECT	100uF	20% 10V
C209	1-163-038-91	CERAMIC CHIP	0.1uF	25V
C252	1-162-638-11	CERAMIC CHIP	1uF	16V
C253	1-163-031-11	CERAMIC CHIP	0.01uF	50V
C254	1-124-589-11	ELECT	47uF	20% 16V
C255	1-137-372-11	FILM	0.022uF	5% 50V
C256	1-137-441-11	FILM	0.027uF	5% 50V
C261	1-126-176-11	ELECT	220uF	20% 10V
C262	1-163-009-11	CERAMIC CHIP	0.001uF	10% 50V

Ref. No.	Part No.	Description		Remark
C264	1-163-009-11	CERAMIC CHIP	0.001uF	10% 50V
C266	1-163-009-11	CERAMIC CHIP	0.001uF	10% 50V
C267	1-163-009-11	CERAMIC CHIP	0.001uF	10% 50V
C273	1-163-031-11	CERAMIC CHIP	0.01uF	50V
C275	1-163-038-91	CERAMIC CHIP	0.1uF	25V
C291	1-163-077-00	CERAMIC CHIP	0.1uF	10% 25V
C292	1-163-077-00	CERAMIC CHIP	0.1uF	10% 25V
C294	1-124-455-00	ELECT	100uF	20% 16V
C295	1-163-077-00	CERAMIC CHIP	0.1uF	10% 25V
C296	1-163-077-00	CERAMIC CHIP	0.1uF	10% 25V
C298	1-163-038-91	CERAMIC CHIP	0.1uF	25V
C301	1-163-227-11	CERAMIC CHIP	10PF	0.5PF 50V
C302	1-163-121-00	CERAMIC CHIP	150PF	5% 50V
C303	1-163-239-11	CERAMIC CHIP	33PF	5% 50V
C304	1-124-589-11	ELECT	47uF	20% 16V
C305	1-124-589-11	ELECT	47uF	20% 16V(960)
C308	1-126-964-11	ELECT	10uF	20% 50V
C309	1-124-589-11	ELECT	47uF	20% 16V
C312	1-163-031-11	CERAMIC CHIP	0.01uF	50V
C313	1-163-031-11	CERAMIC CHIP	0.01uF	50V
C352	1-163-031-11	CERAMIC CHIP	0.01uF	50V
C353	1-163-241-11	CERAMIC CHIP	39PF	5% 50V
C354	1-124-589-11	ELECT	47uF	20% 16V
C356	1-163-031-11	CERAMIC CHIP	0.01uF	50V
C357	1-163-127-00	CERAMIC CHIP	270PF	5% 50V
C358	1-163-253-11	CERAMIC CHIP	120PF	5% 50V
C359	1-163-239-11	CERAMIC CHIP	33PF	5% 50V
C360	1-163-235-11	CERAMIC CHIP	22PF	5% 50V
C401	1-163-239-11	CERAMIC CHIP	33PF	5% 50V
C402	1-163-031-11	CERAMIC CHIP	0.01uF	50V
C406	1-124-589-11	ELECT	47uF	20% 16V
C407	1-163-031-11	CERAMIC CHIP	0.01uF	50V
C408	1-164-505-11	CERAMIC CHIP	2.2uF	16V
C409	1-124-589-11	ELECT	47uF	20% 16V
C410	1-163-227-11	CERAMIC CHIP	10PF	0.5PF 50V
C411	1-163-235-11	CERAMIC CHIP	22PF	5% 50V
C412	1-163-239-11	CERAMIC CHIP	33PF	5% 50V
C413	1-163-235-11	CERAMIC CHIP	22PF	5% 50V
C414	1-124-584-00	ELECT	100uF	20% 10V
C416	1-124-257-00	ELECT	2.2uF	20% 50V
C417	1-163-037-11	CERAMIC CHIP	0.022uF	10% 25V
C418	1-163-037-11	CERAMIC CHIP	0.022uF	10% 25V
C419	1-124-589-11	ELECT	47uF	20% 16V
C420	1-163-031-11	CERAMIC CHIP	0.01uF	50V
C421	1-162-306-11	CERAMIC	0.01uF	20% 16V
C422	1-126-160-11	ELECT	1uF	20% 50V
C423	1-163-139-00	CERAMIC CHIP	820PF	5% 50V
C424	1-124-589-11	ELECT	47uF	20% 16V
C425	1-164-004-11	CERAMIC CHIP	0.1uF	10% 25V

Ref. No.	Part No.	Description	Remark
C427	1-163-038-91	CERAMIC CHIP	0. 1uF 25V
C428	1-163-038-91	CERAMIC CHIP	0. 1uF 25V
C461	1-163-031-11	CERAMIC CHIP	0. 01uF 50V
C462	1-163-038-91	CERAMIC CHIP	0. 1uF 25V
C463	1-163-031-11	CERAMIC CHIP	0. 01uF 50V
C464	1-163-031-11	CERAMIC CHIP	0. 01uF 50V
C465	1-163-251-11	CERAMIC CHIP	100PF 5% 50V
C501	1-163-011-11	CERAMIC CHIP	0. 0015uF 10% 50V
C502	1-163-011-11	CERAMIC CHIP	0. 0015uF 10% 50V
C503	1-124-589-11	ELECT	47uF 20% 16V
C510	1-104-760-11	CERAMIC CHIP	0. 047uF 10% 50V
C520	1-126-162-11	ELECT	3. 3uF 20% 50V
C521	1-126-096-11	ELECT	10uF 20% 35V
C522	1-137-372-11	FILM	0. 022uF 5% 50V
C523	1-126-163-11	ELECT	4. 7uF 20% 50V
C524	1-124-589-11	ELECT	47uF 20% 16V
C525	1-137-370-11	FILM	0. 01uF 5% 50V
C530	1-126-162-11	ELECT	3. 3uF 20% 50V
C531	1-126-096-11	ELECT	10uF 20% 35V
C532	1-137-372-11	FILM	0. 022uF 5% 50V
C533	1-126-963-11	ELECT	4. 7uF 20% 50V
C534	1-124-589-11	ELECT	47uF 20% 16V
C535	1-137-370-11	FILM	0. 01uF 5% 50V
C541	1-137-372-11	FILM	0. 022uF 5% 50V
C542	1-115-438-91	ELECT	100uF 20% 10V
C551	1-124-248-00	ELECT	22uF 20% 35V
C552	1-124-234-00	ELECT	22uF 20% 16V
C561	1-126-160-11	ELECT	1uF 20% 50V
C562	1-137-370-11	FILM	0. 01uF 5% 50V
C563	1-126-163-11	ELECT	4. 7uF 20% 50V
C565	1-163-143-00	CERAMIC CHIP	0. 0012uF 5% 50V
C566	1-163-014-00	CERAMIC CHIP	0. 0027uF 5% 50V
C571	1-163-141-00	CERAMIC CHIP	0. 001uF 5% 50V
C572	1-163-141-00	CERAMIC CHIP	0. 001uF 5% 50V
C591	1-124-584-00	ELECT	100uF 20% 10V
C592	1-115-438-91	ELECT	100uF 20% 10V
C593	1-124-589-11	ELECT	47uF 20% 16V
C610	1-163-009-11	CERAMIC CHIP	0. 001uF 10% 50V
C631	1-163-038-91	CERAMIC CHIP	0. 1uF 25V
C632	1-163-038-91	CERAMIC CHIP	0. 1uF 25V
C633	1-163-038-91	CERAMIC CHIP	0. 1uF 25V
C634	1-163-009-11	CERAMIC CHIP	0. 001uF 10% 50V
C635	1-163-009-11	CERAMIC CHIP	0. 001uF 10% 50V
C636	1-126-967-11	ELECT	47uF 20% 16V
C637	1-163-038-91	CERAMIC CHIP	0. 1uF 25V
C681	1-163-031-11	CERAMIC CHIP	0. 01uF 50V
C682	1-126-967-11	ELECT	47uF 20% 16V
C683	1-126-935-11	ELECT	470uF 20% 6. 3V
C684	1-126-967-11	ELECT	47uF 20% 16V

Ref. No.	Part No.	Description	Remark
C701	1-126-967-11	ELECT	47uF 20% 16V
C702	1-126-964-11	ELECT	10uF 20% 50V
C703	1-126-964-11	ELECT	10uF 20% 50V
C704	1-163-009-11	CERAMIC CHIP	0. 001uF 10% 50V
C705	1-126-964-11	ELECT	10uF 20% 50V
C706	1-163-031-11	CERAMIC CHIP	0. 01uF 50V
C707	1-126-967-11	ELECT	47uF 20% 16V
C708	1-163-031-11	CERAMIC CHIP	0. 01uF 50V
C711	1-126-935-11	ELECT	470uF 20% 16V
C712	1-163-031-11	CERAMIC CHIP	0. 01uF 50V
C713	1-126-967-11	ELECT	47uF 20% 16V
C714	1-163-031-11	CERAMIC CHIP	0. 01uF 50V
C716	1-126-964-11	ELECT	10uF 20% 50V
C717	1-126-964-11	ELECT	10uF 20% 50V
C718	1-128-551-11	ELECT	22uF 20% 25V
C719	1-164-161-11	CERAMIC CHIP	0. 0022uF 10% 100V
C721	1-164-004-11	CERAMIC CHIP	0. 1uF 10% 25V
C725	1-163-809-11	CERAMIC CHIP	0. 047uF 10% 25V
C727	1-126-933-11	ELECT	100uF 20% 10V
C873	1-124-257-00	ELECT	2. 2uF 20% 50V
C881	1-104-696-11	FILM	0. 015uF 5% 100V(790)
C881	1-137-612-11	FILM	0. 0068uF 5% 100V(960)
C882	1-164-232-11	CERAMIC CHIP	0. 01uF 50V
C883	1-163-011-11	CERAMIC CHIP	0. 0015uF 10% 50V
C884	1-126-933-11	ELECT	100uF 20% 16V
C885	1-137-431-11	FILM	560PF 5% 50V
C891	1-104-697-11	FILM	0. 047uF 5% 100V(960)
C892	1-164-232-11	CERAMIC CHIP	0. 01uF 50V(960)
C893	1-163-011-11	CERAMIC CHIP	0. 0015uF 10% 50V(960)
C894	1-124-455-00	ELECT	100uF 20% 16V(960)
< JACK >			
CJ621	1-764-222-11	JACK, PIN 6P (LINE-1 IN/LINE OUT)	
CJ631	1-563-330-11	JACK (CONTROL S IN)	
CJ632	1-566-822-21	JACK (CONTROL S OUT)	
< CONNECTOR >			
CN101	1-506-468-11	PIN, CONNECTOR 3P	
* CN271	1-766-538-11	CONNECTOR, BOARD TO BOARD 8P	
* CN275	1-766-717-11	CONNECTOR, BOARD TO BOARD 5P	
* CN281	1-766-537-11	CONNECTOR (HMD) 5P	
* CN291	1-766-716-11	CONNECTOR, BOARD TO BOARD 3P	
CN301	1-766-718-11	CONNECTOR, BOARD TO BOARD 17P	
* CN501	1-766-600-11	CONNECTOR, BOARD TO BOARD 7P	
* CN851	1-560-892-00	PIN, CONNECTOR 4P	
* CN881	1-560-891-00	PIN, CONNECTOR 3P	
CN901	1-774-461-11	CONNECTOR, FFC/FPC 15P	
CN902	1-774-461-11	CONNECTOR, FFC/FPC 15P	

Ref. No.	Part No.	Description	Remark
CN903	1-774-461-11	CONNECTOR, FFC/FPC 15P	
CN904	1-766-980-71	CONNECTOR, FFC/FPC 7P	
CN905	1-506-470-11	PIN, CONNECTOR 5P	
CN906	1-569-338-11	CONNECTOR, BOARD TO BOARD 19P	
CN907	1-506-469-11	PIN, CONNECTOR 4P	
< DIODE >			
D151	8-719-200-82	DIODE 11ES2	
D152	8-719-200-82	DIODE 11ES2	
D201	8-719-200-82	DIODE 11ES2	
D202	8-719-801-48	DIODE 1SS193	
D251	8-719-801-48	DIODE 1SS193	
D261	8-719-048-26	LED GL528V1	
D265	8-719-109-93	DIODE RD6. 2ES-B2	
D267	8-719-109-93	DIODE RD6. 2ES-B2	
D291	8-719-977-24	DIODE DTZ9. 1B	
D301	8-719-911-19	DIODE 1SS119-25	
D402	8-719-801-48	DIODE 1SS193	
D403	8-719-801-48	DIODE 1SS193	
D591	8-719-404-46	DIODE MA110	
D610	8-719-109-74	DIODE RD4. 3ES-B1	
D631	8-719-110-08	DIODE RD8. 2ES-B2	
D632	8-719-110-08	DIODE RD8. 2ES-B2	
D633	8-719-110-08	DIODE RD8. 2ES-B2	
D635	8-719-110-08	DIODE RD8. 2ES-B2	
D701	8-719-200-82	DIODE 11ES2	
△D702	8-719-800-76	DIODE 1SS226	
D703	8-719-110-78	DIODE RB33ES-B2	
D902	8-719-200-82	DIODE 11ES2	
< IC >			
IC101	8-759-246-14	IC TA8823N	
IC131	8-759-364-14	IC LC7455M-TLM	
IC151	8-752-868-41	IC CXP82948-002Q	
IC152	8-759-248-87	IC MM1256XF-BE	
IC153	8-759-278-56	IC AK6440HF-E2	
IC201	8-752-871-05	IC CXP87248A-008Q	
IC251	8-759-335-76	IC uPC5023GR-089-E2	
IC291	8-759-294-26	IC BA6209-V2	
IC302	1-801-097-11	IC YC MODULE 3 (NTSC-YC)	
IC401	8-759-288-96	IC MB90089PFG-118R	
IC402	8-759-164-09	IC LA7218M	
IC461	8-759-295-66	IC BA7653AF-E2	
IC501	8-759-365-32	IC XLH7779K-VP	
IC551	8-759-089-84	IC BA7755AF	
IC631	8-759-356-27	IC NJM2129M-TE2	
IC701	8-759-701-59	IC NJM78M09FA	

Ref. No.	Part No.	Description	Remark
< JUMPER RESISTOR >			
JP1	1-216-296-00	METAL CHIP	0 5% 1/8W
JP14	1-216-296-00	METAL CHIP	0 5% 1/8W
JP17	1-216-296-00	METAL CHIP	0 5% 1/8W
JP31	1-216-296-00	METAL CHIP	0 5% 1/8W
JP43	1-216-296-00	METAL CHIP	0 5% 1/8W
JP45	1-216-296-00	METAL CHIP	0 5% 1/8W
JP53	1-216-296-00	METAL CHIP	0 5% 1/8W
JP54	1-216-296-00	METAL CHIP	0 5% 1/8W
JP56	1-216-296-00	METAL CHIP	0 5% 1/8W
JP77	1-216-296-00	METAL CHIP	0 5% 1/8W
JP78	1-216-296-00	METAL CHIP	0 5% 1/8W
JP81	1-216-296-00	METAL CHIP	0 5% 1/8W
JP82	1-216-296-00	METAL CHIP	0 5% 1/8W
JP90	1-216-296-00	METAL CHIP	0 5% 1/8W
JP049	1-216-295-00	METAL CHIP	0 5% 1/10W
JP083	1-216-295-00	METAL CHIP	0 5% 1/10W
< JUMPER RESISTOR >			
JR101	1-216-295-00	METAL CHIP	0 5% 1/10W
JR131	1-216-295-00	METAL CHIP	0 5% 1/10W
JR132	1-216-295-00	METAL CHIP	0 5% 1/10W
JR151	1-216-295-00	METAL CHIP	0 5% 1/10W
JR152	1-216-295-00	METAL CHIP	0 5% 1/10W
JR252	1-216-295-00	METAL CHIP	0 5% 1/10W
JR253	1-216-295-00	METAL CHIP	0 5% 1/10W
JR301	1-216-295-00	METAL CHIP	0 5% 1/10W
JR303	1-216-295-00	METAL CHIP	0 5% 1/10W
JR305	1-216-295-00	METAL CHIP	0 5% 1/10W
JR404	1-216-295-00	METAL CHIP	0 5% 1/10W
JR461	1-216-295-00	METAL CHIP	0 5% 1/10W
JR576	1-216-295-00	METAL CHIP	0 5% 1/10W
JR631	1-216-295-00	METAL CHIP	0 5% 1/10W
JR633	1-216-295-00	METAL CHIP	0 5% 1/10W
JR635	1-216-295-00	METAL CHIP	0 5% 1/10W
JR702	1-216-295-00	METAL CHIP	0 5% 1/10W
JR703	1-216-295-00	METAL CHIP	0 5% 1/10W
JR706	1-216-295-00	METAL CHIP	0 5% 1/10W
JR707	1-216-295-00	METAL CHIP	0 5% 1/10W
JR710	1-216-295-00	METAL CHIP	0 5% 1/10W
JR716	1-216-295-00	METAL CHIP	0 5% 1/10W
JR885	1-216-295-00	METAL CHIP	0 5% 1/10W (790)
JR895	1-216-295-00	METAL CHIP	0 5% 1/10W (960)
< COIL >			
L101	1-408-421-00	INDUCTOR	100uH
L151	1-408-970-21	INDUCTOR	10uH
L201	1-408-970-21	INDUCTOR	10uH

<p>The components identified by mark △ or dotted line with mark ▲ are critical for safety. Replace only with part number specified.</p>	<p>Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.</p>
---	---

Ref. No.	Part No.	Description	Remark
L301	1-410-521-11	INDUCTOR	100uH
L302	1-414-186-31	INDUCTOR	33uH
L303	1-414-186-31	INDUCTOR	33uH
L305	1-414-186-31	INDUCTOR	33uH
L351	1-410-525-11	INDUCTOR	220uH
L352	1-414-189-31	INDUCTOR	100uH
L353	1-410-513-11	INDUCTOR	22uH
L401	1-408-421-00	INDUCTOR	100uH
L403	1-408-974-21	INDUCTOR	22uH
L404	1-408-421-00	INDUCTOR	100uH
L461	1-414-189-31	INDUCTOR	100uH
L681	1-410-482-31	INDUCTOR	100uH
L701	1-414-183-41	INDUCTOR	10uH
L702	1-414-189-31	INDUCTOR	100uH
L703	1-414-183-41	INDUCTOR	10uH
L704	1-410-501-11	INDUCTOR	2. 2uH
L705	1-414-187-11	INDUCTOR	47uH
L881	1-410-687-11	INDUCTOR	1. 2mH
L891	1-410-687-11	INDUCTOR	1. 2mH (960)
L901	1-412-364-11	INDUCTOR	0uH
< PIN CABLE >			
P701	1-555-110-00	CABLE, PIN	
< PHOTO INTERRUPTER >			
PH261	8-749-010-19	PHOTO INTERRUPTER GP3S113	
PH262	8-749-010-20	PHOTO INTERRUPTER GP3S114	
< IC LINK >			
△PS271	1-532-727-11	LINK, IC ICP-N5 (0. 25A)	
△PS885	1-532-727-11	LINK, IC ICP-N5 (0. 25A)	
< THERMISTOR >			
△PTH592	1-202-855-00	THERMISTOR, POSITIVE	
< TRANSISTOR >			
Q131	8-729-010-05	TRANSISTOR	MSB709-RT1
Q132	8-729-421-19	TRANSISTOR	UN2213
Q201	8-729-010-25	TRANSISTOR	MSD601-RT1
Q202	8-729-901-06	TRANSISTOR	DTA144EK
Q261	8-729-025-92	PHOTO TRANSISTOR	PT380F
Q262	8-729-025-92	PHOTO TRANSISTOR	PT380F
Q263	8-729-281-53	TRANSISTOR	2SC1815-GR
Q301	8-729-421-19	TRANSISTOR	UN2213
Q306	8-729-421-19	TRANSISTOR	UN2213
Q352	8-729-010-29	TRANSISTOR	MSD601-RST1
Q353	8-729-010-29	TRANSISTOR	MSD601-RST1

Ref. No.	Part No.	Description	Remark
Q402	8-729-901-06	TRANSISTOR	DTA144EK
Q404	8-729-010-05	TRANSISTOR	MSB709-RT1
Q406	8-729-010-05	TRANSISTOR	MSB709-RT1
Q407	8-729-010-05	TRANSISTOR	MSB709-RT1
Q413	8-729-010-25	TRANSISTOR	MSD601-RT1
Q591	8-729-804-41	TRANSISTOR	2SB1122-S
Q592	8-729-820-68	TRANSISTOR	2SD1802FA-S
Q681	8-729-010-05	TRANSISTOR	MSB709-RT1
Q701	8-729-421-19	TRANSISTOR	UN2213
△Q703	8-729-173-38	TRANSISTOR	2SA733-K
Q705	8-729-010-29	TRANSISTOR	MSD601-RST1
Q707	8-729-010-05	TRANSISTOR	MSB709-RT1
Q708	8-729-010-05	TRANSISTOR	MSB709-RT1
Q709	8-729-010-29	TRANSISTOR	MSD601-RST1
Q715	8-729-901-06	TRANSISTOR	DTA144EK
Q716	8-729-901-06	TRANSISTOR	DTA144EK
Q717	8-729-421-19	TRANSISTOR	UN2213
Q881	8-729-012-31	TRANSISTOR	2SC4040-TL2-Q
Q882	8-729-900-51	TRANSISTOR	DTA114TK
Q886	8-729-010-29	TRANSISTOR	MSD601-RST1
Q891	8-729-012-31	TRANSISTOR	2SC4040-TL2-Q (960)
Q892	8-729-900-51	TRANSISTOR	DTA114TK (960)
< RESISTOR >			
R101	1-216-119-00	METAL CHIP	820K 5% 1/10W
R102	1-216-093-00	METAL CHIP	68K 5% 1/10W
R103	1-216-097-91	METAL GLAZE	100K 5% 1/10W
R104	1-216-097-91	METAL GLAZE	100K 5% 1/10W
R105	1-216-085-00	METAL CHIP	33K 5% 1/10W
R106	1-216-065-00	METAL CHIP	4. 7K 5% 1/10W
R107	1-216-186-00	METAL GLAZE	330 5% 1/8W
R108	1-216-121-91	METAL GLAZE	1M 5% 1/10W
R111	1-216-097-91	METAL GLAZE	100K 5% 1/10W
R131	1-216-061-00	METAL CHIP	3. 3K 5% 1/10W
R132	1-216-121-91	METAL GLAZE	1M 5% 1/10W
R133	1-216-073-00	METAL CHIP	10K 5% 1/10W
R135	1-216-025-91	METAL GLAZE	100 5% 1/10W
R136	1-216-049-91	METAL GLAZE	1K 5% 1/10W
R137	1-216-083-00	METAL CHIP	27K 5% 1/10W
R138	1-216-079-00	METAL CHIP	18K 5% 1/10W
R139	1-216-089-91	METAL GLAZE	47K 5% 1/10W
R140	1-216-206-00	METAL GLAZE	2. 2K 5% 1/8W
R141	1-216-222-00	METAL GLAZE	10K 5% 1/8W
R151	1-216-095-00	METAL CHIP	82K 5% 1/10W
R152	1-216-049-91	METAL GLAZE	1K 5% 1/10W
R153	1-216-113-00	METAL CHIP	470K 5% 1/10W
R154	1-216-049-91	METAL GLAZE	1K 5% 1/10W
R157	1-216-113-00	METAL CHIP	470K 5% 1/10W
R158	1-216-095-00	METAL CHIP	82K 5% 1/10W

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark
R159	1-216-049-91	METAL GLAZE	1K 5% 1/10W
R160	1-216-049-91	METAL GLAZE	1K 5% 1/10W
R161	1-216-049-91	METAL GLAZE	1K 5% 1/10W
R162	1-216-089-91	METAL GLAZE	47K 5% 1/10W
R163	1-216-073-00	METAL CHIP	10K 5% 1/10W
R164	1-216-073-00	METAL CHIP	10K 5% 1/10W
R165	1-216-073-00	METAL CHIP	10K 5% 1/10W
R166	1-216-073-00	METAL CHIP	10K 5% 1/10W
R167	1-216-222-00	METAL GLAZE	10K 5% 1/8W
R168	1-216-095-00	METAL CHIP	82K 5% 1/10W
R169	1-216-113-00	METAL CHIP	470K 5% 1/10W
R201	1-216-073-00	METAL CHIP	10K 5% 1/10W
R203	1-216-073-00	METAL CHIP	10K 5% 1/10W
R204	1-216-073-00	METAL CHIP	10K 5% 1/10W
R205	1-216-049-91	METAL GLAZE	1K 5% 1/10W
R206	1-216-073-00	METAL CHIP	10K 5% 1/10W
R207	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
R208	1-216-049-91	METAL GLAZE	1K 5% 1/10W
R209	1-216-073-00	METAL CHIP	10K 5% 1/10W
R210	1-216-073-00	METAL CHIP	10K 5% 1/10W
R211	1-216-101-00	METAL CHIP	150K 5% 1/10W
R212	1-216-089-91	METAL GLAZE	47K 5% 1/10W
R213	1-216-077-00	METAL CHIP	15K 5% 1/10W
R214	1-216-085-00	METAL CHIP	33K 5% 1/10W
R215	1-216-095-00	METAL CHIP	82K 5% 1/10W
R218	1-216-089-91	METAL GLAZE	47K 5% 1/10W
R219	1-216-089-91	METAL GLAZE	47K 5% 1/10W
R233	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R234	1-216-049-91	METAL GLAZE	1K 5% 1/10W
R251	1-216-049-91	METAL GLAZE	1K 5% 1/10W
R252	1-216-079-00	METAL CHIP	18K 5% 1/10W
R253	1-216-689-11	METAL CHIP	39K 0.5% 1/10W
R254	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R255	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R256	1-216-103-91	METAL GLAZE	180K 5% 1/10W
R261	1-249-400-11	CARBON	39 5% 1/4W
R262	1-249-400-11	CARBON	39 5% 1/4W
R263	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R264	1-216-107-00	METAL CHIP	270K 5% 1/10W
R265	1-216-107-00	METAL CHIP	270K 5% 1/10W
R266	1-249-413-11	CARBON	470 5% 1/4W
R267	1-216-089-91	METAL GLAZE	47K 5% 1/10W
R268	1-216-089-91	METAL GLAZE	47K 5% 1/10W
R271	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
R274	1-216-083-00	METAL CHIP	27K 5% 1/10W
R275	1-216-093-00	METAL CHIP	68K 5% 1/10W
R276	1-216-056-00	METAL GLAZE	2K 5% 1/10W
R277	1-216-068-00	METAL CHIP	6.2K 5% 1/10W
R278	1-216-075-00	METAL CHIP	12K 5% 1/10W

Ref. No.	Part No.	Description	Remark
R281	1-216-238-91	METAL GLAZE	47K 5% 1/8W
R282	1-216-238-91	METAL GLAZE	47K 5% 1/8W
R283	1-216-238-91	METAL GLAZE	47K 5% 1/8W
R284	1-216-238-91	METAL GLAZE	47K 5% 1/8W
R293	1-216-295-00	METAL CHIP	0 5% 1/10W
R301	1-216-295-00	METAL CHIP	0 5% 1/10W
R302	1-216-053-00	METAL CHIP	1.5K 5% 1/10W (790)
R302	1-216-052-00	METAL CHIP	1.3K 5% 1/10W (960)
R303	1-216-031-00	METAL CHIP	180 5% 1/10W
R304	1-208-798-11	METAL GLAZE	4.7K 0.50% 1/10W
R305	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R306	1-216-081-00	METAL CHIP	22K 5% 1/10W
R313	1-216-041-00	METAL CHIP	470 5% 1/10W
R314	1-216-240-00	METAL GLAZE	56K 5% 1/8W
R315	1-216-105-91	METAL GLAZE	220K 5% 1/10W
R317	1-216-107-00	METAL CHIP	270K 5% 1/10W
R335	1-216-073-00	METAL CHIP	10K 5% 1/10W
R351	1-216-049-91	METAL GLAZE	1K 5% 1/10W
R352	1-216-051-00	METAL CHIP	1.2K 5% 1/10W
R353	1-216-045-00	METAL CHIP	680 5% 1/10W
R354	1-216-083-00	METAL CHIP	27K 5% 1/10W
R355	1-216-089-91	METAL GLAZE	47K 5% 1/10W
R356	1-216-055-00	METAL CHIP	1.8K 5% 1/10W
R357	1-216-067-00	METAL CHIP	5.6K 5% 1/10W
R358	1-216-035-00	METAL CHIP	270 5% 1/10W
R401	1-216-049-91	METAL GLAZE	1K 5% 1/10W
R404	1-216-073-00	METAL CHIP	10K 5% 1/10W
R407	1-249-414-11	CARBON	560 5% 1/4W
R408	1-216-101-00	METAL CHIP	150K 5% 1/10W
R409	1-216-063-91	METAL GLAZE	3.9K 5% 1/10W
R410	1-216-043-91	METAL GLAZE	560 5% 1/10W
R411	1-216-025-91	METAL GLAZE	100 5% 1/10W
R412	1-216-295-00	METAL CHIP	0 5% 1/10W
R413	1-216-295-00	METAL CHIP	0 5% 1/10W
R414	1-216-081-00	METAL CHIP	22K 5% 1/10W
R415	1-216-051-00	METAL CHIP	1.2K 5% 1/10W
R416	1-216-059-00	METAL CHIP	2.7K 5% 1/10W
R417	1-216-033-00	METAL CHIP	220 5% 1/10W
R418	1-216-033-00	METAL CHIP	220 5% 1/10W
R421	1-216-230-00	METAL GLAZE	22K 5% 1/8W
R423	1-216-073-00	METAL CHIP	10K 5% 1/10W
R461	1-216-295-00	METAL CHIP	0 5% 1/10W
R462	1-216-295-00	METAL CHIP	0 5% 1/10W
R501	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
R502	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
R503	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
R504	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
R505	1-216-295-00	METAL CHIP	0 5% 1/10W

Ref. No.	Part No.	Description	Remark		
R506	1-216-295-00	METAL CHIP	0	5%	1/10W
R507	1-216-295-00	METAL CHIP	0	5%	1/10W
R510	1-216-129-00	METAL CHIP	2. 2M	5%	1/10W
R514	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R515	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R521	1-216-073-00	METAL CHIP	10K	5%	1/10W
R522	1-216-050-00	METAL GLAZE	1. 1K	5%	1/10W
R523	1-216-079-00	METAL CHIP	18K	5%	1/10W
R524	1-216-067-00	METAL CHIP	5. 6K	5%	1/10W
R525	1-208-809-11	METAL GLAZE	13K	0. 50%	1/10W
R531	1-216-073-00	METAL CHIP	10K	5%	1/10W
R532	1-216-050-00	METAL GLAZE	1. 1K	5%	1/10W
R533	1-216-079-00	METAL CHIP	18K	5%	1/10W
R534	1-216-067-00	METAL CHIP	5. 6K	5%	1/10W
R535	1-208-806-11	METAL GLAZE	10K	0. 50%	1/10W
R541	1-216-081-00	METAL CHIP	22K	5%	1/10W
R551	1-216-129-00	METAL CHIP	2. 2M	5%	1/10W
R561	1-216-073-00	METAL CHIP	10K	5%	1/10W
R562	1-216-109-00	METAL CHIP	330K	5%	1/10W
R563	1-216-069-00	METAL CHIP	6. 8K	5%	1/10W
R564	1-216-041-00	METAL CHIP	470	5%	1/10W
R565	1-216-099-00	METAL CHIP	120K	5%	1/10W
R566	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R567	1-216-295-00	METAL CHIP	0	5%	1/10W
R571	1-216-073-00	METAL CHIP	10K	5%	1/10W
R572	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R573	1-216-214-00	METAL GLAZE	4. 7K	5%	1/8W
R575	1-216-295-00	METAL CHIP	0	5%	1/10W
R591	1-249-421-11	CARBON	2. 2K	5%	1/4W
R592	1-216-069-00	METAL CHIP	6. 8K	5%	1/10W
R601	1-216-022-00	METAL CHIP	75	5%	1/10W
R611	1-216-041-00	METAL CHIP	470	5%	1/10W
R612	1-216-041-00	METAL CHIP	470	5%	1/10W
R631	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R681	1-216-037-00	METAL CHIP	330	5%	1/10W
R683	1-249-407-11	CARBON	150	5%	1/4W
R684	1-249-408-11	CARBON	180	5%	1/4W
R685	1-216-021-00	METAL CHIP	68	5%	1/10W
R701	1-216-041-00	METAL CHIP	470	5%	1/10W
R702	1-216-041-00	METAL CHIP	470	5%	1/10W
R703	1-249-404-00	CARBON	82	5%	1/4W
R704	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R706	1-216-073-00	METAL CHIP	10K	5%	1/10W
R713	1-216-041-00	METAL CHIP	470	5%	1/10W
R714	1-216-041-00	METAL CHIP	470	5%	1/10W
R715	1-216-025-91	METAL GLAZE	100	5%	1/10W
R716	1-216-065-00	METAL CHIP	4. 7K	5%	1/10W
R717	1-216-073-00	METAL CHIP	10K	5%	1/10W

Ref. No.	Part No.	Description	Remark		
R719	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R720	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R721	1-216-037-00	METAL CHIP	330	5%	1/10W
R722	1-216-061-00	METAL CHIP	3. 3K	5%	1/10W
R725	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R726	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R733	1-216-081-00	METAL CHIP	22K	5%	1/10W
R734	1-216-081-00	METAL CHIP	22K	5%	1/10W
R736	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R737	1-216-295-00	METAL CHIP	0	5%	1/10W
R740	1-216-093-00	METAL CHIP	68K	5%	1/10W
R747	1-249-421-11	CARBON	2. 2K	5%	1/4W
R748	1-216-081-00	METAL CHIP	22K	5%	1/10W
R749	1-249-437-11	CARBON	47K	5%	1/4W
R874	1-216-075-00	METAL CHIP	12K	5%	1/10W
R881	1-216-081-00	METAL CHIP	22K	5%	1/10W
△R882	1-249-389-11	CARBON	4. 7	5%	1/4W F(790)
△R882	1-249-395-11	CARBON	15	5%	1/4W F(960)
R885	1-216-071-00	METAL CHIP	8. 2K	5%	1/10W
R886	1-216-073-00	METAL CHIP	10K	5%	1/10W
R887	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R891	1-216-083-00	METAL CHIP	27K	5%	1/10W (960)
△R892	1-249-394-11	CARBON	12	5%	1/4W F(960)
< RF MODULATOR >					
△RF701	1-466-989-11	MODULATOR, RF			
< VARIABLE RESISTOR >					
RV521	1-241-763-11	RES, ADJ, CERMET 4.7K			
RV531	1-241-763-11	RES, ADJ, CERMET 4.7K			
RV541	1-241-764-11	RES, ADJ, CERMET 10K			
< SWITCH >					
S251	1-570-953-11	SWITCH, PUSH (1 KEY) (REC PRE)			
< TRANSFORMER >					
T881	1-423-414-11	TRANSFORMER, BIAS OSCILLATION	(790)		
T881	1-423-413-11	TRANSFORMER, BIAS OSCILLATION	(960)		
T891	1-423-415-11	TRANSFORMER, BIAS OSCILLATION	(960)		
< TUNER >					
△TU701	8-598-342-00	TUNER BTF-WA406			
< VIBRATOR >					
X151	1-579-463-11	VIBRATOR, CRYSTAL (32.768kHz)			
X201	1-760-494-11	VIBRATOR, CRYSTAL (16MHz)			
X401	1-577-381-11	VIBRATOR, CRYSTAL (14MHz)			

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark
X402	1-577-165-11	VIBLATOR, CERAMIC (500kHz)	
<hr/>			
*	A-6782-792-A	MA-252 BOARD, COMPLETE (760, 761)	
*	A-6782-802-A	MA-252 BOARD, COMPLETE (L5)	
*	A-6782-817-A	MA-252 BOARD, COMPLETE (L7)	

(Ref. No. 4, 000 Series)			
*	3-960-273-01	SPACER, TOP END	
*	3-960-274-01	SPACER, LED	
< CAPACITOR >			
C101	1-164-232-11	CERAMIC CHIP	0.01uF 50V
C102	1-126-967-11	ELECT	47uF 20% 16V
C103	1-164-344-11	CERAMIC CHIP	0.068uF 10% 25V
C104	1-124-248-00	ELECT	22uF 20% 35V
C105	1-124-584-00	ELECT	100uF 20% 10V
C106	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V
C107	1-163-017-00	CERAMIC CHIP	0.0047uF 5% 50V
C108	1-163-077-00	CERAMIC CHIP	0.1uF 10% 25V
C109	1-124-257-00	ELECT	2.2uF 20% 50V
C111	1-124-257-00	ELECT	2.2uF 20% 50V
C114	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V
C133	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V (760, 761)
C134	1-124-257-00	ELECT	2.2uF 20% 50V (760, 761)
C135	1-163-077-00	CERAMIC CHIP	0.1uF 10% 25V (760, 761)
C136	1-163-077-00	CERAMIC CHIP	0.1uF 10% 25V (760, 761)
C137	1-109-982-11	CERAMIC CHIP	1uF 10% 10V (760, 761)
C138	1-164-161-11	CERAMIC CHIP	0.0022uF 10% 100V (760, 761)
C139	1-126-964-11	ELECT	10uF 20% 50V (760, 761)
C140	1-163-038-91	CERAMIC CHIP	0.1uF 25V (760, 761)
C160	1-125-507-11	CAPACITOR	0.22F 5.5V
C201	1-163-229-11	CERAMIC CHIP	12PF 5% 50V
C202	1-163-038-91	CERAMIC CHIP	0.1uF 25V
C203	1-163-229-11	CERAMIC CHIP	12PF 5% 50V
C204	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V
C205	1-163-081-00	CERAMIC CHIP	0.22uF 25V
C206	1-163-038-91	CERAMIC CHIP	0.1uF 25V
C207	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V
C208	1-124-584-00	ELECT	100uF 20% 10V
C209	1-163-038-91	CERAMIC CHIP	0.1uF 25V

Ref. No.	Part No.	Description	Remark
C210	1-124-589-11	ELECT	47uF 20% 16V
C211	1-163-059-00	CERAMIC CHIP	0.01uF 10% 50V
C214	1-163-038-91	CERAMIC CHIP	0.1uF 25V
C215	1-163-237-11	CERAMIC CHIP	27PF 5% 50V
C216	1-163-231-11	CERAMIC CHIP	15PF 5% 50V
C252	1-162-638-11	CERAMIC CHIP	1uF 16V
C253	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C254	1-124-589-11	ELECT	47uF 20% 16V
C255	1-137-372-11	FILM	0.022uF 5% 50V
C256	1-137-441-11	FILM	0.027uF 5% 50V
C261	1-126-176-11	ELECT	220uF 20% 10V
C262	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V
C264	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V
C266	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V
C267	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V
C273	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C275	1-163-038-91	CERAMIC CHIP	0.1uF 25V
C291	1-163-077-00	CERAMIC CHIP	0.1uF 10% 25V
C292	1-163-077-00	CERAMIC CHIP	0.1uF 10% 25V
C294	1-124-455-00	ELECT	100uF 20% 16V
C295	1-163-077-00	CERAMIC CHIP	0.1uF 10% 25V
C296	1-163-077-00	CERAMIC CHIP	0.1uF 10% 25V
C298	1-163-038-91	CERAMIC CHIP	0.1uF 25V
C301	1-163-227-11	CERAMIC CHIP	10PF 0.5PF 50V
C302	1-163-121-00	CERAMIC CHIP	150PF 5% 50V
C303	1-163-239-11	CERAMIC CHIP	33PF 5% 50V
C304	1-124-589-11	ELECT	47uF 20% 16V
C305	1-124-589-11	ELECT	47uF 20% 16V (760, 761)
C308	1-126-964-11	ELECT	10uF 20% 50V
C309	1-124-589-11	ELECT	47uF 20% 16V
C312	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C313	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C352	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C353	1-163-241-11	CERAMIC CHIP	39PF 5% 50V
C354	1-124-589-11	ELECT	47uF 20% 16V
C356	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C357	1-163-127-00	CERAMIC CHIP	270PF 5% 50V
C358	1-163-253-11	CERAMIC CHIP	120PF 5% 50V
C359	1-163-239-11	CERAMIC CHIP	33PF 5% 50V
C360	1-163-235-11	CERAMIC CHIP	22PF 5% 50V
C401	1-124-589-11	ELECT	47uF 20% 16V
C402	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C403	1-163-099-00	CERAMIC CHIP	18PF 5% 50V
C404	1-163-102-00	CERAMIC CHIP	24PF 5% 50V
C409	1-124-589-11	ELECT	47uF 20% 16V
C410	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C417	1-163-119-00	CERAMIC CHIP	120PF 5% 50V
C418	1-126-160-11	ELECT	1uF 20% 50V

Ref. No.	Part No.	Description	Remark
C420	1-130-481-00	MYLAR	0.0068uF 5% 50V
C421	1-124-499-11	ELECT. NONPOLAR	1uF 20% 50V
C422	1-130-487-00	MYLAR	0.022uF 5% 50V
C423	1-124-465-00	ELECT	0.47uF 20% 50V
C424	1-163-102-00	CERAMIC CHIP	24PF 5% 50V
C427	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C461	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C462	1-163-038-91	CERAMIC CHIP	0.1uF 25V
C463	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C464	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C465	1-163-251-11	CERAMIC CHIP	100PF 5% 50V (760, 761)
C501	1-163-011-11	CERAMIC CHIP	0.0015uF 10% 50V (760, 761, L7)
C502	1-163-011-11	CERAMIC CHIP	0.0015uF 10% 50V (760, 761, L7)
C503	1-124-589-11	ELECT	47uF 20% 16V (760, 761, L7)
C510	1-104-760-11	CERAMIC CHIP	0.047uF 10% 50V (760, 761, L5)
C520	1-126-162-11	ELECT	3.3uF 20% 50V (760, 761, L7)
C521	1-126-096-11	ELECT	10uF 20% 35V (760, 761, L7)
C522	1-137-372-11	FILM	0.022uF 5% 50V (760, 761, L7)
C523	1-126-163-11	ELECT	4.7uF 20% 50V (760, 761, L7)
C524	1-124-589-11	ELECT	47uF 20% 16V (760, 761, L7)
C525	1-137-370-11	FILM	0.01uF 5% 50V (760, 761, L7)
C530	1-126-162-11	ELECT	3.3uF 20% 50V (760, 761, L7)
C531	1-126-096-11	ELECT	10uF 20% 35V (760, 761, L7)
C532	1-137-372-11	FILM	0.022uF 5% 50V (760, 761, L7)
C533	1-126-963-11	ELECT	4.7uF 20% 50V (760, 761, L7)
C534	1-124-589-11	ELECT	47uF 20% 16V (760, 761, L7)
C535	1-137-370-11	FILM	0.01uF 5% 50V (760, 761, L7)
C541	1-137-372-11	FILM	0.022uF 5% 50V (760, 761, L7)

Ref. No.	Part No.	Description	Remark
C542	1-115-438-91	ELECT	100uF 20% 10V (760, 761, L7)
C551	1-124-248-00	ELECT	22uF 20% 35V (760, 761, L7)
C552	1-124-234-00	ELECT	22uF 20% 16V (760, 761, L7)
C561	1-126-160-11	ELECT	1uF 20% 50V
C562	1-137-370-11	FILM	0.01uF 5% 50V
C563	1-126-163-11	ELECT	4.7uF 20% 50V
C565	1-163-143-00	CERAMIC CHIP	0.0012uF 5% 50V
C566	1-163-014-00	CERAMIC CHIP	0.0027uF 5% 50V
C571	1-163-141-00	CERAMIC CHIP	0.001uF 5% 50V (760, 761, L7)
C572	1-163-141-00	CERAMIC CHIP	0.001uF 5% 50V (760, 761, L7)
C591	1-124-584-00	ELECT	100uF 20% 10V (760, 761, L7)
C592	1-115-438-91	ELECT	100uF 20% 10V (760, 761, L7)
C593	1-124-589-11	ELECT	47uF 20% 16V (760, 761, L7)
C610	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V
C681	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C682	1-126-967-11	ELECT	47uF 20% 16V
C683	1-126-935-11	ELECT	470uF 20% 6.3V
C684	1-126-967-11	ELECT	47uF 20% 16V
C701	1-126-967-11	ELECT	47uF 20% 16V
C702	1-126-964-11	ELECT	10uF 20% 50V
C703	1-126-964-11	ELECT	10uF 20% 50V (760, 761, L7)
C704	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V
C705	1-126-964-11	ELECT	10uF 20% 50V
C706	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C707	1-126-967-11	ELECT	47uF 20% 16V
C708	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C711	1-126-935-11	ELECT	470uF 20% 16V
C712	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C713	1-126-967-11	ELECT	47uF 20% 16V
C714	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C716	1-126-964-11	ELECT	10uF 20% 50V (760, 761, L7)
C717	1-126-964-11	ELECT	10uF 20% 50V
C718	1-128-551-11	ELECT	22uF 20% 25V (760, 761, L7)
C719	1-164-161-11	CERAMIC CHIP	0.0022uF 10% 100V
C721	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V
C725	1-163-809-11	CERAMIC CHIP	0.047uF 10% 25V (760, 761, L7)

Ref. No.	Part No.	Description	Remark
C727	1-126-933-11	ELECT	100uF 20% 10V
C730	1-163-031-11	CERAMIC CHIP	0.01uF 50V (L5)
C731	1-163-031-11	CERAMIC CHIP	0.01uF 50V (L5)
C732	1-163-031-11	CERAMIC CHIP	0.01uF 50V (L5)
C733	1-163-031-11	CERAMIC CHIP	0.01uF 50V (L5)
C734	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V (L5)
C735	1-163-031-11	CERAMIC CHIP	0.01uF 50V (L5)
C851	1-126-157-11	ELECT	10uF 20% 16V (L5)
C852	1-124-234-00	ELECT	22uF 20% 16V (L5)
C853	1-124-234-00	ELECT	22uF 20% 16V (L5)
C854	1-124-252-00	ELECT	0.33uF 20% 50V (L5)
C855	1-126-157-11	ELECT	10uF 20% 16V (L5)
C856	1-126-160-11	ELECT	1uF 20% 50V (L5)
C858	1-126-160-11	ELECT	1uF 20% 50V (L5)
C864	1-126-162-11	ELECT	3.3uF 20% 50V (L5)
C871	1-163-141-00	CERAMIC CHIP	0.001uF 5% 50V (L5)
C872	1-163-141-00	CERAMIC CHIP	0.001uF 5% 50V (L5)
C873	1-124-257-00	ELECT	2.2uF 20% 50V
C881	1-104-696-11	FILM	0.015uF 5% 100V
C882	1-164-232-11	CERAMIC CHIP	0.01uF 50V
C883	1-163-011-11	CERAMIC CHIP	0.0015uF 10% 50V
C884	1-126-933-11	ELECT	100uF 20% 16V
C885	1-137-431-11	FILM	560PF 5% 50V
< JACK >			
CJ621	1-764-222-11	JACK, PIN 6P (LINE-1 IN/LINE OUT)	(760, 761, L7)
CJ621	1-764-801-11	JACK, PIN 5P (LINE-1 IN/LINE OUT)	(L5)

Ref. No.	Part No.	Description	Remark
< CONNECTOR >			
CN101	1-506-468-11	PIN, CONNECTOR	3P
* CN271	1-766-538-11	CONNECTOR, BOARD TO BOARD	8P
* CN275	1-766-717-11	CONNECTOR, BOARD TO BOARD	5P
* CN281	1-766-537-11	CONNECTOR (HMD)	5P
* CN291	1-766-716-11	CONNECTOR, BOARD TO BOARD	3P
CN301	1-766-718-11	CONNECTOR, BOARD TO BOARD	17P
* CN501	1-766-600-11	CONNECTOR, BOARD TO BOARD	7P
* CN851	1-560-892-00	PIN, CONNECTOR	4P
* CN881	1-560-891-00	PIN, CONNECTOR	3P
CN903	1-774-461-11	CONNECTOR, FFC/FPC	15P
CN905	1-506-470-11	PIN, CONNECTOR	5P (760, 761)
CN906	1-569-338-11	CONNECTOR, BOARD TO BOARD	19P
CN908	1-506-473-11	PIN, CONNECTOR	8P
< TRIMMER >			
CT401	1-141-334-11	CAP, VAR, TRIMMER	
< DIODE >			
D201	8-719-200-82	DIODE	11ES2
D202	8-719-801-48	DIODE	1SS193
D203	8-719-801-78	DIODE	1SS184 (L5)
D204	8-719-200-82	DIODE	11ES2
D251	8-719-801-48	DIODE	1SS193
D261	8-719-048-26	LED	GL528V1
D265	8-719-109-93	DIODE	RD6. 2ES-B2
D267	8-719-109-93	DIODE	RD6. 2ES-B2
D291	8-719-977-24	DIODE	DTZ9. 1B
D403	8-719-801-48	DIODE	1SS193
D591	8-719-404-46	DIODE	MA110 (760, 761, L7)
D610	8-719-109-74	DIODE	RD4. 3ES-B1
D701	8-719-200-82	DIODE	11ES2
△D702	8-719-800-76	DIODE	1SS226
D703	8-719-110-78	DIODE	RD33ES-B2
D708	8-719-911-19	DIODE	1SS119-25 (L5)
D853	8-719-911-19	DIODE	1SS119-25 (L5)
D902	8-719-200-82	DIODE	11ES2
< IC >			
IC101	8-759-246-14	IC	TA8823N
IC131	8-759-364-14	IC	LC7455M-TLM (760, 761)
IC201	8-752-869-65	IC	CXP87360-040Q (L5, L7)
IC201	8-752-869-64	IC	CXP87360-039Q (760, 761)
IC202	8-759-248-87	IC	MM1256XF-BE
IC203	8-759-278-56	IC	AK6440HF-E2
IC251	8-759-335-76	IC	uPC5023GR-089-E2
IC291	8-759-294-26	IC	BA6209-V2

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark
IC302	1-801-097-11	IC YC MODULE 3 (NTSC-YC)	
IC401	8-759-289-30	IC LC74761M-9075-TLM	
IC461	8-759-295-66	IC BA7653AF-E2	
IC501	8-759-365-32	IC XLN7779K-VP	(760, 761, L7)
IC551	8-759-089-84	IC BA7755AF	(760, 761, L7)
IC701	8-759-701-59	IC NJM78M09FA	(760, 761, L7)
IC851	8-759-268-02	IC BA7796FS-E2	(L5)
< JUMPER RESISTOR >			
JP21	1-216-295-00	METAL CHIP	0 5% 1/10W (L5)
JP22	1-216-295-00	METAL CHIP	0 5% 1/10W (L5)
JP95	1-216-295-00	METAL CHIP	0 5% 1/10W (L5)
JP96	1-216-295-00	METAL CHIP	0 5% 1/10W (L5)
JP001	1-216-296-00	METAL CHIP	0 5% 1/8W
JP014	1-216-296-00	METAL CHIP	0 5% 1/8W
JP017	1-216-296-00	METAL CHIP	0 5% 1/8W
JP021	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761, L7)
JP022	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761, L7)
JP031	1-216-296-00	METAL CHIP	0 5% 1/8W
JP045	1-216-296-00	METAL CHIP	0 5% 1/8W
JP057	1-216-296-00	METAL CHIP	0 5% 1/8W
< JUMPER RESISTOR >			
JR101	1-216-295-00	METAL CHIP	0 5% 1/10W
JR131	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761)
JR132	1-216-296-00	METAL CHIP	0 5% 1/8W (760, 761)
JR202	1-216-295-00	METAL CHIP	0 5% 1/10W (L5)
JR203	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761, L7)
JR204	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761, L7)
JR205	1-216-295-00	METAL CHIP	0 5% 1/10W
JR212	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761)
JR213	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761, L7)
JR221	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761)
JR222	1-216-296-00	METAL CHIP	0 5% 1/8W (L5, L7)
JR224	1-216-295-00	METAL CHIP	0 5% 1/10W
JR252	1-216-295-00	METAL CHIP	0 5% 1/10W
JR253	1-216-295-00	METAL CHIP	0 5% 1/10W
JR301	1-216-295-00	METAL CHIP	0 5% 1/10W

Ref. No.	Part No.	Description	Remark
JR303	1-216-295-00	METAL CHIP	0 5% 1/10W
JR305	1-216-295-00	METAL CHIP	0 5% 1/10W
JR402	1-216-295-00	METAL CHIP	0 5% 1/10W
JR403	1-216-295-00	METAL CHIP	0 5% 1/10W
JR404	1-216-295-00	METAL CHIP	0 5% 1/10W
JR461	1-216-295-00	METAL CHIP	0 5% 1/10W
JR576	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761, L7)
JR701	1-216-295-00	METAL CHIP	0 5% 1/10W (L5)
JR702	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761, L7)
JR706	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761, L7)
JR707	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761, L7)
JR710	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761, L7)
JR716	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761, L7)
JR722	1-216-295-00	METAL CHIP	0 5% 1/10W (L5)
JR737	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761, L7)
JR738	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761, L7)
JR739	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761, L7)
JR741	1-216-295-00	METAL CHIP	0 5% 1/10W (760, 761, L7)
JR851	1-216-295-00	METAL CHIP	0 5% 1/10W (L5)
JR854	1-216-295-00	METAL CHIP	0 5% 1/10W (L5)
JR856	1-216-295-00	METAL CHIP	0 5% 1/10W (L5)
JR859	1-216-295-00	METAL CHIP	0 5% 1/10W (L5)
JR885	1-216-295-00	METAL CHIP	0 5% 1/10W
< COIL >			
L101	1-408-421-00	INDUCTOR	100uH
L201	1-408-970-21	INDUCTOR	10uH
L301	1-410-521-11	INDUCTOR	100uH
L302	1-414-186-31	INDUCTOR	33uH
L303	1-414-186-31	INDUCTOR	33uH
L305	1-414-186-31	INDUCTOR	33uH
L351	1-410-525-11	INDUCTOR	220uH
L352	1-414-189-31	INDUCTOR	100uH
L353	1-410-513-11	INDUCTOR	22uH
L401	1-408-421-00	INDUCTOR	100uH

Ref. No.	Part No.	Description	Remark
L402	1-408-421-00	INDUCTOR 100uH	
L404	1-410-506-11	INDUCTOR 5.6uH	
L461	1-414-189-31	INDUCTOR 100uH	
L681	1-410-482-31	INDUCTOR 100uH	
L701	1-414-183-41	INDUCTOR 10uH	(760, 761, L7)
L702	1-414-189-31	INDUCTOR 100uH	
L703	1-414-183-41	INDUCTOR 10uH	
L704	1-410-501-11	INDUCTOR 2.2uH	
L705	1-414-187-11	INDUCTOR 47uH	
L708	1-410-501-11	INDUCTOR 2.2uH	(L5)
L709	1-410-501-11	INDUCTOR 2.2uH	(L5)
L851	1-410-482-31	INDUCTOR 100uH	(L5)
L881	1-410-687-11	INDUCTOR 1.2mH	
L901	1-412-364-11	INDUCTOR 0uH	
< PIN CABLE >			
P701	1-555-110-00	CABLE, PIN	(760, 761, L7)
< PHOTO INTERRUPTER >			
PH261	8-749-010-19	PHOTO INTERRUPTER GP3S113	
PH262	8-749-010-20	PHOTO INTERRUPTER GP3S114	
< IC LINK >			
△PS271	1-532-727-11	LINK, IC ICP-N5 (0.25A)	
△PS885	1-532-727-11	LINK, IC ICP-N5 (0.25A)	
< THERMISTOR >			
△PTH592	1-202-855-00	THERMISTOR, POSITIVE	(760, 761, L7)
< TRANSISTOR >			
Q131	8-729-010-05	TRANSISTOR MSB709-RT1	(760, 761)
Q132	8-729-421-19	TRANSISTOR UN2213	(760, 761)
Q201	8-729-010-25	TRANSISTOR MSD601-RT1	
Q202	8-729-901-06	TRANSISTOR DTA144EK	
Q261	8-729-025-92	PHOTO TRANSISTOR PT380F	
Q262	8-729-025-92	PHOTO TRANSISTOR PT380F	
Q263	8-729-281-53	TRANSISTOR 2SC1815-GR	
Q301	8-729-421-19	TRANSISTOR UN2213	
Q306	8-729-421-19	TRANSISTOR UN2213	
Q352	8-729-010-29	TRANSISTOR MSD601-RST1	
Q353	8-729-010-29	TRANSISTOR MSD601-RST1	
Q404	8-729-010-05	TRANSISTOR MSB709-RT1	
Q405	8-729-010-05	TRANSISTOR MSB709-RT1	
Q406	8-729-010-05	TRANSISTOR MSB709-RT1	
Q591	8-729-804-41	TRANSISTOR 2SB1122-S	(760, 761, L7)
Q592	8-729-820-68	TRANSISTOR 2SD1802FA-S	(760, 761, L7)
Q681	8-729-010-05	TRANSISTOR MSB709-RT1	
Q701	8-729-421-19	TRANSISTOR UN2213	(760, 761, L7)

Ref. No.	Part No.	Description	Remark
△Q703	8-729-173-38	TRANSISTOR 2SA733-K	
Q705	8-729-010-29	TRANSISTOR MSD601-RST1	(760, 761, L7)
Q707	8-729-010-05	TRANSISTOR MSB709-RT1	(760, 761, L7)
Q708	8-729-010-05	TRANSISTOR MSB709-RT1	(760, 761, L7)
Q709	8-729-010-29	TRANSISTOR MSD601-RST1	(760, 761, L7)
Q710	8-729-010-05	TRANSISTOR MSB709-RT1	(L5)
Q711	8-729-424-67	TRANSISTOR UN2216	(L5)
Q714	8-729-010-05	TRANSISTOR MSB709-RT1	(L5)
Q853	8-729-424-67	TRANSISTOR UN2216	(L5)
Q881	8-729-012-31	TRANSISTOR 2SC4040-TL2-Q	
Q882	8-729-900-51	TRANSISTOR DTA114TK	
Q886	8-729-010-29	TRANSISTOR MSD601-RST1	
< RESISTOR >			
R101	1-216-119-00	METAL CHIP 820K 5%	1/10W
R102	1-216-093-00	METAL CHIP 68K 5%	1/10W
R103	1-216-097-91	METAL GLAZE 100K 5%	1/10W
R104	1-216-097-91	METAL GLAZE 100K 5%	1/10W
R105	1-216-085-00	METAL CHIP 33K 5%	1/10W
R106	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
R107	1-216-186-00	METAL GLAZE 330 5%	1/8W
R108	1-216-121-91	METAL GLAZE 1M 5%	1/10W
R111	1-216-097-91	METAL GLAZE 100K 5%	1/10W
R131	1-216-061-00	METAL CHIP 3.3K 5%	1/10W (760, 761)
R132	1-216-121-91	METAL GLAZE 1M 5%	1/10W (760, 761)
R133	1-216-222-00	METAL GLAZE 10K 5%	1/8W (760, 761)
R135	1-216-025-91	METAL GLAZE 100 5%	1/10W (760, 761)
R136	1-216-049-91	METAL GLAZE 1K 5%	1/10W (760, 761)
R137	1-216-083-00	METAL CHIP 27K 5%	1/10W (760, 761)
R138	1-216-079-00	METAL CHIP 18K 5%	1/10W (760, 761)
R139	1-216-238-91	METAL GLAZE 47K 5%	1/8W (760, 761)
R140	1-216-057-00	METAL CHIP 2.2K 5%	1/10W (760, 761)
R141	1-216-073-00	METAL CHIP 10K 5%	1/10W (760, 761)
R201	1-216-073-00	METAL CHIP 10K 5%	1/10W
R202	1-216-295-00	METAL CHIP 0 5%	1/10W (760, 761)
R202	1-216-081-00	METAL CHIP 22K 5%	1/10W (L5)
R202	1-216-065-00	METAL CHIP 4.7K 5%	1/10W (L7)

<p>The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.</p>	<p>Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.</p>
---	---

Ref. No.	Part No.	Description	Remark		
R203	1-216-073-00	METAL CHIP	10K	5%	1/10W
R204	1-216-073-00	METAL CHIP	10K	5%	1/10W (L5, L7)
R206	1-216-073-00	METAL CHIP	10K	5%	1/10W
R207	1-216-065-00	METAL CHIP	4.7K	5%	1/10W
R208	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R209	1-216-073-00	METAL CHIP	10K	5%	1/10W
R210	1-216-073-00	METAL CHIP	10K	5%	1/10W
R211	1-216-101-00	METAL CHIP	150K	5%	1/10W
R212	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R213	1-216-077-00	METAL CHIP	15K	5%	1/10W
R214	1-216-085-00	METAL CHIP	33K	5%	1/10W
R215	1-216-095-00	METAL CHIP	82K	5%	1/10W
R216	1-216-083-00	METAL CHIP	27K	5%	1/10W (L5)
R217	1-216-085-00	METAL CHIP	33K	5%	1/10W (L5)
R218	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R219	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R220	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R221	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R222	1-216-113-00	METAL CHIP	470K	5%	1/10W
R223	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R224	1-216-025-91	METAL GLAZE	100	5%	1/10W
R225	1-216-053-00	METAL CHIP	1.5K	5%	1/10W
R226	1-216-025-91	METAL GLAZE	100	5%	1/10W
R227	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R228	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R229	1-216-109-00	METAL CHIP	330K	5%	1/10W
R230	1-216-105-91	METAL GLAZE	220K	5%	1/10W
R233	1-216-057-00	METAL CHIP	2.2K	5%	1/10W
R234	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R251	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R252	1-216-079-00	METAL CHIP	18K	5%	1/10W
R253	1-216-689-11	METAL CHIP	39K	0.5%	1/10W
R254	1-216-057-00	METAL CHIP	2.2K	5%	1/10W
R255	1-216-057-00	METAL CHIP	2.2K	5%	1/10W
R256	1-216-103-91	METAL GLAZE	180K	5%	1/10W
R261	1-249-400-11	CARBON	39	5%	1/4W
R262	1-249-400-11	CARBON	39	5%	1/4W
R263	1-216-057-00	METAL CHIP	2.2K	5%	1/10W
R264	1-216-107-00	METAL CHIP	270K	5%	1/10W
R265	1-216-107-00	METAL CHIP	270K	5%	1/10W
R266	1-249-413-11	CARBON	470	5%	1/4W
R267	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R268	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R271	1-216-065-00	METAL CHIP	4.7K	5%	1/10W
R274	1-216-083-00	METAL CHIP	27K	5%	1/10W
R275	1-216-093-00	METAL CHIP	68K	5%	1/10W
R276	1-216-056-00	METAL GLAZE	2K	5%	1/10W

Ref. No.	Part No.	Description	Remark		
R277	1-216-068-00	METAL CHIP	6.2K	5%	1/10W
R278	1-216-075-00	METAL CHIP	12K	5%	1/10W
R281	1-216-238-91	METAL GLAZE	47K	5%	1/8W
R282	1-216-238-91	METAL GLAZE	47K	5%	1/8W
R283	1-216-238-91	METAL GLAZE	47K	5%	1/8W
R284	1-216-238-91	METAL GLAZE	47K	5%	1/8W
R293	1-216-295-00	METAL CHIP	0	5%	1/10W
R301	1-216-295-00	METAL CHIP	0	5%	1/10W
R302	1-216-052-00	METAL CHIP	1.3K	5%	1/10W (L5)
R302	1-216-053-00	METAL CHIP	1.5K	5%	1/10W (760, 761, L7)
R303	1-216-031-00	METAL CHIP	180	5%	1/10W
R304	1-208-798-11	METAL GLAZE	4.7K	0.50%	1/10W
R305	1-216-057-00	METAL CHIP	2.2K	5%	1/10W
R306	1-216-081-00	METAL CHIP	22K	5%	1/10W
R313	1-216-041-00	METAL CHIP	470	5%	1/10W
R314	1-216-240-00	METAL GLAZE	56K	5%	1/8W
R315	1-216-105-91	METAL GLAZE	220K	5%	1/10W
R317	1-247-889-00	CARBON	270K	5%	1/4W
R335	1-216-073-00	METAL CHIP	10K	5%	1/10W
R351	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R352	1-216-051-00	METAL CHIP	1.2K	5%	1/10W
R353	1-216-045-00	METAL CHIP	680	5%	1/10W
R354	1-216-083-00	METAL CHIP	27K	5%	1/10W
R355	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R356	1-216-055-00	METAL CHIP	1.8K	5%	1/10W
R357	1-216-067-00	METAL CHIP	5.6K	5%	1/10W
R358	1-216-035-00	METAL CHIP	270	5%	1/10W
R413	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R414	1-216-057-00	METAL CHIP	2.2K	5%	1/10W
R415	1-216-053-00	METAL CHIP	1.5K	5%	1/10W
R416	1-216-069-00	METAL CHIP	6.8K	5%	1/10W
R417	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R418	1-216-045-00	METAL CHIP	680	5%	1/10W
R419	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R420	1-216-065-00	METAL CHIP	4.7K	5%	1/10W
R421	1-216-057-00	METAL CHIP	2.2K	5%	1/10W
R423	1-216-073-00	METAL CHIP	10K	5%	1/10W
R425	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R431	1-216-081-00	METAL CHIP	22K	5%	1/10W
R432	1-216-121-91	METAL GLAZE	1M	5%	1/10W
R461	1-216-295-00	METAL CHIP	0	5%	1/10W
R462	1-216-295-00	METAL CHIP	0	5%	1/10W
R501	1-216-065-00	METAL CHIP	4.7K	5%	1/10W (760, 761, L7)
R502	1-216-065-00	METAL CHIP	4.7K	5%	1/10W (760, 761, L7)

MA-252

Ref. No.	Part No.	Description			Remark
R505	1-216-295-00	METAL CHIP	0	5%	1/10W (760, 761, L7)
R506	1-216-295-00	METAL CHIP	0	5%	1/10W (760, 761, L7)
R507	1-216-295-00	METAL CHIP	0	5%	1/10W (760, 761, L7)
R510	1-216-129-00	METAL CHIP	2.2M	5%	1/10W (760, 761, L7)
R514	1-216-049-91	METAL GLAZE	1K	5%	1/10W (760, 761, L7)
R515	1-216-049-91	METAL GLAZE	1K	5%	1/10W (760, 761, L7)
R521	1-216-073-00	METAL CHIP	10K	5%	1/10W (760, 761, L7)
R522	1-216-050-00	METAL GLAZE	1.1K	5%	1/10W (760, 761, L7)
R523	1-216-079-00	METAL CHIP	18K	5%	1/10W (760, 761, L7)
R524	1-216-067-00	METAL CHIP	5.6K	5%	1/10W (760, 761, L7)
R525	1-208-809-11	METAL GLAZE	13K	0.50%	1/10W (760, 761, L7)
R531	1-216-073-00	METAL CHIP	10K	5%	1/10W (760, 761, L7)
R532	1-216-050-00	METAL GLAZE	1.1K	5%	1/10W (760, 761, L7)
R533	1-216-079-00	METAL CHIP	18K	5%	1/10W (760, 761, L7)
R534	1-216-067-00	METAL CHIP	5.6K	5%	1/10W (760, 761, L7)
R535	1-208-806-11	METAL GLAZE	10K	0.50%	1/10W (760, 761, L7)
R541	1-216-081-00	METAL CHIP	22K	5%	1/10W (760, 761, L7)
R551	1-216-129-00	METAL CHIP	2.2M	5%	1/10W (760, 761, L7)
R561	1-216-073-00	METAL CHIP	10K	5%	1/10W
R562	1-216-109-00	METAL CHIP	330K	5%	1/10W
R563	1-216-069-00	METAL CHIP	6.8K	5%	1/10W
R564	1-216-041-00	METAL CHIP	470	5%	1/10W
R565	1-216-099-00	METAL CHIP	120K	5%	1/10W
R566	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R567	1-216-295-00	METAL CHIP	0	5%	1/10W (760, 761, L7)
R571	1-216-073-00	METAL CHIP	10K	5%	1/10W (760, 761, L7)

Ref. No.	Part No.	Description			Remark
R572	1-216-089-91	METAL GLAZE	47K	5%	1/10W (760, 761, L7)
R573	1-216-214-00	METAL GLAZE	4.7K	5%	1/8W (760, 761, L7)
R575	1-216-295-00	METAL CHIP	0	5%	1/10W (760, 761, L7)
R591	1-249-421-11	CARBON	2.2K	5%	1/4W (760, 761, L7)
R592	1-216-069-00	METAL CHIP	6.8K	5%	1/10W (760, 761, L7)
R601	1-216-022-00	METAL CHIP	75	5%	1/10W
R611	1-216-041-00	METAL CHIP	470	5%	1/10W
R612	1-216-041-00	METAL CHIP	470	5%	1/10W (760, 761, L7)
R681	1-216-037-00	METAL CHIP	330	5%	1/10W
R683	1-249-407-11	CARBON	150	5%	1/4W
R684	1-249-408-11	CARBON	180	5%	1/4W
R685	1-216-021-00	METAL CHIP	68	5%	1/10W
R702	1-216-041-00	METAL CHIP	470	5%	1/10W (760, 761, L7)
R703	1-249-404-00	CARBON	82	5%	1/4W
R704	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R705	1-216-057-00	METAL CHIP	2.2K	5%	1/10W (L5)
R706	1-216-073-00	METAL CHIP	10K	5%	1/10W (760, 761, L7)
R709	1-216-049-91	METAL GLAZE	1K	5%	1/10W (L5)
R711	1-216-073-00	METAL CHIP	10K	5%	1/10W (L5)
R712	1-216-025-91	METAL GLAZE	100	5%	1/10W (L5)
R713	1-216-041-00	METAL CHIP	470	5%	1/10W (760, 761, L7)
R714	1-216-041-00	METAL CHIP	470	5%	1/10W (760, 761, L7)
R715	1-216-025-91	METAL GLAZE	100	5%	1/10W (760, 761, L7)
R716	1-216-065-00	METAL CHIP	4.7K	5%	1/10W (760, 761, L7)
R717	1-216-073-00	METAL CHIP	10K	5%	1/10W (760, 761, L7)
R719	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R720	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R721	1-216-037-00	METAL CHIP	330	5%	1/10W
R722	1-216-061-00	METAL CHIP	3.3K	5%	1/10W
R725	1-216-049-91	METAL GLAZE	1K	5%	1/10W (760, 761, L7)

Ref. No.	Part No.	Description			Remark
R726	1-216-049-91	METAL GLAZE	1K	5%	1/10W (760, 761, L7)
R733	1-216-081-00	METAL CHIP	22K	5%	1/10W (760, 761, L7)
R734	1-216-081-00	METAL CHIP	22K	5%	1/10W (760, 761, L7)
R736	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R737	1-216-295-00	METAL CHIP	0	5%	1/10W (760, 761, L7)
R738	1-216-025-91	METAL GLAZE	100	5%	1/10W (L5)
R740	1-216-093-00	METAL CHIP	68K	5%	1/10W (760, 761, L7)
R746	1-216-073-00	METAL CHIP	10K	5%	1/10W (760, 761, L7)
R747	1-249-421-11	CARBON	2.2K	5%	1/4W F (760, 761, L7)
R851	1-216-129-00	METAL CHIP	2.2M	5%	1/10W (L5)
R852	1-216-049-91	METAL GLAZE	1K	5%	1/10W (L5)
R853	1-216-041-00	METAL CHIP	470	5%	1/10W (L5)
R854	1-216-089-91	METAL GLAZE	47K	5%	1/10W (L5)
R855	1-216-067-00	METAL CHIP	5.6K	5%	1/10W (L5)
R858	1-216-089-91	METAL GLAZE	47K	5%	1/10W (L5)
R859	1-216-067-00	METAL CHIP	5.6K	5%	1/10W (L5)
R871	1-216-073-00	METAL CHIP	10K	5%	1/10W (L5)
R872	1-216-089-91	METAL GLAZE	47K	5%	1/10W (L5)
R873	1-216-065-00	METAL CHIP	4.7K	5%	1/10W (L5)
R874	1-216-075-00	METAL CHIP	12K	5%	1/10W
R881	1-216-081-00	METAL CHIP	22K	5%	1/10W
△R882	1-249-389-11	CARBON	4.7	5%	1/4W F
R885	1-216-071-00	METAL CHIP	8.2K	5%	1/10W
R886	1-216-073-00	METAL CHIP	10K	5%	1/10W
R887	1-216-089-91	METAL GLAZE	47K	5%	1/10W
< RF MODULATOR >					
△RF701	1-466-989-11	MODULATOR, RF			(760, 761, L7)
< VARIABLE RESISTOR >					
RV521	1-241-763-11	RES, ADJ, CERMET 4.7K			(760, 761, L7)
RV531	1-241-763-11	RES, ADJ, CERMET 4.7K			(760, 761, L7)
RV541	1-241-764-11	RES, ADJ, CERMET 10K			(760, 761, L7)
< SWITCH >					
S251	1-570-953-11	SWITCH, PUSH (1 KEY) (REC PRF)			
S701	1-571-588-11	SWITCH, SLIDE (RF UNIT CH3/CH4)			(L5)

Ref. No.	Part No.	Description			Remark
< TRANSFORMER >					
T881	1-423-414-11	TRANSFORMER, BIAS OSCILLATION			
< TUNER >					
△TU701	8-598-345-00	TUNER, BTf-WA407			(760, 761, L7)
△TU702	1-693-318-11	TUNER, RF MOD/IF (BTf-2MA402)			(L5)
< VIBRATOR >					
X201	1-760-494-11	VIBRATOR, CRYSTAL (16MHz)			
X202	1-579-463-11	VIBRATOR, CRYSTAL (32.768kHz)			
X401	1-577-381-11	VIBRATOR, CRYSTAL (14MHz)			

*	A-6782-798-A	MF-283 BOARD, COMPLETE (790, 960HF/HFMX)			
*	A-6782-806-A	MF-289 BOARD, COMPLETE (960HFCS/HFPX)			

(Ref. No. 1, 000 Series)					
< CAPACITOR >					
C201	1-163-035-00	CERAMIC CHIP	0.047uF		50V
< CONNECTOR >					
CN201	1-695-368-31	CONNECTOR, FPC/FPC 7P			
< LED >					
D201	8-719-056-07	LED SLR-342MC3F			(POWER)
D202	8-719-056-07	LED SLR-342MC3F			(POWER)
< IC >					
IC201	1-466-833-11	IC RAY-CATCHER BLOCK, REMOCON			
< TRANSISTOR >					
Q201	8-729-421-22	TRANSISTOR UN2211			
< RESISTOR >					
R201	1-216-089-91	METAL GLAZE	47K	5%	1/10W
R202	1-216-021-00	METAL CHIP	68	5%	1/10W
< SWITCH >					
S201	1-571-977-11	SWITCH, TACTIL (POWER)			

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

MF-284

MF-290

PS-355

PS-356

Ref. No.	Part No.	Description	Remark
*	A-6782-794-A	MF-284 BOARD, COMPLETE (760, 761, L5MX/PA, L7HFMX/HFPA)	
*	A-6782-795-A	MF-290 BOARD, COMPLETE (760HFPX, L5CS, L7HFGS)	

(Ref. No. 2, 000 Series)			
< CONNECTOR >			
CN201	1-691-068-21	HOUSING, CONNECTOR 9P	
< LED >			
D201	8-719-056-07	LED SLR-342MC3F (POWER)	
D202	8-719-056-07	LED SLR-342MC3F (POWER)	
< RESISTOR >			
R202	1-216-021-00	METAL CHIP 68 5% 1/10W	
< SWITCH >			
S201	1-571-977-11	SWITCH, TACTIL (POWER)	

(Ref. No. 1, 000 Series)			
1-533-223-11 HOLDER, FUSE			
*	3-951-893-01	HEAT SINK	
*	7-685-646-79	SCREW +BVTP 3X8 TYPE2 IT-3	
< CAPACITOR >			
△C101	1-104-705-11	FILM 0.1uF 20% 250V	
△C102	1-104-705-11	FILM 0.1uF 20% 250V	
△C103	1-107-401-11	ELECT 150uF 20% 200V	
△C104	1-113-900-11	ELECT 470PF 10% 250V	
△C105	1-113-900-11	ELECT 470PF 10% 250V	
△C107	1-113-919-11	ELECT 0.0015uF 99% 125V	
C121	1-126-935-11	ELECT 470uF 20% 16V	
C122	1-126-926-11	ELECT 1000uF 20% 10V	
C125	1-128-551-11	ELECT 22uF 20% 25V	
C131	1-128-499-11	ELECT 220uF 20% 16V	
C132	1-128-551-11	ELECT 22uF 20% 25V	
C133	1-104-664-11	ELECT 47uF 20% 25V	
C141	1-126-967-11	ELECT 47uF 20% 16V	
C142	1-126-933-11	ELECT 100uF 20% 16V	
C161	1-126-967-11	ELECT 47uF 20% 16V	
C162	1-126-924-11	ELECT 330uF 20% 10V	

Ref. No.	Part No.	Description	Remark
C171	1-126-924-11	ELECT 330uF 20% 10V	
C181	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C182	1-126-967-11	ELECT 47uF 20% 16V	
C183	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C184	1-126-967-11	ELECT 47uF 20% 50V	
C185	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C186	1-126-967-11	ELECT 47uF 20% 50V	
C187	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C188	1-126-967-11	ELECT 47uF 20% 50V	
C189	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C190	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C191	1-124-248-00	ELECT 22uF 20% 35V	
< AC INLET >			
△CJ101	1-251-135-11	INLET, AC. (AC IN ~)	
< CONNECTOR >			
CN101	1-569-341-11	CONNECTOR, BOARD TO BOARD 19P	
< POWER BLOCK >			
△CP101	1-468-086-11	POWER BLOCK	
△CP102	1-467-811-12	UNIT, DC-DC CONVERTER	
< DIODE >			
△D101	8-719-510-06	DIODE S1WB60	
D161	8-719-911-19	DIODE 1SS119-25	
D162	8-719-109-85	DIODE RD5.1ES-B2	
< FUSE >			
△F101	1-532-743-11	FUSE, GLASS CYLINDRICAL (DIA. 5) (2A/125V)	
< IC >			
△IC141	8-759-189-48	IC PQ12RE11	
< COIL >			
△L121	1-403-588-11	CIL, CHOKE 22uH	
△L122	1-403-588-11	CIL, CHOKE 22uH	
L181	1-408-970-21	INDUCTOR 10uH	
L182	1-414-142-11	INDUCTOR 1uH	
L183	1-414-142-11	INDUCTOR 1uH	
L184	1-410-322-11	INDUCTOR 3.3UH(790, 960HF/HFMX)	
< LINE FILTER >			
△LF102	1-424-117-11	FILTER, LINE 18ah	

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

PS-355

PS-356

PS-367

PS-368

Ref. No.	Part No.	Description	Remark
< IC LINK >			
△PS121	1-532-637-00	LINK, IC ICP-N25 (1.0A)	
△PS122	1-532-637-00	LINK, IC ICP-N25 (1.0A)	
△PS123	1-532-637-00	LINK, IC ICP-N25 (1.0A)	
△PS181	1-532-605-00	LINK, IC ICP-N10 (0.4A)	
< TRANSISTOR >			
△Q131	8-729-140-93	TRANSISTOR 2SB733-34	
Q132	8-729-421-22	TRANSISTOR UN2211	
△Q161	8-729-140-98	TRANSISTOR 2SD773-34	
< RESISTOR >			
△R102	1-202-729-00	SOLID 6.8M 20% 1/2W	
△R102	1-202-729-00	SOLID 6.8M 20% 1/2W	
△R102	1-202-729-00	SOLID 6.8M 20% 1/2W	
R102	1-202-729-00	SOLID 6.8M 20% 1/2W	
R125	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R131	1-249-417-11	CARBON 1K 5% 1/4W	
R132	1-216-430-11	METAL OXIDE 390 5% 1W	
R133	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R141	1-216-089-91	METAL GLAZE 47K 5% 1/10W	
R161	1-249-412-11	CARBON 390 5% 1/4W	
R182	1-216-378-11	METAL OXIDE 5.6 5% 2W	
R183	1-216-480-11	METAL OXIDE 820 5% 3W	
<p>* A-6782-804-A PS-367 BOARD, COMPLETE (960HFC5/HFPX)</p> <p>* A-6782-819-A PS-368 BOARD, COMPLETE (760HFPX/HFCS)</p> <p>* A-6782-820-A PS-368 BOARD, COMPLETE (L5CS)</p> <p>*****</p> <p style="text-align: center;">(Ref. No. 2,000 Series)</p>			
<p>1-533-223-11 HOLDER, FUSE</p> <p>* 3-951-893-01 HEAT SINK</p> <p>7-685-646-79 SCREW +BVTIP 3X8 TYPE2 IT-3</p>			
< CAPACITOR >			
△C101	1-104-705-11	FILM 0.1uF 20% 250V	
△C102	1-104-705-11	FILM 0.1uF 20% 250V	
△C103	1-107-414-11	ELECT 220uF 20% 400V	
△C104	1-113-935-11	ELECT 0.001uF 99% 125V	
△C105	1-113-935-11	ELECT 0.001uF 99% 125V	
△C106	1-113-935-11	ELECT 0.001uF 99% 125V	
△C107	1-113-935-11	ELECT 0.001uF 99% 125V	
△C108	1-113-935-11	ELECT 0.001uF 99% 125V	
△C112	1-113-895-11	CERAMIC 150PF 10% 250V	
C121	1-126-935-11	ELECT 470uF 20% 16V	
C122	1-126-926-11	ELECT 1000uF 20% 10V	
C125	1-128-551-11	ELECT 22uF 20% 25V	
C131	1-128-499-11	ELECT 220uF 20% 16V	
C132	1-128-551-11	ELECT 22uF 20% 25V	

Ref. No.	Part No.	Description	Remark
C133	1-104-664-11	ELECT 47uF 20% 25V	
C141	1-126-967-11	ELECT 47uF 20% 16V	
C142	1-126-933-11	ELECT 100uF 20% 16V	
C161	1-126-967-11	ELECT 47uF 20% 16V	
C162	1-126-924-11	ELECT 330uF 20% 10V	
C171	1-126-924-11	ELECT 330uF 20% 10V	
C181	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C182	1-126-967-11	ELECT 47uF 20% 16V	
C183	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C184	1-126-967-11	ELECT 47uF 20% 50V	
C185	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C186	1-126-967-11	ELECT 47uF 20% 50V	
C187	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C188	1-126-967-11	ELECT 47uF 20% 50V	
C189	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C190	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C191	1-124-248-00	ELECT 22uF 20% 35V	
< AC INLET >			
△CJ101	1-251-134-11	INLET, AC (NONPOLAR) (AC IN ~)	
< CONNECTOR >			
CN101	1-569-341-11	CONNECTOR, BOARD TO BOARD 19P	
< POWER BLOCK >			
△CP101	1-468-083-11	POWER BLOCK	
△CP101	1-468-083-11	POWER BLOCK	
CP102	1-467-811-12	UNIT, DC-DC CONVERTER	
< DIODE >			
△D101	8-719-510-06	DIODE S1WB60	
D161	8-719-911-19	DIODE 1SS119-25	
D162	8-719-109-85	DIODE RD5.1ES-B2	
< FUSE >			
△F101	1-532-203-00	FUSE (T2AL/250V)	
< IC >			
△IC141	8-759-189-48	IC PQ12RE11	
< COIL >			
△L121	1-403-588-11	CIL, CHOKE 22uH	
△L122	1-403-588-11	CIL, CHOKE 22uH	
L181	1-408-970-21	INDUCTOR 10uH	
L182	1-414-142-11	INDUCTOR 1uH	
L183	1-414-142-11	INDUCTOR 1uH	
L184	1-410-322-11	INDUCTOR 3.3UH (960HFC5/HFPX)	

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

PS-367

PS-368

RP-197

RP-202

Ref. No.	Part No.	Description	Remark		
< LINE FILTER >					
△LF102	1-424-117-11	FILTER, LINE 18mH			
△LF103	1-424-117-11	FILTER, LINE 18mH			
< IC LINK >					
△PS121	1-532-637-00	LINK, IC ICP-N25 (1.0A)			
△PS122	1-532-637-00	LINK, IC ICP-N25 (1.0A)			
△PS123	1-532-637-00	LINK, IC ICP-N25 (1.0A)			
△PS181	1-532-605-00	LINK, IC ICP-N10 (0.4A)			
< TRANSISTOR >					
△Q131	8-729-140-93	TRANSISTOR 2SB733-34			
Q132	8-729-421-22	TRANSISTOR UN2211			
△Q161	8-729-140-98	TRANSISTOR 2SD773-34			
< RESISTOR >					
△R101	1-214-947-00	METAL 2.7M 1% 1/2W			
R125	1-216-061-00	METAL CHIP 3.3K 5% 1/10W			
R131	1-249-417-11	CARBON 1K 5% 1/4W			
R132	1-216-430-11	METAL OXIDE 390 5% 1W			
R133	1-216-061-00	METAL CHIP 3.3K 5% 1/10W			
R141	1-216-089-91	METAL GLAZE 47K 5% 1/10W			
R161	1-249-412-11	CARBON 390 5% 1/4W			
R182	1-216-378-11	METAL OXIDE 5.6 5% 2W			
R183	1-216-480-11	METAL OXIDE 820 5% 3W			
<p>* A-6782-799-A RP-197 BOARD, COMPLETE (790)</p> <p>* A-6782-811-A RP-197 BOARD, COMPLETE (960HF/HFMX)</p> <p>* A-6782-808-A RP-202 BOARD, COMPLETE (960HFC/S/HFPX)</p> <p>*****</p> <p style="text-align: center;">(Ref. No. 1,000 Series)</p>					
< CAPACITOR >					
C501	1-163-229-11	CERAMIC CHIP 12PF 5% 50V			
C502	1-163-229-11	CERAMIC CHIP 12PF 5% 50V			
C503	1-163-033-91	CERAMIC CHIP 0.022uF 50V			
C504	1-163-033-91	CERAMIC CHIP 0.022uF 50V			
C505	1-163-031-11	CERAMIC CHIP 0.01uF 50V			
C506	1-163-033-91	CERAMIC CHIP 0.022uF 50V			
C507	1-163-241-11	CERAMIC CHIP 39PF 5% 50V			
C508	1-163-241-11	CERAMIC CHIP 39PF 5% 50V			
C509	1-163-033-91	CERAMIC CHIP 0.022uF 50V			
C510	1-163-033-91	CERAMIC CHIP 0.022uF 50V			
C511	1-163-227-11	CERAMIC CHIP 10PF 0.5PF 50V			
C512	1-163-227-11	CERAMIC CHIP 10PF 0.5PF 50V			
C513	1-163-033-91	CERAMIC CHIP 0.022uF 50V			
C514	1-163-033-91	CERAMIC CHIP 0.022uF 50V			
C515	1-163-033-91	CERAMIC CHIP 0.022uF 50V			

Ref. No.	Part No.	Description	Remark		
C516	1-163-033-91	CERAMIC CHIP 0.022uF 50V			
C517	1-163-033-91	CERAMIC CHIP 0.022uF 50V			
C518	1-124-584-00	ELECT 100uF 20% 10V			
C519	1-163-038-91	CERAMIC CHIP 0.1uF 25V			
C521	1-163-038-91	CERAMIC CHIP 0.1uF 25V			
C522	1-163-038-91	CERAMIC CHIP 0.1uF 25V			
C523	1-163-059-00	CERAMIC CHIP 0.01uF 10% 50V			
C524	1-163-239-11	CERAMIC CHIP 33PF 5% 50V			
C525	1-163-239-11	CERAMIC CHIP 33PF 5% 50V			
C526	1-124-584-00	ELECT 100uF 20% 10V			
C527	1-163-038-91	CERAMIC CHIP 0.1uF 25V			
C528	1-163-127-00	CERAMIC CHIP 270PF 5% 50V			
C529	1-163-038-91	CERAMIC CHIP 0.1uF 25V			
C531	1-163-038-91	CERAMIC CHIP 0.1uF 25V			
C532	1-163-038-91	CERAMIC CHIP 0.1uF 25V			
C571	1-163-099-00	CERAMIC CHIP 18PF 5% 50V(960)			
C572	1-163-099-00	CERAMIC CHIP 18PF 5% 50V(960)			
C573	1-164-232-11	CERAMIC CHIP 0.01uF 50V(960)			
C575	1-163-251-11	CERAMIC CHIP 100PF 5% 50V(960)			
C576	1-163-121-00	CERAMIC CHIP 150PF 5% 50V(960)			
C577	1-163-245-11	CERAMIC CHIP 56PF 5% 50V(960)			
C578	1-163-038-91	CERAMIC CHIP 0.1uF 25V(960)			
C579	1-124-589-11	ELECT 47uF 20% 16V(960)			
C580	1-163-038-91	CERAMIC CHIP 0.1uF 25V(960)			
C760	1-163-031-11	CERAMIC CHIP 0.01uF 50V			
C761	1-124-584-00	ELECT 100uF 20% 10V			
C762	1-163-031-11	CERAMIC CHIP 0.01uF 50V			
C763	1-163-038-91	CERAMIC CHIP 0.1uF 25V			
C764	1-124-257-00	ELECT 2.2uF 20% 50V			
C765	1-163-031-11	CERAMIC CHIP 0.01uF 50V			
C766	1-163-031-11	CERAMIC CHIP 0.01uF 50V			
C768	1-163-135-00	CERAMIC CHIP 560PF 5% 50V			
C769	1-163-135-00	CERAMIC CHIP 560PF 5% 50V			
C770	1-163-038-91	CERAMIC CHIP 0.1uF 25V			
C773	1-163-031-11	CERAMIC CHIP 0.01uF 50V			
C774	1-163-031-11	CERAMIC CHIP 0.01uF 50V			
C775	1-126-160-11	ELECT 1uF 20% 50V			
C776	1-163-031-11	CERAMIC CHIP 0.01uF 50V			
C901	1-163-031-11	CERAMIC CHIP 0.01uF 50V			
C902	1-163-224-11	CERAMIC CHIP 7PF 0.25PF 50V			
C903	1-163-243-11	CERAMIC CHIP 47PF 5% 50V			
C904	1-163-249-11	CERAMIC CHIP 82PF 5% 50V			
C906	1-163-038-91	CERAMIC CHIP 0.1uF 25V			
C907	1-126-967-11	ELECT 47uF 20% 16V			
C909	1-163-031-11	CERAMIC CHIP 0.01uF 50V			
C912	1-163-241-11	CERAMIC CHIP 39PF 5% 50V			
R519	1-163-031-11	CERAMIC CHIP 0.01MF 50V			

<p>The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.</p>	<p>Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.</p>
---	---

Ref. No.	Part No.	Description	Remark
< CONNECTOR >			
CN501	1-766-986-11	CONNECTOR, FFC/FPC 13P	
* CN502	1-564-029-00	PIN, CONNECTOR 4P	
CN503	1-766-720-11	CONNECTOR, BOARD TO BOARD 17P	
CN701	1-766-724-11	CONNECTOR, BOARD TO BOAR 7P	
< IC >			
IC501	8-759-352-17	IC HA118195NT	
IC760	8-759-055-49	IC AN3327K	
< JUMPER RESISTOR >			
JR502	1-216-295-00	METAL CHIP	0 5% 1/10W
JR503	1-216-295-00	METAL CHIP	0 5% 1/10W
JR504	1-216-295-00	METAL CHIP	0 5% 1/10W
JR505	1-216-295-00	METAL CHIP	0 5% 1/10W
JR506	1-216-296-00	METAL CHIP	0 5% 1/10W
JR507	1-216-295-00	METAL CHIP	0 5% 1/10W
JR508	1-216-295-00	METAL CHIP	0 5% 1/10W
JR509	1-216-295-00	METAL CHIP	0 5% 1/10W
JR901	1-216-296-00	METAL CHIP	0 5% 1/10W
< COIL >			
L501	1-414-189-31	INDUCTOR	100uH
L502	1-414-189-31	INDUCTOR	100uH
L503	1-410-525-11	INDUCTOR	220uH
L571	1-410-509-11	INDUCTOR	10uH (960)
L572	1-410-509-11	INDUCTOR	10uH (960)
L573	1-410-507-11	INDUCTOR	6.8uH (960)
L574	1-414-189-31	INDUCTOR	100uH (960)
L760	1-414-189-31	INDUCTOR	100uH
L901	1-414-189-31	INDUCTOR	100uH
L903	1-410-516-11	INDUCTOR	39uH
L904	1-410-512-11	INDUCTOR	18uH
L906	1-410-518-41	INDUCTOR	56uH
< TRANSISTOR >			
Q501	8-729-271-21	TRANSISTOR	2SC2712Y
Q502	8-729-216-21	TRANSISTOR	2SA1162Y
Q571	8-729-216-22	TRANSISTOR	2SA1162-G (960)
Q572	8-729-216-22	TRANSISTOR	2SA1162-G (960)
Q573	8-729-421-19	TRANSISTOR	UN2213 (960)
Q574	8-729-421-19	TRANSISTOR	UN2213 (960)
Q575	8-729-804-41	TRANSISTOR	2SB1122-S (960)
Q901	8-729-271-21	TRANSISTOR	2SC2712Y
Q904	8-729-216-21	TRANSISTOR	2SA1162Y
Q905	8-729-271-21	TRANSISTOR	2SC2712Y

Ref. No.	Part No.	Description	Remark
< RESISTOR >			
C520	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
C911	1-216-295-00	METAL CHIP	0 5% 1/10W
R501	1-216-044-00	METAL CHIP	620 5% 1/10W
R502	1-216-044-00	METAL CHIP	620 5% 1/10W
R503	1-216-295-00	METAL CHIP	0 5% 1/10W
R504	1-216-295-00	METAL CHIP	0 5% 1/10W
R505	1-216-295-00	METAL CHIP	0 5% 1/10W
R506	1-216-295-00	METAL CHIP	0 5% 1/10W
R507	1-216-053-00	METAL CHIP	1.5K 5% 1/10W
R508	1-216-073-00	METAL CHIP	10K 5% 1/10W
R509	1-216-075-00	METAL CHIP	12K 5% 1/10W
R510	1-216-081-00	METAL CHIP	22K 5% 1/10W
R511	1-216-081-00	METAL CHIP	22K 5% 1/10W
R512	1-216-224-91	METAL GLAZE	12K 5% 1/8W
R513	1-216-081-00	METAL CHIP	22K 5% 1/10W
R514	1-216-059-00	METAL CHIP	2.7K 5% 1/10W
R515	1-216-081-00	METAL CHIP	22K 5% 1/10W
R516	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R517	1-216-049-91	METAL GLAZE	1K 5% 1/10W
R518	1-216-049-91	METAL GLAZE	1K 5% 1/10W
R520	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R571	1-216-013-00	METAL CHIP	33 5% 1/10W (960)
R572	1-216-041-00	METAL CHIP	470 5% 1/10W (960)
R573	1-216-057-00	METAL CHIP	2.2K 5% 1/10W (960)
R574	1-216-095-00	METAL CHIP	82K 5% 1/10W (960)
R575	1-216-089-91	METAL GLAZE	47K 5% 1/10W (960)
R576	1-216-689-11	METAL CHIP	39K 0.5% 1/10W (960)
R577	1-216-061-00	METAL CHIP	3.3K 5% 1/10W (960)
R578	1-216-073-00	METAL CHIP	10K 5% 1/10W (960)
R762	1-216-035-00	METAL CHIP	270 5% 1/10W
R763	1-216-067-00	METAL CHIP	5.6K 5% 1/10W
R765	1-216-033-00	METAL CHIP	220 5% 1/10W
R766	1-249-418-11	CARBON	1.2K 5% 1/4W
R767	1-216-035-00	METAL CHIP	270 5% 1/10W
R768	1-216-097-91	METAL GLAZE	100K 5% 1/10W
R771	1-216-079-00	METAL CHIP	18K 5% 1/10W
R776	1-216-073-00	METAL CHIP	10K 5% 1/10W
R901	1-216-053-00	METAL CHIP	1.5K 5% 1/10W
R902	1-216-077-00	METAL CHIP	15K 5% 1/10W
R903	1-216-075-00	METAL CHIP	12K 5% 1/10W
R904	1-216-037-00	METAL CHIP	330 5% 1/10W
R905	1-216-295-00	METAL CHIP	0 5% 1/10W
R906	1-216-043-91	METAL GLAZE	560 5% 1/10W
R908	1-216-039-00	METAL CHIP	390 5% 1/10W
R912	1-216-075-00	METAL CHIP	12K 5% 1/10W
R913	1-216-077-00	METAL CHIP	15K 5% 1/10W
R914	1-216-037-00	METAL CHIP	330 5% 1/10W

RP-197

RP-202

RP-198

RP-203

Ref. No.	Part No.	Description	Remark		
R916	1-216-037-00	METAL CHIP	330	5%	1/10W
R917	1-216-047-91	METAL GLAZE	820	5%	1/10W
R918	1-216-049-91	METAL GLAZE	1K	5%	1/10W
R919	1-216-295-00	METAL CHIP	0	5%	1/10W
R920	1-216-075-00	METAL CHIP	12K	5%	1/10W
R921	1-216-077-00	METAL CHIP	15K	5%	1/10W
R931	1-216-295-00	METAL CHIP	0	5%	1/10W
R932	1-216-295-00	METAL CHIP	0	5%	1/10W

- * A-6782-832-A RP-198 BOARD, COMPLETE (L5MX/PA)
 - * A-6782-791-A RP-198 BOARD, COMPLETE (760, 761, L7HFMX/HFPA)
 - * A-6782-796-A RP-203 BOARD, COMPLETE (760HFPX, L7HFGS)
 - * A-6782-821-A RP-203 BOARD, COMPLETE (L5CS)
- *****
(Ref. No. 2, 000 Series)

< CAPACITOR >

C501	1-163-229-11	CERAMIC CHIP	12PF	5%	50V
C502	1-163-229-11	CERAMIC CHIP	12PF	5%	50V
C503	1-163-033-91	CERAMIC CHIP	0.022uF		50V
C504	1-163-033-91	CERAMIC CHIP	0.022uF		50V
C505	1-163-031-11	CERAMIC CHIP	0.01uF		50V
C506	1-163-033-91	CERAMIC CHIP	0.022uF		50V
C507	1-163-241-11	CERAMIC CHIP	39PF	5%	50V
C508	1-163-241-11	CERAMIC CHIP	39PF	5%	50V
C509	1-163-033-91	CERAMIC CHIP	0.022uF		50V
C510	1-163-033-91	CERAMIC CHIP	0.022uF		50V
C511	1-163-227-11	CERAMIC CHIP	10PF	0.5PF	50V
C512	1-163-227-11	CERAMIC CHIP	10PF	0.5PF	50V
C513	1-163-033-91	CERAMIC CHIP	0.022uF		50V
C514	1-163-033-91	CERAMIC CHIP	0.022uF		50V
C515	1-163-033-91	CERAMIC CHIP	0.022uF		50V
C516	1-163-033-91	CERAMIC CHIP	0.022uF		50V
C517	1-163-033-91	CERAMIC CHIP	0.022uF		50V
C518	1-124-584-00	ELECT	100uF	20%	10V
C519	1-163-038-91	CERAMIC CHIP	0.1uF		25V
C521	1-163-038-91	CERAMIC CHIP	0.1uF		25V
C522	1-163-038-91	CERAMIC CHIP	0.1uF		25V
C523	1-163-059-00	CERAMIC CHIP	0.01uF	10%	50V
C524	1-163-239-11	CERAMIC CHIP	33PF	5%	50V
C525	1-163-239-11	CERAMIC CHIP	33PF	5%	50V
C526	1-124-584-00	ELECT	100uF	20%	10V
C527	1-163-038-91	CERAMIC CHIP	0.1uF		25V
C528	1-163-127-00	CERAMIC CHIP	270PF	5%	50V
C529	1-163-038-91	CERAMIC CHIP	0.1uF		25V
C531	1-163-038-91	CERAMIC CHIP	0.1uF		25V
C532	1-163-038-91	CERAMIC CHIP	0.1uF		25V
C760	1-163-031-11	CERAMIC CHIP	0.01uF		50V

Ref. No.	Part No.	Description	Remark		
C761	1-124-584-00	ELECT	100uF	20%	10V (760, 761, L7)
C762	1-163-031-11	CERAMIC CHIP	0.01uF		50V (760, 761, L7)
C763	1-163-038-91	CERAMIC CHIP	0.1uF		25V (760, 761, L7)
C764	1-124-257-00	ELECT	2.2uF	20%	50V (760, 761, L7)
C765	1-163-031-11	CERAMIC CHIP	0.01uF		50V (760, 761, L7)
C767	1-163-031-11	CERAMIC CHIP	0.01uF		50V (760, 761, L7)
C768	1-163-135-00	CERAMIC CHIP	560PF	5%	50V (760, 761, L7)
C769	1-163-135-00	CERAMIC CHIP	560PF	5%	50V (760, 761, L7)
C770	1-163-038-91	CERAMIC CHIP	0.1uF		25V (760, 761, L7)
C773	1-163-031-11	CERAMIC CHIP	0.01uF		50V (760, 761, L7)
C774	1-163-031-11	CERAMIC CHIP	0.01uF		50V (760, 761, L7)
C775	1-126-160-11	ELECT	1uF	20%	50V (760, 761, L7)
C776	1-163-031-11	CERAMIC CHIP	0.01uF		50V (760, 761, L7)
C901	1-163-031-11	CERAMIC CHIP	0.01uF		50V
C902	1-163-224-11	CERAMIC CHIP	7PF		0.25PF 50V
C903	1-163-243-11	CERAMIC CHIP	47PF	5%	50V
C904	1-163-249-11	CERAMIC CHIP	82PF	5%	50V
C906	1-163-038-91	CERAMIC CHIP	0.1uF		25V
C907	1-126-967-11	ELECT	47uF	20%	16V
C909	1-163-031-11	CERAMIC CHIP	0.01uF		50V
C912	1-163-241-11	CERAMIC CHIP	39PF	5%	50V
R519	1-163-031-11	CERAMIC CHIP	0.01uF		50V

< CONNECTOR >

CN501	1-563-585-11	CONNECTOR, FLEXIBLE 8P			(L5)
CN501	1-766-986-11	CONNECTOR, FFC/FPC 13P			(760, 761, L7)
* CN502	1-564-029-00	PIN, CONNECTOR 4P			
CN503	1-766-720-11	CONNECTOR, BOARD TO BOARD 17P			
CN701	1-766-724-11	CONNECTOR, BOARD TO BOAR 7P			

< IC >

IC501	8-759-352-17	IC	HA118195NT		
IC760	8-759-055-49	IC	AN3327K		(760, 761, L7)

Ref. No.	Part No.	Description	Remark
< JUMPER RESISTOR >			
JR502	1-216-295-00	METAL CHIP 0 5%	1/10W
JR503	1-216-295-00	METAL CHIP 0 5%	1/10W
JR504	1-216-295-00	METAL CHIP 0 5%	1/10W
JR505	1-216-295-00	METAL CHIP 0 5%	1/10W
JR506	1-216-296-00	METAL CHIP 0 5%	1/8W
JR507	1-216-295-00	METAL CHIP 0 5%	1/10W
JR508	1-216-295-00	METAL CHIP 0 5%	1/10W
JR509	1-216-295-00	METAL CHIP 0 5%	1/10W
JR901	1-216-296-00	METAL CHIP 0 5%	1/8W
< COIL >			
L501	1-414-189-31	INDUCTOR 100uH	
L502	1-414-189-31	INDUCTOR 100uH	
L503	1-410-525-11	INDUCTOR 220uH	
L760	1-414-189-31	INDUCTOR 100uH	(760, 761, L7)
L901	1-414-189-31	INDUCTOR 100uH	
L903	1-410-516-11	INDUCTOR 39uH	
L904	1-410-512-11	INDUCTOR 18uH	
L906	1-410-518-41	INDUCTOR 56uH	
< TRANSISTOR >			
Q501	8-729-271-21	TRANSISTOR 2SC2712Y	
Q502	8-729-216-21	TRANSISTOR 2SA1162Y	
Q901	8-729-271-21	TRANSISTOR 2SC2712Y	
Q904	8-729-216-21	TRANSISTOR 2SA1162Y	
Q905	8-729-271-21	TRANSISTOR 2SC2712Y	
< RESISTOR >			
C520	1-216-057-00	METAL CHIP 2.2K 5%	1/10W
C911	1-216-295-00	METAL CHIP 0 5%	1/10W
R501	1-216-044-00	METAL CHIP 620 5%	1/10W
R502	1-216-044-00	METAL CHIP 620 5%	1/10W
R503	1-216-295-00	METAL CHIP 0 5%	1/10W
R504	1-216-295-00	METAL CHIP 0 5%	1/10W
R505	1-216-295-00	METAL CHIP 0 5%	1/10W
R506	1-216-295-00	METAL CHIP 0 5%	1/10W
R507	1-216-053-00	METAL CHIP 1.5K 5%	1/10W
R508	1-216-073-00	METAL CHIP 10K 5%	1/10W
R509	1-216-075-00	METAL CHIP 12K 5%	1/10W
R510	1-216-081-00	METAL CHIP 22K 5%	1/10W
R511	1-216-081-00	METAL CHIP 22K 5%	1/10W
R512	1-216-224-91	METAL GLAZE 12K 5%	1/8W
R513	1-216-081-00	METAL CHIP 22K 5%	1/10W
R514	1-216-059-00	METAL CHIP 2.7K 5%	1/10W
R515	1-216-081-00	METAL CHIP 22K 5%	1/10W
R516	1-216-057-00	METAL CHIP 2.2K 5%	1/10W
R517	1-216-049-91	METAL GLAZE 1K 5%	1/10W
R518	1-216-049-91	METAL GLAZE 1K 5%	1/10W

Ref. No.	Part No.	Description	Remark
R520	1-216-061-00	METAL CHIP 3.3K 5%	1/10W
R762	1-216-035-00	METAL CHIP 270 5%	1/10W (760, 761, L7)
R763	1-216-067-00	METAL CHIP 5.6K 5%	1/10W (760, 761, L7)
R765	1-216-033-00	METAL CHIP 220 5%	1/10W (760, 761, L7)
R766	1-249-418-11	CARBON 1.2K 5%	1/4W F (760, 761, L7)
R767	1-216-035-00	METAL CHIP 270 5%	1/10W (760, 761, L7)
R768	1-216-097-91	METAL GLAZE 100K 5%	1/10W (760, 761, L7)
R771	1-216-079-00	METAL CHIP 18K 5%	1/10W (760, 761, L7)
R776	1-216-073-00	METAL CHIP 10K 5%	1/10W (760, 761, L7)
R901	1-216-053-00	METAL CHIP 1.5K 5%	1/10W
R902	1-216-077-00	METAL CHIP 15K 5%	1/10W
R903	1-216-075-00	METAL CHIP 12K 5%	1/10W
R904	1-216-037-00	METAL CHIP 330 5%	1/10W
R905	1-216-295-00	METAL CHIP 0 5%	1/10W
R906	1-216-043-91	METAL GLAZE 560 5%	1/10W
R908	1-216-039-00	METAL CHIP 390 5%	1/10W
R912	1-216-075-00	METAL CHIP 12K 5%	1/10W
R913	1-216-077-00	METAL CHIP 15K 5%	1/10W
R914	1-216-037-00	METAL CHIP 330 5%	1/10W
R916	1-216-037-00	METAL CHIP 330 5%	1/10W
R917	1-216-047-91	METAL GLAZE 820 5%	1/10W
R918	1-216-049-91	METAL GLAZE 1K 5%	1/10W
R919	1-216-295-00	METAL CHIP 0 5%	1/10W
R920	1-216-075-00	METAL CHIP 12K 5%	1/10W
R921	1-216-077-00	METAL CHIP 15K 5%	1/10W
R931	1-216-295-00	METAL CHIP 0 5%	1/10W
R932	1-216-295-00	METAL CHIP 0 5%	1/10W
R933	1-216-295-00	METAL CHIP 0 5%	1/10W

MISCELLANEOUS

13	1-776-226-11	CABLE, FLAT (FMH-1) 9P
55	1-473-518-11	SWITCH BLOCK, CONTROL (790)
55	1-473-518-21	SWITCH BLOCK, CONTROL (960)
72	1-776-227-11	CABLE, FLAT (FMH-13) 7P
103	1-776-228-11	CABLE, FLAT (FDL-1) 10P (790, 960)
107	1-776-225-11	CABLE, FLAT (FMH-9) 15P
152	1-500-144-11	HEAD, FE
162	A-6739-103-A	ACE BLOCK ASSY

Ref. No.	Part No.	Description	Remark
164	1-506-485-11	PIN, CONNECTOR 6P	
220	8-848-576-02	DRUM ASSY, ROTARY UPPER (DZR-45-R)	(760, 761, 790, L7)
220	8-848-594-02	DRUM ASSY, ROTARY UPPER (DZR-51-R)	(960)
221	8-848-658-11	DRUM ASSY, LOWER (DZL-45B/J-RP)	(760, 761, 790, L7)
221	8-848-666-11	DRUM ASSY, LOWER (DZL-51B/J-RP)	(960)
223	8-848-681-11	DRUM ASSY, (DZH-73B/Q-RP)	(L5)
M902	1-698-409-11	MOTOR, DC SCV-0801A/Z-NP (CAPSTAN)	
M903	X-3943-883-1	MOTOR ASSY, CAM	
S410	1-572-662-11	SWITCH, ROTARY (DUAL MODE SHUTTLE)	

ACCESSORIES & PACKING MATERIALS

	1-473-483-11	REMOTE COMMANDER (RMT-V158C)	(960)
	1-473-483-21	REMOTE COMMANDER (RMT-V161A)	(790)
	1-473-487-11	REMOTE COMMANDER (RMT-V186)	(L7)
	1-473-487-21	REMOTE COMMANDER (RMT-V186A)	(L5)
	1-473-515-11	REMOTE COMMANDER (RMT-V184A)	(760, 761)
△	1-569-008-11	ADAPTER, CONVERSION 2P	(760HFPX, 960HFCS/HFPX, L5CS, L7HFCS)
△	1-575-131-11	CORD, POWER SUPPLY	(760HFPX, 960HFCS/HFPX, L5CS, L7HFCS)
	1-575-334-11	CORD, CONNECTION	(AUDIO, VIDEO) (760, 761, L7)
	1-696-592-11	CORD, CONNECTION (NTSC) (ANT)	
△	1-751-676-11	CORD, POWER	(EXCEPT 760HFPX, 960HFCS/HFPX, L5CS, L7HFCS)
	1-769-181-21	MOUSE, INTERIJENT CABLE	(790, 960)
	1-776-258-11	CORD, AVC CONNECTION	(790, 960)
	3-708-817-01	COVER, BATTERY (V-158C, V161A, V184A, V186, V186A)	
	3-800-533-11	MANUAL, INSTRUCTION (ENGLISH)	(960HFPX)
	3-800-552-11	MANUAL, INSTRUCTION (ENGLISH)	(760HF/HFPX, 761)
	3-800-552-21	MANUAL, INSTRUCTION (FRENCH)	(760HF)
	3-800-553-11	MANUAL, INSTRUCTION (ENGLISH)	(960HF)
	3-800-553-21	MANUAL, INSTRUCTION (FRENCH)	(960HF)
	3-800-553-31	MANUAL, INSTRUCTION (SPANISH)	(960HFCS/HFMX)
	3-810-205-11	MANUAL, INSTRUCTION (SPANISH)	(L7)
	3-810-206-11	MANUAL, INSTRUCTION (SPANISH)	(L5)
	3-810-321-11	MANUAL, INSTRUCTION (ENGLISH)	(790)
	3-810-321-21	MANUAL, INSTRUCTION (FRENCH)	(790)
	3-957-513-11	RING, SHUTTLE	(V-158C, V161A, V184A, V186, V186A)
*	3-966-238-01	INDIVIDUAL CARTON	(760)

Ref. No.	Part No.	Description	Remark
*	3-966-238-21	INDIVIDUAL CARTON	(761)
*	3-966-258-01	INDIVIDUAL CARTON	(790)
*	3-966-258-11	INDIVIDUAL CARTON	(960HF/HFPX)
*	3-967-323-01	CUSHION	(790, 960)
*	3-967-324-01	CUSHION (EXCEPT 790, 960)	
*	3-967-421-01	INDIVIDUAL CARTON	(960HFCS/HFMX)
*	3-967-422-01	INDIVIDUAL CARTON	(L7)
*	3-967-422-11	INDIVIDUAL CARTON	(L5)
	X-3944-446-2	BUTTON ASSY (C) (V-158C, V161A, V184A, V186, V186A)	

HARDWARE LIST

#1	7-685-648-79	SCREW +BVTP 3X12 TYPE2 IT-3
#2	7-685-646-79	SCREW (3X6)
#3	7-682-547-04	SCREW +P 3X6
#4	7-624-190-61	STOP RING 2.4, TYPE-CS
#5	7-624-106-04	STOP RING 3.0, TYPE-E
#6	7-682-645-01	SCREW +PS 3X4
#7	7-621-772-08	SCREW +B 2X3
#8	7-628-254-10	SCREW +PS 2.6X6

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

6-12. SYSTEM CONTROL - SYSTEM CONTROL PERIPHERAL CIRCUIT INTERFACE (MA-252 BOARD IC201)

Signal	Pin No.	I/O	I/O level
ASURA RESET	MA-252 IC201⑥	I	Normally "H", "L" when service interruption is detected or restored.
ASURA CS	MA-252 IC201⑦	I	Chip select signal from timer microprocessor. V period "L" pulse.
S IN 0	MA-252 IC201⑧	I	Serial communication data from timer microprocessor. V period "L" pulse.
S OUT 0	MA-252 IC201⑨	O	Serial communication data to timer microprocessor. V period "L" pulse.
S CLK	MA-252 IC201⑩	I	Serial communication clock with timer microprocessor. V period "L" pulse.

6-13. SYSTEM CONTROL - HI-FI AUDIO BLOCK INTERFACE (MA-252 BOARD IC201)

Signal	Pin No.	I/O	STOP/ FF/ REW	TAPE LOADING	TAPE UNLOADING	PB	PB * PAUSE	SLOW	x 2	CUE	REVIEW	REC	REC * PAUSE
AF ENV	MA-252 IC201⑪	I											
A MUTE	MA-252 IC201⑫	O (O.D)	L	L	L	*1	H	H	H	H	H	L	L
NA REC P	MA-252 IC201⑬	O	L	L	L	L	L	L	L	L	L	H	L
AF REC P	MA-252 IC201⑭	O	L	L	L	L	L	L	L	L	L	H	L
AF SWP	MA-252 IC201⑮	O	*1	L	L	*1	*1	*1	*1	*1	*1	*1	*1
FULL ERS	MA-252 IC201⑯	O (O.D)	H	H	H	H	H	H	H	H	H	L	H

*1. 30 Hz 50% duty pulse approx. 5 msec delayed from RF SW P.

6-14. SYSTEM CONTROL - NORMAL AUDIO BLOCK INTERFACE (MA-252 BOARD IC201)

Signal	Pin No.	I/O	STOP/ FF/ REW	TAPE LOADING	TAPE UNLOADING	PB	PB • PAUSE	SLOW	× 2	CUE	REVIEW	REC	REC • PAUSE
AF ENV	MA-252 IC201	I											
NA PB	MA-252 IC201	O	L	L	L	H	H	H	H	H	H	L	L
A MUTE	MA-252 IC201	O (O.D.)	L	L	L	*1	H	H	H	H	H	L	L
NA SP POWER CONT2	MA-252 IC201	O	*2	*2	*2	*3	*3	*3	*3	*3	*2	*2	*2
NA REC P	MA-252 IC201	O	L	L	L	L	L	L	L	L	L	H	L
AF REC P	MA-252 IC201	O	L	L	L	L	L	L	L	L	L	H	L
AF SWP	MA-252 IC201	O	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1
FULL ERS	MA-252 IC201	O (O.D.)	H	H	H	H	H	H	H	H	H	L	H

AF RF envelope signal input terminal for automatic tracking.

*1. 30 Hz 50% duty pulse approx. 5 msec delayed from RF SW P.

*2. Selected by REC mode selector. SP mode: "L".

*3. Selected by tape recording mode. SP mode: "L".

6-15. SYSTEM CONTROL AND RF MODULATOR - INPUT SELECTION BLOCK INTERFACE

Signal	Pin No.	I/O	I/O level
LINE 1	MA-252 IC201	O	*1. Input select control signal.
LINE 2	MA-252 IC201	O	

*1.

Input Signal	Tuner	LINE 1	LINE 2
LINE 1	L	H	L
LINE 2	L	L	H


6-16. SERVO/SYSTEM CONTROL MICROPROCESSOR PIN FUNCTION
 (MA-252 BOARD IC201 CXP87360-040Q: SLV-L5, L7/CXP87360-039Q: SLV-760,761)

Pin No.	Pin name	IO	Function
1	RF SWP	0	RF switching pulse output
2	QVD	0	Quasi V0 pulse output
3	QHD ENABLE	0	Quasi HD voltage level control
4	AF REC P	0	"H" output when hi-fi audio REC input selection control signal
5	LINE 1	0	MAINSAP logic signal output
6	MAINSAP	0	REC CTL signal output
7	REC CTL	0	Captain current control
8	CAP TRC2	0	APC control input terminal 2
9	APC2	0	APC control input terminal 1
10	APC1	1	APC control input terminal 1
11	NR REC P	0	Normal audio recording mode H, recording mode L, when SP mode "H" when EPALP mode
12	SP/EP/LP	0	Leading motor rotating direction control
13	CAM LOAD	1	Leading motor rotating direction control
14	CAM UNLOAD	1	Leading motor rotating direction control
15	C IN (REC PRF)	1	Erasing protection (be), cassette IN detection input
16	RENTAL	0	YMR control
17	A MUTE	0	"H" when audio mute
18	NC	-	Not used
19	STEREO	1	Tuner audio mode input (stereo)
20	F MAND	0	Tuner audio select signal
21	TVTR	0	"H" when TV mode "L" when VTR mode
22	SYS CHECK	0	System check control signal
23	EPAS CS	0	EPAS chip select signal
24	TU CLOCK	0	Tuner PLL clock
25	TU DATA	0	Tuner PLL data
26	TU ENABLE	0	Tuner chip select
27	MODE 4	1	Mechanism section CAM encoder input
28	MODE 3	1	Mechanism section CAM encoder input
29	MODE 2	1	Mechanism section CAM encoder input
30	MODE 1	1	Mechanism section CAM encoder input
31	CAM 1PV	0	CAM motor reference voltage
32	TVE LED	0	TVE LED output
33	CAP TRC2	0	Captain current control signal 2 L: FEEDREW to STOP
34	CAP TRC1	0	Captain current control signal 1 L: SLOW speed down
35	CAP STOP	0	Captain STOP signal output
36	FULL ER5	0	Full erase control
37	REP RESET	0	EEP ROM reset output
38	MP	0	EEP ROM select
39	ASURR RESET	1	System reset input
40	VSS	-	GND
41	XTAL	-	System clock 16 MHz
42	EXTAL	-	System clock 16 MHz
43	ASURR CS	1	S/S microcomputer chip select signal
44	S IN 0	1	Serial communication signal
45	S IN 1	1	Serial communication signal
46	S OUT 0	0	Serial communication signal
47	S OUT 1	0	Serial communication signal
48	OSD CS	0	OSD chip select signal
49	SYS RESET	0	System reset output
50	FLD CS	0	FLD chip select signal


Pin No.	Pin name	IO	Function
51	POWER CONT1	0	Power control signal 1
52	AVSW	-	UNSW GND
53	AVREF	-	AD port reference input UNSW SV
54	AVDD	-	UNSW SV
55	APC ERROR	1	APC error input
56	ATF	1	ATF signal input
57	DEST2 DEW	1	DEW sensor input (Not used)
58	VAUX1	1	ADU mode DC SWP Adj 2.5V; Hi-Fi Adj
59	AF ENV	1	Hi-Fi audio playback signal envelope
60	RF ENV	1	Video playback signal envelope
61	T SENS	1	Take up and sensor input
62	S SENS	1	Supply and sensor input
63	S REEL FG	1	S side reel FG input
64	T REEL FG	1	T side reel FG input
65	H DET	1	H sync separation input
66	V SYNC	1	Composite sync input
67	FB CTL	1	Feedback CTL input
68	DIRM FG	1	Drum FG input
69	DIRM FG	1	Drum FG input
70	CAP FG	1	Captain FG input
71	AUTOPHRESET	0	Autopreset on display
72	CAP RVS	0	Captain reverse control H when Reverse
73	CAP DA	0	Captain error D/A output
74	DIRM DA	0	Drum FG input
75	CTL REED	0	"H" CTL wette
76	CTL STEP	0	CTL wette, STEP operation control
77	EEP BUSHY	1	EEP ROM busy signal input
78	EDS DAV	0	Not used
79	CTL INDEX	0	CTL INDEX signal input
80	S IN	0	Signal for serial communication
81	S OUT	0	Signal for serial communication
82	POWER FAIL	1	Power voltage drop detection terminal
83	LINE 2 CONT	0	Input selection control signal
84	APC PWM	0	PWM output for APC
85	RMC	1	Remote control signal input
86	TEX	-	Liquid crystal oscillation terminal (327kHz)
87	TX	-	Liquid crystal oscillation terminal (327kHz)
88	VSS	-	GND
89	VDD	-	SV
90	NC	-	Not used
91	ORC SETTEL	0	H when ORC measurement
92	NC	0	Not used
93	SIF	0	Time speed select
94	POWER CONT 2	0	Power control signal 2
95	MA PB	0	Audio output control signal H when normal audio playback
96	AF REC	0	"H" output when hi-fi audio REC
97	JOG	0	"H" when JCK play mode
98	V PB	0	Video system playback mode "L" when playback
99	STEP PLS	0	Step pulse H when Capstan stop driving
100	AF SWP	0	AF emitting pulse output

2-7. PARTS ARRANGEMENT DIAGRAM FOR ADJUSTMENTS


MA-251/252 BOARD (CONDUCTOR SIDE)



RP-197/198/202/203 BOARD (COMPONENT SIDE)





PS-355/356/367/368 BOARD (COMPONENT SIDE)



VHS MECHANICAL ADJUSTMENT MANUAL IV

H MECHANISM

Please use with the service manual.



VHS VIDEO CASSETTE RECORDER
SONY®



TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
1.	PREPARATION FOR MECHANISM CHECK ADJUSTMENT AND REPLACEMENT		3-11.	Soft Brake T Assembly (Fig. 3-13)	21
1-1.	Loading and Threading Procedure When the Power Turns Off (Fig. 1-1)	3	3-12.	RVS Brake Arm Assembly, Reel Table (T) Assembly (Fig. 3-14)	22
1-1-1.	Loading and Threading Procedure With Hands	3	3-13.	TG8 Assembly (Fig. 3-15)	23
1-1-2.	Loading and Threading Procedure With Regulated DC Power Supply	3	3-14.	TG8 Holder (Fig. 3-16)	24
1-2.	Unloading and Unthreading Procedure When the Power Turns Off (Figs. 1-2 and 1-3)	4	3-15.	TG8 and Press Gears (Fig. 3-17)	25
1-2-1.	Unloading and Unthreading Procedure With Hands	4	3-16.	Cam Motor Chassis Block Assembly, Upper/Lower Communication Gear (Fig. 3-18)	26
1-2-2.	Unloading and Unthreading Procedure With Regulated DC Power Supply	4	3-17.	Rotary Encoder Switch (Fig. 3-19)	27
1-3.	How to Complete Threading Without Cassette Compartment (Fig. 1-4)	6	3-18.	Main Slider (Fig. 3-20)	28
2.	PERIODIC CHECK AND REPLACEMENT		3-19.	Shuttle T Block and Loading Gear T Block Assemblies (Fig. 3-21)	29
2-1.	Cleaning of Rotating Head Disk Assembly	7	3-20.	Shuttle S Block and Loading Gear S Block Assemblies (Fig. 3-22)	30
2-2.	Cleaning of the Tape Movement System	7	3-21.	Reel Table (S) Assembly (Fig. 3-23)	31
2-3.	Cleaning the Drive System	7	3-22.	TG1 Assembly (Fig. 3-24)	32
2-4.	Periodic Check Items	8	3-23.	S Winding Block Assembly (Fig. 3-25)	33
2-5.	Tools and Fixtures Required for Servicing	9	3-24.	Trigger Lever and RKB Block Assemblies (Fig. 3-26) ..	34
3.	MAINLY MECHANICAL PARTS REPLACEMENT		4.	ADJUSTMENT	
3-1.	FL Block Assembly (Fig. 3-1)	10	4-1.	Tape Path Adjustment	35
3-2.	Drum Assembly (Fig. 3-2)	11	4-1-1.	Tension Regulator (TG1) Position/ Tension Adjustment (Fig. 4-1)	35
3-3.	Timing Belt (Fig. 3-3)	12	4-1-2.	TG8 Guide Roller Height Adjustment (Fig. 4-2)	36
3-4.	Cap Brake Assembly (Fig. 3-4)	13	4-1-3.	Height Adjustment of Guide Rollers No. 3 and No. 6 (Fig. 4-3)	36
3-5.	TG2 Roller, FE Head Assembly (Fig. 3-5)	14	4-1-4.	Ace Head Assembly Adjustment (Rough Adjustment) (Figs. 4-4 and 4-5)	37
3-6.	Pinch Press Block Assembly, Elevator Gear (Fig. 3-6) ..	15	4-1-5.	Ace Head Assembly Adjustment (Precision Adjustment)	38
3-7.	Ace Block Assembly (Fig. 3-7)	16	4-1-6.	X-Value Adjustment	38
3-8.	TG3, TG6 Guide Roller Assemblies (Fig. 3-8)	17	4-1-7.	Adjustments After Replacing the Drum (Video Head)	40
3-9.	Capstan Motor (Fig. 3-11)	19	4-1-8.	Checking the Tension and Torque	42
3-10.	Main Brake Assemblies S and T (Fig. 3-12)	20			

1. PREPARATION FOR MECHANISM CHECK ADJUSTMENT AND REPLACEMENT

Refer to the service manual, "DISASSEMBLY" for removal of the cabinet and boards.

1-1. LOADING AND THREADING PROCEDURE WHEN THE POWER TURNS OFF (Fig. 1-1)

1-1-1. LOADING AND THREADING PROCEDURE WITH HANDS

- 1) Turn cam motor in the arrow \odot direction until loading and threading are end.

1-1-2. LOADING AND THREADING PROCEDURE WITH REGULATED DC POWER SUPPLY

- 1) Applying approx. +9 V (300 mA) to cam motor with regulated DC power supply makes it loading and threading.

Note: When loading and threading without cassette, claws are caught in four positions as following figure (in the order ① → ② → ③ → ④).
So release them with hands.




Fig. 1-1

1-2. UNLOADING AND UNTHREADING PROCEDURE WHEN THE POWER TURNS OFF (Figs. 1-2 and 1-3)

1-2-1. UNLOADING AND UNTHREADING PROCEDURE WITH HANDS

- 1) Turn cam motor in the arrow \oplus direction until unthreading is end.
- 2) Turn capstan motor in the arrow \ominus direction to take up tape in cassette.
- 3) Turn cam motor in the arrow \oplus direction until unloading is end.

1-2-2. UNLOADING AND UNTHREADING PROCEDURE WITH REGULATED DC POWER SUPPLY

- 1) Apply approx. +9 V (300 mA) to contrary polarities of cam motor.
- 2) Unthreading operation begins, tape guides return to their original positions (Unthreading operation is end but tape remains), then stop cam motor by turning power off.

Note: When unloading begins and cassette lid is closed, turn cam motor in the arrow \ominus direction to open tape guard.

- 3) Turn capstan motor in the arrow \ominus direction to take up tape in cassette.

Note: That tape is not caught at pinch roller. (Fig. 1-3)

- 4) Check that tape is not loosened completely, and apply approx. +9 V (300 mA) to contrary polarities of cam motor with regulated DC power supply. (Fig. 1-2)




Fig. 1-2




Fig. 1-3

1-3. HOW TO COMPLETE THREADING WITHOUT CASSETTE COMPARTMENT (Fig. 1-4)

Note 1: Put the FL block assembly removed the FL top plate on the bottom not to put dust or grease the top sensor and the end sensor luminous plates or not to scratch them.
(Fig. A)

- 1) Pull out AC plug from wall outlet.
- 2) Shade near the end and top sensors with a black masking tape on the like.
- 3) Press cassette in/rec proof switch with a tip of screwdriver or the like.
- 4) Connect AC plug to wall outlet.
- 5) Release cassette in/rec proof switch by putting off a tip of screwdriver or the like.

(At this time, power turns on, rewind operates for 10 seconds, after that power turns off.)

Note 2: In this condition, each mode can be set to video cassette recorder. (including recording mode)
However, fast forward should be done after rewinding for 15 seconds or more.

Note 3: After above mentioned operation, be sure to return the mode in the following order.

- 1) Remove the tape near the end and top sensors.
- 2) Pull out AC plug from wall outlet to reset the system control microcomputer.




Fig. 1-4

2. PERIODIC CHECK AND REPLACEMENT

In order to obtain the best performance from this unit and make full use of its capabilities, and to extend the life of the unit and tapes, it is recommended that the following periodic checks and maintenance be performed.

* The following must be done after every repair regardless of how many hours the user has operated the machine.

2-1. CLEANING OF ROTATING HEAD DISK ASSEMBLY

- 1) Press a chamois cloth (Jig Ref. No. J-9) which has been dipped in cleaning fluid (Jig Ref. No. J-8) lightly against the rotating drum assembly, then do the cleaning by slowly rotating the rotating head disk by hand. (Never try to clean by using the motor to turn it.)
- 2) Never try to clean by moving the chamois cloth at a vertical angle to the head tip. There is a very great danger of damaging the head tip if this is done.

2-2. CLEANING OF THE TAPE MOVEMENT SYSTEM

- 1) Clean the surfaces which the tape contacts during its movement (tape guide, drum assembly surface, capstan, pinch roller, etc.) with a chamois cloth that has been dipped in cleaning fluid.

2-3. CLEANING THE DRIVE SYSTEM

- 1) Clean the driving parts with a cloth that been dipped in cleaning fluid.




Fig. 2-1 Parts requiring cleaning

2-4. PERIODIC CHECK ITEMS

Perform the maintenance and check listed on the table below, according to users operating hours.

Maintenance & Check		Operating Hours (H)										Remarks
		500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	
Tape Transportation System	Cleaning of tape transportation system	○	○	○	○	○	○	○	○	○	○	This cleaning must be done whenever a repair is made.
	Cleaning and degaussing of ACE assembly	○	○	○	○	○	○	○	○	○	○	
	Cleaning & degaussing of upper drum assembly	○	○	○	○	○	○	○	○	○	○	The life of the head varies, depending on operational conditions and method.
Performance Confirmation	Abnormal sound	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Adjust or replace the section which causes abnormal sound.
	Measurement of FWD back tension	-	☆	-	☆	-	☆	-	☆	-	☆	Confirmation must be made according to 4-1-1. Specified value: adjust to 36 to 44 g*cm (when measured with torque cassette tape)
	Confirmation of brake system	-	☆	-	☆	-	☆	-	☆	-	☆	Confirmation must be made according to section.
	Confirmation of record & playback functions	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Perform the confirmation whenever repair is made.
	Measurement of forward torque	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Adjust to 70 to 120 g*cm


○ Cleaning ☆ Confirmation

Note: On overhaul

When overhauling the unit, replace parts as indicated in the above table.

2-5. TOOLS AND FIXTURES REQUIRED FOR SERVICING

Ref No.	Name	Part No.	Carved Jig No.	Remarks
J-1	Master Plane	H-7099-279-H		Applicable to S-VHS
J-2	Reel Disk Height Jig	H-7099-038-H		
J-3	Torque Gauge Adaptor	H-7099-035-H		
J-4	0.93 mm Torque Gauge	H-7099-039-H		
J-5	Hex. Wrench	H-7099-202-H		
J-6	Torque Measurement Cassette VHT-063S	J-6082-011-A		For FWD & back tension torque measurement.
	Torque Measurement Cassette VHT-404S	J-6082-012-A		For CUE and review torque measurement.
J-7	Alignment Tape JVC-MH-1 (NTSC)	H-7099-046-H		
	24HASF-2 (NTSC Hi-Fi)	H-7099-153-H		
	JVC-MH-2 (PAL)	H-7099-052-H		
	JVC-MH-4 (SECAM)	H-7099-053-H		
J-8	Cleaning Fluid	Y-2031-001-0	—	
J-9	Chamois Leather	2-034-697-00	—	
J-10	Head Demagnetizer	Widely available	—	Demagnetize video heads and audio heads.
J-11	Dental Mirror (With handle)	J-6080-029-A	SL-5052	Tape path and tape traveling adjustments or checks.
	Dental Mirror (Mirror)	J-6080-030-1		
J-12	FLOIL SG-055G	7-651-000-09		
J-13	Diamond Oil NT-68	7-661-018-18		
J-14	Screw Lock G (I401B)	7-432-114-11		



3. MAINLY MECHANICAL PARTS REPLACEMENT

Notes:

- Refer to the service manual, "DISASSEMBLY" for removal of the cabinet and boards.
- On mounting, while referring to notes on mounting perform reversely in the removal order.
- When replacing greased parts, grease them in the same way.
- Do not oil, grease or touch with bare hands the surfaces contacts tape of guides and brake shoes.
- Install gears to engage each other.
- Basically, disassembling and assembling should be done in the unthreading-end condition.

3-1. FL BLOCK ASSEMBLY (Fig. 3-1)

- 1) Remove screws ①.
- 2) Remove FL block assembly ② in the arrow **A** direction.

Note: Be careful not to damage claws on the bottom and front.

[Note on Mounting]

- First insert claws on the bottom and front not to damage.
- Engage FL slide plate to FL driving gear with slightly sliding FL slide plate. (Fig. A)
- Keep clean top sensor and end sensor luminous plates. (Refer to 1-3.)




Fig. 3-1

3-2. DRUM ASSEMBLY (Fig. 3-2)

- 1) Remove screw ①.
- 2) Remove ground shaft assembly ② not to touch its tip with bare hand or tools.
- 3) Remove screws ③ to remove drum assembly ④.

[Note on Mounting]

- Don't touch head chips ⑤ and ground shaft assembly ④ with bare hand or tools.
- Keep clean the surface contacts tape of drum assembly ④.

[Adjustment after Mounting]

- 4-l. Tape path adjustment.




Fig. 3-2

3-3. TIMING BELT (Fig. 3-3)

- 1) Remove screw ① to remove tension vehicle arm assembly ②.
- 2) Remove timing belt ③.

[Note on Mounting]

- Tighten screw ① while pressing tension vehicle arm in the arrow ④ direction.




Fig. 3-3

3-4. CAP BRAKE ASSEMBLY (Fig. 3-4)

- 1) Remove tension vehicle arm assembly. (Refer to 3-3)
- 2) Remove torsion coil spring ① from portion ④ to remove CAP brake assembly.

[Note on Mounting]

- Mount torsion coil spring ① to CAP brake assembly ② in the order ④ and ③. (Fig. A)
- Put the fulcrum of CAP brake assembly ② to CAP brake shaft ③ and the tip of torsion coil spring to ④.
- Don't touch brake shoe ⑤ with bare hand.




Fig. 3-4

**3-5. TG2 ROLLER, FE HEAD ASSEMBLY
(Fig. 3-5)**

- 1) Remove claw **A** to pull out TG2 roller **①**.
- 2) Remove screw **②** to pull out FE head assembly.

[Note on Mounting]

- Keep clean the surface contacts tape of TG2 roller **①**.




Fig. 3-5

3-6. PINCH PRESS BLOCK ASSEMBLY, ELEVATOR GEAR (Fig. 3-6)

- 1) Remove E ring ① to pull out pinch press block assembly ②.
- 2) Remove lid opener ③ by pressing claw ④ in the arrow ⑤ direction.
- 3) Pull out elevator gear ④.

[Note on Mounting]

- Apply grease FLOIL SG-055G (Jig Ref. No. J-12) to ☆ marked portions.
- Be sure to match the phase ● between elevator gear ④ and press gear ⑤ on mounting elevator gear ④.




Fig. 3-6

3-7. ACE BLOCK ASSEMBLY (Fig. 3-7)

- 1) Move torsion coil spring (ACE) ① in the arrow ④ direction.
- 2) Remove ACE adjustment screw ②.
- 3) Remove AC height adjustment nut ③ to pull out ACE block assembly ④.

[Note on Mounting]

- Keep clean the surface contacts tape of ACE block assembly ④.
- Be sure to hang torsion coil spring (ACE) ① in the arrow ⑤ direction.
- Set ACE adjustment screw ② to the height as shown in Fig. A.

[Adjustment after Mounting]

- 4-1. Tape path adjustment.
- After adjustment apply Screw Lock G (1401B) (Jig Ref. No. J-14) at ☆ marked portion.




Fig. 3-7

3-8. TG3, TG6 GUIDE ROLLER ASSEMBLIES (Fig. 3-8)

- 1) Loosen screw ① and pull out. TG3 guide roller assembly ② by turning it in the arrow Ⓐ direction.
- 2) Loosen screw ③ and pull out TG6 guide roller assembly ④ by turning it in the arrow Ⓑ direction.

[Note on Mounting]

- Keep clean the surface contacts tape of TG3 and TG6 guide roller assemblies ②, ④.

[Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-8




Fig. 3-9




Fig. 3-10

3-9. CAPSTAN MOTOR (Fig. 3-11)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove screws ① to pull out capstan motor ②.

[Note on Mounting]

- Keep clean the surface contacts tape of capstan motor ②.
- On tightening screws ①, first tighten screw A temporarily, next tighten screws in the order B to C to A.

[Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-11

3-10. MAIN BRAKE ASSEMBLIES S AND T
(Fig. 3-12)

- 1) Remove tension spring ①.
- 2) Remove stopper washer (2) ② to remove neutrality arm ③.
- 3) Remove pendulum compulsion arm ④ and tension coil spring ⑤.
- 4) Remove stopper washer (2) ⑥ to remove main brake S assembly ⑦.
- 5) Remove stopper washer (2) ⑧ to remove main brake T assembly ⑨.

[Note on Mounting]

- Don't touch brake shoes ④ and ⑤ with bare hand.
- Apply FLOIL FG-055G (Jig Ref. No. J-12) to ☆ marked portions.




Fig. 3-12

3-11. SOFT BRAKE T ASSEMBLY (Fig. 3-13)

- 1) Remove pinch press block assembly. (Refer to 3-6.)
- 2) Remove lid opener ① carefully not to damage claw ④.
- 3) Remove tension spring ② from side ⑤ to pull out soft brake T assembly ③.

[Note on Mounting]

- Don't touch brake shoes ⑥ with bare hand.




Fig. 3-13

3-12. RVS BRAKE ARM ASSEMBLY, REEL TABLE (T) ASSEMBLY (Fig. 3-14)

- 1) Remove main brake T assembly. (Refer to 3-10.)
- 2) Remove soft brake T assembly. (Refer to 3-11.)
- 3) Remove tension coil spring ① in the order ④ to ③.
- 4) Remove RVS brake arm assembly ②.
- 5) Remove stopper washer (2) ③ to pull out reel table (T) assembly ④.

[Note on Mounting]

- Apply one drop of Diamond Oil NT-68 (Jig Ref. No. J-13) to ☆ marked portion before mounting reel table (T) assembly ④. (Fig. A)
- Don't touch the hatched portion on reel table (T) assembly ④ and brake shoe ⑥ of RVS brake arm assembly ② with bare hand.




Fig. 3-14

3-13. TG8 ASSEMBLY (Fig. 3-15)

1) Remove TG8 retainer ① to pull out TG8 assembly ②.

[Note on Mounting]

- Apply FLOIL SG-055G (Jig Ref. No. J-12) to ☆ marked portion.
- Keep clean the surface contacts tape of TG8 assembly ②.
- Be careful not to change the shape of TG8 retainer ①.

[Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-15

3-14. TG8 HOLDER (Fig. 3-16)

- 1) Remove TG8 assembly. (Refer to 3-13)
- 2) Pull out TG8 holder ①.

[Note on Mounting]

- Be careful about the direction of TG8 holder ①. (A of Fig. A)

[Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-16

3-15. TG8 AND PRESS GEARS (Fig. 3-17)

- 1) Remove pinch press block assembly. (Refer to 3-6.)
- 2) Remove soft brake T assembly. (Refer to 3-11.)
- 3) Remove TG8 assembly. (Refer to 3-13.)
- 4) Remove TG8 holder. (Refer to 3-14.)
- 5) Pull out TG8 gear ① or press gear ②.

[Note on Mounting]

- Adjust the holes on gears to the holes on chassis. (Fig. A)
- Adjust the arrows carved on gears each other. (Fig. A)




Fig. 3-17

3-16. CAM MOTOR CHASSIS BLOCK ASSEMBLY, UPPER/LOWER COMMUNICATION GEAR (Fig. 3-18)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove screws ① to remove cam motor chassis assembly ②.
- 4) Pull out upper/lower communication gear ③.

[Note on Mounting]

- First, check main slider ④ slides fully in the arrow direction.
- Set rotary encoder switch position to "E" seen from the window of cam motor chassis. (Fig. A)
- Tighten screws ① in the order ① to ② to ③ to ④.




Fig. 3-18

3-17. ROTARY ENCODER SWITCH (Fig. 3-19)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove cam motor chassis block assembly (Refer to 3-15.) and turn upside on the bottom.
- 4) Remove stopper washer (2) ① to pull out worm wheel ②.
- 5) Remove stopper washer (2) ③ to pull out cam gear ④.
- 6) Pull out FL driving gear ⑤ and rotary encoder switch ⑥.

[Note on Mounting]

- Apply FLOIL SG-055G (Jig Ref. No. J-12) to ☆ marked portions. (Fig. 3-19, A)
- Adjust the hole ① to the hole on cam motor chassis. (Fig. B)
- Adjust the holes ② and ③ to the hole on cam motor chassis. (Fig. C)




Fig. 3-19

3-18. MAIN SLIDER (Fig. 3-20)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove cam motor chassis block assembly. (Refer to 3-16.)
- 4) Remove screw ① to remove retainer ②.
- 5) Pull out main slider ③.

[Note on Mounting]

- Apply FLOIL SG-055G (Jig Ref. No. J-12) as shown in Fig. A.
- At the last, slide main slider fully in the arrow A direction.




Fig. 3-20

3-19. SHUTTLE T BLOCK AND LOADING GEAR T BLOCK ASSEMBLIES (Fig. 3-21)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove cam motor chassis block assembly. (Refer to 3-16.)
- 4) Remove main slider. (Refer to 3-18.)
- 5) Remove screw ① to remove loading leaf (T) spring ② and shuttle T block assembly ③.
- 6) Pull out loading gear T block assembly ④.

[Note on Mounting]

- Adjust the phase **A** between loading gear (T) and loading gear (S). (Fig. A)
- Keep clean the surface contacts tape of shuttle T block assembly ③.




Fig. 3-21

3-20. SHUTTLE S BLOCK AND LOADING GEAR S BLOCK ASSEMBLIES (Fig. 3-22)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove cam motor chassis block assembly. (Refer to 3-16.)
- 4) Remove main slider. (Refer to 3-15.)
- 5) Remove screw ① to remove loading leaf (S) spring ② and shuttle S block assembly ③.
- 6) Pull out loading gear S block assembly ④.

[Note on Mounting]

- Adjust the phase Ⓐ between loading gear (S) and loading gear (T). (Fig. A)
- Keep clean the surface contacts tape of shuttle S block assembly ③.




Fig. 3-22

3-21. REEL TABLE (S) ASSEMBLY (Fig. 3-23)

- 1) Remove tension spring ① from the chassis side.
- 2) Remove stopper washer (2) ② to pull out soft brake (S) ③.
- 3) Move TG1 band ④ over the reel table.
- 4) Remove stopper washer (2) ⑤.
- 5) While pressing main brake S assembly ⑥, pull out reel table (S) assembly ⑦.

[Note on Mounting]

- Apply one drop of Diamond Oil NT-68 (Jig Ref. No. J-13) to ☆ marked portion before mounting reel table (S) assembly ⑦.
(Fig. A)
- Don't touch the hatched portion on reel table (S) assembly ⑦ with bare hand.




Fig. 3-23

3-22. TG1 ASSEMBLY (Fig. 3-24)

- 1) Set the mechanism to the loading-end condition referring to 1-1. (Cam gear indicates "LE". (Refer to Fig. A and B of Fig. 3-18.))
- 2) Remove tension spring ① in the order Ⓐ to Ⓑ.
- 3) Remove stopper washer (2) ② to pull out TG1 assembly ③.

[Note on Mounting]

- Apply one drop of Diamond Oil NT-68 (Jig Ref. No. J-13) to ☆ marked portion.
- Keep clean the felt side of TG1 assembly.




Fig. 3-24

3-23. S WINDING BLOCK ASSEMBLY (Fig. 3-25)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove cam motor chassis block assembly. (Refer to 3-16.)
- 4) Remove main slider. (Refer to 3-18.)
- 5) Remove stopper washer (2) ① to pull out S winding block assembly ②.
- 6) Remove torsion spring ③.

[Note on Mounting]

- At the last, hang torsion spring ② to the position ④.
- Apply FLOIL SG-055G (Jig Ref. No. J-12) to ☆ marked portions.




Fig. 3-25

3-24. TRIGGER LEVER AND RKB BLOCK ASSEMBLIES (Fig. 3-26)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove cam motor chassis block assembly. (Refer to 3-16.)
- 4) Remove main slider. (Refer to 3-18.)
- 5) Remove tension spring ① in the order ④ to ③ to remove trigger lever assembly ②.
- 6) Remove screws (3 × 8) ③ to remove RKB block assembly ④.

[Note on Mounting]

- Apply FLOIL SG-055G (Jig Ref. No. J-12) to ☆ marked portions on trigger lever assembly. (Fig. A)




Fig. 3-26

4. ADJUSTMENT

4-1. TAPE PATH ADJUSTMENT

The "Tape path" refers to the route of the tape from the supply reel disk to the take-up reel disc via the video heads.

Each component part of the tape transport system particularly the surface of parts which make direct contact with the tape must always be kept clean, free of dust, oil, scratches and so forth.

The tape path system is factory preadjusted, when parts of the tape transport system are replaced, be sure to make the required adjustments as precisely as possible in order to ensure stable tape transport.

4-1-1. TENSION REGULATOR (TG1) POSITION/ TENSION ADJUSTMENT (Fig. 4-1)

Purpose: stabilizes contact of the video head and the tape to maintain the tension of the tape so that it feeds at a constant level.

• Position adjustment

Mode	Treading is completed without a cassette loaded
Adjustment locations	Eccentric pin of TG1 band assembly

[Adjustment Method]

- 1) Allow the unit to go through the threading procedure without a cassette loaded.

- 2) Set the unit to play back, then turn the eccentric pin so that the tip of tension arm goes to the left side line carved on the mechanical chassis. (Fig. A)
- 3) After adjustment, go through the loading procedure once more without a cassette loaded, then check the position of the tension arm.

• Tension adjustment

Mode	Playback
Measuring instrument/tool	Torque cassette
Adjustment locations	Position for hooking the tension spring
Specified value	36 to 44 g*cm

[Adjustment Method]

- 1) Playback the torque cassette.
 - 2) Check that the center value deviation reading on the torque cassette meets with the standards.
 - 3) When the reading is higher than the standards: Move the spring toward direction ㉔.
- When the reading is less than the standards: Move the spring toward direction ㉕.




Fig. 4-1

4-1-2. TG8 GUIDE ROLLER HEIGHT ADJUSTMENT (Fig. 4-2)

Mode	Playback
Jig	Blank tape
Adjustment locations	Guide roller height adjustment screw
Specified value	0 to 0.1 mm

Procedure:

- 1) Set the tape, during CUE playing back, check the height from lower flange of TG7 to the running tape. (Fig. A)
- 2) During REV playing back, check the height from lower flange of TG7 to the running tape. (Fig. B)
- 3) When the difference between items 1) and 2) doesn't go to specified value, adjust by turning TG8 guide roller height adjustment screw.
- 4) Check the tape is creased or not between the capstan and TG8, adjust with TG8 guide roller height adjustment screw so that the tape is not creased during normal playback, CUE and REV.




Fig. 4-2

4-1-3. HEIGHT ADJUSTMENT OF GUIDE ROLLERS NO. 3 AND NO. 6 (Fig. 4-3)

Mode	Playback
Signal	Alignment tape
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SW P pin for RF PC board check.
Adjustment locations	Guide roller height adjuster screw

[Adjustment Method]

- 1) Tracking (playback): Turn off the auto tracking, then press the tracking buttons ∇ and \triangle simultaneously to set the tracking at the center position.
(If adjustment is made after the drum is replaced, the tracking must be set at the max. RF output position.)
- 2) Height adjuster screw: Even out the RF output waveforms.
- 3) Press the tracking buttons (playback), ∇ and \triangle alternately.
- 4) Check that RF output drops the same amount at the front and rear edges.




Fig. 4-3

**4-1-4. ACE HEAD ASSEMBLY ADJUSTMENT
(ROUGH ADJUSTMENT) (Figs. 4-4 and 4-5)**

Purpose: Allows the tape to make even contact with the head for recording and playback of the specified track.

Mode	Playback
Tool	Blank tape
Adjustment locations	Height adjuster nut, Tilt adjuster screw

[Adjustment Method]

- 1) Mount the ACE head assembly. At this time, adjust the height so that the height of guide flange No. 7 matches the level of the lower edge of the control head.
- 2) Remove the adjustment tool and load a new tape, then set the unit for playback.
- 3) Check that the tape does not curl or rise up noticeably near the ACE head.
- 4) If the tape curls up or rises noticeably, readjust the tilt adjuster screw, the azimuth adjuster screw and the height adjuster nut.

(The height of the ACE head should be adjusted so that the lower edge of the tape is approx. 0.1 to 0.15 mm from the control head.)

- 5) Perform precision adjustment.




Fig. 4-4




Fig. 4-5

4-1-5. ACE HEAD ASSEMBLY ADJUSTMENT (PRECISION ADJUSTMENT)

Mode	Playback
Signal	Alignment tape (1kHz track)
Measuring instrument	Oscilloscope
Measuring point	Audio output terminal
Adjustment locations	Azimuth adjuster screw, Height adjuster nut, Tilt adjuster screw

[Adjustment Method]

- 1) Adjust the tilt adjuster screw in the FWD or REV mode so that the lower flange of guide No. 7 does not curl up or rise.
- 2) Alternately adjust the azimuth adjuster screw, the height adjuster nut, and the tilt adjuster screw to maintain even audio output at maximum with minimum deviation.




Fig. 4-6

4-1-6. X-VALUE ADJUSTMENT

Purpose: To obtain compatibility with other VTR

Precaution: Be sure to perform the preset tracking adjustment before perform this adjustment. (Refer to the Service Guide.)

Turn off the auto tracking and set the VTR for manual tracking mode.

Mode	Playback
Signal	Alignment tape
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SW P pin for RF PC board check.
Adjustment locations	X-value adjuster screw

[Adjustment Method]

• Adjustment by Hi-Fi alignment tape (NTSC only)

When the tracking is set at the center position (by pressing the ∇ and \triangle keys simultaneously), adjust the RF output to maximum.




Fig. 4-7

• **Adjustment by alignment tape**

Adjust the X-value adjuster screw so that maximum RF output is obtained and also that the RF output drops to the same position on pressing the respective ▽ and ▴ buttons while the tracking is set at the center position.




Fig. 4-8


4-1-7. ADJUSTMENTS AFTER REPLACING THE DRUM (VIDEO HEAD)

Purpose: Co-relative height, X-value and other factors of the drum will deviate from those of the guide roller. If the drum is replaced properly, these deviations are extremely small.

Precaution: Turn off the auto tracking and set the manual tracking mode.


Mode	Playback
Signal	Alignment tape, blank tape
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SW P pin for RF PC board check.
Adjustment locations	Guide roller (refer to 4-1-2, 4-1-3.) Switching position, Tracking preset, SP delay mono-multi (Refer to the Service Manual), X-value. (refer to 4-1-6.)

[Adjustment Method]




[Checking the evenness and fluctuation of the RF output]


- 1) Set the RF output to the maximum level using the tracking buttons.



- 2) Perform fine adjustment of the voltage level range of the oscilloscope, then adjust the RF output deviation to within 4 gradations.



- 3) Press the tracking buttons and adjust the maximum amplitude of the RF output to within 3 gradations.
- 4) At this time, check if the minimum amplitude is more than 2 gradations.



- 5) Check that the RF output fluctuation between minimum and maximum levels is within 13%.

4-1-8. CHECKING THE TENSION AND TORQUE

Purpose: To check that the tension, torque and compression force of the tape take-up section and mobile sections to ensure smooth tape run and achieve standard VTR performance.

If the tape transport is not smooth or problems occur in relation to the tape transport speed, perform the following check.

Mode	Each operation mode without loading a cassette tape. (Refer to section 1-3.)
Measuring instrument	Torque gauge, Torque gauge adaptor

Item	VTR operation mode	Reel to be measured	Measurement value
Main brake torque	Stop	Supply and take-up reels	170 g·cm or more
Review torque	Review	Supply reel	180 ± 30 g·cm (using the torque cassette)
Take-up torque	Playback	Take-up reel	95 ± 25 g·cm (using the torque cassette)
Back tension torque	Playback	Take-up reel	33 to 44 g·cm (using the torque cassette)

[Check Method]

Measure the torque using the torque gauge and torque gauge adaptor with the torque gauge fixed.




Fig. 4-9

V03056

VHS MECHANICAL ADJUSTMENT MANUAL IV

SONY SERVICE MANUAL

H MECHANISM

SUPPLEMENT-1

1. How to Use the Mode Selector II for Adjusting H Type Mechanism Assembly.
2. Adjusting Mechanism Using New Alignment Tape (KRV-52NE For NTSC).

File this supplement with the VHS mechanical adjustment IV.

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>
1.	HOW TO USE THE MODE SELECTOR II FOR ADJUSTING H TYPE MECHANISM ASSEMBLY	2
1-1.	Outline	2
1-2.	Preparation	2
1-3.	Connection	2
1-4.	Operation	2
1-5.	Precautions	2
2.	ADJUSTING THE MECHANISM USING NEW ALIGNMENT TAPE (KRV-52NE for NTSC)	4
2-1.	Adjustment Using Alignment Tape (KRV-52NE for NTSC having no version No.)	4
2-1-1.	X-Value Adjustment (Using the tape having no version No.)	4
2-2.	Adjustment Using Alignment Tape (KRV-52NE for NTSC having the version No.)	6
2-2-1.	X-Value Adjustment (Using the tape having the version No.)	6
2-3.	Adjusting the Mechanism Using Alignment Tape (KRV-52NE for NTSC)	10
2-3-1.	Height Adjustment of Guide Rollers No. 3 and No. 6	10
2-3-2.	ACE Head Assembly Adjustment (Rough Adjustment)	11
2-3-3.	ACE Head Assembly Adjustment (Precision Adjustment)	11
2-3-4.	Adjustments After Replacing the Drum (Video Head)	12



1. HOW TO USE THE MODE SELECTOR II FOR ADJUSTING H TYPE MECHANISM ASSEMBLY

1-1. OUTLINE

To activate the VHS system H type mechanism assembly using mode selector II (J-6082-282-A), use connector conversion jig (J-6090-052-A). By using the connector conversion jig, the following operations are possible.

- Loading and unloading action by the loading motor
- Reading of the current setting of the mode switch
- Normal and reverse rotation of the capstan motor

1-2. PREPARATION


1-2-1. ADDITION OF POWER SUPPLY CABLE

(Already added Mode Selector II also available)

In order to drive the capstan motor, the power +5 V and +12 V are supplied from the Mode Selector II. Disassemble the D-SUB connector of the Mode Selector cable, then solder the following three places.

Supplied 3-pin cable	DSUB connector of the mode selector II	Voltage
Pin 1 (Red index)	Pin 20	+12 V
Pin 2	Pin 25	GND
Pin 3	Pin 24	+5 V

- Connector pin number assignment of the DSUB connector (From the soldering side)



- When connections are made, check that +5 V and +12 V are available at the 3-pin cable connector.

1-2-2. CHECKING THE SOFTWARE VERSION

Turn on the power of the mode selector II.

If the reading for the software version on the mode selector II is not 1.10 or higher, replace the New ROM (J-6082-314-A).

1-3. CONNECTION

1-3-1. CONNECTION BETWEEN THE CONNECTOR CONVERSION JIG AND THE MODE SELECTOR II (See Fig. 1-1)

Insert the connectors of the two 6-pin cables (one is white and the other is black) and the 3-pin cable from the mode selector II to the corresponding connectors on the connector conversion jig (J-6090-052-A).

1-3-2. CONNECTION BETWEEN THE CONNECTOR CONVERSION JIG AND THE H TYPE MECHANISM ASSEMBLY

With the power of the mode selector II turned off, insert the following three connectors to the corresponding connectors on the H type mechanism assembly.

- 3-pin connector for the loading motor
- 5-pin connector for the mode switch
- 8-pin connector for the capstan motor

Set the speed control for the minimum setting (fully counterclockwise).

1-4. OPERATION

1-4-1. OPERATION OF THE LOADING MOTOR ON THE H TYPE MECHANISM ASSEMBLY

- (1) Select the H type mechanism assembly setting on the mode selector II.
- (2) After this, procedures are the same as those for the previous model types.

For the operating method, see pages 3 to 5 of "8 mm Video Mechanism Manual VI (TK Mechanism) Supplement-1".

For the loading method, see page 3 of "VHS Mechanical Adjustment Manual IV (H Mechanism)".

1-4-2. OPERATION OF THE CAPSTAN MOTOR ON THE H TYPE MECHANISM ASSEMBLY

- (1) For the loading motor operation under Section 1-4-1, change the mode setting to the FF/REW mode with the mode switch.
- (2) Turn the speed control gradually in clockwise direction, and the capstan motor starts rotating. To turn the capstan motor in desired rotating direction, change the FWD/RVS setting of the rotating direction switch.

1-5. PRECAUTIONS

- Turn the speed control only when necessary. Otherwise, hold the speed control turned at fully counterclockwise direction. If the power of the mode selector II is turned on with the speed control turned in clockwise direction, +12V power fails and the power of the mode selector II cannot be turned on.
- Although the connector conversion jig (J-6090-052-A) has rubber feet, do not make a short circuit on the bottom surface of the connector conversion jig via foreign conductive materials.




Fig. 1-1


2. ADJUSTING THE MECHANISM USING NEW ALIGNMENT TAPE (KRV-52NE for NTSC)

The conventional alignment tape (For NTSC) is now replaced with alignment tape KRV-52NE, and the following describes how to align the mechanism using the KRV-52NE. For details on the use of KRV-51N2 for each model, refer to the service manuals which will be issued in the future.

Name	Parts No.	Remarks
Alignment tape KRV-52NE for NTSC	8-192-605-41	For tape path, audio azimuth, and X-value adjustments
Alignment tape KRV-51N2 for NTSC	8-192-605-32	For electrical adjustments (RF, AF, and switching position) and operation check

Note: The KRV-52NE has or does not have Ver No. depending on new or old type as shown below. (New one has Ver No.)

Note that an adjusting method of X-value is different.



Contents:

KRV-52NE (NTSC)

Time	Video	Audio
20 min.	Recording only at 1 MHz, A-ch. EP mode RF skipping once per 5 frames	5 kHz full tracks

KRV-51N2 (NTSC)

Class	Mode	Time	Video	Audio (HiFi/Normal)
1	SP	7 min.	Color bar	400 Hz
2	SP	3 min.	Mono. scope	400 Hz
3	EP	7 min.	Color bar	400 Hz
4	EP	3 min.	Mono. scope	400 Hz

2-1. ADJUSTMENT USING ALIGNMENT TAPE (KRV-52NE for NTSC having no version No.)



2-1-1. X-VALUE ADJUSTMENT (Using the tape having no version No.)

Purpose: To obtain compatibility with other VCRs.

Precaution: Before starting to adjust X-value, set the tracking control at the center position. To set the tracking

control at the center position for the VCRs equipped with the ▲ and ▼ tracking control keys, press both the ▲ and ▼ tracking control keys at the same time. For the VCRs not equipped with the tracking control keys, deactivate the automatic tracking control by pressing the tracking **AUTO/MANUAL** key on the remote control unit during threading operation (after a tape is inserted but before the VCR starts playing back the tape).

Mode	Playback
Signal	Alignment tape KRV-52NE (For NTSC having no version No.)
Measuring instrument	Oscilloscope TIM/DIV: 2ms Trigger source: CH2 Trigger slope: +
Measuring point	CH-1: Connector PB RF pin for RF PC board check CH-2: Connector RF SWP pin for RF PC board check
Adjustment locations	X-value adjuster screw




RF output shall be maximum at the center position of the tracking control.

[Adjustment Method]

Set the tracking control at the center position. For the VCRs equipped with narrow gap video heads, set the X-value adjustment screw where a maximum RF output is obtained. For the VCRs equipped with wide gap video heads, set the X-value adjustment screw both where a maximum RF output is obtained and where the RF output decreases immediately when the ▼ tracking control key is pressed.

X-VALUE ADJUSTMENT (Using the tape having no version No.)



When adjustment is complete, adjust the height of No. 3 and No. 6 guide rollers on page 10.


2-2. ADJUSTMENT USING ALIGNMENT TAPE (KRV-52NE for NTSC having the version No.)

2-2-1. X-VALUE ADJUSTMENT (Using the tape having the version No.)

Purpose: To obtain compatibility with other VCRs.

Precaution: Before starting to adjust X-value, set the tracking control at the center position. To set the tracking control at the center position for the VCRs equipped with the ▲ and ▼ tracking control keys, press both the ▲ and ▼ tracking control keys at the same time. For the VCRs not equipped with the tracking control keys, deactivate the automatic tracking control by pressing the tracking **AUTO/MANUAL** key on the remote control unit during threading operation (after a tape is inserted but before the VCR starts playing back the tape).

Mode	Playback
Signal	Alignment tape KRV-52NE (For NTSC having the version No.)
Measuring instrument	Oscilloscope TIM/DIV: 2ms Trigger source: CH2 Trigger slope: +
Measuring point	CH-1: Connector PB RF pin for RF PC board check CH-2: Connector RF SWP pin for RF PC board check
Adjustment locations	X-value adjuster screw




RF output shall be maximum at the center position of the tracking control.


[Adjustment Method]

Set the tracking control at the center position. For the VCRs equipped with narrow gap video heads, set the X-value adjustment screw where a maximum RF output is obtained. For the VCRs equipped with wide gap video heads, set the X-value adjustment screw both where a maximum RF output is obtained and where the RF output decreases immediately when the tracking control key is pressed.

1. Adjusting X-value (Using the tape having the version No.)




2. Checking false tracking (Using the tape having the version No.)



Using the tape having the version No.

No signal section of the audio signal
(continuously)

RF signal sampling every 5 frames







2-3. ADJUSTING THE MECHANISM USING ALIGNMENT TAPE (KRV-52NE for NTSC)

2-3-1. HEIGHT ADJUSTMENT OF GUIDE ROLLERS NO. 3 AND NO. 6


Mode	Playback
Signal	Alignment tape KRV-52NE (For NTSC)
Measuring instrument	Oscilloscope TIM/DIV: 2ms Trigger source: CH2 Trigger slope: +
Measuring point	CH-1: Connector PB RF pin for RF PC board check CH-2: Connector RF SWP pin for RF PC board check
Adjustment locations	Height adjustment screw for No.3 tape guide roller Height adjustment screw for No.6 tape guide roller



[Adjustment Method]

The following adjustment shall be carried out after completed Section 2-1-1 "X-value adjustment and check".


- 1) Deactivate the automatic tracking control, and set the tracking control at the center position. To set the tracking control at the center position for the VCRs equipped with the  and  tracking control keys, press both the  and  tracking control keys at the same time. For the VCRs not equipped with the tracking control keys, deactivate the automatic tracking control by pressing the tracking **AUTO/MANUAL** key on the remote control unit during threading operation (after a tape is inserted but before the VCR starts playing back the tape).



- 2) Check if the RF output changes in amplitude by pressing the tracking control key. The RF output should change periodically (changes from a minimum amplitude to a maximum amplitude, and to the minimum amplitude again).




- 3) Turn the height adjustment screws of tape guide rollers No.3 and No.6 so that the RF output envelope becomes as flat as possible.
- 4) Press the  tracking control key, and check that both the beginning and end of the RF output change together the same in amplitude.
- 5) Press the  tracking control key, and check that both the beginning and end of the RF output change together the same in amplitude.

Turn the height adjustment screws of tape guide rollers No.3 and No.6 little by little so that the RF output envelope becomes as flat as possible.




Press the  tracking control key, then the  tracking control key, and check that both the beginning and end of the RF output change together the same in amplitude.


When the  tracking control key is pressed.



At the tracking center position.



When the  tracking control key is pressed.



**2-3-2. ACE HEAD ASSEMBLY ADJUSTMENT
(ROUGH ADJUSTMENT) (Figs. 2-1 and 2-2)**

Purpose: Allows the tape to make even contact with the head for recording and playback of the specified track.

Mode	Playback
Jig	Blank tape
Adjustment locations	Height adjuster nut, Tilt adjuster screw

[Adjustment Method]

- 1) Mount the ACE head assembly. At this time, adjust the height so that the height of guide flange No. 7 matches the level of the lower edge of the control head.
- 2) Remove the adjustment tool and load a new tape, then set the unit for playback.
- 3) Check that the tape does not curl or rise up noticeably near the ACE head.
- 4) If the tape curls up or rises noticeably, readjust the tilt adjuster screw and the height adjuster nut.
(The height of the ACE head should be adjusted so that the lower edge of the tape is approx. 0.1 to 0.15 mm from the control head.)
- 5) Perform precision adjustment.




Fig. 2-1




Fig. 2-2

**2-3-3. ACE HEAD ASSEMBLY ADJUSTMENT
(PRECISION ADJUSTMENT)**

Mode	Playback
Signal	Alignment tape (KRV-52NE 5 kHz) (For NTSC)
Measuring instrument	Oscilloscope
Measuring point	Audio output terminal
Adjustment locations	Azimuth adjuster screw, Height adjuster nut, Tilt adjuster screw

[Adjustment Method]

- 1) Adjust the tilt adjuster screw in the FWD or REV mode so that the lower flange of guide No. 7 does not curl up or rise.
- 2) Alternately adjust the azimuth adjuster screw, the height adjuster nut, and the tilt adjuster screw to maintain even audio output at maximum with minimum deviation.




Fig. 2-3

2-3-4. ADJUSTMENTS AFTER REPLACING THE DRUM (VIDEO HEAD)


Purpose: Co-relative height, X-value and other factors of the drum will deviate from those of the guide roller. If the drum is replaced properly, these deviations are extremely small.

Note 1: Deactivate the automatic tracking control for setting the mechanism in manual tracking control mode.

Note 2: To set the tracking control at the center position, deactivate the automatic tracking control by pressing the tracking **AUTO/MANUAL** key on the remote control unit during threading operation (after a tape is inserted but before the VCR starts playing back the tape).


Mode	Playback
Signal	Alignment tape KRV-52NE (For NTSC), blank tape
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SWP pin for RF PC board check.
Adjustment locations	Guide roller (Refer to 2-3-1.) Switching position (Refer to the Service Manual) X-value (Refer to 2-1-1, 2-1-2.)

[Adjustment Method]




[Checking the evenness and fluctuation of the RF output]


- 1) Set the RF output to the maximum level using the tracking buttons.



- 2) Perform fine adjustment of the voltage level range of the oscilloscope, then adjust the RF output deviation to within 4 gradations.



- 3) Press the tracking buttons and adjust the maximum amplitude of the RF output to within 3 gradations.
- 4) At this time, check if the minimum amplitude is more than 2 gradations.



- 5) Check that the RF output fluctuation between minimum and maximum levels is within 13%.

VHS MECHANICAL ADJUSTMENT MANUAL IV

9-973-623-82

Sony Corporation
Consumer A&V Products Company
Home A&V Products Div.

English
95D05112-1
Printed in Japan
© 1995. 4
Published by Personal A&V Products Div.
Quality Engineering Dept.

VHS MECHANICAL ADJUSTMENT MANUAL IV

SONY
SERVICE MANUAL

H MECHANISM

SUPPLEMENT-2

File this supplement with the VHS mechanical adjustment IV and supplement-1.

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>
1.	CORRECTION	1
1-1.	Adjustment Sequence	1
2.	MODIFICATION	2
2-1.	Changing the Recorded Contents of Alignment Tape ...	2
2-2.	TG2 Roller, FE Head Assembly	2
2-3.	TG3, TG6 Guide Roller Assembly	3
2-4.	TG8 Assembly	4
2-5.	Tension Regulator (TG1) Position Tension Adjustment	5
2-6.	TG8 Guide Roller Height Adjustment	6

1. CORRECTION

In the VHS Mechanism Adjustment Manual IV (Supplement-1), an adjustment sequence was wrong, and it is corrected as follow;

1-1. Adjustment Sequence (VHS Mechanism Adjustment Manual IV (Supplement-1) Page 6 to 11)

(1) Adjustment of No. 3 and No. 6 guide roller height

Delete the "The following adjustment shall be carried out after completed Section 2-1-1 "X-value adjustment and check" under "Adjustment Method" on page 10.

(2) Adjustment of ACE head assembly

Note: In the adjustment of ACE head assembly (coarse adjustment and fine adjustment), if a azimuth, height and tilt were adjusted, again adjust the height of No. 3 and No. 6 guide rollers.

(3) Adjustment of X value



2. MODIFICATION

2-1. CHANGING THE RECORDED CONTENTS OF ALIGNMENT TAPE

KRV-S2NE (NTSC) (Ver. 1.2)

Time	Video	Audio
20 min.	Recording only at 1 MHz, A-ch. EP mode RF skipping once per 5 frames	5 kHz → 4 kHz full tracks

2-2. TG2 ROLLER, FE HEAD ASSEMBLY (Refer to VHS Mechanical Adjustment Manual IV page14)

- The TG2 roller is provided with either of two types, fixed or straight. For the fixed type, section 3-5 is added.

3-5. TG2 ROLLER, FE HEAD ASSEMBLY (Fig. 3-5)

- 1) Remove screw ① to pull out FE head assembly ②.

[Note on Mounting]

- Keep clean the surface contacts tape of TG2 roller.




Fig. 3-5

2-3. TG3, TG6 GUIDE ROLLER ASSEMBLIES
(Refer to VHS Mechanical Adjustment Manual IV page 17)

- There is another type in TG3 and TG6 guide roller assemblies, which is not attached with a screw (B2X3). For the screwless type, section 3-8 is added.

3-8. TG3, TG6 GUIDE ROLLER ASSEMBLIES
(Fig. 3-8)

- 1) TG3 guide roller assembly ① by turning it in arrow A direction.
- 2) Removal the spring ②.
- 3) TG6 guide roller assembly ③ by turning it in arrow B direction.
- 4) Removal the spring ④.

[Note on Mounting]

- Keep clean the surface contacts tape of TG3 and TG6 guide roller assemblies ①, ③.

[Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-8

2-4. TG8 ASSEMBLY
(Refer to VHS Mechanical Adjustment
Manual IV page 23)

- As the shape of TG8 assembly was changed, Section 3-13 is changed.

 : Changed portion

3-13. TG8 ASSEMBLY (Fig. 3-15)

- 1) Remove TG7 tape retainer ① to pull out TG8 assembly ②.

[Note on Mounting]

- Apply FLOIL SG-055G (Jig Ref. No. J-12) to ☆ marked portion.
- Keep clean the surface contacts tape of TG8 assembly ②.
- Be careful not to change the shape of TG7 tape retainer ①.
- After attaching the TG7 tape retainer ①, check that side ① of ① is below side ② of the stepped-part of the TG7 shaft. (Fig. A)

[Adjustment after Mounting]

- 4-1. Tape path adjustment.





Fig. 3-15

**2-5. TENSION REGULATOR (TG1) POSITION/
TENSION ADJUSTMENT**
(Refer to VHS Mechanical Adjustment
Manual IV page 35)

- As the tension regulator position and tension adjustment were changed, the tension adjustment and Fig. 4-1 are changed.

 : Changed portion

• Tension adjustment

Mode	Playback
Measuring instrument/tool	Torque cassette
Adjustment locations	Position for hooking the tension spring
Specified value	$34 \pm 4 \text{ g}\cdot\text{cm}$




Fig. 4-1

VHS MECHANICAL ADJUSTMENT MANUAL IV

2-6. TG8 GUIDE ROLLER HEIGHT ADJUSTMENT (Refer to VHS Mechanical Adjustment Manual IV page 36)

• As the use of TG8 height adjusting screw was cancelled, section 4-1-2 is changed.

4-1-2. TG7 TAPE PATH ADJUSTMENT (Fig. 4-2)

[Adjustment Method]

1) Load a tape, and playback the tape in the CUE mode, confirm the distance between lower flange of No. 7 guide roller and lower side of tape (Fig. A).

2) Then, feeding the tape in the REV mode, confirm the distance between lower flange of No. 7 guide roller and lower side of tape.

3) If the tape height in the REV feed is higher than that in the CUE playback (Fig. B), rotate the ACE head flapping adjust screw in the direction Ⓐ so that a difference in tape height between CUE mode and REV mode becomes zero.

4) If the tape height in the REV feed is lower than that in the CUE playback (Fig. C), rotate the ACE head flapping adjust screw in the direction Ⓑ so that a difference in tape height between CUE mode and REV mode becomes zero.




Fig. 4-2

Sony Corporation
Consumer A&V Products Company
Home A&V Products Div.

English
95H05103-1
Printed in Japan
© 1995. 8

Published by Personal A&V Products Div.
Quality Engineering Dept.