

**SLV-640HF/733HF/733HFCS/733HFMX/733HFPA/740HF/740HFPX  
/741HF/780HF/781HF/940HF/940HFCS/940HFMX/940HFPX  
RMT-V154C/V158/V161/V162/V164B**

**SERVICE MANUAL**

SLV-640HF/740HF/740HFPX/741HF/780HF/781HF/940HF/940HFPX



Photo: SLV-940HF/RMT-V158

Remote commander is available as a unit. See page 5-1 for repair parts.

• Refer to the SERVICE MANUAL of VHS MECHANICAL ADJUSTMENT IV (H MECHA) for MECHANICAL ADJUSTMENTS. (9-973-623-11)

*US Model*

*Canadian Model*

SLV-640HF/740HF/741HF/780HF/940HF

*Mexican Model*

SLV-733HFMX/940HFMX

*Panama Model*

SLV-733HFPA

*Chilean Model*

SLV-733HFCS/940HFCS

*Tourist Model*

SLV-733HF



**H MECHANISM**

**SPECIFICATIONS**

**System**

**Format**

VHS NTSC standard

**Video recording system**

Rotary two-head helical scanning FM system

**Video signal**

NTSC color, EIA standards

**Tape speed**

SP: 33.35 mm/s (1.318 inches/s)  
EP: 11.11 mm/s (0.716 inches/s)  
LP: 16.67 mm/s (1.116 inches/s),  
playback only

**Maximum recording/playback time**

8 hrs. in EP mode (with T-160 tape)

**Fast-forward and rewind time**

Approx. 3 min. (with T-130 tape)

**Tuner section**

**Channel coverage**

VHF 2 to 13  
UHF 34 to 69  
CATV A-6 to A-1, A to W, W-1 to  
W+84

**Antenna**

75-ohm antenna terminal for  
VHF/UHF

**Inputs and outputs**

**LINE IN 1 and 2**

VIDEO IN, phono jack (1 each)  
Input signal: 1 V<sub>pp</sub>, 75 ohms,  
unbalanced, sync negative  
AUDIO IN, phono jack (2 each)  
Input level: -7.5 dBs (0 dBs =  
0.775 Vrms)  
Input impedance: more than  
47 kilohms

**LINE OUT**

VIDEO OUT, phono jack (1)  
Output signal: 1 V<sub>pp</sub>, 75 ohms,  
unbalanced, sync negative  
AUDIO OUT, phono jack (2)  
Standard output: -2.5 dBs  
Load impedance: 47 kilohms  
Output impedance: less than  
10 kilohms

**CONTROL 5 IN**

Mini jack (1)

**CABLE BOX CONTROL  
(CONTROL 5 OUT)**

Mini jack (plug in power) (1)

**Timer section**

**Clock**

Quartz locked

**Timer indication**

12-hour cycle

**Timer setting**

Only for recording 8 programs in  
one month at max.

**Power back-up**

Pull-in self-charging capacitor  
Back-up duration:  
up to three hours at time time (for  
SLV-940HF/940HFPX)  
up to one hour at one time (for  
SLV-940HF CS/940HF ATX)

**General**

**Power requirements**

110 V AC, 60 Hz  
(for SLV-640HF/940HF MX)  
110 V AC to 240 V AC, 50/60 Hz  
(for SLV-940HF CS/940HF PX)

**Power consumption**

27 W (max.) (for SLV-940HF)  
24 W (max.) (for SLV-940HF CS/  
940HF MX/940HF PX)

**Operating temperature**

5°C to 40°C (41°F to 104°F)

— continued on next page —



**VIDEO CASSETTE RECORDER**  
**SONY**

#### Storage temperature

-20°C to 60°C (-4°F to 140°F)

#### Dimensions

Approx. 430 x 103 x 323 mm  
(w/h/d)  
Approx. (17 x 4 x 12 1/4 inches)  
Including projecting parts and  
controls

#### Weight

Approx. 5.2 kg (11 lb 7 oz)

#### Supplied accessories

Remote commander (1)  
Size AA (R6) batteries (2)  
75-ohm coaxial cable with F-type  
connectors (1)  
AC power cord (1)  
Audio/video cable (3 phono to 3 phono)  
(1)  
Cable Mouse (cable box controller) (1)  
Plug adaptor (1)  
(SLV-940HF/CS990HF/PX only)

The remote commander used for each model is as follows.

- RMT-V154C: SLV-640HF
- RMT-V162: SLV-740UF/740HFPX/741BF
- RMT-V164B: SLV-733HF/733HFPX/733HFMX/733HFPX
- RMT-V161: SLV-780HF/78111F
- RMT-V155: SLV-940HF/940HFPX/940HFMX/940HFPX

Design and specifications are subject to change without notice.

### SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
5. Check the line cord for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
6. Check the B+ voltage to see it is at the value specified.
7. Check the antenna terminals, metal trim, "metalized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

#### LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)




Fig. A. Using an AC voltmeter to check AC leakage.

#### SAFETY-RELATED COMPONENT WARNING!

COMPONENTS IDENTIFIED BY MARK  $\Delta$  OR DOTTED LINE WITH MARK  $\Delta$  ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

#### ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE  $\Delta$  SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

## TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
<b>SERVICE NOTE</b>					
1	Removal of Drum Assembly	5			
2	Upper Drum Replacement	5			
2-1	Removal of Upper Drum	5			
2-2	Mounting Upper Drum	5			
3	Periodic Check and Replacement	6			
3-1	Cleaning of Rotating Head Disk Assembly	6			
3-2	Cleaning of the Tape Movement System	6			
3-3	Cleaning the Drive System	6			
<b>1. GENERAL</b>					
•	Welcome/	1-1			
•	Step 1: Unpacking	1-1			
•	Step 2: Setting up the remote commander	1-2			
•	Step 3: Hookups	1-3			
•	Selecting a language (Canadian Model only)	1-9			
•	Setting the clock	1-10			
•	Presetting channels	1-11			
•	Setting up cable box control	1-13			
•	Setting up VCR Plus+	1-14			
•	Using the ADVANCED OPTIONS	1-15			
•	Playing a tape	1-16			
•	Recording TV programs	1-18			
•	Recording TV programs using the timer	1-20			
•	Recording TV programs using VCR Plus+	1-21			
•	Checking/charging/cancelling timer settings	1-22			
•	Playing/searching at various speeds	1-23			
•	Adjusting the picture	1-24			
•	Searching using the Index function	1-24			
•	Editing with another VCR	1-25			
•	Insert editing	1-26			
•	Synchronized editing	1-27			
•	General setup information	1-28			
•	Index to parts and controls	1-28			
<b>2. DISASSEMBLY</b>					
2-1	Removal of Upper Case	2-1			
2-2	Removal of Front Panel Assembly	2-1			
2-3	Removal of Control Switch Block	2-2			
2-4	Removal of MF-253/274 Board	2-2			
2-5	Removal of HI-5/19 Board	2-3			
2-6	Removal of Bottom Plate	2-3			
2-7	Removal of PS-327/349 Board	2-4			
2-8	Removal of ED-40/43 Board and HF-34 Board	2-4			
2-9	Removal of RV-36/45 Board	2-5			
2-10	Removal of MA-214 Board	2-5			
2-11	Removal of MD Block Assembly	2-6			
2-12	Mechanical Internal Views	2-7			
2-13	Circuit Boards Location	2-8			
<b>3. BLOCK DIAGRAMS</b>					
3-1	Overall Block Diagram	3-1			
3-2	Video Block Diagram	3-5			
3-3	Servo/System Control Block Diagram	3-9			
3-4	Tuner/Toner/Mode Control Block Diagram	3-11			
3-5	Audio Block Diagram	3-14			
3-6	Tuner Block Diagram	3-17			
3-7	Power Block Diagram	3-19			
<b>4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS</b>					
4-1	Frame Schematic Diagram	4-1			
4-2	Printed wiring Boards and Schematic Diagrams	4-3			
•	This Note is Common for Printed Wiring Boards and Schematic Diagrams	4-3			
•	RV-36/45 Board	4-4			
•	MA-214 (SERVO/SYSCON) and IC-37/65 Board	4-13			
•	MA-214 (INPUT/OUTPUT, TUNER)	4-17			
•	ED-40/43 Board	4-21			
•	HF-34 Board	4-25			
•	HI-5/19 and MF-253/274 Board	4-30			
•	PS-327/349 Board	4-37			
<b>5. REPAIR PARTS LIST</b>					
5-1	EXPLODED VIEWS	5-1			
5-1-1	Case Assembly	5-1			
5-1-2	Front Panel Assembly	5-2			
5-1-3	Chassis Assembly	5-4			
5-1-4	Mechanical Deck Assembly (1)	5-6			
5-1-5	Mechanical Deck Assembly (2)	5-7			
5-1-6	Mechanical Deck Assembly (3)	5-8			
5-1-7	Mechanical Deck Assembly (4)	5-9			
5-2	ELECTRICAL PARTS LIST	5-10			
•	DC-57/65 Board	5-10			
•	ED-40/43 Board	5-10			
•	HF-34 Board	5-11			
•	HI-5/19 Board	5-12			
•	MA-214 Board	5-14			
•	MF-253/274 Board	5-21			
•	PS-327/349 Board	5-21			
•	RV-36/45 Board	5-23			
•	Hardware List	5-27			
<b>6. INTERFACE AND IC PIN FUNCTION</b>					
6-1	System Control—Video Block Interface (MA-214 Board IC201)	6-1			
6-2	System Control—Servo Peripheral Circuit Interface (MA-214 Board IC201)	6-2			
6-3	System Control—Mechanism Block Interface (MA-214 Board IC201)	6-3			
6-4	System Control—System Control Peripheral Circuit Interface (MA-214 Board IC201)	6-4			
6-5	System Control—Audio Block Interface (MA-214 Board IC201)	6-4			
6-6	System Control—RF Modulator, Input Section Block Interface (MA-214 Board IC201)	6-4			
6-7	Servo/System Control Microprocessor CXP87240 057Q (MA-214 Board IC201) Port Function Description	6-5			
6-8	Timer/Tuner Control Microprocessor MR89096PP-G-159-BND (HI-5/19 Board IC302) Port Function Description	6-7			

<u>Section</u>	<u>Title</u>	<u>Page</u>
<b>7.</b>	<b>ADJUSTMENTS</b>	
7-1.	MECHANICAL ADJUSTMENTS . . . . .	7-1
7-2.	ELECTRICAL ADJUSTMENTS . . . . .	7-1
2-1.	Preparation Before Adjustment . . . . .	7-1
2-1-1.	Equipment Required . . . . .	7-1
2-1-2.	Equipment Connection . . . . .	7-2
2-1-3.	Check of Input Signal . . . . .	7-2
2-1-4.	Alignment Tape . . . . .	7-2
2-1-5.	Specified Input - Output Level and the Impedance . . . . .	7-2
2-1-6.	Adjustment Procedures . . . . .	7-2
2-2.	Power Supply Check . . . . .	7-3
2-2-1.	Output Voltage Check . . . . .	7-3
2-3.	Servo System Adjustment . . . . .	7-3
2-4.	System Control/Timer System Adjustment . . . . .	7-4
2-4-1.	Clock Adjustment . . . . .	7-4
2-5.	Video System Adjustment . . . . .	7-4
2-5-1.	X'tal OSC Check . . . . .	7-4
2-5-2.	SYNC AGC Check . . . . .	7-5
2-5-3.	White Clip/Dark Clip Check . . . . .	7-5
2-5-4.	Y FM Carrier Frequency Check . . . . .	7-5
2-5-5.	Playback Y Level Check . . . . .	7-6
2-6.	Audio System Adjustment . . . . .	7-6
2-6-1.	VCO $f_0$ Adjustment . . . . .	7-7
2-6-2.	Deviation Check . . . . .	7-7
2-6-3.	Band Pass Filter $f_0$ Adjustment . . . . .	7-8
2-6-4.	AF Switching Position Adjustment . . . . .	7-8
2-6-5.	ACE Head Adjustment . . . . .	7-9
2-6-6.	Recording Bias Adjustment . . . . .	7-9
2-6-7.	E-E Output Level Check . . . . .	7-9
2-6-8.	Overall Output Level and Distortion Factor Check . . . . .	7-9
2-6-9.	Overall Noise Level Check . . . . .	7-9
2-7.	Adjustment Parts Location Diagram . . . . .	7-10

## SERVICE NOTE

## 1. REMOVAL OF DRUM ASSEMBLY

- 1) Remove the screw ① (P3×8)
- 2) Remove the shaft ground assembly ②.
- 3) Remove three screws ③ (P3×6).
- 4) Remove the drum assembly ④.

**Note:** When attaching the drum assembly, be careful not to blur the contacting surface with fingerprint or like.

When attaching the shaft ground assembly, be careful not to apply force to the spring section of it.




Fig. 1.

## 2. UPPER DRUM REPLACEMENT

## 2-1. Removal of Upper Drum

- 1) Remove the screw ① (P3×8).
- 2) Remove the shaft ground assembly ②.
- 3) Completely remove the rotary upper drum board and desolder the soldering indicated by the arrows. (16 points)
- 4) Remove the screws ③ (PSW 3×8) and tap out the rotary upper drum assembly in the direction of arrow. (See Fig. 3.)

If it is difficult, remove by shaking the rotary upper drum gradually.

**Note:** If the drum can not be removed, check whether the solders have been removed or not again.

## 2-2. Mounting Upper Drum

- 1) Mount the rotary upper drum assembly by aligning marked  $\blacktriangle$  with marked  $\blacktriangle$  of rotary transformer board (lower drum) so that the screw holes of both upper and lower drums match.




Fig. 2.

**Note:** When inserting the rotary upper drum assembly into the lower drum, be careful not to blur the contacting surface with fingerprint or like.

- 2) If it is difficult, mount the upper drum by shaking it gradually.

**Note:** Be careful not to damage the head.

Make sure that the upper drum is tightly inserted.

- 3) Tighten two screws ④ (PSW3×8).
- Note:** Temporary tighten two screws. After making sure that upper drum is tightly inserted, tighten the screws.




Fig. 3.

- 4) Solder 16 points on the rotary upper drum board (See FIG. 2)
- 5) Fix the shaft ground assembly ② using the screw ① (P3 - 8) so that the protrusion of the shaft ground assembly end contacts the center of the drum shaft. (See Fig. 2.)  
**Note:** When attaching the shaft ground assembly, be careful not to apply force to the spring section of it.
- 6) Tighten the screw ③ (P3-8).

### 3. PERIODIC CHECK AND REPLACEMENT

In order to obtain the best performance from this unit and make full use of its capabilities, and to extend the life of the unit and tapes, it is recommended that the following periodic checks and maintenance be performed.

- The following must be done after every repair regardless of how many hours the user has operated the machine.

#### 3-1. CLEANING OF ROTATING HEAD DISK ASSEMBLY

- 1) Press a chamouis cloth (Jig Ref. No. J-9) which has been dipped in cleaning fluid (Jig Ref. No. J-5) lightly against the rotating drum assembly, then do the cleaning by slowly rotating the rotating head disk by hand. (Never try to clean by using the motor to turn it.)
- 2) Never try to clean by moving the chamouis cloth at a

vertical angle to the head tip. There is a very great danger of damaging the head tip if this is done.

#### 3-2. CLEANING OF THE TAPE MOVEMENT SYSTEM

- 1) Clean the surfaces which the tape contacts during its movement (tape guide, drum assembly surface, capstan, pinch roller, etc.) with a chamouis cloth that has been dipped in cleaning fluid.

#### 3-3. CLEANING THE DRIVE SYSTEM

- 1) Clean the driving parts with a cloth that been dipped in cleaning fluid.




Fig. 4. Parts requiring cleaning

SECTION 1  
GENERALThis section is extracted from  
SLV-940HF instruction manual.

## Welcome!

Thank you for purchasing the Sony Video Cassette Recorder (VCR).  
Here are some of the features you'll enjoy with your VCR.

- Easy Set-Up feature allows you to use the clock, cable box control and preset channels easily using the EASY SET UP button.
- Auto-Link™ Set feature that sets and adjusts the time and date automatically.
- Cable box control line allows your VCR to control digital satellite receivers and cable boxes.
- VCR Tracer™ system lets you quickly and easily locate the VCR in record progress.
- Adaptive Picture Control (APC) that automatically optimizes recording and playback performance.
- Remote controls that feature multi-directional TV control.
- Piping (loop) that will allow your VCR to be connected with a loop cable.

\* To obtain useful data, refer to the Customer Development Center. VCR  
has a system for requesting repair orders from Special Customer Operations.

Check that you have the following items:

- Remote controller



- Size A4 (RFD) batteries



- Antistatic cloth  
(3 options to 3-pk-100)



- Cable Modem (cable box  
controller)



- 75-ohm coaxial cable with  
F-type connectors



- AC power cord  
(SLV-3000V/3000HF MC)



SLV-3000V/3000HF MC



- Plug adapter  
(SLV-3000V/3000HF MC only)




## Step 2: Setting up the remote commander

### Notes


- With maximum life expectancy, the batteries should be replaced every 12 months.
- If you do not use the remote commander for a long time, the batteries should be replaced every 6 months.
- Do not use same battery
- Do not use alkaline battery

Inserting the batteries based on the AA (LR6) battery by pushing the 2 red-on-the-battery in the diagram inside the battery compartment.



### Using the remote commander

You can use the remote commander to operate the VCR and Set-Top TV. To operate the VCR, set the COMMAND MODE switch on the remote commander on the VCR. To operate the TV, set the switch on the front panel. The POWER, VCR, TV, CH 1-7, TV/VCR, and numeric KEYS, along with the CHANNEL NUMBER buttons on the remote commander, can be used to operate your TV.



### Notes

- To use a device, you must connect it to the remote commander.
- To use a device, you must connect it to the remote commander.
- To use a device, you must connect it to the remote commander.
- To use a device, you must connect it to the remote commander.
- To use a device, you must connect it to the remote commander.
- To use a device, you must connect it to the remote commander.

### Controlling other TVs with the remote commander

The remote commander is programmed to control other TVs. If your TV is listed in the table below, set the appropriate model/brand/serial number.

1. Set [TV/TV] on the top of the remote commander to [TV].
2. Set [TV/TV] on the top of the remote commander to [TV].
3. Set [TV/TV] on the top of the remote commander to [TV].
4. Set [TV/TV] on the top of the remote commander to [TV].
5. Set [TV/TV] on the top of the remote commander to [TV].
6. Set [TV/TV] on the top of the remote commander to [TV].
7. Set [TV/TV] on the top of the remote commander to [TV].
8. Set [TV/TV] on the top of the remote commander to [TV].
9. Set [TV/TV] on the top of the remote commander to [TV].
10. Set [TV/TV] on the top of the remote commander to [TV].
11. Set [TV/TV] on the top of the remote commander to [TV].
12. Set [TV/TV] on the top of the remote commander to [TV].
13. Set [TV/TV] on the top of the remote commander to [TV].
14. Set [TV/TV] on the top of the remote commander to [TV].
15. Set [TV/TV] on the top of the remote commander to [TV].
16. Set [TV/TV] on the top of the remote commander to [TV].
17. Set [TV/TV] on the top of the remote commander to [TV].
18. Set [TV/TV] on the top of the remote commander to [TV].
19. Set [TV/TV] on the top of the remote commander to [TV].
20. Set [TV/TV] on the top of the remote commander to [TV].

Manufacturer	Code number	Manufacturer	Code number
Sony	8	Hitachi	18
Ayat	5	Philips	8
AOC	4	Thomson	16
Corona	22	Vertical	3
Conquest	3	Quasar	6, 15
Cosmos	12	Telefunken	5, 11
Genpak	42	VCA	4, 18
Inter	11	Sanyo	22
General Electric	4, 16	Sanyo	18
Hitachi	2, 5	Sanyo	12
JVC	5, 12	Sanyo	21, 10, 11
JVC	8	Sanyo	2, 3, 10
Kenwood	3	Sanyo	6, 12
Magnum	2, 5, 12	Teleshare	3, 6, 10
Mitsubishi	6, 13	Teleshare	7
Hitachi	6, 12, 13, 17	Sharp	1, 2, 3, 4, 10
MRC	5, 12	Sharp	12
Daewoo	8, 15	Sharp	15



## Step 3: Hookups

**Caution**  
 Connecting the VCR to the TV system is a delicate task. If you are not sure of the correct wiring, do not attempt to connect the VCR to the TV system until you have consulted the following instructions. Failure to follow these instructions could result in damage to the VCR or the TV system.

**Connections**  
 Connections should be made to the VCR in the order listed below. The VCR should be connected to the TV system and VCR connections should be made in the order listed below.

**Note**  
 The VCR is a CATV system. The receiver is provided in the VCR. The receiver is not to be connected to the TV system. The receiver is provided in the VCR. The receiver is not to be connected to the TV system.

**Note**  
 The receiver is provided in the VCR. The receiver is not to be connected to the TV system. The receiver is provided in the VCR. The receiver is not to be connected to the TV system.

### Selecting the best hookup option

Before you use your VCR for the first time, you need to connect it to your TV, and set it up to receive programs by viewing and recording. This section explains how to hook up and set up your VCR so that you can start enjoying it right away. There are, however, many types of TVs on the market today. Each type of TV has its own special hookup instructions. Check the following pages to see if your VCR will fit.

To hook up your VCR to a TV, you need to know the type of TV you have. Then use the accompanying diagrams and procedures on the following pages to set up your VCR.

TV type	See	Refer to
TV that has audio/video inputs	Audio/video (AV) hookup, Page 9	Page 9
TV that has only video inputs	Video (V) hookup, Page 10	Page 10
TV that has only video inputs and a VCR with line control	Video (V) hookup with line control, Page 11	Page 11
TV that has only video inputs and a VCR with line control	Video (V) hookup with line control, Page 12	Page 12
TV that has only video inputs and a VCR with line control	Video (V) hookup with line control, Page 13	Page 13
TV that has only video inputs and a VCR with line control	Video (V) hookup with line control, Page 14	Page 14
TV that has only video inputs and a VCR with line control	Video (V) hookup with line control, Page 15	Page 15
TV that has only video inputs and a VCR with line control	Video (V) hookup with line control, Page 16	Page 16

After you've completed the connections, follow the instructions for each type of TV. Check the VCR manual for more information. The VCR manual contains detailed information about the VCR and its features. It also contains information about the VCR's operation and maintenance.

After you've completed the connections, refer to the VCR manual for more information. The VCR manual contains detailed information about the VCR and its features. It also contains information about the VCR's operation and maintenance.

Before you get started:

- Read the VCR manual for more information.
- Check the VCR manual for more information.
- Check the VCR manual for more information.
- Check the VCR manual for more information.
- Check the VCR manual for more information.
- Check the VCR manual for more information.
- Check the VCR manual for more information.
- Check the VCR manual for more information.
- Check the VCR manual for more information.
- Check the VCR manual for more information.


### Audio-video (AV) hookup

If your TV has audio-video (AV) inputs, you will just need to connect the VCR to the TV. The VCR will be connected to the TV's AV inputs. The VCR will be connected to the TV's AV inputs. The VCR will be connected to the TV's AV inputs.


If you're planning to use your VCR only to play back pictures and movies, you'll need to connect the VCR to the TV's AV inputs. The VCR will be connected to the TV's AV inputs. The VCR will be connected to the TV's AV inputs.

For more information, see the VCR manual for more information. The VCR manual contains detailed information about the VCR and its features. It also contains information about the VCR's operation and maintenance.

A. Use this hookup if your TV has stereo jacks.




B. Use this hookup if your TV doesn't have stereo jacks.



### AV Hookup VCR Setup

After you've connected your TV and completed set-up or cable hookup, use the following procedure to set up the VCR.



For more information, see the VCR manual for more information. The VCR manual contains detailed information about the VCR and its features. It also contains information about the VCR's operation and maintenance.

## Hookup 1


### Using cable box control

#### Recommended Use

This hookup is recommended for power cable systems with cable boxes. It allows the VCR's cable box control feature to control the channel on the TV. For more information on this feature, see page 27. Hookup 1 also allows a cable box to be used if your cable system is scrambled or if it has a control cable box. A list of compatible cable boxes is on page 27.


Make sure you can and can't do with this hookup:

- Record your own shows
- Record any channel using the VCR's cable box control feature to select channels on the cable box
- Record over channels while watching another channel
- Record with the cable box turned off
- Record over channels while watching another channel



#### Hookup 1: VCR setup

- 1 Set the SET UNIT to CH 2 or CH 4 in Memory Mode and use it to program the VCR. For more information on this feature, see page 27. Hookup 1 also allows a cable box to be used if your cable system is scrambled or if it has a control cable box. A list of compatible cable boxes is on page 27.



- 2 Turn on your cable box.

- 3 Press EASY SETUP on the VCR. The SET UP screen appears.


The diagram shows the VCR's SET UP screen with various options. The first screenshot shows the 'Channel name entry' screen where the user can select a language for the channel display. The second screenshot shows the 'CLOCK SET' screen where the user can select 'AUTO' for auto-tuning. The third screenshot shows the 'CABLE BOX' screen where the user can select 'CH 2' and 'CH 4' in Memory Mode. The fourth screenshot shows the 'Low rate channels' screen where the user can select 'number on the screen'. The fifth screenshot shows the 'Select your cable box name' screen where the user can select 'CH 2' and 'CH 4' in Memory Mode.

## Getting Started

If your setup box is not compatible, check with your cable company to see if there can provide a compatible setup box. For more information on this feature, see page 27. Hookup 1 also allows a cable box to be used if your cable system is scrambled or if it has a control cable box. A list of compatible cable boxes is on page 27.

#### Hookup 1: VCR Plus+ channel setup

- 1 Find the VCR Plus+ Channel Learning program guide. For details on the VCR Plus+ Channel Learning, see page 24.
- 2 If the channels do not register, find the channel list on the channels that do register. See page 27. Set the channels that are different as follows.



#### Automatic clock setting

Once you've set up the VCR, it automatically sets the clock the first time you connect the VCR. After that, whenever you set up the VCR, it checks if the clock is set. If it's not, it sets the clock for you. For details on this feature, see page 27. The VCR sets the clock by using up a digital channel's provided by some TV channels. With the automatic clock setting feature, you don't have to set the clock or turn on the auto-tune feature. For details on this feature, see page 27. For details on this feature, see page 27.

#### You are now ready to use your VCR

A Quick reference is provided to help you get the most out of your VCR. For more information on this feature, see page 27. Hookup 1 also allows a cable box to be used if your cable system is scrambled or if it has a control cable box. A list of compatible cable boxes is on page 27.

#### Recommended use

Use the hookup if you do not have a cable box. Also use the hookup if you have a cable box but you do not have a compatible one for the VCR's cable box control feature, and your cable box can scramble only a few channels.


When you can and want to work with this hookup

know you can do

- Record any unscrambled channel by selecting the channel on the VCR panel you want to do
- Record scrambled channels that require a cable box

### No cable box or

### Incompatible cable box with only a few scrambled channels



#### Hookup 2: VCR setup

- 1 Set the **RF INPUT** selector on the VCR to the channel to be used in your area. If feature card set X you need an RF separator (from page 3), you can skip this step.



- 2 Press **EASY SET UP** on the VCR. The **SETUP** menu appears.

#### Getting Started

#### Hookup 2: VCR Plus+ channel setup

- 1 Press the **VCR Plus+ Channel** (CH) key in the program menu, such as the **VCR Plus+ Channel Setup** on page 33.
- 2 If the channel in the program guide no longer fits the channel that you want, use on your TV, set the channel from an adjacent channel.

#### Automatic check, setting

Once you've set up the VCR, it automatically sets the clock for the time you turn off the VCR. After that, whenever you turn off the VCR, a check of the clock displays on-screen. It asks if you'd like to adjust the clock. Press **YES** to adjust the clock. The VCR sets the clock by asking you a time (set that's provided by your TV channel). With the automatic clock setting feature, you don't have to set the clock or even adjust it. In fact, you can't. If you want to set the clock to a certain time, set it manually. For details, see pages 25-26.

#### You are now ready to use your VCR


A Quick reference to operations is provided on the back cover to help you quickly enjoy the best features. These procedures differ slightly depending on the hookup used. Make a note of which hookup you used (hookup 2a or 2b) so that you can refer to the correct instructions.

### Hookup 3


Make the following connections if you're using a stereo (if you don't have cable TV).

### Antenna hookup

- Use this hookup if you're using:
  - UHF antenna (see page 46)
  - VHF antenna (see page 46)
  - separate VHF and UHF antennas



- Use this hookup if you're using a VHF-only antenna (you get channels 3-18 only)



If you don't connect your antenna cable to the VCR directly (if you're using a cable or a flat cable [500-ohm twin lead cable]), which is a bad idea, you'll need a separate converter that connects the cable to the VCR's LIGHT connection. If you have separate cables for VHF and UHF antennas, you may use a U-V converter (not supplied). For details, see page 58.

### Hookup 3: VCR setup

- Set the LIGHT switch on CH 3 on CH 4, whichever channel you use for your set. If both are used, set the switch to allow channel 3.




- Press **BACK** SET UP on the VCR.


The SET UP screen appears.




- Change the **Channel mode** to **Auto**. Press the **Left Arrow** key to highlight **Auto**, and press **ENTER**. For details, see page 23.



- The **Cable mode** is **None**. Change the **Cable mode** to **None**. Press the **Left Arrow** key to highlight **None**, and press **ENTER**. For details, see page 23.



- The **Cable type** is **None**. Change the **Cable type** to **None**. Press the **Left Arrow** key to highlight **None**, and press **ENTER**. For details, see page 23.



- The **Light** is **Set**. Press the **Right Arrow** key to highlight **Set**, and press **ENTER**. For details, see page 25.


Normal display. ☺

### Getting started

### Hookup 3: VCR Plus+ channel setup

- Find the VCR Plus+ Channel List on your program guide for details on the VCR Plus+ Channel List; see page 21.

- If the channels in the program guide are different from the channels that you should use on your TV, set the Channel List on the VCR to match the channels.



### Automatic check setting

Once you've set up the VCR, it automatically sets the clock. The first time you turn off the VCR. After that, whenever you turn off the VCR, it checks if the clock displays the current time. If not, it adjusts the clock. The VCR usually checks the clock by using the radio time signal broadcast by some TV stations. You can start automatic clock setting whenever you turn on the clock or even adjust the Daylight Saving Time. If you want to reset the time to around night time, or if the time automatically sets the time to the wrong day of the day (perhaps), for example, see page 24-26.

### You are now ready to use your VCR

A Quick reference to operations is provided on this book, down to help you quickly enjoy the basic functions. These procedures differ slightly depending on the hookup used. Make a note of which hookup you used (Hookup 1) so that you can always follow the correct instructions.


## Insulation 6

### Incompatible cable box with many scrambled channels

**Recommended use**  
Use this setup for cable boxes that cannot accept a cable box that is incompatible with the VCR cable box control format and your cable system. Scrambled channels will be lost.

When you can and want to do with this hookup:

- Record any channel by entering the channel on the cable box
- When you want to:
  - Record with the cable box, record all
  - Record with the VCR, record all
  - Record by address, OUTSIDE directly with the VCR



## Insulation 4: VCR setup

- 1 Set the TV UNIT switch on CH3 or CH4, whichever channel is not used for your area. If you wish, set the TV UNIT switch on the VCR. If you make A/V connections from page 16, you can skip this step.



- 2 Turn on your cable box.
- 3 Press **FAST SET UP** on the VCR. The SET UP screen appears.



- 4 Press **NUMBER** until the language is French. Change the selected cable language to French. If you want to skip this step, press **EXIT**. For details, see page 21.

- 5 The **VIDEO** screen appears. Press **NUMBER** until the video format is PAL. For details, see page 24.

- 6 The **VIDEO** screen appears. Press **NUMBER** until the video format is PAL. For details, see page 24.


- 7 The **VIDEO** screen appears. Press **NUMBER** until the video format is PAL. For details, see page 24.

- 8 The **VIDEO** screen appears. Press **NUMBER** until the video format is PAL. For details, see page 24.

- 9 The **VIDEO** screen appears. Press **NUMBER** until the video format is PAL. For details, see page 24.

- 10 Press the **VCR** button. Channel 3 appears as your program. Check the details on the VCR Menu Channel Listing, see page 31.

- 2 Enter all the channels you want to record while the cable box output channel listing is 2, 3, or 4:



Block: You have to set the channel manually on the cable box for each recording.

## Automatic channel setting

Since the channels have to be selected manually on the cable box with this hookup, the Auto-CH3 Set (option) will not function fully (page 22). If you want to set the Auto-CH3 Set, set feature to help available, proceed as follows:

- 1 Turn the cable box to a channel that carries a live signal.
- 2 Leave the cable box on.
- 3 Turn on the Auto-CH3 Set feature.
- 4 Turn off the VCR.

## You are now ready to use your VCR

A Quick reference to operation is provided on the back cover to help you quickly program the VCR. However, there are some important details that you should know. Make sure you do each hookup you read through it so that you can always follow the correct connections.



### Backup 5

Incompatible cable box with  
only a few scrambled  
channels, using an AFD switch  
(continued)

### You are now ready to use your VCR

To accept an unscrambled channel:

1. Set the AFD switch to "VCR."
2. Enter channel on the VCR.

To receive a scrambled channel:


1. Set the AFD switch to "E."
2. Select channel on the cable box (or channel on the cable rec. see page 43).

To watch TV:

1. Turn off your VCR, so your VCRS TV/OTR button and the VTR button on the display screen go off.
2. Turn on the TV.
3. Turn on your cable box.
4. Set the TV to the cable box output channel (usually 2, 3, or 4).
5. Set the cable box to the channel you want to watch.

### Selecting a language

(Cannot be accessed any)



If you prefer French or English, you can change the on-screen display language.

When you put up your VCR for the first time, you can select the on-screen display language. For the VCR, the on-screen display language is set to "EN" (English).

Use the following steps to change the language using the remote:

1. Press **MENU**.  
The sub MENU appears on the TV screen.


2. Press the **DOWN (V)** button to move the cursor to **LANGUAGE**. Press **ENTER**.  
The LANGUAGE menu appears on the TV screen.

3. Using the **CURSOR (V)** buttons, select **FRANCAIS** or **ENGLISH**, then press **ENTER**.

### Getting Started



## Setting the clock



The VCR can be programmed to turn the TV on or off at a certain time. To do this, you must first set the clock. To set the clock, follow these steps:

1. Press the **CLOCK** button.
2. Press the **CLOCK SET** button.
3. Press the **CLOCK** button again.
4. Press the **CLOCK SET** button again.
5. Press the **CLOCK** button again.

Set the time and date to turn the TV on or off at a certain time. To do this, you must first set the clock. To set the clock, follow these steps:

### Using the Auto Clock Set feature

Some TVs and other devices are programmed to receive data signals with their broadcast. Your VCR can pick up this data signal to automatically set the clock. After completing the setup below, when you turn off the VCR, it will automatically search for external data (such as a data signal) and set the clock. This Auto-Clock Set feature only works if it is turned on in your area's broadcasting program. For more information, see the user manual for your TV.



1. Press the **ENTER** button.



2. Press the **CLOCK SET** button to select **CLOCK SET**. The **CLOCK SET** menu appears on the TV screen.



3. Press the **CLOCK** (power) button to select **MODE**, then press **ENTER**. The **AUTO-CLOCK SET** menu appears on the TV screen.



4. Press the **CLOCK** (power) button to select **PAUSE**, then press **ENTER**.



5. To set the **CLOCK** (power) button to select **PAUSE**, then press **ENTER**.

If the clock function is not working:

### 1. Verify the clock function is activated



2. Press the **CLOCK** (power) button to select **CLOCK SET**. The **CLOCK SET** menu appears on the TV screen.



3. Press the **CLOCK** (power) button to select **MODE**, then press **ENTER**.



4. Press the **CLOCK** (power) button to select **PAUSE**, then press **ENTER**.



5. Press the **CLOCK** (power) button to select **PAUSE**, then press **ENTER**.




6. Press the **CLOCK** (power) button to select **PAUSE**, then press **ENTER**.



7. Press the **CLOCK** (power) button to select **PAUSE**, then press **ENTER**.



### Setting the clock (continued)




### Using the Manual Clock Set

- 1 Press **MANUAL**.  
The main MENU appears on the TV screen.
- 2 Press the **CURSOR (left)** buttons to move the cursor (B) to **CLOCK SET**. Then press **EXECUTE**.
- 3 Press the **CURSOR (center)** buttons to select **MANUAL**. Then press **EXECUTE**.
- 4 Set the month using the **CURSOR (up)** buttons.
- 5 Press **CURSOR (right)** to highlight the day and set the day using the **CURSOR (left)** buttons.  
The day of the week will automatically appear.
- 6 Press **CURSOR (right)** to highlight the year and set the year using the **CURSOR (left)** buttons.
- 7 Press **CURSOR (right)** to highlight the hour and set the hour using the **CURSOR (left)** buttons.
- 8 Press **CURSOR (right)** to highlight the minutes and set the minutes using the **CURSOR (left)** buttons.
- 9 Press **EXECUTE** to save the clock.

### Presetting channels

(Skip this section if you are using cable box control.)



The **MEMORY** (M) button is used to store up to 100 channels in a VCR channel list. Press the **MEMORY** (M) button to store channels in the VCR channel list.

Channel numbers are stored in the VCR channel list. Press the **MEMORY** (M) button to store channels in the VCR channel list.

The VCR is capable of receiving VHF channels 2 to 12, UHF channels 14 through 69, and automatic CATV channels 1 to 120. However, we recommend that you preset the receivable channels in your area using automatic presetting. Then, if there are any unassigned channels, change these manually. It may have appeared which channel you wish to preset, set them directly using the manual presetting. Also, you can preset the channels using the **EAS/SETUP** button (pages 11, 13, 15, 17 and 19). You can also preset the channels using the menu.


- Before you start, make sure that the TV is connected to the VCR using AV connections on the TV to video input.
- Press **TV/VTR** to display the VTR indicator in the VCR's display.
  - Press **MEMORY SELECT** so that a channel number appears in the VCR's display window.

### Presetting all receivable channels automatically

- 1 Press **MEMORY**.  
The main MENU appears on the TV screen.
- 2 Press the **CURSOR (left)** buttons to move the cursor (B) to **TUNING PRESET**. Then press **EXECUTE**.  
The TV screen displays **MEMORY SELECT**.
- 3 Press the **CURSOR (left)** buttons to move the cursor (B) to **ALL CHANNELS**.
- 4 Select **START** or **CALL** using the **CURSOR (right)** buttons.
  - To preset cable TV channels, select **CALL**.
  - To preset VHF and UHF channels, select **START**.

Continued

### Presetting channels (continued)



- 5** Press the **CUSTOM (P13)** button to move the cursor to **AUTO**.  
 All available channels preset in memory will appear. When no more channels are available, the following message and the picture from the chosen channel will be displayed on the TV screen.

### Presetting disabling channels manually

- 1** Display the **TUNING PRESET** menu.  
 For automatic disabling steps 1 and 2, see "Presetting all non-viable channels automatically."
- 2** Select the channel to preset or disable:  
 • To preset a channel, enter the channel number on the numeric keypad.  
 • To disable a channel, select the channel number by pressing **CH. LK.**
- 3** Set **MANUAL SET TO AUTO or SEARCH**, using the **CUSTOM (P13)** buttons:  
 • To preset channels, enter **AUTO**.  
 • To disable channels, enter **SEARCH**.
- 4** Pressing steps 2 and 3 to preset or disable channels will be required, then press **EXECUTE**.



### Cable TV Channel Assignment

Cable TV channels use letters or numbers to designate (number). This VCR is designed to correspond with standard CATV systems. The cable TV channel numbers on this VCR and the corresponding channel numbers on the TV are listed below. The numbers in the chart may not correspond to the channel number used by your local cable company. Check with your local cable TV company for more information on the available channels.


Channel No. on VCR	1	2	3	4	5	6	7	8	9	10	11	12
Channel No. on TV	44	2	3	4	5	6	7	8	9	10	11	12
1	12	13	14	15	16	17	18	19	20	21	22	23
2	24	25	26	27	28	29	30	31	32	33	34	35
3	36	37	38	39	40	41	42	43	44	45	46	47
4	48	49	50	51	52	53	54	55	56	57	58	59
5	60	61	62	63	64	65	66	67	68	69	70	71
6	72	73	74	75	76	77	78	79	80	81	82	83
7	84	85	86	87	88	89	90	91	92	93	94	95
8	96	97	98	99	100	101	102	103	104	105	106	107
9	108	109	110	111	112	113	114	115	116	117	118	119
10	120	121	122	123	124	125	126	127	128	129	130	131

### If the picture is not clear

Normally, the Auto Fine Tuning (AFT) function automatically tunes in channels clearly. If, however, the picture of a channel is not clear, you may also use the manual tuning function.

- 1** Display the **TUNING PRESET** menu.  
 Press the **VIEW** button (P12) and the **NUMBER** button (P13) corresponding to the channel to be preset manually.
- 2** Select the channel you want to fine-tune by pressing the **NUMBER** buttons and then **ENTER**.
- 3** Press the **CUSTOM (P13)** button to move the cursor to **2nd** channel. The following message appears:
- 4** Press the **CUSTOM (P13)** button to get a clearer picture. Then press **EXECUTE**. Note that the AFT setting returns to OFF.

## Setting up cable box control



This VCR is programmed with codes necessary to control channel control from buttons of cable boxes. If the Cable Box does not work with cable box control, the VCR controls obtained on the cable box for their recording. You can also use the VCR's channel controller to change the channel on the TV. To use the VCR's channel controller, you must connect the Cable Box to the TV. To use cable box control, you need to connect the Cable Box to the TV and set the cable number and setup channel.

This VCR is programmed with codes necessary to control channel control from buttons of cable boxes. If the Cable Box does not work with cable box control, the VCR controls obtained on the cable box for their recording. You can also use the VCR's channel controller to change the channel on the TV. To use the VCR's channel controller, you must connect the Cable Box to the TV and set the cable number and setup channel.

When you set up using VCR for the first time, you can set up with cable box control using the EASY-SET UP feature (pages 11, 13, 15, 17 and 19). You can also set up by using the menu.

**1 Press MENU**  
The main MENU appears on the TV screen.

**2 Press the OUTSIDE buttons to move the cursor to CABLE BOX CONTROL, then press ERASE.**  
The CABLE BOX CONTROL menu appears.

**3 Press the OUTSIDE (number) buttons to select ON, then press ERASE.**

**4 Enter the cable box code number by pressing the number buttons. Press the ERASE button to return to the start of the list of codes.**


**5 Select the setup channel for cable box using the CHANNEL (1-15) buttons, then press ERASE.**

**Cable box brands and the corresponding cable box codes numbers are listed in the following table. The codes are listed by country. You can also refer to the correct code for your equipment.**

Country	Cable box brand	Cable box model	Cable box code	Setup channel
USA	Arcade	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
Canada	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2
	Archie	ARC 100, 101	100, 101	1-2

## Setting up cable box control (continued)

Tip: For normal viewing



... Signal

**Note:**  
 • Why can't you see the VCR when you turn on the TV? The VCR takes power off a secondary line called the "standby" line. The VCR takes power from this line only when you turn on the TV. To see the VCR, you must turn on the TV first.

- Turn the Cable Box on to turn it back on.
- Don't place the cable box on top of the VCR.
- Point the remote controller at the VCR, not at the cable box.

The cable box control setting

- Turn the cable box control setting on the cable box control panel. Don't use channel numbers on the cable box.
- Press all the number buttons 4 to 9 to see the remote controller. Don't the channel number on the cable box change?

If the answer is both 1 and 2 or "Yes," you have made the correct setting.

If you cannot get your VCR to control the cable box

- ✓ Check the Cable Box in Component or the CABLE BOX CONTROL Tab on the VCR.
  - ✓ Check the position of the CABLE MODE.
  - ✓ Place the cable box and VCR as far from each other. Do not place the cable box on top of the VCR.
  - ✓ The two settings again making sure to use the correct remote code. If the cable box still does not respond, you can try other codes.
- If your cable box still does not operate with the Cable Remote, contact your cable company to see if they can provide you with a compatible cable box.

## 30 | Setting a channel

## 31 | Getting started

VCR Plus+ is a service in Sony VCR that simplifies the task of programming the VCR to watch certain recordings.

Since VCR Plus+ records have a TV program, all you need to do is look up the program you want to watch on the TV. Then, you can use the VCR Plus+ to set up the VCR to watch that program. The VCR Plus+ is a service that is established by the TV network of each country's cable TV. Listings for TV programs are printed in the TV's program guide. Then, you enter the PlusCode of the program you want and the VCR is automatically programmed to record that show. It's that simple. With VCR Plus+, you no longer have to go through a lengthy and often repetitive process of setting up the VCR manually each time you want to watch a program.

Here is how to use VCR Plus+ to program your VCR to watch a program. The number you turn on your TV to watch a program with the guide channel the number you're assigned to the channel in your program guide. To get the guide channel numbers, find the "Channel Line-up Chart" in the program guide for your area and locate the PlusCode. It usually looks like the example on the left.

For each channel your VCR records, use the Channel Line-up Chart to check that the channel number match. For example, HBO is listed in the Channel Line-up Chart on channel 25, and your VCR tuner is HBO on channel 15, you need to combine these numbers using the following programming method:  $25 \times 10 + 15 = 2515$ . The number 2515 is the VCR Plus+ code you use to program the VCR to watch the HBO channel (instead of 25, you can skip this procedure).

(continued)

## Setting up VCR Plus+


Example 1 "Example"

Channel	PlusCode
15	2515
16	2616
17	2717
18	2818
19	2919
20	3020
21	3121
22	3222
23	3323
24	3424
25	3525
26	3626
27	3727
28	3828
29	3929
30	4030
31	4131
32	4232
33	4333
34	4434
35	4535
36	4636
37	4737
38	4838
39	4939
40	5040
41	5141
42	5242
43	5343
44	5444
45	5545
46	5646
47	5747
48	5848
49	5949
50	6050
51	6151
52	6252
53	6353
54	6454
55	6555
56	6656
57	6757
58	6858
59	6959
60	7060
61	7161
62	7262
63	7363
64	7464
65	7565
66	7666
67	7767
68	7868
69	7969
70	8070
71	8171
72	8272
73	8373
74	8474
75	8575
76	8676
77	8777
78	8878
79	8979
80	9080
81	9181
82	9282
83	9383
84	9484
85	9585
86	9686
87	9787
88	9888
89	9989
90	0090
91	0191
92	0292
93	0393
94	0494
95	0595
96	0696
97	0797
98	0898
99	0999
00	1000

Example 2 "Example"

Channel	PlusCode
15	2515
16	2616
17	2717
18	2818
19	2919
20	3020
21	3121
22	3222
23	3323
24	3424
25	3525
26	3626
27	3727
28	3828
29	3929
30	4030
31	4131
32	4232
33	4333
34	4434
35	4535
36	4636
37	4737
38	4838
39	4939
40	5040
41	5141
42	5242
43	5343
44	5444
45	5545
46	5646
47	5747
48	5848
49	5949
50	6050
51	6151
52	6252
53	6353
54	6454
55	6555
56	6656
57	6757
58	6858
59	6959
60	7060
61	7161
62	7262
63	7363
64	7464
65	7565
66	7666
67	7767
68	7868
69	7969
70	8070
71	8171
72	8272
73	8373
74	8474
75	8575
76	8676
77	8777
78	8878
79	8979
80	9080
81	9181
82	9282
83	9383
84	9484
85	9585
86	9686
87	9787
88	9888
89	9989
90	0090
91	0191
92	0292
93	0393
94	0494
95	0595
96	0696
97	0797
98	0898
99	0999
00	1000

### Setting Up VCR Plus+ (continued)



- 1 Press **MENU**.  
The **MAIN MENU** appears on the TV screen.



- 2 Press the **CHANNEL (+/-)** buttons to move the cursor (TV) to **SET VCR CHANNELS**, then press **ENTER**.  
The **SET VCR CHANNELS** screen appears and the **CHANNEL** screen is highlighted.



- 3 Enter the channel number assigned in the program guide and press **ENTER**.  
The **TV CH** column is highlighted.



- 4
  - If you made lookup 1, 2, or 3, enter the actual number on your TV (not VCR) and press **ENTER**.
  - If you made lookup 4, enter the cable output channel (usually 2, 3, or 4).
  - If you made lookup 5, enter the actual number on your TV (not VCR) for an unregistered channel and press **ENTER**. For a satellite channel, enter the cable base number (usually 2, 3, or 4) and press **ENTER**.



- 5 Repeat steps 3 and 4 for each channel whose numbers don't match.

- 6 When you finish set all channels, press **DISCRETE** to confirm your channel settings.



- 7 When you're finished, press **MENU** to exit.

### Using the **ADVANCED OPTIONS**

The **ADVANCED OPTIONS** allow you to make a number of optional changes. For a list of menu choices, see the address in the following page.



- 1 Press **MENU**.  
The **MAIN MENU** appears on the TV screen.



- 2 Press the **CHANNEL (+/-)** buttons to move the cursor (TV) to **ADVANCED OPTIONS**, then press **ENTER**.  
The **ADVANCED OPTIONS** menu appears on the TV screen.

- 3 Press the **CHANNEL (+/-)** buttons to move the cursor (TV) to the desired menu choice.

- 4 Set the item to the desired setting using the **Cursor** (arrow) buttons.

- 5 Press **DISCRETE** to return to the original screen.



## Using the ADVANCED OPTIONS (continued)

Menu choices  
Initial settings are indicated in bold letters

<b>Menu system</b> AUTO-SET/SEE	<p>Select this option as:</p> <ul style="list-style-type: none"> <li>• Only if your TV is connected to a VCR. The TV will automatically scan for VCRs to use the VCR. (An external antenna is not required.)</li> <li>• OFF (your TV is connected to a VCR, but you do not want to use the VCR).</li> <li>• OFF (your TV is not connected to a VCR).</li> </ul>
<b>AUDIO/VIDEO</b>	<ul style="list-style-type: none"> <li>• OFF to receive stereo programs.</li> <li>• OFF to receive monaural stereo programs.</li> <li>• OFF to receive monaural stereo programs for Dolby Surround.</li> </ul>
<b>CHANNEL</b>	<p>For details, see page 33.</p> <ul style="list-style-type: none"> <li>• OFF to receive digital stereo data.</li> </ul>
<b>AUDIO/VIDEO</b>	<ul style="list-style-type: none"> <li>• ON to receive the sound transmitted on the high and normal audio tracks.</li> <li>• OFF to receive the sound transmitted on the high and normal audio tracks.</li> <li>• OFF to receive the sound transmitted on the high and normal audio tracks.</li> <li>• OFF to receive the sound transmitted on the high and normal audio tracks.</li> <li>• OFF to receive the sound transmitted on the high and normal audio tracks.</li> </ul>
<b>NORMAL AUDIO</b>	<p>For details, see page 33.</p> <ul style="list-style-type: none"> <li>• ON to receive stereo programs.</li> <li>• OFF to receive monaural stereo programs.</li> <li>• OFF to receive monaural stereo programs for Dolby Surround.</li> </ul>
<b>AFC</b>	<ul style="list-style-type: none"> <li>• ON to receive stereo programs.</li> <li>• OFF to receive monaural stereo programs.</li> <li>• OFF to receive monaural stereo programs for Dolby Surround.</li> </ul>
<b>CLERK LAMP</b>	<p>For details, see page 33.</p> <ul style="list-style-type: none"> <li>• ON to receive stereo programs.</li> <li>• OFF to receive monaural stereo programs.</li> <li>• OFF to receive monaural stereo programs for Dolby Surround.</li> </ul>
<b>TAPE SELECT</b>	<ul style="list-style-type: none"> <li>• ON to receive stereo programs.</li> <li>• OFF to receive monaural stereo programs.</li> <li>• OFF to receive monaural stereo programs for Dolby Surround.</li> </ul>

## Basic Operations Playing a tape




Fig. 1 For detailed information on features and controls, see the "Basic Operations" section of the manual.

Fig. 1

For detailed information on features and controls, see the "Basic Operations" section of the manual.

The section shows you how to play back a video tape.

- Turn the power on and set the VCR to the VCR mode.

  - Press the **POWER** button on the TV.
  - Press the **VCR** button on the TV.
  - If the TV is connected to a VCR, set the TV to the VCR mode.
  - If the TV is connected to a VCR, set the TV to the VCR mode.
- Open the tape door panel and insert a tape.

The VCR runs on automatically. The tape will start to play.
- Press the **PLAY** button to start playing.

The VCR will start to play the tape automatically.


(The power remains on.)

Additional buttons

To	Press
Stop the tape	<b>STOP</b>
Pause the tape	<b>PAUSE</b>
Resume play after pause	<b>PAUSE</b> or <b>PLAY</b>
Search forward	<b>SEARCH</b> or <b>SKIP</b>
Search backward	<b>SEARCH</b> or <b>SKIP</b>
Fast forward by tape	<b>FAST FORWARD</b>
Fast reverse by tape	<b>FAST REVERSE</b>
Fast stop	<b>STOP</b>

### Displaying the date and time, remaining tape length and time counter

Press DISPLAY to make display on or off.



### Displaying the remaining tape counter

Press COUNTER/REMAIN to display the remaining tape counter in the display window. To display it on the TV screen, press DISPLAY to turn the display on. Then press COUNTER/REMAIN. Each time you press COUNTER/REMAIN, the one counter and the remaining tape counter appear alternately.



When you use a tape with more than 2-hour recording, press "120" or "180" after the screen.

- 1 Press MENU and select ADVANCED OPTIONS.



- 2 Set TIME SELECT to "120" or "180" using the CURSOR (4) or (5) buttons.




- 3 Press EXIT to close the setting.

### Using the time counter

At the point on a tape that you wish to find later, press COUNTER RESET to save the counter to MEMORIES. When you need to advance the tape to this point, refer to the Counter

### Playing stereo and bilingual programs

From AUDIO MONITOR, to add the desired sound. Each press of the button changes the display on the VCR.



Have played is protected on a stereo tape. The VCR records separately in different tracks. High-fidelity sound is recorded on the left channel, and the stereo sound is recorded on the right channel. Mono sound is recorded on both channels along the edge of the tape.



To listen to both audio channels, play at the same speed.



- 1 Press MENU and select ADVANCED OPTIONS.



- 2 Set AUDIO MIX to OFF using the CURSOR (4) or (5) buttons. The AUDIO MIX button becomes inoperative, and the sound you hear is mono.

- 3 Press EXIT to close the setting. After playing the tape, use AUDIO MIX to OFF.


Notes:

- When you use a tape with more than 2-hour recording, the VCR records separately in different tracks. High-fidelity sound is recorded on the left channel, and the stereo sound is recorded on the right channel. Mono sound is recorded on both channels along the edge of the tape.

- AUDIO MIX to OFF using the CURSOR (4) or (5) buttons. The AUDIO MIX button becomes inoperative, and the sound you hear is mono.

After playing the tape, use AUDIO MIX to OFF.

## Recording TV Programs



**Note**

- To use the timer with the VCR, refer to the VCR manual. When you use the VCR, always use the red box.

**To**

- To edit a timer, you can use the timer menu. Refer to the VCR manual for more information. When you edit a timer, you can use the timer menu to change the timer. Refer to the VCR manual for more information.

This section shows you how to record TV programs on the record timer. You must record with normal recording. You can also record with the VCR. The VCR also provides the following: a set of recording.

- Manually start recording, then stop it automatically. — "Recording using the stop timer." (page 48)
- Automatically start and stop recording. — "Recording TV programs using the timer." (page 49)
- Automatically stop and stop recording. — "Recording TV programs using the timer." (page 49)

**1 Turn on your TV and tune in the VCR.**

- Turn on the TV, set the VCR to record the timer, and turn on the TV to record the timer.
- Turn on the TV, set the VCR to record the timer, and turn on the TV to record the timer.

**2 Press the stop timer button and insert a tape with the timer on in place.**

**3 Press the timer button with a channel number appears in the VCR's display window.**

**4 Select the channel desired by pressing OK or .**

**5 Select the tape mode, SP or EP, by pressing the timer button.**

**6 Start recording by pressing REC.**

When the timer reaches the end of the VCR, automatically records a timer recording.

**To stop recording:**

Press **STOP**.

**To select tape speeds:**

When recording, select either SP or EP. EP provides recording time three times as long as SP. However, SP provides better picture quality than EP. The VCR has a timer menu that lets you select the VCR recording speed. Refer to the VCR manual for more information.

**To stop recording:**

Press **STOP**.

**To record the recording duration with recording:**

Press **QUICK TIMER** until the desired duration appears on the display window.

**To stop recording:**

Press **STOP**.

**To record the recording duration with recording:**

Press **QUICK TIMER** until the desired duration appears on the display window.

**To stop recording:**

Press **STOP**.

**To record the recording duration with recording:**

Press **QUICK TIMER** until the desired duration appears on the display window.

**To stop recording:**

Press **STOP**.

**To record the recording duration with recording:**

Press **QUICK TIMER** until the desired duration appears on the display window.

**To stop recording:**

Press **STOP**.

**To record the recording duration with recording:**

Press **QUICK TIMER** until the desired duration appears on the display window.

**To stop recording:**

Press **STOP**.

**To record the recording duration with recording:**

Press **QUICK TIMER** until the desired duration appears on the display window.

**To stop recording:**

Press **STOP**.

**To record the recording duration with recording:**

Press **QUICK TIMER** until the desired duration appears on the display window.

**To stop recording:**

Press **STOP**.

**To record the recording duration with recording:**

Press **QUICK TIMER** until the desired duration appears on the display window.

**To stop recording:**

Press **STOP**.



## Recording TV programs (Continued)

- Watching a TV program while recording another**  
You can watch a TV program and record another at the same time.
- 1 Press TV/VCR to turn on the VCR indicator on the display window.
  - 2 If the TV is connected to the VCR using the audio/video cables, set the TV to **TV**.
  - 3 Use the TV's channel selector to select the channel you wish to watch.
  - 4 When the channel changes on the TV.

### Recording stereo and bilingual programs

**Stereo programs**  
The VCR automatically records stereo programs as stereo. When stereo programs are recorded, the STEREO indicator on the VCR lights up. If you want to record a stereo program, record the program in **STEREO**. Refer to the setup tables.

**Bilingual programs**  
The VCR records audio tracks on both main and normal audio tracks. To record bilingual Audio Programs, refer to the normal audio track, below. The steps below:

- 1 Press **MEMO** and select **ADVANCED-OPTIONS**.



- 2 To record stereo programs as mono:  
Set **AUTOSTEREO** to **OFF** using the **CURSOR** (←/→) keys.



- 3 To record SMP sound on normal audio track:  
Set **AUTOSTEREO** to **ON** using the **CURSOR** (←/→) keys.



- 3 Press **DISCLOSE** to enter the setup.

To monitor SMP sound while recording:  
Press **ALTIMONITOR** until the SMP indicator lights up on the display window.

### Setting a recording

Video tapes have a safety tab to prevent accidental recording. To prevent accidental erasure of a recording, break off the safety tab with a sharp object such as a paper toothpick. Unrecorded spots if you try to record them.


To record on a tape with a safety tab removed, cover the tab both with adhesive tape.



**Tip**  
• The **ALTIMONITOR** key lets you record tracks and watch them on a video tape (see page 11).

**Note**  
• The **NORMAL**, **MONO** or **SMP** indicator on the recording window is lit when the recording mode is set. The indicator is lit in the recording window and the **TV** indicator on the TV is lit when the TV is set to **TV**. When the TV is set to **TV**, the TV will not record. When the TV is set to **VCR**, the TV will not record. When the TV is set to **TV**, the TV will not record. When the TV is set to **VCR**, the TV will not record.

## Recording TV programs using the timer



This section shows you how to let the VCR automatically start and stop recording TV programs. You can record up to eight programs within a one month time frame. A VCR timer is available in your area, see the section "Recording TV programs using VCR Timer" on page 43 for easier timer recording.

### Before you start...

- Check that the clock is set correctly.
- Insert a tape with its safety lock release tab in the tape magazine.
- Turn on your TV and tune to the VCR channel using a cable box, term kit or antenna.

### 1 Press MENU and select TIMER SET.

If the clock value in the "Clock on the dial" appears on the screen and the VCR automatically enters the clock setting mode.

### 2 Set the date to start recording.

- 1 Press CURSOR  $\uparrow$ . The date in the timer menu is highlighted. If it is not the date in the correct time, press CURSOR  $\leftarrow$  to get the month and day of the month set.

The day of the week is set automatically.

To see what your program starts every day or the one day once a week, see "Daily / Weekly" recording" on page 44.

### 3 Set the date to start recording.

- 1 Press CURSOR  $\uparrow$  to highlight the hour counter "START". Move the CURSOR  $\leftarrow$  to move to set the hour.
- 2 Press CURSOR  $\uparrow$  to highlight the minute counter "STOP". Press the CURSOR  $\leftarrow$  button to set the minute.

### Tip

- To set the channel, use the channel buttons on the remote control or a channel selector on the VCR.
- To pause a video cassette recording, press PAUSE or STOP.
- To stop a recording, press STOP.
- To stop a recording, press STOP.

### Tip

- Press the numeric key board on the remote control to change TAKE SPEED.

### Tip

- To change a timer recording, it is possible to highlight the recording and change the recording date.

- 4 Press CURSOR  $\uparrow$ , then set the time to stop recording in the same way.



- 5 Press CURSOR  $\uparrow$ , then press the CHANNEL (F4) button to select the channel you want to record. Only set channel preset in the VCR will appear. After using a cabinet, the cable box appears.



- 6 Press CURSOR  $\uparrow$ , then press the same number to select the same record. See "To select tape speed" on page 39.



- 7 To continue your program, press CURSOR  $\uparrow$ . All the settings are highlighted. After the cursor is shown in the channel number, you can change the channel. To select the recording speed, press the TAPE SPEED button.



- 8 After making the desired timer setting, press ESCAPE.



- 9 Press EXIT to turn off the VCR. The timer appears on the VCR display. When using a cable box, leave the VCR automatically turn on and same recording at the previous time, and same set at the present stop time.



### 4 Starting recording utility recording.

Press  $\llcorner$  STOP.

### Recording TV programs using the TIMER (continued)

To use the VCR with recording, be certain to check the following items during timer recording:

TV	Make sure the mode is "HOLD".
Remote control	Make sure the mode is "HOLD".
Display	Display timer information on the TV DISPLAY.
Check the timer settings.	Make sure the timer is set to "TIMER".
Check the timer program.	Make sure the timer is set to "TIMER".
Check the timer program.	Make sure the timer is set to "TIMER".

### Using the VCR before timer recording begins


Press POWER to turn on the VCR. The TIMER indicator on the VCR goes off and the VCR is ready for use.

When using the VCR, turn off the VCR light to turn on the TIMER indicator on the VCR. When using a cable box, turn it on. Remember to turn off the VCR before the time you set for the VCR to start recording so the timer setting will be successful.


### Daily/weekly recording

Daily recording records the same program every day of the week, weekly recording records the same program on the same day every week.

When you set the date to start recording in step 2 of "Recording TV programs using the timer," press CLEAR to start the timer recording. Each time you press the button, the indication changes as shown on the left.



### Recording TV programs using VCR Plus+



### Notes

- The timer on VCR Plus+ is for recording only.
- When VCR Plus+ is turned on, the timer will stop.
- The timer will stop when the timer is turned off.
- The timer will stop when the timer is turned off.
- The timer will stop when the timer is turned off.
- The timer will stop when the timer is turned off.
- The timer will stop when the timer is turned off.
- The timer will stop when the timer is turned off.
- The timer will stop when the timer is turned off.
- The timer will stop when the timer is turned off.
- The timer will stop when the timer is turned off.
- The timer will stop when the timer is turned off.

This section shows you another way of timer recording: recording using VCR Plus+. Make sure you have the VCR Plus+ feature on the VCR. You can record up to eight programs a week with a one-month delay feature.

### Before you start

- Check that the clock is set correctly.
- Turn on the VCR with the timer set in Place. Make sure the timer is longer than the total recording time.
- Turn on your TV, and tune to the VCR. When using a cable box, turn it on.

### 1 Press VCR Plus+

Press VCR Plus+ to start recording. This is the "VCR Plus+" button on the front of the VCR. Press the button and the VCR will automatically enter the clock setup mode.

### 2 Enter the desired program's PlusCode using the number buttons

If you make a mistake, press TIMER CLEAR and enter the PlusCode again.

### 3 Select the tape speed, SP or BP by pressing TAPE SPEED.

Press ONCE, DAILY or WEEKLY according to the following:

### To record the program

- Only once.
- Once.
- DAILY.
- WEEKLY.

The recording light on the VCR Plus+ will be on the TV screen. The program start and stop times, channel number and tape speed. Check that the information is correct. If it is not, press TIMER CLEAR to reset. If it is correct, press TIMER to stop recording.

## Recording TV programs using VCR (Part-Continued)

- 5 Press **POWER** to turn off the VCR. The TIMER indicator on the VCR lights up and the VCR starts to be recording. When using a cable box, leave it on. The VCR automatically stops on, records the program and turns off.

To stop recording while recording  
Press **STOP**

To use the VCR while recording

You can do the following while recording using VCR Plus+.


Key	Action
Stop the current TV program	CONTRACTSHEET
Pause for later information on the TV screen	DISPLAY
Check the timer settings	MENU and when TIMER SET CHECK is displayed on the screen
Pause or stop TV program	TV-STOP (on "Walkaway" TV program recording mode) or PAUSE

### Using the VCR before recording begins

Press **POWER** to turn on the VCR. The TIMER indicator on the VCR goes off and the VCR is ready for use.

After using the VCR, turn off the VCR using the **POWER** button on the front of the VCR, when using a cable box, leave it on. Remember to reset the VCR to (stand) by its recording before ending you've set the VCR to start, stop time, or the timer setting will be cancelled.

## Checking/Changing/Canceling timer settings



This section shows you how to check, change and cancel the timer settings after a time period has run on the VCR.

Before you start:

- Turn on your TV and tape in to the VCR.

- 1 Press **POWER** to turn on the VCR. The TIMER indicator on the VCR goes off.

- 2 Press **MENU** and select **Timer SET CHECK**.



- 3 Check the timer settings.

- To check the timer settings, press **ENTER** (press **EXECUTE** from the VCR off to return to recording mode).

- If you want to change or cancel the timer settings, press **ENTER** (press **EXECUTE** from the VCR off to return to recording mode) when you want to change or cancel.

- 4 Change or cancel the timer settings.

- To change the timer settings, press **ENTER** (press **EXECUTE** from the VCR off to return to recording mode) to go to the next setting, and then using the **UP** and **DOWN** buttons to change the timer settings. Press **ENTER** (press **EXECUTE** from the VCR off to return to recording mode) to return to recording mode.
- To cancel the timer, press **ENTER** (press **EXECUTE** from the VCR off to return to recording mode).

- 5 Press **EXECUTE**.

- The VCR returns to the original screen. If you have changed the timer settings, the **TIMER SET/CHECK** screen is shown on the VCR as you return to recording mode.

To check the timer settings during timer recording  
Press **MENU** and select **TIMER SET/CHECK**. After checking, press **EXECUTE** to turn off the display.

### Checking program recording timer settings (continued)

#### When the timer settings overlap

The VCR will air record overlapping programs if any of your timer settings overlap. Change the timer settings as follows:

**Case 1:** If you enter two programs to start recording at the same time...

The program listed first in the TIMER SET/CHECK menu has priority over the other program. The start times of the timer programs will be raised from the TIMER SET/CHECK menu to start the first program before recording.

**Case 2:** If you record program 2 in still recording of the same time...  
The last 30 seconds of program 1 will not be recorded because the VCR will enter recording mode for program 2 before program 1 is finished.

**Case 3:** If you record program 2 in still recording before program 1 is finished recording...

Program 2 will start recording before program 1 has finished.

**Case 1**  
Program 1 10:00-10:30  
Program 2 10:00-10:30  
Both start times will be raised to 11:00.

**Case 2**  
Program 1 10:00-10:30  
Program 2 10:00-10:30  
The last 30 seconds of program 1 will not be recorded.

**Case 3**  
Program 1 10:00-10:30  
Program 2 10:00-10:30  
Program 2 will start recording before program 1 has finished.

### Additional Operations Playing/Searching at various speeds




Fig. 1


- Push the green stop button (STOP) to stop recording.
- Push the yellow STILL button (STILL) to stop recording.
- Push the yellow SLOW button (SLOW) to play back at half speed.
- Push the yellow FAST button (FAST) to play back at 1.5 times normal speed.

**Note:**  
• There are several built-in modes for the VCR. To see the list of modes, push the MODE button. The list of modes will be shown on the screen.

You can play back at various speeds: high-speed, slow motion, stills, freeze and so on. These options are also useful for searching for a specific point during playback. The record is marked during these operations.

Playback option	Operation	For return
Playing at various speeds	During playback or pause mode, press the STILL, SLOW, FAST, or PAUSE button. Press the MODE button to stop recording.	Return to the normal playback mode.
Overplay (the recorded tape longer than normal)	High-speed	From the PAUSE mode, press the STILL, SLOW, or FAST button.
Freezing the recording	During stop mode, press the STILL, SLOW, or FAST button. Press the MODE button to stop recording.	From the PAUSE mode, press the STILL, SLOW, or FAST button.
Viewing the picture during playback	During playback or pause mode, press the STILL, SLOW, or FAST button. Press the MODE button to stop recording.	From the PAUSE mode, press the STILL, SLOW, or FAST button.
Looking for a high-speed point	During playback or pause mode, press the STILL, SLOW, or FAST button. Press the MODE button to stop recording.	From the PAUSE mode, press the STILL, SLOW, or FAST button.
Looking for a slow-motion point	During playback or pause mode, press the STILL, SLOW, or FAST button. Press the MODE button to stop recording.	From the PAUSE mode, press the STILL, SLOW, or FAST button.
Freezing frame by frame	During playback or pause mode, press the STILL, SLOW, or FAST button. Press the MODE button to stop recording.	From the PAUSE mode, press the STILL, SLOW, or FAST button.
Stopping a scene	During playback or pause mode, press the STILL, SLOW, or FAST button. Press the MODE button to stop recording.	From the PAUSE mode, press the STILL, SLOW, or FAST button.
Advanced search mode	During playback or pause mode, press the STILL, SLOW, or FAST button. Press the MODE button to stop recording.	From the PAUSE mode, press the STILL, SLOW, or FAST button.

## Adjusting the picture



- Stop**
- Automatic adjustment is cancelled in 10 seconds.

- Play**
- When recording, the VCR begins to play back the tape when you press the PLAY button.
  - Press **PAUSE** to make the tape stop. Press the button again to make the tape start recording again.
  - Press **REVERSE** to make the tape start recording in reverse.

The VCR automatically adjusts the picture for the best possible picture or recording. However, you find the automatic adjustment unsatisfactory, you can enter the picture manually.

### Adjusting the tracking

Though the VCR automatically adjusts the tracking when playing a tape, the **AUTO TRACKING** indicator flashes in the display window. Use the **TRACKING** button to manually adjust the tracking manually.

Press the **TRACKING NORMAL** button to display the tracking menu. The alternate should disappear as you press one of the two buttons. If you cannot get a clear picture with manual adjustment, press **TRACKING AUTO/ MANUAL** to return to automatic adjustment.



### About Adaptive Picture Control (APC)

Adaptive Picture Control (APC) automatically improves recording and playback picture quality. It works on all types of tapes, including Hi-Fi and Hi-Fi VHS tapes. To maximize your picture quality, we recommend that you set APC to ON in the **ADVANCED OPTION** menu (refer to the APC section in the **DISPLAY** window (1)).

### To use APC during playback


The APC function automatically works on all types of tapes, including Hi-Fi and Hi-Fi VHS tapes. You can play a tape using the APC function even if the tape was not recorded with it.

### To use APC while recording

Whenever you insert a tape and the tape recording, the VCR adjusts the tape using the APC function (the APC indicator flashes rapidly). This adjustment is not used until the tape is played. There is a short delay before the VCR actually starts recording while the VCR analyzes the tape.

If you want to start recording precisely the first time you record, set the VCR in **RECORDING PAUSE MODE** (APC defines **Replay Mode**). Press **RECALL** to let the VCR analyze the tape. When the APC indicator starts flashing, press **RECALL** to start recording. Recording begins immediately.

## Searching using the index function



The VCR automatically searches for index signal at the point where recording stops (with the exception of when you start recording from recording pause). Use this as a reference to find the beginning of the recording. The VCR automatically searches for the beginning of the current position, usually near many index signals ahead or behind the specific index signal to find the current position. The VCR can search up to 99 index signals ahead or behind of the current position.

### Press an indexed tape into the VCR.

### Press the **INDEX SEARCH** button repeatedly until the index signal appears on the TV screen.

- To locate recording programs, press **INDEX SEARCH**.
- To locate preceding programs, press **INDEX REVERSE**.
- To locate succeeding programs, press **INDEX SEARCH**.


The VCR will stop at the beginning of the recording when the TV screen starts to stream. Playback starts automatically from this point.

## Editing with another VCR

- Tip:**
- Ask to rent your own VCR for only a few days.
  - Turn on the other VCR. You can use the ERASE (E) button to erase any unwanted tape.
  - In the other VCR, set the display to "E" for the other VCR to receive the video.
  - If the other VCR is a standard VCR, have the video processed.
- Note:**
- When connecting the VCRs, connect the LINE IN and LINE OUT ports on the VCR you are editing to the LINE IN and LINE OUT ports of the VCR you are editing to.

This section shows you how to edit up or down another VCR or camcorder. You can make a copy of a tape using the VCR for recording or playback.


### How to hook up to record on this VCR



Line in - Signal from Drive VCR (Player) to My VCR (Recorder)

Line out - Signal from My VCR (Recorder) to TV

### How to hook up to record to another VCR



Line in - Signal from My VCR (Player) to Drive VCR (Recorder)

Line out - Signal from Drive VCR (Recorder) to TV

## Operation (when recording on this VCR)

Before you start editing:

- Press VCR SELECT to enter "L" mode display mode.
- Press ERASE on the remote controller to select the editing tape you want to erase.
- On this VCR, or the ERASE switch is ON in the other VCR has a similar format, set it to ON as well.

- 1 Insert a source tape with its safety tab removed into the other VCR. Press the button for the source tape, and set it to playback again.


- 2 Insert a tape into this (recording) VCR. Search for the point to start recording and press II PAUSE.

- 3 Press @ REC on this VCR and set it to recording phase.

- 4 To start editing, press the II PAUSE button on both VCRs at playback time VCRs from pause. For the result, press the PAUSE button on the other VCR for playback pause. If FALSE on the VCR.


To stop editing:

Press the STOP button on both VCRs.



- Tip:**
- To remove the VCR from pause, press the II PAUSE button on the VCR to the VCR from pause.
  - To stop editing, press the STOP button on both VCRs.
  - Press the PAUSE button on the VCR to the VCR from playback pause.
  - Press the ERASE button on the VCR to the VCR from playback pause.
  - Press the PAUSE button on the VCR to the VCR from playback pause.
  - Press the STOP button on the VCR to the VCR from playback pause.

## Insert editing



Press the **INSERT** button to insert a new video frame into the current frame. The **INSERT** button is only available when the video is in the **EDIT** mode.

You may replace unwanted content with other scenes by recording pictures and/or sound over the recorded tape. With the video under pause, the original video and its sound are retained while the original (unwanted) sound is replaced with the audio from the new, original material found at the end. The original video and its sound, however, are erased.

- Follow the procedure of page 52 to lock up your VCR. To insert sound into a video system, see "To lock up with a stereo system".
- Press **INPUT SELECT** to display "A3" on the display to indicate.

- 1 Insert a source tape into the playback VCR or into the stereo system. Search for the point to start playback and set it to playback mark.
- 2 Insert the programmed tape into the recording VCR. Search for the end of the unwanted scene and press **PAUSE**.
- 3 Press **CHANGER** once on this VCR to reset the counter to "00000000".
- 4 Repeat the steps in the beginning of the unrecorded scene. This VCR is on.
- 5 Press the **INSERT** button according to the following table.

Function	Button	Display
Insert a new scene	<b>INSERT</b>	"A TO DISC" appears on the display.
Insert a new scene and sound	<b>INSERT</b> + <b>VIDEO</b>	"AV INSERT" appears on the display.
Insert a new scene and sound only	<b>INSERT</b> + <b>VIDEO</b> + <b>VIDEO</b>	"VID DISC" appears on the display.
Insert a new scene and sound only	<b>INSERT</b> + <b>VIDEO</b> + <b>VIDEO</b> + <b>VIDEO</b>	"VID DISC" appears on the display.

- 6 To start editing, automatically press the **PAUSE** button on this VCR and on the other VCR or stereo system. When the counter of the VCR reaches "00000000", editing starts automatically.

**To stop editing**  
Press the **STOP** button on this VCR and on the other VCR or stereo system.

To lock up with a stereo system  
Connect LINE IN 2 AUDIO of the VCR and the audio-out jack of the stereo system, using the BK-C3000 cable (available for purchase). Display "LINE 2" on the TV screen using **INPUT SELECT**.



## Synchronized editing


NOTE

- THE CABLE BOX: This device is used to connect the VCR to the CONTROL 5 unit. The additional connection also connects from VCR to main unit VCR when editing.

If either VCR has a CONTROL 5 OUT and the other has a recording, connect the VCRs via the CONTROL 5 unit. The additional connection also connects from VCR to main unit VCR when editing.

### How to hook up via the CONTROL 5 feeds

The CONTROL 5 connection only enables you to pause and release feeds.



## Operation (when recording on the other VCR)


As before, see page 44.

- On the VCR with EDIT enabled, if the other VCR has a similar function, set it ON to edit.

- 1 Insert a tape into the other (recording) VCR, switch for the point to start recording and press **REWIND**.
- 2 Insert a tape into the other (recording) VCR, switch for the point to start recording and press **REWIND**.
- 3 Press **REC** on the other VCR to check for recording.
- 4 To start editing, press **EDITING** (top) on the other VCR.
- 5 As the edit you want to stop recording, press **EDITING** (left) to stop editing. Don't VCRS begin to edit.

To stop editing

Press the **STOP** buttons on both VCRs.



### Setting the RF unit

When connecting the VCR to the TV, using only the antenna cable, you need to set the RF Unit to the correct channel in the VCR so that the TV can receive the signal from the VCR.

If you connect the VCR to the TV using the supplied audio/video cable, you can skip this step.

1 Set the RF UNIT switch on the rear of the VCR to CH2 or CH1, whichever channel is not used in your area. It is here you would set the switch to other channels.

2 Press **POWER** to turn on the VCR.

3 Press **TV/VIDEO** to turn on the VTR indicator in the VCR's display window.

4 Press **CHANNEL** until a display channel number is in the display window. Store a value channel number in your area.

5 Turn on your TV and set it to the channel you selected in step 4.

The selected TV channel broadcast appears on the TV screen. If the channel is being used by another TV set, you may need to change the channel. To do so, you use the VCR. Set the TV to a different channel selected in step 4.

### Attaching the external antenna connector

When using an antenna (as indicated for VHF/UHF signals), use the EAC-33 antenna connector (not supplied) to connect the antenna to the VCR.

1 Loosen the screws on the antenna connector.

2 Wind the pins held against the screws on the antenna connector.

3 Tighten the screws.

### Attaching an UHF/UHF lead mixer

When using both 75-ohm coaxial cable and 300-ohm twin lead cable for VHF/UHF signals, use the EAC-35 UHF/UHF lead mixer (not supplied) to connect the antenna to the VCR.

1 Loosen the screws on the mixer.

2 Wind the mixer leads around the screws on the plate.


3 Tighten the screws.

4 Connect the 75-ohm coaxial cable to the mixer.

Refer to the pages indicated by C, L or R.


## Index to parts and controls

### Front panel




- 1 POWER POKER indicator
- 2 SELECT type on SPD
- 3 PAUSE button (PH)
- 4 PLAY/REVERSE button (PL)
- 5 STOP button (STP)
- 6 EJECT button (EJ)
- 7 DUAL MODE SHUTTLE (mg. 35, 45)
- 8 TIME/REPAIR call
- 9 EASY SET button (EH)
- 10 EDIT switch (ED)
- 11 COMPASS PROTECT push (CP)
- 12 LOCK IN 2 VOLUME/AUDIO LEVEL push (LV)

### Display window




- 1 A/C indicator (AC)
- 2 VTR indicator (VTR)
- 3 REMAIN indicator (RM)
- 4 SPEED UP indicator (SU)
- 5 SRT indicator (SRT)
- 6 AUDIO TRACKING indicator (AT)
- 7 Type speed indicator (SP)
- 8 Eject/Status indicator (EJ)
- 9 AV INSERT indicator (AV)
- 10 Time counter/remaining time counter/doub. Ch
- 11 Type indicator
- 12

Front cover, with upper opened



- 1 Tape eject/insert
- 2 CANCEL TIMER button (10)
- 3 COUNTER RESET button (24)
- 4 VIDEO INSERT button (24)
- 5 AUDIO INSERT button (14)
- 6 TAPE SPEED SELECT button (13)
- 7 CHAINING +/- buttons (24)
- 8 INPUT SELECT button (24, 25)
- 9 TV/VTR button (40)

Rear panel



- 1 AC IN connector
- 2 REMOTE SWITCH (19)
- 3 VHS TAPE connector (24, 25, 15, 16)
- 4 CABLE BOX CONTROL (CONTROL 5-OUT) jack
- 5 LINE IN +/- AUDIO L/R (VIDEO) jacks (6)
- 6 LINE OUT AUDIO L/R (VIDEO) jacks (18, 20)
- 7 CONTROL 5 IN jack (16)


Index to parts and controls  
(continued)

Remote commander


- 1 COMMAND MODE switch (4)
- 2 EJECT button (15)
- 3 Menu operation buttons (25):
  - ▶ RECALL
  - ▶ CURSOR < > < >
  - ▶ EXECUTE button
- 4 COUNTER RESET button (15)
- 5 Channel number buttons and ENTER button (14)
- 6 STOP button (40)
- 7 TRACKING buttons (16)
  - ▶ T.V. NORMAL SLOW
  - ▶ STILL ADJUST buttons
  - ▶ AUTO/REGULAL buttons
- 8 +/- SLOW buttons (41)
- 9 < > / < > FRAME buttons (19)
- 10 HALL JUMP/INDEX/SEARCH buttons (21)
- 11 < > SEARCH buttons (21)
- 12 PAUSE button (15)
- 13 PLAY button (15)
- 14 STOP button (15)
- 15 < > / < > power control (15, 19)
- 16 POWER button
- 17 TIMER CLEAR button (10)
- 18 TV/VTR button (40)
- 19 ASPECT MONITOR button (24)
- 20 VCR Plus+ buttons (45)
  - ▶ VCR Plus+ button
  - ▶ SILENT button
  - ▶ STILL button
- 21 AUDIO/VIDEO INSERT buttons (14)
- 22 COUNTER/REMAIN buttons (14)
- 23 DISPLAY button (14)
- 24 TAPE SPEED buttons (13)
- 25 INPUT SELECT button (24, 25)
- 26 CH +/- buttons (24)
- 27 VOL +/- buttons (45)
- 28 PAUSE button (15)
- 29 REC button (14)
- 30 DUAL LOCK SHUTTLE (15, 19)

## SECTION 2 DISASSEMBLY


### 2-1. REMOVAL OF UPPER CASE



### 2-2. REMOVAL OF FRONT PANEL ASSEMBLY




## 2-3. REMOVAL OF CONTROL SWITCH BLOCK (780HF, 781HF, 940HF/HFCS/HFMX/HFPX)




## 2-4. REMOVAL OF MF-253, MF-274 BOARD

(MF-253 BOARD: EXCEPT 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)  
(MF-274 BOARD: 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)




## 2-5. REMOVAL OF HI-5, HI-19 BOARD

(HI-5 BOARD . EXCEPT 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)  
(HI-19 BOARD . 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)




## 2-6. REMOVAL OF BOTTOM PLATE




## 2-7. REMOVAL OF PS-327, PS-349 BOARD

(PS-327 BOARD : EXCEPT 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)  
(PS-349 BOARD : 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)




## 2-8. REMOVAL OF ED-40, ED-43 BOARD AND HF-34 BOARD

(ED-40 BOARD : 740HF, 741HF, 780HF, 781HF, 940HF/HFMX MODEL)  
(ED-43 BOARD : 740HFPX, 940HFCS/HFPX MODEL)




## 2-9. REMOVAL OF RV-36, RV-45 BOARD

(RV-36 BOARD : EXCEPT 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)  
 (RV-45 BOARD : 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)




## 2-10. REMOVAL OF MA-214 BOARD





## 2-11. REMOVAL OF MD BLOCK ASSEMBLY




## 2-12. MECHANICAL INTERNAL VIEWS


—Upper side—

M901


Drum Assy	8-848-576-12 (D2H-45A-R)	(EXCEPT 940HF/HFCS/HFMX/HFPX)
	8-848-599-12 (D2H-51A-R)	(940HF/HFCS/HFMX/HFPX)
Rotary taper drum Assy	8-846-576-02 (D2R-45-R)	(EXCEPT 940HF/HFCS/HFMX/HFPX)
	8-846-594-02 (D2R-51-R)	(940HF/HFCS/HFMX/HFPX)



—Lower side—



## 2-13. CIRCUIT BOARDS LOCATION





SLV-733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL	EXCEPT SLV-733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL	SLV-740HFPX, 940HFCS/HFPX MODEL	SLV-740HF, 741HF, 780HF, 781HF, 940HF/HFMS MODEL
DC-65 BOARD HI-19 BOARD MF-274 BOARD PS-349 BOARD RV-45 BOARD	DC-57 BOARD HI-5 BOARD MF-253 BOARD PS-327 BOARD RV-36 BOARD	ED-43 BOARD	ED-40 BOARD

## SECTION 3 BLOCK DIAGRAMS

### 3-1. OVERALL BLOCK DIAGRAM


• The boards which signals only pass through may be omitted.






### 3-2. VIDEO BLOCK DIAGRAM


• The boards which signals only pass through may be omitted.





### 3-3. SERVO, SYSTEM CONTROL BLOCK DIAGRAM


\* The boards which signals only pass through may be omitted.






### 3-4. TIMER, TUNER, MODE CONTROL BLOCK DIAGRAM

• The boards which signals only pass through may be omitted.




3-4. TIMER, TUNER, MODE CONTROL BLOCK DIAGRAM  
 \*The boards which signals only pass through may be omitted.




**3-5. AUDIO BLOCK DIAGRAM**

• The boards which signals only pass through may be omitted.




**I4 BOARD**  
ICB007, ICB08  
(See page 4-27)




**3-6. TUNER BLOCK DIAGRAM**

•The boards which signals only pass through may be omitted.




### 3-6. TUNER BLOCK DIAGRAM

• The boards which signals only pass through may be omitted.




## 3-7. POWER BLOCK DIAGRAM

• The boards which signals only pass through may be omitted.



**SECTION 4**  
**PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS**



**4-1. FRAME SCHEMATIC DIAGRAMS**



RV-36/45 (V/C VIDEO PROCESS, HI-FI AUDIO, HEAD AMP) PRINTED WIRING BOARD  
 Ref. No. RV-36 IS BOARD 2000 series


**RV-36 BOARD (EXCEPT 733HF/HFCS, 740HF/PA, 940HFCS/HFPA MODEL)**  
**RV-45 BOARD (733HF/HFCS, 740HF/PA, 940HFCS/HFPA MODEL)**

- Q101 100K
- Q102 100K
- Q103 100K
- Q104 100K
- Q105 100K
- Q106 100K
- Q107 100K
- Q108 100K
- Q109 100K
- Q110 100K
- Q111 100K
- Q112 100K
- Q113 100K
- Q114 100K
- Q115 100K
- Q116 100K
- Q117 100K
- Q118 100K
- Q119 100K
- Q120 100K
- Q121 100K
- Q122 100K
- Q123 100K
- Q124 100K
- Q125 100K
- Q126 100K
- Q127 100K
- Q128 100K
- Q129 100K
- Q130 100K
- Q131 100K
- Q132 100K
- Q133 100K
- Q134 100K
- Q135 100K
- Q136 100K
- Q137 100K
- Q138 100K
- Q139 100K
- Q140 100K
- Q141 100K
- Q142 100K
- Q143 100K
- Q144 100K
- Q145 100K
- Q146 100K
- Q147 100K
- Q148 100K
- Q149 100K
- Q150 100K
- Q151 100K
- Q152 100K
- Q153 100K
- Q154 100K
- Q155 100K
- Q156 100K
- Q157 100K
- Q158 100K
- Q159 100K
- Q160 100K
- Q161 100K
- Q162 100K
- Q163 100K
- Q164 100K
- Q165 100K
- Q166 100K
- Q167 100K
- Q168 100K
- Q169 100K
- Q170 100K
- Q171 100K
- Q172 100K
- Q173 100K
- Q174 100K
- Q175 100K
- Q176 100K
- Q177 100K
- Q178 100K
- Q179 100K
- Q180 100K
- Q181 100K
- Q182 100K
- Q183 100K
- Q184 100K
- Q185 100K
- Q186 100K
- Q187 100K
- Q188 100K
- Q189 100K
- Q190 100K
- Q191 100K
- Q192 100K
- Q193 100K
- Q194 100K
- Q195 100K
- Q196 100K
- Q197 100K
- Q198 100K
- Q199 100K
- Q200 100K






1FCS, 740HFPX, 940HFCS/HFPX MODEL)  
HFPX, 940HFCS/HFPX MODEL)




**RV-36/45 (Y/C VIDEO PROCESS, HIFI AUDIO, HEAD AMP) SCHEMATIC DIAGRAM**  
 — Ref. No. RV-36/45 BOARD : 2,000 series —

**RV-36/45 BOARD**




\* Signal path

	VIDEO Signal		AUDIO Signal	
	CHROMA	Y	CHROMA	Y
#FC	↔	→	↔	→
PB	↔	→	↔	→



9 10 11 12 13 14 15 16 17 18 19 20 21 22





MA-214 (SERVO/SYSTEM CONTROL), DC-57/65 (RELAY) PRINTED WIRING BOARDS



-- Ref. No. MA-214 BOARD: 1,000 series, DC-57/65 BOARD: 4,000 series --

MA-214 BOARD			
02651	M-9	0801	1-1
08021	M-2	0572	2-14
01601	L-18	0609	1-6
01644	G-2.6	0757	H-11
08860	D-16	0302	1-12
04892	G-17	0104	1-14
01922	G-18	0492	2-6
08880	L-20	0104	E-9
04803	L-15	0462	H-2
08818	H-19	0467	G-5
08905	H-17	0262	G-17
04840	C-5	3709	R-9
10558	F-11	0703	G-2
08905	H-7	0520	H-10
04910	L-1	0326	H-8
04812	S-31	0751	H-4
		0752	K-8
0001	N-9	U-92	H-2
04626	H-2	0762	H-2
0007	N-4	0762	H-6
0071	G-9	0194	I-5
0766	I-10	0774	I-8
0221	L-1	0279	H-2
0512	K-8	0778	H-2
2053	L-10	0778	H-2
04622	H-5	0778	I-3
3604	H-5	0731	H-9
04626	H-15	0752	I-5
0762	F-5	0723	H-5
0709	H-4	0801	H-12
0764	G-2	0882	H-5
0761	I-5	0888	H-5
0762	H-4	0801	H-18
0761	H-8	0882	H-8
0762	H-4		
0776	H-2		
0777	H-6		
0778	H-4		
0823	H-14		
0903	L-9		
0902	M-3		
0902	H-14		
0904	H-10		
IC002	N-7		
IC021	G-6		
IC101	H-15		
IC201	L-12		
IC251	H-8		
IC301	H-11		
IC401	F-4		
IC402	G-7		
IC501	E-12		
IC506	D-5		
IC601	C-18		
IC701	B-2		
IC811	H-15		


MA-214 BOARD




DC-57 BOARD (EXCEPT 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)  
DC-65 BOARD (733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)



MA-214 (SERVO/SYSTEM CONTROL), DC-57/65 (RELAY) SCHEMATIC DIAGRAMS  
 -- Ref. No. MA 214 BOARD - 1,000 series, DC-57/65 BOARD - 4,000 series --



MA-214 BOARD





• Signal path

	REC	PB
REC	→	→
PB	→	→

• Signal path

	REC	REC/PB	PB
On the board level	→	→	→
From the board level	→	→	→
On the board level or 2/3 level	→	→	→
A signal signal signal	→	→	→
A signal signal signal	→	→	→
A signal signal signal	→	→	→
Rel signal	→	→	→





(See page 4-9)  
10 by 20x2 7/16x 0.033

(See page 4-8)  
10 by 20x2 7/16x 0.033

(See page 4-19)  
10 by 20x2 7/16x 0.033

PS-205 BOARD  
(See page 4-38)

DC-57 BOARD  
8 X 11 P.T. 2.54xP.T. 2.54x0.076x 0.076x 0.076x 0.076x  
DC-65 BOARD  
19.5x27.1x 1.27x 1.27x 0.076x 0.076x 0.076x  
RELAY


CAM ENCODER

**Note:**  
The components identified by mark (A) or star (\*) are critical for safety. Replace only with part number specified.

**Note:**  
Les composants identifiés par une marque (A) sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.




**MA-214 (INPUT/OUTPUT, TUNER) SCHEMATIC DIAGRAM**  
 — Ref. No. MA 214 BOARD : L400 series —  
 • Refer to page 4-10 for Printed Wiring Board.



• Signal path

	CHROMA	VIDEO Signal Y	... L... R... CHROMA	AUDIO Signal
REC			→	→
PB			←	←



**MA-214 BOARD (3/3)**  
INPUT/OUTPUT:

**74C01**  
NAND  
5VCC

WAVEFORMS


1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----

MA-214 BOARD (3/3)  
(See page 4-15)

MA-214 BOARD (3/3)  
(See page 4-14)

MA-214 BOARD (3/3)  
(See page 4-13)

22 23 24 25 26 27 28 29 30 31 32 33 34




<p><b>Note:</b> The components identified by mark <math>\Delta</math> or dotted line with mark <math>\Delta</math> are critical for safety. Replace only with part number specified.</p>	<p><b>Note:</b> Les composants identifiés par une marque <math>\Delta</math> sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.</p>
--	--

ED-40/43 (EDS CONTROL) PRINTED WIRING BOARD

- Ref. No. ED-40-43 BOARD 1: 3000 series -

**ED-40 BOARD (740HF, 741HF, 780HF, 781HF, 940HF/HFMX MODEL)**


**ED-43 BOARD (740HFPX, 940HFC S/HFPX MODEL)**



04


1-654-724 (ED-40)

1-655-864 (ED-43)



ED-40/43 (EDS CONTROL) SCHEMATIC DIAGRAM


- Ref. No. ED-40-43 BOARD 1: 3000 series -




ED-40/43 (EDS CONTROL) SCHEMATIC DIAGRAM

- Ref. No. ED-40/43 BOARD : 3,000 series -

IFMX MODEL)



ED-40/43 BOARD




**HF-34 (AUDIO PROCESS) PRINTED WIRING BOARD**

-- Ref. No. HF-34 BOARD - 1000 series

**HF-34 BOARD (COMPONENT SIDE)**

HF-34 BOARD  
 CN101 D-1  
 CN102 D-1  
 CN103 A-1  
 CN104 C-2  
 CN105 B-1  
 CN106 C-2  
 CN107 C-2




**HF-3-**





**HF-34 (AUDIO PROCESS) PRINTED WIRING BOARD**  
 Ref. No. HF-34 BOARD : 4000 series

HF-34 BOARD  
 Q101 D1  
 Q102 D1  
 Q103 C2  
 Q104 B2  
 Q105 C2  
 Q106 C2

**HF-34 BOARD (COMPONENT SIDE)**




**HF-34 BOARD (CONDUCTOR SIDE)**




HF-5/19 (TIMER/TUNER/MODE CONTROL), HF-253/274 (LED CONTROL) PRINTED WIRING BOARDS

Ref. No. H15-19 BOARD, MF-253/274 BOARD - 2 BOARD SERIES

H1-5 BOARD (EXCEPT 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)  
H1-19 BOARD (733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)




9301	82K
9302	82K
9303	82K
9304	82K
9305	82K
9306	82K
9307	82K
9308	82K
9309	82K
9310	82K
9311	82K
9312	82K
9313	82K
9314	82K
9315	82K
9316	82K
9317	82K
9318	82K
9319	82K
9320	82K
9321	82K
9322	82K
9323	82K
9324	82K
9325	82K
9326	82K
9327	82K
9328	82K
9329	82K
9330	82K
9331	82K
9332	82K
9333	82K
9334	82K
9335	82K
9336	82K
9337	82K
9338	82K
9339	82K
9340	82K
9341	82K
9342	82K
9343	82K
9344	82K
9345	82K
9346	82K
9347	82K
9348	82K
9349	82K
9350	82K
9351	82K
9352	82K
9353	82K
9354	82K
9355	82K
9356	82K
9357	82K
9358	82K
9359	82K
9360	82K
9361	82K
9362	82K
9363	82K
9364	82K
9365	82K
9366	82K
9367	82K
9368	82K
9369	82K
9370	82K
9371	82K
9372	82K
9373	82K
9374	82K
9375	82K
9376	82K
9377	82K
9378	82K
9379	82K
9380	82K
9381	82K
9382	82K
9383	82K
9384	82K
9385	82K
9386	82K
9387	82K
9388	82K
9389	82K
9390	82K
9391	82K
9392	82K
9393	82K
9394	82K
9395	82K
9396	82K
9397	82K
9398	82K
9399	82K
9400	82K







## HF-34 (AUDIO PROCESS) SCHEMATIC DIAGRAM

Ref. No.: HF-31 BOARD : 4000 series






MF-253 BOARD (EXCEPT 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)  
MF-274 BOARD (733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)





9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19




MF-5/19 (TIMER/TUNER/MODE CONTROL), MF-253/274 (LED CONTROL) SCHEMATIC DIAGRAMS

— Ref. No. HI-5/19 BOARD; MF-253/274 BOARD, 1000 series —

HI-5/19 BOARD



19 20 21 22 23 24 25 26 27 28 29 30 31



\* Signal path


	ChROMA	VIDEO	Y	V/CHROMA	AUDIO
REC	→	→	→	→	→
PB	→	→	→	→	→

BOARD

US —

4	5	6	7	8	9	10	11	12	13	14	15
---	---	---	---	---	---	----	----	----	----	----	----

PS-327/349 BOARD




GREEN: 1000V 100μF 50°C ELECTROLYTIC CAP.  
 YELLOW: 50V 100μF 50°C ELECTROLYTIC CAP.  
 RED: 50V 100μF 50°C ELECTROLYTIC CAP.  
 BLUE: 50V 100μF 50°C ELECTROLYTIC CAP.  
 PURPLE: 50V 100μF 50°C ELECTROLYTIC CAP.  
 BROWN: 50V 100μF 50°C ELECTROLYTIC CAP.

PS-327/349 BOARD  
 (See page 4-18)

PS-327/349 BOARD  
 (See page 4-20)

PS-327/349 (POWER) SCHEMATIC DIAGRAM  
 Ref. No. PS-327/349 BOARD: 2,000 series


PS-327 BOARD (EXCEPT 733HF/  
 PS-349 BOARD (733HF/HFCS, 7




04

3 (POWER) SCHEMATIC DIAGRAM  
 PS-327/319 BOARD) : 3,000 series

7 BOARD (EXCEPT 733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)  
 8 BOARD (733HF/HFCS, 740HFPX, 940HFCS/HFPX MODEL)



PS-327/319 BOARD	
733HF	A-22
740HFPX	C-23
C-01	D-1
C-02	B-11
D-01	B-4
R-01	A-9
K-01	R-4
C-10	B-10
C-13	C-1
D-01	D-1



## SECTION 5 REPAIR PARTS LIST

### 5-1. EXPLODED VIEWS

#### NOTE:


- The mechanical parts with no reference number in the exploded views are not supplied.
- Items marked "\*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- "X" and "Y" mean standardized parts, so they may have some difference from the original one.
- Hardware (X mark) list and accessories and packing materials are given in the last of this parts list.

Les composants identifiés par une marque X ou pointillés avec une X sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Les composants identifiés par une marque X sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.


#### 5-1-1. CASE ASSEMBLY



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
1	X-3844-290-1	BUTTON ASSY, FUNCTION (640HF, 740HF/MPX, 740HF, 940HF/AFCS/ARNA/AFPS)		8	1-467-947-11	REMOTE COMMANDER (RM-1161) (740HF, 741HF)	
1	X-3844-308-1	BUTTON ASSY, FUNCTION (733HF/AFCS/ARNA/AFPS/MPX, 741HF, 741HF)		8	1-467-947-21	REMOTE COMMANDER (RM-V164B) (741HF/AFCS/MPX/AFPS)	
2	X-3844-285-1	RM, ASSY, SHUTTLE (640HF, 740HF/MPX, 740HF, 940HF/AFCS/ARNA/AFPS)		8	1-467-948-11	REMOTE COMMANDER (RM-V159) (640HF/AFCS/MPX/AFPS)	
2	X-3844-309-1	RM, ASSY, SHUTTLE (733HF/AFCS/ARNA/AFPS, 741HF, 741HF)		8	1-467-951-11	REMOTE COMMANDER (RM-V159C) (640HF)	
3	7-040-080-01	KNOB (RP), SLIDE (940HF/AFCS/ARNA/AFPS)		8	1-467-951-11	REMOTE COMMANDER (RM-V162) (740HF/MPX, 741HF)	
*4	1-940-969-01	CASE, UPPER (640HF, 740HF/MPX, 740HF, 940HF/AFCS/ARNA/AFPS)		9	3-957-513-11	RM, SHUTTLE (EXCEPT 640HF)	
*4	1-940-068-11	CASE, UPPER (733HF/AFCS/ARNA/AFPS)		10	3-748-817-01	COVER, BATTERY (EXCEPT 640HF)	
*4	1-940-069-01	CASE, UPPER (740HF/MPX/AFPS)		11	3-900-080-01	KNOB (RP), SLIDE (940HF/AFCS/ARNA/AFPS)	
5	3-730-901-11	SCREW, TAPPING		12	1-467-951-11	REMOTE COMMANDER (RM-V159C) (640HF)	
*6	3-940-061-01	PLATE, BOTTOM		13	3-708-923-01	COVER, BATTERY (640HF)	
7	3-900-082-01	INSULATOR					

## 5-1-2. FRONT PANEL ASSEMBLY


(SLV-780HF, 781HF, 940HF/HFCS/HFMX/HFPX MODEL)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
51	1-467-943-11	SWITCH BLOCK, CONTROL (940HF/HFCS/HFMX/HFPX)		59	3-957-389-01	BUTTON, POWER/EJECT (780HF, 940HF/HFCS/HFMX/HFPX)	
51	1-467-943-21	SWITCH BLOCK, CONTROL (780HF)		59	3-957-389-21	BUTTON, POWER/EJECT (781HF)	
51	1-473-020-E1	SWITCH BLOCK, CONTROL (781HF)		60	3-957-386-01	SPRING, COMPRESSION	
* 52	3-960-077-01	SHAFT (LEFT), PULCHIN		61	3-944-564-03	CLAMP, LOCK	
53	X-2944-487-1	PLATE (RIGHT) ASSY, PULCHIN, DOOR		* 62	3-940-556-01	SPRING, DOOR LOCK	
* 54	3-940-676-01	PLATE (LEFT), PULCHIN, DOOR		* 63	3-940-090-01	LENS, TH ILLUMINATION	
55	3-961-745-01	BANDER, OIL		* 64	3-940-089-01	LENS, REC ILLUMINATION	
56	X-2944-293-1	PANEL ASSY, FRONT (780HF)		* 65	3-957-546-01	HOLDER, LOCK CLAMP	
56	X-2944-708-1	PANEL ASSY, FRONT (940HF/HFCS/HFMX/HFPX)		* 66	3-940-086-01	BASE (L), TR (780HF, 940HF/HFCS/HFMX/HFPX)	
56	X-2944-701-1	PANEL ASSY, FRONT (781HF)		* 66	3-940-086-13	BASE (L), TR (781HF)	
57	3-960-093-01	DOOR, JACK (780HF)		67	3-953-432-01	STRING (GE), FL	
57	3-960-093-11	DOOR, JACK (940HF/HFCS/HFMX/HFPX)		68	3-940-094-01	DOOR, CASSETTE (780HF, 940HF/HFCS/HFMX/HFPX)	
57	3-960-093-21	DOOR, JACK (781HF)		68	3-940-094-73	DOOR, CASSETTE (781HF)	
58	4-921-277-41	SCREW (8.8X6), TAPPING END					




(SLV-640HF, 733HF/HFCS/HFMX/HFPA, 740HF/HFPX, 741HF MODEL)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
	4-121-277-01	SCREW (Ø2.4X6), TAPPING, BLIND		70	3-900-054-00	DOOR JACK (640HF, 740HF/HFPX)	
+ 62	3-960-556-01	SPRING, DOOR LOCK		70	3-900-053-21	DOOR JACK (733HF/HFCS/HFMX/HFPA)	
+ 63	3-960-090-01	LENS, TR. ILLUMINATION		70	3-900-055-21	DOOR JACK (541HF)	
+ 64	3-960-099-01	LENS, REC. ILLUMINATION		71	3-021-992-00	BUTTON, RF	
67	3-953-432-01	SPRING (GEL), PL.		72	3-957-257-00	BUTTON, POWER/EJECT (640HF, 740HF/HFPX)	
68	3-960-094-91	DOOR CASSETTE (733HF/HFCS/HFMX/HFPA, 740HF/HFPX)		72	3-957-257-11	BUTTON, POWER/EJECT (733HF/HFCS/HFMX/HFPA, 741HF)	
69	3-960-094-71	DOOR CASSETTE (741HF)		73	3-900-814-00	TR. POWER BUTTON	
69	X-2844-267-1	PANEL ASSY. FRONT (740HF/HFPX)		74	3-900-324-01	BUTTON, QUICK TIMER	
69	X-2844-704-1	PANEL ASSY. FRONT (741HF)		+ 75	3-900-005-03	BASE, TR. (640HF, 740HF/HFPX)	
69	X-2844-705-1	PANEL ASSY. FRONT (640HF)		+ 75	3-900-009-11	BASE, TR. (733HF/HFCS/HFMX/HFPA, 741HF)	
69	X-2844-704-1	PANEL ASSY. FRONT (733HF/HFCS/HFMX/HFPA)					

### 5-1-3. CHASSIS ASSEMBLY




Ref. No.	Part No.	Description	Remark
* 104	3-960-107-02	TRIGGER, MA	
* 102	A-6794-032-A	40-57 BOARD, COMPLETE (EXCEPT 733HF/74FCS, 740HPX, 940HPCS/HPFX)	
		40-45 BOARD, COMPLETE (733HF/HFCS, 740HPFX, 940HPCS/HPFX)	
* 100	A-6782-126-A	34-36 BOARD, COMPLETE (733HPX/HFPA, 700ME, 181HE)	
		RV-45 BOARD, COMPLETE (733HF/HFCS)	
* 103	A-6782-433-A	RV-78 BOARD, COMPLETE (640HE, 740HF, 74LHF)	
		RV-45 BOARD, COMPLETE (740HPX)	
* 103	A-6782-436-A	RV-26 BOARD, COMPLETE (640HF/HFCS)	
		RV-45 BOARD, COMPLETE (940HPCS/HPFX)	
104	1-789-354-13	CABLE, FLEXIBLE (FLAT (190)IN)	
* 105	3-960-066-01	HOLDER (A), PL	
* 106	A-6782-429-A	HI-5 BOARD, COMPLETE (733HFPA, 740HF/US, 743HF)	
* 106	A-6782-425-A	HI-3 BOARD, COMPLETE (640HF/US/HFCS)	
* 106	A-6782-442-A	HI-5 BOARD, COMPLETE (730HF/US, 74LHF)	
* 106	A-6782-060-A	HI-10 BOARD, COMPLETE (740HFPA)	
* 106	A-6782-500-A	HI-10 BOARD, COMPLETE (730HF/HFCS)	
* 106	A-6782-507-A	HI-10 BOARD, COMPLETE (940HPCS/HPFX)	
* 106	A-6782-625-A	HI-5 BOARD, COMPLETE (640HF/US)	
* 106	A-6782-026-A	HI-5 BOARD, COMPLETE (640HF/Canadian)	
* 106	A-6782-527-A	HI-5 BOARD, COMPLETE (640HF/Canadian)	
* 106	A-6782-528-A	HI-5 BOARD, COMPLETE (733HE/US)	
* 106	A-6782-529-A	HI-5 BOARD, COMPLETE (730HE/Canadian)	
* 106	A-6782-530-A	HI-5 BOARD, COMPLETE (640HF/Canadian)	
* 107	3-960-059-01	PLATE (PS), ORNAMENTAL, REAR JACK	
* 108	3-960-060-01	PLATE (PS), ORNAMENTAL, REAR JACK (700HF)	
* 108	3-960-060-01	PLATE (PS), ORNAMENTAL, REAR JACK (940HF)	
* 108	3-960-060-21	PLATE (PS), ORNAMENTAL, REAR JACK (940HPFX)	
* 108	3-960-060-31	PLATE (PS), ORNAMENTAL, REAR JACK (740HF)	
* 108	3-960-060-41	PLATE (PS), ORNAMENTAL, REAR JACK (740HPFX)	
* 108	3-960-060-51	PLATE (PS), ORNAMENTAL, REAR JACK (640HF)	
* 108	3-960-060-61	PLATE (PS), ORNAMENTAL, REAR JACK (74LHF)	
* 108	3-960-060-71	PLATE (PS), ORNAMENTAL, REAR JACK (74LHF)	
* 108	3-960-060-81	PLATE (PS), ORNAMENTAL, REAR JACK (940HPCS)	
* 108	3-960-060-91	PLATE (PS), ORNAMENTAL, REAR JACK (940HPFX)	
* 108	3-962-034-01	PLATE (PS), ORNAMENTAL, REAR JACK (733HFPA)	
* 108	3-962-034-11	PLATE (PS), ORNAMENTAL, REAR JACK (733HPCS)	
* 108	3-962-034-21	PLATE (PS), ORNAMENTAL, REAR JACK (733HE/US)	
* 108	3-962-034-31	PLATE (PS), ORNAMENTAL, REAR JACK (733HF)	

Ref. No.	Part No.	Description	Remark
* 109	3-960-058-01	PLATE (IO), ORNAMENTAL, REAR JACK (290HF, 701HE, 940HE)	
* 109	3-960-058-11	PLATE (IO), ORNAMENTAL, REAR JACK (940HPCS/HPFX, 940HPX)	
* 109	3-960-058-21	PLATE (IO), ORNAMENTAL, REAR JACK (640HE, 740HF, 74LHF)	
* 109	3-960-058-31	PLATE (IO), ORNAMENTAL, REAR JACK (733HF/HFCS, HPFX/HFPA, 740HPX)	
* 110	3-951-093-01	NEAT STRIP	
111	3-790-387-01	STRIPPER, WINDING	
* 112	A-6782-428-A	MA-214 BOARD, COMPLETE (700HF, 701HF)	
* 112	A-6782-437-A	MA-214 BOARD, COMPLETE (740HF/HFPA, 74LHF)	
* 112	A-6782-434-A	MA-214 BOARD, COMPLETE (733HF/HFCS, HPFX/HFPA)	
* 112	A-6782-437-A	MA-214 BOARD, COMPLETE (640HF/HFCS, HPFX/HFPA)	
* 112	A-6782-438-A	MA-214 BOARD, COMPLETE (640HF)	
* 113	A-6782-425-A	ED-40 BOARD, COMPLETE (740HF/74LHF, 740HF, 74LHF, 940HF/HFCS)	
		ED-42 BOARD, COMPLETE (740HPX, 940HPCS/HPFX)	
* 114	A-6782-500-A	HE-34 BOARD, COMPLETE	
* 115	A-6782-424-A	ME-253 BOARD, COMPLETE (700HF, 701HF, 940HF/HFCS)	
* 115	A-6782-430-A	ME-253 BOARD, COMPLETE (640HF, 733HPX/HFPA, 74LHF, 74LHF)	
* 115	A-6782-503-A	ME-274 BOARD, COMPLETE (733HF/HFCS, 740HPX)	
* 115	A-6782-502-A	ME-274 BOARD, COMPLETE (940HPCS/HPFX)	
* 116	3-960-274-01	SPACER, L2D	
* 117	3-940-275-01	SPACER, TOP END	
118	1-555-110-06	CABLE, PIN	
* 119	A-6782-427-A	PS-323 BOARD, COMPLETE (EXCEPT 733HF/HFCS, 740HPX, 940HPCS/HPFX)	
* 119	A-6782-419-A	PS-349 BOARD, COMPLETE (733HF/HFCS, 740HPX, 940HPCS/HPFX)	
* 120	3-960-064-01	INDULATOR, PS	
120	8-719-048-24	DIODE (125V) (TUBE TON-ER)	
120	1-576-226-11	FUSE (IN H.C.) (250V/2A) (733HF/HFCS, 740HPX, 940HPCS/HPFX)	
120	1-532-743-11	FUSE, GLASS (ELECTRONIC) (1/4A) (EXCEPT 733HF/HFCS, 740HPX, 940HPCS/HPFX)	
F201	1-533-293-11	FUSE, HOLDER	
F202	1-533-233-01	FUSE, HOLDER	
F203	1-517-325-01	TUBE, #CDOSSEMENT INDICATOR	
10341	8-758-180-48	IC PU20E11	
Q001	8-121-025-02	PHOTO TRANSISTOR P100F (TUBE TOP)	
Q002	8-729-025-02	PHOTO TRANSISTOR P100F (TUBE END)	

The components identified by mark  $\Delta$  or dotted line with mark  $\Delta$  are critical for safety. Replace only with part number specified.


Les composants identifiés par une marque  $\Delta$  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

### 5-1.4. MECHANISM DECK ASSEMBLY 1




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
151	A-6751-406-A	PL. BRACH ASSY		168	3-958-439-01	SPRING (ACE), COMPRESSION	
152	3-958-463-01	SPRING, TENSION COIL		169	3-942-847-01	NUT, AG HEIGHT ADJUSTMENT	
153	3-958-195-01	SPRING, TENSION		168	3-958-491-01	BASE, ACE	
154	3-960-215-01	PLATE, LIGHT GUIDE, END SENSOR		169	A-6746-072-A	PRESS BLOCK ASSY, PUNCH	
155	3-940-216-01	PLATE, LIGHT GUIDE, TOP SENSOR		170	3-958-505-01	SPRING (SOFT BRAKE T.), TENSION	
156	X-3944-408-1	ROLLER ASSY, T02		171	3-958-435-01	SPRING (PENCE), TENSION	
157	3-958-437-01	SPRING, COILS TENSION COIL		172	3-958-151-01	GEAR, PLEXTON	
158	1-590-144-11	HEAD, FE		173	3-958-454-01	OPNER, LID	
159	3-958-141-01	HOLDER, FEH		174	3-958-501-01	SCREW, ACE ADJUSTMENT	
160	3-942-298-01	BRACKET, TGT TAPE		175	3-958-151-01	GEAR, PRESS	
161	X-3944-397-1	TGB ASSY		176	3-958-462-01	SPRING (ING BRAKE), TENSION	
162	3-958-421-01	HOLDER, TGB		177	X-3943-848-1	WIN ASSY, BUS DRANE	
163	3-958-152-01	GEAR, TGB		178	X-1943-682-1	BRAKE TD ASSY, SOFT	
164	A-6770-103-A	ACE BLOCK ASSY (INCLUDING AG-104 DMRD)		170	3-701-434-11	WASHER, 2.5	
165	3-594-945-11	PH, CONNECTOR EP					

5-1-6. MECHANISM DECK ASSEMBLY 2




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
201	X-3943-889-1	GROUND ASSY, SHAFT		212	3-324-593-01	WASHER, STOPPER	
202	3-643-205-01	SCREW (PSM) 3/8		214	X-3943-303-1	ROLLER ASSY, HC	
203	3-648-570-02	DRUM ASSY, ROTARY UPPER (GR-45-R) (EXCEPT 94HF/AFCS/AFMK/AFYX)		215	X-3943-306-1	ARM ASSY, HC	
204	B-848-594-02	MAIN ASSY, ROTARY UPPER (GR-51-R) (94HF/AFCS/AFMK/AFYX)		216	3-960-139-01	ARM, REDUNDANTLY	
205	3-958-443-01	SPRING, STRETCH COIL SPRING		217	3-958-535-01	SPRING, TENSION	
206	3-669-595-00	WASHER (2), STOPPER		218	3-960-136-01	ARM, PENDULUM COMPULSION	
207	3-954-450-01	BRACE (5), SOFT		219	X-3943-502-1	TABLE, REEL (2) ASSY	
208	3-954-100-02	SHAFT, PC BOARD		220	X-3943-503-1	TABLE, REEL (7) ASSY	
209	3-969-381-01	PLATE, LIGHT GUIDE, LED		221	X-3943-548-01	CAP ASSY, MAIN BLADE	
210	3-958-369-01	CATCHER		222	3-958-411-01	SCREW (PS 3/8)	
211	X-3944-539-1	BRACE (5) ASSY, MAIN		M901	6-048-575-12	DRUM ASSY (GR-45A-R) (EXCEPT 94HF/AFCS/AFMK/AFYX)	
212	3-958-517-01	SPRING, TENSION COIL		M902	6-048-593-12	DRUM ASSY (GR-51A-R) (94HF/AFCS/AFMK/AFYX)	
213	X-3943-303-1	ROLLER ASSY, HC					
214	X-3943-306-1	ARM ASSY, HC					
215	X-3943-306-1	ARM ASSY, HC					
216	3-960-139-01	ARM, REDUNDANTLY					
217	3-958-535-01	SPRING, TENSION					
218	3-960-136-01	ARM, PENDULUM COMPULSION					
219	X-3943-502-1	TABLE, REEL (2) ASSY					
220	X-3943-503-1	TABLE, REEL (7) ASSY					
221	X-3943-548-01	CAP ASSY, MAIN BLADE					
222	3-958-411-01	SCREW (PS 3/8)					

### 5-1-6. MECHANISM DECK ASSEMBLY 3



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
251	3-701-439-01	WASHER		202	3-058-156-01	GEAR, FL. DRIVING	
252	3-959-800-01	BURRBEIL JOINT		203	3-058-415-01	SPRING, TENSION/COIL (CAP DRIVE)	
253	3-958-150-01	WORM		204	X-3043-216-1	BRAKE ASSY, CAP	
254	3-958-150-01	SPRING, ONE-WAY		205	X-3043-209-1	ARM ASSY, TENSION VEHICLE	
255	1-958-100-01	PROPELLOR		206	3-058-361-01	BELT, TENSION	
256	3-958-155-01	BEARING, CAM MOTOR		267	3-058-448-01	WHEEL, TENSION	
257	X-3043-604-1	CHAIRSS ASSY, CAM MOTOR		268	3-958-703-01	RETAINER	
258	3-958-157-01	WHEEL, ROLL		269	3-058-143-01	SLIDER, ALUM	
259	3-958-595-00	WASHER (2), STOPPER		270	3-058-162-01	GEAR, UPPER/LOWER COMMUNICATION	
260	1-582-076-11	SWITCH, ROTARY		M000	X-3043-213-1	MOTOR ASSY, CAM	
261	3-950-161-01	GEAR, CAM					

### 5-1-7. MECHANISM CHASSIS ASSEMBLY 4



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
301	A-6738-102-A	HUB ASSY		314	3-962-940-01	GEAR (T-K), JULEX	
302	X-1943-890-01	LEVER ASSY, TRIGGERED		317	3-962-058-01	GEAR (S-K), JULEX	
303	3-950-485-01	GEAR (CT), LOADING		318	3-950-524-01	CLAMP, S WINDING	
304	3-960-449-01	SPRING (CT), TENSION COIL		319	3-058-632-01	ARM, S WINDING	
305	X-1943-891-01	LEVER (T) ASSY, LOADING		320	3-950-524-01	SPRING, TENSION	
306	3-950-478-01	GEAR (S), LOADING		321	3-960-212-01	SCREW (2-K)	
307	3-960-448-01	SPRING (CS), TENSION COIL		322	X-1943-896-1	VGI ASSY	
308	X-1943-898-1	LEVER (S) ASSY, LOADING		323	3-950-592-01	SPRING (TG), TENSION COIL	
309	3-058-529-01	SPRING (MOUNT), TENSION		324	A-6750-314-A	T BLOCK ASSY, SHUTTLE	
310	3-950-940-01	RUBBER JOINT		325	L-1944-328-1	ROLLER ASSY, GUIDE	
311	3-990-720-01	NUT		326	A-6750-310-A	SHUTTLE (S) BLOCK ASSY	
312	3-960-688-01	SPRING LEAF (T), LOADING		327	3-050-504-01	ARM, FIXED RELEASE	
313	3-960-687-01	SPRING LEAF (S), LOADING		328	3-962-914-01	U-NUT	
314	X-1943-874-1	CHASSIS ASSY, MECHANICAL		M912	1-698-604-11	ROTOR, DC (CAPSTAR)	
315	3-460-595-01	WASHER (S), STOPPER					

## 5-2. ELECTRICAL PARTS LIST

## NOTE:

- Use the standardization, replacements in the parts list may be different from the parts specified in the diagram or the components used on the set.
- -X and -Y mean standardized parts, so they may have some differences from the original one.
- RESISTORS  
All resistors are in Ohms.  
METAL: Metal-film resistor.  
METAL OXIDE: Metal oxide-film resistor.  
Enameleable

- Items marked "\*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS  
In each case, specify, for example:  
M : 2N1, MPA : 2N1A,  
MPC : 2N1B, MFC : 2N1C, MPD : 2N1D.
- CAPACITORS  
M : 2F  
MFC : 2FC  
MPC : 2PC  
MPD : 2PD
- COILS  
M : 2H

The components identified by mark \* or A-acted line with mark \* are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque \* ou A-actés ligne avec marque \* sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
*	A-5794-032-A	DC-57 BOARD, COMPLETE (EXCEPT 733MF/10CS, 740MPC, 900MPC/10FP)				< DIODE >	
*	A-5794-032-A	DC-55 BOARD (733MF/10CS, 740MPC, 900MPC/10FP)		1401	8-719-914-19	DIODE 1SS119-25	
		***** (Ref. No 4,000 series)				< IC >	
		< CONNECTOR >		1CS01	8-759-152-51 IC	MS68HC05CWB-4.5(261)	
>	C0701	1-746-714-11 CONNECTOR, BOARD TO BOARD 5P		1CS02	8-759-164-09 IC	LA72126	
>	C0702	1-746-713-11 CONNECTOR, BOARD TO BOARD 5P				< JUMPER RESISTOR >	
		*****		J0003	1-216-296-00 METAL CHIP	0 5% 1/2W	
>	A-5782-425-A	ED-40 BOARD, COMPLETE (700MF, 741MF, 760MF, 781MF, 940MF/REMO)				< COIL >	
		ED-43 BOARD, COMPLETE (740MPC, 900MPC/10FP)		L042	1-410-508-11 INDUCTOR 10uH		
		***** (Ref. No 3,000 series)				< TRANSISTOR >	
		< CAPACITOR >		0601	8-729-010-25 TRANSISTOR	MSD01-BTL	
C001	1-163-019-00	CERAMIC CHIP	0.006uF 10% 50V	0602	8-729-010-25 TRANSISTOR	MSD01-BTL	
C002	1-124-126-00	ELECT	47uF 20% 16V	0603	8-729-901-06 TRANSISTOR	DEA34EX	
C003	1-163-031-13	CERAMIC CHIP	0.01uF			< RESISTOR >	
C004	1-163-155-00	CERAMIC CHIP	500PF 5% 50V	R001	1-216-049-00 METAL CHIP	1K 5% 1/10W	
C005	1-604-340-11	CERAMIC CHIP	1uF 15V	R002	1-216-049-00 METAL CHIP	1K 5% 1/10W	
C006	1-164-329-13	CERAMIC CHIP	0.1uF 10% 50V	R003	1-216-049-00 METAL CHIP	1K 5% 1/10W	
C007	1-163-091-13	CERAMIC CHIP	0.01uF 5% 50V	R004	1-216-149-00 METAL CHIP	1K 5% 1/10W	
C008	1-163-263-13	CERAMIC CHIP	330PF 5% 50V	R005	1-216-149-00 METAL CHIP	1K 5% 1/10W	
C009	1-163-179-00	CERAMIC CHIP	47PF 5% 50V	R006	1-216-081-00 METAL CHIP	22K 5% 1/10W	
C010	1-177-370-11	FILM	0.01uF 5% 50V	R007	1-216-073-00 METAL CHIP	10K 5% 1/10W	
C011	1-163-063-00	CERAMIC CHIP	0.022uF 10% 20V	R008	1-216-057-00 METAL CHIP	1.0K 5% 1/10W	
C012	1-163-342-11	CERAMIC CHIP	0.05uF 10% 25V	R009	1-216-043-00 METAL GLAZE	560 5% 1/10W	
C013	1-124-925-13	ELECT	2.2uF 20% 100	R010	1-216-296-00 CONDUCTOR, CHIP (2032)		
C014	1-163-031-13	CERAMIC CHIP	0.01uF 50V	R012	1-216-033-00 METAL CHIP	330 5% 1/10W	
C015	1-124-826-00	ELECT	47uF 20% 16V	R013	1-216-043-00 METAL GLAZE	560 5% 1/10W	
C016	1-163-091-13	CERAMIC CHIP	0.01uF 50V	R014	1-216-049-00 METAL CHIP	1K 5% 1/10W	
C017	1-124-903-13	ELECT	1uF 20% 50V	R015	1-216-057-00 METAL CHIP	2.2K 5% 1/10W	
C018	1-163-159-00	CERAMIC CHIP	820PF 5% 50V	R016	1-216-073-00 METAL CHIP	10K 5% 1/10W	
		< CONNECTOR >		R017	1-216-081-00 METAL CHIP	22K 5% 1/10W	
C091	1-746-710-11	CONNECTOR, BOARD TO BOARD 10P		R018	1-216-081-00 METAL CHIP	22K 5% 1/10W	



Ref. No.	Part No.	Description	Remark
R619	1-216-104-00	METAL CHIP	150K 5% 1/10W
R620	1-216-043-00	METAL CHIP	3.9K 5% 1/10W
R621	1-216-043-91	METAL GLAZE	560 5% 1/10W
R622	1-216-070-00	METAL CHIP	10K 5% 1/10W
R623	1-216-070-60	METAL CHIP	10K 5% 1/10W
< VIBRATOR >			
Z601	1-579-125-11	VIBRATOR, CERAMIC (8.0MHz)	
Z602	1-577-165-11	VIBRATOR, CERAMIC (20.0MHz)	
*****			
4-0721-500-A HF-34 BOARD, COMPLETE			
*****			
(Ref. No 4.000 series)			
< CAPACITOR >			
C101	1-124-997-11	ELECT	10uF 20% 50V
C102	1-124-967-11	ELECT	10uF 20% 50V
C103	1-124-827-11	ELECT	4.7uF 20% 100V
C104	1-124-917-11	ELECT	4.7uF 20% 100V
C105	1-124-126-00	ELECT	47uF 20% 10V
C106	1-124-126-00	ELECT	47uF 20% 10V
C107	1-124-126-00	ELECT	47uF 20% 10V
C108	1-126-962-11	ELECT	1.2uF 20% 50V
C109	1-126-962-11	ELECT	3.3uF 20% 50V
C110	1-124-962-11	ELECT	1.2uF 20% 50V
C111	1-126-962-11	ELECT	1.2uF 20% 50V
C112	1-126-223-11	ELECT	22uF 20% 50V
C113	1-126-213-11	ELECT	22uF 20% 50V
C114	1-124-252-00	ELECT	0.33uF 20% 50V
C115	1-124-443-00	ELECT	100uF 20% 10V
C116	1-124-443-00	ELECT	100uF 20% 10V
C117	1-191-792-11	ELECT	33uF 20% 10V
C118	1-137-372-11	FILM	0.022uF 5% 50V
C119	1-137-372-11	FILM	0.022uF 5% 50V
C120	1-137-370-11	FILM	0.01uF 5% 50V
C121	1-137-370-11	FILM	0.01uF 5% 50V
C122	1-137-367-11	FILM	0.0033uF 5% 50V
C123	1-137-367-11	FILM	0.0033uF 5% 50V
C124	1-137-364-11	FILM	0.001uF 5% 50V
C125	1-163-006-11	CERAMIC CHIP	500PF 10% 50V
C126	1-163-006-11	CERAMIC CHIP	500PF 10% 50V
C127	1-163-006-11	CERAMIC CHIP	500PF 10% 50V
C128	1-163-006-11	CERAMIC CHIP	500PF 10% 50V
C129	1-163-007-11	CERAMIC CHIP	680PF 10% 50V
C130	1-163-007-11	CERAMIC CHIP	680PF 10% 50V
C131	1-137-372-11	FILM	0.022uF 5% 50V
C132	1-137-372-11	FILM	0.022uF 5% 50V
C133	1-163-145-00	CERAMIC CHIP	0.0015uF 5% 50V
C134	1-163-145-00	CERAMIC CHIP	0.0015uF 5% 50V

Ref. No.	Part No.	Description	Remark
C135	1-163-018-11	CERAMIC CHIP	0.1uF 25V
< CONNECTOR >			
* CH101	1-573-825-11	CONNECTOR, BOARD TO BOARD 13P	
* CH102	1-573-825-11	CONNECTOR, BOARD TO BOARD 13P	
* CH103	1-544-913-11	PLUG, CONNECTOR 3P	
< DIODE >			
D101	8-719-404-06	DIODE, 1N410	
< IC >			
IC101	8-759-486-01	TC, XLR7776K-VP	
< TRANSISTOR >			
Q101	8-729-804-81	TRANSISTOR, 2S8142Z-5	
Q102	8-729-820-68	TRANSISTOR, 2S8180FA-3	
< RESISTOR >			
R101	1-209-306-11	METAL GLAZE	10K 0.50% 1/10W
R102	1-209-309-11	METAL GLAZE	12K 0.50% 1/10W
R103	1-216-043-00	METAL CHIP	27K 5% 1/10W
R104	1-216-043-00	METAL CHIP	22K 5% 1/10W
R105	1-216-089-00	METAL CHIP	47K 5% 1/10W
R106	1-216-089-00	METAL CHIP	47K 5% 1/10W
R107	1-216-043-00	METAL CHIP	27K 5% 1/10W
R108	1-216-075-00	METAL CHIP	12K 5% 1/10W
R109	1-216-075-00	METAL CHIP	12K 5% 1/10W
R110	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R111	1-216-168-91	METAL GLAZE	220K 5% 1/10W
R112	1-216-169-91	METAL GLAZE	250K 5% 1/10W
R113	1-216-169-00	METAL CHIP	330K 5% 1/10W
R114	1-216-069-00	METAL CHIP	6.8K 5% 1/10W
R115	1-216-069-00	METAL CHIP	6.8K 5% 1/10W
R116	1-216-077-00	METAL CHIP	15K 5% 1/10W
R118	1-216-123-00	METAL CHIP	2.2K 5% 1/10W
R120	1-216-295-91	CONNECTOR, CHIP (2012)	
R121	1-216-295-91	CONNECTOR, CHIP (2012)	
R124	1-216-006-00	METAL CHIP	5.1K 5% 1/10W
R125	1-216-045-60	METAL CHIP	1K 5% 1/10W
R130	1-216-049-00	METAL CHIP	1K 5% 1/10W
< VARIABLE RESISTOR >			
RV101	1-241-764-31	RES, ADJ, CERMET 10K	
RV102	1-241-763-21	RES, ADJ, CERMET 4.7K	
RV103	1-241-763-31	RES, ADJ, CERMET 4.7K	

Ref. No	Part No	Description	Remark
*	A-6782-429-A	HI-5 BOARD, COMPLETE (73XHPA, 7401F; US, 7411F)	
*	A-6782-435-A	HI-5 BOARD, COMPLETE (6401F; US/FRN)	
*	A-6782-442-A	HI-5 BOARD, COMPLETE (6301F; US, 5811F)	
*	A-6782-505-A	HI-19 BOARD, COMPLETE (7301F; F)	
*	A-6782-500-A	HI-19 BOARD, COMPLETE (7301F; AFCS)	
*	A-6782-507-A	HI-19 BOARD, COMPLETE (5401F; AFCS)	
*	A-6782-525-A	HI-5 BOARD, COMPLETE (6401F; OS)	
*	A-6782-528-A	HI-5 BOARD, COMPLETE (6401F; Canadian)	
*	A-6782-527-A	HI-5 BOARD, COMPLETE (7401F; Canadian)	
*	A-6782-528-A	HI-5 BOARD, COMPLETE (7301F; F)	
*	A-6782-529-A	HI-5 BOARD, COMPLETE (6301F; Canadian)	
*	A-6782-531-A	HI-5 BOARD, COMPLETE (9401F; Canadian)	
		***** (Ref. No. 8, 100 series)	
*	J-960-968-01	WASHER (A), FL  < BRUSH >	
B200	L-529-104-11	TRIGGER, MICRO ELECTRIC  < CAPACITOR >	
C102	L-160-346-11	CERAMIC CHIP 1uF	10V
C104	L-160-009-11	CERAMIC CHIP 0.001uF 10% 50V (EXCEPT 600F, 7301F; AFCS/7401F, 7411F)	
C105	L-160-009-11	CERAMIC CHIP 0.001uF 10% 50V (EXCEPT 600F, 7301F; AFCS/7401F, 7411F)	
C106	L-160-009-11	CERAMIC CHIP 0.001uF 10% 50V (EXCEPT 600F, 7301F; AFCS/7401F, 7411F)	
C107	L-160-239-11	CERAMIC CHIP 100F 5% 50V	
C109	L-160-031-11	CERAMIC CHIP 0.01uF	50V
C110	L-160-031-11	CERAMIC CHIP 0.01uF	50V
C111	L-160-031-11	CERAMIC CHIP 0.01uF	50V
C112	L-160-346-11	CERAMIC CHIP 1uF	15V
C113	L-160-219-11	CERAMIC CHIP 0.1uF	50V
C114	L-160-031-11	CERAMIC CHIP 0.01uF	50V
C115	L-160-036-91	CERAMIC CHIP 0.1uF	25V
C116	L-128-057-11	ELECT 200uF	20% 0.3V
C117	L-160-036-91	CERAMIC CHIP 0.1uF	25V
C118	J-125-705-11	Cap. DOUBLE LAYERS 0.22F	
C120	L-160-035-00	CERAMIC CHIP 0.64uF	50V
C121	L-124-261-00	ELECT 10uF	20% 0.5V
C122	L-128-754-11	ELECT 47uF	20% 0.3V
C130	L-124-594-00	ELECT 10uF	20% 31V
		< CONNECTOR >	
CN001	L-491-051-21	HOUSING, CONNECTOR 10P	
CN002	L-491-051-21	HOUSING, CONNECTOR 10P	
CN003	J-508-673-11	CONNECTOR, BOARD TO BOARD 14P	

Ref. No.	Part No.	Description	Remark
CN004	J-696-038-21	PIA, CONNECTOR (PC BOARD) 4P 17011F, 7611F, 9401F; AFCS/190, 195F)	
CN005	J-508-669-11	PIA, CONNECTOR 4P  TRIGGER >	
CT001	J-141-432-91	TRIGGER, CERAMIC  < DIODE >	
D001	8-719-445-04	LED SLD-342MC-A-47 (POWER)	
D002	8-719-445-04	LED SLD-342MC-A-47 (POWER)	
D004	8-719-811-19	DIODE 1ES119-25 (EXCEPT 6401F, 7301F; F/AFCS, 7401F, 7411F)	
D002	8-719-811-19	DIODE 1ES119-25	
D013	8-719-200-82	DIODE 1ES22	
D020	8-719-110-08	DIODE 1ES2-2ES-82  < FLUORESCENT INDICATOR >	
FL004	L-517-315-11	TUBE, FLUORESCENT INDICATOR  < IC >	
IC001	8-759-279-61	IC STRONGARM	
IC002	8-759-288-09	IC MICRODRIVE-6-154-B40	
IC003	8-759-248-67	IC 8MS280F-8E	
IC005	L-460-833-11	IC DAY-CATCHER BLOCK, REMOVED  < JUMPER RESISTOR >	
JR001	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR005	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR009	L-216-294-00	METAL, CHIP 0 5% 1/8W	
JR010	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR011	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR012	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR017	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR018	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR020	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR021	L-216-295-91	CONDUCTOR, CHIP (2012)	
JR032	L-214-296-91	CONDUCTOR, CHIP (2012) (7801F, 7810F, 7810F; AFCS/195F/195F)	
JR043	L-216-296-00	METAL, CHIP 0 5% 1/8W	
JR054	L-216-296-00	METAL, CHIP 0 5% 1/8W	
JR055	L-216-296-00	METAL, CHIP 0 5% 1/8W	
JR056	L-216-296-00	METAL, CHIP 0 5% 1/8W	
JR057	L-216-296-00	METAL, CHIP 0 5% 1/8W	
JR058	L-216-296-00	METAL, CHIP 0 5% 1/8W	
JR059	L-216-296-00	METAL, CHIP 0 5% 1/8W	
JR040	L-216-296-00	METAL, CHIP 0 5% 1/8W	
JR041	L-216-296-00	METAL, CHIP 0 5% 1/8W	

Ref. No.	Part No.	Description	QTY	UNIT	REMARKS
JR342	1-216-296-00	METAL CHIP	6	EA	1/200
JR345	1-216-296-00	METAL CHIP	6	EA	1/200
JR373	1-216-295-01	CONDUCTOR, CHIP (2012)			
JR375	1-216-295-01	CONDUCTOR, CHIP (2012)			
JR376	1-216-295-01	CONDUCTOR, CHIP (2012)			
		< COIL >			
R097	1-414-107-41	INDUCTOR 10uH			
R110	1-410-513-11	INDUCTOR 22uH			
		< JACK >			
R306	1-786-061-11	JACK, P1W (3P) 4.0H (1W 2) (780HF, 781HF)			
R308	1-786-061-21	JACK, P1W (3P) 6.2H (1W 2) (940HF/9FCS, 940HF/9FPC)			
		< TRANSISTOR >			
Q301	8-729-421-19	TRANSISTOR, 0W2210			
		< RESISTOR >			
R210	1-216-057-00	METAL CHIP 2.2K 5% 1/10W			
R202	1-216-020-00	METAL GLAZE 62 5% 1/10W			
R104	1-216-057-00	METAL CHIP 2.2K 5% 1/10W (640HF, 733HF/9FCS, 940HF/9FPC, 940HF/9FPC, 741HF)			
R105	1-216-061-00	METAL CHIP 3.3K 5% 1/10W (640HF, 733HF/9FCS, 940HF/9FPC, 740HF/9FPC, 741HF)			
R107	1-216-020-00	METAL CHIP 75 5% 1/10W (780HF, 781HF, 940HF/9FCS, 940HF/9FPC)			
R210	1-216-296-00	METAL CHIP 0 5% 1/200			
R212	1-216-073-00	METAL CHIP 10K 5% 1/10W (640HF, 733HF/9FCS, 940HF/9FPC, 740HF/9FPC, 741HF)			
R242	1-216-111-00	METAL CHIP 100K 5% 1/10W (780HF, 781HF, 940HF/9FCS, 940HF/9FPC)			
R343	1-216-073-00	METAL CHIP 10K 5% 1/10W (640HF, 733HF/9FCS, 940HF/9FPC, 740HF/9FPC, 741HF)			
R343	1-216-111-00	METAL CHIP 100K 5% 1/10W (780HF, 781HF, 940HF/9FCS, 940HF/9FPC)			
R354	1-249-424-11	CARBON 10K 5% 1/4W			
R395	1-216-073-00	METAL CHIP 10K 5% 1/10W			
R346	1-216-073-00	METAL CHIP 10K 5% 1/10W			
R377	1-216-222-00	METAL GLAZE 10K 5% 1/200			
R348	1-216-093-00	METAL CHIP 10K 5% 1/10W			
R321	1-216-073-00	METAL CHIP 10K 5% 1/10W			
R322	1-216-049-00	METAL CHIP 1K 5% 1/10W			
R323	1-216-222-00	METAL GLAZE 10K 5% 1/200			
R324	1-216-222-00	METAL GLAZE 10K 5% 1/200			
R325	1-216-295-01	CONDUCTOR, CHIP (2012)			

Ref. No.	Part No.	Description	QTY	UNIT	REMARKS
R326	1-249-424-11	CARBON 4.7K 5% 1/4W F			
R327	1-216-041-00	METAL CHIP 470 5% 1/10W (780HF, 781HF, 940HF/9FCS, 940HF/9FPC, 940HF/9FPC)			
R328	1-216-041-00	METAL CHIP 470 5% 1/10W (780HF, 781HF, 940HF/9FCS, 940HF/9FPC)			
R329	1-216-073-00	METAL CHIP 10K 5% 1/10W			
R330	1-216-073-00	METAL CHIP 10K 5% 1/10W			
R331	1-216-089-00	METAL CHIP 47K 5% 1/10W			
R332	1-216-111-00	METAL CHIP 470K 5% 1/10W			
R333	1-216-199-01	METAL GLAZE 1K 5% 1/200			
R334	1-216-096-00	METAL CHIP 61K 5% 1/10W			
R336	1-216-057-00	METAL CHIP 2.2K 5% 1/10W (640HF, 733HF/9FCS, 940HF/9FPC, 740HF/9FPC, 741HF)			
R336	1-216-295-01	CONDUCTOR, CHIP (2012) (780HF, 781HF, 940HF/9FCS, 940HF/9FPC)			
R337	1-216-296-00	METAL GLAZE 2.2K 5% 1/200 (640HF, 733HF/9FCS, 940HF/9FPC, 740HF/9FPC, 741HF)			
R337	1-216-296-00	METAL CHIP 0 5% 1/200 (780HF, 781HF, 940HF/9FCS, 940HF/9FPC)			
R338	1-216-295-01	CONDUCTOR, CHIP (2012) (780HF, 781HF, 940HF/9FCS, 940HF/9FPC)			
R340	1-216-061-00	METAL CHIP 3.3K 5% 1/10W			
R341	1-216-057-00	METAL CHIP 2.2K 5% 1/10W (640HF, 733HF/9FCS, 940HF/9FPC, 740HF/9FPC, 741HF)			
R342	1-216-045-00	METAL CHIP 4.7K 5% 1/10W (640HF, 733HF/9FCS, 940HF/9FPC, 740HF/9FPC, 741HF)			
R344	1-247-858-11	CARBON 47K 5% 1/4W (940HF/9FCS, 940HF/9FPC)			
R345	1-216-073-00	METAL CHIP 10K 5% 1/10W (640HF/9FCS, 940HF/9FPC)			
R346	1-249-413-11	CARBON 22K 5% 1/4W (940HF/9FCS, 940HF/9FPC)			
R347	1-247-810-11	CARBON 47K 5% 1/4W (940HF/9FCS, 940HF/9FPC)			
R348	1-249-437-11	CARBON 47K 5% 1/4W			
R349	1-216-222-00	METAL GLAZE 10K 5% 1/200			
R350	1-216-073-00	METAL CHIP 10K 5% 1/10W			
R351	1-216-073-00	METAL CHIP 10K 5% 1/10W			
R360	1-216-113-00	METAL CHIP 470K 5% 1/10W			
R361	1-249-417-11	CARBON 1K 5% 1/4W F			
R362	1-249-417-11	CARBON 1K 5% 1/4W F			
R363	1-249-417-11	CARBON 1K 5% 1/4W F			
R364	1-249-417-11	CARBON 1K 5% 1/4W F			
R365	1-249-417-11	CARBON 1K 5% 1/4W F			
		< SWITCH >			
S301	1-021-077-11	SWITCH TACTIL 00080			

Ref. No.	Part No.	Description	Remark
S302	1-571-977-11	SWITCH TACTIL (+) (EJECT)	
S301	1-571-977-11	SWITCH TACTIL (IV/VR)	
		(640HF, 703HF, 705FC, 706HC, 707HA, 740HF, 707FA, 741HF)	
S304	1-571-977-11	SWITCH TACTIL (+) (CHANGE)	
		(640HF, 703HF, 705FC, 706HC, 707HA, 740HF, 707FA, 741HF)	
S305	1-571-977-11	SWITCH TACTIL (-) (CHANNEL)	
		(640HF, 703HF, 705FC, 706HC, 707HA, 740HF, 707FA, 741HF)	
S306	1-571-977-11	SWITCH TACTIL (BASIC SET UP)	
		(640HF, 703HF, 705FC, 706HC, 707HA, 740HF, 707FA, 741HF)	
S307	1-571-977-11	SWITCH TACTIL (INPUT SELECT)	
		(640HF, 703HF, 705FC, 706HC, 707HA, 740HF, 707FA, 741HF)	
S308	1-571-977-11	SWITCH TACTIL (TAPE SPEED)	
		(640HF, 703HF, 705FC, 706HC, 707HA, 740HF, 707FA, 741HF)	
S309	1-571-977-11	SWITCH TACTIL (QUICK TIME)	
		(640HF, 703HF, 705FC, 706HC, 707HA, 740HF, 707FA, 741HF)	
S310	1-571-977-11	SWITCH TACTIL (PRESS) (700HF, 701HC, NOISE, 701CS, 701NS, 701PS)	
S311	1-362-171-11	SWITCH SLIDE (COMMAND MODE)	
		(640HF, 705FC, 706HC, 707FA)	
S311	1-572-508-11	SWITCH SLIDE (EJECT) (640HF, 705FC, 706HC, 707FA)	
		< VIBRATOR >	
X301	1-579-436-11	VIBRATOR, CRYSTAL (12MHz)	
X302	1-570-420-11	VIBRATOR, CRYSTAL (12MHz)	
*****			
*	A-6782-422-A	MA-214 BOARD, COMPLETE (300HF, 701HF)	
*	A-6782-432-A	MA-214 BOARD, COMPLETE (700HF, 701HF, 741HF)	
*	A-6502-474-A	MA-214 BOARD, COMPLETE (710HF, 705FC, 706HC, 707FA)	
*	A-6782-437-A	MA-214 BOARD, COMPLETE (840HF, 705FC, 706HC, 707FA)	
*	A-6782-438-A	MA-214 BOARD, COMPLETE (640HF)	
		*****	
		(Def. No. 1,000 series)	
*	3-940-273-01	SWITCH, TOP END	
*	3-940-274-01	SWITCH, LED	
		< CAPACITOR >	
C001	1-163-073-91	CERAMIC CHIP	0.022uF 50V
C002	1-163-030-91	CERAMIC CHIP	0.022uF 50V
C003	1-124-096-31	ELECT	10uF 20V 35V
C004	1-104-232-31	CERAMIC CHIP	0.01uF 50V
C006	1-124-124-40	ELECT	47uF 20V 10V

Ref No	Part No	Description	Remark
C007	1-124-025-00	ELECT	230uF 20V 6.3V
C008	1-163-099-81	CERAMIC CHIP	0.001uF 10V 50V
C009	1-163-098-81	CERAMIC CHIP	0.01uF 10V 50V
C010	1-163-099-81	CERAMIC CHIP	0.001uF 10V 50V
C012	1-163-099-81	CERAMIC CHIP	0.001uF 10V 50V
C013	1-163-038-91	CERAMIC CHIP	0.1uF 25V
C014	1-124-456-00	ELECT	100uF 50V 15V
C015	1-163-038-91	CERAMIC CHIP	0.1uF 25V
C016	1-163-038-91	CERAMIC CHIP	0.1uF 25V
C017	1-163-038-91	CERAMIC CHIP	0.1uF 25V
C018	1-163-038-91	CERAMIC CHIP	0.1uF 25V
C019	1-163-038-91	CERAMIC CHIP	0.1uF 25V
C401	1-164-232-11	CERAMIC CHIP	0.01uF 50V
C102	1-124-120-00	ELECT	47uF 20V 10V
C103	1-164-344-81	CERAMIC CHIP	0.068uF 10V 25V
C104	1-124-273-11	ELECT	22uF 20V 50V
C105	1-124-440-00	ELECT	100uF 20V 10V
C106	1-163-099-81	CERAMIC CHIP	0.001uF 10V 50V
C107	1-163-017-00	CERAMIC CHIP	0.001uF 5V 50V
C108	1-164-004-11	CERAMIC CHIP	0.1uF 10V 25V
C109	1-124-945-11	ELECT	2.2uF 20V 100V
C110	1-124-477-11	ELECT	47uF 20V 25V
C111	1-124-925-11	ELECT	2.2uF 20V 100V
C210	1-124-584-00	ELECT	100uF 20V 10V
C211	1-163-229-11	CERAMIC CHIP	12PF 5V 50V
C212	1-163-228-11	CERAMIC CHIP	12PF 5V 50V
C213	1-163-078-91	CERAMIC CHIP	0.1uF 25V
C214	1-163-009-11	CERAMIC CHIP	0.001uF 10V 50V
C264	1-137-372-11	FILM	0.022uF 5V 50V
C265	1-164-232-11	CERAMIC CHIP	0.01uF 10V 50V
C266	1-124-240-00	ELECT	22uF 20V 35V
C267	1-137-411-11	FILM	0.027uF 5V 50V
C268	1-124-261-00	ELECT	10uF 20V 50V
C273	1-163-099-00	CERAMIC CHIP	0.01uF 10V 50V
C272	1-164-548-11	ELECT	47uF 20V 10V
C351	1-163-028-91	CERAMIC CHIP	0.1uF 25V
C352	1-164-004-11	CERAMIC CHIP	0.1uF 10V 25V
		(710HF, 705FC, 706HC, 707FA, 708HF, 731HF, 840HF, 705FC, 706HC, 707FA)	
		(731HF, 705FC, 706HC, 707FA, 708HF, 731HF, 840HF, 705FC, 706HC, 707FA)	
C353	1-124-664-11	ELECT	0.22uF 20V 50V
		(731HF, 705FC, 706HC, 707FA, 708HF, 731HF, 840HF, 705FC, 706HC, 707FA)	
C354	1-163-008-91	CERAMIC CHIP	0.1uF 25V
C361	1-163-317-00	CERAMIC CHIP	100PF 5V 50V
		(723HF, 705FC, 706HC, 707FA, 708HF, 731HF, 840HF, 705FC, 706HC, 707FA)	

Ref. No.	Part No.	Description	Remark
C362	1-163-317-00	CERAMIC CHIP (733HF/AFCS/AFMS/AFPA, 703HF, 703HF, 910HF/AFCS/AFMS/AFPA)	300PF 5% 50V
C404	1-163-035-00	CERAMIC CHIP	20PF 5% 50V
C402	1-163-034-14	CERAMIC CHIP	0.01uF 50V
C406	1-126-765-14	ELECT	45k 20% 10V
C407	1-163-034-00	CERAMIC CHIP	0.01uF 10% 50V
C408	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C409	1-126-765-11	ELECT	47k 20% 10V
C410	1-163-227-13	CERAMIC CHIP	10PF 0.5PF 50V
C411	1-163-235-13	CERAMIC CHIP	22PF 5% 50V
C412	1-163-239-13	CERAMIC CHIP	30PF 5% 50V
C413	1-163-235-14	CERAMIC CHIP	22PF 5% 50V
C414	1-124-257-00	ELECT	2.2k 20% 50V
C417	1-163-037-11	CERAMIC CHIP	0.022uF 10% 25V
C418	1-163-037-11	CERAMIC CHIP	0.022uF 10% 25V
C419	1-124-126-00	ELECT	47uF 20% 16V
C420	1-163-031-13	CERAMIC CHIP	0.01uF 50V
C421	1-162-305-11	CERAMIC	0.01uF 20% 16V
C422	1-124-905-11	ELECT	1uF 50% 50V
C423	1-163-139-00	CERAMIC CHIP	070PF 5% 50V
C424	1-126-765-14	ELECT	47uF 20% 10V
C425	1-163-044-11	CERAMIC CHIP	0.1uF 10% 25V
C427	1-163-038-91	CERAMIC CHIP	0.1uF 25V
C401	1-126-096-11	ELECT	10k 20% 35V
C402	1-126-096-11	ELECT	10k 20% 35V
C403	1-124-907-11	ELECT	10uF 20% 50V
C610	1-124-126-00	ELECT	47uF 20% 10V
C617	1-163-031-14	CERAMIC CHIP	0.01uF 50V
C618	1-124-124-00	ELECT	47uF 20% 10V
C619	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C621	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C622	1-124-437-11	ELECT	47k 20% 25V
C623	1-124-426-00	ELECT	47uF 20% 10V
C624	1-124-472-11	ELECT	47uF 20% 10V
C625	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V
C626	1-163-009-11	CERAMIC CHIP	0.003uF 10% 50V
C703	1-124-261-00	ELECT	30uF 20% 50V
C704	1-163-031-11	CERAMIC CHIP	0.01uF 10% 50V
C706	1-124-281-00	ELECT	30uF 20% 50V
C707	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C709	1-124-477-11	ELECT	47k 20% 25V
C708	1-163-031-13	CERAMIC CHIP	0.01uF 50V
C710	1-164-163-11	CERAMIC CHIP	0.0022uF 10% 100V
C711	1-124-103-11	ELECT	100uF 20% 16V
C712	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C713	1-124-124-00	ELECT	47uF 20% 10V
C714	1-163-031-91	CERAMIC CHIP	0.01uF 50V
C716	1-124-261-00	ELECT	10uF 20% 50V

Ref. No.	Part No.	Description	Remark
C717	1-124-261-00	ELECT	10uF 20% 50V
C718	1-124-263-00	ELECT	22uF 20% 35V
C719	1-164-161-11	CERAMIC CHIP	0.0022uF 10% 100V
C721	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C723	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C724	1-124-263-00	ELECT	30uF 20% 50V
C727	1-124-269-11	ELECT	57uF 20% 16V
C754	1-107-602-11	CERAMIC CHIP (900HF, 703HF, 910HF/AFCS/AFMS/AFPA)	1uF 10% 16V
C761	1-103-662-11	CERAMIC CHIP (EXCEPT 610HF, 733HF/AFCS/AFMS/AFPA)	1uF 10% 16V
C861	1-164-159-11	CERAMIC	0.1uF 50V
C853	1-164-159-11	CERAMIC	0.1uF 50V
C854	1-124-905-11	ELECT	1uF 20% 50V
C855	1-164-160-11	CERAMIC	0.1uF 50V
C856	1-137-370-11	FILM	0.01uF 5% 50V
C857	1-126-163-11	ELECT	4.7uF 20% 50V
C858	1-126-962-11	ELECT	1.3uF 20% 50V
C859	1-163-664-00	CERAMIC CHIP	0.0022uF 5% 50V
C860	1-163-643-00	CERAMIC CHIP	0.0015uF 5% 50V
C861	1-124-925-11	ELECT	2.2uF 20% 100V
C862	1-163-151-00	CERAMIC CHIP	0.001uF 5% 50V
C863	1-163-141-00	CERAMIC CHIP	0.001uF 5% 50V
C864	1-124-231-11	ELECT	22uF 20% 50V
C865	1-124-231-11	ELECT	22uF 20% 50V
C866	1-124-252-00	ELECT	0.3uF 20% 50V
C867	1-124-907-11	ELECT	10uF 20% 50V
C881	1-104-400-11	FILM (EXCEPT 540HF/AFCS/AFMS/AFPA)	0.015uF 5% 100V
C881	1-137-612-11	FILM (900HF/AFCS/AFMS/AFPA)	0.0005uF 5% 100V
C882	1-164-232-11	CERAMIC CHIP	0.01uF 50V
C883	1-163-011-11	CERAMIC CHIP	0.0015uF 10% 50V
C884	1-124-120-11	ELECT (EXCEPT 940HF/AFCS/AFMS/AFPA)	220uF 20% 25V
C884	1-126-801-11	ELECT (940HF/AFCS/AFMS/AFPA)	100uF 20% 16V
C889	1-137-452-11	FILM 540HF	5% 100V
C891	1-104-097-11	FILM (900HF/AFCS/AFMS/AFPA)	0.04uF 5% 100V
C892	1-164-232-11	CERAMIC CHIP	0.01uF 50V
C893	1-163-011-11	CERAMIC CHIP	0.0015uF 10% 50V
C893	1-163-011-11	CERAMIC CHIP	0.0015uF 10% 50V
C894	1-124-104-11	ELECT (940HF/AFCS/AFMS/AFPA)	100uF 20% 16V
C895	1-163-031-11	CERAMIC CHIP	0.01uF 50V
C897	1-124-843-00	ELECT	100uF 20% 10V
C898	1-163-031-91	CERAMIC CHIP	0.1uF 50V
C899	1-126-916-11	ELECT (EXCEPT 610HF, 733HF/AFCS/AFMS/AFPA)	100uF 20% 6.3V

Ref. No.	Part No.	Description	Remark
		. JACK >	
CJ002	1-766-222-11	JACK, PIN 6P (LINE IN / LINE OUT)	
CJ754	1-566-962-11	JACK (CONTROL S (1)) (740HF, 740HF, 940HF, 940HF/AFCS/AFMA/AFPA)	
CJ764	1-566-972-11	JACK (CONTROL S (0)) (EXCEPT 640WF, 733HF, 733HF/AFCS/AFMA/AFPA)	
		. CONNECTOR >	
* CW651	1-766-537-11	CONNECTOR (HMD) 5P	
* CW671	1-766-716-11	CONNECTOR, BOARD TO BOARD 3P	
CK101	1-506-466-11	PIN, CONNECTOR 3P	
CK881	1-506-469-11	PIN, CONNECTOR 4P	
* CW682	1-506-391-00	PIN, CONNECTOR 3P	
CK891	1-506-468-11	PIN, CONNECTOR 3P	
* CW901	1-573-949-11	CONNECTOR, BOARD TO BOARD 11P	
* CW902	1-573-949-11	CONNECTOR, BOARD TO BOARD 11P	
* CW903	1-766-715-11	CONNECTOR, BOARD TO BOARD 19P (740HF/AFPA, 741HF, 780HF, 781HF, 940HF/AFCS/AFMA/AFPA)	
CW904	1-766-992-11	CONNECTOR, FFC/FFC (LIE) 19P	
CW905	1-766-992-11	CONNECTOR, FFC/FFC (LIE) 19P	
CK907	1-573-944-11	CONNECTOR, BOARD TO BOARD 14P	
CK908	1-573-946-11	CONNECTOR, BOARD TO BOARD 14P	
* CW909	1-766-536-11	CONNECTOR, BOARD TO BOARD 3P	
CK910	1-770-017-11	CONNECTOR, BOARD TO BOARD 19P	
* CW912	1-766-717-11	CONNECTOR, BOARD TO BOARD 5P	
		< DIODE >	
D001	8-719-043-26	LED, GL5291 (TOP/END LED)	
D006	8-719-109-91	DIODE, 90V, 2ES-82	
D097	8-719-109-80	DIODE, 90V, 2ES-82	
D071	8-719-110-14	DIODE, 90V, JES-83	
D096	8-719-081-43	DIODE, 1SS187	
D251	8-719-091-43	DIODE, 1SS180	
D252	8-719-101-50	DIODE, 90V, 3E-12	
D253	8-719-101-47	DIODE, 90V, 3E-12	
D402	8-719-091-43	DIODE, 1SS183	
D604	8-719-109-75	DIODE, 90V, 3ES-82	
D605	8-719-109-75	DIODE, 90V, 3ES-82	
ΔD702	8-719-010-76	DIODE, 1SS220	
D703	8-719-979-94	DIODE, 073-TT11-30C	
D704	8-719-200-82	DIODE, 1JES2	
D751	8-719-001-78	DIODE, 1SS164 (740HF, 741HF, 940HF/AFCS/AFMA/AFPA)	
D752	8-719-110-08	DIODE, 90V, 2ES-82 (740HF, 741HF, 940HF/AFCS/AFMA/AFPA)	
D841	8-719-001-78	DIODE, 1SS164 (EXCEPT 640WF, 733HF/AFCS/AFMA/AFPA)	
D842	8-719-010-08	DIODE, 90V, 2ES-82 (EXCEPT 640WF, 733HF/AFCS/AFMA/AFPA)	

Ref. No.	Part No.	Description	Remark
D724	8-719-001-48	DIODE, 1SS163 (EXCEPT 640WF, 733HF/AFCS/AFMA/AFPA)	
D772	8-719-109-51	DIODE, 90V, 2ES82 (EXCEPT 640WF, 733HF/AFCS/AFMA/AFPA)	
D772	8-719-110-08	DIODE, 90V, 2ES-82 (EXCEPT 640WF, 733HF/AFCS/AFMA/AFPA)	
D851	8-719-001-78	DIODE, 1SS164	
D901	8-719-001-48	DIODE, 1SS163	
D902	8-719-200-82	DIODE, 1JES2	
D907	8-719-200-82	DIODE, 1JES2	
D904	8-719-001-75	DIODE, 1SS160	
		. IC >	
IC002	8-759-100-95	IC, μPC2140Z	
IC011	8-759-244-26	IC, BA6201-Y2	
IC191	8-759-246-14	IC, TA8623M	
IC201	8-759-051-50	IC, CP67249-0510 (EXCEPT 640WF, 733HF/AFCS/AFMA/AFPA)	
IC201	8-759-040-49	IC, CP67249-0574 (640WF, 733HF/AFCS/AFMA/AFPA)	
IC251	8-759-702-02	IC, NJM452M	
IC351	8-759-097-20	IC, HD4933FP (EXCEPT 640WF, 740HF/AFPA, 741HF)	
IC401	8-759-288-96	IC, M70303FP-118-ED	
IC402	8-759-164-09	IC, LA1215M	
IC601	8-759-927-56	IC, BA7021	
IC606	8-759-099-06	IC, MC14052ZF	
IC607	8-759-924-46	IC, BA1560F	
IC701	8-759-701-59	IC, NJM4569M	
IC851	8-759-049-02	IC, BA7786FS-E2	
		< RESISTOR >	
J010	1-216-296-00	METAL CHIP, 0 Ω, 5%, 1/8W	
J011	1-216-296-00	METAL CHIP, 0 Ω, 5%, 1/8W	
J012	1-216-295-91	CONDUCTOR, CHIP (2012)	
J013	1-216-296-81	CONDUCTOR, CHIP (2012)	
J014	1-216-296-00	METAL CHIP, 0 Ω, 5%, 1/8W	
J015	1-216-295-91	CONDUCTOR, CHIP (2012)	
J016	1-216-295-91	CONDUCTOR, CHIP (2012)	
J017	1-216-296-00	METAL CHIP, 0 Ω, 5%, 1/8W	
J018	1-216-296-00	METAL CHIP, 0 Ω, 5%, 1/8W	
J019	1-216-296-01	CONDUCTOR, CHIP (2012)	
J020	1-216-295-91	CONDUCTOR, CHIP (2012)	
J021	1-216-295-91	CONDUCTOR, CHIP (2012)	
J022	1-216-295-91	CONDUCTOR, CHIP (2012)	
J023	1-216-296-00	METAL CHIP, 0 Ω, 5%, 1/8W	
J024	1-216-295-91	CONDUCTOR, CHIP (2012)	
J025	1-216-295-91	CONDUCTOR, CHIP (2012)	
J026	1-216-295-91	CONDUCTOR, CHIP (2012)	
J027	1-216-295-01	CONDUCTOR, CHIP (2012)	
J028	1-216-295-91	CONDUCTOR, CHIP (2012)	
J029	1-216-295-91	CONDUCTOR, CHIP (2012)	

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	QTY	UOM
JR706	1-216-296-00	METAL CHIP	0	EA 1/30
JR710	1-216-295-01	CONDUCTOR, CHIP (2012)		
JR716	1-216-295-01	CONDUCTOR, CHIP (2012)		
JR891	1-216-295-01	CONDUCTOR, CHIP (2012)		
JR901	1-216-295-31	(EXCEPT 940HF, 9FCS, 9FMC, 9FFX) CONDUCTOR, CHIP (2012) (740HF, 9FPA, 741UF, 730HF, 731HF, 940HF, 9FUS, 9FVCL, 9FFX)		
JR806	1-216-295-91	CONDUCTOR, CHIP (2012)		
		< COIL >		
L101	1-410-482-31	INDUCTOR 100uH		
L202	1-410-419-11	INDUCTOR 10uH		
L251	1-410-512-11	INDUCTOR 20uH		
L401	1-410-482-31	INDUCTOR 100uH		
L403	1-405-974-21	INDUCTOR 20uH		
L404	1-410-482-31	INDUCTOR 100uH		
L401	1-410-509-11	INDUCTOR 10uH		
L403	1-410-482-31	INDUCTOR 100uH		
L404	1-410-482-31	INDUCTOR 100uH		
L405	1-410-482-31	INDUCTOR 100uH		
L506	1-410-501-11	INDUCTOR 2.2uH		
L701	1-414-183-40	INDUCTOR 10uH		
L702	1-414-169-31	INDUCTOR 100uH		
L703	1-414-183-40	INDUCTOR 10uH		
L712	1-410-589-11	INDUCTOR 2.2uH		
L851	1-410-482-31	INDUCTOR 100uH		
L881	1-410-587-11	INDUCTOR 1.2uH		
L891	1-410-587-11	INDUCTOR 1.2uH (940HF, 9FCS, 9FMC, 9FFX)		
		< FIB CABLE >		
P701	1-565-110-00	CABLE, FIB		
		< PHOTO INTERUMPTER >		
PH001	6-749-010-19	PHOTO INTERUMPTER GP33113		
PH002	6-749-010-20	PHOTO INTERUMPTER GP33114		
		< IC LINK >		
ΔPS201	1-512-727-11	LINK, IC 0.25A (1CP-NS)		
ΔPS301	1-512-727-11	LINK, IC 0.25A (1CP-NS)		
		< TRANSISTOR >		
Q101	8-729-025-92	PHOTO TRANSISTOR PT330F		
Q102	8-729-025-92	PHOTO TRANSISTOR PT330F		
Q601	8-729-016-05	TRANSISTOR 2SC1415-UB		
Q351	8-729-011-06	TRANSISTOR 2SA1428 (EXCEPT 640HF, 740HF, 9FFX, 741HF)		
Q253	8-729-012-19	TRANSISTOR 2N213 (EXCEPT 640HF, 740HF, 9FFX, 741HF)		

Ref. No.	Part No.	Description	Remark
Q354	8-729-010-25	TRANSISTOR 2SD404-RT1 (EXCEPT 640HF, 740HF, 9FFX, 741HF)	
Q402	8-729-011-06	TRANSISTOR 2SA1428	
Q404	8-729-010-05	TRANSISTOR 2SD109-RT1	
Q406	8-729-010-05	TRANSISTOR 2SD109-RT1	
Q407	8-729-010-05	TRANSISTOR 2SD109-RT1	
Q603	8-729-010-05	TRANSISTOR 2SD109-RT1	
Q202	8-729-021-19	TRANSISTOR 2N2213	
ΔQ203	8-729-173-30	TRANSISTOR 2SA1733-B	
Q205	8-729-010-25	TRANSISTOR 2SD404-RT1	
Q906	8-729-010-25	TRANSISTOR 2SD404-RT1	
Q751	8-729-021-19	TRANSISTOR 2N2213 (280HF, 730HF, 940HF/ 9FCS, 9FVCL, 9FFX)	
Q752	8-729-010-05	TRANSISTOR 2SD109-RT1 (730HF, 731HF, 940HF, 9FCS, 9FVCL, 9FFX)	
Q761	8-729-010-25	TRANSISTOR 2SD404-RT1 (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q762	8-729-010-05	TRANSISTOR 2SD109-RT1 (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q763	8-729-010-05	TRANSISTOR 2SD109-RT1 (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q764	8-729-021-19	TRANSISTOR 2N2213 (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q776	8-729-100-01	TRANSISTOR 2SD174-3A (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q777	8-729-010-25	TRANSISTOR 2SD404-RT1 (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q778	8-729-010-05	TRANSISTOR 2SD109-RT1 (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q779	8-729-010-05	TRANSISTOR 2SD109-RT1 (EXCEPT 640HF, 740HF, 9FCS, 9FVCL, 9FFX)	
Q781	8-729-010-05	TRANSISTOR 2SD109-RT1 (640HF, 731HF, 940HF, 9FCS, 9FVCL, 9FFX)	
Q792	8-729-010-05	TRANSISTOR 2SD109-RT1 (740HF, 731HF, 940HF, 9FCS, 9FVCL, 9FFX)	
Q793	8-729-010-25	TRANSISTOR 2SD404-RT1 (740HF, 731HF, 940HF, 9FCS, 9FVCL, 9FFX)	
Q811	8-729-012-21	TRANSISTOR 2SC4040-TL2-0	
Q812	8-729-216-22	TRANSISTOR 2SA1162	
Q819	8-729-010-25	TRANSISTOR 2SD404-RT1	
Q821	8-729-012-21	TRANSISTOR 2SC4040-TL2-0 (940HF, 9FCS/ 9FVCL, 9FFX)	
Q822	8-729-216-22	TRANSISTOR 2SA1162-0 (940HF, 9FCS/ 9FVCL, 9FFX)	
		< RESISTOR >	
R001	1-216-104-00	METAL CHIP	50K 5% 1/30
R002	1-247-391-00	CARBON	120K 5% 1/4W
R003	1-249-937-11	CARBON	47K 5% 1/4W
R004	1-216-089-00	METAL CHIP	47K 5% 1/30
R005	1-249-913-11	CARBON	470 5% 1/4W 7

The components identified by mark Δ or dotted line with mark Δ are critical for safely. Replace only with part number specified.	Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.
--	--

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
W004	1-216-037-00	METAL CHIP	100K 5% 1/10W	R277	1-216-068-00	METAL CHIP	8.2K 5% 1/10W
W007	1-216-043-00	METAL CHIP	100K 5% 1/10W	R278	1-216-234-91	METAL GLAZE	10K 5% 1/5W
W008	1-216-065-00	METAL CHIP	4.7K 5% 1/10W	R351	1-216-226-00	METAL GLAZE	15K 5% 1/5W
W009	1-216-033-00	METAL CHIP	100 5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
W010	1-216-059-00	METAL CHIP	2.7K 5% 1/10W	R352	1-216-073-00	METAL CHIP	100 5% 1/10W
						(EXCEPT 640HF, 740HF, 740HF, 740HF)	
W011	1-216-089-00	METAL CHIP	47K 5% 1/10W	R353	1-216-073-00	METAL CHIP	100 5% 1/10W
W012	1-216-051-00	METAL CHIP	2.2K 5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
W015	1-216-090-00	METAL CHIP	47K 5% 1/10W	R354	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
W016	1-249-421-11	CARBON	2.2K 5% 1/5W F			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
W017	1-249-400-11	CARBON	39 5% 1/5W F	R355	1-216-073-00	METAL CHIP	100 5% 1/10W
						(EXCEPT 640HF, 740HF, 740HF, 740HF)	
W018	1-249-400-11	CARBON	39 5% 1/5W F	R361	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
W019	1-249-421-11	CARBON	2.2K 5% 1/5W F			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
W051	1-216-089-00	METAL CHIP	47K 5% 1/10W	R361	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
W052	1-216-089-00	METAL CHIP	47K 5% 1/10W	R361	1-216-295-91	CONNECTOR, CHIP (2012)	
W053	1-216-089-00	METAL CHIP	47K 5% 1/10W			(640HF, 740HF, 740HF, 740HF)	
W054	1-216-089-00	METAL CHIP	47K 5% 1/10W	R362	1-216-049-00	METAL CHIP	1K 5% 1/10W
W071	1-216-073-00	METAL CHIP	100 5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
W072	1-216-073-00	METAL CHIP	100 5% 1/10W	R363	1-216-049-00	METAL CHIP	1K 5% 1/10W
R101	1-216-119-00	METAL CHIP	820K 5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
R102	1-216-093-00	METAL CHIP	68K 5% 1/10W	R364	1-216-232-00	METAL GLAZE	20K 5% 1/5W
R103	1-216-093-00	METAL CHIP	100K 5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
R104	1-216-093-00	METAL CHIP	100K 5% 1/10W	R365	1-216-063-00	METAL CHIP	6.8K 5% 1/10W
R105	1-216-085-00	METAL CHIP	30K 5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
R106	1-216-063-00	METAL CHIP	6.7K 5% 1/10W	R366	1-216-069-00	METAL CHIP	6.8K 5% 1/10W
R107	1-216-057-00	METAL CHIP	330 5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
R108	1-216-123-00	METAL CHIP	1M 5% 1/10W	R368	1-216-069-00	METAL CHIP	6.8K 5% 1/10W
R109	1-216-659-11	METAL CHIP	2.2K 0.5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
R110	1-216-651-11	METAL CHIP	1K 0.5% 1/10W	R369	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R111	1-216-037-00	METAL CHIP	100K 5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
R126	1-216-654-11	METAL CHIP	2.2K 0.5% 1/10W	R370	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
						(EXCEPT 640HF, 740HF, 740HF, 740HF)	
R214	1-216-049-00	METAL CHIP	1K 5% 1/10W	R371	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R217	1-216-073-00	METAL CHIP	100 5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
R219	1-216-073-00	METAL CHIP	100 5% 1/10W	R372	1-216-060-00	METAL CHIP	6.8K 5% 1/10W
R220	1-216-065-00	METAL CHIP	4.7K 5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
R224	1-249-421-11	CARBON	2.2K 5% 1/5W F	R310	1-216-085-00	METAL CHIP	4.3K 5% 1/10W
						(EXCEPT 640HF, 740HF, 740HF, 740HF)	
R225	1-216-090-00	METAL CHIP	47K 5% 1/10W	R311	1-216-295-91	CONNECTOR, CHIP (2012)	
R226	1-216-689-11	METAL CHIP	30K 0.5% 1/10W			(640HF, 740HF, 740HF, 740HF)	
R227	1-216-689-11	METAL CHIP	30K 0.5% 1/10W	R314	1-216-063-00	METAL CHIP	1.9K 5% 1/10W
R257	1-249-429-11	CARBON	100 5% 1/5W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
R258	1-216-049-00	METAL CHIP	1K 5% 1/10W	R001	1-216-049-00	METAL CHIP	1K 5% 1/10W
				R004	1-216-073-00	METAL CHIP	100 5% 1/10W
R262	1-216-057-00	METAL CHIP	2.2K 5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
R267	1-216-053-00	METAL CHIP	2.2K 5% 1/10W	R005	1-216-295-91	CONNECTOR, CHIP (2012)	
R264	1-216-103-91	METAL GLAZE	100K 5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
R265	1-216-073-00	METAL CHIP	100 5% 1/10W	R007	1-249-114-11	CARBON	550 5% 1/5W F
R266	1-216-079-00	METAL CHIP	18K 5% 1/10W	R009	1-216-101-00	METAL CHIP	150K 5% 1/10W
				R009	1-216-063-00	METAL CHIP	3.9K 5% 1/10W
R271	1-216-065-00	METAL CHIP	4.7K 5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
R274	1-216-083-00	METAL CHIP	27K 5% 1/10W	R010	1-216-043-91	METAL GLAZE	550 5% 1/10W
R275	1-216-093-00	METAL CHIP	82K 5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	
R276	1-216-056-00	METAL GLAZE	2K 5% 1/10W			(EXCEPT 640HF, 740HF, 740HF, 740HF)	



Ref. No.	Part No.	Description	QTY	UOM	Week
R411	1-216-025-00	METAL CHIP	105	EA	1/10W
R412	1-216-025-91	CONDUCTOR, CHIP (2612)			
R413	1-216-295-91	CONDUCTOR, CHIP (2612)			
R414	1-216-081-00	METAL CHIP	228	EA	1/10W
R415	1-216-051-00	METAL CHIP	1.2K	EA	1/10W
R416	1-216-059-00	METAL CHIP	2.7K	EA	1/10W
R417	1-216-013-00	METAL CHIP	220	EA	1/10W
R418	1-216-295-91	CONDUCTOR, CHIP (2612)			
R421	1-216-081-00	METAL CHIP	218	EA	1/10W
R422	1-216-073-00	METAL CHIP	108	EA	1/10W
R423	1-216-017-00	METAL CHIP	67	EA	1/10W
R424	1-216-017-00	METAL CHIP	67	EA	1/10W
R429	1-216-081-00	METAL CHIP	228	EA	1/10W
		(780HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
R431	1-216-230-00	METAL GLAZE	728	EA	1/10W
		(780HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
R432	1-216-081-00	METAL CHIP	228	EA	1/10W
R433	1-216-095-00	METAL CHIP	21K	EA	1/10W
		(380HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
R435	1-216-295-91	CONDUCTOR, CHIP (2012)			
		(640HF, 733HF/AFCS/AFMG/AFPS/AFPA, 740HF/AFPA, 741HF)			
R434	1-216-085-00	METAL CHIP	22K	EA	1/10W
R435	1-216-085-00	METAL CHIP	22K	EA	1/10W
R436	1-216-295-91	CONDUCTOR, CHIP (2012)			
R438	1-216-084-00	METAL CHIP	22K	EA	1/10W
R439	1-216-084-00	METAL CHIP	22K	EA	1/10W
R440	1-216-085-90	METAL CHIP	22K	EA	1/10W
R441	1-216-085-00	METAL CHIP	22K	EA	1/10W
		(780HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
R441	1-216-295-91	CONDUCTOR, CHIP (2012)			
		(640HF, 733HF/AFCS/AFMG/AFPS/AFPA, 740HF/AFPA, 741HF)			
R442	1-216-295-91	CONDUCTOR, CHIP (2012)			
R443	1-216-085-00	METAL CHIP	22K	EA	1/10W
R444	1-216-081-00	METAL CHIP	22K	EA	1/10W
R445	1-216-085-00	METAL CHIP	22K	EA	1/10W
R446	1-249-435-11	CARBON	35K	EA	1/4W
R453	1-216-037-00	METAL CHIP	281	EA	1/10W
R455	1-249-408-11	CARBON	140	EA	1/4W F
R456	1-247-813-21	CARBON	150	EA	1/4W
R457	1-216-022-00	METAL CHIP	68	EA	1/10W
R458	1-216-190-00	METAL GLAZE	470	EA	1/10W
R459	1-216-041-00	METAL CHIP	470	EA	1/10W
R460	1-216-043-91	METAL GLAZE	540	EA	1/10W
R461	1-216-043-91	METAL GLAZE	540	EA	1/10W
R462	1-216-022-00	METAL CHIP	75	EA	1/10W
R463	1-216-041-00	METAL CHIP	470	EA	1/10W
R464	1-216-295-91	CONDUCTOR, CHIP (2012)			
R464	1-216-295-91	CONDUCTOR, CHIP (2012)			
R466	1-216-067-00	METAL CHIP	2.2K	EA	1/10W

Ref. No.	Part No.	Description	QTY	UOM	Week
R466	1-216-065-00	METAL CHIP	4.7K	EA	1/10W
R468	1-216-025-00	METAL CHIP	100	EA	1/10W
R469	1-216-080-00	METAL CHIP	47K	EA	1/10W
R470	1-216-049-00	METAL CHIP	1K	EA	1/10W
R471	1-216-037-00	METAL CHIP	130	EA	1/10W
R474	1-216-037-00	METAL CHIP	130	EA	1/10W
R475	1-216-025-00	METAL CHIP	100	EA	1/10W
R476	1-216-071-00	METAL CHIP	8.2K	EA	1/10W
R477	1-216-075-00	METAL CHIP	12K	EA	1/10W
R478	1-216-025-00	METAL CHIP	100	EA	1/10W
R479	1-216-089-00	METAL CHIP	1K	EA	1/10W
R480	1-216-085-00	METAL CHIP	1K	EA	1/10W
R481	1-216-037-00	METAL CHIP	300	EA	1/10W
R482	1-249-423-11	CARBON	3.3K	EA	1/4W F
R483	1-216-073-00	METAL CHIP	10K	EA	1/10W
R486	1-216-049-00	METAL CHIP	1K	EA	1/10W
R487	1-216-084-00	METAL CHIP	22K	EA	1/10W
R488	1-249-417-11	CARBON	1K	EA	1/4W F
R489	1-216-210-91	CONDUCTOR, CHIP (2012)			
R490	1-216-242-91	METAL GLAZE	62K	EA	1/4W
R494	1-216-295-91	CONDUCTOR, CHIP (2012)			
R491	1-216-045-00	METAL CHIP	4.7K	EA	1/10W
		(780HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
R492	1-216-087-00	METAL CHIP	100K	EA	1/4W
		(780HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
R493	1-216-106-91	METAL GLAZE	220K	EA	1/10W
		(780HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
R494	1-216-057-00	METAL CHIP	2.2K	EA	1/10W
		(780HF, 781HF, 940HF/AFCS/AFMG/AFPS)			
R494	1-247-807-31	CARBON	100	EA	1/4W
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
R492	1-216-041-00	METAL CHIP	470	EA	1/10W
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
R493	1-216-065-00	METAL CHIP	4.7K	EA	1/10W
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
R494	1-216-073-00	METAL CHIP	10K	EA	1/10W
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
R495	1-216-080-00	METAL CHIP	47K	EA	1/10W
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
R496	1-216-075-00	METAL CHIP	10K	EA	1/10W
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
R497	1-216-057-00	METAL CHIP	2.2K	EA	1/10W
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
R498	1-216-105-91	METAL GLAZE	220K	EA	1/10W
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
R499	1-216-057-00	METAL CHIP	10K	EA	1/10W
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
R499	1-216-065-00	METAL CHIP	4.7K	EA	1/10W
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			
R499	1-216-101-00	METAL CHIP	150K	EA	1/10W
		(EXCEPT 640HF, 733HF/AFCS/AFMG/AFPA)			

Ref. No.	Part No.	Description	Remark
R776	1-216-049-00	METAL CHIP (EXCEPT 640HF, 730HF/AFC5/AFM4, HPFA)	1K 5% 1/10W
R777	1-216-049-00	METAL CHIP (EXCEPT 640HF, 730HF/AFC5/AFM4, HPFA)	10 5% 1/10W
R778	1-216-049-00	METAL CHIP (EXCEPT 640HF, 730HF/AFC5/AFM4, HPFA)	10 5% 1/10W
R779	1-216-073-00	METAL CHIP (EXCEPT 640HF, 730HF/AFC5/AFM4, HPFA)	10K 5% 1/10W
R780	1-216-049-00	METAL CHIP (EXCEPT 640HF, 730HF/AFC5/AFM4, HPFA)	1K 5% 1/10W
R781	1-216-025-00	METAL CHIP (EXCEPT 640HF, 730HF/AFC5/AFM4, HPFA)	150 5% 1/10W
R784	1-216-037-00	METAL CHIP 100K 5% 1/10W	
X782	1-216-093-00	METAL CHIP (700HF, 701HF, 940HF/AFC5/AFM4/AFPC)	100W 5% 1/10W
R793	1-216-089-00	METAL CHIP (700HF, 701HF, 940HF/AFC5/AFM4/AFPC)	47K 5% 1/10W
R794	1-216-073-00	METAL CHIP (700HF, 701HF, 940HF/AFC5/AFM4/AFPC)	10K 5% 1/10W
R851	1-216-081-00	METAL CHIP	22K 5% 1/10W
R852	1-216-071-00	METAL CHIP	2.2K 5% 1/10W
R855	1-216-093-00	METAL CHIP	10K 5% 1/10W
R856	1-216-071-00	METAL CHIP	8.2K 5% 1/10W
R857	1-216-085-00	METAL CHIP	33K 5% 1/10W
R858	1-216-129-00	METAL CHIP	2.2K 5% 1/10W
R859	1-216-295-91	CONDUCTOR, CHIP (2012)	
R860	1-216-083-00	METAL CHIP	27K 5% 1/10W
R861	1-216-073-00	METAL CHIP	10K 5% 1/10W
R862	1-216-109-00	METAL CHIP	1500K 5% 1/10W
R863	1-216-089-00	METAL CHIP	6.8K 5% 1/10W
R864	1-216-041-00	METAL CHIP	470 5% 1/10W
R865	1-216-049-00	METAL CHIP	47K 5% 1/10W
R866	1-216-099-00	METAL CHIP	120W 5% 1/10W
R867	1-216-075-00	METAL CHIP	82K 5% 1/10W
R868	1-216-089-00	METAL CHIP	47K 5% 1/10W
R869	1-216-075-00	METAL CHIP	10K 5% 1/10W
R870	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
R871	1-216-073-00	METAL CHIP	10K 5% 1/10W
R872	1-216-037-00	METAL CHIP	100K 5% 1/10W
R873	1-216-295-91	CONDUCTOR, CHIP (2012)	
R875	1-249-430-11	CARBON	32K 5% 1/4W
R876	1-216-001-00	METAL CHIP	10 5% 1/10W
R877	1-216-049-00	METAL CHIP	1K 5% 1/10W
R881	1-216-081-00	METAL CHIP	22K 5% 1/10W
ΔR882	1-249-349-11	CARBON (EXCEPT 940HF/AFC5/AFM4/AFPC)	4.7 5% 1/4W F
ΔR883	1-249-395-11	CARBON (940HF/AFC5/AFM4/AFPC)	15 5% 1/4W F
R901	1-249-417-11	CARBON	1K 5% 1/4W F

Ref. No.	Part No.	Description	Remark
R884	1-216-089-11	METAL CHIP (EXCEPT 940HF/AFC5/AFM4/AFPC)	39K 0.5% 1/10W
R884	1-216-097-00	METAL CHIP (940HF/AFC5/AFM4/AFPC)	100K 5% 1/10W
R887	1-216-295-91	CONDUCTOR, CHIP (2012)	
R891	1-216-083-00	METAL CHIP (940HF/AFC5/AFM4/AFPC)	27K 5% 1/10W
ΔR892	1-249-394-11	CARBON (940HF/AFC5/AFM4/AFPC)	12 5% 1/4W F
R893	1-249-417-11	CARBON (940HF/AFC5/AFM4/AFPC)	1K 5% 1/4W F
R894	1-216-097-00	METAL CHIP (940HF/AFC5/AFM4/AFPC)	100K 5% 1/10W
R896	1-216-089-00	METAL CHIP	47K 5% 1/10W
R897	1-216-073-00	METAL CHIP	10K 5% 1/10W
R898	1-216-085-00	METAL CHIP	33K 5% 1/10W
R899	1-216-085-00	METAL CHIP	33K 5% 1/10W
R903	1-216-093-00	METAL CHIP	5.6K 0.5% 1/10W
R904	1-208-784-11	METAL CHIP	1.2K 0.5% 1/10W
R906	1-216-019-00	METAL CHIP	1K 5% 1/10W
R906	1-216-049-00	METAL CHIP	1K 5% 1/10W
R911	1-216-057-00	METAL CHIP (700HF/AFPC, 701HF, 700HF, 701HF, 940HF/ AFPC/AFM4/AFPC)	2.2K 5% 1/10W
		< RF INDUCTOR >	
ΔR701	1-454-989-11	INDUCTOR, RF	
		< VARIABLE RESISTOR >	
R7201	1-238-602-11	RES, ADJ, CARBON 40W	
R7202	1-238-602-11	RES, ADJ, CARBON 40W	
R7203	1-238-602-11	RES, ADJ, CARBON 40W	
		< SWITCH >	
S902	1-579-953-11	SWITCH PUSH (1 NEED) (REC PROOF)	
		< TRANSFORMER >	
T881	1-423-413-11	TRANSFORMER, BIAS OSCILLATION (940HF/AFC5/AFM4/AFPC)	
T881	1-423-414-11	TRANSFORMER, BIAS OSCILLATION (EXCEPT 940HF/AFC5/AFM4/AFPC)	
T883	1-423-415-11	TRANSFORMER, BIAS OSCILLATION (940HF/AFC5/AFM4/AFPC)	
		< TUNER >	
ΔT8701	8-590-254-00	TUNER BEE-W402	
		< VIBRATOR >	
X204	1-789-494-11	VIBRATOR, CRYSTAL (14MHz)	
X801	1-577-251-11	VIBRATOR, CRYSTAL (14.3MHz)	

The components identified by  
mark Δ or dotted line with  
mark Δ are critical for  
safely. Replace only with  
part number specified.

Les composants identifiés  
par une marque Δ sont  
critiques pour la sécurité.  
Ne les remplacez que par une pièce  
portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark
X402	1-077-165-11	VIOLATOR CERAMIC (500PCS)	
*****			
*	A-6782-424-A	MF-253 BOARD, COMPLETE (300PF, 700PF, 300PF, 400PF)	
*	A-6782-430-A	MF-253 BOARD, COMPLETE (600PF, 700PF, 700PF, 700PF, 700PF)	
*	A-6782-501-A	MF-274 BOARD, COMPLETE (730PF, 400PF, 340PF)	
*	A-6782-502-A	MF-274 BOARD, COMPLETE (340PFCS, 400PF)	
*****			
(Ref No 1,000 series)			
< CAPACITOR >			
C401	1-163-1030-31	CERAMIC CHIP	0.1uF 25V
C402	1-124-584-00	ELECT	100uF 20% 50V
< CONNECTOR >			
C403	1-766-850-11	CONNECTOR, BOARD TO BOARD 14P	
* C402	1-695-822-11	CONNECTOR, BOARD TO BOARD 2P	
< DIODE >			
D403	8-719-045-62	LED SLR-342YC-A-47 (● REC)	
D404	8-719-045-63	LED SLR-342YC-A-47 (● REC (TLW))	
D405	8-719-045-68	LED SLR-342YC-A-47 (● REC (TLW))	
D406	8-719-045-62	LED SLR-342YC-A-47 (TIMER)	
D408	8-719-045-63	LED SLR-342YC-A-47 (TIMER (TLW))	
D409	8-719-045-63	LED SLR-342YC-A-47 (TIMER (TLW))	
D410	8-719-051-17	LED SLR-342DCT31 (● PAUSE)	
D415	8-719-200-02	DIODE 1E132	
D424	8-719-015-63	LED SLR-342YC-A-47 (REC (TLW))	
D425	8-719-045-63	LED SLR-342YC-A-47 (REC (TLW))	
D428	8-719-045-63	LED SLR-342YC-A-47 (TIMER (TLW))	
D429	8-719-045-63	LED SLR-342YC-A-47 (TIMER (TLW))	
< IC >			
IC103	8-752-815-76	IC CAP201M	
< RESISTOR >			
R001	1-216-012-00	METAL CHIP	200 5% 1/10W
R002	1-216-032-00	METAL CHIP	200 5% 1/10W
R003	1-216-032-00	METAL CHIP	200 5% 1/10W
R004	1-216-168-00	METAL GLAZE	47 5% 1/8W
R005	1-216-017-00	METAL CHIP	47 5% 1/10W
R006	1-216-032-00	METAL CHIP	200 5% 1/10W
R008	1-216-017-00	METAL CHIP	47 5% 1/10W
R009	1-216-032-00	METAL CHIP	47 5% 1/10W
R010	1-216-168-11	METAL GLAZE	200 5% 1/8W
R015	1-216-057-00	METAL CHIP	1.2K 5% 1/10W

Ref. No.	Part No.	Description	Remark
R416	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R417	1-216-049-00	METAL CHIP	1K 5% 1/10W
R418	1-216-049-00	METAL CHIP	1K 5% 1/10W
R419	1-216-072-00	METAL CHIP	200 5% 1/10W
R420	1-216-032-00	METAL CHIP	200 5% 1/10W
R422	1-216-032-00	METAL CHIP	200 5% 1/10W
R423	1-216-032-00	METAL CHIP	200 5% 1/10W
R424	1-216-032-00	METAL CHIP	200 5% 1/10W
R425	1-216-032-00	METAL CHIP	200 5% 1/10W
R426	1-216-032-00	METAL CHIP	200 5% 1/10W
R427	1-216-032-00	METAL CHIP	200 5% 1/10W
R428	1-216-206-00	METAL GLAZE	2.2K 5% 1/8W
R429	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R430	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
< SWITCH >			
S401	1-762-172-11	SWITCH, ROTARY (ON/OFF) (640PF, 730PF, 400PFCS, 100PF, 100PF, 240PF, 240PF, 241PF)	
S401	1-762-172-21	SWITCH, ROTARY (ON/OFF) (700PF, 700PF, 340PF, 400PFCS, 100PF, 100PF)	
S403	1-571-977-11	SWITCH, TACTIL (● REC)	
S420	1-571-977-11	SWITCH, TACTIL (● PAUSE)	
*****			
*	A-6782-427-A	PS-327 BOARD, COMPLETE (EXCEPT 730PF, 400PF, 240PFCS, 940PFCS, 940PFCS)	
*	A-6782-439-A	PS-349 BOARD, COMPLETE (730PF, 400PF, 740PFCS, 940PFCS, 940PFCS)	
*****			
(Ref. No 1,000 series)			
*	Q-951-093-01	HEAT SINK	
	7-688-646-79	SCREW +W/TP 3/16 TYPES 4T-7	
< CAPACITOR >			
△C101	1-104-795-31	FILM	0.1uF 20% 250V
△C102	1-104-795-31	FILM	0.1uF 20% 250V
△C103	1-107-401-11	ELECT	150uF 20% 200V
△C103	1-107-414-11	ELECT	220uF 20% 400V
△C104	1-101-740-00	CERAMIC	470PF 10% 500V (EXCEPT 730PF, 400PF, 240PFCS, 940PFCS, 940PFCS)
△C104	1-104-720-11	CERAMIC	0.001uF 10% 400V (730PF, 400PF, 240PFCS, 940PFCS, 940PFCS)
△C105	1-101-740-00	CERAMIC	470PF 10% 400V (EXCEPT 730PF, 400PF, 240PFCS, 940PFCS, 940PFCS)
△C105	1-161-120-13	CERAMIC	0.001uF 10% 400V (730PF, 400PF, 240PFCS, 940PFCS, 940PFCS)
△C106	1-104-320-31	CERAMIC	0.001uF 10% 400V (730PF, 400PF, 240PFCS, 940PFCS, 940PFCS)
△C107	1-101-068-11	CERAMIC	0.0015uF 20% 500V (EXCEPT 730PF, 400PF, 240PFCS, 940PFCS, 940PFCS)

The components identified by mark △ or dotted line with \* are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Value	Tol.	Remark
ΔC107	1-164-320-11	CERAMIC (733HF/MFCS, 740HFPL, 940HFCS/HPFS)	0.001μF	10%	90V
ΔC108	1-164-320-11	CERAMIC (733HF/MFCS, 740HFPL, 940HFCS/HPFS)	0.001μF	10%	90V
C121	1-126-103-11	ELECT	470μF	20%	16V
C122	1-124-473-11	ELECT	1000μF	20%	10V
C125	1-126-213-11	ELECT	22μF	20%	50V
C131	1-126-490-11	ELECT	220μF	20%	16V
C132	1-126-233-11	ELECT	22μF	20%	50V
C133	1-124-477-11	ELECT	47μF	20%	25V
C141	1-124-477-11	ELECT	47μF	20%	25V
C142	1-126-101-11	ELECT	100μF	20%	16V
C161	1-124-126-00	ELECT	47μF	20%	10V
C162	1-124-442-00	ELECT	220μF	20%	6.3V
C171	1-124-604-00	ELECT	330μF	20%	10V
C181	1-163-091-11	CERAMIC CHIP	0.01μF		50V
C182	1-124-477-11	ELECT	47μF	20%	25V
C183	1-163-071-11	CERAMIC CHIP	0.01μF		50V
C184	1-124-916-11	ELECT	47μF	20%	50V
C185	1-163-071-11	CERAMIC CHIP	0.01μF		50V
C186	1-124-916-11	ELECT	47μF	20%	50V
C187	1-163-071-11	CERAMIC CHIP	0.01μF		50V
C188	1-124-916-11	ELECT	47μF	20%	50V
C189	1-163-071-11	CERAMIC CHIP	0.01μF		50V
C190	1-163-071-11	CERAMIC CHIP	0.01μF		50V
C191	1-124-916-11	ELECT	22μF	20%	50V
< AC INLET >					
ΔC1101	1-251-174-11	INLET, AC (HORIZONTAL) (AC IN-)			
ΔC1101	1-251-175-11	INLET, AC (AC IN-) (EXCEPT 733HF/MFCS, 740HFPL, 940HFCS/HPFS)			
< CONNECTOR >					
C101	1-770-015-11	CONNECTOR, BOARD TO BOARD 19P			
C102	1-495-821-11	CONNECTOR, BOARD TO BOARD 8P			
< COMPOSITION CIRCUIT BLOCK >					
ΔCP101	1-413-895-11	POWER BLOCK (EXCEPT 733HF/MFCS, 740HFPL, 940HFCS/HPFS)			
ΔCP101	1-413-206-11	POWER BLOCK (733HF/MFCS, 740HFPL, 940HFCS/HPFS)			
ΔCP102	1-447-811-11	UNIT, DC-DC CONVERTER			
< DIODE >					
ΔD101	8-719-510-06	DIODE 3A960			
D131	8-719-200-82	DIODE 13E52			
D102	8-719-911-19	DIODE 1SS145-25			
D162	8-719-109-85	DIODE 1R6, 1R52C			

Ref. No.	Part No.	Description	Value	Tol.	Remark
< FUSE >					
ΔF101	1-532-743-11	FUSE, GLASS CILINDRICAL (DIA. 5) (2A/125V) (EXCEPT 733HF/MFCS, 740HFPL, 940HFCS/HPFS)			
ΔT101	1-576-228-11	FUSE (R.B.C.) (72AH/250V) (733HF/MFCS, 740HFPL, 940HFCS/HPFS)			
< FUSE HOLDER >					
FH01	1-533-203-11	FUSE HOLDER			
FH02	1-576-292-11	FUSE HOLDER			
< IC >					
ΔIC101	3-759-189-00	IC PIC22E11			
< COIL >					
ΔL121	1-403-206-11	COIL, CHoke 22μH			
ΔL122	1-403-506-11	COIL, CHoke 22μH			
L131	1-400-409-00	INDUCTOR 10μH			
L132	1-404-142-11	INDUCTOR 10μH			
L133	1-404-142-11	INDUCTOR 10μH			
< LINE FILTER >					
ΔLF101	1-009-976-11	FILTER, LINE			
ΔLF102	1-009-976-11	FILTER, LINE (733HF/MFCS, 740HFPL, 940HFCS/HPFS)			
< IC LINK >					
ΔPS121	1-532-437-00	LINK, IC 1.0A (ICP-R25)			
ΔPS122	1-532-437-00	LINK, IC 1.0A (ICP-R25)			
ΔPS123	1-532-437-00	LINK, IC 1.0A (ICP-R25)			
ΔPS131	1-532-436-00	LINK, IC 0.4A (ICP-R10)			
< TRANSISTOR >					
ΔQ131	8-729-140-50	TRANSISTOR 2SD238-04			
Q132	8-729-421-22	TRANSISTOR UM211			
ΔQ161	8-729-140-50	TRANSISTOR 2SD238-04			
< RESISTOR >					
ΔR101	1-214-947-60	RESISTOR 2.7K 1% 1/2W (733HF/MFCS, 740HFPL, 940HFCS/HPFS)			
ΔR102	1-202-729-00	RESISTOR 6.0K 20% 1/2W (EXCEPT 733HF/MFCS, 740HFPL, 940HFCS/HPFS)			
R125	1-210-323-11	CARBON 3.3K 5% 1/4W F			
R131	1-249-413-11	CARBON 1K 5% 1/4W F			
R132	1-216-430-11	RESISTOR METAL OXIDE 50 5% 1/4 W F			
R171	1-216-061-00	METAL CHIP 5.1K 5% 1/10W			
R141	1-216-089-00	METAL CHIP 47K 5% 1/10W			
R161	1-249-412-11	CARBON 300 5% 1/4W F			
R152	1-249-478-11	CARBON 2.2 5% 1/2W F			

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with parts number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	QTY	SA	3M	F	Remark
W183	1-218-478-13	METAL OXIDE	340	SA	3M	F	
*****							
*	A-6782-424-A	RY-45 BOARD, COMPLETE (940HF/AFCS/AFMC/AFPC/AFPS/330HE/281HF)					
*	A-6282-021-A	RY-36 BOARD, COMPLETE (640HE, 340HF/AFPC, 340HF)					
*	A-6782-430-A	RY-45 BOARD, COMPLETE (940HF/AFCS/AFMC/AFPC)					
*****							
(Ref. No 2.000 see 142)							
CAPACITOR							
C002	1-162-123-00	CERAMIC CHIP	100PF	SA		50V	
C003	1-162-105-00	CERAMIC CHIP	50PF	SA		50V	
C006	1-128-157-11	ELECT	10uF	20%	16V		
C007	1-128-154-11	ELECT	47uF	20%	6.3V		
C008	1-128-164-11	ELECT	47uF	20%	6.3V		
C009	1-128-154-11	ELECT	47uF	20%	6.3V		
C010	1-128-154-21	ELECT	47uF	20%	6.3V		
C011	1-162-031-11	CERAMIC CHIP	0.1uF			50V	
C012	1-124-638-11	ELECT	32uF	20%	10V		
C013	1-162-103-00	CERAMIC CHIP	22PF	SA		50V	
C017	1-162-105-00	CERAMIC CHIP	23PF	SA		50V	
C019	1-162-117-00	CERAMIC CHIP	100PF	SA		50V	
C015	1-162-127-00	CERAMIC CHIP	210PF	SA		50V	
C019	1-162-031-11	CERAMIC CHIP	0.1uF			50V	
C085	1-124-638-11	ELECT	22uF	20%	10V		
C099	1-162-031-11	CERAMIC CHIP	0.1uF			50V	
C100	1-162-031-11	CERAMIC CHIP	0.1uF			50V	
C104	1-124-584-00	ELECT	200uF	20%	16V		
C062	1-162-031-11	CERAMIC CHIP	0.1uF			50V	
C063	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C264	1-124-257-00	ELECT	2.2uF	20%	50V		
C065	1-162-031-11	CERAMIC CHIP	0.6uF			50V	
C067	1-162-031-11	CERAMIC CHIP	0.91uF			50V	
C068	1-162-135-00	CERAMIC CHIP	500PF	SA		50V	
C069	1-162-135-00	CERAMIC CHIP	500PF	SA		50V	
C270	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C271	1-162-059-00	CERAMIC CHIP	0.01uF	10%		50V	
C274	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C275	1-124-740-11	ELECT	3uF	20%	50V		
C276	1-162-031-11	CERAMIC CHIP	0.04uF			50V	
C001	1-162-032-91	CERAMIC CHIP	0.022uF			50V	
C002	1-162-032-91	CERAMIC CHIP	0.022uF			50V	
C003	1-162-032-91	CERAMIC CHIP	0.022uF			50V	
C004	1-162-032-91	CERAMIC CHIP	0.1uF			50V	
C005	1-162-032-91	CERAMIC CHIP	0.022uF			50V	
C006	1-162-032-91	CERAMIC CHIP	100PF	SA		50V	
C007	1-162-038-91	CERAMIC CHIP	0.1uF			25V	

Ref. No.	Part No.	Description	QTY	SA	3M	F	Remark
C004	1-124-584-00	ELECT	100uF			20%	10V
C005	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C010	1-124-584-00	ELECT	100uF			20%	10V
C011	1-162-032-11	CERAMIC CHIP	0.01uF			50V	
C017	1-104-326-11	CERAMIC CHIP	0.13uF			25V	
C084	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C015	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C016	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C017	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C018	1-162-031-11	CERAMIC CHIP	0.01uF			50V	
C022	1-162-125-00	CERAMIC CHIP	330PF	SA		50V	
C024	1-124-259-00	ELECT	33uF	20%		16V	
C027	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
C029	1-162-034-11	CERAMIC CHIP	0.01uF			50V	
C030	1-162-111-00	CERAMIC CHIP	50PF	SA		50V	
C034	1-162-099-00	CERAMIC CHIP	10PF	SA		50V	
(940HF/AFCS/AFMC/AFPC)							
C038	1-162-031-11	CERAMIC CHIP	0.01uF			50V	
C039	1-162-099-00	CERAMIC CHIP	10PF	SA		50V	
(940HF/AFCS/AFMC/AFPC)							
C040	1-162-031-11	CERAMIC CHIP	0.01uF			50V	
C042	1-128-169-11	ELECT	3uF	20%		50V	
C050	1-164-252-11	CERAMIC CHIP	0.01uF			50V	
(940HF/AFCS/AFMC/AFPC)							
C051	1-162-251-11	CERAMIC CHIP	100PF	SA		50V	
(940HF/AFCS/AFMC/AFPC)							
C054	1-102-121-00	CERAMIC CHIP	150PF	SA		50V	
(940HF/AFCS/AFMC/AFPC)							
C055	1-162-245-11	CERAMIC CHIP	50PF	SA		50V	
(940HF/AFCS/AFMC/AFPC)							
C066	1-162-038-91	CERAMIC CHIP	0.1uF			25V	
(940HF/AFCS/AFMC/AFPC)							
C057	1-128-153-11	ELECT	10uF	20%		16V	
(940HF/AFCS/AFMC/AFPC)							
C059	1-162-077-91	CERAMIC CHIP	0.1uF			50V	
C060	1-162-088-00	CERAMIC CHIP	5PF			50V	
C062	1-161-109-00	CERAMIC CHIP	47PF	SA		50V	
C009	1-162-021-11	CERAMIC CHIP	0.01uF			50V	
C010	1-162-031-11	CERAMIC CHIP	0.01uF			50V	
C017	1-162-035-00	CERAMIC CHIP	0.047uF			50V	
C018	1-162-104-00	CERAMIC CHIP	30PF	SA		50V	
C021	1-128-154-11	ELECT	47uF	20%		6.3V	
C067	1-162-115-00	CERAMIC CHIP	82PF	SA		50V	
CONNECTOR							
C0001	1-572-828-11	CONNECTOR, BOARD TO BOARD 14P					
C0002	1-572-828-11	CONNECTOR, BOARD TO BOARD 14P					
C0003	1-548-988-11	CONNECTOR, FCC/AFPC (LIF) 13P					
* C0002	1-584-025-00	PLK, CONNECTOR 4P					
* C0003	1-564-013-11	PLK, CONNECTOR 3P					

Qty	Part No.	Description	Remark	Qty	Part No.	Description	Remark
< DIODE >							
0001	8-719-911-19	DIODE 1SS119-25 (723HF/AFCS/AFNS/AFPA/340HF, 760HF)		1004	1-408-976-21	INDUCTOR 33uH	
0001	8-719-901-78	DIODE 1SS144		1005	1-810-521-11	INDUCTOR 100uH	
0002	8-719-901-78	DIODE 1SS144		1006	1-410-516-11	INDUCTOR 27uH	
0003	8-719-901-78	DIODE 1SS144		1006	1-410-513-11	INDUCTOR 22uH	
				1007	1-410-525-11	INDUCTOR 250uH	
				1008	1-410-521-11	INDUCTOR 100uH	
				1260	1-408-982-21	INDUCTOR 100uH	
				1009	1-408-918-00	INDUCTOR 220uH	
				1002	1-408-949-00	INDUCTOR 220uH	
				1000	1-408-982-21	INDUCTOR 100uH	
				1004	1-408-982-21	INDUCTOR 100uH	
				1010	1-408-985-21	INDUCTOR 100uH	
				1012	1-408-982-21	INDUCTOR 100uH	
				1013	1-408-970-21	INDUCTOR 10uH (940HF/AFCS/AFNS/AFPA)	
				1014	1-408-970-21	INDUCTOR 10uH (940HF/AFCS/AFNS/AFPA)	
				1000	1-408-983-21	INDUCTOR 100uH	
				1001	1-410-521-11	INDUCTOR 100uH (940HF/AFCS/AFNS/AFPA)	
				1001	1-410-521-11	INDUCTOR 100uH (940HF/AFCS/AFNS/AFPA)	
				1001	1-408-977-21	INDUCTOR 33uH	
				1005	1-410-521-11	INDUCTOR 100uH	
				1005	1-408-978-21	INDUCTOR 50uH	
				1001	1-408-977-21	INDUCTOR 33uH	
				< TRANSISTOR >			
J001	1-216-295-91	CONDUCTOR, CHIP (2012)		0002	8-729-424-19	TRANSISTOR UM213	
J003	1-216-295-91	CONDUCTOR, CHIP (2012)		0005	8-729-230-49	TRANSISTOR 2SC2712-VG (EXCEPT 640HF, 740HF/AFPA, 741HF)	
J0021	1-216-296-00	METAL CHIP 0 5% 1/8W		0006	8-729-424-19	TRANSISTOR UM213 (723HF/AFCS/AFNS/ (EXCEPT 640HF, 740HF/AFPA, 741HF)	
J0022	1-216-296-00	METAL CHIP 0 5% 1/8W		0007	8-729-216-21	TRANSISTOR 2SA1162-Y (723HF/AFCS/AFNS/ (EXCEPT 640HF, 740HF/AFPA, 741HF)	
J0023	1-216-296-00	METAL CHIP 0 5% 1/8W		0008	8-729-424-67	TRANSISTOR UM210 (723HF/AFCS/AFNS/ (EXCEPT 640HF, 740HF/AFPA, 741HF)	
J0025	1-216-296-00	METAL CHIP 0 5% 1/8W		0009	8-729-424-67	TRANSISTOR UM216 (723HF/AFCS/AFNS/ (EXCEPT 640HF, 740HF/AFPA, 741HF)	
J0026	1-216-295-91	CONDUCTOR, CHIP (2012)		0036	8-729-230-49	TRANSISTOR 2SC2712-VG	
J0027	1-216-296-00	METAL CHIP 0 5% 1/8W		0010	8-729-421-19	TRANSISTOR UM213	
J0028	1-216-296-00	METAL CHIP 0 5% 1/8W		0011	8-729-521-12	TRANSISTOR 2SA1854	
J0029	1-216-296-00	METAL CHIP 0 5% 1/8W		0017	8-729-230-49	TRANSISTOR 2SC2712-VG	
J0030	1-216-295-91	CONDUCTOR, CHIP (2012)		0018	8-729-421-19	TRANSISTOR UM213	
J0031	1-216-296-00	METAL CHIP 0 5% 1/8W		0019	8-729-230-49	TRANSISTOR 2SC2712-VG	
J0032	1-216-295-91	CONDUCTOR, CHIP (2012)		0040	8-729-230-49	TRANSISTOR 2SC2712-VG	
J0033	1-216-296-00	METAL CHIP 0 5% 1/8W		0041	8-729-216-21	TRANSISTOR 2SA1162-Y	
J0034	1-216-296-00	METAL CHIP 0 5% 1/8W		0049	8-729-216-22	TRANSISTOR 2SA1162-Y (940HF/AFCS/AFNS/ AFPA)	
J0035	1-216-296-00	METAL CHIP 0 5% 1/8W		0091	8-729-216-22	TRANSISTOR 2SA1162-Y (940HF/AFCS/AFNS/ AFPA)	
J0036	1-216-296-00	METAL CHIP 0 5% 1/8W		0092	8-729-421-19	TRANSISTOR UM213 (940HF/AFCS/AFNS/ AFPA)	
J0037	1-216-296-00	METAL CHIP 0 5% 1/8W		0094	8-729-230-49	TRANSISTOR 2SC2712-VG	
J0038	1-216-296-00	METAL CHIP 0 5% 1/8W		0096	8-729-230-49	TRANSISTOR 2SC2712-VG	
J0039	1-216-296-00	METAL CHIP 0 5% 1/8W					
J0040	1-216-296-00	METAL CHIP 0 5% 1/8W					
J0041	1-216-291-00	METAL CHIP 0 5% 1/8W					
J0042	1-216-291-00	METAL CHIP 0 5% 1/8W					
J0043	1-216-291-00	METAL CHIP 0 5% 1/8W					
J0044	1-216-296-00	METAL CHIP 0 5% 1/8W					
J0045	1-216-296-00	METAL CHIP 0 5% 1/8W					
J0046	1-216-296-00	METAL CHIP 0 5% 1/8W					
J0047	1-216-295-91	CONDUCTOR, CHIP (2012)					
J0048	1-216-296-00	METAL CHIP 0 5% 1/8W					
J0049	1-216-295-91	CONDUCTOR, CHIP (2012)					
J0050	1-216-295-91	CONDUCTOR, CHIP (2012)					
J0051	1-216-295-91	CONDUCTOR, CHIP (2012)					
				< COIL >			
L001	1-408-976-21	INDUCTOR 33uH					
L002	1-408-982-21	INDUCTOR 100uH					

Req. No	Part No.	Description	Remark
0011	8-729-236-00	TRANSISTOR	252212-Y6
0012	8-729-216-24	TRANSISTOR	22A162 Y
		RESISTOR	
0002	1-216-035-00	METAL CHIP	170 5% 1/10W
0003	1-216-052-00	METAL CHIP	1.5K 5% 1/10W
0004	1-216-067-13	METAL CHIP	4.7K 4.5% 1/10W
0005	1-216-036-00	METAL CHIP	170 5% 1/10W
0009	1-216-059-13	METAL CHIP	2.2K 0.5% 1/10W (EXCEPT 640HF, 740HF/HP73, 741HF)
0010	1-216-059-18	METAL CHIP	1.2K 0.5% 1/10W (EXCEPT 640HF, 740HF/HP73, 741HF)
0012	1-216-039-00	METAL CHIP	120K 5% 1/10W (EXCEPT 640HF, 740HF/HP73, 741HF)
0014	1-216-117-00	METAL CHIP	470W 5% 1/10W (EXCEPT 640HF, 740HF/HP73, 741HF)
0022	1-216-035-00	METAL CHIP	1.2K 5% 1/10W
0043	1-216-063-00	METAL CHIP	27K 5% 1/10W
0044	1-216-063-00	METAL CHIP	47K 5% 1/10W
0045	1-216-045-00	METAL CHIP	600 5% 1/10W
0046	1-216-067-00	METAL CHIP	5.6K 5% 1/10W
0047	1-216-295-91	CONDUCTOR, CHIP	420(2)
0048	1-216-421-11	CARDOM	2.2K 5% 1/4W F
0242	1-216-405-90	METAL CHIP	230 5% 1/10W
0243	1-216-067-00	METAL CHIP	5.6K 5% 1/10W
0245	1-216-033-00	METAL CHIP	230 5% 1/10W
0246	1-216-051-00	METAL CHIP	1.2K 5% 1/10W
0247	1-216-035-00	METAL CHIP	270 5% 1/10W
0248	1-210-097-00	METAL CHIP	180K 5% 1/10W
0211	1-216-079-00	METAL CHIP	18K 5% 1/10W
0258	1-216-073-00	METAL CHIP	180 5% 1/10W
0054	1-216-023-00	METAL CHIP	62 5% 1/10W
0062	1-216-037-00	METAL CHIP	230 5% 1/10W
0067	1-216-081-00	METAL CHIP	22K 5% 1/10W
0068	1-216-404-21	METAL CHIP	13 0.5% 1/10W
0066	1-216-023-00	METAL CHIP	62 5% 1/10W
0067	1-216-023-00	METAL CHIP	62 5% 1/10W
0011	1-216-037-00	METAL CHIP	330 5% 1/10W
0032	1-216-023-00	METAL CHIP	62 5% 1/10W
0030	1-216-041-00	METAL CHIP	52K 5% 1/10W
0036	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
0037	1-216-049-00	METAL CHIP	1K 5% 1/10W
0035	1-216-051-00	METAL CHIP	1.2K 5% 1/10W
0036	1-216-047-00	METAL CHIP	820 5% 1/10W
0038	1-216-075-00	METAL CHIP	12K 5% 1/10W
0042	1-216-619-11	METAL CHIP	47 0.5% 1/10W
0043	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
0244	1-216-423-11	CARDOM	3.2K 5% 1/4W F
0044	1-216-059-00	METAL CHIP	1.2K 5% 1/10W

Req. No	Part No.	Description	Remark
0047	1-216-078-00	METAL GLAZE	16K 5% 1/10W
0056	1-216-033-00	METAL CHIP	230 5% 1/10W
0057	1-216-037-00	METAL CHIP	230 5% 1/10W
0056	1-216-053-00	METAL CHIP	4.7K 5% 1/10W
0059	1-216-049-00	METAL CHIP	47K 5% 1/10W
0300	1-216-433-11	CARDOM	22K 5% 1/4W
0061	1-216-264-00	METAL GLAZE	1.5K 5% 1/8W
0062	1-216-061-00	METAL CHIP	3.2K 5% 1/10W
0063	1-216-047-00	METAL CHIP	820 5% 1/10W
0061	1-216-021-00	METAL CHIP	27 5% 1/10W (930HF/HP73/HP70/HP72)
0064	1-216-041-00	METAL CHIP	670 5% 1/10W (930HF/HP73/HP70/HP72)
0065	1-216-054-00	METAL GLAZE	1.6K 5% 1/10W (930HF/HP73/HP70/HP72)
0066	1-216-095-00	METAL CHIP	82K 5% 1/10W (930HF/HP73/HP70/HP72)
0067	1-216-043-00	METAL CHIP	47K 5% 1/10W (930HF/HP73/HP70/HP72)
0068	1-216-683-11	METAL CHIP	39K 0.5% 1/10W (930HF/HP73/HP70/HP72)
0068	1-216-063-00	METAL CHIP	1.5K 5% 1/10W
0082	1-216-215-91	CONDUCTOR, CHIP	22(2)
0084	1-216-477-00	METAL CHIP	35K 5% 1/10W
0087	1-216-075-00	METAL CHIP	12K 5% 1/10W
0089	1-216-043-91	METAL GLAZE	560 5% 1/10W
0044	1-216-077-00	METAL CHIP	85K 5% 1/10W
0045	1-216-075-00	METAL CHIP	12K 5% 1/10W
0046	1-216-295-01	CONDUCTOR, CHIP	22(2)
0047	1-216-045-00	METAL CHIP	680 5% 1/10W
0048	1-216-039-00	METAL CHIP	330 5% 1/10W
0077	1-216-030-00	METAL CHIP	390 5% 1/10W
0078	1-216-047-00	METAL CHIP	320 5% 1/10W
0079	1-216-049-00	METAL CHIP	8K 5% 1/10W
2068	1-216-205-91	CONDUCTOR, CHIP	22(2)
0070	1-216-039-00	METAL CHIP	390 5% 1/10W
0071	1-216-036-00	METAL CHIP	360 5% 1/10W

Ref. No.	Part No.	Description	Remark
		ACCESSORIES	
		*****	
51	1-467-943-11	SWITCH BLOCK, CONTROL (840HF, 940HFC/AFCS)	
51	1-467-943-21	SWITCH BLOCK, CONTROL (780HF)	
51	1-473-029-11	SWITCH BLOCK, CONTROL (781HF)	
104	1-789-354-11	CABLE, FLEXIBLE FLAT (1900IE)	
118	1-555-110-00	CABLE, P37	
156	1-500-144-11	HEAD, EC	
165	1-506-465-11	PJ1R, CONNECTOR 6P	
202	8-848-576-02	DYNAM ASSY, ROTARY UPPER (848-45-R) (EXCEPT 840HF/AFCS/AFNFC/AFPC)	
203	8-848-594-02	DYNAM ASSY, ROTARY UPPER (848-51-R) (840HF/AFCS/AFNFC/AFPC)	
260	1-782-076-11	SWITCH, ROTARY	
MSD1	8-848-575-10	DYNAM ASSY (DYN-45-R) (EXCEPT 840HF/AFCS/AFNFC/AFPC)	
MSD1	8-848-593-10	DYNAM ASSY (DYN-51-R) (840HF/AFCS/AFNFC/AFPC)	
MSD2	X-3943-003-11	MOTOR ASSY, CAM	
MSD2	1-589-409-11	MOTOR, DC (CAPSTAN)	
		*****	
		ACCESSORIES & PACKING MATERIALS	
		*****	
	1-447-947-11	REMOTE COMMANDER (RMT-V114) (780HF, 781HF)	
	1-467-947-21	REMOTE COMMANDER (RMT-V154B) (733HF/AFCS/AFNFC/AFPC)	
	1-467-948-11	REMOTE COMMANDER (RMT-V153) (840HF/AFCS/AFNFC/AFPC)	
	1-467-951-11	REMOTE COMMANDER (RMT-V154C) (840HF)	
	1-467-953-11	REMOTE COMMANDER (RMT-V162) (740HF/AFPC, 741HF)	
	1-467-951-11	REMOTE COMMANDER (RMT-V154C) (840HF)	
	1-543-908-11	ADAPTER, CONVERSION 2P (733HF, AFCS, 740HF/AFPC, 940HFC/AFPC)	
Δ	1-575-121-11	CORD, POWER SUPPLY (733HF/AFCS, 740HF/AFPC, 940HFC/AFPC) (250V/7, 5A)	
	1-575-334-11	CORD, CONNECTION	
	1-696-582-11	CORD, CONNECTION (RFS3C)	
Δ	1-754-676-11	CORD, POWER (EXCEPT 733HF/AFCS, 740HF/AFPC, 940HFC/AFPC)	
	1-769-121-11	HOUSE, INTERJECT CABLE (740HF/AFPC, 741HF, 760HF, 761HF, 840HF/AFCS/AFNFC/AFPC)	
	1-769-397-11	WIRE, FLAT TYPE 1HF	
	3-759-161-22	MANUAL, INSTRUCTION (740HF/AFPC, 741HF) (ENGLISH)	
	3-759-161-32	MANUAL, INSTRUCTION (740HF-Canadian, 741HF-Canadian) (FRENCH)	

Ref. No.	Part No.	Description	Remark
	3-759-161-22	MANUAL, INSTRUCTION (740HF, 760HF) (ENGLISH)	
	3-759-161-32	MANUAL, INSTRUCTION (740HF-Canadian) (FRENCH)	
	3-759-079-12	MANUAL, INSTRUCTION (733HF/AFCS/AFNFC/AFPC) (ENGLISH/JAPANESE)	
	3-759-080-22	MANUAL, INSTRUCTION (940HF/AFCS/AFNFC/AFPC) (ENGLISH)	
	3-759-080-32	MANUAL, INSTRUCTION (940HF-Canadian) (FRENCH)	
	3-759-080-42	MANUAL, INSTRUCTION (940HFC/AFPC) (SPANISH)	
	3-759-081-22	MANUAL, INSTRUCTION (840HF) (ENGLISH)	
	3-759-081-32	MANUAL, INSTRUCTION (840HF-Canadian) (FRENCH)	
*	3-900-054-01	INDIVIDUAL CARTON (740HF/AFPC)	
*	3-900-054-01	CUSHION (CUPPER) (840HF, 733HF/AFCS/AFNFC/AFPC, 740HF/AFPC, 741HF)	
*	3-900-056-01	CUSHION (LOWER) (840HF, 733HF/AFCS/AFNFC/AFPC, 740HF/AFPC, 741HF)	
*	3-900-081-01	INDIVIDUAL CARTON (730HF)	
*	3-900-082-01	CUSHION (CUPPER) (780HF, 781HF, 840HF/AFCS/AFNFC/AFPC)	
*	3-900-083-01	CUSHION (LOWER) (780HF, 781HF, 840HF/AFCS/AFNFC/AFPC)	
*	3-902-317-01	INDIVIDUAL CARTON (840HF/AFPC)	
*	3-902-318-01	INDIVIDUAL CARTON (781HF)	
*	3-902-319-01	INDIVIDUAL CARTON (840HFC/AFPC)	
*	3-902-320-01	INDIVIDUAL CARTON (741HF)	
*	3-902-321-01	INDIVIDUAL CARTON (840HF)	
*	3-902-322-01	INDIVIDUAL CARTON (733HF/AFCS/AFNFC/AFPC)	
		*****	

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une croix Δ ou une ligne pointillée avec une croix Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.



Ref. No.	Part No.	Description	Remark
***** HARDWARE LIST *****			
41	7-685-648-79	SCREW -DTP 3/12 TYPE2 IT-1	
42	7-682-645-01	SCREW +PS 3/16	
43	7-621-255-15	SCREW +S 3/16	
44	7-602-543-04	SCREW +P 3/16	
45	7-685-646-79	SCREW -DTP 3/14 TYPE2 IT-1	
46	7-685-646-79	SCREW -DTP 3/16 TYPE2 IT-1	
47	7-024-106-04	STOP RING 3 0. TYPE -E	

SECTION 6  
INTERFACE AND IC PIN FUNCTION

6-1. SYSTEM CONTROL—VIDEO BLOCK INTERFACE (MA-214 BOARD IC201)

Signal	Pin No.	I/O	STOP	FF	REW	TAPE THREADING	TAPE UNTHREADING	PB	PB + PAUSE	SLOW	x 2	PICTURE CUE	SEARCH REVIEW	REC	REC + PAUSE
V-EB	IC104④	O	H	H	H	H	H	L	L	L	L	L	L	H	H
RF-SW P (SW2H)	IC105⑤	O	H	H	H	H	H	L	L	L	L	L	L	H	H
CLIPBY PRUTE	IC200⑩	O	L	L	L	L	L	L	L	L	L	L	L	L	L
HA-SP	IC201⑪	O	L	L	L	L	L	L	L	L	L	L	L	L	L
LP	IC202⑫	O	L	L	L	L	L	L	L	L	L	L	L	L	L
REC-P	IC203⑬	O	L	L	L	L	L	L	L	L	L	L	L	L	L
REC	IC204⑭	O	L	L	L	L	L	L	L	L	L	L	L	L	L
V SYNC	IC205⑮	I	H	H	H	H	H	L	L	L	L	L	L	L	L
OSD MUTE	IC206⑯	O	L	L	L	L	L	L	L	L	L	L	L	L	L
CTL REC	IC207⑰	O	L	L	L	L	L	L	L	L	L	L	L	L	L
SYNC	IC208⑱	O	L	L	L	L	L	L	L	L	L	L	L	L	L
FXS	IC209⑲	O	L	L	L	L	L	L	L	L	L	L	L	L	L
CRS SETTEL	IC210⑳	O	L	L	L	L	L	L	L	L	L	L	L	L	L

- ① 3RHS 30V delay pulse synchronizing with drum rotation.  
 ② Normally "L" or "H" when the video signal is not detected.  
 ③ V period "FF" pulse.  
 ④ "L" in the SP mode. Selected according to the recording mode.  
 ⑤ Selected according to the tape recording mode.

- ⑥ Composite sync signal (positives).  
 ⑦ "H" when menu screen or 4/99 back screen.  
 ⑧ Selected by BEZ mode. "L" in the SP mode.  
 ⑨ "H" while APV is set.

Mode	SP	LP	EP
Signal			
SP⑧	L	H	H
EP⑨	L	L	L

6-2. SYSTEM CONTROL—SERVO PERIPHERAL CIRCUIT INTERFACE (MA-214 BOARD IC201)

Signal	Pin No.	I/O	STOP	FF	REW	TAPE TIMEAD- RING	TAPE UNTH- READING	PB	PB - PAUSE	SLOW	X2	PICTURE		SEARCH	REC	REG - PAUSE	PB INDEX WRT/ERS
												VIEW	REVIEW				
REC CTL	K201①	0	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	
CAP STOP	K201②	0	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	L	*3	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	H-Z (OLD)	
STEP PLS	K201③	0	L	L	L	L	L	L	L	*2	L	L	L	L	L	L	
CTL REC	K201④	0	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
CTL INDEX	K201⑤	0	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
PB CTL	K201⑥	1	H	*8	*8	*1	*1	H/L	H/L	*2	*6	*6	*6	*8	*1	H	H
DRUM PG	K201⑦	1	*4	*7	*7	*5	*5	*7	*7	*2	*7	*7	*7	*7	*7	*7	*7
DRUM FG	K201⑧	1	*2	*8	*8	*5	*5	*8	*8	*8	*8	*8	*8	*8	*8	*8	*8
CAP FC	K201⑨	1	H/L	*6	*8	*5	*5	*6	H/L	*9	*8	*8	*8	*8	*6	H/L	
CAP DA	K201⑩	0	*10	*10	*10	*10	*10	*11	*10	*10	*11	*11	*11	*11	*11	*11	
DRUM STA	K201⑪	0	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	
CTL STEP	K201⑫	0	L	L	L	L	L	L	L	*15	L	L	L	L	L	L	L

\* 1. 30Hz pulse.

\* 2. Pulse in tape running.

\* 3. Reverse logic pulse of STEP PLS.

\* 4. "L" when drum rotation stops

\* 5. Unstable period pulse.

\* 6. Pulse of period proportionate to tape speed.

\* 7. 30Hz pulse

\* 8. 360Hz pulse.

\* 9. Pulse in tape running.

\* 10. Approx. 2 msec. period "H" or "L" pulse.

\* 11. Approx. 1.5 msec. period "H" or "L" pulse.

\* 12. Approx. 3 msec. period "H" or "L" pulse.

\* 13. "H" in FWD direction and STEP drive.

6-3. SYSTEM CONTROL - MECHANISM BLOCK INTERFACE (MA-214 BOARD IC201)

Signal	Pin No.	U/O	CASSETTE LOADING	CASSETTE UNLOAD- ING	TAPE THREAD- ING	TAPE LURTH- READING	STOP	FF	REW	PB PAUSE	SLOW	XZ	PICTURE CUE	SEARCH REVIEW	REC PAUSE
CAM LOAD	IC200②	0	L	H	L	H	L	L	L	L	L	L	L	L	L
CAM UNLOAD	IC200③	0	L	L	H	L	L	L	L	L	L	L	L	L	L
CAM LV	IC200④	0	L	L	L	H	L	L	L	L	L	L	L	L	L
MP00E 1	IC200⑤	1	H	L	L	L	H	H	H	H	H	H	H	H	H
MP00E 2	IC200⑥	1	L	L	L	H	L	L	L	L	L	L	L	L	L
MP00E 3	IC200⑦	1	L	L	L	H	L	L	L	L	L	L	L	L	L
MP00E 4	IC200⑧	1	L	L	L	H	L	L	L	L	L	L	L	L	L
REC PRF	IC200⑨	1	L	H	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L
T REEL FG	IC200⑩	1	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L
S REEL FG	IC200⑪	1	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L	H/L
END LED	IC200⑫	0	H	H	H	H	H	H	H	H	H	H	H	H	H
CAP TRQ 1	IC200⑬	0													
CAP TRQ 2	IC200⑭	0													
CAP TRQ 3	IC200⑮	0													
CAP STOP	IC200⑯	0	L	L	L	H	H	H	H	H	H	H	H	H	H
CAP RVS	IC200⑰	0	H	H	L	H	H/L	L	L	L	L	L	L	L	L
CAP DA	IC200⑱	0													
T SENS	IC200⑲	1	H	H	H	H	H	H	H	H	H	H	H	H	H
S SENS	IC200⑳	1	H	H	H	H	H	H	H	H	H	H	H	H	H

- \* 1. Uncertainty
- \* 2. "L" when the eaving protection tab is bent, "H" when not bent.
- \* 3. Pulse of period proportionate to reel rotating speed.
- \* 4. Approx. 2 msec. period "H" pulse.
- \* 5. Pulse in tape running.
- \* 6. "L" only in tape running and when CAP RVS is "H".
- \* 7. Normally "L". 2 msec. period "H" pulse when tape top or tape end is detected

### 6-4. SYSTEM CONTROL — SYSTEM CONTROL PERIPHERAL CIRCUIT INTERFACE (MA-214 BOARD IC201)

Signal	Pin No.	I/O	I/O Level
ASUBRA DRST	IC201④	I	Normally "H", "L" when service interruption is detected or restored.
ASUBRA CR	IC201⑤	I	Chip select signal from the drive microprocessor. V period "L" pulse.
SE BUS	IC201⑥	I	Serial communication data from the timer microprocessor. V period "L" pulse.
SD BUS	IC201⑦	I	Serial communication data to the timer microprocessor. V period "L" pulse.
S CLIC	IC201⑧	I	Serial communication clock with the timer microprocessor. V period "L" pulse.

### 6-5. SYSTEM CONTROL — AUDIO BLOCK INTERFACE (MA-214 BOARD IC201)

Signal	Pin No.	I/O	STOP	FF	REW	TAPE LOADING	TAPE UNLOADING	PB	PB PAUSE	SLOW	X-2	PICTURE CUE	SEARCH REVIEW	REC	REC PAUSE
AF ENVELOP	IC201①	I	L	L	L	L	L	H	H	H	H	H	H	L	L
NA PG	IC201②	O	L	L	L	L	L	H	H	H	H	H	H	L	L
A BUTE	IC201③	O	L	L	L	L	L	H	H	H	H	H	H	L	L
RA SP	IC201④	O	L	L	L	L	L	H	H	H	H	H	H	L	L
NA REC-P	IC201⑤	O	L	L	L	L	L	H	H	H	H	H	H	L	L
AF REC-F	IC201⑥	O	L	L	L	L	L	H	H	H	H	H	H	L	L
AF SW-P	IC201⑦	O	L	L	L	L	L	H	H	H	H	H	H	L	L
AF SW JUNCTION	IC201⑧	O	L	L	L	L	L	H	H	H	H	H	H	L	L
FULLER	IC201⑨	O	L	L	L	L	L	H	H	H	H	H	H	L	L

① L: 20Hz 50% duty pulse approximately 5 msec, derived from RF SW-P.

② L: Selected according to SP/EP selector. "L" in the SP mode, "H" in the EP mode.

③ L: Selected according to the tape recording mode. "L" in the SP mode, "H" in the EP mode.

### 6-6. SYSTEM CONTROL — RF MODULATOR, INPUT SELECTION BLOCK INTERFACE (MA-214 BOARD IC201)

Signal	Pin No.	I/O	I/O Level	
LINE 1	IC201①	O	TUNER	LINE 2
LINE 2	IC201②	O	L	H
			L	L
			L	H

6-7. SERVO/SYSTEM CONTROL MICROPROCESSOR EXP87240-057Q (MA-214 BOARD KC203) PORT FUNCTION DESCRIPTION

Pin No.	Signal	I/O	Funcn	Function
1	REF SWP	O	DE switching pulse	
2	QVDT	O	False VD	
3	CHP ENBL	O	Fiber HD voltage and control	
4	XF RES F	O	RFN recording control	
5	REC P	O	Recording signal	
6	PE ON	O	Flange error	
7	REC CTL	I/O	REC CTL	
8	CAP TRQ1	O	Capstan current control	
9	HEATLAL	I/O	VCR control	
10	ENFT	O	EDIT control	
11	RV REC P	I/O	Normal audio recording mode R recording mode	
12	LP	O	H & L P mode	
13	CANLOAD	I/O	Load & motor status data into control	
14	CANLOAD	I/O	Head change control	
15	UNREPROFF	O	Generate IR and erasing protection the operation while input	
16	HEAD CONT	I/O	Head change control	
17	T SENS	I	Tape top sensor input	
18	S SENS	I	Tape web sensor input	
19	MAID CONT	O	Modulator power supply (R) (RF control)	
20	AV CONT	O	ON/OFF control (R) (RF control)	
21	NR SGRAM	I	H-ME SGRAM pin control	
22	SGRAM	I	H-SGRAM data read output	
23	VPH	O	Variable VPH W. P&B	
24	STEP PUL	O	Step pulse, R. Capstan step driving	
25	PAL W	O	H: EPSC on PAL TV. (R) used output	
26	NR BTSC	O	Color audio correction signal H: 1.5x XTAL (R) used output	
27	LE TRQE	O	H: (R) PAL (R) used output	
28	BLU	O	H: (R) type (R) used output	
29	C+CONT	O	H: output: BS digital mode (R) used output	
30	CAM LV	O	CAM LV control (R) used output	
31	QVDT	O	Capstan current control	
32	CAP TRQ2	O	Capstan current control signal 2 L: FF NEW to STOP	
33	CAP TRQ1	O	Capstan current control signal 1 L: SLOW speed down	
34	PAL	O	H: PAL (R) used output	
35	FULL CRN	O	Full erase control (R) used output	
36	A MUTE	O	Audio mute H: mute	
37	CAP STOP	O	Capstan step reversal L: Capstan stop	
38	HP	I	Head to L	

Pin No.	Signal	I/O	Function
39	ASURA RESET	I	System reset input
40	VSS		GND
41	X TAL		System clock 26.212
42	ASURA CS	I	Chip select signal. (R) 15:19 board (CA2)
43	ST BUS	O	Serial communication signal
44	3 CLK	I	3.579545 MHz clock
45	DEST 2	I	Destination judge input. (R) used output
46	AD	I	AD input for APV 2
47	AC CLR BUR	O	AC CLR BUR output
48	APSV LOS	I	H-FI tracking position adjustment
49	A VSS		GND
50	A VREF	I	AD just reference input. (UNSW) 3.0
51	A VYD	I	UDSR 3V
52	MODE 4	I	Cam encoder data 4
53	MODE 2	I	Cam encoder data 2
54	MODE 3	I	Cam encoder data 3
55	NEW	I	Confirmation sensor input. H: used output
56	RF ENV	I	Video playback signal envelope
57	RF ENV	I	H-FI audio playback signal envelope
58	RF SW VOS	I	Video head overdrive position adjustment
59	RF ENV	I	Video head overdrive position adjustment
60	REEL PO	I	3-wire reel PG input
61	REEL PU	I	3-wire reel PG input
62	RT JUDGE	I	4.433MHz input. (R) used output
63	V SW CTL	I	Composite sync input
64	DRM PG	I	Servo-CTL input
65	DRM PG	I	Drain PG input
66	CAP PG	I	Drain PG input
67	CAP PG	I	Capstan PG input
68	USB MUTE	O	Video output mute signal. H: Gray back. (R) used output
69	CAP RMS	O	Capstan reverse control H: Reverse
70	TRM DA	O	Capstan D/A output
71	TRM DA	O	Drain D/A output
72	FF	O	H: FF (R) used output
73	REC REVERSE	O	H: REC REVERSE
74	CTL COUNT INVT	I	CTL counter input. (R) used output
75	DEST 1	I	Destination judge input

Pin No.	Signal	IO	Function
79	LINE 1	0	Input selection control signal
80	SD 1	UX	Expanded port data
81	CLK 1	UX	Expanded port clock
82	LINE 2	0	Input selection control signal
83	NAFB	0	Audio output control signal. <b>N</b> - Normal work playback.
84	FBW1	U	PAWN output for ADC2
85	W TAPE	0	W - Write blank
86	N C	1	Not used (open)
87	TX		Not used (open)
88	VSS		GND
89	VDD		VCC5V 5V
90	VDD		VCC5V 5V
91	NA SF	0	For normal audio L: SF mode
92	ENV GAIN	0	Video envelope gain enable
93	CTL STEP	0	CTL step STEP operation control
94	CTL RE	0	H: CTL write
95	VFB	0	Video system feedback mode reversal L: Playback.
96	CTL BTRX	0	Index control output reverse. <b>R</b> : Erase
97	JOG	0	H: JOG
98	REC	0	Head amplifier recording power supply
99	ST	0	L: SF mode
100	SP SWF	U	AF selection pulse

6-8. TIMER/TUNER CONTROL MICROPROCESSOR MB89096PF-G-159-BND (HI-5/19 BOARD IC302) PORT FUNCTION DESCRIPTION

Pin No.	Signal	I/O	Function
1	CLK1		Liquid crystal oscillation pin (IC14-3 for ICR4)
2	CLK2		Liquid crystal oscillation pin (IC14-3 for ICR4)
3	MODE/EN10		Operation mode specification pin (IC10 when open)
4	INFO1/EN10		Operation mode specification pin (IC10 when open)
5	X.0		Liquid crystal oscillation pin (IC14-1 for audio)
6	X.1		Liquid crystal oscillation pin (IC14-1 for audio)
7	VSS		GND
8	RESSET	I	Reset input pin
9-12	N. C.		Not used pins
13	S-SHIFT CS	O	S-SHIFT chip select signal
14	TUNER V	I	TUNER V Syno signal input
15	RAM/RSSET	O	RAM/RSSET chip select signal (IC21 reset signal)
16	ZFC CS	O	Character generator chip select signal (IC4-24 board IC10)
17	POWER PATT	I	Power voltage drop detection pin
18	V SYNC	I	V sync input
19	POWER CONV	O	Main power supply control signal
20	ASPECT CS	O	ASPECT chip select signal (IC4-24 board IC10)
21	R DET	I	R DET signal input
22	FRG CS	O	FRG chip select signal (IC4-24 board IC10)
23	SEL	I/O	T BUS select/IC14-15 BUS select
24	SIA	I/O	IC BUS data bus
25	NOT SYNC	I/O	Syn. detection error
26	N. C.		Not used signal
27	F MONO	O	Tuner radio detect
28	VIDEO	I	Normally CH-D. V. Connected to ground by IC10
29	RAM/RSSET	O	RAM/RSSET chip select signal
30	STREED	I/O	Strobe pulse input
31	SP	I/O	RAM/RSSET pulse input
32	SIRCS IN	I	Reserve control input
33	PILL CLOCK	O	Tuner PLL clock
34	PILL DATA	O	Tuner PLL data
35	PILL ENABLE	O	Tuner chip select
36	TUN MUTE	O	Tuner mute pulse
37	SIRCS OUT	O	SIRCS signal output
38	A PRESET	O	Tuner channel select signal for auto preset
39-41	N. C.		Not used pins
42-48	SD-S11	O	RFIC segment 20-15
49	VDD		D. V.
50-52	S14-S16	O	RFIC segment 14-13

Pin No.	Signal	I/O	Function
53	VDD		D. V.
54-59	S11-S16	O	RFIC segment 13-8
60	VSS		GND
60-65	S17-S21	O	RFIC segment 7-1
66	RD	O	RFIC grid 6
67	VDD		D. V.
68-71	TU-TC	O	RFIC Grid 7-1
72	LEAD IN	O	LEAD-IN chip select signal (MF-232/271 board IC10)
73	TUNER CONV	O	Tuner power supply control
74	RAM	I	Serial data input
75	SO BUS	I	Serial data output
76	SR CLR	O	Serial communication clock
77	SR CLR	O	Serial communication clock
78	SR CLR	O	Serial communication clock
79	SR CLR	O	Serial communication clock
80	SR CLR	O	Serial communication clock
81	MEM CLK	O	EEPROM CS. III (278 board IC20)
82	MEM DATA	I/O	EEPROM DATA
83	AVSS		GND
84	AFT	I	Ground sense (not AFT) detection
85	AV1	I	Key input
86-91	AD3-AD8	I	Membrane key reading
92	AV1D	I	D. V.
93	AVDA	I	Membrane key reading
94	DEST 1	I	Destination discrimination
95	DEST 2	I	Destination discrimination
96	AVD II	I	Membrane key reading
97	LANC IN	I	LANC input
98	LANC OUT	O	LANC output
99	BUS2EE	O	Header output/clock signal crystal frequency down/up output
100	VDD		D. V.



## SECTION 7 ADJUSTMENTS

### 7-1. MECHANICAL ADJUSTMENTS

For the procedures how to adjust and check the mechanism, as well as how to replace mechanical parts, refer to the VHS Mechanical Adjustment Manual IV (H MECHANISM) (9-973-623-11).

However, for the procedures how to set the Track Shift mode, refer to the following text.

### 7-2. ELECTRICAL ADJUSTMENTS

See the adjusting part location diagram from on page 7-10 for the adjustment.

SLV-733HF/HFCS, 740HF/XP, 940HFCS/HFPX MODEL	DC-85 BOARD HI-19 BOARD MF-274 BOARD PS-349 BOARD RV-45 BOARD
EXCEPT SLV-733HF/ HFCS, 740HF/XP, 940HFCS/HFPX MODE	DC-87 BOARD HI-5 BOARD MP-253 BOARD PS-327 BOARD RV-36 BOARD
SLV-740(HFPX, 940HFCS/HFPX) MODEL	ED-43 BOARD
SLV-740(HF, 741HF, 780HF, 781HF, 940HF/HF/XP MODEL	ED-40 BOARD

### 2-1. PREPARATION BEFORE ADJUSTMENT

#### 2-1-1. Equipment Required

The measuring instruments used for this alignment include:

#### (Instruments for Use)

- 1) Monitor TV
- 2) Oscilloscope, dual-trace, bandwidth of 30MHz or more, with delay mode (A probe to; 1 should be used unless otherwise specified).
- 3) Frequency counter (8 columns or more)
- 4) NTSC pattern generator
- 5) Digital voltmeter
- 6) Audio level meter
- 7) Audio generator
- 8) Attenuator
- 9) Distortion rate meter
- 10) Sound dual multiplex signal generator
- 11) Alignment tape.
  - Normal VHS (KRV-51N2)  
Part No.: 8-192-605-32
- 12) Extension cable
  - ① HI-5/19 Board
    - HI-5/19 board CN301 - MA-214 board CN904
    - HI-5/19 board CN302 - MA-214 board CN905  
Part No.: J-6090-053-A (18 pin)




Fig. 7-2-1.

- ② RV-36/45 Board
  - RV-36/45 board CN801 - MA-214 board CN906
  - RV-36/45 board CN802 - MA-214 board CN907  
Part No.: J-6090-025-A (14 pin)
  - RV-36/45 board CN801 - Drum Head flexible  
Part No.: J-6090-054-A (13 pin)
- ③ HF-34 Board
  - HF-34 board CN101 - MA-214 board CN902
  - HF-34 board CN102 - MA-214 board CN904  
Part No.: J-6090-047-A (11 pin)
- ④ ED-40/43 Board
  - ED-40/43 board CN601 - MA-214 board CN903  
Part No.: J-6090-048-A (10 pin)




Fig. 7-2-2.

### 2-1-2. Equipment Connection

Unless otherwise specified, connect and adjust the measuring instruments as shown in the following diagram.




Fig. 7-2-3.

Unless otherwise specified, place the switches and controls of this unit in the following positions:

- CHANNEL switch ..... LINE 1
- TAPE SPEED (SP/EP) switch .....

### 2-1-3. Check of Input Signal

Because the video signal obtained from the pattern generator is used as the adjustment signal for the adjustment, the video output signal is required to satisfy the specified value.

Connect the oscilloscope to the picture input terminal (terminal board). And check that the synchronizing signal amplitude of the video signal is approximately 0.3V, the amplitude of the picture part is approximately 0.7V, the amplitude of the burst signal is approximately 0.3V and is flat, and the ratio of level between the burst signal and the "red" signal is 0.30 : 0.66. The video signal (color bar) used for the adjustment is shown in the fig. 7-2-4.




Fig. 7-2-4. Color bar signal of the pattern generator

### 2-1-4. Alignment Tape

● Contents of KRV-GIN? (Normal-VHS)

	Mode	Period	Video signal	Audio signal	
				Hi-Fi	Normal
1	SP	7 minutes	Color bar	400Hz	400Hz
2	SP	9 minutes	Mono scope	400Hz	400Hz
3	EP	7 minutes	Color bar	400Hz	400Hz
4	EP	3 minutes	Mono scope	400Hz	400Hz

### 2-1-5. Specified input-output Level and the Impedance

#### LINE IN 1 and 2

VIDEO IN Phono jack (1 each)  
Input signal: 1 V<sub>p-p</sub>, 75Ω,  
unbalanced, sync negative

AUDIO IN Phono jack (2 each)  
Input level: -7.5dBs (0 dBs=0.775 Vrms)  
Input impedance: more than 47kΩ

#### LINE OUT

VIDEO OUT Phono Jack (1)  
Output signal: 1 V<sub>p-p</sub>, 75Ω,  
unbalanced, sync negative

AUDIO OUT Phono jack (2)  
Standard output: -7.5dBs  
Load impedance: 47kΩ  
Output impedance: less than 10kΩ

#### CONTROL

S IN


CABLE BOX

CONTROL

(CONTROL) S OUT (plug in power)

### 2-1-6. Adjustment Procedures

Perform the adjustment following the procedures given below



## 2-2. POWER SUPPLY CHECK

### 2-2-1. Output Voltage Check (PS-327/349 Board)

Mode	B.R
Measuring instrument	Digital voltmeter
38V check	
Measurement point	CN101 Pin ①
Specified value	$38 \pm 3Vdc$
13V check	
Measurement point	CN101 Pin ③④
Specified value	$13 \pm 1Vdc$
MTR 12V check	
Measurement point	CN101 Pin ⑤⑥
Specified value	$12.7 \pm 10Vdc$
SW 12V check	
Measurement point	CN101 Pin ⑦
Specified value	$12.0 \pm 0.5Vdc$
SW 5V check	
Measurement point	CN101 Pin ⑧
Specified value	$5.0 \pm 0.5Vdc$
D 6V check	
Measurement point	CN101 Pin ⑨
Specified value	$5.9 \pm 0.5Vdc$
-8V check	
Measurement point	CN101 Pin ⑩
Specified value	$-13 \pm 2Vdc$
D 6V check	
Measurement point	CN102 Pin ②
Specified value	$5.9 \pm 0.5Vdc$
-30V check	
Measurement point	CN102 Pin ③
Specified value	$-29 \pm 3Vdc$

## 2-3. SERVO SYSTEM ADJUSTMENT

### 2-3-1. RF Switching Position Adjustment (MA-214 Board)

#### [Adjustment Object]

To adjust the link of the Ach and Bch of the tape playback outputs.

To make the unit compatible with other tapes and units. If this specification is not satisfied, the link will appear on the screen and the screen will be disrupted, etc.

Mode	Playback (SP)
Signal	Alignment tape: KR-V-S1N2 SP color bar portion
Measurement point	CH1: Video Line out terminal CH2: CN802 pin ② (RF SWP) (RV.36/45 board)
Measuring instrument	Oscilloscope
Adjustment element	RV202
Specified value	$6.5 \pm 0.5H$ ( $410 \pm 32\mu sec$ )

#### [Adjustment Method]

- 1) Set **TRACKING** switch (Remote commander) to MAN-UAL ("Auto tracking" display will disappear on the display window indicator.)
- 2) Press the tracking buttons **▼** and **▲** and adjust the tracking position to the center.
- 3) Adjust to  $410 \pm 32\mu sec$  ( $6.5 \pm 0.5H$ ) using RV502.




Fig. 7-2-5.

## 2-4. SYSTEM CONTROL/TIMER SYSTEM ADJUSTMENT

### 2-4-1. Clock Adjustment (H1-5/19 Board)

#### (Adjustment Object)

To raise the accuracy of the clock.

If the clock is not accurate, its error difference will gradually increase.

Measurement point	IC302 pin ⑨ (BUZZER OUT)
Measuring instrument	Frequency counter (Interval counter mode)
Measuring element	CT301
Specified value	$0.1249995 \pm 0.0000005 \text{sec}$

**Note:** Do not adjust CT301 except when replacing IC302.

#### (Adjustment Method)

- 1) Connect 47k $\Omega$  resistor (J-249-487-11) between pin ⑨ of IC302 and ground. (This sets the adjustments mode.)
- 2) Connect the frequency counter as shown in the figure below.
- 3) Adjust the oscillation frequency to the specified value using CT301.
- 4) After this adjustment, remove the resistor.




Fig. 7-2-6.

## 2-5. VIDEO SYSTEM ADJUSTMENT

For the video system adjustment, follow the adjustment procedures given below as a rule. The color bar video signal supplied from the pattern generator is used as the video input signal for the video system adjustment of the recording mode. Check that this signal satisfies the specified value designated in the "Check of input signal" (Fig. 7-2-4).

#### (Adjustment Sequence)

- 1) X'tal OSC Check
- 2) SYNC AGC Check
- 3) White clip/Dark clip check
- 4) Y FM carrier frequency check
- 5) Playback Y Level check

### 2-5-1. X'tal OSC Check (RV-36/45 Board)

Mode	Playback
Signal	Alignment tape. Color bar portion
Measurement point	IC001 pin ②
Measuring instrument	Oscilloscope and Frequency counter
Specified value	$3.579545 \pm 82 \text{Hz}$

**Note:** A frequency counter should be connected through a buffer amplifier (oscilloscope, etc.) having a high impedance and a low capacitance.

#### (Check Method)

- 1) Check that the oscillation frequency is  $3.579545 \pm 82 \text{Hz}$  and that the oscillation voltage is  $450 \pm 200 \text{mVpp}$ .




Fig. 7-2-7.

#### 2-5-2. SYNC AGC Check (RV-36/45 Board)

Mode	E-E
Signal	Color bar
Measurement point	Video output terminal
Measuring instrument	Oscilloscope
Specified value	$A = 2.0 \pm 0.14V_{p-p}$

##### [Check Method]

- 1) Check that the SYNC AGC level (A) satisfies the specified value.




Fig. 7-2-8.

#### 2-5-3. White Clip/Dark Clip Check (RV-36/45 Board)

Mode	E-E
Signal	Color bar
Measurement point	IC001 pin ⑦
Measuring instrument	Oscilloscope
Specified value	White clip: $190 \pm 15\%$ Dark clip: $52 \pm 10\%$

##### [Check Method]

- 1) Check that the white clip level is  $190 \pm 15\%$  to the white (100%) level
- 2) Check that the dark clip level is  $52 \pm 10\%$  to the white (100%) level.




Fig. 7-2-9.

#### 2-5-4. Y FM Carrier Frequency Check (RV-36/45 Board)

Mode	E-E
Signal	No-signal
Measurement point	Q34 Emitter
Measuring instrument	Frequency counter
Specified value	$3.40 \pm 0.18MHz$

**Note:** A frequency counter should be connected through a buffer amplifier (oscilloscope, etc.) having a high impedance and a low capacitance.

##### [Check Method]

- 1) Check that the carrier frequency satisfies the specified value.



$3.40 \pm 0.18MHz$

Fig. 7-2-10.

### 2-5-5. Playback Y Level Check (RV-36/45 Board)

Mode	Playback
Signal	Alignment tape - SP mode color bar portion
Measurement point	Video output terminal
Measuring instrument	Oscilloscope
Specified value	$A = 1.96 \pm 0.18V_{p-p}$

#### [Check Method]

- Check that the playback Y level satisfies the specified value.




Fig. 7-2-11.

### 2-6. AUDIO SYSTEM ADJUSTMENT

- For the adjustment of the audio system, perform in the SP mode if there is no special notes. Use the alignment tape.
- Adjust both LCH and RCH.

#### [Connecting Instruments]




Fig. 7-2-12.

#### ● Hi-Fi Audio System Adjustment

Perform the adjustment setting the switches and controls on the following positions if there is no special indications

- CHANNEL** switch ..... LINE 1  
**AUDIO MONITOR** ..... Stereo

#### [Adjustment Sequence]

- VCO  $f_c$  adjustment
- Deviation adjustment
- Band pass filter  $f_c$  Adjustment
- AF Switching pulse position adjustment

**2-6-1. VCO f<sub>0</sub> Adjustment (HF-34 Board)**  
**(Adjustment Object)**

To attain HiFi audio compatibility.  
 If this specification is not satisfied, the sound will be distorted.

Mode	Recording
Signal	No-signal
Measuring instrument	Frequency counter
1.3MHz adjustment	
Measurement point	IC101 pin ③ (Lch RF) (JL111)
Adjustment element	RV103 (Lch)
Specified value	1300 ± 1kHz
1.7MHz adjustment	
Measurement point	IC101 pin ④ (Rch RF) (JL110)
Adjustment element	RV102 (Rch)
Specified value	1700 ± 1kHz

**Note:** Connect the frequency counter through the buffer amplifier (oscilloscope, etc) with high input resistance (1MΩ or more) and low capacity (10pF or less).

**[Adjustment Method]**

- 1) Connect the frequency counter with each measurement points.
- 2) Adjust with RV103 and RV102 so that the frequency satisfies each specified value.

**2-6-2. Deviation Check (HF-34 Board)**

Mode	Recording
Signal	400Hz, ~12dBs: CN102 pin ①, ②
Measurement point	IC101 pin ③ (Lch) (JL111) IC101 pin ④ (Rch) (JL110)
Measuring instrument	Frequency counter
Specified value	50 ± 5kHz

**[Check Method]**

- 1) Check that the frequency satisfies the specified value.

○ HF-34 Board (COMPONENT SIDE)




Fig. 7-2-13.

### 2-6-3. Band Pass Filter $f_0$ Adjustment (HF-34 board)

#### (Adjustment Object)

To separate the carrier accurately and ensure that the filter for cutting the video signal functions normally. If this specification is not satisfied, the sound will be distorted.

Mode	Playback
Signal	1.505MHz, 200mVp-p · CN103 pin ①
Measurement point	IC101 pin ③ (Lch RF) (JL111) IC101 pin ④ (Rch RF) (JL110)
Measuring instrument	Oscilloscope
Adjustment element	RV101
Specified value	Adjust the A and B amplitudes to the same level. (A - B = $\pm 2mVp-p$ )

#### (Connection)

- 1) Disconnect CN103 of the HF-34 board and input the 1.505MHz and 200mVp-p sine wave from the signal generator to Pin ① of CN103.




Fig. 7-2-14.

#### (Adjustment Method)

- 1) Rotate RV101 fully in the counterclockwise direction (C) as seen from the component side.
- 2) Rotate RV101 slowly in the clockwise direction (C) until the amplitudes of Pin ③ of IC101 and Pin ④ of IC101 become equal.




Fig. 7-2-15.

### 2-6-4. AF Switching Position Adjustment (MA-214 Board)

#### (Adjustment Object)

To adjust the link of the Ach and Bch of the tape playback outputs.


If this specification is not satisfied, the noise will increase and cracking sounds will be produced.

Mode	Playback
Signal	Alignment tape: Hi-Fi 400Hz portion
Measurement point	CH1: IC101 pin ③ (Lch RF) (JL111) (HF-31 board) CH2: CN802 pin ③ (RF SWP) (RV-35/45 board)
Measuring instrument	Oscilloscope
Adjustment element	RV201
Specified value	No dropouts in the RF signal

#### (Adjustment Method)

- 1) Set **TRACKING** switch (Remote comander) to MANUAL. ("Auto tracking" display will disappear on the display window indicator.)
- 2) Press tracking buttons  $\nabla$  and  $\blacktriangle$  and adjust the tracking position to the center.
- 3) Adjust to the minimum specified value using RV501.

TV screen



Moves to the right when the  $\blacktriangle$  button is pressed and to the left when the  $\nabla$  button is pressed.




Fig. 7-2-16.



● Normal Audio System Adjustment

- Adjust in the SP mode if there is no special indications.
- Perform the adjustment, setting the switch on the following positions.

CHANNEL switch ..... LINE 1

AUDIO MONITOR switch ..... NORMAL

- 1: No indicators on the display window indicator and monitor TV

[Adjustment Method]

- ACE head adjustment. Refer to the VHS mechanical adjustment manual IV
- Recording bias adjustment
- E-E output level check
- Overall output level and distortion factor check
- Overall noise level check

2-6-5. ACE Head Adjustment

Refer to the "VHS Mechanical adjustment manual IV" (9-973-623-11).

2-6-6. Recording Bias Adjustment (MA-214 Board)

Mode	Self-record playback
Signal	400Hz, -27.5dBs } Audio line in 1 7kHz, -27.5dBs } (L or R)
Measurement point	Audio line out (L or R)
Measuring instrument	Audio level meter
Adjustment element	RV887
Specified value	0±1dBs

[Adjustment Method]

- Supply a signal of 400Hz, -27.5dBs to Audio Line Input
- Connect the audio level meter to the Audio Line Output.
- Adjust the attenuator so that the audio level meter will indicate -27.5dBs.
- Make recording in the SP mode.
- Set an audio line input signal to 7kHz and make recording.
- Playback a recorded portion, and measure output levels at 400Hz and 7kHz.
- Confirm that the 7kHz playback output levels within a range of the ±0dB; playback output level 0±1dB. When it is out of this range, adjust RV887 and repeat the steps 1) through 7) above.

	Direction of Rotating RV887
400Hz level > 7kHz level	Clockwise (C)
400Hz level < 7kHz level	Counterclockwise (C)

2-6-7. E-E Output Level Check

Mode	E-E
Signal	400Hz, -7.5dBs; Audio Line in 1
Measurement point	Audio line output terminal
Measuring instrument	Audio level meter
Specified value	-7.5±3dBs

[Checking Method]

- Input signal of 400Hz and -7.5dBs to the L and R channel of the audio input at the same time.
- Check that the audio output level is -7.5±3dBs.

2-6-8. Overall Output Level and Distortion Factor Check

Mode	Self-record playback
Signal	400Hz, -7.5dBs; Audio Line Input 1 terminals, left and right
Measurement point	Audio Line Output terminals, left and right
Measuring instrument	Audio level meter and Distortion meter
Specified value	Playback Level: -7.5±3dBs Distortion: 40% or less

[Check Method]

- Record signal.
- Playback the recorded portion.
- Check that the output level is -7.5±3dBs.
- Check that the distortion factor is 40% or less on the left and right side.

2-6-9. Overall Noise Level Check


Mode	Self-record playback
Signal	No signal (insert a shorting plug into the Audio Line Input jacks, left and right.)
Measurement point	Audio Line Output terminals, left and right
Measuring instrument	Audio level meter
Specified value	Less than -46dBs

[Checking Method]


- Record.
- Playback recorded portion.
- Check that noise level is -46dBs or less on the left side and right side.

2-7. ADJUSTMENT PARTS LOCATION DIAGRAM

MA-214 BOARD (COMPONENT SIDE)




HI-5/19 BOARD (COMPONENT SIDE)




2-7. ADJUSTMENT PARTS LOCATION DIAGRAM


MA-214 BOARD (COMPONENT SIDE)




RV-36/45 BOARD (COMPONENT SIDE)



HF-34 BOARD (COMPONENT SIDE)



HI-5/19 BOARD (COMPONENT SIDE)



\*Part on the conductor side.

# VHS MECHANICAL ADJUSTMENT MANUAL IV



---



V03056

## H MECHANISM

Please use with the service manual.



VHS VIDEO CASSETTE RECORDER  
**SONY.**



## TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
<b>1.</b>	<b>PREPARATION FOR MECHANISM CHECK ADJUSTMENT AND REPLACEMENT</b>		3-11.	Slit Brake T Assembly (Fig. 3-13)	21
			3-12.	RVS Brake Arm Assembly, Reel Table (T) Assembly (Fig. 3-14)	22
1-1.	Loading and Threading Procedure When the Power Turns Off (Fig. 1-1)	3	3-13.	TGB Assembly (Fig. 3-15)	23
1-1-1.	Loading and Threading Procedure With Hands	3	3-14.	TGB Holder (Fig. 3-18)	24
1-1-2.	Loading and Threading Procedure With Regulated DC Power Supply	3	3-15.	TGB and Press Gears (Fig. 3-17)	25
1-2.	Unloading and Unthreading Procedure When the Power Turns Off (Figs. 1-2 and 1-3)	4	3-18.	Cam Motor Chassis Block Assembly, Upper/Lower Communication Gear (Fig. 3-18)	26
1-2-1.	Unloading and Unthreading Procedure With Hands	4	3-17.	Rotary Encoder Switch (Fig. 3-18)	27
1-2-2.	Unloading and Unthreading Procedure With Regulated DC Power Supply	4	3-18.	Main Sactor (Fig. 3-20)	28
1-3.	How to Complete Threading Without Cassette Compartment (Fig. 1-4)	6	3-19.	Shuttle T Block and Loading Gear T Block Assemblies (Fig. 3-21)	29
<b>2.</b>	<b>PERIODIC CHECK AND REPLACEMENT</b>		3-20.	Shuttle S Block and Loading Gear S Block Assemblies (Fig. 3-22)	30
2-1.	Cleaning of Rotating Head Disk Assembly	7	3-21.	Reel Table (S) Assembly (Fig. 3-23)	31
2-2.	Cleaning of the Tape Movement System	7	3-22.	TGI Assembly (Fig. 3-24)	32
2-3.	Cleaning the Drive System	7	3-23.	S Winding Block Assembly (Fig. 3-25)	33
2-4.	Periodic Check Items	8	3-24.	Trigger Lever and RKB Block Assemblies (Fig. 3-26)	34
2-5.	Tools and Fixtures Required for Servicing	8	<b>4.</b>	<b>ADJUSTMENT</b>	
<b>3.</b>	<b>MAINLY MECHANICAL PARTS REPLACEMENT</b>		4-1.	Tape Path Adjustment	35
3-1.	FL Block Assembly (Fig. 3-1)	10	4-1-1.	Tension Regulator (TG1) Position/Tension Adjustment (Fig. 4-1)	35
3-2.	Drum Assembly (Fig. 3-2)	11	4-1-2.	TGB Guide Roller Height Adjustment (Fig. 4-2)	36
3-3.	Timing Belt (Fig. 3-3)	12	4-1-3.	Height Adjustment of Guide Rollers No. 3 and No. 6 (Fig. 4-3)	38
3-4.	CSB Brake Assembly (Fig. 3-4)	13	4-1-4.	Ace Head Assembly Adjustment (Rough Adjustment) (Figs. 4-4 and 4-5)	37
3-5.	TQ2 Roller, FE Head Assembly (Fig. 3-5)	14	4-1-6.	Ace Head Assembly Adjustment (Precision Adjustment)	38
3-6.	Pinch Press Block Assembly, Elevator Gear (Fig. 3-6)	15	4-1-6.	X-Velux Adjustment	38
3-7.	Ace Block Assembly (Fig. 3-7)	19	4-1-7.	Adjustments After Replacing the Drum (Video Head)	40
3-8.	TGB, TGB Guide Roller Assemblies (Fig. 3-8)	17	4-1-8.	Checking the Tension and Torque	42
3-9.	Cassette Motor (Fig. 3-11)	19			
3-10.	Main Brake Assemblies S and T (Fig. 3-12)	20			

## 1. PREPARATION FOR MECHANISM CHECK ADJUSTMENT AND REPLACEMENT

Refer to the service manual, "DISASSEMBLY" for removal of the cabinet and boards.

### 1-1. LOADING AND THREADING PROCEDURE WHEN THE POWER TURNS OFF (Fig. 1-1)

#### 1-1-1. LOADING AND THREADING PROCEDURE WITH HANDS

- 1) Turn cam motor in the arrow  $\odot$  direction until loading and threading are end.

#### 1-1-2. LOADING AND THREADING PROCEDURE WITH REGULATED DC POWER SUPPLY

- 1) Applying approx. +9 V (300 mA) to cam motor with regulated DC power supply makes it loading and threading.

Note: When loading and threading without cassette, claws are caught in four positions as following figure (in the order ① → ② → ③ → ④).

So release them with hands.









Fig. 1-1

**1-2. UNLOADING AND UNTHREADING PROCEDURE WHEN THE POWER TURNS OFF (Figs. 1-2 and 1-3)**

**1-2-1. UNLOADING AND UNTHREADING PROCEDURE WITH HANDS**

- 1) Turn cam motor in the arrow  direction until unthreading is end.
- 2) Turn capstan motor in the arrow  direction to take up tape in cassette.
- 3) Turn cam motor in the arrow  direction until unloading is end.

**1-2-2. UNLOADING AND UNTHREADING PROCEDURE WITH REGULATED DC POWER SUPPLY**

- 1) Apply approx. +9 V (300 mA) to contrary polarities of cam motor
- 2) Unthreading operation begins, tape guides return to their original positions (Unthreading operation is end but tape remains), then stop cam motor by turning power off
- Note:** When unloading begins and cassette lid is closed, turn cam motor in the arrow  direction to open tape guard.
- 3) Turn capstan motor in the arrow  direction to take up tape in cassette

**Note:** That tape is not caught at pinch roller. (Fig. 1-3)

- 4) Check that tape is not loosened completely, and apply approx. +9 V (300 mA) to contrary polarities of cam motor with regulated DC power supply. (Fig. 1-2)




Fig. 1-2




Fig 1-3

### 1-3. HOW TO COMPLETE THREADING WITHOUT CASSETTE COMPARTMENT (Fig. 1-4)

**Note 1:** Put the FL block assembly removed the FL top plate on the bottom not to put dust or grease the top sensor and the end sensor luminous plates or not to scratch them.  
(Fig. A)

- 1) Pull out AC plug from wall outlet.
- 2) Shade near the end and top sensors with a black masking tape on the like.
- 3) Press cassette in/rec proof switch with a tip of screwdriver or the like.
- 4) Connect AC plug to wall outlet.
- 5) Release cassette in/rec proof switch by putting off a tip of screwdriver or the like.

(At this time, power turns on, rewind operates for 10 seconds, after that power turns off.)

**Note 2:** In this condition, each mode can be set to video cassette recorder. (including recording mode)  
However, fast forward should be done after rewinding for 15 seconds or more.

**Note 3:** After above mentioned operation, be sure to return the mode in the following order.

- 1) Remove the tape near the end and top sensors.
- 2) Pull out AC plug from wall outlet to reset the system control microcomputer.




Fig. 1-4



## 2. PERIODIC CHECK AND REPLACEMENT

In order to obtain the best performance from this unit and make full use of its capabilities, and to extend the life of the unit and tapes, it is recommended that the following periodic checks and maintenance be performed.

\* The following must be done after every repair regardless of how many hours the user has operated the machine.

### 2-1. CLEANING OF ROTATING HEAD DISK ASSEMBLY

- 1) Press a chamois cloth (Jig Ref. No. J-9) which has been dipped in cleaning fluid (Jig Ref. No. J-3) lightly against the rotating drum assembly, then do the cleaning by slowly rotating the rotating head disk by hand. (Never try to clean by using the motor to turn it.)
- 2) Never try to clean by moving the chamois cloth at a vertical angle to the head tip. There is a very great danger of damaging the head tip if this is done.

### 2-2. CLEANING OF THE TAPE MOVEMENT SYSTEM

- 1) Clean the surfaces which the tape contacts during its movement (tape guide, drum assembly surface, capstan, pinch roller, etc.) with a chamois cloth that has been dipped in cleaning fluid.

### 2-3. CLEANING THE DRIVE SYSTEM

- 1) Clean the driving parts with a cloth that been dipped in cleaning fluid.




Fig. 2-1 Parts requiring cleaning

## 2-4. PERIODIC CHECK ITEMS

Perform the maintenance and check listed on the table below, according to users operating hours.

Maintenance & Check		Operating Hours (H)										Remarks
		500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	
Tape Transportation System	Cleaning of tape transportation system	○	○	○	○	○	○	○	○	○	○	This cleaning must be done whenever a repair is made.
	Cleaning and degaussing of ACE assembly	○	○	○	○	○	○	○	○	○	○	
	Cleaning & degaussing of upper drum assembly	○	○	○	○	○	○	○	○	○	○	The life of the head varies, depending on operational conditions and method.
Performance Confirmation	Abnormal sound	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Adjust or replace the sections which causes abnormal sound.
	Measurement of FWD back torque	-	☆	-	☆	-	☆	-	☆	-	☆	Confirmation must be made according to 4-1-2. Specified value: adjust to 36 to 44 gram (when measured with torque cassette tape).
	Confirmation of brake system	-	☆	-	☆	-	☆	-	☆	-	☆	Confirmation must be made according to section.
	Confirmation of record & playback functions	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Perform the confirmation whenever repair is made.
	Measurement of forward torque	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Adjust to 70 to 120 gram.


○ Cleaning ☆ Confirmation

**Note:** On overhaul

When overhauling the unit, replace parts as indicated in the above table.

## 2-5. TOOLS AND FIXTURES REQUIRED FOR SERVICING

Ref No.	Name	Part No.	Corved Jig No.	Remarks
J-1	Master Plane	H-7099-279-H		Applicable to S-VHS
J-2	Reel Disk Height Jig	H-7099-038-F		
J-3	Torque Gauge Adapter	H-7099-035-H		
J-4	0.93 mm Torque Gauge	H-7099-039-H		
J-5	Hex Wrench	H-7099-202-H		
J-6	Torque Measurement Cassette VHT-063S	J-6062-011-A		For PWD & back tension torque measurement
	Torque Measurement Cassette VHT-404S	J-6062-012-A		For CUE and reverse torque measurement.
J-7	Alignment Tape			
	JVC-MH-1 (NTSC)	H-7099-046-H		
	24HASP-2 (NTSC Hi-Fi)	H-7099-153-H		
	JVC-MH-2 (PAL)	H-7099-052-H		
	JVC-MH-4 (SECAM)	H-7099-053-H		
J-8	Cleaning Fluid	Y-2031-001-0		
J-9	Charcoal Leather	2-034-697-00		
J-10	Head Disassembler	Widely available		Demagnetize video heads and audio heads.
J-11	Dental Mirror (With handle) Dental Mirror (Mirror)	J-6060-029-A J-6060-030-J	SL-5052	Tape path and tape traveling adjustments or checks.
J-12	FLOBL SG-655G	7-651-000-09		
J-13	Diamond Oil NT-68	7-661-018-18		
J-14	Screw Lock G (H401R)	7-632-114-11		



### 3. MAINLY MECHANICAL PARTS REPLACEMENT

#### Notes:

- Refer to the service manual, "DISASSEMBLY" for removal of the cabinet and boards.
- On mounting, while referring to notes on mounting perform reversely in the removal order.
- When replacing greased parts, grease them in the same way.
- Do not oil, grease or touch with bare hands the surfaces contacts tape of guides and brake shoes.
- Install gears to engage each other.
- Basically, disassembling and assembling should be done in the unthreading-end condition.

#### 3-1. FL BLOCK ASSEMBLY (Fig. 3-1)

- 1) Remove screws ①.
- 2) Remove FL block assembly ② in the arrow direction.

**Note:** Be careful not to damage claws on the bottom and front.

#### [Note on Mounting]

- First insert claws on the bottom and front not to damage.
- Engage FL slide plate to FL driving gear with slightly sliding FL slide plate. (Fig. A)
- Keep clean top sensor and end sensor luminous plates. (Refer to 1-3.)




Fig. 3-1

### 3-2. DRUM ASSEMBLY (Fig. 3-2)

- 1) Remove screw ①.
- 2) Remove ground shaft assembly ② not to touch its tip with bare hand or tools.
- 3) Remove screws ③ to remove drum assembly ④.

#### [Note on Mounting]

- Don't touch head chips ⑤ and ground shaft assembly ② with bare hand or tools.
- Keep clean the surface contacts tape of drum assembly ④.

#### [Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-2

### 3-3. TIMING BELT (Fig. 3-3)

- 1) Remove screw ① to remove tension vehicle arm assembly ②.
- 2) Remove timing belt ③.

#### [Note on Mounting]

- Tighten screw ① while pressing tension vehicle arm in the arrow direction.




Fig. 3-3

### 3-4. CAP BRAKE ASSEMBLY (Fig. 3-4)

- 1) Remove tension vehicle arm assembly. (Refer to 3-3)
- 2) Remove torsion coil spring ① from portion ② to remove CAP brake assembly.

#### [Note on Mounting]

- Mount torsion coil spring ① to CAP brake assembly ② in the order ③ and ④. (Fig. A)
- Put the fulcrum of CAP brake assembly ② to CAP brake shaft ③ and the tip of torsion coil spring to ④.
- Don't touch brake shoe ⑤ with bare hand.




Fig. 3-4

### 3-5. TG2 ROLLER, FE HEAD ASSEMBLY

(Fig. 3-5)

- 1) Remove claw ② to pull out TG2 roller ①.
- 2) Remove screw ③ to pull out FE head assembly.

#### [Note on Mounting]

- Keep clean the surface contacts tape of TG2 roller ①.




Fig. 3-5



### 3-6. PINCH PRESS BLOCK ASSEMBLY, ELEVATOR GEAR (Fig. 3-6)

- 1) Remove E ring ① to pull out pinch press block assembly ②
- 2) Remove lid opener ③ by pressing claw ④ in the arrow direction.
- 3) Pull out elevator gear ⑤.

#### [Note on Mounting]

- Apply grease FLOIL SG-055G (Jug Ref. No. J-12) to ☆ marked portions.
- Be sure to match the phase ④ between elevator gear ④ and press gear ⑤ on mounting elevator gear ④.




Fig. 3-6

### 3-7. ACE BLOCK ASSEMBLY (Fig. 3-7)

- 1) Move torsion coil spring (ACE) ① in the arrow ➀ direction.
- 2) Remove ACE adjustment screw ②.
- 3) Remove AC height adjustment nut ③ to pull out ACE block assembly ④.

#### [Note on Mounting]

- Keep clean the surface contacts tape of ACE block assembly ④.
- Be sure to bang torsion coil spring (ACE) ① in the arrow ➀ direction.
- Set ACE adjustment screw ② to the height as shown in Fig. A.

#### [Adjustment after Mounting]

- 4-1. Tape path adjustment.
- After adjustment apply Screw Lock G (1401B) (Jlg Ref. No. J-14) at ☆ marked portion.




Fig. 3-7

### 3-8. TG3, TG6 GUIDE ROLLER ASSEMBLIES

(Fig. 3-8)

- 1) Loosen screw ① and pull out TG3 guide roller assembly ② by turning it in the arrow ③ direction.
- 2) Loosen screw ④ and pull out TG6 guide roller assembly ⑤ by turning it in the arrow ⑥ direction.

#### [Note on Mounting]

- Keep clean the surface contacts tape of TG3 and TG6 guide roller assemblies ②, ⑤.

#### [Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-8




Fig. 3-9




Fig. 3-10

### 3-9. CAPSTAN MOTOR (Fig. 3-11)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove screws ① to pull out capstan motor ②.

#### [Note on Mounting]

- Keep clean the surface contacts tape of capstan motor ②.
- On tightening screws ①, first tighten screw A temporarily, next tighten screws in the order B to C to A.

#### [Adjustment after Mounting]

- 4-1. Tape path adjustment




Fig. 3-11

**3-10. MAIN BRAKE ASSEMBLIES S AND T**  
(Fig. 3-12)

- 1) Remove tension spring ①.
- 2) Remove stopper washer (2) ② to remove neutrality arm ③.
- 3) Remove pendulum compulsion arm ④ and tension coil spring ⑤.
- 4) Remove stopper washer (2) ⑥ to remove main brake S assembly ⑦.
- 5) Remove stopper washer (2) ⑧ to remove main brake T assembly ⑨.

**[Note on Mounting]**

- Don't touch brake shoes ④ and ⑤ with bare hand.
- Apply FLOIL PG-055G (Fig Ref. No. J-12) to ☆ marked portions.




Fig. 3-12

### 3-11. SOFT BRAKE T ASSEMBLY (Fig. 3-13)

- 1) Remove pinch press block assembly. (Refer to 3-6.)
- 2) Remove lid opener ① carefully not to damage claw ②.
- 3) Remove tension spring ③ from side ④ to pull out soft brake T assembly ⑤.

#### [Note on Mounting]

- Don't touch brake shoes ⑥ with bare hand.




Fig. 3-13

### 3-12. RVS BRAKE ARM ASSEMBLY, REEL TABLE (T) ASSEMBLY (Fig. 3-14)

- 1) Remove main brake T assembly (Refer to 3-10.)
- 2) Remove soft brake T assembly. (Refer to 3-11.)
- 3) Remove tension coil spring ① in the order ⑥ to ⑤.
- 4) Remove RVS brake arm assembly ②.
- 5) Remove stopper washer (2) ③ to pull out reel table (T) assembly ④.

#### [Note on Mounting]

- Apply one drop of Diamond Oil NT-68 (Jlg Ref. No. J-13) to ☆ marked portion before mounting reel table (T) assembly ④. (Fig. A)
- Don't touch the hatched portion on reel table (T) assembly ④ and brake shoe ⑥ of RVS brake arm assembly ② with bare hand.




Fig. 3-14



### 3-13. TGS ASSEMBLY (Fig. 3-15)

- 1) Remove TGS retainer ① to pull out TGS assembly ②.

#### [Note on Mounting]

- Apply FLOIL SG-055G (Fig Ref No. J-12) to ☆ marked portion.
- Keep clean the surface contacts tape of TGS assembly ②.
- Be careful not to change the shape of TGS retainer ①.

#### [Adjustment after Mounting]

- 4-L. Tape path adjustment.




Fig. 3-15

### 3-14. TGS HOLDER (Fig. 3-16)

- 1) Remove TGS assembly. (Refer to 3-13)
- 2) Pull out TGS holder ①.

#### [Note on Mounting]

- Be careful about the direction of TGS holder ①. (② of Fig. A)

#### [Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-16

### 3-15. TGS AND PRESS GEARS (Fig. 3-17)

- 1) Remove pinch press block assembly. (Refer to 3-6.)
- 2) Remove soft brake T assembly. (Refer to 3-11.)
- 3) Remove TGS assembly. (Refer to 3-13.)
- 4) Remove TGS holder. (Refer to 3-14.)
- 5) Pull out TGS gear ① or press gear ②.

#### [Note on Mounting]

- Adjust the holes on gears to the holes on chassis. (Fig. A)
- Adjust the arrows carved on gears each other. (Fig. A)




Fig. 3-17

### 3-16. CAM MOTOR CHASSIS BLOCK ASSEMBLY, UPPER/LOWER COMMUNICATION GEAR (Fig. 3-18)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove screws ① to remove cam motor chassis assembly ②.
- 4) Pull out upper/lower communication gear ③.

#### [Note on Mounting]

- First, check main slider ④ slides fully in the arrow direction.
- Set rotary encoder switch position to "B" seen from the window of cam motor chassis. (Fig. A)
- Tighten screws ① in the order ② to ③ to ④ to ⑤.




Fig. 3-18

### 3-17. ROTARY ENCODER SWITCH (Fig. 3-19)

- 1) Remove timing belt. (Refer to 3-3)
- 2) Remove CAP brake assembly. (Refer to 3-4)
- 3) Remove cam motor chassis block assembly (Refer to 3-15.) and turn upside out the bottom.
- 4) Remove stopper washer (2) ① to pull out worm wheel ②.
- 5) Remove stopper washer (2) ③ to pull out cam gear ④.
- 6) Pull out FL driving gear ⑤ and rotary encoder switch ⑥.

#### [Note on Mounting]

- Apply FLOIL SG-055C (Jig Ref. No. J-12) to ☆ marked portions. (Fig. 3-19, A)
- Adjust the hole ⑦ to the hole on cam motor chassis. (Fig. B)
- Adjust the holes ⑧ and ⑨ to the hole on cam motor chassis. (Fig. C)




Fig. 3-19

### 3-18. MAIN SLIDER (Fig. 3-20)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove cam motor chassis block assembly. (Refer to 3-16.)
- 4) Remove screw ① to remove retainer ②.
- 5) Pull out main slider ③.

#### [Note on Mounting]

- Apply FLOLIL SG-055G (Jig Ref. No. J-12) as shown in Fig. A.
- At the last, slide main slider fully in the arrow direction.




Fig. 3-20

### 3-19. SHUTTLE T BLOCK AND LOADING GEAR T BLOCK ASSEMBLIES (Fig. 3-21)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove card motor chassis block assembly. (Refer to 3-16.)
- 4) Remove main slider. (Refer to 3-18.)
- 5) Remove screw ① to remove loading leaf (T) spring ② and shuttle T block assembly ③.
- 6) Pull out loading gear T block assembly ④.

#### [Note on Mounting]

- Adjust the phase ⑤ between loading gear (T) and loading gear (S). (Fig. A)
- Keep clean the surface contacts tape of shuttle T block assembly ③.




Fig. 3-21

### 3-20. SHUTTLE S BLOCK AND LOADING GEAR S BLOCK ASSEMBLIES (Fig. 3-22)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove cam motor chassis block assembly. (Refer to 3-16.)
- 4) Remove main slider. (Refer to 3-15.)
- 5) Remove screw ① to remove loading leaf (S) spring ② and shuttle S block assembly ③.
- 6) Pull out loading gear S block assembly ④.

#### [Note on Mounting]

- Adjust the phase Ⓞ between loading gear (S) and loading gear (T). (Fig. A)
- Keep clean the surface contacts type of shuttle S block assembly ④.




Fig. 3-22



### 3-21. REEL TABLE (S) ASSEMBLY (Fig. 3-23)

- 1) Remove tension spring ① from the chassis side.
- 2) Remove stopper washer (2) ② to pull out soft brake (S) ③.
- 3) Move TGI band ④ over the reel table.
- 4) Remove stopper washer (2) ⑤.
- 5) While pressing main brake S assembly ⑥, pull out reel table (S) assembly ⑦.

#### [Note on Mounting]

- Apply one drop of Diamond Oil NT-68 (Jlg Ref. No. J-13) to ☆ marked portion before mounting reel table (S) assembly ⑦ (Fig. A)
- Don't touch the hatched portion on reel table (S) assembly ⑦ with bare hand.




Fig. 3-23

### 3-22. TG1 ASSEMBLY (Fig. 3-24)

- 1) Set the mechanism to the loading-end condition referring to 1-1. (Cam gear indicates "LE". (Refer to Fig. A and B of Fig. 3-18.))
- 2) Remove tension spring ① in the order ④ to ③.
- 3) Remove stopper washer (2) ② to pull out TG1 assembly ③.

#### [Note on Mounting]

- Apply one drop of Diamond Oil NT-68 (Jig Ref. No. J-13) to ☆ marked portion.
- Keep clean the felt side of TG1 assembly




Fig. 3-24

### 3-23. S WINDING BLOCK ASSEMBLY (Fig. 3-25)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove cam motor chassis block assembly. (Refer to 3-16.)
- 4) Remove main slider. (Refer to 3-18.)
- 5) Remove stopper washer (2) ① to pull out S winding block assembly ②.
- 6) Remove torsion spring ③.

#### [Note on Mounting]

- At the last, hang torsion spring ③ to the position ④.
- Apply FLOIL SG-055G (Jig Ref. No. J-12) to ☆ marked portions.




Fig. 3-25

### 3-24. TRIGGER LEVER AND RKB BLOCK ASSEMBLIES (Fig. 3-26)

- 1) Remove timing belt. (Refer to 3-3.)
- 2) Remove CAP brake assembly. (Refer to 3-4.)
- 3) Remove cam motor chassis block assembly. (Refer to 3-16.)
- 4) Remove main slider. (Refer to 3-18.)
- 5) Remove tension spring ① in the order ② to ④ to remove trigger lever assembly ⑤.
- 6) Remove screws (3 x 6) ③ to remove RKB block assembly ④.

#### [Note on Mounting]

- Apply FLOIL SG-055G (Jig Ref. No. J-12) to ☆ marked portions on trigger lever assembly. (Fig. A)




Fig. 3-26

## 4. ADJUSTMENT

### 4-1. TAPE PATH ADJUSTMENT

The "Tape path" refers to the route of the tape from the supply reel disk to the take-up reel disc via the video heads.

Each component part of the tape transport system particularly the surface of parts which make direct contact with the tape must always be kept clean, free of dust, oil, scratches and so forth.

The tape path system is factory preadjusted, when parts of the tape transport system are replaced, be sure to make the required adjustments as precisely as possible in order to ensure stable tape transport.

#### 4-1-1. TENSION REGULATOR (TG1) POSITION/ TENSION ADJUSTMENT (Fig. 4-1)

**Purpose:** stabilizes contact of the video head and the tape to maintain the tension of the tape so that it feeds at a constant level.

##### • Position adjustment

Mode	Treading is completed without a cassette loaded
Adjustment locations	Eccentric pin of TGI1 band assembly

##### [Adjustment Method]

- 1) Allow the unit to go through the threading procedure without a cassette loaded.

- 2) Set the unit to play back, then turn the eccentric pin so that the tip of tension arm goes to the left side line carved on the mechanical chassis. (Fig. A)

- 3) After adjustment, go through the loading procedure once more without a cassette loaded, then check the position of the tension arm.

##### • Tension adjustment

Mode	Playback
Measuring instrument/tool	Torque cassette
Adjustment locations	Position for backing the tension spring
Specified value	36 to 44 g/cm

##### [Adjustment Method]

- 1) Playback the torque cassette.
- 2) Check that the center value deviation reading on the torque cassette meets with the standards.
- 3) When the reading is higher than the standards: Move the spring toward direction ②.  
When the reading is less than the standards: Move the spring toward direction ①.




Fig. 4-1

#### 4-1-2. TGS GUIDE ROLLER HEIGHT ADJUSTMENT (Fig. 4-2)

Mode	Playback
Jig	Blank tape
Adjustment locations	Guide roller height adjustment screw
Specified value	0 to 0.1 mm

##### Procedure:

- 1) Set the tape, during CUE playing back, check the height from lower flange of TG7 to the running tape (Fig. A)
- 2) During REV playing back, check the height from lower flange of TG7 to the running tape. (Fig. B)
- 3) When the difference between items 1) and 2) doesn't go to specified value, adjust by turning TGS guide roller height adjustment screw.
- 4) Check the tape is crossed or not between the capstan and TGS, adjust with TGS guide roller height adjustment screw so that the tape is not crossed during normal playback, CUE and REV.




Fig. 4-2

#### 4-1-3. HEIGHT ADJUSTMENT OF GUIDE ROLLERS NO. 3 AND NO. 6 (Fig. 4-3)

Mode	Playback
Signal	Alignment tape
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SW P pin for RF PC board check.
Adjustment locations	Guide roller height adjuster screw

##### [Adjustment Method]

- 1) Tracking (playback) Turn off the auto tracking, then press the tracking buttons  $\square$  and  $\square$  simultaneously to set the tracking at the center position.  
(If adjustment is made after the drum is replaced, the tracking must be set at the max. RF output position.)
- 2) Height adjuster screw: Even out the RF output waveforms.
- 3) Press the tracking buttons (playback):  $\square$  and  $\square$  alternately.
- 4) Check that RF output drops the same amount at the front and rear edges.




Fig. 4-3

**4-1-4. ACE HEAD ASSEMBLY ADJUSTMENT  
(ROUGH ADJUSTMENT) (Figs. 4-4 and 4-5)**

**Purpose:** Allows the tape to make even contact with the head for recording and playback of the specified track.

Mode	Playback
Tool	Blank tape
Adjustment locations	Height adjuster nut, Tilt adjuster screw

**[Adjustment Method]**

- 1) Mount the ACE head assembly. At this time, adjust the height so that the height of guide flange No. 7 matches the level of the lower edge of the control head.
- 2) Remove the adjustment tool and load a new tape, then set the unit for playback.
- 3) Check that the tape does not curl or rise up noticeably near the ACE head.
- 4) If the tape curls up or rises noticeably, readjust the tilt adjuster screw, the azimuth adjuster screw and the height adjuster nut.  
(The height of the ACE head should be adjusted so that the lower edge of the tape is approx. 0.1 to 0.15 mm from the control head.)
- 5) Perform precision adjustment.




Fig. 4-4




Fig. 4-5

#### 4-1-5. ACE HEAD ASSEMBLY ADJUSTMENT (PRECISION ADJUSTMENT)

Mode	Playback
Signal	Alignment tape (1kHz track)
Measuring instrument	Oscilloscope
Measuring point	Audio output terminal
Adjustment locations	Azimuth adjuster screw, Height adjuster nut, Tilt adjuster screw

##### [Adjustment Method]

- 1) Adjust the tilt adjuster screw in the FWD or REV mode so that the lower flange of guide No. 7 does not curl up or rise.
- 2) Alternately adjust the azimuth adjuster screw, the height adjuster nut, and the tilt adjuster screw to maintain even audio output at maximum with minimum deviation.




Fig. 4-6

#### 4-1-6. X-VALUE ADJUSTMENT

**Purpose:** To obtain compatibility with other VTR.

**Precaution:** Be sure to perform the preset tracking adjustment before perform this adjustment (Refer to the Service Guide.)

Turn off the auto tracking and set the VTR for manual tracking mode.

Mode	Playback
Signal	Alignment tape
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SW P pin for RF PC board check.
Adjustment locations	X-value adjuster screw

##### [Adjustment Method]

- **Adjustment by Hi-Fi alignment tape (NTSC only)**  
When the tracking is set at the center position (by pressing the  $\nabla$  and  $\Delta$  keys simultaneously), adjust the RF output to maximum.




Fig. 4-7



• **Adjustment by alignment tape**

Adjust the X-value adjuster screw so that maximum RF output is obtained and also that the RF output drops to the same position on pressing the respective  $\nabla$  and  $\Delta$  buttons while the tracking is set at the center position.




Fig. 4-8


#### 4-1-7. ADJUSTMENTS AFTER REPLACING THE DRUM (VIDEO HEAD)

**Purpose:** Co-relative height, X-value and other factors of the drum will deviate from those of the guide roller. If the drum is replaced properly, these deviations are extremely small.

**Precaution:** Turn off the auto tracking and set the manual tracking mode


Mode	Playback
Signal	Alignment tape, blank tape
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SW P pin for RF PC board check.
Adjustment locations	Guide roller (refer to 4-1-2, 4-1-3.) Switching position, Tracking preset, SP delay mono-multi (Refer to the Service Manual), X-value. (refer to 4-1-6.)

#### [Adjustment Method]




**[Checking the evenness and fluctuation of the RF output]**


- 1) Set the RF output to the maximum level using the tracking buttons.



- 2) Perform fine adjustment of the voltage level range of the oscilloscope, then adjust the RF output deviation to within 4 gradations.



- 3) Press the tracking buttons and adjust the maximum amplitude of the RF output to within 3 gradations.
- 4) At this time, check if the minimum amplitude is more than 2 gradations.



- 5) Check that the RF output fluctuation between minimum and maximum levels is within 13%.

#### 4-1-8. CHECKING THE TENSION AND TORQUE

**Purpose:** To check that the tension, torque and compression force of the tape take-up section and mobile sections to ensure smooth tape run and achieve standard VTR performance.

If the tape transport is not smooth or problems occur in relation to the tape transport speed, perform the following check.

Mode	Each operation mode without loading a cassette tape. (Refer to section 1-3.)
Measuring instrument	Torque gauge, Torque gauge adaptor

Item	VTR operation mode	Reel to be measured	Measurement value
Main brake torque	Stop	Supply and take-up reels	170 g/cm or more
Review torque	Review	Supply reel	180 $\pm$ 30 g/cm (using the torque cassette)
Take-up torque	Playback	Take-up reel	95 $\pm$ 25 g/cm (using the torque cassette)
Back tension torque	Playback	Take-up reel	33 to 44 g/cm (using the torque cassette)

#### [Check Method]

Measure the torque using the torque gauge and torque gauge adaptor with the torque gauge fixed.




Fig. 4-8

# VHS MECHANICAL ADJUSTMENT MANUAL IV

# VHS MECHANICAL ADJUSTMENT MANUAL IV

## SONY SERVICE MANUAL

H MECHANISM

### SUPPLEMENT-1

1. How to Use the Mode Selector II for Adjusting H Type Mechanism Assembly.
2. Adjusting Mechanism Using New Alignment Tape (KRV-52NE For NTSC).

File this supplement with the VHS mechanical adjustment (V).

#### TABLE OF CONTENTS

Section	Title	Page
1.	HOW TO USE THE MODE SELECTOR II FOR ADJUSTING H TYPE MECHANISM ASSEMBLY .....	2
1-1	Outline .....	2
1-2	Preparation .....	2
1-3	Connection .....	2
1-4	Operation .....	2
1-5	Precautions .....	2
2.	ADJUSTING THE MECHANISM USING NEW ALIGNMENT TAPE (KRV-52NE for NTSC) .....	4
2-1.	Adjustment Using Alignment Tape (KRV-52NE for NTSC having no version No.) .....	4
2-1-1.	X-Value Adjustment (Using the tape having no version No.) .....	4
2-2.	Adjustment Using Alignment Tape (KRV-52NE for NTSC having the version No.) .....	6
2-2-1.	X-Value Adjustment (Using the tape having the version No.) .....	6
2-3.	Adjusting the Mechanism Using Alignment Tape (KRV-52NE for NTSC) .....	10
2-3-1.	Height Adjustment of Guide Rollers No. 3 and No. 8 .....	10
2-3-2.	ACE Head Assembly Adjustment (Rough Adjustment) .....	11
2-3-3.	ACE Head Assembly Adjustment (Precision Adjustment) .....	11
2-3-4.	Adjustments After Replacing the Drum (Video Head) .....	12



## 1. HOW TO USE THE MODE SELECTOR II FOR ADJUSTING H TYPE MECHANISM ASSEMBLY

### 1-1. OUTLINE

To activate the VHS system H type mechanism assembly using mode selector II (J-6062-282-A), use connector conversion jig (J-6090-052-A). By using the connector conversion jig, the following operations are possible.

- Loading and unloading action by the loading motor
- Reading of the current setting of the mode switch
- Normal and reverse rotation of the capstan motor

### 1-2. PREPARATION

#### 1-2-1. ADDITION OF POWER SUPPLY CABLE

(Already added Mode Selector II also available)

In order to drive the capstan motor, the power +5 V and +12 V are supplied from the Mode Selector II. Disassemble the D-SUB connector of the Mode Selector cable, then solder the following three places.

Supplied 3-pin cable	DSUB connector of the mode selector II	Voltage
Pin 1 (Red index)	Pin 20	+12 V
Pin 2	Pin 25	GND
Pin 3	Pin 24	+5 V

- Connector pin number assignment of the DSUB connector (From the soldering side)



- When connections are made, check that +5 V and +12 V are available at the 3-pin cable connector.

#### 1-2-2. CHECKING THE SOFTWARE VERSION

Turn on the power of the mode selector II.

If the reading for the software version on the mode selector II is not 1.10 or higher, replace the New ROM (J-6062-314-A).

### 1-3. CONNECTION

#### 1-3-1. CONNECTION BETWEEN THE CONNECTOR CONVERSION JIG AND THE MODE SELECTOR II (See Fig. 1-1)

Insert the connectors of the two 6-pin cables (one is white and the other is black) and the 3-pin cable from the mode selector II to the corresponding connectors on the connector conversion jig (J-6090-052-A).

#### 1-3-2. CONNECTION BETWEEN THE CONNECTOR CONVERSION JIG AND THE H TYPE MECHANISM ASSEMBLY

With the power of the mode selector II turned off, insert the following three connectors to the corresponding connectors on the H type mechanism assembly.

- 3-pin connector for the loading motor
- 5-pin connector for the mode switch
- 8-pin connector for the capstan motor

Set the speed control for the minimum setting (fully counterclockwise).

### 1-4. OPERATION

#### 1-4-1. OPERATION OF THE LOADING MOTOR ON THE H TYPE MECHANISM ASSEMBLY

- (1) Select the H type mechanism assembly setting on the mode selector II.
- (2) After this, procedures are the same as those for the previous model types.

For the operating method, see pages 3 to 5 of "8 mm Video Mechanism Manual VI (TK Mechanism) Supplement-1".

For the loading method, see page 3 of "VHS Mechanical Adjustment Manual IV (H Mechanism)".

#### 1-4-2. OPERATION OF THE CAPSTAN MOTOR ON THE H TYPE MECHANISM ASSEMBLY

- (1) For the loading motor operation under Section 1-4-1, change the mode setting to the FF/REW mode with the mode switch.
- (2) Turn the speed control gradually in clockwise direction, and the capstan motor starts rotating. To turn the capstan motor in desired rotating direction, change the FWD/RVS setting of the rotating direction switch.

### 1-5. PRECAUTIONS

- Turn the speed control only when necessary. Otherwise, hold the speed control turned at fully counterclockwise direction. If the power of the mode selector II is turned on with the speed control turned in clockwise direction, +12V power fails and the power of the mode selector II cannot be turned on.
- Although the connector conversion jig (J-6090-052-A) has rubber feet, do not make a short circuit on the bottom surface of the connector conversion jig via foreign conductive materials.




Fig. 1-1




## 2. ADJUSTING THE MECHANISM USING NEW ALIGNMENT TAPE (KRV-52NE for NTSC)

The conventional alignment tape (For NTSC) is now replaced with alignment tape KRV-52NE, and the following describes how to align the mechanism using the KRV-52NE. For details on the use of KRV-51N2 for each model, refer to the service manuals which will be issued in the future.

Name	Parts No.	Remarks
Alignment tape KRV-52NE for NTSC	8-192-605-41	For tape path, audio azimuth, and X-value adjustments
Alignment tape KRV-51N2 for NTSC	8-192-605-32	For electrical adjustments (RF, AF, and switching position) and operation check

**Note:** The KRV-52NE has or does not have Ver No. depending on new or old type as shown below. (New one has Ver No.)

Note that an adjusting method of X-value is different.



**Contents:**  
KRV-52NE (NTSC)

Time	Video	Audio
20 min.	Recording only at 1 MHz, A-ch. EP mode RF skipping once per 5 frames	5 kHz full tracks

KRV-51N2 (NTSC)

Class	Mode	Time	Video	Audio (RF/Normal)
1	SP	7 min.	Color bar	400 Hz
2	SP	3 min.	Mono. scope	400 Hz
3	EP	7 min.	Color bar	400 Hz
4	EP	3 min.	Mono. scope	400 Hz

### 2-1. ADJUSTMENT USING ALIGNMENT TAPE (KRV-52NE for NTSC having no version No.)


#### 2-1-1. X-VALUE ADJUSTMENT (Using the tape having no version No.)

**Purpose:** To obtain compatibility with other VCRs.

**Precaution:** Before starting to adjust X-value, set the tracking control at the center position. To set the tracking control at the center position for the VCRs

equipped with the and tracking control keys, press both the and tracking control keys at the same time. For the VCRs not equipped with the tracking control keys, deactivate the automatic tracking control by pressing the tracking key on the remote control unit during threading operation (after a tape is inserted but before the VCR starts playing back the tape).

Mode	Playback
Signal	Alignment tape KRV-52NE (For NTSC having no version No.)
Measuring instrument	Oscilloscope TIM/DIV: 2ms Trigger source: CH2 Trigger slope: $\uparrow$
Measuring point	CH-1: Connector PB RF pin for RF PC board check CH-2: Connector RF SWP pin for RF PC board check
Adjustment location	X-value adjuster screw




RF output shall be maximum at the center position of the tracking control

#### [Adjustment Method]

Set the tracking control at the center position. For the VCRs equipped with narrow gap video heads, set the X-value adjustment screw where a maximum RF output is obtained. For the VCRs equipped with wide gap video heads, set the X-value adjustment screw both where a maximum RF output is obtained and where the RF output decreases immediately when the tracking control key is pressed

X-VALUE ADJUSTMENT (Using the tape having no version No.)








When adjustment is complete, adjust the height of No. 3 and No. 6 guide rollers on page 10.


## 2-2. ADJUSTMENT USING ALIGNMENT TAPE (KRV-52NE for NTSC having the version No.)

### 2-2-1. X-VALUE ADJUSTMENT (Using the tape having the version No.)

**Purpose:** To obtain compatibility with other VCRs.

**Precaution:** Before starting to adjust X-value, set the tracking control at the center position. To set the tracking control at the center position for the VCRs equipped with the  and  tracking control keys, press both the  and  tracking control keys at the same time. For the VCRs not equipped with the tracking control keys, deactivate the automatic tracking control by pressing the tracking  key on the remote control unit during threading operation (after a tape is inserted but before the VCR starts playing back the tape).

Mode	Playback
Signal	Alignment tape KRV-52NE (For NTSC having the version No.)
Measuring instrument	Oscilloscope TIM/DIV: 2ms Trigger source: CH2 Trigger slope: +
Measuring point	CH-1: Connector PB RF pin for RF PC board check CH-2: Connector RF SWP pin for RF PC board check
Adjustment locations	X-value adjuster screw




RF output shall be maximum at the center position of the tracking control.


### [Adjustment Method]

Set the tracking control at the center position. For the VCRs equipped with narrow gap video heads, set the X-value adjustment screw where a maximum RF output is obtained. For the VCRs equipped with wide gap video heads, set the X-value adjustment screw both where a maximum RF output is obtained and where the RF output decreases immediately when the  $\nabla$  tracking control key is pressed.


#### 1. Adjusting X-value (Using the tape having the version No.)



2. Checking false tracking (Using the tape having the version No.)



Using the tape having the version No.



## 2-3. ADJUSTING THE MECHANISM USING ALIGNMENT TAPE (KRV-52NE for NTSC)

### 2-3-1. HEIGHT ADJUSTMENT OF GUIDE ROLLERS NO. 3 AND NO. 6


Mode	Playback
Signal	Alignment tape KRV-52NE (For NTSC)
Measuring instrument	Oscilloscope TIM/DIV: 2ns Trigger source: CH2 Trigger slope: +
Measuring point	CH-1: Connector PB RF pin for RF PC board check CH-2: Connector RF SWP pin for RF PC board check
Adjustment locations	Height adjustment screw for No.3 tape guide roller Height adjustment screw for No.6 tape guide roller

#### [Adjustment Method]

The following adjustment shall be carried out after completed Section 2-1-1 "X-value adjustment and check".


- 1) Deactivate the automatic tracking control, and set the tracking control at the center position. To set the tracking control at the center position for the VCRs equipped with the **▲** and **▼** tracking control keys, press both the **▲** and **▼** tracking control keys at the same time. For the VCRs not equipped with the tracking control keys, deactivate the automatic tracking control by pressing the tracking **AUTOMANUAL** key on the remote control unit during threading operation (after a tape is inserted but before the VCR starts playing back the tape).

- 2) Check if the RF output changes in amplitude by pressing the tracking control key. The RF output should change periodically (changes from a minimum amplitude to a maximum amplitude, and to the minimum amplitude again).



- 3) Turn the height adjustment screws of tape guide rollers No.3 and No.6 so that the RF output envelope becomes as flat as possible.
- 4) Press the **▲** tracking control key, and check that both the beginning and end of the RF output change together the same in amplitude.
- 5) Press the **▼** tracking control key, and check that both the beginning and end of the RF output change together the same in amplitude.

Turn the height adjustment screws of tape guide rollers No.3 and No.6 into by little so that the RF output envelope becomes as flat as possible.



Height adjustment screw of tape guide roller No.3  
Tape guide No.4  
Tape guide No.6  
Height adjustment screw of tape guide roller No.6

Press the **▼** tracking control key, then the **▲** tracking control key, and check that both the beginning and end of the RF output change together the same in amplitude.

When the **▲** tracking control key is pressed.



At the tracking center position.



When the **▼** tracking control key is pressed.



### 2-3-2. ACE HEAD ASSEMBLY ADJUSTMENT (ROUGH ADJUSTMENT) (Figs. 2-1 and 2-2)

**Purpose:** Allows the tape to make even contact with the head for recording and playback of the specified track.

Mode	Playback
Jig	Blank tape
Adjustment locations	Height adjuster nut, Tilt adjuster screw

#### [Adjustment Method]

- 1) Mount the ACE head assembly. At this time, adjust the height so that the height of guide flange No. 7 matches the level of the lower edge of the control head.
- 2) Remove the adjustment tool and load a new tape, then set the unit for playback.
- 3) Check that the tape does not curl or rise up noticeably near the ACE head.
- 4) If the tape curls up or rises noticeably, readjust the tilt adjuster screw and the height adjuster nut.  
(The height of the ACE head should be adjusted so that the lower edge of the tape is approx. 0.1 to 0.15 mm from the control head.)
- 5) Perform precision adjustment.




Fig. 2-1




Fig. 2-2

### 2-3-3. ACE HEAD ASSEMBLY ADJUSTMENT (PRECISION ADJUSTMENT)

Mode	Playback
Signal	Alignment tape (KRV-52NE 5 kHz) (For NTSC)
Measuring instrument	Oscilloscope
Measuring point	Audio output terminal
Adjustment locations	Azimuth adjuster screw, Height adjuster nut, Tilt adjuster screw

#### [Adjustment Method]

- 1) Adjust the tilt adjuster screw in the FWD or REV mode so that the lower flange of guide No. 7 does not curl up or rise.
- 2) Alternately adjust the azimuth adjuster screw, the height adjuster nut, and the tilt adjuster screw to maintain even audio output at maximum with minimum deviation.




Fig. 2-3



### 2-3-4. ADJUSTMENTS AFTER REPLACING THE DRUM (VIDEO HEAD)


**Purpose:** Co-relative height, X-value and other factors of the drum will deviate from those of the guide roller. If the drum is replaced properly, these deviations are extremely small.

**Note 1:** Deactivate the automatic tracking control for setting the mechanism in manual tracking control mode.

**Note 2:** To set the tracking control at the center position, deactivate the automatic tracking control by pressing the tracking [AUTO/MANUAL] key on the remote control unit during threading operation (after a tape is inserted but before the VCR starts playing back the tape).


Mode	Playback
Signal	Alignment tape KRV-52NE (For NTSC), blank tape
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SWP pin for RF PC board check.
Adjustment locations	Guide roller (Refer to 2-3-1.) Switching position (Refer to the Service Manual) X-value (Refer to 2-1-1, 2-1-2.)

#### [Adjustment Method]




**[Checking the evenness and fluctuation of the RF output]**


- 1) Set the RF output to the maximum level using the tracking buttons.



- 2) Perform fine adjustment of the voltage level range of the oscilloscope, then adjust the RF output deviation to within 4 gradations.



- 3) Press the tracking buttons and adjust the maximum amplitude of the RF output to within 3 gradations.
- 4) At this time, check if the minimum amplitude is more than 2 gradations.



- 5) Check that the RF output fluctuation between minimum and maximum levels is within 13%

# VHS MECHANICAL ADJUSTMENT MANUAL IV

# VHS MECHANICAL ADJUSTMENT MANUAL IV

## SONY SERVICE MANUAL

VHS MECHANISM

### SUPPLEMENT-2

File this supplement with the VHS mechanical adjustment IV and supplement-1.

#### TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>
1.	CORRECTION .....	1
1-1.	Adjustment Sequence .....	1
2.	MODIFICATION .....	2
2-1.	Changing the Recorded Contents of Alignment Tape .....	2
2-2.	TG2 Roller, FE Head Assembly .....	2
2-3.	TG3, TG6 Guide Roller Assembly .....	3
2-4.	TG8 Assembly .....	4
2-5.	Tension Regulator (TG1) Position Tension Adjustment .....	5
2-6.	TG8 Guide Roller Height Adjustment .....	6

#### 1. CORRECTION

In the VHS Mechanism Adjustment Manual IV (Supplement-1), an adjustment sequence was wrong, and it is corrected as follows:

##### 1-1. Adjustment Sequence (VHS Mechanism Adjustment Manual IV (Supplement-1) Page 6 to 11)

(1) Adjustment of No. 3 and No. 6 guide roller height

Delete the "The following adjustment shall be carried out after completed Section 2-1-1 "X-value adjustment and check" under "Adjustment Method" on page 10.

(2) Adjustment of ACE head assembly

**Note:** In the adjustment of ACE head assembly (coarse adjustment and fine adjustment), if an azimuth, height and tilt were adjusted, again adjust the height of No. 3 and No. 6 guide rollers

(3) Adjustment of X value



## 2. MODIFICATION

### 2-1. CHANGING THE RECORDED CONTENTS OF ALIGNMENT TAPE

KRV-S2NE (NTSC) (Ver. 1.2)

Time	Video	Audio
20 min.	Recording only at 1 MHz. A-eb. EP mode RF flipping once per 5 frames	5 kHz → 4.5 kHz full tracks

### 2-2. TG2 ROLLER, FE HEAD ASSEMBLY (Refer to VHS Mechanical Adjustment Manual IV page14)

- The TG2 roller is provided with either of two types, fixed or straight. For the fixed type, section 3-5 is added.

### 3-5. TG2 ROLLER, FE HEAD ASSEMBLY (Fig. 3-5)

- 1) Remove screw ① to pull out FE head assembly ②.

#### [Note on Mounting]

- Keep clean the surface contacts tape of TG2 roller.




Fig. 3-5

### 2-3. TG3, TG6 GUIDE ROLLER ASSEMBLIES (Refer to VHS Mechanical Adjustment Manual [V page 17])

- There is another type in TG3 and TG6 guide roller assemblies, which is not attached with a screw (B2X3). For the screwless type, section 3-8 is added.

### 3-8. TG3, TG6 GUIDE ROLLER ASSEMBLIES (Fig. 3-8)

- 1) TG3 guide roller assembly ① by turning it in arrow ➊ direction.
- 2) Removal the spring ②.
- 3) TG6 guide roller assembly ③ by turning it in arrow ➋ direction.
- 4) Removal the spring ④.

#### [Note on Mounting]

- Keep clean the surface contacts tape of TG3 and TG6 guide roller assemblies ①, ③.

#### [Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-8

## 2-4. TGS ASSEMBLY

(Refer to VHS Mechanical Adjustment  
Manual IV page 23)

- As the shape of TGS assembly was changed, Section 3-13 is changed.

 : Changed portion

## 3-13. TGS ASSEMBLY (Fig. 3-15)

- Remove TG7 tape retainer (1) to pull out TGS assembly (2).

### [Note on Mounting]

- Apply FLOIL SG-055G (Jig Ref. No J-12) to ☆ marked portion
- Keep clean the surface contacts top of TGS assembly (2).
- Be careful not to change the shape of TG7 tape retainer (1).
- After attaching the TG7 tape retainer (1), check that side (3) of (1) is below side (4) of the stepped-part of the TG7 shaft. (Fig. A)

### [Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-15

**2-5. TENSION REGULATOR (TG1) POSITION/  
TENSION ADJUSTMENT**  
(Refer to VHS Mechanical Adjustment  
Manual IV page 35)

- As the tension regulator position and tension adjustment were changed, the tension adjustment and Fig. 4-1 are changed.

Changed portion

• Tension adjustment

Mode	Playback
Measuring instrument/tool	Torque cassette
Adjustment locations	Position for hooking the tensioned spring
Specified value	$34 \pm 4$ gcm




Fig. 4-1



## VHS MECHANICAL ADJUSTMENT MANUAL IV

### 2-6. TG8 GUIDE ROLLER HEIGHT ADJUSTMENT (Refer to VHS Mechanical Adjustment Manual IV page 36)

\* As the use of TG8 height adjusting screw was cancelled, section 4-1-2 is changed.

### 4-1-2. TG7 TAPE PATH ADJUSTMENT (Fig. 4-2)

#### [Adjustment Method]

1) Load a tape, and playback the tape in the CUE mode, confirm the distance between lower flange of No. 7 guide roller and lower side of tape (Fig. A).

- 2) Then, feeding the tape in the REV mode, confirm the distance between lower flange of No. 7 guide roller and lower side of tape.
- 3) If the tape height in the REV feed is higher than in the CUE playback (Fig. B), rotate the ACE head flapping adjust screw in the direction  $\odot$  so that a difference in tape height between CUE mode and REV mode becomes zero.
- 4) If the tape height in the REV feed is lower than in the CUE playback (Fig. C), rotate the ACE head flapping adjust screw in the direction  $\ominus$  so that a difference in tape height between CUE mode and REV mode becomes zero.




Fig. 4-2

Sony Corporation  
Consumer A&V Products Company  
Home A&V Products Div.

Published by Personal A&V Products Div.  
Quality Engineering Dept.

# VHS MECHANICAL ADJUSTMENT MANUAL IV

SONY

H MECHANISM

## SERVICE MANUAL

### SUPPLEMENT-3

File this supplement with the VHS mechanical adjustment IV and supplement-1, 2.

Subject: Mechanism chassis assembly changed.  
PAL alignment tape changed.

(SL-600060)

#### TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>
1.	MODIFICATION . . . . .	2
1-1	Parts Requiring Clearing . . . . .	2
1-2	Drum Assembly, Drum Base . . . . .	3
1-3	TG2 Roller, FE Head Assembly . . . . .	4
1-4	TG3, TG6 Guide Roller Assemblies . . . . .	5
1-5	Shuttle T Block and Loading Gear T Block Assemblies . . . . .	6
1-6	Shuttle S Block and Loading Gear S Block Assemblies . . . . .	7
2.	ADJUSTING THE MECHANISM USING NEW ALIGNMENT TAPE (KRV-S2PL for PAL) . . . . .	8
2-1	Height Adjustment of Guide Rollers No. 3 and No. 6 . . . . .	8
2-2	ACE Head Assembly Adjustment (Rough Adjustment) . . . . .	9
2-3	ACE Head Assembly Adjustment (Precision Adjustment) . . . . .	9
2-4	X-Value Adjustment . . . . .	10
2-5	Adjustments After Replacing the Drum (Video Head) . . . . .	14

## 1. MODIFICATION

### 1-1. PARTS REQUIRING CLEANING (Refer to VHS Mechanical Adjustment Manual IV page 7)

- Parts requiring a cleaning were changed in shape, and therefore, Fig. 2-1 for new type is added.

 : Modified portion




Fig. 2-1 Parts Requiring Cleaning

## 1-2. DRUM ASSEMBLY, DRUM BASE (Refer to VHS Mechanical Adjustment Manual IV page 11)

- The ground shaft assembly was changed and the drum base was added, and therefore Section 3-2 for new type is added.

## 3-2. DRUM ASSEMBLY, DRUM BASE (Fig. 3-2)

- 1) Remove screw ①.
- 2) Remove ground shaft assembly ② not to touch its tip with bare hand or tools.
- 3) Remove screws ③ to remove drum assembly ④.
- 4) Remove screws ⑤ to remove drum base ⑥.

### [Note on Mounting]

- Don't touch bead chips and ground shaft assembly ④ with bare hand or tools.
- Keep clean the surface contacts tape of drum assembly ④.

### [Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-2

### 1-3. TG2 ROLLER, FE HEAD ASSEMBLY (Refer to VHS Mechanical Adjustment Manual IV page 14)

- The TG2 roller was assembled to the FE head assembly, and therefore Section 3-5 for new type is added.

### 3-5. TG2 ROLLER, FE HEAD ASSEMBLY (Fig. 3-5)

- 1) Remove screw ①.
- 2) Pull out FE head assembly ②.

#### [Notes on Mounting]

- Keep clean the surface contacts tape of TG2 roller.




Fig. 3-5

### 1-4. TG3, TG6 GUIDE ROLLER ASSEMBLIES (Refer to VHS Mechanical Adjustment Manual IV page 17)

- The TG3 and TG6 guide roller assemblies were changed, and therefore Section 3-8 for new type is added.

### 3-8. TG3, TG6 GUIDE ROLLER ASSEMBLIES (Fig. 3-8)

- 1) TG3 guide roller assembly ① by turning it in the arrow ② direction
- 2) Removal the spring ③.
- 3) TG6 guide roller assembly ④ by turning it in the arrow ⑤ direction.
- 4) Removal the spring ⑥.

#### [Note on Mounting]

- Keep clean the surface contacts tape of TG3 and TG6 guide roller assemblies ①, ④.

#### [Adjustment after Mounting]

- 4-1. Tape path adjustment.




Fig. 3-8

### 1-5. SHUTTLE T BLOCK AND LOADING GEAR T BLOCK ASSEMBLIES (Refer to VHS Mechanical Adjustment Manual IV page 29)

- The shuttle T block and loading gear T block assemblies were changed, and therefore Section 3-19 for new type is added.

### 3-19. SHUTTLE T BLOCK AND LOADING GEAR T BLOCK ASSEMBLIES (Fig. 3-21)

- 1) Remove drum assembly and drum base. (Refer to 3-2.)
- 2) Remove timing belt. (Refer to 3-3.)
- 3) Remove CAP brake assembly. (Refer to 3-4.)
- 4) Remove cam motor chassis block assembly. (Refer to 3-18.)
- 5) Remove main slider. (Refer to 3-20.)
- 6) Sliding the shuttle T block assembly ① toward the direction ②, remove it through the hole ③.
- 7) Pull out loading gear T block assembly ②.

#### [Note on Mounting]

- Adjust the phase ④ between loading gear (T) and loading gear (S). (Fig. A)
- Keep clean the surface contacts tape of shuttle T block assembly ①.




Fig. 3-21

**1-6. SHUTTLE S BLOCK AND LOADING GEAR S BLOCK ASSEMBLIES**  
**(Refer to VHS Mechanical Adjustment Manual IV page 30)**

- The shuttle S block and loading gear S block assemblies were changed, and therefore Section 3-20 for new type is added.

**3-20. SHUTTLE S BLOCK AND LOADING GEAR S BLOCK ASSEMBLIES**  
**(Fig. 3-22)**

- 1) Remove drum assembly and drum base. (Refer to 3-2.)
- 2) Remove timing belt. (Refer to 3-3.)
- 3) Remove CAP brake assembly. (Refer to 3-4.)
- 4) Remove cam motor chassis block assembly. (Refer to 3-18.)
- 5) Remove main slider. (Refer to 3-20.)
- 6) Sliding the shuttle S block assembly ① toward the direction ②, remove it through the hole ③.
- 7) Pull out loading gear S block assembly ④.

**[Note on Mounting]**

- Adjust the phase ⑤ between loading gear (S) and loading gear (T) (Fig. A)
- Keep clean the surface contacts tape of shuttle S block assembly ①.




Fig. 3-22



## 2. ADJUSTING THE MECHANISM USING NEW ALIGNMENT TAPE (KRV-52PL for PAL)

The conventional alignment tape (For PAL) is now replaced with alignment tape KRV-52PL, and the following describes how to align the mechanism using the KRV-52PL. For details on the use of KRV-51P for each model, refer to the service manuals which will be issued in the future.

Name	Parts No.	Remarks
Alignment tape KRV-52PL for PAL	8-192-605-46	For tape path, audio, azimuth, and X-value adjustments
Alignment tape KRV-51P for PAL	8-192-605-36	For electrical adjustments (RF, AF, and switching position) and operation check

### Contents:

KRV-52PL (PAL)

Time	Video	Audio
20 min.	Recording only at 1 MHz, A-cl, EP mode RF skipping once per 5 frames	4 kHz full tracks

KRV-51P (PAL)

Class	Mode	Time	Video	Audio (HF/Normal)
1	SP	7 min.	Color bar	400 Hz
2	SP	3 min.	Mono scope	400 Hz
3	EP	7 min.	Color bar	400 Hz
4	EP	3 min.	Mono scope	400 Hz

### 2-1. HEIGHT ADJUSTMENT OF GUIDE ROLLERS NO. 3 AND NO. 6

Mode	Playback
Signal	Alignment tape KRV-52PL (For PAL)
Measuring instrument	Oscilloscope TIM/DIV: 2us Trigger source: CH2 Trigger slope: +
Measuring point	CH-1: Connector PB RF pin for RP PC board check CH-2: Connector RF SWP pin for RP PC board check
Adjustment locations	Height adjustment screw for No. 3 tape guide roller Height adjustment screw for No. 6 tape guide roller

#### [Adjustment Method]

- Deactivate the automatic tracking control, and set the tracking control at the center position. To set the tracking control at the center position for the VCRs equipped with the **[A]** and **[V]** tracking control keys, press both the **[A]** and **[V]** tracking control keys at the same time. For the VCRs not equipped with the tracking control keys, deactivate the automatic tracking control by pressing the tracking **[AUTO/MANUAL]** key on the remote control unit during the ejection operation (after a tape is inserted but before the VCR starts playing back the tape).
- Turn the height adjustment screws of tape guide rollers No. 3 and No. 6 so that the RF output envelope becomes as flat as possible.
- Press the **[A]** tracking control key, and check that both the beginning and end of the RF output change together the same in amplitude.
- Press the **[V]** tracking control key, and check that both the beginning and end of the RF output change together the same in amplitude.




Fig. 2-1




Fig. 2-2

## 2-2. ACE HEAD ASSEMBLY ADJUSTMENT (ROUGH ADJUSTMENT) (Figs. 2-3 and 2-4)

**Purpose:** Allows the tape to make even contact with the head for recording and playback of the specified track.

Mode	Playback
Jig	Blank tape
Adjustment locations	Height adjuster nut, Tilt adjuster screw

### [Adjustment Method]

- 1) Mount the ACE head assembly. At this time, adjust the height so that the height of guide flange No. 7 matches the level of the lower edge of the control head.
- 2) Remove the adjustment tool and load a new tape, then set the unit for playback.
- 3) Check that the tape does not curl or rise up noticeably near the ACE head.
- 4) If the tape curls up or rises noticeably, readjust the tilt adjuster screw and the height adjuster nut. (The height of the ACE head should be adjusted so that the lower edge of the tape is approx. 0.1 to 0.15 mm from the control head.)
- 5) Perform precision adjustment.




Fig. 2-3




Fig. 2-4

## 2-3. ACE HEAD ASSEMBLY ADJUSTMENT (PRECISION ADJUSTMENT)

Mode	Playback
Signal	Alignment tape (KRV-52PL 4 kHz) (For PAL)
Measuring instrument	Oscilloscope
Measuring point	Audio output terminal
Adjustment locations	Azimuth adjuster screw, Height adjuster nut, Tilt adjuster screw

### [Adjustment Method]

- 1) Adjust the tilt adjuster screw in the FWD or REV mode so that the lower flange of guide No. 7 does not curl up or rise.
- 2) Alternately adjust the azimuth adjuster screw, the height adjuster nut, and the tilt adjuster screw to maintain even audio output at maximum with minimum deviation.




Fig. 2-5


**Note:** In the adjustment of ACE head assembly (coarse adjustment and fine adjustment), if a azimuth, height and tilt were adjusted, again adjust the height of No. 5 and No. 6 guide rollers.

## 2-4. X-VALUE ADJUSTMENT

**Purpose:** To obtain compatibility with other VCRs.

**Precaution:** Before starting to adjust X-value, set the tracking control at the center position. To set the tracking control at the center position for the VCRs equipped with the **A** and **V** tracking control keys, press both the **A** and **V** tracking control keys at the same time. For the VCRs not equipped with the tracking control keys, deactivate the automatic tracking control by pressing the tracking **AUTO/MANUAL** key on the remote control unit during threading operation (after a tape is inserted but before the VCR starts playing back the tape).

Mode	Playback
Signal	Alignment tape KRV-52PL
Measuring instrument	Oscilloscope TIM/DIV: 2ms Trigger source: CH2 Trigger slope: +
Measuring point	CH-1: Connector PB RF pin for RF PC board check CH-2: Connector RF SWP pin for RF PC board check
Adjustment locations	X-value adjuster screw



RF output shall be maximum at the center position of the tracking control.

Fig. 2-6

### [Adjustment Method]

Set the tracking control at the center position. For the VCRs equipped with narrow gap video heads, set the X-value adjustment screw where a maximum RF output is obtained. For the VCRs equipped with wide gap video heads, set the X-value adjustment screw both where a maximum RF output is obtained and where the RF output decreases immediately when the [T] tracking control key is pressed.

#### 1. Adjusting X-value




Fig. 2-7

## 2. Checking false tracking




Fig. 2-8




Fig. 2-9

## 2-5. ADJUSTMENT AFTER REPLACING THE DRUM (VIDEO HEAD)

**Purpose:** Co-relative height, X-value and other factors of the drum will deviate from those of the guide roller. If the drum is replaced properly, these deviations are extremely small.

**Note 1:** Deactivate the automatic tracking control for setting the mechanism in manual tracking control mode.

**Note 2:** To set the tracking control at the center position, deactivate the automatic tracking control by pressing the tracking [AUTOMANUAL] key on the remote control unit during the loading operation (after a tape is inserted but before the VCR starts playing back the tape).

Mode	Playback
Signal	Alignment tape KRV-52PL (For PAL), blank tape
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SWP pin for RF PC board check.
Adjustment locations	Guide roller (Refer to 2-1.) Switching position (Refer to the Service Manual) X-value (Refer to 2-5.)

### [Adjustment Method]






Fig. 2-10

**[Checking the evenness and fluctuation of the RF output]**


- 1) Set the RF output to the maximum level using the tracking buttons.



- 2) Perform fine adjustment of the voltage level range of the oscilloscope, then adjust the RF output deviation to within 4 gradations.



- 3) Press the tracking buttons and adjust the maximum amplitude of the RF output to within 3 gradations.
- 4) AT this time, check if the minimum amplitude is more than 2 gradations.



- 5) Check that the RF output fluctuation between minimum and maximum levels is within 13%.

Fig. 2-11