


TC131SD



SPECIFICATIONS

Power Requirements:	AC 120V 60 Hz (USA, Canada) 110, 127, 220, 240 V 50/60 Hz (AEP, AUS) 100, 110, 120, 127, 220, 240 V 50/60 Hz (E)	Outputs:	LINE OUT (2) Load impedance: greater than 10 k Ω Level: 0.775 V (0 dB) with 100 k Ω load
Power Consumption:	11W		HEADPHONE Load impedance: 8 Ω Level: 31 mV (-28 dB)
Track:	Two-track two-channel stereo		
Frequency Response:	With chromium dioxide cassette 40 ~ 15000 Hz (NAB) 50 ~ 12000 Hz (DIN) With ordinary cassette 40 ~ 13000 Hz (NAB) 50 ~ 10000 Hz (DIN)	REC/PB Connector:	Input impedance: less than 10 k Ω (AEP, E, AUS) Output impedance: less than 50 k Ω
Overall Signal-to-Noise Ratio:	48 dB (DOLBY NR switch to OFF) Ratio: (With DOLBY NR switch to ON, S/N ratio improves 5 dB at 1 kHz) and 10 dB at 5 kHz.	Semiconductors:	32 transistors and 20 diodes
Wow and Flutter:	0.22% (NAB) (RMS weighted) \pm 0.38% (DIN)	Record/playback Head:	PF145-3602A6 (ferrite)
Record Bias Frequency:	Approximately 85 kHz	Erase Head:	EF135-36
Inputs:	MICROPHONE (2) Impedance: low Maximum sensitivity: 0.2 mV (-72 dB)	Motor:	D-015G (DC governor)
	LINE IN (2) Impedance: 100 k Ω or more Maximum sensitivity: 0.06 V (-22 dB)	Accessories:	Connection cord RK-74 (2) Printed matters Cleaning tips (AEP, Canada, E, AUS)
		Dimensions:	388 (w) x 95 (h) x 230 (d) mm 15 ⁵ / ₁₆ (w) x 3 ³ / ₄ (h) x 9 ¹ / ₁₆ (d) inches
		Weight:	4.1 kg, 9 lb 1 oz (USA, Canada) 4.5 kg, 9 lb 15 oz (AEP, E, AUS)

SERVICE MANUAL

658

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
	Specifications	i			
1.	OUTLINE		4.	DIAGRAMS	
1-1.	DOLBY Noise Reduction System	3	4-1.	Schematic Diagram, Amp Circuit ...	27
1-2.	Automatic Shut-off Mechanism Operation.....	5	4-2.	Mounting Diagrams	29
1-3.	Block Diagram	7	4-3.	Schematic Diagram, DOLBY Circuit	30
1-4.	External View (1).....	8	4-4.	Level Diagrams	31
1-5.	External View (2).....	8			
1-6.	Internal View (1).....	9	5.	EXPLODED VIEWS AND PACKING	
1-7.	Internal View (2).....	9	5-1.	Exploded View (1)	32
			5-2.	Exploded View (2)	33
2.	DISASSEMBLY		5-3.	Exploded View (3)	34
2-1.	Case Removal	10	5-4.	Exploded View (4)	35
2-2.	Cassette Lid Removal	10	5-5.	Exploded View (5)	36
			5-6.	Exploded View (6)	37
3.	ADJUSTMENTS		5-7.	Exploded View (7)	38
3-1.	Mechanical Adjustments	11	5-8.	Packing	39
3-2.	Electrical Adjustments and Measurements	18	6.	ELECTRICAL PARTS LIST.....	40
			7.	HARDWARE	44

MODEL IDENTIFICATION (See specification label)


Model	Identification on specification label
USA	AC 120V 60Hz
Canada	AC 120V 60Hz
E	AC 100, 110, 120, 127, 220, 240V 50/60 Hz
AEP	110, 127, 220, 240V 50/60 Hz
AUS	110, 127, 220, 240 V 50/60 Hz

CAUTION

1. Record and playback level adjustments should be carefully made. The levels must be as specified for correct DOLBY circuit operation.
2. When replacing resistors and capacitors needing $\pm 2\%$ tolerance, use only those with red line (or dot) or G mark, as DOLBY system requires precise circuit operation.


$\pm 2\%$ Tolerance Identification

Resistor



Red line (or dot) indicates $\pm 2\%$ tolerance selected from resistors of $\pm 5\%$ tolerance.

Capacitor



When ordering replacement parts, use PART NUMBERS listed in Parts Lists or shown in EXPLODED VIEWS.
Parts List reference numbers should not be used.

All screws in this service manual are Phillips type (cross recess type) unless otherwise indicated.
(-) : slotted head

SECTION 1 OUTLINE

1-1. DOLBY NOISE REDUCTION SYSTEM *

1. OUTLINE

The TC-131SD uses a DOLBY NOISE REDUCTION system to reduce hissing noise during low level or zero level sound passages. This system pre-emphasizes the low-level high-frequency recorded signals which are disturbed by hissing noise. During playback, it de-emphasizes these signals along with tape hiss and thus improves signal-to-noise ratio.

(1) The DOLBY system differs from other noise reduction systems as follows:

- * High-fidelity sound cannot be obtained if the DOLBYIZED tape is played back on other systems or vice versa.
- * Signal levels must be precisely adjusted since these levels control the DOLBY system.

(2) The DOLBY system of the TC-131SD has the following features:

The DOLBY unit (DCB-020) contains a variable high-pass filter controlled by input level. During Record:
The DOLBY unit (DCB-020) is series-connected to boost the low-level high-frequency signal.




Fig. 1-1. Unit connection in record mode and frequency response

During Playback:
The DOLBY unit is connected as a negative feedback circuit to decrease the gain for low-level high frequency signals boosted during record.





Fig. 1-2. Unit connection in playback mode and frequency response


2. CIRCUIT OPERATION

(Refer to schematic diagram on page 30.)

Stage/Control	Function
R501, R502	These resistors attenuate signal level 20 dB. High resistance value is due to high output impedance of LINE OUT jack since DOLBY unit input is connected to LINE OUT jack.
Q501	This emitter-follower amplifier is an impedance-translator for the low-impedance high-pass filter.
filter C503, C504, C505 R509, Q502	Q502 changes the filter curve determined by C503, C504, C505 and R509.



Attenuation at 10 kHz:
6 dB



Attenuation at 10 kHz:
16 dB

Q502-control amplifier
Q505, Q506, Q507

This high gain (more than 50 dB) amplifier is used for flat frequency response. Normal input level of this amplifier is -56 dB (1.2 mV) at 1,000 Hz.

rectifier
D501, D502

These diodes performing as a voltage doubler rectify amplified signals to obtain a dc component greater than 1V.

C507

This capacitor prevents abnormal oscillation of high frequency signals. The capacitance value is small (6 pF) because the amplifier requires a short attack time.

release time
C517, R534

C517 and R534 effect a release time of about 10 m sec.

C515, R530

C515 and R530 connected to the negative feedback circuit of Q502-control amplifier boost the high frequency signal input attenuated by the filter.

C518, R537

For increasing-transient inputs, C518 and R537 reduce attack time to 25 μsec. When signal level increases suddenly, attack time—time until DOLBY system begins to operate—causes a click noise due to over-shoot as shown in Fig. 1-3. To prevent

the click noise, by-pass circuits are added. See Fig. 1-4.




Fig. 1-3.




Fig. 1-4.

C513, R525

R525 is series-connected to the by-pass capacitor C513 of Q505 emitter. R525 and a small value coupling-capacitor C512 decrease the control amplifier gain of low frequencies.

flat amplifier
Q503, Q504

This stage amplifies the filter output signals.

* The word DOLBY is a trade mark of Dolby Laboratories, Inc.

1-2. AUTOMATIC SHUT-OFF MECHANISM OPERATION


The TC-131SD mechanism is designed so that the unit will shut itself off automatically at tape end in any mode by detecting stop mode of take-up reel spindle.

As an example, the mechanism operation in playback mode is illustrated step by step.


Playback – Normal Operation –

4


As long as tape remains on the spindle, take-up reel spindle continues to rotate. Shut-off belt (C) transmits turning force to the detecting pulley and then to the detecting pulley lever.



2



Detecting pulley lever operation in playback mode.



5

As a result of rotational friction on the detecting pulley lever, the pin always wants to hug the back side of the slot, (upper side as shown). The constant motion of a shut-off lever A slides the pin back and forth along the back side of the slot.



3

On being caught by the nail, shut-off lever moves back and forth between positions A and B repetitively. In order to shut the machine off, shut-off lever must pull the shut-off link.

Playback – Automatic Shut-off Operation –

6

When tape runs out on the spindle, the turning force on the detecting pulley lever halts. When the pin starts to move inward in the slot, it no longer wants to hug the side of the slot as previously, but stops in the middle on the finger.




7

The finger holds the pin (and shut-off lever A) playback far enough so that the nail is able to catch shut-off lever A in position ① as shown.


8

Now shut-off lever A can move far enough to pull the shut-off link which shuts the machine off.

For fast forward, automatic operation is the same as for the playback mode. For rewind mode, the pin hugs the opposite side of the slot, as shown below.



1.3. BLOCK DIAGRAM



Note:

1. Switch Mode:

Ref. No.	Switch	Mode
S101.201	record/playback	playback
S1	LIMITER	ON
S2	DOLBY NR	ON
S3	timing	playback
S4	TAPE SELECT	NORMAL
S5	muting	OFF
S6	motor	ON
S7	POWER	OFF

2. Timing Switch (S3) Functions in stop mode:


- * Timing switch stops the LINE OUT signal.
- * Timing switch stops the bias oscillation.
- * Timing switch cuts the DOLBY circuit OFF.

3. Muting Switch (S5) Functions:


When record/playback switch is changed, muting switch grounds HEADPHONE/METER AMP circuit and prevents misoperation of limiter circuit caused by click noise.

(Muting switch is turned ON for a moment to ground click noise when record/playback switch is changed or when each button is depressed.)

1-4. EXTERNAL VIEW (1)



1-5. EXTERNAL VIEW (2)



1-6. INTERNAL VIEW (1)

CNJ301
(AEP, AUS, E)

LINE IN R

LINE OUT L

LINE IN L

LINE OUT R

1-224-193-00
resistor, 20 k Ω (A); variable:
REC VOLUME (R221)
1-224-193-00
resistor, 20 k Ω (A); variable:
REC VOLUME (R121)


automatic shut-off
mechanism section

1-516-268-00
switch, lever slide: TAPE SELECT
(S4)

1-516-268-00
switch, lever slide: LIMITER (S1)

1-516-268-00
switch, lever slide; DOLBY NR (S2)

8-825-506-00
head, erase (EF 135-36) (EH)



8-825-584-00
head, record/playback
(PF 145-3602A6) (RPH)

X-34893-06-0
pinch roller ass'y


1-7. INTERNAL VIEW (2)

3-533-357-01 (no groove)
3-533-357-11 (one groove)
3-533-357-21 (two grooves)
3-533-357-31 (three grooves)
pulley, motor

1-582-440-00
printed circuit board, jack

X-35333-51-0
complete circuit board, amp

automatic shut-off
mechanism section



1-442-201-00 (E)
1-442-097-00 (USA)
1-442-167-00 (Canada)
1-442-189-11 (AEP, AUS)
transformer, power (T301)

X-35133-52-0
complete circuit board,
DOLBY

1-514-792-00
switch, leaf: motor (S6)

1-513-273-00
switch, slide: timing (S3)

1-514-346-00
switch, leaf: muting (S5)




X-34893-07-2
flywheel ass'y

X-34890-08-0
arm ass'y, tension


SECTION 2 DISASSEMBLY

2-1. CASE REMOVAL

REC VOLUME knob



2-2. CASSETTE LID REMOVAL




SECTION 3 ADJUSTMENTS

3-1. MECHANICAL ADJUSTMENTS

Head Height Adjustment

- playback mode -


Adjust by removing or adding the adjusting washer so that tape straight runs without curl at positions shown by arrows.



Part. No.	Description
3-513-237-01	adjusting washer (t=0.1)
3-513-237-11	adjusting washer (t=0.2)

Shut-off Release Arm Adjustment


- stop mode -



Note: If above adjustment is not correctly made, automatic shut-off mechanism will operate during pause mode.

Motor Leaf Switch (S6) Adjustment


- stop mode -



Note: When slowly depressing forward button, ensure that slide switch is changed after leaf switch is closed.

Record Lever Holder Adjustment


- stop mode -



Muting Leaf Switch (S5) Adjustment


- stop mode -

Perform in numerical order .




Note: After this adjustment.

- When depressing RECORD button without tape cassette, ensure that record/playback switch is not changed.
- When depressing RECORD button with a tape cassette that has safety tab, ensure that record/playback switch is changed.




Motor Pulley Height Adjustment

- stop mode -



Note: Ensure that capstan belt is installed without twist and dirt.




Checks After Mechanical Adjustments (1)

Button Operation Check

Depress	Results
forward button fast forward button rewind button REC button	locked
stop button EJECT button	not locked
PAUSE button	{ first depressinglocked second depressingreleased

Mode	Depress	Results
playback	fast forward button	fast forward mode
	rewind button	rewind mode
	stop button	stop mode
	REC button	not depressed
	EJECT button	playback mode with cassette lid opened
fast forward	forward button	playback mode
	rewind button	rewind mode
	stop button	stop mode
	EJECT button	eject, stop mode
	REC button	not depressed
rewind	forward button	playback mode
	fast forward button	fast forward mode
	stop button	stop mode
	EJECT button	eject, stop mode
	REC button	not depressed
record	fast forward button	fast forward mode
	rewind button	rewind mode
	stop button	stop mode
	EJECT button	record mode with cassette lid opened

Pinch Roller Pressure Measurement




Note: The pressure should be measured just when the pinch roller contacts the capstan after being separated.

Forward Button Timing Check


When slowly depressing forward button, ensure that the following functions occur in the numerical order. (or simultaneously.)

1. Brake separates from each reel spindle.
2. Tension pulley contacts take-up reel spindle.
3. Motor switch turns on and capstan starts to rotate.
4. Pinch roller contacts capstan.




Torque Measurement

Mode	Torque
Playback	40 ~ 60 g · cm (0.56 ~ 0.83 oz · inch)
Fast forward Rewind	70 ~ 150 g · cm (0.84 ~ 2.1 oz · inch)




Motor Current Measurement

Measure current as shown.



Fast Forward Spring Check

— stop mode —




Note: When fast forward and rewind torques are poor, clean idlers and adjust fast forward spring.

Lock Lever Operation Check

— record mode —

1. With forward button kept depressed, depress stop button. (REC button is only released and record function is not completely released.)
2. With forward button gradually returned, ensure that lock lever releases in the direction shown by the arrow.




Note: If lock lever does not release, REC button may not be depressed with a cassette loaded.

Checks After Mechanical Adjustments (2)

**Automatic Shut-off Mechanism Operation Check
Release-Lever-C Operation Check**

1. Turn POWER switch OFF and place the unit in stop mode.
2. Pull brake release lever in the direction shown by the arrow ① to obtain the clearance marked ○.
3. Pull shut-off lever A in the direction shown by the arrow ② to interlock shut-off lever B with shut-off lever A.
4. Lift shut-off lever B to stop the pin of shut-off lever A at finger of detecting lever.
5. When returning release lever C, ensure that the pin of shut-off lever A returns to position A.

Note: Release Function Order:
release lever C → release lever A →
release lever B → detecting lever



Do not break marked ✱, apply lock paint there.

If the pin of shut-off lever A does not return to position A in Step 5, automatic shut-off mechanism will operate, as soon as mode changes from stop to playback, fast forward or rewind.


This trouble is caused by the following:

Cause	Remedy
Lengthened spring marked ▲	Replace.
Clearance marked ○	Loosen screws marked * and adjust release-lever-C position for no clearance.
Unsmooth return of brake release lever	Make the lever free from being caught by other levers or projections.

Detecting-Lever and Release-Lever-B Operation Check

1. Rewind Mode

Check as shown below:



If necessary, adjust by bending release lever B. (Do not bend the portion of release lever B shown in black.)


Note: If the above adjustment is not correctly made, automatic shut-off mechanism will operate during rewind mode.

2. Playback and Fast Forward Modes

Check as shown below:

Settings:
* With cassette loaded
* POWER switch: ON

Detecting pulley should turn clockwise.




- Ensure that the pin moves along the slot B.

If the pin does not move along the slot B, automatic shut-off mechanism will operate during playback and fast forward modes.

Check the following:

- Friction between detecting pulley and detecting lever should not weak.
- Detecting pulley belt should not slip.




**Shut-off Lever-A and Shut-off Lever-B
Operation Check (1)**

— playback, fast forward and rewind mode —
(during tape running)

Check the following:

1. Shut-off lever B should completely interlock shut-off lever A at 1st step.
2. The release lever should not push shut-off lever B.
3. There should be a clearance between the release lever and release lever A.

Note: If the above checks are not satisfied, automatic shut-off mechanism will operate during tape running or will not operate even at end of tape. Perform Release-Lever-C Operation Check on Page 15.




**Shut-off Lever-A and Shut-off Lever-B
Operation Check (2)**

With stop button or PAUSE button depressed in playback, fast forward and rewind mode, and with automatic shut-off mechanism operated at end of tape.

Check the following:



1. Release lever A should push the release lever which pushes shut-off lever B.
2. Shut-off lever B should repeat constant motion not to interlock shut-off lever A.



Release-Lever-B Operation Check.

Check the following:

1. When the pin comes at position "d" or "e" before automatic shut-off operation at end of tape in playback mode, the pin should be stopped at position "b" by depressing PAUSE button.
2. When the pin comes at position "d" in playback, fast forward and rewind modes, the pin should be stopped at position "a" or "b" by depressing stop button.
3. After automatic shut-off mechanism has operated at end of tape in playback, fast forward and rewind modes, the pin should be stopped at position "b".



3-2. ELECTRICAL ADJUSTMENTS AND MEASUREMENTS

Precaution:

1. Clean the following parts with an alcohol moistened swab:
 - * record/playback head
 - * erase head
 - * capstan
 - * pinch roller
 - * rubber belts
 - * idlers
2. Demagnetize record/playback head with a head demagnetizer.
3. Do not use magnetized screwdriver for adjustments.
4. After adjustments, apply locking paint to the parts adjusted.
5. Adjustments should be performed in the order arranged in this service manual.
6. Adjustments and measurements should be performed for both L-CH and R-CH with rated power supply voltage unless otherwise specified.
7. Record and playback level adjustments should be carefully performed. In case the levels are not as specified, DOLBY circuit will not correctly operate.

Test Equipment/Tools Required:

- audio oscillator (af osc)
- VTVM
- digital frequency counter
- oscilloscope
- wow meter
- 1 kHz } bandpass filter
- 5 kHz }
- attenuator (600Ω)
- non-magnetic screwdriver
- blank tape cassette (completely erased with bulk eraser) C-60 HF
- C-60 CR
- resistors 100 kΩ (¼W), 600 Ω (¼W)
- 300 Ω (¼W),
- SONY test tapes
- SPC-4 (1kHz, 0 dB)
- WS-48 (3kHz, 0 dB)
- P-4-L81 (333 Hz, 0 dB)
- P-4-A81 (6.3kHz, -10 dB)
- Normal Input Level

	MICROPHONE	LINE IN
impedance	600 Ω	100 kΩ or more
input level	-60 dB (0.77 mV)	-10 dB (0.25 V)

Normal Output Level

	LINE OUT
load impedance	100 kΩ
output level	0 dB (0.775 V)


1. Tape Speed Adjustment

Settings:

- LIMITER switch: OFF
- TAPE SELECT switch: NORMAL
- DOLBY NR switch: OFF

Procedure:

1. Mode: Playback



Specification: 985 ~ 1015 Hz
Frequency difference between beginning and end is within 10 Hz.

2. If necessary, change motor pulley.

Part No.	Motor Pulley (groove)	Tape Speed
3-533-357-01		faster
3-533-357-11		↑ ↓
3-533-357-21		
3-533-357-31		slower

Note: After the motor pulley is changed, perform Motor Pulley Height Adjustment on Page 11.

2. Head Azimuth Adjustment


Settings:

LIMITER switch: OFF
 TAPE SELECT switch: NORMAL
 DOLBY NR switch: OFF

Procedure:

1. Mode: Playback


P-4-A81
 (6.3 kHz, -10 dB)





Adjust	VTVM reading	Remarks
azimuth adjusting screw	highest peak	If the azimuth angles of L-CH and R-CH are not the same, set the screw midway between two screw positions.


3. Mode: Playback

P-4-A81
 (6.3 kHz, -10 dB)



Adjust	On the oscilloscope
azimuth adjusting screw	in phase  90° 

Adjustment Location:



azimuth adjusting screw

3. Playback Level Adjustment


Settings:

LIMITER switch: OFF
 TAPE SELECT switch: NORMAL
 DOLBY NR switch: OFF

Procedure:

1. Mode: Playback


P-4-L81
 (333 Hz, 0 dB)



- 2.

Adjust	VTVM reading	Remarks
R115 R215	0 dB (0.775V)	1. Allowance: within ± 0.5 dB 2. Level difference between the L-CH and R-CH should be within 1 dB.

Adjustment Location:



R215
(R-CH)

R115
(L-CH)

4. Playback Equalizer Adjustment


Settings:

LIMITER switch: OFF
 TAPE SELECT switch: NORMAL
 DOLBY NR switch: OFF

Procedure:

1. Mode: Playback


P-4-L81
 (333 Hz, 0 dB)



Memorize the VTVM reading.

2. Mode: Playback


P-4-A81
 (6.3 kHz, -10 dB)



Adjust	VTVM reading	Remarks
R114 (L-CH) R214 (R-CH)	Level in Step 2 are lower by 10 dB than level in Step 1.	Allowance: within ± 1 dB

Note: When adjustable resistors R114 and R214 are much turned, perform playback level adjustment on Page 19.

Adjustment Location:



R214
(R-CH)

R114
(L-CH)


5. LEVEL Meter Calibration

Settings:

LIMITER switch: OFF
 TAPE SELECT switch: NORMAL
 DOLBY NR switch: OFF
 REC VOLUME control: For 0 dB (0.775 V)
 LINE OUT level with 333 Hz, -60 dB (0.77 mV)
 MICROPHONE signal in record mode.

Procedure:

1. Mode: Record




333 Hz, -60 dB (0.77 mV) 0 dB (0.775 V)

2.

Adjust	LEVEL meter reading
R159 (L-CH) R259 (R-CH)	-20 0 +3

Adjustment Location:

R259 (R-CH) R159 (L-CH)




6. 19 kHz Filter Adjustment

Settings:

LIMITER switch: OFF
 TAPE SELECT switch: NORMAL
 DOLBY NR switch: OFF
 REC VOLUME control: For 0 dB (0.775 V)
 LINE OUT level with
 333 Hz, -60 dB (0.77 mV)
 MICROPHONE signal
 in record mode.

Procedure:


1. Mode: Record



Note: 19 kHz pilot signal of stereo signal generator may be used for input signal.

Adjust	VTVM reading	Remarks
L102 (L-CH)	minimum (less than -28 dB, 31 mV)	Frequency Allowance: within ± 20 Hz.
L202 (R-CH)		

Adjustment Location:



L202 (R-CH)

L102 (L-CH)


7. Record Bias Adjustment

Settings:


LIMITER switch: OFF
 TAPE SELECT switch: NORMAL
 DOLBY NR switch: OFF
 REC VOLUME control: For 0 dB (0.775 V)
 LINE OUT level with
 333 Hz, -60 dB (0.77 mV)
 MICROPHONE signal
 in record mode.

Procedure:

1. Mode: Record



2. Mode: Playback




Adjust	VTVM reading
C143 (L-CH)	1 kHz level = 7.5 kHz level Allowance: within ± 0.5 dB
C243 (R-CH)	
C144 (L-CH)	
C244 (R-CH)	

Level	Capacitance Value
7.5 kHz > 1 kHz	increase
7.5 kHz < 1 kHz	decrease

Adjust by soldering and repeat steps 1 and 2.

— Continued on next page —

Adjustment Location:



If the specified results are not obtained, connect additional capacitor:

Level	Adjust
7.5 kHz > 1 kHz	Connect capacitor 56pF at (A) position and repeat Steps 1 to 2.
7.5 kHz < 1 kHz	Connect capacitor 56pF at (B) position and repeat Steps 1 to 2.


8. Record Level Adjustment

Settings:


- LIMITER switch: OFF
- TAPE SELECT switch: NORMAL
- DOLBY NR switch: OFF
- REC VOLUME control: For 0 dB (0.775 V) LINE OUT level with 333 Hz, -60 dB (0.77 mV) MICROPHONE signal in record mode.

Procedure:

1. Mode: Record




2. Mode: Playback



Adjust	VTVM reading	Remarks
R139 (L-CH) R239 (R-CH)	0 dB (0.775 V)	Allowance: within ± 0.5 dB

Adjust R139 and R239 and repeat steps 1 and 2.

Adjustment Location:




9. Overall Signal-to-Noise Ratio Measurement

Settings:


LIMITER switch: OFF
 TAPE SELECT switch: NORMAL
 DOLBY NR switch: OFF
 REC VOLUME control: for 0 dB (0.775 V)
 LINE OUT level with 333 Hz, -60 dB (0.77 mV)
 MICROPHONE signal in record mode.

Procedure:


1. Mode: Record



2. Mode: Record



3. Mode: Playback



Playback	VTVM reading
333 Hz	level difference: greater than 44 dB
no signal	


10. Overall Frequency Response Measurement

Settings:


LIMITER switch: OFF
 TAPE SELECT switch: NORMAL
 REC VOLUME control: For 0 dB (0.775 V)
 LINE OUT level with 333 Hz, -60 dB (0.77 mV)
 MICROPHONE signal in record mode.

Procedure:

1. Mode: Record



2. Mode: Playback



Playback	Output level difference from 333 Hz level		
	DOLBY NR switch: ON	DOLBY NR switch: OFF	
	TAPE: C-60 HF C-60CR	TAPE: C-60 CR TAPE SELECT switch: CrO ₂	TAPE: C-60 HF
333 Hz	0 dB	0 dB	0 dB
40 Hz	—	± ₁₃ ³ dB	± ₁₃ ³ dB
70 Hz	±3 dB	±3 dB	±3 dB
1 kHz	±4 dB	—	—
5 kHz	±4 dB	±3 dB	±3 dB
7.5 kHz	±4 dB	±3 dB	±3 dB
12 kHz	—	—	± ₁₃ ³ dB
15 kHz	—	± ₁₃ ³ dB	—

— : not specified


11. LIMITER Response Measurement

Settings:

LIMITER switch: ON
 TAPE SELECT switch: NORMAL
 REC VOLUME control: For 0 dB (0.775 V)
 LINE OUT level with
 333 Hz, -60 dB (0.77 mV)
 MICROPHONE signal
 in record mode.

Procedure:

1. Mode: Record



Input signal	VTVM reading
333 Hz, -60 dB (0.77 mV)	-0.5 dB (0.73 V) ±1 dB
333 Hz, -30 dB (25 mV)	+4 dB (1.2 V) ±1.5 dB


12. DOLBY System Signal-to-Noise Ratio Improvement Measurement

Settings:


LIMITER switch: OFF
 TAPE SELECT switch: NORMAL
 REC VOLUME control: MIN
 DOLBY NR switch: OFF

Procedure:

1. Mode: Record
no signal input



2. Mode: Playback



3. With DOLBY NR switch set to ON position, perform Steps 1 and 2.
4. Ensure that DOLBY system improves S/N ratio. S/N ratio should be improved,
 4 dB or more at 1 kHz
 8 dB or more at 5 kHz


13. Erase Ratio Measurement

Settings:


LIMITER switch: OFF
 TAPE SELECT switch: CrO₂
 DOLBY NR switch: OFF
 REC VOLUME control: For 0 dB (0.775 V)
 LINE OUT level with
 333 Hz, -60 dB (0.77 mV)
 MICROPHONE signal
 in record mode.
 blank tape: C-60 CR

Procedure:


1. Mode: Record



2. Rewind half of recorded portion.
3. Set the REC VOLUME control to MIN position.
4. Mode: Record
no signal input (erase)



5. Mode: Playback



Playback	VTVM reading
1 kHz	level difference: greater than 60 dB
erased portion	


14. Cross-talk Measurement (between channels)

Settings:


LIMITER switch: OFF
 TAPE SELECT switch: NORMAL
 DOLBY NR switch: OFF
 R-CH REC VOLUME control: For 0 dB (0.775 V)
 LINE OUT level with
 333 Hz, -60 dB (0.77 mV)
 MICROPHONE signal
 in record mode.

Procedure:

1. Set L-CH REC VOLUME control to the same as R-CH REC VOLUME control position.
2. Terminate L-CH MIC jack with 300 Ω resistor.
3. Mode: Record



4. Mode: Playback



Play back	VTVM reading
R-CH (1 kHz)	level difference: greater than 25 dB
L-CH (no signal)	


15. Cross-talk Measurement (between tracks)

Settings:


LIMITER switch: OFF
 TAPE SELECT switch: NORMAL
 DOLBY NR switch: OFF
 R-CH REC VOLUME control: For 0 dB (0.775 V)
 LINE OUT level with
 333 Hz, -60 dB (0.77 mV)
 MICROPHONE signal
 in record mode.

Procedure:


1. Set L-CH REC VOLUME control to the same as R-CH REC VOLUME position.
2. Terminate L-CH MIC jack with 300 Ω resistor.
3. Mode: Record



4. Mode: Playback



5. Turn the cassette over.
6. Mode: Playback



Playback	VTVM reading
1 kHz	level difference: greater than 60 dB
adjacent track of the recorded track	


16. Wow and Flutter Measurement

Settings:

LIMITER switch: OFF
 TAPE SELECT switch: NORMAL
 DOLBY NR switch: OFF

Procedure:

WS-48
 (3 kHz, 0 dB)




Specification: 0.25 % (RMS) weighted

Note: Measure wow and flutter for beginning and end portion of tape (WS-48).


SECTION 4 DIAGRAMS

4-1. SCHEMATIC DIAGRAM

Amp Circuit



Muting switch is turned ON for a moment to ground click noise when record/playback switch is changed or when each button is depressed.



Red Line Circuit: AEP, E, AUS

- Note:**
- All resistors and capacitors are in Ω and μF unless otherwise specified.
 - Letter in () suffixed to variable resistor value indicates characteristics.
 - Chassis ground.
 - Components for R-CH have the same values as for L-CH.
 - (N): Low noise resistor
 - Voltage values shown are measured with a voltmeter (20k Ω /V). Variations may be noted due to normal production tolerances.
 - no mark: stop mode
 - (): record mode
 - AC voltage values across heads are measured with a VTVM in record mode.

• Switch mode:

Ref. No.	Switch	Mode
S101, 201	record/playback	playback
S1	LIMITER	ON
S2	DOLBY NR	ON
S3	timing	STOP
S4	TAPE SELECT	CrO ₂
S5	muting	OFF
S6	motor	OFF
S7	POWER	ON


• When replacing resistors and capacitors needing $\pm 2\%$ tolerance, use only those with red line (or dot) or G mark, as DOLBY system requires precise circuit operation.

2% Tolerance Identification

Resistor: value tolerance (gold: $\pm 5\%$)

Capacitor: value G mark indicates $\pm 2\%$ tolerance

Red line (or dot) indicates $\pm 2\%$ tolerance selected from resistors of $\pm 5\%$ tolerance






4.2. MOUNTING DIAGRAMS

- Conductor Side -

DOLBY CIRCUIT BOARD
DCB-020

JACK CIRCUIT BOARD
(Component Side)



Q	D
601	501
603	503
602	502
604	504
605	505
606	506
607	507
603	503
601	501
602	502
501	501
503	503
604	504

• Switch mode:

Ref. No.	Switch	Mode
S101, 201	record/playback	playback
S1	LIMITER	ON
S2	DOLBY NR	ON
S3	timing	STOP
S4	TAPE SELECT	C/O ₂
S5	muting	OFF
S6	motor	OFF
S7	POWER	ON

• When replacing resistors and capacitors needing ±2% tolerance, use only those with red line (or dot) or G mark, as DOLBY system requires precise circuit operation.

2% Tolerance Identification

Resistor: value tolerance (gold: ±5%)



Capacitor: value G mark indicates ±2% tolerance

Red line (or dot) indicates ±2% tolerance selected from resistors of ±5% tolerance




Q	204	205	203	206	202	201	207	208
D								
ADJ				R239, L202			R221	R1
				R215, R214				

Resistors and capacitors are in Ω and μF otherwise specified.
in () suffixed to variable resistor indicates characteristics.
: chassis ground
: components for R-CH have the same values as L-CH.



• (N) : Low noise resistor
• Voltage values shown are measured with a voltmeter (20kΩ/V). Variations may be noted due to normal production tolerances.
no mark : stop mode
() : record mode
• AC voltage values across heads are measured with a VTVM in record mode.



- Q101, 102, 104 2SC631A
- 201, 202, 204 2SC633A
- 203, 208 2SC634A
- Q105 ~ 107 2SC634A
- 205 ~ 207 2SC634A
- 501, 502 2SC634A
- 504 ~ 507 2SC634A
- 601, 602 2SC634A
- 604 ~ 607 2SC634A
- Q503, 603 2SC632A




- D103, 203 T22
- D501, 502 T22A
- 601, 602 T22A
- D503, 504 IS155
- 603, 604 IS155




3	206	103	106	301	302
202 201 207	208 101, 107 108, 102	104	105	303, 302, 301	304
202	102, 101, 103				305
R221	R121 R259 R139 R114	R159 R139 R114	C244, 243 R115 L102	C144, 143	

4-3. SCHEMATIC DIAGRAM

DOLBY Circuit





- Note:**
1. All resistors and capacitors are rated in Ω and μF unless otherwise indicated.
 2. The letter (N) which is suffixed to rating values shows a low noise resistor.
 3. Voltage values shown are measured with a voltmeter (20 k Ω /V) in playback mode. Variations may be noted because of normal production tolerances.
 4. Components for R-CH are the same value as for L-CH.
 5. When replacing resistors and capacitors needing $\pm 2\%$ tolerance, use only those with red line (or dot) or G mark, as DOLBY system requires precise circuit operation.





4.4. LEVEL DIAGRAMS

Playback




Record



SECTION 5 EXPLODED VIEWS AND PACKING


5-1. EXPLODED VIEW (1)



Note:


- Parts without part numbers and names are not available.
- All screws are Phillips type (cross recess type) unless otherwise indicated.
(-): slotted head

5.2. EXPLODED VIEW (2)




- Note:**
1. Parts without part numbers and names are not available.
 2. All screws are Phillips type (cross recess type) unless otherwise indicated.
(-): slotted head

5-3. EXPLODED VIEW (3)





- Note:**
1. Parts without part numbers and names are not available.
 2. All screws are Phillips type (cross recess type) unless otherwise indicated.
 (-): slotted head

5-4. EXPLODED VIEW (4)




- Note:** 1. Parts without part numbers and names are not available.
 2. All screws are Phillips type (cross recess type) unless otherwise indicated.
 (-): slotted head

5-5. EXPLODED VIEW (5)




5-6. EXPLODED VIEW (6)



- Note:** 1. Parts without part numbers and names are not available.
 2. All screws are Phillips type (cross recess type) unless otherwise indicated.
 (-): slotted head

5-8. PACKING



Note: Parts without part numbers and names are not available.

SECTION 6 ELECTRICAL PARTS LIST

<i>Ref. No.</i>	<i>Part No.</i>	<i>Description</i>	<i>Ref. No.</i>	<i>Part No.</i>	<i>Description</i>
COMPLETE CIRCUIT BOARDS			COILS		
X-35133-52-0	DOLBY		L101, 201	1-407-561-00	microinductor, 33 mH
X-35333-51-0	amp		L102, 202	1-407-658-00	trap, 35 mH
PRINTED CIRCUIT BOARDS			L103, 203	1-407-497-00	microinductor, 2.7 mH
1-539-812-00	timing switch		L104, 204	1-407-499-00	microinductor, 3.9 mH
1-582-440-00	jack		L105, 205	1-407-212-00	microinductor, 33 mH
SEMICONDUCTORS			TRANSFORMERS		
Q101, 201	transistor	2SC631A	T101, 201	1-427-299-00	output
Q102, 202	transistor	2SC631A	T301	1-442-097-00	power (USA)
Q103, 203	transistor	2SC633A		1-442-167-00	power (Canada)
Q104, 204	transistor	2SC631A		1-442-189-11	power (AEP, AUS)
Q105, 205	transistor	2SC634A		1-442-201-00	power (E)
Q106, 206	transistor	2SC634A	T302	1-433-132-14	bias osc
Q107, 207	transistor	2SC634A	CAPACITORS		
Q108, 208	transistor	2SC633A	All capacitors are in μF unless otherwise indicated. (p = $\mu\mu$, elect = electrolytic)		
Q301	transistor	2SA678	C101, 201	1-107-095-11	270 p 50 V silvered mica
Q302	transistor	2SC1384	C102, 202	1-121-651-11	10 16 V elect
Q501, 601	transistor	2SC634A	C103, 203	1-121-398-11	10 25 V elect
Q502, 602	transistor	2SC634A	C104, 204	1-107-131-11	100 p 50 V silvered mica
Q503, 603	transistor	2SC632A	C105, 205	1-107-131-11	100 p 50 V silvered mica
Q504, 604	transistor	2SC634A	C106, 206	1-121-420-11	220 10 V elect
Q505, 605	transistor	2SC634A	C107, 207	1-105-680-12	0.039 50 V mylar
Q506, 606	transistor	2SC634A	C108, 208	1-121-651-11	10 16 V elect
Q507, 607	transistor	2SC634A	C109, 209	1-121-402-11	33 10 V elect
D101, 201	diode	VO-6C	C110, 210	1-107-139-11	220 p 50 V silvered mica
D102, 202	diode	10D-05	C111, 211	1-105-821-12	0.001 50 V mylar
D103, 203	diode	1T-22	C112, 212	1-121-398-11	10 25 V elect
D301	diode	10D-2	C113, 213	1-105-668-12	0.0039 50 V mylar
D302	diode	10D-2	C114, 214	1-105-665-12	0.0022 50 V mylar
D303	diode	10D-2	C115, 215	1-105-665-12	0.0022 50 V mylar
D304	diode	10D-2	C116, 216	1-121-416-11	100 25 V elect
D305	diode	10D-2	C117, 217	1-127-020-11	0.22 10 V solid aluminum
D306	diode	MZ-08	C118, 218	1-127-020-11	0.22 10 V solid aluminum
D501, 601	diode	1T-22	C119, 219	1-107-141-11	270 p 50 V silvered mica
D502, 602	diode	1T-22	C120, 220	1-121-409-11	47 16 V elect
D503, 603	diode	1S1555	C121, 221	1-121-402-11	33 10 V elect
D504, 604	diode	1S1555	C122, 222	1-105-821-12	0.001 50 V mylar
			C123, 223	1-107-115-11	22 p 50 V silvered mica
			C124, 224	1-121-651-11	10 16 V elect
			C125, 225	1-107-113-11	18 p 50 V silvered mica
			C126, 226	1-121-402-11	33 10 V elect
			C127, 227	1-121-409-11	47 16 V elect
			C128, 228	1-121-391-11	1 50 V elect

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	
C129, 229	1-105-509-12	0.0047	50 V mylar
C130, 230	1-105-685-12	0.1	50 V mylar
C131, 231	1-121-392-11	3.3	25 V elect
C132, 232	1-121-651-11	10	16 V elect
C133, 233	1-121-726-11	0.47	50 V elect
C134, 234	1-105-521-12	0.047	50 V mylar
C135, 235	1-105-517-12	0.022	50 V mylar
C136, 236	1-107-060-11	390 p	500 V silvered mica
C137, 237	1-107-004-11	100 p	500 V silvered mica
C138, 238	1-105-501-12	0.01	50 V mylar
C139, 239	1-121-396-11	4.7	50 V elect
C140, 240	1-107-127-11	68 p	50 V silvered mica
C141, 241	1-121-395-11	4.7	50 V elect
C142, 242	1-121-395-11	4.7	50 V elect
C143, 243	1-107-253-11	15+18+22+27 p	500 V silvered mica
C144, 244	1-107-042-11	2.2 p	500 V silvered mica
C301	1-121-361-11	470	35 V elect
C302	1-121-361-11	470	35 V elect
C303	1-121-411-11	47	50 V elect
C304	1-121-738-11	10	50 V elect
C305	1-121-420-11	220	10 V elect
C306	1-121-426-11	470	16 V elect
C307	1-121-426-11	470	16 V elect
C308	1-105-675-12	0.015	50 V mylar
C309	1-105-680-12	0.039	50 V mylar
C310	1-129-795-11	3900 p	500 V polystyrol
C311	1-131-197-11	3.3	16 V solid tantalum
C312	1-121-398-11	10	25 V elect
C313	1-105-833-12	0.01	50 V mylar
C314	1-105-821-12	0.001	50 V mylar
C501, 601	1-121-392-11	3.3	25 V elect
C502, 602	1-121-404-11	33	25 V elect
C503, 603	1-129-896-21	0.012	±2% 100 V polypropylene
C504, 604	1-129-701-21	0.01	±2% 100 V polypropylene
C505, 605	1-129-899-11	0.056	±2% 100 V polypropylene
C506, 606	1-121-391-11	1	50 V elect
C507, 607	1-107-103-11	6 p	50 V silvered mica
C508, 608	1-121-413-11	100	6.3 V elect
C509, 609	1-107-119-11	33 p	50 V silvered mica
C510, 610	1-121-398-11	10	25 V elect
C511, 611	1-121-409-11	47	16 V elect
C512, 612	1-105-670-12	0.0056	50 V mylar
C513, 613	1-121-402-11	33	10 V elect
C514, 614	1-121-651-11	10	16 V elect
C515, 615	1-129-794-21	0.0033	±2% 100 V polypropylene
C516, 616	1-121-392-11	3.3	25 V elect
C517, 617	1-127-025-11	3.3	10 V solid aluminum
C518, 618	1-105-669-12	0.0047	50 V mylar

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	
RESISTORS			
All resistors are 1/4W, carbon type and in Ω unless otherwise indicated. (k = 1000, M = 1000 k)			
R101, 201	1-244-721-09	100 k	low noise (USA, Canada)
	1-244-739-09	560 k	low noise (AEP, E, AUS)
R102, 202	1-242-668-11	620	(USA, Canada)
R103	1-242-690-11	5.1 k	
	R203	1-244-690-11	5.1 k
R104	1-242-697-09	10 k	low noise
	R204	1-244-697-09	10 k
R105, 205	1-210-832-11	6.8 M	low noise
R106, 206	1-242-734-09	360 k	low noise
R107, 207	1-242-667-11	560	
R108, 208	1-242-687-09	3.9 k	low noise
R109, 209	1-242-649-11	100	
R110, 210	1-242-721-09	100 k	low noise
R111, 211	1-242-709-11	33 k	
R112, 212	1-242-709-09	33 k	low noise
R113, 213	1-242-717-11	68 k	
R114, 214	1-222-701-00	10 k (B),	adjustable: playback equalizer
R115, 215	1-221-979-00	22 k (B),	adjustable: playback level
R116, 216	1-242-687-11	3.9	
R117, 217	1-242-671-11	820	
R118, 218	1-242-701-09	15 k	low noise
R119, 219	1-242-676-11	1.3 k	
R120, 220	1-242-697-11	10 k	
R121, 221	1-224-193-00	20 k (A),	variable: REC VOLUME
R122, 222	1-244-697-11	10 k	
R123, 223	1-244-695-11	8.2 k (AEP, E, AUS)	
R124, 224	1-242-705-11	22 k	
R125, 225	1-242-702-11	16 k	
R126, 226	1-242-719-09	82 k	low noise
R127, 227	1-242-721-09	100 k	low noise
R128, 228	1-242-721-09	100 k	low noise
R129	1-244-671-11	820	
	R229	1-242-671-11	820
R130, 230	1-242-695-11	8.2 k	
R131	1-244-717-11	68 k	
	R231	1-242-717-11	68 k
R132, 232	1-242-683-11	2.7 k	
R133, 233	1-242-689-11	4.7 k	
R134, 234	1-242-677-11	1.5 k	
R135, 235	1-242-713-11	47 k	
R136, 236	1-242-725-11	150 k	
R137	1-244-705-11	22 k	
	R237	1-242-705-11	22 k
R138, 238	1-242-725-11	150 k	
R139, 239	1-222-783-00	47 k (B),	adjustable: record level
R140, 240	1-244-697-11	10 k	
R141	1-242-699-11	12 k	
	R241	1-244-699-11	12 k

When ordering 2%- tolerance resistor and capacitor, note "2%" in addition to part number.

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>
MISCELLANEOUS					
CP301	1-231-057-31	encapsulated component C-R, 0.033 μ F + 120 Ω (USA, Canada)	M	8-834-015-01	motor, D-015G
	1-231-057-12	encapsulated component C-R, 0.033 μ F + 120 Ω (E)		1-534-526-00	cord, power (USA, Canada)
ME101, 201	1-524-078-21	meter, LEVEL		1-534-551-22	cord, power (E)
PL1, 2	1-518-129-71	lamp, LEVEL meter; 4.5 V 40 mA	F1	1-534-587-00	cord, power (AEP, AUS)
PL3	1-518-130-91	lamp, REC; 4.5 V 40 mA		1-532-205-00	fuse 200 mA (AEP, AUS)
EH	8-825-506-00	head, erase (EF 135-36)	F2, 3	1-532-129-00	fuse 0.2A (E)
RPH	8-825-584-00	head, record/playback (PF145-3602A6)	F4, 5	1-532-084-11	fuse 100 mA T (AEP, AUS)
				1-532-284-11	fuse 630 mA T (AEP, AUS)
				1-533-118-11	holder, fuse; 4 P (AEP, AUS)
				1-533-102-00	holder, fuse (E)

SECTION 7 HARDWARE

<u>Part No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Description</u>
SCREWS		RETAINING RINGS	
All screws are phillips type (cross recess type) unless otherwise indicated. (-): slotted head.		7-624-102-01	E 1.5
7-621-255-25	P 2 x 4	7-624-104-01	E 2
7-621-255-45	P 2 x 6	7-624-106-01	E 3
7-621-259-01	PS 2.6 x 4	7-624-108-01	E 4
7-621-259-15	P 2.6 x 3	7-624-118-01	E 2.5
7-621-259-25	P 2.6 x 4		
7-621-305-35	(-) F 2 x 5	WASHERS	
7-621-559-52	K 2.6 x 8	7-623-105-02	2 (small)
7-621-710-39	(-) SC 2 x 4	7-623-105-12	2 (middle)
7-621-759-45	PSW 2.6 x 6	7-623-107-02	2.6 (small)
7-621-759-75	PSW 2.6 x 10	7-623-107-12	2.6 (middle)
7-621-770-62	B 2.6 x 5	7-623-108-02	3 (small)
7-621-771-13	B 2.6 x 6	7-623-108-12	3 (middle)
7-621-771-38	B 2.6 x 8	7-623-108-15	3 (middle)
7-621-843-25	R 3.1 x 10, wooden	7-623-110-02	4 (small)
7-628-253-15	PS 2 x 5		
7-628-253-35	PS 2 x 8	SPRING WASHERS	
7-628-254-03	PS 2.6 x 5	7-623-205-11	2
7-628-254-05	PS 2.6 x 5	7-623-207-22	2.6
7-628-254-12	PS 2.6 x 6		
7-628-254-25	PS 2.6 x 8	MISCELLANEOUS	
7-682-548-04	B 3 x 8	7-623-507-01	lug, 2.6; egg type
7-682-646-01	PS 3 x 5	7-671-112-01	steel ball, 2
7-682-648-01	PS 3 x 8	7-671-112-11	steel ball, 2.5
7-682-659-01	PS 4 x 5	7-684-013-01	nut, 3
7-682-947-01	PSW 3 x 6		
7-682-953-00	PSW 3 x 20		
7-685-144-41	P 3 x 5, self-tapping		
7-685-145-23	P 3 x 6, self-tapping		

Hardware Nomenclature

<p>P - Pan Head Screw </p> <p>PS - Pan Head Screw with Spring Washer </p> <p>K - Flat Countersunk Head Screw </p> <p>B - Binding Head Screw </p> <p>RK - Oval Countersunk Head Screw </p> <p>T - Truss Head Screw </p> <p>R - Round Head Screw </p> <p>F - Flat Fillister Head Screw </p>	<p>SC - Set Screw </p> <p>E - Retaining Ring (E Washer) </p> <p style="margin-left: 40px;">W - Washer</p> <p style="margin-left: 40px;">SW - Spring Washer</p> <p style="margin-left: 40px;">LW - Lock Washer</p> <p style="margin-left: 40px;">N - Nut</p> <p>Example</p> <div style="margin-left: 20px;"> <p style="margin-left: 20px;">P 3x10</p> <p style="margin-left: 40px;">Length in mm (L)</p> <p style="margin-left: 40px;">Diameter in mm (D)</p> <p style="margin-left: 40px;">Type of Head</p> </div>
---	---

9-954-122-01

Sony Corporation

© 1973

— 45 —

77J0605-7
Printed in Japan

MC-Service

SUPPLEMENT

This supplement updates the service manual to include production changes starting with **Serial No. 45,601 and later.**

File this supplement with the service manual.

Subject: Change and Addition of Circuit Board

No. 1
December, 1973

ADDED PARTS

Part No.	Description
A-2095-004-A	complete circuit board, filter
1-582-966-00	printed circuit board, shield
3-533-428-00	bracket, circuit board
3-533-430-00	shield
3-533-431-00	shield C
3-533-432-00	shield D

CHANGED PARTS



Part No.		Description
Former	New	
X-35333-51-0	A-2010-002-A	complete circuit board, amp
3-489-122-00	3-533-429-00	lever, lock

OMITTED PARTS

Part No.	Description
3-533-401-00	shield

SERVICE MANUAL

1. CHANGED PORTIONS OF EXPLODED VIEW



2. ELECTRICAL PARTS LIST

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>
COMPLETE CIRCUIT BOARDS			D503,603	Diode	1S1555
			D504,604	Diode	1S1555
X-35133-52-0	DOLBY		COILS		
A-2010-002-A	Amp		L101,201	1-407-561-00	33 mH, microinductor
A-2095-004-A	Filter		L102,202	1-407-658-00	35 mH, trap
PRINTED CIRCUIT BOARDS			L103,203	1-407-500-00	4.7 mH, microinductor
1-539-812-00	Timing Switch		L104,204	1-407-500-00	4.7 mH, microinductor
1-582-440-00	Jack		L105,205	1-407-561-00	33 mH, microinductor
SEMICONDUCTORS			TRANSFORMERS		
Q101,201	Transistor	2SC631A	T101,201	1-427-299-00	Output
Q102,202	Transistor	2SC631A	T301	{ 1-442-167-00 Power (Canada) { 1-442-185-11 Power (USA) { 1-442-189-11 Power (AEP, AUS) { 1-442-201-11 Power (E)	
Q103,203	Transistor	2SC633A			
Q104,204	Transistor	2SC631A			
Q105,205	Transistor	2SC634A			
Q106,206	Transistor	2SC634A	T302	1-433-132-00	Bias Osc
Q107,207	Transistor	2SC634A	CAPACITORS		
Q108,208	Transistor	2SC633A	All capacitors are μF unless otherwise indicated. (p = μF , elect = electrolytic)		
Q301	Transistor	2SA678	C101,201	1-107-097-11	330p 50V silvered mica
Q302	Transistor	2SC1384	C102,202	1-121-651-11	10 16V elect
Q501,601	Transistor	2SC634A	C103,203	1-121-398-11	10 25V elect
Q502,602	Transistor	2SC634A	C104,204	1-107-137-11	180p 50V silvered mica
Q503,603	Transistor	2SC632A	C105,205	1-107-131-11	100p 50V silvered mica
Q504,604	Transistor	2SC634A	C106,206	1-107-141-11	270p 50V silvered mica
Q505,605	Transistor	2SC634A	C107,207	1-121-420-11	220 10V elect
Q506,606	Transistor	2SC634A	C108,208	1-105-680-12	0.039 50V mylar
Q507,607	Transistor	2SC634A	C109,209	1-105-513-12	0.01 50V mylar
D101,201	Diode	VO6C	C110,210	1-121-402-11	33 10V elect
D102,202	Diode	10D-05	C111,211	1-105-821-12	0.001 50V mylar
D103,203	Diode	1T22	C112,212	1-121-398-11	10 25V elect
D301	Diode	SIB01-02	C113,213	1-105-668-12	0.0039 50V mylar
D302	Diode	SIB01-02	C114,214	1-105-665-12	0.0022 50V mylar
D303	Diode	SIB01-02	C115,215	1-105-665-12	0.0022 50V mylar
D304	Diode	SIB01-02	C116,216	1-121-416-11	100 25V elect
D305	Diode	SIB01-02	C117,217	1-131-211-11	0.22 35V solid tantalum
D306	Diode	SIB01-02	C118,218	1-131-211-11	0.22 35V solid tantalum
D307	Diode	MZ08	C119,219	1-107-141-11	270p 50V silvered mica
D501,601	Diode	1T22A	C120,220	1-121-409-11	47 16V elect
D502,602	Diode	1T22A			

The word DOLBY is a trademark of Dolby Laboratories, Inc.

Ref. No.	Part No.	Description
R133,233	1-242-689-11	4.7k
R134,234	1-242-677-11	1.5k
R135,235	1-242-713-11	47k
R136,236	1-242-725-11	150k
R137,237	1-242-705-11	22k
R138	1-242-725-11	150k
R238	1-244-725-11	150k
R139,239	1-222-783-00	47k, adjustable
R140	1-244-697-11	10k
R240	1-242-697-11	10k
R141,241	1-244-697-11	10k
R142,242	1-244-697-11	10k
R143,243	1-242-715-11	56k
R144	1-244-733-11	330k
R244	1-242-733-11	330k
R145,245	1-242-673-11	1k
R146,246	1-242-691-11	5.6k
R147,247	1-242-675-11	1.2k
R148,248	1-242-713-11	47k
R149	1-242-625-11	10
R249	1-244-625-11	10
R150	1-242-647-11	82
R250	1-244-647-11	82
R151,251	1-244-688-11	4.3k
R152	1-244-699-11	12k
R252	1-242-699-11	12k
R153,253	1-242-709-11	33k
R154,254	1-244-693-11	6.8k
R155,255	1-242-681-11	2.2k
R156,256	1-242-695-11	8.2k
R157,257	1-242-677-11	1.5k
R158,258	1-242-681-11	2.2k
R159,259	1-221-978-00	4.7k, adjustable
R160	1-242-693-11	6.8k
R260	1-244-693-11	6.8k
R301	1-206-081-11	100 1W metal oxide
R302	1-244-897-11	10k ½W
R303	1-242-709-11	33k
R304	1-242-707-11	27k
R305	1-242-683-11	2.7k
R306	1-202-547-31	82 ½W composition
R307	1-202-549-31	100 ½W composition
R308	1-202-557-31	220 ½W composition
R309	1-242-697-11	10k
R310	1-242-721-11	100k
R311	1-242-653-11	150
R312	1-206-093-11	1k 1W metal oxide
R313	1-206-091-11	680 1W metal oxide
R314	1-242-601-11	1
R501,601	1-210-858-11	200k ±2%

Ref. No.	Part No.	Description
R502,602	1-210-854-11	27k ±2%
R503,603	1-242-729-09	220k, low noise
R504,604	1-242-719-09	82k, low noise
R505,605	1-242-699-09	12k, low noise
R506,606	1-242-737-09	470k, low noise
R507,607	1-242-737-09	470k, low noise
R508,608	1-242-641-11	47
R509,609	1-210-853-11	6.2k ±2%
R510,610	1-242-719-09	82k, low noise
R511,611	1-242-721-09	100k, low noise
R512,612	1-242-701-09	15k, low noise
R513,613	1-242-721-09	100k, low noise
R514,614	1-242-695-09	8.2k, low noise
R515,615	1-242-687-11	3.9k
R516,616	1-210-856-11	68k ±2%
R517,617	1-210-815-11	910 ±2%
R518,618	1-242-689-11	4.7k
R519,619	1-242-677-11	1.5k
R520,620	1-242-721-11	100k
R521,621	1-242-719-11	82k
R522,622	1-242-701-11	15k
R523,623	1-242-723-11	120k
R524,624	1-242-695-11	8.2k
R525,625	1-210-850-11	300 ±2%
R526,626	1-242-705-11	22k
R527,627	1-242-695-11	8.2k
R528,628	1-210-855-11	33k ±2%
R529,629	1-210-855-11	33k ±2%
R530,630	1-210-852-11	5.6k ±2%
R531,631	1-242-601-11	1
R532,632	1-242-701-11	15k
R533,633	1-242-719-11	82k
R534,634	1-242-713-11	47k
R535,635	1-242-727-11	180k
R536,636	1-242-727-11	180k
R537,637	1-242-637-11	33
R538,638	1-242-721-11	100k
R539,639	1-242-653-11	150
SWITCHES		
S1	1-516-268-00	lever slide, LIMITER
S2	1-516-268-00	lever slide, DOLBY NR
S3	1-513-273-00	slide, timing
S4	1-516-268-00	lever slide, TAPE SELECT
S5	1-514-346-00	leaf, muting
S6	1-514-792-00	leaf, motor
S7	1-516-259-11	seesaw, POWER (USA, Canada)
	1-516-259-21	seesaw, POWER (E, AEP, AUS)
S101,201	1-514-976-21	slide, record/playback

Ref. No.	Part No.	Description
JACKS		
J101,201	1-507-251-21	mini, MICROPHONE
J301	1-507-282-31	binaural, HEADPHONE
CNJ101,201	1-507-402-00	4p, LINE IN (USA, Canada)
	1-507-403-00	4p, LINE IN (E, AEP, AUS)
CNJ102,202	1-507-402-00	4p, LINE OUT (USA, Canada)
	1-507-403-00	4p, LINE OUT (E, AEP, AUS)
CNJ301	1-509-549-00	Connector, REC/PB (E, AEP, AUS)
MISCELLANEOUS		
E.H	8-825-506-00	Head, erase; EF135-36
F1	1-532-129-11	Fuse, 0.2A (E)
	1-532-205-11	Fuse, 200 mA (AEP, AUS)
F2	1-532-084-11	Fuse, 100 mA (AEP, AUS)
F3	1-532-084-11	Fuse, 100 mA (AEP, AUS)
F4	1-532-284-11	Fuse, 630 mA (AEP, AUS)

Ref. No.	Part No.	Description
F5	1-532-284-11	Fuse, 630 mA (AEP, AUS)
M	8-834-015-01	Motor, D-015G
PL1	1-518-129-00	Lamp, 4.5V 40 mA
PL2	1-518-129-00	Lamp, 4.5V 40 mA
PL3	1-518-130-71	Lamp, 4.5V 40 mA
	1-231-057-12	Encapsulated Component C-R,
	1-231-057-12	0.033µF + 120Ω (E)
CP301	1-231-057-21	Encapsulated Component C-R,
		0.033µF + 120Ω (USA, Canada)
	1-524-078-21	Meter, level
	1-533-102-11	Holder, fuse (E)
	1-533-118-11	Holder, fuse (AEP, AUS)
	1-534-526-21	Cord, power (USA, Canada)
	1-534-551-00	Cord, power (E)
	1-534-580-13	Cord, power (AUS)
	1-534-587-11	Cord, power (AEP)
	1-509-427-12	Socket, voltage selector (E)
	1-509-482-11	Socket, voltage selector (AEP, AUS)

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>
JACKS		
J101,201	1-507-251-21	mini, MICROPHONE
J301	1-507-282-31	binaural, HEADPHONE
CNJ101,201	1-507-402-00	4p, LINE IN (USA, Canada)
	1-507-403-00	4p, LINE IN (E, AEP, AUS)
CNJ102,202	1-507-402-00	4p, LINE OUT (USA, Canada)
	1-507-403-00	4p, LINE OUT (E, AEP, AUS)
CNJ301	1-509-549-00	Connector, REC/PB (E, AEP, AUS)


MISCELLANEOUS


E.H	8-825-506-00	Head, erase; EF135-36
F1	1-532-129-11	Fuse, 0.2A (E)
	1-532-205-11	Fuse, 200 mA (AEP, AUS)
F2	1-532-084-11	Fuse, 100 mA (AEP, AUS)
F3	1-532-084-11	Fuse, 100 mA (AEP, AUS)
F4	1-532-284-11	Fuse, 630 mA (AEP, AUS)

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>
F5	1-532-284-11	Fuse, 630 mA (AEP, AUS)
M	8-834-015-01	Motor, D-015G
PL1	1-518-129-00	Lamp, 4.5 V 40 mA
PL2	1-518-129-00	Lamp, 4.5 V 40 mA
PL3	1-518-130-71	Lamp, 4.5 V 40 mA
CP301	1-231-057-12	Encapsulated Component C-R, 0.033 μ F + 120 Ω (E)
	1-231-057-12	Encapsulated Component C-R, 0.033 μ F + 120 Ω (USA, Canada)
	1-231-057-21	Encapsulated Component C-R, 0.033 μ F + 120 Ω (USA, Canada)
	1-524-078-21	Meter, level
	1-533-102-11	Holder, fuse (E)
	1-533-118-11	Holder, fuse (AEP, AUS)
	1-534-526-21	Cord, power (USA, Canada)
	1-534-551-00	Cord, power (E)
	1-534-580-13	Cord, power (AUS)
	1-534-587-11	Cord, power (AEP)
	1-509-427-12	Socket, voltage selector (E)
	1-509-482-11	Socket, voltage selector (AEP, AUS)


3. MOUNTING DIAGRAM

- Conductor Side -





FILTER CIRCUIT BOARD





Note:

- All resistors and capacitors are in Ω and μF unless otherwise specified.
- Letter in () suffixed to variable resistor value indicates characteristics.
- --- : chassis ground
- Components for R-CH have the same values as for L-CH.
- Switch mode:


Ref. No.	Switch	Mode
S101, 201	record/playback	playback
S1	LIMITER	ON
S2	DOLBY NR	ON
S3	timing	STOP
S4	TAPE SELECT	CrO ₂
S5	muting	OFF
S6	motor	OFF
S7	POWER	ON

- (NI) : Low noise resistor
- Voltage values shown are measured with a voltmeter (20k Ω /V). Variations may be noted due to normal production tolerances.
- no mark : stop mode
- () : record mode
- AC voltage values across heads are measured with a VTVM in record mode.
- When replacing resistors and capacitors needing $\pm 2\%$ tolerance, use only those with red line (or dot) or G mark, as DOLBY system requires precise circuit operation.



- Q101, 201
- 102, 202 2SC631A
- 104, 204
- 503, 603 2SC632A
- 103, 203 2SC633A
- 108, 208
- 105, 205
- 107, 207
- 501, 601 2SC634A
- 502, 602
- 504, 604
- 507, 607


- D103, 203 1T22
- D501, 601 1T22A
- 502, 602
- D503, 603 1S1555
- 504, 604





Q205	Q206	Q207	Q208	Q108	Q103	Q104	Q106	Q105	Q302
Q204	Q203	Q202	Q201	Q101	Q107	Q102		Q301	
	D201	D202		D103	D101	D102		D304	D306
				D203				D303	D302
								D301	D305
R239	R215	R221	R212	R121	R259	R139	R159	R115	C244
									C243
									C144
									C143

4. SCHEMATIC DIAGRAM


- Amp Circuit -
AMP CIRCUIT BOARD



Red Line Circuit: AEP, E, AUS



- Note:**
- All resistors and capacitors are in Ω and μF unless otherwise specified.
 - Letter in () suffixed to variable resistor value indicates characteristics.
 - : chassis ground
 - Components for R-CH have the same values as for L-CH.
 - (N): Low noise resistor
 - Voltage values shown are measured with a voltmeter (20k Ω /V). Variations may be noted due to normal production tolerances.
 - no mark: stop mode
 - (): record mode
 - AC voltage values across heads are measured with a VTVM in record mode.
 - When replacing resistors and capacitors needing $\pm 2\%$ tolerance, use only those with red line (for dot) or G mark, as DOLBY system requires precise circuit operation.




Switch mode:

Ref. No.	Switch	Mode
S101, 201	record/playback	playback
S1	LIMITER	ON
S2	DOLBY NR	ON
S3	timing	STOP
S4	TAPE SELECT	CrO ₂
S5	muting	OFF
S6	motor	OFF
S7	POWER	ON


5. SCHEMATIC DIAGRAM

- DOLBY Circuit -



L-CH
Same as R-CH
Reference numbers
start from 601.



- Note:**
- All resistors and capacitors are rated in Ω and μF unless otherwise indicated.
 - The letter (N) which is suffixed to rating values shows a low noise resistor.
 - Voltage values shown are measured with a voltmeter (20k Ω /V) in playback mode. Variations may be noted because of normal production tolerances.
 - Components for R-CH are the same value as for L-CH.
 - When replacing resistors and capacitors needing $\pm 2\%$ tolerance, use only those with red line (or dot) or G mark, as DOLBY system requires precise circuit operation.



6. CHANGED PORTIONS OF ELECTRICAL ADJUSTMENT

Page	Former	New
20	4. Playback Equalizer Adjustment Adjust R114 (L-CH) R214 (R-CH)	R112 (L-CH) R212 (R-CH) Note: After the playback equalizer adjustment, setting the TAPE SELECT switch to CrO ₂ , play back the SONY test tape P-4-A81 and ensure that VTVM reading drops 4.5 dB ± 1 dB.
21	7. Record Bias Adjustment Input signal (1) 1 kHz, -90 dB (25 μV)	750 Hz, -90 dB (25 μV)
22	8. Record Level Adjustment Adjust R139 (L-CH) R239 (R-CH)	R140 (L-CH) R240 (R-CH)

7. CHANGED PLAYBACK LEVEL DIAGRAM



6. CHANGED PORTIONS OF ELECTRICAL ADJUSTMENT

Page	Former	New
20	4. Playback Equalizer Adjustment Adjust R114 (L-CH) R214 (R-CH)	R112 (L-CH) R212 (R-CH) Note: After the playback equalizer adjustment, setting the TAPE SELECT switch to CrO ₂ , play back the SONY test tape P-4-A81 and ensure that VTVM reading drops 4.5 dB \pm 1 dB.
21	7. Record Bias Adjustment Input signal (1) 1 kHz, -90 dB (25 μ V)	750 Hz, -90 dB (25 μ V)
22	8. Record Level Adjustment Adjust R139 (L-CH) R239 (R-CH)	R140 (L-CH) R240 (R-CH)

7. CHANGED PLAYBACK LEVEL DIAGRAM

