

# UNITED MOTORS SERVICE

DIVISION OF GENERAL MOTORS CORPORATION

Buick Models 980744 and 980745


## PUSH BUTTON SET-UP

Release holding spring in bottom of button, pull button off. Loosen re-set screw and push in until it bottoms. Tune in desired station while holding in re-set screw. Release and tighten screw. Replace button.

## ALIGNMENT PROCEDURE

Volume Control Maximum.

Signal Generator output minimum for satisfactory output indication.



MODEL 980744


Series Condenser or Dummy Antenna	Connect To	Tune Receiver To	Signal Generator Frequency	Adjust Screws In Order
0.1 Mfd.	6SA7 Pin #8	No Broadcast Sig.	262 KC	A B C D
*.000060 Mfd.	Antenna Connector	Extreme Hi. Freq.	1615 KC	E F G
***.000060 Mfd.	Antenna Connector	End of Dial Signal Generator	1430 KC	**J K

\*Before making this adjustment turn core screws J, K, H by means of a bakelite screwdriver, so that the rear end of the cores are  $1\frac{1}{8}$ " from the rear of the coil form. The purpose of this adjustment is to set the cores at the correct starting point with respect to the windings.


\*\*Cores J and K are adjusted by means of a bakelite screwdriver through the rear end of the coils. There must not be any metal in part of screwdriver inserted in the coil.

\*\*\*Should it be necessary to calibrate the pointer after this adjustment, tune signal generator to 1300 KC and the receiver to the signal. Loosen dial cord pulley set screws and adjust pointer to 1300 KC. Tighten set screws.


Adjust trimmer G to match car antenna (at approx. 1400 KC) when radio is installed.




1st I. F. TRANS.




2nd I. F. TRANS.



AUDIO PACK - DRIVER AND OUTPUT TRANS.



TUNER COILS



**United Motors**  
**Buick Models**  
**980744, 980745**

