



GENERAL ELECTRIC

MODELS 200, 203 & 205

1. Turn dial scale pointer as far counterclockwise as possible. The pointer should coincide with the first marking at the left of the scale. If it doesn't, remove chassis and slip pointer on shaft until the pointer is under reference mark when chassis is bolted in place.

2. For i-f and r-f alignments, the output meter is connected across the loudspeaker voice coil terminals.

3. Keep radio volume control at maximum and attenuate test oscillator signal output so that the output meter reading never exceeds $1\frac{1}{4}$ volts.

4. The chassis must be removed from the cabinet during I-F alignment. For R-F alignment bolt the chassis in the cabinet securely.

5. Connect the capacitor as listed in column 2, between the output "High Side" of test oscillator and the point of input specified.

ALIGNMENT CHART

Step	Connect Test Oscillator to	Test Osc. Setting	Pointer Setting on Radio	Adjustment for Maximum Output
1	12SK7 grid in series with 0.05 mf cap.	455 kc	1500 kc	2nd I-F Trans. Trimmers
2	12SA7 grid in series with 0.05 mf cap.	455 kc	1500 kc	1st and 2nd I-F Trans. Trimmers
3	Ant. Post in series with 50 mmf	1500 kc	1500 kc	C3 (Osc.)
4	Ant. Post in series with 50 mmf	1500 kc	1500 kc	C2 (R-F)