


MODEL TB-503 SPIEGEL



ALIGNMENT AND SERVICE DATA (For Professional Service Men Only)

Remove chassis from cabinet for alignment.

A signal generator is required having the following frequencies: 456KC, 1400KC, 1720KC.

First Step: Connect the generator lead through a .1 mfd. condenser to the terminal lug next to the Antenna trimmer on top of the tuning condenser. The ground lead from the generator may be connected to any convenient spot on the metal chassis. Adjust generator to 456KC and adjust IF trimmer screws until a maximum reading is noted on the output meter which has been connected across the speaker. The tuning condenser should be turned out to complete minimum capacity when aligning the IF. With generator lead still connected to antenna trimmer terminal, adjust generator frequency to 1720KC, and with tuning condenser still at minimum, adjust oscillator trimmer till the 1720KC signal is tuned in. Next, remove generator leads from set and connect both to a transmitting loop. This loop can be made with 2 turns of wire about 6 inches in diameter and placed about one foot away from the loop antenna of the receiver. Adjust generator frequency to 1400KC. Turn tuning condenser until the signal is tuned in and adjust antenna trimmer until a maximum reading is noted. No further adjustment should be necessary, unless the set has been damaged, as the coils and condenser in this receiver have been specially handled at the factory so as to insure proper alignment at the lower frequency end of the dial.

TUBE AND TRIMMER LOCATION

