



MOTOROLA INC.

MODELS	CHASSIS
C12B	HS-815
C12P	HS-815
C12W	HS-815



DIAL STRINGING DETAIL




ALIGNMENT POINTS AND PARTS LOCATION

TO REMOVE CHASSIS FROM CABINET

1. Remove cabinet back - 5 screws hold it in place.
2. From rear, unsolder 2 cabinet back loop leads, then remove the 2 screws that mount the pointer slide bracket (on chassis) to the cabinet.
3. Unsolder 2 chassis leads connected to clock and 2 speaker leads.
4. Remove volume and tuning knobs.
5. From front, remove palnut located under volume knob.
6. Remove chassis from cabinet.

TO REMOVE CLOCK FROM CABINET

1. Remove cabinet back - 5 screws hold it in place.
2. Unsolder all leads connected to clock.
3. Remove 2 appliance outlet bracket mounting screws and remove bracket.
4. Insert a screwdriver between the cabinet and left edge of the clock crystal (near 9 o'clock on clock face) to release catch, then pry out crystal.
5. Set the Hour, Minute and Alarm Set hands to 12 o'clock (use the Time Set-Auto Set knob for this purpose). Remove clock hands by pulling them straight off from their mounting shaft in this order: Second, Minute, Hour and Alarm Set.
6. From rear, remove 4 clock mounting lock screws and remove clock from cabinet.



NOTES:
 CAPACITORS—Unless otherwise specified, decimal values in MF, all others in MMF.
 VOLTAGES—Measured from point indicated to B— with a VTVM $\pm 10\%$, no signal input, with 120V 60 cycle AC In.
 TUNING RANGE—535KC to 1620KC IF—455KC
 B—
 PLATED-CHASSIS BOARD WIRING LEGEND
 ■ B+ □ -AVC ▨ FILAMENT