


Models 40-215, 40-217, code 121

RECEIVER CIRCUIT ADJUSTMENTS — Models 40-215, 40-217

Operation	SIGNAL GENERATOR		RECEIVER			SPECIAL INSTRUCTIONS
	Output Connections to Receiver	Dial Setting	Dial Setting	Control Setting	Adjust Compensators	
1	781 F. Grid	470 K. C.	580 K. C.	Vol. Max. Range Switch "Brdest"	41A, 41B	Turn Out 38B Full
2	6J8G Det. Osc. Grid	470 K. C.	580 K. C.	Vol. Max. Range Switch "Brdest"	38A, 38C, 38B	Note A
3	Use Loop on Generator	18.0 M. C.	18.0 M. C.	Vol. Max. Range Switch "Short Wave"	29B, 2A	Note C, Note D 2A on SW Loop
4	Use Loop on Generator	1500 K. C.	1500 K. C.	Vol. Max. Range Switch "Brdest"	29, 8A	Note A
5	Use Loop on Generator	580 K. C.	580 K. C.	Vol. Max. Range Switch "Brdest"	30	Rollgang
6	Use Loop on Generator	1500 K. C.	1500 K. C.	Vol. Max. Range Switch "Brdest"	29	
7	Use Loop on Generator	3.5 M. C.	3.5 M. C.	Vol. Max. Range Switch "Police"	29A, 8	Note B



SCHEMATIC DIAGRAM OF
WIRELESS REMOTE CONTROL UNIT

**FIG. 3. SCHEMATIC DIAGRAM,
WIRELESS REMOTE CONTROL.**





FIG. 4. WIRING OF STEPPER UNIT, WIRELESS REMOTE CONTROL.



NOTE A — DIAL CALIBRATION: In order to adjust the receiver correctly the dial must be aligned to track properly with the tuning condenser. To adjust the dial, proceed as follows: With the tuning condenser closed (maximum capacity), set the dial pointer on the extreme left index line at the low frequency end of the broadcast scale. The arrangement of the drive cable and dial pointer is shown

NOTE C — If two peaks (signals) are observed on the aligning meter when adjusting the oscillator padder No. 29B, tune the padder to the second peak from the maximum capacity position (screw all the way in).

NOTE D—If two peaks (signals) are observed on the aligning meter when adjusting the loop padder 2A, tune the padder to the first peak signal from the maximum capacity position (screw all the way in). When adjusting the padders to this first peak roll the tuning condenser (rock) slightly back and forth to obtain the maximum readings on the aligning meter.

