

INPUT (AUX) JACK

For direct recording without use of microphone, use this jack for connection with another audio instrument as explained below :

1) Direct recording from radio

Connect output terminal of radio to input (AUX) jack of this set.

2) Direct recording from record player

* If it is a record player equipped with built-in amplifier, the connection will be made between output terminal of the player's amplifier and input (AUX) jack of this set.

* If your record player's pick up is of crystal type, clip Patch Cord, an accessory item, to the outer husk of a shielded wire from the pickup by means of its black clip and to the internal wire of the same shielded wire by means of its red clip, and then connect it to input (AUX) jack of this set.

* If your record player has a magnetic type pickup, its output is too low that direct hookup can not produce good recording. In this case, use a pre-amplifier through which audio output will be taken for recording with this set.

JACK D'ENTREE (AUX)

Lors d'un enregistrement direct sans microphones, employer ce jack pour la connexion d'autre appareil entre cet appareil.

1) Enregistrement direct de radio

Relier le jack de sortie du radio au jack AUX de votre magnétophone.

2) Enregistrement direct de tourne-disque

* Pour l'un tourne-disque équipé un amplificateur, relier la sortie d'amplificateur au jack AUX de votre magnétophone.

* Si le pick-up est un type crystal, employer le câble d'écran (pourvu dans accessoires). Relier la gousse métallique à la griffe noire et le fil métallique à la griffe rouge au moyen du câble d'écran.

* Si le pick-up est un type magnétique, il est très faible de brancher sa sortie directement pour votre magnétophone. Dans ce cas, utiliser un pré-amplificateur pour enregistrer la sortie de pick-up.