



ALIGNMENT PROCEDURE

STEP	CONNECTION OF SIGNAL GENERATOR	SIGNAL GENERATOR FREQUENCY	RECEIVER GANG SETTING	ADJUSTMENT
1	Through a .1 mf capacitor to stator, Antenna section of gang tuning capacitor	455 KC	Gang fully open	"F", *"E", "D" and *"C" for maximum output
2	Same as "STEP 1"	1620 KC	Gang fully open	"B" for maximum output
3	Radiated Signal. Loop of several turns of wire, or place generator lead close to receiver loop for adequate signal pickup.	1400 KC	Tune in on generator signal	"A" for maximum output

*Adjustments "C" and "E" made from underside of chassis.

Admiral

CHASSIS 5C4
MODELS 263 • 264 • 265 • 268