GENERAL ELECTRIC

PHONO
MODEL
RP-1112A



TO REPLACE TUBES

1. Open cabinet lid.
2. Remove the screws holding vent panel board and interlock.
3. Remove vent panel.board. (Interlock is automatically disconnected.)

TO REMOVE AMPLIFIER CHASSIS

1. Follow steps 1 thru 3 as above.
2. Remove volume and tone knobs.
3. Loosen screws on interlock bracket, slide interlock out of mounting slot. (Mark location of bracket on cabinet before removing so that bracket can be "keyed" to correct location when replacing.)
4. Remove three screws on cabinet brace above speaker.
5. Lift out grille (with all electronic components) and place down in front of cabinet carefully.
6. Remove amplifier chassis by removing the three screws holding chassis to grille.
   When replacing knobs, brace back of each control (volume and tone) with one finger as the knob is pressed on.



COMPONENT LOCATIONS - BOTTOM VIEW - RP-1112A