



DIAL STRINGING

BEFORE STARTING THE STRINGING OPERATION, THE POINTER SHOULD BE MOVED TO EXTREME RIGHT WITH TUNING GANG IN A CLOSED POSITION. THE NOTCHES IN WINDLASSES MUST BE IN APPROXIMATE POSITIONS AS INDICATED BY "A" AND "D."

COMPONENT WIRING DIAGRAM



GENERAL ELECTRIC

MODELS
T115A
T116A