

MOTOROLA

MODELS	CHASSIS
3F13B	HS-668
3F13W	HS-668

NOTES:
CAPACITORS - Decimal values in MF, all others in MMF unless otherwise specified.
VOLTAGES - Measured from point indicated to B- with a VTVM, ±10%. Line Voltage maintained at 120V AC.

⏚ = B- ⏚ = Chassis

TO REMOVE CHASSIS & RECORD CHANGER FROM CABINET

1. Remove volume and tone knobs.
2. From inside cabinet, remove 3 baffle mounting screws, then remove baffle.
3. Unclip speaker leads.
4. Remove 4 motorboard mounting screws.
5. Grasp record changer at base of tone arm and record support arm, then lift straight out of cabinet (to facilitate servicing, both record changer and chassis are mounted on the motorboard).
6. To remove chassis, remove 4 chassis mounting nuts; unsolder leads connected to chassis if necessary.