



Precautinary Lead Dress.—

1. Dress shielded lead from diode filter to tone control switch away from grid of the 6SQ7 a-f amplifier.
2. Dress shielded lead from grid of 6SQ7 a-f amplifier away from diode output system.
3. Power leads to rear of volume control should be dressed towards side apron.
4. Plate leads on output tubes should be dressed towards chassis.