



| | | | | | |
|---|---|--|--|--|---|
| <p>"M" & "S" BAND OSC. COIL SA-202</p> <p>LUG VIEW</p> | <p>"S" BAND ANT. COIL SA-203</p> <p>LUG VIEW</p> | <p>BAND SELECTOR SWITCH FM-736</p> <p>REAR VIEW</p> | <p>ALIGNING TRIMMERS LOCATION</p> <p>1500 K.C. ANT. SHUNT TRIMMER I.F. ADJUSTING TRIMMERS ANT. POST</p> | <p>I.F. FREQUENCY = 455 K.C.</p> <p>"M" BAND: 600 K.C. OR 500 METERS 1500 K.C. OR 200 METERS</p> <p>"S" BAND: 18 M.C. OR 16.67 METERS</p> <p>IMPORTANT: RECEIVER MUST BE ALIGNED WITH LOOP CORRECTLY ASSEMBLED ON CHASSIS</p> | <p>NOTE: BAND SELECTOR SWITCH SHOWN ON "S" BAND POSITION, TO THE EXTREME CLOCKWISE POSITION.</p> <p>ANDREA RADIO CORP. WOODSIDE, N. Y.</p> <p>WIRING DIAGRAM "UG 55" REC.</p> <p>MODEL: "25G5"</p> <p>DR: J.R. DATE: 2-2-40 APP: [Signature]</p> <p>PART NO:</p> |
|---|---|--|--|--|---|