

Service Manual

 **PIONEER®**
The future of sound and vision.

ORDER NO.
ARP1678

SPEAKER SYSTEM

CS-G9000 XC

CS-G7000 XC

CS-G5000 XC

PARTS LIST OF PACKING

Mark	Part No.	Description
	169397	Packing case (For CS-G9000)
	170243	Packing case (For CS-G7000)
	169699	Packing case (For CS-G5000)
	149744	Corner pad assembly
	143404	Poly bag
	101717	Speaker wire (For CS-G9000, CS-G7000, CS-G5000)
	169159	Instructions manual (For CS-G9000)
	169179	Instructions manual (For CS-G7000)
	169199	Instructions manual (For CS-G5000)

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan
PIONEER ELECTRONICS SERVICE INC. P.O. Box 1760, Long Beach, California 90801 U.S.A.
PIONEER ELECTRONICS OF CANADA, INC. 505 Cochrane Drive, Markham, Ontario L3R 8E3 Canada
PIONEER ELECTRONIC [EUROPE] N.V. Keetberglaan 1, 2740 Beveren, Belgium
PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL: [03] 580-9911
© **PIONEER ELECTRONIC CORPORATION 1989**

MA FEB. 1989 Printed in Japan

CS-G9000, CS-G7000, CS-G5000

PARTS LIST OF EXPLODED

NOTES:

- Parts without part number cannot be supplied.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "⊙" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.


Parts List

Mark	Part No.	Description	Mark	Part No.	Description
	160538	Grille (For CS-G9000, CS-G7000)		158401	Tweeter (For CS-G9000)
	162509	Grille (For CS-G5000)		169357	Tweeter (For CS-G7000, CS-G5000)
	119317	Input cup		101584	Cross recessed binding head tapping screw (5 x 25)
⊙	159197	Network assembly (For CS-G9000)		100254	Cross recessed binding head tapping screw (4 x 25)
⊙	159206	Network assembly (For CS-G7000, CS-G5000)			
	157611	F.T.C. sticker			
	158392	Woofer (For CS-G9000)			
	158436	Woofer (For CS-G7000, CS-G5000)			
	158387	Mid-range (For CS-G9000)			
	169342	Mid-range (For CS-G7000, CS-G5000)			

NETWORK AND PARTS LIST

Circuit Diagram

⊙ Network Assembly



Parts List

Mark	Symbol & Description	Part No.
	L1 Choke coil (0.47mH)	
	C1 Capacitor (3.9μF)	
	C2 Capacitor (2.7μF)	
	S1 Poly switch	

P. SW (POLYSWITCH):

P. SW has extreme positive resistance-temperature characteristics. (Less than 0.3Ω at the normal temperature). If an abnormal current flows to P. SW due to an excessive input or unusual signal, P. SW heats up and the resistance extremely increases. With this function, the tweeter is protected from excessive input or unusual signal. The resistance increase even by soldering iron during repairing so that cool it enough before using.