

SERVICE MANUAL **& PARTS LIST** (with price)

POCKET TELEVISION


TV-600B


DECEMBER 1994

	Page
Specifications.....	1
Block Diagram	2
Circuit Description.....	3
Adjustment	
Linear PCB.....	5
A/D PCB	9
Troubleshooting	10
Printed Circuit Boards	11
Wiring Diagram	15
Exploded View / Disassembly.....	16
Electrical Parts List	17
Mechanical Parts List.....	23
IC and Transistor Lead Identification	24
Schematic Diagrams and Waveforms	26


CASIO®

SCHMATIC DIAGRAMS AND WAVEFORMS







WAVEFORMS




① Q200 Collector




② IC200 Pin 19




③ IC200 Pin 18




④ IC300 Pin 23




⑤ IC300 Pins 10, 11, 12




⑥ IC300 Pin 5




⑦ IC300 Pin 4




⑧ IC300 Pin 1




⑨ Q111 Collector



⑩ Q111 Base



⑪ IC700 Pin 16



⑫ IC700 Pin 14