

## CONTENTS

	<i>Page No.</i>
Introduction . . . . .	4
Table of Ranges . . . . .	5
Scope of Instrument . . . . .	6
Limits of Accuracy . . . . .	6
Design and Construction of the Avometer . . . . .	7
Controls . . . . .	8
Overload Protection . . . . .	8
The Movement . . . . .	9
Scaling . . . . .	9
The $\div 2$ Button . . . . .	10
Replacement of Internal Batteries and Cell . . . . .	11
Operation of Instrument . . . . .	12
Current Measurement . . . . .	12
Voltage Measurement . . . . .	13
Resistance Measurement . . . . .	14
The 1,000 Ohms and 10,000 Ohms Ranges . . . . .	14
The 100,000 Ohms Range . . . . .	15
Battery Condition . . . . .	16
The 1 Megohm Range . . . . .	16
Accessories . . . . .	17
Multipliers . . . . .	17
Shunts . . . . .	17
Transformers . . . . .	18
The Model 40 Power Factor and Wattage Unit . . . . .	19
Resistance Range Extension Unit . . . . .	26
Circuit Diagram of the Model 40 Mk. II Avometer . . . . .	29

### Copyright

Information or diagrams in whole or in part must not be copied or reproduced without the prior permission in writing of AVO LTD.