


SANWA 2012


Trasonic Intermarket Hamburg

1. TUNING
2. BAND SELECTOR
3. VOLUME CONTROL (R)
4. TONE SELECTOR
5. VOLUME CONTROL (L)
6. FUNCTION SWITCH
7. LED DISPLAY
8. DIMMER CONTROL
9. SNOOZE BUTTON
10. TIME SETTING BUTTON
11. ALARM SETTING BUTTON
12. SLEEP BUTTON
13. SLOW BUTTON
14. FAST BUTTON
15. STEREO LITE
16. DIAL SCALE
17. HEADPHONE JACK
18. AC CORD.
19. EXT. ANT. WIRE
20. SENSOR ALARM OFF



SANWA 2012

Trasonic Intermarket Hamburg




BAND COVERAGE: MW 515-1625 KHz 24 HOURS
 FM 87.5-104.5 MHz

SANWA 2012






Trasonic Intermarket Hamburg

THIS CIRCUIT DIAGRAM IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.



SANWA 2012

Trasonic Intermarket Hamburg



SANWA 2012

Transonic Intermarket Hamburg

SANWA 2012

LEVEL
TOP
VIEW

01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100

