




Alimentation



Oscillogrammes




21ATP4 ou 17AV P4
AW 53/80 ou AW 43/80



DY 86




EY 81




ECC 84




ECF 80
6U8



EF 80




EL 83




EABC 80
6AK8




ECL 82
6CN8




EB 91
6AL5



ECC 82
12AU7



EBF 80



EL 36