



Unless otherwise specified: Capacitors in decimils are UF  
All others are PF

Ⓢ Denotes precision film resistors

Ⓢ Denotes components selected for optimum circuit operation

All tube sockets shown in side position  
All rotary switches are viewed from the front and are shown in the positions indicated at left

AUG 1967 - UNITS STARTING WITH SERIAL NO 15001 99-1013

**MARANTZ**  
Model 7T  
STEREO PREAMPLIFIER

