



STEREO TUNER TX 410L

- RESISTORS:** Indicated in Ω, MW, +5% tolerance unless otherwise noted k: kΩ, M: MΩ, (F): 1%, (G): ±2%, (K): 10% tolerance
 - CAPACITORS:** Indicated in capacity (μF)/Voltage (V) unless otherwise noted p: pF. Indication without voltage is 50V except electrolytic capacitor.
 - VOLTAGE:** DC voltage (V) or no input signal
 - OTHERS:** ⊕: Adjusting point. : Part of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- SWITCHES:**
 ON — STAND BY
 S1: POWER SELECTOR MW — LW
 S2: AM SELECTOR FM — AM
 S3: FUNCTION FM — AM
 S4: FM MUTING ON — OFF
 The underlined indicates the switch position.

This is the basic schematic diagram, but the actual circuit may vary due to improvements in design.

