

## MODEL 3716

L-2 CHASSIS (cont)			SPEAKERS (cont)		
Item No.	Part No.	Description	Item No.	Part No.	Description
60	B-42951	500 ohm Treble Input Vol. Cont.		651DT4-M	"M" Speaker Spec. 1D708
61	B-42953-A	100,000 ohm Bass Vol. Cont. P.P.P. Grids		43174	Cone Assy.
61	B-42953-A	100,000 ohm Mezzo Vol. Cont. P.P. Grids		43178	Field Coil
62	B-42952	500,000 ohm Mike Input Vol. Cont.		43181	Terminal Cover
63	W-30321-A	1 mf. 160 v. Cond.		252DT4-J	Tweeter Speaker
64	W-30323	.01 mf. 200 v. Cond.		MG11-43029	Cable (Tweeter Field) Assy.
65	G5-43000	Plug "AFIP" (male)		MG12-43029	Cable (Tweeter Voice) Assy.
66	W-30805	.01 mf. 400 v. Cond.		MG13-43029	Cable (18"Speaker Field) Assy.
67	35928	60,000 ohm $\frac{1}{2}$ w. Res.		MG14-43029	Cable (18"Speaker Voice) Assy.
68	G6-43000	"SF" 4 Prong Socket		MG15-43029	Cable (12"Speaker Voice) Assy.
69	26578	5 meg. $\frac{1}{2}$ w. Res.			
L-3 CHASSIS			MISCELLANEOUS		
1				C-43030-A	Cont. Panel Body
2	W-42737	45 mf. 400 v. Cond.		T-134	Screw Panel Body Mtg.
3	W-42736	40 mf. 400 v. Cond.		B-43031	Escutcheon Cont. Panel
4	W-22688	.1 mf. 400 v. Cond.		D-30	Screw CP Escutcheon Mtg.
5	G45-25669	Filter Choke		B-42936	LH Dial Glass (small holes)
6	G3-33339	Fuse Panel Assy.		B-43032	LH Dial Glass (large holes)
7	W-32757	Fuse 12 Amp. Fuse Cover		B-42937	RH Dial Glass (small holes)
8	G154-36400	524 Type Socket		B-43033	RH Dial Glass (large holes)
9	G4-37900	Power Trans. 60 cy. 110 v.		W-43040	Pad for Cont. Panel Glass
10	G44-25669	Power Trans. 60 cy. 110 v.		B-43034	Mask Support-Cont. Panel
11	G1-43001	Plug 4 Prong (female)		B-43035	Gasket Cont. Panel
12	G2-43001	Plug 5 Prong (female)		B-43036	Mask LH Cont. Panel
	42905	Power Cord & Plug		B-43037	Mask RH Cont. Panel
L-4 CHASSIS				B-43038	Shield Plate Cont. Panel
1	W-37922	Dial Light Bulb		W-43039	Light Bracket Cont. Panel
2	W-42737	35 mf. 400 v. Cond.		W-43047	Microphone Clip
3	W-23615	.05 mf. 400 v. Cond.		W-43069	Microphone
4	42903	Power Cord & Plug		W-43232	Knob-Cont. Panel
5	G154-36400	524 Type Socket		43067-A	Cable Cont.-4 ft. 10 in.
6	G97-28807	SF Type Socket		43068-A	Cable Cont.-4 ft. 6 in.
7	G46-25669	Power Trans. 60 Cy. 110 v.		43076-A	Cable Cont.-7 ft. 2 in.
SPEAKERS				43077-A	Cable Cont.-7 ft.
	953GT4-J	18" Speaker		43078-A	Cable Cont.-6 ft. 10 in.
	650DT4-M	"M" Speaker Spec. 1D707		W-43046	Duplex Outlet
	43173	Cone Assy.		W-43045	AC Receptacle Plate
	43177	Field Coil		R-154	Screw Outlet Mtg.
	43180	Terminal Cover		W-23840	Screw Receptacle Plate Mtg.
	43182	Pot Cover			

Crosley supplies a general replacement line of radio parts through its national distributor organization. Do not hesitate to write to the factory for information as to where these parts may be purchased.