


Service
Service
Service

Service Manual


12 V 



15824 C14




51 4822 102 50018
 52 4822 276 10703
 53 4822 276 10702
 54 4822 413 30793
 56 4822 459 80117
 57 4822 411 60633
 58 4822 502 11139
 59 4822 321 20334
 61 4822 267 40235



15314014

					
D1,2	1N4003	5322 130 30208	C1	2200 μ F-16V	4822 124 20866
D3	RD10E	4822 130 31084	C2	470 μ F-10V	4822 124 40127
LED1	CQY54	4822 130 30914	C3	220 μ F-10V	4822 124 20864
			C105,106	4.7 μ F-16V tantal	5322 124 14064
TR101,102	2SC732BL	4822 130 41286	C107,108	0.022 μ F	4822 121 40513
			C109,110	1 μ F-16V tantal	5322 124 14021
IC101÷103	TA75902P	4822 209 80473	C111,112	0.0068 μ F	4822 122 31266
IC201÷204	TA7222P	4822 209 80472	C113,114	0.22 μ F-16V tantal	4822 124 10194
			C115,116	0.0022 μ F	4822 122 31263
R101,102	18 Ω - 2,5 W	4822 116 51112	C121,122	0.022 μ F	4822 121 40513
VR101÷105	20 k Ω	4822 105 10354	C125	4.7 μ F-16V tantal	5322 124 14064
VR201	FADER	4822 102 50018	C219÷222	2200 μ F-16V	4822 124 20865
			-Miscellaneous-		
			Fuse	5A	4822 253 20027
			E2	0,2 μ H	4822 157 50935


MISC.	IC101	F1	S2	D1	D2	IC102	LED1	D3	IC103
C	101.102	103...108	109...112	1	223	224	113...116	2	125.117...120
R	101...158...161	105...108	109.110	VR101a.b	111...116	118.117	VR102a.b	119...122	VR103a.b
									123...128
									1
									2
									3
									4
									5
									6
									7
									8
									9
									10
									11
									12
									13
									14
									15
									16
									17
									18
									19
									20
									21
									22
									23
									24
									25
									26
									27
									28
									29
									30
									31
									32
									33
									34
									35
									36
									37
									38
									39
									40
									41
									42
									43
									44
									45
									46
									47
									48
									49
									50
									51
									52
									53
									54
									55
									56
									57
									58
									59
									60
									61
									62
									63
									64
									65
									66
									67
									68
									69
									70
									71
									72
									73
									74
									75
									76
									77
									78
									79
									80
									81
									82
									83
									84
									85
									86
									87
									88
									89
									90
									91
									92
									93
									94
									95
									96
									97
									98
									99
									100




1104a.b	VR105a.b	135...140	144...153.142.141	154...157.201...204	205... 208	209... 212	VR201a.b
---------	----------	-----------	-------------------	---------------------	------------	------------	----------



MISC	LED1	TS102 TS101 IC101-103	SK-B
C	122 114 118 121 117 113	126-129 115 119 123 124 120 116	101 102
C	110 106 109 105	111 107 103 112 106 104 125	
R	VR103-105	125 131 135 141 137 145 154-157 144 123 126 132 140 146-153 139 142 133 136 130 134 143	158-161
R	VR102 VR101	127-129 113 117 115 109 111 119 105-108 120 124 110 112 121 116 118 114 122 138	VR201




SK-A	D3, D1	S2, D2	IC201, IC202				IC203, IC204			
	1-3		209	219	215	205 201	223	213	203 207	217 221
			210	220	216	206 202	224	214	204 208	218 222
	1-4	101-104	209		205	201			203 207	217
			210		206	202			204 208	212



15993E12

MISC	SK-A	D1 IC204,IC202	S2, D2	D3	IC203,IC201	F1
C		224, 212, 218, 214, 216, 210, 202, 204, 222, 208, 220, 206, 1, 221, 207, 205, 219, 203, 201, 209, 217, 215, 211, 213, 2, 223, 3				
R		202, 204, 206	208	209-212, 1	207, 2	201, 4, 203, 205, 3
						101-104



LED1	IC101		IC102		IC103	SK-B	TS102	TS101
	103-106	125	107-112		113-116,119,120	117,118,124,123	126-129,101,102,121,122	
	VR101 105-110 111-113,VR102,VR201		114-120	121-124,VR103,143,125-130	131-134,VR104,158,159,135-137,138-142,VR105,160,161,144-157			

