





4121

R140

RESISTANCE

12	A	A	A	C4	C5	L/S	12/ 13	22/ 23	32/ 33	42/ 43	14	24					
	OC	OM	OL	OC	OC												
	100	365	460	10	10	25	10	10	10	10	5	5					
11	14	18	24	25	28	34	37	38	45/ 48	A							
	330	450	310	310	455	365	450	400	300	OL							
										190							
10	15	16	17	27	P/35												
	200	150	250	80	160												
9	29	35	36	39	19	19	19	C3	C3	C3	C4	C4	P/U				
					OC	OM	OL	OC	OM	OL	OL	OL					
	70	240	130	130	500	60	60	60	60	60	60	60	260				

CAPACITÉ

12	39	C5	C5														
	OM	OL															
	110	70	40														
11	17	27	29														
	260	140	150														
10																	
9																	

NUMÉROTAGE DES CONTACTS: Le premier chiffre indique le numéro de la tube concernante sur le schéma de principe le second chiffre correspond avec le numérotage des contacts sur les schémas. 9 indique le sommet de la tube.