


PYE PE-177 1954

modified from model PZ69



NOTE, ALL SWITCHES SHOWN IN FULLY ANTI-CLOCKWISE POSITION, I.E. WAVECHANGE SWITCH S1 IN 'GRAM' POSITION, AND TONE SWITCH S2 IN 'OFF' POSITION. ALL SWITCHES ARE VIEWED FROM THE FRONT, AND THE DIRECTION OF ROTATION IS CLOCKWISE.

Edited by Daniele Giacomini appunti2@gmail.com

Full documentation available at:

<https://sites.google.com/view/daniele-giacomini/dgpn>


<https://daniele-giacomini.blogspot.com/p/dgpn.html>

<https://archive.org/download/dgs-practical-notes>

Last time edited: 2025-08-07

PYE PE-177 1954

simplified, original schematic diagram



Written by Daniele Giacomini appunti2@gmail.com

Full documentation available at:

<https://sites.google.com/view/daniele-giacomini/dgpn>

<https://daniele-giacomini.blogspot.com/p/dgpn.html>

<https://archive.org/download/dgs-practical-notes>

Last time edited: 2025-08-07

original map of components under the chassis

