

BX 297 U




Fig. 6







Fig 7

BX297U


S:	D										C:	B:
C: 28	16	31, 32	30	34	28, 26, 1, 2, 9	15, 21	33, 18					
R: 14, 14, 19, 6, 17, 16	18	15	13	1	12	11	21					




UY 41
B5




UL 41
B4




UBC 41
B3



UAP 42
B2



UCH 42
B1







S22

BX297U


V

D				C				B				A			
34	28	26	12	9	15	21	33	18	10	20	22	19	23	13	17
1	12	11	21	9	7										





D	C	B	A
34, 28, 26, 1, 2, 9,	7, 15, 21,	18, 10, 20, 22,	19, 23, 13, 17, 10, 12, 11, 35, 6
12,	11,	21,	9,



BEWAKEN! RECHT-EN-RECHT ON-EN-ON OPERATION	SCHAKEL- MASST- SCHAKEL- SCALE	Ontvanger 49150	BX 297U	10-150
		Montageschema	V. Gent	27-1-51
N.V. PHILIPS' GLOEILAMPENFABRIEKEN TE EINDHOVEN - HOLLAND				