


PHILIPS Service

notes

A3X95A




UITLEENBIBLIOTHEEK
PHILIPS NEDERLAND N.V.
Technische Dienst


<u>Mains voltages - Netspanningen</u> <u>Tensiones de red - Tensions de réseau</u> 90 - 110 - 127 - 145 - 165 - 190 - 220 - 245 V <u>Consumptions - Verbruik</u> <u>Consumo - Consommation</u> ± 40 W <u>Dimensions - Afmetingen</u> <u>Dimensiones - Dimensions</u> 452 x 207 x 173 mm <u>Loudspeaker - Luidspreker</u> <u>Altavoz - Haut parleur</u> AD 3690 AM	<u>Controls - Bedieningsorganen</u> <u>Organos de mando - Organes de commande</u> 1. Volume control - Volume regelaar Control de volumen - Contrôle de volume 2. Mono 3. Stereo - Stereo - Estereo - Stereo 4. Radio 5. Tone control - Toonregeling Regulador de tono - Régulateur de tonalité 6. Mains switch - Netschakelaar Interruptor de red - Interrupteur de réseau
--	--

LIST OF PARTS	LIJST VAN ONDERDELEN	LISTA DE PIEZAS	LISTE DES PIÈCES
Cabinet Knob Spring (in knob) Plate (behind knobs) Lens Female plug (ext. speaker) Voltage adaptor Push button Contacts slide (5) Contacts slide (2-4) Contacts spring Contact strip Contact lip	Kast Knop Veer (in knob) Plaat (achter knoppen) Lens Contra plug (luidspr.) Spannings-omschakelaar Druktoets Schuifstrip (5) Schuifstrip (2-4) Contact veer Contact strip Contact mes	Mueble Botón Resorte (en botón) Placa (detrás botones) Lente Clavija hembra (altavoz) Cambiador de tensiones Pulsador Pletina deslizando (5) Pletina deslizando (2-4) Muelle de contacto Pletina de contacto Lámina de contacto	Boîtier Bouton Ressort Plaque (derrière les boutons) Lentille Fiche femelle (haut-parleur) Carrousel de tension Touche poussoir Bande coulissante (5) Bande coulissante (2-4) Ressort de contact Bande de contact Lame de contact
S1) S2) S3) Z1) A3 143 20	S4) S5) S6) R1 A3 154 08 927/G1K	R4) R5) R6) R7) 2P 604 10	R17 R22 B8 305 08B/220K 927/G1K GS/SP

3.	1.	2.	4.	3.6	9.11	7.	5.	1.2.	8.	10.	6.5.	4.	7.
22	15.23	18.16	21.12	13.9	11.9	17.	14.	8.10	7.6	5.4.	1.	12.	20.



R 182 19



R 182 18