



Yacht-Boy 210
(14-1648-8201)

AM-FM DRIVE CORD
length approx. 890 mm
(variable capacitor opened)

When putting on a new drive cord, the notch in the plastic frame may be used to temporarily store one end of the cord.